

**Source:** T1  
**Title:** CR's to TS 34.123-1 v4.2.0 for creation of Rel-5 specification for approval  
**Agenda item:** 5.1.3  
**Document for:** Approval

---

This document contains 3 CRs to TS 34.123-1 v4.2.0 related to the creation of Rel-5 specification. These CRs have been agreed by T1 and are put forward to TSG T for approval.

*These CRs were agreed by T1 conditionally to the approval of T2 CR 23.040-054 in TP-020104.*

| Spec     | CR  | Rev | Phase | Subject                                                                        | Cat | Version Current | Version -New | Doc-2nd-Level | Workitem | Remarks           |
|----------|-----|-----|-------|--------------------------------------------------------------------------------|-----|-----------------|--------------|---------------|----------|-------------------|
| 34.123-1 | 255 |     | Rel-5 | Section 16.1.6 & 16.2.6: Addition of test of short message type 0 (CS/PS) Rel5 | F   | 4.2.0           | 5.0.0        | T1-020408     | TEI      | Rel-5             |
| 34.123-1 | 256 |     | Rel-5 | Creation of 34.123-1 REL-5                                                     | F   | 4.2.0           | 5.0.0        | T1-020404     | TEI      | R99, Rel-4, Rel-5 |
| 34.123-1 | 257 |     | Rel-4 | Inclusion of pointer to maintained specification                               | F   | 4.2.0           | 4.3.0        | T1-020406     | TEI      | R99, Rel-4        |

---

## Foreword

This Technical Specification (TS) has been produced by the 3<sup>rd</sup> Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
  - 1 presented to TSG for information;
  - 2 presented to TSG for approval;
  - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

---

## Introduction

The present document is the first part of a multi-part conformance specification valid for 3GPP Release 1999 and 3GPP Release 4. 3GPP TS 34.123-2 [11] contains a pro-forma for the Implementation Conformance Statement (ICS) and an applicability table, indicating the release from which each test case is applicable. 3GPP TS 34.123-3 [12] contains a detailed and executable description of the test cases written in a standard testing language, TTCN, as defined in ISO/IEC 9646.

For at least a minimum set of services, the prose descriptions of test cases will have a matching detailed test case implemented in TTCN [12].

For Release 1999, the minimum set of services are defined as:

- voice calls;
- emergency calls;
- SMS (both Point-to-point and Cell broadcast);
- Circuit Switched data at up to 64 k bits/second;
- fax;

including the underlying layers to support these services.

Release 4 will also include the areas:

- auto-calling restrictions.

The present document may contain descriptions of tests for additional services, but these tests may not have matching TTCN test cases.

The present document will not contain any tests on the USIM, or the interface between the UE and the USIM. These tests are documented elsewhere.

---

# 1 Scope

The present document specifies the protocol conformance testing for the 3<sup>rd</sup> Generation User Equipment (UE).

This is the first part of a multi-part test specification. The following information can be found in this part:

- the overall test structure;
- the test configurations;
- the conformance requirement and reference to the core specifications;
- the test purposes; and
- a brief description of the test procedure, the specific test requirements and short message exchange table.

The following information relevant to testing can be found in accompanying specifications:

- the default setting of the test parameters [9];
- the applicability of each test case [11].

A detailed description of the expected sequence of messages can be found in the 3<sup>rd</sup> part of this test specification.

The Implementation Conformance Statement (ICS) pro-forma can be found in the 2<sup>nd</sup> part of the present document.

The present document is valid for UE implemented according to 3GPP Release 1999 or 3GPP Release 4.

---

# 2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document in the same Release as the present document.
  - For a Release 1999 UE, references to 3GPP documents are to version 3.x.y, when available.
  - For a Release 4 UE, references to 3GPP documents are to version 4.x.y, when available.

[1] ——— 3GPP TR 21.905: "Vocabulary for 3GPP Specifications".

[2] ——— 3GPP TS 23.003: "Numbering, Addressing and Identification".

[3] ——— 3GPP TS 23.122: "Non-Access Stratum functions related to Mobile Station (MS) in idle mode".

[4] ——— 3GPP TS 24.008: "Mobile Radio Interface Layer 3 specification; Core Network Protocols; Stage 3".

[5] ——— 3GPP TS 25.214: "Physical layer procedures (FDD)".

[6] ——— 3GPP TS 25.321: "MAC protocol specification".

[7] ——— 3GPP TS 25.322: "RLC protocol specification".

- [8] ——— 3GPP TS 25.331: "RRC Protocol Specification".
- [1] to [8] ——— (void)
- [9] ——— 3GPP TS 34.108: "Common Test Environments for User Equipment (UE) Conformance Testing".
- [10] ——— (void) 3GPP TS 34.109: "Terminal logical test interface; Special conformance testing functions".
- [11] ——— 3GPP TS 34.123-2: "User Equipment (UE) conformance specification; Part 2: Implementation Conformance Statement (ICS) proforma specification".
- [12] ——— 3GPP TS 34.123-3: "User Equipment (UE) conformance specification; Part 3: Abstract Test Suites (ATS)".
- [13] to [39] ——— (void)
- [13] ——— 3GPP TS 51.010-1: "Mobile Station (MS) conformance specification; Part 1: Conformance specification".
- [14] ——— ISO/IEC 9646 (all parts): "Information technology – Open Systems Interconnection – Conformance testing methodology and framework".
- [15] ——— 3GPP TS 25.304: "UE Procedures in Idle Mode and Procedures for Cell Reselection in Connected Mode".
- [16] ——— 3GPP TS 34.121: "Terminal Conformance Specification; Radio Transmission and Reception (FDD)".
- [17] ——— 3GPP TS 34.122: "Terminal Conformance Specification; Radio Transmission and Reception (TDD)".
- [18] ——— 3GPP TS 31.102: "Characteristics of the USIM Application".
- [19] ——— 3GPP TS 25.224: "Physical Layer Procedures (TDD)".
- [20] ——— 3GPP TS 25.215: "Physical layer – Measurements (FDD)".
- [21] ——— 3GPP TS 25.101: "UE Radio Transmission and Reception (FDD)".
- [22] ——— 3GPP TS 25.123: "Requirements for support of radio resource management (TDD)".
- [23] ——— 3GPP TS 25.133: "Requirements for Support of Radio Resource Management (FDD)".
- [24] ——— 3GPP TS 03.22: "Functions related to Mobile Station (MS) in idle mode and group receive mode".
- [25] ——— 3GPP TS 04.18: "Mobile radio interface layer 3 specification; Radio Resource Control Protocol".
- [26] ——— 3GPP TS 05.08: "Radio Subsystem Link Control".
- [27] ——— 3GPP TS 22.001: "Principles of circuit telecommunication services supported by a Public Land Mobile Network (PLMN)".
- [28] ——— 3GPP TS 24.007: "Mobile radio interface signalling layer 3; General aspects".
- [29] ——— 3GPP TS 25.211: "Physical channels and mapping of transport channels onto physical channels (FDD)".
- [30] ——— 3GPP TS 25.323: "Packet Data Convergence Protocol (PDCP) Specification".
- [31] ——— 3GPP TS 33.102: "3G Security; Security Architecture".
- [32] ——— 3GPP TS 23.060: "General Packet Radio Service (GPRS) Service description; Stage 2".
- [33] ——— Void.
- [34] ——— 3GPP TS 23.040: "Technical realization of the Short Message Service (SMS)".



- [35] — 3GPP TS 23.038: "Alphabets and language-specific information".
- [36] — 3GPP TS 24.011: "Point-to-Point (PP) Short Message Service (SMS) support on mobile radio interface".
- [37] — 3GPP TS 25.324: "Broadcast/Multicast Control BMC".
- [38] — 3GPP TS 23.041: "Technical realization of Cell Broadcast Service (CBS)".
- [39] — RFC 2507: "IP Header Compression". [40] 3GPP TS 34.123-1 version 5 (Release 5): "User Equipment (UE) Conformance Specification, Part 1 – Protocol conformance specification."

---

## 3 Definitions and abbreviations

(void)

### 3.1 Definitions

For the purposes of the present document, the terms and definitions given in TR 21.905 apply, unless specified below:

**example:** text used to clarify abstract rules by applying them literally

### 3.2 Abbreviations

For the purposes of the present document, the abbreviations specified in TR 25.905 apply, with any additional abbreviations specified below:

SS — System Simulator

---

## 4 Requirements Overview

The requirements of the present document are provided in 3GPP TS 34.123-1 version 5 (Release 5) [40].

### 4.1 Test Methodology

#### 4.1.1 Testing of optional functions and procedures

Any function or procedure which is optional, as indicated in the present document, may be subject to a conformance test if it is implemented in the UE.

A declaration by the apparatus supplier (ICS) is used to determine whether an optional function/procedure has been implemented.

#### 4.1.2 Test interfaces and facilities

Detailed descriptions of the UE test interfaces and special facilities for testing are provided in [10].

### 4.2 Implicit Testing

For some 3GPP signalling and protocol features conformance is not verified explicitly in the present document. This does not imply that correct functioning of these features is not essential, but that these are implicitly tested to a sufficient degree in other tests.

## 5 – 18 (void) – Reference Conditions

The reference environments used by all signalling and protocol tests are specified in TS 34.108. Where a test requires an environment that is different, this will be specified in the test itself.

### 5.1 Generic setup procedures

A set of basic generic procedures for radio resource signalling, and generic setup procedures for layer 3 NAS signalling are described in TS 34.108 clause 7. These procedures are used in numerous test cases throughout the present document.

### 6 – Idle mode operations

In the following paragraphs some explanatory text is given concerning the nature of the tests in this clause and the general behaviour of the SS is described.

Since the conformance requirements of most of the tests in this clause cannot be tested explicitly, testing is done implicitly by testing the UE behaviour from its responses to the SS.

In some cases, a test is performed in multiple stages in order that the requirements can be tested within the above constraints.

For any UE all the carriers are in its supported band(s) of operation.

Unless otherwise stated in the method of test, in all of the tests of this clause:

— the default values of the system information data fields given in TS 34.108 are used;

— the UE is equipped with a USIM containing default values. The USIM is in the idle updated state in the default location area with a TMSI assigned at the beginning of each test;

— the cells shall be configured such that  $Squal > 0$  (FDD only) and  $Srxlev > 0$  while applying  $Qqualmin$  (FDD only) and  $Qrxlevmin$  in table 6.1. In addition, for an FDD cell, the measured primary CPICH RSCP value shall be greater than or equal to  $-95$  dBm (definition of High Quality cell, see TS 25.304, clause 5.1.2.2). In addition, for a TDD cell, the measured P-CCPCH RSCP shall be greater than or equal to  $-84$  dBm (definition of High Quality cell, see TS 25.304, clause 5.1.2.2).

Three different methods A, B and C are applied in the tests:

#### Method A:

— the SS is continuously paging the UE on all cells at the start of the test and does not respond to RACH requests from the UE (which causes a cell reselection). Where a test specifies that the UE is not paged on a particular cell, only idle paging is transmitted. This method is similar to the one used in TS 51.010-1, clause 20.

#### Method B:

— the SS is continuously paging the UE on all cells at the start of the test and responds to RACH requests from the UE with an IMMEDIATE ASSIGNMENT REJECT (GERAN cell) or RRC CONNECTION REJECT (UTRAN cell) message which causes the UE to return to Idle mode. Where a test specifies that the UE is not paged in a particular cell, only idle paging is transmitted.

#### Method C:

— no continuously paging as in method A or B. Normal response to RACH requests so Location Updating and Calls can be done.

Table 6.1: Default values of the system information fields

| Parameter          | Setting                  |
|--------------------|--------------------------|
| IMSI attach/detach | Method A, B: Not allowed |
|                    | Method C: Allowed        |

|                                                |                 |
|------------------------------------------------|-----------------|
| Intra-frequency cell re-selection indicator    | Allowed         |
| Cell_selection_and_reselection_quality_measure | CPICH_RSCP(FDD) |
| Qqualmin (FDD-only)                            | -24 dB          |
| Qrxlevmin (FDD)                                | -115 dBm        |
| <b>Qrxlevmin (TDD)</b>                         | <b>-103 dBm</b> |
| DRX-cycle-length                               | 1,28 s          |

CPICH\_Ec/Io and SCH\_Ec/Io shall fulfil requirements in TS 25.133, clause 8.1.2.2.1: The UE is able to identify a new detectable cell belonging to the monitored set within  $T_{\text{identify-intra}}$  when CPICH\_Ec/Io  $\geq$  -20 dB and SCH\_Ec/Io  $\geq$  -20 dB.

It is a UE option whether to indicate access technologies to the user (TS 23.122, clause 4.4.3.1.2). Therefore, for combined UTRAN/GSM tests, it is indicated in parentheses which access technology shall be indicated to the user if the UE has this capability.

If a parameter is indicated with a \*, it means that the parameter is calculated internally in the UE and is only shown for clarification of the test procedure.

The PLMN numbers indicated in table 6.2 are used in test cases to associate a cell with an MCC and MNC for that cell. If no PLMN is explicitly specified, the default value is PLMN 1.

Table 6.2: Location Area Information (LAI) in System Information type 3 messages broadcast on the BCCH

| PLMN                         | MCC1 | MCC2 | MCC3 | MNC1 | MNC2 | MNC3        | LAC |
|------------------------------|------|------|------|------|------|-------------|-----|
| 1                            | 0    | 0    | 1    | 0    | 1    | Not-present | x   |
| 2                            | 0    | 0    | 2    | 1    | 1    | Not-present | x   |
| 3                            | 0    | 0    | 4    | 2    | 1    | Not-present | x   |
| 4                            | 0    | 0    | 5    | 3    | 1    | Not-present | x   |
| 5                            | 0    | 0    | 6    | 4    | 1    | Not-present | x   |
| 6                            | 0    | 0    | 7    | 5    | 1    | Not-present | x   |
| 7                            | 0    | 0    | 8    | 6    | 1    | Not-present | x   |
| 8                            | 0    | 0    | 9    | 7    | 1    | Not-present | x   |
| 9                            | 0    | 1    | 0    | 0    | 2    | Not-present | x   |
| 10                           | 0    | 1    | 1    | 1    | 2    | Not-present | x   |
| 11                           | 0    | 1    | 2    | 2    | 2    | Not-present | x   |
| 12                           | 0    | 1    | 3    | 3    | 2    | Not-present | x   |
| NOTE: 'x' denotes any value. |      |      |      |      |      |             |     |

References: TS 23.122, annex A and TS 23.003, clause 2.

The test channel numbers indicated in tables 6.3, 6.4 and 6.5 are used in test cases to associate a cell with a frequency for that cell. The frequencies for GSM and DCS cells in table 6.5 are identical to those used in TS 51.010-1, clause 26.3.1. The RF signal levels for GSM cells are given in table 6.5 for UTRAN FDD cells in TS 34.108, table 6.1.1

and for UTRAN TDD cells in TS 34.108, table 6.1.5. If no channel is explicitly specified, the default value is Test Channel 1.

Table 6.3: UTRA (FDD) test frequencies

| Test Channel |                               |        | ITU region 2               |        |
|--------------|-------------------------------|--------|----------------------------|--------|
|              | CPICH_Ec<br>dBm / 3.84<br>MHz | UARFCN | CPICH_Ec<br>dBm / 3.84 MHz | UARFCN |
| 1            | -72                           | 9 613  | -72                        | 9 263  |
| 2            | -75                           | 9 663  | -75                        | 9 313  |
| 3            | -78                           | 9 713  | -78                        | 9 363  |
| 4            | -81                           | 9 763  | -81                        | 9 413  |
| 5            | -84                           | 9 813  | -84                        | 9 463  |
| 6            | -87                           | 9 863  | -87                        | 9 513  |

References: TS 34.108, clause 5.1.1 and TS 34.121, clause 4.

Table 6.4: UTRA TDD test frequencies

| Test Channel |                        |        | ITU region 2           |        |
|--------------|------------------------|--------|------------------------|--------|
|              | P-CCPCH_<br>RSCP [dBm] | UARFCN | P-CCPCH_<br>RSCP [dBm] | UARFCN |
| 1            | -61                    | 9 513  | -61                    | 9 263  |
| 2            | -64                    | 9 550  | -64                    | 9 537  |
| 3            | -67                    | 9 587  | -67                    | 9 663  |
| 4            | -70                    | 10 063 | -70                    | 9 937  |
| 5            | -73                    | 10 087 | -73                    | 9 563  |
| 6            | -76                    | 10 112 | -76                    | 9 637  |

References: TS 34.108, clause 5.1.2 and TS 34.122, clause 4.

Table 6.5: GSM/DCS test frequencies and levels

| Test Channel | GSM 900                                         |            | DCS 1 800                                       |            |
|--------------|-------------------------------------------------|------------|-------------------------------------------------|------------|
|              | level<br>dB $\mu$ V <sub>emf</sub> (-)<br>/ dBm | BCCH ARFCN | level<br>dB $\mu$ V <sub>emf</sub> (-)<br>/ dBm | BCCH ARFCN |
| 1            | +65 / -48                                       | 1          | +65 / -48                                       | 520        |
| 2            | +63 / -50                                       | 7          | +63 / -50                                       | 580        |

|   |         |     |         |     |
|---|---------|-----|---------|-----|
| 3 | +61/-52 | 39  | +61/-52 | 610 |
| 4 | +55/-58 | 65  | +55/-58 | 702 |
| 5 | +59/-54 | 66  | +59/-54 | 703 |
| 6 | +57/-56 | 85  | +57/-56 | 830 |
| 7 | +55/-58 | 97  | +55/-58 | 885 |
| 8 | +53/-60 | 124 |         |     |

|              | GSM-450                     |            | DCS-480                     |            |
|--------------|-----------------------------|------------|-----------------------------|------------|
| Test Channel | level<br>dBmVemf(-)<br>/dBm | BCCH ARFCN | level<br>dBmVemf(-)<br>/dBm | BCCH ARFCN |
| 1            | +65/-48                     | 259        | +65/-48                     | 306        |
| 2            | +63/-50                     | 261        | +63/-50                     | 308        |
| 3            | +61/-52                     | 267        | +61/-52                     | 314        |
| 4            | +55/-58                     | 268        | +55/-58                     | 315        |
| 5            | +59/-54                     | 281        | +59/-54                     | 328        |
| 6            | +57/-56                     | 288        | +57/-56                     | 335        |
| 7            | +55/-58                     | 291        | +55/-58                     | 338        |
| 8            | +53/-60                     | 293        | +53/-60                     | 340        |

|              | Multiband 900/1800          |            | PCS-1900                    |            |
|--------------|-----------------------------|------------|-----------------------------|------------|
| Test Channel | level<br>dBmVemf(-)<br>/dBm | BCCH ARFCN | level<br>dBmVemf(-)<br>/dBm | BCCH ARFCN |
| 1            | +65/-48                     | 520        | +65/-48                     | 512        |
| 2            | +63/-50                     | 7          | +63/-50                     | 520        |
| 3            | +61/-52                     | 39         | +61/-52                     | 580        |
| 4            | +55/-58                     | 702        | +55/-58                     | 610        |
| 5            | +59/-54                     | 66         | +59/-54                     | 702        |
| 6            | +57/-56                     | 85         | +57/-56                     | 703        |
| 7            | +55/-58                     | 885        | +55/-58                     | 800        |
| 8            | +53/-60                     | 124        |                             |            |

|              | Multiband 450/900           |            | Multiband 480/900           |            |
|--------------|-----------------------------|------------|-----------------------------|------------|
| Test Channel | level<br>dBμVemf(-)<br>/dBm | BCCH ARFCN | level<br>dBμVemf(-)<br>/dBm | BCCH ARFCN |
| 1            | +65/-48                     | 1          | +65/-48                     | 1          |
| 2            | +63/-50                     | 261        | +63/-50                     | 308        |
| 3            | +61/-52                     | 267        | +61/-52                     | 314        |
| 4            | +55/-58                     | 65         | +55/-58                     | 65         |
| 5            | +59/-54                     | 281        | +59/-54                     | 328        |
| 6            | +57/-56                     | 288        | +57/-56                     | 335        |
| 7            | +55/-58                     | 124        | +55/-58                     | 124        |
| 8            | +53/-60                     | 293        | +53/-60                     | 340        |

|              | Multiband 450/1800          |            | Multiband 480/1800          |            |
|--------------|-----------------------------|------------|-----------------------------|------------|
| Test Channel | level<br>dBμVemf(-)<br>/dBm | BCCH ARFCN | level<br>dBμVemf(-)<br>/dBm | BCCH ARFCN |
| 1            | +65/-48                     | 520        | +65/-48                     | 520        |
| 2            | +63/-50                     | 261        | +63/-50                     | 308        |
| 3            | +61/-52                     | 267        | +61/-52                     | 314        |
| 4            | +55/-58                     | 702        | +55/-58                     | 702        |
| 5            | +59/-54                     | 281        | +59/-54                     | 328        |
| 6            | +57/-56                     | 288        | +57/-56                     | 335        |
| 7            | +55/-58                     | 885        | +55/-58                     | 885        |
| 8            | +53/-60                     | 293        | +53/-60                     | 340        |

For testing an E-GSM Mobile station, the BCCH ARFCN of GSM Test Channel 7 at GSM 900 column shall be 985 (instead of 97). For testing an R-GSM Mobile station, the BCCH ARFCN of GSM Test Channel 7 at GSM 900 column shall be 965 (instead of 97).

#### 6.1 In a pure 3GPP environment

##### 6.1.1 PLMN selection and reselection

##### 6.1.1.1 PLMN selection of RPLMN, HPLMN, UPLMN and OPLMN; Manual mode

##### 6.1.1.1.1 Definition

Test to verify that the UE can present the available PLMNs in priority order to the user when asked to do so in manual mode and that the displayed PLMNs can be selected / reselected by the user. Forbidden PLMNs shall also be displayed in the list. If available, the RPLMN shall be selected at switch-on, otherwise the displayed list shall include in priority

order HPLMN, User-PLMN and Operator-PLMN. The last priority in the list is "Other PLMN/access technology combinations" which is not included in this test.

Only UTRAN cells and a UE equipped with a USIM with Radio Access Technology fields set to UTRAN are considered.

#### 6.1.1.1.2 Conformance requirement

1. At switch on, or following recovery from lack of coverage, the MS selects the registered PLMN or equivalent PLMN (if it is available) using all access technologies that the MS is capable of and if necessary (in the case of recovery from lack of coverage, see TS 23.122, clause 4.5.2) attempts to perform a Location Registration.

If successful registration is achieved, the MS indicates the selected PLMN.

If there is no registered PLMN, or if registration is not possible due to the PLMN being unavailable or registration failure, the MS follows either Automatic or Manual Network Selection Mode Procedure depending on its operating mode.

#### 2. Manual Network Selection Mode Procedure:

The MS indicates whether there are any PLMNs, which are available using all supported access technologies. This includes PLMNs in the "forbidden PLMNs" list and PLMNs which only offer services not supported by the MS.

If displayed, PLMNs meeting the criteria above are presented in the following order:

##### 2.1 HPLMN;

2.2 PLMNs contained in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

2.3 PLMNs contained in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

2.4 Other PLMN/access technology combinations with received high quality signal in random order;

2.5 Other PLMN/access technology combinations in order of decreasing signal quality.

The user may select his desired PLMN and the MS then initiates registration on this PLMN using the access technology chosen by the user for that PLMN or using the highest priority available access technology for that PLMN, if the associated access technologies have a priority order. (This may take place at any time during the presentation of PLMNs). For such a registration, the MS shall ignore the contents of the "forbidden LAs for roaming", "forbidden LAs for regional provision of service", "forbidden PLMNs for GPRS service" and "forbidden PLMNs" lists.

If the user does not select a PLMN, the selected PLMN shall be the one that was selected before the PLMN selection procedure started. If no such PLMN was selected or that PLMN is no longer available, then the MS shall attempt to camp on any acceptable cell and enter the limited service state.

3. If a "PLMN not allowed" message is received by an MS in response to an LR request from a VPLMN, that VPLMN is added to a list of "forbidden PLMNs" in the SIM and thereafter that VPLMN will not be accessed by the MS when in automatic mode. A PLMN is removed from the "forbidden PLMNs" list if, after a subsequent manual selection of that PLMN, there is a successful LR. This list is retained when the MS is switched off or the SIM is removed. The HPLMN shall not be stored on the list of "forbidden PLMNs".

#### References

1. TS 23.122, clause 4.4.3.1;

2. TS 23.122, clause 4.4.3.1.2;

3. TS 23.122, clause 3.1.

NOTE: TS 31.102 defines the USIM fields.

#### 6.1.1.1.3 Test purpose

1. To verify that if available, the RPLMN is selected at switch-on.

2. To verify that in Manual Network Selection Mode Procedure, the UE presents the HPLMN, UPLMN and OPLMN in a prioritized order.

3. To verify that forbidden PLMNs are also displayed in the list.

#### 6.1.1.1.4 Method of test

##### Initial conditions

The UE is in manual PLMN selection mode.

Cell levels are from table 6.3. (FDD).

All Radio Access Technology USIM fields and cells are UTRAN.

| Cell   | CPICH_<br>Ec [dBm/3.84<br>MHz]<br>(FDD) | P-CCPCH_<br>RSCP [dBm]<br>(TDD) | Test Channel | PLMN   |
|--------|-----------------------------------------|---------------------------------|--------------|--------|
| Cell 1 | -72                                     | -61                             | 1            | PLMN 1 |
| Cell 2 | -75                                     | -64                             | 2            | PLMN 2 |
| Cell 3 | -78                                     | -67                             | 3            | PLMN 3 |
| Cell 4 | -81                                     | -70                             | 4            | PLMN 4 |
| Cell 5 | -84                                     | -73                             | 5            | PLMN 5 |
| Cell 6 | -87                                     | -76                             | 6            | PLMN 6 |

The UE is equipped with a USIM containing default values except for those listed below.

| USIM field              | Priority        | PLMN   |
|-------------------------|-----------------|--------|
| EF <sub>LOC1</sub>      |                 | PLMN 1 |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN 2 |
| EF <sub>PLMNwAcT</sub>  | 1 <sup>st</sup> | PLMN 3 |
|                         | 2 <sup>nd</sup> | PLMN 4 |
| EF <sub>OPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN 5 |
|                         | 2 <sup>nd</sup> | PLMN 6 |
| EF <sub>FPLMN</sub>     | PLMN 3          |        |

##### Test procedure

Method B is applied.

a) The SS activates cells 1-6 and monitors the cells for random access requests from the UE.

b) The UE is switched on.

c) The SS waits for random access requests from the UE.

d) Cell 1 is switched off.

e) PLMN 4 shall be selected when the PLMN list is presented.



- f) ~~The SS waits for random access requests from the UE.~~
- g) ~~Cell 4 is switched off.~~
- h) ~~PLMN 3 shall be selected when the PLMN list is presented. The SS shall reject the Registration Request from the UE.~~
- i) ~~PLMN 5 shall be selected (the list is already available).~~
- j) ~~The SS waits for random access requests from the UE.~~
- k) ~~Cell 5 is switched off.~~
- l) ~~PLMN 2 shall be selected when the PLMN list is presented.~~
- m) ~~The SS waits for random access requests from the UE.~~
- n) ~~Cell 2 is switched off.~~
- o) ~~PLMN 6 shall be selected when the PLMN list is presented.~~
- p) ~~The SS waits for random access requests from the UE.~~
- q) ~~Cell 6 is switched off.~~

#### 6.1.1.1.5 Test Requirements

- 1) ~~In step c), the response from the UE shall be on Cell 1. The displayed PLMN shall be PLMN 1.~~
- 2) ~~In step e), the list shall be presented. The priority shall be as follows: PLMN 2, PLMN 3, PLMN 4, PLMN 5, PLMN 6.~~
- 3) ~~In step f), the response from the UE shall be on Cell 4. The displayed PLMN shall be PLMN 4.~~
- 4) ~~In step h), the list shall be presented. The priority shall be as follows: PLMN 2, PLMN 3, PLMN 5, PLMN 6. After PLMN 3 has been selected, the list shall appear again as the UE cannot perform registration.~~
- 6) ~~In step j), the response from the UE shall be on Cell 5. The displayed PLMN shall be PLMN 5.~~
- 7) ~~In step l), the list shall be presented. The priority shall be as follows: PLMN 2, PLMN 3, PLMN 6.~~
- 8) ~~In step m), the response from the UE shall be on Cell 2. The displayed PLMN shall be PLMN 2.~~
- 9) ~~In step o), the list shall be presented. The priority shall be as follows: PLMN 3, PLMN 6.~~
- 10) ~~In step p), the response from the UE shall be on Cell 6. The displayed PLMN shall be PLMN 6.~~
- 11) ~~After step q), the UE shall inform that only limited service is possible.~~

#### 6.1.1.2 PLMN selection of "Other PLMN / access technology combinations"; Manual mode

##### 6.1.1.2.1 Definition

Test to verify that the UE can present the available PLMNs in priority order to the user when asked to do so in manual mode and that the displayed PLMNs can be selected / reselected by the user. Forbidden PLMNs shall also be displayed in the list. In this test are only considered "Other PLMN/access technology combinations" in the priority list.

Only UTRAN cells and a UE equipped with a USIM with Radio Access Technology fields set to UTRAN are considered.

##### 6.1.1.2.2 Conformance requirement

1. At switch on, or following recovery from lack of coverage, the MS selects the registered PLMN or equivalent PLMN (if it is available) using all access technologies that the MS is capable of and if necessary (in the case of recovery from lack of coverage, see TS 23.122, clause 4.5.2) attempts to perform a Location Registration.

If successful registration is achieved, the MS indicates the selected PLMN.

If there is no registered PLMN, or if registration is not possible due to the PLMN being unavailable or registration failure, the MS follows either Automatic or Manual Network Selection Mode Procedure depending on its operating mode.

## 2. Manual Network Selection Mode Procedure:

The MS indicates whether there are any PLMNs, which are available using all supported access technologies. This includes PLMNs in the "forbidden PLMNs" list and PLMNs which only offer services not supported by the MS.

If displayed, PLMNs meeting the criteria above are presented in the following order:

### 2.1 HPLMN;

2.2 PLMNs contained in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

2.3 PLMNs contained in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

2.4 Other PLMN/access technology combinations with received high quality signal in random order;

2.5 Other PLMN/access technology combinations in order of decreasing signal quality.

In 2.5, the MS shall order the PLMN/access technology combinations in order of decreasing signal quality within each access technology. The order between PLMN/access technology combinations with different access technologies is an MS implementation issue.

The user may select his desired PLMN and the MS then initiates registration on this PLMN using the access technology chosen by the user for that PLMN or using the highest priority available access technology for that PLMN, if the associated access technologies have a priority order. (This may take place at any time during the presentation of PLMNs). For such a registration, the MS shall ignore the contents of the "forbidden LAs for roaming", "forbidden LAs for regional provision of service", "forbidden PLMNs for GPRS service" and "forbidden PLMNs" lists.

If the user does not select a PLMN, the selected PLMN shall be the one that was selected before the PLMN selection procedure started. If no such PLMN was selected or that PLMN is no longer available, then the MS shall attempt to camp on any acceptable cell and enter the limited service state.

3. If a "PLMN not allowed" message is received by an MS in response to an LR request from a VPLMN, that VPLMN is added to a list of "forbidden PLMNs" in the SIM and thereafter that VPLMN will not be accessed by the MS when in automatic mode. A PLMN is removed from the "forbidden PLMNs" list if, after a subsequent manual selection of that PLMN, there is a successful LR. This list is retained when the MS is switched off or the SIM is removed. The HPLMN shall not be stored on the list of "forbidden PLMNs".

4. The UE shall scan all RF channels in the UTRA band according to its capabilities to find available PLMNs. On each carrier, the UE shall search for the strongest cell according to the cell search procedures (for FDD, see TS 25.214, and TDD, see TS 25.224) and read its system information, in order to find out which PLMN the cell belongs to. If the UE can read the PLMN identity, the found PLMN shall be reported to the NAS as a high quality PLMN (but without the RSCP value), provided that the following high quality criterion is fulfilled:

— For an FDD cell, the measured primary CPICH RSCP value shall be greater than or equal to -95 dBm.

— For a TDD cell, the measured P-CCPCH RSCP shall be greater than or equal to -84 dBm.

— Found PLMNs that do not satisfy the high quality criterion, but for which the UE has been able to read the PLMN identities are reported to the NAS together with the CPICH RSCP value for UTRA FDD cells and P-CCPCH RSCP for UTRA TDD cells.

## References

1. TS 23.122, clause 4.4.3.1.
2. TS 23.122, clause 4.4.3.1.2.
3. TS 23.122, clause 3.1.
4. TS 25.304, clause 5.1.2.2.

NOTE: — TS 31.102 defines the USIM fields.

#### 6.1.1.2.3 Test purpose

1. — To verify that in Manual Network Selection Mode Procedure, the UE presents "Other PLMN/access technology combinations" in a prioritized order according to conformance requirement 2.4 and 2.5.

2. — To verify that forbidden PLMNs are also displayed in the list.

#### 6.1.1.2.4 Method of test

Initial conditions

The UE is in manual PLMN selection mode.

All Radio Access Technology USIM fields and cells are UTRAN.

| Cell   | CPICH_Ec<br>[dBm/3.84<br>MHz]<br><br>(FDD) | P-CCPCH_<br>RSCP [dBm]<br><br>(TDD) | High-Quality<br>signal | Test-Channel | PLMN    |
|--------|--------------------------------------------|-------------------------------------|------------------------|--------------|---------|
| Cell 1 | -85                                        | -74                                 | Yes                    | 1            | PLMN-6  |
| Cell 2 | -80                                        | -69                                 | Yes                    | 2            | PLMN-7  |
| Cell 3 | -80                                        | -69                                 | Yes                    | 3            | PLMN-8  |
| Cell 4 | -98                                        | -87                                 | No                     | 4            | PLMN-9  |
| Cell 5 | -101                                       | -90                                 | No                     | 5            | PLMN-10 |
| Cell 6 | -104                                       | -93                                 | No                     | 6            | PLMN-11 |

The UE is equipped with a USIM containing default values except for those listed below.

| USIM field              | Priority        | PLMN   |
|-------------------------|-----------------|--------|
| EF <sub>LOCI</sub>      |                 | PLMN-1 |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN-2 |
| EF <sub>PLMNwAcT</sub>  | 1 <sup>st</sup> | PLMN-3 |
|                         | 2 <sup>nd</sup> | PLMN-4 |
| EF <sub>OPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN-5 |
|                         | 2 <sup>nd</sup> | PLMN-6 |
| EF <sub>FPLMN</sub>     | PLMN-10         |        |

Test procedure

Method B is applied.

a) — The SS activates cells 1-6 and monitors the cells for random access requests from the UE.

b) — The UE is switched on.

c) — PLMN-9 shall be selected when the PLMN list is presented.

d) — The SS waits for random access requests from the UE.

- e) Cell 4 is switched off.
- f) PLMN 7 shall be selected when the PLMN list is presented.
- g) The SS waits for random access requests from the UE.
- h) Cell 2 is switched off.
- i) PLMN 6 shall be selected when the PLMN list is presented.
- j) The SS waits for random access requests from the UE.
- k) Cell 1 is switched off.
- l) PLMN 11 shall be selected when the PLMN list is presented.
- m) The SS waits for random access requests from the UE.
- n) Cell 6 is switched off.
- o) PLMN 10 shall be selected when the PLMN list is presented. The SS shall reject the Registration Request from the UE.
- p) Cell 5 is switched off.
- q) PLMN 8 shall be selected (the list is already available)
- r) The SS waits for random access requests from the UE.
- s) Cell 3 is switched off.

#### 6.1.1.2.5 Test Requirements

- 1) In step c), the list shall be presented. The priority shall be as follows: PLMN 6 followed by PLMN 7, PLMN 8 in random order, followed by PLMN 9, PLMN 10, PLMN 11.
- 2) In step d), the response from the UE shall be on Cell 4. The displayed PLMN shall be PLMN 9.
- 3) In step f), the list shall be presented. The priority shall be as follows: PLMN 6 followed by PLMN 7, PLMN 8 in random order, followed by PLMN 10, PLMN 11.
- 4) In step g), the response from the UE shall be on Cell 2. The displayed PLMN shall be PLMN 7.
- 5) In step i), the list shall be presented. The priority shall be as follows: PLMN 6, PLMN 8, PLMN 10, PLMN 11.
- 6) In step j), the response from the UE shall be on Cell 1. The displayed PLMN shall be PLMN 6.
- 7) In step l), the list shall be presented. The priority shall be as follows: PLMN 8, PLMN 10, PLMN 11.
- 8) In step m), the response from the UE shall be on Cell 6. The displayed PLMN shall be PLMN 11.
- 9) In step o), the list shall be presented. The priority shall be as follows: PLMN 8, PLMN 10. After PLMN 10 has been selected, the list shall appear again as the UE cannot perform registration.
- 10) In step q), the list shall be presented and shall only contain PLMN 8.
- 11) In step r), the UE shall respond on Cell 3. The displayed PLMN shall be PLMN 8.
- 12) After step s), the UE shall inform that no network is available.

#### 6.1.1.3 PLMN selection; independence of RF level and preferred PLMN; Manual mode

##### 6.1.1.3.1 Definition

Test to verify that in Manual Network Selection Mode, the UE is able to obtain normal service on a PLMN which is neither the better nor a preferred PLMN and that it tries to obtain service on a VPLMN if and only if the user selects it manually.

#### 6.1.1.3.2 Conformance requirement

1. ~~At switch-on, or following recovery from lack of coverage, the MS selects the registered PLMN or equivalent PLMN (if it is available) using all access technologies that the MS is capable of and if necessary (in the case of recovery from lack of coverage, see TS 23.122, clause 4.5.2) attempts to perform a Location Registration.~~

~~If successful registration is achieved, the MS indicates the selected PLMN.~~

~~If there is no registered PLMN, or if registration is not possible due to the PLMN being unavailable or registration failure, the MS follows either Automatic or Manual Network Selection Mode Procedure depending on its operating mode.~~

#### 2. ~~Manual Network Selection Mode Procedure:~~

~~The MS indicates whether there are any PLMNs, which are available using all supported access technologies. This includes PLMNs in the "forbidden PLMNs" list and PLMNs which only offer services not supported by the MS.~~

~~If displayed, PLMNs meeting the criteria above are presented in the following order:~~

##### 2.1 ~~HPLMN;~~

2.2 ~~PLMNs contained in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);~~

2.3 ~~PLMNs contained in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);~~

2.4 ~~Other PLMN/access technology combinations with received high quality signal in random order;~~

2.5 ~~Other PLMN/access technology combinations in order of decreasing signal quality.~~

~~—The user may select his desired PLMN and the MS then initiates registration on this PLMN using the access technology chosen by the user for that PLMN or using the highest priority available access technology for that PLMN, if the associated access technologies have a priority order. (This may take place at any time during the presentation of PLMNs). For such a registration, the MS shall ignore the contents of the "forbidden LAs for roaming", "forbidden LAs for regional provision of service", "forbidden PLMNs for GPRS service" and "forbidden PLMNs" lists.~~

~~If the user does not select a PLMN, the selected PLMN shall be the one that was selected before the PLMN selection procedure started. If no such PLMN was selected or that PLMN is no longer available, then the MS shall attempt to camp on any acceptable cell and enter the limited service state.~~

#### References

1. ~~TS 23.122, clause 4.4.3.1.~~

2. ~~TS 23.122, clause 4.4.3.1.2~~

NOTE: ~~— TS 31.102 defines the USIM fields.~~

#### 6.1.1.3.3 Test purpose

1. ~~To verify that the selected PLMN at switch-on is the HPLMN.~~

2. ~~To verify that in Manual Network Selection Mode Procedure the UE tries to obtain service on a VPLMN if and only if the user selects it manually.~~

3. ~~To verify that the UE is able to obtain normal service on a PLMN which is neither the better nor a preferred PLMN.~~

#### 6.1.1.3.4 Method of investigation

##### Initial conditions

~~The UE is in manual PLMN selection mode.~~

~~"IMSI attach" flag in the BCCH is set to allowed.~~

~~For FDD only:~~

Step a-d:

| Parameter    | Unit         | Cell 1 | Cell 2 | Cell 3 |
|--------------|--------------|--------|--------|--------|
| Test Channel |              | 1      | 2      | 3      |
| CPICH_Ec     | dBm/3.84 MHz | -60    | -70    | OFF    |
| PLMN         |              | 1      | 2      | 3      |

Step e-f:

|          |              |           |     |     |
|----------|--------------|-----------|-----|-----|
| CPICH_Ec | dBm/3.84 MHz | -60 → OFF | -70 | OFF |
|----------|--------------|-----------|-----|-----|

Step g-h:

|          |              |     |     |           |
|----------|--------------|-----|-----|-----------|
| CPICH_Ec | dBm/3.84 MHz | OFF | -70 | OFF → -60 |
|----------|--------------|-----|-----|-----------|

Step i-l:

|          |              |     |           |     |
|----------|--------------|-----|-----------|-----|
| CPICH_Ec | dBm/3.84 MHz | OFF | -70 → OFF | -60 |
|----------|--------------|-----|-----------|-----|

For TDD only:

Step a-d:

| Parameter    | Unit | Cell 1 | Cell 2 | Cell 3 |
|--------------|------|--------|--------|--------|
| Test Channel |      | 1      | 2      | 3      |
| P-CCPCH_RSCP | dBm  | -69    | -72    | OFF    |
| Qrxlevmin    | dBm  | -103   | -103   | -103   |
| Srxlev*      | dB   | 34     | 31     | -      |
| PLMN         |      | 1      | 2      | 3      |

Step e-f:

|              |  |           |     |     |
|--------------|--|-----------|-----|-----|
| P-CCPCH_RSCP |  | -69 → OFF | -72 | OFF |
|--------------|--|-----------|-----|-----|

Step g-h:

|              |  |     |     |           |
|--------------|--|-----|-----|-----------|
| P-CCPCH_RSCP |  | OFF | -72 | OFF → -69 |
|--------------|--|-----|-----|-----------|

Step i-l:

|              |  |     |           |     |
|--------------|--|-----|-----------|-----|
| P-CCPCH_RSCP |  | OFF | -72 → OFF | -69 |
|--------------|--|-----|-----------|-----|

The UE is equipped with a USIM containing default values except for those listed below.

| USIM field              | Priority        | PLMN   |
|-------------------------|-----------------|--------|
| EF <sub>LOCI</sub>      |                 |        |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN-1 |

|                        |                 |        |
|------------------------|-----------------|--------|
| EF <sub>PLMNwAcT</sub> | 1 <sup>st</sup> | PLMN-3 |
|------------------------|-----------------|--------|

#### Test procedure

Method C is applied.

- a) ~~The SS activates cells 1 and 2.~~
- b) ~~The UE is switched on.~~
- c) ~~PLMN 1 is selected manually.~~
- d) ~~The SS waits for random access requests from the UE. A complete Location Update is done.~~
- e) ~~Cell 1 is switched off.~~
- f) ~~The SS waits to see if there is any random access request from the UE.~~
- g) ~~Cell 3 is switched on.~~
- h) ~~The SS waits to see if there is any random access request from the UE.~~
- i) ~~PLMN 2 is selected manually.~~
- j) ~~The SS waits for random access requests from the UE. A complete Location Update is done.~~
- k) ~~Cell 2 is switched off.~~
- l) ~~The SS waits to see if there is any random access request from the UE.~~

#### 6.1.1.3.5 Test Requirements

- 1) ~~In step d), there shall be a response on Cell 1. The selected PLMN shall be PLMN 1.~~
- 2) ~~In step f), there shall be no response from the UE within 2 min.~~
- 3) ~~In step h), there shall be no response from the UE within 2 min.~~
- 4) ~~In step j), there shall be a response on Cell 2. The selected PLMN shall be PLMN 2.~~
- 5) ~~In step l), there shall be no response from the UE within 2 min.~~

#### 6.1.1.4 PLMN selection of RPLMN, HPLMN, UPLMN and OPLMN; Automatic mode

##### 6.1.1.4.1 Definition

Test to verify that in Automatic Network Selection Mode, the UE selects PLMNs in a prioritized order. Forbidden PLMNs shall not be selected. If available, the RPLMN shall be selected at switch-on, otherwise the list shall include in priority order HPLMN, User-PLMN and Operator-PLMN. The last priority in the list is "Other PLMN/access technology combinations" which is not included in this test.

Only UTRAN cells and a UE equipped with a USIM with Radio Access Technology fields set to UTRAN are considered.

##### 6.1.1.4.2 Conformance requirement

1. ~~At switch-on, or following recovery from lack of coverage, the MS selects the registered PLMN or equivalent PLMN (if it is available) using all access technologies that the MS is capable of and if necessary (in the case of recovery from lack of coverage, see TS 23.122, clause 4.5.2) attempts to perform a Location Registration.~~

~~—If successful registration is achieved, the MS indicates the selected PLMN.~~

If there is no registered PLMN, or if registration is not possible due to the PLMN being unavailable or registration failure, the MS follows either Automatic or Manual Network Selection Mode Procedure depending on its operating mode.

2. ~~Automatic Network Selection Mode Procedure:~~

The MS selects and attempts registration on other PLMNs, if available and allowable in the following order:

2.1 HPLMN (if not previously selected);

2.2 Each PLMN in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

2.3 Each PLMN in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

2.4 Other PLMN/access technology combinations with received high quality signal in random order;

2.5 Other PLMN/access technology combinations in order of decreasing signal quality.

If successful registration is achieved, the MS indicates the selected PLMN.

If registration cannot be achieved because no PLMNs are available and allowable, the MS indicates "no service" to the user, waits until a new PLMN is available and allowable and then repeats the procedure.

If there were one or more PLMNs which were available and allowable, but an LR failure made registration on those PLMNs unsuccessful or an entry in the "forbidden LAs for regional provision of service" list prevented a registration attempt, the MS selects the first such PLMN again and enters a limited service state.

3. If a "PLMN not allowed" message is received by an MS in response to an LR request from a VPLMN, that VPLMN is added to a list of "forbidden PLMNs" in the SIM and thereafter that VPLMN will not be accessed by the MS when in automatic mode. A PLMN is removed from the "forbidden PLMNs" list if, after a subsequent manual selection of that PLMN, there is a successful LR. This list is retained when the MS is switched off or the SIM is removed. The HPLMN shall not be stored on the list of "forbidden PLMNs".

#### References

1. TS 23.122, clause 4.4.3.1.

2. TS 23.122, clause 4.4.3.1.1.

3. TS 23.122, clause 3.1.

NOTE: TS 31.102 defines the USIM fields.

#### 6.1.1.4.3 Test purpose

1. To verify that if available, the RPLMN is selected at switch-on.

2. To verify that in Automatic Network Selection Mode Procedure, the UE selects the RPLMN, HPLMN, UPLMN and OPLMN in a prioritized order.

3. To verify that forbidden PLMNs are not selected.

#### 6.1.1.4.4 Method of test

#### Initial conditions

The UE is in automatic PLMN selection mode.

Cell levels are from table 6.3 (FDD).

All Radio Access Technology USIM fields and cells are UTRAN.

| Cell   | CPICH_<br>Ec [dBm/3.84<br>MHz]<br>(FDD) | P-CCPCH_<br>RSCP [dBm]<br>(TDD) | Test Channel | PLMN   |
|--------|-----------------------------------------|---------------------------------|--------------|--------|
| Cell 1 | -72                                     | -61                             | 1            | PLMN 1 |



|        |     |     |   |        |
|--------|-----|-----|---|--------|
| Cell-2 | -75 | -64 | 2 | PLMN-2 |
| Cell-3 | -78 | -67 | 3 | PLMN-3 |
| Cell-4 | -81 | -70 | 4 | PLMN-4 |
| Cell-5 | -84 | -73 | 5 | PLMN-5 |
| Cell-6 | -87 | -76 | 6 | PLMN-6 |

The UE is equipped with a USIM containing default values except for those listed below.

| USIM-field              | Priority        | PLMN   |
|-------------------------|-----------------|--------|
| EF <sub>LOGI</sub>      |                 | PLMN-1 |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN-2 |
| EF <sub>PLMNwAcT</sub>  | 1 <sup>st</sup> | PLMN-3 |
|                         | 2 <sup>nd</sup> | PLMN-4 |
| EF <sub>OPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN-5 |
|                         | 2 <sup>nd</sup> | PLMN-6 |
| EF <sub>FPLMN</sub>     | PLMN-3          |        |

#### Test procedure

Method B is applied.

- a) The SS activates cells 1-6 and monitors the cells for random access requests from the UE.
- b) The UE is switched on.
- c) The SS waits for random access requests from the UE.
- d) Cell 1 is switched off.
- e) The SS waits for random access requests from the UE.
- f) Cell 2 is switched off.
- g) The SS waits for random access requests from the UE.
- i) Cell 4 is switched off.
- j) The SS waits for random access requests from the UE.
- k) Cell 5 is switched off.
- l) The SS waits for random access requests from the UE.
- m) Cell 6 is switched off.

#### 6.1.1.4.5 Test Requirements

- 1) In step c), the response from the UE shall be on Cell 1. The displayed PLMN shall be PLMN-1.
- 2) In step e), the response from the UE shall be on Cell 2. The displayed PLMN shall be PLMN-2.
- 3) In step g), the response from the UE shall be on Cell 4. The displayed PLMN shall be PLMN-4.

4) In step j), the response from the UE shall be on Cell 5. The displayed PLMN shall be PLMN 5.

5) In step l), the response from the UE shall be on Cell 6. The displayed PLMN shall be PLMN 6.

6) After step m), the UE shall inform that only limited service is possible

#### 6.1.1.5 PLMN selection of "Other PLMN / access technology combinations"; Automatic mode

##### 6.1.1.5.1 Definition

Test to verify that in Automatic Network Selection Mode, the UE selects PLMNs in a prioritized order. Forbidden PLMNs shall not be selected. In this test are only considered "Other PLMN/access technology combinations" in the priority list.

Only UTRAN cells and a UE equipped with a USIM with Radio Access Technology fields set to UTRAN are considered.

##### 6.1.1.5.2 Conformance requirement

1. At switch on, or following recovery from lack of coverage, the MS selects the registered PLMN or equivalent PLMN (if it is available) using all access technologies that the MS is capable of and if necessary (in the case of recovery from lack of coverage, see TS 23.122, clause 4.5.2) attempts to perform a Location Registration.

If successful registration is achieved, the MS indicates the selected PLMN.

If there is no registered PLMN, or if registration is not possible due to the PLMN being unavailable or registration failure, the MS follows either Automatic or Manual Network Selection Mode Procedure depending on its operating mode.

##### 2. Automatic Network Selection Mode Procedure:

The MS selects and attempts registration on other PLMNs, if available and allowable in the following order:

2.1 HPLMN (if not previously selected);

2.2 Each PLMN in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

2.3 Each PLMN in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

2.4 Other PLMN/access technology combinations with received high quality signal in random order;

2.5 Other PLMN/access technology combinations in order of decreasing signal quality.

In 2.5, the MS shall order the PLMN/access technology combinations in order of decreasing signal quality within each access technology. The order between PLMN/access technology combinations with different access technologies is an MS implementation issue.

If successful registration is achieved, the MS indicates the selected PLMN.

If registration cannot be achieved because no PLMNs are available and allowable, the MS indicates "no service" to the user, waits until a new PLMN is available and allowable and then repeats the procedure.

If there were one or more PLMNs which were available and allowable, but an LR failure made registration on those PLMNs unsuccessful or an entry in the "forbidden LAs for regional provision of service" list prevented a registration attempt, the MS selects the first such PLMN again and enters a limited service state.

3. If a "PLMN not allowed" message is received by an MS in response to an LR request from a VPLMN, that VPLMN is added to a list of "forbidden PLMNs" in the SIM and thereafter that VPLMN will not be accessed by the MS when in automatic mode. A PLMN is removed from the "forbidden PLMNs" list if, after a subsequent manual selection of that PLMN, there is a successful LR. This list is retained when the MS is switched off or the SIM is removed. The HPLMN shall not be stored on the list of "forbidden PLMNs".

4. The UE shall scan all RF channels in the UTRA band according to its capabilities to find available PLMNs. On each carrier, the UE shall search for the strongest cell according to the cell search procedures (for FDD, see TS 25.214, and TDD, see TS 25.224) and read its system information, in order to find out which PLMN the cell belongs to. If the UE

can read the PLMN identity, the found PLMN shall be reported to the NAS as a high quality PLMN (but without the RSCP value), provided that the following high quality criterion is fulfilled:

— For an FDD cell, the measured primary CPICH RSCP value shall be greater than or equal to -95 dBm.

— For a TDD cell, the measured P-CCPCH RSCP shall be greater than or equal to -84 dBm.

Found PLMNs that do not satisfy the high quality criterion, but for which the UE has been able to read the PLMN identities are reported to the NAS together with the CPICH RSCP value for UTRA FDD cells and P-CCPCH RSCP for UTRA TDD cells.

#### References

1. TS 23.122, clause 4.4.3.1.

2. TS 23.122, clause 4.4.3.1.1.

3. TS 23.122, clause 3.1.

4. TS 25.304, clause 5.1.2.2.

NOTE: TS 31.102 defines the USIM fields.

#### 6.1.1.5.3 Test purpose

1. To verify that in Automatic Network Selection Mode Procedure, the UE selects "Other PLMN/access technology combinations" in a prioritized order according to conformance requirement 2.4 and 2.5.

2. To verify that forbidden PLMNs are not selected.

#### 6.1.1.5.4 Method of test

#### Initial conditions

The UE is in automatic PLMN selection mode.

All Radio Access Technology USIM fields and cells are UTRAN.

| Cell   | CPICH_Ec<br>[dBm/3.84<br>MHz]<br>(FDD) | P-CCPCH_RSCP<br>[dBm]<br>(TDD) | High<br>Quality<br>signal | Test Channel | PLMN    |
|--------|----------------------------------------|--------------------------------|---------------------------|--------------|---------|
| Cell 1 | -85                                    | -74                            | Yes                       | 1            | PLMN 6  |
| Cell 2 | -80                                    | -69                            | Yes                       | 2            | PLMN 7  |
| Cell 3 | -80                                    | -69                            | Yes                       | 3            | PLMN 8  |
| Cell 4 | -98                                    | -87                            | No                        | 4            | PLMN 9  |
| Cell 5 | -101                                   | -90                            | No                        | 5            | PLMN 10 |
| Cell 6 | -104                                   | -93                            | No                        | 6            | PLMN 11 |

The UE is equipped with a USIM containing default values except for those listed below.

| USIM field              | Priority        | PLMN   |
|-------------------------|-----------------|--------|
| EF <sub>LOGI</sub>      |                 | PLMN 1 |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN 2 |
| EF <sub>PLMNwAcT</sub>  | 1 <sup>st</sup> | PLMN 3 |

|                         |                 |        |
|-------------------------|-----------------|--------|
|                         | 2 <sup>nd</sup> | PLMN 4 |
| EF <sub>OPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN 5 |
|                         | 2 <sup>nd</sup> | PLMN 6 |
| EF <sub>FPLMN</sub>     | PLMN 10         |        |

#### Test procedure

Method B is applied.

- a) ~~The SS activates cells 1-6 and monitors the cells for random access requests from the UE.~~
- b) ~~The UE is switched on.~~
- c) ~~The SS waits for random access requests from the UE.~~
- d) ~~Cell 1 is switched off.~~
- e) ~~The SS waits for random access requests from the UE.~~
- f) ~~The cell associated to the currently shown PLMN shall be switched off.~~
- g) ~~The SS waits for random access requests from the UE.~~
- h) ~~The cell associated to the currently shown PLMN shall be switched off.~~
- i) ~~The SS waits for random access requests from the UE.~~
- j) ~~Cell 4 is switched off.~~
- k) ~~The SS waits for random access requests from the UE.~~
- l) ~~Cell 6 is switched off.~~

#### 6.1.1.5.5 Test Requirements

- 1) ~~In step c), the response from the UE shall be on Cell 1. The displayed PLMN shall be PLMN 6.~~
- 2) ~~In step e), the response from the UE shall be on either Cell 2 or 3. The displayed PLMN shall be the one associated with the cell on which the response was received.~~
- 3) ~~In step g), the response from the UE shall be on either Cell 2 or 3 (excluding the cell in step 2). The displayed PLMN shall be the one associated with the cell on which the response was received.~~
- 4) ~~In step i), the response from the UE shall be on Cell 4. The displayed PLMN shall be PLMN 9.~~
- 5) ~~In step k), the response from the UE shall be on Cell 6. The displayed PLMN shall be PLMN 11.~~
- 6) ~~After step l), the UE shall inform that only limited service is possible.~~

#### 6.1.1.6 UE will transmit only if PLMN available

##### 6.1.1.6.1 Definition

Test to verify that the UE will not generate any RF output if no PLMN is available.

##### 6.1.1.6.2 Conformance requirement

[FFS: Currently no requirements exist in core specs.]

##### 6.1.1.6.3 Test purpose

- 1. ~~To verify that the UE does not give any "Service indication" when no PLMN is available.~~
- 2. ~~To verify that the UE will not generate any RF output when no PLMN is available.~~

## 6.1.1.6.4 Method of test

## Initial conditions

For FDD only:

| Parameter | Unit         | Cell 1 | Cell 2 | Cell 3 |
|-----------|--------------|--------|--------|--------|
| CPICH_Ec  | dBm/3.84 MHz | -60    | -65    | -70    |

For TDD only:

| Parameter    | Unit | Cell 1 | Cell 2 | Cell 3 |
|--------------|------|--------|--------|--------|
| P-CCPCH_RSCP | dBm  | -69    | -71    | -73    |
| Qrxlevmin    | dBm  | -103   | -103   | -103   |
| Srxlev*      | dB   | 34     | 32     | 30     |

## Test procedure

Method C is applied:

- a) The SS activates the cells 1-3 and monitors them for random access requests from the UE.
- b) The UE is switched on.
- c) The SS waits for random access request from the UE.
- d) Cells 1-3 are switched off.
- e) The SS shall wait 20 s to allow the UE to detect the loss of cells.
- f) By MMI, an attempt to originate a call is made.
- g) By MMI, an attempt to originate an emergency call is made (only if UE supports speech).

## 6.1.1.6.5 Test Requirements

- 1) In step c), after the UE has responded on Cell 1, it shall not respond on any other cell within 1 min.
- 2) In step f) and g), the UE shall not produce any RF output, neither give any "service indication" within 2 min.

## 6.1.1.7 Cell reselection of ePLMN in manual mode

## 6.1.1.7.1 Definition

Test to verify that the UE shall be able to reselect another PLMN declared as equivalent PLMN as the registered PLMN in the manual mode:

## 6.1.1.7.2 Conformance requirement

## B) Manual network selection mode

Once the UE has registered on a PLMN selected by the user, the UE shall not automatically register on a different PLMN unless:

- i) The new PLMN is declared as an equivalent PLMN by the registered PLMN;
- or;
- ii) The user selects automatic mode.

## References:

TS 22.011 clause 3.2.2.2B

## 6.1.1.7.3 Test purpose

To verify that in Manual Network Selection Mode Procedure, the UE can perform reselection to an equivalent PLMN.

## 6.1.1.7.4 Method of test

## Initial conditions

The UE is in manual PLMN selection mode.

Cell\_selection\_and\_reselection\_quality\_measure is CPICH\_RSCP (FDD).

All Radio Access Technology-USIM fields and cells are UTRAN.

| Cell   | CPICH_<br>RSCP [dBm]<br>(FDD) | P-CCPCH_<br>RSCP [dBm]<br>(TDD) | Test Channel | PLMN   |
|--------|-------------------------------|---------------------------------|--------------|--------|
| Cell 1 | -78                           | [TBD]                           | 1            | PLMN 1 |
| Cell 2 | -62                           | [TBD]                           | 2            | PLMN 2 |
| Cell 3 | -68                           | [TBD]                           | 3            | PLMN 3 |

PLMN1 is the HPLMN.

The UE is equipped with a USIM containing default values except for those listed below.

| USIM field         | Priority | PLMN   |
|--------------------|----------|--------|
| EF <sub>LOCI</sub> |          | PLMN 1 |

## Test procedure

a) The SS activates cells 1.

b) The UE is switched on.

c) The SS waits for random access requests from the UE.

d) A Location Update Accept message shall be sent on reception of a Location Update message from the UE. The Location Update Accept message shall include PLMN3 in the equivalent PLMN list.

e) Cell 2 and 3 are activated.

## 6.1.1.7.5 Test Requirements

1) In step c), the response from the UE shall be on Cell 1. The displayed PLMN shall be PLMN 1.

2) In step e), the UE shall perform a cell reselection and Location Update to PLMN 3, which is equivalent to PLMN1.

## 6.1.2 Cell selection and reselection

## 6.1.2.1 Cell reselection

## 6.1.2.1.1 Definition

Test to verify that the UE performs the cell reselection correctly for intra/inter-frequency cells if the serving cell becomes barred or  $S < 0$ .

#### 6.1.2.1.2—Conformance requirement

1.—When camped on a cell, the UE shall regularly search for a better cell according to the cell reselection criteria. If a better cell is found, that cell is selected. The change of cell may imply a change of RAT.

2.—A "suitable cell" is a cell on which the UE may camp on to obtain normal service. Such a cell shall fulfil all the following requirements:

2.1 The cell is part of the selected PLMN or of a PLMN considered as equivalent by the UE according to the information provided by the NAS.

2.2 The cell is not barred.

2.3 The cell is not part of the list of "forbidden LAs for roaming".

2.4 The cell selection criteria are fulfilled.

3.—When camped normally, the UE shall execute the cell reselection evaluation process on the following occasions/triggers:

3.1 UE internal triggers, so as to meet performance as specified in TS 25.133 for FDD mode and in TS 25.123 for TDD mode.

3.2 When information on the BCCH used for the cell reselection evaluation procedure has been modified.

4.—Cell Reselection Criteria:

4.1 The UE shall perform ranking of all cells that fulfil the S criterion.

4.2 The cells shall be ranked according to the R criteria. The best ranked cell is the cell with the highest R value. If an FDD cell is ranked as the best cell, the UE shall perform cell re-selection to that FDD cell. If a TDD cell is ranked as the best cell, the UE shall perform cell re-selection to that TDD cell.

4.3 In all cases, the UE shall reselect the new cell, only if the cell reselection criteria are fulfilled during a time interval T<sub>res</sub>.

4.4 The cell-ranking criterion R is derived from Q, Q<sub>hyst</sub>, Q<sub>offset</sub>, TEMP\_OFFSET and PENALTY\_TIME. However, TEMP\_OFFSET<sub>n</sub> and PENALTY\_TIME<sub>n</sub> are only applicable if the usage of HCS is indicated in system information.

5.—When cell status "barred" is indicated, the UE shall select another cell according to the following rule:

5.1 If the "Intra-frequency cell re-selection indicator" IE in Cell Access Restriction IE is set to value "allowed", the UE may select another cell on the same frequency if selection/re-selection criteria are fulfilled.

5.2 If the "Intra-frequency cell re-selection indicator" IE is set to "not allowed" the UE shall not re-select a cell on the same frequency as the barred cell. For emergency call, the Intra-frequency cell re-selection indicator IE shall be ignored, i.e. even if it is set to "not allowed" the UE may select another intra-frequency cell.

#### References

1.—TS 25.304, clause 5.2.1.

2.—TS 25.304, clause 4.3.

3.—TS 25.304, clause 5.2.5.1.

4.—TS 25.304, clause 5.2.6.1.4.

5.—TS 25.304, clause 5.3.1.1.

#### 6.1.2.1.3—Test purpose

1.—To verify that the UE performs cell reselection on the following occasions:

1.1 Serving cell becomes barred;

1.2  $S < 0$  for serving cell.

2. To verify conformance requirement 5.

NOTE: Reselection triggered by the cell becoming a part of a forbidden registration area is tested in clause 9.4.2.3 and clause 9.4.2.4.

6.1.2.1.4 Method of test

Initial conditions

Reselection,  $Q_{\text{hyst}}$ ,  $Q_{\text{offset}}$ ,  $\text{TEMP\_OFFSET}$  and  $\text{PENALTY\_TIME}$  are not used, so the cell-ranking criterion  $R$  equals  $\text{CPICH\_RSCP}$  for FDD cells, and  $\text{P-CCPCH\_RSCP}$  for TDD cells.

Step a-c (FDD):

| Parameter                                   | Unit         | Cell 1      | Cell 2      | Cell 3      |
|---------------------------------------------|--------------|-------------|-------------|-------------|
| Test Channel                                |              | 1           | 1           | 2           |
| $\text{CPICH\_Ec}$                          | dBm/3.84 MHz | -60         | -70         | -80         |
| $Q_{\text{rxlevmin}}$                       | dBm          | -115        | -115        | -115        |
| $S_{\text{rxlev}}^*$                        | dBm          | 55          | 45          | 35          |
| Intra-frequency cell re-selection indicator |              | Not Allowed | Not Allowed | Not Allowed |
| CellBarred                                  |              | 0           | 0           | 0           |

Step a-c (TDD):

| Parameter              | Unit | Cell 1 | Cell 2 | Cell 3 |
|------------------------|------|--------|--------|--------|
| $\text{P-CCPCH\_RSCP}$ | dBm  | -69    | -71    | -73    |
| $Q_{\text{rxlevmin}}$  | dBm  | -103   | -103   | -103   |
| $S_{\text{rxlev}}^*$   | dB   | 34     | 32     | 30     |

Step d-f:

|            |  |       |   |   |
|------------|--|-------|---|---|
| CellBarred |  | 0 → 1 | 0 | 0 |
|------------|--|-------|---|---|

Step g-h:

|                                             |  |                       |                       |                       |
|---------------------------------------------|--|-----------------------|-----------------------|-----------------------|
| Intra-frequency cell re-selection indicator |  | Not Allowed → Allowed | Not Allowed → Allowed | Not Allowed → Allowed |
|---------------------------------------------|--|-----------------------|-----------------------|-----------------------|

Step i (FDD):

|                       |     |            |      |      |
|-----------------------|-----|------------|------|------|
| $Q_{\text{rxlevmin}}$ | dBm | -115 → -50 | -115 | -115 |
|-----------------------|-----|------------|------|------|



|         |     |          |    |    |
|---------|-----|----------|----|----|
| Srxlev* | dBm | 55 → -10 | 45 | 35 |
|---------|-----|----------|----|----|

Step i (TDD):

|           |  |            |      |      |
|-----------|--|------------|------|------|
| Qrxlevmin |  | -103 → -68 | -103 | -103 |
| Srxlev*   |  | 34 → -6    | 32   | 30   |

#### Test procedure

Method B is applied.

- a) The SS activates Cell 1-3 and monitors them for random access requests from the UE.
- b) The UE is switched on.
- c) The SS waits for random access requests from the UE.
- d) The SS sets Cell 1 to be barred.
- e) The SS waits for random access requests from the UE.
- f) The SS sets "Intra-frequency cell re-selection indicator" to "Allowed".
- g) The SS waits for random access requests from the UE.
- h) The stored information cell selection list in the UE is deleted and the UE is switched off.
- i) Step a-e) is repeated except that in step d) for FDD cells, Qrxlevmin is increased to -50 dBm, or in step d) for TDD cells, Qrxlevmin is increased to -68, so S will become negative instead of the cell being barred while maintaining the same RF level.

#### 6.1.2.1.5 Test requirements

- 1) In step c), after the UE has responded on Cell 1, it shall not respond on any other cell within 1 min.
- 2) In step e), the UE shall respond on Cell 3.
- 3) In step g), the UE shall respond on Cell 2.
- 4) In step i), the UE shall respond on Cell 2.

#### 6.1.2.2 Cell reselection using Qhyst, Qoffset and Treselection

##### 6.1.2.2.1 Definition

Test to verify that the UE performs the cell reselection correctly if system information parameters Qoffset, Qhyst and Treselection are applied for non-hierarchical cell structures. TEMP\_OFFSET and PENALTY\_TIME are only applicable when HCS is applied and are tested in clauses 6.1.2.4 and 6.1.2.5.

##### 6.1.2.2.2 Conformance requirement

1. When camped normally, the UE shall execute the cell reselection evaluation process on the following occasions/triggers:

1.1 UE internal triggers, so as to meet performance as specified in TS 25.133 for FDD mode and in TS 25.123 for TDD mode.

1.2 When information on the BCCH used for the cell reselection evaluation procedure has been modified.

2. Cell Reselection Criteria:

2.1 The UE shall perform ranking of all cells that fulfil the S criterion.

2.2 The cells shall be ranked according to the R criteria. The best ranked cell is the cell with the highest R value. If an FDD cell is ranked as the best cell, the UE shall perform cell re-selection to that FDD cell. If a TDD cell is ranked as the best cell, the UE shall perform cell re-selection to that TDD cell.

2.3 In all cases, the UE shall reselect the new cell, only if the cell reselection criteria are fulfilled during a time interval Treselection.

2.4 The cell-ranking criterion R is derived from Q, Qhyst, Qoffset, TEMP\_OFFSET and PENALTY\_TIME. However, TEMP\_OFFSETn and PENALTY\_TIMEn are only applicable if the usage of HCS is indicated in system information.

#### References

1. TS 25.304, clause 5.2.5.1.

2. TS 25.304, clause 5.2.6.1.4.

#### 6.1.2.2.3 Test purpose

1. To verify that the UE calculates R from Qhyst and Qoffset and that the modification of these parameters on the BCCH triggers the cell reselection evaluation process. TEMP\_OFFSET and PENALTY\_TIME are not applied.

2. To verify that the UE reselects the new cell, if the cell reselection criteria are fulfilled during a time interval Treselection.

#### 6.1.2.2.4 Method of test

##### Initial conditions

For FDD only:

Step a-e:

| Parameter        | Unit         | Cell 1 | Cell 2 |
|------------------|--------------|--------|--------|
| CPICH_Ec         | dBm/3.84 MHz | -60    | -70    |
| Qhyst1s          | dBm          | 20     |        |
| R <sub>s</sub> * | dBm          | -40    |        |
| R <sub>n</sub> * | dBm          | -70    |        |

Step d-e:

|                  |              |           |           |
|------------------|--------------|-----------|-----------|
| CPICH_Ec         | dBm/3.84 MHz | -60 → -70 | -70 → -60 |
| R <sub>s</sub> * | dBm          | -40 → -50 |           |
| R <sub>n</sub> * | dBm          | -70 → -60 |           |

Step f-g:

|                  |     |           |  |
|------------------|-----|-----------|--|
| Qhyst1s          | dBm | 20 → 0    |  |
| R <sub>s</sub> * | dBm | -50 → -70 |  |
| R <sub>n</sub> * | dBm | -60       |  |

Step h-j:

|                             |              |     |     |
|-----------------------------|--------------|-----|-----|
| CPICH_Ec                    | dBm/3.84 MHz | -60 | -70 |
| Qoffset1 <sub>s,n</sub>     | dBm          | 20  |     |
| R <sub>s</sub> <sup>*</sup> | dBm          | -60 |     |
| R <sub>n</sub> <sup>*</sup> | dBm          | -90 |     |

Step k-l:

|                             |              |           |           |
|-----------------------------|--------------|-----------|-----------|
| CPICH_Ec                    | dBm/3.84 MHz | -60 → -70 | -70 → -60 |
| R <sub>s</sub> <sup>*</sup> | dBm          | -60 → -70 |           |
| R <sub>n</sub> <sup>*</sup> | dBm          | -90 → -80 |           |

Step m-n:

|                             |     |           |  |
|-----------------------------|-----|-----------|--|
| Qoffset1 <sub>s,n</sub>     | dBm | 20 → 0    |  |
| R <sub>s</sub> <sup>*</sup> | dBm | -70       |  |
| R <sub>n</sub> <sup>*</sup> | dBm | -80 → -60 |  |

Step o-p:

|                           |   |    |  |
|---------------------------|---|----|--|
| Treselection <sub>s</sub> | s | 30 |  |
|---------------------------|---|----|--|

For TDD-only:

Step a-c:

| Parameter                   | Unit | Cell 1 | Cell 2 |
|-----------------------------|------|--------|--------|
| P-CCPCH RSCP                | dBm  | -68    | -71    |
| Qhyst1 <sub>s</sub>         | dB   | 10     |        |
| R <sub>s</sub> <sup>*</sup> | dB   | -58    |        |
| R <sub>n</sub> <sup>*</sup> | dB   | -71    |        |

Step d-e:

|                             |     |           |           |
|-----------------------------|-----|-----------|-----------|
| P-CCPCH RSCP                | dBm | -68 → -71 | -71 → -68 |
| R <sub>s</sub> <sup>*</sup> | dB  | -58 → -61 |           |
| R <sub>n</sub> <sup>*</sup> | dB  | -71 → -68 |           |

Step f-g:

|                             |    |           |  |
|-----------------------------|----|-----------|--|
| Qhyst1 <sub>s</sub>         | dB | 10 → 0    |  |
| R <sub>s</sub> <sup>*</sup> | dB | -61 → -71 |  |
| R <sub>n</sub> <sup>*</sup> | dB | -68       |  |

Step h-j:

|              |     |     |     |
|--------------|-----|-----|-----|
| P-CCPCH RSCP | dBm | -68 | -71 |
|--------------|-----|-----|-----|

|                           |    |     |  |
|---------------------------|----|-----|--|
| $Q_{\text{offset}_{s,n}}$ | dB | 10  |  |
| $R_s^*$                   | dB | -68 |  |
| $R_n^*$                   | dB | -81 |  |

Step k-l:

|              |     |           |           |
|--------------|-----|-----------|-----------|
| P-CCPCH RSCP | dBm | -68 → -71 | -71 → -68 |
| $R_s^*$      | dB  | -68 → -71 |           |
| $R_n^*$      | dB  | -81 → -78 |           |

Step m-n:

|                           |    |           |  |
|---------------------------|----|-----------|--|
| $Q_{\text{offset}_{s,n}}$ | dB | 10 → 0    |  |
| $R_s^*$                   | dB | -71       |  |
| $R_n^*$                   | dB | -78 → -68 |  |

Step o-p:

|                            |   |    |  |
|----------------------------|---|----|--|
| $T_{\text{reselection}_s}$ | s | 30 |  |
|----------------------------|---|----|--|

#### Test procedure

Method B is applied.

- a) The SS activates Cell 1 and 2 and monitors them for random access requests from the UE.
- b) The UE is switched on.
- c) The SS waits to see if there is any random access requests from the UE.
- d) The SS changes the level of Cell 1 and 2 and waits for 10 s (TS 25.133, A.4.2.1.2 for FDD mode and TS 25.123, A.4.2.1.2 for TDD mode).
- e) The SS waits for random access requests from the UE.
- f) The SS resets  $Q_{\text{hyst}}$  for Cell 1.
- g) The SS waits for random access requests from the UE.
- h) The stored information cell selection list in the UE is deleted and the UE is switched off.
- i) The UE is switched on.
- j) The SS waits to see if there is any random access requests from the UE.
- k) The SS changes the level of Cell 1 and 2 and waits for 10 s (TS 25.133, clause A.4.2.1.2 for FDD mode and TS 25.123, clause A.4.2.1.2 for TDD mode).
- l) The SS waits for random access requests from the UE.
- m) The SS resets  $Q_{\text{offset}}$  for Cell 1.
- n) The SS waits for random access requests from the UE.
- o) Step h-n) is repeated except that  $T_{\text{reselection}}$  is 30 s

#### 6.1.2.2.5 Test Requirements

- 1) In step c), after the UE has responded on Cell 1, it shall not respond on any other cell within 1 min.

- 2) In step e), the UE shall keep responding on Cell 1.
- 3) In step g), the UE shall respond on Cell 2.
- 4) In step j), the UE shall select a cell to camp on and eventually make a reselection to Cell 1.
- 5) In step l), the UE shall keep responding on Cell 1.
- 6) In step n), the UE shall respond on Cell 2.
- 7) In step o), the UE shall respond as in previous steps except that when reselecting to Cell 2, there shall be no response from the UE on Cell 2 within 28 s of broadcasting Qoffset but the UE shall respond on Cell 2 within 34 s.

NOTE:— Minimum time set by Treselection— 2 s tolerance. Maximum time set by Treselection + 1 280 msec. for DRX cycle + 2 s tolerance

#### 6.1.2.3 HCS Cell reselection

##### 6.1.2.3.1 Definition

Test to verify that the UE performs the cell reselection correctly for hierarchical cell structures. This shall be done according to the HCS priority, the received signal quality value Q and the quality level threshold criterion H.

##### 6.1.2.3.2 Conformance requirement

1. When camped normally, the UE shall execute the cell reselection evaluation process on the following occasions/triggers:

1.1 UE internal triggers, so as to meet performance as specified in TS 25.133 for FDD mode and in TS 25.123 for TDD mode.

1.2 When information on the BCCH used for the cell reselection evaluation procedure has been modified.

2. Cell Reselection Criteria for hierarchical cells:

2.1 The quality level threshold criterion H for hierarchical cell structures is used to determine whether prioritised ranking according to hierarchical cell re-selection rules shall apply, and is calculated from the Q, Qhcs, TEMP\_OFFSET and PENALTY\_TIME parameters.

2.2 The UE shall perform ranking of all cells that fulfil the S criterion among all cells that have the highest HCS\_PRIO among those cells that fulfil the criterion  $H \geq 0$ .

2.3 The cells shall be ranked according to the R criteria. The best ranked cell is the cell with the highest R value. If an FDD cell is ranked as the best cell, the UE shall perform cell re-selection to that FDD cell. If a TDD cell is ranked as the best cell, the UE shall perform cell re-selection to that TDD cell.

2.4 In all cases, the UE shall reselect the new cell, only if the cell reselection criteria are fulfilled during a time interval Treselection.

2.5 The cell-ranking criterion R is derived from Q, Qhyst, Qoffset, TEMP\_OFFSET, PENALTY\_TIME.

#### References

- 1. TS 25.304, clause 5.2.2.
- 2. TS 25.304, clause 5.2.6.1.4.

##### 6.1.2.3.3 Test purpose

- 1. Verify that the UE ignores cells with  $H < 0$  for reselection and that H is calculated from Qhcs. The modification of this parameter on the BCCH shall trigger the cell reselection evaluation process.
- 2. Verify that the UE ranks cells based on both HCS priority and R. Qhyst, Qoffset, TEMP\_OFFSET, PENALTY\_TIME and Treselection are not applied so R equals CPICH\_RSCP for FDD cells, and P-CCPCH\_RSCP for TDD cells.

##### 6.1.2.3.4 Method of test

Initial conditions

For FDD only:

Step a-c:

| Parameter                   | Unit         | Cell 1 | Cell 2 | Cell 3 |
|-----------------------------|--------------|--------|--------|--------|
| CPICH_Ec                    | dBm/3.84 MHz | -60    | -65    | -70    |
| HCS_priority                |              | 6      | 7      | 7      |
| Qhcs <sub>s</sub>           | dBm          | -80    | -50    | -50    |
| H <sub>s</sub> <sup>*</sup> | dBm          | 20     | -15    | -20    |

Step d-e:

|                             |     |     |     |           |
|-----------------------------|-----|-----|-----|-----------|
| Qhcs <sub>s</sub>           | dBm | -80 | -50 | -50 → -80 |
| H <sub>s</sub> <sup>*</sup> | dBm | 20  | -15 | -20 → 10  |

Step f-g:

|                             |     |     |           |     |
|-----------------------------|-----|-----|-----------|-----|
| Qhcs <sub>s</sub>           | dBm | -80 | -50 → -80 | -80 |
| H <sub>s</sub> <sup>*</sup> | dBm | 20  | -15 → 15  | 10  |

For TDD only:

Step a-c:

| Parameter                   | Unit | Cell 1 | Cell 2 | Cell 3 |
|-----------------------------|------|--------|--------|--------|
| P-CCPCH_RSCP                | dBm  | -69    | -71    | -73    |
| HCS_priority                |      | 6      | 7      | 7      |
| Qhcs <sub>s</sub>           | dB   | -30    | -10    | -10    |
| H <sub>s</sub> <sup>*</sup> | dB   | -39    | -61    | -63    |

Step d-e:

|                             |    |     |     |           |
|-----------------------------|----|-----|-----|-----------|
| Qhcs <sub>s</sub>           | dB | -30 | -10 | -10 → -30 |
| H <sub>s</sub> <sup>*</sup> | dB | -39 | -61 | -63 → -43 |

Step f-g:

|                             |    |     |           |     |
|-----------------------------|----|-----|-----------|-----|
| Qhcs <sub>s</sub>           | dB | -30 | -10 → -30 | -30 |
| H <sub>s</sub> <sup>*</sup> | dB | -39 | -61 → -41 | -43 |

Test procedure

Method B is applied.

- The SS activates the cells 1-3 and monitors them for random access requests from the UE.
- The UE is switched on.
- The SS waits for random access requests from the UE.
- The SS changes Qhcs for Cell 3.

- e) The SS waits for random access requests from the UE.
- f) The SS changes Qhcs for Cell 2.
- g) The SS waits for random access requests from the UE.

#### 6.1.2.3.5 Test requirements

- 1) In step c), after the UE has responded on Cell 1, it shall not respond on any other cell within 1 min.
- 2) In step e), the UE shall respond on Cell 3.
- 3) In step g), the UE shall respond on Cell 2.

#### 6.1.2.4 HCS Cell reselection using reselection timing parameters for the H criterion

##### 6.1.2.4.1 Definition

Test to verify that the UE performs the cell reselection correctly for hierarchical cell structures using TEMP\_OFFSET and PENALTY\_TIME applied to the H criterion.

##### 6.1.2.4.2 Conformance requirement

1. When camped normally, the UE shall execute the cell reselection evaluation process on the following occasions/triggers:

1.1 UE internal triggers, so as to meet performance as specified in TS 25.133 for FDD mode and in TS 25.123 for TDD mode.

1.2 When information on the BCCH used for the cell reselection evaluation procedure has been modified.

2. Cell Reselection Criteria for hierarchical cells:

2.1 The quality level threshold criterion H for hierarchical cell structures is used to determine whether prioritised ranking according to hierarchical cell re-selection rules shall apply, and is calculated from the Q, Qhcs, TEMP\_OFFSET and PENALTY\_TIME parameters.

2.2 The UE shall perform ranking of all cells that fulfil the S criterion among all cells that have the highest HCS\_Prio among those cells that fulfil the criterion  $H \geq 0$ .

2.3 The cells shall be ranked according to the R criteria. The best ranked cell is the cell with the highest R value. If an FDD cell is ranked as the best cell, the UE shall perform cell re-selection to that FDD cell. If a TDD cell is ranked as the best cell, the UE shall perform cell re-selection to that TDD cell.

2.4 In all cases, the UE shall reselect the new cell, only if the cell reselection criteria are fulfilled during a time interval T<sub>reselction</sub>.

2.5 The cell-ranking criterion R is derived from Q, Q<sub>hyst</sub>, Q<sub>offset</sub>, TEMP\_OFFSET and PENALTY\_TIME.

3. TEMP\_OFFSET<sub>n</sub> applies an offset to the H criteria for the duration of PENALTY\_TIME<sub>n</sub> after the timer T<sub>n</sub> has started for that cell. T<sub>n</sub> shall be started from zero when  $Q_{meas,n} > Q_{hcs,n}$ . TEMP\_OFFSET is only applied to the H criteria if the cells have different HCS priorities.

#### References

- 1. TS 25.304, clause 5.2.2.
- 2,3. TS 25.304, clause 5.2.6.1.4.

#### 6.1.2.4.3 Test purpose

1. Verify that TEMP\_OFFSET is applied to the H criterion for a period of PENALTY\_TIME and that the timer is started when  $Q_{meas,n} > Q_{hcs,n}$  if serving and neighbour cell have different HCS priorities.

#### 6.1.2.4.4 Method of test

#### Initial conditions

For FDD only:

Step a-c:

| Parameter                   | Unit         | Cell 1 | Cell 2 | Cell 3 |
|-----------------------------|--------------|--------|--------|--------|
| CPICH_Ec                    | dBm/3.84 MHz | -60    | -70    | -70    |
| HCS-priority                |              | 2      | 4      | 7      |
| $Q_{hcs_s}$                 | dBm          | -80    |        |        |
| $Q_{hcs_{n=2}}$             | dBm          | -50    |        |        |
| $Q_{hcs_{n=3}}$             | dBm          | -50    |        |        |
| TEMP_OFFSET1 <sub>n=2</sub> | dBm          | 30     |        |        |
| TEMP_OFFSET1 <sub>n=3</sub> | dBm          | 30     |        |        |
| $H_s^*$                     | dBm          | 20     |        |        |
| $H_{n=2}^*$                 | dBm          | -20    |        |        |
| $H_{n=3}^*$                 | dBm          | -20    |        |        |
| PENALTY_TIME <sub>n=2</sub> | sec          | 40     |        |        |
| PENALTY_TIME <sub>n=3</sub> | sec          | 60     |        |        |

Step d-e:

|                 |     |                            |  |  |
|-----------------|-----|----------------------------|--|--|
| $Q_{hcs_s}$     | dBm | -80                        |  |  |
| $Q_{hcs_{n=2}}$ | dBm | -50 → -80                  |  |  |
| $Q_{hcs_{n=3}}$ | dBm | -50 → -80                  |  |  |
| $H_s^*$         | dBm | 20                         |  |  |
| $H_{n=2}^*$     | dBm | -20 → 10<br>(after 40 sec) |  |  |
| $H_{n=3}^*$     | dBm | -20 → 10<br>(after 60 sec) |  |  |

For TDD only:

Step a-c:

| Parameter       | Unit | Cell 1 | Cell 2 | Cell 3 |
|-----------------|------|--------|--------|--------|
| P-CCPCH-RSCP    | dBm  | -69    | -73    | -73    |
| HCS-priority    |      | 2      | 4      | 7      |
| $Q_{hcs_s}$     | dB   | -20    |        |        |
| $Q_{hcs_{n=2}}$ | dB   | -10    |        |        |



|                       |     |     |  |  |
|-----------------------|-----|-----|--|--|
| $Q_{hcs_{n=3}}$       | dB  | -10 |  |  |
| $TEMP\_OFFSET2_{n=2}$ | dB  | 10  |  |  |
| $TEMP\_OFFSET2_{n=3}$ | dB  | 10  |  |  |
| $H_s^*$               | dB  | -49 |  |  |
| $H_{n=2}^*$           | dB  | -63 |  |  |
| $H_{n=3}^*$           | dB  | -63 |  |  |
| $PENALTY\_TIME_{n=2}$ | sec | 40  |  |  |
| $PENALTY\_TIME_{n=3}$ | sec | 60  |  |  |

Step d-e:

|                 |    |                             |  |  |
|-----------------|----|-----------------------------|--|--|
| $Q_{hcs_s}$     | dB | -20                         |  |  |
| $Q_{hcs_{n=2}}$ | dB | -10 → -20                   |  |  |
| $Q_{hcs_{n=3}}$ | dB | -10 → -20                   |  |  |
| $H_s^*$         | dB | -49                         |  |  |
| $H_{n=2}^*$     | dB | -63 → -53<br>(after 40 sec) |  |  |
| $H_{n=3}^*$     | dB | -63 → -53<br>(after 60 sec) |  |  |

Test procedure

Method B is applied.

- a) The SS activates the cells 1-3 and monitors them for random access requests from the UE.
- b) The UE is switched on.
- c) The SS waits for random access requests from the UE.
- d) The SS changes  $Q_{hcs}$  for Cell 2 and 3.
- e) The SS waits for random access requests from the UE.

#### 6.1.2.4.5 Test requirements

- 1) In step c), after the UE has responded on Cell 1, it shall not respond on any other cell within 1 min.
- 2) In step e), there shall be no response from the UE on Cell 2 within 38 s of changing the parameters but the UE shall respond on Cell 2 within 44 s. There shall be no response from the UE on Cell 3 within 58 s of changing the parameters but the UE shall respond on Cell 3 within 64 s.

NOTE: — Minimum time set by  $PENALTY\_TIME$  (cell 2) – 2 s tolerance. Maximum time set by  $PENALTY\_TIME$  (cell 2) + 1 280 msec. for DRX cycle + 2 s tolerance. Same calculation for Cell 3.

#### 6.1.2.5 HCS Cell reselection using reselection timing parameters for the R criterion

##### 6.1.2.5.1 Definition

Test to verify that the UE performs the cell reselection correctly for hierarchical cell structures using TEMP\_OFFSET and PENALTY\_TIME applied to the R criterion.

#### 6.1.2.5.2—Conformance requirement

1.—When camped normally, the UE shall execute the cell reselection evaluation process on the following occasions/triggers:

1.1 UE internal triggers, so as to meet performance as specified in TS 25.133 for FDD mode and in TS 25.123 for TDD mode.

1.2 When information on the BCCH used for the cell reselection evaluation procedure has been modified.

2.—Cell Reselection Criteria for hierarchical cells:

2.1 The quality level threshold criterion H for hierarchical cell structures is used to determine whether prioritised ranking according to hierarchical cell re-selection rules shall apply, and is calculated from the  $Q$ ,  $Q_{hcs}$ , TEMP\_OFFSET and PENALTY\_TIME parameters.

2.2 The UE shall perform ranking of all cells that fulfil the S criterion among all cells, not considering HCS priority levels, if no cell fulfil the criterion  $H \geq 0$ .

2.3 The cells shall be ranked according to the R criteria. The best ranked cell is the cell with the highest R value. If a FDD cell is ranked as the best cell, the UE shall perform cell re-selection to that FDD cell. If a TDD cell is ranked as the best cell, the UE shall perform cell re-selection to that TDD cell.

2.4 In all cases, the UE shall reselect the new cell, only if the cell reselection criteria are fulfilled during a time interval Treselection.

2.5 The cell-ranking criterion R is derived from  $Q$ ,  $Q_{hyst}$ ,  $Q_{offset}$ , TEMP\_OFFSET, PENALTY\_TIME.

3.—TEMP\_OFFSET<sub>n</sub> applies an offset to the R criteria for the duration of PENALTY\_TIME<sub>n</sub> after the timer T<sub>n</sub> has started for that cell. T<sub>n</sub> shall be started from zero when  $Q_{meas,n} > Q_{meas,s} + Q_{offset2_{s,n}}$ . TEMP\_OFFSET is only applied to the R criteria if the cells have identical priorities.

#### References

1.—TS 25.304, clause 5.2.2.

2,3.—TS 25.304, clause 5.2.6.1.4.

#### 6.1.2.5.3—Test purpose

1.—Verify that TEMP\_OFFSET is applied to the R criterion for a period of PENALTY\_TIME and that the timer is started when  $Q_{meas,n} > Q_{meas,s} + Q_{offset2_{s,n}}$  if serving and neighbour cell have identical HCS priorities.

#### 6.1.2.5.4—Method of test

##### Initial conditions

For FDD only:

Step a-c:

| Parameter                   | Unit         | Cell 1 | Cell 2 | Cell 3 |
|-----------------------------|--------------|--------|--------|--------|
| CPICH_Ec                    | dBm/3.84 MHz | -60    | -70    | -70    |
| HCS priority                |              | 1      | 1      | 1      |
| TEMP_OFFSET2 <sub>n=2</sub> | dBm          | 20     |        |        |
| TEMP_OFFSET2 <sub>n=3</sub> | dBm          | 20     |        |        |
| PENALTY_TIME <sub>n=2</sub> | sec          | 40     |        |        |

|                             |     |     |  |  |
|-----------------------------|-----|-----|--|--|
| PENALTY_TIME <sub>n=3</sub> | sec | 60  |  |  |
| H <sub>s</sub> *            | dBm | -60 |  |  |
| H <sub>n=2</sub> *          | dBm | -70 |  |  |
| H <sub>n=3</sub> *          | dBm | -70 |  |  |
| R <sub>s</sub> *            | dBm | -60 |  |  |
| R <sub>n=2</sub> *          | dBm | -70 |  |  |
| R <sub>n=3</sub> *          | dBm | -70 |  |  |

Step d-e:

|                    |              |                                        |                      |                      |
|--------------------|--------------|----------------------------------------|----------------------|----------------------|
| CPICH_Ec           | dBm/3.84 MHz | <del>-60</del> → -70                   | <del>-70</del> → -65 | <del>-70</del> → -60 |
| R <sub>s</sub> *   | dBm          | -70                                    |                      |                      |
| R <sub>n=2</sub> * | dBm          | <del>-85</del> → -65<br>(after 40 sec) |                      |                      |
| R <sub>n=3</sub> * | dBm          | <del>-80</del> → -60<br>(after 60 sec) |                      |                      |

For TDD only:

Step a-c:

| Parameter          | Unit | Cell 1 | Cell 2 | Cell 3 |
|--------------------|------|--------|--------|--------|
| P-CCPCH RSCP       | dBm  | -69    | -73    | -73    |
| HCS priority       |      | 1      | 1      | 1      |
| H <sub>s</sub> *   | dB   | -69    |        |        |
| H <sub>n=2</sub> * | dB   | -73    |        |        |
| H <sub>n=3</sub> * | dB   | -73    |        |        |
| R <sub>s</sub> *   | dB   | -69    |        |        |
| R <sub>n=2</sub> * | dB   | -73    |        |        |
| R <sub>n=3</sub> * | dB   | -73    |        |        |

Step d-e:

|                             |    |         |  |  |
|-----------------------------|----|---------|--|--|
| Qoffset1 <sub>s,n=2</sub>   | dB | 0 → -10 |  |  |
| Qoffset1 <sub>s,n=3</sub>   | dB | 0 → -10 |  |  |
| TEMP_OFFSET1 <sub>n=2</sub> | dB | 10      |  |  |
| TEMP_OFFSET1 <sub>n=3</sub> | dB | 10      |  |  |

|                                        |                |                                                   |  |  |
|----------------------------------------|----------------|---------------------------------------------------|--|--|
| <del>PENALTY_TIME<sub>n=2</sub></del>  | <del>sec</del> | <del>40</del>                                     |  |  |
| <del>PENALTY_TIME<sub>n=3</sub></del>  | <del>sec</del> | <del>60</del>                                     |  |  |
| <del>R<sub>s</sub><sup>*</sup></del>   | <del>dB</del>  | <del>-13</del>                                    |  |  |
| <del>R<sub>n=2</sub><sup>*</sup></del> | <del>dB</del>  | <del>-73 → -63</del><br><del>(after 40 sec)</del> |  |  |
| <del>R<sub>n=3</sub><sup>*</sup></del> | <del>dB</del>  | <del>-73 → -63</del><br><del>(after 60 sec)</del> |  |  |

### Test procedure

Method B is applied.

- ~~The SS activates the cells 1-3 and monitors them for random access requests from the UE.~~
- ~~The UE is switched on.~~
- ~~The SS waits for random access requests from the UE.~~
- ~~The SS changes the level of Cell 1-3.~~
- ~~The SS waits for random access requests from the UE.~~

#### 6.1.2.5.5 Test requirements

- ~~In step c), after the UE has responded on Cell 1, it shall not respond on any other cell within 1 min.~~
- ~~In step c), there shall be no response from the UE on Cell 2 within 38 s of changing the parameters but the UE shall respond on Cell 2 within 50 s. There shall be no response from the UE on Cell 3 within 58 s of changing the parameters but the UE shall respond on Cell 3 within 70 s.~~

NOTE: — Minimum time set by PENALTY\_TIME (cell 2) — 2 s tolerance. Maximum time set by PENALTY\_TIME (cell 2) + 6.4 s ( $T_{\text{evaluateFDD}}$  from TS 25.133, table 4.1 for FDD mode and  $T_{\text{evaluateTDD}}$  from TS 25.123, table 4.1 for TDD mode) + 1 280 msec. for system info scheduling + 2 s tolerance. Same calculation for Cell 3.

#### 6.1.2.6 Emergency calls

##### 6.1.2.6.1 Definition

Test to verify that the UE shall be able to initiate emergency calls when no suitable cells of the selected PLMN are available, but at least one acceptable cell is available.

##### 6.1.2.6.2 Conformance requirement

###### 1. Acceptable cell:

An "acceptable cell" is a cell on which the UE may camp to obtain limited service (originate emergency calls). Such a cell shall fulfil the following requirements, which is the minimum set of requirements to initiate an emergency call in a UTRAN network:

1.1 The cell is not barred;

1.2 The cell selection criteria are fulfilled.

2. A "suitable cell" is a cell on which the UE may camp on to obtain normal service. Such a cell shall fulfil all the following requirements:

2.1 The cell is part of the selected PLMN or, of a PLMN considered as equivalent by the UE according to the information provided by the NAS.

2.2 The cell is not barred.

~~2.3 The cell is not part of the list of "forbidden LAs for roaming".~~

~~2.4 The cell selection criteria are fulfilled.~~

~~3. If the UE is unable to find any suitable cell of selected PLMN the UE shall enter the *Any cell selection* state.~~

~~4. *Any Cell Selection State*: In this state, the UE shall attempt to find an acceptable cell of an any PLMN to camp on, trying all RATs that are supported by the UE and searching first for a high quality cell. The UE, which is not camped on any cell, shall stay in this state until an acceptable cell is found.~~

~~5. *Camped on Any Cell State*: In this state the UE obtains limited service. The UE shall regularly attempt to find a suitable cell of the selected PLMN, trying RATs that are supported by the UE. If a suitable cell is found, this causes an exit to the *Camped normally State*.~~

~~6. In the *Camped on Any Cell State*, the UE shall perform the cell reselection evaluation process on the following occasions/triggers:~~

~~6.1 UE internal triggers, so as to meet performance as specified in TS 25.133 for FDD mode and TS 25.123 for TDD mode.~~

~~6.2 When information on the BCCH used for the cell reselection evaluation procedure has been modified.~~

#### References

~~1. TS 25.304, clause 4.3.~~

~~2. TS 25.304, clause 4.3.~~

~~3. TS 25.304, clause 5.2.2.1.~~

~~4. TS 25.304, clause 5.2.8.~~

~~5. TS 25.304, clause 5.2.2.5.~~

~~6. TS 25.304, clause 5.2.9.1.~~

#### ~~6.1.2.6.3 Test purpose~~

~~1. To verify that the UE shall be able to initiate emergency calls when no suitable cells of the selected PLMN are available, but at least one acceptable cell is available.~~

~~2. To verify that the UE selects a cell with  $S > 0$  and  $\text{CellBarred} = 0$  (acceptable cell) when no suitable cells of the selected PLMN are available.~~

~~3. To verify that the UE ranks the acceptable cells according to the cell ranking criterion  $R$  which in this test case equals  $Q$  as  $Q_{\text{hyst}}$ ,  $Q_{\text{offset}}$ ,  $\text{TEMP\_OFFSET}$  and  $\text{PENALTY\_TIME}$  parameters are not used. Treselection is not used either.~~

#### ~~6.1.2.6.4 Method of test~~

##### Initial conditions

~~In step a-d, Cell 1 and 2 are neither suitable nor acceptable cells. Cell 3 is an acceptable cell but not suitable.~~

~~In step e-f, both Cell 1 and 3 are acceptable cells.~~

~~Step a-d:~~

~~For FDD only:~~

| Parameter | Unit         | Cell 1 | Cell 2 | Cell 3 |
|-----------|--------------|--------|--------|--------|
| CPICH_Ec  | dBm/3.84 MHz | -65    | -60    | -70    |
| Qrxlevmin | dBm          | -80    | -50    | -80    |

|            |     |           |           |           |
|------------|-----|-----------|-----------|-----------|
| Srxlev*    | dBm | 15        | -10       | 10        |
| CellBarred |     | 1         | 0         | 0         |
| PLMN       |     | forbidden | forbidden | forbidden |

For TDD only:

|              |      |           |           |           |
|--------------|------|-----------|-----------|-----------|
| Parameter    | Unit | Cell 1    | Cell 2    | Cell 3    |
| P-CCPCH RSCP | dBm  | -69       | -77       | -71       |
| CellBarred   |      | 1         | 0         | 0         |
| PLMN         |      | forbidden | forbidden | forbidden |

Step e-f:

|            |  |     |   |   |
|------------|--|-----|---|---|
| CellBarred |  | 1→0 | 0 | 0 |
|------------|--|-----|---|---|

NOTE: — All the BCCH cells belong to the same PLMN, which is not the UE's home PLMN and is in the USIM's forbidden PLMN's list.

Test procedure

Method C is applied.

- a) The SS activates the cells and monitors them for random access requests from the UE.
- b) The UE is switched on.
- c) 50 s after switch on, an emergency call is initiated on the UE.
- d) The SS waits for random access request from the UE.
- e) The SS changes the CellBarred of Cell 1 to 0.
- f) After 30 s an emergency call is initiated on the UE.
- g) The SS waits for random access request from the UE.

#### 6.1.2.6.5 Test requirements

- 1) In step d), the first access from the UE shall be on Cell 3.
- 2) In step g), the first access from the UE shall be on Cell 1.

#### 6.1.2.7 Emergency calls; Intra-frequency cell "Not allowed"

##### 6.1.2.7.1 Definition

Test to verify that for emergency call and cell status "barred", the Intra-frequency cell re-selection indicator IE is ignored, i.e. even if it is set to "not allowed" the UE may select another intra-frequency cell.

##### 6.1.2.7.2 Conformance requirement

- 1. When cell status "barred" is indicated:

— The UE is not permitted to select/re-select this cell, not even for emergency calls.

— The UE shall select another cell according to the following rule:

~~— If the "Intra-frequency cell re-selection indicator" IE is set to "not allowed" the UE shall not re-select a cell on the same frequency as the barred cell. For emergency call, the Intra-frequency cell re-selection indicator IE" shall be ignored, i.e. even if it is set to "not allowed" the UE may select another intra-frequency cell.~~

#### References

1. ~~TS 25.304, clause 5.3.1.1.~~

#### 6.1.2.7.3 Test purpose

~~To verify that for emergency call and cell status "barred", the Intra-frequency cell re-selection indicator IE is ignored, i.e. even if it is set to "not allowed" the UE may select another intra-frequency cell.~~

#### 6.1.2.7.4 Method of test

##### Initial conditions

~~Cell 1 and 2 are on the same carrier frequency.~~

~~Step a-c:~~

~~For FDD only:~~

| Parameter                                   | Unit         | Cell 1      | Cell 2      |
|---------------------------------------------|--------------|-------------|-------------|
| CPICH_Ec                                    | dBm/3.84 MHz | -60         | -70         |
| Intra-frequency cell re-selection indicator |              | Not allowed | Not allowed |
| CellBarred                                  |              | 0           | 0           |

~~For TDD only:~~

| Parameter    | Unit | Cell 1 | Cell 2 |
|--------------|------|--------|--------|
| P-CCPCH-RSCP | dBm  | -77    | -69    |
| CellBarred   | dBm  | 0      | 0      |

~~Step d-i:~~

|            |  |       |   |
|------------|--|-------|---|
| CellBarred |  | 0 → 1 | 0 |
|------------|--|-------|---|

#### Test procedure

~~Method C is applied.~~

- ~~a) The SS activates the cells and monitors them for any random access requests from the UE.~~
- ~~b) The UE is switched on.~~
- ~~c) The SS waits for random access request from the UE.~~
- ~~d) The SS sets Cell 1 to be barred.~~
- ~~e) The SS waits to see if there is any random access request from the UE.~~
- ~~f) By MMI, an attempt to originate a call is made.~~

- ~~g) The SS waits to see if there is any random access request from the UE.~~
- ~~h) By MMI, an emergency call is initiated on the UE.~~
- ~~i) The SS waits for random access request from the UE.~~

#### ~~6.1.2.7.5 Test requirements~~

- ~~1) In step c), after the UE has responded on Cell 1, it shall not respond on any other cell within 1 min.~~
- ~~2) In step e), there shall be no response from the UE within 2 min.~~
- ~~3) In step g), there shall be no response from the UE within 2 min. It shall not be possible to originate the call.~~
- ~~4) In step i), the UE shall respond on Cell 2. It shall be possible to originate the emergency call.~~

#### ~~6.1.2.8 Cell reselection: Equivalent PLMN~~

##### ~~6.1.2.8.1 Definition~~

~~Test to verify that the UE performs the cell reselection correctly to a cell belonging to a PLMN Equivalent to the registered PLMN, if the serving cell of registered PLMN becomes barred or  $S < 0$ .~~

##### ~~6.1.2.8.2 Conformance requirement~~

~~1. When camped on a cell, the UE shall regularly search for a better cell according to the cell reselection criteria. If a better cell is found, that cell is selected. The change of cell may imply a change of RAT.~~

~~2. A "suitable cell" is a cell on which the UE may camp on to obtain normal service. Such a cell shall fulfil all the following requirements.~~

~~2.1 The cell is part of the selected PLMN or of a PLMN considered as equivalent by the UE according to the information provided by the NAS~~

~~2.2 The cell is not barred~~

~~2.3 The cell is not part of the list of "forbidden LAs for roaming"~~

~~2.4 The cell selection criteria are fulfilled~~

~~3. When camped normally, the UE shall execute the cell reselection evaluation process on the following occasions/triggers:~~

~~3.1 UE internal triggers, so as to meet performance as specified in TS 25.133 for FDD mode and in TS 25.123 for TDD mode.~~

~~3.2 When information on the BCCH used for the cell reselection evaluation procedure has been modified~~

~~4. Cell Reselection Criteria:~~

~~4.1 The UE shall perform ranking of all cells that fulfil the S-criterion~~

~~4.2 The cells shall be ranked according to the R-criteria. The best ranked cell is the cell with the highest R value. If an FDD cell is ranked as the best cell, the UE shall perform cell re-selection to that FDD cell. If a TDD cell is ranked as the best cell, the UE shall perform cell re-selection to that TDD cell.~~

~~4.3 In all cases, the UE shall reselect the new cell, only if the cell reselection criteria are fulfilled during a time interval T<sub>res</sub>.~~

~~4.4 The cell-ranking criterion R is derived from Q, Q<sub>hyst</sub>, Q<sub>offset</sub>, TEMP\_OFFSET and PENALTY\_TIME. However, TEMP\_OFFSET<sub>n</sub> and PENALTY\_TIME<sub>n</sub> are only applicable if the usage of HCS is indicated in system information.~~

~~5. When cell status "barred" is indicated, the UE shall select another cell according to the following rule:~~

~~5.1 If the "Intra-frequency cell re-selection indicator" IE in Cell Access Restriction IE is set to value "allowed", the UE may select another cell on the same frequency if selection/re-selection criteria are fulfilled.~~



5.2 If the "Intra-frequency cell re-selection indicator" IE is set to "not-allowed" the UE shall not re-select a cell on the same frequency as the barred cell. For emergency call, the Intra-frequency cell re-selection indicator IE" shall be ignored, i.e. even if it is set to "not-allowed" the UE may select another intra-frequency cell.

#### References

1. TS 25.304, 5.2.1

2. TS 25.304, 4.3

3. TS 25.304, 5.2.5.1

4. TS 25.304, 5.2.6.1.4

5. TS 25.304, 5.3.1.1

6.1.2.8.3 Test purpose

1. To confirm that the UE treats the cell of the equivalent PLMN as a cell of the current PLMN.

2. To verify that the UE performs cell reselection on the following occasions:

2.1 Serving cell becomes barred.

2.2  $S < 0$  for serving cell.

3. To verify conformance requirement 5.

NOTE: Reselection triggered by the cell becoming a part of a forbidden registration area is tested in clause 9.4.2.3 "Location updating / rejected / location area not allowed" and 9.4.2.4 "Location updating / rejected / roaming not allowed in this LA".

6.1.2.8.4 Method of test

#### Initial conditions

Treselection, Qhyst, Qoffset, TEMP\_OFFSET and PENALTY\_TIME are not used, so the cell-ranking criterion R equals CPICH\_Ec/Io for FDD cells, and P-CCPCH RSCP for TDD cells.

The UE is Idle Updated on PLMN1 in cell 1, and The SS includes PLMN 2 and PLMN 3 under IE 'Equivalent PLMN' during Idle Update Procedure.

Step a-c (FDD):

| Parameter                                   | Unit | Cell 1      | Cell 2      | Cell 3      |
|---------------------------------------------|------|-------------|-------------|-------------|
| Test Channel                                |      | 1           | 1           | 2           |
| PLMN                                        |      | PLMN 1      | PLMN 2      | PLMN 3      |
| CPICH_Ec/Io                                 | dB   | -13         | -15         | -17         |
| Qqualmin                                    | dB   | -20         | -20         | -20         |
| Squal*                                      | dB   | 7           | 5           | 3           |
| Intra-frequency cell re-selection indicator |      | Not Allowed | Not Allowed | Not Allowed |
| CellBarred                                  |      | 0           | 0           | 0           |

Step d-f:

|            |  |     |   |   |
|------------|--|-----|---|---|
| CellBarred |  | 0→1 | 0 | 0 |
|------------|--|-----|---|---|

Step g-h:

|                                             |  |                          |                          |                          |
|---------------------------------------------|--|--------------------------|--------------------------|--------------------------|
| Intra-frequency cell re-selection indicator |  | Not Allowed<br>→ Allowed | Not Allowed<br>→ Allowed | Not Allowed<br>→ Allowed |
|---------------------------------------------|--|--------------------------|--------------------------|--------------------------|

Step i (FDD):

|          |    |         |     |     |
|----------|----|---------|-----|-----|
| Qqualmin | dB | -20→-10 | -20 | -20 |
| Squal*   | dB | 7→3     | 5   | 3   |

Test procedure

Method C is applied.

- a) The SS activates Cell 1-3 and monitors them for random access requests from the UE.
- b) The UE is switched on.
- c) The SS waits for random access requests from the UE. A complete Location Update is done. SS specifies PLMN 2 and 3 are Equivalent to PLMN 1 in Location Update Accept Message.
- d) The SS sets Cell 1 to be barred.
- e) The SS waits for random access requests from the UE. A complete Location Update is done. SS specifies PLMN 2 is Equivalent to PLMN 3 in Location Update Accept Message.
- f) The SS sets "Intra-frequency cell re-selection indicator" to "Allowed".
- g) The SS waits for random access requests from the UE. A complete Location Update is done.
- h) The stored information cell selection list in the UE is deleted and the UE is switched off.
- i) Step a-e) is repeated except that in step d) for FDD cells, Qqualmin is increased to -10 dB, or in step d) for TDD cells, Qrxlevmeas is increased to [TBD], so S will become negative instead of the cell being barred while maintaining the same RF level.

#### 6.1.2.8.5 Test requirements

- 1) In step c), after the UE has responded on Cell 1, it shall not respond on any other cell within 1 min.
- 2) In step e), the UE shall respond on Cell 3.
- 3) In step g), the UE shall respond on Cell 2.
- 4) In step i), the UE shall respond on Cell 2.

### 6.2 Multi-mode environment (2G/3G case)

#### 6.2.1 PLMN and RAT selection and reselection

##### 6.2.1.1 Selection of the correct PLMN and associated RAT

###### 6.2.1.1.1 Definition

Test to verify that the UE selects the correct combination of PLMN and associated access technology according to the fields on the USIM.

###### 6.2.1.1.2 Conformance requirement

1. At switch on, or following recovery from lack of coverage, the MS selects the registered PLMN or equivalent PLMN (if it is available) using all access technologies that the MS is capable of and if necessary (in the case of recovery from lack of coverage, see TS 23.122, clause 4.5.2) attempts to perform a Location Registration.

If successful registration is achieved, the MS indicates the selected PLMN.

If there is no registered PLMN, or if registration is not possible due to the PLMN being unavailable or registration failure, the MS follows either Automatic or Manual Network Selection Mode Procedure depending on its operating mode.

#### References

1. TS 23.122, clause 4.4.3.1.

NOTE: — TS 31.102 defines the USIM fields.

#### 6.2.1.1.3 Test purpose

1. To verify that the UE selects the correct combination of PLMN and associated access technology according to the fields on the USIM.

#### 6.2.1.1.4 Method of test

##### Initial conditions

The UE is in automatic PLMN selection mode.

Cell levels are from tables 6.3 and 6.4.

| Cell   | CPICH <sub>Ec</sub> / RF<br>signal level<br>[dBm/3.84 MHz] | P-CCPCH_RSCP/<br>RF signal level<br>[dBm] (TDD) | Test Channel | PLMN   | Radio Access<br>Technology |
|--------|------------------------------------------------------------|-------------------------------------------------|--------------|--------|----------------------------|
| Cell 1 | -48                                                        | -48                                             | 1            | PLMN 1 | GSM                        |
| Cell 2 | -72                                                        | -61                                             | 1            | PLMN 1 | UTRAN                      |
| Cell 3 | -75                                                        | -64                                             | 2            | PLMN 2 | UTRAN                      |
| Cell 4 | -50                                                        | -50                                             | 2            | PLMN 2 | GSM                        |

The UE is equipped with a USIM containing default values except for those listed below.

#### USIM A

| USIM field              | Priority        | PLMN   | Access Technology Identifier |
|-------------------------|-----------------|--------|------------------------------|
| EF <sub>LOCI</sub>      |                 |        |                              |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN 1 | GSM                          |
|                         | 2 <sup>nd</sup> |        | UTRAN                        |

#### USIM B

| USIM field              | Priority        | PLMN   | Access Technology Identifier |
|-------------------------|-----------------|--------|------------------------------|
| EF <sub>LOCI</sub>      |                 |        |                              |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN 2 | UTRAN                        |
|                         | 2 <sup>nd</sup> |        | GSM                          |

#### Test procedure

Method B is applied.

- a) ~~The SS activates cells 1-4 and monitors the cells for random access requests from the UE. The UE shall have a USIM with settings according to USIM A.~~
- b) ~~The UE is switched on.~~
- c) ~~The SS waits for random access requests from the UE.~~
- d) ~~The UE is switched off and a USIM with settings according to USIM B is inserted.~~
- e) ~~The UE is switched on.~~
- f) ~~The SS waits for random access requests from the UE.~~

#### 6.2.1.1.5 Test Requirements

- 1) ~~In step c), the response from the UE shall be on Cell 1. The displayed PLMN shall be PLMN1 (GSM).~~
- 2) ~~In step f), the response from the UE shall be on Cell 3. The displayed PLMN shall be PLMN2 (UTRAN).~~

#### 6.2.1.2 Selection of RAT for HPLMN; Manual mode

##### 6.2.1.2.1 Definition

Test to verify that the UE selects the HPLMN RAT according to the HPLMN RAT priority list on the USIM. If no RAT on the list is available, the UE shall try to obtain registration on the same PLMN using other UE-supported RATs.

##### 6.2.1.2.2 Conformance requirement

1. ~~To allow provision for multiple HPLMN codes, the HPLMN access technologies are stored on the SIM together with PLMN codes. This version of the specification does not support multiple HPLMN codes and the "HPLMN Selector with Access Technology" data field is only used by the MS to get the HPLMN access technologies. The HPLMN code is the PLMN code included in the IMSI.~~

2. ~~For HPLMN, the MS shall search for all access technologies it is capable of. The MS shall start its search using the access technologies stored in the "HPLMN Selector with Access Technology" data field on the SIM in priority order (i.e. the PLMN/access technology combinations are listed in priority order, if an entry includes more than one access technology then no priority is defined for the preferred access technology and the priority is an implementation issue).~~

##### 3. ~~Manual Network Selection Mode Procedure:~~

The MS indicates whether there are any PLMNs, which are available using all supported access technologies. This includes PLMNs in the "forbidden PLMNs" list and PLMNs which only offer services not supported by the MS.

If displayed, PLMNs meeting the criteria above are presented in the following order:

##### 3.1 HPLMN;

3.2 PLMNs contained in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

3.3 PLMNs contained in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

3.4 Other PLMN/access technology combinations with received high quality signal in random order;

3.5 Other PLMN/access technology combinations in order of decreasing signal quality.

The user may select his desired PLMN and the MS then initiates registration on this PLMN using the access technology chosen by the user for that PLMN or using the highest priority available access technology for that PLMN, if the associated access technologies have a priority order. (This may take place at any time during the presentation of PLMNs). For such a registration, the MS shall ignore the contents of the "forbidden LAs for roaming", "forbidden LAs for regional provision of service", "forbidden PLMNs for GPRS service" and "forbidden PLMNs" lists.

If the user does not select a PLMN, the selected PLMN shall be the one that was selected before the PLMN selection procedure started. If no such PLMN was selected or that PLMN is no longer available, then the MS shall attempt to camp on any acceptable cell and enter the limited service state.

NOTE: — It is an MS implementation option whether to indicate access technologies to the user. If the MS does display access technologies, then the access technology used should be the access technology chosen by the user for that PLMN. If the MS does not display access technologies, then the access technology chosen for a particular PLMN should be the highest priority available access technology for that PLMN, if the associated access technologies have a priority order.

#### References

1. TS 23.122, clause 4.4.3.
2. TS 23.122, clause 4.4.3.1.1 (f).
3. TS 23.122, clause 4.4.3.1.2.

NOTE: — TS 31.102 defines the USIM fields.

#### 6.2.1.2.3 Test purpose

1. To verify that:

1.1 the UE searches for a HPLMN RAT according to the HPLMN Selector with Access Technology data field on the USIM in priority order;

1.2 If no RAT on the priority list is available, the UE tries to obtain registration on the same PLMN using other UE-supported RATs.

#### 6.2.1.2.4 Method of test

##### Initial conditions

The UE is in manual PLMN selection mode.

Cell levels are from tables 6.3 and 6.4.

| Cell   | CPICH_Ec / RF<br>signal level<br>[dBm/3.84 MHz]<br>(FDD) | P-CCPCH_RSCP/<br>RF signal level<br>[dBm] (TDD) | Test Channel | PLMN   | Radio Access<br>Technology |
|--------|----------------------------------------------------------|-------------------------------------------------|--------------|--------|----------------------------|
| Cell 1 | -72                                                      | -61                                             | 1            | PLMN-2 | UTRAN                      |
| Cell 2 | -48                                                      | -48                                             | 1            | PLMN-2 | GSM                        |
| Cell 3 | -75                                                      | -64                                             | 2            | PLMN-3 | UTRAN                      |
| Cell 4 | -50                                                      | -50                                             | 2            | PLMN-3 | GSM                        |

The UE is equipped with a USIM containing default values except for those listed below.

##### USIM A

| USIM field              | Priority        | PLMN   | Access Technology Identifier |
|-------------------------|-----------------|--------|------------------------------|
| EF <sub>LOGI</sub>      |                 | PLMN-1 |                              |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN-2 | UTRAN                        |
|                         | 2 <sup>nd</sup> |        | GSM                          |

## USIM B

| USIM field              | Priority        | PLMN   | Access Technology Identifier |
|-------------------------|-----------------|--------|------------------------------|
| EF <sub>LOCI</sub>      |                 | PLMN 1 |                              |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN 2 | UTRAN                        |
|                         | 2 <sup>nd</sup> |        |                              |

## Test procedure

Method B is applied.

- a) ~~The SS activates cells 1-4 and monitors the cells for random access requests from the UE. The UE shall have a USIM with settings according to USIM A.~~
- b) ~~The UE is switched on.~~
- c) ~~PLMN2 (UTRAN) shall be selected when the PLMN list is presented.~~
- d) ~~The SS waits for random access requests from the UE.~~
- e) ~~Cell 1 is switched off.~~
- f) ~~PLMN2 (GSM) shall be selected when the PLMN list is presented.~~
- g) ~~The SS waits for random access requests from the UE.~~
- h) ~~The UE is switched off and a USIM with settings according to USIM B is inserted. All cells except Cell 1 are active.~~
- i) ~~The UE is switched on.~~
- j) ~~PLMN2 (GSM) shall be selected when the PLMN list is presented.~~
- k) ~~The SS waits for random access requests from the UE.~~

## 6.2.1.2.5 Test Requirements

- 1) ~~In step c), the list shall be presented. It shall contain as highest priority PLMN2 (UTRAN as number 1 on the list and GSM as number 2).~~
- 2) ~~In step d), the response from the UE shall be on Cell 1 (1<sup>st</sup> priority RAT for EF<sub>HPLMNwAcT</sub>). The displayed PLMN shall be PLMN2 (UTRAN).~~
- 3) ~~In step f), the list shall be presented. It shall contain as highest priority PLMN2 (GSM).~~
- 4) ~~In step g), the response from the UE shall be on Cell 2 (2<sup>nd</sup> priority RAT for EF<sub>HPLMNwAcT</sub>). The displayed PLMN shall be PLMN2 (GSM).~~
- 5) ~~In step j), the list shall be presented. It shall contain as highest priority PLMN2 (GSM).~~
- 6) ~~In step k), the response from the UE shall be on Cell 2. The displayed PLMN shall be PLMN2 (GSM). (PLMN2 is not available on UTRAN so registration on the same PLMN is attempted using other UE-supported RATs).~~

## 6.2.1.3 Selection of RAT for UPLMN; Manual mode

## 6.2.1.3.1 Definition

Test to verify that the UE selects the UPLMN RAT according to the UPLMN RAT priority list on the USIM. If no RAT on the list is available, the UE shall not try to obtain registration on the same PLMN(s) with other RAT(s) but instead search for PLMNs in the OPLMN list.

## 6.2.1.3.2 Conformance requirement

### 1. Manual Network Selection Mode Procedure:

The MS indicates whether there are any PLMNs, which are available using all supported access technologies. This includes PLMNs in the "forbidden PLMNs" list and PLMNs which only offer services not supported by the MS.

If displayed, PLMNs meeting the criteria above are presented in the following order:

#### 1.1 HPLMN;

1.2 PLMNs contained in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

1.3 PLMNs contained in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

1.4 Other PLMN/access technology combinations with received high quality signal in random order;

1.5 Other PLMN/access technology combinations in order of decreasing signal quality.

The user may select his desired PLMN and the MS then initiates registration on this PLMN using the access technology chosen by the user for that PLMN or using the highest priority available access technology for that PLMN, if the associated access technologies have a priority order. (This may take place at any time during the presentation of PLMNs). For such a registration, the MS shall ignore the contents of the "forbidden LAs for roaming", "forbidden LAs for regional provision of service", "forbidden PLMNs for GPRS service" and "forbidden PLMNs" lists.

If the user does not select a PLMN, the selected PLMN shall be the one that was selected before the PLMN selection procedure started. If no such PLMN was selected or that PLMN is no longer available, then the MS shall attempt to camp on any acceptable cell and enter the limited service state.

NOTE:— It is an MS implementation option whether to indicate access technologies to the user. If the MS does display access technologies, then the access technology used should be the access technology chosen by the user for that PLMN. If the MS does not display access technologies, then the access technology chosen for a particular PLMN should be the highest priority available access technology for that PLMN, if the associated access technologies have a priority order.

### References

1. TS 23.122, clause 4.4.3.1.2.

NOTE:— TS 31.102 defines the USIM fields.

#### 6.2.1.3.3 Test purpose

1. To verify that:

1.1 the UE selects the UPLMN RAT according to the UPLMN RAT priority list on the USIM.

1.2 If no RAT on the list is available, the UE does not try to obtain registration on the same PLMN with another RAT but instead searches for PLMNs in the OPLMN list.

#### 6.2.1.3.4 Method of test

#### Initial conditions

The UE is in manual PLMN selection mode.

Cell levels are from tables 6.3 and 6.4.

| Cell   | CPICH_Ec / RF<br>signal level<br><br>[dBm/3.84 MHz]<br>(FDD) | P-CCPCH_RSCP/<br>RF signal level<br>[dBm] (TDD) | Test Channel | PLMN   | Radio Access<br>Technology |
|--------|--------------------------------------------------------------|-------------------------------------------------|--------------|--------|----------------------------|
| Cell 1 | -72                                                          | -61                                             | 1            | PLMN-3 | UTRAN                      |

|        |     |     |   |        |       |
|--------|-----|-----|---|--------|-------|
| Cell 2 | -48 | -48 | 1 | PLMN-3 | GSM   |
| Cell 3 | -75 | -64 | 2 | PLMN-4 | UTRAN |
| Cell 4 | -50 | -50 | 2 | PLMN-4 | GSM   |
| Cell 5 | -78 | -67 | 3 | PLMN-5 | UTRAN |

The UE is equipped with a USIM containing default values except for those listed below.

| USIM field              | Priority        | PLMN   | Access Technology Identifier |
|-------------------------|-----------------|--------|------------------------------|
| EF <sub>LOCI</sub>      |                 | PLMN-1 |                              |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN-2 | UTRAN                        |
|                         | 2 <sup>nd</sup> |        | GSM                          |
| EF <sub>PLMNwAcT</sub>  | 1 <sup>st</sup> | PLMN-3 | UTRAN                        |
|                         | 2 <sup>nd</sup> | PLMN-4 | GSM                          |
| EF <sub>OPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN-5 | UTRAN                        |
|                         | 2 <sup>nd</sup> | PLMN-6 | GSM                          |

#### Test procedure

Method B is applied.

- The SS activates cells 1-5 and monitors the cells for random access requests from the UE.
- The UE is switched on.
- PLMN3 (UTRAN) shall be selected when the PLMN list is presented.
- The SS waits for random access requests from the UE.
- Cell 1 is switched off.
- PLMN4 (GSM) shall be selected when the PLMN list is presented.
- The SS waits for random access requests from the UE.
- Cell 4 is switched off.
- PLMN5 (UTRAN) shall be selected when the PLMN list is presented.
- The SS waits for random access requests from the UE.

#### 6.2.1.3.5 Test Requirements

- In step c), the list shall be presented. It shall contain in priority PLMN3 (UTRAN), PLMN4 (GSM), other PLMNs.
- In step d), the response from the UE shall be on Cell 1 (1<sup>st</sup> priority RAT for EF<sub>PLMNwAcT</sub>). The displayed PLMN shall be PLMN3 (UTRAN).
- In step f), the list shall be presented. It shall contain in priority PLMN4 (GSM), PLMN5 (UTRAN), other PLMNs.
- In step g), the response from the UE shall be on Cell 4 (2<sup>nd</sup> priority RAT for EF<sub>PLMNwAcT</sub>). The displayed PLMN shall be PLMN4 (GSM).
- In step i), the list shall be presented. It shall contain as highest priority PLMN5 (UTRAN).



6) In step j), the response from the UE shall be on Cell 5 (1<sup>st</sup> priority RAT for EF<sub>OPLMNwAcT</sub>). The displayed PLMN shall be PLMN5 (UTRAN).

#### 6.2.1.4 Selection of RAT for OPLMN; Manual mode

##### 6.2.1.4.1 Definition

Test to verify that the UE selects the OPLMN RAT according to the OPLMN RAT priority list on the USIM. If no RAT on the list is available, the UE shall not try to obtain registration on the same PLMN(s) with other RAT(s) but instead search for other PLMN/access technology combinations with received high quality signal in random order.

##### 6.2.1.4.2 Conformance requirement

###### 1. Manual Network Selection Mode Procedure:

The MS indicates whether there are any PLMNs, which are available using all supported access technologies. This includes PLMNs in the "forbidden PLMNs" list and PLMNs which only offer services not supported by the MS.

If displayed, PLMNs meeting the criteria above are presented in the following order:

###### 1.1 HPLMN;

1.2 PLMNs contained in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

1.3 PLMNs contained in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

1.4 Other PLMN/access technology combinations with received high quality signal in random order;

1.5 Other PLMN/access technology combinations in order of decreasing signal quality.

The user may select his desired PLMN and the MS then initiates registration on this PLMN using the access technology chosen by the user for that PLMN or using the highest priority available access technology for that PLMN, if the associated access technologies have a priority order. (This may take place at any time during the presentation of PLMNs). For such a registration, the MS shall ignore the contents of the "forbidden LAs for roaming", "forbidden LAs for regional provision of service", "forbidden PLMNs for GPRS service" and "forbidden PLMNs" lists.

If the user does not select a PLMN, the selected PLMN shall be the one that was selected before the PLMN selection procedure started. If no such PLMN was selected or that PLMN is no longer available, then the MS shall attempt to camp on any acceptable cell and enter the limited service state.

NOTE: — It is an MS implementation option whether to indicate access technologies to the user. If the MS does display access technologies, then the access technology used should be the access technology chosen by the user for that PLMN. If the MS does not display access technologies, then the access technology chosen for a particular PLMN should be the highest priority available access technology for that PLMN, if the associated access technologies have a priority order.

#### References

1. TS 23.122, clause 4.4.3.1.2.

NOTE: — TS 31.102 defines the USIM fields.

##### 6.2.1.4.3 Test purpose

###### 1. To verify that:

1.1 the UE selects the OPLMN RAT according to the OPLMN RAT priority list on the USIM.

1.2 If no RAT on the list is available, the UE does not try to obtain registration on the same PLMN(s) with other RAT(s) but instead searches for "other PLMN/access technology combinations with received high quality signal in random order".

##### 6.2.1.4.4 Method of test

#### Initial conditions

The UE is in manual PLMN selection mode.

Cell levels are from tables 6.3 and 6.4.

| Cell   | CPICH_Ec / RF<br>signal level<br>[dBm/3.84 MHz]<br>(FDD) | P-CCPCH_RSCP /<br>RF signal level<br>[dBm] (TDD) | Test Channel | PLMN   | Radio Access<br>Technology |
|--------|----------------------------------------------------------|--------------------------------------------------|--------------|--------|----------------------------|
| Cell-1 | -72                                                      | -61                                              | 1            | PLMN-5 | UTRAN                      |
| Cell-2 | -48                                                      | -48                                              | 1            | PLMN-5 | GSM                        |
| Cell-3 | -75                                                      | -64                                              | 2            | PLMN-6 | UTRAN                      |
| Cell-4 | -50                                                      | -50                                              | 2            | PLMN-6 | GSM                        |
| Cell-5 | -78                                                      | -67                                              | 3            | PLMN-7 | UTRAN                      |

The UE is equipped with a USIM containing default values except for those listed below.

| USIM field              | Priority        | PLMN   | Access<br>Technology<br>Identifier |
|-------------------------|-----------------|--------|------------------------------------|
| EF <sub>LOC1</sub>      |                 | PLMN-1 |                                    |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN-2 | UTRAN                              |
|                         | 2 <sup>nd</sup> |        | GSM                                |
| EF <sub>PLMNwAcT</sub>  | 1 <sup>st</sup> | PLMN-3 | UTRAN                              |
|                         | 2 <sup>nd</sup> | PLMN-4 | GSM                                |
| EF <sub>OPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN-5 | UTRAN                              |
|                         | 2 <sup>nd</sup> | PLMN-6 | GSM                                |

Test procedure

Method B is applied.

- a) The SS activates cells 1-5 and monitors the cells for random access requests from the UE.
- b) The UE is switched on.
- c) PLMN5 (UTRAN) shall be selected when the PLMN list is presented.
- d) The SS waits for random access requests from the UE.
- e) Cell 1 is switched off.
- f) PLMN6 (GSM) shall be selected when the PLMN list is presented.
- g) The SS waits for random access requests from the UE.
- h) Cell 4 is switched off.
- i) PLMN7 (UTRAN) shall be selected when the PLMN list is presented.
- j) The SS waits for random access requests from the UE.

#### 6.2.1.4.5 Test Requirements

- 1) In step c), the list shall be presented. It shall contain in priority PLMN5 (UTRAN), PLMN6 (GSM), other PLMNs.
- 2) In step d), the response from the UE shall be on Cell 1 (1<sup>st</sup> priority RAT for EF<sub>OPLMNwAcT</sub>). The displayed PLMN shall be PLMN5 (UTRAN).
- 3) In step f), the list shall be presented. It shall contain as highest priority PLMN6 (GSM) followed by PLMN5 (GSM), PLMN6 (UTRAN) and PLMN7 (UTRAN) in random order.
- 4) In step g), the response from the UE shall be on Cell 4 (2<sup>nd</sup> priority RAT for EF<sub>OPLMNwAcT</sub>). The displayed PLMN shall be PLMN6 (GSM).
- 5) In step i), the list shall be presented. It shall contain PLMN5 (GSM), PLMN6 (UTRAN) and PLMN7 (UTRAN) in random order.
- 6) In step j), the response from the UE shall be on Cell 5. The displayed PLMN shall be PLMN7 (UTRAN).

#### 6.2.1.5 Selection of "Other PLMN / access technology combinations"; Manual mode

##### 6.2.1.5.1 Definition

Test to verify that if neither RPLMN, HPLMN, UPLMN nor OPLMN is available, the UE first tries to obtain registration on "Other PLMN/access technology combinations with received high quality signal in random order" and secondly on "Other PLMN/access technology combinations in order of decreasing signal quality".

##### 6.2.1.5.2 Conformance requirement

##### 1. Manual Network Selection Mode Procedure:

The MS indicates whether there are any PLMNs, which are available using all supported access technologies. This includes PLMNs in the "forbidden PLMNs" list and PLMNs which only offer services not supported by the MS.

If displayed, PLMNs meeting the criteria above are presented in the following order:

##### 1.1 HPLMN;

1.2 PLMNs contained in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

1.3 PLMNs contained in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

1.4 Other PLMN/access technology combinations with received high quality signal in random order;

1.5 Other PLMN/access technology combinations in order of decreasing signal quality.

In 1.5, the MS shall order the PLMN/access technology combinations in order of decreasing signal quality within each access technology. The order between PLMN/access technology combinations with different access technologies is an MS implementation issue.

The user may select his desired PLMN and the MS then initiates registration on this PLMN using the access technology chosen by the user for that PLMN or using the highest priority available access technology for that PLMN, if the associated access technologies have a priority order. (This may take place at any time during the presentation of PLMNs). For such a registration, the MS shall ignore the contents of the "forbidden LAs for roaming", "forbidden LAs for regional provision of service", "forbidden PLMNs for GPRS service" and "forbidden PLMNs" lists.

If the user does not select a PLMN, the selected PLMN shall be the one that was selected before the PLMN selection procedure started. If no such PLMN was selected or that PLMN is no longer available, then the MS shall attempt to camp on any acceptable cell and enter the limited service state.

NOTE: — It is an MS implementation option whether to indicate access technologies to the user. If the MS does display access technologies, then the access technology used should be the access technology chosen by the user for that PLMN. If the MS does not display access technologies, then the access technology chosen for a particular PLMN should be the highest priority available access technology for that PLMN, if the associated access technologies have a priority order.

2. ~~UTRA case: The UE shall scan all RF channels in the UTRA band according to its capabilities to find available PLMNs. On each carrier, the UE shall search for the strongest cell according to the cell search procedures (for FDD, see TS 25.214, and TDD, see TS 25.224) and read its system information, in order to find out which PLMN the cell belongs to. If the UE can read the PLMN identity, the found PLMN shall be reported to the NAS as a high quality PLMN (but without the RSCP value), provided that the following high quality criterion is fulfilled:~~

~~— For an FDD cell, the measured primary CPICH RSCP value shall be greater than or equal to  $-95$  dBm.~~

~~— For a TDD cell, the measured P-CCPCH RSCP value shall be greater than or equal to  $-84$  dBm.~~

~~Found PLMNs that do not satisfy the high quality criterion, but for which the UE has been able to read the PLMN identities are reported to the NAS together with the CPICH RSCP value for UTRA FDD cells and P-CCPCH RSCP for UTRA TDD cells.~~

3. ~~GSM case: A PLMN shall be understood to be received with high quality signal if the signal level is above  $-85$  dBm.~~

#### References

1. ~~TS 23.122, clause 4.4.3.1.2.~~

2. ~~TS 25.304, clause 5.1.2.2.~~

3. ~~TS 03.22, clause 4.4.3.~~

NOTE: ~~TS 31.102 defines the USIM fields.~~

#### 6.2.1.5.3 Test purpose

1. ~~To verify that:~~

1.1 ~~If neither RPLMN, HPLMN, UPLMN nor OPLMN is available, the UE tries to obtain registration on "Other PLMN/access technology combinations with received high quality signal in random order".~~

1.2 ~~If no PLMN is available in test purpose 1.1, the UE tries to obtain registration on "Other PLMN/access technology combinations in order of decreasing signal quality".~~

2. ~~The "random order" in test purpose 1.1 is not verified.~~

#### 6.2.1.5.4 Method of test

##### Initial conditions

~~The UE is in manual PLMN selection mode.~~

| Cell   | CPICH_Ec /RF<br>signal level<br>[dBm/3.84 MHz]<br>(FDD) | P-CCPCH_RSCP /<br>RF signal level<br>[dBm] (TDD) | High Quality<br>signal | Test<br>Channel | PLMN    | Radio Access<br>Technology |
|--------|---------------------------------------------------------|--------------------------------------------------|------------------------|-----------------|---------|----------------------------|
| Cell 1 | -80                                                     | -69                                              | Yes                    | 1               | PLMN 7  | UTRAN                      |
| Cell 2 | -65                                                     | -65                                              | Yes                    | 1               | PLMN 8  | GSM                        |
| Cell 3 | -98                                                     | -87                                              | No                     | 2               | PLMN 9  | UTRAN                      |
| Cell 4 | -101                                                    | -90                                              | No                     | 2               | PLMN 10 | UTRAN                      |
| Cell 5 | -88                                                     | -88                                              | No                     | 3               | PLMN 11 | GSM                        |
| Cell 6 | -91                                                     | -91                                              | No                     | 3               | PLMN 12 | GSM                        |

~~The UE is equipped with a USIM containing default values except for those listed below.~~

| USIM field | Priority | PLMN | Access<br>Technology |
|------------|----------|------|----------------------|
|------------|----------|------|----------------------|

|                                   |                           |                   | Identifier       |
|-----------------------------------|---------------------------|-------------------|------------------|
| <del>EF<sub>LOGI</sub></del>      |                           | <del>PLMN 1</del> |                  |
| <del>EF<sub>HPLMNwAcT</sub></del> | <del>1<sup>st</sup></del> | <del>PLMN 2</del> | <del>UTRAN</del> |
|                                   | <del>2<sup>nd</sup></del> |                   | <del>GSM</del>   |
| <del>EF<sub>PLMNwAcT</sub></del>  | <del>1<sup>st</sup></del> | <del>PLMN 3</del> | <del>UTRAN</del> |
|                                   | <del>2<sup>nd</sup></del> | <del>PLMN 4</del> | <del>GSM</del>   |
| <del>EF<sub>OPLMNwAcT</sub></del> | <del>1<sup>st</sup></del> | <del>PLMN 5</del> | <del>UTRAN</del> |
|                                   | <del>2<sup>nd</sup></del> | <del>PLMN 6</del> | <del>GSM</del>   |
| <del>EF<sub>FPLMN</sub></del>     | <del>PLMN 7</del>         |                   |                  |
|                                   | <del>PLMN 12</del>        |                   |                  |

#### Test procedure

Method B is applied.

- a) ~~The SS activates cells 1-6 and monitors the cells for random access requests from the UE.~~
- b) ~~The UE is switched on.~~
- c) ~~PLMN11 shall be selected when the PLMN list is presented.~~
- d) ~~The SS waits for random access requests from the UE.~~
- e) ~~Cell 5 is switched off.~~
- f) ~~PLMN8 shall be selected when the PLMN list is presented.~~
- g) ~~The SS waits for random access requests from the UE.~~
- h) ~~Cell 2 is switched off.~~
- i) ~~PLMN10 shall be selected when the PLMN list is presented.~~
- j) ~~The SS waits for random access requests from the UE.~~
- k) ~~Cell 4 is switched off.~~
- l) ~~PLMN7 shall be selected when the PLMN list is presented. The SS shall reject the Registration Request from the UE.~~
- m) ~~Cell 1 is switched off.~~
- n) ~~PLMN9 shall be selected when the PLMN list is presented.~~
- o) ~~The SS waits for random access requests from the UE.~~
- p) ~~Cell 3 is switched off.~~
- q) ~~PLMN12 shall be selected when the PLMN list is presented. The SS shall reject the Registration Request from the UE.~~
- r) ~~Cell 6 is switched off.~~

#### 6.2.1.5.5 Test Requirements

In all steps, the PLMN priority list shall be as follows: PLMN7, PLMN8 in random order followed by the other PLMNs. PLMN9 shall always come before PLMN10 and PLMN11 shall always come before PLMN12.

- 1) In step c), the list shall be presented and contain PLMN7, 8, 9, 10, 11, 12.
- 2) In step d), the response from the UE shall be on Cell 5. The displayed PLMN shall be PLMN11.
- 3) In step f), the list shall be presented and contain PLMN7, 8, 9, 10, 12.
- 4) In step g), the response from the UE shall be on Cell 2. The displayed PLMN shall be PLMN8.
- 5) In step i), the list shall be presented and contain PLMN7, 9, 10, 12.
- 6) In step j), the response from the UE shall be on Cell 4. The displayed PLMN shall be PLMN10.
- 7) In step l), the list shall be presented and contain PLMN7, 9, 12. After the PLMN has been selected, the list shall appear again as the UE cannot perform registration.
- 9) In step n), the list shall be presented and contain PLMN9, 12.
- 10) In step o), the response from the UE shall be on Cell 3. The displayed PLMN shall be PLMN9.
- 11) In step q), the list shall be presented and shall only contain PLMN12. After the PLMN has been selected, the list shall appear again as the UE cannot perform registration.
- 13) After step r), the UE shall inform that no network is available

#### 6.2.1.6 Selection of RAT for HPLMN; Automatic mode

##### 6.2.1.6.1 Definition

Test to verify that the UE selects the HPLMN RAT according to the HPLMN RAT priority list on the USIM. If no RAT on the list is available, the UE shall try to obtain registration on the same PLMN using other UE-supported RATs.

##### 6.2.1.6.2 Conformance requirement

1. To allow provision for multiple HPLMN codes, the HPLMN access technologies are stored on the SIM together with PLMN codes. This version of the specification does not support multiple HPLMN codes and the "HPLMN Selector with Access Technology" data field is only used by the MS to get the HPLMN access technologies. The HPLMN code is the PLMN code included in the IMSI.

2. For HPLMN, the MS shall search for all access technologies it is capable of. The MS shall start its search using the access technologies stored in the "HPLMN Selector with Access Technology" data field on the SIM in priority order (i.e. the PLMN/access technology combinations are listed in priority order, if an entry includes more than one access technology then no priority is defined for the preferred access technology and the priority is an implementation issue).

##### 3. Automatic Network Selection Mode Procedure:

The MS selects and attempts registration on other PLMNs, if available and allowable in the following order:

3.1 HPLMN (if not previously selected);

3.2 Each PLMN in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

3.3 Each PLMN in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);

3.4 Other PLMN/access technology combinations with received high quality signal in random order;

3.5 Other PLMN/access technology combinations in order of decreasing signal quality.

If successful registration is achieved, the MS indicates the selected PLMN.

If registration cannot be achieved because no PLMNs are available and allowable, the MS indicates "no service" to the user, waits until a new PLMN is available and allowable and then repeats the procedure.

If there were one or more PLMNs which were available and allowable, but an LR failure made registration on those PLMNs unsuccessful or an entry in the "forbidden LAs for regional provision of service" list prevented a registration attempt, the MS selects the first such PLMN again and enters a limited service state.

## References

1. TS 23.122, clause 4.4.3.
2. TS 23.122, clause 4.4.3.1.1 (f).
3. TS 23.122, clause 4.4.3.1.1.

NOTE: TS 31.102 defines the USIM fields.

## 6.2.1.6.3 Test purpose

## 1. To verify that:

1.1 the UE searches for a HPLMN RAT according to the HPLMN Selector with Access Technology data field on the USIM in priority order.

1.2 If no RAT on the priority list is available, the UE tries to obtain registration on the same PLMN using other UE-supported RATs.

## 6.2.1.6.4 Method of test

## Initial conditions

The UE is in automatic PLMN selection mode.

Cell levels are from tables 6.3 and 6.4.

| Cell   | CPICH <sub>E<sub>c</sub></sub> / RF<br>signal level<br>[dBm/3.84 MHz]<br>(FDD) | P-CCPCH <sub>RSCP</sub> /<br>RF signal level<br>[dBm] (TDD) | Test Channel | PLMN   | Radio Access<br>Technology |
|--------|--------------------------------------------------------------------------------|-------------------------------------------------------------|--------------|--------|----------------------------|
| Cell 1 | -72                                                                            | -61                                                         | 1            | PLMN 2 | UTRAN                      |
| Cell 2 | -48                                                                            | -48                                                         | 1            | PLMN 2 | GSM                        |
| Cell 3 | -75                                                                            | -64                                                         | 2            | PLMN 3 | UTRAN                      |
| Cell 4 | -50                                                                            | -50                                                         | 2            | PLMN 3 | GSM                        |

The UE is equipped with a USIM containing default values except for those listed below.

## USIM A

| USIM field              | Priority        | PLMN   | Access Technology Identifier |
|-------------------------|-----------------|--------|------------------------------|
| EF <sub>LOCI</sub>      |                 | PLMN 1 |                              |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN 2 | UTRAN                        |
|                         | 2 <sup>nd</sup> |        | GSM                          |

## USIM B

| USIM field              | Priority        | PLMN   | Access Technology Identifier |
|-------------------------|-----------------|--------|------------------------------|
| EF <sub>LOCI</sub>      |                 | PLMN 1 |                              |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN 2 | UTRAN                        |
|                         | 2 <sup>nd</sup> |        |                              |

### Test procedure

Method B is applied.

- a) ~~The SS activates cells 1-4 and monitors the cells for random access requests from the UE. The UE shall have a USIM with settings according to USIM A.~~
- b) ~~The UE is switched on.~~
- c) ~~The SS waits for random access requests from the UE.~~
- d) ~~The UE is switched off and a USIM with settings according to USIM A is again inserted. All cells except Cell 1 are active.~~
- e) ~~The SS waits for random access requests from the UE.~~
- f) ~~The UE is switched off and a USIM with settings according to USIM B is inserted. All cells except Cell 1 are active.~~
- g) ~~The UE is switched on.~~
- h) ~~The SS waits for random access requests from the UE.~~

### 6.2.1.6.5 Test Requirements

- 1) ~~In step c), the response from the UE shall be on Cell 1 (1<sup>st</sup> priority RAT for EF<sub>HPLMNwAct</sub>). The displayed PLMN shall be PLMN2 (UTRAN).~~
- 2) ~~In step e), the response from the UE shall be on Cell 2 (2<sup>nd</sup> priority RAT for EF<sub>HPLMNwAct</sub>). The displayed PLMN shall be PLMN2 (GSM).~~
- 3) ~~In step h), the response from the UE shall be on Cell 2. The displayed PLMN shall be PLMN2 (GSM). (PLMN2 is not available on UTRAN so registration on the same PLMN is attempted using other UE-supported RATs).~~

### 6.2.1.7 Selection of RAT for UPLMN; Automatic mode

#### 6.2.1.7.1 Definition

Test to verify that the UE selects the UPLMN RAT according to the UPLMN RAT priority list on the USIM. If no RAT on the list is available, the UE shall not try to obtain registration on the same PLMN(s) with other RAT(s) but instead search for PLMNs in the OPLMN list.

#### 6.2.1.7.2 Conformance requirement

##### 1. Automatic Network Selection Mode Procedure:

The MS selects and attempts registration on other PLMNs, if available and allowable in the following order:

- 1.1 HPLMN (if not previously selected);
- 1.2 Each PLMN in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);
- 1.3 Each PLMN in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);
- 1.4 Other PLMN/access technology combinations with received high quality signal in random order;
- 1.5 Other PLMN/access technology combinations in order of decreasing signal quality.

If successful registration is achieved, the MS indicates the selected PLMN.

If registration cannot be achieved because no PLMNs are available and allowable, the MS indicates "no service" to the user, waits until a new PLMN is available and allowable and then repeats the procedure.



If there were one or more PLMNs which were available and allowable, but an LR failure made registration on those PLMNs unsuccessful or an entry in the "forbidden LAs for regional provision of service" list prevented a registration attempt, the MS selects the first such PLMN again and enters a limited service state.

#### References

1. TS 23.122, clause 4.4.3.1.1.

NOTE: TS 31.102 defines the USIM fields.

#### 6.2.1.7.3 Test purpose

1. To verify that:

1.1 the UE selects the UPLMN RAT according to the UPLMN RAT priority list on the USIM.

1.2 If no RAT on the list is available, the UE does not try to obtain registration on the same PLMN with another RAT but instead searches for PLMNs in the OPLMN list.

#### 6.2.1.7.4 Method of test

##### Initial conditions

The UE is in automatic PLMN selection mode.

Cell levels are from tables 6.3 and 6.4.

| Cell   | CPICH <sub>E<sub>c</sub></sub> / RF signal level [dBm/3.84 MHz] (FDD) | P-CCPCH / RF signal level [dBm] (TDD) | Test Channel | PLMN   | Radio Access Technology |
|--------|-----------------------------------------------------------------------|---------------------------------------|--------------|--------|-------------------------|
| Cell 1 | -72                                                                   | -61                                   | 1            | PLMN 3 | UTRAN                   |
| Cell 2 | -48                                                                   | -48                                   | 1            | PLMN 3 | GSM                     |
| Cell 3 | -75                                                                   | -64                                   | 2            | PLMN 4 | UTRAN                   |
| Cell 4 | -50                                                                   | -50                                   | 2            | PLMN 4 | GSM                     |
| Cell 5 | -78                                                                   | -67                                   | 3            | PLMN 5 | UTRAN                   |

The UE is equipped with a USIM containing default values except for those listed below.

| USIM field              | Priority        | PLMN   | Access Technology Identifier |
|-------------------------|-----------------|--------|------------------------------|
| EF <sub>LOCI</sub>      |                 | PLMN 1 |                              |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN 2 | UTRAN                        |
|                         | 2 <sup>nd</sup> |        | GSM                          |
| EF <sub>PLMNwAcT</sub>  | 1 <sup>st</sup> | PLMN 3 | UTRAN                        |
|                         | 2 <sup>nd</sup> | PLMN 4 | GSM                          |
| EF <sub>OPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN 5 | UTRAN                        |
|                         | 2 <sup>nd</sup> | PLMN 6 | GSM                          |

#### Test procedure

Method B is applied.

- a) ~~The SS activates cells 1-5 and monitors the cells for random access requests from the UE.~~
- b) ~~The UE is switched on.~~
- c) ~~The SS waits for random access requests from the UE.~~
- d) ~~Cell 1 is switched off.~~
- e) ~~The SS waits for random access requests from the UE.~~
- f) ~~Cell 4 is switched off.~~
- g) ~~The SS waits for random access requests from the UE.~~

#### 6.2.1.7.5 Test Requirements

- 1) ~~In step c), the response from the UE shall be on Cell 1 (1<sup>st</sup> priority RAT for EF<sub>PLMNwAcT</sub>). The displayed PLMN shall be PLMN3 (UTRAN).~~
- 2) ~~In step e), the response from the UE shall be on Cell 4 (2<sup>nd</sup> priority RAT for EF<sub>PLMNwAcT</sub>). The displayed PLMN shall be PLMN4 (GSM).~~
- 3) ~~In step g), the response from the UE shall be on Cell 5 (1<sup>st</sup> priority RAT for EF<sub>OPLMNwAcT</sub>). The displayed PLMN shall be PLMN5 (UTRAN).~~

#### 6.2.1.8 Selection of RAT for OPLMN; Automatic mode

##### 6.2.1.8.1 Definition

~~Test to verify that the UE selects the OPLMN RAT according to the OPLMN RAT priority list on the USIM. If no RAT on the list is available, the UE shall not try to obtain registration on the same PLMN(s) with other RAT(s) but instead search for other PLMN/access technology combinations with received high quality signal in random order.~~

##### 6.2.1.8.2 Conformance requirement

##### 1. Automatic Network Selection Mode Procedure:

~~The MS selects and attempts registration on other PLMNs, if available and allowable in the following order:~~

- 1.1 ~~HPLMN (if not previously selected);~~
- 1.2 ~~Each PLMN in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);~~
- 1.3 ~~Each PLMN in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);~~
- 1.4 ~~Other PLMN/access technology combinations with received high quality signal in random order;~~
- 1.5 ~~Other PLMN/access technology combinations in order of decreasing signal quality.~~

~~If successful registration is achieved, the MS indicates the selected PLMN.~~

~~If registration cannot be achieved because no PLMNs are available and allowable, the MS indicates "no service" to the user, waits until a new PLMN is available and allowable and then repeats the procedure.~~

~~If there were one or more PLMNs which were available and allowable, but an LR failure made registration on those PLMNs unsuccessful or an entry in the "forbidden LAs for regional provision of service" list prevented a registration attempt, the MS selects the first such PLMN again and enters a limited service state.~~

#### References

- 1. ~~TS 23.122, clause 4.4.3.1.1.~~

~~NOTE: —TS 31.102 defines the USIM fields.~~

## 6.2.1.8.3 Test purpose

1. To verify that:

1.1 the UE selects the OPLMN RAT according to the OPLMN RAT priority list on the USIM.

1.2 If no RAT on the list is available, the UE does not try to obtain registration on the same PLMN(s) with other RAT(s) but instead searches for "other PLMN/access technology combinations with received high quality signal in random order".

## 6.2.1.8.4 Method of test

Initial conditions

The UE is in automatic PLMN selection mode.

Cell levels are from tables 6.3 and 6.4.

| Cell   | CPICH_Ec / RF<br>signal level<br>[dBm/3.84 MHz]<br>(FDD) | P-CCPCH_RSCP /<br>RF signal level<br>[dBm] (TDD) | Test<br>Channel | PLMN   | Radio Access<br>Technology |
|--------|----------------------------------------------------------|--------------------------------------------------|-----------------|--------|----------------------------|
| Cell 1 | -72                                                      | -61                                              | 1               | PLMN-5 | UTRAN                      |
| Cell 2 | -48                                                      | -48                                              | 1               | PLMN-5 | GSM                        |
| Cell 3 | -75                                                      | -64                                              | 2               | PLMN-6 | UTRAN                      |
| Cell 4 | -50                                                      | -50                                              | 2               | PLMN-6 | GSM                        |
| Cell 5 | -78                                                      | -67                                              | 3               | PLMN-7 | UTRAN                      |

The UE is equipped with a USIM containing default values except for those listed below.

| USIM field              | Priority        | PLMN   | Access<br>Technology<br>Identifier |
|-------------------------|-----------------|--------|------------------------------------|
| EF <sub>LOGI</sub>      |                 | PLMN-1 |                                    |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN-2 | UTRAN                              |
|                         | 2 <sup>nd</sup> |        | GSM                                |
| EF <sub>PLMNwAcT</sub>  | 1 <sup>st</sup> | PLMN-3 | UTRAN                              |
|                         | 2 <sup>nd</sup> | PLMN-4 | GSM                                |
| EF <sub>OPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN-5 | UTRAN                              |
|                         | 2 <sup>nd</sup> | PLMN-6 | GSM                                |

Test procedure

Method B is applied.

a) The SS activates cells 1-5 and monitors the cells for random access requests from the UE.

b) The UE is switched on.

c) The SS waits for random access requests from the UE.

- d) ~~Cell 1 is switched off.~~
- e) ~~The SS waits for random access requests from the UE.~~
- f) ~~Cell 4 is switched off.~~
- g) ~~The SS waits for random access requests from the UE.~~

#### 6.2.1.8.5 ~~Test Requirements~~

- 1) ~~In step c), the response from the UE shall be on Cell 1 (1<sup>st</sup> priority RAT for EF<sub>OPLMNwAcT</sub>). The displayed PLMN shall be PLMN5 (UTRAN).~~
- 2) ~~In step e), the response from the UE shall be on Cell 4 (2<sup>nd</sup> priority RAT for EF<sub>OPLMNwAcT</sub>). The displayed PLMN shall be PLMN6 (GSM).~~
- 3) ~~In step g), the response from the UE shall be on either Cell 2, 3 or 5 (other PLMN/access technology combination) with associated PLMN5 (GSM), PLMN6 (UTRAN) or PLMN7 (UTRAN) shown.~~

#### 6.2.1.9 ~~Selection of "Other PLMN / access technology combinations"; Automatic mode~~

##### 6.2.1.9.1 ~~Definition~~

~~Test to verify that if neither RPLMN, HPLMN, UPLMN nor OPLMN is available, the UE first tries to obtain registration on "Other PLMN/access technology combinations with received high quality signal in random order" and secondly on "Other PLMN/access technology combinations in order of decreasing signal quality".~~

##### 6.2.1.9.2 ~~Conformance requirement~~

##### 1. ~~Automatic Network Selection Mode Procedure;~~

~~The MS selects and attempts registration on other PLMNs, if available and allowable in the following order:~~

- 1.1 ~~HPLMN (if not previously selected);~~
- 1.2 ~~Each PLMN in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);~~
- 1.3 ~~Each PLMN in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);~~
- 1.4 ~~Other PLMN/access technology combinations with received high quality signal in random order;~~
- 1.5 ~~Other PLMN/access technology combinations in order of decreasing signal quality.~~

~~In 1.5, the MS shall order the PLMN/access technology combinations in order of decreasing signal quality within each access technology. The order between PLMN/access technology combinations with different access technologies is an MS implementation issue.~~

~~If successful registration is achieved, the MS indicates the selected PLMN.~~

~~If registration cannot be achieved because no PLMNs are available and allowable, the MS indicates "no service" to the user, waits until a new PLMN is available and allowable and then repeats the procedure.~~

~~If there were one or more PLMNs which were available and allowable, but an LR failure made registration on those PLMNs unsuccessful or an entry in the "forbidden LAs for regional provision of service" list prevented a registration attempt, the MS selects the first such PLMN again and enters a limited service state.~~

~~2. UTRA case: The UE shall scan all RF channels in the UTRA band according to its capabilities to find available PLMNs. On each carrier, the UE shall search for the strongest cell according to the cell search procedures (for FDD, see TS 25.214, and TDD, see TS 25.224) and read its system information, in order to find out which PLMN the cell belongs to. If the UE can read the PLMN identity, the found PLMN shall be reported to the NAS as a high quality PLMN (but without the RSCP value), provided that the following high quality criterion is fulfilled:~~

- ~~— For an FDD cell, the measured primary CPICH RSCP value shall be greater than or equal to -95 dBm.~~
- ~~— For a TDD cell, the measured P-CCPCH RSCP shall be greater than or equal to -84 dBm.~~

Found PLMNs that do not satisfy the high quality criterion, but for which the UE has been able to read the PLMN identities are reported to the NAS together with the CPICH RSCP value for UTRA FDD cells and P-CCPCH RSCP for UTRA TDD cells.

3. ~~GSM case: A PLMN shall be understood to be received with high quality signal if the signal level is above -85 dBm.~~

#### References

1. ~~TS 23.122, clause 4.4.3.1.1.~~

2. ~~TS 25.304, clause 5.1.2.2.~~

3. ~~TS 03.22, clause 4.4.3.~~

NOTE: ~~TS 31.102 defines the USIM fields.~~

#### 6.2.1.9.3 Test purpose

1. ~~To verify that:~~

1.1 ~~If neither RPLMN, HPLMN, UPLMN nor OPLMN is available, the UE tries to obtain registration on "Other PLMN/access technology combinations with received high quality signal in random order".~~

1.2 ~~If no PLMN is available in test purpose 1.1, the UE tries to obtain registration on "Other PLMN/access technology combinations in order of decreasing signal quality".~~

2. ~~The "random order" in test purpose 1.1 is not verified.~~

#### 6.2.1.9.4 Method of test

##### Initial conditions

The UE is in automatic PLMN selection mode.

| Cell   | CPICH_Ec /RF<br>signal level<br>[dBm/3.84 MHz]<br>(FDD) | P-CCPCH_RSCP<br>/ RF signal level<br>[dBm] (TDD) | "High<br>Quality<br>signal" | Test<br>Channel | PLMN    | Radio Access<br>Technology |
|--------|---------------------------------------------------------|--------------------------------------------------|-----------------------------|-----------------|---------|----------------------------|
| Cell 1 | -80                                                     | -69                                              | Yes                         | 1               | PLMN 7  | UTRAN                      |
| Cell 2 | -65                                                     | -65                                              | Yes                         | 1               | PLMN 8  | GSM                        |
| Cell 3 | -98                                                     | -87                                              | No                          | 2               | PLMN 9  | UTRAN                      |
| Cell 4 | -101                                                    | -90                                              | No                          | 2               | PLMN 10 | UTRAN                      |
| Cell 5 | -88                                                     | -88                                              | No                          | 3               | PLMN 11 | GSM                        |
| Cell 6 | -91                                                     | -91                                              | No                          | 3               | PLMN 12 | GSM                        |

The UE is equipped with a USIM containing default values except for those listed below.

| USIM field              | Priority        | PLMN   | Access<br>Technology<br>Identifier |
|-------------------------|-----------------|--------|------------------------------------|
| EF <sub>LOC1</sub>      |                 | PLMN 1 |                                    |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN 2 | UTRAN                              |
|                         | 2 <sup>nd</sup> |        | GSM                                |
| EF <sub>PLMNwAcT</sub>  | 1 <sup>st</sup> | PLMN 3 | UTRAN                              |

|                         |                 |        |       |
|-------------------------|-----------------|--------|-------|
|                         | 2 <sup>nd</sup> | PLMN 4 | GSM   |
| EF <sub>OPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN 5 | UTRAN |
|                         | 2 <sup>nd</sup> | PLMN 6 | GSM   |

Test procedure

Method B is applied.

- a) The SS activates cells 1-6 and monitors the cells for random access requests from the UE.
- b) The UE is switched on.
- c) The SS waits for random access requests from the UE.
- d) The cell on which a response was received, is switched off.
- e) Step c-d) is repeated until the UE informs that no network is available.

#### 6.2.1.9.5 Test Requirements

- 1) In step c), the displayed PLMN is noted.
- 2) When the test procedure has finished, the noted PLMNs shall have appeared in the following order: PLMN7, PLMN8 in random order followed by the other PLMNs. PLMN9 shall come before PLMN10 and PLMN11 shall come before PLMN12.

#### 6.2.2 Cell selection and reselection

##### 6.2.2.1 Cell reselection if cell becomes barred or $S < 0$ ; UTRAN to GSM

###### 6.2.2.1.1 Definition

Test to verify that if both a GSM and UTRAN network is available, the UE performs cell reselection from UTRAN to GSM if the UTRAN cell becomes barred or  $S$  falls below zero.

###### 6.2.2.1.2 Conformance requirement

1. When camped on a cell, the UE shall regularly search for a better cell according to the cell reselection criteria. If a better cell is found, that cell is selected. The change of cell may imply a change of RAT.

2. A "suitable cell" is a cell on which the UE may camp on to obtain normal service. Such a cell shall fulfil all the following requirements:

2.1 The cell is part of the selected PLMN or, of a PLMN considered as equivalent by the UE according to the information provided by the NAS.

2.2 The cell is not barred.

2.3 The cell is not part of the list of "forbidden LAs for roaming".

2.4 The cell selection criteria are fulfilled.

3. When camped normally, the UE shall execute the cell reselection evaluation process on the following occasions/triggers:

3.1 UE internal triggers, so as to meet performance as specified in TS 25.133 for FDD and TS 25.123 for TDD.

3.2 When information on the BCCH used for the cell reselection evaluation procedure has been modified.

4. Cell Reselection Criteria:

4.1 The UE shall perform ranking of all cells that fulfil the  $S$  criterion.

4.2 The cells shall be ranked according to the R criteria specified above, deriving  $Q_{meas,n}$  and  $Q_{meas,s}$  and calculating the R values using CPICH RSCP, P-CCPCH RSCP and the averaged received signal level as specified in TS 25.133 and TS 25.123 for FDD, TDD and GSM cells, respectively. The best ranked cell is the cell with the highest R value. If a TDD or GSM cell is ranked as the best cell, then the UE shall perform cell re-selection to that TDD or GSM cell.

4.3 In all cases, the UE shall reselect the new cell, only if the cell reselection criteria are fulfilled during a time interval  $T_{res}$ .

4.4 The cell-ranking criterion R is derived from Q,  $Q_{hyst}$ ,  $Q_{offset}$ ,  $TEMP\_OFFSET$  and  $PENALTY\_TIME$ . However,  $TEMP\_OFFSET$  and  $PENALTY\_TIME$  are only applicable if the usage of HCS is indicated in system information.

#### References

1. TS 25.304, clause 5.2.1.
2. TS 25.304, clause 4.3.
3. TS 25.304, clause 5.2.5.1.
4. TS 25.304, clause 5.2.6.1.4.

#### 6.2.2.1.3 Test purpose

1. To verify that the UE performs reselection from UTRAN to GSM on the following occasions:

1.1 Serving cell becomes barred.

1.2  $S < 0$  for serving cell.

#### 6.2.2.1.4 Method of test

#### Initial conditions

The USIM does not contain any preferred RAT.

#### Step a-c:

| Parameter          | Unit | Cell 1<br>(UTRAN) |
|--------------------|------|-------------------|
| Test Channel       |      | 1                 |
| CPICH Ec (FDD)     | dBm  | -60               |
| P-CCPCH RSCP (TDD) | dBm  | -63               |
| $Q_{rxlevmin}$     | dBm  | -100              |
| $S_{rxlev}^*$      | dBm  | 40                |
| CellBarred         |      | 0                 |

| Parameter            | Unit | Cell 2<br>(GSM) | Cell 3<br>(GSM) |
|----------------------|------|-----------------|-----------------|
| Test Channel         |      | 1               | 2               |
| RF Signal Level      | dBm  | -80             | -85             |
| $RXLEV\_ACCESS\_MIN$ | dBm  | -100            | -100            |
| $C1^*$               | dBm  | 20              | 15              |

|             |     |     |     |
|-------------|-----|-----|-----|
| FDD_Qmin    | dB  | -20 | -20 |
| FDD_Qoffset | dBm | 0   | 0   |

Step d-f:

|            |      |                   |
|------------|------|-------------------|
| Parameter  | Unit | Cell 1<br>(UTRAN) |
| CellBarred |      | 0 → 1             |

Step g:

|           |      |                   |
|-----------|------|-------------------|
| Parameter | Unit | Cell 1<br>(UTRAN) |
| Qrxlevmin | dB   | -100 → -40        |
| Srxlev*   | dB   | 40 → -20          |

Test procedure

Method B is applied.

- The SS activates cells 1, 2, and 3. The SS monitors cells 1, 2 and 3 for random access requests from the UE.
- The UE is switched on.
- The SS waits for random access request from the UE.
- The SS sets Cell 1 to be barred.
- The SS waits for random access request from the UE.
- The stored information cell selection list in the UE is deleted and the UE is switched off.
- Step a-e) is repeated except that in step d), Qrxlevmin is increased, so S will become negative instead of being barred. Step g does not apply to TDD cells.

#### 6.2.2.1.5 Test Requirements

- In step c), after the UE has responded on Cell 1, it shall not respond on any other cell within 1 min.
- In step e), the UE shall respond on Cell 2.
- In step g), the UE shall respond on Cell 2 after Qrxlevmin is increased. Step g does not apply to the testing of TDD cells.

#### 6.2.2.2 Cell reselection if cell becomes barred or C1 < 0; GSM to UTRAN

##### 6.2.2.2.1 Definition

Test to verify that if both a GSM and UTRAN network is available, the UE performs cell reselection from GSM to UTRAN if the GSM cell becomes barred or the path loss criterion C1 falls below zero for a period of 5 s.

##### 6.2.2.2.2 Conformance requirement

- At least every 5 s the MS shall calculate the value of C1 and C2 for the serving cell and re-calculate C1 and C2 values for non-serving cells (if necessary). The MS shall then check whether:

1.1 The path loss criterion (C1) for current serving cell falls below zero for a period of 5 s. This indicates that the path loss to the cell has become too high.



2. While camped on a cell of the registered PLMN ("camped normally"), the MS may need to select a different cell ("normal cell reselection" state). The following events trigger a cell reselection:

2.1 The path loss criterion parameter C1 (see TS 03.22, clause 3.6) indicates that the path loss to the cell has become too high;

2.2 The cell camped on (current serving cell) has become barred.

#### References

1. TS 05.08, clause 6.6.2.

2. TS 03.22, clause 4.5.

#### 6.2.2.2.3 Test purpose

1. To verify that the UE performs reselection from GSM to UTRAN on the following occasions:

1.1 Serving cell becomes barred.

1.2 The path loss criterion C1 for serving cell falls below zero for a period of 5 s.

#### 6.2.2.2.4 Method of test

#### Initial conditions

The USIM does not contain any preferred RAT. Step a-c:

| Parameter          | Unit | Cell 1<br>(GSM)         |
|--------------------|------|-------------------------|
| Test Channel       |      | 1                       |
| RF Signal Level    | dBm  | -50                     |
| RXLEV_ACCESS_MIN   | dBm  | -70                     |
| MS_TXPWR_MAX = CCH | dBm  | Max. output power of UE |
| FDD_Qmin           | dB   | -20                     |
| FDD_Qoffset        | dBm  | 0                       |
| CellBarred         |      | 0                       |
| C1*                | dBm  | 20                      |

| Parameter          | Unit         | Cell 2<br>(UTRAN) | Cell 3<br>(UTRAN) |
|--------------------|--------------|-------------------|-------------------|
| P-CCPCH_RSCP (FDD) | dBm          | -65               | -67               |
| CPICH_Ec (FDD)     | dBm/3.84 MHz | -60               | -70               |
| Qrxlevmin          | dBm          | -100              | -100              |
| Srxlev*            | dBm          | 40                | 30                |

Step d-e:

| Parameter  | Unit | Cell 1<br>(GSM) |
|------------|------|-----------------|
| CellBarred |      | 0 → 1           |

Step f-g:

| Parameter       | Unit | Cell 1<br>(GSM)              |
|-----------------|------|------------------------------|
| RF Signal Level | dBm  | -50 →<br>-80 (4sec) →<br>-50 |
| C1*             | dBm  | 20 →<br>-10 (4sec) →<br>20   |

Step h:

| Parameter       | Unit | Cell 1<br>(GSM) |
|-----------------|------|-----------------|
| RF Signal Level | dBm  | -50 →<br>-80    |
| C1*             | dBm  | 20 →<br>-10     |

Test procedure

Method B is applied.

- The SS activates cells 1, 2, and 3. The SS monitors cells 1, 2 and 3 for random access requests from the UE.
- The UE is switched on.
- The SS waits for random access request from the UE.
- The SS sets Cell 1 to be barred.
- The SS waits for random access request from the UE.
- The stored information cell selection list in the UE is deleted and the UE is switched off.
- Step a-c) is repeated except that in step d), the SS reduces signal level on Cell 1 to -80 dBm for 4 s and then raises the level back to -50 dBm (C1 becomes -10 dBm during this period).
- The SS reduces signal level on Cell 1 to -80 dBm.

#### 6.2.2.2.5 Test Requirements

- In step c), after the UE has responded on Cell 1, it shall not respond on any other cell within 1 min.
- In step e), the UE shall respond on Cell 2.
- In step g), there shall be no access on Cell 2 within 30 s, after having reduced the signal level on Cell 1.

~~4) In step h), the UE shall respond on Cell 2.~~

### ~~6.2.2.3 Cell reselection timings; GSM to UTRAN~~

#### ~~6.2.2.3.1 Definition~~

~~Test to verify that the UE meets the cell reselection timing requirements when both a GSM and UTRAN network is available.~~

#### ~~6.2.2.3.2 Conformance requirement~~

~~1. If the 3G Cell Reselection list (see TS 04.18) includes UTRAN frequencies, the MS shall, at least every 5 s update the value RLA\_C for the serving cell and each of the at least 6 strongest non-serving GSM cells.~~

~~1.1 The MS shall then reselect a suitable UTRAN cell if its measured RSCP value exceeds the value of RLA\_C for the serving cell and all of the suitable non-serving GSM cells by the value XXX\_Qoffset for a period of 5 s and, for FDD, the UTRAN cells measured Ec/No value is equal or greater than the value FDD\_Qmin.~~

~~— Ec/No and RSCP are the measured quantities.~~

~~— FDD\_Qmin and XXX\_Qoffset are broadcast on BCCH of the serving cell. XXX indicates other radio access technology/mode.~~

~~1.2 In case of a cell reselection occurring within the previous 15 s, XXX\_Qoffset is increased by 5 dB.~~

~~1.3 Cell reselection to UTRAN shall not occur within 5 s after the MS has reselected a GSM from an UTRAN cell if a suitable GSM cell can be found.~~

~~1.4 If more than one UTRAN cell fulfils the above criteria, the UE shall select the cell with the greatest RSCP value.~~

~~2. The MS shall be able to identify and select a new best UTRAN cell on a frequency, which is part of the 3G Cell Reselection list, within 30 s after it has been activated under the condition that there is only one UTRAN frequency in the list and under good radio conditions.~~

~~— The allowed time is increased by 30 s for each additional UTRAN frequency in the 3G Cell Reselection list. However, multiple UTRAN cells on the same frequency in the neighbour cell list does not increase the allowed time.~~

~~NOTE: — Definitions of measurements are in TS 25.215 and TS 25.101 for FDD mode, in TS 25.225 and TS 25.102 for TDD mode, clause 3.2 and TS 05.08, clause 6.1.~~

#### ~~References~~

~~1. TS 05.08, clause 6.6.5.~~

~~2. TS 05.08, clause 6.6.4.~~

#### ~~6.2.2.3.3 Test purpose~~

~~1. To verify that:~~

~~1.1 The UE meets conformance requirement 1.1 and additionally, that no reselection is performed if the period is less than 5 s~~

~~1.2 The UE meets conformance requirement 1.2.~~

~~1.3 The UE meets conformance requirement 1.3.~~

#### ~~6.2.2.3.4 Method of test~~

##### ~~Initial conditions~~

~~The USIM does not contain any preferred RAT.~~

~~Step a-c:~~

| Parameter        | Unit | Cell 1 (GSM)            | Cell 2 (GSM)            |
|------------------|------|-------------------------|-------------------------|
| Test Channel     |      | 1                       | 2                       |
| RF Signal Level  | dBm  | -70                     | -85                     |
| RXLEV_ACCESS_MIN | dBm  | -100                    | -100                    |
| MS_TXPWR_MAX_CCH | dBm  | Max. output power of UE | Max. output power of UE |
| FDD_Qmin         | dBm  | -20                     | -20                     |
| FDD_Qoffset      | dBm  | 5                       | 5                       |

| Parameter          | Unit | Cell 3 (UTRAN) |
|--------------------|------|----------------|
| Test Channel       |      | 1              |
| CPICH_RSCP (FDD)   | dBm  | -74            |
| P-CCPCH_RSCP (TDD) | dBm  | -63            |
| Qrxlevmin          | dBm  | -100           |
| Srxlev*            | dBm  | 26             |

Step d-g:

| Parameter       | Unit | Cell 1 (GSM)                | Cell 2 (GSM) |
|-----------------|------|-----------------------------|--------------|
| RF Signal Level | dBm  | -70 →<br>-82 (4 s) →<br>-70 | OFF          |

Step h-j:

| Parameter       | Unit | Cell 1 (GSM) | Cell 2 (GSM) |
|-----------------|------|--------------|--------------|
| RF Signal Level | dBm  | -82 →<br>-70 | OFF          |

Step k-m:

| Parameter       | Unit | Cell 1 (GSM)          | Cell 2 (GSM) |
|-----------------|------|-----------------------|--------------|
| RF Signal Level | dBm  | -82 →<br>-70 →<br>-82 | OFF          |

Test procedure

NOTE: — Step a-c): Test purpose 1.3. Step d-g): test purpose 1.1. Step h-k): test purpose 1.2.

Method A is applied.

- a) ~~The SS activates the channels. The UE is not paged on any of the cells.~~
- b) ~~The UE is switched on.~~
- c) ~~After 50 s, the SS starts paging continuously on cells 1 and 3 for 20 s. The SS monitors cells 1 and 3 for random access requests from the UE.~~
- d) ~~Cell 2 is switched off. The SS stops paging on the cells and waits for 20 s. (The UE should revert to Cell 1 due to cell reselection).~~
- e) ~~The SS starts paging continuously on Cell 3.~~
- f) ~~The SS decreases the transmit level of Cell 1 to -82 dBm for a period of 4 s (RSCP will then exceed RXLEV by more than XXX\_Qoffset) and then changes the level back to -70 dBm.~~
- g) ~~The SS waits to see if there is any random access requests from the UE on Cell 3.~~
- h) ~~The SS stops paging on all cells and sets the transmit level of Cell 1 to -82 dBm.~~
- i) ~~The SS waits 20 s and then starts paging continuously on Cell 1. (The UE should revert to Cell 3 due to cell reselection).~~
- j) ~~The SS increases the transmit level of Cell 1 to -70 dBm and waits for the UE to access on Cell 1. The SS records the time t from the increase in the level of Cell 1 to the first response from the UE.~~
- k) ~~The SS stops paging on all cells and sets the transmit level of Cell 1 back to -82 dBm.~~
- l) ~~The SS waits 20 s (The UE should revert to Cell 3 due to cell reselection).~~
- m) ~~The SS increases the transmit level of Cell 1 to -70 dBm. After t+2 s (i.e. 2 s after reselection to Cell 1), the SS starts paging continuously on Cell 3, changes the level of Cell 1 back to -82 dBm and waits to see if there is any random access request on Cell 3. (Within 15 sec after reselection to GSM, the level of Cell 1 is -82 + 10 dBm = -72 dBm. After the 15 s period, the level of Cell 1 is -82 + 5 dBm = -77 dBm. The level of Cell 3 is -74 dBm, thus leading to reselection to Cell 3 after 15 s).~~

#### 6.2.2.3.5 Test Requirements

- 1) ~~In step c), after the UE has reselected Cell 1 from Cell 3 as indicated by random access requests, any random access requests on Cell 3 shall not occur within 4,5 s of the last random access request on Cell 1.~~
- 2) ~~In step g), there shall be no access on Cell 3 within 34 s of decreasing the level of Cell 1.~~
- 3) ~~In step j), the UE shall respond on Cell 1.~~
- 4) ~~In step m), there shall be no response on Cell 3 within 11 s after the level of Cell 1 is changed back to -82 dBm.~~

NOTE: — The 11 s is derived from (t+15) s minimum cell reselection timer minus (t+2) s from the start of step m) up to the decrease of the level of Cell 1. A further 2 s are subtracted to cover for any uncertainty introduced by the random access process occurring after step g).

## 7 Layer 2

### 7.1 MAC

#### General

If not otherwise mentioned, the same procedures as used in RRC test specification (TS 34.123-1) or in the Generic procedure (TS 34.108) applies to reach Initial conditions for MAC testing.

If not explicitly described, the same message contents and settings are applied as described in the RRC test description default settings.

#### 7.1.1 Mapping between logical channels and transport channels

##### 7.1.1.1 CCCH mapped to RACH/FACH / Invalid TCTF


###### 7.1.1.1.1 Definition

This tests that the MAC applies the correct header to the MAC PDU according to the type of logical channel carried on the RACH/FACH transport channel. Incorrect application of MAC headers would result in inoperation of the UE.

###### 7.1.1.1.2 Conformance requirement

CCCH mapped to RACH/FACH:

- TCTF field is included in MAC header.



The following fields are defined for the MAC header:

- Target Channel Type Field
- ...

#### Coding of the Target Channel Type Field on FACH for FDD

| TCTF              | Designation                                                                           |
|-------------------|---------------------------------------------------------------------------------------|
| 00                | BCCH                                                                                  |
| 01000000          | CCCH                                                                                  |
| 01000001-01111111 | Reserved<br>(PDUs with this coding will be discarded by this version of the protocol) |
| 10000000          | CTCH                                                                                  |
| 10000001-10111111 | Reserved<br>(PDUs with this coding will be discarded by this version of the protocol) |
| 11                | DCCH or DTCH over FACH                                                                |

#### Reference(s)

TS 25.321 clauses 9.2.1 and 9.2.1.4.

### 7.1.1.1.3 Test purpose

1. To verify that the UE discards PDUs with reserved or incorrect values in the TCTF field.
2. To verify that the TCTF field is correctly applied when a CCCH is mapped to the RACH/FACH.

### 7.1.1.1.4 Method of test

#### Initial conditions

#### System Simulator:

- 1 cell, default parameters, Ciphering Off.
- The SCCPCH is configured as specified in TS 34.108 clause 6.10.2.4.3.3 (Interactive/Background 32 kbps RAB + SRB for PCCH + SRB for CCCH + SRB for DCCH + SRB for BCCH) with the following exceptions for the FACH:

|                                                                                                                                                                      |                                             |           |                    |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------|-----------|--------------------|
| Higher layer                                                                                                                                                         | RAB/signalling-RB                           |           | SRB#1              |
|                                                                                                                                                                      | User of Radio Bearer                        |           | Test               |
| RLC                                                                                                                                                                  | Logical channel type                        |           | CCCH               |
|                                                                                                                                                                      | RLC mode                                    |           | TM                 |
|                                                                                                                                                                      | Payload sizes, bit                          |           | 168                |
|                                                                                                                                                                      | Max data rate, bps                          |           | 33600 (alt. 50400) |
|                                                                                                                                                                      | RLC header, bit                             |           | 0                  |
| MAC                                                                                                                                                                  | MAC header, bit                             |           | 0 (note)           |
|                                                                                                                                                                      | MAC multiplexing                            |           | Simulated by SS    |
| Layer 1                                                                                                                                                              | TrCH type                                   |           | FACH               |
|                                                                                                                                                                      | TB sizes, bit                               |           | 168                |
|                                                                                                                                                                      | TFS                                         | TF0, bits | 0 x 168            |
|                                                                                                                                                                      |                                             | TF1, bits | 1 x 168            |
|                                                                                                                                                                      |                                             | TF2, bits | 2 x 168            |
|                                                                                                                                                                      |                                             | TF3, bits | N/A (alt. 3 x 168) |
|                                                                                                                                                                      | TTI, ms                                     |           | 10                 |
|                                                                                                                                                                      | Coding type                                 |           | CC-1/2             |
|                                                                                                                                                                      | CRC, bit                                    |           | 16                 |
|                                                                                                                                                                      | Max number of bits/TTI before rate matching |           | 752 (alt. 1136)    |
|                                                                                                                                                                      | RM attribute                                |           | 200-240            |
| NOTE: —The SS MAC layer must be configured not to add a MAC header so that the header can be added by the test case in order to create the necessary invalid values. |                                             |           |                    |

- And using the configuration in TS 34.108 clause 6.10.2.4.3.3 for the PCH.

- The TFCS should be configured as specified in clause 6.10.2.4.3.3.1.4.

#### User Equipment:

- The UE shall operate under normal test conditions, Ciphering Off.
- The Test-USIM shall be inserted.
- The SS starts broadcasting the System Information as specified in TS 34.108 clause 6.1, using the configuration for the PRACH and SCCPCH (signalled in SYSTEM INFORMATION 5) as follows:
  1. The SCCPCH is configured as specified in TS 34.108 clause 6.10.2.4.3.3 (Interactive/Background 32 kbps RAB + SRB for PCCH + SRB for CCCH + SRB for DCCH + SRB for BCCH).
  2. The PRACH is configured as specified in TS 34.108 clause 6.10.2.4.4.1.

~~—The SS follows the procedure in TS 34.108 clause 7.2.2.1 (CS UE) or 7.2.2.2 (PS UE) so that the UE shall be in idle mode and registered.~~

#### ~~Test procedure~~

- ~~a) The SS pages the UE.~~
- ~~b) The SS waits for the first RRC CONNECTION REQUEST message to arrive on the PRACH/CCCH.~~
- ~~c) The SS responds with an RRC CONNECTION SETUP message (specified in TS 34.108 clause 9: Contents of RRC CONNECTION SETUP message: UM (Transition to CELL\_DCH). In this case the SS will transmit the message in 152-bit (note) segments, with a valid UM RLC header and with the MAC header set as follows:~~

| Field | Value |
|-------|-------|
| TCTF  | 00'B  |

~~NOTE:—In the case of a 2-bit MAC header the segment shall be padded to the correct length.~~

- ~~d) The SS waits for retransmission of the RRC CONNECTION REQUEST on the PRACH/CCCH due to expiry of timer T300.~~
- ~~e) The SS repeats steps c) and d), with the TCTF field set as follows:~~

| Iteration | TCTF Value |
|-----------|------------|
| 2         | 01000001'B |
| 3         | 10000000'B |
| 4         | 10000001'B |
| 5         | 11'B       |

- ~~f) The SS repeats steps c) and d), with the TCTF field set as to 01000000'B.~~



## Expected sequence

| Step | Direction |    | Message                                                              | Comments                                         |
|------|-----------|----|----------------------------------------------------------------------|--------------------------------------------------|
|      | UE        | SS |                                                                      |                                                  |
| 1    | ←         |    | PAGING-TYPE 1                                                        |                                                  |
| 2    | →         |    | RRC CONNECTION REQUEST                                               |                                                  |
| 3    | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT 1))        | Sent with incorrect TCTF = 00'B                  |
|      | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT 2))        | Sent with incorrect TCTF = 00'B                  |
|      |           |    | ...                                                                  |                                                  |
|      | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT n))        | Sent with incorrect TCTF = 00'B                  |
| 4    | →         |    | RRC CONNECTION REQUEST                                               |                                                  |
| 5    | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT 1))        | Sent with incorrect TCTF = 0100 0001'B           |
|      | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT 2))        | Sent with incorrect TCTF = 0100 0001'B           |
|      |           |    | ...                                                                  |                                                  |
|      | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT n))        | Sent with incorrect TCTF = 0100 0001'B           |
| 6    | →         |    | RRC CONNECTION REQUEST                                               |                                                  |
| 7    | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT 1))        | Sent with incorrect TCTF = 1000 0000'B           |
|      | ←         |    | MAC PDU(TCTF, UE-ID, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT 2)) | Sent with incorrect TCTF = 1000 0000'B           |
|      |           |    | ...                                                                  |                                                  |
|      | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT n))        | Sent with incorrect TCTF = 1000 0000'B           |
| 8    | →         |    | RRC CONNECTION REQUEST                                               |                                                  |
| 9    | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT 1))        | Sent with incorrect TCTF = 1000 0001'B           |
|      | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT 2))        | Sent with incorrect TCTF = 1000 0001'B           |
|      |           |    | ...                                                                  |                                                  |
|      | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT n))        | Sent with incorrect TCTF = 1000 0001'B           |
| 10   | →         |    | RRC CONNECTION REQUEST                                               |                                                  |
| 11   | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT 1))        | Sent with incorrect TCTF = 11'B                  |
|      | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT 2))        | Sent with incorrect TCTF = 'B                    |
|      |           |    | ...                                                                  |                                                  |
|      | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT n))        | Sent with incorrect TCTF = 'B                    |
| 12   | →         |    | RRC CONNECTION REQUEST                                               |                                                  |
| 13   | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT 1))        | Sent with correct TCTF = 0100 0000'B             |
|      | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT 2))        | Sent with correct TCTF = 0100 0000'B             |
|      |           |    | ...                                                                  |                                                  |
|      | ←         |    | MAC PDU(TCTF, RLC UM PDU(SN, RRC CONNECTION SETUP SEGMENT n))        | Sent with correct TCTF = 0100 0000'B             |
| 14   | →         |    | RRC CONNECTION SETUP COMPLETE                                        | TCTF Field is recognised as correct for the CCCH |

## Specific Message Contents

None.

**7.1.1.1.5 ——— Test Requirement**

On the first iteration, and on each iteration in step e) the UE should not recognise the RRC CONNECTION SETUP message and therefore should retransmit the RRC CONNECTION REQUEST after each expiry of T300 (the UE should send up to N300=7 RRC CONNECTION REQUESTs before abandoning the procedure).

On the final iteration the UE should respond with an RRC CONNECTION SETUP COMPLETE message.

**7.1.1.2 ——— DTCH or DCCH mapped to RACH/FACH / Invalid TCTF****7.1.1.2.1 ——— Definition**

This tests that the MAC applies the correct header to the MAC PDU according to the type of logical channel carried on the RACH/FACH transport channel. Incorrect application of MAC headers would result in inoperation of the UE.

**7.1.1.2.2 ——— Conformance requirement**

DTCH or DCCH mapped to RACH/FACH:

TCTF field, C/T field, UE-Id type field and UE-Id are included in the MAC header.

The following fields are defined for the MAC header:

—— Target Channel Type Field

...

**Coding of the Target Channel Type Field on FACH for FDD**

| TCTF                  | Designation                                                                                 |
|-----------------------|---------------------------------------------------------------------------------------------|
| 00                    | BCCH                                                                                        |
| 01000000              | CCCH                                                                                        |
| 01000001-<br>01111111 | Reserved<br>(PDUs with this coding<br>will be discarded by this<br>version of the protocol) |
| 10000000              | CTCH                                                                                        |
| 10000001-<br>10111111 | Reserved<br>(PDUs with this coding<br>will be discarded by this<br>version of the protocol) |
| 11                    | DCCH or DTCH<br>over FACH                                                                   |

**Reference(s)**

TS 25.321 clauses 9.2.1 and 9.2.1.1 c).

**7.1.1.2.3 ——— Test purpose**

1. To verify that the UE discards PDUs with reserved or incorrect values in the TCTF field.
2. To verify that the TCTF field, C/T field, UE-Id type and UE-Id field are correctly applied when a DTCH or DCCH is mapped to the RACH/FACH.

**7.1.1.2.4 ——— Method of test****Initial conditions****System Simulator:**

—— 1 cell, default parameters, Ciphering Off.

- The SCCPCH is configured as specified in TS 34.108 clause 6.10.2.4.3.3 (Interactive/Background 32 kbps RAB + SRB for PCCH + SRB for CCCH + SRB for DCCH + SRB for BCCH) with the following exceptions for the FACH:

|                                                                                                                                                                     |                                             |           |                    |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------|-----------|--------------------|
| Higher layer                                                                                                                                                        | RAB/signalling RB                           |           | RB#3 (SRB#3)       |
|                                                                                                                                                                     | User of Radio Bearer                        |           | Test               |
| RLC                                                                                                                                                                 | Logical channel type                        |           | DCCH               |
|                                                                                                                                                                     | RLC mode                                    |           | TM                 |
|                                                                                                                                                                     | Payload sizes, bit                          |           | 168                |
|                                                                                                                                                                     | Max data rate, bps                          |           | 33600 (alt. 50400) |
|                                                                                                                                                                     | RLC header, bit                             |           | 0                  |
| MAC                                                                                                                                                                 | MAC header, bit                             |           | 0 (note)           |
|                                                                                                                                                                     | MAC multiplexing                            |           | Simulated by SS    |
| Layer 1                                                                                                                                                             | TrCH type                                   |           | FACH               |
|                                                                                                                                                                     | TB sizes, bit                               |           | 168                |
|                                                                                                                                                                     | TFS                                         | TF0, bits | 0 x 168            |
|                                                                                                                                                                     |                                             | TF1, bits | 1 x 168            |
|                                                                                                                                                                     |                                             | TF2, bits | 2 x 168            |
|                                                                                                                                                                     |                                             | TF3, bits | N/A (alt. 3 x 168) |
|                                                                                                                                                                     | TTI, ms                                     |           | 10                 |
|                                                                                                                                                                     | Coding type                                 |           | CC 1/2             |
|                                                                                                                                                                     | CRC, bit                                    |           | 16                 |
|                                                                                                                                                                     | Max number of bits/TTI before rate matching |           | 752 (alt. 1136)    |
|                                                                                                                                                                     | RM attribute                                |           | 200-240            |
| NOTE: The SS MAC layer must be configured not to add a MAC header so that the header can be added by the test case in order to create the necessary invalid values. |                                             |           |                    |

- and using the configuration in TS 34.108 clause 6.10.2.4.3.3 for the PCH.

- The TFCS should be configured as specified in clause 6.10.2.4.3.3.1.4.

#### User Equipment:

- The UE shall operate under normal test conditions, Ciphering Off.
- The Test-USIM shall be inserted.
- The SS starts broadcasting the System Information as specified in TS 34.108 clause 6.1, using the configuration for the PRACH and SCCPCH (signalled in SYSTEM INFORMATION 5) as follows:
1. The SCCPCH is configured as specified in TS 34.108 clause 6.10.2.4.3.3 (Interactive/Background 32 kbps RAB + SRB for PCCH + SRB for CCCH + SRB for DCCH + SRB for BCCH).
  2. The PRACH is configured as specified in TS 34.108 clause 6.10.2.4.4.1.
- The SS follows the procedure in TS 34.108 clause 7.4.2.1 (Mobile Terminated) so that the UE shall be in state BGP 6-2 (CS-CELL\_FACH\_INITIAL) with the following exception:
1. The RLC entity for RB#3 (SRB#3), AM DCCH for high priority NAS signalling has Missing PDU Indicator enabled.
  2. The RLC entity for RB#3 (SRB#3), AM DCCH for high priority NAS signalling, has Transmission window size set to 128, and has Receive window size set to 128.

#### Test procedure

- a) The SS receives the PAGING RESPONSE message from the UE and checks the TCTF field.
- b) The SS transmits MAC PDUs containing RLC AM PDUs containing a DIRECT TRANSFER message containing an AUTHENTICATION REQUEST message.

—The DIRECT TRANSFER message shall be segmented into 128-bit PDUs, with correct RLC AM headers.

—The MAC header shall be set as follows:

| Field      | Value                                                     |
|------------|-----------------------------------------------------------|
| TCTF       | 00'B                                                      |
| UE-ID Type | C-RNTI                                                    |
| UE-ID      | As set in RRC CONNECTION SETUP message.                   |
| C/T        | Logical Channel ID for SRB #3 (AM-DCCH-NAS High Priority) |

—Where a TCTF size of 8-bits is used, 6-bits from the RLC payload shall be discarded.

c) The SS again transmits MAC PDUs as in b) above, but this time uses the correct TCTF of 11'B. The sequence numbers in the RLC headers shall be incremented normally from those sent in b).

d) The SS receives a STATUS PDU on SRB #3 AM RLC on the RACH due to detection of missing PDUs.

e) The SS repeats steps b), c) and d), with the TCTF field set as follows:

| Iteration | TCTF Value |
|-----------|------------|
| 2         | 01000000'B |
| 3         | 01000001'B |
| 4         | 10000000'B |
| 5         | 10000001'B |

#### Expected sequence

| Step | Direction |    | Message                                                                                            | Comments                                                                                |
|------|-----------|----|----------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                                                    |                                                                                         |
| 1    | →         |    | PAGING RESPONSE                                                                                    | Check TCTF                                                                              |
| 2    | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 1))     | Sent with incorrect TCTF = 00'B, 0100-0000'B, 0100-0001'B, 1000-0000'B, or 1000-0001'B, |
|      | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+1, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 2))   | Sent with incorrect TCTF = 00'B, 0100-0000'B, 0100-0001'B, 1000-0000'B, or 1000-0001'B, |
|      |           |    | ...                                                                                                |                                                                                         |
|      | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+n, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT n))   | Sent with incorrect TCTF = 00'B, 0100-0000'B, 0100-0001'B, 1000-0000'B, or 1000-0001'B, |
| 3    | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+n+1, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 1)) | Sent with correct TCTF = 11'B                                                           |
|      | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+n+2, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 2)) | Sent with correct TCTF = 11'B                                                           |
|      |           |    | ...                                                                                                |                                                                                         |
|      | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+n+n, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT n)) | Sent with correct TCTF = 11'B                                                           |
| 4    | →         |    | RLC-STATUS-PDU                                                                                     | NAK PDUs with SN = x to x+n                                                             |
| 5    | →         |    | AUTHENTICATION RESPONSE                                                                            | TCTF Field is recognised as correct for the DCCH                                        |

Expected sequence is repeated for iterations 2 to 5.

## Specific Message Contents

None

### 7.1.1.2.5 Test Requirement

In step a) the TCTF field should have the value 00'B. Note that this may be implied from receipt of the PAGING RESPONSE message correctly by the SS test script.

On the first iteration, and on each iteration in step d) the UE shall transmit a STATUS PDU on the RLC AM entity associated with SRB #3 each time the first PDU with TCTF=11'B is received in step c), negatively acknowledging the PDUs transmitted in step b) as missing.

At the end of each expected sequence the SS shall receive an AUTHENTICATION RESPONSE message.

### 7.1.1.3 DTCH or DCCH mapped to RACH/FACH / Invalid C/T Field

#### 7.1.1.3.1 Definition

This tests that the MAC applies the correct header to the MAC PDU according to the type of logical channel carried on the RACH/FACH transport channel. Incorrect application of MAC headers would result in inoperation of the UE.

#### 7.1.1.3.2 Conformance requirement

DTCH or DCCH mapped to RACH/FACH:

TCTF field, C/T field, UE-Id type field and UE-Id are included in the MAC header.

The following fields are defined for the MAC header:

##### — C/T field

The C/T field provides identification of the logical channel instance when multiple logical channels are carried on the same transport channel...

**Structure of the C/T field**

| C/T field | Designation                                                                           |
|-----------|---------------------------------------------------------------------------------------|
| 0000      | Logical channel 1                                                                     |
| 0001      | Logical channel 2                                                                     |
| ...       | ...                                                                                   |
| 1110      | Logical channel 15                                                                    |
| 1111      | Reserved<br>(PDUs with this coding will be discarded by this version of the protocol) |

## Reference(s)

TS 25.321 clauses 9.2.1 and 9.2.1.1 c).

### 7.1.1.3.3 Test purpose

1. To verify that the UE discards PDUs with reserved or incorrect values in C/T field.
2. To verify that the TCTF field, C/T field, UE-Id type and UE-Id field are correctly applied when a DTCH or DCCH is mapped to the RACH/FACH.

### 7.1.1.3.4 Method of test

Initial conditions

System Simulator:

See clause 7.1.1.2.4.

**User Equipment:**

See clause 7.1.1.2.4.

**Test procedure**

a) The SS receives the **PAGING RESPONSE** message from the UE and checks the **C/T** field.

b) The SS transmits MAC PDUs containing RLC AM PDUs containing a **DIRECT TRANSFER** message containing an **AUTHENTICATION REQUEST** message:

— The **DIRECT TRANSFER** message shall be segmented into 128-bit PDUs, with correct RLC AM headers.

— The MAC header shall be set as follows:

| Field      | Value                                   |
|------------|-----------------------------------------|
| TCTF       | 11'B                                    |
| UE ID Type | C-RNTI                                  |
| UE ID      | As set in RRC CONNECTION SETUP message. |
| C/T        | 0111'B                                  |

c) The SS again transmits MAC PDUs as in b) above, but this time uses the correct **C/T** value for **AM-DCCH-NAS** High Priority of 0010'B. The sequence numbers in the RLC headers shall be incremented normally from those sent in b).

d) The SS receives a **STATUS PDU** on **SRB #3 AM RLC** on the **RACH** due to detection of missing PDUs.

e) The SS repeats steps b), c) and d), with the **C/T** field set as follows:

| Iteration | C/T Value |
|-----------|-----------|
| 2         | 1111'B    |

## Expected sequence

| Step | Direction |    | Message                                                                                            | Comments                                        |
|------|-----------|----|----------------------------------------------------------------------------------------------------|-------------------------------------------------|
|      | UE        | SS |                                                                                                    |                                                 |
| 1    | →         |    | PAGING RESPONSE                                                                                    | Check C/T field                                 |
| 2    | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 1))     | Sent with incorrect C/T = 0111'B, or 1111'B.    |
|      | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+1, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 2))   | Sent with incorrect C/T = 0111'B, or 1111'B.    |
|      |           |    | ...                                                                                                |                                                 |
|      | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+n, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT n))   | Sent with incorrect C/T = 0111'B, or 1111'B.    |
| 3    | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+n+1, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 1)) | Sent with correct C/T = 0010'B                  |
|      | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+n+2, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 2)) | Sent with correct C/T = 0010'B                  |
|      |           |    | ...                                                                                                |                                                 |
|      | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+n+n, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT n)) | Sent with correct C/T = 0010'B                  |
| 4    | →         |    | RLC-STATUS-PDU                                                                                     | NAK PDUs with SN = x to x+n                     |
| 5    | →         |    | AUTHENTICATION RESPONSE                                                                            | C/T Field is recognised as correct for the DCCH |

Expected sequence is repeated for iteration 2.

## Specific Message Contents

None

## 7.1.1.3.5 — Test Requirement

In step a) the C/T field should be set to the Logical Channel ID for SRB #4 (0010'B). Note that this may be implied from receipt of the PAGING RESPONSE message correctly by the SS test script.

On the first iteration, and on each iteration in step d) the UE shall transmit a STATUS PDU on the RLC AM entity associated with SRB #3 each time the first PDU with C/T=0010'B is received in step c), negatively acknowledging the PDUs transmitted in step b) as missing.

At the end of each expected sequence the SS shall receive an AUTHENTICATION RESPONSE message.

## 7.1.1.4 — DTCH or DCCH mapped to RACH/FACH / Invalid UE ID Type Field

## 7.1.1.4.1 — Definition

This tests that the MAC applies the correct header to the MAC PDU according to the type of logical channel carried on the RACH/FACH transport channel. Incorrect application of MAC headers would result in inoperation of the UE.

## 7.1.1.4.2 — Conformance requirement

DTCH or DCCH mapped to RACH/FACH:

TCTF field, C/T field, UE-Id type field and UE-Id are included in the MAC header.

The following fields are defined for the MAC header:

—UE-Id Type

The UE-Id Type field is needed to ensure correct decoding of the UE-Id field in MAC Headers.

**Table 9.2.1.7: UE-Id Type field definition**

| UE-Id Type field 2 bits | UE-Id Type                                                                            |
|-------------------------|---------------------------------------------------------------------------------------|
| 00                      | U-RNTI                                                                                |
| 01                      | C-RNTI                                                                                |
| 10                      | Reserved<br>(PDUs with this coding will be discarded by this version of the protocol) |
| 11                      | Reserved<br>(PDUs with this coding will be discarded by this version of the protocol) |

**Reference(s)**

TS 25.321 clauses 9.2.1 and 9.2.1.1 c).

**7.1.1.4.3 ————— Test purpose**

1. To verify that the UE discards PDUs with reserved values in UE-Id type field.
2. To verify that the TCTF field, C/T field, UE-Id type and UE-Id field are correctly applied when a DTCH or DCCH is mapped to the RACH/FACH.

**7.1.1.4.4 ————— Method of test**

**Initial conditions**

System Simulator:

See clause 7.1.1.2.4.

User Equipment:

See clause 7.1.1.2.4.

**Test procedure**

- a) The SS receives the PAGING RESPONSE message from the UE and checks the UE-Id Type field.
  - b) The SS transmits MAC PDUs containing RLC AM PDUs containing a DIRECT TRANSFER message containing an AUTHENTICATION REQUEST message.
- The DIRECT TRANSFER message shall be segmented into 128-bit PDUs, with correct RLC AM headers.
- The MAC header shall be set as follows:

| Field      | Value                                                             |
|------------|-------------------------------------------------------------------|
| TCTF       | 11'B                                                              |
| UE ID Type | 10'B                                                              |
| UE ID      | As set in RRC CONNECTION SETUP message.                           |
| C/T        | Logical Channel ID for SRB #3 (AM-DCCH NAS High Priority): 0010'B |



- c) The SS again transmits MAC PDUs as in b) above, but this time uses the correct UE-Id type value for C-RNTI of 01'B. The sequence numbers in the RLC headers shall be incremented normally from those sent in b).
- d) The SS receives a STATUS PDU on SRB #3 AM RLC on the RACH due to detection of missing PDUs.
- e) The SS repeats steps b), c) and d), with the UE-Id type field set as follows:

| Iteration | UE-Id type Value |
|-----------|------------------|
| 2         | 11'B             |

#### Expected sequence

| Step | Direction |    | Message                                                                                            | Comments                                        |
|------|-----------|----|----------------------------------------------------------------------------------------------------|-------------------------------------------------|
|      | UE        | SS |                                                                                                    |                                                 |
| 1    | →         |    | PAGING RESPONSE                                                                                    | Check UE-Id Type                                |
| 2    | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 1))     | Sent with incorrect UE-Id Type = 10'B, or 11'B. |
|      | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+1, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 2))   | Sent with incorrect UE-Id Type = 10'B, or 11'B. |
|      | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+n, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT n))   | Sent with incorrect UE-Id Type = 10'B, or 11'B. |
| 3    | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+n+1, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 1)) | Sent with correct UE-Id Type = 01'B             |
|      | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+n+2, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 2)) | Sent with correct UE-Id Type = 01'B             |
|      | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+n+n, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT n)) | Sent with correct UE-Id Type = 01'B             |
| 4    | →         |    | RLC-STATUS-PDU                                                                                     | NAK PDUs with SN = x to x+n                     |
| 5    | →         |    | AUTHENTICATION RESPONSE                                                                            | UE-Id is recognised as correct for the UE       |

Expected sequence is repeated for iteration 2.

#### Specific Message Contents

None

#### 7.1.1.4.5 Test Requirement

In step a) the UE-Id Type field should be set to 01'B. Note that this may be implied from receipt of the PAGING RESPONSE message correctly by the SS test script.

On the first iteration, and on each iteration in step d) the UE shall transmit a STATUS PDU on the RLC AM entity associated with SRB #3 each time the first PDU with UE-Id Type=01'B is received in step c), negatively acknowledging the PDUs transmitted in step b) as missing.

At the end of each expected sequence the SS shall receive an AUTHENTICATION RESPONSE message.

### ~~7.1.1.5 DTCH or DCCH mapped to RACH/FACH / Incorrect UE Id~~

#### ~~7.1.1.5.1 Definition~~

~~This tests that the MAC applies the correct header to the MAC PDU according to the type of logical channel carried on the RACH/FACH transport channel. Incorrect application of MAC headers would result in inoperation of the UE.~~

#### ~~7.1.1.5.2 Conformance requirement~~

~~DTCH or DCCH mapped to RACH/FACH:~~

~~TCTF field, C/T field, UE-Id type field and UE-Id are included in the MAC header.~~

~~The following fields are defined for the MAC header:~~

##### ~~— UE-Id~~

~~The UE-Id field provides an identifier of the UE on common transport channels...~~

**Lengths of UE Id field**

| <b>UE Id type</b> | <b>Length of UE Id field</b> |
|-------------------|------------------------------|
| <b>U-RNTI</b>     | <b>32 bits</b>               |
| <b>C-RNTI</b>     | <b>16 bits</b>               |

#### ~~Reference(s)~~

~~TS 25.321 clauses 9.2.1 and 9.2.1.1 c).~~

#### ~~7.1.1.5.3 Test purpose~~

- ~~1. To verify that the UE ignores PDUs with UE-Ids that do not match the Id allocated to it.~~
- ~~2. To verify that the TCTF field, C/T field, UE-Id type and UE-Id field are correctly applied when a DTCH or DCCH is mapped to the RACH/FACH.~~

#### ~~7.1.1.5.4 Method of test~~

#### ~~Initial conditions~~

~~System Simulator:~~

~~See clause 7.1.1.2.4.~~

~~User Equipment:~~

~~See clause 7.1.1.2.4.~~

#### ~~Test procedure~~

- ~~a) The SS receives the PAGING RESPONSE message from the UE and checks the UE-Id field.~~
  - ~~b) The SS transmits MAC PDUs containing RLC AM PDUs containing a DIRECT TRANSFER message containing an AUTHENTICATION REQUEST message.~~
- ~~— The DIRECT TRANSFER message shall be segmented into 128-bit PDUs, with correct RLC AM headers.~~
- ~~— The MAC header shall be set as follows:~~

| Field      | Value                                                             |
|------------|-------------------------------------------------------------------|
| TCTF       | 11'B                                                              |
| UE-ID-Type | C-RNTI                                                            |
| UE-ID      | Address allocated in RRC CONNECTION SETUP message + 1.            |
| C/T        | Logical Channel ID for SRB #3 (AM-DCCH-NAS High Priority): 0010'B |

c) The SS again transmits MAC PDUs as in b) above, but this time uses the correct UE-Id value of the address allocated in the RRC CONNECTION SETUP message. The sequence numbers in the RLC headers shall be incremented normally from those sent in b).

d) The SS receives a STATUS PDU on SRB #3 AM RLC on the RACH due to detection of missing PDUs.

#### Expected sequence

| Step | Direction |    | Message                                                                                            | Comments                                  |
|------|-----------|----|----------------------------------------------------------------------------------------------------|-------------------------------------------|
|      | UE        | SS |                                                                                                    |                                           |
| 1    | →         |    | PAGING RESPONSE                                                                                    | Check UE-Id                               |
| 2    | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 1))     | Sent with incorrect UE-Id = C-RNTI+1      |
|      | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+1, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 2))   | Sent with incorrect UE-Id = C-RNTI+1      |
|      |           |    | ...                                                                                                |                                           |
|      | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+n, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT n))   | Sent with incorrect UE-Id = C-RNTI+1      |
| 3    | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+n+1, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 1)) | Sent with correct UE-Id = C-RNTI          |
|      | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+n+2, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 2)) | Sent with correct UE-Id = C-RNTI          |
|      |           |    | ...                                                                                                |                                           |
|      | ←         |    | MAC PDU(TCTF, UE-ID, C/T, RLC AM PDU(SN=x+n+n, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT n)) | Sent with correct UE-Id = C-RNTI          |
| 4    | →         |    | RLC-STATUS-PDU                                                                                     | NAK PDUs with SN = x to x+n               |
| 5    | →         |    | AUTHENTICATION RESPONSE                                                                            | UE-Id is recognised as correct for the UE |

#### Specific Message Contents

None

#### 7.1.1.5.5 Test Requirement

In step a) the UE-Id field should be set to the C-RNTI allocated in the RRC CONNECTION SETUP message. Note that this may be implied from receipt of the PAGING RESPONSE message correctly by the SS test script.

In step d) the UE shall transmit a STATUS PDU on the RLC AM entity associated with SRB #3 when the first PDU with UE-Id = value of the address allocated in the RRC CONNECTION SETUP message, is received in step c); negatively acknowledging the PDUs transmitted in step b) as missing.

At the end of the expected sequence the SS shall receive an AUTHENTICATION RESPONSE message.

#### ~~7.1.1.6 DTCH or DCCH mapped to DSCH or USCH~~

##### ~~7.1.1.6.1 Definition and applicability~~

Applicable for if mode TDD only or FDD only is supported.

##### ~~7.1.1.6.2 Conformance requirement~~

The TCTF field is included in the MAC header for TDD only. The UE-Id type and UE-Id are included in the MAC header for FDD only. The C/T field is included if multiplexing on MAC is applied.

#### Reference(s)

TS 25.321 clause 9.2.1.1.

##### ~~7.1.1.6.3 Test purpose~~

To verify when DTCH or DCCH is mapped to DSCH or USCH, the TCTF field is applied for TDD only, the UE-Id type and UE-Id are applied for FDD only. If multiplexing on MAC is applied, C/T field is included, otherwise, the C/T field is not included in the MAC header.

##### ~~7.1.1.6.4 Method of test~~

#### Initial conditions

System Simulator:

- 1 cell, default parameters. Ciphering Off.

User Equipment:

- The UE shall operate under normal test conditions, Ciphering Off.
- The Test-USIM shall be inserted.

The UE is in Connected mode and a connection is established as described in the TS 34.123-1, 7.3 PDCP testing, clause "Setup a UE-originated PS session using IP Header compression in AM RLC (using Loop-back test mode 1).

#### Related ICS/IXIT Statement(s)

TBD

#### Foreseen Final State of the UE

#### Test procedure

- The SS sends a certain data block to the UE.
- After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.
- The SS receives the returned data block and checks its MAC header whether the TCTF is applied for TDD only, or the UE-Id type and UE-Id are applied for FDD only and the C/T field shall not be applied.
- The SS configures the RLC.
- The SS starts a Radio Bearer Reconfiguration procedure to be connected in RLC transparent mode and configures the Radio Bearer for multiplexing.
- The SS sends a certain data block to the UE.

- g) After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.
- h) The SS receives the returned data block and check its MAC header whether the TCTF is applied for TDD only, or the UE-Id type and UE-Id are applied for FDD only and the C/T field is applied.
- i) The SS reconfigures its RLC mode to be in AM.

#### Expected sequence

| Step | Direction |    | Message                               | Comments                                                                                                                                                                                                   |
|------|-----------|----|---------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                                                                                                                            |
| 1    |           | ←  | DATA-BLOCK                            | The SS sends one data block with MAC header, sets TCTF as "DCCH or DTCH over USCH or DSCH" for TDD only, or sets UE-Id type as "C-RNTI", and UE-Id as C-RNTI of UE for FDD only.                           |
| 2    |           | →  | LOOP-BACK DATA-BLOCK                  | SS receives the loop back data block from the Uplink RB and checks the MAC header.                                                                                                                         |
| 3    |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM-mode".                                                                                                        |
| 4    |           | ←  | RADIO-BEARER RECONFIGURE              | Reconfigures the downlink and uplink radio bearer as multiplexing.                                                                                                                                         |
| 5    |           | →  | RADIO-BEARER RECONFIGURATION COMPLETE |                                                                                                                                                                                                            |
| 6    |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode".                                                                                              |
| 7    |           | ←  | DATA-BLOCK                            | The SS sends one data block with MAC header, sets TCTF as "DCCH or DTCH over USCH or DSCH" for TDD only, or sets UE-Id type as "C-RNTI", and UE-Id as C-RNTI of UE for FDD only and C/T field is included. |
| 8    |           | →  | LOOP-BACK DATA-BLOCK                  | SS receives the loop back data block from the Uplink RB and checks the MAC header.                                                                                                                         |
| 9    |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM-mode".                                                                                                        |

#### Specific Message Contents

##### RADIO-BEARER SET-UP:

| Information Element                                                                             | Value/remark |
|-------------------------------------------------------------------------------------------------|--------------|
| RLC-info<br>—RLC mode                                                                           | AM-RLC       |
| RB-mapping info<br>—Downlink<br>-Number of logical channels<br>-Downlink transport channel type | 1<br>DSCH    |
| —Uplink<br>-Number of logical channels<br>-Uplink transport channel type                        | 1<br>USCH    |

**RADIO-BEARER RECONFIGURE:**

| Information Element                                                                                                                                                               | Value/remark           |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|
| RLC info<br>— RLC mode                                                                                                                                                            | AM-RLC                 |
| RB-mapping info<br>— Downlink<br>- Number of logical channels<br>- Downlink transport channel type<br>— Uplink<br>- Number of logical channels<br>- Uplink transport channel type | 2<br>DSCH<br>2<br>USCH |

**7.1.1.6.5 — Test requirements**

TCTF field in the MAC header of loop back data block is "DTCH or DCCH over DSCH or USCH" for TDD only. The UE-ID type and UE-Id are applied in the MAC header for FDD only. If multiplexing on MAC is applied, C/T field is included, otherwise, C/T field is not included.

**7.1.1.7 — DTCH or DCCH mapped to CPCH****7.1.1.7.1 — Definition and applicability**

All UEs which support CPCH.

**7.1.1.7.2 — Conformance requirement**

UE-Id type field and UE-Id are included in the MAC header. The C/T field is included in the MAC header if multiplexing on MAC is applied.

**Reference(s)**

TS 25.321 clauses 9.2.1.1 and 11.3.

TS 25.214 clause 6.2.

TS 25.211 clause 5.3.3.11.

**7.1.1.7.3 — Test purpose**

To verify when DTCH or DCCH mapped to CPCH, UE-Id type field and UE-Id are included in the MAC header. if multiplexing on MAC is applied, the C/T field is included in the MAC header, otherwise, C/T field is not included.

**7.1.1.7.4 — Method of test****Initial conditions****System Simulator:**

- 1 cell, default parameters, Ciphering Off.

**User Equipment:**

- The UE shall operate under normal test conditions, Ciphering Off.
- The Test-USIM shall be inserted.

The UE is in Connected mode and a connection is established as described in the TS 34.123-1, 7.3 PDCP testing, clause "Setup a UE-originated PS session using IP Header compression in UM RLC (using Loop back test mode 1).

## Related ICS/IXIT Statement(s)

TBD

## Foreseen Final State of the UE

## Test procedure

- a) The SS sends SIBs 7, 8, and 9, sends CSICH information and waits 30 s.
- b) The SS reconfigures its RLC mode to be in transparent mode RLC. Afterwards it sends a certain data block to the UE.
- c) After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.
- d) The SS receives the returned data block and checks its MAC header, whether a UE-Id type and a UE-Id are included.
- e) The SS reconfigures its RLC mode to be in AM.
- f) The SS starts a Radio Bearer Reconfiguration procedure to be connected in RLC transparent mode and configures the Radio Bearer for multiplexing.
- g) The SS sends the next data block via its MAC entity with MAC header, including the UE-Id type as "C-RNTI" and UE-Id as C-RNTI of the UE. C/T field.
- h) After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.
- i) The SS receives the returned data block and checks its MAC header, whether UE-Id type, UE-Id field are included and C/T field is applied or not.

## Expected sequence

| Step | Direction |    | Message                               | Comments                                                                                                        |
|------|-----------|----|---------------------------------------|-----------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                                 |
| 1    | ←         |    | SIBs 7, 8 and 9 and CSICH information | Containing default settings for CPCH.                                                                           |
| 2    | ←         |    | DATA-BLOCK                            | The SS sends one data block with MAC header, sets UE-Id type as "C-RNTI", and UE-Id as C-RNTI of UE.            |
| 3    | →         |    | LOOP BACK DATA BLOCK                  | SS receives the loop back data block from the Uplink RB and checks the MAC header.                              |
| 4    |           |    |                                       | SS sends C-MAC_MAC_HEADER_REQ with enable_mac_header and C-RLC_CONFIG_REQ with RLC mode as "AM mode".           |
| 5    | ←         |    | RADIO-BEARER RECONFIGURE              | Reconfigures the downlink and uplink radio bearer as multiplexing.                                              |
| 6    | →         |    | RADIO-BEARER RECONFIGURATION COMPLETE |                                                                                                                 |
| 7    |           |    |                                       | SS sends C-MAC_MAC_HEADER_REQ with disable_mac_header and C-RLC_CONFIG_REQ with RLC mode as "Transparent mode". |
| 8    | ←         |    | DATA-BLOCK                            | The SS sends one data block with MAC header, sets UE-Id type as "C-RNTI", and UE-Id as C-RNTI of UE.            |
| 9    | →         |    | LOOP BACK DATA BLOCK                  | SS receives the loop back data block from the Uplink RB and checks the MAC header.                              |
| 10   |           |    |                                       | SS sends C-MAC_MAC_HEADER_REQ with enable_mac_header and C-RLC_CONFIG_REQ with RLC mode as "AM mode".           |

## Specific Message Contents

## RADIO BEARER SET-UP:

| Information Element                                                                               | Value/remark |
|---------------------------------------------------------------------------------------------------|--------------|
| RLC info<br>—> RLC mode                                                                           | AM-RLC       |
| RB-mapping info<br>—> Downlink<br>-Number of logical channels<br>-Downlink transport channel type | 1<br>FACH    |
| —> Uplink<br>-Number of logical channels<br>-Uplink transport channel type                        | 1<br>CPCH    |

## RADIO BEARER RECONFIGURE:

| Information Element                                                                               | Value/remark |
|---------------------------------------------------------------------------------------------------|--------------|
| RLC info<br>—> RLC mode                                                                           | AM-RLC       |
| RB-mapping info<br>—> Downlink<br>-Number of logical channels<br>-Downlink transport channel type | 2<br>FACH    |
| —> Uplink<br>-Number of logical channels<br>-Uplink transport channel type                        | 2<br>CPCH    |

## PRACH persistence level info in System Information Block type 7

| Information Element                                    | Value/Remark                                                                |
|--------------------------------------------------------|-----------------------------------------------------------------------------|
| PRACHs listed in SIB-5<br>-Dynamic persistence level   | All set to 8, which maps to minimum persistence value,<br>no access allowed |
| PRACHs listed in SIB-6<br>—> Dynamic persistence level | All set to 8, which maps to minimum persistence value,<br>no access allowed |

## CPCH parameters in System Information Block type 8

| Information Element                                                                                                                                                                                                                                                                                | Value/Remark                                                    |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------|
| Back-off control parameters<br>-N <sub>ap_retrans_max</sub><br>-N <sub>access_fails</sub><br>-N <sub>F_bo_no_aich</sub><br>-N <sub>S_bo_busy</sub><br>-N <sub>F_bo_all_busy</sub><br>-N <sub>F_bo_mismatch</sub><br>-T <sub>CPCH</sub><br>Power Control Algorithm<br>TPC step size<br>DL-DPCCH BER | 15<br>15<br>15<br>15<br>15<br>15<br>0<br>algorithm 1<br>1<br>15 |



## CPCH set info in System Information Block type 8

| Information Element           | Value/Remark |
|-------------------------------|--------------|
| AP-preamble scrambling-code   | 16           |
| AP-AICH channelisation-code   | 15           |
| CD-preamble scrambling-code   | 17           |
| CD/CA-ICH channelisation-code | 16           |
| DeltaPp-m                     | 0            |
| UL-DPCCH Slot Format          | 1            |
| N_start_message               | 8            |
| CPCH status indication mode   | PA mode      |
| PCPCH Channel #1 info         |              |
| -UL scrambling-code           | 18           |
| -DL channelisation-code       | 15           |
| -PCP length                   | 8            |
| -UCSM info                    |              |
| - Minimum spreading factor    | 64           |
| - NF_max                      | 64           |
| -AP signature                 | 15           |
| PCPCH Channel #2 info         |              |
| -UL scrambling-code           | 19           |
| -DL channelisation-code       | 14           |
| -PCP length                   | 8            |
| -UCSM info                    |              |
| - Minimum spreading factor    | 64           |
| - NF_max                      | 64           |
| -AP signature                 | 14           |

## PCPCH persistence level info in System Information Block type 9

| Information Element         | Value/Remark                            |
|-----------------------------|-----------------------------------------|
| CPCH set persistence levels |                                         |
| -PCPCH persistence level    | Both set to 1, immediate access allowed |

## CSICH Information broadcast by SS PHY

| Information Element                | Value/Remark |
|------------------------------------|--------------|
| PCPCH Channel Availability (PCA) : |              |
| -PCA1                              | Available    |
| -PCA2                              | Available    |

## 7.1.1.7.5 Test requirements

The UE-Id type and UE-Id field are included in the MAC header. When multiplexing on MAC is not applied, C/T field is included in the MAC header. Otherwise, C/T field is not included.

## 7.1.1.8 DTCH or DCCH mapped to DCH / Invalid C/T Field

## 7.1.1.8.1 Definition

This tests that the MAC applies the correct header to the MAC PDU according to the type of logical channel carried on the DCH transport channel. Incorrect application of MAC headers would result in inoperation of the UE.

## 7.1.1.8.2 Conformance requirement

DTCH or DCCH mapped to DCH, no multiplexing of dedicated channels on MAC: -no MAC header is required.

DTCH or DCCH mapped to DCH, with multiplexing of dedicated channels on MAC: -C/T field is included in MAC header.

The following fields are defined for the MAC header:

— C/T field

The C/T field provides identification of the logical channel instance when multiple logical channels are carried on the same transport channel.

**Structure of the C/T field**

| C/T field | Designation                                                                                 |
|-----------|---------------------------------------------------------------------------------------------|
| 0000      | Logical channel 1                                                                           |
| 0001      | Logical channel 2                                                                           |
| ...       | ...                                                                                         |
| 1110      | Logical channel 15                                                                          |
| 1111      | Reserved<br>(PDUs with this coding will be<br>discarded by this version of<br>the protocol) |

Reference(s)

TS 25.321 clauses 9.2.1 and 9.2.1.1 b).

7.1.1.8.3 — Test purpose

1. To verify that the UE discards PDUs with reserved or incorrect values in C/T field.
2. To verify that the C/T field is correctly applied when a DTCH or DCCH is mapped to a DCH.

7.1.1.8.4 — Method of test

Initial conditions

System Simulator:

- 1 cell, default parameters, Ciphering Off.

- The DCH/DPCH is configured as specified in TS 34.108 clause 6.10.2.4.1.2: Stand-alone UL:3.4 DL:3.4 kbps SRBs for DCCH) with the following exception:

|                                                                                                                                                                      |                                                             |                     |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------|---------------------|
| Higher layer                                                                                                                                                         | RAB/signalling RB                                           | RB#3 (SRB#3)        |
|                                                                                                                                                                      | User of Radio Bearer                                        | NAS-DT<br>High prio |
| RLC                                                                                                                                                                  | Logical channel type                                        | DCCH                |
|                                                                                                                                                                      | RLC mode                                                    | TM                  |
|                                                                                                                                                                      | Payload sizes, bit                                          | 148                 |
|                                                                                                                                                                      | Max data rate, bps                                          | 3700                |
|                                                                                                                                                                      | RLC header, bit                                             | 0                   |
| MAC                                                                                                                                                                  | MAC header, bit                                             | 0 (note)            |
|                                                                                                                                                                      | MAC multiplexing                                            | Simulated by SS     |
| Layer 1                                                                                                                                                              | TrCH type                                                   | DCCH                |
|                                                                                                                                                                      | TB sizes, bit                                               | 148                 |
|                                                                                                                                                                      | TFS                                                         | -TF0, bits          |
|                                                                                                                                                                      |                                                             | -TF1, bits          |
|                                                                                                                                                                      | TTI, ms                                                     | 40                  |
|                                                                                                                                                                      | Coding type                                                 | CC 1/3              |
|                                                                                                                                                                      | CRC, bit                                                    | 16                  |
|                                                                                                                                                                      | Max number of bits/TTI before rate matching                 | 516                 |
|                                                                                                                                                                      | Uplink: Max number of bits/radio frame before rate matching | 129                 |
|                                                                                                                                                                      | RM attribute                                                | 155-165             |
| NOTE: —The SS MAC layer must be configured not to add a MAC header so that the header can be added by the test case in order to create the necessary invalid values. |                                                             |                     |

The TFCS should be configured as specified in clause 6.10.2.4.1.2.1.1.2.

#### User Equipment:

- The UE shall operate under normal test conditions, Ciphering Off.
- The Test-USIM shall be inserted.
- The SS starts broadcasting the System Information as specified in TS 34.108 clause 6.1, using the configuration for the PRACH and SCCPCH (signalled in SYSTEM INFORMATION 5) as follows:
  1. The SCCPCH is configured as specified in TS 34.108 clause 6.10.2.4.3.3 (Interactive/Background 32 kbps RAB + SRB for PCCH + SRB for CCCH + SRB for DCCH + SRB for BCCH).
  2. The PRACH is configured as specified in TS 34.108 clause 6.10.2.4.4.1.
- The SS follows the procedure in TS 34.108 clause 7.4.2.1 (Mobile Terminated) so that the UE shall be in state BGP-6-1 (CS-CELL\_DCH\_INITIAL). During this procedure the RRC CONNECTION SETUP message shall allocate a DCH to carry the signalling radio bearers as follows:
  1. The DCH/DPCH is configured as specified in TS 34.108 clause 6.10.2.4.1.2: Stand-alone UL:3.4 DL:3.4 kbps SRBs for DCCH) with the following exception:
    - 1.1 The RLC entity for RB#3 (SRB#3), AM-DCCH for high priority NAS signalling has Missing PDU Indicator enabled.
    - 1.2 The RLC entity for RB#3 (SRB#3), AM-DCCH for high priority NAS signalling, has Transmission window size set to 128, and has Receive window size set to 128.

#### Test procedure

- a) The SS receives the PAGING RESPONSE message from the UE and checks the C/T field.
- b) The SS transmits MAC PDUs containing RLC-AM PDUs containing a DIRECT TRANSFER message containing an AUTHENTICATION REQUEST message.

—The DIRECT TRANSFER message shall be segmented into 128-bit PDUs, with correct RLC AM headers.

—The MAC header shall be set as follows:

| Field | Value  |
|-------|--------|
| C/T   | 0100'B |

c) The SS again transmits MAC PDUs as in b) above, but this time uses the correct C/T value for AM-DCCH NAS High Priority of 0010'B. The sequence numbers in the RLC headers shall be incremented normally from those sent in b).

d) The SS receives a STATUS PDU on SRB #3 AM RLC on the DCH due to detection of missing PDUs.

e) The SS repeats steps b), c) and d), with the C/T field set as follows:

| Iteration | C/T Value |
|-----------|-----------|
| 2         | 1111'B    |

#### Expected sequence

| Step | Direction |    | Message                                                                               | Comments                                        |
|------|-----------|----|---------------------------------------------------------------------------------------|-------------------------------------------------|
|      | UE        | SS |                                                                                       |                                                 |
| 1    | →         |    | PAGING RESPONSE                                                                       | Check C/T field                                 |
| 2    | ←         |    | MAC PDU(C/T, RLC AM PDU(SN=x, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 1))     | Sent with incorrect C/T = 0100'B, or 1111'B     |
|      | ←         |    | MAC PDU(C/T, RLC AM PDU(SN=x+1, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 2))   | Sent with incorrect C/T = 0100'B, or 1111'B     |
|      |           |    | ...                                                                                   |                                                 |
|      | ←         |    | MAC PDU(C/T, RLC AM PDU(SN=x+n, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT n))   | Sent with incorrect C/T = 0100'B, or 1111'B     |
| 3    | ←         |    | MAC PDU(C/T, RLC AM PDU(SN=x+n+1, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 1)) | Sent with correct C/T = 0010'B                  |
|      | ←         |    | MAC PDU(C/T, RLC AM PDU(SN=x+n+2, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT 2)) | Sent with correct C/T = 0010'B                  |
|      |           |    | ...                                                                                   |                                                 |
|      | ←         |    | MAC PDU(C/T, RLC AM PDU(SN=x+n+n, DIRECT TRANSFER(AUTHENTICATION REQUEST) SEGMENT n)) | Sent with correct C/T = 0010'B                  |
| 4    | →         |    | RLC-STATUS-PDU                                                                        | NAK PDUs with SN = x to x+n                     |
| 5    | →         |    | AUTHENTICATION RESPONSE                                                               | C/T Field is recognised as correct for the DCCH |

#### Specific Message Contents

None

#### 7.1.1.8.5 ————— Test Requirement

In step a) the C/T field should be set to the Logical Channel ID for SRB #3 (0010'B). Note that this may be implied from receipt of the PAGING RESPONSE message correctly by the SS test script.

On the first iteration, and on each iteration in step d) the UE shall transmit a STATUS PDU on the RLC AM entity associated with SRB #3 each time the first PDU with C/T=0010'B is received in step c), negatively acknowledging the PDUs transmitted in step b) as missing.

At the end of each expected sequence the SS shall receive an AUTHENTICATION RESPONSE message.

## 7.1.2 RACH/FACH procedures

### 7.1.2.1 Selection and control of Power Level

#### 7.1.2.1.1 Selection and control of Power Level (FDD)

##### 7.1.2.1.1.1 Definition

Selection and control of power level for PRACH is controlled by the physical random access procedure which is initiated upon request of a PHY-Data-REQ primitive from the MAC sublayer.

The UE selection of "PRACH system information" is described in TS 25.331 clause 8.5.17.

##### 7.1.2.1.1.2 Conformance requirement

A. For FDD and prior to PRACH or PCPCH transmission the UE shall:

- read the IEs "Primary CPICH DL TX power", "UL interference" and "Constant value" in System Information Block type 6 (or System Information Block type 5, if system information block type 6 is not being broadcast) and System Information Block type 7;

- measure the value for the CPICH\_RSCP;

- calculate the power for the first preamble as:

$$\text{Preamble\_Initial\_Power} = \text{Primary CPICH DL TX power} - \text{CPICH\_RSCP} + \text{UL interference} + \text{Constant Value}$$

Where;

- Primary CPICH DL TX power shall have the value of IE "Primary CPICH DL TX power";

- UL interference shall have the value of IE "UL interference"; and

- Constant Value shall have the value of IE "Constant Value".

- as long as the physical layer is configured for PRACH or PCPCH transmission:

- continuously recalculate the Preamble\_Initial\_Power when any of the broadcast parameters used in the above formula changes; and

- resubmit to the physical layer the new calculated Preamble\_Initial\_Power.

B. The physical random-access procedure shall be performed as follows:

....

3. Set the Preamble Retransmission Counter to Preamble Retrans Max.

4. Set the parameter Commanded Preamble Power to Preamble\_Initial\_Power.

5. In the case that the Commanded Preamble Power exceeds the maximum allowed value, set the preamble transmission power to the maximum allowed power. In the case that the Commanded Preamble Power is below the minimum level required in 3GPP TS 25.101, set the preamble transmission power to a value, which shall be at or above the Commanded Preamble Power and at or below the required minimum power specified in 3GPP TS 25.101. Otherwise set the preamble transmission power to the Commanded Preamble Power. Transmit a preamble using the selected uplink access slot, signature, and preamble transmission power.

6. If no positive or negative acquisition indicator ( $AI \neq +1$  nor  $-1$ ) corresponding to the selected signature is detected in the downlink access slot corresponding to the selected uplink access slot:

6.1 Select the next available access slot in the set of available RACH sub-channels within the given ASC.

6.2 Randomly select a new signature from the set of available signatures within the given ASC. The random function shall be such that each of the allowed selections is chosen with equal probability.

6.3 Increase the Commanded Preamble Power by  $\Delta P_0$  = Power Ramp Step [dB]. If the Commanded Preamble Power exceeds the maximum allowed power by 6dB, the UE may pass L1 status ("No ack on AICH") to the higher layers (MAC) and exit the physical random access procedure.

6.4 Decrease the Preamble Retransmission Counter by one.

6.5 If the Preamble Retransmission Counter  $> 0$  then repeat from step 5. Otherwise pass L1 status ("No ack on AICH") to the higher layers (MAC) and exit the physical random access procedure.

7—If a negative acquisition indicator corresponding to the selected signature is detected in the downlink access slot corresponding to the selected uplink access slot, pass L1 status ("Nack on AICH received") to the higher layers (MAC) and exit the physical random access procedure.

#### Reference(s)

TS 25.331 clause 8.5.7.

TS 25.214 clause 6.1.

#### 7.1.2.1.1.3 ————— Test purpose

To verify that:

A— the UE selects the correct initial preamble transmit power at start of a power ramp cycle, taking account of the "Primary CPICH DL TX power", "UL interference" and "Constant value" parameter values as received in SIB5 as well as the measured CPICH\_RSCP;

B1— the UE, when not receiving any reply from UTRAN:

- performs a power ramp cycle taking into account the Power Ramp Step and Preamble Retrans Max parameter values as received in SIB 5;
- does not transmit on the PRACH resources specified in the BCH message SIB 5 after that the physical random access procedure is terminated.

B2— the UE, when detecting a negative acquisition indicator:

- does not transmit on the PRACH resources specified in the BCH message SIB 5 after that the physical random access procedure is terminated.

#### 7.1.2.1.1.4 ————— Method of test

##### Initial conditions

The UE is attached to the network and in idle mode.

Preamble Retrans Max parameter in SIB5 set to 5.

##### Related ICS/IXIT Statement(s)

TBD

##### Foreseen Final State of the UE

The same as the initial conditions.

##### Test procedure

- a) The SS pages the UE until it performs a RACH access.
- b) The SS measures the power level of the RACH access.

- c) The SS does not acknowledge the RACH access, causing the UE to retry.
- d) The SS again measures the power level of the RACH access.
- e) The SS repeats the procedure from step c) until the maximum number of retries  $N_{RA}$  have been attempted, and monitors the RACH channel for [TBD] seconds to ensure that no further RACH accesses occur.
- f) The SS pages the UE until it performs a RACH access.
- g) The SS measures the power level of the RACH access.
- h) The SS responds with a negative acquisition indicator on the AICH.
- i) The SS monitors the RACH channel for [TBD] seconds to ensure that no further RACH accesses occur.

#### Expected sequence

| Step | Direction |    | Message                    | Comments                                                                                             |
|------|-----------|----|----------------------------|------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                            |                                                                                                      |
| 1    | ←         |    | PAGE                       | Preamble Retransmission Counter = 5                                                                  |
| 2    | →         |    | RRC_CONNECTION_REQUEST     | Power should be set to Preamble_Initial_Power                                                        |
| 3    | →         |    | RRC_CONNECTION_REQUEST     | Preamble Retransmission Counter = 4<br>Power should be set to Preamble_Initial_Power + $\Delta P_0$  |
| 4    | →         |    | RRC_CONNECTION_REQUEST     | Preamble Retransmission Counter = 3<br>Power should be set to Preamble_Initial_Power + $2\Delta P_0$ |
| 5    | →         |    | RRC_CONNECTION_REQUEST     | Preamble Retransmission Counter = 2<br>Power should be set to Preamble_Initial_Power + $3\Delta P_0$ |
| 6    | →         |    | RRC_CONNECTION_REQUEST     | Preamble Retransmission Counter = 1<br>Power should be set to Preamble_Initial_Power + $4\Delta P_0$ |
| 7    |           |    | Wait for T = [TBD]s        | Preamble Retransmission Counter = 0<br>SS monitors for RACH access attempts                          |
| 8    | ←         |    | PAGE                       |                                                                                                      |
| 9    | →         |    | RRC_CONNECTION_REQUEST     | Power should be set to Preamble_Initial_Power                                                        |
| 10   | ←         |    | AICH = NEG ACQUISITION IND |                                                                                                      |
| 11   |           |    | Wait for T = [TBD]s        | SS monitors for RACH access attempts                                                                 |

#### Specific Message Contents

##### PRACH power offset info in System Information Block type 5

| Information Element   | Value/Remark   |
|-----------------------|----------------|
| PRACH power offset    |                |
| -Power Ramp Step      | [TBD: 1..8] dB |
| -Preamble Retrans Max | 5              |

#### 7.1.2.1.1.5 Test requirements

A. At step 2 and 9 the measured power level shall be:

—  $P_{RACH}$  = Primary CPICH DL TX power – CPICH\_RSCP + UL interference + Constant Value ± [TBD] dB

— Where "Primary CPICH DL TX power", "UL interference" and "Constant Value" are set by the SS via SIB5, and CPICH\_RSCP is the UE measured received power on one code measured on the Primary CPICH which is reported back to the SS in measurement reports.

B1

— After step 6 the UE does not perform any RACH access attempts; and

— At step 2, 3, 4, 5 and 6 the measured power level shall be

$$P_{\text{RACH}} = \text{Preamble\_Initial\_Power} + k * \Delta P_0$$

Where

- Preamble\_Initial\_Power is the SS measured  $P_{\text{RACH}}$  in step 1;
- $\Delta P_0$  is the Power Ramp Step value set in SIB5; and
- $k=1$  for step 2,  $k=2$  for step 3,  $k=3$  for step 4,  $k=4$  for step 5 and  $k=5$  for measurement in step 6

B2 After step 10 the UE does not perform any RACH access attempts

#### ~~7.1.2.1.2 Selection and control of Power Level (3,84 Mcps TDD option)~~ (FFS)

#### ~~7.1.2.1.3 Selection and control of Power Level (1,28 Mcps TDD option)~~

##### ~~7.1.2.1.3.1 Definition and applicability~~

All TDD 1,28 Mcps UE

##### ~~7.1.2.1.3.2 Conformance requirement~~

- ~~1. The UE sets the initial preamble transmit power to the value  $P_{\text{UpPCH}}$  given in clause 8.5.7 of TS 25.331.~~
- ~~2. If the UE does not receive an acknowledgement on the FPACH then the UE increases the preamble transmission power by the specified increment  $P_{\text{wr\_ramp}}$ .~~
- ~~3. The UE ceases power ramping after the maximum number of pre-amble increments permitted has been completed.~~
- ~~4. Where the UE is permitted to complete a number of power ramping cycles, the UE returns to the initial transmit power (no increment applied) at the start of each cycle. The number of cycles completed before the UE ceases transmission should equal the maximum number of permitted power ramping cycles.~~
- ~~5. The UE does not transmit on PRACH resources.~~

#### Reference(s)

TS 25.224 clause 5.6.

TS 25.331 clause 8.5.7.

TS 25.321 clause 11.2.3.

#### ~~7.1.2.1.3.3 Test Purpose~~

To verify that:

- the UE selects the correct preamble transmit powers during a power ramp cycle, taking account of the desired  $P_{\text{UpPCH}}$  receive power and power ramp step specified in the BCH layer 3 message SIB 5,
- the number of steps in a power ramp cycle and the number of power ramp cycles completed when no reply is received from the UTRAN is equal to the values specified for these parameters in the BCH layer 3 messages SIB 5,
- the UE does not transmit on the PRACH resources specified in the BCH message SIB 5.



~~7.1.2.1.3.4 Method of test~~~~Initial conditions~~

The UE is attached to the network and in idle mode.

~~Related ICS/IXT Statement(s)~~

TBD

~~Foreseen Final State of the UE~~

The same as the initial condition.

~~Test procedure~~

- ~~a) The SS pages the UE to initiate the RACH access procedure;~~
- ~~b) The SS does not respond to UpPCH transmissions received from the UE;~~
- ~~c) The SS measures the power level of each UpPCH code that the UE transmits;~~
- ~~d) The SS monitors the PRACH resources to ensure that no transmissions are received from the UE;~~
- ~~e) The procedure is continued until the maximum permitted power ramping cycles, and within each power ramping cycle, the maximum number of UpPCH transmissions have been made. The UpPCH and PRACH channels are then continued for time, tbd, to ensure that no further transmissions are made by the UE.~~

~~Expected sequence~~

| Step | Direction |    | Message              | Comments                                                                                          |
|------|-----------|----|----------------------|---------------------------------------------------------------------------------------------------|
|      | UE        | SS |                      |                                                                                                   |
| 1    |           | <  | PAGE                 |                                                                                                   |
| 2    |           | >  | UpPCH                | $P_{\text{UpPCH}} = L_{\text{PCCPCH}} + \text{PRX}_{\text{UpPCHdes}}$                             |
| 3    |           | >  | UpPCH                | $P_{\text{UpPCH}} = L_{\text{PCCPCH}} + \text{PRX}_{\text{UpPCHdes}} + P_{\text{Wrfamp}}$         |
| 4    |           |    | .....                |                                                                                                   |
| 5    |           | >  | UpPCH                | $P_{\text{UpPCH}} = L_{\text{PCCPCH}} + \text{PRX}_{\text{UpPCHdes}} + n \cdot P_{\text{Wrfamp}}$ |
| 6    |           | >  | UpPCH                | $P_{\text{UpPCH}} = L_{\text{PCCPCH}} + \text{PRX}_{\text{UpPCHdes}}$                             |
| 7    |           | >  | UpPCH                | $P_{\text{UpPCH}} = L_{\text{PCCPCH}} + \text{PRX}_{\text{UpPCHdes}} + P_{\text{Wrfamp}}$         |
| 8    |           |    | .....                |                                                                                                   |
| 9    |           | >  | UpPCH                | $P_{\text{UpPCH}} = L_{\text{PCCPCH}} + \text{PRX}_{\text{UpPCHdes}} + n \cdot P_{\text{Wrfamp}}$ |
| 10   |           |    | Wait for time-period |                                                                                                   |

~~7.1.2.1.3.5 Test requirements~~

The power of the first UpPCH transmission should equal  $P_{\text{UpPCH}} = L_{\text{PCCPCH}} + \text{PRX}_{\text{UpPCHdes}}$ ; subsequent transmissions should increase in power by  $P_{\text{Wrfamp}}$  until the maximum permitted number of steps in a power ramping cycle has been completed. The power ramping cycle should be repeated  $M_{\text{max}}$  times before the UE ceases to transmit. The UE should not transmit on any PRACH resources.

~~7.1.2.2 Correct application of Dynamic Persistence~~~~7.1.2.2.1 Correct application of Dynamic Persistence (FDD)~~~~7.1.2.2.1.1 Definition and applicability~~

All FDD UE.

#### ~~7.1.2.2.1.2 Conformance requirement~~

The UE implements the dynamic persistence algorithm by:

- ~~1. reading the current dynamic persistence value from the BCH;~~
- ~~2. perform a random draw against the current dynamic persistence value. The random function is TBD;~~
- ~~3. defer transmission for one frame and repeat the process if the result of the random draw is negative, otherwise proceed with a RRC CONNECTION REQUEST.~~

#### Reference(s)

TS 25.321, clause 11.2.2 (figure 11.2.2.1).

#### ~~7.1.2.2.1.3 Test purpose~~

To verify that if the UE correctly operates the dynamic persistence algorithm outlined in fig 11.2.2.1 of TS25.321.

#### ~~7.1.2.2.1.4 Method of test~~

##### Initial conditions

System Simulator:

- ~~— 1 cell, default parameters, Ciphering Off.~~

User Equipment:

- ~~— The UE shall operate under normal test conditions, Ciphering Off.~~
- ~~— The Test-USIM shall be inserted.~~

##### Related ICS/IXIT Statement(s)

TBD

##### Foreseen Final State of the UE

The same as the initial conditions.

##### Test procedure

###### Iteration 1

- ~~a) The SS changes the default system information messages such that the dynamic persistence level is set to 8, and scaling factors are not transmitted. This results in a dynamic persistence value ( $P_i$ ) of 0.0078125 for all access service classes. Note: ASC#0 is not used because NumASC=7 and the lowest MLP value =1. -- See 25.321, clause 11.2.1.~~
- ~~b) The SS waits until the UE has enough time to take account of the changes.~~
- ~~c) The SS repeatedly pages the UE 100 times, waiting for the reception of a RRC CONNECTION REQUEST from the UE before each subsequent page.~~

###### Iteration 2

The SS performs step a to c) once more, but changes the default system information messages such that the dynamic persistence level is set to 1, and no scaling factors are transmitted. This results in a dynamic persistence value ( $P_i$ ) of 1 for all access service classes.

## Expected sequence

| Step | Direction |    | Message                | Comments |
|------|-----------|----|------------------------|----------|
|      | UE        | SS |                        |          |
| 1    |           | ←  | PAGE                   |          |
| 2    |           | →  | RRC CONNECTION REQUEST |          |

The above sequence is repeated 100 times.

## 7.1.2.2.5 Test requirements

## Iteration 1

The SS shall receive a RRC CONNECTION REQUEST from the UE on average every 1.28 seconds  $\pm 0.15$ s after each paging request.

## Iteration 2

The SS shall receive a RRC CONNECTION REQUEST from the UE within 150ms after each paging request.

## 7.1.2.2.2 Correct application of Dynamic Persistence (3.84 Mcps TDD option)

(FFS)

## 7.1.2.2.3 Correct application of Dynamic Persistence (1.28 Mcps TDD option)

## 7.1.2.2.3.1 Definition and applicability

All TDD 1.28 Mcps UE

## 7.1.2.2.3.2 Conformance requirement

The UE responds to changes in the dynamic persistence parameter broadcast in SIB 7.

## Reference(s)

TS 25.331 clause 8.5.12.

TS 25.321 clause 11.2.3.

## 7.1.2.2.3.3 Test Purpose

To verify that if the dynamic persistence value broadcast in SIB7 is set to zero, the UE will not attempt RACH access.

## 7.1.2.2.3.4 Method of test

## Initial conditions

The UE is attached to the network and in idle mode. The Sim card should be configured so that the UE adopts  $ASC = 1$  or greater. The SS BCH broadcast will include SIB 7 with the dynamic persistence parameter set to zero.

## Related ICS/IXT Statement(s)

TBD

## Foreseen Final State of the UE

The same as the initial condition.

**Test procedure**

- a) The SS repeatedly pages the UE for  $T_{22}$  seconds.
- b) The SS monitors UpPCH for a response from the UE.

**Expected sequence**

| Step | Direction |    | Message | Comments |
|------|-----------|----|---------|----------|
|      | UE        | SS |         |          |
| 1    |           | ←  | PAGE    |          |
| 2    |           |    | Wait    |          |

**7.1.2.2.3.5 Test Requirements**

No UpPCH transmission should be received from the UE.

**7.1.2.3 Correct Selection of RACH parameters****7.1.2.3.1 Correct Selection of RACH parameters (FDD)****7.1.2.3.1.1 Definition**

The physical random access procedure described in this subclause is initiated upon request of a PHY-Data-REQ primitive from the MAC sublayer.

The UE selection of "PRACH system information" is described in TS 25.331 clause 8.5.17.

**7.1.2.3.1.2 Conformance requirement**

A. The physical random access procedure shall be performed as follows:

- 1—Derive the available uplink access slots, in the next full access slot set, for the set of available RACH sub-channels within the given ASC with the help of TS 25.214, subclauses 6.1.1. and 6.1.2. Randomly select one access slot among the ones previously determined. If there is no access slot available in the selected set, randomly select one uplink access slot corresponding to the set of available RACH sub-channels within the given ASC from the next access slot set. The random function shall be such that each of the allowed selections is chosen with equal probability.
- 2—Randomly select a signature from the set of available signatures within the given ASC. The random function shall be such that each of the allowed selections is chosen with equal probability.
- 3—Set the Preamble Retransmission Counter to Preamble Retrans Max.
- ...
- 5—... Transmit a preamble using the selected uplink access slot, signature, and preamble transmission power.
- 6—If no positive or negative acquisition indicator ( $AI \neq +1$  nor  $-1$ ) corresponding to the selected signature is detected in the downlink access slot corresponding to the selected uplink access slot:
  - 6.1 Select the next available access slot in the set of available RACH sub-channels within the given ASC.
  - 6.2 Randomly select a new signature from the set of available signatures within the given ASC. The random function shall be such that each of the allowed selections is chosen with equal probability.
  - ...
  - 6.4 Decrease the Preamble Retransmission Counter by one.
  - 6.5 If the Preamble Retransmission Counter  $> 0$  then repeat from step 5. Otherwise pass L1 status ("No ack on AICH") to the higher layers (MAC) and exit the physical random access procedure.

- 7—If a negative acquisition indicator corresponding to the selected signature is detected in the downlink access slot corresponding to the selected uplink access slot, pass L1 status ("Nack on AICH received") to the higher layers (MAC) and exit the physical random access procedure.
- 8—Transmit the random access message three or four uplink access slots after the uplink access slot of the last transmitted preamble depending on the AICH transmission timing parameter. Transmission power of the control part of the random access message should be  $P_{p-m}$  [dB] higher than the power of the last transmitted preamble. Transmission power of the data part of the random access message is set according to subclause 5.1.1.2.
- 9—Pass L1 status "RACH message transmitted" to the higher layers and exit the physical random access procedure.

#### Reference(s)

TS 25.214 clause 6.1.

#### 7.1.2.3.1.3 ————— Test purpose

To verify that:

A1—the UE, initially:

- derives the available uplink access slots, in the next full access slot set, for the set of available RACH sub-channels within the given ASC with the help of TS 25.214, subclauses 6.1.1. and 6.1.2. and randomly select one access slot among the ones previously determined.
- randomly select a new signature from the set of available signatures within the given ASC.

A2—the UE, when not receiving any reply from UTRAN:

- selects the next available access slot in the set of available RACH sub-channels within the given ASC.
- randomly select a new signature from the set of available signatures within the given ASC.
- does not transmit on the PRACH resources specified in the BCH message SIB 5 after that the physical random access procedure is terminated.

A3—the UE, when detecting a negative acquisition indicator:

- does not transmit on the PRACH resources specified in the BCH message SIB 5 after that the physical random access procedure is terminated.

A4—the UE, when detecting a positive acquisition indicator:

- transmits the random access message three or four uplink access slots after the uplink access slot of the last transmitted preamble depending on the AICH transmission timing parameter.
- terminates the random access procedure.

#### 7.1.2.3.1.4 ————— Method of test

##### Initial conditions

The UE shall be attached to the network and in idle mode.

Preamble Retrans Max parameter in SIB5 set to 5.

2 ASC settings (ASC#0 and ASC#1) are defined (with default parameters) in SIB5, except that the parameter assigned sub-channel number is set as follows:

ASC#0—Assigned sub-channel number = '0001'B

ASC#1—Assigned sub-channel number = '0010'B

The available sub-channel number defined in SIB5 is set to '0000 0000 0011'B. Note: this value allows RACH transmission on sub-channels 0 (ASC#0) and 1 (ASC#1) only.

**Related ICS/IXIT Statement(s)**

TBD

**Foreseen Final State of the UE**

The same as the initial conditions.

**Test procedure**

- a) The SS pages the UE until it performs a RACH access.
- b) The SS measures the access slot and preamble signature used.
- c) The SS does not acknowledge the RACH access, causing the UE to retry.
- d) The SS again measures the access slot and preamble signature used.
- e) The SS repeats the procedure from step c) until the maximum number of retries  $N_{RA}$  have been attempted, and monitors the RACH channel for [TBD] seconds to ensure that no further RACH accesses occur.
- f) The SS pages the UE until it performs a RACH access.
- g) The SS measures the the access slot and preamble signature used.
- h) The SS responds with a negative acquisition indicator on the AICH.
- i) The SS monitors the RACH channel for [TBD] seconds to ensure that no further RACH accesses occur.
- j) The SS pages the UE until it performs a RACH access.
- k) The SS measures the access slot used.
- l) The SS acknowledges the RACH access normally.
- m) The SS measures the first access slot used in the PRACH message part.
- n) The SS monitors the RACH channel for [TBD] seconds to ensure that no further RACH accesses occur.

## Expected sequence

| Step | Direction |    | Message                    | Comments                                                                                                                                                 |
|------|-----------|----|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                            |                                                                                                                                                          |
| 1    | ←         |    | PAGE                       | Preamble Retransmission Counter = 5                                                                                                                      |
| 2    | →         |    | RRC_CONNECTION_REQUEST     | Access slot used = 1 from {0,1,3,4,6,7,9,10,12,13}<br>Signature used = 1 from {P <sub>0</sub> ...P <sub>7</sub> }<br>Preamble Retransmission Counter = 4 |
| 3    | →         |    | RRC_CONNECTION_REQUEST     | Access slot used = 1 from {0,1,3,4,6,7,9,10,12,13}<br>Signature used = 1 from {P <sub>0</sub> ...P <sub>7</sub> }<br>Preamble Retransmission Counter = 3 |
| 4    | →         |    | RRC_CONNECTION_REQUEST     | Access slot used = 1 from {0,1,3,4,6,7,9,10,12,13}<br>Signature used = 1 from {P <sub>0</sub> ...P <sub>7</sub> }<br>Preamble Retransmission Counter = 2 |
| 5    | →         |    | RRC_CONNECTION_REQUEST     | Access slot used = 1 from {0,1,3,4,6,7,9,10,12,13}<br>Signature used = 1 from {P <sub>0</sub> ...P <sub>7</sub> }<br>Preamble Retransmission Counter = 1 |
| 6    | →         |    | RRC_CONNECTION_REQUEST     | Access slot used = 1 from {0,1,3,4,6,7,9,10,12,13}<br>Signature used = 1 from {P <sub>0</sub> ...P <sub>7</sub> }<br>Preamble Retransmission Counter = 0 |
| 7    |           |    | Wait for T = [TBD]s        | SS monitors for RACH access attempts                                                                                                                     |
| 8    | ←         |    | PAGE                       | Access slot used = 1 from {0,1,3,4,6,7,9,10,12,13}                                                                                                       |
| 9    | →         |    | RRC_CONNECTION_REQUEST     | Signature used = 1 from {P <sub>0</sub> ...P <sub>7</sub> }                                                                                              |
| 10   | ←         |    | AICH = NEG-ACQUISITION-IND |                                                                                                                                                          |
| 11   |           |    | Wait for T = [TBD]s        | SS monitors for RACH access attempts                                                                                                                     |
| 12   | ←         |    | PAGE                       |                                                                                                                                                          |
| 13   | →         |    | RRC_CONNECTION_REQUEST     | Access slot used = n = 1 from {0,1,3,4,6,7,9,10,12,13}<br>Signature used = 1 from {P <sub>0</sub> ...P <sub>7</sub> }                                    |
| 14   | ←         |    | AICH = POS-ACQUISITION-IND |                                                                                                                                                          |
| 15   | →         |    | RRC_CONNECTION_REQUEST     | Message part. Access slot used = n+3                                                                                                                     |
| 16   |           |    | Wait for T = [TBD]s        | SS monitors for RACH access attempts                                                                                                                     |

## Specific Message Contents

PRACH power offset info, PRACH info, and PRACH partitioning in System Information Block type 5

| Information Element              | Value/Remark           |
|----------------------------------|------------------------|
| PRACH info                       |                        |
| -CHOICE                          | FDD                    |
| -Available Sub Channel number    | '0000-0000-0000-0001'B |
| PRACH partitioning               |                        |
| -Access Service Class            |                        |
| -ASC Setting                     |                        |
| -CHOICE mode                     | FDD                    |
| -Available signature Start Index | 0 (ASC#0)              |
| -Available signature End Index   | 7 (ASC#0)              |
| -Assigned Sub-channel Number     | '0001'B                |
| -ASC Setting                     |                        |
| -CHOICE mode                     | FDD                    |
| -Available signature Start Index | 0 (ASC#1)              |
| -Available signature End Index   | 7 (ASC#1)              |
| -Assigned Sub-channel Number     | '0010'B                |
| PRACH power offset               |                        |
| -Preamble Retrans Max            | 5                      |

## 7.1.2.3.1.5 Test requirements

A1

At step 2

- the SS shall receive a PRACH preamble using an access slot from the set of access slots {0,1,3,4,6,7,9,10,12,13} and using a preamble signature from the set of preamble signatures { $P_0 \dots P_x$ }. See TS 25.213, clause 4.3.3.3 for a list of preamble codes.

A2

At steps 3, 4, 5, and 6

- the SS shall receive a PRACH preamble using an access slot from the set of access slots {0,1,3,4,6,7,9,10,12,13} and using a preamble signature from the set of preamble signatures { $P_0 \dots P_x$ }. See TS 25.213, clause 4.3.3.3 for a list of preamble codes.

At step 7

- the SS shall not receive on the PRACH resources specified in the BCH message SIB-5 after that the physical random access procedure is terminated.

A3

At step 11

- the SS shall not receive on the PRACH resources specified in the BCH message SIB-5 after that the physical random access procedure is terminated.

A4

At step 15

- the SS shall receive the random access message three access slots after the uplink access slot of the preamble received in step 13.

At step 11

- the SS shall not receive on the PRACH resources specified in the BCH message SIB-5 after that the physical random access procedure is terminated.

NOTE:— Due to the indeterminate timing parameter  $T_{p-p}$  (see TS 25.211, clause 7.3) it is not possible to determine the SFN and therefore the exact access slot set that should be used for PRACH preamble re-transmissions. It is only possible to determine a larger set based on allowed sub-channels.

#### ~~7.1.2.3.2 Correct Selection of RACH parameters (3.84 Mcps TDD option)~~

(FFS)

#### ~~7.1.2.3.3 Correct Selection of RACH parameters (1.28 Mcps TDD option)~~

##### ~~7.1.2.3.3.1 Definition and applicability~~

All TDD 1.28 Mcps UE

##### ~~7.1.2.3.3.2 Conformance requirement~~

That the UE selects UpPCH codes and UpPCH sub-channels that are defined for the ASC that the UE should adopt based on its AC (when the RACH message to be transmitted is an 'RRC Connection Request'). Parameters are defined in the SIB-5 messages received by the UE.

#### Reference(s)

TS25.224 clauses 4.7.1 and 5.6.

TS25.321 clause 11.2.3.



**7.1.2.3.3.3 Test Purpose**

To verify that the UE selects UpPCH codes and sub-channels that are allocated to the ASC that the UE should adopt based on its AC.

**7.1.2.3.3.4 Method of test****Initial conditions**

The UE is attached to the network and in idle mode. The Sim card should be configured so that the UE can adopt a known ASC based on its AC. The SS will broadcast SIB 5 messages that allocate to each ASC subsets of the total UpPCH codes and sub-channels.

**Related ICS/IXT Statement(s)**

TBD

**Foreseen Final State of the UE**

The same as the initial condition.

**Test procedure**

The test procedure is similar to that specified for test 7.1.2.1.3. In place of power level the test monitors the UpPCH codes that are used for the UE's UpPCH transmissions and the sub-channels in which they are made.

- a) The SS pages the UE to initiate the RACH access procedure;
- b) The SS does not respond to UpPCH transmissions received from the UE;
- c) The SS identifies the UpPCH codes on which the UE transmits;
- d) The SS identifies the system frame numbers of the frames in which the UE's UpPCH transmissions are received;
- e) The procedure is continued until the maximum permitted power ramping cycles, and within each power ramping cycle, the maximum number of UpPCH transmissions have been made.

**Expected sequence**

| Step | Direction |    | Message | Comments                              |
|------|-----------|----|---------|---------------------------------------|
|      | UE        | SS |         |                                       |
| 1    |           | <= | PAGE    |                                       |
| 2    |           | => | UpPCH   | Code and sub-channel should be valid. |
| 3    |           | => | UpPCH   | Code and sub-channel should be valid. |
| 4    |           |    | .....   |                                       |
| 5    |           | => | UpPCH   | Code and sub-channel should be valid. |
| 6    |           | => | UpPCH   | Code and sub-channel should be valid. |
| 7    |           | => | UpPCH   | Code and sub-channel should be valid. |
| 8    |           |    | .....   |                                       |
| 9    |           | => | UpPCH   | Code and sub-channel should be valid. |

**7.1.2.3.3.5 Test Requirements**

The UpPCH transmissions should be made in sub-channels and using codes that are allocated to the ASC that the UE should adopt based on its AC.

**7.1.2.4 Correct Detection and Response to FPACH (1.28 Mcps TDD option)****7.1.2.4.1 Definition and applicability**

All TDD 1,28 Mcps UE.

#### 7.1.2.4.2 Conformance requirement

That the UE:

1. Receives and acts upon an FPACH message transmitted within WT sub-frames of the UE transmitting a UpPCH code, provided that:
  - The FPACH was transmitted in the FPACH resource associated with the UpPCH code used by the UE; and
  - The FPACH message correctly identifies the UpPCH codes identity and the number of sub-frames between the UpPCH and the FPACH transmissions.
2. Responds to the valid FPACH by transmitting an 'RRC Connection Request' message in the PRACH resources associated with the FPACH. The transmission should:
  - Occupy the PRACH resource associated with the FPACH and the sub-channel in which the FPACH was received for the duration of the TTI;
  - Be made with a timing correction and a transmission power that are based on information received in the FPACH.
3. Does not respond to FPACH messages that are transmitted, within WT sub-frames of the UE UpPCH transmission, in FPACH resources that are not associated with the UpPCH code that the UE used. Nor should it respond to FPACH messages that are received on the correct FPACH resources within WT sub-frames but which contain the incorrect UpPCH code identifier or an incorrect indication of the number of sub-frames elapsed between the UpPCH and FPACH transmissions.

#### Reference(s)

TS 25.224 clauses 4.7.1, 5.2.3, 5.6.

TS 25.331 clause 8.5.7.

TS 25.321 clause 11.2.3.

#### 7.1.2.4.3 Test Purpose

To verify that:

- The UE does not respond to FPACH transmissions that are either, received on incorrect FPACH resources, or are received on correct resources and within WT sub-frames of the UpPCH transmission, but which do not contain the correct UpPCH identity or elapsed sub-frames.
- The UE does respond to an FPACH transmission that is received, within WT sub-frames of the UpPCH transmission, on the correct FPACH resources for the UpPCH code that was used, provided that the FPACH contains the identity of the UpPCH code and the number of sub-frames elapsed between the UpPCH and the FPACH transmissions.
- The UE response is to transmit an 'RRC Connection Request' message on the PRACH resources that are associated with the FPACH taking account of the timing correction and power adjustment parameters received in the FPACH.

#### 7.1.2.4.4 Method of test

##### Initial conditions

The UE is attached to the network and in idle mode. The SS-BCH-SIB-5 message will specify that there are two or more FPACH associated with the UpPCH code set in a single PRACH system information. The UpPCH code set must include one or more odd and one or more even numbered codes.

##### Related ICS/IXT Statement(s)

TBD

### Foreseen Final State of the UE

The same as the initial condition.

### Test procedure

The test procedure consists of a number of stages:

- a) The SS pages the UE to initiate RACH access.
- b) When UpPCH transmissions are received from the UE the SS should transmit FPACH responses within WT sub-frames of each UpPCH transmission but on an incorrect FPACH resource for the UpPCH code used. It is noted that the UE may change the code used for each UpPCH transmission randomly amongst those available to its ASC.
- c) The PRACH resources associated with all of the FPACH should be monitored for a transmission from the UE.
- d) The SS pages the UE to initiate RACH access.
- e) When UpPCH transmissions are received from the UE the SS should transmit FPACH responses within WT sub-frames of each UpPCH transmission on the correct FPACH resource for the UpPCH code used. The FPACH transmission should contain a signature reference number that is different from that of the UpPCH code that was used by the UE.
- f) The PRACH resources associated with all of the FPACH should be monitored for a transmission from the UE.
- g) The SS pages the UE to initiate RACH access.
- h) When UpPCH transmissions are received from the UE the SS should transmit FPACH responses within WT sub-frames of each UpPCH transmission on the correct FPACH resource for the UpPCH code used. The FPACH transmission should contain a relative sub-frame number that is different from that defined by the elapsed number of frames between the UpPCH and the FPACH transmissions.
- i) The PRACH resources associated with all of the FPACH should be monitored for a transmission from the UE.
- j) The SS pages the UE to initiate RACH access.
- k) When UpPCH transmissions are received from the UE the SS should transmit an FPACH response on the correct FPACH resources for the UpPCH code that was used by the UE. The FPACH response should include correct values for the signature reference and relative sub-frame number fields. The FPACH should also include known entries for the Received starting position of the UpPCH ( $\text{UpPCH}_{\text{POS}}$ ) and the Transmit Power Level Command for RACH ( $\text{PRX}_{\text{PRACHdes}}$ ) fields.
- l) The SS should monitor the PRACH resources associated with the FPACH commencing two or three sub-frames (depending upon the sub-frame in which the FPACH was transmitted and the length of the TTI) following the sub-frame in which the FPACH was transmitted and continuing for the number of sub-frames in the RACH TTI. The power level of the PRACH transmissions and the time of arrival of their mid-ambles should be measured. The SS should continue to monitor the UpPCH slot to ensure that the UE has ceased UpPCH transmissions.

## Expected sequence

| Step | Direction |    | Message                | Comments                                 |
|------|-----------|----|------------------------|------------------------------------------|
|      | UE        | SS |                        |                                          |
| 1    |           | ←  | PAGE                   |                                          |
| 2    |           | →  | UpPCH                  |                                          |
| 3    |           | ←  | FPACH                  | Incorrect FPACH resources                |
| 4    |           | →  | UpPCH                  |                                          |
| 5    |           |    | .....                  |                                          |
| 6    |           | →  | PAGE                   |                                          |
| 7    |           | →  | UpPCH                  |                                          |
| 8    |           | ←  | FPACH                  | Incorrect signature reference            |
| 9    |           | →  | UpPCH                  |                                          |
| 10   |           |    | .....                  |                                          |
| 11   |           | ←  | PAGE                   |                                          |
| 12   |           | →  | UpPCH                  |                                          |
| 13   |           | ←  | FPACH                  | Incorrect relative sub-frame number      |
| 14   |           | →  | UpPCH                  |                                          |
| 15   |           |    | .....                  |                                          |
| 16   |           | ←  | PAGE                   |                                          |
| 17   |           | →  | UpPCH                  |                                          |
| 18   |           | ←  | FPACH                  | Correct resources and information fields |
| 19   |           | →  | RRC Connection Request |                                          |

$$P_{PRACH} = L_{PCCPCH} + PRX_{PRACHdes} + i * P_{Wf_{ramp}}$$

$$UpPCH_{RX-offset} - UpPCH_{POS}$$

## 7.1.2.4.5 Test Requirements

The UE should not respond to FPACH transmissions, which are made on the incorrect FPACH resources for the UpPCH code that the UE uses. The UE should continue to transmit UpPCH until the permitted maximum number of power ramping cycles is complete.

The UE should not respond to FPACH transmissions which are made within WT sub-frames of a UpPCH transmission and on the correct FPACH resources for the UpPCH code that it used if the FPACH contains either an incorrect signature reference number or an incorrect relative sub-frame number. The UE should continue to transmit UpPCH until the permitted maximum number of power ramping cycles is complete.

The UE should respond to an FPACH received within WT sub-frames of a UpPCH transmission if the FPACH is received on the correct FPACH resources for the UpPCH code used and if it contains valid information fields. The UE should cease transmitting UpPCH bursts and transmit an RRC Connection Request message using the PRACH resources that are associated with the FPACH and the sub-frame in which the FPACH was received. The transmission should commence two or three sub-frames after that containing the FPACH (dependent upon the sub-frame in which the FPACH was transmitted and the length of the TTI) and is made in all sub-frames within the TTI. Each PRACH burst should be made using the transmission power:

$$P_{PRACH} = L_{PCCPCH} + PRX_{PRACHdes} + i * P_{Wf_{ramp}}$$

When the power used by the UE for the UpPCH transmission acknowledged by the FPACH was:

$$P_{UpPCH} = L_{PCCPCH} + PRX_{UpPCHdes} + i * P_{Wf_{ramp}}$$

And transmission timing should be such that the start of each PRACH burst is offset from the beginning of the PRACH slot by:

$$UpPCH_{RX-offset} - UpPCH_{POS} \text{ chips, to an accuracy of } 1/8 \text{ chip.}$$

Where  $UpPCH_{RX-offset}$  denotes the offset from the start of the UpPCH slot of the UE's transmission measured by SS and  $UpPCH_{POS}$  is the timing correction signalled to the UE in the FPACH.

## 7.1.2.4a Access Service class selection for RACH transmission

## 7.1.2.4a.1 Definition and applicability

All UE.

#### 7.1.2.4a.2 ~~Conformance requirement~~

~~The following ASC selection scheme shall be applied, where NumASC is the highest available ASC number and MinMLP the highest logical channel priority assigned to one logical channel:~~

- ~~— In case all TBs in the TB set have the same MLP, select  $ASC = \min(\text{NumASC}, \text{MLP})$ .~~
- ~~— In case TBs in a TB set have different priority, determine the highest priority level MinMLP and select  $ASC = \min(\text{NumASC}, \text{MinMLP})$ .~~

#### Reference(s)

~~TS 25.321 clause 11.2.1.~~

#### 7.1.2.4a.3 ~~Test purpose~~

~~To verify that MAC selects ASC correctly.~~

#### 7.1.2.4a.4 ~~Method of test~~

#### Initial conditions

System Simulator:

- ~~— 1 cell, default parameters, Ciphering Off.~~

User Equipment:

- ~~— The UE shall operate under normal test conditions, Ciphering Off.~~
- ~~— The Test-USIM shall be inserted~~
- ~~— The SS starts broadcasting the System Information as specified in TS 34.108 clause 6.1, using the configuration for the PRACH and SCCPCH (signalled in SYSTEM INFORMATION 5) as follows:~~
  - ~~1. The SCCPCH is configured as specified in TS 34.108 clause 6.10.2.4.3.3 (Interactive/Background 32 kbps RAB + SRB for PCCH + SRB for CCCH + SRB for DCCH + SRB for BCCH).~~
  - ~~2. The PRACH is configured as specified in TS 34.108 clause 6.10.2.4.4.1.~~
- ~~— The SS follows the procedure in TS 34.108 clause 7.4.2.1 (Mobile Terminated) so that the UE shall be in state BGP 6-2 (CS-CELL\_FACH\_INITIAL) with the following exception:~~
  - ~~1. The MAC Logical Priority (MLP) of the user RAB is set to 8.~~

~~The user RAB is placed into loop-back mode 1 each with the UL SDU size set to 39 bytes.~~

#### Related ICS/IXIT Statement(s)

~~TBD~~

#### Foreseen Final State of the UE

#### Test procedure

- ~~a) The SS receives the PAGING RESPONSE message from the UE and checks the access slots and preamble signatures used correspond to a valid ASC as transmitted in system information.~~
- ~~b) The SS reconfigures the transmitted system information as follows:~~
  - ~~— Only one ASC setting (ASC#0) is defined (with default parameters).~~

~~The available sub-channel number defined in system information is set to '0000 0000 0001'B. Note: this value allows RACH transmission on sub-channel 0 only.~~

- The SS then waits enough time for the UE to take the system information change into account.
- c) The SS sends 1 RLC SDU of size 10 bytes on the downlink user RAB.
- d) The SS waits to receive uplink data on RACH TrCH via the user RAB, then checks that the access slots and preamble signatures used correspond to ASC#0.
- e) The SS reconfigures the transmitted system information as follows:
  - Four ASC settings (ASC#0 to ASC#3) are defined (with default parameters), except that the parameter assigned sub-channel number is set as follows:
    - ASC#0 — Assigned sub-channel number = '0000'B
    - ASC#1 — Assigned sub-channel number = '0001'B
    - ASC#2 — Assigned sub-channel number = '0000'B
    - ASC#3 — Assigned sub-channel number = '0010'B
- The available sub-channel number defined in system information is set to '0000-0000-0001'B Note: this value allows RACH transmission on sub-channel 0 only (ASC#1).
- The SS then waits enough time for the UE to take the system information change into account.
- f) The SS sends 1 RLC SDU of size 10 bytes on the downlink user RAB.
- g) The SS waits 2s to ensure no uplink data is received on RACH TrCH via the user RAB.
- h) The SS then reconfigures the uplink user RAB to have a MAC Logical Priority of 1.
- i) The SS sends 1 RLC SDU of size 10 bytes on the downlink user RAB.
- j) The SS waits to receive uplink data on RACH TrCH via the user RAB, then checks that the access slots and preamble signatures used correspond to ASC#1.
- k) The SS may optionally release the radio bearer.

#### Expected sequence

| Step | Direction |    | Message            | Comments                                   |
|------|-----------|----|--------------------|--------------------------------------------|
|      | UE        | SS |                    |                                            |
| 1    | →         |    | PAGING RESPONSE    | SS checks ASC parameters                   |
| 2    | ←         |    |                    | Modified system information                |
| 3    | ←         |    | RLC PDU            |                                            |
| 4    | →         |    | RLC PDU            | SS checks ASC parameters (ASC#0)           |
| 5    | ←         |    |                    | Modified system information                |
| 6    | ←         |    | RLC PDU            |                                            |
| 6a   |           |    |                    | SS waits to check no RLC PDUs are received |
| 7    | ↔         |    | RB RECONFIGURATION | User RAB MLP = 1                           |
| 8    | ←         |    | RLC PDU            |                                            |
| 9    | →         |    | RLC PDU            | SS checks ASC parameters (ASC#1)           |
| 10   | ↔         |    | RB RELEASE         | optional                                   |

#### 7.1.2.4a.5 — Test requirements

In step 1, the access slots and preamble signatures used on the PRACH TrCH on which the PAGING RESPONSE message was received shall correspond to configured legal values for the allowed ASCs on the PRACH.

In step 4, the access slots and preamble signatures used on the PRACH TrCH on which the RLC PDU was received shall correspond to configured legal values for the allowed ASC#0.

In step 6a, no PDUs shall be received on PRACH.

In step 9, the access slots and preamble signatures used on the PRACH TrCH on which the RLC PDU was received shall correspond to configured legal values for the allowed ASC#1.

#### ~~7.1.2.5 Control of RACH transmissions for FDD mode~~

##### ~~7.1.2.5.1 Definition and applicability~~

~~All UE.~~

##### ~~7.1.2.5.2 Conformance requirement~~

~~MAC receives the following RACH transmission control parameters from RRC with the CMAC-Config-REQ primitive: maximum number of preamble ramping cycles Mmax.~~

~~When preamble transmission counter M larger than Mmax, then the procedure will stop and enter Error handling procedure.~~

#### ~~Reference(s)~~

~~TS 25.321 11.2.2, TS 25.321 figure 11.2.2.1.~~

##### ~~7.1.2.5.3 Test purpose~~

~~To verify that the MAC entity controls RACH transmission correctly.~~

##### ~~7.1.2.5.4 Method of test~~

#### ~~Initial conditions~~

~~System Simulator:~~

- ~~— 1 cell, default parameters, Ciphering Off.~~
- ~~— SS broadcast System Information 5 with Mmax in RACH transmission parameters set as 0.~~

~~User Equipment:~~

- ~~— The UE shall operate under normal test conditions, Ciphering Off.~~
- ~~— The Test-USIM shall be inserted.~~

~~The SS starts broadcasting the System Information as specified in TS 34.108 clause 6.1, using the configuration for the PRACH and SCCPCH (signalled in SYSTEM INFORMATION 5) as follows:~~

- ~~1. The SCCPCH is configured as specified in TS 34.108 clause 6.10.2.4.3.3 (Interactive/Background 32 kbps RAB + SRB for PCCH + SRB for CCCH + SRB for DCCH + SRB for BCCH).~~
- ~~2. The PRACH is configured as specified in TS 34.108 clause 6.10.2.4.4.1.~~

~~The SS follows the procedure in TS 34.108 clause 7.2.2.1 (CS UE) or 7.2.2.2 (PS UE) so that the UE shall be in idle mode and registered.~~

#### ~~Related ICS/IXIT Statement(s)~~

~~TBD~~

#### ~~Foreseen Final State of the UE~~

~~The same as the initial conditions.~~

**Test procedure**

- a) ~~Transmission of the default system information messages specified in TS 34.108, clause 6.1 is modified such that:~~
- ~~—The dynamic persistence level (N) defined in SIB7 is set to 1, and the persistence scaling factors ( $s_x$ ) defined in SIB5 are not broadcast. Note: these values should result in an attempted RACH transmission at every persistence check.~~
  - ~~—The RACH transmission parameter  $M_{\max}$  defined in SIB5 is set to 1.~~
  - ~~—The counter N300 broadcast in SIB1 is set to 1.~~
- b) ~~The SS pages the UE for a RRC CONNECTION REQUEST.~~
- c) ~~The SS waits for a RACH preamble transmission on AICH, and does not respond to the RACH preamble transmission on AICH. This step shall be repeated  $M_{\max}$  times.~~
- d) ~~The SS checks for 100ms that no further RACH preamble transmissions are received.~~

~~The above procedure is repeated with  $M_{\max}$  set to 5.~~

**Expected sequence:**

| Step | Direction |    | Message            | Comments                   |
|------|-----------|----|--------------------|----------------------------|
|      | UE        | SS |                    |                            |
| 1    |           | ←  | System information | Modified SIB5, SIB7        |
| 2    |           | ←  | PAGING             |                            |
| 3    |           | →  | RACH preamble      | Repeated $M_{\max}$ times. |

**7.1.2.5.5 Test requirements**

~~The SS shall receive 1 RACH preamble from the UE when  $M_{\max} = 1$ .~~

~~The SS shall receive 5 RACH preambles from the UE when  $M_{\max} = 5$ .~~

**7.1.3 Priority handling between data flows of one UE****7.1.3.1 Priority handling between data flows of one UE****7.1.3.1.1 Definition and applicability****7.1.3.1.2 Conformance requirement**

~~When selecting between the Transport Format Combinations in the given Transport FormatCombination Set, priorities of the data flows to be mapped onto the corresponding Transport Channels can be taken into account.~~

~~The chosen TFC shall be selected from within the set of valid TFCs and shall satisfy the following criteria in the order in which they are listed below:~~

- ~~1. No other TFC shall allow the transmission of more highest priority data than the chosen TFC.~~
- ~~2. No other TFC shall allow the transmission of more data from the next lower priority logical channels. Apply this criterion recursively for the remaining priority levels.~~
- ~~3. No other TFC shall have a lower bit rate than the chosen TFC.~~

~~The above rules for TFC selection in the UE shall apply to DCH, and the same rules shall apply for TF selection on RACH and CPGH.~~



## Reference(s)

~~TS 25.301 clause 5.3.1.2.~~

~~TS 25.321, clause 11.4.~~

### ~~7.1.3.1.3 Test purpose~~

~~To verify that the priority between data flows of one UE was correctly handled.~~

### ~~7.1.3.1.4 Method of test~~

## Initial conditions

### System Simulator:

- ~~— 1 cell, default parameters, Ciphering Off.~~

### User Equipment:

- ~~— The UE shall operate under normal test conditions, Ciphering Off.~~
- ~~— The Test-USIM shall be inserted.~~

~~The UE is in Connected mode and a connection is established as described in the TS 34.123-1, 7.3.1.2.1.1 PDCP testing, clause "Setup a UE terminated PS session using IP Header compression in AM RLC (using Loop back test mode 1)", but for two Radio Bearer entities user (RAB#0 and RAB#1). Both user RABs shall be initially configured with a MAC logical priority of 3. The allowed TFCs shall be limited in the UE such that it's not possible to simultaneously transmit at the highest possible data rate on the DCH for each user RAB. Simultaneous transmission at lower data rates shall be possible.~~

~~The RABs are placed into loop-back mode 1 each with the UL SDU size set to 39 bytes.~~

## Related ICS/EXIT Statement(s)

~~TBD~~

## Foreseen Final State of the UE

## Test procedure

- ~~a) The SS simultaneously sends 40 RLC SDUs of size 9 bytes each on each user RAB. The SDUs are concatenated, 4 to each PDU.~~
- ~~b) After having received the PDUs via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.~~
- ~~c) The SS receives the returned data and reads each TFCI which indicates the Transport Format.~~
- ~~d) The SS checks, that high data rate RBs have a high bit rate Transport Format.~~
- ~~e) Repeat step a) to d) with different MAC logical channel priority (MAC priority of RAB#0 set as 3, MAC priority of RAB#1 set as 1).~~

## Expected sequence

| Step | Direction |    | Message                                                                                                         | Comments                                                                                                                                          |
|------|-----------|----|-----------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                                                                 |                                                                                                                                                   |
| 1    |           |    |                                                                                                                 | SS sends CRLC_CONFIG_REQ with RLC mode as "Transparent Mode".                                                                                     |
| 2    |           | ←  | DATA BLOCKS<br>(Simultaneous PDUs on RAB#0 and RAB#1)                                                           |                                                                                                                                                   |
| 3    |           | →  | LOOP BACK DATA BLOCKS<br>(Order of received PDUs on RAB#0 and RAB#1 depends on configured MAC Logical Priority) | Read the Transfer Format of loop back data blocks, the high bit transfer format apply to the Radio Bearer with high MAC logical channel priority. |
| 4    |           |    |                                                                                                                 | The step 1 to 3 shall be repeated with different MAC logical channel priority.                                                                    |

## 7.1.3.1.5 Test requirements

## Iteration1:

The high bit rate TF is applied to the high MAC logical channel priority Radio Bearer. That is, the bit rate of TF used in user RAB#1 should be the same as that used in user RAB#0. Note: UE and SS timing issues may produce a slightly biased result.

NOTE:—Measurements shall be taken over the 5<sup>th</sup> to 35<sup>th</sup> RLC PDUs received.

## Iteration2:

The high bit rate TF is applied to the high MAC logical channel priority Radio Bearer. That is, the bit rate of TF used in user RAB#1 should be not less than that used in user RAB#0.

NOTE:—Measurements shall be taken over the 5<sup>th</sup> to 35<sup>th</sup> RLC PDUs received.

## 7.1.4 Control of CPCH transmissions.

## 7.1.4.1 Control of CPCH transmissions for FDD

## 7.1.4.1.1 Definition and applicability

All UEs which support CPCH.

## 7.1.4.1.2 Conformance requirement

1. If counter M is not less than N<sub>access\_fails</sub>, the UE shall execute an access failure error procedure and the CPCH access procedure ends.
2. If the sum of the Frame Count Transmitted counter plus the number of frames in the next TTI is larger than NF<sub>max</sub>, the UE shall exit the CPCH transmission procedure.
3. If the CSICH information indicates no PCPCH is available, the UE shall not attempt CPCH access.
4. If the CPCH Persistency levels are all set to 8, the UE shall not attempt CPCH access.
5. If the SS issues an immediate Emergency Stop command in the DL-DPCCH for CPCH, the UE shall abort CPCH access.

## Reference(s)

TS 25.321 clause 11.3

TS 25.214 clause 6.

TS 25.211 clause 5.3.3.11.

#### 7.1.4.1.3 ~~Test purpose~~

~~To verify that the MAC entity control CPH transmission correctly.~~

#### 7.1.4.1.4 ~~Method of test~~

##### ~~Initial conditions~~

##### ~~System Simulator:~~

- ~~— 1 cell, default parameters, Ciphering Off.~~

##### ~~User Equipment:~~

- ~~— The UE shall operate under normal test conditions, Ciphering Off.~~
- ~~— The Test-USIM shall be inserted.~~

~~The UE is in Connected mode and a connection is established as described in the TS 34.123-1, clause 7.3 PDCP testing, clause "Setup a UE originated PS session using IP Header compression in AM RLC (using Loop back test mode 1).~~

##### ~~Related ICS/IXIT Statement(s)~~

~~TBD~~

##### ~~Foreseen Final State of the UE~~

~~The same as the initial conditions.~~

##### ~~Test procedure~~

- ~~a) The SS ends SIBs 7, 8 and 9, sends CSICH information and waits 30 s.~~
- ~~b) The SS configures its RLC entity for "Transparent Mode".~~
- ~~c) The SS sends certain DATA BLOCKS to UE with UE-Id type and UE-Id field.~~
- ~~d) After having received the data block via configured mapped channels, the UE forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its MAC configuration to the SS.~~
- ~~e) The SS receives returned DATA BLOCKS.~~
- ~~f) The SS configures its RLC entity for "AM mode".~~
- ~~g) The SS starts the RB reconfiguration procedure by sending the RADIO BEARER RECONFIGURATION message.~~
- ~~h) After having received the UE confirmation for the reconfiguration procedure, the SS configures its RLC entity for "Transparent Mode".~~
- ~~i) The SS sends SIB 8 on BCH with parameter : N\_access\_fails = 0 and waits 30 s.~~
- ~~j) The SS sends certain DATA BLOCKS.~~
- ~~k) The SS shall not receive any LOOP BACK DATA BLOCKS within 30 s.~~
- ~~l) The SS configures its RLC entity for "AM mode".~~
- ~~m) The SS starts the RB reconfiguration procedure by sending the RADIO BEARER RECONFIGURATION message.~~
- ~~n) The SS receives RADIO BEARER RECONFIGURE COMPLETE.~~
- ~~o) After having received the UE confirmation for the reconfiguration procedure, the SS configures its RLC entity for "Transparent Mode".~~

- p) — The SS sends SIB-8 on BCH with parameter : NF\_max = 0 and waits 30 s.
- q) — The SS sends certain DATA BLOCKS.
- r) — The SS shall not receive any returned DATA BLOCKS within 30 s.
- s) — The SS configures its RLC entity for "AM mode".
- t) — The SS starts the RB reconfiguration procedure by sending the RADIO BEARER RECONFIGURATION message.
- u) — The SS receives RADIO BEARER RECONFIGURE COMPLETE.
- v) — After having received the UE confirmation for the reconfiguration procedure, the SS configures its RLC entity for "Transparent Mode".
- w) — The SS sends SIB-8 on BCH and waits 30 s.
- x) — The SS continuously sends CSICH information with PCA1=PCA2= NOT AVAILABLE.
- y) — The SS sends certain DATA BLOCKS.
- z) — The SS shall not receive any returned DATA BLOCKS within 30 s.
- aa) — The SS configures its RLC entity for "AM mode".
- bb) — The SS starts the RB reconfiguration procedure by sending the RADIO BEARER RECONFIGURATION message.
- cc) — The SS receives RADIO BEARER RECONFIGURE COMPLETE.
- dd) — After having received the UE confirmation for the reconfiguration procedure, the SS configures its RLC entity for "Transparent Mode".
- ee) — The SS sends CSICH information with PCA1=PCA2= AVAILABLE and the SS PHY is configured to send CPCH Emergency Stop message in all DL DPCCHs for CPCH after N\_start\_message frames.
- ff) — The SS sends certain DATA BLOCKS.
- gg) — The SS shall not receive any returned DATA BLOCKS within 30 s.
- hh) — The SS configures its RLC entity for "AM mode".
- ii) — The SS starts the RB reconfiguration procedure by sending the RADIO BEARER RECONFIGURATION message.
- jj) — The SS receives RADIO BEARER RECONFIGURE COMPLETE.
- kk) — After having received the UE confirmation for the reconfiguration procedure, the SS configures its RLC entity for "Transparent Mode".
- ll) — The SS sends SIB-9 on BCH with the CPCH persistence levels set to 8, no access allowed.
- mm) — The SS sends certain DATA BLOCKS.
- nn) — The SS shall not receive any returned DATA BLOCKS within 30 s.
- oo) — The SS configures its RLC entity for "AM mode".
- pp) — The SS starts the RB reconfiguration procedure by sending the RADIO BEARER RECONFIGURATION message.
- qq) — The SS receives RADIO BEARER RECONFIGURE COMPLETE.
- rr) — After having received the UE confirmation for the reconfiguration procedure, the SS configures its RLC entity for "Transparent Mode".
- ss) — The SS sends SIB-9 on BCH with the CPCH persistence levels set to 1, immediate access allowed.

tt) — The SS sends certain DATA BLOCKS.

uu) — The SS receives returned DATA BLOCKS.

vv) — The SS configures its RLC entity for "AM mode".

## Expected sequence

| Step | Direction |    | Message                               | Comments                                                                                                      |
|------|-----------|----|---------------------------------------|---------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                               |
| 1    | ←         |    | SIBs 7, 8 and 9 and CSICH information | Containing default settings for CPCH                                                                          |
| 2    |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode". |
| 3    | ←         |    | DATA BLOCKS                           |                                                                                                               |
| 4    | →         |    | LOOP BACK DATA BLOCKS                 |                                                                                                               |
| 5    |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".           |
| 6    | ←         |    | RADIO BEARER RECONFIGURATION          |                                                                                                               |
| 7    | →         |    | RADIO BEARER RECONFIGURATION COMPLETE |                                                                                                               |
| 8    |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode". |
| 9    | ←         |    | SIB-8                                 | N_access_fails = 0                                                                                            |
| 10   | ←         |    | DATA BLOCK                            |                                                                                                               |
| 11   |           |    |                                       | The SS can't receive loop back data blocks from UE in 30s.                                                    |
| 12   |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".           |
| 13   | ←         |    | RADIO BEARER RECONFIGURATION          |                                                                                                               |
| 14   | →         |    | RADIO BEARER RECONFIGURATION COMPLETE |                                                                                                               |
| 15   |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode". |
| 16   | ←         |    | SIB-8                                 | NF_max = 0                                                                                                    |
| 17   | ←         |    | DATA BLOCK                            | UE was triggered to send data block.                                                                          |
| 18   |           |    |                                       | The SS can't receive data from UE in 30s                                                                      |
| 19   |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".           |
| 20   | ←         |    | RADIO BEARER RECONFIGURATION          |                                                                                                               |
| 21   | →         |    | RADIO BEARER RECONFIGURATION COMPLETE |                                                                                                               |
| 22   |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode". |
| 23   | ←         |    | SIB-8 and CSICH information           | PCA1=PCA2= NOT AVAILABLE                                                                                      |
| 24   | ←         |    | DATA BLOCK                            |                                                                                                               |
| 25   |           |    |                                       | The SS can't receive data from UE in 30s                                                                      |
| 26   |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".           |
| 27   | ←         |    | RADIO BEARER RECONFIGURATION          |                                                                                                               |
| 28   | →         |    | RADIO BEARER RECONFIGURATION COMPLETE |                                                                                                               |
| 29   |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode". |

| Step | Direction |    | Message                               | Comments                                                                                                      |
|------|-----------|----|---------------------------------------|---------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                               |
| 30   | ←         |    | SIB-8 and CSICH information           | PCA1=PCA2=AVAILABLE                                                                                           |
| 31   |           |    |                                       | SS sends a CPCH-Estop command in all DLDPCHs for CPCH after N_start_message frames                            |
| 32   | ←         |    | DATA BLOCK                            |                                                                                                               |
| 33   |           |    |                                       | The SS can't receive data from UE in 30s                                                                      |
| 34   |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".           |
| 35   | ←         |    | RADIO-BEARER RECONFIGURATION          |                                                                                                               |
| 36   | →         |    | RADIO-BEARER RECONFIGURATION COMPLETE |                                                                                                               |
| 37   |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode". |
| 38   | ←         |    | SIB-9                                 | CPCH Persistence levels set to 8; no access allowed                                                           |
| 39   | ←         |    | DATA BLOCK                            |                                                                                                               |
| 40   |           |    |                                       | The SS can't receive data from UE in 30s                                                                      |
| 41   |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".           |
| 42   | ←         |    | RADIO-BEARER RECONFIGURATION          |                                                                                                               |
| 43   | →         |    | RADIO-BEARER RECONFIGURATION COMPLETE |                                                                                                               |
| 44   |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with disable_mac_header and CRLC_CONFIG_REQ with RLC mode as "Transparent mode". |
| 45   | ←         |    | SIB-9                                 | CPCH Persistence levels set to 1; immediate access allowed                                                    |
| 46   | ←         |    | DATA BLOCK                            |                                                                                                               |
| 47   | →         |    | LOOP-BACK DATA BLOCKS                 |                                                                                                               |
| 48   |           |    |                                       | SS sends CMAC_MAC_HEADER_REQ with enable_mac_header and CRLC_CONFIG_REQ with RLC mode as "AM mode".           |

### Specific Message Contents

#### RADIO-BEARER SET-UP:

| Information Element                                                                                | Value/remark |
|----------------------------------------------------------------------------------------------------|--------------|
| RLC info<br>— RLC mode                                                                             | AM-RLC       |
| RB-mapping info<br>— Downlink<br>- Number of logical channels<br>- Downlink transport channel type | 1<br>FACH    |
| — Uplink<br>- Number of logical channels<br>- Uplink transport channel type                        | 1<br>CPCH    |

## PRACH persistence level info in System Information Block type 7

| Information Element                                  | Value/Remark                                                                |
|------------------------------------------------------|-----------------------------------------------------------------------------|
| PRACHs listed in SIB-5<br>-Dynamic persistence level | All set to 8, which maps to minimum persistence value,<br>no access allowed |
| PRACHs listed in SIB-6<br>-Dynamic persistence level | All set to 8, which maps to minimum persistence value,<br>no access allowed |

## CPCH parameters in System Information Block type 8

| Information Element          | Value/Remark |
|------------------------------|--------------|
| Back-off control parameters  |              |
| -N <sub>ap_retrans_max</sub> | 15           |
| -N <sub>access_fails</sub>   | 15           |
| -N <sub>F_bo_no_aich</sub>   | 15           |
| -N <sub>S_bo_busy</sub>      | 15           |
| -N <sub>F_bo_all_busy</sub>  | 15           |
| -N <sub>F_bo_mismatch</sub>  | 15           |
| -T <sub>CPCH</sub>           | 0            |
| Power Control Algorithm      | algorithm 1  |
| TPC step size                | 1            |
| DL DPCCH BER                 | 15           |

## CPCH set info in System Information Block type 8

| Information Element           | Value/Remark |
|-------------------------------|--------------|
| AP preamble scrambling code   | 16           |
| AP-AICH channelisation code   | 15           |
| CD preamble scrambling code   | 17           |
| CD/CA-ICH channelisation code | 16           |
| DeltaPp-m                     | 0            |
| UL DPCCH Slot Format          | 1            |
| N <sub>start_message</sub>    | 8            |
| CPCH status indication mode   | PA mode      |
| PCPCH Channel #1 info         |              |
| -UL scrambling code           | 18           |
| -DL channelisation code       | 15           |
| -PCP length                   | 8            |
| -UCSM info                    |              |
| -Minimum spreading factor     | 64           |
| -N <sub>F_max</sub>           | 64           |
| -AP signature                 | 15           |
| PCPCH Channel #2 info         |              |
| -UL scrambling code           | 19           |
| -DL channelisation code       | 14           |
| -PCP length                   | 8            |
| -UCSM info                    |              |
| -Minimum spreading factor     | 64           |
| -N <sub>F_max</sub>           | 64           |
| -AP signature                 | 14           |



## PCPCH persistence level info in System Information Block type 9

| Information Element                                     | Value/Remark                            |
|---------------------------------------------------------|-----------------------------------------|
| CPCH set persistence levels<br>—PCPCH persistence level | Both set to 1, immediate access allowed |

## CSICH Information broadcast by SS PHY

| Information Element                                  | Value/Remark           |
|------------------------------------------------------|------------------------|
| PCPCH Channel Availability (PCA) :<br>—PCA1<br>—PCA2 | Available<br>Available |

## 7.1.4.1.5 ————— Test requirements

The SS can't receives data blocks from UE when N\_access\_fails or NF\_max set as 0.

The SS can't receives data blocks from UE when NF\_max set as 0.

The SS can't receives data blocks from UE when CSICH info indicates channels not available.

The SS can't receives data blocks from UE when CPCH Persistency level set to 8.

The SS can't receives data blocks from UE when Emergency Stop message terminates access.

## 7.2 ——— RLC testing

## 7.2.1 ——— Transparent mode

## 7.2.1.1 ——— Segmentation and reassembly

Transparent mode segmentation and reassembly are not tested in this release of the specification.

## 7.2.2 ——— Unacknowledged mode

## 7.2.2.1 ——— General information for UM tests

Two generic Radio Access Bearers are provided for UM tests.

The UM test RAB is set up using the Generic Procedure described in clause 7.1.3 of TS 34.108, and with the default RAB replaced as follows:

- For UM 7-bit length indicator tests: the RB configuration described in 3G TS 34.108 clause 6.11.1 is used. For these tests, let UM\_7\_PayloadSize denote the RAB payload size in octets.
- For UM 15-bit length indicator tests: the RB configuration described in 3G TS 34.108 clause 6.11.2 is used. For these tests, let UM\_15\_PayloadSize denote the RAB payload size in octets.

The UM test RABs are used in all tests with the following exception:

- Tests that explicitly specify a different Radio Bearer configuration.

All other settings are the same.

### ~~7.2.2.2 Segmentation and reassembly / Selection of 7 or 15 bit Length Indicators~~

#### ~~7.2.2.2.1 Definition~~

~~The RLC segments and concatenates SDUs into payload units according to the payload unit size requested by MAC. Length indicators are added to allow correct reconstruction of SDUs. The selection of the size of the length indicator fields used must follow the specified rules. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.~~

#### ~~7.2.2.2.2 Conformance requirement~~

~~The size of the Length Indicator may be either 7 bits or 15 bits.~~

~~For UM, 7 bit indicators shall be used if the UMD PDU size is  $\leq 125$  octets. Otherwise 15bit indicators shall be used.~~

~~The length of the Length Indicator only depends on the size of the largest RLC PDU. The length of the Length Indicator is always the same for all PDUs, for one RLC entity.~~

#### ~~Reference(s)~~

~~TS 25.322 clauses 9.2.2.8 and 9.2.2.9.~~

#### ~~7.2.2.2.3 Test purpose~~

~~To test that if the size of the largest PDU is  $\leq 125$  octets, 7 bit indicators are used, otherwise, 15-bit indicators are used.~~

#### ~~7.2.2.2.4 Method of test~~

#### ~~Initial conditions~~

~~The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 7-bit length indicator tests in clause 7.2.2.1.~~

~~These settings apply to both the uplink and downlink DTCH.~~

~~The radio bearer is placed into UE test loop mode 1 with the UL SDU size set to 10 bytes.~~

#### ~~Test procedure~~

- ~~a) The SS transmits an RLC SDU of size 10 bytes.~~
- ~~b) The SS checks the length indicator sizes and values of the RLC PDU returned on the uplink.~~
- ~~c) The SS releases the RB, and performs the Radio Bearer establishment procedure (clause 7.1.3 of TS 34.108) with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 15-bit length indicator tests in clause 7.2.2.1.~~

~~All other settings the same.~~

- ~~d) The SS transmits an RLC SDU of size 10 bytes.~~
- ~~e) The SS checks the length indicator sizes and values of the RLC PDU returned on the uplink.~~
- ~~f) The SS may optionally release the radio bearer.~~

## Expected sequence

| Step | Direction |    | Message          | Comments                                                                       |
|------|-----------|----|------------------|--------------------------------------------------------------------------------|
|      | UE        | SS |                  |                                                                                |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures for UM 7-bit LIs<br>10-byte SDU + padding               |
| 2    | ←         |    | DOWNLINK RLC PDU |                                                                                |
| 3    | →         |    | UPLINK RLC PDU   |                                                                                |
| 4    | ←         |    | RB RELEASE       | See generic procedures for UM 15-bit LIs<br>(largest UMD-PDU size > 125 bytes) |
| 5    |           |    | RB ESTABLISHMENT |                                                                                |
| 6    | ←         |    | DOWNLINK RLC PDU |                                                                                |
| 7    | →         |    | UPLINK RLC PDU   |                                                                                |
| 8    |           |    | RB RELEASE       | Optional step                                                                  |

## 7.2.2.2.5 Test requirements

1. The UE shall send 7-bit length indicators with values that correctly indicate the end of the SDU received in step 3.
2. The UE shall send 15-bit length indicators with values that correctly indicate the end of the SDU received in step 7.

## 7.2.2.3 Segmentation and reassembly / 7-bit Length Indicators / Padding

## 7.2.2.3.1 Definition

The RLC segments and concatenates SDUs into payload units according to the payload unit size requested by MAC. Length indicators are added to allow correct reconstruction of SDUs. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

## 7.2.2.3.2 Conformance requirement

A PDU that has unused space, to be referred to as padding, shall use a Length Indicator to indicate that this space is used as padding unless the padding size is one octet for PDUs with 15-bit LIs. A padding Length Indicator must be placed after any Length Indicators for a PDU.

One length indicator field shall be included for each end of a SDU that the PDU includes. The LI shall be set equal to the number of octets between the end of the header fields and the end of the segment. If padding is needed, another LI field set to only 1's shall be added unless the padding size is one octet for PDUs with 15-bit LIs.

## Reference(s)

TS 25.322 clauses 9.2.2.8 and 11.2.2.1.

## 7.2.2.3.3 Test purpose

1. To test that the UE correctly segments a large SDU and padding is added at the end.
2. To test that the UE correctly deals with a 7-bit padding LI when present in a received PDU.

## 7.2.2.3.4 Method of test

## Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 7-bit length indicator tests in clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into UE test loop mode 1 with the UL SDU size set to UM\_7\_PayloadSize + 1 bytes.

### Test procedure

- a) The SS transmits an RLC SDU of size UM\_7\_PayloadSize + 1 bytes. The second of the 2 PDUs sent shall contain an LI indicating that padding is present.
- b) The SS checks the length indicator sizes and values of the RLC PDU returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

### Expected sequence

| Step | Direction |    | Message          | Comments                       |
|------|-----------|----|------------------|--------------------------------|
|      | UE        | SS |                  |                                |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures         |
| 2    |           | ←  | DOWNLINK RLC PDU | SDU 1                          |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU 1 & Padding                |
| 4    |           | →  | UPLINK RLC PDU   | No LI                          |
| 5    |           | →  | UPLINK RLC PDU   | Check LIs and re-assembled SDU |
| 6    |           |    | RB RELEASE       | Optional step                  |

### 7.2.2.3.5 Test requirements

1. The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the PDU contains an SDU boundary after octet 1 of the data field, and the second shall indicate that the remainder of the PDU contains padding.
2. The length and data content of the received SDU should be the same as the transmitted SDU.

### 7.2.2.4 Segmentation and Reassembly / 7-bit Length Indicators / LI = 0

#### 7.2.2.4.1 Definition

The RLC segments and concatenates SDUs into payload units according to the payload unit size requested by MAC. A pre-defined length indicator value is used to indicate when an SDUs ends coincident with the end of the previous PDU. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

#### 7.2.2.4.2 Conformance requirement

If the PDU is exactly filled with the last segment of a SDU and there is no room for an LI field, an LI field set to only 0's shall be included as the first length indicator in the following PDU.

### Reference(s)

TS 25.322 clause 11.2.2.1

#### 7.2.2.4.3 Test purpose

1. To test that where an SDU exactly fills a PDU, an LI of value zero is placed by the transmitter as the first LI in the next PDU.
2. To test that where an SDU exactly fills a PDU, the receiver accepts an LI of value of zero, placed as the first LI in the next PDU.

#### 7.2.2.4.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 7-bit length indicator tests in clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to UM\_7\_PayloadSize bytes.

##### Test procedure

- a) The SS transmits an RLC SDU of size  $2 * \text{UM\_7\_PayloadSize}$  bytes.
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

##### Expected sequence

| Step | Direction |    | Message          | Comments                       |
|------|-----------|----|------------------|--------------------------------|
|      | UE        | SS |                  |                                |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures         |
| 2    |           | ←  | DOWNLINK RLC PDU | SDU 1                          |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU 1                          |
| 4    |           | ←  | DOWNLINK RLC PDU | LI=0 and padding               |
| 5    |           | →  | UPLINK RLC PDU   | No Lis                         |
| 6    |           | →  | UPLINK RLC PDU   | Check Lis and re-assembled SDU |
| 7    |           |    | RB RELEASE       | Optional step                  |

#### 7.2.2.4.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have an LI indicating that the SDU exactly filled the previous PU, and an LI indicating that the remainder of the PDU contains padding.

The length of the received SDU should be UM\_7\_PayloadSize bytes, and the data content the same as the first UM\_7\_PayloadSize bytes of the transmitted SDU.

#### 7.2.2.5 Reassembly / 7-bit Length Indicators / Invalid LI value

##### 7.2.2.5.1 Definition

The RLC segments and concatenates SDUs into payload units according to the payload unit size requested by MAC. Length indicators are added to allow correct reconstruction of SDUs. The behaviour of the RLC on reception of an invalid LI value has been specified. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

##### 7.2.2.5.2 Conformance requirement

Upon reception of an UMD PDU that contains Length Indicator value 1111110 ("piggybacked STATUS PDU") the receiver shall discard that UMD PDU.

##### Reference(s)

TS 25.322 clause 11.2.4.1.

### 7.2.2.5.3 Test purpose

To test that PDUs with invalid length indicators are discarded by the receiving RLC.

### 7.2.2.5.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 7-bit length indicator tests in clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to UM\_7\_PayloadSize + 1 bytes.

#### Test procedure

- a) The SS transmits two RLC SDUs of size UM\_7\_PayloadSize + 1 bytes. In the third PDU for transmission, the SS sets the value of the second (padding) LI to 1111110.
- b) The SS checks the length indicator sizes and values of any RLC PDUs returned on the uplink, and checks for the presence of any received RLC SDUs.
- c) The SS may optionally release the radio bearer.

#### Expected sequence

| Step | Direction |    | Message          | Comments                              |
|------|-----------|----|------------------|---------------------------------------|
|      | UE        | SS |                  |                                       |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures                |
| 2    |           | ←  | DOWNLINK RLC PDU | SDU 1                                 |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU 1 & SDU 2                         |
| 4    |           | ←  | DOWNLINK RLC PDU | SDU 2 and invalid LI (=11111110)      |
| 5    |           | →  | UPLINK RLC PDU   | SDU 1                                 |
| 6    |           | →  | UPLINK RLC PDU   | SDU 1: Check Lis and re-assembled SDU |
| 7    |           |    | RB RELEASE       | Optional step                         |

### 7.2.2.5.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the end of the SDU, and a padding LI.

The length and data content of the received SDU should be the same as the first transmitted SDU. The second SDU should not be returned.

### 7.2.2.6 Reassembly / 7-bit Length Indicators / LI value > PDU size

#### 7.2.2.6.1 Definition

The RLC segments and concatenates SDUs into payload units according to the payload unit size requested by MAC. Length indicators are added to allow correct reconstruction of SDUs. The behaviour of the RLC on reception of an invalid LI value has been specified. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

#### 7.2.2.6.2 Conformance requirement

If the length indicator of a PDU has a value that is larger than the PDU size—the number of octets containing LIs in the PDU—1 and is not one of the predefined values listed in the table of 3GPP TS 25.322 clause 9.2.2.8, the PDU shall be discarded and treated as a missing PDU.

If a PDU with sequence number < VR(US) is missing then all SDUs that have segments in this PDU shall be discarded.

#### Reference(s)

TS 25.322 clauses 11.2.4.2 and 11.2.3.

#### 7.2.2.6.3 ————— Test purpose

To test that PDUs with length indicators that point beyond the end of the PDU are discarded by the receiving RLC.

#### 7.2.2.6.4 ————— Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 7-bit length indicator tests in clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to UM\_7\_PayloadSize + 1 bytes.

#### Test procedure

- a) The SS transmits three RLC SDUs of size UM 7 PayloadSize + 1 bytes. All the SDUs are concatenated or segmented over successive RLC PDUs. In the third PDU for transmission, the SS sets value of the length indicator to be UM 7 PayloadSize + 1 (decimal).
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDUs.
- c) The SS may optionally release the radio bearer.

#### Expected sequence

| Step | Direction |    | Message          | Comments                                          |
|------|-----------|----|------------------|---------------------------------------------------|
|      | UE        | SS |                  |                                                   |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures                            |
| 2    | ←         |    | DOWNLINK RLC PDU | SDU 1                                             |
| 3    | ←         |    | DOWNLINK RLC PDU | SDU 1 & SDU 2                                     |
| 4    | ←         |    | DOWNLINK RLC PDU | SDU 2 & SDU 3, with bad LI                        |
| 5    | ←         |    | DOWNLINK RLC PDU | SDU 3 and padding                                 |
| 6    | →         |    | UPLINK RLC PDU   | SDU 1                                             |
| 7    | →         |    | UPLINK RLC PDU   | SDU 1 and padding: Check Lis and re-assembled SDU |
| 8    |           |    | RB RELEASE       | Optional step                                     |

#### 7.2.2.6.5 ————— Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the end of an SDU and an LI indicating that the remainder of the PDU contains padding.

The length and data content of the received SDU should be the same as the first transmitted SDU. No further SDUs or PDUs should be received.

#### 7.2.2.7 ————— Reassembly / 7-bit Length Indicators / First data octet LI

##### 7.2.2.7.1 ————— Definition

The RLC segments and concatenates SDUs into payload units according to the payload unit size requested by MAC. Length indicators are added to allow correct reconstruction of SDUs. A special LI is defined to indicate that the start of

on SDU is coincident with the start of the PDU. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

#### 7.2.2.7.2 ~~Conformance requirement~~

LI = 1111100, UMD PDU: The first data octet in this RLC PDU is the first octet of a RLC SDU.

#### Reference(s)

TS 25.322 clause 9.2.2.8.

#### 7.2.2.7.3 ~~Test purpose~~

To test that a UE in unacknowledged mode correctly handles a received RLC PDU with a 7-bit length indicator having its value equal to the special length indicator value 1111100.

#### 7.2.2.7.4 ~~Method of test~~

#### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 7-bit length indicator tests in clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into UE test loop mode 1 with the UL SDU size set to 12 bytes.

#### Test procedure

- a) The SS transmits a RLC SDU of size 12 bytes in a PDU which has the 'First Data Octet LI' as the first LI in the PDU.
- b) The SS waits until the SDU has been received back from the UE, and then transmits another SDU of 12 bytes in a PDU which has the 'First Data Octet LI' as the first LI in the PDU.
- c) The SS waits until this SDU has been received back from the UE.
- e) The SS may optionally release the radio bearer.

#### Expected sequence

| Step | Direction |    | Message          | Comments                                                                                                                             |
|------|-----------|----|------------------|--------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                  |                                                                                                                                      |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures<br>SDU 1 with LI = 1111100<br>Wait for loopback<br>SDU 1<br>SDU 2 with LI = 1111100<br>SDU 2<br>Optional step |
| 2    |           | ←  | DOWNLINK RLC PDU |                                                                                                                                      |
| 3    |           |    | ...              |                                                                                                                                      |
| 4    |           | →  | UPLINK RLC PDU   |                                                                                                                                      |
| 5    |           | ←  | DOWNLINK RLC PDU |                                                                                                                                      |
| 6    |           | →  | UPLINK RLC PDU   |                                                                                                                                      |
| 7    |           |    | RB RELEASE       |                                                                                                                                      |

#### 7.2.2.7.5 ~~Test requirements~~

1. The UE shall return two RLC PDUs.
2. The length and data content of each received SDU should be the same as the transmitted SDU.



## 7.2.2.8 Segmentation and reassembly / 15-bit Length Indicators / Padding

### 7.2.2.8.1 Definition

The RLC segments and concatenates SDUs into payload units according to the payload unit size requested by MAC. Length indicators are added to allow correct reconstruction of SDUs. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

### 7.2.2.8.2 Conformance requirement

A PDU that has unused space, to be referred to as padding, shall use a Length Indicator to indicate that this space is used as padding unless the padding size is one octet for PDUs with 15-bit LIs. A padding Length Indicator must be placed after any Length Indicators for a PU.

One length indicator field shall be included for each end of a SDU that the PDU includes. The LI shall be set equal to the number of octets between the end of the header fields and the end of the segment. If padding is needed, another LI field set to only 1's shall be added unless the padding size is one octet for PDUs with 15-bit LIs.

### Reference(s)

TS 25.322 clauses 9.2.2.8 and 11.2.2.1.

### 7.2.2.8.3 Test purpose

1. To test that the UE correctly segments a large SDU and padding is added at the end.
2. To test that the UE correctly deals with a 15-bit padding LI when present in a received PDU.

### 7.2.2.8.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 15-bit length indicator tests in clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into UE test loop mode 1 with the UL SDU size set to UM\_15\_PayloadSize + 1 bytes.

#### Test procedure

- a) The SS transmits an RLC SDU of size UM\_15\_PayloadSize + 1 bytes. The second of the 2 PDUs sent shall contain an LI indicating that padding is present.
- b) The SS checks the length indicator sizes and values of the RLC PDU returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

#### Expected sequence

| Step | Direction |    | Message          | Comments                       |
|------|-----------|----|------------------|--------------------------------|
|      | UE        | SS |                  |                                |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures         |
| 2    | ←         |    | DOWNLINK RLC PDU | SDU 1                          |
| 3    | ←         |    | DOWNLINK RLC PDU | SDU 1 & Padding                |
| 4    | →         |    | UPLINK RLC PDU   | No LI                          |
| 5    | →         |    | UPLINK RLC PDU   | Check LIs and re-assembled SDU |
| 6    |           |    | RB RELEASE       | Optional step                  |

#### ~~7.2.2.8.5 Test requirements~~

- ~~1. The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the PDU contains an SDU boundary after octet 1 of the data field, and the second shall indicate that the remainder of the PDU contains padding.~~
- ~~2. The length and data content of the received SDU should be the same as the transmitted SDU.~~

#### ~~7.2.2.9 Segmentation and Reassembly / 15-bit Length Indicators / LI = 0~~

##### ~~7.2.2.9.1 Definition~~

~~The RLC segments and concatenates SDUs into payload units according to the payload unit size requested by MAC. A pre-defined length indicator value is used to indicate when an SDUs ends coincident with the end of the previous PU. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.~~

##### ~~7.2.2.9.2 Conformance requirement~~

~~If the PDU is exactly filled with the last segment of a SDU and there is no room for an LI field, an LI field set to only 0's shall be included as the first length indicator in the following PDU.~~

##### ~~Reference(s)~~

~~TS 25.322 clause 11.2.2.1.~~

##### ~~7.2.2.9.3 Test purpose~~

- ~~1. To test that where an SDU exactly fills a PDU, an LI of value zero is placed by the transmitter as the first LI in the next PDU.~~
- ~~2. To test that where an SDU exactly fills a PDU, and an LI of value zero is the first LI in the next PDU, the receiver correctly reassembles the PDU.~~

##### ~~7.2.2.9.4 Method of test~~

##### ~~Initial conditions~~

~~The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 15-bit length indicator tests in clause 7.2.2.1.~~

~~These settings apply to both the uplink and downlink DTCH.~~

~~The radio bearer is placed into loop-back mode 1 with the UL SDU size set to UM\_15\_PayloadSize bytes.~~

##### ~~Test procedure~~

- ~~a) The SS transmits an RLC SDU of size 2 \* UM\_15\_PayloadSize bytes.~~
- ~~b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDU.~~
- ~~c) The SS may optionally release the radio bearer.~~

## Expected sequence

| Step | Direction |    | Message          | Comments                       |
|------|-----------|----|------------------|--------------------------------|
|      | UE        | SS |                  |                                |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures         |
| 2    |           | ←  | DOWNLINK RLC PDU | SDU 1                          |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU 1                          |
| 4    |           | ←  | DOWNLINK RLC PDU | LI=0 and padding               |
| 5    |           | →  | UPLINK RLC PDU   | No Lis                         |
| 6    |           | →  | UPLINK RLC PDU   | Check Lis and re-assembled SDU |
| 7    |           |    | RB RELEASE       | Optional step                  |

## 7.2.2.9.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have an LI indicating that the SDU exactly filled the previous PU, and an LI indicating that the remainder of the PDU contains padding.

The length of the received SDU should be UM\_15\_PayloadSize bytes, and the data content the same as the first UM\_15\_PayloadSize bytes of the transmitted SDU.

## 7.2.2.10 Segmentation and reassembly / 15-bit Length Indicators / One octet short LI

## 7.2.2.10.1 Definition

The RLC segments and concatenates SDUs into payload units according to the payload unit size requested by MAC. A pre-defined length indicator value is used to indicate when an SDUs ends one octet short of the end of the previous PDU. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

## 7.2.2.10.2 Conformance requirement

In the case where the last segment of an RLC SDU is one octet short of exactly filling the last RLC PDU, and 15-bit Length Indicators are used, the next Length Indicator shall be placed as the first Length Indicator in the next PDU and have value LI=111 1111 1111 1011.

In the case where a PDU contains a 15-bit LI indicating that an SDU ends with one octet left in the PDU, the last octet of this PDU shall be ignored and shall not be filled with the first octet of the next SDU data.

## Reference(s)

TS 25.322 clause 9.2.2.8.

## 7.2.2.10.3 Test purpose

1. To test that where the UE transmits an SDU, which is one byte short of filling a PDU, an LI indicating one byte short is placed as the first LI in the next PDU.
2. To test that where the UE correctly handles a received PDU containing an LI indicating that an SDU ended one byte short of the end of the previous PDU.

## 7.2.2.10.4 Method of test

## Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM-15-bit length indicator tests in clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into UE test loop mode 1 with the UL SDU size set to UM\_15\_PayloadSize – 1 bytes.

**Test procedure**

- a) The SS transmits an RLC SDU of size  $(2 * \text{UM\_15\_PayloadSize}) - 1$  bytes.
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

**Expected sequence**

| Step | Direction |    | Message          | Comments                          |
|------|-----------|----|------------------|-----------------------------------|
|      | UE        | SS |                  |                                   |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures            |
| 2    |           | ←  | DOWNLINK RLC PDU | SDU 1                             |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU 1                             |
| 4    |           | ←  | DOWNLINK RLC PDU | LI=111 1111 1111 1011 and padding |
| 5    |           | →  | UPLINK RLC PDU   | No LIs                            |
| 6    |           | →  | UPLINK RLC PDU   | Check LIs and re-assembled SDU    |
| 7    |           |    | RB RELEASE       | Optional step                     |

**7.2.2.10.5 Test requirements**

- 1. The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have 2 LIs. The first LI shall be an LI indicating that the SDU was one byte short of filling the previous PDU, and the second an LI indicating that the remainder of the PDU contains padding.
- 2. The length of the received SDU should be  $\text{UM\_15\_PayloadSize} - 1$  bytes, and the data content the same as the first  $\text{UM\_15\_PayloadSize} - 1$  bytes of the transmitted SDU.

**7.2.2.11 Reassembly / 15-bit Length Indicators / Invalid LI value****7.2.2.11.1 Definition**

The RLC segments and concatenates SDUs into payload units according to the payload unit size requested by MAC. Length indicators are added to allow correct reconstruction of SDUs. The behaviour of the RLC on reception of an invalid LI value has been specified. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

**7.2.2.11.2 Conformance requirement**

Upon reception of an UMD PDU that contains Length Indicator value 11111111111110 ("piggybacked STATUS PDU") the receiver shall discard that UMD PDU.

**Reference(s)**

TS 25.322 clause 11.2.4.1.

**7.2.2.11.3 Test purpose**

To test that PDUs with invalid length indicators are discarded by the receiving RLC.

**7.2.2.11.4 Method of test****Initial conditions**

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 15-bit length indicator tests in clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio-bearer is placed into loop-back mode 1 with the UL SDU-size set to UM\_15\_PayloadSize + 1 bytes.

#### Test procedure

- a) The SS transmits two RLC SDUs of size UM\_15\_PayloadSize + 1 bytes. In the third PDU for transmission, the SS sets the value of the second (padding) LI to 11111111111110.
- b) The SS checks the length indicator sizes and values of any RLC PDUs returned on the uplink, and checks for the presence of any received RLC SDUs.
- c) The SS may optionally release the radio-bearer.

#### Expected sequence

| Step | Direction |    | Message          | Comments                               |
|------|-----------|----|------------------|----------------------------------------|
|      | UE        | SS |                  |                                        |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures                 |
| 2    |           | ←  | DOWNLINK RLC PDU | SDU 1                                  |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU 1 & SDU 2                          |
| 4    |           | ←  | DOWNLINK RLC PDU | SDU 2 and invalid LI (=11111111111110) |
| 5    |           | →  | UPLINK RLC PDU   | SDU 1                                  |
| 6    |           | →  | UPLINK RLC PDU   | SDU 1: Check Lis and re-assembled-SDU  |
| 7    |           |    | RB RELEASE       | Optional step                          |

#### 7.2.2.11.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the end of the SDU, and a padding LI.

The length and data content of the received SDU should be the same as the first transmitted SDU. The second SDU should not be returned.

#### 7.2.2.12 Reassembly / 15-bit Length Indicators / LI value > PDU size

##### 7.2.2.12.1 Definition

The RLC segments and concatenates SDUs into payload units according to the payload unit size requested by MAC. Length indicators are added to allow correct reconstruction of SDUs. The behaviour of the RLC on reception of an invalid LI value has been specified. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

##### 7.2.2.12.2 Conformance requirement

If the length indicator of a PDU has a value that is larger than the PDU size—the number of octets containing LIs in the PDU—1 and is not one of the predefined values listed in the table of 3GPP TS 25.322 clause 9.2.2.8, the PDU shall be discarded and treated as a missing PDU.

If a PDU with sequence number < VR(US) is missing then all SDUs that have segments in this PDU shall be discarded.

#### Reference(s)

TS 25.322 clauses 11.2.4.2 and 11.2.3.

##### 7.2.2.12.3 Test purpose

To test that PDUs with length indicators that point beyond the end of the PDU are discarded by the receiving RLC.

#### 7.2.2.12.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 15-bit length indicator tests in clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into loop-back mode 1 with the UL SDU size set to UM\_15\_PayloadSize + 1 bytes.

##### Test procedure

- a) The SS transmits three RLC SDUs of size UM\_15\_PayloadSize + 1 bytes. All the SDUs are concatenated or segmented over successive RLC PDUs. In the third PDU for transmission, the SS sets value of the length indicator to be UM\_15\_PayloadSize + 1 (decimal).
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDUs.
- c) The SS may optionally release the radio bearer.

##### Expected sequence

| Step | Direction |    | Message          | Comments                                          |
|------|-----------|----|------------------|---------------------------------------------------|
|      | UE        | SS |                  |                                                   |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures                            |
| 2    |           | ←  | DOWNLINK RLC PDU | SDU 1                                             |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU 1 & SDU 2                                     |
| 4    |           | ←  | DOWNLINK RLC PDU | SDU 2 & SDU 3, with bad LI                        |
| 5    |           | ←  | DOWNLINK RLC PDU | SDU 3 and padding                                 |
| 6    |           | →  | UPLINK RLC PDU   | SDU 1                                             |
| 7    |           | →  | UPLINK RLC PDU   | SDU 1 and padding: Check Lis and re-assembled SDU |
| 8    |           |    | RB RELEASE       | Optional step                                     |

#### 7.2.2.12.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the end of an SDU and an LI indicating that the remainder of the PDU contains padding.

The length and data content of the received SDU should be the same as the first transmitted SDU. No further SDUs or PDUs should be received.

#### 7.2.2.13 Reassembly / 15-bit Length Indicators / First data octet LI

##### 7.2.2.13.1 Definition

The RLC segments and concatenates SDUs into payload units according to the payload unit size requested by MAC. Length indicators are added to allow correct reconstruction of SDUs. A special LI is defined to indicate that the start of an SDU is coincident with the start of the PDU. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

##### 7.2.2.13.2 Conformance requirement

LI = 111111111111100, UMD PDU: The first data octet in this RLC PDU is the first octet of a RLC SDU.

##### Reference(s)

TS 25.322 clause 9.2.2.8.

### 7.2.2.13.3 Test purpose

To test that a UE in unacknowledged mode correctly handles a received RLC PDU with a 15-bit length indicator having its value equal to the special length indicator value 11111111111100.

### 7.2.2.13.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for UM 15-bit length indicator tests in clause 7.2.2.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into UE test loop mode 1 with the UL SDU size set to 150 bytes.

#### Test procedure

- a) The SS transmits a RLC SDU of size 150 bytes in a PDU which has the 'First Data Octet LI' as the first LI in the PDU.
- b) The SS waits until the SDU has been received back from the UE, and then transmits another SDU of 150 bytes in a PDU which has the 'First Data Octet LI' as the first LI in the PDU.
- c) The SS waits until this SDU has been received back from the UE.
- c) The SS may optionally release the radio bearer.

#### Expected sequence

| Step | Direction |    | Message          | Comments                       |
|------|-----------|----|------------------|--------------------------------|
|      | UE        | SS |                  |                                |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures         |
| 2    | ←         |    | DOWNLINK RLC PDU | SDU 1 with LI = 11111111111100 |
| 3    |           |    | ...              | Wait for loopback              |
| 4    | →         |    | UPLINK RLC PDU   | SDU 1                          |
| 5    | ←         |    | DOWNLINK RLC PDU | SDU 2 with LI = 11111111111100 |
| 6    | →         |    | UPLINK RLC PDU   | SDU 2                          |
| 7    |           |    | RB RELEASE       | Optional step                  |

### 7.2.2.13.5 Test requirements

1. The UE shall return two RLC PDUs.
2. The length and data content of each received SDU should be the same as the transmitted SDU.

## 7.2.3 Acknowledged mode

### 7.2.3.1 General information for AM tests

Two generic Radio Access Bearers are provided for AM tests.

The AM test RAB is set up using the Generic Procedure described in clause 7.1.3 of TS 34.108, and with the default RAB replaced as follows:

- For AM 7-bit length indicator tests: the RB configuration described in 3G TS 34.108 clause 6.11.3 is used. For these tests, let AM\_7\_PayloadSize denote the RAB payload size in octets.
- For AM 15-bit length indicator tests: the RB configuration described in 3G TS 34.108 clause 6.11.4 is used. For these tests, let AM\_15\_PayloadSize denote the RAB payload size in octets.

Unless specified in individual test cases, the default RLC settings are given in table 7.2/1.

**Table 7.2/1: RLC Parameters for AM testing**

|                               |          |
|-------------------------------|----------|
| Uplink RLC                    |          |
| —Transmission RLC discard     |          |
| —Max DAT retransmissions      |          |
| —Max_DAT                      | 4        |
| —Transmission window size     | 128      |
| —Timer_RST                    | 500      |
| —Max_RST                      | 4        |
| —Polling info                 |          |
| —Timer_poll_prohibit          | disabled |
| —Timer_poll                   | disabled |
| —Poll_PU                      | disabled |
| —Poll_SDU                     | disabled |
| —Last transmission PDU poll   | TRUE     |
| —Last retransmission PDU poll | TRUE     |
| —Poll_Window                  | disabled |
| —Timer_poll_periodic          | disabled |
| Downlink RLC                  |          |
| —In-sequence delivery         | TRUE     |
| —Receiving window size        | 128      |
| —Timer_Status_Prohibit        | disabled |
| —Timer_EPC                    | disabled |
| —Missing PDU Indicator        | TRUE     |
| —Timer_STATUS_periodic        | disabled |

The AM test RABs are used in all tests with the following exception:

- Tests that explicitly specify a different Radio Bearer configuration.

All other settings are the same.

### 7.2.3.2 Segmentation and reassembly / Selection of 7 or 15 bit Length Indicators

#### 7.2.3.2.1 Definition

The RLC segments and concatenates SDUs into payload units according to the payload unit size configured by RRC. Length indicators are added to allow correct reconstruction of SDUs. The selection of the size of the length indicator fields used must follow the specified rules. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

#### 7.2.3.2.2 Conformance requirement

The size of the Length Indicator may be either 7 bits or 15 bits.

For AM, 7bit indicators shall be used if the AMD PDU size is  $\leq 126$  octets. Otherwise 15bit indicators shall be used.

The length of the Length Indicator only depends on the size of the largest RLC PDU. The length of the Length Indicator is always the same for all PUs, for one RLC entity.

#### Reference(s)

TS 25.322 clauses 9.2.2.8 and 9.2.2.9.

#### 7.2.3.2.3 Test purpose

To test that if PDU carries a single PDU, and the size of the largest PDU is  $\leq 126$  octets, 7 bit indicators are used, otherwise, 15-bit indicators are used.



#### 7.2.3.2.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into UE test loop mode 1 with the UL SDU size set to 10 bytes.

##### Test procedure

- a) The SS transmits an RLC SDU of size 10 bytes. The PDU carrying this SDU is transmitted with a poll for status.
- b) The SS checks the length indicator sizes and values of the RLC PDU returned on the uplink.
- c) The SS releases the RB, and performs the Radio Bearer establishment procedure (clause 7.1.3 of TS 34.108) with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 15-bit length indicator tests in clause 7.2.3.1.

All other settings the same.

- d) The SS transmits an RLC SDUs of size 10 bytes. The PDU carrying this SDU is transmitted with a poll for status.
- e) The SS checks the length indicator sizes and values of the RLC PDU returned on the uplink.
- f) The SS may optionally release the radio bearer.

##### Expected sequence

| Step | Direction |    | Message          | Comments                                                                                              |
|------|-----------|----|------------------|-------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                  |                                                                                                       |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures for AM 7 bit LIs<br>10 byte SDU + padding + poll                               |
| 2    | ←         |    | DOWNLINK RLC PDU |                                                                                                       |
| 3    | →         |    | UPLINK RLC PDU   |                                                                                                       |
| 3a   | →         |    | STATUS PDU       | 10 byte SDU + piggy-backed status + poll<br>If piggy-backed status is not used in 3                   |
| 4    | ←         |    | STATUS PDU       |                                                                                                       |
| 5    | ←         |    | RB RELEASE       |                                                                                                       |
| 6    |           |    | RB ESTABLISHMENT | See generic procedures for AM 7 bit LIs<br>(AMD PDU size > 126 bytes)<br>10 byte SDU + padding + poll |
| 7    | ←         |    | DOWNLINK RLC PDU |                                                                                                       |
| 8    | →         |    | UPLINK RLC PDU   |                                                                                                       |
| 8a   | →         |    | STATUS PDU       | 10 byte SDU + piggy-backed status + poll<br>If piggy-backed status is not used in 7                   |
| 9    | ←         |    | STATUS PDU       |                                                                                                       |
| 10   |           |    | RB RELEASE       |                                                                                                       |

#### 7.2.3.2.5 Test requirements

The UE shall send 7 bit length indicators with values that correctly indicate the end of SDU in step b).

The UE shall send 15 bit length indicators with values that correctly indicate the end of SDU in step c).

#### 7.2.3.3 Segmentation and Reassembly / 7-bit Length Indicators / Padding or Piggy-backed Status

##### 7.2.3.3.1 Definition

The RLC segments and concatenates SDUs into payload units according to the payload unit size configured by RRC. Length indicators are added to allow correct reconstruction of SDUs. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

#### 7.2.3.3.2 Conformance requirement

The Length Indicator is used to indicate, each time, the end of an SDU occurs in the PU. The Length Indicator points out the number of octets between the end of the last Length Indicator field and up to and including the octet at the end of an SDU segment.

A PDU that has unused space, to be referred to as padding, shall use a Length Indicator to indicate that this space is used as padding unless the padding size is one octet for PDUs with 15-bit LIs. A padding Length Indicator must be placed after any Length Indicators for a PDU.

Upon reception of a SDU, RLC shall segment the SDU to fit into the fixed size of a PU. The segments are inserted in the data field of a PU. A length indicator shall be added to each PDU that includes a border of an SDU, i.e. if a PDU does not contain an LI, the SDU continues in the next PU. The length indicator indicates where the border occurs in the PU. The data after the indicated border can be either a new SDU, padding or piggybacked information. If padding or piggybacking is added another LI shall be added unless the padding size is one octet for PDUs with 15-bit LIs, see clauses 9.2.2.8 and 9.2.2.9.

#### Reference(s)

TS 25.322 clauses 9.2.2.8 and 11.3.2.1.2.

#### 7.2.3.3.3 Test purpose

1. To test that a large SDU is correctly segmented and padding added at the end.
2. To test that a large SDU is received correctly, whether or not it has piggy-backed status at the end.

#### 7.2.3.3.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into UE test loop mode 1 with the UL SDU size set to  $AM\_7\_PayloadSize + 1$  bytes.

##### Test procedure

- a) The SS transmits an RLC SDU (SDU1) of size  $AM\_7\_PayloadSize + 1$  bytes, and polls the receiver for status.
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS transmits another RLC SDU (SDU2) of size  $AM\_7\_PayloadSize + 1$  bytes, and includes piggy-backed status in the second of the 2 PDUs sent. The SS also polls the receiver for status.
- d) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDU.
- e) The SS may optionally release the radio bearer.

## Expected sequence

| Step | Direction |    | Message          | Comments                                |
|------|-----------|----|------------------|-----------------------------------------|
|      | UE        | SS |                  |                                         |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures                  |
| 2    |           | ←  | DOWNLINK RLC PDU | SDU 1                                   |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU 1 + poll + Padding                  |
| 4    |           | →  | UPLINK RLC PDU   | No LI                                   |
| 5    |           | →  | UPLINK RLC PDU   | Poll, Check LIs and re-assembled SDU    |
| 5a   |           | →  | STATUS PDU       | If piggy-backed status is not used in 5 |
| 6    |           | ←  | DOWNLINK RLC PDU | SDU 2                                   |
| 7    |           | ←  | DOWNLINK RLC PDU | SDU 2 + poll + piggy-backed status      |
| 8    |           | →  | UPLINK RLC PDU   | No LI                                   |
| 9    |           | →  | UPLINK RLC PDU   | Poll, Check LIs and re-assembled SDU    |
| 9a   |           | →  | STATUS PDU       | If piggy-backed status is not used in 9 |
| 10   |           | ←  | STATUS PDU       |                                         |
| 11   |           |    | RB RELEASE       | Optional step                           |

## 7.2.3.3.5 Test requirements

1. In steps 4 and 5, the UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the PDU contains an SDU boundary after octet 1 of the data field, and the second shall indicate either that the remainder of the PDU contains padding, or that it contains a piggy-backed status PDU.
2. In steps 8 and 9, the UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the PDU contains an SDU boundary after octet 1 of the data field, and the second shall indicate either that the remainder of the PDU contains padding, or that it contains a piggy-backed status PDU.
3. The length and data content of all received SDUs shall be the same as the transmitted SDUs.

## 7.2.3.4 Segmentation and Reassembly / 7-bit Length Indicators / LI = 0

## 7.2.3.4.1 Definition

The RLC segments and concatenates SDUs into payload units according to the payload unit size configured by RRC. A pre-defined length indicator value is used to indicate when an SDUs ends coincident with the end of the previous PU. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

## 7.2.3.4.2 Conformance requirement

If the PDU is exactly filled with the last segment of a SDU and there is no room for an LI field, an LI field set to only 0's shall be included as the first length indicator in the following PDU.

## Reference(s)

TS 25.322 clause 11.3.2.1.

## 7.2.3.4.3 Test purpose

1. To test that where an SDU exactly fills a PDU, an LI of value zero is placed by the transmitter as the first LI in the next PDU.
2. To test that where an SDU exactly fills a PDU, and an LI of value zero is the first LI in the next PDU, the receiver correctly reassembles the SDU.

#### 7.2.3.4.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into UE test loop mode 1 with the UL SDU size set to AM\_7\_PayloadSize bytes.

##### Test procedure

- a) The SS transmits an RLC SDU of size  $2 * AM\_7\_PayloadSize$  bytes. The SS polls the receiver for status in the last RLC PDU sent.
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

##### Expected sequence

| Step | Direction |    | Message          | Comments                                       |
|------|-----------|----|------------------|------------------------------------------------|
|      | UE        | SS |                  |                                                |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures                         |
| 2    |           | ←  | DOWNLINK RLC PDU | SDU 1                                          |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU 1                                          |
| 4    |           | ←  | DOWNLINK RLC PDU | LI=0, poll and padding                         |
| 5    |           | →  | UPLINK RLC PDU   | No Lis                                         |
| 6    |           | →  | UPLINK RLC PDU   | (Poll) Check Lis and re-assembled SDU          |
| 6a   |           | →  | STATUS PDU       | <i>If piggy-backed status is not used in 6</i> |
| 7    |           | ←  | STATUS PDU       |                                                |
| 8    |           |    | RB RELEASE       | Optional step                                  |

#### 7.2.3.4.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have an LI indicating that the SDU exactly filled the previous PU, and an LI indicating either that the remainder of the PDU contains padding, or that it contains a piggy-backed STATUS PDU.

The length of the received SDU should be AM\_7\_PayloadSize bytes, and the data content the same as the first AM\_7\_PayloadSize bytes of the transmitted SDU.

#### 7.2.3.5 Reassembly / 7-bit Length Indicators / Reserved LI value

##### 7.2.3.5.1 Definition

The RLC segments and concatenates SDUs into payload units according to the payload unit size configured by RRC. Length indicators are added to allow correct reconstruction of SDUs. The behaviour of the RLC on reception of a reserved LI value has been specified. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

##### 7.2.3.5.2 Conformance requirement

Upon reception of an AMD PDU that contains Length Indicator value "1111100" or "1111101": PDUs with this coding will be discarded by this version of the protocol.

Reference(s)

TS 25.322 clause 9.2.2.8.

7.2.3.5.3 ~~Test purpose~~

To test that PDUs with reserved length indicators are discarded by the receiving RLC.

7.2.3.5.4 ~~Method of test~~

Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                                         |       |
|-----------------------------------------|-------|
| Downlink RLC<br>— Missing PDU Indicator | FALSE |
|-----------------------------------------|-------|

These settings apply to both the uplink and downlink DTCH.

Test procedure

- a) The SS transmits three RLC SDUs of size AM\_7\_PayloadSize + 1 bytes. In the second PDU, the SS sets the value of the LI to 1111100. In the third PDU for transmission, the SS sets the value of the second (padding) LI to 1111101.
- b) The SS waits to receive a status report from the UE.
- c) The SS may optionally release the radio bearer.

Expected sequence

| Step | Direction |    | Message             | Comments                    |
|------|-----------|----|---------------------|-----------------------------|
|      | UE        | SS |                     |                             |
| 1    |           |    | RB ESTABLISHMENT    | See generic procedures      |
| 2    |           | ←  | DOWNLINK RLC PDU #0 | SDU 1                       |
| 3    |           | ←  | DOWNLINK RLC PDU #1 | SDU 1 + SDU 2, LI = 1111100 |
| 4    |           | ←  | DOWNLINK RLC PDU #2 | SDU 2 + SDU 3, LI = 1111101 |
| 5    |           | ←  | DOWNLINK RLC PDU #3 | SDU 3 + poll                |
| 6    |           | →  | STATUS PDU          | Nack PDUs 1 and 2           |
| 7    |           |    | RB RELEASE          | Optional step               |

7.2.3.5.5 ~~Test requirements~~

- 1. The UE shall return a STATUS PDU indicating that PDUs with sequence numbers 1 and 2 were incorrectly received.
- 2. No uplink SDUs shall be received.

7.2.3.6 ~~Reassembly / 7-bit Length Indicators / LI value > PDU size~~

7.2.3.6.1 ~~Definition~~

The RLC segments and concatenates SDUs into payload units according to the payload unit size configured by RRC. Length indicators are added to allow correct reconstruction of SDUs. The behaviour of the RLC on reception of an invalid LI value has been specified. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

7.2.3.6.2 Conformance requirement

If the length indicator of a PDU has a value that is larger than the PDU size—the number of octets containing LIs in the PDU—1 and is not one of the predefined values listed in the table of 3GPP TS 25.322 clause 9.2.2.8, the PDU shall be discarded and treated as a missing PDU.

Reference(s)

TS 25.322 clause 11.3.4.5.

7.2.3.6.3 Test purpose

To test that PDUs with length indicators that point beyond the end of the PDU are discarded by the receiving RLC.

7.2.3.6.4 Method of test

Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                                       |       |
|---------------------------------------|-------|
| Downlink RLC<br>Missing PDU Indicator | FALSE |
|---------------------------------------|-------|

These settings apply to both the uplink and downlink DTCH.

Test procedure

- a) The SS transmits three RLC SDUs of size AM\_7\_PayloadSize + 1 bytes. All the SDUs are concatenated or segmented over successive RLC PDUs. In the third PDU for transmission, the SS sets value of the length indicator to be AM\_7\_PayloadSize + 1 (decimal).
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the content of the received STATUS PDU.
- c) The SS may optionally release the radio bearer.

Expected sequence

| Step | Direction |    | Message             | Comments                   |
|------|-----------|----|---------------------|----------------------------|
|      | UE        | SS |                     |                            |
| 1    |           |    | RB ESTABLISHMENT    | See generic procedures     |
| 2    | ←         |    | DOWNLINK RLC PDU #0 | SDU 1                      |
| 3    | ←         |    | DOWNLINK RLC PDU #1 | SDU 1 & SDU 2              |
| 4    | ←         |    | DOWNLINK RLC PDU #2 | SDU 2 & SDU 3, with bad LI |
| 5    | ←         |    | DOWNLINK RLC PDU #3 | SDU 3, poll and padding    |
| 6    | →         |    | STATUS PDU          | Nack PDU #2                |
| 7    |           |    | RB RELEASE          | Optional step              |

7.2.3.6.5 Test requirements

The UE shall indicate that the PDU with sequence number 2 was not received.

### ~~7.2.3.7 Segmentation and Reassembly / 15-bit Length Indicators / Padding or Piggy-backed Status~~

#### ~~7.2.3.7.1 Definition~~

~~The RLC segments and concatenates SDUs into payload units according to the payload unit size configured by RRC. Length indicators are added to allow correct reconstruction of SDUs. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.~~

#### ~~7.2.3.7.2 Conformance requirement~~

~~The Length Indicator is used to indicate, each time, the end of an SDU occurs in the PU. The Length Indicator points out the number of octets between the end of the last Length Indicator field and up to and including the octet at the end of an SDU segment~~

~~A PDU that has unused space, to be referred to as padding, shall use a Length Indicator to indicate that this space is used as padding unless the padding size is one octet for PDUs with 15-bit LIs. A padding Length Indicator must be placed after any Length Indicators for a PDU.~~

~~Upon reception of a SDU, RLC shall segment the SDU to fit into the fixed size of a PDU. The segments are inserted in the data field of a PDU. A length indicator shall be added to each PDU that includes a border of an SDU, i.e. if a PDU does not contain an LI, the SDU continues in the next PU. The length indicator indicates where the border occurs in the PU. The data after the indicated border can be either a new SDU, padding or piggybacked information. If padding or piggybacking is added another LI shall be added unless the padding size is one octet for PDUs with 15-bit LIs, see clauses 9.2.2.8 and 9.2.2.9.~~

#### ~~Reference(s)~~

~~TS 25.322 clauses 9.2.2.8 and 11.3.2.1.2.~~

#### ~~7.2.3.7.3 Test purpose~~

- ~~1. To test that a large SDU is correctly segmented and padding added at the end.~~
- ~~2. To test that a large SDU is received correctly, whether or not it has piggy-backed status at the end.~~

#### ~~7.2.3.7.4 Method of test~~

##### ~~Initial conditions~~

~~The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 15-bit length indicator tests in clause 7.2.3.1.~~

~~These settings apply to both the uplink and downlink DTCH.~~

~~The radio bearer is placed into UE test loop mode 1 with the UL SDU size set to AM\_15\_PayloadSize + 1 bytes.~~

##### ~~Test procedure~~

- ~~a) The SS transmits an RLC SDU (SDU1) of size AM\_15\_PayloadSize + 1 bytes, and polls the receiver for status.~~
- ~~b) The SS checks the length indicator sizes and values of the RLC PDU returned on the uplink, and checks the length and content of the received RLC SDU.~~
- ~~c) The SS transmits another RLC SDU (SDU2) of size AM\_15\_PayloadSize + 1 bytes, and includes piggy-backed status in the second of the 2 PDUs sent. The SS also polls the receiver for status.~~
- ~~d) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDU.~~
- ~~e) The SS may optionally release the radio bearer.~~

## Expected sequence

| Step | Direction |    | Message          | Comments                                |
|------|-----------|----|------------------|-----------------------------------------|
|      | UE        | SS |                  |                                         |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures                  |
| 2    | ←         |    | DOWNLINK RLC PDU | SDU 1                                   |
| 3    | ←         |    | DOWNLINK RLC PDU | SDU 1 + poll + Padding                  |
| 4    | →         |    | UPLINK RLC PDU   | No LI                                   |
| 5    | →         |    | UPLINK RLC PDU   | Poll, Check LIs and re-assembled SDU    |
| 5a   | →         |    | STATUS PDU       | If piggy-backed status is not used in 5 |
| 6    | ←         |    | DOWNLINK RLC PDU | SDU 2                                   |
| 7    | ←         |    | DOWNLINK RLC PDU | SDU 2 + poll + piggy-backed status      |
| 8    | →         |    | UPLINK RLC PDU   | No LI                                   |
| 9    | →         |    | UPLINK RLC PDU   | Poll, Check LIs and re-assembled SDU    |
| 9a   | →         |    | STATUS PDU       | If piggy-backed status is not used in 9 |
| 10   | ←         |    | STATUS PDU       |                                         |
| 11   |           |    | RB RELEASE       | Optional step                           |

## 7.2.3.7.5 Test requirements

1. In steps 4 and 5, the UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the PDU contains an SDU boundary after octet 1 of the data field, and the second shall indicate either that the remainder of the PDU contains padding, or that it contains a piggy-backed status PDU.
2. In steps 8 and 9, the UE shall return two RLC PDUs. The first shall have no LIs. The second shall have a LI indicating the PDU contains an SDU boundary after octet 1 of the data field, and the second shall indicate either that the remainder of the PDU contains padding, or that it contains a piggy-backed status PDU.
3. The length and data content of all received SDUs shall should be the same as the transmitted SDUs.

## 7.2.3.8 Segmentation and Reassembly / 15-bit Length Indicators / LI = 0

## 7.2.3.8.1 Definition

The RLC segments and concatenates SDUs into payload units according to the payload unit size configured by RRC. A pre-defined length indicator value is used to indicate when an SDUs ends coincident with the end of the previous PU. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

## 7.2.3.8.2 Conformance requirement

If the PDU is exactly filled with the last segment of a SDU and there is no room for an LI field, an LI field set to only 0's shall be included as the first length indicator in the following PDU.

## Reference(s)

TS 25.322 clause 11.3.2.1.

## 7.2.3.8.3 Test purpose

1. To test that where an SDU exactly fills a PDU, an LI of value zero is placed by the transmitter as the first LI in the next PDU.
2. To test that where an SDU exactly fills a PDU, and an LI of value zero is the first LI in the next PDU, the receiver correctly reassembles the SDU.



#### 7.2.3.8.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 15-bit length indicator tests in clause 7.2.3.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into UE test loop mode 1 with the UL SDU size set to AM\_15\_PayloadSize bytes.

##### Test procedure

- a) The SS transmits an RLC SDU of size  $2 * AM\_15\_PayloadSize$  bytes. The SS polls the receiver for status in the last RLC PDU sent.
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

##### Expected sequence

| Step | Direction |    | Message          | Comments                                       |
|------|-----------|----|------------------|------------------------------------------------|
|      | UE        | SS |                  |                                                |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures                         |
| 2    |           | ←  | DOWNLINK RLC PDU | SDU 1                                          |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU 1                                          |
| 4    |           | ←  | DOWNLINK RLC PDU | LI=0, poll and padding                         |
| 5    |           | →  | UPLINK RLC PDU   | No Lis                                         |
| 6    |           | →  | UPLINK RLC PDU   | (Poll) Check Lis and re-assembled SDU          |
| 6a   |           | →  | STATUS PDU       | <i>If piggy-backed status is not used in 6</i> |
| 7    |           | ←  | STATUS PDU       |                                                |
| 8    |           |    | RB RELEASE       | Optional step                                  |

#### 7.2.3.8.5 Test requirements

The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have an LI indicating that the SDU exactly filled the previous PU, and an LI indicating either that the remainder of the PDU contains padding, or that it contains a piggy-backed STATUS PDU.

The length of the received SDU should be AM\_15\_PayloadSize bytes, and the data content the same as the first AM\_15\_PayloadSize bytes of the transmitted SDU.

#### 7.2.3.9 Segmentation and reassembly / 15-bit Length Indicators / One octet short LI

##### 7.2.3.9.1 Definition

The RLC segments and concatenates SDUs into payload units according to the payload unit size configured by RRC. A pre-defined length indicator value is used to indicate when an SDUs ends one octet short of the end of the previous PU. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

##### 7.2.3.9.2 Conformance requirement

In the case where the last segment of an RLC SDU is one octet short of exactly filling the last RLC PU, and 15-bit Length Indicators are used, the next Length Indicator shall be placed as the first Length Indicator in the next PDU and have value LI=111 1111 1111 1011.

In the case where a PDU contains a 15-bit LI indicating that an SDU ends with one octet left in the PDU, the last octet of this PDU shall be ignored and shall not be filled with the first octet of the next SDU data.

## Reference(s)

TS 25.322 clause 9.2.2.8.

## 7.2.3.9.3 Test purpose

1. To test that where the UE transmits an SDU, which is one byte short of filling a PDU, an LI indicating one byte short is placed as the first LI in the next PDU.
2. To test that where the UE correctly handles a received PDU containing an LI indicating that an SDU ended one byte short of the end of the previous PDU.

## 7.2.3.9.4 Method of test

## Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 15-bit length indicator tests in clause 7.2.3.1.

These settings apply to both the uplink and downlink DTCH.

The radio bearer is placed into UE test loop mode 1 with the UL SDU size set to AM\_15\_PayloadSize – 1 bytes.

## Test procedure

- a) The SS transmits an RLC SDU of size  $(2 * \text{AM\_15\_PayloadSize}) - 1$  bytes. The SS polls the receiver for status in the last RLC PDU sent.
- b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the length and content of the received RLC SDU.
- c) The SS may optionally release the radio bearer.

## Expected sequence

| Step | Direction |    | Message          | Comments                                                                                                                                                                                 |
|------|-----------|----|------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                  |                                                                                                                                                                                          |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures<br>SDU 1<br>SDU 1<br>LI=111 1111 1111 1011, poll and padding<br>No LIs<br>(Poll) Check LIs and re-assembled SDU<br><i>If piggy-backed status is not used in 6</i> |
| 2    |           | ←  | DOWNLINK RLC PDU |                                                                                                                                                                                          |
| 3    |           | ←  | DOWNLINK RLC PDU |                                                                                                                                                                                          |
| 4    |           | ←  | DOWNLINK RLC PDU |                                                                                                                                                                                          |
| 5    |           | →  | UPLINK RLC PDU   |                                                                                                                                                                                          |
| 6    |           | →  | UPLINK RLC PDU   |                                                                                                                                                                                          |
| 6a   |           | →  | STATUS PDU       |                                                                                                                                                                                          |
| 7    |           | ←  | STATUS PDU       |                                                                                                                                                                                          |
| 8    |           |    | RB RELEASE       | Optional step                                                                                                                                                                            |

## 7.2.3.9.5 Test requirements

1. The UE shall return two RLC PDUs. The first shall have no LIs. The second shall have 2 LIs. The first LI shall be an LI indicating that the SDU was one byte short of filling the previous PDU, and the second an LI indicating that the remainder of the PDU contains padding.
2. The length of the received SDU should be AM\_15\_PayloadSize – 1 bytes, and the data content the same as the first AM\_15\_PayloadSize – 1 bytes of the transmitted SDU.

### 7.2.3.10 ~~Reassembly / 15-bit Length Indicators / Reserved LI value~~

#### 7.2.3.10.1 ~~Definition~~

The RLC segments and concatenates SDUs into payload units according to the payload unit size configured by RRC. Length indicators are added to allow correct reconstruction of SDUs. The behaviour of the RLC on reception of a reserved LI value has been specified. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.

#### 7.2.3.10.2 ~~Conformance requirement~~

Upon reception of an AMD PDU that contains Length Indicator value "111111111111100" or "11111111111101"; PDUs with this coding will be discarded by this version of the protocol.

#### Reference(s)

TS 25.322 clause 9.2.2.8.

#### 7.2.3.10.3 ~~Test purpose~~

To test that PDUs with reserved length indicators are discarded by the receiving RLC.

#### 7.2.3.10.4 ~~Method of test~~

#### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 15-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                                       |       |
|---------------------------------------|-------|
| Downlink RLC<br>Missing PDU Indicator | FALSE |
|---------------------------------------|-------|

These settings apply to both the uplink and downlink DTCH.

#### Test procedure

- The SS transmits three RLC SDUs of size AM\_15\_PayloadSize + 1 bytes. In the second PDU, the SS sets the value of the LI to 111111111111100. In the third PDU for transmission, the SS sets the value of the second (padding) LI to 11111111111101.
- The SS waits to receive a status report from the UE.
- The SS may optionally release the radio bearer.

#### Expected sequence

| Step | Direction |    | Message             | Comments                            |
|------|-----------|----|---------------------|-------------------------------------|
|      | UE        | SS |                     |                                     |
| 1    |           |    | RB ESTABLISHMENT    | See generic procedures              |
| 2    | ←         |    | DOWNLINK RLC PDU #0 | SDU 1                               |
| 3    | ←         |    | DOWNLINK RLC PDU #1 | SDU 1 + SDU 2, LI = 111111111111100 |
| 4    | ←         |    | DOWNLINK RLC PDU #2 | SDU 2 + SDU 3, LI = 11111111111101  |
| 5    | ←         |    | DOWNLINK RLC PDU #3 | SDU 3 + poll                        |
| 6    | →         |    | STATUS PDU          | Nack PDUs 1 and 2                   |
| 7    |           |    | RB RELEASE          | Optional step                       |

### 7.2.3.10.5 ~~Test requirements~~

- ~~1. The UE shall return a STATUS PDU indicating that PDUs with sequence numbers 1 and 2 were incorrectly received.~~
- ~~2. No uplink SDUs shall be received.~~

### 7.2.3.11 ~~Reassembly / 15-bit Length Indicators / LI value > PDU size~~

#### 7.2.3.11.1 ~~Definition~~

~~The RLC segments and concatenates SDUs into payload units according to the payload unit size configured by RRC. Length indicators are added to allow correct reconstruction of SDUs. The behaviour of the RLC on reception of an invalid LI value has been specified. Incorrect operation of segmentation, concatenation, or coding of length indicators will result in failure of the UE to communicate.~~

#### 7.2.3.11.2 ~~Conformance requirement~~

~~If the length indicator of a PDU has a value that is larger than the PDU size—the number of octets containing LIs in the PDU—1 and is not one of the predefined values listed in the table of 3GPP TS 25.322 clause 9.2.2.8, the PDU shall be discarded and treated as a missing PDU.~~

#### Reference(s)

~~TS 25.322 clause 11.3.4.5.~~

#### 7.2.3.11.3 ~~Test purpose~~

~~To test that PDUs with length indicators that point beyond the end of the PDU are discarded by the receiving RLC.~~

#### 7.2.3.11.4 ~~Method of test~~

#### Initial conditions

~~The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 15-bit length indicator tests in clause 7.2.3.1.~~

~~The following RLC parameter values are used in place of the values in clause 7.2.3.1:~~

|                                  |                  |
|----------------------------------|------------------|
| <del>Downlink RLC</del>          |                  |
| <del>Missing PDU Indicator</del> | <del>FALSE</del> |

~~These settings apply to both the uplink and downlink DTCH.~~

#### Test procedure

- ~~a) The SS transmits three RLC SDUs of size AM\_15\_PayloadSize + 1 bytes. All the SDUs are concatenated or segmented over successive RLC PDUs. In the third PDU for transmission, the SS sets value of the length indicator to be AM\_15\_PayloadSize + 1 (decimal).~~
- ~~b) The SS checks the length indicator sizes and values of the RLC PDUs returned on the uplink, and checks the content of the received STATUS PDUs.~~
- ~~c) The SS may optionally release the radio bearer.~~

Expected sequence

| Step | Direction |    | Message             | Comments                   |
|------|-----------|----|---------------------|----------------------------|
|      | UE        | SS |                     |                            |
| 1    |           |    | RB ESTABLISHMENT    | See generic procedures     |
| 2    |           | ←  | DOWNLINK RLC PDU #0 | SDU 1                      |
| 3    |           | ←  | DOWNLINK RLC PDU #1 | SDU 1 & SDU 2              |
| 4    |           | ←  | DOWNLINK RLC PDU #2 | SDU 2 & SDU 3, with bad LI |
| 5    |           | ←  | DOWNLINK RLC PDU #4 | SDU 3, poll and padding    |
| 6    |           | →  | STATUS PDU          | Nack PDU #2                |
| 7    |           |    | RB RELEASE          | Optional step              |

7.2.3.11.5 Test requirements

The UE shall indicate that the PDU with sequence number 2 was not received.

7.2.3.12 Correct use of Sequence Numbering

7.2.3.12.1 Definition

Peer RLC entities use sequence numbering to detect missing PDUs, and for flow control purposes. Incorrect operation of sequence numbering will result in failure of the UE to communicate.

7.2.3.12.2 Conformance requirement

PDUs are sequentially and independently numbered and may have the value 0 through n minus 1 (where n is the modulus of the sequence numbers). The modulus equals  $2^{12}$  for AM...; the sequence numbers cycle through the entire range: 0 through  $2^{12}-1$  for AM.

If the PDU is transmitted for the first time, the Sequence Number field shall be set equal to VT(S) and VT(S) shall be updated

Reference(s)

TS 25.322, clauses 9.4 and 11.3.2.1.

7.2.3.12.3 Test purpose

1. To verify that the UE transmits the first PDU with the Sequence Number field equal to 0.
2. To verify that the UE increments the Sequence Number field according to the number of PDUs transmitted.
3. To verify that the UE wraps the Sequence Number after transmitting the  $2^{12}$ -1th PDU.
4. To verify that the UE receiver accepts PDUs with SNs that wrap around every  $2^{12}$ -1th PDU.

7.2.3.12.4 Method of test

Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                                         |      |
|-----------------------------------------|------|
| Uplink RLC<br>—Transmission window size | 4095 |
| Downlink RLC<br>—Receiving window size  | 4095 |

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to  $(2 * AM\_7\_PayloadSize) - 1$  bytes.

#### Test procedure

- a) The SS sends 2049 RLC SDUs to the UE, each of  $(2 * AM\_7\_PayloadSize) - 1$  bytes. The SS polls for status on each 128<sup>th</sup> RLC PDU and the last PDU transmitted
- b) The SS checks the sequence numbers of the RLC PDUs it receives in the uplink
- c) The SS checks the content of the SDUs it receives from the UE.
- d) The SS may optionally release the radio bearer.

#### Expected sequence

| Step | Direction |    | Message                | Comments                                                                                   |
|------|-----------|----|------------------------|--------------------------------------------------------------------------------------------|
|      | UE        | SS |                        |                                                                                            |
| 1    |           |    | RB ESTABLISHMENT       | See generic procedures                                                                     |
| 2    |           | ←  | DOWNLINK RLC PDU #0    |                                                                                            |
| 3    |           | ←  | DOWNLINK RLC PDU #1    |                                                                                            |
|      |           |    | ...                    | Transmission of DOWNLINK PDUs continues                                                    |
| 4    |           | →  | UPLINK RLC PDU         |                                                                                            |
| 5    |           | →  | UPLINK RLC PDU         | SN should be set to 0                                                                      |
|      |           | ←  | ...                    | SN should be set to 1                                                                      |
|      |           |    |                        | Transmission of DOWNLINK PDUs continues to SN = 127                                        |
| 6    |           | ←  | DOWNLINK RLC PDU #127  | Poll                                                                                       |
| 7    |           | →  | UPLINK STATUS PDU      | Transmission of DOWNLINK PDUs continues, polling every 128 <sup>th</sup> PDU, to SN = 4095 |
|      |           | ←  | ...                    |                                                                                            |
| 8    |           | ←  | DOWNLINK RLC PDU #4095 | SN=0                                                                                       |
| 9    |           | ←  | DOWNLINK RLC PDU #4096 | SN=1, Poll                                                                                 |
| 10   |           | ←  | DOWNLINK RLC PDU #4097 | Transfer of RLC PDUs continues to SN = 4095                                                |
|      |           | →  | ...                    |                                                                                            |
| 11   |           | →  | UPLINK RLC PDU         | SN should be set to 4095                                                                   |
| 12   |           | →  | UPLINK RLC PDU         | SN should be set to 0                                                                      |
| 13   |           | →  | UPLINK RLC PDU         | SN should be set to 1, Poll                                                                |
| 14   |           | ←  | DOWNLINK STATUS PDU    | Optional step                                                                              |
| 15   |           |    | RB RELEASE             |                                                                                            |

#### 7.2.3.12.5 Test requirements

1. The first PDU received should have the SN field set to 0. The second PDU should have the SN field set to 1, and the 4097<sup>th</sup> PDU should have the SN field set to 0.
2. The size and data content of the received SDUs shall match those of the transmitted SDUs.

#### 7.2.3.13 Control of Transmit Window

##### 7.2.3.13.1 Definition

This test is to check that the UE is able to correctly control its RLC transmission window. Correct operation of RLC windowing is critical for acknowledged mode operation.

##### 7.2.3.13.2 Conformance requirement

The transmitter shall not transmit a PDU with  $SN \geq VT(MS)$ .

The receiver is always allowed to change the Tx window size of the peer entity during a connection, but the minimum and the maximum allowed value is given by RRC configuration. The Rx window of the receiver is not changed.

#### Reference(s)

TS 25.322, clauses 9.2.2.11.3 and 9.4.

#### 7.2.3.13.3 ——— Test purpose

To verify that the UE does not transmit PDUs with sequence numbers outside of the transmit window, even when the transmit window size is changed by the receiver.

#### 7.2.3.13.4 ——— Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                                           |   |
|-------------------------------------------|---|
| Uplink RLC<br>—— Transmission window size | 8 |
|-------------------------------------------|---|

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to AM\_7\_PayloadSize – 1 bytes.

#### Test procedure

Let W be the size of the transmit window.

The length of all transmitted SDUs is set to AM\_7\_PayloadSize – 1 bytes.

- a) The SS transmits  $3 \cdot W$  RLC SDUs to the UE.
- b) The SS checks the RLC SDUs received on the uplink, but does not reply to poll requests from the UE, or transmit STATUS PDUs for any other reason.
- c) After confirming that the UE has stopped transmitting new RLC SDUs for at least  $(2 \cdot W \cdot TTI)$  ms, the SS transmits a STATUS PDU acknowledging all the RLC PDUs received so far.
- d) The SS again checks the RLC SDUs received on the uplink, but does not reply to poll requests from the UE, or transmit further STATUS PDUs for any other reason.
- e) After confirming that the UE has again stopped transmitting new RLC SDUs for at least  $(2 \cdot W \cdot TTI)$  ms, the SS transmits a STATUS PDU acknowledging all the RLC PDUs received so far, and containing a WINDOW command to reduce the UE transmit window size (W) to half its initial size.
- f) The SS checks the RLC SDUs received on the uplink, but does not reply to poll requests from the UE, or transmit STATUS PDUs for any other reason.
- g) After confirming that the UE has stopped transmitting new RLC SDUs for at least  $(2 \cdot W \cdot TTI)$  ms, the SS transmits a STATUS PDU acknowledging all the RLC PDUs received so far.
- h) The SS checks the RLC SDUs received on the uplink.
- i) The SS may optionally release the radio bearer.

NOTE: — Window arithmetic is carried out modulo 4096.

The test procedure is run with the window transmit window size set to the default (8), and the repeated with the transmit window size set to 1536.

## Expected sequence

| Step | Direction |    | Message          | Comments                          |
|------|-----------|----|------------------|-----------------------------------|
|      | UE        | SS |                  |                                   |
| 1    |           |    | RB-ESTABLISHMENT | See generic procedures            |
| 2    |           | ←  | DOWNLINK RLC-PDU | SDU-1                             |
| 3    |           | ←  | DOWNLINK RLC-PDU | SDU-2                             |
| 4    |           | ←  | DOWNLINK RLC-PDU | SDU-3                             |
| 5    |           | ←  | DOWNLINK RLC-PDU | SDU-4                             |
| 6    |           | ←  | ...              | SS continues to transmit RLC-SDUs |
| 7    |           | ←  | DOWNLINK RLC-PDU | SDU-3W                            |
| 8    | →         |    | UPLINK RLC-PDU   | SDU-1                             |
| 9    | →         |    | UPLINK RLC-PDU   | SDU-2                             |
| 10   | →         |    | ...              | SS continues to receive RLC-SDUs  |
| 11   | →         |    | UPLINK RLC-PDU   | SDU-W                             |
| 12   |           |    |                  | No new transmissions from UE      |
| 13   | ←         |    | STATUS-PDU       |                                   |
| 14   | →         |    | UPLINK RLC-PDU   | SDU-W+1                           |
| 15   | →         |    | UPLINK RLC-PDU   | SDU-W+2                           |
| 16   | →         |    | ...              | SS continues to receive RLC-SDUs  |
| 17   | →         |    | UPLINK RLC-PDU   | SDU-2W                            |
| 18   |           |    |                  | No new transmissions from UE      |
| 19   | ←         |    | STATUS-PDU       | WINDOW = W/2                      |
| 20   | →         |    | UPLINK RLC-PDU   | SDU-2W+1                          |
| 21   | →         |    | UPLINK RLC-PDU   | SDU-2W+2                          |
| 22   | ←         |    | ...              | SS continues to receive RLC-SDUs  |
| 23   | →         |    | UPLINK RLC-PDU   | SDU-2W + W/2                      |
| 24   |           |    |                  | No new transmissions from UE      |
| 25   | ←         |    | STATUS-PDU       |                                   |
| 26   | →         |    | UPLINK RLC-PDU   | SDU-2W+W/2+1                      |
| 27   | →         |    | UPLINK RLC-PDU   | SDU-2W+W/2+2                      |
| 28   | ←         |    | ...              | SS continues to receive RLC-SDUs  |
| 29   | →         |    | UPLINK RLC-PDU   | SDU-3W                            |
| 30   |           |    | RB-RELEASE       | Optional step                     |

NOTE: — The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

## 7.2.3.13.5 — Test requirements

From steps 8 to 11, the SDU contents reassembled from the uplink shall match those of the first W transmitted SDUs.

At step 12 there shall be no further transmission on the uplink DTCH whilst the SS is waiting, except for any repeats of the last transmitted PDU.

After step 13, the UE shall resume transmission of the next W SDUs. The contents of these SDUs shall match those of SDUs W+1 to 2\*W sent on the downlink.

At step 18 there shall be no further transmission on the uplink DTCH whilst the SS is waiting, except for any repeats of the last transmitted PDU.



After step 19, the UE shall resume transmission of the next  $W/2$  SDUs. The contents of these SDUs shall match those of SDUs  $2*W+1$  to  $2*W+W/2$  sent on the downlink.

At step 24 there shall be no further transmission on the uplink DTCH whilst the SS is waiting, except for any repeats of the last transmitted PDU.

After step 25, the UE shall resume transmission of the next  $W/2$  SDUs. The contents of these SDUs shall match those of SDUs  $2*W+W/2+1$  to  $3*W$  sent on the downlink.

### 7.2.3.14 Control of Receive Window

#### 7.2.3.14.1 Definition

This test is to check that the UE is able to correctly control its RLC receive window. Correct operation of RLC windowing is critical for acknowledged mode operation.

This test applies to all UE.

#### 7.2.3.14.2 Conformance requirement

Upon reception of a PDU with  $SN < VR(R)$  or  $SN \geq VR(MR)$  the receiver shall discard the PDU.

#### Reference(s)

TS 25.322, clause 11.3.4.2.

#### 7.2.3.14.3 Test purpose

1. To verify that the UE discards PDUs with sequence numbers outside the upper boundary of the receive window.

#### 7.2.3.14.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                                                                    |            |
|--------------------------------------------------------------------|------------|
| Uplink RLC<br>— Transmission window size                           | 8          |
| Downlink RLC<br>— Missing PDU Indicator<br>— Receiving window size | FALSE<br>8 |

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to  $AM\_7\_PayloadSize - 1$  bytes.

##### Test procedure

Let  $W$  be the size of the receive window.

The length of all transmitted SDUs is set to  $AM\_7\_PayloadSize - 1$  bytes.

- a) The SS transmits  $W$  RLC SDUs to the UE, polling only on the last RLC PDU.
- b) The SS checks the RLC SDUs received on the uplink, and after receiving the STATUS PDU from the UE it transmits a further RLC SDU. The SS sets the sequence number for the associated RLC PDU above the top of the receive window, for example,  $2*W+1$ .

c) The SS transmits a further RLC SDU with the sequence number set to the value of the next sequence number within the receive window.

d) The SS checks the RLC SDUs received on the uplink.

e) The SS may optionally release the radio bearer.

This test case is run once for the default receive window size (8) and again with the receive window size set to 1536.

#### Expected sequence

| Step | Direction |    | Message          | Comments                          |
|------|-----------|----|------------------|-----------------------------------|
|      | UE        | SS |                  |                                   |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures            |
| 2    |           | ←  | DOWNLINK RLC PDU | SDU 1, SN = 0                     |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU 2, SN = 1                     |
| 4    |           | ←  | ...              | SS continues to transmit RLC SDUs |
| 5    |           | ←  | DOWNLINK RLC PDU | SDU W + Poll, SN = W-1            |
| 6    |           | →  | STATUS PDU       |                                   |
| 7    |           | →  | UPLINK RLC PDU   | SDU 1                             |
| 8    |           | →  | UPLINK RLC PDU   | SDU 2                             |
| 9    |           |    | ...              | UE continues to transmit RLC SDUs |
| 10   |           | →  | UPLINK RLC PDU   | SDU W                             |
| 11   |           | ←  | DOWNLINK RLC PDU | SDU W+1, SN = 2W+1                |
| 12   |           | ←  | DOWNLINK RLC PDU | SDU W+2, SN = W                   |
| 13   |           | →  | UPLINK RLC PDU   | SDU W+2                           |
| 14   |           |    | RB RELEASE       | Optional step                     |

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

#### 7.2.3.14.5 Test requirements

1. The SS shall receive back SDUs 1 to W, and SDU W + 2 only. No other SDUs shall be looped back.

#### 7.2.3.15 Polling for status / Last PDU in transmission queue

##### 7.2.3.15.1 Definition

This case tests that the UE will poll for a status request on the last PDU in its transmission queue when that mode is enabled. Incorrect operation of polling will cause degradation of service, or at worst service failure.

##### 7.2.3.15.2 Conformance requirement

The Polling bit shall be set to 1 if any of following conditions are fulfilled except when the poll prohibit function is used and the timer Timer\_Poll\_Prohibit is active:

1. Last PDU in buffer is used and the last PDU available for transmission is transmitted.

#### Reference

TS 25.322 clause 11.3.2.1.1.

#### 7.2.3.15.3 Test purpose

1. To verify that a poll is performed when only one PDU is available for transmission, and the poll prohibit timer is function is not used.

2. To verify that a poll is performed when only one PDU is available for transmission, and the poll prohibit timer is function is used, but inactive.

#### 7.2.3.15.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

| Uplink RLC                      | First run | Second run |
|---------------------------------|-----------|------------|
| —— Polling info                 |           |            |
| —— Timer_poll_prohibit          | disabled  | 200        |
| —— Last transmission PDU poll   | TRUE      | TRUE       |
| —— Last retransmission PDU poll | FALSE     | FALSE      |

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to  $(2 * AM\_7\_PayloadSize) - 1$  bytes.

##### Test procedure

- The SS transmits an RLC SDU of length  $(4 * AM\_7\_PayloadSize) - 1$  bytes to the UE.
- The SS checks the uplink RLC PDUs for a poll for status flag.
- The SS may optionally release the radio bearer.

The test is repeated using the RLC parameters given in the Second run column of the configuration table for the initial conditions.

##### Expected sequence

| Step | Direction |    | Message          | Comments               |
|------|-----------|----|------------------|------------------------|
|      | UE        | SS |                  |                        |
| 1    |           |    | RB ESTABLISHMENT | See generic procedures |
| 2    | ←         |    | DOWNLINK RLC PDU | SDU 1                  |
| 3    | ←         |    | DOWNLINK RLC PDU | SDU 1                  |
| 4    | ←         |    | DOWNLINK RLC PDU | SDU 1                  |
| 5    | ←         |    | DOWNLINK RLC PDU | SDU 1 + Poll           |
| 6    | →         |    | STATUS PDU       |                        |
| 7    | →         |    | UPLINK RLC PDU   | SDU 1                  |
| 8    | →         |    | UPLINK RLC PDU   | SDU 1 + Poll           |
| 9    | ←         |    | STATUS PDU       |                        |
| 10   |           |    | RB RELEASE       | Optional step          |

#### 7.2.3.15.5 Test requirements

The Poll bit shall be set in the AMD PDU header of the PDU returned in step 8.

#### 7.2.3.16 Polling for status / Last PDU in retransmission queue

##### 7.2.3.16.1 Definition

This case tests that the UE will poll for a status request on the last PDU in its retransmission queue when that mode is enabled. Incorrect operation of polling will cause degradation of service, or at worst service failure.

### 7.2.3.16.2 ~~Conformance requirement~~

The Polling bit shall be set to 1 if any of following conditions are fulfilled except when the poll prohibit function is used and the timer Timer\_Poll\_Prohibit is active:

- ~~1) ...~~
- ~~2) Last PDU in retransmission buffer is used and the last PDU to be retransmitted is transmitted.~~

### Reference

~~25.322 clause 11.3.2.1.1.~~

### 7.2.3.16.3 ~~Test purpose~~

- ~~1. To verify that a poll is performed when only one PDU is available for retransmission, and the poll prohibit timer is function is not used.~~
- ~~2. To verify that a poll is performed when only one PDU is available for retransmission, and the poll prohibit timer is function is used, but inactive.~~

### 7.2.3.16.4 ~~Method of test~~

#### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

| Uplink RLC                                | First run | Second run |
|-------------------------------------------|-----------|------------|
| <del>— Polling info</del>                 |           |            |
| <del>— Timer_poll_prohibit</del>          | disabled  | 200        |
| <del>— Last transmission PDU poll</del>   | FALSE     | FALSE      |
| <del>— Last retransmission PDU poll</del> | TRUE      | TRUE       |

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to  $(2 * AM\_7\_PayloadSize) - 1$  bytes.

#### Test procedure

- ~~a) The SS transmits an RLC SDU of length  $(4 * AM\_7\_PayloadSize) - 1$  bytes to the UE.~~
- ~~b) The SS checks the uplink RLC PDUs for a poll for status flag.~~
- ~~c) The SS transmits a STATUS PDU negatively acknowledging the first uplink RLC PDU as missing.~~
- ~~d) The SS waits for the RLC PDU to be retransmitted and then checks the uplink RLC PDU for a poll for status flag.~~
- ~~e) The SS may optionally release the radio bearer.~~

The test is repeated using the RLC parameters given in the Second run column of the configuration table for the initial conditions.

## Expected sequence

| Step | Direction |     | Message          | Comments                |
|------|-----------|-----|------------------|-------------------------|
|      | UE        | SS  |                  |                         |
| 1    |           |     | RB-ESTABLISHMENT | See generic procedures  |
| 2    |           | ←   | DOWNLINK RLC-PDU | SDU 1                   |
| 3    |           | ←   | DOWNLINK RLC-PDU | SDU 1                   |
| 4    |           | ←   | DOWNLINK RLC-PDU | SDU 1                   |
| 5    |           | ←   | DOWNLINK RLC-PDU | SDU 1 + Poll            |
| 6    |           | →   | STATUS-PDU       |                         |
| 7    |           | →   | UPLINK RLC-PDU   | SDU 1, SN=0             |
| 8    |           | →   | UPLINK RLC-PDU   | SDU 1, SN=1             |
| 9    |           | ←   | STATUS-PDU       | NAK: SN=0               |
| 10   |           | ... |                  | Wait for retransmission |
| 11   |           | →   | UPLINK RLC-PDU   | SDU 1, SN=0 + Poll      |
| 12   |           | ←   | STATUS-PDU       |                         |
| 13   |           |     | RB-RELEASE       | Optional step           |

## 7.2.3.16.5 Test requirements

The Poll bit shall be set in the AMD-PDU header of the PDU returned in step 11.

## 7.2.3.17 Polling for status / Poll every Poll\_PDU PDUs

## 7.2.3.17.1 Definition

This case tests that the UE will poll for a status request every Poll\_PDU PDUs when that mode is enabled. Incorrect operation of polling will cause degradation of service, or at worst service failure.

## 7.2.3.17.2 Conformance requirement

VT(PDU) should be incremented for both new and retransmitted PDUs. When it reaches Poll\_PDU a new poll is transmitted and the state variable is set to zero.

The Polling bit shall be set to 1 if ... Every Poll\_PDU PDU is used and when VT(PDU)=Poll\_PDU

## Reference

TS 25.322 clauses 9.4, 9.6 and 11.3.2.1.1.

## 7.2.3.17.3 Test purpose

1. To verify that a poll is performed when VT(PDU) reaches Poll\_PDU.
2. To verify VT(PDU) is incremented for both new and retransmitted PDUs.

#### 7.2.3.17.4 ~~Method of test~~

##### ~~Initial conditions~~

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                                           |       |
|-------------------------------------------|-------|
| Uplink RLC                                |       |
| <del>— Polling info</del>                 |       |
| <del>— Poll_PDU</del>                     | 4     |
| <del>— Last transmission PDU poll</del>   | FALSE |
| <del>— Last retransmission PDU poll</del> | FALSE |

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to  $AM\_7\_PayloadSize - 1$  bytes.

##### ~~Test procedure~~

Let the value of Poll\_PDU be P:

- ~~The SS sends  $3 * P - 2$  RLC SDUs of size  $AM\_7\_PayloadSize - 1$  bytes to the UE in PDUs with sequence numbers that are contiguous, starting from zero.~~
- ~~The SS checks the sequence numbers and polling bits of the RLC SDUs returned on the uplink.~~
- ~~The SS sends a STATUS PDU negatively acknowledging two RLC PDUs with a sequence numbers of already received PDUs. The other PDUs are acknowledged as received correctly.~~
- ~~The SS checks the sequence numbers and polling bits of the RLC SDUs returned on the uplink.~~
- ~~The SS terminates the connection.~~

## Expected sequence

| Step | Direction |    | Message          | Comments                          |
|------|-----------|----|------------------|-----------------------------------|
|      | UE        | SS |                  |                                   |
| 1    | ←         |    | DOWNLINK RLC PDU | SDU 1                             |
| 2    | ←         |    | DOWNLINK RLC PDU | SDU 2                             |
| 3    | ←         |    | ...              | SS continues to transmit RLC SDUs |
| 4    | ←         |    | DOWNLINK RLC PDU | SDU 3P—2                          |
| 5    | →         |    | UPLINK RLC PDU   | SDU 1                             |
| 6    | →         |    | UPLINK RLC PDU   | SDU 2                             |
| 7    | →         |    | ...              | SS continues to receive RLC SDUs  |
| 8    | →         |    | UPLINK RLC PDU   | SDU P, Poll                       |
| 9    | ←         |    | STATUS PDU       | NAK SN=0 and SN=1                 |
| 10   | →         |    | UPLINK RLC PDU   | SDU 1                             |
| 11   | →         |    | UPLINK RLC PDU   | SDU 2                             |
| 12   | →         |    | UPLINK RLC PDU   | SDU P+1                           |
| 13   | →         |    | ...              | SS continues to receive RLC SDUs  |
| 14   | →         |    | UPLINK RLC PDU   | SDU 2P—2, Poll                    |
| 15   | →         |    | ...              | SS continues to receive RLC SDUs  |
| 16   | →         |    | UPLINK RLC PDU   | SDU 3P—2, Poll                    |
| 17   |           |    | RB RELEASE       | Optional step                     |

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

## 7.2.3.17.5 — Test requirements

The SS shall receive a poll for status in the RLC PDUs sent on the uplink in steps 8, 14 and 16 above.

## 7.2.3.18 — Polling for status / Poll every Poll\_SDU SDUs

## 7.2.3.18.1 — Definition

This case tests that the UE will poll for a status request every Poll\_SDU SDUs when that mode is enabled. Incorrect operation of polling will cause degradation of service, or at worst service failure.

## 7.2.3.18.2 — Conformance requirement

The state variable VT(SDU) is used when the poll every Poll\_SDU SDUs function is used. It is incremented with 1 for each SDU that is transmitted. When it reaches Poll\_SDU a new poll is transmitted and the state variable is set to zero. The poll bit should be set in the PDU that contains the last segment of the SDU. The initial value of this variable is 0.

The Polling bit shall be set to 1 if ... Every Poll\_SDU is used and VT(SDU)=Poll\_SDU and the PDU contains the last segment that SDU

## Reference

TS 25.322 clauses 9.4, 9.6 and 11.3.2.1.1.

## 7.2.3.18.3 — Test purpose

1. To verify that a poll is performed when VT(SDU) reaches Poll\_SDU.
2. To verify that the poll is sent in the last PDU of the SDU.

#### 7.2.3.18.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM-7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                              |       |
|------------------------------|-------|
| Uplink RLC                   |       |
| — Polling info               |       |
| — Last transmission PDU poll | FALSE |
| — Poll_SDU                   | 1     |

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to  $(4 * AM\_7\_PayloadSize) - 1$  bytes.

Let the value of Poll\_SDU be P.

- The SS sends  $2 * P$  RLC SDUs of size  $AM\_7\_PayloadSize - 1$  bytes to the UE in PDUs with sequence numbers that are contiguous, starting from zero.
- The SS checks the sequence numbers and polling bits of the RLC SDUs returned on the uplink.
- The SS terminates the connection.

The test is repeated with Poll\_SDU set to 64.

##### Expected sequence

| Step | Direction |    | Message          | Comments                                                                  |
|------|-----------|----|------------------|---------------------------------------------------------------------------|
|      | UE        | SS |                  |                                                                           |
| 1    |           | ←  | DOWNLINK RLC PDU | SDU 1                                                                     |
| 2    |           | ←  | DOWNLINK RLC PDU | SDU 2                                                                     |
| 3    |           | ←  | ...              | SS continues to transmit RLC SDUs                                         |
| 4    |           | ←  | DOWNLINK RLC PDU | SDU 2P                                                                    |
| 5    | →         |    | UPLINK RLC PDU   | SDU 1 Expanded to $(4 * AM\_7\_PayloadSize) - 1$ bytes by test function   |
| 6    | →         |    | UPLINK RLC PDU   |                                                                           |
| 7    | →         |    | ...              | SS continues to receive RLC SDUs                                          |
| 8    | →         |    | UPLINK RLC PDU   | SDU P, Poll                                                               |
| 9    | ←         |    | STATUS PDU       |                                                                           |
| 10   | →         |    | UPLINK RLC PDU   | SDU P+1 Expanded to $(4 * AM\_7\_PayloadSize) - 1$ bytes by test function |
| 11   | →         |    | UPLINK RLC PDU   |                                                                           |
| 12   | →         |    | ...              | SS continues to receive RLC SDUs                                          |
| 13   | →         |    | UPLINK RLC PDU   | SDU 2P, Poll                                                              |
| 14   |           |    | RB RELEASE       | Optional step                                                             |

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

#### 7.2.3.18.5 Test requirements

The UE shall return uplink PDUs that contain polls for status in sequence numbers  $4 * P - 1$  and  $8 * P - 1$ . No other PDUs should poll for status.



### 7.2.3.19 ~~————~~ Polling for status / Timer triggered polling (Timer\_Poll\_Periodic)

#### 7.2.3.19.1 ~~————~~ Definition

This case tests that the UE will poll for a status request every Timer\_Poll\_Periodic ms when that mode is enabled. Incorrect operation of polling will cause degradation of service, or at worst service failure.

#### 7.2.3.19.2 ~~————~~ Conformance requirement

Each time the timer expires, the timer is restarted and a poll is triggered (either by the transmission of a PDU which was not yet sent, or by a retransmission). If there is no PDU to be transmitted and all PDUs have already been acknowledged, a poll shall not be triggered and the timer shall only be restarted. The value of the timer is signalled by RRC.

The Polling bit shall be set to 1 if ... timer-based polling is used and Timer\_Poll\_Periodic has expired.

#### Reference

TS 25.322 clauses 9.5 and 11.3.2.1.1.

#### 7.2.3.19.3 ~~————~~ Test purpose

1. To verify that the UE polls the SS in the next PDU to be transmitted or retransmitted each time the Timer\_Poll\_Periodic timer expires.
2. To verify that if there is no PDU to be transmitted, and all the PDUs have already been acknowledged, the timer is restarted, but no poll is sent.

#### 7.2.3.19.4 ~~————~~ Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                               |           |            |
|-------------------------------|-----------|------------|
| Uplink RLC                    | First run | Second run |
| —— Polling info               |           |            |
| —— Last transmission PDU poll | FALSE     | FALSE      |
| —— Timer_poll_periodic        | 100       | 2000       |

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to AM\_7\_PayloadSize – 1 bytes.

##### Test procedure

Let T be the value of Timer\_Poll\_Periodic:

- a) The SS waits for at least 2\*T ms before starting any transmissions, and monitors the uplink.
- b) The SS sends  $T * 0.1$  RLC SDUs of size AM\_7\_PayloadSize – 1 bytes to the UE.
- c) The SS waits for the first PDU to be received with the P bit set, records the arrival time ( $T_1$ ) and responds with a STATUS PDU normally.
- d) The SS waits for the reception of the next PDU with the P bit set, records the arrival time ( $T_2$ ), and then transmits a STATUS PDU reporting that none of the uplink PDUs were correctly received, except for the PDU with  $SN = \text{ceil}(2T/TTI)$  which is acknowledged.

- e) The SS waits for the next PDU received with the P bit set, and records the arrival time ( $T_3$ ).
- f) The SS waits for the reception of the next PDU with the P bit set and records the arrival time ( $T_4$ ).
- g) The SS may optionally release the radio bearer.

#### Expected sequence

| Step | Direction |    | Message          | Comments                                          |
|------|-----------|----|------------------|---------------------------------------------------|
|      | UE        | SS |                  |                                                   |
| 1    |           | ←  | DOWNLINK RLC PDU | SDU 1                                             |
| 2    |           | ←  | ...              | SS continues to transmit RLC SDUs                 |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU 0.1T                                          |
| 4    |           | →  | UPLINK RLC PDU   | SDU 1                                             |
| 5    |           | →  | UPLINK RLC PDU   | SDU 2                                             |
| 6    |           | →  | ...              | SS continues to receive RLC PDUs                  |
| 7    |           | →  | UPLINK RLC PDU   | SN = ceil( $T/TTI$ ), Poll: Note $T_1$            |
| 8    |           | ←  | STATUS PDU       | ACK SN 0 to SN ceil( $T/TTI$ )                    |
| 9    |           | →  | UPLINK RLC PDU   | SN = ceil( $T/TTI$ )+1                            |
| 10   |           | →  | ...              | SS continues to receive RLC PDUs                  |
| 11   |           | →  | UPLINK RLC PDU   | SN = ceil( $2T/TTI$ ), Poll: Note $T_2$           |
| 12   |           | ←  | STATUS PDU       | NAK SN ceil( $T/TTI$ )+1 to SN ceil( $2T/TTI$ )-1 |
| 13   |           | →  | UPLINK RLC PDU   | PDUs including some retransmissions               |
| 14   |           | →  | UPLINK RLC PDU   |                                                   |
| 15   |           | →  | ...              | SS continues to receive RLC PDUs                  |
| 16   |           | →  | UPLINK RLC PDU   | Poll: Note $T_3$                                  |
| 17   |           | ←  | STATUS PDU       | Normal                                            |
| 18   |           | →  | ...              | SS continues to receive RLC PDUs                  |
| 19   |           | →  | UPLINK RLC PDU   | Poll: Note $T_4$                                  |
| 20   |           |    | RB RELEASE       | Optional step                                     |

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

#### 7.2.3.19.5 Test requirements

Time  $T_2 - T_1$  should be  $T$ .

Time  $T_3 - T_2$  should be  $T$ .

Time  $T_4 - T_3$  should be  $T$ .

#### 7.2.3.20 Polling for status / Polling on Poll\_Window% of transmission window

##### 7.2.3.20.1 Definition

This case tests that the UE will poll for a status request when it has reached Poll\_Window% of the transmission window, when that mode is enabled. Incorrect operation of polling will cause degradation of service, or at worst service failure.

This test applies to all UE.

##### 7.2.3.20.2 Conformance requirement

The Polling bit shall be set to 1 if ... Window based polling is used, , and  $J \geq \text{Poll\_Window}$ , where J is:

—  $J \geq \text{Poll\_Window}$ , where  $J$  is the window transmission percentage defined by

$$J = \frac{(4096 + VT(S) - VT(A)) \bmod 4096}{VT(WS)} * 100,$$

where the constant 4096 is the modulus for AM described in 3GPP TS 25.322 clause 9.4.

## Reference

25.322 clauses 9.6 and 11.3.2.1.1.

### 7.2.3.20.3 Test purpose

1. To verify that the UE polls the SS once the window-based polling equation is satisfied.

### 7.2.3.20.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                              |       |
|------------------------------|-------|
| Uplink RLC                   |       |
| — Polling info               |       |
| — Last transmission PDU poll | FALSE |
| — Poll_Window                | 50    |
| — Transmission window size   | 8     |
| Downlink RLC                 |       |
| — Receiving window size      | 8     |

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to  $\text{AM\_7\_PayloadSize} - 1$  bytes.

#### Test procedure

Let  $W$  be the size of the transmission window.

- a) The SS transmits  $(W/2) + 2$  RLC SDUs of size  $\text{AM\_7\_PayloadSize} - 1$  bytes.
- b) The SS checks the sequence number of the first uplink PDU to be received with the P bit set.
- c) The SS sends another RLC SDU of size  $\text{AM\_7\_PayloadSize} - 1$  bytes.
- d) The SS checks the sequence number of the next uplink PDU to be received with the P bit set.
- e) The SS shall wait until no more new PDUs are received.
- f) The SS sends a STATUS PDU acknowledging the first five RLC PDUs received, followed by two further RLC SDUs.
- g) The SS checks the sequence number of the next uplink PDU to be received with the P bit set.
- h) The SS may optionally release the radio bearer.

## Expected sequence

| Step | Direction |    | Message          | Comments                                     |
|------|-----------|----|------------------|----------------------------------------------|
|      | UE        | SS |                  |                                              |
| 1    | ←         |    | DOWNLINK RLC PDU | SDU 1                                        |
| 2    | ←         |    | ...              | SS continues to transmit RLC SDUs            |
| 3    | ←         |    | DOWNLINK RLC PDU | SDU W/2+2                                    |
| 4    | →         |    | UPLINK RLC PDU   | SDU 1                                        |
| 5    | →         |    | UPLINK RLC PDU   | SDU 2                                        |
| 6    | →         |    | ...              | SS continues to receive RLC PDUs             |
| 7    | →         |    | UPLINK RLC PDU   | SN = W/2-1, Poll                             |
| 8    | ←         |    | DOWNLINK RLC PDU |                                              |
| 9    | →         |    | UPLINK RLC PDU   | SN = W/2, Poll                               |
| 9a   |           |    |                  | SS waits until no more new PDUs are received |
| 10   | ←         |    | STATUS PDU       | ACK SN 0 to 4                                |
| 11   | ←         |    | DOWNLINK RLC PDU |                                              |
| 12   | ←         |    | DOWNLINK RLC PDU |                                              |
| 13   | →         |    | UPLINK RLC PDU   | SN = W/2+3                                   |
| 14   | →         |    | UPLINK RLC PDU   | SN = W/2+4, Poll                             |
| 15   |           |    | RB RELEASE       | Optional step                                |

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

## 7.2.3.20.5 Test requirements

The SS shall receive RLC PDUs with the P bit set in PDUs with sequence numbers of 3, 4, and 8. No other PDUs should have their P bits set.

## 7.2.3.21 Polling for status / Operation of Timer\_Poll timer / Timer expiry

## 7.2.3.21.1 Definition

This case tests that the UE will retransmit a poll for status if it does not receive a STATUS PDU within Timer\_Poll ms after a poll for status is transmitted. Incorrect operation of polling will cause degradation of service, or possible service failure.

## 7.2.3.21.2 Conformance requirement

The Polling bit shall be set to 1 if any of following conditions are fulfilled except when the poll prohibit function is used and the timer Timer\_Poll\_Prohibit is active.

...

3) Poll timer is used and timer Timer\_Poll has expired.

Upon expiry of the Timer\_Poll the sender shall retransmit the poll. The poll can be retransmitted in either a new PDU or a retransmitted PDU.

## Reference

TS 25.322 clauses 11.3.2.1.1 and 11.3.4.1.

## 7.2.3.21.3 Test purpose

1. To verify that if the timer expires and no STATUS PDU containing an acknowledgement or negative acknowledgement of the AMD PDUs up to that which triggered the timer has been received, the receiver is polled once more.

#### 7.2.3.21.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

| Uplink RLC                   | First-run | Second-run |
|------------------------------|-----------|------------|
| — Polling info               |           |            |
| — Last transmission PDU poll | FALSE     | FALSE      |
| — Timer_poll                 | 500       | 1000       |
| — Timer_Poll_Periodic        | 2000      | 2000       |

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to AM\_7\_PayloadSize – 1 bytes.

##### Test procedure

Let T be the value of the Timer\_Poll\_Periodic timer.

- The SS transmits at least  $2 * T / TTI$  SDUs of size AM\_7\_PayloadSize – 1 bytes.
- The SS receives PDUs from the UE, and notes the time on receiving the first PDU with the P bit set, but does not respond. This time will be recorded as  $T_1$ .
- The SS continues to receive PDUs from the UE and notes the time on receipt of the next PDU with the P bit set. This time will be recorded as  $T_2$ .
- The SS may optionally release the radio bearer.

The test case is run once for each set of initial RLC parameters.

##### Expected sequence

| Step | Direction |    | Message          | Comments                           |
|------|-----------|----|------------------|------------------------------------|
|      | UE        | SS |                  |                                    |
| 1    |           | ←  | DOWNLINK RLC PDU | SDU 1                              |
| 2    |           | ←  | ...              | SS continues to transmit RLC SDUs  |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU ceil(2T/TTI)                   |
| 4    | →         |    | UPLINK RLC PDU   | SDU 1                              |
| 5    | →         |    | UPLINK RLC PDU   | SDU 2                              |
| 6    |           | →  | ...              | SS continues to receive RLC PDUs   |
| 7    | →         |    | UPLINK RLC PDU   | SN = ceil(T/TTI), Poll: Note $T_1$ |
| 8    | →         |    | UPLINK RLC PDU   | SN = ceil(T/TTI)+1                 |
| 9    |           | →  | ...              | SS continues to receive RLC PDUs   |
| 10   | →         |    | UPLINK RLC PDU   | Poll: Note $T_2$                   |
| 11   |           |    | RB RELEASE       | Optional step                      |

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

### 7.2.3.21.5 ~~Test requirements~~

For the first run, the measured time  $T_2 - T_1$  should be 500 ms.

For the second run, the measured time  $T_2 - T_1$  should be 1000 ms.

### 7.2.3.22 ~~Polling for status / Operation of Timer\_Poll timer / Stopping Timer\_Poll timer~~

#### 7.2.3.22.1 ~~Definition~~

This case tests that the UE will stop the Timer\_Poll timer if it receives a STATUS PDU within Timer\_Poll ms after a poll for status is transmitted. Incorrect operation of polling will cause degradation of service, or possible service failure.

#### 7.2.3.22.2 ~~Conformance requirement~~

The timer is stopped when receiving a STATUS PDU that contains an acknowledgement of all AMD PDUs with SN up to and including VT(S)-1 at the time the poll was submitted to lower layer, or when a negative acknowledgement of the same PDU is received.

#### Reference

TS 25.322 clause 9.5.

#### 7.2.3.22.3 ~~Test purpose~~

1. ~~To verify that the Timer\_Poll timer is stopped when receiving a STATUS PDU that acknowledges all AMD PDUs with SN up to and including VT(S)-1 at the time the poll was transmitted.~~

#### 7.2.3.22.4 ~~Method of test~~

#### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

| Uplink RLC<br><del>— Polling info</del> | First run | Second run |
|-----------------------------------------|-----------|------------|
| <del>— Last transmission PDU poll</del> | FALSE     | FALSE      |
| <del>— Timer_poll</del>                 | 500       | 1000       |
| <del>— Timer_Poll_Periodic</del>        | 2000      | 2000       |

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to AM\_7\_PayloadSize – 1 bytes.

#### Test procedure

Let T be the value of the Timer\_Poll\_Periodic timer.

- a) The SS transmits at least  $2 * T / TTI$  SDUs of size AM\_7\_PayloadSize – 1 bytes.
- b) The SS receives PDUs from the UE, and notes the time on receiving the first PDU with the P bit set. This time will be recorded as  $T_1$ .
- c) The SS sends a STATUS PDU acknowledging all the PDUs up to and including the PDU carrying the poll request.
- d) The SS continues to receive PDUs from the UE and notes the time on receipt of the next PDU with the P bit set. This time will be recorded as  $T_2$ .

e) The SS may optionally release the radio bearer.

#### Expected sequence

| Step | Direction |    | Message          | Comments                                             |
|------|-----------|----|------------------|------------------------------------------------------|
|      | UE        | SS |                  |                                                      |
| 1    |           | ←  | DOWNLINK RLC PDU | SDU 1                                                |
| 2    |           | ←  | ...              | SS continues to transmit RLC SDUs                    |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU $\text{ceil}(2T/\text{TTI})$                     |
| 4    |           | →  | UPLINK RLC PDU   | SDU 1                                                |
| 5    |           | →  | UPLINK RLC PDU   | SDU 2                                                |
| 6    |           | →  | ...              | SS continues to receive RLC PDUs                     |
| 7    |           | →  | UPLINK RLC PDU   | SN = $\text{ceil}(T/\text{TTI})$ , Poll: Note $T_1$  |
| 8    |           | ←  | STATUS PDU       | ACK SN 0 to SN $\text{ceil}(T/\text{TTI})$           |
| 9    |           | →  | UPLINK RLC PDU   | SN = $\text{ceil}(T/\text{TTI})+1$                   |
| 10   |           | →  | ...              | SS continues to receive RLC PDUs                     |
| 11   |           | →  | UPLINK RLC PDU   | SN = $\text{ceil}(2T/\text{TTI})$ , Poll: Note $T_2$ |
| 12   |           |    | RB RELEASE       | Optional step                                        |

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

#### 7.2.3.22.5 Test requirements

For both execution runs, the measured time  $T_2 - T_1$  should be 2000 ms.

#### 7.2.3.23 Polling for status / Operation of Timer\_Poll timer / Restart of the Timer\_Poll timer

##### 7.2.3.23.1 Definition

This case tests that the UE will restart the Timer\_Poll timer if another poll request is transmitted whilst the timer is running. Incorrect operation of polling will cause degradation of service, or possible service failure.

This test applies to all UE.

##### 7.2.3.23.2 Conformance requirement

If a new poll is sent when the timer is running it is restarted, with a new value of  $VT(S)-1$ .

#### Reference

TS 25.322 clause 9.5.

##### 7.2.3.23.3 Test purpose

1. To verify that if a new poll is sent when the timer is running it is restarted.

##### 7.2.3.23.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                              |       |
|------------------------------|-------|
| Uplink RLC                   |       |
| — Polling info               |       |
| — Last transmission PDU poll | FALSE |
| — Timer_poll                 | 200   |
| — Poll_PDU                   | 8     |

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to AM\_7\_PayloadSize – 1 bytes.

### Test procedure

Let T be the value of the Timer\_Poll timer.

- The SS starts transmission of at least  $2 * \text{Poll\_PDU} + \text{ceil}(T / \text{TTI})$  numbers of SDUs of size AM\_7\_PayloadSize – 1 bytes.
- Whilst transmitting, the SS receives PDUs from the UE, and notes the time on receiving the third PDU with the P bit set. This time will be recorded as  $T_1$ .
- The SS sends a STATUS PDU acknowledging all the PDUs received so far.
- The SS continues to receive PDUs from the UE and notes the time on receipt of the next or fourth PDU with the P bit set. This time will be recorded as  $T_2$ .
- The SS may optionally release the radio bearer.

### Expected sequence

| Step | Direction |    | Message          | Comments                                                                                                       |
|------|-----------|----|------------------|----------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                  |                                                                                                                |
| 1    | ←         |    | DOWNLINK RLC PDU | SDU 1                                                                                                          |
| 2    | ←         |    | ...              | SS continues to transmit RLC SDUs                                                                              |
| 3    | ←         |    | DOWNLINK RLC PDU | $2 * \text{Poll\_PDU} + \text{ceil}(T / \text{TTI})$ numbers of SDUs are sent.                                 |
| 4    | →         |    | UPLINK RLC PDU   | SDU 1                                                                                                          |
| 5    | →         |    | UPLINK RLC PDU   | SDU 2                                                                                                          |
| 6    | →         |    | ...              | SS continues to receive RLC PDUs                                                                               |
| 7    | →         |    | UPLINK RLC PDU   | SN = poll_PDU – 1, 1 <sup>st</sup> Poll, Timer_Poll started                                                    |
| 8    | →         |    | ...              | SS continues to receive RLC PDUs                                                                               |
| 9    | →         |    | UPLINK RLC PDU   | SN = poll_PDU – 1 + $\text{ceil}(T / \text{TTI})$ , 2 <sup>nd</sup> Poll, Timer_Poll expired and again started |
| 10   | →         |    | UPLINK RLC PDU   | SS continues to receive RLC PDUs                                                                               |
| 11   | →         |    | UPLINK RLC PDU   | SN = $2 * \text{Poll\_PDU} - 1$ , 3 <sup>rd</sup> Poll, Timer_Poll restarted: Note T1                          |
| 12   | ←         |    | STATUS PDU       | ACK SN 0 to SN = $2 * \text{Poll\_PDU} - 1$                                                                    |
| 13   | →         |    | UPLINK RLC PDU   | SN = $2 * \text{Poll\_PDU}$                                                                                    |
| 14   | →         |    | ...              | SS continues to receive RLC PDUs                                                                               |
| 15   | →         |    | UPLINK RLC PDU   | SN = $2 * \text{Poll\_PDU} + \text{ceil}(T / \text{TTI}) - 1$ , 4th Poll, Timer_Poll expired: Note T2          |
| 16   |           |    | RB RELEASE       | Optional step                                                                                                  |

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.



### 7.2.3.23.5 ~~Test requirements~~

The measured time  $T_2 - T_1$  should be 200 ms.

## 7.2.3.24 ~~Polling for status / Operation of timer Timer\_Poll\_Prohibit~~

### 7.2.3.24.1 ~~Definition~~

This case tests that the UE will not send a poll request within Timer\_Poll\_Prohibit ms of a previous poll request when this mode of operation is enabled. Incorrect operation of polling will cause degradation of service, or possible service failure.

### 7.2.3.24.2 ~~Conformance requirement~~

This timer is only used when the poll prohibit function is used. It is used to prohibit transmission of polls within a certain period. The timer shall be started when the successful or unsuccessful transmission of a PDU containing a poll is indicated by lower layer (in UE) or a PDU containing a poll is submitted to lower layer (in UTRAN). The prohibit time is calculated from the time a PDU containing a poll is submitted to lower layer until the timer has expired. A poll shall be delayed until the prohibit time expires if a poll is triggered during the prohibit time. Only one poll shall be transmitted when the prohibit time expires even if several polls were triggered during the prohibit time. This timer will not be stopped by a received STATUS PDU.

The Polling bit shall be set to 1 if any of conditions in 3GPP TS 25.322 clause 11.3.2.1.1 are fulfilled except when the poll prohibit function is used and the timer Timer\_Poll\_Prohibit is active.

### Reference

TS 25.322 clauses 9.5 and 11.3.2.1.1.

### 7.2.3.24.3 ~~Test purpose~~

1. To verify that no poll is transmitted if one or several polls are triggered when the Timer\_Poll\_Prohibit timer is active and has not expired.
2. To verify that the UE polls only once after Timer\_Poll\_Prohibit expires even though triggered several times during the prohibit time.

### 7.2.3.24.4 ~~Method of test~~

### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                              |       |
|------------------------------|-------|
| Uplink RLC                   |       |
| — Polling info               |       |
| — Timer_poll_prohibit        | 500   |
| — Last transmission PDU poll | FALSE |
| — Poll_PU                    | 8     |
| — Poll_Window                | 50    |
| — Timer_poll_periodic        | 400   |
| — Transmission window size   | 32    |
| Downlink RLC                 |       |
| — Receiving window size      | 32    |

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to AM\_7\_PayloadSize – 1 bytes.

## Test procedure

Let  $T$  be the value of the `Timer_Poll_Prohibit` timer.

- a) The SS starts transmission of at least  $(2 \cdot \text{Poll\_PDU}) + \text{ceil}(T / \text{TTI})$  SDUs of size `AM_7_PayloadSize` – 1 bytes.
- b) Whilst transmitting, the SS receives PDUs from the UE, and notes the time on receiving the first PDU with the P bit set. This time will be recorded as  $T_1$ .
- c) The SS does not respond to the poll request.
- d) The SS continues to receive PDUs from the UE and notes the time on receipt of the next PDU with the P bit set. This time will be recorded as  $T_2$ .
- e) The SS may optionally release the radio bearer.

## Expected sequence

| Step | Direction |    | Message          | Comments                                                                            |
|------|-----------|----|------------------|-------------------------------------------------------------------------------------|
|      | UE        | SS |                  |                                                                                     |
| 1    |           | ←  | DOWNLINK RLC PDU | SDU 1                                                                               |
| 2    |           | ←  | ...              | SS continues to transmit RLC SDUs                                                   |
| 3    | ←         |    | DOWNLINK RLC PDU | SDU $(2 \cdot \text{Poll\_PDU}) + \text{ceil}(T / \text{TTI})$                      |
| 4    | →         |    | UPLINK RLC PDU   | SDU 1                                                                               |
| 5    | →         |    | UPLINK RLC PDU   | SDU 2                                                                               |
| 6    | →         |    | ...              | SS continues to receive RLC PDUs                                                    |
| 7    | →         |    | UPLINK RLC PDU   | $\text{SN} = \text{Poll\_PDU} - 1$ , Poll: Note $T_1$                               |
| 8    | →         |    | ...              | SS continues to receive RLC PDUs                                                    |
| 9    | →         |    | UPLINK RLC PDU   | $\text{SN} = \text{ceil}(\text{Timer\_poll\_periodic} / \text{TTI}) - 1$ , No Poll  |
| 10   | →         |    | UPLINK RLC PDU   | $\text{SN} = (\text{Transmission Window Size} / 2) - 1$ , No Poll                   |
| 11   | →         |    | ...              | SS continues to receive RLC PDUs                                                    |
| 12   | →         |    | UPLINK RLC PDU   | $\text{SN} = \text{Poll\_PDU} + \text{ceil}(T / \text{TTI}) - 1$ , Poll: Note $T_2$ |
| 13   |           |    | RB RELEASE       | Optional step                                                                       |

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

### 7.2.3.24.5 Test requirements

1. The measured time  $T_2 - T_1$  should be 500 ms.
2. Only one poll shall be received from the UE in step 12.
3. After step 12 no further poll shall be received from the UE for the next 500 ms.

### 7.2.3.25 Receiver Status Triggers / Detection of missing PDUs

#### 7.2.3.25.1 Definition

This case tests that the UE transmits a status report whenever it detects that a PDU is missing, if this mode of operation is enabled. Incorrect operation of status reporting will cause degradation of service, or possible service failure.

~~7.2.3.25.2 Conformance requirement~~

~~The receiver in any of following cases initiates this procedure ... Detection of missing PDUs is used and a missing PDU is detected.~~

~~Reference~~

~~TS 25.322 clause 11.5.2.~~

~~7.2.3.25.3 Test purpose~~

- ~~1. To verify that a status report is transmitted if there are one or more missing PDUs.~~

~~7.2.3.25.4 Method of test~~~~Initial conditions~~

~~The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.~~

~~These settings apply to both the uplink and downlink DTCH.~~

~~Test procedure~~

- ~~a) The SS transmits 7 SDUs, each of size AM\_7\_PayloadSize – 1 bytes, in PDUs with consecutive sequence numbers starting from 0, followed by 5 SDUs in PDUs with consecutive sequence numbers starting from 8, followed by an SDU in a PDU with a sequence number of 15.~~
- ~~b) While transmitting, the SS monitors the uplink for STATUS PDUs.~~
- ~~c) The SS may optionally release the radio bearer~~

~~Expected sequence~~

| Step | Direction |    | Message          | Comments                          |
|------|-----------|----|------------------|-----------------------------------|
|      | UE        | SS |                  |                                   |
| 1    |           | ←  | DOWNLINK RLC PDU | SN = 0                            |
| 2    |           | ←  | ...              | SS continues to transmit RLC SDUs |
| 3    |           | ←  | DOWNLINK RLC PDU | SN = 6                            |
| 4    |           | ←  | DOWNLINK RLC PDU | SN = 8                            |
| 5    |           | →  | STATUS PDU       |                                   |
| 6    |           | ←  | DOWNLINK RLC PDU |                                   |
| 7    |           | ←  | ...              | SS continues to receive RLC PDUs  |
| 8    |           | ←  | DOWNLINK RLC PDU | SN = 12                           |
| 9    |           | ←  | DOWNLINK RLC PDU | SN = 15                           |
| 10   |           | →  | STATUS PDU       |                                   |
| 11   |           |    | RB RELEASE       | Optional step                     |

~~7.2.3.25.5 Test requirements~~

~~A STATUS PDU should be received from the UE after step 4, indicating that the PDU with sequence number 7 was missing.~~

~~A STATUS PDU should be received from the UE after step 9, indicating that the PDUs with sequence numbers 7, 13 and 14 were missing.~~

### ~~7.2.3.26 Receiver Status Triggers / Operation of timer Timer\_Status\_Periodic~~

#### ~~7.2.3.26.1 Definition~~

~~This case tests that the UE transmits a status report every Timer\_Status\_Periodic ms when this mode of operation is enabled. Incorrect operation of status reporting will cause degradation of service, or possible service failure.~~

#### ~~7.2.3.26.2 Conformance requirement~~

~~The timer is started when the successful or unsuccessful transmission of the last STATUS PDU in a status report is indicated by lower layer.~~

~~The receiver in any of following cases initiates this procedure ... The timer based STATUS transfer is used and the timer Timer\_Status\_Periodic has expired.~~

#### ~~Reference~~

~~TS 25.322 clauses 9.5, 9.7.2 and 11.5.2.~~

#### ~~7.2.3.26.3 Test purpose~~

- ~~1. To verify that a status report is transmitted each time the Timer\_Status\_Periodic timer expires.~~

#### ~~7.2.3.26.4 Method of test~~

##### ~~Initial conditions~~

~~The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.~~

~~The following RLC parameter values are used in place of the values in clause 7.2.3.1:~~

|                                                   |                |
|---------------------------------------------------|----------------|
| <del>Downlink RLC<br/>Timer_STATUS_periodic</del> | <del>100</del> |
|---------------------------------------------------|----------------|

~~These settings apply to both the uplink and downlink DTCH.~~

##### ~~Test procedure~~

~~Let T be the value of the Timer\_STATUS\_periodic timer.~~

- ~~a) The SS starts transmission of at least  $\text{ceil}(2 * T / \text{TTI})$  SDUs of size AM\_7\_PayloadSize - 1 bytes.~~
- ~~b) The SS waits to receive a STATUS PDU and notes the time. This time will be recorded as T<sub>1</sub>.~~
- ~~c) The SS waits to receive a second STATUS PDU and notes the time. This time will be recorded as T<sub>2</sub>.~~
- ~~d) The SS may optionally release the radio bearer.~~

## Expected sequence

| Step | Direction |    | Message          | Comments                           |
|------|-----------|----|------------------|------------------------------------|
|      | UE        | SS |                  |                                    |
| 1    |           | ←  | DOWNLINK RLC PDU | SDU 1                              |
| 2    |           | ←  | ...              | SS continues to transmit RLC SDUs  |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU $\text{ceil}(T/\text{TTI})-1$  |
| 4    |           | →  | STATUS PDU       | Note T <sub>1</sub>                |
| 5    |           | ←  | DOWNLINK RLC PDU |                                    |
| 6    |           | ←  | ...              | SS continues to receive RLC PDUs   |
| 7    |           | ←  | DOWNLINK RLC PDU | SDU $\text{ceil}(2T/\text{TTI})-1$ |
| 8    |           | →  | STATUS PDU       | Note T <sub>2</sub>                |
| 9    |           |    | RB RELEASE       | Optional step                      |

## 7.2.3.26.5 Test requirements

The measured time  $T_2 - T_1$  should be 100 ms.

## 7.2.3.27 Receiver Status Triggers / Operation of timer Timer\_Status\_Prohibit

## 7.2.3.27.1 Definition

This case tests that the UE transmits a status report every Timer\_Status\_Prohibit ms when this mode of operation is enabled. Incorrect operation of status reporting will cause degradation of service, or possible service failure.

## 7.2.3.27.2 Conformance requirement

The sending of a status report shall be delayed, if ... STATUS prohibit is used and the timer Timer\_Status\_Prohibit is active.

The status report shall be transmitted after the Timer\_Status\_Prohibit has expired. The receiver shall send only one status report, even if there are several triggers when the timer is active. The rules for when the timer Timer\_status\_Prohibit is active are defined in 3GPP TS 25.322 clause 9.5.

## Reference

TS 25.322 clause 11.5.2.

## 7.2.3.27.3 Test purpose

1. To verify that a status report is not transmitted while the Timer\_Status\_Prohibit timer is active.
2. To verify that only one status report is sent on the expiry of the Timer\_Status\_Prohibit timer if several triggers occur while it is active.

## 7.2.3.27.4 Method of test

## Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                        |     |
|------------------------|-----|
| Downlink RLC           |     |
| —Timer_Status_Prohibit | 500 |
| —Timer_STATUS_periodic | 200 |

These settings apply to both the uplink and downlink DTCH.

#### Test procedure

Let  $T_{pro}$  be the value of the Timer\_Status\_Prohibit timer, and  $T_{per}$  be the value of the Timer\_Status\_Periodic timer.

- The SS starts transmission of at least  $\text{ceil}(2 * T_{pro} / TTI) + \text{ceil}(T_{per} / TTI)$  SDUs of size  $AM\_7\_PayloadSize - 1$  bytes.
- Whilst transmitting, the SS monitors the uplink for a STATUS PDU and notes the time. This time will be recorded as  $T_1$ .
- The SS sets the P bit in a downlink PDU transmitted within the next  $\text{floor}(T_{pro} / TTI)$  PDUs.
- The SS waits to receive a second STATUS PDU and notes the time. This time will be recorded as  $T_2$ .
- The SS may optionally release the radio bearer.

#### Expected sequence

| Step | Direction |    | Message          | Comments                                                      |
|------|-----------|----|------------------|---------------------------------------------------------------|
|      | UE        | SS |                  |                                                               |
| 1    |           | ←  | DOWNLINK RLC PDU | SDU 1                                                         |
| 2    |           | ←  | ...              | SS continues to transmit RLC SDUs                             |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU $\text{ceil}(T_{per} / TTI)$                              |
| 4    |           | →  | STATUS PDU       | Note $T_1$                                                    |
| 5    |           | ←  | DOWNLINK RLC PDU | Poll                                                          |
| 6    |           | ←  | ...              | SS continues to transmit RLC PDUs                             |
| 7    |           | ←  | DOWNLINK RLC PDU | SDU $\text{ceil}(T_{pro} / TTI) + \text{ceil}(T_{per} / TTI)$ |
| 8    |           | →  | STATUS PDU       | Note $T_2$                                                    |
| 9    |           |    | RB RELEASE       | Optional step                                                 |

#### 7.2.3.27.5 Test requirements

- The measured time  $T_2 - T_1$  should be 500 ms.
- Only one STATUS PDU shall be received in step 8, after Timer\_Status\_Prohibit expiry.

#### 7.2.3.28 Status reporting / Abnormal conditions / Reception of LIST SUFI with Length set to zero

##### 7.2.3.28.1 Definition

Peer RLCs use STATUS PDUs to manage flow control and retransmission. On a STATUS report PDU with an invalid LIST SUFI the RLC must behave as specified. Incorrect behaviour may result in degradation of QoS, or failure of the UE to communicate.

##### 7.2.3.28.2 Conformance requirement

The LENGTH field of the LIST SUFI is defined as:

The number of  $(SN_i, L_i)$  pairs in the super-field of type LIST. The value "0000" is invalid and the list is discarded.

## Reference

TS 25.322 clause 9.2.2.11.4.

### 7.2.3.28.3 ~~Test purpose~~

To verify that if a STATUS PDU is received with a LIST SUFI and the LENGTH field is set to "0000" that the list is discarded.

### 7.2.3.28.4 ~~Method of test~~

#### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                           |    |
|---------------------------|----|
| Uplink RLC                |    |
| <del>— Polling info</del> |    |
| <del>— Poll_PDU</del>     | 84 |

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to  $(2 * \text{Poll\_PDU} * \text{AM\_7\_PayloadSize}) - 1$  bytes.

#### Test procedure

- ~~The SS sends an SDU of size  $(2 * \text{Poll\_PDU} * \text{AM\_7\_PayloadSize}) - 1$ .~~
- ~~The SS monitors the received (looped back) PDUs for a poll request.~~
- ~~The SS responds to the poll request by transmitting a STATUS PDU with a LIST SUFI. The list contains an indication that two PDUs were not received, but has the length field set to "0000".~~
- ~~The SS continues to monitor the received PDUs to verify that none are retransmitted.~~
- ~~The SS may optionally release the radio bearer.~~

## Expected sequence

| Step                                                                                       | Direction |    | Message          | Comments                              |
|--------------------------------------------------------------------------------------------|-----------|----|------------------|---------------------------------------|
|                                                                                            | UE        | SS |                  |                                       |
| 1                                                                                          | ←         |    | DOWNLINK RLC PDU | SDU 1 (start)                         |
| 2                                                                                          | ←         |    | ...              | SS continues to transmit RLC PDUs     |
| 3                                                                                          | ←         |    | DOWNLINK RLC PDU | SDU 1 (end)                           |
| 4                                                                                          | →         |    | UPLINK RLC PDU   | SDU 1 (start)                         |
| 5                                                                                          | →         |    | UPLINK RLC PDU   |                                       |
| 6                                                                                          | →         |    | ...              | SS continues to receive RLC PDUs      |
| 7                                                                                          | →         |    | UPLINK RLC PDU   | SN = Poll_PDU - 1, Poll               |
| 8                                                                                          | ←         |    | STATUS PDU       | LIST(LENGTH = "0000", SN = 1, SN = 2) |
| 9                                                                                          | →         |    | ...              | SS continues to receive RLC PDUs      |
| 10                                                                                         | →         |    | UPLINK RLC PDU   | Poll                                  |
| 11                                                                                         | ←         |    | STATUS PDU       | Normal reply                          |
| 12                                                                                         | →         |    | ...              | SS continues to receive RLC PDUs      |
| 13                                                                                         | →         |    | UPLINK RLC PDU   | SDU 1 (end)                           |
| 14                                                                                         |           |    | RB RELEASE       | Optional step                         |
| NOTE: — The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity. |           |    |                  |                                       |

## 7.2.3.28.5 — Test requirements

No RLC PDUs should be retransmitted by the UE.

## 7.2.3.29 — Timer based discard, with explicit signalling / Expiry of Timer\_Discard

## 7.2.3.29.1 — Definition

This case tests that when the transmission of an SDU exceeds a time limit, the SDU is discarded by the sender, and the discard is signalled to the receiver. SDU discard is used to keep network delays within limits, and incorrect operation will effect the quality of service.

## 7.2.3.29.2 — Conformance requirement

If the transmission time exceeds a predefined value for a SDU in acknowledged mode RLC, this SDU is discarded in the transmitter and a Move Receiving Window (MRW) command is sent to the receiver so that AMD PDUs carrying that SDU are discarded in the receiver and the receiver window is updated accordingly.

This procedure is initiated by the sender when the following conditions are fulfilled ... Timer based SDU discard with explicit signalling is used, and Timer\_Discard expires for an SDU.

This status report is sent even if the 'STATUS prohibit' is used and the timer 'Timer\_Status\_Prohibit' is active.

The STATUS PDUs have higher priority than data PDUs.

## Reference

TS 25.322 clauses 9.7.3.1, 11.3.4.3.1 and 11.6.

## 7.2.3.29.3 — Test purpose

1. To verify that if the transmission time for an SDU exceeds Timer\_Discard, the SDU is discarded in the transmitter and the MRW procedure is invoked.
2. ...



#### 7.2.3.29.4 Method of test

##### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                                       |      |
|---------------------------------------|------|
| Uplink RLC                            |      |
| —Transmission RLC discard             |      |
| —Timer based with explicit signalling |      |
| —Timer_Discard                        | 1000 |

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to AM\_7\_PayloadSize—1 bytes.

##### Test procedure

- The SS sends at least 2 RLC SDUs of size AM\_7\_PayloadSize—1 bytes.
- The SS notes the time that the first RLC PDU is received on the uplink. This time will be recorded as  $T_1$ .
- The SS checks the RLC PDUs received on the uplink and responds to all poll requests with a STATUS PDU, negatively acknowledging the RLC PDU with sequence number 0, and positively acknowledging all other RLC PDUs received.
- The SS monitors received STATUS PDUs for the presence of a MRW-SUFI, noting the time it was received. This time will be recorded as  $T_2$ .
- The SS responds to the MRW command with a correct MRW-ACK.
- Void.
- The SS may optionally release the radio bearer.

##### Expected sequence

| Step | Direction |    | Message          | Comments                                         |
|------|-----------|----|------------------|--------------------------------------------------|
|      | UE        | SS |                  |                                                  |
| 1    |           | ←  | DOWNLINK RLC PDU | SDU 1                                            |
| 2    |           | ←  | DOWNLINK RLC PDU | SDU 2                                            |
| 3    |           | →  | UPLINK RLC PDU   | SDU 1: Note $T_1$                                |
| 4    |           | →  | ...              | SS continues to receive RLC PDUs                 |
| 5    |           | →  | UPLINK RLC PDU   | SDU 2 + Poll                                     |
| 6    |           | ←  | STATUS PDU       | NAK SN=0                                         |
| 7    |           | →  | ...              | SS continues to receive RLC PDU with SN=0 + Poll |
| 8    |           | ←  | ...              | STATUS PDU, SS continues to NAK PDU with SN=0    |
| 9    |           | →  | STATUS PDU       | MRW Command: Note $T_2$                          |
| 10   |           | ←  | STATUS PDU       | MRW-ACK                                          |
| 11   |           |    | RB RELEASE       | Optional step                                    |

#### 7.2.3.29.5 Test requirements

- The measured time  $T_2 - T_1$  should be 1000 ms.

2. The STATUS PDU received in step 9 shall contain a MRW-SUFI indicating that the first three PDUs should be discarded, and that the data indicated in the fourth PDU by the first LI should also be discarded.

### ~~7.2.3.29a~~ ~~Timer based discard, with explicit signalling / Expiry of Timer\_Discard when Timer\_STATUS\_prohibit is active~~

#### ~~7.2.3.29a.1~~ ~~Definition~~

~~This case tests that when the transmission of an SDU exceeds a time limit, the SDU is discarded by the sender, and the discard is signalled to the receiver while the Timer\_STATUS-Prohibit is active. SDU discard is used to keep network delays within limits, and incorrect operation will effect the quality of service.~~

~~This test applies to all UE.~~

#### ~~7.2.3.29a.2~~ ~~Conformance requirement~~

~~If the transmission time exceeds a predefined value for a SDU in acknowledged mode RLC, this SDU is discarded in the transmitter and a Move-Receiving Window (MRW) command is sent to the receiver so that AMD-PDUs carrying that SDU are discarded in the receiver and the receiver window is updated accordingly.~~

~~Upon expiry of Timer\_Discard the sender shall initiate the SDU discard with explicit signalling procedure.~~

~~This status report is sent even if the 'STATUS-prohibit' is used and the timer 'Timer\_Status-Prohibit' is active.~~

~~The STATUS PDUs have higher priority than data PDUs.~~

#### ~~Reference~~

~~TS 25.322 clauses 9.7.3.1, 11.3.4.3.1 and 11.6.~~

#### ~~7.2.3.29a.3~~ ~~Test purpose~~

~~1....~~

- ~~2. To verify that the MRW procedure status report is sent even if the 'STATUS-prohibit' is used and the timer 'Timer\_Status-Prohibit' is active.~~

#### ~~7.2.3.29a.4~~ ~~Method of test~~

~~TBD~~

#### ~~7.2.3.29a.5~~ ~~Test requirements~~

~~TBD~~

### ~~7.2.3.30~~ ~~Timer based discard, with explicit signalling / Obsolete MRW\_ACK~~

#### ~~7.2.3.30.1~~ ~~Definition~~

~~This case tests the ability of the receiving AM-RLC entity to handle obsolete information that can be received during a failure of the SDU discard procedure. SDU discard is used to keep network delays within limits, and incorrect operation will effect the quality of service.~~

#### ~~7.2.3.30.2~~ ~~Conformance requirement~~

~~If Timer\_MRW expires before the discard procedure is terminated, the MRW-SUFI shall be retransmitted, VT(MRW) is incremented by one and Timer\_MRW restarted. MRW-SUFI shall be exactly the same as previously transmitted even though some new SDUs would have been discarded during the running of the Timer\_MRW.~~

~~The received MRW\_ACK shall be discarded in the following cases:~~

1. ~~...~~
2. ~~If the SN\_ACK field in the received MRW\_ACK < SN\_MRW\_LENGTH in the transmitted MRW SUFI.~~
3. ~~If the SN\_ACK field in the received MRW\_ACK is equal to the SN\_MRW\_LENGTH in the transmitted MRW SUFI and the N field in the received MRW\_ACK is not equal to the N\_LENGTH field in the transmitted MRW SUFI~~
4. ~~If the SN\_ACK field in the received MRW\_ACK > SN\_MRW\_LENGTH in the transmitted MRW SUFI and the N field in the received MRW\_ACK is not equal to zero.~~

## Reference

TS 25.322 clauses 11.6.5 and 11.6.6.3.

### 7.2.3.30.3 ~~Test purpose~~

1. ~~To verify that the MRW SUFI is retransmitted if Timer\_MRW expires before a valid MRW\_ACK is received.~~
2. ~~To verify that the MRW\_ACK is discarded if the SN\_ACK field < SN\_MRW\_LENGTH.~~
3. ~~To verify that the MRW\_ACK is discarded if the N field is not equal to N\_LENGTH transmitted in the MRW SUFI.~~
4. ~~To verify that the MRW\_ACK is discarded if the N field is not zero and the SN\_ACK field > SN\_MRW\_LENGTH in the transmitted MRW SUFI.~~

### 7.2.3.30.4 ~~Method of test~~

#### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                                                  |      |
|--------------------------------------------------|------|
| Uplink RLC                                       |      |
| <del>—Transmission RLC discard</del>             |      |
| <del>—MaxDAT Retransmissions</del>               |      |
| <del>—MaxDAT</del>                               | 40   |
| <del>—Timer based with explicit signalling</del> |      |
| <del>—Timer_MRW</del>                            | 500  |
| <del>—Timer_Discard</del>                        | 1000 |
| <del>—MaxMRW</del>                               | 4    |

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to AM\_7\_PayloadSize — 1 bytes.

#### Test procedure

- a) ~~The SS sends at least 2 RLC SDUs of size AM\_7\_PayloadSize — 1 bytes.~~
- b) ~~The SS checks the RLC PDUs received on the uplink and responds to all poll requests with a STATUS PDU, negatively acknowledging the RLC PDU with sequence number 0, and positively acknowledging all other RLC PDUs received.~~
- c) ~~The SS monitors received STATUS PDUs for the presence of a MRW SUFI, noting the time it was received. This time will be recorded as T<sub>1</sub>.~~
- d) ~~The SS responds to the MRW command with an MRW\_ACK with the SN\_ACK field set to SN\_MRW\_LENGTH — 1.~~
- e) ~~The SS monitors received STATUS PDUs for another MRW SUFI, noting the time it was received. This time will be recorded as T<sub>2</sub>.~~

- f) The SS responds to the MRW command with an MRW\_ACK with the SN\_ACK field set to SN\_MRW<sub>LENGTH</sub> and the N field set to (N<sub>LENGTH</sub> + 1) modulo 4.
- g) The SS monitors received STATUS PDUs for another MRW SUFI, noting the time it was received. This time will be recorded as T<sub>3</sub>.
- h) The SS responds to the MRW command with an MRW\_ACK with the SN\_ACK field set to SN\_MRW<sub>LENGTH</sub> + 1, and the N field set to 1.
- i) The SS monitors received STATUS PDUs for another MRW SUFI.
- j) The SS responds to the MRW command with a correct MRW\_ACK.
- k) The SS may optionally release the radio bearer.

#### Expected sequence

| Step | Direction |    | Message          | Comments                                                    |
|------|-----------|----|------------------|-------------------------------------------------------------|
|      | UE        | SS |                  |                                                             |
| 1    | ←         |    | DOWNLINK RLC PDU | SDU 1                                                       |
| 2    | ←         |    | DOWNLINK RLC PDU | SDU 2                                                       |
| 3    | →         |    | UPLINK RLC PDU   | SDU 1                                                       |
| 4    | →         |    | UPLINK RLC PDU   | SDU 2 + Poll                                                |
| 5    | ←         |    | STATUS PDU       | NAK SN=0                                                    |
| 6    | →         |    | ...              | SS continues to receive RLC PDU with SN=0 + Poll            |
| 7    | ←         |    | ...              | STATUS PDU, SS continues to NAK PDU with SN=0               |
| 8    | →         |    | STATUS PDU       | MRW Command: Note T <sub>1</sub>                            |
| 9    | ←         |    | STATUS PDU       | MRW_ACK, SN_ACK = SN_MRW <sub>LENGTH</sub> - 1              |
| 10   | →         |    | STATUS PDU       | MRW Command: Note T <sub>2</sub>                            |
| 11   | ←         |    | STATUS PDU       | MRW_ACK, N field = (N <sub>LENGTH</sub> + 1) modulo 4       |
| 12   | →         |    | STATUS PDU       | MRW Command: Note T <sub>3</sub>                            |
| 13   | ←         |    | STATUS PDU       | MRW_ACK, SN_ACK = SN_MRW <sub>LENGTH</sub> + 1, N field = 1 |
| 14   | →         |    | STATUS PDU       | MRW Command                                                 |
| 15   | ←         |    | STATUS PDU       | MRW_ACK                                                     |
| 16   |           |    | RB RELEASE       | Optional step                                               |

#### 7.2.3.30.5 Test requirements

1. The measured time T<sub>2</sub> - T<sub>1</sub> should be 500 ms.
2. The measured time T<sub>3</sub> - T<sub>2</sub> should be 500 ms.
3. The STATUS PDUs received in steps 8, 10, 12 and 14 shall contain an identical MRW SUFI.

#### 7.2.3.31 Timer based discard, with explicit signalling / Failure of MRW procedure

##### 7.2.3.31.1 Definition

This case tests that if a failure occurs during the signalling of an SDU discard to the receiver, the retransmission protocol operates correctly. SDU discard is used to keep network delays within limits, and incorrect operation will effect the quality of service.

##### 7.2.3.31.2 Conformance requirement

If the number of retransmission of a MRW command (i.e. VT(MRW)) reaches MaxMRW, an error indication shall be passed to RRC and RESET procedure shall be performed.

## Reference

TS 25.322 clause 11.6.6.2.

### 7.2.3.31.3 Test purpose

1. To verify that when the number of retransmissions of a MRW command reaches MaxMRW, an error indication is passed to RRC and RESET procedure is initiated.

### 7.2.3.31.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                                                                                                 |              |
|-------------------------------------------------------------------------------------------------|--------------|
| Uplink RLC                                                                                      |              |
| — Transmission RLC discard                                                                      |              |
| — MaxDAT Retransmissions                                                                        |              |
| — MaxDAT                                                                                        | 40, See Note |
| — Timer based with explicit signalling                                                          |              |
| — Timer_MRW                                                                                     | 500          |
| — Timer_Discard                                                                                 | 500          |
| — MaxMRW                                                                                        | 4            |
| — Polling info                                                                                  |              |
| — Poll_PDU                                                                                      | 2            |
| Note: — MaxDat is set to 40 to avoid SDU discard during the test due to $VT(DAT) \geq MaxDAT$ . |              |

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to  $(2 * AM\_7\_PayloadSize) - 1$  bytes.

#### Test procedure

- a) The SS sends 4 RLC SDUs of size  $(2 * AM\_7\_PayloadSize) - 1$  bytes.
- b) The SS checks the RLC PDUs received on the uplink and responds to all poll requests as follows: While the VR(H) is 4 or less, with a STATUS PDU, negatively acknowledging the RLC PDU with sequence number 0, and positively acknowledging all other RLC PDUs received. While the VR(H) is greater than 4, a STATUS PDU negatively acknowledging RLC PDUs with sequence numbers 0 and 4, and positively acknowledging all others.
- c) The SS monitors received STATUS PDUs for the presence of an MRW SUFI, noting the time it was received. This time will be recorded as  $T_1$ .
- d) The SS makes no response, but monitors for the next STATUS PDU containing an MRW SUFI, noting the time it was received. This time will be recorded as  $T_2$ .
- e) The SS sends a STATUS PDU with an MRW\_ACK indicating the discard of SDU 1 moving VR(R) to 4.
- f) The SS monitors for further STATUS PDUs containing an MRW SUFI, or for a RESET PDU. The SS records the number of STATUS PDUs it received with MRW SUFI before it received the RESET PDU.
- g) The SS checks any RLC SDUs reassembled from the uplink.
- h) The SS may optionally release the radio bearer.

## Expected sequence

| Step | Direction |    | Message          | Comments                         |
|------|-----------|----|------------------|----------------------------------|
|      | UE        | SS |                  |                                  |
| 1    | ←         |    | DOWNLINK RLC PDU | SDU 1                            |
| 2    | ←         |    | DOWNLINK RLC PDU | SDU 1                            |
| 3    | ←         |    | DOWNLINK RLC PDU | SDU 2                            |
| 4    | ←         |    | ...              | SS continues to send RLC PDUs    |
| 5    | ←         |    | DOWNLINK RLC PDU | SDU 4                            |
| 6    | →         |    | UPLINK RLC PDU   | SDU 1                            |
| 7    | →         |    | ...              | SS continues to receive RLC PDUs |
| 8    | →         |    | UPLINK RLC PDU   | Poll                             |
| 9    | ←         |    | STATUS PDU       | NAK SN=0                         |
| 10   | →         |    | ...              | SS continues to receive RLC PDUs |
| 11   | →         |    | UPLINK RLC PDU   | Poll                             |
| 12   | ←         |    | STATUS PDU       | NAK SN=0, 4                      |
| 13   | →         |    | ...              | SS continues to receive RLC PDUs |
| 14   | →         |    | STATUS PDU       | MRW Command: Note T <sub>1</sub> |
| 15   | →         |    | STATUS PDU       | MRW Command: Note T <sub>2</sub> |
| 16   | ←         |    | STATUS PDU       | MRW_ACK indicating VR(R) = 4     |
| 17   | →         |    | STATUS PDU       | MRW Command, discard SDU 3       |
| 18   | →         |    | STATUS PDU       | MRW Command                      |
| 19   | →         |    | STATUS PDU       | MRW Command                      |
| 20   | →         |    | STATUS PDU       | MRW Command                      |
| 21   | →         |    | RESET PDU        |                                  |
| 22   | ←         |    | RESET ACK PDU    |                                  |
| 23   |           |    | RB RELEASE       | Optional step                    |

The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

## 7.2.3.31.5 — Test requirements

The measured time T<sub>2</sub>—T<sub>4</sub> should be 500 ms.

After step 17, the SS should detect 3 repeats of the MRW command sent in step 17 before a RESET PDU is sent.

## 7.2.3.32 — SDU discard after MaxDAT number of retransmissions

## 7.2.3.32.1 — Definition

This case tests that if a PDU is unsuccessfully transmitted MaxDAT times, the SDU it carries, and therefore all other associated PDUs, are discarded by the transmitter and receiver. This mode of SDU discard is used to minimize data loss, and incorrect operation will effect the quality of service.

## 7.2.3.32.2 — Conformance requirement

There is one VT(DAT) for each PDU and it is incremented each time the PDU is transmitted. The initial value of this variable is 0.

If SDU discard after MaxDAT number of retransmission is used and VT(DAT) ≥ MaxDAT for any PDU, the sender shall initiate the SDU discard with explicit signalling procedure for the SDUs to which the PDU with VT(DAT) ≥ MaxDAT belongs.

## Reference

TS 25.322 clauses 9.4 and 11.3.4.4.

### 7.2.3.32.3 Test purpose

1. To verify that if  $VT(DAT) \geq MaxDAT$  for any PDU the sender initiates the SDU discard with explicit signalling procedure.

### 7.2.3.32.4 Method of test

#### Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

These settings apply to both the uplink and downlink DTCH.

The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to  $(2 * AM\_7\_PayloadSize) - 1$  bytes.

#### Test procedure

- a) The SS sends 2 RLC SDUs of size  $(2 * AM\_7\_PayloadSize) - 1$  bytes.
- b) The SS checks the RLC PDUs received on the uplink and responds to all poll requests with a STATUS PDU negatively acknowledging the RLC PDU with sequence number 0, and positively acknowledging all other RLC PDUs received.
- c) The SS monitors received STATUS PDUs for the presence of an MRW-SUFI.
- d) The SS responds with a STATUS PDU containing a valid MRW-ACK-SUFI.
- e) The SS checks any RLC SDUs reassembled from the uplink.
- f) The SS may optionally release the radio bearer.

#### Expected sequence

| Step | Direction |    | Message          | Comments                         |
|------|-----------|----|------------------|----------------------------------|
|      | UE        | SS |                  |                                  |
| 1    |           | ←  | DOWNLINK RLC PDU | SDU 1                            |
| 2    |           | ←  | DOWNLINK RLC PDU | SDU 1                            |
| 3    |           | ←  | DOWNLINK RLC PDU | SDU 2                            |
| 4    |           | ←  | DOWNLINK RLC PDU | SDU 2                            |
| 5    |           | →  | UPLINK RLC PDU   | SDU 1                            |
| 6    |           | →  | ...              | SS continues to receive RLC PDUs |
| 7    |           | →  | UPLINK RLC PDU   | SDU 2, Poll                      |
| 8    |           | ←  | STATUS PDU       | NAK SN=0                         |
| 9    |           | →  | UPLINK RLC PDU   | Retransmit SN=0, Poll            |
| 10   |           | ←  | STATUS PDU       | NAK SN=0                         |
| 11   |           | →  | UPLINK RLC PDU   | Retransmit SN=0, Poll            |
| 12   |           | ←  | STATUS PDU       | NAK SN=0                         |
| 13   |           | →  | UPLINK RLC PDU   | Retransmit SN=0, Poll            |
| 14   |           | ←  | STATUS PDU       | NAK SN=0                         |
| 15   |           | →  | STATUS PDU       | MRW Command                      |
| 16   |           | ←  | STATUS PDU       | MRW-ACK                          |
| 17   |           |    | RB RELEASE       | Optional step                    |

NOTE: The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

### 7.2.3.32.5 Test requirements

The uplink RLC PDU with sequence number 0 shall be retransmitted three times, then the SS shall detect a STATUS PDU with an MRW command.

### ~~7.2.3.33 Operation of the RLC Reset procedure / UE Originated~~

#### ~~7.2.3.33.1 Definition~~

~~This case tests that when an unrecoverable protocol error occurs the UE will initiate and perform the RLC Reset procedure. Incorrect operation of this procedure may cause loss of service.~~

#### ~~7.2.3.33.2 Conformance requirement~~

~~The procedure shall be initiated when a protocol error occurs.~~

~~The sender sends the RESET PDU when it is in data transfer ready state and enters reset pending state. The sender shall start the timer Timer\_RST and increase VT(RST) with 1.~~

~~The RSN field shall indicate the sequence number of the RESET PDU. This sequence number is incremented every time a new RESET PDU is transmitted, but not when a RESET PDU is retransmitted.~~

~~Upon reception of a RESET PDU the receiver shall respond with a RESET ACK PDU. The receiver resets the state variables to their initial value and resets configurable parameters to their configured value. Both the transmitter and receiver side of the AM RLC entity are reset. All RLC PDUs in the AM RLC receiver shall be discarded. The RLC SDUs in the AM RLC transmitter that were transmitted before the reset shall be discarded.~~

~~When a RESET PDU is received, the receiver shall set the HFN (DL HFN when the RESET is received in UE or UL HFN when the RESET is received in UTRAN) equal to the HFNI field in the received RESET PDU.~~

~~Upon reception of a RESET ACK the Timer\_RST shall be stopped. The sender resets the state variables to their initial value and resets configurable parameters to their configured value. The sender shall enter data transfer ready state.~~

~~Upon expiry of Timer\_RST the sender shall retransmit the RESET PDU and increase VT(RST) with 1.~~

~~If VT(RST) becomes larger or equal to MaxRST the RRC layer shall be informed.~~

#### ~~Reference~~

~~TS 25.322 clause 11.4.~~

#### ~~7.2.3.33.3 Test purpose~~

- ~~1. To verify that the Reset procedure is initiated when a protocol error occurs.~~
- ~~2. To verify that the sender resets state variables to their initial value and resets configurable parameters to their configured value.~~
- ~~3. To verify that RSN is updated correctly.~~
- ~~4. To verify operation of Timer\_RST.~~

#### ~~7.2.3.33.4 Method of test~~

##### ~~Initial conditions~~

~~The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.~~

~~The following RLC parameter values are used in place of the values in clause 7.2.3.1:~~

|                                                        |  |
|--------------------------------------------------------|--|
| Uplink RLC<br>—Transmission RLC discard<br>—No discard |  |
|--------------------------------------------------------|--|

~~These settings apply to both the uplink and downlink DTCH.~~



The Radio Bearer is placed in UE test loop mode 1 with the UL SDU size set to  $(2 * AM\_7\_PayloadSize) - 1$  bytes.

#### Test procedure

- a) ~~The SS sends 2 RLC SDUs of size  $(2 * AM\_7\_PayloadSize) - 1$  bytes.~~
- b) ~~The SS checks the RLC PDUs received on the uplink and responds to all poll requests with a STATUS PDU negatively acknowledging the RLC PDU with sequence number 0, and positively acknowledging all other RLC PDUs received.~~
- c) ~~The SS notes the time that the RESET PDU is received. This time will be recorded as  $T_1$ . The SS notes the value of the RSN bit.~~
- d) ~~The SS makes no response, and notes the time that the next RESET PDU is received. This time will be recorded as  $T_2$ . The SS notes the value of the RSN bit.~~
- e) ~~The SS sends a RESET ACK PDU with the RSN bit set to the same value as received in the RESET PDU received in step d).~~
- f) ~~The SS sends an RLC SDU of size  $(2 * AM\_7\_PayloadSize) - 1$  bytes.~~
- g) ~~The SS checks the RLC PDUs received on the uplink and responds to all poll requests with a STATUS PDU negatively acknowledging the RLC PDU with sequence number 0, and positively acknowledging all other RLC PDUs received.~~
- h) ~~The SS notes the value of the RSN bit of the RESET PDU received.~~
- i) ~~The SS sends a RESET ACK PDU with the RSN bit set to the value received in the RESET PDU in step c (the incorrect value).~~
- j) ~~The SS waits to receive another RESET PDU and checks the RSN bit.~~
- k) ~~The SS sends a RESET ACK PDU with the correct RSN bit.~~
- l) ~~The SS checks any RLC SDU received on the uplink.~~
- m) ~~The SS may optionally release the radio bearer.~~

## Expected sequence

| Step | Direction |    | Message          | Comments                         |
|------|-----------|----|------------------|----------------------------------|
|      | UE        | SS |                  |                                  |
| 1    | ←         |    | DOWNLINK RLC PDU | SDU 1                            |
| 2    | ←         |    | DOWNLINK RLC PDU | SDU 1                            |
| 3    | ←         |    | DOWNLINK RLC PDU | SDU 2                            |
| 4    | ←         |    | DOWNLINK RLC PDU | SDU 2                            |
| 5    | →         |    | UPLINK RLC PDU   | SDU 1                            |
| 6    | →         |    | ...              | SS continues to receive RLC PDUs |
| 7    | →         |    | UPLINK RLC PDU   | SDU 2, Poll                      |
| 8    | ←         |    | STATUS PDU       | NAK SN=0                         |
| 9    | →         |    | UPLINK RLC PDU   | Retransmit SN=0, Poll            |
| 10   | ←         |    | STATUS PDU       | NAK SN=0                         |
| 11   | →         |    | UPLINK RLC PDU   | Retransmit SN=0, Poll            |
| 12   | ←         |    | STATUS PDU       | NAK SN=0                         |
| 13   | →         |    | UPLINK RLC PDU   | Retransmit SN=0, Poll            |
| 14   | ←         |    | STATUS PDU       | NAK SN=0                         |
| 15   | →         |    | RESET PDU        | Note T <sub>1</sub>              |
| 16   | →         |    | RESET PDU        | Note T <sub>2</sub> , check RSN  |
| 17   | ←         |    | RESET ACK PDU    |                                  |
| 18   | ←         |    | DOWNLINK RLC PDU | SDU 3                            |
| 19   | ←         |    | DOWNLINK RLC PDU | SDU 3                            |
| 20   | →         |    | UPLINK RLC PDU   | SDU 3, SN=0                      |
| 21   | →         |    | UPLINK RLC PDU   | SDU 3, Poll                      |
| 22   | ←         |    | STATUS PDU       | NAK SN=0                         |
| 23   | →         |    | UPLINK RLC PDU   | Retransmit SN=0, Poll            |
| 24   | ←         |    | STATUS PDU       | NAK SN=0                         |
| 25   | →         |    | UPLINK RLC PDU   | Retransmit SN=0, Poll            |
| 26   | ←         |    | STATUS PDU       | NAK SN=0                         |
| 27   | →         |    | UPLINK RLC PDU   | Retransmit SN=0, Poll            |
| 28   | ←         |    | STATUS PDU       | NAK SN=0                         |
| 29   | →         |    | RESET PDU        | Check RSN                        |
| 30   | ←         |    | RESET ACK PDU    | RSN = 0                          |
| 31   | →         |    | RESET PDU        | Check RSN                        |
| 32   | ←         |    | RESET ACK PDU    | RSN = 1                          |
| 33   |           |    | RB RELEASE       | Optional step                    |

NOTE: — The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity.

## 7.2.3.33.5 — Test requirements

1. The measured time  $T_2 - T_1$  should be 500 ms.
2. In steps 20 to 21 the SS shall receive an RLC SDU with contents that match the third RLC SDU sent to the UE. The first RLC PDU containing that SDU shall have sequence number 0.
3. The RSN bit of the first and second RESET PDUs received should be set to 0. The RSN bit of the third and fourth RESET PDU should be set to 1.

## 7.2.3.34 — Operation of the RLC Reset procedure / UE Terminated

## 7.2.3.34.1 — Definition

This case tests that when an unrecoverable protocol error occurs the UE responds correctly to the RLC Reset procedure initiated by the network. Incorrect operation of this procedure may cause loss of service.

## 7.2.3.34.2 — Conformance requirement

Upon reception of a RESET PDU the receiver shall respond with a RESET ACK PDU. The receiver resets the state variables to their initial value and resets configurable parameters to their configured value. Both the transmitter and receiver side of the AM RLC entity are reset. All RLC PDUs in the AM RLC receiver shall be discarded. The RLC SDUs in the AM RLC transmitter that were transmitted before the reset shall be discarded.

## Reference

TS 25.322 clause 11.4.3.

## 7.2.3.34.3 Test purpose

1. To verify that upon reception of a RESET PDU the receiver responds with a RESET ACK PDU.
2. To verify that the receiver resets its state variables to their initial value and resets configurable parameters to their configured value.

## 7.2.3.34.4 Method of test

## Initial conditions

The generic procedure for Radio Bearer establishment (clause 7.1.3 of TS 34.108) is executed, with all the parameters as specified in the procedure, with the exception that the default Radio Access Bearer is replaced with the RAB defined for AM 7-bit length indicator tests in clause 7.2.3.1.

The following RLC parameter values are used in place of the values in clause 7.2.3.1:

|                           |  |
|---------------------------|--|
| Uplink RLC                |  |
| —Transmission RLC discard |  |
| —No discard               |  |

These settings apply to both the uplink and downlink DTCH.

## Test procedure

- a) The SS sends 2 RLC SDUs of size (2 \* AM\_7\_PayloadSize) — 1 bytes, and polls on the last PDU sent.
- b) The SS checks the STATUS PDUs received on the uplink until both SDUs have been acknowledged.
- c) The SS transmits a RESET PDU.
- d) The SS monitors the uplink for a RESET ACK PDU.
- e) The SS sends an RLC SDU of size (2 \* AM\_7\_PayloadSize) — 1 bytes, and polls on the last PDU sent.
- f) The SS checks for STATUS PDUs received on the uplink until the SDU has been acknowledged.
- g) The SS may optionally release the radio bearer.

## Expected sequence

| Step                                                                                       | Direction |    | Message          | Comments             |
|--------------------------------------------------------------------------------------------|-----------|----|------------------|----------------------|
|                                                                                            | UE        | SS |                  |                      |
| 1                                                                                          |           | ←  | DOWNLINK RLC PDU | SDU 1                |
| 2                                                                                          |           | ←  | DOWNLINK RLC PDU | SDU 1                |
| 3                                                                                          |           | ←  | DOWNLINK RLC PDU | SDU 2                |
| 4                                                                                          |           | ←  | DOWNLINK RLC PDU | SDU 2, poll          |
| 5                                                                                          |           | →  | STATUS PDU       | ACK SN=0, 1, 2 and 3 |
| 6                                                                                          |           | ←  | RESET PDU        |                      |
| 7                                                                                          |           | →  | RESET ACK PDU    |                      |
| 8                                                                                          |           | ←  | DOWNLINK RLC PDU | SDU 3                |
| 9                                                                                          |           | ←  | DOWNLINK RLC PDU | SDU 3, poll          |
| 10                                                                                         |           | →  | STATUS PDU       | ACK SN=0 and 1       |
| 11                                                                                         |           |    | RB RELEASE       | Optional step        |
| NOTE: — The UPLINK and DOWNLINK PDU flows may overlap, but are shown separate for clarity. |           |    |                  |                      |

## 7.2.3.34.5 Test requirements

1. The SS shall receive a RESET ACK PDU in step 7.

2. The SS shall receive a STATUS PDU in step 10 acknowledging for the third RLC SDU transmitted with PDUs starting at SN=0.

## ~~7.3 PDCCP~~

### ~~7.3.1 General~~

#### ~~7.3.1.1 General assumptions~~

If not otherwise mentioned, the same procedures as used in RRC test specification (TS 34.123-1) or in the Generic procedure (TS 34.108) applies to reach Initial conditions for PDCCP testing. In this test description, common test sequences for PDCCP (clause 7.3.4.1) are defined and are applied either as preamble or post amble to establish or release a Packet Switched (PS) connection for a test case.

If not explicitly described, the same message contents and settings are applied as described in the RRC test description default settings.

Detailed IP header compression coding mechanism as well as mechanism related error recovery and packet reordering described in IETF RFC 2507 are not verified.

For PDCCP testing TCP/IP data type and UDP/IP data type as Non-TCP/IP data types are applied for IP data.

An UE supporting IP Header compression protocol RFC 2507 shall be capable to store a header compression context of at least 512 bytes (Integer).

It shall be possible to reconfigure PDCCP settings while UE test loop mode 1. With the applied test method using UE test loop mode 1, the UE as Originator and Receiver of PDCCP SDUs (concurrent transmission) is tested.

#### ~~7.3.1.2 Common Test sequences and Default message contents for PDCCP~~

##### ~~General~~

The settings and parameter used in the "Common Test sequences for PDCCP" are described in the "Default PDCCP Message Contents". If not explicitly shown there, the message contents are identical with the default contents for the same message type of layer 3 messages for RRC tests, to establish a packet switched session or connection. The contents of test case specific message parameters are described in the test case (Expected Sequence). If not explicitly shown, default settings and parameter are used as message content for all Common Test sequences.

##### ~~7.3.1.2.1 Common Test sequences for PDCCP~~

###### ~~7.3.1.2.1.1 Setup a UE terminated PS session using IP Header compression in AM RLC (using UE Test loop test mode 1)~~

##### ~~Initial Conditions~~

UE is in Idle mode.

##### ~~Test procedure~~

After having received the System Information, the SS starts to setup a RRC connection. After connection establishment and Radio Bearer Setup, the UE test loop mode 1 is activated and the UE test loop mode 1 is closed.

## Expected Sequence

| Step | Direction |    | Message                        | Comments                                                                                                                                                                                                                                                         |
|------|-----------|----|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                |                                                                                                                                                                                                                                                                  |
| 1    | ←         |    | SYSTEM INFORMATION             | CN domain identity: PS domain<br>Paging cause: interactive session                                                                                                                                                                                               |
| 2    | ←         |    | PAGING TYPE 1                  |                                                                                                                                                                                                                                                                  |
| 3    | →         |    | RRC CONNECTION REQUEST         | Connection Setup message PS sessions in AM<br>RLC used in RRC testing matches here                                                                                                                                                                               |
| 4    | ←         |    | RRC CONNECTION SETUP           |                                                                                                                                                                                                                                                                  |
| 5    | →         |    | RRC CONNECTION SETUP COMPLETE  | The Radio Bearer configuration is as described<br>in TS 34.108, clause 6.10, Prioritised RAB No:<br>23; QoS parameter: Traffic Class: Interactive or<br>Background, max. UL:64 kbps max. DL:64 kbps,<br>Residual BER as described in TS 34.108,<br>clause: 6.10. |
| 6    | ←         |    | ACTIVATE RB TEST MODE          |                                                                                                                                                                                                                                                                  |
| 7    | →         |    | ACTIVATE RB TEST MODE COMPLETE |                                                                                                                                                                                                                                                                  |
| 8    | ←         |    | RADIO BEARER SETUP             |                                                                                                                                                                                                                                                                  |
| 9    | →         |    | RADIO BEARER SETUP COMPLETE    | The SS initiates UE test loop mode 1, indicated<br>by the Parameter: "UE test loop mode" = 1<br>(X1=0 and X2=0)<br>The "DCCH dummy transmission" not used:<br>disabled: (Y1=0)                                                                                   |
| 10   | ←         |    | CLOSE UE TEST LOOP             |                                                                                                                                                                                                                                                                  |
| 11   | →         |    | CLOSE UE TEST LOOP COMPLETE    | After having received the test mode<br>acknowledgement, the UE test loop mode 1 is<br>activated.                                                                                                                                                                 |

## Specific message contents

The contents of test case specific message parameters are described in the test case (Expected Sequence). Default contents of messages are described in the clause Default PDCP Message Contents.

7.3.1.2.1.2 ——— Setup a UE terminated PS session using IP Header compression in UM RLC (using UE Test loop test mode 1)

## Initial Conditions

UE is in idle mode.

## Test procedure

After having received the System Information, the SS starts to setup a RRC connection. After connection establishment and Radio Bearer Setup, the UE test loop mode 1 is activated and the UE test loop mode 1 is closed.

## Expected Sequence

| Step | Direction |    | Message                        | Comments                                                                                                                                                                                                                                          |
|------|-----------|----|--------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                |                                                                                                                                                                                                                                                   |
| 1    | ←         |    | SYSTEM INFORMATION             | CN domain identity: PS domain<br>Paging cause: interactive session                                                                                                                                                                                |
| 2    | ←         |    | PAGING TYPE 1                  |                                                                                                                                                                                                                                                   |
| 3    | →         |    | RRC CONNECTION REQUEST         | Connection Setup message PS sessions in UM<br>RLC used in RRC testing matches here                                                                                                                                                                |
| 4    | ←         |    | RRC CONNECTION SETUP           |                                                                                                                                                                                                                                                   |
| 5    | →         |    | RRC CONNECTION SETUP COMPLETE  | The Radio Bearer configuration is as described in TS 34.108, clause 6.10, Prioritised RAB No: 23; QoS parameter: Traffic Class: Interactive or Background, max. UL:64 kbps max. DL:64 kbps, Residual BER as described in TS 34.108, clause: 6.10. |
| 6    | ←         |    | ACTIVATE RB TEST MODE          |                                                                                                                                                                                                                                                   |
| 7    | →         |    | ACTIVATE RB TEST MODE COMPLETE |                                                                                                                                                                                                                                                   |
| 8    | ←         |    | RADIO BEARER SETUP             |                                                                                                                                                                                                                                                   |
| 9    | →         |    | RADIO BEARER SETUP COMPLETE    | The SS initiates UE test loop mode 1, indicated by the Parameter: "UE test loop mode"1 (X1=0 and X2=0)<br>The "DCCH dummy transmission" not used: disabled: (Y1=0)                                                                                |
| 10   | ←         |    | CLOSE UE TEST LOOP             |                                                                                                                                                                                                                                                   |
| 11   | →         |    | CLOSE UE TEST LOOP COMPLETE    | After having received the test mode acknowledgement, the UE test loop mode 1 is activated.                                                                                                                                                        |

## Specific message contents

The contents of test case specific message parameters are described in the test case (Expected Sequence) Default contents of messages are described in the clause Default PDCP Message Contents.

### 7.3.1.2.1.3 Deactivate a UE terminated PS session using IP Header compression (using UE test loop mode 1)

## Initial Conditions

UE is in connected mode, a UE test loop mode 1 for PDCP is activated, and the UE loop mode 1 is "closed".

## Test procedure

The UE opens the UE test loop mode 1, deactivates the test mode and the PS session, releases the Radio Bearer and enters Idle mode.

## Expected Sequence

| Step | Direction |    | Message                          | Comments                                                                                                                                                          |
|------|-----------|----|----------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                  |                                                                                                                                                                   |
| 1    | ←         |    | OPEN UE TEST LOOP                | The SS terminates the UE test loop mode 1, (see described parameter)<br>After having received the test mode acknowledgement, the test loop mode 1 is deactivated. |
| 2    | →         |    | OPEN UE TEST LOOP COMPLETE       |                                                                                                                                                                   |
| 3    | ←         |    | DEACTIVATE RB TEST MODE          | SS deactivates the RB test mode                                                                                                                                   |
| 4    | →         |    | DEACTIVATE RB TEST MODE COMPLETE | UE shall confirm the previous message.<br>Afterwards, the UE returns to normal operation                                                                          |
| 5    | ←         |    | RRC CONNECTION RELEASE           | SS terminates the connection                                                                                                                                      |
| 6    | →         |    | RRC CONNECTION RELEASE COMPLETE  | UE confirms the connection release and returns to Idle mode                                                                                                       |

## Specific message contents

The contents of test case specific message parameter is described in the test case (Expected Sequence). Default contents of messages are described in the clause Default PDCP Message Contents.

### 7.3.1.2.2 Default PDCP Message Contents

This clause contains the default values of RRC messages used for PDCP testing, other than those specified in TS 34.108 clauses 6 and 9, and default values of PDCP messages. Unless indicated otherwise in specific test cases, only PDCP related specific message contents are described here which shall be transmitted by the system simulator in RRC messages, and which are required to be received from the UE under test. If not explicitly described, the message contents are identical with the default contents for the same message type of layer 3 messages for RRC tests, to establish a packet switched session or connection.

The necessary L3 messages are listed in alphabetic order, with the exception of the SYSTEM INFORMATION messages, where it is the information elements which are listed in alphabetic order (this is because some information elements occur in several SYSTEM INFORMATION types).

In this clause, decimal values are normally used. However, sometimes a hexadecimal value, indicated by an "H", or a binary value, indicated by a "B" is used.

#### Default SYSTEM INFORMATION:

NOTE:—SYSTEM INFORMATION BLOCK TYPE 1 (except for PLMN type "GSM-MAP"), SYSTEM INFORMATION BLOCK TYPE 8, SYSTEM INFORMATION BLOCK TYPE 9, SYSTEM INFORMATION BLOCK TYPE 10, SYSTEM INFORMATION BLOCK TYPE 14, SYSTEM INFORMATION BLOCK TYPE 15 and INFORMATION BLOCK TYPE 16 messages are not used.

#### Contents of CONNECTION SETUP message:

| Information Element                                     | Value/remark              |
|---------------------------------------------------------|---------------------------|
| Capability update requirement                           |                           |
| ———> UE radio access capability update requirement      | TRUE                      |
| ———> System specific capability update requirement list | UE only supports 1 system |

#### Contents of CONNECTION SETUP COMPLETE message:

| Information Element                      | Value/remark                                                                                                                        |
|------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| UE radio access capability               | Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings |
| ———> Conformance test compliance         |                                                                                                                                     |
| ———> PDCP Capability                     |                                                                                                                                     |
| ———> Max PDCP SN                         |                                                                                                                                     |
| ———> Support of lossless SRNS relocation |                                                                                                                                     |
| ———> Support for RFC2507                 |                                                                                                                                     |
| ———> Max HC context space                | (TCP_SPACE + NON_TCP_SPACE))                                                                                                        |
| ———> RLC Capability                      |                                                                                                                                     |
| ———> Transport channel capability        |                                                                                                                                     |
| ———> RF Capability                       |                                                                                                                                     |
| ———> Physical channel capability         |                                                                                                                                     |
| ———> UE multi-mode/multi-RAT capability  |                                                                                                                                     |
| ———> Security Capability                 |                                                                                                                                     |
| ———> LCS Capability                      |                                                                                                                                     |
| ———> Measurement capability              |                                                                                                                                     |
| UE system specific capability            | Value will be check. UE must include the classmark information for the supported system                                             |

## Contents of ACTIVATE RB TEST MODE message:

| Information Element    | Value/remark          |
|------------------------|-----------------------|
| Protocol Discriminator | TS 24.007, 11.2.3.1.1 |
| Skip indicator         | TS 24.007, 11.2.3.1.2 |
| Message type           | 01000100B             |

## Contents of ACTIVATE RB TEST MODE COMPLETE message:

| Information Element    | Value/remark          |
|------------------------|-----------------------|
| Protocol Discriminator | TS 24.007, 11.2.3.1.1 |
| Skip indicator         | TS 24.007, 11.2.3.1.2 |
| Message type           | 01000101B             |

## Contents of DEACTIVATE RB TEST MODE message:

| Information Element    | Value/remark          |
|------------------------|-----------------------|
| Protocol Discriminator | TS 24.007, 11.2.3.1.1 |
| Skip indicator         | TS 24.007, 11.2.3.1.2 |
| Message type           | 01000110B             |

## Contents of DEACTIVATE RB TEST MODE COMPLETE message:

| Information Element    | Value/remark          |
|------------------------|-----------------------|
| Protocol Discriminator | TS 24.007, 11.2.3.1.1 |
| Skip indicator         | TS 24.007, 11.2.3.1.2 |
| Message type           | 01000111B             |

## Contents of CLOSE UE TEST LOOP message:

| Information Element                          | Value/remark                                                                            |
|----------------------------------------------|-----------------------------------------------------------------------------------------|
| Protocol Discriminator                       | TS 24.007, 11.2.3.1.1                                                                   |
| Skip indicator                               | TS 24.007, 11.2.3.1.2                                                                   |
| Message type                                 | 01000000B                                                                               |
| UE test loop mode                            | 000000100B (X2=0 and X1=0 for UE test mode 1, Y1=0<br>DCCH dummy transmission disabled) |
| UE test loop mode 1 LB setup                 |                                                                                         |
| —Length of UE loop mode 1 LB setup IE        | 4 octets                                                                                |
| —→ LB setup list                             |                                                                                         |
| ——→ LB setup RAB subflow #1                  |                                                                                         |
| ————→ Z13...Z0 (Uplink RLC SDU size in bits) | 0...16383 (binary coded, Z13 most significant bit); value<br>as negotiated              |

## Contents of CLOSE UE TEST LOOP COMPLETE message:

| Information Element    | Value/remark          |
|------------------------|-----------------------|
| Protocol Discriminator | TS 24.007, 11.2.3.1.1 |
| Skip indicator         | TS 24.007, 11.2.3.1.2 |
| Message type           | 01000001B             |

## Contents of OPEN UE TEST LOOP message:

| Information Element        | Value/remark          |
|----------------------------|-----------------------|
| IE Identifier (only in AM) | 1000xxxx              |
| Protocol Discriminator     | TS 24.007, 11.2.3.1.1 |
| Skip indicator             | TS 24.007, 11.2.3.1.2 |
| Message type               | 01000010B             |



Contents of OPEN UE TEST LOOP COMPLETE message:

| Information Element    | Value/remark          |
|------------------------|-----------------------|
| Protocol Discriminator | TS 24.007, 11.2.3.1.1 |
| Skip indicator         | TS 24.007, 11.2.3.1.2 |
| Message type           | 01000011B             |

## 7.3.2 IP Header Compression and PID assignment

### 7.3.2.1 UE in RLC AM

#### 7.3.2.1.1 Transmission of uncompressed Header

##### 7.3.2.1.1.1 Definition and applicability

Applicable for all UEs supporting RLC AM and a Radio Bearer as described in the Common Test Sequences. The UE shall be capable to deal with TCP/IP and UDP/IP data packets with uncompressed IP header.

##### 7.3.2.1.1.2 Conformance requirement

Packet Data Convergence Protocol shall perform the following functions:

—...

—transfer of user data. Transmission of user data means that PDCP receives PDCP SDU from the NAS and forwards it to the RLC layer and vice versa;

—PDCP shall be able (...) to handle them with a correct header compression protocol and furthermore to indicate the type of the packet within a certain protocol.

—PID value 0 is reserved permanently for no compression

#### Reference(s)

TS 25.323 clause 5.

TS 25.323 clause 5.1.1.

##### 7.3.2.1.1.3 Test purpose

The test case consists of two test procedures:

The first test procedure verifies, that the "PDCP Data" PDU is used for uncompressed IP header packets, if no IP header compression is configured by higher layers. The second test procedure verifies, that the "PDCP No header" PDU is used for uncompressed IP header packets, if no IP header compression is configured by higher layers.

1. To verify, that the UE transmits and receives in acknowledged mode (RLC AM) TCP/IP and UDP/IP data packets without IP header compression as configured by higher layers.

2. To verify, that PID assignment rules are correctly applied, if usage of "PDCP Data" PDU are negotiated, i.e. the UE shall recognize PID value = 0 for a received TCP/IP and UDP/IP data packet and it shall use PID=0 to transmit IP data packets, if no IP header compression is negotiated. If usage of "PDCP No Header" PDU is negotiated, no PID assignment is used for transmitting and receiving TCP/IP and UDP/IP data packets.

##### 7.3.2.1.1.4 Method of test

#### Initial conditions

UE is in idle mode.

Test procedure 1: Usage of "PDCP Data" PDU and no IP header compression is configured.

Test procedure 2: No IP header compression is configured.

~~Related ICS/IXIT Statement(s)~~

~~Support of PS— Yes/No~~

~~PIXIT: Test\_PDCP\_TCP/IP\_Packet1~~

~~PIXIT: Test\_PDCP\_UDP/IP\_Packet1~~

~~Test procedure 1: Transmission of uncompressed IP header packets using PDCP Data PDU~~

- ~~a) The SS setups a packet switched session including radio bearer and UE test loop mode 1 in RLC AM using Common test procedures for mobile terminated PS switched sessions. Usage of "PDCP Data" PDU has been configured by higher layers.~~
- ~~b) The SS sends a TCP/IP data packet with uncompressed IP Header.~~
- ~~c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PDCP PDU type and shall handle the received data packet with the appropriate decoding method. Then it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration using PDCP Data PDU.~~
- ~~d) The SS receives and decodes the TCP/IP data packet. The decoded data packet shall be identical with the data as sent before.~~
- ~~e) Step b) to d) shall be repeated by using a UDP/IP data packet with uncompressed IP Header.~~

~~The SS deactivates the UE test loop mode and terminates the connection.~~

~~Expected sequence~~

| Step                                                                                               | Direction |           | Message                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Comments |
|----------------------------------------------------------------------------------------------------|-----------|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|
|                                                                                                    | UE        | SS        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |          |
| Setup a UE terminated PS session using IP Header compression in AM RLC (using UE test loop mode 1) |           |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |          |
| 1                                                                                                  | ←         | PDCP Data | <p>The SS creates a TCP/IP packet without IP header compression (PDCP Data PDU).</p> <p>The SS sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE:<br/>PDU type = 000 (PDCP Data PDU)<br/>PID = 0 (uncompressed IP header)<br/>data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression)<br/>Therefore, no IP header decompression is applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCP entity.</p> |          |

| Step                                                                                          | Direction |    | Message    | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|-----------------------------------------------------------------------------------------------|-----------|----|------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                               | UE        | SS |            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 2                                                                                             | →         |    | PDCCP-Data | <p>The UE sends a PDCCP-Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS:<br/>data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function for the received data</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 3                                                                                             | ←         |    | PDCCP-Data | <p>The SS creates a UDP/IP packet without IP header-compression (PDCCP-Data PDU).</p> <p>The SS sends a PDCCP-Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE:<br/>PDU type = 000 (PDCCP-Data PDU)<br/>PID = 0 (uncompressed IP header)<br/>data: below-described UDP/IP packet</p> <p>After having received the PDCCP-Data PDU, the UE decodes the PDU and recognizes with PID value = 0, there was no IP header-compression applied for the UDP/IP packet.<br/>Therefore, no IP header-decompression is applied for this packet.</p> <p>The data packet is forwarded via PDCCP-SAP to the Radio-Bearer Loop-Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCCP entity.</p> |
| 4                                                                                             | →         |    | PDCCP-Data | <p>The UE sends a PDCCP-Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS:<br/>data: previously received UDP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS decodes the received data</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Deactivate a UE terminated PS session using IP Header compression (using UE test loop mode 1) |           |    |            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |

### Specific Message Contents

#### RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE-terminated PS session using IP Header-compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) with the following exceptions:

| Information Element                                                              | Value/remark                                                                                                                                                 |
|----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Capability update requirement<br>— UE radio access capability update requirement | <p>TRUE</p> <p>NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (e.f. PICS/PIXIT statements in GSM) and the user settings</p> |

**RADIO BEARER SETUP message**

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE terminated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) which fits to the below described parameters with the following exceptions:

| Information Element                                                                                                        | Value/remark                                                                                                                                                                                                                                                                                 |
|----------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RAB information for setup<br>- RAB info<br>→ RAB identity                                                                  | No. # 23 as described in TS 34.108, Table 6.10.2.1.1<br>Prioritised RABs.<br>QoS parameter:<br>Traffic Class: Interactive or Background,<br>max. UL: 64 kbps and max. DL: 64 kbps as described in<br>TS 34.108, including described physical channel<br>parameters, configuration for AM RLC |
| → CN domain identity<br>- RB information to setup<br>→ RB identity<br>→ PDCP info<br>→ Support of lossless SRNS relocation | PS domain<br><br>20<br><br>False<br>(IE "Support of lossless SRNS relocation" only present,<br>if RLC "In-sequence delivery" is TRUE and in AM)<br>present                                                                                                                                   |
| → PDCP PDU header<br>→ RLC info<br>→ Downlink RLC mode                                                                     | (AM RLC)                                                                                                                                                                                                                                                                                     |

**Content of PDCP Data PDU (Step 1)**

| Information Element     | Value/remark                                                                                                                                                                                    |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type<br>PID<br>Data | 000<br>00000 (No header compression, PID = 0)<br>PDCP test data type #1: TCP/IP data packet without IP<br>header compression with any data content. The data<br>shall be limited to 1500 bytes. |

**Content of PDCP Data PDU (Step 3)**

| Information Element     | Value/remark                                                                                                                                                                                    |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type<br>PID<br>Data | 000<br>00000 (No header compression, PID = 0)<br>PDCP test data type #2: UDP/IP data packet without IP<br>header compression with any data content. The data<br>shall be limited to 1500 bytes. |

**Test procedure 2: Transmission of uncompressed IP header packets using No Header PDU**

- a) The SS setups a packet-switched session including radio bearer and UE test loop mode 1 in RLC AM using Common test procedures for mobile terminated PS-switched sessions. Usage of "PDCP No Header" PDU has been configured by higher layers.
- b) The SS sends a TCP/IP data packet with uncompressed IP Header.

- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PDCP PDU type and shall handle the received data packet with the appropriate decoding method. Then it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration using PDCP No Header PDU.
- d) The SS receives and decodes the TCP/IP data packet. The decoded data packet shall be identical with the data as sent before.
- e) Step b) to d) shall be repeated by using a UDP/IP data packet with uncompressed IP Header.
- f) The SS deactivates the UE test loop mode and terminates the connection.

#### Expected sequence

| Step                                                                                               | Direction |                | Message                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Comments |
|----------------------------------------------------------------------------------------------------|-----------|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|
|                                                                                                    | UE        | SS             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |          |
| Setup a UE terminated PS session using IP Header compression in AM RLC (using UE test loop mode 1) |           |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |          |
| 1                                                                                                  | ←         | PDCP No Header | <p>The SS creates a TCP/IP packet without IP header compression (PDCP No Header PDU).</p> <p>The SS sends a PDCP No Header PDU using the RLC-AM-Data-Request-Primitive with the following content to the UE:<br/>data: below described TCP/IP packet</p> <p>After having received the PDCP No Header PDU, the UE decodes the PDU and recognizes, there was no PID applied for the TCP/IP packet. Therefore, no IP header decompression shall be applied for this packet. Then, the data packet is forwarded via PDCP-SAP to the Radio Bearer Loop Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCP entity.</p> |          |
| 2                                                                                                  | →         | PDCP No Header | <p>The UE sends a PDCP No Header PDU using the RLC-AM-Data-Request-Primitive with the following content back to the SS:<br/>data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function for the received data</p>                                                                                                                                                                                                                                                                                                                                                                                                |          |
|                                                                                                    |           |                | The SS creates a UDP/IP packet without IP header compression (PDCP No Header PDU).                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |          |

| Step                                                                                           | Direction |    | Message         | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|------------------------------------------------------------------------------------------------|-----------|----|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                | UE        | SS |                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 3                                                                                              |           | ←  | PDCCP-No Header | <p>The SS sends a PDCCP-No Header PDU using the RLC-AM-Data-Request Primitive with the following content to the UE:<br/>data: below-described UDP/IP packet</p> <p>After having received the PDCCP-No Header PDU, the UE decodes the PDU and recognizes, there was no PID applied for the UDP/IP packet. Therefore, no IP header decompression shall be applied for this packet. Then, the data packet is forwarded via PDCCP-SAP to the Radio Bearer Loop-Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCCP entity.</p> |
| 4                                                                                              | →         |    | PDCCP-No Header | <p>The UE sends a PDCCP-No Header PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS:<br/>data: previously received UDP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS decodes the received data</p>                                                                                                                                                                                                                                                                                                                                               |
| Deactivate a UE terminated PS session using IP Header compression (using UE test loop mode 1). |           |    |                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |

### Specific Message Contents

#### RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE-terminated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) with the following exceptions:

| Information Element                                                              | Value/remark                                                                                                                                      |
|----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| Capability update requirement<br>— UE radio access capability update requirement | TRUE<br>NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings |

### RADIO BEARER SETUP message

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE terminated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) which fits to the below described parameters with the following exceptions:

| Information Element                                                                                                        | Value/remark                                                                                                                                                                                                                                                                                 |
|----------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RAB information for setup<br>- RAB info<br>→ RAB identity                                                                  | No. # 23 as described in TS 34.108, Table 6.10.2.1.1<br>Prioritised RABs.<br>QoS-parameter:<br>Traffic Class: Interactive or Background,<br>max. UL: 64 kbps and max. DL: 64 kbps as described in<br>TS 34.108, including described physical channel<br>parameters, configuration for AM RLC |
| → CN domain identity<br>- RB information to setup<br>→ RB identity<br>→ PDCP info<br>→ Support of lossless SRNS relocation | PS domain<br><br>20<br><br>False<br>(IE "Support of lossless SRNS relocation" only present,<br>if RLC "In-sequence delivery" is TRUE and in AM)                                                                                                                                              |
| → PDCP PDU header<br>→ RLC info<br>→ Downlink RLC mode                                                                     | absent<br><br>(AM RLC)                                                                                                                                                                                                                                                                       |

### Content of PDCP No Header PDU (Step 1)

| Information Element | Value/remark                                                                                                                             |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| Data                | PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 1500 bytes. |

### Content of PDCP No Header PDU (Step 3)

| Information Element | Value/remark                                                                                                                             |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| Data                | PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 1500 bytes. |

### 7.3.2.1.1.5 ——— Test requirements

#### 1. — Test requirements: Transmission of uncompressed IP header packets using PDCP Data PDU

The UE shall return the TCP/IP and UDP/IP data packets as indication, that the previous packets have been received and handled correctly (PDCP Data PDU). This verifies, that the PDCP configuration on UE side works as negotiated by the RRC.

#### 2. — Test requirements: Transmission of uncompressed IP header packets using PDCP No Header PDU

The UE shall return the TCP/IP and UDP/IP data packets as indication, that the previous packets have been received and handled correctly (PDCP No Header PDU). This verifies, that the PDCP configuration on UE side works as negotiated by the RRC.

### ~~7.3.2.1.2 Transmission of compressed Header~~

#### ~~7.3.2.1.2.1 Definition and applicability~~

~~Applicable for all UEs supporting RLC AM and a Radio Bearer as described in the Common Test Sequences.~~

~~The UE shall be capable to deal with compressed TCP/IP and UDP/IP data packets and furthermore to establish a PDCP entity which applies IP header compression protocol RFC 2507.~~

#### ~~7.3.2.1.2.2 Conformance requirement~~

~~Packet Data Convergence Protocol shall perform the following functions:~~

~~—...~~

~~—transfer of user data. Transmission of user data means that PDCP receives PDCP SDU from the NAS and forwards it to the RLC layer and vice versa;~~

~~—PDCP shall be able (...) to handle them with a correct header compression protocol and furthermore to indicate the type of the packet within a certain protocol.~~

#### ~~Reference(s)~~

~~TS 25.323 clause 5.~~

~~TS 25.323 clause 5.1.1.~~

#### ~~7.3.2.1.2.3 Test purpose~~

- ~~1. To verify, that the UE transmits and receives in acknowledged mode (RLC AM) TCP/IP and UDP/IP data packets by using IP header compression protocol as described in RFC2507 as configured by higher layers.~~
- ~~2. To verify, that the PID assignment rules are correctly applied by the UE. The UE as shall use the correct PID value for the applied optimisation method for transmitting and receiving TCP/IP and UDP/IP data packets.~~

#### ~~7.3.2.1.2.4 Method of test~~

##### ~~Initial conditions~~

~~UE is in Idle mode. Usage of "PDCP Data" PDU and IP header compression is configured.~~

##### ~~Related ICS/IXIT Statement(s)~~

~~Support of IP header compression protocol RFC 2507 – YES/NO.~~

~~Support of PS – Yes/No~~

~~PIXIT: Test\_PDCP\_TCP/IP\_Packet1~~

~~PIXIT: Test\_PDCP\_TCP/IP\_Packet2~~

~~PIXIT: Test\_PDCP\_UDP/IP\_Packet1~~

~~PIXIT: Test\_PDCP\_UDP/IP\_Packet2~~

##### ~~Test procedure~~

- ~~a) The SS setups a packet switched session including radio bearer and UE test loop mode 1 in RLC AM using Common test procedures for mobile terminated PS switched sessions. Usage of "PDCP Data" PDU has been configured by higher layers.~~
- ~~b) The SS sends a "normal" TCP/IP data packet (no compression packet type), PID=0.~~



- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression protocol. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
  - d) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.
  - e) The SS sends a TCP/IP data packet with packet type: Full\_Header, PID=1.
- NOTE:—According to the compression protocol RFC 2507, this is necessary to transmit the created CONTEXT and the assigned CID.
- f) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression protocol. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
  - g) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.
  - h) The SS sends a TCP/IP data packet with packet type: Compressed\_TCP, PID=2.
  - i) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression protocol. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
  - j) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.
  - k) Step b) to d) is repeated for a "normal" UDP/IP data packet, PID=0.
  - l) Step e) to g) is repeated for a UDP/IP data packet with packet type: Full\_Header, PID=1.
  - m) The SS sends a UDP/IP data packet with packet type: Compressed\_non\_TCP, PID=4.
  - n) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression protocol. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
  - o) The SS receives and decodes the UDP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.
  - p) The SS deactivates the UE tests loop mode 1 and terminates the connection.

## Expected sequence

| Step                                                                                               | Direction |            | Message                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Comments |
|----------------------------------------------------------------------------------------------------|-----------|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|
|                                                                                                    | UE        | SS         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |          |
| Setup a UE terminated PS session using IP Header compression in AM RLC (using UE test loop mode 1) |           |            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |          |
| 1                                                                                                  | ←         | PDCCP-Data | <p>The SS creates a TCP/IP packet without IP header compression.</p> <p>The SS sends a PDCCP-Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE:<br/>PDU type = 000 (PDCCP-Data PDU)<br/>PID = 0 (uncompressed IP header)<br/>data: below described TCP/IP packet</p> <p>After having received the PDCCP-Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression). Therefore, no IP header decompression is applied for this packet.</p> <p>The data packet is forwarded via PDCCP-SAP to its Radio Bearer Loop Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCCP entity.</p> |          |
| 2                                                                                                  | →         | PDCCP-Data | <p>The UE sends a PDCCP-Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS:<br/>PDU type = 000 (PDCCP-Data PDU)<br/>PID value = 0 to 3<br/>data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                                                                                                                                                                  |          |
| 3                                                                                                  | ←         | PDCCP-Data | <p>The SS sends a PDCCP-Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE:<br/>PDU type = 000 (PDCCP-Data PDU)<br/>PID = 1 (Full_Header packet type [TCP/IP])<br/>data: below described TCP/IP packet</p> <p>After having received the PDCCP-Data PDU, the UE decodes the PDU, recognizes PID value = 1 applied for this TCP/IP data packet and decompresses it with the appropriate method. The data packet is forwarded via PDCCP-SAP to its Radio Bearer Loop Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCCP entity.</p>                                                                               |          |

| Step | Direction |    | Message   | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|------|-----------|----|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 4    | →         |    | PDCP-Data | <p>The UE sends a PDCP-Data PDU using the RLC-AM-Data-Request-Primitive with the following content back to the SS:<br/> PDU type = 000 (PDCP-Data PDU)<br/> PID value = 0 to 3<br/> data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 5    | ←         |    | PDCP-Data | <p>The SS sends a PDCP-Data PDU using the RLC-AM-Data-Request-Primitive with the following content to the UE:<br/> PDU type = 000 (PDCP-Data PDU)<br/> PID = 2 (Compressed TCP packet type)<br/> data: below described TCP/IP packet</p> <p>After having received the PDCP-Data PDU, the UE decodes the PDU, recognizes PID value = 2 applied for this TCP/IP data packet and decompress it with the appropriate method. The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop-Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCP entity.</p>                                                                                                                                            |
| 6    | →         |    | PDCP-Data | <p>The UE sends a PDCP-Data PDU using the RLC-AM-Data-Request-Primitive with the following content back to the SS:<br/> PDU type = 000 (PDCP-Data PDU)<br/> PID value = 0 to 3<br/> data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 7    | ←         |    | PDCP-Data | <p>The SS creates a UDP/IP packet without compressed IP header compression.<br/> The SS sends a PDCP-Data PDU using the RLC-AM-Data-Request-Primitive with the following content to the UE:<br/> PDU type = 000 (PDCP-Data PDU)<br/> PID = 0 (uncompressed IP header)<br/> data: below described UDP/IP packet</p> <p>After having received the PDCP-Data PDU, the UE decodes the PDU and recognizes with PID value = 0, there was no IP header compression applied for the UDP/IP packet. Therefore, no IP header decompression is applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to the Radio Bearer Loop-Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCP entity.</p> |

| Step | Direction |    | Message    | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|------|-----------|----|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |            |                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 8    | →         |    | PDCCP-Data | <p>The UE sends a PDCCP-Data PDU using the RLC-AM-Data-Request-Primitive with the following content back to the SS:</p> <p>PDU type = 000 (Data PDU with Header)</p> <p>PID value = 0,1 or 4 (depending on which UDP/IP header format is used by the UE)</p> <p>data: previously received UDP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p> |

| Step                                                                                          | Direction |    | Message   | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|-----------------------------------------------------------------------------------------------|-----------|----|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                               | UE        | SS |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 9                                                                                             | ←         |    | PDCP-Data | <p>The SS sends a PDCP-Data PDU using the RLC-AM-Data-Request-Primitive with the following content to the UE:<br/>PDU type = 000 (PDCP-Data PDU)<br/>PID = 1 (Full_Header packet type)<br/>data: below-described UDP/IP packet</p> <p>After having received the PDCP-Data PDU, the UE decodes the PDU and recognizes PID-value = 1 applied for this UDP/IP data packet and decompress it with the appropriate method.</p> <p>The data packet is forwarded via PDCP-SAP to the Radio-Bearer-Loop-Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCP entity.</p>        |
| 10                                                                                            | →         |    | PDCP-Data | <p>The UE sends a PDCP-Data PDU using the RLC-AM-Data-Request-Primitive with the following content back to the SS:<br/>PDU type = 000 (Data PDU with Header)<br/>PID-value = 0,1 or 4 (depending on which UDP/IP header format is used by the UE)<br/>data: previously received UDP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                  |
| 11                                                                                            | ←         |    | PDCP-Data | <p>The SS sends a PDCP-Data PDU using the RLC-AM-Data-Request-Primitive with the following content to the UE:<br/>PDU type = 000 (PDCP-Data PDU)<br/>PID = 4 (Compressed_non-TCP packet type)<br/>data: below-described UDP/IP packet</p> <p>After having received the PDCP-Data PDU, the UE decodes the PDU and recognizes PID-value = 4 applied for this UDP/IP data packet and decompress it with the appropriate method.</p> <p>The data packet is forwarded via PDCP-SAP to the Radio-Bearer-Loop-Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCP entity.</p> |
| 12                                                                                            | →         |    | PDCP-Data | <p>The UE sends a PDCP-Data PDU using the RLC-AM-Data-Request-Primitive with the following content back to the SS:<br/>PDU type = 000 (Data PDU with Header)<br/>PID-value = 0,1 or 4 (depending on which UDP/IP header format is used by the UE)<br/>data: previously received UDP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                  |
| Deactivate a UE terminated PS-session using IP-Header compression (using UE test-loop mode 1) |           |    |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

## Specific Message Contents

## RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE terminated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) with the following exceptions:

| Information Element                                                              | Value/remark                                                                                                                                      |
|----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| Capability update requirement<br>→ UE radio access capability update requirement | TRUE<br>NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings |

## RADIO BEARER SETUP message

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE terminated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) which fit to the here described parameters with the following exceptions:

| Information Element                                                                                | Value/remark                                                                                                                                                                                                                                                                                 |
|----------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RAB information for setup<br>→ RAB info<br>→ RAB identity                                          | No. # 23 as described in TS 34.108, Table 6.10.2.1.1<br>Prioritised RABs.<br>QoS parameter:<br>Traffic Class: Interactive or Background,<br>max. UL: 64 kbps and max. DL: 64 kbps as described in<br>TS 34.108, including described physical channel<br>parameters, configuration for AM RLC |
| → CN domain identity                                                                               | PS domain                                                                                                                                                                                                                                                                                    |
| → RB information to setup<br>→ RB identity<br>→ PDCP info<br>→ Support of lossless SRNS relocation | 20<br><br>False<br>(IE "Support of lossless SRNS relocation" only present,<br>if RLC "In-sequence delivery" is TRUE and in AM)                                                                                                                                                               |
| → PDCP PDU header<br>→ Header compression information<br>→ CHOICE algorithm type<br>→ RFC2507      | present<br>1                                                                                                                                                                                                                                                                                 |
| → F_MAX_PERIOD                                                                                     | 256 (Default)                                                                                                                                                                                                                                                                                |
| → F_MAX_TIME                                                                                       | 5 (Default)                                                                                                                                                                                                                                                                                  |
| → MAX_HEADER                                                                                       | 168 (Default)                                                                                                                                                                                                                                                                                |
| → TCP_SPACE                                                                                        | 15 (Default)                                                                                                                                                                                                                                                                                 |
| → NON_TCP_SPACE                                                                                    | 15 (Default)                                                                                                                                                                                                                                                                                 |
| → EXPECT_REORDERING                                                                                | reordering not expected (Default)                                                                                                                                                                                                                                                            |
| → RLC info<br>→ Downlink RLC mode                                                                  | (AM RLC)                                                                                                                                                                                                                                                                                     |

## Content of PDCP Data PDU (Step 1)

| Information Element | Value/remark                                                                                                                             |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type            | 000                                                                                                                                      |
| PID                 | 00000 (No header compression, PID = 0)                                                                                                   |
| Data                | PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 1500 bytes. |

## Content of PDCP Data PDU (Step 3)

| Information Element | Value/remark                                                                                                                             |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type            | 000                                                                                                                                      |
| PID                 | 00001 (Full_Header, PID = 1)                                                                                                             |
| Data                | PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 1500 bytes. |

## Content of PDCP Data PDU (Step 5)

| Information Element | Value/remark                                                                                                                             |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type            | 000                                                                                                                                      |
| PID                 | 00010 (Compressed_TCP, PID = 2)                                                                                                          |
| Data                | PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 1500 bytes. |

## Content of PDCP Data PDU (Step 7)

| Information Element | Value/remark                                                                                                                             |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type            | 000                                                                                                                                      |
| PID                 | 00000 (No header compression, PID = 0)                                                                                                   |
| Data                | PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 1500 bytes. |

## Content of PDCP Data PDU (Step 9)

| Information Element | Value/remark                                                                                                                             |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type            | 000                                                                                                                                      |
| PID                 | 00001 (Full_Header, PID = 1)                                                                                                             |
| Data                | PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 1500 bytes. |

## Content of PDCP Data PDU (Step 11)

| Information Element | Value/remark                                                                                                                             |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type            | 000                                                                                                                                      |
| PID                 | 00100 (Compressed_non-TCP, PID = 4)                                                                                                      |
| Data                | PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 1500 bytes. |

#### ~~7.3.2.1.2.5 Test requirements~~

~~The UE shall return the TCP/IP and UDP/IP data packets as indication, that the previous packets have been received and handled with the correct compression protocol. This verifies, that the PDCP configuration on UE side works as negotiated by the RRC.~~

#### ~~7.3.2.2 UE in RLC UM~~

##### ~~7.3.2.2.1 Transmission of uncompressed Header~~

###### ~~7.3.2.2.1.1 Definition and applicability~~

~~Applicable for all UEs supporting RLC UM and a Radio Bearer as described in the Common Test Sequences.~~

~~The UE shall be capable to deal with TCP/IP and UDP/IP data packets with uncompressed IP header.~~

###### ~~7.3.2.2.1.2 Conformance requirement~~

~~Packet Data Convergence Protocol shall perform the following functions:~~

~~—...~~

~~—transfer of user data. Transmission of user data means that PDCP receives PDCP SDU from the NAS and forwards it to the RLC layer and vice versa;~~

~~—PDCP shall be able (...) to handle them with a correct header compression protocol and furthermore to indicate the type of the packet within a certain protocol;~~

~~—PID value 0 is reserved permanently for no compression.~~

#### ~~Reference(s)~~

~~TS 25.323 clause 5.~~

~~TS 25.323 clause 5.1.1.~~

###### ~~7.3.2.2.1.3 Test purpose~~

~~The test case consists of two test procedures:~~

~~The first test procedure verifies, that the "PDCP Data" PDU is used for uncompressed IP header packets, if no IP header compression is configured by higher layers. The second test procedure verifies, that the "PDCP No header" PDU is used for uncompressed IP header packets, if no IP header compression is configured by higher layers.~~

~~1. To verify, that the UE transmits and receives in unacknowledged mode (RLC UM) TCP/IP and UDP/IP data packets without IP header compression as configured by higher layers.~~

~~2. To verify, that PID assignment rules are correctly applied, if usage of "PDCP Data" PDU are negotiated, i.e. the UE shall recognize PID value = 0 for a received TCP/IP and UDP/IP data packet and it shall use PID=0 to transmit IP data packets, if no IP header compression is negotiated. If usage of "PDCP No Header" PDU is negotiated, no PID assignment is used for transmitting and receiving TCP/IP and UDP/IP data packets.~~

###### ~~7.3.2.2.1.4 Method of test~~

#### ~~Initial conditions~~

~~UE is in Idle mode.~~

~~Test procedure 1: Usage of "PDCP Data" PDU and no IP header compression is configured.~~

~~Test procedure 2: no IP header compression is configured.~~



#### Related ICS/IXIT Statement(s)

Support of PS — Yes/No

PIXIT: Test\_PDCP\_TCP/IP\_Packet1

PIXIT: Test\_PDCP\_UDP/IP\_Packet1

#### Test procedure 1: Transmission of uncompressed IP header packets using PDCP Data PDU

- a) The SS setups a packet switched session including radio bearer and UE test loop mode 1 in RLC UM using Common test procedures for mobile terminated PS switched sessions. Usage of "PDCP Data" PDU has been configured by higher layers.
- b) The SS sends a TCP/IP data packet with uncompressed IP Header.
- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PDCP PDU type and shall handle the received data packet with the appropriate decoding method. Then it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration using PDCP Data PDU.
- d) The SS receives and decodes the TCP/IP data packet. The decoded data packet shall be identical with the data as sent before.
- e) Step b) to d) shall be repeated by using a UDP/IP data packet with uncompressed IP Header.

The SS deactivates the UE test loop mode and terminates the connection.

## Expected sequence

| Step                                                                                               | Direction |           | Message                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Comments |
|----------------------------------------------------------------------------------------------------|-----------|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|
|                                                                                                    | UE        | SS        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |          |
| Setup a UE terminated PS session using IP Header compression in UM RLC (using UE test loop mode 1) |           |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |          |
| 1                                                                                                  | ←         | PDCP Data | <p>The SS creates a TCP/IP packet without IP header compression (PDCP Data PDU).</p> <p>The SS sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE:<br/>PDU type = 000 (PDCP Data PDU)<br/>PID = 0 (uncompressed IP header)<br/>data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression)<br/>Therefore, no IP header decompression is applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCP entity.</p> |          |
| 2                                                                                                  | →         | PDCP Data | <p>The UE sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS:<br/>data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function for the received data</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                     |          |
|                                                                                                    |           |           | The SS creates a UDP/IP packet without IP header compression (PDCP Data PDU).                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |          |

| Step                                                                                          | Direction |    | Message    | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|-----------------------------------------------------------------------------------------------|-----------|----|------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                               | UE        | SS |            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 3                                                                                             |           | ←  | PDCCP-Data | <p>The SS sends a PDCCP-Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE:<br/> PDU type = 000 (PDCCP-Data-PDU)<br/> PID = 0 (uncompressed IP header)<br/> data: below described UDP/IP packet</p> <p>After having received the PDCCP-Data PDU, the UE decodes the PDU and recognizes with PID value = 0, there was no IP header compression applied for the UDP/IP packet. Therefore, no IP header decompression is applied for this packet.</p> <p>The data packet is forwarded via PDCCP-SAP to the Radio-Bearer-Loop-Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCCP entity.</p> |
| 4                                                                                             |           | →  | PDCCP-Data | <p>The UE sends a PDCCP-Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS:<br/> data: previously received UDP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS decodes the received data</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Deactivate a UE terminated PS session using IP Header compression (using UE test loop mode 1) |           |    |            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

### Specific Message Contents

#### RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE-terminated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) with the following exceptions:

| Information Element                                                              | Value/remark                                                                                                                                                 |
|----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Capability update requirement<br>— UE radio access capability update requirement | <p>TRUE</p> <p>NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings</p> |

**RADIO-BEARER-SETUP message**

The contents of the RADIO-BEARER-SETUP message applied in the preamble "Setup a UE terminated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) which fits to the below described parameters with the following exceptions:

| Information Element                                                                                                                                                                                                                | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RAB information for setup<br>-RAB-info<br>→ RAB-identity<br><br><br><br><br><br><br><br>→ CN domain identity<br>-RB information to setup<br>→ RB-identity<br>→ PDCP-info<br>→ PDCP PDU header<br>→ RLC-info<br>→ Downlink RLC mode | No. # 23 as described in TS 34.108, Table 6.10.2.1.1<br>Prioritised RABs.<br>QoS-parameter:<br>Traffic Class: Interactive or Background,<br>max. UL: 64 kbps and max. DL: 64 kbps as described in<br>TS 34.108, including described physical channel<br>parameters, configuration for UM RLC<br><br>Residual BER as described in TS 34.108, clause: 6.10<br>Related Signalling RB-UL: 3.4 kbps, DL: 3.4 kbps<br>DCCH, No. #2 (as described in TS 34.108)<br><br>PS domain<br><br>21<br><br>present<br><br>(UM RLC) |

**Content of PDCP Data PDU (Step 1)**

| Information Element     | Value/remark                                                                                                                                                                                    |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PDU-type<br>PID<br>Data | 000<br>00000 (No header compression, PID = 0)<br>PDCP test data type #1: TCP/IP data packet without IP<br>header compression with any data content. The data<br>shall be limited to 1500 bytes. |

**Content of PDCP Data PDU (Step 3)**

| Information Element     | Value/remark                                                                                                                                                                                    |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PDU-type<br>PID<br>Data | 000<br>00000 (No header compression, PID = 0)<br>PDCP test data type #2: UDP/IP data packet without IP<br>header compression with any data content. The data<br>shall be limited to 1500 bytes. |

### Test procedure 2: Transmission of uncompressed IP header packets using No Header PDU

- a) The SS setups a packet switched session including radio bearer and UE test loop mode 1 in RLC UM using Common test procedures for mobile terminated PS switched sessions. Usage of "PDCP No Header" PDU has been configured by higher layers.
- b) The SS sends a TCP/IP data packet with uncompressed IP Header.
- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PDCP PDU type and shall handle the received data packet with the appropriate decoding method. Then it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration using PDCP No Header PDU.
- d) The SS receives and decodes the TCP/IP data packet. The decoded data packet shall be identical with the data as sent before.
- e) Step b) to d) shall be repeated by using a UDP/IP data packet with uncompressed IP Header.
- f) The SS deactivates the Loop back test mode and terminates the connection.

### Expected sequence

| Step                                                                                               | Direction |                | Message                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Comments |
|----------------------------------------------------------------------------------------------------|-----------|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|
|                                                                                                    | UE        | SS             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |          |
| Setup a UE terminated PS session using IP Header compression in UM RLC (using UE test loop mode 1) |           |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |          |
| 1                                                                                                  | ←         | PDCP No Header | <p>The SS creates a TCP/IP packet without IP header compression (PDCP No Header PDU).</p> <p>The SS sends a PDCP No Header PDU using the RLC-UM-Data-Request-Primitive with the following content to the UE:<br/>data: below described TCP/IP packet</p> <p>After having received the PDCP No Header PDU, the UE decodes the PDU and recognizes, there was no PID applied for the TCP/IP packet. Therefore, no IP header decompression shall be applied for this packet. Then, the data packet is forwarded via PDCP-SAP to the Radio Bearer Loop Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCP entity.</p> |          |
| 2                                                                                                  | →         | PDCP No Header | <p>The UE sends a PDCP No Header PDU using the RLC-UM-Data-Request-Primitive with the following content back to the SS:<br/>data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function for the received data</p>                                                                                                                                                                                                                                                                                                                                                                                                |          |
|                                                                                                    |           |                | <p>The SS creates a UDP/IP packet without IP header compression (PDCP No Header PDU).</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |          |

| Step                                                                                          | Direction |    | Message         | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-----------------------------------------------------------------------------------------------|-----------|----|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                               | UE        | SS |                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 3                                                                                             |           | ←  | PDCCP-No Header | <p>The SS sends a PDCCP-No Header PDU using the RLC-UM-Data-Request Primitive with the following content to the UE:<br/>data: below-described UDP/IP packet</p> <p>After having received the PDCCP-No Header PDU, the UE decodes the PDU and recognizes, there was no PID applied for the UDP/IP packet. Therefore, no IP header decompression shall be applied for this packet. Then, the data packet is forwarded via PDCCP-SAP to the Radio Bearer Loop-Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCCP entity.</p> |
| 4                                                                                             | →         |    | PDCCP-No Header | <p>The UE sends a PDCCP-No Header PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS:<br/>data: previously received UDP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS decodes the received data</p>                                                                                                                                                                                                                                                                                                                                               |
| Deactivate a UE terminated PS session using IP Header compression (using UE test loop mode 1) |           |    |                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |

### Specific Message Contents

#### RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE-terminated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) with the following exceptions:

| Information Element                                                              | Value/remark                                                                                                                                      |
|----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| Capability update requirement<br>— UE radio access capability update requirement | TRUE<br>NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings |

### RADIO-BEARER-SETUP message

The contents of the RADIO-BEARER-SETUP message applied in the preamble "Setup a UE terminated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) which fits to the below described parameters with the following exceptions:

| Information Element                                                                                                                                                                                                                                                                                                 | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RAB information for setup<br><del>→ RAB info</del><br><del>→ RAB identity</del><br><br><del>→ CN domain identity</del><br><del>→ RB information to setup</del><br><del>→ RB identity</del><br><del>→ PDCP info</del><br><br><del>→ PDCP PDU header</del><br><del>→ RLC info</del><br><del>→ Downlink RLC mode</del> | No. # 23 as described in TS 34.108, Table 6.10.2.1.1<br>Prioritised RABs.<br>QoS-parameter:<br>Traffic Class: Interactive or Background,<br>max. UL: 64 kbps and max. DL: 64 kbps as described in<br>TS 34.108, including described physical channel<br>parameters, configuration for UM RLC<br><br>Residual BER as described in TS 34.108, clause: 6.10<br>Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps<br>DCCH, No. #2 (as described in TS 34.108)<br><br>PS domain<br><br>21<br><br>False<br><br>absent<br><br>(UM RLC) |

### Content of PDCP No Header PDU (Step 1)

| Information Element | Value/remark                                                                                                                                   |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| Data                | PDCP test data type #1: TCP/IP data packet without IP<br>header compression with any data content. The data<br>shall be limited to 1500 bytes. |

### Content of PDCP No Header PDU (Step 3)

| Information Element | Value/remark                                                                                                                                   |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| Data                | PDCP test data type #2: UDP/IP data packet without IP<br>header compression with any data content. The data<br>shall be limited to 1500 bytes. |

### 7.3.2.2.1.5 Test requirements

#### 1. Test requirements: Transmission of uncompressed IP header packets using PDCP Data PDU

The UE shall return the TCP/IP and UDP/IP data packets as indication, that the previous packets have been received and handled correctly (PDCP Data PDU). This verifies, that the PDCP configuration on UE side works as negotiated by the RRC.

#### 2. Test requirements: Transmission of uncompressed IP header packets using PDCP No Header PDU

The UE shall return the TCP/IP and UDP/IP data packets as indication, that the previous packets have been received and handled correctly (PDCP No Header PDU). This verifies, that the PDCP configuration on UE side works as negotiated by the RRC.

~~7.3.2.2.2 Transmission of compressed Header~~~~7.3.2.2.2.1 Definition and applicability~~

~~Applicable for all UEs supporting RLC UM and a Radio Bearer as described in the Common Test Sequences.~~

~~The UE shall be capable to deal with compressed TCP/IP and UDP/IP data packets and furthermore to establish a PDCP entity which applies IP header compression protocol RFC 2507.~~

~~7.3.2.2.2.2 Conformance requirement~~

~~Packet Data Convergence Protocol shall perform the following functions:~~

~~—...~~

~~—transfer of user data. Transmission of user data means that PDCP receives PDCP SDU from the NAS and forwards it to the RLC layer and vice versa;~~

~~—PDCP shall be able (...) to handle them with a correct header compression protocol and furthermore to indicate the type of the packet within a certain protocol.~~

~~Reference(s)~~

~~TS 25.323 clause 5.~~

~~TS 25.323 clause 5.1.1.~~

~~7.3.2.2.2.3 Test purpose~~

- ~~1. To verify, that the UE transmits and receives in unacknowledged mode (RLC UM) TCP/IP and UDP/IP data packets by using IP header compression protocol as described in RFC2507 as configured by higher layers.~~
- ~~2. To verify, that the PID assignment rules are correctly applied by the UE. The UE as shall use the correct PID value for the applied optimisation method for transmitting and receiving TCP/IP and UDP/IP data packets.~~

~~7.3.2.2.2.4 Method of test~~~~Initial conditions~~

~~UE is in Idle mode. Usage of "PDCP Data" PDU and no IP header compression is configured.~~

~~Related ICS/IXIT Statement(s)~~

~~Support of IP header compression protocol RFC 2507 – YES/NO~~

~~Support of PS – Yes/No~~

~~PIXIT: Test\_PDCP\_TCP/IP\_Packet1~~

~~PIXIT: Test\_PDCP\_TCP/IP\_Packet2~~

~~PIXIT: Test\_PDCP\_UDP/IP\_Packet1~~

~~PIXIT: Test\_PDCP\_UDP/IP\_Packet2~~

~~Test procedure~~

- ~~a) The SS setups a packet switched session including radio bearer and UE test loop mode 1 in RLC UM using Common test procedures for mobile terminated PS switched sessions. Usage of "PDCP Data" PDU has been configured by higher layers.~~
- ~~b) The SS sends a "normal" TCP/IP data packet (no compression packet type), PID=0.~~



- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression protocol. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
  - d) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.
  - e) The SS sends a TCP/IP data packet with packet type: Full\_Header, PID=1.
- NOTE:—According to the compression protocol RFC 2507, this is necessary to transmit the created CONTEXT and the assigned CID.
- f) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression protocol. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
  - g) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.
  - h) The SS sends a TCP/IP data packet with packet type: Compressed\_TCP, PID=2.
  - i) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression protocol. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
  - j) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.
  - k) Step b) to d) is repeated for a "normal" UDP/IP data packet, PID=0.
  - l) Step e) to g) is repeated for a UDP/IP data packet with packet type: Full\_Header, PID=1.
  - m) The SS sends a UDP/IP data packet with packet type: Compressed\_non\_TCP, PID=4.
  - n) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decompression protocol. Then, it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
  - o) The SS receives and decodes the UDP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.
  - p) The SS deactivates the UE test loop test mode and terminates the connection.

## Expected sequence

| Step                                                                                               | Direction |            | Message                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Comments |
|----------------------------------------------------------------------------------------------------|-----------|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|
|                                                                                                    | UE        | SS         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |          |
| Setup a UE terminated PS session using IP Header compression in UM RLC (using UE test loop mode 1) |           |            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |          |
| 1                                                                                                  | ←         | PDCCP Data | <p>The SS creates a TCP/IP packet without IP header compression.</p> <p>The SS sends a PDCCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE:<br/>PDU type = 000 (PDCCP Data PDU)<br/>PID = 0 (uncompressed IP header)<br/>data: below described TCP/IP packet</p> <p>After having received the PDCCP Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression). Therefore, no IP header decompression is applied for this packet.</p> <p>The data packet is forwarded via PDCCP-SAP to its Radio Bearer Loop Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCCP entity.</p> |          |
| 2                                                                                                  | →         | PDCCP Data | <p>The UE sends a PDCCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS:<br/>PDU type = 000 (PDCCP Data PDU)<br/>PID value = 0 to 3<br/>data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                                                                                                                                                                  |          |
| 3                                                                                                  | ←         | PDCCP Data | <p>The SS sends a PDCCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE:<br/>PDU type = 000 (PDCCP Data PDU)<br/>PID = 1 (Full_Header packet type [TCP/IP])<br/>data: below described TCP/IP packet</p> <p>After having received the PDCCP Data PDU, the UE decodes the PDU, recognizes PID value = 1 applied for this TCP/IP data packet and decompresses it with the appropriate method. The data packet is forwarded via PDCCP-SAP to its Radio Bearer Loop Back (RB-LB) entity.</p>                                                                                                                                                                                                      |          |

| Step | Direction |    | Message   | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|------|-----------|----|-----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 4    | →         |    | PDCP-Data | <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCP entity.</p> <p>The UE sends a PDCP-Data PDU using the RLC-UM-Data-Request-Primitive with the following content back to the SS:<br/> PDU type = 000 (PDCP-Data PDU)<br/> PID value = 0 to 3<br/> data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                                                                                         |
| 5    | ←         |    | PDCP-Data | <p>The SS sends a PDCP-Data PDU using the RLC-UM-Data-Request-Primitive with the following content to the UE:<br/> PDU type = 000 (PDCP-Data PDU)<br/> PID = 2 (Compressed TCP packet type)<br/> data: below described TCP/IP packet</p> <p>After having received the PDCP-Data PDU, the UE decodes the PDU, recognizes PID value = 2 applied for this TCP/IP data packet and decompress it with the appropriate method. The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop-Back (RB-LB) entity.</p>                                                                                                                                                                                                                                                             |
| 6    | →         |    | PDCP-Data | <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCP entity.</p> <p>The UE sends a PDCP-Data PDU using the RLC-UM-Data-Request-Primitive with the following content back to the SS:<br/> PDU type = 000 (PDCP-Data PDU)<br/> PID value = 0 to 3<br/> data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                                                                                         |
| 7    | ←         |    | PDCP-Data | <p>The SS creates a UDP/IP packet without compressed IP header compression. The SS sends a PDCP-Data PDU using the RLC-UM-Data-Request-Primitive with the following content to the UE:<br/> PDU type = 000 (PDCP-Data PDU)<br/> PID = 0 (uncompressed IP header)<br/> data: below described UDP/IP packet</p> <p>After having received the PDCP-Data PDU, the UE decodes the PDU and recognizes with PID value = 0, there was no IP header compression applied for the UDP/IP packet. Therefore, no IP header decompression is applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to the Radio Bearer Loop-Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCP entity.</p> |

| Step | Direction |    | Message    | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|------|-----------|----|------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 8    | →         |    | PDCCP-Data | <p>The UE sends a PDCCP-Data PDU using the RLC-UM-Data-Request-Primitive with the following content back to the SS:<br/> PDU type = 000 (Data PDU with Header)<br/> PID value = 0,1 or 4 (depending on which UDP/IP header format is used by the UE)<br/> data: previously received UDP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                      |
| 9    | ←         |    | PDCCP-Data | <p>The SS sends a PDCCP-Data PDU using the RLC-UM-Data-Request-Primitive with the following content to the UE:<br/> PDU type = 000 (PDCCP-Data PDU)<br/> PID = 1 (Full_Header packet type)<br/> data: below described UDP/IP packet</p> <p>After having received the PDCCP-Data PDU, the UE decodes the PDU and recognizes PID value = 1 applied for this UDP/IP data packet and decompress it with the appropriate method.</p> <p>The data packet is forwarded via PDCCP-SAP to the Radio-Bearer-Loop-Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCCP entity.</p>        |
| 10   | →         |    | PDCCP-Data | <p>The UE sends a PDCCP-Data PDU using the RLC-UM-Data-Request-Primitive with the following content back to the SS:<br/> PDU type = 000 (Data PDU with Header)<br/> PID value = 0,1 or 4 (depending on which UDP/IP header format is used by the UE)<br/> data: below described UDP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                          |
| 11   | ←         |    | PDCCP-Data | <p>The SS sends a PDCCP-Data PDU using the RLC-UM-Data-Request-Primitive with the following content to the UE:<br/> PDU type = 000 (PDCCP-Data PDU)<br/> PID = 4 (Compressed_non-TCP packet type)<br/> data: below described UDP/IP packet</p> <p>After having received the PDCCP-Data PDU, the UE decodes the PDU and recognizes PID value = 1 applied for this UDP/IP data packet and decompress it with the appropriate method.</p> <p>The data packet is forwarded via PDCCP-SAP to the Radio-Bearer-Loop-Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCCP entity.</p> |

| Step                                                                                          | Direction |    | Message    | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-----------------------------------------------------------------------------------------------|-----------|----|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                               | UE        | SS |            |                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 12                                                                                            | →         |    | PDCCP-Data | <p>The UE sends a PDCCP-Data PDU using the RLC-UM-Data-Request-Primitive with the following content back to the SS:<br/> PDU type = 000 (Data PDU with Header)<br/> PID value = 0,1 or 4 (depending on which UDP/IP header format is used by the UE)<br/> data: previously received UDP/IP packet</p> <p>After reception of this UDP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p> |
| Deactivate a UE terminated PS session using IP Header compression (using UE test loop mode 1) |           |    |            |                                                                                                                                                                                                                                                                                                                                                                                                                                          |

### Specific Message Contents

#### RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE terminated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) with the following exceptions:

| Information Element                                                              | Value/remark                                                                                                                                                 |
|----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Capability update requirement<br>— UE radio access capability update requirement | <p>TRUE</p> <p>NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (e.f. PICS/PIXIT statements in GSM) and the user settings</p> |

**RADIO BEARER SETUP message**

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE terminated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) which fit to the here described parameters with the following exceptions:

| Information Element                                                                                                                                                                                                                                                                                                                                                                                            | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RAB information for setup<br>— RAB info<br>— RAB identity<br><br>— CN domain identity<br>— RB information to setup<br>— RB identity<br>— PDCP info<br><br>— PDCP PDU header<br>— Header compression information<br>— CHOICE <i>algorithm type</i><br>— RFC2507<br>— F_MAX_PERIOD<br>— F_MAX_TIME<br>— MAX_HEADER<br>— TCP_SPACE<br>— NON_TCP_SPACE<br>— EXPECT_REORDERING<br>— RLC info<br>— Downlink RLC mode | No. # 23 as described in TS 34.108, Table 6.10.2.1.1<br>Prioritised RABs.<br>QoS parameter:<br>Traffic Class: Interactive or Background,<br>max. UL: 64 kbps and max. DL: 64 kbps as described in<br>TS 34.108, including described physical channel<br>parameters, configuration for UM RLC<br><br>Residual BER as described in TS 34.108, clause: 6.10<br>Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps<br>DCCH, No. #2 (as described in TS 34.108)<br><br>PS domain<br><br>21<br><br>False<br><br>present<br>1<br><br>256 (Default)<br>5 (Default)<br>168 (Default)<br>15 (Default)<br>15 (Default)<br>reordering not expected (Default)<br><br>(UM RLC) |

**Content of PDCP Data PDU (Step 1)**

| Information Element     | Value/remark                                                                                                                                                                                    |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type<br>PID<br>Data | 000<br>00000 (No header compression, PID = 0)<br>PDCP test data type #1: TCP/IP data packet without IP<br>header compression with any data content. The data<br>shall be limited to 1500 bytes. |

**Content of PDCP Data PDU (Step 3)**

| Information Element     | Value/remark                                                                                                                                                                          |
|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type<br>PID<br>Data | 000<br>00001 (Full_Header, PID = 1)<br>PDCP test data type #1: TCP/IP data packet without IP<br>header compression with any data content. The data<br>shall be limited to 1500 bytes. |

## Content of PDCP Data PDU (Step 5)

| Information Element | Value/remark                                                                                                                             |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type            | 000                                                                                                                                      |
| PID                 | 00010 (Compressed_TCP, PID = 2)                                                                                                          |
| Data                | PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 1500 bytes. |

## Content of PDCP Data PDU (Step 7)

| Information Element | Value/remark                                                                                                                             |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type            | 000                                                                                                                                      |
| PID                 | 00000 (No header compression, PID = 0)                                                                                                   |
| Data                | PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 1500 bytes. |

## Content of PDCP Data PDU (Step 9)

| Information Element | Value/remark                                                                                                                             |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type            | 000                                                                                                                                      |
| PID                 | 00001 (Full_Header, PID = 1)                                                                                                             |
| Data                | PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 1500 bytes. |

## Content of PDCP Data PDU (Step 11)

| Information Element | Value/remark                                                                                                                             |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type            | 000                                                                                                                                      |
| PID                 | 00100 (Compressed_non-TCP, PID = 4)                                                                                                      |
| Data                | PDCP test data type #2: UDP/IP data packet without IP header compression with any data content. The data shall be limited to 1500 bytes. |

## 7.3.2.2.2.5 ——— Test requirements

The UE shall return the TCP/IP and UDP/IP data packets as indication, that the previous packets have been received and handled with the correct compression method. This verifies, that the PDCP configuration on UE side works as negotiated by the RRC.

## 7.3.2.2.3 ——— Extension of used compression methods

## 7.3.2.2.3.1 ——— Definition and applicability

Applicable for all UEs supporting RLC UM and a Radio Bearer as described in the Common Test Sequences.

The UE shall be capable to deal with compressed TCP/IP data packets and furthermore to establish a PDCP entity which applies IP header compression protocol: RFC 2507.

## 7.3.2.2.3.2 ——— Conformance requirement

Packet Data Convergence Protocol shall perform the following functions:

———

—— transfer of user data. Transmission of user data means that PDCP receives PDCP SDU from the NAS and forwards it to the RLC layer and vice versa;

- PDCP shall be able (...) to handle them with a correct header compression protocol and furthermore to indicate the type of the packet within a certain protocol.

The PDCP layer shall be able to support several header compression protocols and it shall always be possible to extend the list of supported protocols in the future.

The table (PID value allocation table) is reconfigured every time the PDCP entity is reconfigured, with a change in the supported header compression protocols.

The assignment of the PID values follow the general rules listed below:

- PID values are reassigned for the PDCP entity after renegotiation of the header compression protocols;
- the list of negotiated (or re-negotiated) header compression entities shall be examined, starting from the first one in the list. The number of PID values to be assigned is specified in the clause for this protocol.

#### Reference(s)

TS 25.323 clause 5.

TS 25.323 clause 5.1.1.

TS 25.323 clause 5.1.

#### 7.3.2.2.3.3 — Test purpose

1. To verify, that the UE is able to handle an extended PID value allocation table after PDCP reconfiguration as configured by RRC.

#### 7.3.2.2.3.4 — Method of test

#### Initial conditions

UE is in Idle mode. Usage of "PDCP Data" PDU and no IP header compression is configured.

#### Related ICS/IXIT Statement(s)

Support of IP header compression protocol RFC 2507 — YES/NO

Support of PS — Yes/No

PIXIT: Test\_PDCP\_TCP/IP\_Packet1

PIXIT: Test\_PDCP\_TCP/IP\_Packet2

#### Test procedure

- a) The SS setups a packet-switched session including radio bearer and UE test loop mode 1 in RLC-UM using Common test procedures for mobile terminated PS-switched sessions (with the UE test loop mode 1). Usage of "PDCP Data PDU" and no optimisation method has been configured by higher layers.
- b) The SS sends a TCP/IP data packet (no compression packet type), PID=0.
- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet correctly. Afterwards it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
- d) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.
- e) The SS reconfigures (using RRC Radio Bearer Reconfiguration message) the PDCP entity by extending the PID value allocation table and therefore the applied optimisation method with the IP header compression protocol RFC 2507. The UE test loop mode 1 in RLC-UM is still active.



- ~~f) The SS sends a TCP/IP data packet (no compression packet type), PID=0.~~
- ~~g) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet correctly. Afterwards it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.~~
- ~~h) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.~~
- ~~i) The SS sends a TCP/IP data packet with packet type: Full\_Header, PID=1.~~
- ~~j) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet correctly. Afterwards it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.~~
- ~~k) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.~~
- ~~l) The SS deactivates the UE test loop mode and terminates the connection.~~

## Expected sequence

| Step                                                                                               | Direction |                                           | Message                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Comments |
|----------------------------------------------------------------------------------------------------|-----------|-------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|
|                                                                                                    | UE        | SS                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |          |
| Setup a UE terminated PS session using IP Header compression in UM RLC (using UE test loop mode 1) |           |                                           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |          |
| 1                                                                                                  | ←         | PDCCP-Data                                | <p>The SS creates a TCP/IP packet without IP header compression.</p> <p>The SS sends a PDCCP-Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE:<br/>PDU type = 000 (PDCCP-Data PDU)<br/>PID = 0 (uncompressed IP header)<br/>data: below described TCP/IP packet</p> <p>After having received the PDCCP-Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression). Therefore, no IP header decompression shall be applied for this packet.</p> <p>The data packet is forwarded via PDCCP-SAP to its Radio Bearer Loop Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCCP entity.</p> |          |
| 2                                                                                                  | →         | PDCCP-Data                                | <p>The UE sends a PDCCP-Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS:<br/>PDU type = 000 (PDCCP-Data PDU)<br/>PID value = 0<br/>data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                                                                                                                                                                             |          |
| 3                                                                                                  | ←         | RRC-RADIO-BEARER RECONFIGURATION          | SS extends the "PID value allocation table" with IP header compression PID (RFC-2507) in the UE.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |          |
| 4                                                                                                  | →         | RRC-RADIO-BEARER RECONFIGURATION COMPLETE | UE acknowledges its new settings                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |          |
| 5                                                                                                  | ←         | PDCCP-Data                                | <p>The SS sends a PDCCP-Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE:<br/>PDU type = 000 (PDCCP-Data PDU)<br/>PID = 0 (normal packet type [TCP/IP])<br/>data: below described TCP/IP packet.</p> <p>After having received the PDCCP-Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression). Therefore, no IP header decompression shall be applied for this packet.</p> <p>The data packet is forwarded via PDCCP-SAP to its Radio Bearer Loop Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCCP entity.</p>                                                                |          |

| Step                                                                                          | Direction |    | Message    | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|-----------------------------------------------------------------------------------------------|-----------|----|------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                               | UE        | SS |            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 6                                                                                             |           | →  | PDCCP-Data | <p>The UE sends a PDCCP-Data PDU using the RLC-UM-Data-Request-Primitive with the following content back to the SS:<br/> PDU type = 000 (PDCCP-Data PDU)<br/> PID value = 0 to 3<br/> data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                                                                                                  |
| 7                                                                                             |           | ←  | PDCCP-Data | <p>The SS sends a PDCCP-Data PDU using the RLC-UM-Data-Request-Primitive with the following content to the UE:<br/> PDU type = 000 (PDCCP-Data PDU)<br/> PID = 1 (Full_Header packet type [TCP/IP])<br/> data: below described TCP/IP packet</p> <p>After having received the PDCCP-Data PDU, the UE decodes the PDU and recognizes PID value = 1 applied for this TCP/IP data packet and shall decompress it with the appropriate method.</p> <p>The data packet is forwarded via PDCCP-SAP to its Radio-Bearer-Loop-Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCCP entity.</p> |
| 8                                                                                             |           | →  | PDCCP-Data | <p>The UE sends a PDCCP-Data PDU using the RLC-UM-Data-Request-Primitive with the following content back to the SS:<br/> PDU type = 000 (PDCCP-Data PDU)<br/> PID value = 0 to 3<br/> data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                                                                                                  |
| Deactivate a UE terminated PS session using IP Header compression (using UE test loop mode 1) |           |    |            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

### Specific Message Contents

#### RRC RADIO BEARER RECONFIGURATION message

The contents of the RRC RADIO BEARER RECONFIGURATION message applied in the preamble "Setup a UE terminated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) with the following exceptions:

| Information Element                | Value/remark                      |
|------------------------------------|-----------------------------------|
| RB-information-to-reconfigure-list | 1                                 |
| RB-information-to-reconfigure      |                                   |
| → PDCCP-info                       |                                   |
| → PDCCP-PDU-header                 | present                           |
| → Header compression information   | 1                                 |
| → CHOICE algorithm-type            |                                   |
| → RFC2507                          |                                   |
| → F_MAX_PERIOD                     | 256 (Default)                     |
| → F_MAX_TIME                       | 5 (Default)                       |
| → MAX_HEADER                       | 168 (Default)                     |
| → TCP_SPACE                        | 15 (Default)                      |
| → NON_TCP_SPACE                    | 15 (Default)                      |
| → EXPECT_REORDERING                | reordering-not-expected (Default) |

**RRC CONNECTION SETUP message**

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE terminated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) with the following exceptions:

| Information Element                                                              | Value/remark                                                                                                                                      |
|----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| Capability update requirement<br>— UE radio access capability update requirement | TRUE<br>NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings |

**RADIO BEARER SETUP message**

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE terminated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) which fit to the here described parameters with the following exceptions:

| Information Element                                       | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-----------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RAB information for setup<br>— RAB info<br>— RAB identity | No. # 23 as described in TS 34.108, Table 6.10.2.1.1<br>Prioritised RABs.<br>QoS parameter:<br>Traffic Class: Interactive or Background,<br>max. UL: 64 kbps and max. DL: 64 kbps as described in<br>TS 34.108, including described physical channel<br>parameters, configuration for UM RLC<br><br>Residual BER as described in TS 34.108, clause: 6.10<br>Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps<br>DCCH, No. #2 (as described in TS 34.108) |
| — CN domain identity                                      | PS domain                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| — RB information to setup<br>— RB identity                | 21                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| — PDCP info                                               | present                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| — PDCP PDU header                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| — RLC info                                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| — Downlink RLC mode                                       | (UM RLC)                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

**Content of PDCP Data PDU (Step 1 and 5)**

| Information Element | Value/remark                                                                                                                                   |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type            | 000                                                                                                                                            |
| PID                 | 00000 (No header compression, PID = 0)                                                                                                         |
| Data                | PDCP test data type #1: TCP/IP data packet without IP<br>header compression with any data content. The data<br>shall be limited to 1500 bytes. |

**Content of PDCP Data PDU (Step 7)**

| Information Element | Value/remark                                                                                                                                   |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type            | 000                                                                                                                                            |
| PID                 | 00001 (Full_Header, PID = 1)                                                                                                                   |
| Data                | PDCP test data type #1: TCP/IP data packet without IP<br>header compression with any data content. The data<br>shall be limited to 1500 bytes. |

#### 7.3.2.2.3.5 ——— Test requirements

After PDCP reconfiguration, the UE shall return the TCP/IP data packets as indication, that the extension of used optimisation method are applied by UE. This verifies, that the PDCP configuration on UE side works as negotiated by the RRC.

#### 7.3.2.2.4 ——— Compression type used for different entities

##### 7.3.2.2.4.1 ——— Definition and applicability

Applicable only for an UE supporting the establishment of more than one PDCP entity in parallel, i.e. it shall be possible to configure more than one Radio Bearer Loop Back entities (each PDCP entity are assigned via PDCP-SAP to its own Radio Bearer Loop Back entity).

Applicable for all UEs supporting two Radio Bearers in RLC UM and RLC AM as described in this test case, clause

##### 7.3.2.2.4.6 Combined PDCP Acknowledged and Unacknowledged mode configuration:

The UE shall be capable to deal with compressed TCP/IP data packets and furthermore it shall apply IP header compression protocol RFC 2507.

##### 7.3.2.2.4.2 ——— Conformance requirement

Packet Data Convergence Protocol shall perform the following functions:

—...

—transfer of user data. Transmission of user data means that PDCP receives PDCP SDU from the NAS and forwards it to the RLC layer and vice versa;

—PDCP shall be able (...) to handle them with a correct header compression protocol and furthermore to indicate the type of the packet within a certain protocol.

The assignment of the PID values follow the general rules listed below:

—PID values are assigned independently to each PDCP entity;

Different PDCP entities may include header compression protocols of the same type

#### Reference(s)

TS 25.323 clause 5.

TS 25.323 clause 5.1.1.

TS 25.323 clause 5.1.

##### 7.3.2.2.4.3 ——— Test purpose

NOTE:—For this test case, the SS shall be configured to handle more than one received PDCP messages.

1. To verify, that a configured IP header compression protocol are applied to compress and decompress TCP/IP data packets by several PDCP entities in parallel, if more than one entities are established, i.e. the UE uses the same PID to transmit two TCP/IP data packets with the same content in parallel using two Radio Bearer configurations.

##### 7.3.2.2.4.4 ——— Method of test

#### Initial conditions

UE is in Idle mode. Usage of "PDCP Data" PDU and IP header compression is configured for both PDCP entities.

### Related ICS/IXIT Statement(s)

~~Establishment of more than one PDCP entities – YES/NO.~~

~~Support of IP header compression protocol RFC 2507 – YES/NO~~

~~Support of UM RB and AM RB~~

~~Support of PS – Yes/No~~

~~IXIT: Test\_PDCP\_TCP/IP\_Packet1~~

~~IXIT: Test\_PDCP\_TCP/IP\_Packet2~~

### Test procedure

- ~~a) The SS setups a packet switched session including two radio bearer configurations in parallel in UE test loop mode 1 and in RLC UM using Common test procedures for mobile terminated PS switched sessions. Usage of IP header compression protocol RFC 2507 has been configured by higher layers.~~
- ~~b) The SS sends two successive a "normal" TCP/IP data packet, PID=0 via both PDCP configurations to their peer entities.~~
- ~~c) After having received the TCP/IP data packets, the PDCP entities of the UE shall recognize the PID value and shall handle the received data packet independent of the used PID with the correct decompression method. Then they forward the data to their Radio Bearer Loop Back entity. Both received data shall be returned by each Radio Bearer Loop Back entity.~~
- ~~d) The SS receives and decodes TCP/IP data packets according to the inserted PID. The decoded data packets shall be identical with the data as sent before.~~
- ~~e) After having received the TCP/IP data packets, the PDCP entities of the UE shall recognize the PID value and shall handle the received data packets independent of the used PID with the correct decompression method. Then they forward the data to their Radio Bearer Loop Back entity. Both received data shall be returned by each Radio Bearer Loop Back entity.~~
- ~~f) The SS receives and decodes TCP/IP data packets according to the inserted PID. The decoded data packets shall be identical with the data as sent before.~~
- ~~g) The SS deactivates the UE test loop mode and terminates the connection.~~

## Expected sequence

| Step                                                                                               | Direction |    | Message   | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|----------------------------------------------------------------------------------------------------|-----------|----|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                    | UE        | SS |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Setup a UE terminated PS session using IP Header compression in UM RLC (using UE test loop mode 1) |           |    |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 1                                                                                                  | ←         |    | PDCP Data | <p>The SS sends two successive a PDCP Data PDU using the RLC-UM-Data-Request Primitive via both PDCP entities with the following contents to the UE:<br/>PDU type = 000 (PDCP Data PDU)<br/>PID = 0 (uncompressed IP header)<br/>data: below described TCP/IP packet</p> <p>After having received both PDCP Data PDUs, the UE decodes each PDU and recognizes PID value = 0 (no IP header compression applied for both TCP/IP data packets).</p> <p>Although the same PID is used for both PDUs, the UE shall handle they with the correct method and it forwards both data packets via PDCP-SAPs to their Radio Bearer Loop Back (RB-LB) entities.</p> <p>The RB-LB entities in UE test loop mode 1 return the received data packets and send they back to their PDCP entities.</p> |

| Step                                                                                          | Direction |    | Message   | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|-----------------------------------------------------------------------------------------------|-----------|----|-----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                               | UE        | SS |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 2                                                                                             | →         |    | PDCP Data | <p>The UE sends back for each PDCP configuration a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS:<br/>PDU type = 000 (PDCP Data PDU)<br/>PID value = 0 to 3<br/>data: previously received TCP/IP packet</p> <p>After reception of TCP/IP data packets, the SS applies the appropriate decoding function for both received messages depending on which PID was assigned to the received data</p>                                                                                                                                                                                                                                                                                                                                             |
| 3                                                                                             | ←         |    | PDCP Data | <p>The SS sends two successive a PDCP Data PDU using the RLC-UM-Data-Request Primitive via both PDCP entities with the following contents to the UE:<br/>PDU type = 000 (PDCP Data PDU)<br/>PID = 1 (Full_Header packet type [TCP/IP])<br/>data: below described TCP/IP packet</p> <p>After having received both PDCP Data PDUs, the UE decodes each PDU and recognizes PID value = 1 (Full_Header packet type applied for both TCP/IP data packets).</p> <p>Although the same PID is used for both PDUs, the UE shall handle them with the correct method and it forwards both data packets via PDCP-SAPs to their Radio Bearer Loop-Back (RB-LB) entities.</p> <p>The RB-LB entities in UE test loop mode 1 return the received data packets and send them back to their PDCP entities.</p> |
| 4                                                                                             | →         |    | PDCP Data | <p>The UE sends back for each PDCP configuration a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS:<br/>PDU type = 000 (PDCP Data PDU)<br/>PID value = 0 to 3<br/>data: previously received TCP/IP packet</p> <p>After reception of TCP/IP data packets, the SS applies the appropriate decoding function for both received messages depending on which PID was assigned to the received data</p>                                                                                                                                                                                                                                                                                                                                             |
| Deactivate a UE terminated PS session using IP Header compression (using UE test loop mode 1) |           |    |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |

### Specific Message Contents

#### RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE terminated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) with the following exceptions:

| Information Element                                                              | Value/remark                                                                                                                                                 |
|----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Capability update requirement<br>— UE radio access capability update requirement | <p>TRUE</p> <p>NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings</p> |



## RADIO BEARER SETUP message

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE terminated PS session using IP Header compression in UM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for UM) which fit to the here described parameters with the following exceptions:

| Information Element             | Value/remark                                           |
|---------------------------------|--------------------------------------------------------|
| RAB information for setup       |                                                        |
| -RAB info                       | No. # 23 as described in TS 34.108, Table 6.10.2.1.1   |
| -RAB identity                   | Prioritised RABs.                                      |
|                                 | QoS parameter:                                         |
|                                 | Traffic Class: Interactive or Background,              |
|                                 | max. UL: 64 kbps and max. DL: 64 kbps as described in  |
|                                 | TS 34.108, including described physical channel        |
|                                 | parameters, configuration for UM RLC configuration for |
|                                 | UM RLC                                                 |
|                                 | Residual BER as described in TS 34.108, clause: 6.10   |
|                                 | Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps       |
|                                 | DCCH, No. #2 (as described in TS 34.108)               |
| -CN domain identity             | PS domain                                              |
| -RB information to setup        |                                                        |
| -RB identity                    | 20                                                     |
| -PDCP info                      |                                                        |
| -PDCP PDU header                | present                                                |
| -Header compression information | 1                                                      |
| -CHOICE <i>algorithm type</i>   |                                                        |
| -RFC2507                        |                                                        |
| -F_MAX_PERIOD                   | 256 (Default)                                          |
| -F_MAX_TIME                     | 5 (Default)                                            |
| -MAX_HEADER                     | 168 (Default)                                          |
| -TCP_SPACE                      | 15 (Default)                                           |
| -NON_TCP_SPACE                  | 15 (Default)                                           |
| -EXPECT_REORDERING              | reordering not expected (Default)                      |
| -RLC info                       | (AM RLC)                                               |
| -Downlink RLC mode              | (NOTE: for RB ID 21, the same RAB configurations are   |
| -RB information to setup        | used (No. # 23 as described in TS 34.108) as described |
|                                 | for RB ID 20)                                          |
| -RB identity                    | 21                                                     |
| -PDCP info                      |                                                        |
| -PDCP PDU header                | present                                                |
| -Header compression information | 1                                                      |
| -CHOICE <i>algorithm type</i>   |                                                        |
| -RFC2507                        |                                                        |
| -F_MAX_PERIOD                   | 256 (Default)                                          |
| -F_MAX_TIME                     | 5 (Default)                                            |
| -MAX_HEADER                     | 168 (Default)                                          |
| -TCP_SPACE                      | 15 (Default)                                           |
| -NON_TCP_SPACE                  | 15 (Default)                                           |
| -EXPECT_REORDERING              | reordering not expected (Default)                      |
| -RLC info                       |                                                        |
| -Downlink RLC mode              | (UM RLC)                                               |

## Content of both PDCP Data PDU (Step 1)

| Information Element | Value/remark                                          |
|---------------------|-------------------------------------------------------|
| PDU type            | 000                                                   |
| PID                 | 00000 (No header compression, PID = 0)                |
| Data                | PDCP test data type #1: TCP/IP data packet without IP |
|                     | header compression with any data content. The data    |
|                     | shall be limited to 1500 bytes.                       |

## Content of both PDCP Data PDU (Step 3)

| Information Element | Value/remark                                                                                                                             |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type            | 000                                                                                                                                      |
| PID                 | 00001 (Full_Header, PID = 1)                                                                                                             |
| Data                | PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 1500 bytes. |

## 7.3.2.2.4.5 Test requirements

The UE shall return both TCP/IP data packets as indication that the previous received data packets associated with the same PID value are handled in parallel with the same decompression protocol. This verifies, that more than one PDCP configuration on UE side using the same compression protocol is able to apply it in parallel.

## 7.3.2.2.4.6 Combined PDCP Acknowledged and Unacknowledged mode configuration

This configuration is based on the interactive or background / UL:64 DL 64 kbps / PS RAB. The SRB configurations are UL:3.4 DL:3.4 kbps for DCCH aligned to this combined RABs are described for SRB DL 3.4 kbps in TS 34.108, clause 6.10.2.4.1.2.2 and for SRB DL 3.4 kbps in TS 34.108, clause 6.10.2.4.1.2.1. The TFCS refer to TS34.108, clause 6.10.2.4.1.24.1.1.3 for UL and clause 6.10.2.4.1.25.2.1.3 for DL, the Physical channel parameters refer to TS 34.108, clause 6.10.2.4.1.24.1.2 for UL clause 6.10.2.4.1.25.2.2 and for DL accordingly. The configuration is applied to PDCP test cases using both the acknowledged and unacknowledged mode.

Table 7.3.2.2.4/1: Uplink Transport channel parameter for combined RABs PS AM\_UM

| Higher layer | RAB/Signalling RB                                           |           | RAB #20                        | RAB #21 |
|--------------|-------------------------------------------------------------|-----------|--------------------------------|---------|
| RLC          | Logical channel type                                        |           | DTCH                           | DTCH    |
|              | RLC mode                                                    |           | AM                             | UM      |
|              | Payload sizes, bit                                          |           | 316                            | 324     |
|              | Max data rate, bps                                          |           | 63200                          | 64800   |
|              | TrD PDU header, bit                                         |           | 16                             | 8       |
| MAC          | MAC header, bit                                             |           | 4                              |         |
|              | MAC multiplexing                                            |           | 2 logical channel multiplexing |         |
| Layer 1      | TrCH type                                                   |           | DCH                            |         |
|              | TB sizes, bit                                               |           | 336                            |         |
|              | TFS                                                         | TF0, bits | 0x336                          |         |
|              |                                                             | TF1, bits | 1x336                          |         |
|              |                                                             | TF2, bits | 2x336                          |         |
|              |                                                             | TF3, bits | 3x336                          |         |
|              |                                                             | TF4, bits | 4x336                          |         |
|              | TTI, ms                                                     |           | 20                             |         |
|              | Coding type                                                 |           | TC                             |         |
|              | CRC, bit                                                    |           | 16                             |         |
|              | Max number of bits/TTI after channel coding                 |           | 4236                           |         |
|              | Uplink: Max number of bits/radio frame before rate matching |           | 2118                           |         |
|              | RM attribute                                                |           | 130-170                        |         |

Table 7.3.2.2.4/2: Downlink Transport channel parameter for combined RABs PS AM\_UM

| Higher layer | RAB/Signalling RB    | RAB #20 | RAB #21 |
|--------------|----------------------|---------|---------|
| RLC          | Logical channel type | DTCH    | DTCH    |
|              | RLC mode             | AM      | UM      |
|              | Payload sizes, bit   | 316     | 324     |

|         |                                             |                                |       |
|---------|---------------------------------------------|--------------------------------|-------|
|         | Max data rate, bps                          | 63200                          | 64800 |
|         | TrD PDU header, bit                         | 16                             | 8     |
| MAC     | MAC header, bit                             | 4                              |       |
|         | MAC multiplexing                            | 2 logical channel multiplexing |       |
| Layer 1 | TrCH type                                   | DCH                            |       |
|         | TB sizes, bit                               | 336                            |       |
|         | TFS                                         | TF0, bits                      | 0x336 |
|         |                                             | TF1, bits                      | 1x336 |
|         |                                             | TF2, bits                      | 2x336 |
|         |                                             | TF3, bits                      | 3x336 |
|         |                                             | TF4, bits                      | 4x336 |
|         | TTI, ms                                     | 20                             |       |
|         | Coding type                                 | TC                             |       |
|         | CRC, bit                                    | 16                             |       |
|         | Max number of bits/TTI after channel coding | 4236                           |       |
|         | RM attribute                                | 130-170                        |       |

### 7.3.2.2.5 ~~Reception of not defined PID values~~

#### 7.3.2.2.5.1 ~~Definition and applicability~~

Applicable for all UEs supporting RLC UM and a Radio Bearer as described in the Common Test Sequences.

The UE shall be capable to deal with compressed TCP/IP data packets and furthermore to establish a PDCP entity, which applies PDCP Data PDU if no IP header compression protocol, is negotiated.

The UE shall not forward invalid PDCP PDU data contents to its Radio Bearer.

#### 7.3.2.2.5.2 ~~Conformance requirement~~

PDCP shall be able (...) to handle them with a correct header compression protocol and furthermore to indicate the type of the packet within a certain protocol;

PID values that are used and are not defined invalidate the PDCP PDU;

#### Reference(s)

TS 25.323 clause 5.1.1.

TS 25.323 clause 5.1.2.1.

#### 7.3.2.2.5.3 ~~Test purpose~~

1. ~~To verify, that a UE considers a received PDCP PDU message with not defined PID value as invalid, i.e. such an invalid PDCP PDU is not forwarded to the Radio Bearer entity on UE side. Therefore the UE using test loop mode 1 does not return such data packet to the SS.~~

#### 7.3.2.2.5.4 ~~Method of test~~

##### Initial conditions

UE is in Idle mode. Usage of "PDCP Data" PDU and no IP header compression is configured.

##### Related ICS/IXIT Statement(s)

Support of IP header compression protocol RFC 2507 – YES/NO

Support of PS – Yes/No

IXIT: Test\_PDCP\_TCP/IP\_Packet1

IXIT: Test\_PDCP\_TCP/IP\_Packet2

## Test procedure

- a) The SS setups a packet-switched session including radio bearer and UE test loop mode 1 in RLC UM using Common test procedures for mobile-terminated PS-switched sessions. Usage of "PDCP Data PDU" and no PDCP IP header compression protocol has been configured by higher layers.
- b) The SS sends a "normal" TCP/IP data packet (no compression packet type), PID=0.
- c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decoding method. Afterwards it forwards the data to its Radio Bearer Loop-Back entity. The received data shall be returned by the UE via its PDCP configuration.
- d) The SS receives and decodes TCP/IP data packets according to the inserted PID. The decoded data packets shall be identical with the data as sent before.
- e) The SS sends a TCP/IP data packet with packet type: Full\_Header, PID=1.
- f) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet with the correct decoding method.
- g) The SS waits an amount of time to make sure, that no returned data packet was sent by UE.
- h) The SS deactivates the UE test loop mode and terminates the connection.

## Expected sequence

| Step                                                                                               | Direction |    | Message   | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|----------------------------------------------------------------------------------------------------|-----------|----|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                    | UE        | SS |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Setup a UE terminated PS session using IP Header compression in UM RLC (using UE test loop mode 1) |           |    |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| 1                                                                                                  | ←         |    | PDCP Data | <p>The SS sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content to the UE:<br/>PDU type = 000 (PDCP Data PDU)<br/>PID = 0 (uncompressed IP header)<br/>data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression)<br/>Therefore, no IP header decompression shall be applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCP entity.</p> |
| 2                                                                                                  | →         |    | PDCP Data | <p>The UE sends a PDCP Data PDU using the RLC-UM-Data-Request Primitive with the following content back to the SS:<br/>PDU type = 000 (PDCP Data PDU)<br/>PID value = 0<br/>data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                                                                                                        |

| Step                                                                                          | Direction |    | Message   | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|-----------------------------------------------------------------------------------------------|-----------|----|-----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                               | UE        | SS |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 3                                                                                             | ←         |    | PDCP-Data | <p>The SS sends a PDCP-Data PDU using the RLC-UM-Data-Request-Primitive with the following content to the UE:<br/> PDU-type = 000 (PDCP-Data-PDU)<br/> PID = 1 (Full-Header packet type [TCP/IP])<br/> data: below-described TCP/IP packet.</p> <p>After having received the PDCP-Data PDU, the UE shall recognize, that a not-defined PID-value (as configured by higher layers) is inserted in the PDCP-PDU.</p> <p>The UE shall consider this PDU as invalid, i.e. the data packet is not forwarded via PDCP-SAP to its Radio-Bearer-Loop-Back (RB-LB) entity.</p> <p>Therefore this data packet is not returned to the SS.</p> |
| 4                                                                                             |           |    |           | <p>The SS waits a amount of time to make sure, that the previously sent data packet is not returned to the SS.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Deactivate a UE terminated PS session using IP-Header compression (using UE test loop mode 1) |           |    |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

### Specific Message Contents

#### RRC CONNECTION SETUP message

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE-terminated PS session using IP-Header compression in UM RLC" of this test case is identical to those of the default contents of layer-3 messages for RRC tests [TS 34.123-1] (PS connection for UM) with the following exceptions:

| Information Element                                                              | Value/remark                                                                                                                                      |
|----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| Capability update requirement<br>— UE radio access capability update requirement | TRUE<br>NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings |

#### RADIO BEARER SETUP message

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE-terminated PS session using IP-Header compression in UM RLC" of this test case is identical to those of the default contents of layer-3 messages for RRC tests [TS 34.123-1] (PS connection for UM) which fit to the here-described parameters with the following exceptions:

| Information Element                                                                                                                                                                                                                | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RAB information for setup<br>— RAB info<br>—— RAB identity<br><br><br><br><br><br>—— CN domain identity<br>— RB information to setup<br>—— RB identity<br>—— PDCP info<br>—— PDCP PDU header<br>— RLC info<br>—— Downlink RLC mode | No. # 23 as described in TS 34.108, Table 6.10.2.1.1<br>Prioritised RABs.<br>QoS parameter:<br>Traffic Class: Interactive or Background,<br>max. UL: 64 kbps and max. DL: 64 kbps as described in<br>TS 34.108, including described physical channel<br>parameters, configuration for UM RLC<br><br>Residual BER as described in TS 34.108, clause: 6.10<br>Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps<br>DCCH, No. #2 (as described in TS 34.108)<br><br>PS domain<br><br>21<br><br>present<br><br>(UM RLC) |

#### Content of PDCP Data PDU (Step 1)

| Information Element     | Value/remark                                                                                                                                                                                   |
|-------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type<br>PID<br>Data | 000<br>00000 (No header compression, PID = 0)<br>PDCP test data type #1: TCP/IP data packet without IP<br>header compression with any data content. The data<br>shall be limited to 1500 bytes |

#### Content of PDCP Data PDU (Step 3)

| Information Element     | Value/remark                                                                                                                                                                          |
|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type<br>PID<br>Data | 000<br>00001 (Full_Header, PID = 1)<br>PDCP test data type #1: TCP/IP data packet without IP<br>header compression with any data content. The data<br>shall be limited to 1500 bytes. |

#### 7.3.2.2.5.5 — Test requirements

The UE shall return the received TCP/IP data packet using the PDCP Data PDU with PID = 0 as indication, that the UE works as configured.

The UE shall not return the TCP/IP data packet using the PDCP Data PDU with PID = 1 as indication, that this PDU was considered as invalid by the UE. This verifies, that the PDCP configuration on UE side has considered this PDU as invalid.

### 7.3.3 — PDCP sequence numbering when lossless SRNS Relocation

#### 7.3.3.1 — Data transmission if lossless SRNS Relocation is supported

##### 7.3.3.1.1 — Definition and applicability

Applicable for all UEs supporting RLC AM, RLC in-sequence delivery, a Radio Bearer as described in the Common Test Sequences and lossless SRNS relocation.

The UE shall be capable to deal with uncompressed TCP/IP data packets and furthermore to establish a PDCP entity which applies PDCP Sequence Numbering

### 7.3.3.1.2 ~~Conformance requirement~~

The PDCP layer shall carry out the following functions during lossless SRNS relocation:

- ~~—support PDCP sequence numbering as specified in clause 5.4.1.~~

The PDCP layer shall carry out the following during lossless SRNS relocation:

- ~~—provide unconfirmed PDCP SDUs and sequence numbers for forwarding to the target RNC.~~

### Reference(s)

~~TS 25.323 clause 5.4.~~

### 7.3.3.1.3 ~~Test purpose~~

- ~~1. To verify, that a UE supporting lossless SRNS relocation is able to receive and to send IP data packets by using PDCP Sequence Numbering as configured by higher layers.~~

### 7.3.3.1.4 ~~Method of test~~

#### Initial conditions

~~SS: 2 cells – Cell A belonging to the valid SRNS (Source SRNS), Cell B belonging to the DRNS (Target SRNS). Both cells are neighbour cells. Cell A has a higher RF power level than Cell B such that an UE shall find Cell A more suitable for service.~~

~~UE: It is in Idle mode and has selected cell A with valid SRNS (Source SRNS). Usage of "PDCP Data" PDU and no IP header compression is configured.~~

#### Related ICS/IXIT Statement(s)

~~Support of lossless SRNS Relocation – YES/NO~~

~~Support of PS – Yes/No~~

~~IXIT: Test\_PDCP\_TCP/IP\_Packet1~~

~~IXIT: Test\_PDCP\_TCP/IP\_Packet2~~

#### Test procedure

- ~~a) The SS setups a packet switched session including Radio Bearer and UE test loop mode 1 in RLC AM and in-sequence delivery using Common test procedures for mobile terminated PS switched sessions in Cell A. Usage of "PDCP Data" PDU, support of lossless SRNS relocation and no IP header compression has been configured by higher layers. The PDCP SN window size has been negotiated by RRC.~~
- ~~b) The SS sends a TCP/IP data packet (no compression packet type), PID=0.~~
- ~~c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet correctly. Afterwards it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.~~
- ~~d) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.~~
- ~~e) The SS starts to broadcast BCCH messages on the primary CPICH in cell B with a power level higher than in cell A. The UE shall chose cell B to be more suitable for service and hence perform a cell reselection.~~
- ~~f) After completion of cell reselection, the UE transmits a CELL UPDATE message to the SS on the uplink CCCH of cell B with the Cell update cause "Cell Reselection".~~

- ~~g) After having performed SRNS relocation (target RNC allocated with new S-RNTI for the UE), the Target SRNS is the valid SRNS and the SS sends a "CELL UPDATE CONFIRM" message with new RNC\_ID to indicate the completion of the cell update.~~
- ~~h) The UE shall confirm the reallocation.~~
- ~~i) The SS sends the next TCP/IP data packet (no compression packet type), PID=0 using the "PDCP Data" PDU to the UE.~~
- ~~j) After having received the TCP/IP data packet, the UE shall recognize the PID value and shall handle the received data packet correctly. Afterwards it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.~~
- ~~k) The SS receives and decodes TCP/IP data packets according to the inserted PID. The decoded data packets shall be identical with the data as sent before.~~
- ~~l) The SS deactivates the UE test loop mode and terminates the connection.~~



## Expected sequence

| Step                                                                                                         | Direction |                 | Message                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Comments |
|--------------------------------------------------------------------------------------------------------------|-----------|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|
|                                                                                                              | UE        | SS              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |          |
| Setup a UE terminated PS session using IP Header compression in AM RLC (using UE test loop mode 1) in Cell A |           |                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |          |
| 1                                                                                                            | ←         | PDCCP Data      | <p>The SS creates a TCP/IP packet without IP header compression.</p> <p>The SS sends a PDCCP Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE:<br/>PDU type = 000 (PDCCP Data PDU)<br/>PID = 0 (uncompressed IP header)<br/>data: below described TCP/IP packet</p> <p>After having received the PDCCP Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression). Therefore, no IP header decompression shall be applied for this packet.</p> <p>The data packet is forwarded via PDCCP-SAP to its Radio Bearer Loop Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCCP entity.</p> |          |
| 2                                                                                                            | →         | PDCCP Data      | <p>The UE sends a PDCCP Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS:<br/>PDU type = 000 (PDCCP Data PDU)<br/>PID value = 0<br/>data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                                                                                                                                                                             |          |
| 3                                                                                                            | →         | RRC CELL UPDATE | The SS increases the RF power level of cell B and decreases the power level of Cell A such that the UE finds cell B more suitable for service.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |          |
| 4                                                                                                            |           |                 | The UE cell reselection is performed and Cell B are selected for service.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |          |
| 5                                                                                                            |           |                 | Then, the UE shall inform the SS about the new cell selection by sending cell update with new parameters (parameter values as used in RRC testing).                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |          |

| Step                                                                                          | Direction |    | Message                    | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-----------------------------------------------------------------------------------------------|-----------|----|----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                               | UE        | SS |                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 6                                                                                             |           | ←  | RRC-CELL-UPDATE-CONFIRM    | After having performed SRNS-relocation, the Target SRNS is the valid SRNS and the SS sends a "CELL-UPDATE-CONFIRM" message with new parameter "RNC_ID" to indicate the completion of SRNS-relocation (parameters as used in RRC testing).                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 7                                                                                             |           | →  | RNTI-REALLOCATION-COMPLETE | The UE confirms the newly received information (parameters as used in RRC testing).                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 8                                                                                             |           | ←  | PDCP-Data                  | <p>The SS sends the next PDCP-Data-PDU using the RLC-AM-Data-Request Primitive with the following content to the UE:<br/> PDU-type = 000 (PDCP-Data-PDU)<br/> PID = 0 (uncompressed IP header)<br/> data: below described TCP/IP packet</p> <p>After having received the PDCP-Data PDU, the UE decodes the PDU and recognizes PID-value = 0 (no IP header-compression)</p> <p>Therefore, no IP header-decompression shall be applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop-Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test-loop mode 1 returns the received data packet and sends it back to its PDCP-entity.</p> |
| 9                                                                                             |           | →  | PDCP-Data                  | <p>The UE sends a PDCP-Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS:<br/> PDU-type = 000 (PDCP-Data-PDU)<br/> PID-value = 0<br/> data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP-data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                                                                                                                  |
| Deactivate a UE terminated PS-session using IP-Header-compression (using UE test-loop mode 1) |           |    |                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |

### Specific Message Contents

#### RRC-CONNECTION-SETUP message

The contents of the RRC-CONNECTION-SETUP message applied in the preamble "Setup a UE-terminated PS session using IP-Header-compression in AM-RLC" of this test case is identical to those of the default contents of layer-3 messages for RRC tests [TS 34.123-1] (PS-connection for AM) with the following exceptions:

| Information Element                                                              | Value/remark                                                                                                                                      |
|----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| Capability update requirement<br>— UE radio-access-capability update requirement | TRUE<br>NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (e.f. PICS/PIXIT-statements in GSM) and the user settings |

**RADIO-BEARER-SETUP message**

The contents of the **RADIO-BEARER-SETUP** message applied in the preamble "Setup a UE terminated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) which fit to the here described parameters with the following exceptions:

| Information Element                                                                                                                                                                                                                         | Value/remark                                                                                                                                                                                                                                                                                 |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RAB information for setup<br>- RAB info<br>- RAB identity                                                                                                                                                                                   | No. # 23 as described in TS 34.108, Table 6.10.2.1.1<br>Prioritised RABs.<br>QoS-parameter:<br>Traffic Class: Interactive or Background,<br>max. UL: 64 kbps and max. DL: 64 kbps as described in<br>TS 34.108, including described physical channel<br>parameters, configuration for AM RLC |
| - CN domain identity<br>- RB information to setup<br>- RB identity<br>- PDCP info<br>- Max PDCP SN window size<br>- Support of lossless SRNS relocation<br>- PDCP PDU header<br>- RLC info<br>- Downlink RLC mode<br>- In-sequence delivery | Residual BER as described in TS 34.108, clause: 6.10<br>Related Signalling RB UL: 3.4 kbps, DL: 3.4 kbps<br>DCCH, No. #2 (as described in TS 34.108)<br><br>PS domain<br><br>20<br><br>65535<br>TRUE<br>present<br><br>(AM RLC)<br>True                                                      |

**Content of PDCP Data PDU (Step 1)**

| Information Element     | Value/remark                                                                                                                                                                                    |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type<br>PID<br>Data | 000<br>00000 (No header compression, PID = 0)<br>PDCP test data type #1: TCP/IP data packet without IP<br>header compression with any data content. The data<br>shall be limited to 1500 bytes. |

**Content of PDCP Data PDU (Step 8)**

| Information Element     | Value/remark                                                                                                                                                                                    |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type<br>PID<br>Data | 000<br>00000 (No header compression, PID = 0)<br>PDCP test data type #1: TCP/IP data packet without IP<br>header compression with any data content. The data<br>shall be limited to 1500 bytes. |

**7.3.3.1.5 Test requirements**

After having sent the "RRC RNTI REALLOCATION COMPLETE", the UE shall return the received TCP/IP data packets as indication, that it supports lossless SRNS relocation. This implicitly verifies, that Sequence Numbering is used for lossless SRNS relocation.

### ~~7.3.3.2 Synchronisation of PDCP sequence numbers~~

#### ~~7.3.3.2.1 Definition and applicability~~

~~Applicable for all UEs supporting RLC AM, RLC in-sequence delivery, a Radio Bearer as described in the Common Test Sequences.~~

~~The UE shall be capable to deal with compressed TCP/IP and UDP/IP data packets and furthermore it shall be capable to use IP Header compression protocol RFC 2507.~~

#### ~~7.3.3.2.2 Conformance requirement~~

~~The PDCP SeqNum PDU shall be sent by the peer PDCP entities when synchronisation of the PDCP SN is required. (...) Synchronisation of PDCP SN is required after (...) RB reconfiguration.~~

#### ~~Reference(s)~~

~~TS 25.323 clause 5.4.~~

#### ~~7.3.3.2.3 Test purpose~~

- ~~1. To verify, that the UE supporting lossless SRNS relocation as configured by higher layers is able to handle the "PDCP SeqNum" PDU to synchronize the used PDCP Sequence Number after reconfiguration of the Radio Bearer.~~

#### ~~7.3.3.2.4 Method of test~~

##### ~~Initial conditions~~

~~SS: 2 cells – Cell A belonging to the valid SRNS (Source SRNS), Cell B belonging to the DRNS (Target SRNS). Both cells are neighbour cells. Cell A has a higher RF power level than Cell B such that an UE shall find Cell A more suitable for service.~~

~~UE: It is in Idle mode and has selected cell A with valid SRNS (Source SRNS). Usage of "PDCP Data" PDU, "PDCP SeqNum" PDU and no IP header compression is configured.~~

##### ~~Related ICS/IXIT Statement(s)~~

~~Support of lossless SRNS relocation – YES/NO~~

~~Support of RLC in-sequence delivery – YES/NO~~

##### ~~Test procedure~~

- ~~a) The SS setups a packet switched session including Radio Bearer and UE test loop mode 1 in RLC AM and in-sequence delivery using Common test procedures for mobile terminated PS switched sessions in Cell A. Usage of "PDCP Data" PDU, support of lossless SRNS relocation and no IP header compression has been configured by higher layers. The PDCP SN window size has been negotiated by RRC.~~
- ~~b) The SS sends a TCP/IP data packet (no compression packet type), PID=0.~~
- ~~c) After having received the TCP/IP data packet, the PDCP entity of the UE shall recognize the PID value and shall handle the received data packet correctly. Afterwards it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.~~
- ~~d) The SS receives and decodes the TCP/IP data packet according to the inserted PID. The decoded data packet shall be identical with the data as sent before.~~
- ~~e) The SS reconfigures (using RRC Radio Bearer Reconfiguration message) the PDCP entity by extending the PID value allocation table and therefore the applied optimisation method with the IP header compression protocol RFC 2507. The UE test loop mode 1 in RLC AM is still active.~~

- f) The SS sends the next TCP/IP data packet (no compression packet type), PID=0 using the "PDCP SeqNum" PDU including the current PDCP Sequence Number value to the UE.
- g) After having received the TCP/IP data packet, the UE shall recognize the PID value and shall handle the received data packet correctly. Afterwards it forwards the data to its Radio Bearer Loop Back entity. The received data shall be returned by the UE via its PDCP configuration.
- h) The SS receives and decodes TCP/IP data packets according to the inserted PID. The decoded data packets shall be identical with the data as sent before.
- i) The SS deactivates the UE test loop mode and terminates the connection.

#### Expected sequence

| Step                                                                                                         | Direction |                                           | Message                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Comments |
|--------------------------------------------------------------------------------------------------------------|-----------|-------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|
|                                                                                                              | UE        | SS                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |          |
| Setup a UE terminated PS session using IP Header compression in AM RLC (using UE test loop mode 1) in Cell A |           |                                           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |          |
| 1                                                                                                            | ←         | PDCP Data                                 | <p>The SS creates a TCP/IP packet without IP header compression.</p> <p>The SS sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content to the UE:<br/>PDU type = 000 (PDCP Data PDU)<br/>PID = 0 (uncompressed IP header)<br/>data: below described TCP/IP packet</p> <p>After having received the PDCP Data PDU, the UE decodes the PDU and recognizes PID value = 0 (no IP header compression). Therefore, no IP header decompression shall be applied for this packet.</p> <p>The data packet is forwarded via PDCP-SAP to its Radio Bearer Loop Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCP entity.</p> |          |
| 2                                                                                                            | →         | PDCP Data                                 | <p>The UE sends a PDCP Data PDU using the RLC-AM-Data-Request Primitive with the following content back to the SS:<br/>PDU type = 000 (PDCP Data PDU)<br/>PID value = 0<br/>data: previously received TCP/IP packet</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                                                                                                                                                                          |          |
| 3                                                                                                            | ←         | RRC-RADIO BEARER RECONFIGURATION          | SS extends the "PID value allocation table" with IP header compression PID (RFC 2507) in the UE.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |          |
| 4                                                                                                            | →         | RRC-RADIO BEARER RECONFIGURATION COMPLETE | UE acknowledges its new settings                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |          |

| Step                                                                                          | Direction |    | Message      | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|-----------------------------------------------------------------------------------------------|-----------|----|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                               | UE        | SS |              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 5                                                                                             |           | ←  | PDCCP-SeqNum | <p>The SS sends a PDCCP-SeqNum-PDU including its current Sequence Number with the following content to the UE:<br/> PDU type = 001 (PDCCP-SeqNum-PDU)<br/> PID = 0 (normal packet type [TCP/IP])<br/> SeqNum = current PDCCP Sequence Number<br/> data: below described TCP/IP packet</p> <p>After having received the PDCCP-SeqNum-PDU, the UE shall set the received PDCCP Sequence Number as its own valid value. It decodes the PDU, recognizes PID-value = 0 applied for this TCP/IP data packet and shall decompress it with the appropriate method.</p> <p>The data packet is forwarded via PDCCP-SAP to its Radio Bearer Loop-Back (RB-LB) entity.</p> <p>The RB-LB entity in UE test loop mode 1 returns the received data packet and sends it back to its PDCCP entity.</p> |
| 6                                                                                             |           | →  | PDCCP-PDU    | <p>The UE sends a PDCCP-PDU with PDCCP Header back to the SS. The content is as follows:<br/> PDU type = 000 (PDCCP-Data-PDU)<br/> PID-value = 0 to 3<br/> SeqNum: current UE value, (optional parameter, depending on the used PDU)<br/> data: previously received TCP/IP packet.</p> <p>After reception of this TCP/IP data packet, the SS applies the appropriate decoding function depending on the assigned PID.</p>                                                                                                                                                                                                                                                                                                                                                             |
| Deactivate a UE terminated PS session using IP Header compression (using UE test loop mode 1) |           |    |              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

### Specific Message Contents

#### RRC RADIO BEARER RECONFIGURATION message

The contents of the RRC RADIO BEARER RECONFIGURATION message applied in the preamble "Setup a UE terminated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) with the following exceptions:

| Information Element                   | Value/remark                      |
|---------------------------------------|-----------------------------------|
| RB information to reconfigure list    | 1                                 |
| RB information to reconfigure         |                                   |
| → PDCCP info                          |                                   |
| → Max PDCCP SN window size            | 65535                             |
| → Support of lossless SRNS relocation | TRUE                              |
| → PDCCP PDU header                    | present                           |
| → Header compression information      | 1                                 |
| → CHOICE algorithm type               |                                   |
| → RFC2507                             |                                   |
| → F_MAX_PERIOD                        | 256 (Default)                     |
| → F_MAX_TIME                          | 5 (Default)                       |
| → MAX_HEADER                          | 168 (Default)                     |
| → TCP_SPACE                           | 15 (Default)                      |
| → NON_TCP_SPACE                       | 15 (Default)                      |
| → EXPECT_REORDERING                   | reordering not expected (Default) |

**RRC CONNECTION SETUP message**

The contents of the RRC CONNECTION SETUP message applied in the preamble "Setup a UE terminated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) with the following exceptions:

| Information Element                                                              | Value/remark                                                                                                                                      |
|----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| Capability update requirement<br>— UE radio access capability update requirement | TRUE<br>NOTE: Value will be checked. Stated capability must be compatible with 34.123-2 (c.f. PICS/PIXIT statements in GSM) and the user settings |

**RADIO BEARER SETUP message**

The contents of the RADIO BEARER SETUP message applied in the preamble "Setup a UE terminated PS session using IP Header compression in AM RLC" of this test case is identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] (PS connection for AM) which fit to the here described parameters with the following exceptions:

| Information Element                                       | Value/remark                                                                                                                                                                                                                                                                           |
|-----------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RAB information for setup<br>— RAB info<br>— RAB identity | No. # 23 as described in TS 34.108, Table 6.10.2.1.1<br>Prioritised RABs.<br>QoS parameter:<br>Traffic Class: Interactive or Background,<br>max. UL: 64 kbps and max. DL: 64 kbps as described in TS 34.108, including described physical channel parameters, configuration for AM RLC |
| — CN domain identity                                      | PS domain                                                                                                                                                                                                                                                                              |
| — RB information to setup<br>— RB identity                | 20                                                                                                                                                                                                                                                                                     |
| — PDCP info<br>— Max PDCP SN window size                  | 65535                                                                                                                                                                                                                                                                                  |
| — Support of lossless SRNS relocation                     | TRUE                                                                                                                                                                                                                                                                                   |
| — PDCP PDU header                                         | present                                                                                                                                                                                                                                                                                |
| — RLC info<br>— Downlink RLC mode                         | (AM RLC)                                                                                                                                                                                                                                                                               |
| — In-sequence delivery                                    | True                                                                                                                                                                                                                                                                                   |

**Content of PDCP Data PDU (Step 1)**

| Information Element | Value/remark                                                                                                                             |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type            | 000                                                                                                                                      |
| PID                 | 00000 (No header compression, PID = 0)                                                                                                   |
| Data                | PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 1500 bytes. |

**Content of PDCP SeqNum PDU (Step 5)**

| Information Element | Value/remark                                                                                                                             |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| PDU type            | 001                                                                                                                                      |
| PID                 | 00000 (No header compression, PID = 0)                                                                                                   |
| Sequence number     | (16 Bit value) valid Sequence Number of the SS                                                                                           |
| Data                | PDCP test data type #1: TCP/IP data packet without IP header compression with any data content. The data shall be limited to 1500 bytes. |

### 7.3.3.2.5 Test requirements

After having received the TCP/IP data packet conveyed with the "PDCP SeqNum" PDU, the UE shall return the TCP/IP data packets as indication, that the UE is able to handle a Sequence Number synchronisation.

## 7.4 BMC

### General

For BMC testing, the UE manufacturers shall define CB data as PIXIT (CB-Data 1 and 2) for different CB message types and for CB-Data41 (ANSI-41 data) and it shall describe how the reception is indicated in a clear way on UE side.

Only Cell Broadcast Services (CBS) as distributed BMC service is applied. For a UE supporting BMC, it is assumed, that there is a BMC entity established, if Initial conditions are reached.

If not otherwise mentioned, the same procedures as used in RRC test specification [TS 34.123-1] are applied to reach Initial conditions for BMC testing.

It shall be possible to activate and deactivate a CB message types by using the Message ID of CB data 1, 2 and CB41 data 1 on UE side.

### 7.4.1 BMC RAB + SRBs for CCCH + SRB for DCCH + SRB for BCCH

#### 7.4.1.1 Transport channel parameters of BMC RAB and SRBs for CCCH, SRB for DCCH, and SRB for BCCH

|              |                                                |                                |                      |       |                     |                    |       |        |
|--------------|------------------------------------------------|--------------------------------|----------------------|-------|---------------------|--------------------|-------|--------|
| Higher layer | RAB/signalling-RB                              | SRB#1                          | SRB#2                | SRB#3 | SRB#4               | SRB#5              | SRB#6 | RAB#30 |
|              | User of Radio-Bearer                           | RRC                            | RRC                  | RRC   | NAS-DT<br>High-prio | NAS-DT<br>Low-prio | RRC   | -      |
| RLC          | Logical-channel-type                           | CCCH                           | DCCH                 | DCCH  | DCCH                | DCCH               | BCCH  | CTCH   |
|              | RLC mode                                       | UM                             | UM                   | AM    | AM                  | AM                 | TM    | UM     |
|              | Payload-sizes, bit                             | 152                            | 136-or<br>120*       | 128   | 128                 | 128                | 166   | 152    |
|              | Max-data-rate, bps                             | 45600                          | 40800<br>or<br>36000 | 38400 | 38400               | 38400              | 49800 | 45600  |
|              | AMD/UMD/TrD-PDU<br>header, bit                 | 8                              | 8                    | 16    | 16                  | 16                 | 0     | 8      |
| MAC          | MAC-header, bit                                | 8                              | 24-or<br>40          | 24    | 24                  | 24                 | 2     | 8      |
|              | MAC-multiplexing                               | 7-logical-channel-multiplexing |                      |       |                     |                    |       |        |
| Layer-1      | TrCH-type                                      |                                | FACH                 |       |                     |                    |       |        |
|              | TB-sizes, bit                                  |                                | 168                  |       |                     |                    |       |        |
|              | TFS                                            | TF0, bits                      | 0x168                |       |                     |                    |       |        |
|              |                                                | TF1, bits                      | 1x168                |       |                     |                    |       |        |
|              |                                                | TF2, bits                      | 2x168                |       |                     |                    |       |        |
|              |                                                | TF3, bits                      | 3x168                |       |                     |                    |       |        |
|              | TTI, ms                                        |                                | 10                   |       |                     |                    |       |        |
|              | Coding-type                                    |                                | CC-1/2               |       |                     |                    |       |        |
|              | CRC, bit                                       |                                | 16                   |       |                     |                    |       |        |
|              | Max-number-of-bits/TTI<br>before-rate-matching |                                | 1136                 |       |                     |                    |       |        |
|              | RM-attribute                                   |                                | 200-240              |       |                     |                    |       |        |

\* MAC header size and RLC payload size depend on use of U-RNTI or C-RNTI.

#### 7.4.1.2 TFCS

|           |                                                            |
|-----------|------------------------------------------------------------|
| TFCS size | 4                                                          |
| TFCS      | (BMC RAB and SRBs for CCCH/DCCH/BCCH) = TF0, TF1, TF2, TF3 |



### 7.4.1.3 Physical channel parameters

|        |                           |          |
|--------|---------------------------|----------|
| SCCPCH | DTX position              | Flexible |
|        | Spreading factor          | 64       |
|        | Number of TFCI bits/slot  | 8        |
|        | Number of Pilot bits/slot | 0        |
|        | Number of data bits/slot  | 72       |
|        | Number of data bits/frame | 1080     |

### 7.4.2 General BMC message reception

#### 7.4.2.1 UE in RRC Idle mode

##### 7.4.2.1.1 Definition and applicability

Applicable only for a UE supporting Cell Broadcast Services (CBS) as a type of Broadcast/Multicast Services.

It shall be possible to indicate the reception of certain CBS message contents carried with certain activated CB message types in a clear way on UE side.

##### 7.4.2.1.2 Conformance requirement

A UE supporting Cell Broadcast Services shall be capable to receive BMC messages in the RRC Idle mode.

##### Reference(s)

TS 25.324 clause 9.1

##### 7.4.2.1.3 Test purpose

To verify, that a BMC configuration for a UE is able to receive activated CBS messages when in RRC Idle mode.

##### 7.4.2.1.4 Method of test

##### Initial conditions

UE is in RRC Idle mode; BMC entity is established

SS: 1 cell,

NOTE: The CB message ID stored on the SIM shall be known for this test (parameter for CBS PDU's). The CBS data type shall be allocated and activated in the UE.

##### Related ICS/IXIT Statement(s)

Support of BMC—Yes/No

Support of PS—Yes/No

ICS: CBS message support—YES/No

IXIT: CBS-Data 1: Octetstring of N (where  $N \geq 1$  and less than 1246)

NOTE: For CB-Data 1 IXIT, the manufacturer shall define CBS data as Octetstring together with the CB message ID used for transmitting this CB data, which is indicated by the UE after reception in a clear way according to the capabilities stored on the SIM. Furthermore, the manufacturer shall describe the indication on UE side (e.g. certain CBS traffic information)

### Test procedure

- a) The UE in RRC Idle mode is triggered to wait for the next system information. The UE is activated to receive CBS messages;
- b) The UE and the SS have configured their RLC, MAC and PHYs layers with all CB related system information, broadcasted by SS
- c) The SS sends the CBS message containing an activated CBS message type according to CB-Data 1 to the UE; this shall be repeated for "CPREP" times (indicated by parameter "repetition period")
- d) The UE indicates in an unambiguous way, that this message was received, by certain clear indications (e.g. a unique part of the CB data contents)

### Expected sequence

| Step | Direction |    | Message            | Comments                                                                                                                                                                                                                                                                                                            |
|------|-----------|----|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                                                                                                                                                                                                     |
| 1    |           | ←  | SYSTEM INFORMATION | Transmit this message as described below on the BCCH, in addition to the regular BCCH transmissions (see RRC test description). Included are CB related system information parameter of the CBS:<br>- CTCH ID,<br>- FACH ID and associated format set,<br>- S-CCPCH ID,<br>- BMC Schedule Level 1 information (N,K) |
| 2    |           |    |                    | The SS waits for about 10 s to make sure, that the UE is configured to receive CBS data                                                                                                                                                                                                                             |
| 3    |           | ←  | BMC CBS Message    | Activated CBS message with CB Data 1 message content as described by the manufacturer. This message shall be repeated "CPREP" times, Parameter:<br>- Message_ID,<br>- Serial-No,<br>- Data coding scheme,<br>- CB-Data 1,                                                                                           |
| 4    |           |    |                    | After having received the BMC CBS message the UE shall indicate the reception of CB Data 1 in a clear way.                                                                                                                                                                                                          |

### Specific Message Contents

#### SYSTEM INFORMATION TYPE 5 AND 6

The contents of SYSTEM INFORMATION TYPE 5 AND 6 Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

| Information Element          | Value/remark                    |
|------------------------------|---------------------------------|
| CHOICE mode                  | (see RRC default test settings) |
| -CTCH allocation period      | N                               |
| -CTCH frame offset           | K                               |
| Secondary CCPCH system       | 1                               |
| -Secondary CCPCH information | (see RRC default test settings) |
| -TFCS                        | 1                               |
| -FACH/PCH information        | (see RRC default test settings) |
| —TFS                         | TRUE                            |
| —CTCH indicator              |                                 |

**BMC-CBS Message**

| Information Element                 | Value/remark                                                                                                                                                                        |
|-------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                        | 1 (CBS message)                                                                                                                                                                     |
| Message ID                          | Bitstring (16) CB message ID, it shall fit to the stored Message ID in the SIM inserted in the UE (source and type) [see TS 23.041] according to the transmitted CB-Data 1 content. |
| Serial Number                       | [see TS 23.041]                                                                                                                                                                     |
| -Geographic Scope Indicator (2 bit) | 11 (Normal Cell wide)                                                                                                                                                               |
| -Message Code (10 bit)              | in accordance with the Message ID                                                                                                                                                   |
| -Update Number (4 bit)              | for a new message: 0000, incremented by one for each repetition                                                                                                                     |
| Data Coding Scheme                  | Bitstring (16) ID of the alphabet/coding and the applied language [see TS 23.041]                                                                                                   |
| CB-Data                             | Octetstring, [see IXIT value: CB-Data 1]                                                                                                                                            |

**7.4.2.1.5 Test requirements**

The UE shall store and decode a received activated CBS message.

**7.4.2.2 UE in RRC Connected mode, state CELL\_PCH****7.4.2.2.1 Definition and applicability**

Applicable only for a UE supporting Cell Broadcast Services (CBS) as a type of Broadcast/Multicast Services.

It shall be possible to indicate the reception of certain CBS message contents carried with certain activated CB message types in a clear way on UE side.

**7.4.2.2.2 Conformance requirement**

A UE supporting Cell Broadcast Service (CBS) shall be capable to receive BMC messages (...) in CELL\_PCH RRC-state of Connected mode.

**Reference(s)**

TS 25.324 clause 9.1

**7.4.2.2.3 Test purpose**

To verify, that a BMC configuration for a UE is able to receive activated CBS messages when in RRC Connected mode, state CELL\_PCH.

**7.4.2.2.4 Method of test****Initial conditions**

UE is in Connected mode state CELL\_PCH; BMC entity is established

SS: 1 cell,

NOTE: The CB message ID stored on the SIM shall be known for this test (parameter for CBS PDU's). The CBS data type shall be allocated and activated in the UE.

**Related ICS/IXIT Statement(s)**

ICS:

Support of BMC—Yes/No

Support of PS—Yes/No

CBS message support—YES/No

IXIT: CBS-Data 1: Octetstring of N (where  $N \geq 1$  and less than 1246)

NOTE:—For CB-Data 1 IXIT, the manufacturer shall define CBS data as Octetstring together with the CB message ID used for transmitting this CB data, which is indicated by the UE after reception in a clear way according to the capabilities stored on the SIM. Furthermore, the manufacturer shall describe the indication on UE side (e.g. certain CBS traffic information)

**Test procedure**

- a) The UE in RRC CELL\_PCH is triggered to wait for the next system information. The UE is activated to receive CBS messages.
- b) The UE and the SS have configured their RLC, MAC and PHYs layers with all CB-related system information, broadcasted by SS.
- c) The SS sends the CBS message containing an activated CBS message type according to CB-Data 1 to the UE; this shall be repeated for "CPREP" times (indicated by parameter "repetition period").
- d) The UE indicates in an unambiguous way, that this message was received, by certain clear indications (e.g. a unique part of the CB data contents).

**Expected sequence**

| Step | Direction |    | Message            | Comments                                                                                                                                                                                                                                                                                                            |
|------|-----------|----|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                                                                                                                                                                                                     |
| 1    |           | ←  | SYSTEM INFORMATION | Transmit this message as described below on the BCCH, in addition to the regular BCCH transmissions (see RRC test description). Included are CB-related system information parameter of the CBS:<br>- CTCH ID;<br>- FACH ID and associated format set;<br>- S-CCPCH ID;<br>- BMC Schedule Level 1 information (N,K) |
| 2    |           |    |                    | The SS waits for about 10 s to make sure, that the UE is configured to receive CBS data                                                                                                                                                                                                                             |
| 3    |           | ←  | BMC CBS Message    | Activated CBS message with CB-Data 1 message content as described by the manufacturer. This message shall be repeated "CPREP" times, Parameter:<br>- Message_ID;<br>- Serial-No;<br>- Data coding scheme;<br>- CB-Data 1;                                                                                           |
| 4    |           |    |                    | After having received the BMC CBS message the UE shall indicate the reception of CB-Data 1 in a clear way.                                                                                                                                                                                                          |

## Specific Message Contents

### SYSTEM INFORMATION TYPE 5 and 6

The contents of SYSTEM INFORMATION TYPE 5 and 6 Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

| Information Element          | Value/remark                    |
|------------------------------|---------------------------------|
| CHOICE mode                  | (see RRC default test settings) |
| —CTCH allocation period      | N                               |
| —CTCH frame offset           | K                               |
| Secondary CCPCH system       | 1                               |
| —Secondary CCPCH information | (see RRC default test settings) |
| —TFCS                        | 1                               |
| —FACH/PCH information        | (see RRC default test settings) |
| —TFS                         | TRUE                            |
| —CTCH indicator              | (see RRC default test settings) |

### BMC CBS Message

| Information Element                 | Value/remark                                                                                                                                                                        |
|-------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                        | 1 (CBS message)                                                                                                                                                                     |
| Message ID                          | Bitstring (16) CB message ID, it shall fit to the stored Message ID in the SIM inserted in the UE (source and type) [see TS 23.041] according to the transmitted CB-Data-1 content. |
| Serial Number                       | [see TS 23.041]                                                                                                                                                                     |
| —Geographic Scope Indicator (2 bit) | 11 (Normal Cell wide)                                                                                                                                                               |
| —Message Code (10 bit)              | in accordance with the Message ID                                                                                                                                                   |
| —Update Number (4 bit)              | for a new message: 0000, incremented by one for each repetition                                                                                                                     |
| Data Coding Scheme                  | Bitstring (16) ID of the alphabet/coding and the applied language [see TS 23.041]                                                                                                   |
| CB-Data                             | Octetstring, [see IXIT value: CB-Data-1]                                                                                                                                            |

#### 7.4.2.2.5 Test requirements

The UE shall store and decode a received activated CBS message.

#### 7.4.2.3 UE in RRC Connected mode, state URA\_PCH

##### 7.4.2.3.1 Definition and applicability

Applicable only for a UE supporting Cell Broadcast Services (CBS) as a type of Broadcast/Multicast Services.

It shall be possible to indicate the reception of certain CBS message contents carried with certain activated CB message types in a clear way on UE side.

##### 7.4.2.3.2 Conformance requirement

A UE supporting Cell Broadcast Service (CBS) shall be capable to receive BMC messages (...) in CELL\_PCH and URA\_PCH RRC-state of Connected mode.

### Reference(s)

TS 25.324 clause 9.1.

#### ~~7.4.2.3.3 Test purpose~~

~~To verify, that a BMC configuration for a UE is able to receive activated CBS messages when in RRC Connected mode, state URA\_PCH.~~

#### ~~7.4.2.3.4 Method of test~~

##### ~~Initial conditions~~

~~UE is in Connected mode state URA\_PCH; BMC entity is established~~

~~SS: 1 cell.~~

~~NOTE:—The CB message ID stored on the SIM shall be known for this test (parameter for CBS PDU's). The CBS data type shall be allocated and activated in the UE.~~

##### ~~Related ICS/IXIT Statement(s)~~

~~ICS:~~

~~Support of BMC—Yes/No~~

~~Support of PS—Yes/No~~

~~CBS message support—YES/No.~~

~~IXIT: CBS-Data 1: Octetstring of N (where  $N \geq 1$  and less than 1246).~~

~~NOTE:—For CB-Data 1 IXIT, the manufacturer shall define CBS data as Octetstring together with the CB message ID used for transmitting this CB data, which is indicated by the UE after reception in a clear way according to the capabilities stored on the SIM. Furthermore, the manufacturer shall describe the indication on UE side (e.g. certain CBS traffic information)~~

##### ~~Test procedure~~

- ~~a) The UE in RRC URA\_PCH is triggered to wait for the next system information. The UE is activated to receive CBS messages.~~
- ~~b) The UE and the SS have configured their RLC, MAC and PHYs layers with all CB-related system information, broadcasted by SS.~~
- ~~c) The SS sends the CBS message containing an activated CBS message type according to CB-Data 1 to the UE, this shall be repeated for "CPREP" times (indicated by parameter "repetition period").~~
- ~~d) The UE indicates in an unambiguous way, that this message was received, by certain clear indications (e.g. a unique part of the CB data contents).~~

## Expected sequence

| Step | Direction |    | Message            | Comments                                                                                                                                                                                                       |
|------|-----------|----|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                                                                                                |
| 1    | ←         |    | SYSTEM INFORMATION | Transmit this message as described below on the BCCH, in addition to the regular BCCH transmissions (see RRC test description). Included are CB-related system information parameter of the CBS:               |
| 2    |           |    |                    | - CTCH ID;<br>- FACH ID and associated format set;<br>- S-CCPCH ID;<br>- BMC Schedule Level 1 information (N,K)<br><br>The SS waits for about 10 s to make sure, that the UE is configured to receive CBS data |
| 3    | ←         |    | BMC CBS Message    | Activated CBS message with CB Data 1 message content as described by the manufacturer. This message shall be repeated "CPREP" times, Parameter:                                                                |
| 4    |           |    |                    | - Message_ID;<br>- Serial No;<br>- Data coding scheme;<br>- CB Data 1;<br><br>After having received the BMC CBS message the UE shall indicate the reception of CB Data 1 in a clear way.                       |

## Specific Message Contents

## SYSTEM INFORMATION TYPE 5 and 6

The contents of SYSTEM INFORMATION TYPE 5 and 6 Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

| Information Element           | Value/remark                    |
|-------------------------------|---------------------------------|
| CHOICE mode                   | (see RRC default test settings) |
| - CTCH allocation period      | N                               |
| - CTCH frame offset           | K                               |
| Secondary CCPCH system        | 1                               |
| - Secondary CCPCH information | (see RRC default test settings) |
| - TFCS                        | 1                               |
| - FACH/PCH information        | (see RRC default test settings) |
| - TFS                         | TRUE                            |
| - CTCH indicator              | (see RRC default test settings) |

**BMC CBS Message**

| Information Element                 | Value/remark                                                                                                                                                                        |
|-------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                        | 1 (CBS message)                                                                                                                                                                     |
| Message ID                          | Bitstring (16) CB message ID, it shall fit to the stored Message ID in the SIM inserted in the UE (source and type) [see TS 23.041] according to the transmitted CB-Data 1 content. |
| Serial Number                       | [see TS 23.041]                                                                                                                                                                     |
| -Geographic Scope Indicator (2 bit) | 11 (Normal Cell wide)                                                                                                                                                               |
| -Message Code (10 bit)              | in accordance with the Message ID                                                                                                                                                   |
| -Update Number (4 bit)              | for a new message: 0000, incremented by one for each repetition                                                                                                                     |
| Data Coding Scheme                  | Bitstring (16) ID of the alphabet/coding and the applied language [see TS 23.041]                                                                                                   |
| CB-Data                             | Octetstring, [see I-XIT value: CB-Data 1]                                                                                                                                           |

**7.4.2.3.5 Test requirements**

The UE shall store and decode a received activated CBS message.

**7.4.2.4 UE in RRC Idle mode (ANSI-41 CB data)****7.4.2.4.1 Definition and applicability**

Applicable only for a UE supporting Cell Broadcast Services (CBS) for ANSI-41 CB data as a type of Broadcast/Multicast Services.

It shall be possible to indicate the reception of a certain CBS41 message content carried with certain activated CB41 message types in a clear way on UE side.

**7.4.2.4.2 Conformance requirement**

A UE supporting Cell Broadcast Services shall be capable to receive BMC messages in RRC Idle mode. (...)BMC messages are identified: (...), CBS41 Message

**Reference(s)**

TS 25.324 clause 9.1.

**7.4.2.4.3 Test purpose**

To verify, that a BMC configuration supporting ANSI-41 CB Data is able to receive activated CBS41 messages when in RRC Idle mode.

**7.4.2.4.4 Method of test****Initial conditions**

UE is in RRC Idle mode; BMC entity is established.

SS: 1 cell,

NOTE: The CB message ID stored on the SIM shall be known for this test (parameter for CBS41 PDU's). The CBS41 data type shall be allocated and activated in the UE.



**Related ICS/IXIT Statement(s)**

ICS:

Support of BMC—Yes/No

Support of PS—Yes/No

CBS41 message support—YES/No.

IXIT: CB41-Data 1: Octetstring of N (where  $N \geq 1$  and less than 1246).

NOTE:—For CB41-Data 1 IXIT, the manufacturer shall define CBS data as Octetstring together with the CB message ID used for transmitting this CB41 data, which is indicated by the UE after reception in a clear way according to the capabilities stored on the SIM. Furthermore, the manufacturer shall describe the indication on UE side (e.g. certain CBS41 traffic information)

**Test procedure**

- a) The UE in RRC Idle mode is triggered to wait for the next system information. The UE is activated to receive expected CBS41 messages as described by the manufacturer.
- b) The UE and the SS have configured their RLC, MAC and PHYs layers with all CB-related system information, broadcasted by SS.
- c) The SS sends the CBS41 message containing an activated CBS41 message type according to CB41-Data 1 to the UE; this shall be repeated for "CPREP" times (indicated by parameter "repetition period").
- d) The UE indicates in an unambiguous way, that this message was received, by certain clear indications (e.g. a unique part of the CB41 data contents).

**Expected sequence**

| Step | Direction |    | Message            | Comments                                                                                                                                                                                                                                                                                                                                                                                                           |
|------|-----------|----|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 1    |           | ←  | SYSTEM INFORMATION | Transmit this message as described below on the BCCH, in addition to the regular BCCH transmissions (see RRC test description). Included are CB-related system information parameter of the CBS:<br>- CTCH ID;<br>- FACH ID and associated format set;<br>- S-CCPCH ID;<br>- BMC-Schedule-Level 1 information (N,K)<br>In addition, the MIB and SIB 16 are sent as described below to setup the ANSI-41 parameters |
| 2    |           |    |                    | The SS waits for about 10 s to make sure, that the UE is configured to receive CB41 data                                                                                                                                                                                                                                                                                                                           |
| 3    |           | ←  | BMC CBS41 Message  | Activated CBS message with CB41-Data 1 message content as described by the manufacturer. This message shall be repeated "CPREP" times, Parameter:<br>- Message_type;<br>- Broadcast Address<br>- CB41-Data 1                                                                                                                                                                                                       |
| 4    |           |    |                    | After having received the BMC CBS message the UE shall indicate the reception of CB41-Data 1 in a clear way.                                                                                                                                                                                                                                                                                                       |

## Specific Message Contents

### MASTER INFORMATION BLOCK (MIB)

The contents of MASTER INFORMATION BLOCK Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

| Information Element              | Value/remark |
|----------------------------------|--------------|
| ANSI-41 Core Network information | Present      |

### SYSTEM INFORMATION TYPE 5 AND 6

The contents of SYSTEM INFORMATION TYPE 5 AND 6 Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

| Information Element          | Value/remark                    |
|------------------------------|---------------------------------|
| CHOICE mode                  | (see RRC default test settings) |
| -CTCH allocation period      | N                               |
| -CTCH frame offset           | K                               |
| Secondary CCPCH system       | 1                               |
| -Secondary CCPCH information | (see RRC default test settings) |
| -TFCS                        | 1                               |
| -FACH/PCH information        | (see RRC default test settings) |
| -TFS                         | TRUE                            |
| -CTCH indicator              | (see RRC default test settings) |

### SYSTEM INFORMATION TYPE 13

The contents of SYSTEM INFORMATION TYPE 13 Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

| Information Element                 | Value/remark |
|-------------------------------------|--------------|
| CHOICE CN Type                      | ANSI-41      |
| -CN domain specific NAS information |              |
| -NAS (ANSI-41) system information   | T.B.D        |

### BMC CBS41 Message

| Information Element | Value/remark                                        |
|---------------------|-----------------------------------------------------|
| Message Type        | 3 (CBS41 Message)                                   |
| Broadcast Address   | Bitstring (40) Address Information of higher layer  |
| CB Data41           | Octetstring, [see IXT value: CB41-Data 1] (ANSI-41) |

#### 7.4.2.4.5 Test requirements

The UE shall store and decode a received activated CBS41 message.

#### 7.4.2.5 UE in RRC Connected mode, state CELL\_PCH (ANSI-41 CB data)

##### 7.4.2.5.1 Definition and applicability

Applicable only for a UE supporting Cell Broadcast Services (CBS) for ANSI-41 CB data as a type of Broadcast/Multicast Services.

It shall be possible to indicate the reception of certain CBS41 message contents carried with certain activated CB41 message types in a clear way on UE side.

#### 7.4.2.5.2 ~~Conformance requirement~~

~~A UE supporting Cell Broadcast Service (CBS) shall be capable to receive BMC messages (...) in CELL\_PCH RRC-state of Connected mode. (...) BMC messages are identified: (...), CBS41 Message.~~

#### Reference(s)

~~TS 25.324 clause 9.1.~~

#### 7.4.2.5.3 ~~Test purpose~~

~~To verify, that a BMC configuration supporting ANSI-41 CB Data is able to receive activated CBS41 messages when in RRC Connected mode, state CELL\_PCH.~~

#### 7.4.2.5.4 ~~Method of test~~

##### Initial conditions

~~UE is in Connected mode state CELL\_PCH; BMC entity is established.~~

~~SS: 1 cell,~~

~~NOTE:—The CB41 message ID stored on the SIM shall be known for this test (parameter for CBS41 PDU's). The CBS41 data type shall be allocated and activated in the UE.~~

##### Related ICS/IXIT Statement(s)

~~ICS:~~

~~Support of BMC—Yes/No~~

~~Support of PS—Yes/No~~

~~CBS41 message support—YES/No.~~

~~IXIT: CBS41-Data 1: Octetstring of N (where  $N \geq 1$  and less than 1246).~~

~~NOTE:—For CB41-Data 1 IXIT, the manufacturer shall define CBS data as Octetstring together with the CB message ID used for transmitting this CB41 data, which is indicated by the UE after reception in a clear way according to the capabilities stored on the SIM. Furthermore, the manufacturer shall describe the indication on UE side~~

##### Test procedure

- ~~a) The UE in RRC CELL\_PCH is triggered to wait for the next system information. The UE is activated to receive expected CBS41 messages as described by the manufacturer.~~
- ~~b) The UE and the SS have configured their RLC, MAC and PHYs layers with all CB41 related system information, broadcasted by SS.~~
- ~~c) The SS sends the CBS41 message containing an activated CBS41 message type according to CB41-Data 1 to the UE; this shall be repeated for "CPREP" times (indicated by parameter "repetition period").~~
- ~~d) The UE indicates in an unambiguous way, that this message was received, by certain clear indications (e.g. a unique part of the CB41 data contents).~~

## Expected sequence

| Step | Direction |    | Message            | Comments                                                                                                                                                                                                                                                                                                                                                                                                            |
|------|-----------|----|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 1    |           | ←  | SYSTEM INFORMATION | Transmit this message as described below on the BCCH, in addition to the regular BCCH transmissions (see RRC test description). Included are CB-related system information parameter of the CBS:<br>- CTCH ID;<br>- FACH ID and associated format set;<br>- S-CCPCH ID;<br>- BMC Schedule Level 1 information (N,K)<br>In addition, the MIB and SIB-13 are sent as described below for setup the ANSI-41 parameters |
| 2    |           |    |                    | The SS waits for about 10 s to make sure, that the UE is configured to receive CB41 data                                                                                                                                                                                                                                                                                                                            |
| 3    |           | ←  | BMC CBS41 Message  | Activated CBS message with CB41-Data 1 message content as described by the manufacturer. This message shall be repeated "CPREP" times, Parameter:<br>- Message_type;<br>- Broadcast Address<br>- CB41-Data 1                                                                                                                                                                                                        |
| 4    |           |    |                    | After having received the BMC CBS message the UE shall indicate the reception of CB41-Data 1 in a clear way.                                                                                                                                                                                                                                                                                                        |

## Specific Message Contents

## MASTER INFORMATION BLOCK (MIB)

The contents of MASTER INFORMATION BLOCK Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

| Information Element              | Value/remark |
|----------------------------------|--------------|
| ANSI-41 Core Network information | Present      |

## SYSTEM INFORMATION TYPE 5 and 6

The contents of SYSTEM INFORMATION TYPE 5 and 6 Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

| Information Element           | Value/remark                    |
|-------------------------------|---------------------------------|
| CHOICE mode                   | (see RRC default test settings) |
| - CTCH allocation period      | N                               |
| - CTCH frame offset           | K                               |
| Secondary CCPCH system        | 1                               |
| - Secondary CCPCH information | (see RRC default test settings) |
| - TFCS                        | 1                               |
| - FACH/PCH information        | (see RRC default test settings) |
| — TFS                         | TRUE                            |
| — CTCH indicator              | (see RRC default test settings) |

### SYSTEM INFORMATION TYPE 13

The contents of SYSTEM INFORMATION TYPE 13 Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

| Information Element                 | Value/remark |
|-------------------------------------|--------------|
| CHOICE CN-Type                      | ANSI-41      |
| -CN domain specific NAS information |              |
| -NAS (ANSI-41) system information   | T.B.D        |

### BMC CBS41 Message

| Information Element | Value/remark                                        |
|---------------------|-----------------------------------------------------|
| Message Type        | 3 (CBS41 Message)                                   |
| Broadcast Address   | Bitstring (40) Address Information of higher layer  |
| CB Data41           | Octetstring, [see IXT value: CB41-Data 1] (ANSI-41) |

#### 7.4.2.5.5 Test requirements

The UE shall store and decode a received activated CBS41 message.

#### 7.4.2.6 UE in RRC Connected mode, state URA\_PCH (ANSI-41 CB data)

##### 7.4.2.6.1 Definition and applicability

Applicable only for a UE supporting Cell Broadcast Services (CBS) for ANSI-41 CB data as a type of Broadcast/Multicast Services.

It shall be possible to indicate the reception of a certain CBS41 message content carried with certain activated CB41 message types in a clear way on UE side.

##### 7.4.2.6.2 Conformance requirement

A UE supporting Cell Broadcast Service (CBS) shall be capable to receive BMC messages (...) in URA\_PCH RRC-state of Connected mode. (...)BMC messages are identified: (...), CBS41 Message.

#### Reference(s)

TS 25.324 clause 9.1.

##### 7.4.2.6.3 Test purpose

To verify, that a BMC configuration supporting ANSI-41 CB Data is able to receive activated CBS41 messages when in RRC Connected mode, state URA\_PCH.

##### 7.4.2.3.4 Method of test

#### Initial conditions

UE is in Connected mode state URA\_PCH; BMC entity is established.

SS: 1 cell,

NOTE:—The CB41 message ID stored on the SIM shall be known for this test (parameter for CBS41 PDU's). The CBS41 data type shall be allocated and activated in the UE.

**Related ICS/IXIT Statement(s)**

ICS:

Support of BMC—Yes/No

Support of PS—Yes/No

CBS41 message support—YES/No.

IXIT: CBS41-Data 1: Octetstring of N (where  $N \geq 1$  and less than 1246).

NOTE:—For CB41-Data 1 IXIT, the manufacturer shall define CBS data as Octetstring together with the CB message ID used for transmitting this CB41 data, which is indicated by the UE after reception in a clear way according to the capabilities stored on the SIM. Furthermore, the manufacturer shall describe the indication on UE side (e.g. certain CBS41 traffic information).

**Test procedure**

- a) The UE in RRC URA\_PCH is triggered to wait for the next system information. The UE is activated to receive expected CBS41 messages as described by the manufacturer.
- b) The UE and the SS have configured their RLC, MAC and PHYs layers with all CB related system information, broadcasted by SS.
- c) The SS sends the CBS41 message containing an activated CBS41 message type according to CB41-Data 1 to the UE, this shall be repeated for "CPREP" times (indicated by parameter "repetition period").
- d) The UE indicates in an unambiguous way, that this message was received, by certain clear indications (e.g. a unique part of the CB41 data contents).

**Expected sequence**

| Step | Direction |    | Message            | Comments                                                                                                                                                                                                                                                                                                                                                                                                            |
|------|-----------|----|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 1    |           | ←  | SYSTEM INFORMATION | Transmit this message as described below on the BCCH, in addition to the regular BCCH transmissions (see RRC test description). Included are CB related system information parameter of the CBS:<br>- CTCH ID;<br>- FACH ID and associated format set;<br>- S-CCPCH ID;<br>- BMC Schedule Level 1 information (N,K)<br>In addition, the MIB and SIB 13 are sent as described below for setup the ANSI-41 parameters |
| 2    |           |    |                    | The SS waits for about 10 s to make sure, that the UE is configured to receive CB41 data                                                                                                                                                                                                                                                                                                                            |
| 3    |           | ←  | BMC CBS41 Message  | Activated CBS message with CB41-Data 1 message content as described by the manufacturer. This message shall be repeated "CPREP" times, Parameter:<br>- Message_type;<br>- Broadcast Address<br>- CB41-Data 1                                                                                                                                                                                                        |
| 4    |           |    |                    | After having received the BMC CBS message the UE shall indicate the reception of CB41-Data 1 in a clear way.                                                                                                                                                                                                                                                                                                        |

## Specific Message Contents

### MASTER INFORMATION BLOCK (MIB)

The contents of MASTER INFORMATION BLOCK Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

| Information Element              | Value/remark |
|----------------------------------|--------------|
| ANSI-41 Core Network information | Present      |

### SYSTEM INFORMATION TYPE 5 and 6

The contents of SYSTEM INFORMATION TYPE 5 and 6 Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

| Information Element          | Value/remark                    |
|------------------------------|---------------------------------|
| CHOICE mode                  | (see RRC default test settings) |
| -CTCH allocation period      | N                               |
| -CTCH frame offset           | K                               |
| Secondary CCPCH system       | 1                               |
| -Secondary CCPCH information | (see RRC default test settings) |
| -TFCS                        | 1                               |
| -FACH/PCH information        | (see RRC default test settings) |
| -TFS                         | TRUE                            |
| -CTCH indicator              | (see RRC default test settings) |

### SYSTEM INFORMATION TYPE 13

The contents of SYSTEM INFORMATION TYPE 13 Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

| Information Element                 | Value/remark |
|-------------------------------------|--------------|
| CHOICE CN Type                      | ANSI-41      |
| -CN domain specific NAS information |              |
| -NAS (ANSI-41) system information   | T.B.D        |

### BMC CBS41 Message

| Information Element | Value/remark                                        |
|---------------------|-----------------------------------------------------|
| Message Type        | 3 (CBS41 Message)                                   |
| Broadcast Address   | Bitstring (40) Address Information of higher layer  |
| CB Data41           | Octetstring, [see IXT value: CB41-Data 1] (ANSI-41) |

#### 7.4.2.6.5 Test requirements

The UE shall store and decode a received activated CBS41 message.

### 7.4.3 BMC message reception procedure

#### 7.4.3.1 Reception of certain CBS message types

##### 7.4.3.1.1 Definition and applicability

Applicable only for a UE supporting Cell Broadcast Services (CBS) as type of Broadcast/Multicast Services.

It shall be possible to indicate the reception of two different CBS message contents carried with different activated CB message types in a clear way on UE side.

It shall be possible to activate/deactivate the CBS message types used to receive CB Data 1 or 2.

#### 7.4.3.1.2 ~~Conformance requirement~~

A UE supporting Cell Broadcast Service (CBS) shall be capable to receive BMC messages in RRC Idle mode.

The BMC entity on UE side evaluates received BMC Schedule Messages and takes decisions which BMC messages are received.

If not otherwise requested by upper layers, only those CB messages received in BMC CBS Messages should be delivered to upper layers for which the Serial Number associated with the CB message has changed. This implies that the BMC has to store the last received Serial Number of each CB message activated by upper layers.

#### Reference(s)

TS 25.324 clause 9.1.

TS 25.324 clause 9.4.

#### 7.4.3.1.3 ~~Test purpose~~

1. ~~To verify, that a UE supporting CBS ignores a deactivated CBS message type which has been broadcasted by SS.~~
2. ~~To verify, that a UE only stores Serial Numbers of a newly transmitted CBS messages. This shall be verified by indication of a received CBS message with changed Serial Number as indication for the storage of Serial Numbers.~~

#### 7.4.3.1.4 ~~Method of test~~

#### ~~Initial conditions~~

~~UE is in RRC Idle mode.~~

~~SS: 1 cell,~~

~~NOTE: The CB message ID stored on the SIM shall be known for this test (as parameter for the CBS message PDU). The CBS data type shall be allocated and in the UE. It shall be possible to activate/deactivate such CBS data type.~~

#### Related ICS/IXIT Statement(s)

ICS:

Support of BMC—Yes/No

Support of PS—Yes/No

CBS message support—YES/No.

IXIT:

~~—CBS-Data 1: Octetstring of N (where  $N \geq 1$  and less than 1246), with used CB message ID for CB-Data 1.~~

~~—CBS-Data 2: Octetstring of N (where  $N \geq 1$  and less than 1246), with used CB message ID for CB-Data 2 (CB message ID for CB-Data 1 shall be different to CB message ID for CB-Data 2).~~

~~NOTE: For CBS data IXIT's, the manufacturer shall define CBS data as Octetstring as described in the IXIT, which is indicated by the UE after reception in a clear way according to the capabilities stored on the SIM. The manufacturer shall describe the indication on UE side for both CBS data types (e.g. certain CBS broadcast information shown in the display of the UE).~~



### Test procedure

- a) ~~The UE in RRC Idle mode is triggered to wait for the next system information. The UE is activated to receive CBS data 1, CBS data 2) are deactivated.~~
- b) ~~The UE and the SS have configured their RLC, MAC and PHYs layers with all CB related system information, broadcasted by SS.~~
- c) ~~The SS sends the first BMC CBS schedule message to predict the next CBS messages to the UE.~~
- d) ~~The SS sends the CBS message containing CB Data 1 to the UE, together with the CBS schedule message to predict the next CBS messages (repetition of CB Data 1, and the next CBS schedule message).~~
- e) ~~The UE indicates on an unambiguous way, that this CB Data 1 has been received by the UE (e.g. a unique part of the CBS data contents shown on the display).~~
- f) ~~The SS sends the repeated CB Data 1, and the next CBS schedule message to predict the next CBS messages to the UE. (CBS schedule message predicts the first repetition of CB Data).~~
- g) ~~The UE indicates on an unambiguous way, that CB Data 2 has been received by the UE (e.g. a unique part of the CBS data contents shown in the display).~~
- h) ~~The UE deactivates the CB Message type ID used for CB Data 1.~~
- i) ~~The SS sends the CB Data 2 (as deactivated CB Data type) to the UE.~~
- j) ~~The UE ignores the newly received CB Data 2, i.e. there is no indication for this CB Data 2 as described in step e).~~

## Expected sequence

| Step | Direction |    | Message            | Comments                                                                                                                                                                                                                                                                                                                                                                                                 |
|------|-----------|----|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                                                                                                                                                                                                                                                                                          |
| 1    | ←         |    | SYSTEM INFORMATION | Transmit these messages as described below on the BCCH, in addition to the regular BCCH transmissions.<br>Included are all CB-related system information parameter of the CBS:<br>- CTCH ID,<br>- FACH ID and associated format set,<br>- S-CCPCH ID,<br>- BMC Schedule Level 1 information (N,K)<br>The SS waits for about 10 s to make sure, that the UE is configured to receive the CBS Data message |
| 2    |           |    |                    |                                                                                                                                                                                                                                                                                                                                                                                                          |
| 3    |           |    | BMC CBS Schedule   | Inband CBS schedule message with BMC schedule information Level 2 (DRX) to predict the next CB data block (CB Data 1 –new-, CBS Schedule message)                                                                                                                                                                                                                                                        |
| 4    | ←         |    | BMC CBS Message    | Activated CBS message with certain CB data content (CBS data 1 as described by the manufacturer). This message is sent the first time. Parameter:<br>- Message_ID,<br>- Serial-No,<br>- Data coding scheme,<br>- CB-Data 1 (new)                                                                                                                                                                         |
| 5    |           |    |                    | After having received the BMC CB-Data 1 the UE shall indicate the reception in a clear way.                                                                                                                                                                                                                                                                                                              |
| 6    | ←         |    | BMC CBS Schedule   | Inband CBS schedule message with BMC schedule information Level 2 (DRX) to predict the next CB data block (CB Data 1 –rep.1-, CBS Schedule message)                                                                                                                                                                                                                                                      |
| 7    |           |    | BMC CBS Message    | Activated CBS message with certain CB data content (CBS data 1 as described by the manufacturer). This message is repeated. Parameter:<br>- Message_ID,<br>- Serial-No,<br>- Data coding scheme,<br>- CB-Data 1 (old)                                                                                                                                                                                    |
| 8    | ←         |    |                    | The UE deactivates "CB message type ID" used for CB-Data 1                                                                                                                                                                                                                                                                                                                                               |
| 9    |           |    | BMC CBS Schedule   | Inband CBS schedule message with BMC schedule information Level 2 (DRX) to predict the next CB data block (CB Data 2 –new-).                                                                                                                                                                                                                                                                             |
| 10   | ←         |    | BMC CBS Message    | Deactivated CBS message with certain CB data content (CBS data 2 as described by the manufacturer). This message is sent the first time. Parameter:<br>- Message_ID,<br>- Serial-No,<br>- Data coding scheme,<br>- CB-Data 2 (new)                                                                                                                                                                       |
| 11   |           |    |                    | After having received the BMC CBS message (CB-Data 2) the UE shall ignore the newly received CBS data 1 message, i.e. there is no indication as described by the manufacturer.                                                                                                                                                                                                                           |

## Specific Message Contents

## SYSTEM INFORMATION TYPE 5 and 6

The contents of SYSTEM INFORMATION TYPE 5 and 6 Information Element in this test case are identical to those of the default contents of layer 3 messages for RRC tests [TS 34.123-1] with the following exceptions:

| Information Element          | Value/remark                    |
|------------------------------|---------------------------------|
| CHOICE mode                  | (see RRC default test settings) |
| —CTCH allocation period      | N                               |
| —CTCH frame offset           | K                               |
| Secondary CCPCH system       | 1                               |
| —Secondary CCPCH information | (see RRC default test settings) |
| —TFCS                        | 1                               |
| —FACH/PCH information        | (see RRC default test settings) |
| —TFS                         | TRUE                            |
| —CTCH indicator              | (see RRC default test settings) |

## BMC CBS Message (Step 4 and 7)

| Information Element                 | Value/remark                                                                                                                        |
|-------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                        | 1 (CBS message)                                                                                                                     |
| Message ID                          | Bitstring (16) CB message ID, it shall fit to the stored Message ID in the SIM inserted in the UE (source and type) [see TS 23.041] |
| Serial Number                       | [see TS 23.041]                                                                                                                     |
| —Geographic Scope Indicator (2 bit) | 11 (Normal Cell wide)                                                                                                               |
| —Message Code (10 bit)              | according with the Message ID                                                                                                       |
| —Update Number (4 bit)              | for a new message: 0000, incremented by one for each repetition                                                                     |
| Data Coding Scheme                  | Bitstring (16) ID of the alphabet/coding and the applied language [see TS 23.041]                                                   |
| CB Data                             | Octetstring, [see IXIT value: CB-Data 1]                                                                                            |

## BMC CBS Message (Step 10)

| Information Element                 | Value/remark                                                                                                                        |
|-------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                        | 1 (CBS message)                                                                                                                     |
| Message ID                          | Bitstring (16) CB message ID, it shall fit to the stored Message ID in the SIM inserted in the UE (source and type) [see TS 23.041] |
| Serial Number                       | [see TS 23.041]                                                                                                                     |
| —Geographic Scope Indicator (2 bit) | 11 (Normal Cell wide)                                                                                                               |
| —Message Code (10 bit)              | according with the Message ID                                                                                                       |
| —Update Number (4 bit)              | for a new message: 0000, incremented by one for each repetition                                                                     |
| Data Coding Scheme                  | Bitstring (16) ID of the alphabet/coding and the applied language [see TS 23.041]                                                   |
| CB Data                             | Octetstring, [see IXIT value: CB-Data 2]                                                                                            |

## BMC Schedule Message (Step 3, 6 and Step 9)

The parameters for BMC Schedule Message (inband schedule message) in Step 5 are inserted for CB-Data 2 and in Step 8 for CB-Data 1.

| Information Element                               | Value/remark                                                                                                  |
|---------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
| Message Type                                      | 2 (Schedule message)                                                                                          |
| Offset to begin CTCH-BS index                     | calculated offset value of the BS (Integer: 0...255) as recommended in TR 25.925                              |
| Length of CBS Schedule Period                     | Number of consecutive CTCH-BS of the next CBS Schedule Period, (Integer: 1...255) as recommended in TR 25.925 |
| New Message Bitmap                                | Bitmap ( $N \times 8$ ), $N$ = Length of CBS Schedule Period as recommended in TR 25.925                      |
| Message Description                               | 1 for new message (see TS 25.324, Table 11.9-3)                                                               |
| - Message Description Type                        | 5 for old message (see TS 25.324, Table 11.9-3)                                                               |
| - Message ID                                      | CB message ID used for the next CB data                                                                       |
| - Offset to CTCH (BS index of first transmission) | for Message description type 1 or 5: CB message ID IE included (see TS 23.041)                                |

#### 7.4.3.1.5 ——— Test requirements

After having received the CB-Data 1 message (step 4), the UE shall store the Serial Number of this message and indicate the reception of the CBS message as described by the manufacturer.

After CB-Data 2 message was newly broadcasted (step 10), the UE shall not indicate the reception for the deactivated CBS message (CB-Data 1).

## 8 Radio Resource Control RRC

### 8.1 RRC Connection Management Procedure

#### 8.1.1 Paging

##### 8.1.1.1 Paging for Connection in idle mode

###### 8.1.1.1.1 Definition

###### 8.1.1.1.2 Conformance requirement

In idle mode, UE monitors the paging occasions determined using parameters from SYSTEM INFORMATION BLOCK messages. When the UE receives a PAGING TYPE 1 message transmitted on PCCH during one of its assigned paging occasions, it shall attempt to establish an RRC connection.

###### Reference

3GPP TS 25.331 clause 8.1.2, 3GPP TS 25.211 clause 5.3.3.7 (FDD), 3GPP TS 25.221 (TDD), 3GPP TS 25.304 clause 8.

###### 8.1.1.1.3 Test purpose

To confirm that the UE establishes an RRC connection after it receives a PAGING TYPE 1 message which includes IE "UE identity" (in IE "Paging Record") set to the IMSI of the UE.

###### 8.1.1.1.4 Method of test

###### Initial Condition

System Simulator: 1 cell

UE: Idle state (state 2 or state 3 or state 7) as specified in clause 7.4 of TS 34.108 with a CN UE identity (set to IMSI), depending on the CN domain(s) supported by the UE.

###### Test Procedure

SS transmits SYSTEM INFORMATION BLOCK TYPE 1 or 13 messages, depending on the CN type supported by the UE. The SS transmits a PAGING TYPE 1 message, which includes an unmatched CN UE identity for the UE in the idle state. The UE shall not change its state. The SS transmits a PAGING TYPE 1 message, which includes a matched CN UE identity for the UE in the idle state. During transmission of PAGING TYPE 1 messages, SS selects the correct paging indicator on the PICH in order to allow the UE to respond to paging. Then the UE transmits an RRC CONNECTION REQUEST to the SS, the SS transmits an RRC CONNECTION SETUP to the UE. When the UE receives this message, the UE establishes an RRC connection and transmits an RRC CONNECTION SETUP COMPLETE message on the uplink DCCH.

NOTE: For UEs supporting GSM-MAP CN type only, SYSTEM INFORMATION TYPE 1 messages are to be sent by SS in this test case. On the other hand, SS transmits SYSTEM INFORMATION TYPE 13 messages if the UE under test supports only ANSI-41 CN type.

## Expected sequence

| Step | Direction |    | Message                                                             | Comment                                                                                                                    |
|------|-----------|----|---------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                     |                                                                                                                            |
| 1    |           | ←  | SYSTEM INFORMATION BLOCK TYPE 13 or SYSTEM INFORMATION BLOCK TYPE 1 | Transmit these messages on the BCCH, in addition to the normal BCCH transmissions. See specific message contents.          |
| 2    |           | ←  | PAGING TYPE 1                                                       | The SS transmits the message, which includes an unmatched identity (incorrect IMSI), and the UE does not change its state. |
| 3    |           | ←  | PAGING TYPE 1                                                       | The SS transmits the message, which includes a matched identity (test-SIM-IMSI).                                           |
| 4    |           | →  | RRC CONNECTION REQUEST                                              |                                                                                                                            |
| 5    |           | ←  | RRC CONNECTION SETUP                                                | SS assigns DPCH resources to allow UE to establish an RRC connection.                                                      |
| 6    |           | →  | RRC CONNECTION SETUP COMPLETE                                       |                                                                                                                            |

## Specific Message Contents

## SYSTEM INFORMATION BLOCK TYPE 1 (Step 1) — for UEs supporting GSM-MAP core networks

| Information Element                               | Value/remark                              |
|---------------------------------------------------|-------------------------------------------|
| CN common GSM-MAP NAS system information          | Location Area Information (LAI)           |
| CN domain system information list                 |                                           |
| — CN domain system information                    |                                           |
| — CN domain identity                              | Supported Domain (PS Domain or CS Domain) |
| — CHOICE CN Type                                  | Supported CN type                         |
| — CN domain specific NAS system information       | 00-00(CS) or 1E-01(PS)                    |
| — CN domain specific DRX cycle length coefficient | 7                                         |
| UE Timers and constants in idle mode              |                                           |
| — T300                                            | 4000 milliseconds                         |
| — N300                                            | 3                                         |
| — T312                                            | 10 seconds                                |
| — N312                                            | 200                                       |

## SYSTEM INFORMATION TYPE 13 (Step 1) — for UEs supporting ANSI-41 core networks

| Information Element                               | Value/remark                              |
|---------------------------------------------------|-------------------------------------------|
| CN domain system information list                 | Only 1 entry                              |
| CN domain system information                      |                                           |
| — CN domain identity                              | Supported Domain (PS Domain or CS Domain) |
| — CHOICE CN Type                                  | Supported CN type                         |
| — CN domain specific NAS system information       | Default                                   |
| — CN domain specific DRX cycle length coefficient | 6                                         |
| UE Timers and constants in idle mode              |                                           |
| — T300                                            | 6000 milliseconds                         |
| — N300                                            | 3                                         |
| — T312                                            | 10 sec                                    |
| — N312                                            | 200                                       |

## PAGING TYPE 1 (Step 2)

| Information Element         | Value/remark                                                                                                            |
|-----------------------------|-------------------------------------------------------------------------------------------------------------------------|
| Message Type                |                                                                                                                         |
| Paging record list          | Only 1 entry                                                                                                            |
| Paging record               |                                                                                                                         |
| CHOICE Used paging identity | CN identity                                                                                                             |
| Paging cause                | Terminating Call with one of the supported services                                                                     |
| CN domain identity          | Supported Domain (PS Domain or CS Domain)                                                                               |
| CHOICE UE Identity          | IMSI                                                                                                                    |
| IMSI                        | Set to an arbitrary octet string of length 7 bytes which is different from the IMSI value stored in the TEST USIM card. |
| BCCH modification info      | Not Present                                                                                                             |

## PAGING TYPE 1 (Step 3)

| Information Element         | Value/remark                                                             |
|-----------------------------|--------------------------------------------------------------------------|
| Message Type                |                                                                          |
| Paging record list          | Only 1 entry                                                             |
| Paging record               |                                                                          |
| CHOICE Used paging identity | CN identity                                                              |
| Paging cause                | Terminating Call with one of the supported services                      |
| CN domain identity          | Supported Domain (PS Domain or CS Domain)                                |
| CHOICE UE Identity          | IMSI                                                                     |
| IMSI                        | Set to the same octet string as in the IMSI stored in the TEST USIM card |
| BCCH modification info      | Not Present                                                              |

## RRC CONNECTION REQUEST (Step 4)

| Information Element      | Value/remark                                                                                                         |
|--------------------------|----------------------------------------------------------------------------------------------------------------------|
| Message type             |                                                                                                                      |
| Initial UE identity      | Same as the IMSI stored in the TEST USIM card, or the registered TMSI or P-TMSI                                      |
| Establishment Cause      | Check to see if it is set to the same value as "Paging Cause" IE in the PAGING TYPE 1 message transmitted on step 3. |
| Protocol Error Indicator | Check to see if it is set to FALSE                                                                                   |
| Measured results on RACH | Not checked.                                                                                                         |

## 8.1.1.1.5 Test requirement

After step 2 the UE shall not transmit on the uplink CCCH in order to establish a RRC connection.

After step 5 the UE shall have an RRC connection based on dedicated physical channel resources and transmit an RRC CONNECTION SETUP COMPLETE message on the uplink DCCH.

## 8.1.1.2 Paging for Connection in connected mode (CELL\_PCH)

## 8.1.1.2.1 Definition

## 8.1.1.2.2 Conformance requirement

In CELL\_PCH state, a UE can respond to a paging request from UTRAN. In this case, the UTRAN has requested to establish a connection with the UE. The UE shall then attempt to perform a cell update procedure and move to CELL\_FACH state in order to respond to the paging using uplink CCCH.

## Reference

3GPP TS 25.331 clause 8.1.2.

### 8.1.1.2.3 Test purpose

To confirm that the UE enters the CELL\_FACH state after it receives a PAGING TYPE 1 message which indicates that the paging has originated from UTRAN. To verify that the UE performs cell update procedure after entering the CELL\_FACH state.

### 8.1.1.2.4 Method of test

#### Initial Condition

System Simulator: 1 cell

UE: CELL\_PCH state (state 6-12) as specified in clause 7.4 of TS 34.108, with a valid U-RNTI already assigned by the SS.

#### Test Procedure

SS transmits SYSTEM INFORMATION BLOCK TYPE 1 or 13 messages, depending on the CN type supported by the UE. The SS transmits a PAGING TYPE 1 message, which includes an unmatched U-RNTI. The UE does not change its state. Then SS transmits a PAGING TYPE 1 message with a matched identifier but originates from the CN instead of UTRAN. The UE shall not change state after receiving this message. The SS transmits a PAGING TYPE 1 message, which includes a matched U-RNTI. Then the UE enters the CELL\_FACH state and performs the cell updating procedure.

NOTE: For UEs supporting GSM-MAP CN type only, SYSTEM INFORMATION TYPE 1 messages are to be sent by SS in this test case. On the other hand, SS transmits SYSTEM INFORMATION TYPE 13 messages if the UE under test supports only ANSI-41 CN type.

#### Expected sequence

| Step | Direction |    | Message                                                             | Comment                                                                                                                                                               |
|------|-----------|----|---------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                     |                                                                                                                                                                       |
| 1    |           | ←  | SYSTEM INFORMATION BLOCK TYPE 13 or SYSTEM INFORMATION BLOCK TYPE 1 | Transmit these messages on the BCCH, in addition to the normal BCCH transmissions. See specific message contents                                                      |
| 2    |           | ←  | PAGING TYPE 1                                                       | The SS transmits a message including an unmatched identifier. UE shall not respond to the paging.                                                                     |
| 3    |           | ←  | PAGING TYPE 1                                                       | The SS transmits a message includes a matched identifier but with the originator being the CN; UE shall not respond to the paging.                                    |
| 4    |           | ←  | PAGING TYPE 1                                                       | The SS transmits the message with the UTRAN being the originator and including the UE's assigned U-RNTI                                                               |
| 5    |           | →  | CELL UPDATE                                                         | The UE enters the CELL_FACH state. UE performs cell updating procedure. The CELL UPDATE message shall contain the value "Cell Update Cause" set to "paging response". |
| 6    |           | ←  | CELL UPDATE CONFIRM                                                 | Use the default message specified in Annex A.                                                                                                                         |



## Specific Message Contents

## PAGING TYPE 1 (Step 2)

| Information Element                        | Value/remark                                                                          |
|--------------------------------------------|---------------------------------------------------------------------------------------|
| Message Type                               | Only 1 entry                                                                          |
| Paging record list                         |                                                                                       |
| Paging record                              |                                                                                       |
| —— CHOICE Used paging identity             | UTRAN identity                                                                        |
| —— U-RNTI                                  |                                                                                       |
| —— SRNC Identity                           | Set to an arbitrary 16-bit string which is different from the SRNC identity assigned. |
| —— S-RNTI                                  | Set to an arbitrary 20-bit string which is different from the S-RNTI assigned.        |
| —— CN originated page to connected mode UE | Not Present                                                                           |
| BCCH modification info                     | Not Present                                                                           |

## PAGING TYPE 1 (Step 3)

Same as the PAGING TYPE 1 message as in step 3 of clause 8.1.1.1.4.

## PAGING TYPE 1 (Step 4)

| Information Element                        | Value/remark                                          |
|--------------------------------------------|-------------------------------------------------------|
| Message Type                               | Only 1 entry                                          |
| Paging record list                         |                                                       |
| Paging record                              |                                                       |
| —— CHOICE Used paging identity             | UTRAN identity                                        |
| —— U-RNTI                                  |                                                       |
| —— SRNC Identity                           | Set to the same SRNC identity as previously assigned. |
| —— S-RNTI                                  | Set to the same S-RNTI as previously assigned.        |
| —— CN originated page to connected mode UE | Not Present                                           |
| BCCH modification info                     | Not Present                                           |

## SYSTEM INFORMATION BLOCK TYPE 13

Use the same SYSTEM INFORMATION BLOCK TYPE 13 message as specified in clause 8.1.1.1.4.

## SYSTEM INFORMATION BLOCK TYPE 1

Use the same SYSTEM INFORMATION BLOCK TYPE 1 message as specified in clause 8.1.1.1.4.

## 8.1.1.2.5 ——— Test requirement

After step 2 the UE shall not respond to the PAGING TYPE 1 message sent in step 2.

After step 3 the UE shall not respond to the PAGING TYPE 1 message sent in step 3.

After step 4 the UE shall enter the CELL\_FACH state and send a CELL\_UPDATE message with "Cell Update Cause" IE set to "paging response".

After step 6 the UE shall be in the CELL\_FACH state.

## 8.1.1.3 ——— Paging for Connection in connected mode (URA\_PCH)

## 8.1.1.3.1 ——— Definition

## 8.1.1.3.2 ——— Conformance requirement

This procedure is used to transmit a PAGING TYPE 1 message from the network to selected UEs in URA\_PCH state using the paging control channel (PCCH). The UE listens to it and then enters the CELL\_FACH state.

## Reference

3GPP TS 25.331 clause 8.1.2.

## 8.1.1.3.3 Test purpose

To confirm that the UE enters the CELL\_FACH state after it receives a PAGING TYPE 1 message which is set to "UTRAN identity" in IE "Used paging identity" and the U-RNTI value assigned to UE in the IE "U-RNTI".

## 8.1.1.3.4 Method of test

## Initial Condition

System Simulator: 1 cell.

UE: URA\_PCH state (state 6-13) as specified in clause 7.4 of TS 34.108, with a valid U-RNTI assigned by the SS.

## Test Procedure

The SS transmits a PAGING TYPE 1 message, which includes an unmatched U-RNTI. The UE does not change its current state. The SS transmits a PAGING TYPE 1 message which includes a matched U-RNTI. Then the UE listens to it and enters the CELL\_FACH state to transmit a CELL\_UPDATE message using uplink CCCH in respond to the paging.

## Expected sequence

| Step | Direction |    | Message             | Comment                                                                                               |
|------|-----------|----|---------------------|-------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                     |                                                                                                       |
| 1    |           | ←  | PAGING TYPE 1       | The SS transmits the message that includes an unmatched identifier, but UE does not change its state. |
| 2    |           | ←  | PAGING TYPE 1       | The SS transmits the message that includes a matched identifier.                                      |
| 3    |           | →  | CELL_UPDATE         | The UE enters the CELL_FACH state.                                                                    |
| 4    |           | ←  | CELL_UPDATE_CONFIRM | Use the default message specified in Annex A.                                                         |

## Specific Message Contents

## PAGING TYPE 1 (Step 1)

| Information Element                       | Value/remark                                                                       |
|-------------------------------------------|------------------------------------------------------------------------------------|
| Message Type                              | Only 1 entry                                                                       |
| Paging record list                        |                                                                                    |
| Paging record                             |                                                                                    |
| → CHOICE Used paging identity             | UTRAN identity                                                                     |
| → U-RNTI                                  |                                                                                    |
| → SRNC Identity                           | Set to an unused SRNC identity which is different from the SRNC identity assigned. |
| → S-RNTI                                  | Set to an arbitrary 20-bit string which is different from the S-RNTI assigned.     |
| → CN originated page to connected mode UE | Not Present                                                                        |
| BCCH modification info                    | Not Present                                                                        |

## PAGING TYPE 1 (Step 2)

| Information Element                     | Value/remark                                 |
|-----------------------------------------|----------------------------------------------|
| Message Type                            |                                              |
| Paging record list                      | Only 1 entry                                 |
| Paging record                           |                                              |
| CHOICE Used paging identity             | UTRAN identity                               |
| U-RNTI                                  |                                              |
| SRNC Identity                           | Set to the previously assigned SRNC identity |
| S-RNTI                                  | Set to previously assigned S-RNTI            |
| CN originated page to connected mode UE | Not Present                                  |
| BCCH modification info                  | Not Present                                  |

## 8.1.1.3.5 Test requirement

After step 1 the UE shall not respond to the paging.

After step 2 the UE shall enter the CELL\_FACH state, and transmit CELL\_UPDATE message to initiate the cell updating procedure with the paging cause set to "paging response".

After step 4 the UE shall be in the CELL\_FACH state.

## 8.1.1.4 Paging for Notification in idle mode

## 8.1.1.4.1 Definition

## 8.1.1.4.2 Conformance requirement

When a system information block on the BCCH is modified, the PAGING TYPE 1 message can be sent on the PCCH to inform UE in the idle mode about the changes, which are currently taking place. The PAGING TYPE 1 message includes the IE "BCCH Modification Information". Upon receiving this notification from the UTRAN, the UE shall read the relevant MIB and/or SIB(s) subsequently during idle mode.

## Reference

3GPP TS 25.331 clause 8.1. 2.

## 8.1.1.4.3 Test purpose

To confirm that the UE checks the new value tag of the master information block and reads the updated SYSTEM INFORMATION BLOCK messages after it receives a PAGING TYPE 1 message which includes the IE "BCCH Modification Information".

## 8.1.1.4.4 Method of test

## Initial Condition

System Simulator: 1 cell.

UE: Idle state (state 2 or state 3 or state 7) as specified in clause 7.4 of TS 34.108 with a CN UE identity, depending on the CN domain(s) supported by the UE.

## Test Procedure

The SS transmits a PAGING TYPE 1 message on the paging occasions assigned to the UE. The message shall include the IE "BCCH Modification Information" indicating the time when the first modified master information block is available. Before the starting time, SS continuously broadcast the original MASTER INFORMATION BLOCK and various types of SYSTEM INFORMATION BLOCK on the BCCH mapped to BCH transport channel. SS maintains this status until the SFN which corresponds to the modification time is reached. Then it transmits the new master information block followed by the new SYSTEM INFORMATION BLOCK TYPE 5 message. In the new SIB TYPE 5 message, the IE "Available Signature" is different when compared to the original SIB TYPE 5 message. At the paging occasion, SS transmits a new PAGING TYPE 1 message. This message addresses the UE using its IMSI and the "paging cause" IE set to a terminating call type that is supported by the UE. The UE shall respond with RRC CONNECTION REQUEST message. Then SS shall transmit RRC CONNECTION REJECT message to UE.

## Expected sequence

| Step | Direction |    | Message                         | Comment                                                                                                                                                                                                                                                                                                                                                                                                     |
|------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                             |
| 1    |           |    | Void                            |                                                                                                                                                                                                                                                                                                                                                                                                             |
| 2    |           | ←  | PAGING TYPE 1                   | SS transmits the message includes the IE "BCCH Modification Information", with the "Value Tag" changed from the "MIB Value Tag" of the current Master Information Block. Also the modification time is set to 4088 radio frame from the current SFN. SS continuously broadcast the same MASTER INFORMATION BLOCK and various types of SYSTEM INFORMATION BLOCK on BCCH for a period stretching 4087 frames. |
| 3    |           | ←  | MASTER INFORMATION BLOCK        | SS starts to transmit the MIB with the "MIB Value Tag" IE different from the original setting.                                                                                                                                                                                                                                                                                                              |
|      |           | ←  | SYSTEM INFORMATION BLOCK TYPE 5 | At the same time, SS starts to transmit the affected SIB TYPE 5 messages continuously. The IE "Available Signature" is changed from "0000 0000 1111 1111(B)" to "1111 1111 0000 0000(B)".<br><br>SS starts to monitor the uplink RACH after approximately 4087 frames from step 2.                                                                                                                          |
| 4    |           | ←  | PAGING TYPE 1                   | SS starts to transmit this message continuously on the PCCH at the correct paging occasion.                                                                                                                                                                                                                                                                                                                 |
| 5    |           | →  | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                             |
| 6    |           | ←  | RRC CONNECTION REJECT           |                                                                                                                                                                                                                                                                                                                                                                                                             |

## Specific Message Contents

### PAGING TYPE 1 (Step 2)

| Information Element    | Value/remark |
|------------------------|--------------|
| Message Type           |              |
| Paging record list     | Not Present  |
| BCCH modification info |              |
| MIB Value Tag          | 2            |
| BCCH Modification time | 4088         |

**MASTER INFORMATION BLOCK (Step 3)**

| Information Element | Value/remark |
|---------------------|--------------|
| MIB Value tag       | 2            |

**SYSTEM INFORMATION BLOCK TYPE 5 (Step 3)**

Use the same message type found in clause 6.1 of TS 34.108, with the following exception.

| Information Element                                                                                                              | Value/remark                  |
|----------------------------------------------------------------------------------------------------------------------------------|-------------------------------|
| <del>- PRACH system information</del><br><del>- PRACH info</del><br><del>— CHOICE mode</del><br><del>— Available Signature</del> | FDD<br>'1111 1111 0000 0000'B |

**PAGING TYPE 1 (Step 4)**

| Information Element                                                                                                                                                                                                                               | Value/remark                                                                                                                                                                                                                                 |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>Paging record list<br>Paging record<br><del>— CHOICE Used paging identity</del><br><del>— Paging Cause</del><br><del>— CN Domain Identity</del><br><del>— CHOICE UE Identity</del><br><del>— IMSI</del><br>BCCH modification info | Only 1 entry<br><br>CN identity<br>Terminating Call with one of the supported services<br>Supported Domain (PS Domain or CS Domain)<br>IMSI<br>Set to the same octet string as in the IMSI value stored in the TEST USIM card<br>Not Present |

**RRC CONNECTION REJECT**

Use the same message type found in clause Annex A.

**8.1.1.4.5 — Test requirement**

After step 4 the UE shall transmit RRC CONNECTION REQUEST messages in response to the PAGING TYPE 1 messages sent in step 4.

**8.1.1.5 — Paging for Notification in connected mode (CELL\_PCH)****8.1.1.5.1 — Definition****8.1.1.5.2 — Conformance requirement**

When a system information block on the BCCH is modified, the message PAGING TYPE 1 can be sent on the PCCH to inform UE in the CELL\_PCH state about this change. This message includes the IE "BCCH Modification Information". Upon receiving this notification from the UTRAN, the UE shall read the relevant MIB and/or SIB(s) subsequently while in CELL\_PCH state.

**Reference**

3GPP TS 25.331 clause 8.1. 2.

**8.1.1.5.3 — Test purpose**

To confirm that the UE, checks the new value tag of the master information block, and read the SYSTEM INFORMATION messages after it receives a PAGING TYPE 1 message which includes the IE "BCCH Modification Information".

#### 8.1.1.5.4 Method of test

##### Initial Condition

System Simulator: 1 cell.

UE: CELL\_PCH state (state 6-12) as specified in clause 7.4 of TS 34.108 with valid a U-RNTI assigned to it.

##### Test Procedure

The SS transmits a PAGING TYPE 1 message on the paging occasions assigned to the UE. The message shall include the IE "BCCH Modification Information" indicating the time when the first modified master information block is available. Before the starting time, SS continuously broadcast the original MASTER INFORMATION BLOCK and various types of SYSTEM INFORMATION BLOCK on the BCCH mapped to BCH transport channel. SS maintains this status until the SFN, which corresponds to the modification time, is reached. Then it transmits the new master information block followed by the new SYSTEM INFORMATION BLOCK TYPE 5 message. In the new SIB TYPE 5 message, the IE "Available Signature" is different when compared to the original SIB TYPE 5 message. At the paging occasion, SS transmits a new PAGING TYPE 1 message. This message addresses the UE using its U-RNTI. The UE shall respond with a CELL UPDATE message and set IE "cell update cause" to "paging response".

##### Expected sequence

| Step | Direction |    | Message                         | Comment                                                                                                                                                                                                                                                                                                                                                                                                               |
|------|-----------|----|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 1    |           |    | Void                            |                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 2    |           | ←  | PAGING TYPE 1                   | SS transmits the paging message which comprises IE "BCCH Modification Information", with the "Value Tag" changed from the "MIB Value Tag" of the current Master Information Block. Also the modification time is set to 4088 radio frame from the current SFN. SS continuously broadcast the same MASTER INFORMATION BLOCK and various types of SYSTEM INFORMATION BLOCK on BCCH for a period stretching 4087 frames. |
| 3    |           | ←  | MASTER INFORMATION BLOCK        | SS starts to transmit the MIB with the "MIB Value Tag" IE different from the original setting.                                                                                                                                                                                                                                                                                                                        |
|      |           | ←  | SYSTEM INFORMATION BLOCK TYPE 5 | At the same time, SS starts to transmit the affected SIB TYPE 5 continuously. The value of IE "Available Signature" is changed from "0000 0000 1111 1111(B)" to "1111 1111 0000 0000(B)".<br><br>SS starts to monitor the uplink RACH after approximately 4087 SFN from step 2.                                                                                                                                       |
| 4    |           | ←  | PAGING TYPE 1                   | SS transmits this message continuously on the PCCH at the correct paging occasion.                                                                                                                                                                                                                                                                                                                                    |
| 5    |           | →  | CELL UPDATE                     |                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 6    |           | ←  | CELL UPDATE CONFIRM             |                                                                                                                                                                                                                                                                                                                                                                                                                       |

## Specific Message Contents

## PAGING TYPE 1 (Step 2)

| Information Element                        | Value/remark                          |
|--------------------------------------------|---------------------------------------|
| Message Type                               |                                       |
| Paging record list                         | Only 1 entry                          |
| Paging record                              |                                       |
| —— CHOICE Used paging identity             | UTRAN identity                        |
| —— U-RNTI                                  | Equal to the U-RNTI assigned earlier. |
| —— SRNC Identity                           |                                       |
| —— S-RNTI                                  |                                       |
| —— CN originated page to connected mode UE | Not Present                           |
| BCCH modification info                     | 2                                     |
| —— MIB Value Tag                           | 4088                                  |
| —— BCCH Modification time                  |                                       |

## MASTER INFORMATION BLOCK (Step 3) and

## SYSTEM INFORMATION BLOCK TYPE 5 (Step 3)

The content of these messages is the same in the message used in step 3 specified in clause 8.1.1.4.4.

## PAGING TYPE 1 (Step 4)

| Information Element                        | Value/remark                          |
|--------------------------------------------|---------------------------------------|
| Message Type                               |                                       |
| Paging record list                         | Only 1 entry                          |
| Paging record                              |                                       |
| —— CHOICE Used paging identity             | UTRAN identity                        |
| —— U-RNTI                                  | Equal to the U-RNTI assigned earlier. |
| —— SRNC Identity                           |                                       |
| —— S-RNTI                                  |                                       |
| —— CN originated page to connected mode UE | Not Present                           |
| BCCH modification info                     | Not Present                           |

## CELL UPDATE (Step 5)

Check to see if the same message type found in Annex A is received, with the following exceptions:

| Information Element | Value/remark                                                |
|---------------------|-------------------------------------------------------------|
| U-RNTI              | Checked to see if it is set to the same values as in step 4 |
| —— SRNC identity    |                                                             |
| —— S-RNTI           |                                                             |
| Cell update cause   | Paging response                                             |

## CELL UPDATE CONFIRM (Step 6)

Use the same message type found in clause Annex A.

## 8.1.1.5.5 ——— Test requirement

After step 4 the UE shall transmit a CELL UPDATE message with IE "cell update cause" set to "paging response".

### ~~8.1.1.6 Paging for Notification in connected mode (URA\_PCH)~~

#### ~~8.1.1.6.1 Definition~~

#### ~~8.1.1.6.2 Conformance requirement~~

~~When a system information block on the BCCH is modified, the UTRAN can send a PAGING TYPE 1 message on the PCCH to inform UE about the changes while the UE is in the URA\_PCH state. This message includes the IE "BCCH Modification Information". When receiving this message in URA\_PCH state, the UE shall read the relevant MIB and/or SIB(s).~~

#### ~~Reference~~

~~3GPP TS 25.331 clause 8.1.2.~~

#### ~~8.1.1.6.3 Test purpose~~

~~To confirm that the UE checks the included new value tag of the master information block and reads the relevant SYSTEM INFORMATION block(s) after it receives a PAGING TYPE 1 message which includes the IE "BCCH Modification Information".~~

#### ~~8.1.1.6.4 Method of test~~

#### ~~Initial Condition~~

~~System Simulator: 1 cell~~

~~UE: URA\_PCH state (state 6-13) as specified in clause 7.4 of TS 34.108 with a valid U-RNTI assigned.~~

#### ~~Test Procedure~~

~~The SS transmits a PAGING TYPE 1 message on the paging occasions assigned to the UE. The message shall include the IE "BCCH Modification Information" indicating the time when the first modified master information block is available. Before the starting time, SS continuously broadcast the original MASTER INFORMATION BLOCK and various types of SYSTEM INFORMATION BLOCK on the BCCH mapped to BCH transport channel. SS maintains this status until the SFN which corresponds to the modification time is reached. Then it transmits the new master information block followed by the new SYSTEM INFORMATION BLOCK TYPE 5 message. In the new SIB TYPE 5 message, the IE "Available Signature" is different when compared to the original SIB TYPE 5 message. At the next paging occasion, SS transmits a new PAGING TYPE 1 message. This message addresses the UE using its U-RNTI and the "paging cause" IE set to a terminating call type that is supported by the UE. The UE shall respond with a CELL UPDATE message and set IE "cell update cause" to "paging response".~~



## Expected sequence

| Step | Direction |    | Message                         | Comment                                                                                                                                                                                                                                                                                                                                                                                                               |
|------|-----------|----|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 1    |           |    | Void                            |                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 2    |           | ←  | PAGING TYPE 1                   | SS transmits the paging message which comprises IE "BCCH Modification Information", with the "Value Tag" changed from the "MIB Value Tag" of the current Master Information Block. Also the modification time is set to 4088 radio frame from the current SFN. SS continuously broadcast the same MASTER INFORMATION BLOCK and various types of SYSTEM INFORMATION BLOCK on BCCH for a period stretching 4087 frames. |
| 3    |           | ←  | MASTER INFORMATION BLOCK        | SS starts to transmit the MIB with the "MIB Value Tag" IE different from the original setting.                                                                                                                                                                                                                                                                                                                        |
|      |           | ←  | SYSTEM INFORMATION BLOCK TYPE 5 | At the same time, SS starts to transmit the affected SIB TYPE 5 message continuously. The value of IE "Available Signature" is changed from "0000 0000 1111 1111(B)" to "1111 1111 0000 0000(B)".<br><br>SS starts to monitor the uplink RACH after approximately 4087 SFN from step 2.                                                                                                                               |
| 4    |           | ←  | PAGING TYPE 1                   | SS transmits this message continuously on the PCCH at the correct occasion.                                                                                                                                                                                                                                                                                                                                           |
| 5    |           | →  | CELL UPDATE                     |                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 6    |           | ←  | CELL UPDATE CONFIRM             |                                                                                                                                                                                                                                                                                                                                                                                                                       |

## Specific Message Contents

## PAGING TYPE 1 (Step 2)

| Information Element                       | Value/remark                                            |
|-------------------------------------------|---------------------------------------------------------|
| Message Type                              | Only 1 entry                                            |
| Paging record list                        |                                                         |
| Paging record                             | UTRAN identity<br>Equal to the U-RNTI assigned earlier. |
| — CHOICE Used paging identity             |                                                         |
| — U-RNTI                                  |                                                         |
| — SRNC Identity                           |                                                         |
| — S-RNTI                                  | Not Present                                             |
| — CN originated page to connected mode UE |                                                         |
| BCCH modification info                    | 2                                                       |
| — MIB Value Tag                           | 4088                                                    |
| — BCCH Modification time                  |                                                         |

## MASTER INFORMATION BLOCK (Step 3) and SYSTEM INFORMATION BLOCK TYPE 5 (Step 3)

The content of these messages is the same in the message used in step 3 specified in clause 8.1.1.4.4.

**PAGING TYPE 1 (Step 4)**

| Information Element                        | Value/remark                                            |
|--------------------------------------------|---------------------------------------------------------|
| Message Type                               | Only 1 entry                                            |
| Paging record list                         |                                                         |
| Paging record                              |                                                         |
| —— CHOICE Used paging identity             | UTRAN identity<br>Equal to the U-RNTI assigned earlier. |
| —— U-RNTI                                  |                                                         |
| —— SRNC Identity                           |                                                         |
| —— S-RNTI                                  | Not Present                                             |
| —— CN originated page to connected mode UE |                                                         |
| BCCH modification info                     | Not Present                                             |

**CELL UPDATE (Step 5)**

Check to see if the same message type found in Annex A is received, with the following exceptions:

| Information Element | Value/remark                                                |
|---------------------|-------------------------------------------------------------|
| U-RNTI              | Checked to see if it is set to the same values as in step 4 |
| —— SRNC identity    |                                                             |
| —— S-RNTI           |                                                             |
| Cell update cause   | Paging response                                             |

**CELL UPDATE CONFIRM (Step 6)**

Use the same message type found in clause Annex A.

**8.1.1.6.5 — Test requirement**

After step 4, the UE shall transmit a CELL UPDATE message with IE "cell update cause" set to "paging response".

**8.1.1.7 — Paging for Connection in connected mode (CELL\_DCH)****8.1.1.7.1 — Definition****8.1.1.7.2 — Conformance requirement**

This procedure is used to transmit a PAGING TYPE 2 message from the network to selected UE in CELL\_DCH state using the dedicated control channel (DCCH). The UE listens to it and responds to this message accordingly.

When UE receives an invalid PAGING TYPE 2 message, UE shall perform procedure specific error handling.

**Reference**

3GPP TS 25.331 clause 8.1.11.

**8.1.1.7.3 — Test purpose**

To confirm that the UE responds to a PAGING TYPE 2 message which includes IE "Paging Record Type Identifier" for the UE.

To confirm that the UE responds with a RRC STATUS message after it received an invalid PAGING TYPE 2 message.

**8.1.1.7.4 — Method of test****Initial Condition**

System Simulator: 1 cell.

UE: CELL\_DCH state (state 6-9 or state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE, after executing a location registration or attach procedure followed by the release of the TMSI of P-TMSI allocated.

### Test Procedure

The SS transmits an invalid PAGING TYPE 2 message. UE shall respond by transmitting a RRC STATUS message on the DCCH using RLC-AM mode. Finally, SS transmits a PAGING TYPE 2 message, which includes a matched Paging Record Type Identifier. Then the UE shall responds to this message by the transmission of an upper layer message.

### Expected sequence

| Step | Direction |    | Message                | Comment                                                                       |
|------|-----------|----|------------------------|-------------------------------------------------------------------------------|
|      | UE        | SS |                        |                                                                               |
| 1    |           |    | Void                   |                                                                               |
| 2    |           | ←  | PAGING TYPE 2          | See message content.                                                          |
| 3    |           | →  | RRC STATUS             | The UE shall respond by reporting the protocol error to the SS.               |
| 4    |           | ←  | PAGING TYPE 2          | SS pages the UE with a matched identifier and with a valid "paging cause" IE. |
| 5    |           | →  | UPLINK DIRECT TRANSFER | The UE shall respond to the paging message sent in step 3.                    |

### Specific Message Contents

#### PAGING TYPE 2 (Step 2)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

#### RRC STATUS (Step 3)

Use the same message type found in Annex A, with the following exception.

| Information Element        | Value/remark                                                 |
|----------------------------|--------------------------------------------------------------|
| Protocol error information | Checked to see if set to "ASN.1 violation or encoding error" |

#### PAGING TYPE 2 (Step 4)

Use the same message type found in Annex A, with the following exception.

| Information Element           | Values/Remarks                                                                                                                       |
|-------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|
| Paging cause                  | Terminating Call supported by the UE                                                                                                 |
| CN domain identity            | Domain supported by the UE                                                                                                           |
| Paging record type identifier | Set to "IMSI (GSM-MAP)" for UEs supporting GSM-MAP core network type or "IMSI (DS-41)" for UEs supporting ANSI-41 core network type. |

#### UPLINK DIRECT TRANSFER (Step 5)

Only the message type IE for this message is checked.

8.1.1.7.5 ~~Test requirement~~

~~After step 2 the UE shall respond to the paging message by transmitting RRC STATUS on the DCCH, stating the protocol error as "ASN.1 violation or encoding error".~~

~~After step 4 the UE shall respond to the paging message by transmitting an UPLINK DIRECT TRANSFER message on the uplink DCCH.~~

8.1.1.8 ~~Paging for Connection in connected mode (CELL\_FACH)~~

8.1.1.8.1 ~~Definition~~

8.1.1.8.2 ~~Conformance requirement~~

~~This procedure is used to transmit a PAGING TYPE 2 message from the network to selected UE in CELL\_FACH state using the dedicated control channel (DCCH). The UE shall listen to it and responds to this message accordingly.~~

Reference

~~3GPP TS 25.331 clause 8.1.11.~~

8.1.1.8.3 ~~Test purpose~~

~~To confirm that the UE responds to a PAGING TYPE 2 message, which includes a matching value for IE "Paging Record Type Identifier".~~

8.1.1.8.4 ~~Method of test~~

Initial Condition

System Simulator: 1 cell.

UE: CELL\_FACH state (state 6-11) as specified in clause 7.4 of TS 34.108.

Test Procedure

The SS transmits a PAGING TYPE 2 message. Then the UE shall respond by transmitting an upper layer message to answer this page.

Expected sequence

| Step | Direction |    | Message                | Comment                                                     |
|------|-----------|----|------------------------|-------------------------------------------------------------|
|      | UE        | SS |                        |                                                             |
| 1    |           |    | Void                   |                                                             |
| 2    |           | ←  | PAGING TYPE 2          | The SS transmits the message includes a matched identifier. |
| 3    |           | →  | UPLINK DIRECT TRANSFER | The UE responds by sending an upper layer message.          |

Specific Message Content

PAGING TYPE 2 (Step 1)

Use the same message content as in step 1 from 8.1.1.7.4.

UPLINK DIRECT TRANSFER (Step 2)

Only the message type IE for this message is checked.

#### 8.1.1.8.5 ~~Test requirement~~

~~After step 1 the UE shall respond to the PAGING TYPE 2 message by transmitting an UPLINK DIRECT TRANSFER message on the uplink DCCH.~~

### 8.1.2 ~~RRC Connection Establishment~~

#### 8.1.2.1 ~~RRC Connection Establishment in CELL\_DCH state: Success~~

##### 8.1.2.1.1 ~~Definition~~

##### 8.1.2.1.2 ~~Conformance requirement~~

- ~~1. The RRC connection establishment is initiated by the UE, which leaves the idle mode and transmits an RRC CONNECTION REQUEST message. This message shall include the IE "Initial UE identity" and is to be transmitted on the uplink CCCH.~~
- ~~2. After the UE receives an RRC CONNECTION SETUP message which includes the same value of the IE "initial UE identity", radio resource parameters (i.e. Signalling radio bearers and multiplexing info) and U-RNTI, UE then configures the layer 2 and layer 1 so as to support the DCCH according to the radio resource parameters specified. The procedure successfully ends when the network receives an RRC CONNECTION SETUP COMPLETE message on the uplink DCCH.~~

#### Reference

~~3GPP TS 25.331 clause 8.1.3.~~

##### 8.1.2.1.3 ~~Test purpose~~

~~To confirm that the UE leaves the Idle Mode and correctly establishes signalling radio bearers on the DCCH.~~

##### 8.1.2.1.4 ~~Method of test~~

#### Initial Condition

System Simulator: 1 cell.

UE: Idle state (state 2 or state 3 or state 7) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE transmits an RRC CONNECTION REQUEST message to the SS on the uplink CCCH by attempting to make an outgoing call. After SS receives this message, it assigns the necessary radio resources and U-RNTI to be used by the UE. SS then transmits an RRC CONNECTION SETUP message containing an IE "Initial UE Identity" that does not match the IE "Initial UE Identity" in the most recent RRC CONNECTION REQUEST message sent by the UE. UE receives the RRC CONNECTION SETUP message before timer T300 expires but discards it due to a IE "Initial UE Identity" mismatch. UE shall wait for timer T300 to time out before re-transmitting a RRC CONNECTION REQUEST message to the SS. SS again assigns the necessary radio resources and U-RNTI. SS then transmits a RRC CONNECTION SETUP message containing an IE "Initial UE Identity" that matches the IE "Initial UE Identity" in the most recent RRC CONNECTION REQUEST sent by the UE. SS then waits for the UE to transmit an RRC CONNECTION SETUP COMPLETE message on the DCCH.

## Expected sequence

| Step | Direction |    | Message                       | Comment                                                                              |
|------|-----------|----|-------------------------------|--------------------------------------------------------------------------------------|
|      | UE        | SS |                               |                                                                                      |
| 1    | →         |    | RRC CONNECTION REQUEST        | By outgoing call operation                                                           |
| 2    | ←         |    | RRC CONNECTION SETUP          | This message is not addressed to the UE.                                             |
| 3    | →         |    | RRC CONNECTION REQUEST        | UE shall re-transmit the request message again after a time out of T300 from step 1. |
| 4    | ←         |    | RRC CONNECTION SETUP          |                                                                                      |
| 5    |           |    |                               | The UE configures the layer 2 and layer 1.                                           |
| 6    | →         |    | RRC CONNECTION SETUP COMPLETE |                                                                                      |

## Specific Message Content

## RRC CONNECTION SETUP (Step 2)

Use the same message type found in clause 9 of TS 34.108, with the following exception.

| Information Element | Value/remark                                                                             |
|---------------------|------------------------------------------------------------------------------------------|
| Initial UE Identity | Set to the same type as in the RRC CONNECTION REQUEST message but with a different value |

## 8.1.2.1.5 ——— Test requirement

After step 2 the UE shall re-transmit the RRC CONNECTION REQUEST message again in order to continue the RRC connection establishment procedure.

After step 6 the UE shall establish an RRC connection and continue the procedure of the outgoing call on the DCCH.

## 8.1.2.2 ——— RRC Connection Establishment: Success after T300 timeout

## 8.1.2.2.1 ——— Definition

## 8.1.2.2.2 ——— Conformance requirement

1. The RRC connection establishment is initiated by the UE, which leaves the idle mode. The UE shall transmit an RRC CONNECTION REQUEST message which includes the IE "Initial UE identity". This message shall be sent on the uplink CCCH.
  - When there are more than one PRACHs available, the UE shall select one PRACH randomly and transmit an RRC CONNECTION REQUEST message by use of selected PRACH.
2. In the case of a failure to establish the RRC connection at the expiry of timer T300, the UE retries to establish the RRC connection until V300 is greater than N300

## Reference

3GPP TS 25.331 clause 8.1.3.

## 8.1.2.2.3 ——— Test purpose

To confirm that the UE retries to establish the RRC connection until V300 is greater than N300 after the expiry of timer T300 when the SS transmits no response for an RRC CONNECTION REQUEST message.

#### 8.1.2.2.4 ~~Method of test~~

##### ~~Initial Condition~~

~~System Simulator: 1 cell.~~

~~UE: Idle state (state 2 or state 3 or state 7) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.~~

##### ~~Test Procedure~~

~~Before the test starts, SYSTEM INFORMATION BLOCK TYPE 5 message is modified and this modification is notified to the UE. An internal counter K in SS is initialized to a value = 0. Following this, the UE shall transmit an RRC CONNECTION REQUEST message to the SS on the uplink CCCH by use of selected PRACH from the available PRACH No.1 and PRACH No.2, after the operator attempts to make an outgoing call. SS ignores this message, increments K every time such a message is received and waits for T300 timer to expire. This cycle is repeated until K reaches N300. When K is equal to N300, the SS transmits the RRC CONNECTION SETUP message specified in step 6 to the UE. The UE shall send another RRC CONNECTION REQUEST message on the uplink CCCH. SS replies with a valid RRC CONNECTION SETUP message. The UE shall then acknowledge the establishment of RRC connection by sending the RRC CONNECTION SETUP COMPLETE message on uplink DCCH.~~

## Expected sequence

| Step | Direction |    | Message                                                     | Comment                                                                                                                                                                                                                                                                                                                                                                                                                 |
|------|-----------|----|-------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                             |                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 1    |           | ←  | PAGING-TYPE 1                                               | SS transmits the paging message which comprises IE "BCCH Modification Information", with the "Value Tag" different from the "MIB Value Tag" of the current Master Information Block. Also the modification time is set to 4088 radio frame from the current SFN. SS continuously broadcast the same MASTER INFORMATION-BLOCK and various types of SYSTEM INFORMATION-BLOCK on BCCH for a period stretching 4087 frames. |
| 1a   |           | ←  | MASTER INFORMATION BLOCK<br>SYSTEM INFORMATION-BLOCK-TYPE 5 | SS starts to transmit the MIB with the "MIB Value Tag" IE different from the original setting. At the same time, SS starts to transmit the affected SIB TYPE 5 messages.                                                                                                                                                                                                                                                |
| 2    |           |    |                                                             | SS initializes counter K to 0. Operator is asked to make an outgoing call and SS starts to wait for RRC CONNECTION REQUEST on uplink CCCH.                                                                                                                                                                                                                                                                              |
| 3    |           | →  | RRC CONNECTION REQUEST                                      |                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 4    |           |    |                                                             | SS checks to see if K is equal to N300. If so, goes to step 6. Else, continues to execute step 5.                                                                                                                                                                                                                                                                                                                       |
| 5    |           |    |                                                             | SS increments K. The next step is step 3.                                                                                                                                                                                                                                                                                                                                                                               |
| 6    |           | ←  | RRC CONNECTION SETUP                                        | Use an invalid message in ASN.1.                                                                                                                                                                                                                                                                                                                                                                                        |
| 7    |           | →  | RRC CONNECTION REQUEST                                      |                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 8    |           | ←  | RRC CONNECTION SETUP                                        | This is a legal message. See the clause 9 in TS 34.108 on default message content for RRC.                                                                                                                                                                                                                                                                                                                              |
| 9    |           |    |                                                             | The UE configures the layer 1 and layer 2.                                                                                                                                                                                                                                                                                                                                                                              |
| 10   |           | →  | RRC CONNECTION SETUP COMPLETE                               |                                                                                                                                                                                                                                                                                                                                                                                                                         |



## Specific Message Contents

## PAGING TYPE 1 (Step 1a)

| Information Element           | Value/remark                          |
|-------------------------------|---------------------------------------|
| Message Type                  |                                       |
| Paging record list            | Only 1 entry                          |
| Paging record                 |                                       |
| — CHOICE Used paging identity | UTRAN identity                        |
| — U-RNTI                      | Equal to the U-RNTI assigned earlier. |
| — SRNC Identity               |                                       |
| — S-RNTI                      |                                       |
| BCCH modification info        |                                       |
| — MIB Value Tag               | 2                                     |
| — BCCH Modification time      | 4088                                  |

## SYSTEM INFORMATION TYPE 5 (Step 1) – (FDD)

|                                            |                           |
|--------------------------------------------|---------------------------|
| — PRACH system information                 | 2PRACHs                   |
| — PRACH info (PRACH No.1)                  |                           |
| — CHOICE mode                              | FDD                       |
| — Available Signature                      | '0000-0000-1111-1111'B    |
| — Available SF                             | 64                        |
| — Preamble scrambling code number          | 0                         |
| — Puncturing Limit                         | 100                       |
| — Available Sub-Channel number             | '1111-1111-1111'B         |
| — Transport Channel Identity               | 15                        |
| — RACH-TFS                                 |                           |
| — CHOICE Transport channel type            | Common transport channels |
| — Dynamic Transport format information     |                           |
| — RLC size                                 | 168                       |
| — Number of TB and TTI List                |                           |
| — Number of Transport blocks               | 1                         |
| — CHOICE Mode                              | FDD                       |
| — CHOICE Logical Channel List              | ALL                       |
| — RLC size                                 | 360                       |
| — Number of TB and TTI List                |                           |
| — Number of Transport blocks               | 1                         |
| — CHOICE Mode                              | FDD                       |
| — CHOICE Logical Channel List              | ALL                       |
| — Semi-static Transport Format information |                           |
| — Transmission time interval               | 20-ms                     |
| — Type of channel coding                   | Convolutional             |
| — Coding Rate                              | 1/2                       |
| — Rate matching attribute                  | 150                       |
| — CRC size                                 | 16                        |
| — RACH-TFCS                                |                           |
| — Normal                                   |                           |
| — TFCI Field 1 information                 |                           |
| — CHOICE TFCS representation               | Complete                  |
| — TFCS addition information                |                           |
| — CHOICE CTFC Size                         | 2-bit                     |
| — CTFC information                         | 0                         |
| — Power offset information                 |                           |
| — CHOICE Gain Factors                      | Computed Gain Factor      |
| — Power offset Pp-m                        | 0dB                       |
| — CTFC information                         | 1                         |
| — Reference TFC ID                         | 0                         |
| — Power offset information                 |                           |
| — CHOICE Gain Factors                      | Signalled Gain Factor     |
| — Gain factor βc                           | 11                        |
| — Gain factor βd                           | 15                        |
| — Reference TFC ID                         | 0                         |
| — Power offset Pp-m                        | 0dB                       |
| — PRACH partitioning                       |                           |
| — Access Service Class                     |                           |

|                                   |                 |  |  |
|-----------------------------------|-----------------|--|--|
| → ASC Setting                     |                 |  |  |
| → CHOICE mode                     | FDD             |  |  |
| → Available signature Start Index | 0 (ASC#0)       |  |  |
| → Available signature End Index   | 7 (ASC#0)       |  |  |
| → Assigned Sub-channel Number     | '1111'B         |  |  |
| → ASC Setting                     |                 |  |  |
| → CHOICE mode                     | FDD             |  |  |
| → Available signature Start Index | 0 (ASC#1)       |  |  |
| → Available signature End Index   | 7 (ASC#1)       |  |  |
| → Assigned Sub-channel Number     | '1111'B         |  |  |
| → ASC Setting                     |                 |  |  |
| → CHOICE mode                     | FDD             |  |  |
| → Available signature Start Index | 0 (ASC#2)       |  |  |
| → Available signature End Index   | 7 (ASC#2)       |  |  |
| → Assigned Sub-channel Number     | '1111'B         |  |  |
| → ASC Setting                     |                 |  |  |
| → CHOICE mode                     | FDD             |  |  |
| → Available signature Start Index | 0 (ASC#3)       |  |  |
| → Available signature End Index   | 7 (ASC#3)       |  |  |
| → Assigned Sub-channel Number     | '1111'B         |  |  |
| → ASC Setting                     |                 |  |  |
| → CHOICE mode                     | FDD             |  |  |
| → Available signature Start Index | 0 (ASC#4)       |  |  |
| → Available signature End Index   | 7 (ASC#4)       |  |  |
| → Assigned Sub-channel Number     | '1111'B         |  |  |
| → ASC Setting                     |                 |  |  |
| → CHOICE mode                     | FDD             |  |  |
| → Available signature Start Index | 0 (ASC#5)       |  |  |
| → Available signature End Index   | 7 (ASC#5)       |  |  |
| → Assigned Sub-channel Number     | '1111'B         |  |  |
| → ASC Setting                     |                 |  |  |
| → CHOICE mode                     | FDD             |  |  |
| → Available signature Start Index | 0 (ASC#6)       |  |  |
| → Available signature End Index   | 7 (ASC#6)       |  |  |
| → Assigned Sub-channel Number     | '1111'B         |  |  |
| → ASC Setting                     |                 |  |  |
| → CHOICE mode                     | FDD             |  |  |
| → Available signature Start Index | 0 (ASC#7)       |  |  |
| → Available signature End Index   | 7 (ASC#7)       |  |  |
| → Assigned Sub-channel Number     | '1111'B         |  |  |
| → Persistence scaling factor      |                 |  |  |
| → Persistence scaling factor      | 0.9 (for ASC#2) |  |  |
| → Persistence scaling factor      | 0.9 (for ASC#3) |  |  |
| → Persistence scaling factor      | 0.9 (for ASC#4) |  |  |
| → Persistence scaling factor      | 0.9 (for ASC#5) |  |  |
| → Persistence scaling factor      | 0.9 (for ASC#6) |  |  |
| → Persistence scaling factor      | 0.9 (for ASC#7) |  |  |
| → AC-to-ASC mapping table         |                 |  |  |
| → AC-to-ASC mapping               | 6 (AC0-9)       |  |  |
| → AC-to-ASC mapping               | 5 (AC10)        |  |  |
| → AC-to-ASC mapping               | 4 (AC11)        |  |  |
| → AC-to-ASC mapping               | 3 (AC12)        |  |  |
| → AC-to-ASC mapping               | 2 (AC13)        |  |  |
| → AC-to-ASC mapping               | 1 (AC14)        |  |  |
| → AC-to-ASC mapping               | 0 (AC15)        |  |  |
| CHOICE mode                       | FDD             |  |  |
| → Primary CPICH DL TX power       | 31              |  |  |
| → Constant value                  | -10             |  |  |
| → PRACH power offset              |                 |  |  |
| → Power Ramp Step                 | 3dB             |  |  |
| → Preamble Retrans Max            | 2               |  |  |
| → RACH transmission parameters    |                 |  |  |
| → Mmax                            | 2               |  |  |
| → NB01min                         | 3 slot          |  |  |
| → NB01max                         | 10 slot         |  |  |

|                                            |                           |  |
|--------------------------------------------|---------------------------|--|
| → AICH info                                | 3                         |  |
| → Channelisation code                      | FALSE                     |  |
| → STTD indicator                           | 0                         |  |
| → AICH transmission timing                 | 0                         |  |
| → PRACH info (PRACH No.2)                  | FDD                       |  |
| → CHOICE mode                              | '0000 0000 1111 1111'B    |  |
| → Available Signature                      | 64                        |  |
| → Available SF                             | 1                         |  |
| → Preamble scrambling code number          | 100                       |  |
| → Puncturing Limit                         | '1111 1111 1111'B         |  |
| → Available Sub-Channel number             | 15                        |  |
| → Transport Channel Identity               | Common transport channels |  |
| → RACH-TFS                                 | 168                       |  |
| → CHOICE Transport channel type            | 1                         |  |
| → Dynamic Transport format information     | FDD                       |  |
| → RLC size                                 | ALL                       |  |
| → Number of TB and TTI List                | 360                       |  |
| → Number of Transport blocks               | 1                         |  |
| → CHOICE Mode                              | FDD                       |  |
| → CHOICE Logical Channel List              | ALL                       |  |
| → RLC size                                 | ALL                       |  |
| → Number of TB and TTI List                | 20 ms                     |  |
| → Number of Transport blocks               | Convolutional             |  |
| → CHOICE Mode                              | 1/2                       |  |
| → CHOICE Logical Channel List              | 150                       |  |
| → Semi-static Transport Format information | 16                        |  |
| → Transmission time interval               |                           |  |
| → Type of channel coding                   |                           |  |
| → Coding Rate                              |                           |  |
| → Rate matching attribute                  |                           |  |
| → CRC size                                 |                           |  |
| → RACH-TFCS                                |                           |  |
| → Normal                                   |                           |  |
| → TFCL Field 1 information                 |                           |  |
| → CHOICE TFCS representation               | Complete                  |  |
| → TFCS addition information                |                           |  |
| → CHOICE CTFC Size                         | 2 bit                     |  |
| → CTFC information                         | 0                         |  |
| → Power offset information                 |                           |  |
| → CHOICE Gain Factors                      | Computed Gain Factor      |  |
| → Power offset Pp-m                        | 0 dB                      |  |
| → CTFC information                         | 1                         |  |
| → Reference TFC-ID                         | 0                         |  |
| → Power offset information                 |                           |  |
| → CHOICE Gain Factors                      | Signalled Gain Factor     |  |
| → Gain factor βc                           | 11                        |  |
| → Gain factor βd                           | 15                        |  |
| → Reference TFC-ID                         | 0                         |  |
| → Power offset Pp-m                        | 0 dB                      |  |
| → PRACH partitioning                       |                           |  |
| → Access Service Class                     |                           |  |
| → ASC Setting                              |                           |  |
| → CHOICE mode                              | FDD                       |  |
| → Available signature Start Index          | 0 (ASC#0)                 |  |
| → Available signature End Index            | 7 (ASC#0)                 |  |
| → Assigned Sub-channel Number              | '1111'B                   |  |
| → ASC Setting                              |                           |  |
| → CHOICE mode                              | FDD                       |  |
| → Available signature Start Index          | 0 (ASC#1)                 |  |
| → Available signature End Index            | 7 (ASC#1)                 |  |
| → Assigned Sub-channel Number              | '1111'B                   |  |
| → ASC Setting                              |                           |  |
| → CHOICE mode                              | FDD                       |  |
| → Available signature Start Index          | 0 (ASC#2)                 |  |
| → Available signature End Index            | 7 (ASC#2)                 |  |
| → Assigned Sub-channel Number              | '1111'B                   |  |
| → ASC Setting                              |                           |  |

|                                   |                 |
|-----------------------------------|-----------------|
| → CHOICE mode                     | FDD             |
| → Available signature Start Index | 0 (ASC#3)       |
| → Available signature End Index   | 7 (ASC#3)       |
| → Assigned Sub-channel Number     | '1111'B         |
| → ASC Setting                     |                 |
| → CHOICE mode                     | FDD             |
| → Available signature Start Index | 0 (ASC#4)       |
| → Available signature End Index   | 7 (ASC#4)       |
| → Assigned Sub-channel Number     | '1111'B         |
| → ASC Setting                     |                 |
| → CHOICE mode                     | FDD             |
| → Available signature Start Index | 0 (ASC#5)       |
| → Available signature End Index   | 7 (ASC#5)       |
| → Assigned Sub-channel Number     | '1111'B         |
| → ASC Setting                     |                 |
| → CHOICE mode                     | FDD             |
| → Available signature Start Index | 0 (ASC#6)       |
| → Available signature End Index   | 7 (ASC#6)       |
| → Assigned Sub-channel Number     | '1111'B         |
| → ASC Setting                     |                 |
| → CHOICE mode                     | FDD             |
| → Available signature Start Index | 0 (ASC#7)       |
| → Available signature End Index   | 7 (ASC#7)       |
| → Assigned Sub-channel Number     | '1111'B         |
| → Persistence scaling factor      |                 |
| → Persistence scaling factor      | 0.9 (for ASC#2) |
| → Persistence scaling factor      | 0.9 (for ASC#3) |
| → Persistence scaling factor      | 0.9 (for ASC#4) |
| → Persistence scaling factor      | 0.9 (for ASC#5) |
| → Persistence scaling factor      | 0.9 (for ASC#6) |
| → Persistence scaling factor      | 0.9 (for ASC#7) |
| → AC-to-ASC mapping table         |                 |
| → AC-to-ASC mapping               | 6 (AC0-9)       |
| → AC-to-ASC mapping               | 5 (AC10)        |
| → AC-to-ASC mapping               | 4 (AC11)        |
| → AC-to-ASC mapping               | 3 (AC12)        |
| → AC-to-ASC mapping               | 2 (AC13)        |
| → AC-to-ASC mapping               | 1 (AC14)        |
| → AC-to-ASC mapping               | 0 (AC15)        |
| CHOICE mode                       | FDD             |
| → Primary CPICH DL TX power       | 31              |
| → Constant value                  | -10             |
| → PRACH power offset              |                 |
| → Power Ramp Step                 | 3dB             |
| → Preamble Retrans Max            | 2               |
| → RACH transmission parameters    |                 |
| → Mmax                            | 2               |
| → NB01min                         | 3-slot          |
| → NB01max                         | 10-slot         |
| → AICH info                       |                 |
| → Channelisation code             | 4               |
| → STTD indicator                  | FALSE           |
| → AICH transmission timing        | 0               |

## SYSTEM INFORMATION TYPE 5 (Step 1) — 3.84 Mcps TDD

|                                            |                           |
|--------------------------------------------|---------------------------|
| → PRACH system information                 | 2PRACHs                   |
| → PRACH info (PRACH No.1)                  |                           |
| → CHOICE mode                              | TDD                       |
| → CHOICE TDD option                        | 3.84 Mcps TDD             |
| → Timeslot Number                          | 14                        |
| → PRACH Channelisation Code                |                           |
| → CHOICE SF                                | 8                         |
| → Channelisation Code List                 |                           |
| → Channelisation Code                      | 8/1                       |
| → Channelisation Code                      | 8/2                       |
| → Channelisation Code                      | 8/3                       |
| → Channelisation Code                      | 8/4                       |
| → PRACH Midamble                           | Direct                    |
| → PNBSCH allocation                        | Not Present               |
| → Transport Channel Identity               | 15                        |
| → RACH TFS                                 |                           |
| → CHOICE Transport channel type            | Common transport channels |
| → Dynamic Transport format information     |                           |
| → RLC size                                 | 168                       |
| → Number of TB and TTI List                |                           |
| → Transport Time Interval                  | Not Present               |
| → Number of Transport Blocks               | 1                         |
| → CHOICE Logical Channel List              | ALL                       |
| → Semi-static Transport Format information |                           |
| → Transmission time interval               | 10-ms                     |
| → Type of channel coding                   | Convolutional             |
| → Coding Rate                              | 1/2                       |
| → Rate matching attribute                  | 150                       |
| → CRC size                                 | 16                        |
| → RACH TFCS                                | Not Present               |
| → PRACH partitioning                       |                           |
| → Access Service Class                     |                           |
| → ASC Setting                              |                           |
| → CHOICE mode                              | TDD                       |
| → CHOICE TDD option                        | 3.84 Mcps TDD             |
| → Available SYNC_UL codes indices          | '11110000'B (ASC#0)       |
| → CHOICE subchannel size                   | Size1                     |
| → ASC Setting                              |                           |
| → CHOICE mode                              | TDD                       |
| → CHOICE TDD option                        | 3.84 Mcps TDD             |
| → Available SYNC_UL codes indices          | '11110000'B (ASC#1)       |
| → CHOICE subchannel size                   | Size1                     |
| → ASC Setting                              |                           |
| → CHOICE mode                              | TDD                       |
| → CHOICE TDD option                        | 3.84 Mcps TDD             |
| → Available SYNC_UL codes indices          | '11110000'B (ASC#2)       |
| → CHOICE subchannel size                   | Size1                     |
| → ASC Setting                              |                           |
| → CHOICE mode                              | TDD                       |
| → CHOICE TDD option                        | 3.84 Mcps TDD             |
| → Available SYNC_UL codes indices          | '11110000'B (ASC#3)       |
| → CHOICE subchannel size                   | Size1                     |
| → ASC Setting                              |                           |
| → CHOICE mode                              | TDD                       |
| → CHOICE TDD option                        | 3.84 Mcps TDD             |
| → Available SYNC_UL codes indices          | '11110000'B (ASC#4)       |
| → CHOICE subchannel size                   | Size1                     |
| → ASC Setting                              |                           |
| → CHOICE mode                              | TDD                       |
| → CHOICE TDD option                        | 3.84 Mcps TDD             |
| → Available SYNC_UL codes indices          | '11110000'B (ASC#5)       |
| → CHOICE subchannel size                   | Size1                     |
| → ASC Setting                              |                           |
| → CHOICE mode                              | TDD                       |

|                                            |                                        |
|--------------------------------------------|----------------------------------------|
| → CHOICE TDD-option                        | 3.84 Mcps TDD                          |
| → Available SYNC_UL codes-indices          | '11110000'B (ASC#6)                    |
| → CHOICE subchannel-size                   | Size1                                  |
| → ASC-Setting                              |                                        |
| → CHOICE mode                              | TDD                                    |
| → CHOICE TDD-option                        | 3.84 Mcps TDD                          |
| → Available SYNC_UL codes-indices          | '11110000'B (ASC#7)                    |
| → CHOICE subchannel-size                   | Size1                                  |
| → Persistence-scaling-factor               |                                        |
| → Persistence-scaling-factor               | 0.9 (for ASC#2)                        |
| → Persistence-scaling-factor               | 0.9 (for ASC#3)                        |
| → Persistence-scaling-factor               | 0.9 (for ASC#4)                        |
| → Persistence-scaling-factor               | 0.9 (for ASC#5)                        |
| → Persistence-scaling-factor               | 0.9 (for ASC#6)                        |
| → Persistence-scaling-factor               | 0.9 (for ASC#7)                        |
| → AC-to-ASC-mapping-table                  |                                        |
| → AC-to-ASC-mapping                        | 6 (AC0-9)                              |
| → AC-to-ASC-mapping                        | 5 (AC10)                               |
| → AC-to-ASC-mapping                        | 4 (AC11)                               |
| → AC-to-ASC-mapping                        | 3 (AC12)                               |
| → AC-to-ASC-mapping                        | 2 (AC13)                               |
| → AC-to-ASC-mapping                        | 1 (AC14)                               |
| → AC-to-ASC-mapping                        | 0 (AC15)                               |
| → CHOICE mode                              | TDD                                    |
| → PRACH-info (PRACH-No.2)                  |                                        |
| → CHOICE mode                              | TDD                                    |
| → CHOICE TDD-option                        | 3.84 Mcps TDD                          |
| → Timeslot-Number                          | 14                                     |
| → PRACH-Channelisation-Code                |                                        |
| → CHOICE SF                                | 8                                      |
| → Channelisation-Code-List                 |                                        |
| → Channelisation-Code                      | 8/5 where i denotes an unassigned-code |
| → Channelisation-Code                      | 8/6 where i denotes an unassigned-code |
| → Channelisation-Code                      | 8/7 where i denotes an unassigned-code |
| → Channelisation-Code                      | 8/8 where i denotes an unassigned-code |
| → PRACH Midamble                           | Direct                                 |
| → PNBSCH allocation                        | Not Present                            |
| → RACH TFS                                 |                                        |
| → CHOICE Transport-channel-type            | Common transport channels              |
| → Dynamic-Transport-format-information     |                                        |
| → RLC-size                                 | 168                                    |
| → Number-of-TB-and-TTI-List                |                                        |
| → Transport-Time-Interval                  | Not Present                            |
| → Number-of-Transport-Blocks               | 1                                      |
| → CHOICE Logical-Channel-List              | ALL                                    |
| → Semi-static-Transport-Format-information |                                        |
| → Transmission-time-interval               | 10-ms                                  |
| → Type-of-channel-coding                   | Convolutional                          |
| → Coding-Rate                              | 1/2                                    |
| → Rate-matching-attribute                  | 150                                    |
| → CRC-size                                 | 16                                     |
| → RACH TFCS                                | Not Present                            |
| → PRACH partitioning                       |                                        |
| → Access-Service-Class                     |                                        |
| → ASC-Setting                              |                                        |
| → CHOICE mode                              | TDD                                    |
| → CHOICE TDD-option                        | 3.84 Mcps TDD                          |
| → Available SYNC_UL codes-indices          | '00001111'B (ASC#0)                    |
| → CHOICE subchannel-size                   | Size1                                  |
| → ASC-Setting                              |                                        |
| → CHOICE mode                              | TDD                                    |
| → CHOICE TDD-option                        | 3.84 Mcps TDD                          |
| → Available SYNC_UL codes-indices          | '00001111'B (ASC#1)                    |
| → CHOICE subchannel-size                   | Size1                                  |
| → ASC-Setting                              |                                        |
| → CHOICE mode                              | TDD                                    |
| → CHOICE TDD-option                        | 3.84 Mcps TDD                          |

|                                   |                     |
|-----------------------------------|---------------------|
| → Available SYNC_UL codes indices | '00001111'B (ASC#2) |
| → CHOICE subchannel size          | Size1               |
| → ASC Setting                     |                     |
| → CHOICE mode                     | TDD                 |
| → CHOICE TDD option               | 3.84 Mcps TDD       |
| → Available SYNC_UL codes indices | '00001111'B (ASC#3) |
| → CHOICE subchannel size          | Size1               |
| → ASC Setting                     |                     |
| → CHOICE mode                     | TDD                 |
| → CHOICE TDD option               | 3.84 Mcps TDD       |
| → Available SYNC_UL codes indices | '00001111'B (ASC#4) |
| → CHOICE subchannel size          | Size1               |
| → ASC Setting                     |                     |
| → CHOICE mode                     | TDD                 |
| → CHOICE TDD option               | 3.84 Mcps TDD       |
| → Available SYNC_UL codes indices | '00001111'B (ASC#5) |
| → CHOICE subchannel size          | Size1               |
| → ASC Setting                     |                     |
| → CHOICE mode                     | TDD                 |
| → CHOICE TDD option               | 3.84 Mcps TDD       |
| → Available SYNC_UL codes indices | '00001111'B (ASC#6) |
| → CHOICE subchannel size          | Size1               |
| → ASC Setting                     |                     |
| → CHOICE mode                     | TDD                 |
| → CHOICE TDD option               | 3.84 Mcps TDD       |
| → Available SYNC_UL codes indices | '00001111'B (ASC#7) |
| → CHOICE subchannel size          | Size1               |
| → Persistence scaling factor      |                     |
| → Persistence scaling factor      | 0.9 (for ASC#2)     |
| → Persistence scaling factor      | 0.9 (for ASC#3)     |
| → Persistence scaling factor      | 0.9 (for ASC#4)     |
| → Persistence scaling factor      | 0.9 (for ASC#5)     |
| → Persistence scaling factor      | 0.9 (for ASC#6)     |
| → Persistence scaling factor      | 0.9 (for ASC#7)     |
| → AC-to-ASC mapping table         |                     |
| → AC-to-ASC mapping               | 6 (AC0-9)           |
| → AC-to-ASC mapping               | 5 (AC10)            |
| → AC-to-ASC mapping               | 4 (AC11)            |
| → AC-to-ASC mapping               | 3 (AC12)            |
| → AC-to-ASC mapping               | 2 (AC13)            |
| → AC-to-ASC mapping               | 1 (AC14)            |
| → AC-to-ASC mapping               | 0 (AC15)            |
| → CHOICE mode                     | TDD                 |

## SYSTEM INFORMATION TYPE 5 (Step 1) — 1.28 Mcps TDD

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>→ PRACH system information</li> <li>→ PRACH info (PRACH No.1)</li> <li>→ CHOICE mode</li> <li>→ CHOICE TDD option</li> <li>→ SYNC_UL info</li> <li>→ SYNC_UL codes bitmap</li> <li>→ PRX<sub>UpPCHdes</sub></li> <li>→ Power Ramping Step</li> <li>→ Max SYNC_UL Transmissions</li> <li>→ Mmax</li> <li>→ PRACH Definition</li> <li>→ Timeslot Number</li> <li>→ CHOICE TDD option</li> <li>→ Timeslot number</li> <li>→ PRACH Channelisation Code</li> <li>→ Channelisation Code List</li> <li>→ Channelisation Code</li> <li>→ Midamble shift and burst type</li> <li>→ CHOICE TDD option</li> <li>→ Midamble Allocation Mode</li> <li>→ Midamble Configuration</li> <li>→ Midamble Shift</li> <li>→ FPACH info</li> <li>→ Timeslot number</li> <li>→ Channelisation code</li> <li>→ Midamble Shift and burst type</li> <li>→ CHOICE TDD option</li> <li>→ Midamble Allocation Mode</li> <li>→ Midamble Configuration</li> <li>→ Midamble Shift</li> <li>→ WT</li> <li>→ PNBSCH allocation</li> <li>→ Transport Channel Identity</li> </ul> | <ul style="list-style-type: none"> <li>2PRACHs</li> <li>TDD</li> <li>1.28 Mcps TDD</li> <li>'11110000'B</li> <li>10</li> <li>3</li> <li>8</li> <li>32</li> <li>1.28 Mcps TDD</li> <li>1</li> <li>8/1</li> <li>1.28 Mcps TDD</li> <li>Default</li> <li>8</li> <li>Not Present</li> <li>6</li> <li>16/16</li> <li>1.28 Mcps TDD</li> <li>Default</li> <li>16</li> <li>Not Present</li> <li>4</li> <li>Not Present</li> <li>15</li> </ul>     |
| <ul style="list-style-type: none"> <li>→ RACH TFS</li> <li>→ CHOICE Transport channel type</li> <li>→ Dynamic Transport format information</li> <li>→ RLC size</li> <li>→ Number of TB and TTI List</li> <li>→ Transport Time Interval</li> <li>→ Number of Transport Blocks</li> <li>→ CHOICE Logical Channel List</li> <li>→ Semi-static Transport Format information</li> <li>→ Transmission time interval</li> <li>→ Type of channel coding</li> <li>→ Coding Rate</li> <li>→ Rate matching attribute</li> <li>→ CRC size</li> <li>→ RACH TFCS</li> <li>→ PRACH partitioning</li> <li>→ Access Service Class</li> <li>→ ASC Setting</li> <li>→ CHOICE mode</li> <li>→ CHOICE TDD option</li> <li>→ Available SYNC_UL codes indices</li> <li>→ CHOICE subchannel size</li> <li>→ ASC Setting</li> <li>→ CHOICE mode</li> <li>→ CHOICE TDD option</li> <li>→ Available SYNC_UL codes indices</li> <li>→ CHOICE subchannel size</li> <li>→ ASC Setting</li> <li>→ CHOICE mode</li> <li>→ CHOICE TDD option</li> </ul>                                                               | <ul style="list-style-type: none"> <li>Common transport channels</li> <li>168</li> <li>Not Present</li> <li>1</li> <li>ALL</li> <li>10 ms</li> <li>Convolutional</li> <li>1/2</li> <li>150</li> <li>16</li> <li>Not Present</li> <li>TDD</li> <li>1.28 Mcps TDD</li> <li>'11110000'B (ASC#0)</li> <li>Size1</li> <li>TDD</li> <li>1.28 Mcps TDD</li> <li>'11110000'B (ASC#1)</li> <li>Size1</li> <li>TDD</li> <li>1.28 Mcps TDD</li> </ul> |



|                                   |                                 |  |
|-----------------------------------|---------------------------------|--|
| → Available SYNC_UL codes indices | '11110000'B (ASC#2)             |  |
| → CHOICE subchannel size          | Size1                           |  |
| → ASC Setting                     |                                 |  |
| → CHOICE mode                     | TDD                             |  |
| → CHOICE TDD option               | 1.28 Mcps TDD                   |  |
| → Available SYNC_UL codes indices | '11110000'B (ASC#3)             |  |
| → CHOICE subchannel size          | Size1                           |  |
| → ASC Setting                     |                                 |  |
| → CHOICE mode                     | TDD                             |  |
| → CHOICE TDD option               | 1.28 Mcps TDD                   |  |
| → Available SYNC_UL codes indices | '11110000'B (ASC#4)             |  |
| → CHOICE subchannel size          | Size1                           |  |
| → ASC Setting                     |                                 |  |
| → CHOICE mode                     | TDD                             |  |
| → CHOICE TDD option               | 1.28 Mcps TDD                   |  |
| → Available SYNC_UL codes indices | '11110000'B (ASC#5)             |  |
| → CHOICE subchannel size          | Size1                           |  |
| → ASC Setting                     |                                 |  |
| → CHOICE mode                     | TDD                             |  |
| → CHOICE TDD option               | 1.28 Mcps TDD                   |  |
| → Available SYNC_UL codes indices | '11110000'B (ASC#6)             |  |
| → CHOICE subchannel size          | Size1                           |  |
| → ASC Setting                     |                                 |  |
| → CHOICE mode                     | TDD                             |  |
| → CHOICE TDD option               | 1.28 Mcps TDD                   |  |
| → Available SYNC_UL codes indices | '11110000'B (ASC#7)             |  |
| → CHOICE subchannel size          | Size1                           |  |
| → Persistence scaling factor      |                                 |  |
| → Persistence scaling factor      | 0.9 (for ASC#2)                 |  |
| → Persistence scaling factor      | 0.9 (for ASC#3)                 |  |
| → Persistence scaling factor      | 0.9 (for ASC#4)                 |  |
| → Persistence scaling factor      | 0.9 (for ASC#5)                 |  |
| → Persistence scaling factor      | 0.9 (for ASC#6)                 |  |
| → Persistence scaling factor      | 0.9 (for ASC#7)                 |  |
| → AC-to-ASC mapping table         |                                 |  |
| → AC-to-ASC mapping               | 6 (AC0-9)                       |  |
| → AC-to-ASC mapping               | 5 (AC10)                        |  |
| → AC-to-ASC mapping               | 4 (AC11)                        |  |
| → AC-to-ASC mapping               | 3 (AC12)                        |  |
| → AC-to-ASC mapping               | 2 (AC13)                        |  |
| → AC-to-ASC mapping               | 1 (AC14)                        |  |
| → AC-to-ASC mapping               | 0 (AC15)                        |  |
| → CHOICE mode                     | TDD                             |  |
| → PRACH info (PRACH No.2)         |                                 |  |
| → CHOICE mode                     | TDD                             |  |
| → CHOICE TDD option               | 1.28 Mcps TDD                   |  |
| → SYNC_UL info                    |                                 |  |
| → SYNC_UL codes bitmap            | '11110000'B                     |  |
| → PRX <sub>UpPCHdes</sub>         | 10                              |  |
| → Power Ramping Step              | 1                               |  |
| → Max SYNC_UL Transmissions       | 8                               |  |
| → Mmax                            | 32                              |  |
| → PRACH Definition                |                                 |  |
| → Timeslot Number                 |                                 |  |
| → CHOICE TDD option               | 1.28 Mcps TDD                   |  |
| → Timeslot number                 | 1                               |  |
| → PRACH Channelisation Code       |                                 |  |
| → Channelisation Code List        |                                 |  |
| → Channelisation Code             | 8/2                             |  |
| → Midamble shift and burst type   |                                 |  |
| → CHOICE TDD option               | 1.28 Mcps TDD                   |  |
| → Midamble Allocation Mode        | Default                         |  |
| → Midamble Configuration          | 8                               |  |
| → Midamble Shift                  | Not Present                     |  |
| → FPACH info                      |                                 |  |
| → Timeslot number                 | An available down-link timeslot |  |

|                                                     |                                      |  |  |
|-----------------------------------------------------|--------------------------------------|--|--|
| <del>Channelisation code</del>                      | <del>16/15</del>                     |  |  |
| <del>Midamble Shift and burst type</del>            |                                      |  |  |
| <del>CHOICE TDD option</del>                        | <del>1.28 Mcps TDD</del>             |  |  |
| <del>Midamble Allocation Mode</del>                 | <del>Default</del>                   |  |  |
| <del>Midamble Configuration</del>                   | <del>16</del>                        |  |  |
| <del>Midamble Shift</del>                           | <del>Not Present</del>               |  |  |
| <del>WT</del>                                       | <del>4</del>                         |  |  |
| <del>PNBSCH allocation</del>                        | <del>Not Present</del>               |  |  |
| <del>RACH TFS</del>                                 |                                      |  |  |
| <del>CHOICE Transport channel type</del>            | <del>Common transport channels</del> |  |  |
| <del>Dynamic Transport format information</del>     |                                      |  |  |
| <del>RLC size</del>                                 | <del>168</del>                       |  |  |
| <del>Number of TB and TTI List</del>                |                                      |  |  |
| <del>Transport Time Interval</del>                  | <del>Not Present</del>               |  |  |
| <del>Number of Transport Blocks</del>               | <del>1</del>                         |  |  |
| <del>CHOICE Logical Channel List</del>              | <del>ALL</del>                       |  |  |
| <del>Semi-static Transport Format information</del> |                                      |  |  |
| <del>Transmission time interval</del>               | <del>10 ms</del>                     |  |  |
| <del>Type of channel coding</del>                   | <del>Convolutional</del>             |  |  |
| <del>Coding Rate</del>                              | <del>1/2</del>                       |  |  |
| <del>Rate matching attribute</del>                  | <del>150</del>                       |  |  |
| <del>CRC size</del>                                 | <del>16</del>                        |  |  |
| <del>RACH TFCS</del>                                | <del>Not Present</del>               |  |  |
| <del>PRACH partitioning</del>                       |                                      |  |  |
| <del>Access Service Class</del>                     |                                      |  |  |
| <del>ASC Setting</del>                              |                                      |  |  |
| <del>CHOICE mode</del>                              | <del>TDD</del>                       |  |  |
| <del>CHOICE TDD option</del>                        | <del>1.28 Mcps TDD</del>             |  |  |
| <del>Available SYNC_UL codes indices</del>          | <del>'00001111'B (ASC#0)</del>       |  |  |
| <del>CHOICE subchannel size</del>                   | <del>Size1</del>                     |  |  |
| <del>ASC Setting</del>                              |                                      |  |  |
| <del>CHOICE mode</del>                              | <del>TDD</del>                       |  |  |
| <del>CHOICE TDD option</del>                        | <del>1.28 Mcps TDD</del>             |  |  |
| <del>Available SYNC_UL codes indices</del>          | <del>'00001111'B (ASC#1)</del>       |  |  |
| <del>CHOICE subchannel size</del>                   | <del>Size1</del>                     |  |  |
| <del>ASC Setting</del>                              |                                      |  |  |
| <del>CHOICE mode</del>                              | <del>TDD</del>                       |  |  |
| <del>CHOICE TDD option</del>                        | <del>1.28 Mcps TDD</del>             |  |  |
| <del>Available SYNC_UL codes indices</del>          | <del>'00001111'B (ASC#2)</del>       |  |  |
| <del>CHOICE subchannel size</del>                   | <del>Size1</del>                     |  |  |
| <del>ASC Setting</del>                              |                                      |  |  |
| <del>CHOICE mode</del>                              | <del>TDD</del>                       |  |  |
| <del>CHOICE TDD option</del>                        | <del>1.28 Mcps TDD</del>             |  |  |
| <del>Available SYNC_UL codes indices</del>          | <del>'00001111'B (ASC#3)</del>       |  |  |
| <del>CHOICE subchannel size</del>                   | <del>Size1</del>                     |  |  |
| <del>ASC Setting</del>                              |                                      |  |  |
| <del>CHOICE mode</del>                              | <del>TDD</del>                       |  |  |
| <del>CHOICE TDD option</del>                        | <del>1.28 Mcps TDD</del>             |  |  |
| <del>Available SYNC_UL codes indices</del>          | <del>'00001111'B (ASC#4)</del>       |  |  |
| <del>CHOICE subchannel size</del>                   | <del>Size1</del>                     |  |  |
| <del>ASC Setting</del>                              |                                      |  |  |
| <del>CHOICE mode</del>                              | <del>TDD</del>                       |  |  |
| <del>CHOICE TDD option</del>                        | <del>1.28 Mcps TDD</del>             |  |  |
| <del>Available SYNC_UL codes indices</del>          | <del>'00001111'B (ASC#5)</del>       |  |  |
| <del>CHOICE subchannel size</del>                   | <del>Size1</del>                     |  |  |
| <del>ASC Setting</del>                              |                                      |  |  |
| <del>CHOICE mode</del>                              | <del>TDD</del>                       |  |  |
| <del>CHOICE TDD option</del>                        | <del>1.28 Mcps TDD</del>             |  |  |
| <del>Available SYNC_UL codes indices</del>          | <del>'00001111'B (ASC#6)</del>       |  |  |
| <del>CHOICE subchannel size</del>                   | <del>Size1</del>                     |  |  |
| <del>ASC Setting</del>                              |                                      |  |  |
| <del>CHOICE mode</del>                              | <del>TDD</del>                       |  |  |
| <del>CHOICE TDD option</del>                        | <del>1.28 Mcps TDD</del>             |  |  |
| <del>Available SYNC_UL codes indices</del>          | <del>'00001111'B (ASC#7)</del>       |  |  |
| <del>CHOICE subchannel size</del>                   | <del>Size1</del>                     |  |  |
| <del>Persistence scaling factor</del>               |                                      |  |  |
| <del>Persistence scaling factor</del>               | <del>0.9 (for ASC#2)</del>           |  |  |

|                              |                 |
|------------------------------|-----------------|
| → Persistence-scaling-factor | 0.9 (for ASC#3) |
| → Persistence-scaling-factor | 0.9 (for ASC#4) |
| → Persistence-scaling-factor | 0.9 (for ASC#5) |
| → Persistence-scaling-factor | 0.9 (for ASC#6) |
| → Persistence-scaling-factor | 0.9 (for ASC#7) |
| → AC-to-ASC-mapping-table    |                 |
| → AC-to-ASC-mapping          | 6 (AC0-9)       |
| → AC-to-ASC-mapping          | 5 (AC10)        |
| → AC-to-ASC-mapping          | 4 (AC11)        |
| → AC-to-ASC-mapping          | 3 (AC12)        |
| → AC-to-ASC-mapping          | 2 (AC13)        |
| → AC-to-ASC-mapping          | 1 (AC14)        |
| → AC-to-ASC-mapping          | 0 (AC15)        |
| → CHOICE mode                | TDD             |

### RRC CONNECTION SETUP (Step 6)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

#### 8.1.2.2.5 ————— Test requirement

After step 2 the UE shall select either PRACH No.1 or PRACH No.2 and transmit an RRC CONNECTION REQUEST message.

After step 6 the UE shall re-send another RRC CONNECTION REQUEST message.

After step 9 the UE shall transmit an RRC CONNECTION SETUP COMPLETE message and establish an RRC connection on the DCCH logical channel.

### 8.1.2.3 ————— RRC Connection Establishment: Failure (V300 is greater than N300)

#### 8.1.2.3.1 ————— Definition

#### 8.1.2.3.2 ————— Conformance requirement

1. The RRC connection establishment is initiated by the UE, which leaves the idle mode and transmits an RRC CONNECTION REQUEST message. This message shall include the IE "Initial UE identity" on the uplink CCCH.
2. In the case of a failure to establish the RRC connection after (N300+1) attempts, the UE goes back to idle mode.

#### Reference

3GPP TS 25.331 clause 8.1.3.

#### 8.1.2.3.3 ————— Test purpose

To confirm that the UE stops retrying to establish the RRC connection if V300 is greater than N300 and goes back to idle mode.

#### 8.1.2.3.4 ————— Method of test

#### Initial Condition

System Simulator: 1 cell

UE: Idle state (state 2 or state 3 or state 7) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

## Test Procedure

Before the test starts, SS initializes an internal counter K to 0. The UE transmits an RRC CONNECTION REQUEST message to the SS on the uplink CCCH by an outgoing call operation. SS shall not respond to any RRC CONNECTION REQUEST message, instead the counter K is increased by 1 every time such a message is received. To arrive at the verdict, the SS checks that a total of (N300+1) such messages are received.

## Expected sequence

| Step | Direction |    | Message                | Comment                                                                                                                                                                                                                             |
|------|-----------|----|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                        |                                                                                                                                                                                                                                     |
| 1    |           |    |                        | SS initializes counter K to 0 and then prompts the operator to make an outgoing call.                                                                                                                                               |
| 2    |           | →  | RRC CONNECTION REQUEST |                                                                                                                                                                                                                                     |
| 3    |           |    |                        | SS increments K by 1.                                                                                                                                                                                                               |
| 4    |           |    |                        | If K is greater than N300, goes to step 5 else proceed to step 2.                                                                                                                                                                   |
| 5    |           |    |                        | SS monitor the uplink CCCH for a time period enough for UE to goes back to idle state. The exact amount of time to wait shall be derived from TS related to cell selection. If any uplink transmission is detected, the test fails. |

## Specific Message Contents

None

### 8.1.2.3.5 Test requirement

After step 5, counter K shall be equal to (N300+1) and there shall be no uplink transmission in the monitoring period specified in step 5.

### 8.1.2.4 RRC Connection Establishment: Reject ("wait time" is not equal to 0)

#### 8.1.2.4.1 Definition

#### 8.1.2.4.2 Conformance requirement

1. The RRC connection establishment is initiated by the UE, which leaves the idle mode and transmits an RRC CONNECTION REQUEST message. This message shall include the IE "Initial UE identity" and is to be sent on the uplink CCCH.
2. After the UE receives an RRC CONNECTION REJECT message which includes IE "wait time" not set to 0, and neither IE "frequency info" nor IE "system info" is present, the UE shall wait for a period specified in the IE "wait time". Thereafter re-transmit an RRC CONNECTION REQUEST message to attempt to establish the RRC connection again.
3. After the UE receives an RRC CONNECTION REJECT message which includes IE "wait time" not set to 0, and either IE "frequency info" or IE "system info" is available in the message, the UE shall attempt to perform cell reselection using these information. Thereafter re-transmit an RRC CONNECTION REQUEST message to attempt to establish the RRC connection again.

## Reference

3GPP TS 25.331 clause 8.1.3.

### 8.1.2.4.3 Test purpose

To confirm that the UE retries to establish the RRC connection after the "wait time" lapses, if the UE receives an RRC CONNECTION REJECT message which includes the IE "wait time" not set to 0.

To confirm that the UE performs a cell reselection when receiving an RRC CONNECTION REJECT message, containing relevant frequency information of the target cell to be re-selected.

### 8.1.2.4.4 Method of test

#### Initial Condition

System Simulator: 2 cells—both cell 1 and cell 2 are active and suitable for camping, but cell 1 is transmitted using a larger power. Cell 1 and cell 2 are being transmitted from different 2 UARFCNs. The transmission power of cell 2 is 15 dB smaller than cell 1.

**Table 8.1.2.4**

| Parameter                  | Unit         | Cell 1 | Cell 2 |
|----------------------------|--------------|--------|--------|
| UTRA—RF Channel Number     |              | Ch. 1  | Ch. 2  |
| CPICH—E <sub>c</sub> (FDD) | dBm/3.84 MHz | -60    | -75    |
| P-CCPCH (TDD)              | dBm          | -60    | -75    |

UE: Idle state (state 2 or state 3 or state 7) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE transmits an RRC CONNECTION REQUEST message to the SS on the uplink CCCH by an outgoing call operation in cell 1. SS rejects the first request by transmitting an RRC CONNECTION REJECT message which indicates a non-zero wait time. In this message, frequency information for cell 2 is available. SS then waits for RRC CONNECTION REQUEST message on the uplink CCCH of cell 2. SS will also monitor the uplink of cell 1 simultaneously to ensure that all transmission activities from cell 1 have ceased. When the UE has successfully camp onto cell 2, it shall send an RRC CONNECTION REQUEST with the same establishment cause as its previous attempt in cell 1. SS responds with an RRC CONNECTION REJECT message, indicating a non-zero "wait time" and omitting the IE "Redirection Info". The UE shall observe the wait time period indicated. After the wait time has elapsed, the UE shall re-transmit RRC CONNECTION REQUEST again. Finally, SS transmits an RRC CONNECTION SETUP message to establish an RRC connection with the UE, and the UE replies with an RRC CONNECTION SETUP COMPLETE message and enters CELL\_DCH state.

## Expected sequence

| Step | Direction |    | Message                       | Comment                                                                                                                                                                    |
|------|-----------|----|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                               |                                                                                                                                                                            |
| 1    | —→        |    | RRC CONNECTION REQUEST        | SS prompts the operator to make an outgoing call in cell 1.                                                                                                                |
| 2    | —←        |    | RRC CONNECTION REJECT         | This message shall includes the IE "wait time" set to 15 seconds and IE "frequency info" set to the UARFCN of cell 2.                                                      |
| 3    |           |    |                               | SS waits for a period of time sufficient for UE to reselect to cell 2. At the same time, it monitors the uplink of cell 1 to make sure that all transmissions have ceased. |
| 4    | —→        |    | RRC CONNECTION REQUEST        | UE shall attempt to re-start an RRC connection establishment procedure in cell 2. The establishment cause shall remain unchanged.                                          |
| 5    | —←        |    | RRC CONNECTION REJECT         | This message shall include the IE "wait time" set to 15 seconds, but with IE "Redirection Info" absent.                                                                    |
| 6    | —→        |    | RRC CONNECTION REQUEST        | SS waits until the duration specified in IE "wait time" has elapsed and then listens to the uplink CCCH for a second RRC CONNECTION REQUEST message.                       |
| 7    | —←        |    | RRC CONNECTION SETUP          | SS sends the message to UE to setup an RRC connection with the UE.                                                                                                         |
| 8    |           |    |                               | The UE shall configure the layer 2 and layer 1 in order to access the uplink and downlink DCCH assigned.                                                                   |
| 9    | —→        |    | RRC CONNECTION SETUP COMPLETE |                                                                                                                                                                            |

## Specific Message Contents

## RRC CONNECTION REQUEST (Step 1)

Use the same message type found in clause 9 of TS 34.108, with the following exception.

| Information Element | Value/remark                                                                    |
|---------------------|---------------------------------------------------------------------------------|
| Initial UE Identity | Same as the IMSI stored in the TEST USIM card, or the registered TMSI or P-TMSI |
| Establishment Cause | Must be "Originating Call"                                                      |

## RRC CONNECTION REJECT (Step 2) – FDD

Use the same message type found in Annex A, with the following exception.

| Information Element  | Value/remark                                   |
|----------------------|------------------------------------------------|
| Wait time            | 15 seconds                                     |
| Redirection Info     |                                                |
| Frequency Info       |                                                |
| —CHOICE mode         | FDD                                            |
| UARFCN uplink (Nu)   | Not present                                    |
| UARFCN downlink (Nd) | Set to the UARFCN for uplink carrier of cell 2 |

**RRC CONNECTION REJECT (Step 2) — TDD**

| Information Element | Value/remark                                         |
|---------------------|------------------------------------------------------|
| Wait time           | 15 seconds                                           |
| —Redirection Info   |                                                      |
| —Frequency Info     |                                                      |
| —CHOICE Mode        | TDD                                                  |
| —UARFCN (Nt)        | Set to a different UARFCN from the carrier of cell 1 |

**RRC CONNECTION REQUEST (Step 4 and step 6)**

Same requirement as in step 1.

**RRC CONNECTION REJECT (Step 5)**

Use the same message type found in Annex A, with the following exception.

| Information Element | Value/remark |
|---------------------|--------------|
| Wait time           | 15 seconds   |

**8.1.2.4.5 — Test requirement**

After step 3 the UE shall have successfully re-selected to cell 2, using information transmitted in IE "frequency info" of RRC CONNECTION REJECT message. UE shall trigger the start of RRC connection establishment by transmitting RRC CONNECTION REQUEST. The establishment cause shall be similar to the message sent in step 1.

After step 5 the UE shall observe the period specified in IE "wait time" of an RRC CONNECTION REJECT message and not transmit an RRC CONNECTION REQUEST message in this period.

After step 7 the UE shall transmit an RRC CONNECTION SETUP COMPLETE message to SS on uplink DCCH and then establish an RRC connection.

**8.1.2.5 — RRC Connection Establishment: Reject ("wait time" is not equal to 0 and  $V_{300}$  is greater than  $N_{300}$ )****8.1.2.5.1 — Definition****8.1.2.5.2 — Conformance requirement**

The RRC connection establishment is initiated by the UE, which leaves the idle mode and transmits an RRC CONNECTION REQUEST message. This message shall include the IE "Initial UE identity" and is to be sent on the uplink CCCH.

After the UE receives an RRC CONNECTION REJECT message which includes IE "wait time" not set to 0, and neither IE "frequency info" nor IE "system info" is present, the UE shall wait for a period specified in the IE "wait time". Thereafter it re-transmits an RRC CONNECTION REQUEST message to attempt to establish the RRC connection again. In the case of a failure to establish the RRC connection after  $(N_{300}+1)$  attempts, the UE goes back to idle mode.

**Reference**

3GPP TS 25.331 clause 8.1.3.

**8.1.2.5.3 — Test purpose**

To confirm that the UE retries to establish the RRC connection after the "wait time" elapses if the UE receives an RRC CONNECTION REJECT message which specifies a non-zero IE "wait time".

To confirm that the UE stops retrying to establish the RRC connection if V300 is greater than N300 and goes back to idle mode.

#### 8.1.2.5.4 Method of test

##### Initial Condition

System Simulator: 1 cell.

UE: Idle state (state 2 or state 3 or state 7) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE

##### Test Procedure

Before the test starts, SS initializes an internal counter K to 0. The UE transmits an RRC CONNECTION REQUEST message to the SS on the uplink CCCH, triggered by an outgoing data call operation. SS rejects all requests by transmitting an RRC CONNECTION REJECT message which indicates a non-zero wait time and the counter K is increased by 1 every time such a message is received. To arrive at the verdict, the SS checks that a total of (N300+1) such messages are received and the UE enters idle state.

##### Expected sequence

| Step | Direction |    | Message                | Comment                                                                                                                                                                                                                             |
|------|-----------|----|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                        |                                                                                                                                                                                                                                     |
| 1    |           |    |                        | SS initializes counter K to 0 and then prompts the operator to make an outgoing data call.                                                                                                                                          |
| 2    | —→        |    | RRC CONNECTION REQUEST | Shall be sent on CCCH and contain the correct establishment cause.                                                                                                                                                                  |
| 3    |           | —← | RRC CONNECTION REJECT  | This message includes the IE "wait time" set to 15 seconds.                                                                                                                                                                         |
| 4    |           |    |                        | SS increments K by 1.                                                                                                                                                                                                               |
| 5    |           |    |                        | If K is greater than N300, goes to step 6. Else SS waits for 15 sec before proceeding to step 2.                                                                                                                                    |
| 6    |           |    |                        | SS monitor the uplink CCCH for a time period enough for UE to goes back to idle state. The exact amount of time to wait shall be derived from TS related to cell selection. If any uplink transmission is detected, the test fails. |

##### Specific Message Contents

##### RRC CONNECTION REQUEST (Step 2)

Use the same message type found in clause 9 of TS 34.108, with the following exception.

| Information Element | Value/remark                                                                    |
|---------------------|---------------------------------------------------------------------------------|
| Initial UE Identity | Same as the IMSI stored in the TEST USIM card, or the registered TMSI or P-TMSI |
| Establishment Cause | Must be "Originating Call"                                                      |

##### RRC CONNECTION REJECT (Step 3)

Use the same message type found in Annex A, with the following exception.



| Information Element | Value/remark |
|---------------------|--------------|
| Wait time           | 15 seconds   |

#### 8.1.2.5.5 ~~Test requirement~~

~~After step 6, counter K shall be equals to (N300+1) and there shall be no uplink transmission in the monitoring period specified in step 6.~~

#### 8.1.2.6 ~~RRC Connection Establishment: Reject ("wait time" is set to 0)~~

##### 8.1.2.6.1 ~~Definition~~

##### 8.1.2.6.2 ~~Conformance requirement~~

- ~~1. The RRC connection establishment is initiated by the UE, which leaves the idle mode and transmits an RRC CONNECTION REQUEST message on the uplink CCCH.~~
- ~~2. In the case of a failure to establish the RRC connection by the reception of a RRC CONNECTION REJECT message which contains IE "wait time" equals to 0, the UE shall go back to idle mode immediately.~~

#### Reference

~~3GPP TS 25.331 clause 8.1.3.~~

##### 8.1.2.6.3 ~~Test purpose~~

~~To confirm that the UE goes back to idle mode, if the SS transmits an RRC CONNECTION REJECT message which includes IE "wait time" set to 0. To confirm that the UE ignores an RRC CONNECT REJECT message not addressed to it. To confirm that the UE is capable of handling an erroneous RRC CONNECTION REJECT message correctly.~~

##### 8.1.2.6.4 ~~Method of test~~

#### Initial Condition

~~System Simulator: 1 cell.~~

~~UE: Idle state (state 2 or state 3 or state 7) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.~~

#### Test Procedure

~~The UE transmits an RRC CONNECTION REQUEST message to the SS on the uplink CCCH by making an outgoing call. After the SS receives this message, it transmits an RRC CONNECTION REJECT message which is not addressed to the UE. The UE shall disregard this message and proceed to re-transmit RRC CONNECTION REQUEST message upon T300 timer expiry. SS answers the second RRC CONNECTION REQUEST message by transmitting an invalid RRC CONNECTION REJECT message. The UE shall continue to send the third RRC CONNECTION REQUEST message upon expiry of T300 timer. Next, the SS sends a legal RRC CONNECTION REJECT message which includes IE "wait time" which is set to '0'. To confirm that the UE goes back to idle mode immediately after receiving the reject message, SS shall monitor the uplink CCCH for the next 60 seconds and verify that there is no further transmission in the uplink direction.~~

## Expected sequence

| Step | Direction |    | Message                | Comment                                                                                          |
|------|-----------|----|------------------------|--------------------------------------------------------------------------------------------------|
|      | UE        | SS |                        |                                                                                                  |
| 1    | —→        |    | RRC CONNECTION REQUEST | Test operator is prompted to make an out-going call;                                             |
| 2    | —←        |    | RRC CONNECTION REJECT  | IE "Initial UE identity" contains an identity different from any of the UE identities available. |
| 3    | —→        |    | RRC CONNECTION REQUEST | UE shall send this message after T300 expires.                                                   |
| 4    | —←        |    | RRC CONNECTION REJECT  |                                                                                                  |
| 5    | —→        |    | RRC CONNECTION REQUEST | UE shall send this message after T300 expires.                                                   |
| 6    | —←        |    | RRC CONNECTION REJECT  | IE "wait time" is set to 0.                                                                      |
| 7    |           |    |                        | The UE goes back to idle mode.                                                                   |

## Specific Message Contents

## RRC CONNECTION REQUEST (Step 1, 3 and 5)

| Information Element      | Value/remark                                                                    |
|--------------------------|---------------------------------------------------------------------------------|
| Message Type             |                                                                                 |
| Initial UE Identity      | Same as the IMSI stored in the TEST USIM card, or the registered TMSI or P-TMSI |
| Establishment Cause      | Checked to see if set to one of the supported originating call types            |
| Protocol Error Indicator | Checked to see if set to "FALSE"                                                |
| Measured Results on RACH | Checked to see if it is absent                                                  |

## RRC CONNECTION REJECT (Step 2)

Use the same message type found in Annex A, with the following exception:

| Information Element | Value/remark                                                                                   |
|---------------------|------------------------------------------------------------------------------------------------|
| Initial UE Identity | Set to the same type as in RRC CONNECTION REQUEST message (step 1) but with a different value. |

## RRC CONNECTION REJECT (Step 4)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

## RRC CONNECTION REJECT (Step 6)

Use the same message type found in Annex A, with the following exception:

| Information Element | Value/remark                                                                  |
|---------------------|-------------------------------------------------------------------------------|
| Initial UE Identity | Same as the type and value defined in RRC CONNECTION REQUEST message (step 5) |
| Reject Cause        | Congestion                                                                    |
| Wait time           | 0 second                                                                      |

## 8.1.2.6.5 ————— Test requirement

After step 2 the UE shall transmit an RRC CONNECTION REQUEST message on uplink CCCH upon expiry of T300 timer.

After step 4 the UE shall re-transmit an RRC CONNECTION REQUEST message on the uplink CCCH upon expiry of T300 timer.

After step 6 the UE shall stop sending an RRC CONNECTION REQUEST message, go back to idle mode immediately and not transmit in the uplink direction again.

### 8.1.2.7 RRC Connection Establishment in CELL\_FACH state: Success

#### 8.1.2.7.1 Definition

#### 8.1.2.7.2 Conformance requirement

During the RRC connection establishment, the UTRAN might assign common physical resource to the UE using an RRC CONNECTION SETUP message. When no information about the physical channels accessible is available from the message, the UE shall utilize the PRACH and S-CCPCH information transmitted on the BCCH and then enter CELL\_FACH state. Subsequently, the UE shall establish the required signalling radio bearers with the UTRAN using common physical resources.

#### Reference

3GPP TS 25.331 clause 8.1.3.

#### 8.1.2.7.3 Test Purpose

To confirm that the UE is able to enter CELL\_FACH state and setup signalling radio bearers using common physical channels.

#### 8.1.2.7.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: Idle state (state 2 or state 3 or state 7) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE transmits an RRC CONNECTION REQUEST message to the SS on the uplink CCCH by attempting to make an outgoing call. After the SS receives this message, it assigns the necessary radio resources and U-RNTI to be used by the UE, and then transmits an RRC CONNECTION SETUP message to the UE within timer T300. SS then waits for the UE to transmit an RRC CONNECTION SETUP COMPLETE message on the DCCH.

#### Expected sequence

| Step | Direction |    | Message                       | Comment                                                                                                                              |
|------|-----------|----|-------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                               |                                                                                                                                      |
| 1    | →         |    | RRC CONNECTION REQUEST        | Test operator is requested to make an outgoing call. The UE shall transmit this message, indicating the correct establishment cause. |
| 2    | ←         |    | RRC CONNECTION SETUP          | SS omits both IE "Uplink DPCCH Info" and IE "Downlink DPCCH Info" from the message.                                                  |
| 3    |           |    |                               | The UE shall configure the layer 2 and layer 1.                                                                                      |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE | UE shall send this message on the DCCH, carried by the assigned PRACH resources.                                                     |

## Specific Message Content

### RRC CONNECTION REQUEST

Use the same message type found in clause 9 of TS 34.108, with the following exception:

| Information Element | Value/remark                                                                              |
|---------------------|-------------------------------------------------------------------------------------------|
| Initial UE identity | Same as the IMSI stored in the TEST USIM card, or the registered TMSI or P-TMSI           |
| Establishment Cause | Originating Interactive Call or Originating Background Call or Originating Streaming Call |

### RRC CONNECTION SETUP

For this message, the contents of the message to be used are basically identical to the message sub-type entitled "RRC CONNECTION SETUP message (Transition to CELL\_FACH)" found in Annex A with the following exception:

| Information Element                                                              | Value/remark |
|----------------------------------------------------------------------------------|--------------|
| Capability update requirement<br>– UE radio access capability update requirement | TRUE         |

### RRC CONNECTION SETUP COMPLETE

Use the same message type found in clause 9 of TS 34.108, with the following exception:

| Information Element                  | Value/remark                                                                      |
|--------------------------------------|-----------------------------------------------------------------------------------|
| UE Radio Access Capability           | Checked to see if compatible with the stated capability in PIXIT/PICS statements. |
| UE radio access capability extension | Checked to see if compatible with the stated capability in PIXIT/PICS statements. |
| UE system specific Capability        | Checked to see if compatible with the stated capability in PIXIT/PICS statements. |

#### 8.1.2.7.5 Test requirements

After step 3 the UE shall establish the RRC connection, and transmit RRC CONNECTION SETUP COMPLETE message on the DCCH using PRACH physical resource specified in system information block messages.

#### 8.1.2.8 Void

#### 8.1.2.9 RRC Connection Establishment: Success after Physical channel failure and Invalid configuration

##### 8.1.2.9.1 Definition

##### 8.1.2.9.2 Conformance requirement

1. The RRC connection establishment is initiated by the UE, which leaves the idle mode. The UE shall transmit an RRC CONNECTION REQUEST message which includes the IE "Initial UE identity". This message shall be sent on the uplink CCCH.
2. In the case of a failure to establish the RRC connection due to a physical channel failure after the UE receives an RRC CONNECTION SETUP message, the UE retries to establish the RRC connection until V300 is greater than N300
3. In the case of a RRC CONNECTION SETUP message is received by UE causes invalid configuration, the UE retries to establish the RRC connection until V300 is greater than N300.

## Reference

3GPP TS 25.331 clause 8.1.3.

### 8.1.2.9.3 ——— Test purpose

To confirm that the UE retries to establish the RRC connection until V300 is greater than N300 when a physical channel failure occurs because SS does not configure the physical channel that is specified in the transmitted RRC CONNECTION SETUP message. To confirm that the UE retries to establish the RRC connection until V300 is greater than N300 when the transmitted RRC CONNECTION SETUP message causes invalid configuration in the UE.

### 8.1.2.9.4 ——— Method of test

#### Initial Condition

System Simulator: 1 cell

UE: Idle state (state 2 or state 3 or state 7) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE

#### Test Procedure

Before the test starts, an internal counter K in SS is initialised to a value = 0. Following this, the UE shall transmit an RRC CONNECTION REQUEST message to the SS on the uplink CCCH, after the operator attempts to make an outgoing call. SS increments K every time such a message is received. Then, SS shall send a RRC CONNECTION SETUP message that contains an invalid configuration. UE shall then send RRC CONNECTION REQUEST message to SS again. Next SS transmits an RRC CONNECTION SETUP message to make the UE configure the physical channel in order to communicate on the DCCH but SS does not configure the physical channel. Then the UE detects the physical channel failure and transmits an RRC CONNECTION REQUEST message. This cycle is repeated until K reaches N300. When K is equal to N300, the SS transmits the RRC CONNECTION SETUP message and configures the physical channel. The UE shall detect "in-sync" from physical layer and then acknowledge the establishment of RRC connection by sending the RRC CONNECTION SETUP COMPLETE message on uplink DCCH.

## Expected sequence

| Step | Direction |    | Message                       | Comment                                                                                                                                    |
|------|-----------|----|-------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                               |                                                                                                                                            |
| 1    |           |    |                               | SS initialises counter K to 0. Operator is asked to make an outgoing call and SS starts to wait for RRC CONNECTION REQUEST on uplink CCCH. |
| 2    |           | →  | RRC CONNECTION REQUEST        |                                                                                                                                            |
| 2a   |           |    |                               | SS increments K by 1 for every RRC CONNECTION REQUEST message received in step 2                                                           |
| 3    |           |    |                               | SS checks to see if K is equal to N300+1. If so, goes to step 6. Else, continues to execute step 4.                                        |
| 4    |           | ←  | RRC CONNECTION SETUP          | See message content below. SS does not configure the physical channel.                                                                     |
| 5    |           |    |                               | The next step is step 2.                                                                                                                   |
| 6    |           | ←  | RRC CONNECTION SETUP          | See the clause 9 in TS 34.108 on default message content for RRC. SS configures the physical channel.                                      |
| 7    |           |    |                               | The UE configures the layer 1 and layer 2.                                                                                                 |
| 8    |           | →  | RRC CONNECTION SETUP COMPLETE |                                                                                                                                            |

## Specific Message Contents

## RRC CONNECTION SETUP (Step 4 and K=1)

Use the same message sub-type found in clause 9 of TS 34.108, with the following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| RRC State Indicator | CELL_DCH     |
| Uplink DPCH info    | Not present  |

## RRC CONNECTION SETUP (Step 4 and K&gt;1)

Use the same message sub-type found in clause 9 of TS 34.108.

## RRC CONNECTION REQUEST (Step 2 and K=1)

Use the same message sub-type found in clause 9 of TS 34.108, with the following exceptions:

| Information Element      | Value/remark                                                                              |
|--------------------------|-------------------------------------------------------------------------------------------|
| Initial UE identity      | Same as the IMSI stored in the TEST USIM card, or the registered TMSI or P-TMSI           |
| Establishment Cause      | Originating Interactive Call or Originating Background Call or Originating Streaming Call |
| Protocol error indicator | TRUE                                                                                      |

#### ~~8.1.2.9.5 Test requirement~~

~~After step 4 the UE shall re-send RRC CONNECTION REQUEST message.~~

~~After step 8 the UE shall transmit an RRC CONNECTION SETUP COMPLETE message and establish an RRC connection.~~

### ~~8.1.3 RRC Connection Release~~

#### ~~8.1.3.1 RRC Connection Release in CELL\_DCH state: Success~~

##### ~~8.1.3.1.1 Definition~~

##### ~~8.1.3.1.2 Conformance requirement~~

- ~~1. The UE shall receive and act on an RRC CONNECTION RELEASE message in states CELL\_DCH and CELL\_FACH. Furthermore this procedure can interrupt any ongoing procedures with the UE in the above listed states.~~

~~When the UE receives the first RRC CONNECTION RELEASE message, it shall:~~

~~...~~

~~— in state CELL\_DCH:~~

~~— initialise the counter V308 to zero;~~

~~...~~

~~— submit an RRC CONNECTION RELEASE COMPLETE message to the lower layers for transmission using UM RLC on the DCCH to the UTRAN;~~

~~...~~

~~— start timer T308 when the RRC CONNECTION RELEASE COMPLETE message is sent on the radio interface.~~

- ~~2. When in state CELL\_DCH and the timer T308 expires, the UE shall:~~

~~— increment V308 by one;~~

~~— if V308 is equal to or smaller than N308:~~

~~— retransmit the RRC CONNECTION RELEASE COMPLETE message, without incrementing "Uplink RRC Message sequence number" for signalling radio bearer RB1 in the variable INTEGRITY\_PROTECTION\_INFO;~~

~~— if V308 is greater than N308:~~

~~— release all its radio resources;~~

~~...~~

~~— enter idle mode;~~

~~— perform the actions specified in TS 25.331 clause 8.5.2 when entering idle mode;~~

~~— and the procedure ends.~~

## Reference

3GPP TS 25.331 clause 8.1.4.3, 8.1.4.6

## 8.1.3.1.3 Test purpose

To verify:

1. that the UE when receiving an RRC CONNECTION RELEASE message transmits N308+1 RRC CONNECTION RELEASE COMPLETE messages before release of radio resources and entering into idle mode
2. that the time between UE transmissions of the RRC CONNECTION RELEASE COMPLETE message is equal to the value of the T308 timer.

## 8.1.3.1.4 Method of test

## Initial Condition

System Simulator: 1 cell

UE: CELL\_DCH state (state 6-1 or state 6-3) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE

## Test Procedure

The UE is brought to the CELL\_DCH state by prompting the operator to initiate an outgoing call. After the DCCH is established, SS transmits an RRC CONNECTION RELEASE message to the UE to disconnect the connection. SS then waits for the UE to transmit an RRC CONNECTION RELEASE COMPLETE message using unacknowledged mode. SS checks to see if P + 1 such messages has been received at each expiry of T308 timer. P is equal to the value of IE "N308" in an RRC CONNECTION RELEASE message.

## Expected sequence

| Step | Direction |    | Message                         | Comment                                                                                                                            |
|------|-----------|----|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                    |
| 1    |           |    |                                 | The UE is in the CELL_DCH state after a successful RRC connection establishment by virtue of the operator making an outgoing call. |
| 2    |           | ←  | RRC CONNECTION RELEASE          | SS disconnect the connection established. The value in IE "N308" is arbitrarily chosen from 1 to 8 and denoted by P.               |
| 3    |           | →  | RRC CONNECTION RELEASE COMPLETE | SS waits for the arrival of N308 + 1 such message at the expiry of each T308 timer, using unacknowledged mode.                     |
| 4    |           |    |                                 | SS verifies that the UE release its L2 signalling radio bearer and dedicated resources and enters idle mode.                       |

## Specific Message Content

## RRC CONNECTION RELEASE (Step 2)

Use the same message type found in clause 9 of TS 34.108, with the following exceptions:

| Information Element | Value/remark                       |
|---------------------|------------------------------------|
| N308                | Arbitrarily chosen between 1 and 8 |



### 8.1.3.1.5 ~~Test requirement~~

After step 2 the UE shall transmit  $P + 1$  RRC CONNECTION RELEASE COMPLETE messages. The time between the transmissions shall be equal to the T308 timer value.

After step 3 the UE shall initiate the release of the L2 signalling radio bearer and dedicated resources and enter idle mode.

### 8.1.3.2 ~~RRC Connection Release using on DCCH in CELL\_FACH state: Success~~

#### 8.1.3.2.1 ~~Definition~~

#### 8.1.3.2.2 ~~Conformance requirement~~

In CELL\_FACH state, the RRC layer entity in the network may issue an RRC CONNECTION RELEASE message using unacknowledged mode on the DCCH. Upon the reception of this message, the UE transmits an RRC CONNECTION RELEASE COMPLETE message using acknowledged mode to UTRAN on the DCCH and goes back to idle mode after it receives an RLC confirmation from the UTRAN.

#### Reference

3GPP TS 25.331 clause 8.1.4.

#### 8.1.3.2.3 ~~Test purpose~~

To confirm that the UE releases the L2 signalling radio bearer and resources and goes back to the idle state after it receives an RRC CONNECTION RELEASE message on downlink DCCH from the SS. It shall transmit an RRC CONNECTON RELEASE COMPLETE message using acknowledged mode on uplink DCCH to the SS.

#### 8.1.3.2.4 ~~Method of test~~

#### Initial Condition

System Simulator: 1 cell.

UE: CELL\_FACH state (state 6-2 or state 6-4) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is brought to an initial state of CELL\_FACH. After the successful establishment of the RRC connection, the SS transmits an RRC CONNECTION RELEASE message to the UE to disconnect the radio link. When the UE receives this message the UE transmits an RRC CONNECTION RELEASE COMPLETE message using acknowledged mode to the SS. Finally, SS checks that the UE performs proper release of all radio resources and then goes back to idle mode.

#### Expected sequence

| Step | Direction |    | Message                         | Comment                                                                                        |
|------|-----------|----|---------------------------------|------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                |
| 1    |           |    |                                 | The UE is brought to the CELL_FACH state.                                                      |
| 2    |           | ←  | RRC CONNECTION RELEASE          | SS sends this message using unacknowledged mode RLC operations on the uplink DCCH.             |
| 3    |           | →  | RRC CONNECTION RELEASE COMPLETE | The UE transmits this message using acknowledged mode.                                         |
| 4    |           |    |                                 | The UE releases L2 signalling radio bearer and radio resources. Then the UE goes to idle mode. |

## Specific Message Contents

None.

### 8.1.3.2.5 ~~Test requirement~~

~~After step 2 the UE shall transmit an RRC CONNECTION RELEASE COMPLETE message using acknowledged mode then it shall receive a response for this message from the SS-RLC.~~

~~After step 3 the UE shall release its L2 signalling radio bearers and radio resources, then it shall go back to idle mode.~~

### 8.1.3.3 ~~RRC Connection Release using on CCCH in CELL\_FACH state: Success~~

#### 8.1.3.3.1 ~~Definition~~

#### 8.1.3.3.2 ~~Conformance requirement~~

~~In CELL\_FACH state, the RRC layer entity in the network may issue an RRC CONNECTION RELEASE message using unacknowledged mode on the CCCH. Upon the reception of this message, the UE shall release the RRC connection immediately, without replying with a RRC CONNECTION RELEASE COMPLETE message on the uplink.~~

## Reference

~~3GPP TS 25.331 clause 8.1.4.~~

#### 8.1.3.3.3 ~~Test purpose~~

~~To confirm that the UE releases all its radio resources upon the reception of a RRC CONNECTION RELEASE message on the downlink CCCH, without transmitting RRC CONNECTION RELEASE COMPLETE message on the uplink.~~

#### 8.1.3.3.4 ~~Method of test~~

## Initial Condition

System Simulator: 1 cell.

UE: CELL\_FACH state (state 6-2 or state 6-4) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

## Test Procedure

The UE is brought to an initial state of CELL\_FACH. After the successful establishment of the RRC connection, SS transmits an RRC CONNECTION RELEASE message on the downlink CCCH. The UE shall terminate the RRC connection and release all radio resources allocated to it. SS monitors the uplink DCCH and CCCH to verify that no transmission is detected.

## Expected sequence

| Step | Direction |    | Message                | Comment                                                                                                                                                                                                    |
|------|-----------|----|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                        |                                                                                                                                                                                                            |
| 1    |           |    |                        | The UE is brought to the CELL_FACH state.                                                                                                                                                                  |
| 2    |           | ←  | RRC CONNECTION RELEASE | SS transmits this message with the contents identical to that found in TS 34.108 clause 9 on downlink CCCH.                                                                                                |
| 3    |           |    |                        | SS waits for a period equivalent to 60 seconds. The UE shall not send any response message on uplink direction during this period. It shall release the radio resources allocated and return to idle mode. |

## Specific Message Contents

None.

## 8.1.3.3.5 — Test requirement

After step 2 the UE shall release all its radio resources, return to idle mode, without transmitting RRC CONNECTION RELEASE COMPLETE message on the uplink direction.

## 8.1.3.4 — RRC Connection Release in CELL\_FACH state: Failure

## 8.1.3.4.1 — Definition

## 8.1.3.4.2 — Conformance requirement

In case of RRC connection release from CELL\_FACH state, the RRC layer entity in the network issues an RRC CONNECTION RELEASE message using unacknowledged mode on the DCCH. When the UE does not succeed to transmit the RRC CONNECTION RELEASE COMPLETE message using acknowledged mode, it shall release all its radio resources, enter idle mode and the procedure ends on the UE side.

## Reference

3GPP TS 25.331 clause 8.1.4

## 8.1.3.4.3 — Test purpose

To confirm that the UE releases all its radio resources and enters idle mode when the UE does not succeed in transmitting the RRC CONNECTION RELEASE COMPLETE message using acknowledged mode to the SS (i.e. the UE RLC cannot receive acknowledgement for the transmission of the RRC CONNECTION RELEASE COMPLETE message from SS).

## 8.1.3.4.4 — Method of test

## Initial Condition

System Simulator: 1 cell

UE: CELL\_FACH state (state 6-2 or state 6-4) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE

## Test Procedure

At the start of the test, the UE is brought to CELL\_FACH state. When the RRC connection has been established, the SS transmits an RRC CONNECTION RELEASE message to the UE to disconnect the radio link. When the UE receives this message the UE transmits an RRC CONNECTION RELEASE COMPLETE message using acknowledged mode to the SS. The SS ignores the message and does not transmit a STATUS PDU of RLC for this message. SS checks to see that UE continues to release all its radio resources and then enters idle mode.

## Expected sequence

| Step | Direction |    | Message                         | Comment                                                                                                                                         |
|------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                 |
| 1    |           |    |                                 | The UE is brought into CELL_FACH state by asking the operator to perform an outgoing call attempt.                                              |
| 2    |           | ←  | RRC CONNECTION RELEASE          | SS ask to disconnect the radio link                                                                                                             |
| 3    | →         |    | RRC CONNECTION RELEASE COMPLETE | The UE transmits this message using acknowledged mode. The SS ignores this message and shall not transmit a STATUS PDU of RLC for this message. |
| 4    |           |    |                                 | SS checks to make sure that UE releases its all radio resources and enter idle mode.                                                            |

## Specific Message Contents

None

### 8.1.3.4.5 Test requirement

After step 3 the UE shall release its L2 signalling radio bearers and radio resources then it shall go to idle mode.

## 8.1.3.5 RRC Connection Release in CELL\_FACH state: Invalid message

### 8.1.3.5.1 Definition

### 8.1.3.5.2 Conformance requirement

In CELL\_FACH state, the RRC layer entity in UTRAN may issue an RRC CONNECTION RELEASE message using unacknowledged mode on the DCCH. If an invalid RRC CONNECTION RELEASE message is received by the UE, the UE shall activate the appropriate error handling mechanism and report the error to the UTRAN.

## Reference

3GPP TS 25.331 clause 8.1.4

### 8.1.3.5.3 Test purpose

When the UE receives an invalid RRC CONNECTION RELEASE message on the downlink DCCH, it shall transmit an RRC STATUS message that includes the appropriate error cause on the uplink DCCH.

### 8.1.3.5.4 Method of test

## Initial Condition

System Simulator: 1 cell

UE: "Registered idle mode on PS" (state 3) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE. If the UE supports both CS and PS domains, the initial UE state shall be "Registered idle mode on CS/PS" (state 7).

### Test Procedure

The UE is initially at idle mode. The System Information Block type 11 messages are modified with respect to the default. In the System Information type 11 messages, reporting of CPICH RSCP is required for intra-frequency reporting when transmitting RACH messages.

SS prompts the operator to make an outgoing call for one of the traffic classes supported by the UE. SS and UE shall execute procedure P6. Next SS and UE shall execute procedure P10. Then SS and UE shall execute procedure P14. The UE shall transmit a RRC CONNECTION REQUEST message on the uplink CCCH, SS replies with RRC CONNECTION SETUP message and allocates PRACH and S-CCPCH physical channels for uplink and downlink usage. UE shall then enter CELL\_FACH state. SS starts timer T305 and waits until timer T305 expires, the UE shall send a CELL UPDATE message on the CCCH which includes the measurement reading of current cell CPICH RSCP values in IE "Measured results on RACH". SS then replies with CELL UPDATE CONFIRM message on the downlink DCCH. SS transmits an invalid RRC CONNECTION RELEASE message on the DCCH to request to disconnect the RRC connection. The UE shall transmit an RRC STATUS message on the uplink DCCH, which includes the IE "Protocol Error Information". This IE shall contain "Protocol error information" IE which is set to "ASN.1 violation or encoding error". Then SS waits until timer T305 expires, the UE shall send a CELL UPDATE message on the CCCH which includes the measurement reading of current cell CPICH RSCP values in IE "Measured results on RACH". SS then replies with CELL UPDATE CONFIRM message on the downlink DCCH.

### Expected sequence

| Step | Direction |    | Message                                                                                          | Comment                                                                                                                                                                      |
|------|-----------|----|--------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                                                  |                                                                                                                                                                              |
| 1    |           | ←  | Master Information Block<br>System Information Block type 1,<br>System Information Block type 11 | The UE is idle mode and camped onto cell 1. System Information Block type 1 and 11 to be transmitted are different from the default settings (see specific message contents) |
| 2    |           | ↔  | SS executes procedure P6 (clause 7.4.2.2.2) specified in TS 34.108.                              | SS prompts the test operator to make an outgoing call.                                                                                                                       |
| 3    |           | ↔  | SS executes procedure P10 (clause 7.4.2.4.2) specified in TS 34.108.                             |                                                                                                                                                                              |
| 4    |           | ↔  | SS executes procedure P14 (clause 7.4.2.6.2) specified in TS 34.108.                             |                                                                                                                                                                              |
| 5    |           |    |                                                                                                  | SS waits for 5 minutes (for the expiry of T305 timer).                                                                                                                       |
| 6    |           | →  | CELL UPDATE                                                                                      | This message shall contain IE "Measured results on RACH" reporting the readings of CPICH RSCP for current cell.                                                              |
| 7    |           | ←  | CELL UPDATE CONFIRM                                                                              |                                                                                                                                                                              |
| 8    |           | ←  | RRC CONNECTION RELEASE                                                                           | See specific message contents for this message                                                                                                                               |
| 9    |           | →  | RRC STATUS                                                                                       | The IE "Protocol error cause" found in IE "Protocol error information" shall be set to "ASN.1 violation or encoding error". This message is sent using acknowledge mode.     |
| 10   |           |    |                                                                                                  | SS waits for 5 minutes (for the expiry of T305 timer).                                                                                                                       |

|    |   |                     |                                                                                                                 |
|----|---|---------------------|-----------------------------------------------------------------------------------------------------------------|
| 11 | → | CELL UPDATE         | This message shall contain IE "Measured results on RACH" reporting the readings of CPICH-RSCP for current cell. |
| 12 | ← | CELL UPDATE CONFIRM |                                                                                                                 |

### Specific Message Contents

#### Master Information Block (Step 1)

| Information Element | Value/Remarks |
|---------------------|---------------|
| MIB Value tag       | 2             |

#### System Information Block type 1 (Step 1)

| Information Element                                 | Value/Remarks |
|-----------------------------------------------------|---------------|
| UE Timers and constants in connected mode<br>→ T305 | 5 minutes.    |

## System Information Block type 11 (Step 1)

| Information Element                                    | Value/Remark                                   |
|--------------------------------------------------------|------------------------------------------------|
| SIB12 indicator                                        | FALSE                                          |
| FACH measurement occasion info                         |                                                |
| → FACH Measurement occasion cycle length coefficient   | 2                                              |
| → Inter-frequency FDD measurement indicator            | FALSE                                          |
| → Inter-frequency TDD measurement indicator            | FALSE                                          |
| → Inter-RAT measurement indicators                     | Not Present                                    |
| Measurement control system information                 |                                                |
| → Intra-frequency measurement system information       |                                                |
| → Intra-frequency measurement identity                 | 5                                              |
| → Intra-frequency cell info list                       |                                                |
| → CHOICE intra-frequency cell removal                  | Remove no intra-frequency cells                |
| → New intra-frequency info list                        |                                                |
| → Intra-frequency cell id                              | 2                                              |
| → Cell info                                            |                                                |
| → Cell individual offset                               | 0 dB                                           |
| → Reference time difference to cell                    | 0 chips                                        |
| → Read SFN Indicator                                   | FALSE                                          |
| → CHOICE mode                                          | FDD                                            |
| → Primary CPICH Info                                   |                                                |
| → Primary Scrambling Code                              | Set to same code as used for cell 2            |
| → Primary CPICH TX power                               | Not Present                                    |
| → TX Diversity Indicator                               | FALSE                                          |
| → Cell selection and Re-selection info                 |                                                |
| → Qoffset <sub>s,n</sub>                               | 0 dB                                           |
| → Maximum allowed UL TX power                          | 0 dBm                                          |
| → HCS neighbouring cell information                    | Not Present                                    |
| → Qqualmin                                             | -20dB                                          |
| → Qrxlevmin                                            | -115dBm                                        |
| → Cells for measurement                                | Not Present                                    |
| → Intra-frequency Measurement quantity                 |                                                |
| → Filter Coefficient                                   | 0                                              |
| → Measurement quantity                                 | CPICH RSCP                                     |
| → Intra-frequency measurement for RACH reporting       |                                                |
| → SFN-SFN observed time difference                     | No report                                      |
| → Reporting quantity                                   | CPICH RSCP                                     |
| → Maximum number of reported cells on RACH             | Current cell                                   |
| → Reporting information for state CELL_DCH             |                                                |
| → Intra-frequency reporting quantity                   |                                                |
| → Reporting quantities for active set cells            |                                                |
| → SFN-SFN observed time difference reporting indicator | No report                                      |
| → Cell synchronisation information reporting indicator | FALSE                                          |
| → Cell identity reporting indicator                    | FALSE                                          |
| → CPICH Ec/No reporting indicator                      | FALSE                                          |
| → CPICH RSCP reporting indicator                       | FALSE                                          |
| → Pathloss reporting indicator                         | FALSE                                          |
| → Reporting quantities for monitored set cells         |                                                |
| → SFN-SFN observed time difference reporting indicator | No report                                      |
| → Cell synchronisation information reporting indicator | FALSE                                          |
| → Cell identity reporting indicator                    | TRUE                                           |
| → CPICH Ec/No reporting indicator                      | FALSE                                          |
| → CPICH RSCP reporting indicator                       | TRUE                                           |
| → Pathloss reporting indicator                         | FALSE                                          |
| → Reporting quantities for detected set cells          | Not present                                    |
| → Measurement Reporting Mode                           |                                                |
| → Measurement Reporting Transfer Mode                  | Acknowledged mode RLC                          |
| → Periodic Reporting/Event Trigger Reporting Mode      | Periodic Reporting                             |
| → CHOICE report criteria                               | Intra-frequency measurement reporting criteria |

| Information Element                            | Value/Remark                                                                                                                  |
|------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Parameters required for each event             | 1a                                                                                                                            |
| Intra-frequency event identity                 | Not Present                                                                                                                   |
| Triggering condition 1                         | Not Present                                                                                                                   |
| Triggering condition 2                         | 20.0 dB                                                                                                                       |
| Reporting Range Constant                       | Not Present                                                                                                                   |
| Cells forbidden to affect reporting range      | FDD                                                                                                                           |
| CHOICE mode                                    |                                                                                                                               |
| Primary CPICH info                             |                                                                                                                               |
| Primary Scrambling Code                        | Set to same code as used for cell 2                                                                                           |
| W                                              | 0.0                                                                                                                           |
| Hysteresis                                     | 1.0 dB                                                                                                                        |
| Threshold used frequency                       | -85 dBm                                                                                                                       |
| Reporting deactivation threshold               | 0                                                                                                                             |
| Replacement activation threshold               | Not Present                                                                                                                   |
| Time to trigger                                | 0msec                                                                                                                         |
| Amount of reporting                            | Infinity                                                                                                                      |
| Reporting interval                             | 12 seconds                                                                                                                    |
| Reporting Cell Status                          |                                                                                                                               |
| CHOICE reported cell                           | Report cells within active and/or monitored set on used frequency or within active and/or monitored set on non-used frequency |
| Maximum number of reported cells               | 2                                                                                                                             |
| Inter-frequency measurement system information | Not Present                                                                                                                   |
| Traffic volume measurement system information  | Not Present                                                                                                                   |
| UE internal measurement system information     | Not Present                                                                                                                   |

## CELL UPDATE (Step 6 and 11)

| Information Element                     | Value/Remarks                                                                       |
|-----------------------------------------|-------------------------------------------------------------------------------------|
| U-RNTI                                  | Check to see if set to same U-RNTI value assigned in the execution of procedure P6. |
| Cell update cause                       | Check to see if set to 'Periodic cell updating'                                     |
| Protocol error indicator                | Check to see if set to 'FALSE'                                                      |
| Measured results on RACH                |                                                                                     |
| Measurement result for current cell     |                                                                                     |
| CHOICE measurement quantity             | Check to see if set to 'CPICH RSCP'                                                 |
| CPICH RSCP                              | Checked to see if set to within an acceptable range.                                |
| Measurement results for monitored cells | Checked to see if this IE is absent.                                                |
| Protocol error information              | Check to see if set to 'FALSE'                                                      |

## RRC CONNECTION RELEASE (Step 8)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

## RRC STATUS (Step 9)

Check to see if the same message type found in clause A is received, with the following exceptions:

| Information Element        | Value/remark                      |
|----------------------------|-----------------------------------|
| Protocol error information |                                   |
| Protocol error cause       | ASN.1 violation or encoding error |

## 8.1.3.5.5 Test requirement

After step 5 and 10, the UE shall initiate cell update procedure by transmitting CELL UPDATE message on CCCH. In this message, IE "cell update cause" shall be set to "periodic cell updating". It shall include IE "measured results on RACH", containing the measurement value for current cell CPICH RSCP.



After step 8 the UE shall transmit an RRC STATUS message which includes the appropriate cause values in IE "Protocol error information".

#### ~~8.1.4~~ ~~Void~~

#### ~~8.1.5~~ ~~UE capability~~

##### ~~8.1.5.1~~ ~~UE Capability in CELL\_DCH state: Success~~

###### ~~8.1.5.1.1~~ ~~Definition~~

###### ~~8.1.5.1.2~~ ~~Conformance requirement~~

- ~~1. The UE CAPABILITY ENQUIRY message is sent by the UTRAN to request the UE to transmit its capability information related to any radio access network that is supported by the UE or if the UTRAN needs an update of the UE's UMTS capability information or of its inter-system classmark.~~
- ~~2. When the UE receives a UE CAPABILITY ENQUIRY message, the UE transmits a UE CAPABILITY INFORMATION message on the uplink DCCH. Then the UTRAN transmits a UE CAPABILITY INFORMATION CONFIRM message.~~
- ~~3. If during the execution of UE capability update procedure, an invalid UE CAPABILITY INFORMATION CONFIRM is received, the UE shall respond with RRC STATUS message and decide whether to re-transmit UE CAPABILITY INFORMATION message by comparing its internal counter against N304.~~

#### ~~Reference~~

~~3GPP TS 25.331 clauses 8.1.6 and 8.1.7.~~

###### ~~8.1.5.1.3~~ ~~Test purpose~~

~~To confirm that the UE transmits a UE CAPABILITY INFORMATION message after it receives a UE CAPABILITY ENQUIRY message from the SS. To confirm that the UE indicates an invalid message reception when invalid UE CAPABILITY ENQUIRY and UE CAPABILITY INFORMATION CONFIRM messages are received. The UE shall transmit RRC STATUS message with the correct error cause value to SS.~~

###### ~~8.1.5.1.4~~ ~~Method of test~~

#### ~~Initial Condition~~

~~System Simulator: 1 cell.~~

~~UE: CELL\_DCH state (state 6-9 or state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.~~

#### ~~Test Procedure~~

~~The UE is brought to the CELL\_DCH state after a successful outgoing call attempt. The SS transmits an invalid UE CAPABILITY ENQUIRY message. This message lacks all IEs except IE "Message Type". After receiving such a message, the UE shall report the error using RRC STATUS message with the appropriate error cause specified. Then SS transmits a correct UE CAPABILITY ENQUIRY message, the UE receives this message and transmits a UE CAPABILITY INFORMATION message on the uplink DCCH which includes the "UE radio access capability" IE. The SS transmits a UE CAPABILITY INFORMATION CONFIRM message to the UE to complete the test. Then SS initiates another UE capability enquiry procedure. The UE shall reply with a UE CAPABILITY INFORMATION message on the uplink DCCH. When SS receives this message, it transmits an invalid UE CAPABILITY INFORMATION CONFIRM message. This message lacks all IEs except IE "Message Type". The UE shall detect a protocol error and send RRC STATUS message to report this event. After receiving RLC acknowledgement for this message, the UE shall re-transmit UE CAPABILITY INFORMATION message on the uplink DCCH after the expiry of~~

T304. SS completes this test by transmitting an error-free UE CAPABILITY INFORMATION CONFIRM message similar to the message sent in step 6.

#### Expected sequence

| Step | Direction |    | Message                           | Comment                                                                                                                    |
|------|-----------|----|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                   |                                                                                                                            |
| 1    |           |    |                                   | The UE is brought to CELL_DCH state after an outgoing call has been established successfully.                              |
| 2    |           | ←  | UE CAPABILITY ENQUIRY             | See specific message contents for this message                                                                             |
| 3    |           | →  | RRC STATUS                        | The IE "Protocol error cause" found in IE "Protocol error information" shall be set to "ASN.1 violation or encoding error" |
| 4    |           | ←  | UE CAPABILITY ENQUIRY             | Use default message.                                                                                                       |
| 5    |           | →  | UE CAPABILITY INFORMATION         | Use default message.                                                                                                       |
| 6    |           | ←  | UE CAPABILITY INFORMATION CONFIRM | Use default message.                                                                                                       |
| 7    |           | ←  | UE CAPABILITY ENQUIRY             | Same as in step 4.                                                                                                         |
| 8    |           | →  | UE CAPABILITY INFORMATION         | Shall be the same message content as in step 5.                                                                            |
| 9    |           | ←  | UE CAPABILITY INFORMATION CONFIRM | See specific message contents for this message                                                                             |
| 10   |           | →  | RRC STATUS                        | UE shall detect an error and then transmit this message.                                                                   |
| 11   |           | →  | UE CAPABILITY INFORMATION         | UE shall re-transmit this message after T304 expires.                                                                      |
| 12   |           | ←  | UE CAPABILITY INFORMATION CONFIRM | SS sends an error-free message to acknowledge the receipt of the uplink message.                                           |

#### Specific Message Contents

##### UE CAPABILITY ENQUIRY (Step 2)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

##### RRC STATUS (Step 3)

Check to see if the same message type found in Annex A is received, with the following exceptions:

| Information Element                                  | Value/remark                      |
|------------------------------------------------------|-----------------------------------|
| Protocol Error Information<br>→ Protocol Error Cause | ASN.1 violation or encoding error |

##### UE CAPABILITY INFORMATION CONFIRM (Step 9)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

## RRC STATUS (Step 10)

Check to see if the same message type found in Annex A is received, with the following exceptions:

| Information Element                                    | Value/remark                      |
|--------------------------------------------------------|-----------------------------------|
| Protocol Error Information<br>——→ Protocol Error Cause | ASN.1 violation or encoding error |

### 8.1.5.1.5 ——— Test requirement

After step 2, the UE shall transmit a RRC STATUS message on the uplink DCCH, reporting the error with protocol error cause set to "ASN.1 violation or encoding error".

After step 4 and 7 the UE shall transmit a UE CAPABILITY INFORMATION message on the uplink DCCH to respond to the UE CAPABILITY ENQUIRY message.

After step 9, the UE shall transmit a RRC STATUS message on the uplink DCCH. The protocol error cause shall be set to "ASN.1 violation or encoding error".

After step 10, the UE shall re-transmit the UE CAPABILITY INFORMATION message with a similar content as in step 8 after the expiry of T304.

## 8.1.5.2 ——— UE Capability in CELL\_DCH state: Success after T304 timeout

### 8.1.5.2.1 ——— Definition

### 8.1.5.2.2 ——— Conformance requirement

1. The UE CAPABILITY ENQUIRY message is sent by the UTRAN to request the UE to transmit its capability information related to any radio access network that is supported by the UE, if the UTRAN needs an update of the UE's UMTS capability information or of its inter-system classmark.
2. After the UE receives a UE CAPABILITY ENQUIRY message, it transmits a UE CAPABILITY INFORMATION message on the uplink DCCH. If it fails to receive a UE CAPABILITY INFORMATION CONFIRM message, the UE re-transmits another UE CAPABILITY INFORMATION message after T304 expires until V304 is greater than N304.

## Reference

3GPP TS 25.331 clause 8.1.6 and 8.1.7.

### 8.1.5.2.3 ——— Test purpose

To confirm that the UE re-transmits a UE CAPABILITY INFORMATION message until V304 is greater than N304, after the expiry of timer T304 when the UE cannot receive a UE CAPABILITY INFORMATION CONFIRM message in response to a UE CAPABILITY INFORMATION message.

### 8.1.5.2.4 ——— Method of test

## Initial Condition

System Simulator: 1 cell.

UE: CELL\_DCH state (state 6-9 or state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

## Test Procedure

The UE is brought to CELL\_DCH state. When the SS transmits a UE CAPABILITY ENQUIRY message which includes the "Capability update requirement" IE, the UE shall reply with a UE CAPABILITY INFORMATION

message on the uplink DCCH which includes the "UE radio access capability" IE. The SS does not transmit a UE CAPABILITY INFORMATION CONFIRM message to the UE, resulting in the T304 timer to expire. SS shall observe that the UE attempts to transmit a UE CAPABILITY INFORMATION message again. The UE shall re-transmit N304 times, and SS transmits a UE CAPABILITY INFORMATION CONFIRM message to answer the last request and completes this test procedure.

#### Expected sequence

| Step | Direction |    | Message                           | Comment                                                                                          |
|------|-----------|----|-----------------------------------|--------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                   |                                                                                                  |
| 1    |           |    |                                   | The UE is brought to CELL_DCH state. SS sets internal counter K=0                                |
| 2    |           | ←  | UE CAPABILITY ENQUIRY             | Including the IE "Capability update requirement".                                                |
| 3    | →         |    | UE CAPABILITY INFORMATION         | Including the "UE radio access capability".                                                      |
| 4    |           |    |                                   | If K is equal to N304, then proceed to step 6.                                                   |
| 5    |           |    |                                   | The SS does not transmit a response and wait for T304 timer to expire. K=K+1 and goes to step 3. |
| 6    |           | ←  | UE CAPABILITY INFORMATION CONFIRM | Use default message contents                                                                     |

#### Specific Message Contents

None

#### 8.1.5.2.5 Test requirement

After step 3 the UE shall re-transmits a UE CAPABILITY INFORMATION message on the uplink DCCH, after each expiry of timer T304. The UE CAPABILITY INFORMATION message shall contain IE "UE radio access capability" indicating the settings found in PIC/PIXIT statements. After (N304) re-transmissions, the UE shall receive a UE CAPABILITY INFORMATION CONFIRM message.

#### 8.1.5.3 UE Capability in CELL\_DCH state: Failure (After N304 re-transmissions)

##### 8.1.5.3.1 Definition

##### 8.1.5.3.2 Conformance requirement

1. The UE CAPABILITY ENQUIRY message is sent by the UTRAN to request the UE to transmit its capability information related to any radio access network that is supported by the UE if the UTRAN needs an update of the UE's UMTS capability information or of its inter-system classmark.
2. If UE re-transmits UE CAPABILITY INFORMATION in excess of N304 times, the UE initiates the cell update procedure.

#### Reference

3GPP TS 25.331 clauses 8.1.6 and 8.1.7.

##### 8.1.5.3.3 Test purpose

To confirm that the UE stops retrying to transmit a UE CAPABILITY INFORMATION message if V304 is greater than N304. It then initiates cell update procedure.

#### 8.1.5.3.4 Method of test

##### Initial Condition

System Simulator: 1 cell.

UE: CELL\_DCH state (state 6-9 or state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

##### Test Procedure

The UE is brought to CELL\_DCH state. When the SS transmits a UE CAPABILITY ENQUIRY message which includes the "Capability update requirement" IE, the UE receives this message and transmits a UE CAPABILITY INFORMATION message on the uplink DCCH which includes the "UE radio access capability" IE. The SS does not respond with a UE CAPABILITY INFORMATION CONFIRM message but keeps a count on the number of messages received. When the T304 timer expires, the UE shall transmit a UE CAPABILITY INFORMATION message again. After sending (N304+1) messages, the UE shall stop sending UE CAPABILITY INFORMATION messages and initiates the cell update procedure. SS allows UE to return to "connected state" by issuing CELL UPDATE CONFIRM message on the downlink DCCH. Then UE shall reconfigured its physical channel according to the CELL UPDATE CONFIRM message and respond with PHYSICAL CHANNEL RECONFIGURATION COMPLETE message to SS.

##### Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                                                                                                        |
|------|-----------|----|-------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                                                |
| 1    |           |    |                                           | The UE starts from CELL_DCH state. SS sets counter K to 0                                                                                                      |
| 2    | ←         |    | UE CAPABILITY ENQUIRY                     | Use default message                                                                                                                                            |
| 3    |           | →  | UE CAPABILITY INFORMATION                 | Use default message                                                                                                                                            |
| 4    |           |    |                                           | The SS does not transmit a response and allows T304 timer to expire. SS increments counter K. If K is greater than N304, proceeds to step 5 else returns to 3. |
| 5    |           | →  | CELL UPDATE                               | The UE assumes that radio link failure has occurred and transmits this message which includes IE "Cell update cause" set to "radio link failure".              |
| 6    |           | ←  | CELL UPDATE CONFIRM                       | This message include IE "Physical channel information elements".                                                                                               |
| 7    |           |    |                                           | The SS configure the dedicated physical channel according to the IE "Physical channel information elements" included in the CELL UPDATE CONFIRM message.       |
| 8    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                                                                |

## Specific Message Contents

## CELL UPDATE CONFIRM (Step 6)—FDD

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A with the following exceptions:

| Information Element                          | Value/remark                                                |
|----------------------------------------------|-------------------------------------------------------------|
| U-RNTI                                       | Same as CELL UPDATE message in step 5                       |
| RRC State indicator                          | CELL_DCH                                                    |
| Frequency info                               |                                                             |
| — CHOICE mode                                | FDD                                                         |
| — UARFCN uplink(Nu)                          | Reference to TS34.108 clause 5.1 Test frequencies           |
| — UARFCN downlink(Nd)                        | Reference to TS34.108 clause 5.1 Test frequencies           |
| Maximum allowed UL TX power                  | 33dBm                                                       |
| CHOICE Mode                                  | FDD                                                         |
| Downlink information for each radio links    |                                                             |
| — Primary CPICH info                         |                                                             |
| — Primary scrambling code                    | 100                                                         |
| — PDSCH with SHO DCH info                    | Not Present                                                 |
| — PDSCH code mapping                         | Not Present                                                 |
| — Downlink DPCH info for each RL             |                                                             |
| — CHOICE mode                                | FDD                                                         |
| — Primary CPICH usage for channel estimation | Primary CPICH may be used                                   |
| — DPCH frame offset                          | 0 chips                                                     |
| — Secondary CPICH info                       | Not Present                                                 |
| — DL channelisation code                     |                                                             |
| — Secondary scrambling code                  | 2                                                           |
| — Spreading factor                           | Reference to TS34.108 clause 6.10 Parameter Set             |
| — Code number                                | SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set) |
| — Scrambling code change                     | No change                                                   |
| — TPC combination index                      | 0                                                           |
| — SSST Cell Identity                         | -a                                                          |
| — Closed loop timing adjustment mode         | Not Present                                                 |
| — SCCPCH information for FACH                | Not Present                                                 |

## CELL UPDATE CONFIRM (Step 6)—3.84 Mcps TDD

| Information Element                       | Value/remark                                      |
|-------------------------------------------|---------------------------------------------------|
| U-RNTI                                    | Same as CELL UPDATE message in step 5             |
| RRC State indicator                       | CELL_DCH                                          |
| Frequency info                            |                                                   |
| — CHOICE mode                             | TDD                                               |
| — UARFCN (Nt)                             | Reference to TS34.108 clause 5.1 Test frequencies |
| Maximum allowed UL TX power               | 30dBm                                             |
| CHOICE Mode                               | TDD                                               |
| Downlink information for each radio links |                                                   |
| — Primary CCPCH info                      |                                                   |
| — CHOICE mode                             | TDD                                               |
| — CHOICE TDD option                       | 3.84 Mcps TDD                                     |
| — CHOICE SyncCase                         | Not Present                                       |
| — Cell Parameters ID                      | Not Present                                       |
| — Block STTD indicator                    | FALSE                                             |
| — Downlink DPCH info for each RL          |                                                   |
| — CHOICE mode                             | TDD                                               |
| — DL CCTrCh List                          |                                                   |
| — TFCS ID                                 | 1                                                 |
| — Time info                               |                                                   |
| — Activation time                         | Not Present (default)                             |
| — Duration                                | Not Present (default)                             |
| — Common timeslot info                    | Not Present (default)                             |
| — Downlink DPCH timeslots and codes       | Not Present (default)                             |
| — UL CCTrCh TPC List                      | Not Present (default)                             |

### CELL UPDATE CONFIRM (Step 6) — 1.28 Mcps TDD

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A with the following exceptions:

| Information Element                       | Value/remark                                      |
|-------------------------------------------|---------------------------------------------------|
| U-RNTI                                    | Same as CELL UPDATE message in step 5             |
| RRC-State indicator                       | CELL_DCH                                          |
| Frequency info                            |                                                   |
| — CHOICE mode                             | TDD                                               |
| — UARFCN (Nt)                             | Reference to TS34.108 clause 5.1 Test frequencies |
| Maximum allowed UL TX power               | 30dBm                                             |
| CHOICE Mode                               | TDD                                               |
| Downlink information for each radio links |                                                   |
| — Primary CCPCH info                      |                                                   |
| — CHOICE mode                             | TDD                                               |
| — CHOICE TDD option                       | 1.28 Mcps TDD                                     |
| — TSTD indicator                          | FALSE                                             |
| — Cell Parameters ID                      | Not Present                                       |
| — Block STTD indicator                    | FALSE                                             |
| — Downlink DPCH info for each RL          |                                                   |
| — CHOICE mode                             | TDD                                               |
| — DL CCTrCh List                          |                                                   |
| — TFCS ID                                 | 1                                                 |
| — Time info                               |                                                   |
| — Activation time                         | Not Present (default)                             |
| — Duration                                | Not Present (default)                             |
| — Common timeslot info                    | Not Present (default)                             |
| — Downlink DPCH timeslots and codes       | Not Present (default)                             |
| — UL CCTrCh TPC List                      | Not Present (default)                             |

#### 8.1.5.3.5 — Test requirement

After step 2, the UE shall transmit a UE CAPABILITY INFORMATION message on the uplink DCCH. The UE shall re-transmit this message for N304 times.

After step 4, the UE shall initiate the cell update procedure.

After step 6, UE shall respond with a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message after it has configured L1 according to the CELL UPDATE CONFIRM message in step 6.

### 8.1.5.4 — UE Capability in CELL\_FACH state: Success

#### 8.1.5.4.1 — Definition

#### 8.1.5.4.2 — Conformance requirement

1. The UE CAPABILITY ENQUIRY message is sent by the UTRAN to request the UE to transmit its capability information related to any radio access network(s) supported by the UE. UTRAN initiates this procedure when it needs an update of the UE's UMTS capability information or of its inter-system classmark.
2. When the UE receives a UE CAPABILITY ENQUIRY message, the UE shall transmit a UE CAPABILITY INFORMATION message on the uplink DCCH.
3. If during the execution of UE capability update procedure, an invalid UE CAPABILITY INFORMATION CONFIRM is received, the UE shall respond with RRC STATUS message and decide whether to re-transmit UE CAPABILITY INFORMATION message by comparing its internal counter against N304.

#### Reference

3GPP TS 25.331 clauses 8.1.6 and 8.1.7.

#### 8.1.5.4.3 ~~Test purpose~~

~~To confirm that the UE transmits a UE-CAPABILITY INFORMATION message after it receives a UE-CAPABILITY ENQUIRY message from the SS. To confirm that the UE indicates an invalid message reception when invalid UE-CAPABILITY ENQUIRY and UE-CAPABILITY INFORMATION CONFIRM messages are received. The UE shall transmit RRC STATUS message with the correct error-cause value to SS.~~

#### 8.1.5.4.4 ~~Method of test~~

##### ~~Initial Condition~~

~~System Simulator: 1-cell.~~

~~UE: CELL\_FACH state (state 6-11) as specified in clause 7.4 of TS 34.108.~~

##### ~~Test Procedure~~

~~The UE is brought to the CELL\_FACH state after a successful outgoing call attempt. The SS transmits an invalid UE-CAPABILITY ENQUIRY message. After receiving such a message, the UE shall report an error using RRC STATUS message with the appropriate error-cause specified. Then SS transmits a UE-CAPABILITY ENQUIRY message which includes the IE "Capability update requirement". After UE receives this message, it transmits a UE-CAPABILITY INFORMATION message on the uplink DCCH, which includes the IE "UE radio access capability". The SS transmits a UE-CAPABILITY INFORMATION CONFIRM message to the UE to complete the UE-capability enquiry procedure. Then SS initiates another UE-capability enquiry procedure. The UE shall reply with a UE-CAPABILITY INFORMATION message on the uplink DCCH. When SS receives this message, it transmits an invalid UE-CAPABILITY INFORMATION CONFIRM message. This message lacks all IEs except IE "Message Type". The UE shall detect a protocol error and send RRC STATUS message to report this event. After receiving the RLC layer acknowledgement PDU for this message, the UE shall re-transmit UE-CAPABILITY INFORMATION message on the uplink DCCH upon the expiry of T304. SS completes this test by sending an error-free UE-CAPABILITY INFORMATION CONFIRM message similar to the message sent in step 6.~~



## Expected sequence

| Step | Direction |    | Message                           | Comment                                                                                                                    |
|------|-----------|----|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                   |                                                                                                                            |
| 1    |           |    |                                   | The UE is brought to CELL_FACH state after an outgoing call has been established successfully.                             |
| 2    |           | ←  | UE CAPABILITY ENQUIRY             | See specific message contents for this message                                                                             |
| 3    |           | →  | RRC STATUS                        | The IE "Protocol error cause" found in IE "Protocol error information" shall be set to "ASN.1 violation or encoding error" |
| 4    |           | ←  | UE CAPABILITY ENQUIRY             | Use default message.                                                                                                       |
| 5    |           | →  | UE CAPABILITY INFORMATION         | Use default message.                                                                                                       |
| 6    |           | ←  | UE CAPABILITY INFORMATION CONFIRM | Use default message.                                                                                                       |
| 7    |           | ←  | UE CAPABILITY ENQUIRY             | Same as in step 4.                                                                                                         |
| 8    |           | →  | UE CAPABILITY INFORMATION         | The message content shall be the same as in step 5.                                                                        |
| 9    |           | ←  | UE CAPABILITY INFORMATION CONFIRM | See specific message contents for this message                                                                             |
| 10   |           | →  | RRC STATUS                        | UE shall detect an error and then transmit this message on uplink DCCH.                                                    |
| 11   |           | →  | UE CAPABILITY INFORMATION         | UE shall re-transmit this message after T304 expires.                                                                      |
| 12   |           | ←  | UE CAPABILITY INFORMATION CONFIRM | SS sends an error-free message to acknowledge the receipt of the uplink message.                                           |

## Specific Message Contents

## UE CAPABILITY ENQUIRY (Step 2)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

## RRC STATUS (Step 3)

Check to is the same message type found in Annex A is received, with the following exceptions:

| Information Element                                   | Value/remark                      |
|-------------------------------------------------------|-----------------------------------|
| Protocol Error Information<br>—— Protocol Error Cause | ASN.1 violation or encoding error |

## UE CAPABILITY INFORMATION CONFIRM (Step 9)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

## RRC STATUS (Step 10)

Check to see if the same message type found in Annex A is received, with the following exceptions:

| Information Element                                   | Value/remark                       |
|-------------------------------------------------------|------------------------------------|
| Protocol Error Information<br>—— Protocol Error Cause | ASN.1 violation or encoding error" |

#### 8.1.5.4.5 ——— Test requirement

After step 2, the UE shall transmit a RRC STATUS message on the uplink DCCH, reporting the error with protocol error cause set to "ASN.1 violation or encoding error".

After step 4 and 7 the UE shall transmit a UE CAPABILITY INFORMATION message on the uplink DCCH to respond to the downlink UE CAPABILITY ENQUIRY message.

After step 9, the UE shall transmit a RRC STATUS message on the uplink DCCH. The protocol error cause shall be set to "ASN.1 violation or encoding error".

After step 10, the UE shall re-transmit the UE CAPABILITY INFORMATION message with a similar content as in step 8 upon the expiry of T304.

### 8.1.5.5 ——— UE Capability in CELL\_FACH state: Success after T304 timeout

#### 8.1.5.5.1 ——— Definition

#### 8.1.5.5.2 ——— Conformance requirement

1. The UE CAPABILITY ENQUIRY message is sent by the UTRAN to request the UE to transmit its capability information related to any radio access network(s) supported by the UE. UTRAN initiates this action when it needs an update of the UE's UMTS capability information or of its inter-system classmark.
2. After the UE receives a UE CAPABILITY ENQUIRY message, it transmits a UE CAPABILITY INFORMATION message on the uplink DCCH. If it fails to receive a UE CAPABILITY INFORMATION CONFIRM message, the UE re-transmits another UE CAPABILITY INFORMATION message until its internal counter V304 is greater than N304.

#### Reference

3GPP TS 25.331 clauses 8.1.6 and 8.1.7.

#### 8.1.5.5.3 ——— Test purpose

To confirm that the UE re-transmits a UE CAPABILITY INFORMATION message until V304 is greater than N304, after the expiry of timer T304 when it fails to receive a downlink UE CAPABILITY INFORMATION CONFIRM message in response to the uplink UE CAPABILITY INFORMATION message sent.

#### 8.1.5.5.4 ——— Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: CELL\_FACH state (state 6-11) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is brought to CELL\_FACH state. When the SS transmits a UE CAPABILITY ENQUIRY message which includes the IE "Capability update requirement", the UE shall reply with a UE CAPABILITY INFORMATION message on the uplink DCCH that contains the IE "UE radio access capability". The SS waits and does not transmit a UE CAPABILITY INFORMATION CONFIRM message to the UE, resulting in the T304 timer to expire. SS shall observe that the UE attempts to transmit a UE CAPABILITY INFORMATION message again. The UE shall

re-transmit N304 times, and SS transmits a UE CAPABILITY INFORMATION CONFIRM message to answer the last request and completes this test procedure.

#### Expected sequence

| Step | Direction |    | Message                           | Comment                                                                                          |
|------|-----------|----|-----------------------------------|--------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                   |                                                                                                  |
| 1    |           |    |                                   | The UE is brought to CELL_FACH state. SS sets internal counter K = 0                             |
| 2    |           | ←  | UE CAPABILITY ENQUIRY             | Including the IE "Capability update requirement".                                                |
| 3    |           | →  | UE CAPABILITY INFORMATION         | Including the IE "UE radio access capability".                                                   |
| 4    |           |    |                                   | If K equals N304, then proceeds to step 6. Else, continue with step 5.                           |
| 5    |           |    |                                   | The SS does not transmit a response and wait for T304 timer to expire. K=K+1 and goes to step 3. |
| 6    |           | ←  | UE CAPABILITY INFORMATION CONFIRM | Use default message contents                                                                     |

#### Specific Message Contents

None

#### 8.1.5.5.5 Test requirement

After step 3 the UE shall re-transmit a UE CAPABILITY INFORMATION message on the uplink DCCH, after each expiry of timer T304. The UE CAPABILITY INFORMATION message shall contain IE "UE radio access capability" with the value matching those stated in the ICS/IXIT statements. After (N304) re-transmissions, the UE shall receive a UE CAPABILITY INFORMATION CONFIRM message.

### 8.1.6 Direct Transfer

#### 8.1.6.1 Direct Transfer in CELL\_DCH state (invalid message reception and no signalling connection exists)

##### 8.1.6.1.1 Definition

##### 8.1.6.1.2 Conformance requirement

The UE shall transmit an RRC STATUS message stating the value "ASN.1 violation or encoding error" in IE "Protocol error cause" when the UE receives a DOWNLINK DIRECT TRANSFER message, which does not include any IEs except IE "Message Type". The UE shall transmit an RRC STATUS message including the IE "Protocol error information" with the IE "Protocol error cause" set to "Message not compatible with receiver state" when the UE receives a DOWNLINK DIRECT TRANSFER message, with invalid IE "CN domain identity".

#### Reference

3GPP TS 25.331 clause 8.1.9.

##### 8.1.6.1.3 Test purpose

To confirm that the UE transmits an RRC STATUS message on the DCCH using AM RLC if it receives a DOWNLINK DIRECT TRANSFER message which does not include any IEs except IE "Message Type". To confirm

that the UE transmits an RRC STATUS message on the DCCH using AM RLC if it receives a DOWNLINK DIRECT TRANSFER message which includes an invalid IE "CN domain identity".

#### 8.1.6.1.4 Method of test

##### Initial Condition

System Simulator: 1 cell.

UE: CELL\_DCH (state 6-9 or state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

##### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits an invalid DOWNLINK DIRECT TRANSFER message to the UE. The UE shall transmit an RRC STATUS message on the DCCH using AM RLC. The error type "ASN.1 violation or encoding error" shall also be indicated in IE "Protocol error cause". The SS transmits a DOWNLINK DIRECT TRANSFER message that contains an invalid IE "CN domain identity" to the UE. The UE shall transmit an RRC STATUS message on the DCCH using AM RLC. The error type "Message not compatible with receiver state" shall also be indicated in IE "Protocol error cause".

##### Expected sequence

| Step | Direction |    | Message                  | Comment                        |
|------|-----------|----|--------------------------|--------------------------------|
|      | UE        | SS |                          |                                |
| 1    | —         | ←  | DOWNLINK DIRECT TRANSFER | Only message type is provided. |
| 2    | —         | →  | RRC STATUS               |                                |
| 3    | —         | ←  | DOWNLINK DIRECT TRANSFER |                                |
| 4    | —         | →  | RRC STATUS               |                                |

##### Specific Message Contents

##### DOWNLINK DIRECT TRANSFER (Step 1)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

##### RRC STATUS (Step 2)

Check to see if same message type found in Annex A is received, with the following exceptions:

| Information Element                                  | Value/remark                       |
|------------------------------------------------------|------------------------------------|
| Protocol error information<br>→ Protocol error cause | -ASN.1 violation or encoding error |

##### DOWNLINK DIRECT TRANSFER (Step 3)

Use the same message type found in clause 9 of TS 34.108, with the following exceptions:

| Information Element               | Value/remark                                                      |
|-----------------------------------|-------------------------------------------------------------------|
| CN-domain-identity<br>NAS-message | CS-domain or PS-domain-as-unselected-domain<br>Arbitrary message. |

#### RRC STATUS (Step 4)

Check to see if same message type found in Annex A is received, with the following exceptions:

| Information Element                                                                                                | Value/remark                                                                              |
|--------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|
| Message Type<br>Identification of received message type<br>— Received message type<br>— RRC transaction identifier | DOWNLINK DIRECT TRANSFER<br>Same value in the DOWNLINK DIRECT TRANSFER message in step 3. |
| Protocol error information<br>— Protocol error cause                                                               | -Message not compatible with receiver state                                               |

#### 8.1.6.1.5 ——— Test requirement

After step 1 the UE shall transmit an RRC STATUS message on the DCCH using AM RLC setting "ASN.1 violation or encoding error" in IE "Protocol error cause".

After step 3 the UE shall transmit a n RRC STATUS message on the DCCH using AM RLC setting "Message not compatible with receiver state" in IE "Protocol error cause".

#### 8.1.6.2 ——— Direct Transfer in CELL\_FACH state (invalid message reception and no signalling connection exists)

##### 8.1.6.2.1 ——— Definition

##### 8.1.6.2.2 ——— Conformance requirement

The UE shall transmit an RRC STATUS message stating the value "ASN.1 violation or encoding error" in IE "Protocol error cause" when the UE receives a DOWNLINK DIRECT TRANSFER message, which does not include any IEs except IE "Message Type". The UE shall transmit an RRC STATUS message including the IE "Protocol error information" with the IE "Protocol error cause" set to "Message not compatible with receiver state" when the UE receives a DOWNLINK DIRECT TRANSFER message, with invalid IE "CN domain identity".

#### Reference

3GPP TS 25.331 clause 8.1.9.

##### 8.1.6.2.3 ——— Test purpose

To confirm that the UE transmits an RRC STATUS message on the DCCH using AM RLC if it receives a DOWNLINK DIRECT TRANSFER message which does not include any IEs except IE "Message Type". To confirm that the UE transmits an RRC STATUS message on the DCCH using AM RLC if it receives a DOWNLINK DIRECT TRANSFER message which includes an invalid IE "CN domain identity".

##### 8.1.6.2.4 ——— Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: CELL\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

## Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a DOWNLINK DIRECT TRANSFER message to the UE and does not include all IEs except IE "Message Type". The UE shall transmit an RRC STATUS message on the DCCH using AM RLC. The error type "ASN.1 violation or encoding error" shall also be indicated in IE "Protocol error cause". The SS transmits a DOWNLINK DIRECT TRANSFER message that contains an invalid IE "CN domain identity" to the UE. The UE shall transmit an RRC STATUS message on the DCCH using AM RLC. The error type "Message not compatible with receiver state" shall also be indicated in IE "Protocol error cause".

## Expected sequence

| Step | Direction |    | Message                  | Comment                       |
|------|-----------|----|--------------------------|-------------------------------|
|      | UE        | SS |                          |                               |
| 1    | —←        |    | DOWNLINK DIRECT TRANSFER | Only message type is provided |
| 2    | —→        |    | RRC STATUS               |                               |
| 3    | —←        |    | DOWNLINK DIRECT TRANSFER |                               |
| 4    | —→        |    | RRC STATUS               |                               |

## Specific Message Contents

### DOWNLINK DIRECT TRANSFER (Step 1)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

### RRC STATUS (Step 2)

Check to see if the same message type found in Annex A is received, with the following exceptions:

| Information Element                                 | Value/remark                       |
|-----------------------------------------------------|------------------------------------|
| Protocol error information<br>—Protocol error cause | -ASN.1 violation or encoding error |

### DOWNLINK DIRECT TRANSFER (Step 3)

| Information Element               | Value/remark                                                      |
|-----------------------------------|-------------------------------------------------------------------|
| CN domain identity<br>NAS message | CS domain or PS domain as unselected domain<br>Arbitrary message. |

### RRC STATUS (Step 4)

Check to see if the same message type found in Annex A is received, with the following exceptions:

| Information Element                                                                              | Value/remark                                                                              |
|--------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|
| Identification of received message type<br>—Received message type<br>—RRC transaction identifier | DOWNLINK DIRECT TRANSFER<br>Same value in the DOWNLINK DIRECT TRANSFER message in step 3. |
| Protocol error information<br>—Protocol error cause                                              | -Message not compatible with receiver state                                               |

#### ~~8.1.6.2.5 Test requirement~~

~~After step 1 the UE shall transmit an RRC STATUS message on the DCCH using AM RLC setting "ASN.1 violation or encoding error" in IE "Protocol error cause".~~

~~After step 3 the UE shall transmit a n RRC STATUS message on the DCCH using AM RLC setting "Message not compatible with receiver state" in IE "Protocol error cause".~~

### ~~8.1.7 Security mode command~~

#### ~~8.1.7.1 Security mode command in CELL\_DCH state~~

##### ~~8.1.7.1.1 Definition~~

##### ~~8.1.7.1.2 Conformance requirement~~

- ~~1. This procedure is used to trigger the stop or start of ciphering or to command the restart of ciphering with the new ciphering configuration for the signalling radio bearers and any of radio bearers. It is also used to start integrity protection or modify integrity protection configuration for the signalling radio bearers.~~
- ~~2. When the UE receives a SECURITY MODE COMMAND message from the UTRAN, which indicates the downlink activation time and new ciphering mode configuration, the UE shall apply the old ciphering configuration before the stated downlink activation time. It shall start to decipher using the new ciphering configuration at the downlink activation time.~~
- ~~3. After the UE has transmitted a SECURITY MODE COMPLETE message using the new integrity protection configuration which includes uplink activation time, it shall start to cipher transmission in the uplink using the new configuration at the uplink activation time.~~

#### Reference

3GPP TS 25.331 clause 8.1.12.

##### ~~8.1.7.1.3 Test purpose~~

~~To confirm that the UE activates the new ciphering configurations after the stated activation time. To confirm that after the UE receives a SECURITY MODE COMMAND message, it transmits a SECURITY MODE COMPLETE message to the UTRAN using the old ciphering configuration together with the application of the new integrity protection configuration. To confirm that UE sends a SECURITY MODE FAILURE message when SS transmits an incompatible simultaneous SECURITY MODE COMMAND messages to UE. To confirm that UE send SECURITY MODE FAILURE message when SS transmits a SECURITY MODE COMMAND message that causes invalid configuration. To confirm that UE send SECURITY MODE FAILURE message when UE receives an invalid SECURITY MODE COMMAND message.~~

##### ~~8.1.7.1.4 Method of test~~

#### Initial Condition

System Simulator: 1 cell.

UE: CELL\_DCH (state 6-9 or state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a SECURITY MODE COMMAND message which does not include any IEs except IE "Message Type". The UE shall respond by sending SECURITY MODE FAILURE message on the DCCH. Then SS transmits a SECURITY MODE COMMAND message with IE "Ciphering mode command" set to "stop". Again the UE shall not trigger any ciphering algorithm and it shall respond by sending SECURITY MODE FAILURE message on the DCCH. Next, SS transmits a valid SECURITY MODE COMMAND message which

includes the "Downlink activation time" IE for RB2 and "Integrity check info" IE. Following that, SS immediately transmit another valid SECURITY MODE COMMAND message to UE. Then the UE shall check the integrity check info and shall start to configure ciphering in downlink according to the first valid SECURITY MODE COMMAND message. Upon the reception of the subsequent SECURITY MODE COMMAND message, the UE shall transmit SECURITY MODE FAILURE message to SS with IE "failure cause" set to "incompatible simultaneous reconfiguration". Then UE shall transmit a SECURITY MODE COMPLETE message which contains the uplink activation time for RB2 and also "Integrity check info" IE using the new integrity protection configuration. SS records the uplink ciphering activation time for RB 2. Next, SS transmits UE CAPABILITY ENQUIRY message repeatedly on the downlink DCCH using RLC-AM mode. The UE shall respond to each downlink message with a UE CAPABILITY INFORMATION message on the uplink DCCH using RLC-AM. SS then send UE CAPABILITY INFORMATION CONFIRM message to UE. This cycle repeats itself until both the uplink and downlink ciphering activation time for RB 2 has elapsed. SS checks all uplink UE CAPABILITY INFORMATION messages are integrity-protected by UIA algorithm, and that the messages contain the correct values for "Integrity check info" IE. This can be verified in SS through the reception of a correctly ciphered and integrity-protected UE CAPABILITY INFORMATION message.

#### Expected sequence

| Step | Direction |    | Message                           | Comment                                                                                                                                                                                                                      |
|------|-----------|----|-----------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                   |                                                                                                                                                                                                                              |
| 1    |           |    |                                   | RRC connected state on DCH state.                                                                                                                                                                                            |
| 2    | —←        |    | SECURITY MODE COMMAND             | See message content.                                                                                                                                                                                                         |
| 3    |           | —→ | SECURITY MODE FAILURE             | IE "Failure Cause" shall be set to "Protocol Error" and IE "Protocol Error Information" shall be set to "ASN.1 violation or encoding error".                                                                                 |
| 4    | —←        |    | SECURITY MODE COMMAND             | See message content.                                                                                                                                                                                                         |
| 5    |           | —→ | SECURITY MODE FAILURE             | IE "Failure Cause" shall be set to "invalid configuration".                                                                                                                                                                  |
| 6    | —←        |    | SECURITY MODE COMMAND             | See specific message contents.                                                                                                                                                                                               |
| 7    | —←        |    | SECURITY MODE COMMAND             | See specific message contents.                                                                                                                                                                                               |
| 8    |           | —→ | SECURITY MODE FAILURE             | IE "Failure Cause" shall be set to "Incompatible simultaneous reconfiguration".                                                                                                                                              |
| 9    |           | —→ | SECURITY MODE COMPLETE            | SS verifies that this message is sent unciphered. SS records the uplink ciphering activation time for RB 2.                                                                                                                  |
| 10   | —←        |    | UE CAPABILITY ENQUIRY             | SS repeats step 10, 11 and 12 until its internal uplink and downlink RLC SN have both surpassed the uplink and downlink ciphering activation time specified for RB2. This message is sent on the downlink DCCH using RLC-AM. |
| 11   |           | —→ | UE CAPABILITY INFORMATION         | UE shall send this message on the uplink DCCH using RLC-AM. SS verifies that the last UE CAPABILITY INFORMATION message is both integrity-protected and ciphered correctly.                                                  |
| 12   | ←         |    | UE CAPABILITY INFORMATION CONFIRM |                                                                                                                                                                                                                              |

#### Specific Message Contents

#### SECURITY MODE COMMAND (Step 2)



| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

### SECURITY MODE FAILURE (Step 3)

The same message found in Annex A shall be transmitted by the UE on the uplink DCCH, with the exception of the following IEs:

| Information Element          | Value/remark                      |
|------------------------------|-----------------------------------|
| Failure cause                |                                   |
| — Failure cause              | Protocol error                    |
| — Protocol error information |                                   |
| — Protocol error cause       | ASN.1 violation or encoding error |

### SECURITY MODE COMMAND (Step 4)

| Information Element                             | Value/remark                                     |
|-------------------------------------------------|--------------------------------------------------|
| RRC transaction identifier                      | 0                                                |
| Integrity check info                            |                                                  |
| — Message authentication code                   | Calculated result in SS                          |
| — RRC Message sequence number                   | 0                                                |
| Security Capability                             |                                                  |
| — Ciphering algorithm capability                |                                                  |
| — UEA0                                          | TRUE                                             |
| — UEA1                                          | TRUE                                             |
| — Spare                                         | FALSE                                            |
| — Integrity protection algorithm capability     |                                                  |
| — UIA1                                          | TRUE                                             |
| — Spare                                         | FALSE                                            |
| Ciphering mode info                             |                                                  |
| — Ciphering mode command                        |                                                  |
| Integrity protection mode info                  | Stop                                             |
| — Integrity protection mode command             |                                                  |
| — Downlink integrity protection activation info | Start                                            |
| — Integrity protection algorithm                | Not Present                                      |
| — Integrity protection initialisation number    | UIA1                                             |
| CN domain identity                              | 0000-0000-0000-0000H (FRESH)<br>Supported domain |

### SECURITY MODE FAILURE (Step 5)

The same message found in Annex A shall be transmitted by the UE on the uplink DCCH, with the exception of the following IEs:

| Information Element | Value/remark          |
|---------------------|-----------------------|
| Failure cause       |                       |
| — Failure cause     | Invalid configuration |

### SECURITY MODE COMMAND (Step 6 and 7)

See notes below for the value of Y.

| Information Element                                    | Value/remark                                  |
|--------------------------------------------------------|-----------------------------------------------|
| RRC transaction identifier                             | 0                                             |
| Integrity check info                                   |                                               |
| — Message authentication code                          | Calculated result in SS                       |
| — RRC Message sequence number                          | 0                                             |
| Security Capability                                    |                                               |
| — Ciphering algorithm capability                       |                                               |
| — UEA0                                                 | TRUE                                          |
| — UEA1                                                 | TRUE                                          |
| — Spare                                                | FALSE                                         |
| — Integrity protection algorithm capability            |                                               |
| — UIA1                                                 | TRUE                                          |
| — Spare                                                | FALSE                                         |
| Ciphering mode info                                    |                                               |
| — Ciphering mode command                               | Start/restart                                 |
| — Ciphering algorithm                                  | Use one of the supported ciphering algorithms |
| — Activation time for DPCH                             | Not Present                                   |
| — Radio bearer downlink ciphering activation time info |                                               |
| — RB Identity                                          | 2                                             |
| — RLC sequence number                                  | Current RLC SN + Y                            |
| Integrity protection mode info                         |                                               |
| — Integrity protection mode command                    | Start                                         |
| — Downlink integrity protection activation info        | Not Present                                   |
| — Integrity protection algorithm                       | UIA1                                          |
|                                                        | 0000-0000-0000-0000-H (FRESH)                 |
| — Integrity protection initialisation number           | Supported domain                              |
| CN domain identity                                     |                                               |

Note — Y=4 (Step 6), Y= 100 (Step 7)

#### SECURITY MODE FAILURE (Step 8)

The same message found in Annex A shall be transmitted by the UE on the uplink DCCH, with the exception of the following IEs:

| Information Element | Value/remark                              |
|---------------------|-------------------------------------------|
| Failure cause       |                                           |
| — Failure cause     | Incompatible simultaneous reconfiguration |

#### SECURITY MODE COMPLETE (Step 9)

| Information Element                           | Value/remark                                               |
|-----------------------------------------------|------------------------------------------------------------|
| RRC transaction identifier                    | 0                                                          |
| Integrity check info                          |                                                            |
| — Message Authentication code                 | Checked to see if present                                  |
| — RRC Message sequence number                 | Checked to see if present                                  |
| Uplink integrity protection activation info   |                                                            |
| — RRC message sequence number list            | Check to see if it the RRC SN for RB 0 to RB 4 are present |
| Radio bearer uplink ciphering activation info |                                                            |
| — RB Identity                                 | 2                                                          |
| — RLC sequence number                         | SS records this value. See step 8 in 'expected sequence'   |

##### 8.1.7.1.5 — Test requirement

After step 2 the UE shall transmit a SECURITY MODE FAILURE message to report the protocol error detected in the first SECURITY MODE COMMAND message.

After step 4 the UE shall transmit a SECURITY MODE FAILURE message to report on the invalid configuration detected in the second SECURITY MODE COMMAND message.

After step 7, UE shall transmit SECURITY MODE FAILURE to SS to indicate an error due to incompatible simultaneous reconfiguration.

After step 8 the UE shall RLC-acknowledge the receipt of the first valid SECURITY MODE COMMAND message using unciphered mode and which includes calculated integrity check info. SS checks that the SECURITY MODE COMPLETE message is received unciphered and that the calculated "integrity check info" IE is correct.

After step 9 SS verifies that all uplink signalling messages on RB2 are integrity protected with UIA1 algorithm.

After uplink ciphering activation time has lapsed, SS verifies that the UE CAPABILITY INFORMATION message received is integrity protected with UIA algorithm and ciphered with the algorithm indicated in the SECURITY MODE COMMAND (Step 6) message.

After downlink ciphering activation time has lapsed, SS shall apply ciphering to all downlink messages. At least one more cycle between step 10 and step 12 shall be repeated correctly after activation time on both directions has lapsed and the messages on both direction shall be ciphered and integrity protected.

### 8.1.7.2 Security mode command in CELL\_FACH state

#### 8.1.7.2.1 Definition

#### 8.1.7.2.2 Conformance requirement

1. This procedure is used to trigger the stop or start of ciphering, or to command the restart of ciphering with the new ciphering configuration for the signalling radio bearers and any of radio bearers. It is also used to start integrity protection or modify integrity protection configuration for signalling radio bearers.
2. When the UE receives a SECURITY MODE COMMAND message from the UTRAN, which indicates the downlink activation time and new ciphering mode configuration, the UE shall apply the old ciphering configuration before the stated downlink activation time. It shall start to decipher using the new ciphering configuration at the downlink activation time.
3. The UE shall transmit SECURITY MODE COMPLETE message using the new integrity protection configuration stated in the received SECURITY MODE COMMAND message. The SECURITY MODE COMPLETE message shall include the ciphering uplink activation time. The UE shall start to apply the new ciphering configuration on the uplink direction, after the uplink activation time has elapsed.

#### Reference

3GPP TS 25.331 clause 8.1.12.

#### 8.1.7.2.3 Test purpose

To confirm that after the UE receives a SECURITY MODE COMMAND message, it transmits a SECURITY MODE COMPLETE message to the UTRAN using the old ciphering configuration together with the application of the new integrity protection configuration. To confirm that the UE applies the old ciphering configuration in the downlink prior to the activation time; and uses the new ciphering configuration on and after the activation time. To confirm that the UE starts to cipher its uplink transmissions after the uplink activation time stated in SECURITY MODE COMPLETE message is reached. To confirm that UE send SECURITY MODE FAILURE message when UE receives an invalid SECURITY MODE COMMAND message.

#### 8.1.7.2.4 Method of test

##### Initial Condition

System Simulator: 1 cell.

UE: CELL\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

### Test Procedure

The UE is in CELL\_FACH state. The SS transmits a SECURITY MODE COMMAND message which does not include any IEs except IE "Message Type". The UE shall respond by sending SECURITY MODE FAILURE message on the DCCH. Next, SS transmits a valid SECURITY MODE COMMAND message which includes IE "Downlink activation time" for RB2 and IE "Integrity check info". The UE shall check the integrity check info. It shall start to configure ciphering in downlink and transmit a SECURITY MODE COMPLETE message, which contains the uplink activation time for RB2 using the new integrity protection configuration. This message shall contain the IE "Integrity check info". SS records the uplink ciphering activation time for RB 2. Next, SS transmits UE CAPABILITY ENQUIRY message repeatedly on the downlink DCCH using RLC-AM mode. The UE shall respond to each downlink message with a UE CAPABILITY INFORMATION message on the uplink DCCH using RLC-AM. SS checks all uplink messages are integrity-protected by UIA1 algorithm, and that the messages contain the correct values for "Integrity check info" IE. This cycle repeats itself until both the uplink and downlink ciphering activation time for RB 2 have elapsed. After both the uplink and downlink ciphering activation time for RB 2 have passed, the UE shall be able to communicate with the SS using the new ciphering configurations. This can be verified in SS through the reception of a correctly ciphered and integrity-protected UE CAPABILITY INFORMATION message.

### Expected sequence

| Step | Direction |    | Message                           | Comment                                                                                                                                                                                                                     |
|------|-----------|----|-----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                   |                                                                                                                                                                                                                             |
| 1    |           |    |                                   | UE is initially in CELL_FACH state.                                                                                                                                                                                         |
| 2    |           | ←  | SECURITY MODE COMMAND             | See specific message content                                                                                                                                                                                                |
| 3    |           | →  | SECURITY MODE FAILURE             | IE "Failure Cause" shall be set to "Protocol Error" and IE "Protocol Error Information" shall be set to "ASN.1 violation or encoding error".                                                                                |
| 4    |           |    | Void                              |                                                                                                                                                                                                                             |
| 5    |           |    | Void                              |                                                                                                                                                                                                                             |
| 6    |           |    | Void                              |                                                                                                                                                                                                                             |
| 7    |           |    | Void                              |                                                                                                                                                                                                                             |
| 8    |           | ←  | SECURITY MODE COMMAND             | See specific message contents.                                                                                                                                                                                              |
| 9    |           | →  | SECURITY MODE COMPLETE            | SS verifies that this message is sent unciphered. SS records the uplink ciphering activation time for RB 2.                                                                                                                 |
| 10   |           | ←  | UE CAPABILITY ENQUIRY             | SS repeats step 10,11 and 12 until its internal uplink and downlink RLC SN have both surpassed the uplink and downlink ciphering activation time specified for RB2. This message is sent on the downlink DCCH using RLC-AM. |
| 11   |           | →  | UE CAPABILITY INFORMATION         | UE shall send this message on the uplink DCCH using RLC-AM. SS verifies that the last UE CAPABILITY INFORMATION message is both integrity-protected and ciphered correctly.                                                 |
| 12   |           | ←  | UE CAPABILITY INFORMATION CONFIRM |                                                                                                                                                                                                                             |

## Specific Message Contents

## SECURITY MODE COMMAND (Step 2)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

## SECURITY MODE COMMAND (Step 8)

See notes below for the value of Y.

| Information Element                                    | Value/remark                                  |
|--------------------------------------------------------|-----------------------------------------------|
| RRC transaction identifier                             | 0                                             |
| Integrity check info                                   |                                               |
| — Message authentication code                          | Calculated result in SS                       |
| — RRC Message sequence number                          | 0                                             |
| Security Capability                                    |                                               |
| — Ciphering algorithm capability                       |                                               |
| — UEA0                                                 | TRUE                                          |
| — UEA1                                                 | TRUE                                          |
| — Spare                                                | FALSE                                         |
| — Integrity protection algorithm capability            |                                               |
| — UIA1                                                 | TRUE                                          |
| — Spare                                                | FALSE                                         |
| Ciphering mode info                                    |                                               |
| — Ciphering mode command                               | Start/restart                                 |
| — Ciphering algorithm                                  | Use one of the supported ciphering algorithms |
| — Activation time for DPCH                             | Not Present                                   |
| — Radio bearer downlink ciphering activation time info |                                               |
| — RB Identity                                          | 2                                             |
| — RLC sequence number                                  | Current RLC SN + 4                            |
| Integrity protection mode info                         |                                               |
| — Integrity protection mode command                    | Start                                         |
| — Downlink integrity protection activation info        | Not Present                                   |
| — Integrity protection algorithm                       | UIA1                                          |
|                                                        | 0000-0000-0000-0000-H (FRESH)                 |
| — Integrity protection initialisation number           | Supported domain                              |
| CN domain identity                                     |                                               |

## SECURITY MODE COMPLETE (Step 9)

| Information Element                           | Value/remark                                               |
|-----------------------------------------------|------------------------------------------------------------|
| RRC transaction identifier                    | 0                                                          |
| Integrity check info                          |                                                            |
| — Message Authentication code                 | Checked to see if present                                  |
| — RRC Message sequence number                 | Checked to see if present                                  |
| Uplink integrity protection activation info   |                                                            |
| — RRC message sequence number list            | Check to see if it the RRC SN for RB 0 to RB 4 are present |
| Radio bearer uplink ciphering activation info |                                                            |
| — RB Identity                                 | 2                                                          |
| — RLC sequence number                         | SS records this value. See step 8 in 'expected sequence'   |

## 8.1.7.2.5 — Test requirement

After step 2 the UE shall transmit a SECURITY MODE FAILURE message to report the protocol error detected in the first SECURITY MODE COMMAND message.

After step 8 the UE shall RLC acknowledge the receipt of the SECURITY MODE COMMAND message using unciphered mode and which includes calculated integrity check info. SS checks that the SECURITY MODE

COMPLETE message is received unciphered and that the calculated MAC-I values in "integrity check info" IE is correct.

After step 9 SS verifies that all uplink signalling messages on RB2 are integrity protected with UIA1 algorithm.

After uplink ciphering activation time has lapsed, SS verifies that the UE CAPABILITY INFORMATION message received is integrity protected with UIA algorithm and ciphered with the algorithm indicated in the SECURITY MODE COMMAND (Step 8) message.

After downlink ciphering activation time has lapsed, SS shall apply ciphering to all downlink messages. At least one more cycle between step 10 and step 12 shall be repeated correctly after activation time on both directions has lapsed and the messages on both directions shall be ciphered and integrity protected.

## 8.1.8 Counter check

### 8.1.8.1 Counter check in CELL\_DCH state

#### 8.1.8.1.1 Definition

#### 8.1.8.1.2 Conformance requirement

When the UE receives a COUNTER CHECK message that includes matched COUNT-C MSB values, the UE shall transmit a COUNTER CHECK RESPONSE message on the uplink DCCH and omitting "RB COUNT-C information" IE in this message.

When the UE receives a COUNTER CHECK message that includes any mismatched COUNT-C MSB values, the UE shall transmit a COUNTER CHECK RESPONSE message on the uplink DCCH and specifies the current COUNT-C information of the RAB(s) with mismatched values.

When the UE receives an invalid COUNTER CHECK message, the UE shall perform procedure specific error handling.

#### Reference

3GPP TS 25.331 clause 8.1.15.

#### 8.1.8.1.3 Test purpose

To confirm that the UE transmits a COUNTER CHECK RESPONSE message after it receives a COUNTER CHECK message from the SS. To confirm that the UE responds to the reception of an invalid downlink COUNTER CHECK message by transmitting a RRC STATUS message on the uplink DCCH, stating the correct error cause value in message.

#### 8.1.8.1.4 Method of test

#### Initial Condition

System Simulator: 1 cell

UE: CELL\_DCH state (state 6-10) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is brought to the CELL\_DCH state after a successful outgoing call attempt. The SS transmits an invalid COUNTER CHECK message. This message lacks all IEs except IE "Message Type". The UE shall detect a protocol error and send RRC STATUS message to report this event. Next, the SS transmits a COUNTER CHECK message that includes the current COUNT-C MSB information in each radio access bearer. The UE shall react by sending a COUNTER CHECK RESPONSE message on the uplink DCCH, which does not include "RB COUNT-C information" IE. The SS transmits a COUNTER CHECK message which includes the current COUNT-C MSB information reversed all the bits in each radio bearer. The UE shall send a COUNTER CHECK RESPONSE message on the uplink DCCH, specifying the current COUNT-C information for each radio access bearer established. The SS transmits a COUNTER

CHECK message which includes a different radio bearer. The UE shall send a COUNTER CHECK RESPONSE message on the uplink DCCH, specifying the current COUNT-C information for each radio access bearer established.

#### Expected sequence

| Step | Direction |    | Message                | Comment                                                                                       |
|------|-----------|----|------------------------|-----------------------------------------------------------------------------------------------|
|      | UE        | SS |                        |                                                                                               |
| 1    |           |    |                        | The UE is brought to CELL_DCH state after an outgoing call has been established successfully. |
| 2    |           | ←  | COUNTER CHECK          | See specific message contents for this message                                                |
| 3    |           | →  | RRC STATUS             | UE shall detect a protocol error and then transmit this message.                              |
| 4    |           | ←  | COUNTER CHECK          | See specific message content.                                                                 |
| 5    |           | →  | COUNTER CHECK RESPONSE | The message shall not include the IE "RB COUNT-C information".                                |
| 6    |           | ←  | COUNTER CHECK          | See specific message content.                                                                 |
| 7    |           | →  | COUNTER CHECK RESPONSE | The message shall include the IE "RB COUNT-C information".                                    |
| 8    |           | ←  | COUNTER CHECK          | See specific message content.                                                                 |
| 9    |           | →  | COUNTER CHECK RESPONSE | The message shall include the IE "RB COUNT-C information".                                    |

#### Specific Message Contents

##### COUNTER CHECK (Step 2)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

##### RRC STATUS (Step 3)

Use the same message type found in Annex A, with the following exception.

| Information Element                                    | Value/remark                                                 |
|--------------------------------------------------------|--------------------------------------------------------------|
| Protocol Error Information<br>——— Protocol Error Cause | Checked to see if set to "ASN.1 violation or encoding error" |

##### COUNTER CHECK (Step 4)

| Information Element        | Value/remark                              |
|----------------------------|-------------------------------------------|
| Message Type               |                                           |
| RRC transaction identifier | 0                                         |
| Integrity check info       | Calculated value                          |
| RB COUNT-C MSB information |                                           |
| ——— RB identity            | 20                                        |
| ——— COUNT-C MSB uplink     | Current COUNT-C MSB for RB#20 in uplink   |
| ——— COUNT-C MSB downlink   | Current COUNT-C MSB for RB#20 in downlink |

## COUNTER CHECK RESPONSE (Step 5)

| Information Element        | Value/remark                  |
|----------------------------|-------------------------------|
| Message Type               |                               |
| RRC transaction identifier | 0                             |
| Integrity check info       | Not checked                   |
| RB COUNT-C information     | Check to if this IE is absent |

## COUNTER CHECK (Step 6)

| Information Element        | Value/remark                                                     |
|----------------------------|------------------------------------------------------------------|
| Message Type               |                                                                  |
| RRC transaction identifier | 0                                                                |
| Integrity check info       | Calculated value                                                 |
| RB COUNT-C MSB information |                                                                  |
| → RB identity              | Check to see if set to 20                                        |
| → COUNT-C MSB uplink       | Toggle all bits of the current COUNT-C MSB in uplink for RB#20   |
| → COUNT-C MSB downlink     | Toggle all bits of the current COUNT-C MSB in downlink for RB#20 |

## COUNTER CHECK RESPONSE (Step 7)

| Information Element        | Value/remark                                               |
|----------------------------|------------------------------------------------------------|
| Message Type               |                                                            |
| RRC transaction identifier | 0                                                          |
| Integrity check info       | Not checked                                                |
| RB COUNT-C information     |                                                            |
| → RB identity              | Check to see if set to 20                                  |
| → COUNT-C uplink           | Check to see if set to Current COUNT-C for RB#20 in uplink |
| → COUNT-C downlink         | Check to see if set to COUNT-C for RB#20 in downlink       |

## COUNTER CHECK (Step 8)

| Information Element        | Value/remark                                |
|----------------------------|---------------------------------------------|
| Message Type               |                                             |
| RRC transaction identifier | 0                                           |
| Integrity check info       | Calculated value                            |
| RB COUNT-C MSB information |                                             |
| → RB identity              | Check to see if set to 25                   |
| → COUNT-C MSB uplink       | Arbitrary COUNT-C MSB in uplink for RB#25   |
| → COUNT-C MSB downlink     | Arbitrary COUNT-C MSB in downlink for RB#25 |



**COUNTER CHECK RESPONSE (Step 9)**

| Information Element        | Value/remark                                                                                               |
|----------------------------|------------------------------------------------------------------------------------------------------------|
| Message Type               | 0                                                                                                          |
| RRC transaction identifier | Not checked                                                                                                |
| Integrity check info       |                                                                                                            |
| RB COUNT-C information     |                                                                                                            |
| —— RB identity             | Check to see if set to 20                                                                                  |
| —— COUNT-C uplink          | Check to see if set to Current COUNT-C for RB#20 in uplink                                                 |
| —— COUNT-C downlink        | Check to see if set to COUNT-C for RB#20 in downlink                                                       |
| —— RB identity             | Check to see if set to 25                                                                                  |
| —— COUNT-C uplink          | Check to see if COUNT-C MSB is set to COUNT-C MSB in uplink for RB#25 in step 8 and LSB is fill with '0'   |
| —— COUNT-C downlink        | Check to see if COUNT-C MSB is set to COUNT-C MSB in downlink for RB#25 in step 8 and LSB is fill with '0' |

**8.1.8.1.5 ——— Test requirement**

After step 2, the UE shall transmit a RRC STATUS message on the uplink DCCH. The protocol error cause shall be set to "ASN.1 violation or encoding error".

After step 4 the UE shall transmit a COUNTER CHECK RESPONSE message which does not includes the IE "RB COUNT-C information" to indicates that a matched comparison result is obtained.

After step 6, the UE shall transmit a COUNTER CHECK RESPONSE message which includes the IE "RB COUNT-C information" to report that a mismatch in COUNT-C value is detected in RB#20.

After step 8, the UE shall transmit a COUNTER CHECK RESPONSE message which includes the IE "RB COUNT-C information" to report that RB#25 is not found in variable ESTABLISHED\_RABS and RB#20 is not found in IE "RB COUNT-C MSB information".

**8.1.8.2 ——— Counter check in CELL\_FACH state****8.1.8.2.1 ——— Definition****8.1.8.2.2 ——— Conformance requirement**

When the UE receives a COUNTER CHECK message that includes matched COUNT-C MSB values, the UE shall transmit a COUNTER CHECK RESPONSE message on the uplink DCCH and omitting "RB COUNT-C information" IE in this message.

When the UE receives a COUNTER CHECK message that includes any mismatched COUNT-C MSB values, the UE shall transmit a COUNTER CHECK RESPONSE message on the uplink DCCH and specifies the current COUNT-C information of the RAB(s) with mismatched values.

When the UE receives an invalid COUNTER CHECK message, the UE shall perform procedure specific error handling.

**Reference**

3GPP TS 25.331 clause 8.1.15.

**8.1.8.2.3 ——— Test purpose**

To confirm that the UE transmits a COUNTER CHECK RESPONSE message after it receives a COUNTER CHECK message from the SS. To confirm that the UE responds to the reception of an invalid downlink COUNTER CHECK message by transmitting a RRC STATUS message on the uplink DCCH, stating the correct error cause value in message.

#### 8.1.8.2.4 Method of test

##### Initial Condition

System Simulator: 1 cell.

UE: CELL\_FACH state (state 6-11) as specified in clause 7.4 of TS 34.108.

##### Test Procedure

The UE is brought to the CELL\_FACH state after a successful outgoing call attempt. The SS transmits an invalid COUNTER CHECK message. This message lacks all IEs. The UE shall detect a protocol error and send RRC STATUS message to report this event. Next, the SS transmits a COUNTER CHECK message that includes the current COUNT-C MSB information in each radio access bearer. The UE shall react by sending a COUNTER CHECK RESPONSE message on the uplink DCCH, which does not include "RB COUNT-C information" IE. The SS transmits a COUNTER CHECK message, which includes the current COUNT-C MSB information for each radio bearer but with all the bits reversed. The UE shall send a COUNTER CHECK RESPONSE message on the uplink DCCH, specifying the current COUNT-C information for each radio access bearer established. The SS transmits a COUNTER CHECK message which includes a different radio bearer. The UE shall send a COUNTER CHECK RESPONSE message on the uplink DCCH, specifying the current COUNT-C information for each radio access bearer established.

##### Expected sequence

| Step | Direction |    | Message                | Comment                                                                                        |
|------|-----------|----|------------------------|------------------------------------------------------------------------------------------------|
|      | UE        | SS |                        |                                                                                                |
| 1    |           |    |                        | The UE is brought to CELL_FACH state after an outgoing call has been established successfully. |
| 2    |           | ←  | COUNTER CHECK          | See specific message contents for this message                                                 |
| 3    |           | →  | RRC STATUS             | UE shall detect a protocol error and then transmit this message.                               |
| 4    |           | ←  | COUNTER CHECK          | See specific message content.                                                                  |
| 5    |           | →  | COUNTER CHECK RESPONSE | The message shall not include the IE "RB COUNT-C information".                                 |
| 6    |           | ←  | COUNTER CHECK          | See specific message content.                                                                  |
| 7    |           | →  | COUNTER CHECK RESPONSE | The message shall include the IE "RB COUNT-C information".                                     |
| 8    |           | ←  | COUNTER CHECK          | See specific message content.                                                                  |
| 9    |           | →  | COUNTER CHECK RESPONSE | The message shall include the IE "RB COUNT-C information".                                     |

##### Specific Message Contents

##### COUNTER CHECK (Step 2)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

## RRC-STATUS (Step-3)

| Information Element                                                    | Value/remark                                           |
|------------------------------------------------------------------------|--------------------------------------------------------|
| Message Type<br>Protocol Error Information<br>——→ Protocol Error Cause | Checked to see if set to "ASN.1 violation or encoding" |

## COUNTER CHECK (Step-4)

| Information Element                                                                                                                                                       | Value/remark                                                                                                            |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier<br>Integrity check info<br>RB COUNT-C MSB information<br>——→ RB identity<br>——→ COUNT-C MSB uplink<br>——→ COUNT-C MSB downlink | 0<br>Calculated value<br><br>20<br>Current COUNT-C MSB for RB#20 in uplink<br>Current COUNT-C MSB for RB#20 in downlink |

## COUNTER CHECK RESPONSE (Step-5)

| Information Element                                                                          | Value/remark                                      |
|----------------------------------------------------------------------------------------------|---------------------------------------------------|
| Message Type<br>RRC transaction identifier<br>Integrity check info<br>RB COUNT-C information | 0<br>Not checked<br>Check to if this IE is absent |

## COUNTER CHECK (Step-6)

| Information Element                                                                                                                                                       | Value/remark                                                                                                                                                          |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier<br>Integrity check info<br>RB COUNT-C MSB information<br>——→ RB identity<br>——→ COUNT-C MSB uplink<br>——→ COUNT-C MSB downlink | 0<br>Calculated value<br><br>20<br>Toggle all bits of the current COUNT-C MSB in uplink for RB#20<br>Toggle all bits of the current COUNT-C MSB in downlink for RB#20 |

**COUNTER CHECK RESPONSE (Step 7)**

| Information Element        | Value/remark                                               |
|----------------------------|------------------------------------------------------------|
| Message Type               | 0                                                          |
| RRC transaction identifier | Not checked                                                |
| Integrity check info       |                                                            |
| RB COUNT-C information     |                                                            |
| ——→ RB identity            | Check to see if set to 20                                  |
| ——→ COUNT-C uplink         | Check to see if set to Current COUNT-C for RB#20 in uplink |
| ——→ COUNT-C downlink       | Check to see if set to COUNT-C for RB#20 in downlink       |

**COUNTER CHECK (Step 8)**

| Information Element        | Value/remark                                |
|----------------------------|---------------------------------------------|
| Message Type               | 0                                           |
| RRC transaction identifier | Calculated value                            |
| Integrity check info       |                                             |
| RB COUNT-C MSB information |                                             |
| ——→ RB identity            | Check to see if set to 25                   |
| ——→ COUNT-C MSB uplink     | Arbitrary COUNT-C MSB in uplink for RB#25   |
| ——→ COUNT-C MSB downlink   | Arbitrary COUNT-C MSB in downlink for RB#25 |

**COUNTER CHECK RESPONSE (Step 9)**

| Information Element        | Value/remark                                                                                               |
|----------------------------|------------------------------------------------------------------------------------------------------------|
| RRC transaction identifier | 0                                                                                                          |
| Integrity check info       | Not checked                                                                                                |
| RB COUNT-C information     |                                                                                                            |
| ——→ RB identity            | Check to see if set to 20                                                                                  |
| ——→ COUNT-C uplink         | Check to see if set to Current COUNT-C for RB#20 in uplink                                                 |
| ——→ COUNT-C downlink       | Check to see if set to COUNT-C for RB#20 in downlink                                                       |
| ——→ RB identity            | Check to see if set to 25                                                                                  |
| ——→ COUNT-C uplink         | Check to see if COUNT-C MSB is set to COUNT-C MSB in uplink for RB#25 in step 8 and LSB is fill with '0'   |
| ——→ COUNT-C downlink       | Check to see if COUNT-C MSB is set to COUNT-C MSB in downlink for RB#25 in step 8 and LSB is fill with '0' |

**8.1.8.2.5 ——— Test requirement**

After step 2, the UE shall transmit a RRC STATUS message on the uplink DCCH. The protocol error cause shall be set to "ASN.1 violation or encoding error".

After step 4 the UE shall transmit a COUNTER CHECK RESPONSE message which does not includes the IE "RB COUNT-C information" to indicates that a matched comparison result is obtained.

After step 6, the UE shall transmit a COUNTER CHECK RESPONSE message which includes the IE "RB COUNT-C information" to report that a mismatch in COUNT-C value is detected in RB#20.

After step 8, the UE shall transmit a COUNTER CHECK RESPONSE message which includes the IE "RB COUNT-C information" to report that RB#25 is not found in variable ESTABLISHED\_RABS and RB#20 is not found in IE "RB COUNT-C MSB information".

## 8.1.9 Signalling Connection Release Request

### 8.1.9.1 Definition

### 8.1.9.2 Conformance requirement

The UE shall initiate the signalling connection release procedure when the higher layer entities in the UE request to release one or more signalling session (one example of such case is location update failure). In this case, the UE shall transmit a SIGNALLING CONNECTION RELEASE REQUEST message, which includes the CN domain identity of the connection flow to be released.

### Reference

3GPP TS 25.331 clause 8.1.14.

### 8.1.9.3 Test purpose

To confirm that the UE transmits a SIGNALLING CONNECTION RELEASE REQUEST message after it fails to receive a response for the LOCATION UPDATING REQUEST message.

### 8.1.9.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: Switched off (state 1) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is turned on and it shall find a suitable cell to camp on. The UE shall initiate a location updating procedure. The UE shall establish an RRC connection and transmit a LOCATION UPDATING REQUEST message using the INITIAL DIRECT TRANSFER message. The SS does not respond to this message, and the UE shall send a SIGNALLING CONNECTION RELEASE REQUEST message which includes the CN domain identity with the same value as that in the INITIAL DIRECT TRANSFER message.

#### Expected sequence

| Step | Direction |    | Message                                             | Comment                                                                                  |
|------|-----------|----|-----------------------------------------------------|------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                     |                                                                                          |
| 1    |           |    |                                                     | The UE is powered on.                                                                    |
| 2    | —→        |    | RRC CONNECTION REQUEST                              | UE shall initiate the location updating procedure.                                       |
| 3    | —←        |    | RRC CONNECTION SETUP                                |                                                                                          |
| 4    |           |    |                                                     | The UE configures the layer 2 and layer 1.                                               |
| 5    | —→        |    | RRC CONNECTION SETUP COMPLETE                       |                                                                                          |
| 6    | —→        |    | INITIAL DIRECT TRANSFER (LOCATION UPDATING REQUEST) | LOCATION UPDATE REQUEST is embedded in this message transmission.                        |
| 7    |           |    |                                                     | The SS does not respond and waits until the timer for location update procedure expires. |
| 8    | —→        |    | SIGNALLING CONNECTION RELEASE REQUEST               |                                                                                          |

## Specific Message Content

## SIGNALLING CONNECTION RELEASE REQUEST (Step 8)

| Information Element | Value/remark                                                                                |
|---------------------|---------------------------------------------------------------------------------------------|
| CN domain identity  | Check to see if this value is the as same as in the uplink INITIAL DIRECT TRANSFER message. |

## 8.1.9.5 Test requirement

After step 1 the UE shall initiate the LOCATION UPDATING procedure and establish an RRC connection.

After step 7 the UE shall transmit a SIGNALLING CONNECTION RELEASE REQUEST message which includes the same CN domain identity as that found in the INITIAL DIRECT TRANSFER message.

## 8.1.10 Broadcast of system information

## 8.1.10.1 Dynamic change of segmentation, concatenation &amp; scheduling and handling of unsupported information blocks

## 8.1.10.1.1 Definition

## 8.1.10.1.2 Conformance requirement

1. The RRC layer in the UE shall perform re-assembly of segments. All segments belonging to the same master information block, scheduling block or system information block shall be assembled in ascending order with respect to the segment index. When all segments of the master information block, scheduling block or a system information block have been received, the UE shall perform decoding of the complete master information block, scheduling block or system information block.

NOTE: There are 4 segment types and 11 different SYSTEM INFORMATION messages to interpret when re-assembling segments. There are many alternative SIB position offsets and repetition rates.

2. For all system information blocks or scheduling blocks that are supported by the UE referenced in the master information block or the scheduling blocks, the UE shall perform the following actions:

.....

- read and store the IEs of that system information block;

NOTE: There are options with and without scheduling blocks.

3. For system information blocks, not supported by the UE.....

- skip reading this system information block;
- skip monitoring changes to this system information block.

4. However, to enable future introduction of new system information blocks, the UE shall also be able to receive system information blocks other than the ones indicated within the scheduling information. The UE may ignore contents of such system information block.

## Reference

3GPP TS 25.331 clause 8.1.1.1.3, 8.1.1.1.4, 8.1.1.1.5, 8.1.1.5 and 8.1.1.6.

## 8.1.10.1.4 Test Purpose

1. To verify that dynamic change of System Information is identified, new information read and used.

- ~~2. To verify that the UE can use "all" combinations of segmentation, concatenation and scheduling.~~
- ~~3. To verify that the UE can dynamically use different configurations~~
- ~~4. To verify that the UE properly uses combinations of Default and assigned values.~~

#### ~~8.1.10.1.5 Method of test~~

~~Alternate two sets of System Information and generate a call after one or the other set has been broadcasted.~~

~~One set contains a "minimum" of data and the other a "maximum". The "maximum" set contains all information blocks including one not yet defined in the R99 release. It also includes all 4 segment types and 11 different SYSTEM INFORMATION messages plus a combination of default and non-default values.~~

~~NOTE: The decoding of system information in the UE is only measurable by functional tests. A large number of functions utilize system information. An extensive test of the system information decoding thus creates a large number of functional tests, which is impractical. This test specification uses a "sample test", where only a few functions are invoked.~~

#### ~~Initial Condition~~

~~System Simulator: 2 cells~~

~~UE: Idle state (state 2 or state 3 or state 7) as specified in clause 7.4 of TS 34.108 with a CN UE identity (set to IMSI), depending on the CN domain(s) supported by the UE.~~

#### ~~Test procedure~~

- ~~a) SS broadcasts the "Minimum" system information.~~
- ~~b) RRC Connection establishment according to clause 8.1.2.1.4.~~
- ~~c) Call setup according to clause 10.1.3, procedure 1.~~
- ~~d) Disconnect call according to clause 10.1.2.6.4. UE shall enter Cell\_PCH state.~~
- ~~e) SS broadcasts the "Maximum" system information and notifies the UE as described in clause 8.1.1.5.~~
- ~~f) Call Setup according to clause 10.1.3, procedure 1.~~

#### ~~Specific message content for "Minimum" configuration~~

~~The minimum set has:~~

- ~~— "minimum" number of system information blocks~~
- ~~— no "unknown future" blocks~~
- ~~— no scheduling blocks~~
- ~~— separate FACH and PCH channels~~
- ~~— There is no SIB4. SIB3 data contains Cell 1 data with default values and Cell 2 data with assigned values, so that Cell1 shall be selected.~~

Contents of Master Information Block PLMN type is the case of GSM-MAP

| Information Element                                                   | Value/remark                                                       |
|-----------------------------------------------------------------------|--------------------------------------------------------------------|
| → MIB value tag                                                       | 1                                                                  |
| → Supported PLMN types                                                |                                                                    |
| → PLMN type                                                           | GSM-MAP                                                            |
| → PLMN identity                                                       |                                                                    |
| → MCC digit                                                           | Set to the same Mobile Country Codes stored in the test USIM card. |
| → MNC digit                                                           | Set to the same Mobile Network Codes stored in the test USIM card. |
| → ANSI-41 Core Network information                                    | Not Present                                                        |
| → References to other system information blocks and scheduling blocks |                                                                    |
| → References to other system information blocks                       |                                                                    |
| → Scheduling information                                              |                                                                    |
| → CHOICE Value tag                                                    | PLMN Value tag                                                     |
| → PLMN Value tag                                                      | 1                                                                  |
| → SEG_COUNT                                                           | 2                                                                  |
| → SIB_REP                                                             | 128                                                                |
| → SIB_POS                                                             | 10                                                                 |
| → SIB_POS offset info                                                 |                                                                    |
| → SIB_OFF                                                             | 2                                                                  |
| → SIB type SIBs only                                                  | System Information Type 1                                          |
| → Scheduling information                                              |                                                                    |
| → CHOICE Value tag                                                    | Cell Value tag                                                     |
| → Cell Value tag                                                      | 1                                                                  |
| → SEG_COUNT                                                           | 1                                                                  |
| → SIB_REP                                                             | 64                                                                 |
| → SIB_POS                                                             | 6                                                                  |
| → SIB_POS offset info                                                 | Not Present — use default                                          |
| → SIB type SIBs only                                                  | System Information Type 3                                          |
| → Scheduling information                                              |                                                                    |
| → CHOICE Value tag                                                    | Cell Value tag                                                     |
| → Cell Value tag                                                      | 1                                                                  |
| → SEG_COUNT                                                           | 3                                                                  |
| → SIB_REP                                                             | 128                                                                |
| → SIB_POS                                                             | 26                                                                 |
| → SIB_POS offset info                                                 |                                                                    |
| → SIB_OFF                                                             | 2                                                                  |
| → SIB_OFF                                                             | 2                                                                  |
| → SIB type SIBs only                                                  | System Information Type 5                                          |
| → Scheduling information                                              |                                                                    |
| → CHOICE Value tag                                                    | Cell Value tag                                                     |
| → Cell Value tag                                                      | 1                                                                  |
| → SEG_COUNT                                                           | 1                                                                  |
| → SIB_REP                                                             | 128                                                                |
| → SIB_POS                                                             | 22                                                                 |
| → SIB_POS offset info                                                 | Not Present — use default                                          |
| → SIB type SIBs only                                                  | System Information Type 7                                          |
| → Scheduling information                                              |                                                                    |
| → CHOICE Value tag                                                    | Cell Value tag                                                     |
| → Cell Value tag                                                      | 1                                                                  |
| → SEG_COUNT                                                           | 2                                                                  |
| → SIB_REP                                                             | 128                                                                |
| → SIB_POS                                                             | 58                                                                 |
| → SIB_POS offset info                                                 |                                                                    |
| → SIB_OFF                                                             | 2                                                                  |
| → SIB type SIBs only                                                  | System Information Type 11                                         |



## Contents of System Information Block type 1 (supported PLMN type is GSM-MAP)

| Information Element                                          | Value/remark                                                             |
|--------------------------------------------------------------|--------------------------------------------------------------------------|
| <del>→ CN common GSM-MAP NAS system information</del>        |                                                                          |
| <del>→ GSM-MAP NAS system information</del>                  | <del>Contains the PLMN Identity and Location Area Code</del>             |
| <del>→ MCC digit</del>                                       | <del>Set to the same Mobile Country Code stored in test USIM card.</del> |
| <del>→ MNC digit</del>                                       | <del>Set to the same Mobile Network Code stored in test USIM card.</del> |
| <del>→ Location area code</del>                              | <del>0001H</del>                                                         |
| <del>→ CN domain system information</del>                    |                                                                          |
| <del>→ CN domain identity</del>                              | <del>PS</del>                                                            |
| <del>→ CHOICE CN Type</del>                                  | <del>GSM-MAP</del>                                                       |
| <del>→ CN domain specific NAS system information</del>       |                                                                          |
| <del>→ GSM-MAP NAS system information</del>                  | <del>T.B.D</del>                                                         |
| <del>→ CN domain specific DRX cycle length coefficient</del> | <del>7</del>                                                             |
| <del>→ CN domain identity</del>                              | <del>CS</del>                                                            |
| <del>→ CHOICE CN Type</del>                                  | <del>GSM-MAP</del>                                                       |
| <del>→ CN domain specific NAS system information</del>       |                                                                          |
| <del>→ GSM-MAP NAS system information</del>                  | <del>T.B.D</del>                                                         |
| <del>→ CN domain specific DRX cycle length coefficient</del> | <del>7</del>                                                             |
| <del>→ UE Timers and constants in idle mode</del>            |                                                                          |
| <del>→ T300</del>                                            | <del>400 milliseconds</del>                                              |
| <del>→ N300</del>                                            | <del>7</del>                                                             |
| <del>→ T312</del>                                            | <del>10 seconds</del>                                                    |
| <del>→ N312</del>                                            | <del>200</del>                                                           |
| <del>→ UE Timers and constants in connected mode</del>       |                                                                          |
| <del>→ T301</del>                                            | <del>2000 milliseconds</del>                                             |
| <del>→ N301</del>                                            | <del>2</del>                                                             |
| <del>→ T302</del>                                            | <del>4000 milliseconds</del>                                             |
| <del>→ N302</del>                                            | <del>3</del>                                                             |
| <del>→ T304</del>                                            | <del>1000 milliseconds</del>                                             |
| <del>→ N304</del>                                            | <del>3</del>                                                             |
| <del>→ T305</del>                                            | <del>60 minutes</del>                                                    |
| <del>→ T307</del>                                            | <del>50 seconds</del>                                                    |
| <del>→ T308</del>                                            | <del>320 milliseconds</del>                                              |
| <del>→ T309</del>                                            | <del>8 seconds</del>                                                     |
| <del>→ T310</del>                                            | <del>320 milliseconds</del>                                              |
| <del>→ N310</del>                                            | <del>5</del>                                                             |
| <del>→ T311</del>                                            | <del>500 milliseconds</del>                                              |
| <del>→ T312</del>                                            | <del>5 seconds</del>                                                     |
| <del>→ N312</del>                                            | <del>200</del>                                                           |
| <del>→ T313</del>                                            | <del>10 seconds</del>                                                    |
| <del>→ N313</del>                                            | <del>20</del>                                                            |
| <del>→ T314</del>                                            | <del>20 seconds</del>                                                    |
| <del>→ T315</del>                                            | <del>30 seconds</del>                                                    |
| <del>→ N315</del>                                            | <del>200</del>                                                           |
| <del>→ T316</del>                                            | <del>50 seconds</del>                                                    |
| <del>→ T317</del>                                            | <del>1800 seconds</del>                                                  |

## Contents of System Information Block type 2

Not included in "Minimum" configuration

## Contents of System Information Block type 3 (FDD)

| Information Element                              | Value/remark                                                                                                                                       |
|--------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| → SIB4 indicator                                 | TRUE                                                                                                                                               |
| → Cell identity                                  | 0000-0000-0000-0000-0000-0000-0001B                                                                                                                |
| → Cell selection and re-selection info           |                                                                                                                                                    |
| → Mapping info                                   |                                                                                                                                                    |
| → Mapping List                                   |                                                                                                                                                    |
| → RAT                                            | UTRA-FDD                                                                                                                                           |
| → Mapping Function Parameter List                | 1                                                                                                                                                  |
| → Function type                                  | Linear                                                                                                                                             |
| → Map_parameter_1                                | 1                                                                                                                                                  |
| → Map_parameter_2                                | 1                                                                                                                                                  |
| → Upper_limit                                    | 1                                                                                                                                                  |
| → Cell selection_and_reselection_quality_measure | CPICH Ec/NO                                                                                                                                        |
| → CHOICE mode                                    | FDD                                                                                                                                                |
| → Sintrasearch                                   | 16 dB                                                                                                                                              |
| → Sintersearch                                   | 16 dB                                                                                                                                              |
| → SsearchHCS                                     | 10 dB                                                                                                                                              |
| → RAT List                                       | For conformance testing in Japan, this IE is omitted. For conformance testing in European countries, this IE is present with the following values. |
| → RAT identifier                                 | GSM                                                                                                                                                |
| → Ssearch,RAT                                    | -105 dB                                                                                                                                            |
| → SHCS,RAT                                       | Not Present                                                                                                                                        |
| → Slimit,SsearchRAT                              | Not Present                                                                                                                                        |
| → Qhyst1s                                        | 0 dB                                                                                                                                               |
| → Qhyst2s                                        | 0 dB                                                                                                                                               |
| → Treselections                                  | 0 seconds                                                                                                                                          |
| → HCS-Serving cell information                   |                                                                                                                                                    |
| → HCS_PRIQ                                       | 0                                                                                                                                                  |
| → QHCS                                           | 0                                                                                                                                                  |
| → TCR <sub>MAX</sub>                             | Not used                                                                                                                                           |
| → NCR                                            | Not Present                                                                                                                                        |
| → TCMAX <sub>Hyst</sub>                          | Not Present                                                                                                                                        |
| → Maximum allowed UL TX power                    | 33dBm                                                                                                                                              |
| → CHOICE mode                                    | FDD                                                                                                                                                |
| → Qqualmin                                       | -20 dB                                                                                                                                             |
| → Qrxlevmin                                      | -115 dBm                                                                                                                                           |
| → Cell Access Restriction                        |                                                                                                                                                    |
| → Cell-barred                                    | Not-barred                                                                                                                                         |
| → Cell Reserved for operator use                 | Not-reserved                                                                                                                                       |
| → Cell Reserved for SoLSA exclusive use          | Not-reserved                                                                                                                                       |
| → Access-Class-Barred0                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred1                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred2                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred3                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred4                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred5                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred6                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred7                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred8                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred9                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred10                          | Not-barred                                                                                                                                         |
| → Access-Class-Barred11                          | Not-barred                                                                                                                                         |
| → Access-Class-Barred12                          | Not-barred                                                                                                                                         |
| → Access-Class-Barred13                          | Not-barred                                                                                                                                         |
| → Access-Class-Barred14                          | Not-barred                                                                                                                                         |
| → Access-Class-Barred15                          | Not-barred                                                                                                                                         |

## Contents of System Information Block type 4 in connected mode (FDD)

Not included in "Minimum" configuration.

## Contents of System Information Block type 5 (FDD)

| Information Element                        | Value/remark                                                                           |
|--------------------------------------------|----------------------------------------------------------------------------------------|
| → SIB6 indicator                           | TRUE                                                                                   |
| → PICH Power offset                        | -5 dB                                                                                  |
| → CHOICE Mode                              | FDD                                                                                    |
| → AICH Power offset                        | 0dB                                                                                    |
| → Primary CCPCH info                       |                                                                                        |
| → TX Diversity indicator                   | FALSE                                                                                  |
| → PRACH system information list            |                                                                                        |
| → PRACH system information                 |                                                                                        |
| → PRACH info                               |                                                                                        |
| → CHOICE mode                              | FDD                                                                                    |
| → Available Signature                      | '0000-0000-1111-1111'B                                                                 |
| → Available SF                             | Reference to clause 6.10 Parameter Set                                                 |
| → Preamble scrambling code number          | 0                                                                                      |
| → Puncturing Limit                         | Reference to clause 6.10 Parameter Set                                                 |
| → Available Sub-Channel number             | '1111-1111-1111'B                                                                      |
| → Transport Channel Identity               | 15                                                                                     |
| → RACH TFCS                                |                                                                                        |
| → CHOICE Transport channel type            | Common transport channels                                                              |
| → Dynamic Transport format information     | (This IE is repeated for TFI number)                                                   |
| → RLC size                                 | Reference to clause 6.10 Parameter Set                                                 |
| → Number of TB and TTI List                | Reference to clause 6.10 Parameter Set                                                 |
| → Number of Transport blocks               | Reference to clause 6.10 Parameter Set                                                 |
| → CHOICE Mode                              | FDD                                                                                    |
| → CHOICE Logical Channel List              | ALL                                                                                    |
| → Semi-static Transport Format information |                                                                                        |
| → Transmission time interval               | Reference to clause 6.10 Parameter Set                                                 |
| → Type of channel coding                   | Reference to clause 6.10 Parameter Set                                                 |
| → Coding Rate                              | Reference to clause 6.10 Parameter Set                                                 |
| → Rate matching attribute                  | Reference to clause 6.10 Parameter Set                                                 |
| → CRC size                                 | Reference to clause 6.10 Parameter Set                                                 |
| → RACH TFCS                                | (This IE is repeated for TFC number.)                                                  |
| → Normal                                   |                                                                                        |
| → TFCI Field 1 information                 |                                                                                        |
| → CHOICE TFCS representation               | Addition                                                                               |
| → TFCS addition information                |                                                                                        |
| → CHOICE CTFC Size                         | Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. |
| → CTFC information                         | Refer to clause 6.10 Parameter Set                                                     |
| → Power offset information                 |                                                                                        |
| → CHOICE Gain Factors                      | Signalled Gain Factor                                                                  |
| → Gain factor βc                           | 0                                                                                      |
| → Gain factor βd                           | 0                                                                                      |
| → Reference TFC ID                         | Not Present                                                                            |
| → Power offset Pp-m                        | 0dB                                                                                    |
| → PRACH partitioning                       |                                                                                        |
| → Access Service Class                     |                                                                                        |
| → ASC Setting                              |                                                                                        |
| → CHOICE mode                              | FDD                                                                                    |
| → Available signature Start Index          | 0 (ASC#0)                                                                              |
| → Available signature End Index            | 7 (ASC#0)                                                                              |
| → Assigned Sub-channel Number              | '1111'B                                                                                |
| → ASC Setting                              |                                                                                        |
| → CHOICE mode                              | FDD                                                                                    |
| → Available signature Start Index          | 0 (ASC#1)                                                                              |
| → Available signature End Index            | 7 (ASC#1)                                                                              |
| → Assigned Sub-channel Number              | '1111'B                                                                                |
| → Available signature Start Index          | 0 (ASC#2)                                                                              |
| → Available signature End Index            | 7 (ASC#2)                                                                              |
| → Assigned Sub-channel Number              | '1111'B                                                                                |
| → Available signature Start Index          | 0 (ASC#3)                                                                              |
| → Available signature End Index            | 7 (ASC#3)                                                                              |
| → Assigned Sub-channel Number              | '1111'B                                                                                |
| → Available signature Start Index          | 0 (ASC#4)                                                                              |
| → Available signature End Index            | 7 (ASC#4)                                                                              |
| → Assigned Sub-channel Number              | '1111'B                                                                                |

|                                              |                                                                                        |
|----------------------------------------------|----------------------------------------------------------------------------------------|
| → Available signature Start Index            | 0 (ASC#5)                                                                              |
| → Available signature End Index              | 7 (ASC#5)                                                                              |
| → Assigned Sub-channel Number                | '1111'B                                                                                |
| → Available signature Start Index            | 0 (ASC#6)                                                                              |
| → Available signature End Index              | 7 (ASC#6)                                                                              |
| → Assigned Sub-channel Number                | '1111'B                                                                                |
| → Available signature Start Index            | 0 (ASC#7)                                                                              |
| → Available signature End Index              | 7 (ASC#7)                                                                              |
| → Assigned Sub-channel Number                | '1111'B                                                                                |
| → Persistence scaling factor                 |                                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#2)                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#3)                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#4)                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#5)                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#6)                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#7)                                                                        |
| → AC-to-ASC mapping table                    |                                                                                        |
| → AC-to-ASC mapping                          | 6 (AC0-9)                                                                              |
| → AC-to-ASC mapping                          | 5 (AC10)                                                                               |
| → AC-to-ASC mapping                          | 4 (AC11)                                                                               |
| → AC-to-ASC mapping                          | 3 (AC12)                                                                               |
| → AC-to-ASC mapping                          | 2 (AC13)                                                                               |
| → AC-to-ASC mapping                          | 1 (AC14)                                                                               |
| → AC-to-ASC mapping                          | 0 (AC15)                                                                               |
| → Primary CPICH DL TX power                  | Reference to clause 6.10 Parameter Set                                                 |
| → Constant value                             | Reference to clause 6.10 Parameter Set                                                 |
| → PRACH power offset                         |                                                                                        |
| → Power Ramp Step                            | 3dB                                                                                    |
| → Preamble Retrans Max                       | 2                                                                                      |
| → RACH transmission parameters               |                                                                                        |
| → Mmax                                       | 2                                                                                      |
| → NB01min                                    | 3 slot                                                                                 |
| → NB01max                                    | 10 slot                                                                                |
| → AICH info                                  |                                                                                        |
| → Channelisation code                        | SF-1(SF is reference to clause 6.10 Parameter Set)                                     |
| → STTD indicator                             | FALSE                                                                                  |
| → AICH transmission timing                   | 0                                                                                      |
| → Secondary CCPCH system info                |                                                                                        |
| → Secondary CCPCH info                       |                                                                                        |
| → Primary CPICH usage for channel estimation | Primary CPICH may be used                                                              |
| → Secondary CPICH info                       | Not Present                                                                            |
| → Secondary scrambling code                  | Not Present                                                                            |
| → STTD indicator                             | FALSE                                                                                  |
| → Spreading factor                           | Reference to clause 6.10 Parameter Set                                                 |
| → Code number                                | SF-1(SF is reference to clause 6.10 Parameter Set)                                     |
| → Pilot symbol existence                     | FALSE                                                                                  |
| → TFCI existence                             | TRUE                                                                                   |
| → Fixed or Flexible position                 | Flexible                                                                               |
| → Timing offset                              | 0                                                                                      |
| → TFCS                                       | (This IE is repeated for TFC number for PCH and FACH.)                                 |
| → Normal                                     |                                                                                        |
| → TFCI Field 1 information                   |                                                                                        |
| → CHOICE TFCS representation                 | Addition                                                                               |
| → TFCS addition information                  |                                                                                        |
| → CHOICE CTFC Size                           | Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. |
| → CTFC information                           | Refer to clause 6.10 Parameter Set                                                     |
| → Power offset information                   | Not Present                                                                            |
| → FACH/PCH information                       |                                                                                        |
| → Transport Channel Identity                 | 12 (for PCH)                                                                           |
| → TFS                                        | (PCH)                                                                                  |
| → CHOICE Transport channel type              | Common transport channels                                                              |
| → Dynamic Transport format information       | (This IE is repeated for TFI number.)                                                  |
| → RLC Size                                   | Reference to clause 6.10 Parameter Set                                                 |
| → Number of TB and TTI List                  | Reference to clause 6.10 Parameter Set                                                 |
| → Number of Transport blocks                 | Reference to clause 6.10 Parameter Set                                                 |
| → CHOICE Mode                                | FDD                                                                                    |
| → CHOICE Logical Channel List                | ALL                                                                                    |
| → Semi-static Transport Format information   |                                                                                        |

|                                            |                                                    |
|--------------------------------------------|----------------------------------------------------|
| → Transmission time interval               | Reference to clause 6.10 Parameter Set             |
| → Type of channel coding                   | Reference to clause 6.10 Parameter Set             |
| → Coding Rate                              | Reference to clause 6.10 Parameter Set             |
| → Rate matching attribute                  | Reference to clause 6.10 Parameter Set             |
| → CRC size                                 | Reference to clause 6.10 Parameter Set             |
| → Transport Channel Identity               | 13 (for FACH)                                      |
| → TFS                                      | (FACH)                                             |
| → CHOICE Transport channel type            | Common transport channels                          |
| → Dynamic Transport format information     | (This IE is repeated for TFI number.)              |
| → RLC Size                                 | Reference to clause 6.10 Parameter Set             |
| → Number of TB and TTI List                | Reference to clause 6.10 Parameter Set             |
| → Number of Transport blocks               | Reference to clause 6.10 Parameter Set             |
| → CHOICE Mode                              | FDD                                                |
| → CHOICE Logical Channel List              | ALL                                                |
| → Semi-static Transport Format information |                                                    |
| → Transmission time interval               | Reference to clause 6.10 Parameter Set             |
| → Type of channel coding                   | Reference to clause 6.10 Parameter Set             |
| → Coding Rate                              | Reference to clause 6.10 Parameter Set             |
| → Rate matching attribute                  | Reference to clause 6.10 Parameter Set             |
| → CRC size                                 | Reference to clause 6.10 Parameter Set             |
| → CTCH indicator                           | FALSE                                              |
| → PICH info                                |                                                    |
| → Channelisation code                      | SF-1(SF is reference to clause 6.10 Parameter Set) |
| → Number of PI per frame                   | 18                                                 |
| → STTD indicator                           | FALSE                                              |
| → CBS DRX Level 1 information              | Not Present                                        |

#### Contents of System Information Block type 6 in connected mode (FDD)

Not included in "Minimum" configuration.

#### Contents of System Information Block type 7 (FDD)

| Information Element                               | Value/remark                         |
|---------------------------------------------------|--------------------------------------|
| CHOICE Mode                                       | FDD                                  |
| → UL interference                                 | -100dBm                              |
| → PRACHs listed in system information block type5 |                                      |
| → Dynamic persistence level                       | 2                                    |
| → PRACHs listed in system information block type6 |                                      |
| → Dynamic persistence level                       | 2                                    |
| → Expiration Time Factor                          | Not Present — use default value of 1 |

#### Contents of System Information Block type 8, 9 (only for FDD)

Not included in "Minimum" configuration.

#### Contents of System Information Block type 10 (only for FDD)

Not included in "Minimum" configuration.

## Contents of System Information Block type 11 (FDD)

| Information Element                                     | Value/remark                                                                |
|---------------------------------------------------------|-----------------------------------------------------------------------------|
| → SIB12 indicator                                       | TRUE                                                                        |
| → FACH measurement occasion info                        | Not Present                                                                 |
| → Measurement control system information                |                                                                             |
| → Use of HCS                                            | Not used                                                                    |
| → Cell_selection_and_reselection_quality_measure        | CPICH RSCP                                                                  |
| → Intra-frequency measurement system information        |                                                                             |
| → Intra-frequency measurement identity                  | 0                                                                           |
| → Intra-frequency cell info list                        |                                                                             |
| → CHOICE intra-frequency cell removal                   | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                             |                                                                             |
| → Intra-frequency cell id                               | 0                                                                           |
| → Cell info                                             |                                                                             |
| → Cell individual offset                                | 0dB                                                                         |
| → Reference time difference to cell                     | Not Present                                                                 |
| → Read SFN indicator                                    | FALSE                                                                       |
| → CHOICE mode                                           | FDD                                                                         |
| → Primary CPICH info                                    |                                                                             |
| → Primary scrambling code                               | The current value plus 50(When the current cell is cell No.8 then minus 50) |
| → Primary CPICH TX power                                | Not Present                                                                 |
| → TX Diversity indicator                                | FALSE                                                                       |
| → Cell Selection and Re-selection info                  |                                                                             |
| → Qoffset1s,n                                           | 0 dB                                                                        |
| → Qoffset2s,n                                           | 0 dB                                                                        |
| → Maximum allowed UL TX power                           | 33 dBm                                                                      |
| → HCS neighbouring cell information                     | Not Present                                                                 |
| → CHOICE mode                                           | FDD                                                                         |
| → Qqualmin                                              | -20 dB                                                                      |
| → Qrxlevmin                                             | -115 dBm                                                                    |
| → Cell measurement                                      |                                                                             |
| → Intra-frequency cell id                               | See test content                                                            |
| → Intra-frequency measurement quantity                  |                                                                             |
| → Filter coefficient                                    | 0                                                                           |
| → Measurement quantity                                  | CPICH RSCP                                                                  |
| → Intra-frequency reporting quantity for RACH Reporting |                                                                             |
| → SFN-SFN observed time difference                      | No report                                                                   |
| → Reporting quantity                                    | No report                                                                   |
| → Maximum number of reported cells on RACH              |                                                                             |
| → Maximum number of reported cells                      | No report                                                                   |
| → Reporting information for state CELL_DCH              |                                                                             |
| → Intra-frequency reporting quantity                    |                                                                             |
| → Reporting quantities for active set cells             |                                                                             |
| → SFN-SFN observed time difference reporting indicator  | No report                                                                   |
| → Cell synchronisation information reporting indicator  | FALSE                                                                       |
| → Cell identity reporting indicator                     | TRUE                                                                        |
| → CHOICE mode                                           | FDD                                                                         |
| → CPICH Ec/N0 reporting indicator                       | FALSE                                                                       |
| → CPICH RSCP reporting indicator                        | TRUE                                                                        |
| → Pathloss reporting indicator                          | FALSE                                                                       |
| → Reporting quantities for monitored set cells          |                                                                             |
| → SFN-SFN observed time difference reporting indicator  | No report                                                                   |
| → Cell synchronisation information reporting indicator  | FALSE                                                                       |
| → Cell identity reporting indicator                     | TRUE                                                                        |
| → CHOICE mode                                           | FDD                                                                         |
| → CPICH Ec/N0 reporting indicator                       | FALSE                                                                       |
| → CPICH RSCP reporting indicator                        | TRUE                                                                        |
| → Pathloss reporting indicator                          | FALSE                                                                       |
| → Reporting quantities for detected set cells           | Not Present                                                                 |

|                                                              |                                                                                       |
|--------------------------------------------------------------|---------------------------------------------------------------------------------------|
| <del>→ Measurement reporting mode</del>                      | <del>Acknowledged mode RLC</del>                                                      |
| <del>→ Measurement Report Transfer Mode</del>                | <del>Event trigger</del>                                                              |
| <del>→ Periodic Reporting/Event Trigger Reporting Mode</del> |                                                                                       |
| <del>→ CHOICE report criteria</del>                          | <del>Intra-frequency measurement reporting criteria</del>                             |
| <del>→ Intra-frequency measurement reporting criteria</del>  |                                                                                       |
| <del>→ Parameters required for each event</del>              |                                                                                       |
| <del>→ Intra-frequency event identity</del>                  | <del>1a</del>                                                                         |
| <del>→ Triggering condition 1</del>                          | <del>Not Present</del>                                                                |
| <del>→ Triggering condition 2</del>                          | <del>Active set cells and monitored set cells</del>                                   |
| <del>→ Reporting Range</del>                                 | <del>5dB</del>                                                                        |
| <del>→ Cells forbidden to affect Reporting range</del>       | <del>Not Present</del>                                                                |
| <del>→ W</del>                                               | <del>1.0</del>                                                                        |
| <del>→ Hysteresis</del>                                      | <del>0.0</del>                                                                        |
| <del>→ Threshold used frequency</del>                        | <del>Not Present</del>                                                                |
| <del>→ Reporting deactivation threshold</del>                | <del>1</del>                                                                          |
| <del>→ Replacement activation threshold</del>                | <del>Not Present</del>                                                                |
| <del>→ Time to trigger</del>                                 | <del>640</del>                                                                        |
| <del>→ Amount of reporting</del>                             | <del>Infinity</del>                                                                   |
| <del>→ Reporting interval</del>                              | <del>0</del>                                                                          |
| <del>→ Reporting cell status</del>                           |                                                                                       |
| <del>→ CHOICE reported cell</del>                            | <del>Report cell within active set and/or monitored set cells on used frequency</del> |
| <del>→ Maximum number of reported cells</del>                | <del>2</del>                                                                          |
| <del>→ Inter-frequency measurement system information</del>  | <del>Not Present</del>                                                                |
| <del>→ Inter-RAT measurement system information</del>        | <del>Not Present</del>                                                                |
| <del>→ Traffic volume measurement system information</del>   | <del>Not Present</del>                                                                |
| <del>→ UE internal measurement system information</del>      | <del>Not Present</del>                                                                |

#### ~~Contents of System Information Block type 12 in connected mode (FDD)~~

~~Not included in "Minimum" configuration.~~

#### ~~Contents of System Information Block types 13, 14~~

~~Not included in "Minimum" configuration.~~

#### ~~Contents of System Information Block type 15~~

~~Not included in "Minimum" configuration.~~

#### ~~Contents of System Information Block type 16~~

~~Not included in "Minimum" configuration.~~

#### ~~Contents of System Information Block type 17~~

~~Not included in "Minimum" configuration.~~

#### ~~Contents of System Information Block type 18~~

~~Not included in "Minimum" configuration.~~

Default settings for cell No.1 (FDD):

| Information Element          | Value/remark                               |
|------------------------------|--------------------------------------------|
| Downlink input level         | Reference to clause 6.10 Parameter Set     |
| Uplink output power          | Minimum supported by the UE's power class. |
| PCCPCH/PCPICH carrier number | Reference to clause 6.10 Parameter Set     |
| Cell Channel Description     |                                            |
| ——→ Primary CPICH info       |                                            |
| ——→ Primary scrambling code  | 100                                        |

#### Cell No.2

The contents of SYSTEM INFORMATION BLOCK TYPE 1 to 16 messages for cell No.2 are identical to those of cell No.1 with the following exceptions:

| Information Element | Value/remark                        |
|---------------------|-------------------------------------|
| Cell identity       | 0000-0000-0000-0000-0000-0000-0010B |
| URA identity        | 0000-0000-0000-0001B                |

Default settings for cell No.2 (FDD):

| Information Element          | Value/remark                               |
|------------------------------|--------------------------------------------|
| Downlink input level         | Reference to clause 6.10 Parameter Set     |
| Uplink output power          | Minimum supported by the UE's power class. |
| PCCPCH/PCPICH carrier number | Reference to clause 6.10 Parameter Set     |
| Cell Channel Description     |                                            |
| ——→ Primary CPICH info       |                                            |
| ——→ Primary scrambling code  | 150                                        |

#### Cell No.3

The contents of SYSTEM INFORMATION BLOCK TYPE 1 to 16 messages for cell No.3 are identical to those of cell No.1 with the following exceptions:

| Information Element | Value/remark                        |
|---------------------|-------------------------------------|
| Cell identity       | 0000-0000-0000-0000-0000-0000-0011B |
| URA identity        | 0000-0000-0000-0010B                |

Default settings for cell No.3 (FDD):

| Information Element          | Value/remark                               |
|------------------------------|--------------------------------------------|
| Downlink input level         | Reference to clause 6.10 Parameter Set     |
| Uplink output power          | Minimum supported by the UE's power class. |
| PCCPCH/PCPICH carrier number | Reference to clause 6.10 Parameter Set     |
| Cell Channel Description     |                                            |
| ——→ Primary CPICH info       |                                            |
| ——→ Primary scrambling code  | 200                                        |

#### Cell No.4

The contents of SYSTEM INFORMATION BLOCK TYPE 1 to 16 messages for cell No.4 are identical to those of cell No.1 with the following exceptions:

| Information Element | Value/remark                        |
|---------------------|-------------------------------------|
| Cell identity       | 0000-0000-0000-0000-0000-0000-0100B |
| URA identity        | 0000-0000-0000-0010B                |



Default settings for cell No.4 (FDD):

| Information Element          | Value/remark                               |
|------------------------------|--------------------------------------------|
| Downlink input level         | Reference to clause 6.10 Parameter Set     |
| Uplink output power          | Minimum supported by the UE's power class. |
| PCCPCH/PCPICH carrier number | Reference to clause 6.10 Parameter Set     |
| Cell Channel Description     |                                            |
| ——→ Primary CPICH info       |                                            |
| ——→ Primary scrambling code  | 250                                        |

#### Cell No.5

The contents of SYSTEM INFORMATION BLOCK TYPE 1 to 16 messages for cell No.5 are identical to those of cell No.1 with the following exceptions:

| Information Element | Value/remark                        |
|---------------------|-------------------------------------|
| Cell identity       | 0000-0000-0000-0000-0000-0000-0101B |
| URA identity        | 0000-0000-0000-0011B                |

Default settings for cell No.5 (FDD):

| Information Element          | Value/remark                               |
|------------------------------|--------------------------------------------|
| Downlink input level         | Reference to clause 6.10 Parameter Set     |
| Uplink output power          | Minimum supported by the UE's power class. |
| PCCPCH/PCPICH carrier number | Reference to clause 6.10 Parameter Set     |
| Cell Channel Description     |                                            |
| ——→ Primary CPICH info       |                                            |
| ——→ Primary scrambling code  | 300                                        |

#### Cell No.6

The contents of SYSTEM INFORMATION BLOCK TYPE 1 to 16 messages for cell No.6 are identical to those of cell No.1 with the following exceptions:

| Information Element | Value/remark                        |
|---------------------|-------------------------------------|
| Cell identity       | 0000-0000-0000-0000-0000-0000-0110B |
| URA identity        | 0000-0000-0000-0011B                |

Default settings for cell No.6 (FDD):

| Information Element          | Value/remark                               |
|------------------------------|--------------------------------------------|
| Downlink input level         | Reference to clause 6.10 Parameter Set     |
| Uplink output power          | Minimum supported by the UE's power class. |
| PCCPCH/PCPICH carrier number | Reference to clause 6.10 Parameter Set     |
| Cell Channel Description     |                                            |
| ——→ Primary CPICH info       |                                            |
| ——→ Primary scrambling code  | 350                                        |

#### Cell No.7

The contents of SYSTEM INFORMATION BLOCK TYPE 1 to 16 messages for cell No.7 are identical to those of cell No.1 with the following exceptions:

| Information Element | Value/remark                        |
|---------------------|-------------------------------------|
| Cell identity       | 0000-0000-0000-0000-0000-0000-0111B |
| URA identity        | 0000-0000-0000-0100B                |

Default settings for cell No.7 (FDD):

| Information Element          | Value/remark                               |
|------------------------------|--------------------------------------------|
| Downlink input level         | Reference to clause 6.10 Parameter Set     |
| Uplink output power          | Minimum supported by the UE's power class. |
| PCCPCH/PCPICH carrier number | Reference to clause 6.10 Parameter Set     |
| Cell Channel Description     |                                            |
| — Primary CPICH info         |                                            |
| — Primary scrambling code    | 400                                        |

#### Cell No.8

The contents of SYSTEM INFORMATION BLOCK TYPE 1 to 16 messages for cell No.8 are identical to those of cell No.1 with the following exceptions:

| Information Element | Value/remark                        |
|---------------------|-------------------------------------|
| Cell identity       | 0000-0000-0000-0000-0000-0000-1000B |
| URA identity        | 0000-0000-0000-0100B                |

Default settings for cell No.8 (FDD):

| Information Element          | Value/remark                               |
|------------------------------|--------------------------------------------|
| Downlink input level         | Reference to clause 6.10 Parameter Set     |
| Uplink output power          | Minimum supported by the UE's power class. |
| PCCPCH/PCPICH carrier number | Reference to clause 6.10 Parameter Set     |
| Cell Channel Description     |                                            |
| — Primary CPICH info         |                                            |
| — Primary scrambling code    | 450                                        |

The mapping of SIB's on segments and SYSTEM INFORMATION messages shall be inserted here, but is currently FFS.

#### Specific message content for "Maximum" configuration

The maximum set has:

- "maximum" number of system information blocks
- one "unknown future" blocks
- scheduling blocks
- combined FACH and PCH channels
- SIB 3 is as in "minimum" set, but SIB4 is included with information as follows. Cell 1 has assigned values and Cell 2 default values, so that Cell2 shall be selected.

Contents of Master Information Block PLMN type is the case of GSM-MAP

| Information Element                                                   | Value/remark                                                       |
|-----------------------------------------------------------------------|--------------------------------------------------------------------|
| → MIB value tag                                                       | 1                                                                  |
| → Supported PLMN types                                                |                                                                    |
| → PLMN type                                                           | GSM-MAP                                                            |
| → PLMN identity                                                       |                                                                    |
| → MCC digit                                                           | Set to the same Mobile Country Codes stored in the test USIM card. |
| → MNC digit                                                           | Set to the same Mobile Network Codes stored in the test USIM card. |
| → ANSI-41 Core Network information                                    | Not Present                                                        |
| → References to other system information blocks and scheduling blocks |                                                                    |
| → References to other system information blocks                       |                                                                    |
| → Scheduling information                                              |                                                                    |
| → CHOICE Value tag                                                    |                                                                    |
| → Cell Value tag                                                      | 1                                                                  |
| → Scheduling                                                          |                                                                    |
| → SEG_COUNT                                                           | 2                                                                  |
| → SIB_REP                                                             | 16                                                                 |
| → SIB_POS                                                             | 2                                                                  |
| → SIB_POS offset info                                                 |                                                                    |
| → SIB_OFF                                                             | 2                                                                  |
| → SIB type                                                            | Scheduling Block 1                                                 |
| → Scheduling information                                              |                                                                    |
| → CHOICE Value tag                                                    | PLMN Value tag                                                     |
| → PLMN Value tag                                                      | 1                                                                  |
| → SEG_COUNT                                                           | 2                                                                  |
| → SIB_REP                                                             | 128                                                                |
| → SIB_POS                                                             | 10                                                                 |
| → SIB_POS offset info                                                 |                                                                    |
| → SIB_OFF                                                             | 2                                                                  |
| → SIB type SIBs only                                                  | System Information Type 1                                          |
| → Scheduling information                                              |                                                                    |
| → CHOICE Value tag                                                    | Cell Value tag                                                     |
| → Cell Value tag                                                      | 1                                                                  |
| → SEG_COUNT                                                           | 1                                                                  |
| → SIB_REP                                                             | 128                                                                |
| → SIB_POS                                                             | 14                                                                 |
| → SIB_POS offset info                                                 | Not Present — use default                                          |
| → SIB type SIBs only                                                  | System Information Type 2                                          |
| → Scheduling information                                              |                                                                    |
| → CHOICE Value tag                                                    | Cell Value tag                                                     |
| → Cell Value tag                                                      | 1                                                                  |
| → SEG_COUNT                                                           | 1                                                                  |
| → SIB_REP                                                             | 64                                                                 |
| → SIB_POS                                                             | 6                                                                  |
| → SIB_POS offset info                                                 | Not Present — use default                                          |
| → SIB type SIBs only                                                  | System Information Type 3                                          |
| → Scheduling information                                              |                                                                    |
| → CHOICE Value tag                                                    | Cell Value tag                                                     |
| → Cell Value tag                                                      | 1                                                                  |
| → SEG_COUNT                                                           | 1                                                                  |
| → SIB_REP                                                             | 64                                                                 |
| → SIB_POS                                                             | 38                                                                 |
| → SIB_POS offset info                                                 | Not Present — use default                                          |
| → SIB type SIBs only                                                  | System Information Type 4                                          |

## Contents of Scheduling Block 1 (FDD)

| Information Element                             | Value/remark               |
|-------------------------------------------------|----------------------------|
| → References to other system information blocks |                            |
| → Scheduling information                        |                            |
| → CHOICE Value tag                              | Cell Value tag             |
| → Cell Value tag                                | 1                          |
| → SEG_COUNT                                     | 3                          |
| → SIB_REP                                       | 128                        |
| → SIB_POS                                       | 26                         |
| → SIB_POS offset info                           |                            |
| → SIB_OFF                                       | 2                          |
| → SIB_OFF                                       | 2                          |
| → SIB type SIBs only                            | System Information Type 5  |
| → Scheduling information                        |                            |
| → CHOICE Value tag                              | Cell Value tag             |
| → Cell Value tag                                | 1                          |
| → SEG_COUNT                                     | 3                          |
| → SIB_REP                                       | 128                        |
| → SIB_POS                                       | 42                         |
| → SIB_POS offset info                           |                            |
| → SIB_OFF                                       | 2                          |
| → SIB_OFF                                       | 2                          |
| → SIB type SIBs only                            | System Information Type 6  |
| → Scheduling information                        |                            |
| → CHOICE Value tag                              | Cell Value tag             |
| → Cell Value tag                                | 1                          |
| → SEG_COUNT                                     | 1                          |
| → SIB_REP                                       | 128                        |
| → SIB_POS                                       | 22                         |
| → SIB_POS offset info                           | Not Present — use default  |
| → SIB type SIBs only                            | System Information Type 7  |
| → Scheduling information                        |                            |
| → CHOICE Value tag                              | Cell Value tag             |
| → Cell Value tag                                | 1                          |
| → SEG_COUNT                                     | 2                          |
| → SIB_REP                                       | 128                        |
| → SIB_POS                                       | 58                         |
| → SIB_POS offset info                           |                            |
| → SIB_OFF                                       | 2                          |
| → SIB type SIBs only                            | System Information Type 11 |
| → Scheduling information                        |                            |
| → CHOICE Value tag                              | Cell Value tag             |
| → Cell Value tag                                | 1                          |
| → SEG_COUNT                                     | 2                          |
| → SIB_REP                                       | 128                        |
| → SIB_POS                                       | 106                        |
| → SIB_POS offset info                           |                            |
| → SIB_OFF                                       | 2                          |
| → SIB type SIBs only                            | System Information Type 12 |
| → Scheduling information                        |                            |
| → CHOICE Value tag                              | Cell Value tag             |
| → Cell Value tag                                | 1                          |
| → SEG_COUNT                                     | TBD                        |
| → SIB_REP                                       | TBD                        |
| → SIB_POS                                       | TBD                        |
| → SIB_POS offset info                           |                            |
| → SIB_OFF                                       | TBD                        |
| → SIB type SIBs only                            | System Information Type 15 |
| → Scheduling information                        |                            |
| → CHOICE Value tag                              | PLMN Value tag             |
| → PLMN Value tag                                | 1                          |
| → SEG_COUNT                                     | 6                          |
| → SIB_REP                                       | 128                        |
| → SIB_POS                                       | 74                         |
| → SIB_POS offset info                           |                            |
| → SIB_OFF                                       | 2                          |

|                      |                            |
|----------------------|----------------------------|
| → SIB_OFF            | 2                          |
| → SIB_OFF            | 8                          |
| → SIB_OFF            | 4                          |
| → SIB_OFF            | 2                          |
| → SIB type SIBs only | System Information Type 16 |

#### Contents of System Information Block type 1 (supported PLMN type is GSM-MAP)

| Information Element                               | Value/remark                                                  |
|---------------------------------------------------|---------------------------------------------------------------|
| → CN common GSM-MAP NAS system information        |                                                               |
| → GSM-MAP NAS system information                  | Contains the PLMN Identity and Location Area Code             |
| → MCC digit                                       | Set to the same Mobile Country Code stored in test USIM card. |
| → MNC digit                                       | Set to the same Mobile Network Code stored in test USIM card. |
| → Location area code                              | 0001H                                                         |
| → CN domain system information                    |                                                               |
| → CN domain identity                              | PS                                                            |
| → CHOICE CN Type                                  | GSM-MAP                                                       |
| → CN domain specific NAS system information       |                                                               |
| → GSM-MAP NAS system information                  | T.B.D                                                         |
| → CN domain specific DRX cycle length coefficient | 7                                                             |
| → CN domain identity                              | CS                                                            |
| → CHOICE CN Type                                  | GSM-MAP                                                       |
| → CN domain specific NAS system information       |                                                               |
| → GSM-MAP NAS system information                  | T.B.D                                                         |
| → CN domain specific DRX cycle length coefficient | 7                                                             |
| → UE Timers and constants in idle mode            |                                                               |
| → T300                                            | 400 milliseconds                                              |
| → N300                                            | 7                                                             |
| → T312                                            | 10 seconds                                                    |
| → N312                                            | 200                                                           |
| → UE Timers and constants in connected mode       |                                                               |
| → T301                                            | 2000 milliseconds                                             |
| → N301                                            | 2                                                             |
| → T302                                            | 4000 milliseconds                                             |
| → N302                                            | 3                                                             |
| → T304                                            | 1000 milliseconds                                             |
| → N304                                            | 3                                                             |
| → T305                                            | 60 minutes                                                    |
| → T307                                            | 50 seconds                                                    |
| → T308                                            | 320 milliseconds                                              |
| → T309                                            | 8 seconds                                                     |
| → T310                                            | 320 milliseconds                                              |
| → N310                                            | 5                                                             |
| → T311                                            | 500 milliseconds                                              |
| → T312                                            | 5 seconds                                                     |
| → N312                                            | 200                                                           |
| → T313                                            | 10 seconds                                                    |
| → N313                                            | 20                                                            |
| → T314                                            | 20 seconds                                                    |
| → T315                                            | 30 seconds                                                    |
| → N315                                            | 200                                                           |
| → T316                                            | 50 seconds                                                    |
| → T317                                            | 1800 seconds                                                  |

#### Contents of System Information Block type 2

| Information Element | Value/remark                    |
|---------------------|---------------------------------|
| → URA identity list | Only 1 URA identity broadcasted |
| → URA identity      | 0000-0000-0000-0001B            |

## Contents of System Information Block type 3 (FDD)

| Information Element                              | Value/remark                                                                                                                                       |
|--------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| → SIB4 indicator                                 | TRUE                                                                                                                                               |
| → Cell identity                                  | 0000 0000 0000 0000 0000 0000 0001B                                                                                                                |
| → Cell selection and re-selection info           |                                                                                                                                                    |
| → Mapping info                                   |                                                                                                                                                    |
| → Mapping List                                   |                                                                                                                                                    |
| → RAT                                            | UTRA-FDD                                                                                                                                           |
| → Mapping Function Parameter List                | 1                                                                                                                                                  |
| → Function type                                  | Linear                                                                                                                                             |
| → Map_parameter_1                                | 1                                                                                                                                                  |
| → Map_parameter_2                                | 1                                                                                                                                                  |
| → Upper_limit                                    | 1                                                                                                                                                  |
| → Cell selection_and_reselection_quality_measure | CPICH Ec/NO                                                                                                                                        |
| → CHOICE mode                                    | FDD                                                                                                                                                |
| → Sintrasearch                                   | 16 dB                                                                                                                                              |
| → Sintersearch                                   | 16 dB                                                                                                                                              |
| → SsearchHCS                                     | 10 dB                                                                                                                                              |
| → RAT List                                       | For conformance testing in Japan, this IE is omitted. For conformance testing in European countries, this IE is present with the following values. |
| → RAT identifier                                 | GSM                                                                                                                                                |
| → Ssearch,RAT                                    | -105 dB                                                                                                                                            |
| → SHCS,RAT                                       | Not Present                                                                                                                                        |
| → Slimit,SsearchRAT                              | Not Present                                                                                                                                        |
| → Qhyst1s                                        | 0 dB                                                                                                                                               |
| → Qhyst2s                                        | 0 dB                                                                                                                                               |
| → Treselections                                  | 0 seconds                                                                                                                                          |
| → HCS-Serving cell information                   |                                                                                                                                                    |
| → HCS_PRIQ                                       | 0                                                                                                                                                  |
| → QHCS                                           | 0                                                                                                                                                  |
| → TCR <sub>MAX</sub>                             | Not used                                                                                                                                           |
| → NCR                                            | Not Present                                                                                                                                        |
| → TCMAX <sub>Hyst</sub>                          | Not Present                                                                                                                                        |
| → Maximum allowed UL TX power                    | 33dBm                                                                                                                                              |
| → CHOICE mode                                    | FDD                                                                                                                                                |
| → Qqualmin                                       | -20 dB                                                                                                                                             |
| → Qrxlevmin                                      | -115 dBm                                                                                                                                           |
| → Cell Access Restriction                        |                                                                                                                                                    |
| → Cell-barred                                    | Not-barred                                                                                                                                         |
| → Cell Reserved for operator use                 | Not-reserved                                                                                                                                       |
| → Cell Reserved for SoLSA exclusive use          | Not-reserved                                                                                                                                       |
| → Access-Class-Barred0                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred1                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred2                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred3                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred4                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred5                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred6                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred7                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred8                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred9                           | Not-barred                                                                                                                                         |
| → Access-Class-Barred10                          | Not-barred                                                                                                                                         |
| → Access-Class-Barred11                          | Not-barred                                                                                                                                         |
| → Access-Class-Barred12                          | Not-barred                                                                                                                                         |
| → Access-Class-Barred13                          | Not-barred                                                                                                                                         |
| → Access-Class-Barred14                          | Not-barred                                                                                                                                         |
| → Access-Class-Barred15                          | Not-barred                                                                                                                                         |

## Contents of System Information Block type 4 in connected mode (FDD)

| Information Element                              | Value/remark                                                                                                                                       |
|--------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| → Cell identity                                  | 0000-0000-0000-0000-0000-0000-0001B                                                                                                                |
| → Cell selection and re-selection info           |                                                                                                                                                    |
| → Mapping Info                                   |                                                                                                                                                    |
| → Mapping List                                   |                                                                                                                                                    |
| → RAT                                            | UTRA-FDD                                                                                                                                           |
| → Mapping Function Parameter List                |                                                                                                                                                    |
| → Function type                                  | Linear                                                                                                                                             |
| → Map_parameter_1                                | 1                                                                                                                                                  |
| → Map_parameter_2                                | 1                                                                                                                                                  |
| → Upper_limit                                    | 1                                                                                                                                                  |
| → Cell_selection_and_reselection_quality_measure | CPICH-RSCP                                                                                                                                         |
| → CHOICE mode                                    | FDD                                                                                                                                                |
| → Sintrasearch                                   | 16-dB                                                                                                                                              |
| → Sintersearch                                   | 16-dB                                                                                                                                              |
| → SsearchHCS                                     | 10-dB                                                                                                                                              |
| → RAT List                                       | For conformance testing in Japan, this IE is omitted. For conformance testing in European countries, this IE is present with the following values. |
| → RAT identifier                                 | GSM                                                                                                                                                |
| → Ssearch,RAT                                    | -105-dB                                                                                                                                            |
| → SHCS,RAT                                       | Not Present                                                                                                                                        |
| → Slimit,SsearchRAT                              | Not Present                                                                                                                                        |
| → Qhyst1s                                        | 0-dB                                                                                                                                               |
| → Qhyst2s                                        | 0-dB                                                                                                                                               |
| → Treselections                                  | 0 seconds                                                                                                                                          |
| → HCS Serving cell information                   |                                                                                                                                                    |
| → HCS_PRIQ                                       | 0                                                                                                                                                  |
| → QHCS                                           | 0                                                                                                                                                  |
| → TCR <sub>MAX</sub>                             | Not used                                                                                                                                           |
| → NCR                                            | Not Present                                                                                                                                        |
| → TCMAX <sub>Hyst</sub>                          | Not Present                                                                                                                                        |
| → Maximum allowed UL TX power                    | 33dBm                                                                                                                                              |
| → CHOICE mode                                    | FDD                                                                                                                                                |
| → Qqualmin                                       | -20-dB                                                                                                                                             |
| → Qrxlevmin                                      | -115-dBm                                                                                                                                           |
| → Cell Access Restriction                        |                                                                                                                                                    |
| → Cell barred                                    | Not barred                                                                                                                                         |
| → Access Class Barred                            | Not barred                                                                                                                                         |
| → Cell Reserved for operator use                 | Not reserved                                                                                                                                       |
| → Cell Reserved for SoLSA exclusive use          | Not reserved                                                                                                                                       |
| → Access Class Barred0                           | Not barred                                                                                                                                         |
| → Access Class Barred1                           | Not barred                                                                                                                                         |
| → Access Class Barred2                           | Not barred                                                                                                                                         |
| → Access Class Barred3                           | Not barred                                                                                                                                         |
| → Access Class Barred4                           | Not barred                                                                                                                                         |
| → Access Class Barred5                           | Not barred                                                                                                                                         |
| → Access Class Barred6                           | Not barred                                                                                                                                         |
| → Access Class Barred7                           | Not barred                                                                                                                                         |
| → Access Class Barred8                           | Not barred                                                                                                                                         |
| → Access Class Barred9                           | Not barred                                                                                                                                         |
| → Access Class Barred10                          | Not barred                                                                                                                                         |
| → Access Class Barred11                          | Not barred                                                                                                                                         |
| → Access Class Barred12                          | Not barred                                                                                                                                         |
| → Access Class Barred13                          | Not barred                                                                                                                                         |
| → Access Class Barred14                          | Not barred                                                                                                                                         |
| → Access Class Barred15                          | Not barred                                                                                                                                         |

## Contents of System Information Block type 5 (FDD)

| Information Element                        | Value/remark                                                                                                              |
|--------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|
| → SIB6 indicator                           | TRUE                                                                                                                      |
| → PICH Power offset                        | -5 dB                                                                                                                     |
| → CHOICE Mode                              | FDD                                                                                                                       |
| → AICH Power offset                        | 0dB                                                                                                                       |
| → Primary CCPCH info                       |                                                                                                                           |
| → TX Diversity indicator                   | FALSE                                                                                                                     |
| → PRACH system information list            |                                                                                                                           |
| → PRACH system information                 |                                                                                                                           |
| → PRACH info                               |                                                                                                                           |
| → CHOICE mode                              | FDD                                                                                                                       |
| → Available Signature                      | '0000 0000 1111 1111'B                                                                                                    |
| → Available SF                             | Reference to clause 6.10 Parameter Set                                                                                    |
| → Preamble scrambling code number          | 0                                                                                                                         |
| → Puncturing Limit                         | Reference to clause 6.10 Parameter Set                                                                                    |
| → Available Sub-Channel number             | '1111 1111 1111'B                                                                                                         |
| → Transport Channel Identity               | 15                                                                                                                        |
| → RACH TFCS                                |                                                                                                                           |
| → CHOICE Transport channel type            | Common transport channels                                                                                                 |
| → Dynamic Transport format information     | (This IE is repeated for TFI number)                                                                                      |
| → RLC size                                 | Reference to clause 6.10 Parameter Set                                                                                    |
| → Number of TB and TTI List                | Reference to clause 6.10 Parameter Set                                                                                    |
| → Number of Transport blocks               | Reference to clause 6.10 Parameter Set                                                                                    |
| → CHOICE Mode                              | FDD                                                                                                                       |
| → CHOICE Logical Channel List              | ALL                                                                                                                       |
| → Semi-static Transport Format information |                                                                                                                           |
| → Transmission time interval               | Reference to clause 6.10 Parameter Set                                                                                    |
| → Type of channel coding                   | Reference to clause 6.10 Parameter Set                                                                                    |
| → Coding Rate                              | Reference to clause 6.10 Parameter Set                                                                                    |
| → Rate matching attribute                  | Reference to clause 6.10 Parameter Set                                                                                    |
| → CRC size                                 | Reference to clause 6.10 Parameter Set                                                                                    |
| → RACH TFCS                                | (This IE is repeated for TFC number.)                                                                                     |
| → Normal                                   |                                                                                                                           |
| → TFCI Field 1 information                 |                                                                                                                           |
| → CHOICE TFCS representation               | Addition                                                                                                                  |
| → TFCS addition information                |                                                                                                                           |
| → CHOICE CTFC Size                         | Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. Refer to clause 6.10 Parameter Set |
| → CTFC information                         |                                                                                                                           |
| → Power offset information                 |                                                                                                                           |
| → CHOICE Gain Factors                      | Signalled Gain Factor                                                                                                     |
| → Gain factor βc                           | 0                                                                                                                         |
| → Gain factor βd                           | 0                                                                                                                         |
| → Reference TFC ID                         | Not Present                                                                                                               |
| → Power offset Pp-m                        | 0dB                                                                                                                       |
| → PRACH partitioning                       |                                                                                                                           |
| → Access Service Class                     |                                                                                                                           |
| → ASC Setting                              |                                                                                                                           |
| → CHOICE mode                              | FDD                                                                                                                       |
| → Available signature Start Index          | 0 (ASC#0)                                                                                                                 |
| → Available signature End Index            | 7 (ASC#0)                                                                                                                 |
| → Assigned Sub-channel Number              | '1111'B                                                                                                                   |
| → ASC Setting                              |                                                                                                                           |
| → CHOICE mode                              | FDD                                                                                                                       |
| → Available signature Start Index          | 0 (ASC#1)                                                                                                                 |
| → Available signature End Index            | 7 (ASC#1)                                                                                                                 |
| → Assigned Sub-channel Number              | '1111'B                                                                                                                   |
| → Available signature Start Index          | 0 (ASC#2)                                                                                                                 |
| → Available signature End Index            | 7 (ASC#2)                                                                                                                 |
| → Assigned Sub-channel Number              | '1111'B                                                                                                                   |
| → Available signature Start Index          | 0 (ASC#3)                                                                                                                 |
| → Available signature End Index            | 7 (ASC#3)                                                                                                                 |
| → Assigned Sub-channel Number              | '1111'B                                                                                                                   |
| → Available signature Start Index          | 0 (ASC#4)                                                                                                                 |
| → Available signature End Index            | 7 (ASC#4)                                                                                                                 |
| → Assigned Sub-channel Number              | '1111'B                                                                                                                   |



|                                              |                                                                                        |
|----------------------------------------------|----------------------------------------------------------------------------------------|
| → Available signature Start Index            | 0 (ASC#5)                                                                              |
| → Available signature End Index              | 7 (ASC#5)                                                                              |
| → Assigned Sub-channel Number                | '1111'B                                                                                |
| → Available signature Start Index            | 0 (ASC#6)                                                                              |
| → Available signature End Index              | 7 (ASC#6)                                                                              |
| → Assigned Sub-channel Number                | '1111'B                                                                                |
| → Available signature Start Index            | 0 (ASC#7)                                                                              |
| → Available signature End Index              | 7 (ASC#7)                                                                              |
| → Assigned Sub-channel Number                | '1111'B                                                                                |
| → Persistence scaling factor                 |                                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#2)                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#3)                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#4)                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#5)                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#6)                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#7)                                                                        |
| → AC-to-ASC mapping table                    |                                                                                        |
| → AC-to-ASC mapping                          | 6 (AC0-9)                                                                              |
| → AC-to-ASC mapping                          | 5 (AC10)                                                                               |
| → AC-to-ASC mapping                          | 4 (AC11)                                                                               |
| → AC-to-ASC mapping                          | 3 (AC12)                                                                               |
| → AC-to-ASC mapping                          | 2 (AC13)                                                                               |
| → AC-to-ASC mapping                          | 1 (AC14)                                                                               |
| → AC-to-ASC mapping                          | 0 (AC15)                                                                               |
| → Primary CPICH DL TX power                  | Reference to clause 6.10 Parameter Set                                                 |
| → Constant value                             | Reference to clause 6.10 Parameter Set                                                 |
| → PRACH power offset                         |                                                                                        |
| → Power Ramp Step                            | 3dB                                                                                    |
| → Preamble Retrans Max                       | 2                                                                                      |
| → RACH transmission parameters               |                                                                                        |
| → Mmax                                       | 2                                                                                      |
| → NB01min                                    | 3 slot                                                                                 |
| → NB01max                                    | 10 slot                                                                                |
| → AICH info                                  |                                                                                        |
| → Channelisation code                        | SF-1(SF is reference to clause 6.10 Parameter Set)                                     |
| → STTD indicator                             | FALSE                                                                                  |
| → AICH transmission timing                   | 0                                                                                      |
| → Secondary CCPCH system info                |                                                                                        |
| → Secondary CCPCH info                       |                                                                                        |
| → Primary CPICH usage for channel estimation | Primary CPICH may be used                                                              |
| → Secondary CPICH info                       | Not Present                                                                            |
| → Secondary scrambling code                  | Not Present                                                                            |
| → STTD indicator                             | FALSE                                                                                  |
| → Spreading factor                           | Reference to clause 6.10 Parameter Set                                                 |
| → Code number                                | SF-1(SF is reference to clause 6.10 Parameter Set)                                     |
| → Pilot symbol existence                     | FALSE                                                                                  |
| → TFCI existence                             | TRUE                                                                                   |
| → Fixed or Flexible position                 | Flexible                                                                               |
| → Timing offset                              | 0                                                                                      |
| → TFCS                                       | (This IE is repeated for TFC number for PCH and FACH.)                                 |
| → Normal                                     |                                                                                        |
| → TFCI Field 1 information                   |                                                                                        |
| → CHOICE TFCS representation                 | Addition                                                                               |
| → TFCS addition information                  |                                                                                        |
| → CHOICE CTFC Size                           | Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. |
| → CTFC information                           | Refer to clause 6.10 Parameter Set                                                     |
| → Power offset information                   | Not Present                                                                            |
| → FACH/PCH information                       |                                                                                        |
| → Transport Channel Identity                 | 12 (for PCH)                                                                           |
| → TFS                                        | (PCH)                                                                                  |
| → CHOICE Transport channel type              | Common transport channels                                                              |
| → Dynamic Transport format information       | (This IE is repeated for TFI number.)                                                  |
| → RLC Size                                   | Reference to clause 6.10 Parameter Set                                                 |
| → Number of TB and TTI List                  | Reference to clause 6.10 Parameter Set                                                 |
| → Number of Transport blocks                 | Reference to clause 6.10 Parameter Set                                                 |
| → CHOICE Mode                                | FDD                                                                                    |
| → CHOICE Logical Channel List                | ALL                                                                                    |
| → Semi-static Transport Format information   |                                                                                        |

|                                            |                                                    |
|--------------------------------------------|----------------------------------------------------|
| → Transmission time interval               | Reference to clause 6.10 Parameter Set             |
| → Type of channel coding                   | Reference to clause 6.10 Parameter Set             |
| → Coding Rate                              | Reference to clause 6.10 Parameter Set             |
| → Rate matching attribute                  | Reference to clause 6.10 Parameter Set             |
| → CRC size                                 | Reference to clause 6.10 Parameter Set             |
| → Transport Channel Identity               | 13 (for FACH)                                      |
| → TFS                                      | (FACH)                                             |
| → CHOICE Transport channel type            | Common transport channels                          |
| → Dynamic Transport format information     | (This IE is repeated for TFI number.)              |
| → RLC Size                                 | Reference to clause 6.10 Parameter Set             |
| → Number of TB and TTI List                | Reference to clause 6.10 Parameter Set             |
| → Number of Transport blocks               | Reference to clause 6.10 Parameter Set             |
| → CHOICE Mode                              | FDD                                                |
| → CHOICE Logical Channel List              | ALL                                                |
| → Semi-static Transport Format information |                                                    |
| → Transmission time interval               | Reference to clause 6.10 Parameter Set             |
| → Type of channel coding                   | Reference to clause 6.10 Parameter Set             |
| → Coding Rate                              | Reference to clause 6.10 Parameter Set             |
| → Rate matching attribute                  | Reference to clause 6.10 Parameter Set             |
| → CRC size                                 | Reference to clause 6.10 Parameter Set             |
| → CTCH indicator                           | FALSE                                              |
| → PICH info                                |                                                    |
| → Channelisation code                      | SF-1(SF is reference to clause 6.10 Parameter Set) |
| → Number of PI per frame                   | 18                                                 |
| → STTD indicator                           | FALSE                                              |
| → CBS DRX Level 1 information              | Not Present                                        |

## Contents of System Information Block type 6 in connected mode (FDD)

| Information Element                        | Value/remark                                                                           |
|--------------------------------------------|----------------------------------------------------------------------------------------|
| → PICH power offset                        | -5 dB                                                                                  |
| → CHOICE Mode                              | FDD                                                                                    |
| → AICH power offset                        | 0 dB                                                                                   |
| → CSICH Power offset                       | Not Present                                                                            |
| → Primary CCPCH info                       |                                                                                        |
| → TX Diversity indicator                   | FALSE                                                                                  |
| → PRACH system information list            |                                                                                        |
| → PRACH system information                 |                                                                                        |
| → PRACH info                               |                                                                                        |
| → CHOICE mode                              | FDD                                                                                    |
| → Available Signature                      | '0000 0000 1111 1111'B                                                                 |
| → Available SF                             | Reference to clause 6.10 Parameter Set                                                 |
| → Preamble scrambling code number          | 0                                                                                      |
| → Puncturing Limit                         | Reference to clause 6.10 Parameter Set                                                 |
| → Available Sub-Channel number             | '1111 1111 1111'B                                                                      |
| → Transport Channel Identity               | 15                                                                                     |
| → RACH TFS                                 |                                                                                        |
| → CHOICE Transport channel type            | Common transport channels                                                              |
| → Dynamic Transport format information     | (This IE is repeated for TFI number)                                                   |
| → RLC size                                 | Reference to clause 6.10 Parameter Set                                                 |
| → Number of TB and TTI List                | Reference to clause 6.10 Parameter Set                                                 |
| → Number of Transport blocks               | Reference to clause 6.10 Parameter Set                                                 |
| → CHOICE Mode                              | FDD                                                                                    |
| → CHOICE Logical Channel List              | ALL                                                                                    |
| → Semi-static Transport Format information |                                                                                        |
| → Transmission time interval               | Reference to clause 6.10 Parameter Set                                                 |
| → Type of channel coding                   | Reference to clause 6.10 Parameter Set                                                 |
| → Coding Rate                              | Reference to clause 6.10 Parameter Set                                                 |
| → Rate matching attribute                  | Reference to clause 6.10 Parameter Set                                                 |
| → CRC size                                 | Reference to clause 6.10 Parameter Set                                                 |
| → RACH TFCS                                | (This IE is repeated for TFC number.)                                                  |
| → Normal                                   |                                                                                        |
| → TFCI Field 1 information                 |                                                                                        |
| → CHOICE TFCS representation               | Addition                                                                               |
| → TFCS addition information                |                                                                                        |
| → CHOICE CTFC Size                         | Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. |
| → CTFC information                         | Refer to clause 6.10 Parameter Set                                                     |
| → Power offset information                 |                                                                                        |
| → CHOICE Gain Factors                      | Signalled Gain Factor                                                                  |
| → Gain factor βc                           | 0                                                                                      |
| → Gain factor βd                           | 0                                                                                      |
| → Reference TFC ID                         | Not Present                                                                            |
| → Power offset Pp-m                        | 0 dB                                                                                   |
| → PRACH partitioning                       |                                                                                        |
| → Access Service Class                     |                                                                                        |
| → ASC Setting                              |                                                                                        |
| → CHOICE mode                              | FDD                                                                                    |
| → Available signature Start Index          | 0 (ASC#0)                                                                              |
| → Available signature End Index            | 7 (ASC#0)                                                                              |
| → Assigned Sub-channel Number              | '1111'B                                                                                |
| → ASC Setting                              |                                                                                        |
| → CHOICE mode                              | FDD                                                                                    |
| → Available signature Start Index          | 0 (ASC#1)                                                                              |
| → Available signature End Index            | 7 (ASC#1)                                                                              |
| → Assigned Sub-channel Number              | '1111'B                                                                                |
| → ASC Setting                              |                                                                                        |
| → CHOICE mode                              | FDD                                                                                    |
| → Available signature Start Index          | 0 (ASC#2)                                                                              |
| → Available signature End Index            | 7 (ASC#2)                                                                              |
| → Assigned Sub-channel Number              | '1111'B                                                                                |
| → ASC Setting                              |                                                                                        |
| → CHOICE mode                              | FDD                                                                                    |
| → Available signature Start Index          | 0 (ASC#3)                                                                              |
| → Available signature End Index            | 7 (ASC#3)                                                                              |

|                                              |                                                                                        |
|----------------------------------------------|----------------------------------------------------------------------------------------|
| → Assigned Sub-channel Number                | '1111'B                                                                                |
| → ASC Setting                                | FDD                                                                                    |
| → CHOICE mode                                | 0 (ASC#4)                                                                              |
| → Available signature Start Index            | 7 (ASC#4)                                                                              |
| → Available signature End Index              | '1111'B                                                                                |
| → Assigned Sub-channel Number                | FDD                                                                                    |
| → ASC Setting                                | 0 (ASC#5)                                                                              |
| → CHOICE mode                                | 7 (ASC#5)                                                                              |
| → Available signature Start Index            | '1111'B                                                                                |
| → Available signature End Index              | FDD                                                                                    |
| → Assigned Sub-channel Number                | 0 (ASC#6)                                                                              |
| → ASC Setting                                | 7 (ASC#6)                                                                              |
| → CHOICE mode                                | '1111'B                                                                                |
| → Available signature Start Index            | FDD                                                                                    |
| → Available signature End Index              | 0 (ASC#7)                                                                              |
| → Assigned Sub-channel Number                | 7 (ASC#7)                                                                              |
| → Persistence scaling factor                 | '1111'B                                                                                |
| → Persistence scaling factor                 | 0.9 (for ASC#2)                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#3)                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#4)                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#5)                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#6)                                                                        |
| → Persistence scaling factor                 | 0.9 (for ASC#7)                                                                        |
| → AC-to-ASC mapping                          | Not Present                                                                            |
| → Primary CPICH DL TX power                  | Reference to clause 6.10 Parameter Set                                                 |
| → Constant value                             | Reference to clause 6.10 Parameter Set                                                 |
| → PRACH power offset                         | 3dB                                                                                    |
| → Power Ramp Step                            | 2                                                                                      |
| → Preamble Retrans Max                       | 2                                                                                      |
| → RACH transmission parameters               | 3 slot                                                                                 |
| → Mmax                                       | 10 slot                                                                                |
| → NB01min                                    |                                                                                        |
| → NB01max                                    |                                                                                        |
| → AICH info                                  |                                                                                        |
| → Channelisation code                        | SF-1(SF is reference to clause 6.10 Parameter Set)                                     |
| → STTD indicator                             | FALSE                                                                                  |
| → AICH transmission timing                   | 0                                                                                      |
| → Secondary CCPCH system info                |                                                                                        |
| → Secondary CCPCH info                       |                                                                                        |
| → Primary CPICH usage for channel estimation | Primary CPICH may be used                                                              |
| → Secondary CPICH info                       | Not Present                                                                            |
| → Secondary scrambling code                  | Not Present                                                                            |
| → STTD indicator                             | FALSE                                                                                  |
| → Spreading factor                           | Reference to clause 6.10 Parameter Set                                                 |
| → Code number                                | Reference to clause 6.10 Parameter Set                                                 |
| → Pilot symbol existence                     | FALSE                                                                                  |
| → TFCI existence                             | TRUE                                                                                   |
| → Fixed or Flexible position                 | Flexible                                                                               |
| → Timing offset                              | 0                                                                                      |
| → TFCS                                       | (This IE is repeated for TFC number for PCH and FACH.)                                 |
| → Normal                                     |                                                                                        |
| → TFCI Field 1 information                   |                                                                                        |
| → CHOICE TFCS representation                 | Addition                                                                               |
| → TFCS addition information                  |                                                                                        |
| → CHOICE CTFC Size                           | Number of bits used must be enough to cover all combinations of CTFC from clause 6.10. |
| → CTFC information                           | Refer to clause 6.10 Parameter Set                                                     |
| → Power offset information                   | Not Present                                                                            |
| → FACH/PCH information                       |                                                                                        |
| → Transport Channel Identity                 | 12 (for PCH)                                                                           |
| → TFS                                        | (PCH)                                                                                  |
| → CHOICE Transport channel type              | Common transport channels                                                              |
| → Dynamic Transport format information       | (This IE is repeated for TFI number.)                                                  |
| → RLC Size                                   | Reference to clause 6.10 Parameter Set                                                 |

|                                            |                                                    |
|--------------------------------------------|----------------------------------------------------|
| → Number of TB and TTI List                | Reference to clause 6.10 Parameter Set             |
| → Number of Transport blocks               | Reference to clause 6.10 Parameter Set             |
| → CHOICE Mode                              | FDD                                                |
| → CHOICE Logical Channel List              | ALL                                                |
| → Semi-static Transport Format information |                                                    |
| → Transmission time interval               | Reference to clause 6.10 Parameter Set             |
| → Type of channel coding                   | Reference to clause 6.10 Parameter Set             |
| → Coding Rate                              | Reference to clause 6.10 Parameter Set             |
| → Rate matching attribute                  | Reference to clause 6.10 Parameter Set             |
| → CRC size                                 | Reference to clause 6.10 Parameter Set             |
| → Transport Channel Identity               | 13 (for FACH)                                      |
| → TFS                                      | (FACH)                                             |
| → CHOICE Transport channel type            | Common transport channels                          |
| → Dynamic Transport format information     | (This IE is repeated for TFI number.)              |
| → RLC Size                                 | Reference to clause 6.10 Parameter Set             |
| → Number of TB and TTI List                | Reference to clause 6.10 Parameter Set             |
| → Number of Transport blocks               | Reference to clause 6.10 Parameter Set             |
| → CHOICE Mode                              | FDD                                                |
| → CHOICE Logical Channel List              | ALL                                                |
| → Semi-static Transport Format information |                                                    |
| → Transmission time interval               | Reference to clause 6.10 Parameter Set             |
| → Type of channel coding                   | Reference to clause 6.10 Parameter Set             |
| → Coding Rate                              | Reference to clause 6.10 Parameter Set             |
| → Rate matching attribute                  | Reference to clause 6.10 Parameter Set             |
| → CRC size                                 | Reference to clause 6.10 Parameter Set             |
| → CTCH indicator                           | FALSE                                              |
| → PICH info                                |                                                    |
| → Channelisation code                      | SF-1(SF is reference to clause 6.10 Parameter Set) |
| → Number of PI per frame                   | 18                                                 |
| → STTD indicator                           | FALSE                                              |
| → CBS-DRX Level 1 information              | Not Present                                        |

#### Contents of System Information Block type 7 (FDD)

| Information Element                               | Value/remark                         |
|---------------------------------------------------|--------------------------------------|
| CHOICE Mode                                       | FDD                                  |
| → UL interference                                 | -100dBm                              |
| → PRACHs listed in system information block type5 |                                      |
| → Dynamic persistence level                       | 2                                    |
| → PRACHs listed in system information block type6 |                                      |
| → Dynamic persistence level                       | 2                                    |
| → Expiration Time Factor                          | Not Present — use default value of 1 |

#### Contents of System Information Block type 8, 9 (only for FDD)

This information is used for static CPCH in the cell, so this is not present.

#### Contents of System Information Block type 10 (only for FDD)

This information is used for DRAC, so this is not present.

## Contents of System Information Block type 11 (FDD)

| Information Element                                     | Value/remark                                                                |
|---------------------------------------------------------|-----------------------------------------------------------------------------|
| → SIB12 indicator                                       | TRUE                                                                        |
| → FACH measurement occasion info                        | Not Present                                                                 |
| → Measurement control system information                |                                                                             |
| → Use of HCS                                            | Not used                                                                    |
| → Cell_selection_and_reselection_quality_measure        | CPICH RSCP                                                                  |
| → Intra-frequency measurement system information        |                                                                             |
| → Intra-frequency measurement identity                  | 0                                                                           |
| → Intra-frequency cell info list                        |                                                                             |
| → CHOICE intra-frequency cell removal                   | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                             |                                                                             |
| → Intra-frequency cell id                               | 0                                                                           |
| → Cell info                                             |                                                                             |
| → Cell individual offset                                | 0dB                                                                         |
| → Reference time difference to cell                     | Not Present                                                                 |
| → Read SFN indicator                                    | FALSE                                                                       |
| → CHOICE mode                                           | FDD                                                                         |
| → Primary CPICH info                                    |                                                                             |
| → Primary scrambling code                               | The current value plus 50(When the current cell is cell No.8 then minus 50) |
| → Primary CPICH TX power                                | Not Present                                                                 |
| → TX Diversity indicator                                | FALSE                                                                       |
| → Cell Selection and Re-selection info                  |                                                                             |
| → Qoffset1s,n                                           | 0 dB                                                                        |
| → Qoffset2s,n                                           | 0 dB                                                                        |
| → Maximum allowed UL TX power                           | 33 dBm                                                                      |
| → HCS neighbouring cell information                     | Not Present                                                                 |
| → CHOICE mode                                           | FDD                                                                         |
| → Qqualmin                                              | -20 dB                                                                      |
| → Qrxlevmin                                             | -115 dBm                                                                    |
| → Cell measurement                                      |                                                                             |
| → Intra-frequency cell id                               | See test content                                                            |
| → Intra-frequency measurement quantity                  |                                                                             |
| → Filter coefficient                                    | 0                                                                           |
| → Measurement quantity                                  | CPICH RSCP                                                                  |
| → Intra-frequency reporting quantity for RACH Reporting |                                                                             |
| → SFN-SFN observed time difference                      | No report                                                                   |
| → Reporting quantity                                    | No report                                                                   |
| → Maximum number of reported cells on RACH              |                                                                             |
| → Maximum number of reported cells                      | No report                                                                   |
| → Reporting information for state CELL_DCH              |                                                                             |
| → Intra-frequency reporting quantity                    |                                                                             |
| → Reporting quantities for active set cells             |                                                                             |
| → SFN-SFN observed time difference reporting indicator  | No report                                                                   |
| → Cell synchronisation information reporting indicator  | FALSE                                                                       |
| → Cell identity reporting indicator                     | TRUE                                                                        |
| → CHOICE mode                                           | FDD                                                                         |
| → CPICH Ec/N0 reporting indicator                       | FALSE                                                                       |
| → CPICH RSCP reporting indicator                        | TRUE                                                                        |
| → Pathloss reporting indicator                          | FALSE                                                                       |
| → Reporting quantities for monitored set cells          |                                                                             |
| → SFN-SFN observed time difference reporting indicator  | No report                                                                   |
| → Cell synchronisation information reporting indicator  | FALSE                                                                       |
| → Cell identity reporting indicator                     | TRUE                                                                        |
| → CHOICE mode                                           | FDD                                                                         |
| → CPICH Ec/N0 reporting indicator                       | FALSE                                                                       |
| → CPICH RSCP reporting indicator                        | TRUE                                                                        |
| → Pathloss reporting indicator                          | FALSE                                                                       |
| → Reporting quantities for detected set cells           | Not Present                                                                 |

|                                                   |                                                                            |
|---------------------------------------------------|----------------------------------------------------------------------------|
| → Measurement reporting mode                      | Acknowledged mode RLC                                                      |
| → Measurement Report Transfer Mode                | Event trigger                                                              |
| → Periodic Reporting/Event Trigger Reporting Mode |                                                                            |
| → CHOICE report criteria                          | Intra-frequency measurement reporting criteria                             |
| → Intra-frequency measurement reporting criteria  |                                                                            |
| → Parameters required for each event              |                                                                            |
| → Intra-frequency event identity                  | 1a                                                                         |
| → Triggering condition 1                          | Not Present                                                                |
| → Triggering condition 2                          | Active set cells and monitored set cells                                   |
| → Reporting Range                                 | 5dB                                                                        |
| → Cells forbidden to affect Reporting range       | Not Present                                                                |
| → W                                               | 1.0                                                                        |
| → Hysteresis                                      | 0.0                                                                        |
| → Threshold used frequency                        | Not Present                                                                |
| → Reporting deactivation threshold                | 1                                                                          |
| → Replacement activation threshold                | Not Present                                                                |
| → Time to trigger                                 | 640                                                                        |
| → Amount of reporting                             | Infinity                                                                   |
| → Reporting interval                              | 0                                                                          |
| → Reporting cell status                           |                                                                            |
| → CHOICE reported cell                            | Report cell within active set and/or monitored set cells on used frequency |
| → Maximum number of reported cells                | 2                                                                          |
| → Inter-frequency measurement system information  | Not Present                                                                |
| → Inter-RAT measurement system information        | Not Present                                                                |
| → Traffic volume measurement system information   | Not Present                                                                |
| → UE internal measurement system information      | Not Present                                                                |

## Contents of System Information Block type 12 in connected mode (FDD)

| Information Element                                     | Value/remark                                                                |
|---------------------------------------------------------|-----------------------------------------------------------------------------|
| → FACH measurement occasion info                        | Not Present                                                                 |
| → Measurement control system information                |                                                                             |
| → Use of HCS                                            | Not used                                                                    |
| → Cell_selection_and_reselection_quality_measure        | CPICH RSCP                                                                  |
| → Intra-frequency measurement system information        |                                                                             |
| → Intra-frequency measurement identity                  | 0                                                                           |
| → Intra-frequency cell info list                        |                                                                             |
| → CHOICE intra-frequency cell removal                   | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                             |                                                                             |
| → Intra-frequency cell id                               | 0                                                                           |
| → Cell info                                             |                                                                             |
| → Cell individual offset                                | 0dB                                                                         |
| → Reference time difference to cell                     | Not Present                                                                 |
| → Read SFN indicator                                    | FALSE                                                                       |
| → CHOICE mode                                           | FDD                                                                         |
| → Primary CPICH info                                    |                                                                             |
| → Primary scrambling code                               | The current value plus 50(When the current cell is cell No.8 then minus 50) |
| → Primary CPICH TX power                                | Not Present                                                                 |
| → Read SFN indicator                                    | TRUE                                                                        |
| → TX Diversity indicator                                | FALSE                                                                       |
| → Cell Selection and Re-selection info                  |                                                                             |
| → Qoffset1 <sub>s,n</sub>                               | 0 dB                                                                        |
| → Qoffset2 <sub>s,n</sub>                               | 0 dB                                                                        |
| → Maximum allowed UL TX power                           | 33dBm                                                                       |
| → HCS neighbouring cell information                     | Not Present                                                                 |
| → CHOICE mode                                           | FDD                                                                         |
| → Qqualmin                                              | -20 dB                                                                      |
| → Qrxlevmin                                             | -115 dBm                                                                    |
| → Cell measurement                                      |                                                                             |
| → Intra-frequency cell id                               | See test contact                                                            |
| → Intra-frequency measurement quantity                  |                                                                             |
| → Filter coefficient                                    | 0                                                                           |
| → Measurement quantity                                  | CPICH RSCP                                                                  |
| → Intra-frequency reporting quantity for RACH Reporting |                                                                             |
| → SFN-SFN observed time difference                      | No report                                                                   |
| → Reporting quantity                                    | No report                                                                   |
| → Maximum number of reported cells on RACH              |                                                                             |
| → Maximum number of reported cells                      | No report                                                                   |
| → Reporting information for state CELL_DCH              |                                                                             |
| → Intra-frequency reporting quantity                    |                                                                             |
| → Reporting quantities for active set cells             |                                                                             |
| → SFN-SFN observed time difference reporting indicator  | No report                                                                   |
| → Cell synchronisation information reporting indicator  | FALSE                                                                       |
| → Cell identity reporting indicator                     | TRUE                                                                        |
| → CHOICE mode                                           | FDD                                                                         |
| → CPICH Ec/N0 reporting indicator                       | FALSE                                                                       |
| → CPICH RSCP reporting indicator                        | TRUE                                                                        |
| → Pathloss reporting indicator                          | FALSE                                                                       |
| → Reporting quantities for monitored set cells          |                                                                             |
| → SFN-SFN observed time difference reporting indicator  | No report                                                                   |
| → Cell identity reporting indicator                     | TRUE                                                                        |
| → CHOICE mode                                           | FDD                                                                         |
| → CPICH Ec/N0 reporting indicator                       | FALSE                                                                       |
| → CPICH RSCP reporting indicator                        | TRUE                                                                        |
| → Pathloss reporting indicator                          | FALSE                                                                       |
| → Reporting quantities for detected set cells           | Not Present                                                                 |
| → Measurement reporting mode                            |                                                                             |
| → Measurement Report Transfer Mode                      | Acknowledged mode RLC                                                       |



|                                                   |                                                                            |
|---------------------------------------------------|----------------------------------------------------------------------------|
| → Periodic Reporting/Event Trigger Reporting Mode | Event trigger                                                              |
| → CHOICE report criteria                          | Intra-frequency measurement reporting criteria                             |
| → Intra-frequency measurement reporting criteria  |                                                                            |
| → Parameters required for each event              |                                                                            |
| → Intra-frequency event identity                  | 1a                                                                         |
| → Triggering condition 1                          | Not Present                                                                |
| → Triggering condition 2                          | Active set cells and monitored set cells                                   |
| → Reporting Range                                 | 5dB                                                                        |
| → Cells forbidden to affect reporting range       | Not Present                                                                |
| → W                                               | 1.0                                                                        |
| → Hysteresis                                      | 0.0                                                                        |
| → Threshold used frequency                        | Not Present                                                                |
| → Reporting deactivation threshold                | 1                                                                          |
| → Replacement activation threshold                | Not Present                                                                |
| → Time to trigger                                 | 0                                                                          |
| → Amount of reporting                             | Infinity                                                                   |
| → Reporting interval                              | 0                                                                          |
| → Reporting cell status                           |                                                                            |
| → CHOICE reported cell                            | Report cell Within active set and/or monitored set cells on used frequency |
| → Maximum number of reported cells                | 2                                                                          |
| → Inter-frequency measurement system information  | Not Present                                                                |
| → Inter-RAT measurement system information        | Not Present                                                                |
| → Traffic volume measurement system information   | Not Present                                                                |
| → UE internal measurement system information      | Not Present                                                                |

#### Contents of System Information Block type 15

| Information Element         | Value/remark |
|-----------------------------|--------------|
| → Reference Position        |              |
| → Latitude sign             | [FFS]        |
| → Degrees Of Latitude       | [FFS]        |
| → Degrees Of Longitude      | [FFS]        |
| → Altitude Direction        | [FFS]        |
| → Altitude                  | [FFS]        |
| → Uncertainty semi-major    | [FFS]        |
| → Uncertainty semi-minor    | [FFS]        |
| → Orientation of major axis | [FFS]        |
| → Uncertainty Altitude      | [FFS]        |
| → Confidence                | [FFS]        |
| → GPS Reference Time        |              |
| → GPS Week                  | [FFS]        |
| → GPS TOW msec              | [FFS]        |

#### Contents of System Information Block type 16

| Information Element             | Value/remark |
|---------------------------------|--------------|
| → Re-establishment timer        | [FFS]        |
| → Predefined RB configuration   | [FFS]        |
| → Predefined TrCh configuration | [FFS]        |
| → Predefined Phy configuration  | [FFS]        |

## Contents of System Information Block type 18

| Information Element                 | Value/remark                              |
|-------------------------------------|-------------------------------------------|
| Idle mode PLMN identities           |                                           |
| PLMNs of intra-frequency cells list |                                           |
| PLMN identity                       | Set to the same value as indicated in MIB |
| PLMNs of inter-frequency cells list | Not present                               |
| PLMNs of inter-RAT cells list       | Not present                               |
| Connected mode PLMN identities      | Not present                               |

## Default settings for cell No.1 (FDD):

| Information Element          | Value/remark                               |
|------------------------------|--------------------------------------------|
| Downlink input level         | Reference to clause 6.10 Parameter Set     |
| Uplink output power          | Minimum supported by the UE's power class. |
| PCCPCH/PCPICH carrier number | Reference to clause 6.10 Parameter Set     |
| Cell Channel Description     |                                            |
| Primary CPICH info           |                                            |
| Primary scrambling code      | 100                                        |

## Cell No.2

The contents of SYSTEM INFORMATION BLOCK TYPE 1 to 16 messages for cell No.2 are identical to those of cell No.1 with the following exceptions:

| Information Element | Value/remark                        |
|---------------------|-------------------------------------|
| Cell identity       | 0000-0000-0000-0000-0000-0000-0010B |
| URA identity        | 0000-0000-0000-0001B                |

## Default settings for cell No.2 (FDD):

| Information Element          | Value/remark                               |
|------------------------------|--------------------------------------------|
| Downlink input level         | Reference to clause 6.10 Parameter Set     |
| Uplink output power          | Minimum supported by the UE's power class. |
| PCCPCH/PCPICH carrier number | Reference to clause 6.10 Parameter Set     |
| Cell Channel Description     |                                            |
| Primary CPICH info           |                                            |
| Primary scrambling code      | 150                                        |

## Cell No.3

The contents of SYSTEM INFORMATION BLOCK TYPE 1 to 16 messages for cell No.3 are identical to those of cell No.1 with the following exceptions:

| Information Element | Value/remark                        |
|---------------------|-------------------------------------|
| Cell identity       | 0000-0000-0000-0000-0000-0000-0011B |
| URA identity        | 0000-0000-0000-0010B                |

## Default settings for cell No.3 (FDD):

| Information Element          | Value/remark                               |
|------------------------------|--------------------------------------------|
| Downlink input level         | Reference to clause 6.10 Parameter Set     |
| Uplink output power          | Minimum supported by the UE's power class. |
| PCCPCH/PCPICH carrier number | Reference to clause 6.10 Parameter Set     |
| Cell Channel Description     |                                            |
| Primary CPICH info           |                                            |
| Primary scrambling code      | 200                                        |

## Cell No.4

The contents of SYSTEM INFORMATION BLOCK TYPE 1 to 16 messages for cell No.4 are identical to those of cell No.1 with the following exceptions:

| Information Element | Value/remark                        |
|---------------------|-------------------------------------|
| Cell identity       | 0000-0000-0000-0000-0000-0000-0100B |
| URA identity        | 0000-0000-0000-0010B                |

Default settings for cell No.4 (FDD):

| Information Element          | Value/remark                               |
|------------------------------|--------------------------------------------|
| Downlink input level         | Reference to clause 6.10 Parameter Set     |
| Uplink output power          | Minimum supported by the UE's power class. |
| PCCPCH/PCPICH carrier number | Reference to clause 6.10 Parameter Set     |
| Cell Channel Description     |                                            |
| → Primary CPICH info         |                                            |
| → Primary scrambling code    | 250                                        |

## Cell No.5

The contents of SYSTEM INFORMATION BLOCK TYPE 1 to 16 messages for cell No.5 are identical to those of cell No.1 with the following exceptions:

| Information Element | Value/remark                        |
|---------------------|-------------------------------------|
| Cell identity       | 0000-0000-0000-0000-0000-0000-0101B |
| URA identity        | 0000-0000-0000-0011B                |

Default settings for cell No.5 (FDD):

| Information Element          | Value/remark                               |
|------------------------------|--------------------------------------------|
| Downlink input level         | Reference to clause 6.10 Parameter Set     |
| Uplink output power          | Minimum supported by the UE's power class. |
| PCCPCH/PCPICH carrier number | Reference to clause 6.10 Parameter Set     |
| Cell Channel Description     |                                            |
| → Primary CPICH info         |                                            |
| → Primary scrambling code    | 300                                        |

## Cell No.6

The contents of SYSTEM INFORMATION BLOCK TYPE 1 to 16 messages for cell No.6 are identical to those of cell No.1 with the following exceptions:

| Information Element | Value/remark                        |
|---------------------|-------------------------------------|
| Cell identity       | 0000-0000-0000-0000-0000-0000-0110B |
| URA identity        | 0000-0000-0000-0011B                |

Default settings for cell No.6 (FDD):

| Information Element          | Value/remark                               |
|------------------------------|--------------------------------------------|
| Downlink input level         | Reference to clause 6.10 Parameter Set     |
| Uplink output power          | Minimum supported by the UE's power class. |
| PCCPCH/PCPICH carrier number | Reference to clause 6.10 Parameter Set     |
| Cell Channel Description     |                                            |
| → Primary CPICH info         |                                            |
| → Primary scrambling code    | 350                                        |

## Cell No.7

The contents of SYSTEM INFORMATION BLOCK TYPE 1 to 16 messages for cell No.7 are identical to those of cell No.1 with the following exceptions:

| Information Element | Value/remark                        |
|---------------------|-------------------------------------|
| Cell identity       | 0000-0000-0000-0000-0000-0000-0111B |
| URA identity        | 0000-0000-0000-0100B                |

Default settings for cell No.7 (FDD):

| Information Element          | Value/remark                               |
|------------------------------|--------------------------------------------|
| Downlink input level         | Reference to clause 6.10 Parameter Set     |
| Uplink output power          | Minimum supported by the UE's power class. |
| PCCPCH/PCPICH carrier number | Reference to clause 6.10 Parameter Set     |
| Cell Channel Description     |                                            |
| ——→ Primary CPICH info       |                                            |
| ——→ Primary scrambling code  | 400                                        |

## Cell No.8

The contents of SYSTEM INFORMATION BLOCK TYPE 1 to 16 messages for cell No.8 are identical to those of cell No.1 with the following exceptions:

| Information Element | Value/remark                        |
|---------------------|-------------------------------------|
| Cell identity       | 0000-0000-0000-0000-0000-0000-1000B |
| URA identity        | 0000-0000-0000-0100B                |

Default settings for cell No.8 (FDD):

| Information Element          | Value/remark                               |
|------------------------------|--------------------------------------------|
| Downlink input level         | Reference to clause 6.10 Parameter Set     |
| Uplink output power          | Minimum supported by the UE's power class. |
| PCCPCH/PCPICH carrier number | Reference to clause 6.10 Parameter Set     |
| Cell Channel Description     |                                            |
| ——→ Primary CPICH info       |                                            |
| ——→ Primary scrambling code  | 450                                        |

The mapping of system information blocks on segments and SYSTEM INFORMATION messages are FFS.

## 8.1.10.1.6 ————— Test requirement

After step 3 the UE shall be in Connected state U10 in Cell 1.

After step 6 the UE shall be in Connected state U10 in Cell 2.

## 8.2 Radio Bearer control procedure

### 8.2.1 Radio Bearer Establishment

#### 8.2.1.1 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_DCH: Success

##### 8.2.1.1.1 Definition

##### 8.2.1.1.2 Conformance requirement

The UE shall correctly set up a new radio bearer according to a RADIO BEARER SETUP message and responds with a RADIO BEARER SETUP COMPLETE message on the DCCH using AM RLC.

##### Reference

3GPP TS 25.331 clause 8.2.1.

##### 8.2.1.1.3 Test purpose

To confirm that the UE establishes a new radio bearer according to a RADIO BEARER SETUP message.

##### 8.2.1.1.4 Method of test

##### Initial Condition

System Simulator: 1 cell

UE: CS\_DCCH\_DCH (state 6-5) or PS\_DCCH\_DCH (state 6-7) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

##### Test Procedure

The UE is in CELL\_DCH state, after the test operator is prompted to make an out-going call. Before step 1, only signalling radio bearers have been established. The SS transmits a RADIO BEARER SETUP message to the UE. This message requests the establishment of radio access bearer. After the UE receives this message, it configures them and establishes a radio access bearer. Finally the UE transmits a RADIO BEARER SETUP COMPLETE message using AM RLC.

##### Expected sequence

| Step | Direction |    | Message                     | Comment                                                                                    |
|------|-----------|----|-----------------------------|--------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                            |
| 1    |           | ←  | RADIO BEARER SETUP          | This message do not contain IE "integrity check info" and "integrity protection mode info" |
| 2    |           | →  | RADIO BEARER SETUP COMPLETE | This message do not contain "integrity check info" and "Uplink integrity activation info"  |
|      |           |    |                             |                                                                                            |

##### Specific Message Contents

None.

8.2.1.1.5 ~~Test requirement~~

~~After step 1 the UE shall transmit a RADIO BEARER SETUP COMPLETE message.~~

8.2.1.2 ~~Void~~

8.2.1.3 ~~Radio Bearer Establishment for transition from CELL\_DCH to CELL\_DCH:  
Failure (Unsupported configuration)~~

8.2.1.3.1 ~~Definition~~

8.2.1.3.2 ~~Conformance requirement~~

~~The UE shall keep its current configuration when the UE receives a RADIO BEARER SETUP message which includes unsupported configuration parameters and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "configuration unsupported" in IE "failure cause".~~

Reference

3GPP TS 25.331 clause 8.2.1.

8.2.1.3.3 ~~Test purpose~~

~~To confirm that the UE keeps its configuration and transmits a RADIO BEARER SETUP FAILURE message in case of receiving a RADIO BEARER SETUP message which includes parameters of its unsupported configuration.~~

8.2.1.3.4 ~~Method of test~~

Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH\_DCH (state 6-5) or PS-DCCH\_DCH (state 6-7) as specified in clause 7.4 of TS 34.108, depending on the domain(s) supported by the UE.

Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER SETUP message in which the frequency cannot be supported by the UE. After the UE receives this message, it transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "configuration unsupported" in IE "failure cause".

Expected sequence

| Step | Direction |    | Message                    | Comment                                             |
|------|-----------|----|----------------------------|-----------------------------------------------------|
|      | UE        | SS |                            |                                                     |
| 1    | ←         |    | RADIO BEARER SETUP         | Including the unsupported configuration for the UE. |
| 2    | →         |    | RADIO BEARER SETUP FAILURE | The UE does not change the configuration.           |

Specific Message Contents

RADIO BEARER SETUP

The contents of RADIO BEARER SETUP message in this test case is indicated as "Non-speech in CS" as found in Annex A or the RADIO BEARER SETUP message as found in clause 9 of TS 34.108 with the following exceptions:

**RADIO BEARER SETUP (FDD)**

| Information Element   | Value/remark |
|-----------------------|--------------|
| Frequency info        |              |
| —CHOICE mode          | FDD          |
| —UARFCN uplink (Nu)   | 0            |
| —UARFCN downlink (Nd) | 950          |

**RADIO BEARER SETUP (TDD)**

| Information Element | Value/remark |
|---------------------|--------------|
| Frequency info      |              |
| —CHOICE mode        | TDD          |
| —UARFCN (Nt)        | 0            |

**RADIO BEARER SETUP FAILURE**

The contents of RADIO BEARER SETUP FAILURE message in this test case is the same as the RADIO BEARER SETUP FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark              |
|---------------------|---------------------------|
| Message Type        |                           |
| Failure cause       | Configuration unsupported |

**8.2.1.3.5 ————— Test requirement**

After step 1 the UE transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "configuration unsupported" in IE "failure cause".

**8.2.1.4 ————— Radio Bearer Establishment for transition from CELL\_DCH to CELL\_DCH:  
Failure (Physical channel Failure and successful reversion to old  
configuration)****8.2.1.4.1 ————— Definition****8.2.1.4.2 ————— Conformance requirement**

The UE shall revert to the old configuration when the UE fails to configure the new radio bearer before T312 expires and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "physical channel failure" in IE "failure cause".

**Reference**

3GPP TS 25.331 clause 8.2.1.

**8.2.1.4.3 ————— Test purpose**

To confirm that the UE reverts to the old configuration and transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC, if the UE fails to reconfigure the radio bearer according to the RADIO BEARER RECONFIGURATION message before timer T312 expires.

**8.2.1.4.4 ————— Method of test****Initial Condition**

System Simulator: 1 cell

UE: CS\_DCCH\_DCH (state 6-5) or PS\_DCCH\_DCH (state 6-7) as specified in clause 7.4 of TS 34.108, depending on the domain(s) supported by the UE.

### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER SETUP message to the UE and SS keep its old dedicated channel configuration. Then after T312 expiry, the UE reverts to the old configuration and transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "physical channel failure" in IE "failure cause".

### Expected sequence

| Step | Direction |    | Message                    | Comment                                                                                     |
|------|-----------|----|----------------------------|---------------------------------------------------------------------------------------------|
|      | UE        | SS |                            |                                                                                             |
| 1    |           | ←  | RADIO BEARER SETUP         | The SS keeps its old L1 configuration after transmitting this message.                      |
| 2    |           |    |                            | The UE does not configure the new radio access bearer and reverts to the old configuration. |
| 3    |           | →  | RADIO BEARER SETUP FAILURE | UE shall transmit this message using the old configuration.                                 |

### Specific Message Contents

#### RADIO BEARER SETUP

The contents of RADIO BEARER SETUP message in this test case is indicated as "Non-speech in CS" as found in annex A or the RADIO BEARER SETUP message as found in clause 9 of TS 34.108.

#### RADIO BEARER SETUP FAILURE

The contents of RADIO BEARER SETUP FAILURE message in this test case is the same as the RADIO BEARER SETUP FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark             |
|---------------------|--------------------------|
| Failure cause       | Physical channel failure |

#### 8.2.1.4.5 ——— Test requirement

After step 2 the UE shall transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "physical channel failure" in IE "failure cause".

#### 8.2.1.5 ——— Radio Bearer Establishment for transition from CELL\_DCH to CELL\_DCH: Failure (Physical channel Failure and reversion failure)

##### 8.2.1.5.1 ——— Definition

##### 8.2.1.5.2 ——— Conformance requirement

The UE shall perform a cell update procedure when the UE fails to revert to the old configuration after the detection of physical channel failure in the radio bearer establishment procedure. After the UE complete cell update procedure, the UE transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "physical channel failure" in IE "failure cause".

### Reference

3GPP TS 25.331 clause 8.2.1.



### 8.2.1.5.3 ~~Test purpose~~

To confirm that UE transmits ~~RADIO BEARER SETUP FAILURE~~ message after it completes a cell update procedure due to a physical channel failure in the radio bearer establishment procedure.

### 8.2.1.5.4 ~~Method of test~~

#### ~~Initial Condition~~

System Simulator: 1 cell.

UE: CS-DCCH\_DCH (state 6-5) or PS-DCCH\_DCH (state 6-7) as specified in clause 7.4 of TS 34.108, depending on the domain(s) supported by the UE.

#### ~~Test Procedure~~

The UE is in CELL\_DCH state. SS transmits a RADIO BEARER SETUP message to the UE. After transmitting the RADIO BEARER SETUP message, the SS shall not configure its dedicated physical channel in accordance with the settings in the message and release the old configuration after the RLC acknowledgement. The UE recognizes that it cannot synchronise on the new physical channel and wants to revert to the old configuration, but the UE cannot revert to the old configuration. The UE transmits a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "radio link failure". The SS shall transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving a CELL UPDATE message. The UE transmits PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC and subsequently transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC, setting the value of IE "failure cause" to "physical channel failure".

#### ~~Expected sequence~~

| Step | Direction |    | Message                                   | Comment                                                                                                                                                   |
|------|-----------|----|-------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                                           |
| 1    | ←         |    | RADIO BEARER SETUP                        |                                                                                                                                                           |
| 2    |           |    |                                           | The SS does not configure new radio access bearer and shall release the configuration.                                                                    |
| 3    | →         |    | CELL UPDATE                               | The value "radio link failure" shall be set in IE "Cell update cause".                                                                                    |
| 4    | ←         |    | CELL UPDATE CONFIRM                       | This message includes IE "Physical channel information elements".                                                                                         |
| 5    |           |    |                                           | The SS configures the dedicated physical channel according to the IE "Physical channel information elements" included in the CELL UPDATE CONFIRM message. |
| 6    | →         |    | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                                                           |
| 7    | →         |    | RADIO BEARER SETUP FAILURE                | The IE "failure cause" shall be set to "physical channel failure"                                                                                         |

#### ~~Specific Message Contents~~

##### ~~RADIO BEARER SETUP (Step 1)~~

The contents of RADIO BEARER SETUP message in this test case is indicated as "Non-speech in CS" as found in Annex A or the RADIO BEARER SETUP message as found in clause 9 of TS 34.108.

##### ~~CELL UPDATE (Step 3)~~

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark         |
|---------------------|----------------------|
| Cell Update Cause   | "radio-link-failure" |

#### CELL UPDATE CONFIRM (Step 4) (FDD)

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A with the following exceptions:

| Information Element                       | Value/remark                                                           |
|-------------------------------------------|------------------------------------------------------------------------|
| RRC State indicator                       | CELL_DCH                                                               |
| UplinkDPCH Info                           | Same as RRC CONNECTION SETUP message used to move to initial condition |
| Downlink information for each radio links | Same as RRC CONNECTION SETUP message used to move to initial condition |

#### CELL UPDATE CONFIRM (Step 4) (TDD)

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A with the following exceptions:

| Information Element                       | Value/remark                                                         |
|-------------------------------------------|----------------------------------------------------------------------|
| RRC State Indicator                       | CELL_DCH                                                             |
| Uplink DPCH timeslots and codes           | Same as RADIO BEARER SETUP message used to move to initial condition |
| Downlink information for each radio links | Same as RADIO BEARER SETUP message used to move to initial condition |

#### RADIO BEARER SETUP FAILURE (Step 7)

The contents of RADIO BEARER SETUP FAILURE message in this test case is the same as the RADIO BEARER SETUP FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark                 |
|---------------------|------------------------------|
| Message Type        | "RADIO BEARER SETUP FAILURE" |
| Failure cause       | "physical channel failure"   |

#### 8.2.1.5.5 Test requirement

After step 2 the UE shall transmit CELL UPDATE message on the CCCH with IE "Cell update cause" set to "radio-link failure".

After step 5 the UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC.

After step 6 the UE shall transmit RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC, setting the IE "failure cause" to "physical channel failure".

#### 8.2.1.6 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

##### 8.2.1.6.1 Definition

##### 8.2.1.6.2 Conformance requirement

If the UE receives a RADIO BEARER SETUP message during a reconfiguring procedure due to a radio bearer message other than RADIO BEARER SETUP message, it shall transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC.

## Reference

3GPP TS 25.331 clause 8.2.1, clause 8.6.3.11.

### 8.2.1.6.3 Test purpose

To confirm that if the UE receives a RADIO BEARER SETUP message during a reconfiguring procedure due to a radio bearer message other than RADIO BEARER SETUP, it shall keep its configuration as if the RADIO BEARER SETUP message had not been received and complete the reconfiguration procedure according to the previously received message.

### 8.2.1.6.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: CS\_DCCH+DTCH\_DCH (state 6-9) or PS\_DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE. The SS transmits a RADIO BEARER SETUP message before the "activation time" indicated in the RADIO BEARER RECONFIGURATION message expires. When the UE receives the RADIO BEARER SETUP message, the UE shall keep its current configuration as if it had not received the RADIO BEARER SETUP message and shall transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC with IE "failure cause" set to "incompatible simultaneous reconfiguration". After the SS acknowledges the RADIO BEARER SETUP FAILURE message, the UE reconfigures the new physical channel parameters upon the specified activation time and transmits a RADIO BEARER RECONFIGURATION COMPLETE message on DCCH using AM RLC.

#### Expected sequence

| Step | Direction |    | Message                               | Comment                                                                                           |
|------|-----------|----|---------------------------------------|---------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                   |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION          | Including IE "Activation Time"                                                                    |
| 2    |           | ←  | RADIO BEARER SETUP                    | The SS send this message before the expiry of activation time specified in the message of step 1. |
| 3    |           | →  | RADIO BEARER SETUP FAILURE            | The UE does not change the configuration according to the RADIO BEARER SETUP message.             |
| 4    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE | This message is on DCCH using AM RLC.                                                             |

#### Specific Message Contents

##### RADIO BEARER RECONFIGURATION (Step 1)

For RADIO BEARER RECONFIGURATION message in step 1, use the message sub-type indicated as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A, with the exception of the following Information Elements:

| Information Element                          | Value/remark                                     |
|----------------------------------------------|--------------------------------------------------|
| Activation Time                              | [256+Current CFN-[current CFN mod 8 + 8]]MOD 256 |
| Uplink DPCH Info<br>— Scrambling code number | 1                                                |

### RADIO-BEARER-SETUP (Step 2)

The contents of RADIO-BEARER-SETUP message in this test case is indicated as "Non-speech in CS" as found in Annex A or the RADIO-BEARER-SETUP message as found in clause 9 of TS 34.108 with the following exceptions:

| Information Element                           | Value/remark |
|-----------------------------------------------|--------------|
| Activation-Time                               | Not Present  |
| Uplink DPCH Info<br>-- Scrambling code number | 2            |

### RADIO-BEARER-SETUP FAILURE

The contents of RADIO-BEARER-SETUP FAILURE message in this test case is the same as the RADIO-BEARER-SETUP FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark                              |
|---------------------|-------------------------------------------|
| Message Type        |                                           |
| Failure case        | Incompatible simultaneous reconfiguration |

#### 8.2.1.6.5 Test requirement

After step 2 the UE shall keep its configuration as if the UE had not received the RADIO-BEARER-SETUP message and shall transmit a RADIO-BEARER-SETUP FAILURE message on the DCCH using AM RLC with IE "failure cause" set to "Incompatible simultaneous reconfiguration".

After step 3 the UE shall transmit a RADIO-BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### 8.2.1.7 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_DCH: Failure (Invalid message reception and Invalid configuration)

##### 8.2.1.7.1 Definition

##### 8.2.1.7.2 Conformance requirement

The UE shall keep its old configuration when the UE receives an invalid RADIO-BEARER-SETUP message, which does not includes any IEs except IE "Message Type". Then it transmits a RADIO-BEARER-SETUP FAILURE message which is set to "protocol error" in IE "failure cause" and is set to "ASN.1 violation or encoding error" in IE "Protocol error cause".

The UE shall keep existing configuration upon reception of a RADIO-BEARER-SETUP message which includes some IEs set to give an invalid configuration, and then the UE shall transmit a RADIO-BEARER-SETUP FAILURE message including IE "failure cause" set to "invalid configuration".

#### Reference

3GPP TS 25.331 clause 8.2.1

##### 8.2.1.7.3 Test purpose

To confirm that the UE transmits a RADIO-BEARER-SETUP FAILURE message on the DCCH using AM RLC if it receives an invalid RADIO-BEARER-SETUP message which does not include any IEs except IE "Message Type".

To confirm that the UE transmits a RADIO-BEARER-SETUP FAILURE message on the DCCH using AM RLC if it receives a RADIO-BEARER-SETUP message including some IEs set to give an invalid configuration.

#### 8.2.1.7.4 Method of test

##### Initial Condition

System Simulator: 1 cell

UE: CS-DCCH\_DCH (state 6-5) or PS-DCCH\_DCH (state 6-7) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

##### Test Procedure

The UE is in CELL\_DCH state. The SS transmits an invalid RADIO BEARER SETUP message to the UE which does not include any IEs except IE "Message Type". The UE keeps the old configuration and transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "protocol error" in IE "failure cause", and is set to "ASN.1 violation or encoding error" in IE "Protocol error cause". The UE keeps current configuration after SS transmits a RADIO BEARER SETUP message including some IEs set to give an invalid configuration. Then UE transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC, setting the value "invalid configuration" to IE "failure cause".

##### Expected sequence

| Step | Direction |    | Message                    | Comment                                        |
|------|-----------|----|----------------------------|------------------------------------------------|
|      | UE        | SS |                            |                                                |
| 1    |           | ←  | RADIO BEARER SETUP         | See specific message content.                  |
| 2    |           | →  | RADIO BEARER SETUP FAILURE | The UE does not change its configuration.      |
| 3    |           | ←  | RADIO BEARER SETUP         | This message includes IE set to invalid value. |
| 4    |           | →  | RADIO BEARER SETUP FAILURE | The UE does not change its configuration.      |

##### Specific Message Contents

##### RADIO BEARER SETUP (Step 1)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

##### RADIO BEARER SETUP FAILURE (Step 2)

| Information Element        | Value/remark                      |
|----------------------------|-----------------------------------|
| Message Type               |                                   |
| Failure cause              |                                   |
| Failure cause              | Protocol error                    |
| Protocol error information |                                   |
| Protocol error cause       | ASN.1 violation or encoding error |
| Other information element  | Not checked                       |

##### RADIO BEARER SETUP (Step 3)

The contents of RADIO BEARER SETUP message in this test case is identical as "Non-speech in CS" as found in Annex A or the RADIO BEARER SETUP message as found in clause 9 of TS 34.108 with the following exceptions:

**RADIO BEARER SETUP (Step 3) (FDD)**

| Information Element                   | Value/remark |
|---------------------------------------|--------------|
| <del>Default DPCCH Offset Value</del> | 512          |
| <del>DPCCH frame offset</del>         | 1024         |

**RADIO BEARER SETUP (Step 3) (TDD)**

| Information Element   | Value/remark |
|-----------------------|--------------|
| <del>PRACH TFCS</del> | Present      |

**RADIO BEARER SETUP FAILURE (Step 5)**

The contents of RADIO BEARER SETUP FAILURE message in this test case is the same as the RADIO BEARER SETUP FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark          |
|---------------------|-----------------------|
| Message Type        |                       |
| Failure cause       | Invalid configuration |

**8.2.1.7.5 ~~Test requirement~~**

After step 1 the UE shall keep its old configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "protocol error" in IE "failure cause" and set to "ASN.1 violation or encoding error" in IE "Protocol error cause".

After step 3 the UE shall keep its old configuration and transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC, setting the value "invalid configuration" to IE "failure cause".

**8.2.1.8 ~~Radio Bearer Establishment for transition from CELL\_DCH to CELL\_FACH:~~  
Success****8.2.1.8.1 ~~Definition~~****8.2.1.8.2 ~~Conformance requirement~~**

The UE shall correctly set up a radio bearer according to a RADIO BEARER SETUP message and responds with a RADIO BEARER SETUP COMPLETE message on the DCCH using AM RLC.

**Reference**

3GPP TS 25.331 clause 8.2.1.

**8.2.1.8.3 ~~Test purpose~~**

To confirm that the UE establishes a new radio bearer according to a RADIO BEARER SETUP message.

**8.2.1.8.4 ~~Method of test~~****Initial Condition**

System Simulator: 1 cell.

UE: PS-DCCH\_DCH (state 6-7) as specified in clause 7.4 of TS 34.108.

### Test Procedure

The UE is in CELL\_DCH state, after the test operator is asked to initiate a packet-switched data call. The SS transmits a RADIO BEARER SETUP message to the UE. After the UE receives this message, it transits from CELL\_DCH to CELL\_FACH state. Finally the UE transmits a RADIO BEARER SETUP COMPLETE message using AM RLC. Then the UE and the SS enters the communicating state.

### Expected sequence

| Step | Direction |    | Message                     | Comment                                                                                    |
|------|-----------|----|-----------------------------|--------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                            |
| 1    |           | ←  | RADIO BEARER SETUP          | SS requests test operator to make an outgoing packet-switched data call.                   |
| 2    |           | →  | RADIO BEARER SETUP COMPLETE | The UE selects PRACH and S-CCPCH indicated in SIB5 or SIB6 after entering CELL_FACH state. |

### Specific Message Contents

For RADIO BEARER SETUP message in step 1, use the message sub-type indicated as "Packet to CELL\_FACH from CELL\_DCH in PS" found in Annex A with the following exception:

| Information Element | Value/remark         |
|---------------------|----------------------|
| New C-RNTI          | 0000-0000-0000-0001B |

#### 8.2.1.8.5 Test requirement

After step 1 the UE shall transmit a RADIO BEARER SETUP COMPLETE message.

### 8.2.1.9 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_FACH: Success (Cell re-selection)

#### 8.2.1.9.1 Definition

#### 8.2.1.9.2 Conformance requirement

1. If after state transition the UE enters CELL\_FACH state, the UE shall, after the state transition:

.....

- if the contents of the variable C\_RNTI is empty:
  - perform a cell update procedure according to clause 8.3.1 using the cause "Cell reselection";

2. If the CELL\_UPDATE\_CONFIRM message

- does not include "RB information elements"; and
- does not include "Transport channel information elements"; and
- does not include "Physical channel information elements"; and
- includes "CN information elements"; or
- includes the IE "Ciphering mode info"; or
- includes the IE "Integrity protection mode info"; or
- includes the IE "New C-RNTI"; or

— includes the IE "New U-RNTI";

the UE shall:

— transmit a UTRAN MOBILITY INFORMATION CONFIRM as response message using AM RLC.

3. In case the procedure was triggered by reception of a RADIO BEARER SETUP message, the UE shall:

— transmit a RADIO BEARER SETUP COMPLETE as response message on the uplink DCCH using AM RLC;

## Reference

3GPP TS 25.331 clause 8.2.2.3, 8.3.1, 8.2.2.4.

### 8.2.1.9.3 Test purpose

1. To verify that the UE when receiving a RADIO BEARER SETUP message not including a value for C-RNTI initiate a cell update procedure and indicating the cause "Cell reselection".
2. To verify that the UE when the CELL UPDATE CONFIRM message does not include "RB information elements", "Transport channel information elements" nor "Physical channel information elements" but include the IE "New C-RNTI" transmit a UTRAN MOBILITY INFORMATION CONFIRM message.
3. To confirm that the UE transmits RADIO BEARER SETUP COMPLETE message after it completes the cell update procedure.

### 8.2.1.9.4 Method of test

#### Initial Condition

System Simulator: 1 cell-Cell 1 is active.

UE: PS-DCCH\_DCH (state 6-7) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER SETUP message which includes IE "Primary CPICH info" and no dedicated physical channel information, to request the UE to transit from CELL\_DCH to CELL\_FACH. Due to absence of the C-RNTI in the RADIO BEARER SETUP message the UE shall initiate the cell update procedure even if the UE selects the same cell as indicated by the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD). The UE transmits a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "cell reselection". The SS shall transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving CELL UPDATE message. The UE transmits a UTRAN MOBILITY UPDATE CONFIRM message on the DCCH using AM RLC. The UE transmits a RADIO BEARER SETUP COMPLETE message on the DCCH using AM RLC.

#### Expected sequence

| Step | Direction |    | Message                            | Comment                                                     |
|------|-----------|----|------------------------------------|-------------------------------------------------------------|
|      | UE        | SS |                                    |                                                             |
| 1    |           |    | Void                               |                                                             |
| 2    |           |    | Void                               |                                                             |
| 3    |           | ←  | RADIO BEARER SETUP                 | Assigned the transition from CELL_DCH to CELL_FACH          |
| 4    |           | →  | CELL UPDATE                        | The value "cell reselection" set in IE "Cell update cause". |
| 5    |           | ←  | CELL UPDATE CONFIRM                | C-RNTI included                                             |
| 6    |           | →  | UTRAN MOBILITY INFORMATION CONFIRM |                                                             |
| 7    |           | →  | RADIO BEARER SETUP COMPLETE        |                                                             |



## Specific Message Contents

### RADIO BEARER SETUP (Step 3) (FDD)

The contents of RADIO BEARER SETUP message in this test case is identical as "Packet to CELL\_FACH from CELL\_DCH in PS" as found in Annex A.

### RADIO BEARER SETUP (Step 3) (TDD)

The contents of RADIO BEARER SETUP message in this test case is identical as "Packet to CELL\_FACH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element                                                                         | Value/remark |
|---------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>—— Primary CCPCH info<br>—— Cell parameters ID | 4            |

### CELL UPDATE (Step 4)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark       |
|---------------------|--------------------|
| Cell Update Cause   | "cell reselection" |

### CELL UPDATE CONFIRM (Step 5)

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A. with the following exceptions:

| Information Element | Value/remark         |
|---------------------|----------------------|
| New C-RNTI          | 0000-0000-0000-0001B |

### UTRAN MOBILITY UPDATE CONFIRM (Step 6)

The contents of UTRAN MOBILITY UPDATE CONFIRM message is identical as "UTRAN MOBILITY UPDATE CONFIRM message" as found in Annex A.

### RADIO BEARER SETUP COMPLETE (Step 7)

The contents of RADIO BEARER SETUP COMPLETE message is identical as "RADIO BEARER SETUP COMPLETE message" as found in Annex A.

#### 8.2.1.9.5 Test requirement

1. After step 3 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "cell reselection".
2. After step 5 the UE shall transmit a UTRAN MOBILITY INFORMATION CONFIRM message on the DCCH using AM RLC.
3. After step 6 the UE shall transmit a RADIO BEARER SETUP COMPLETE message on the DCCH using AM RLC.

~~8.2.1.10 Radio Bearer Establishment for transition from CELL\_FACH to CELL\_DCH: Success~~

~~8.2.1.10.1 Definition~~

~~8.2.1.10.2 Conformance requirement~~

~~The UE shall correctly set up a radio bearer according to a RADIO BEARER SETUP message and responds with a RADIO BEARER SETUP COMPLETE message on the DCCH using AM RLC.~~

~~Reference~~

~~3GPP TS 25.331 clause 8.2.1.~~

~~8.2.1.10.3 Test purpose~~

~~To confirm that the UE establishes a new radio bearer according to a RADIO BEARER SETUP message.~~

~~8.2.1.10.4 Method of test~~

~~Initial Condition~~

~~System Simulator: 1 cell.~~

~~UE: PS-DCCH\_FACH (state 6-8) as specified in clause 7.4 of TS 34.108.~~

~~Test Procedure~~

~~The UE is in CELL\_FACH state, after SS prompts the test operator to initiate a packet-switched data call. The SS transmits a RADIO BEARER SETUP message to the UE. After the UE receives this message, it configures them and establishes the required radio bearers. Finally the UE transmits a RADIO BEARER SETUP COMPLETE message using AM RLC.~~

~~Expected sequence~~

| Step | Direction |    | Message                     | Comment |
|------|-----------|----|-----------------------------|---------|
|      | UE        | SS |                             |         |
| 1    |           | ←  | RADIO BEARER SETUP          |         |
| 2    |           | →  | RADIO BEARER SETUP COMPLETE |         |

~~Specific Message Contents~~

~~RADIO BEARER SETUP~~

~~The contents of RADIO BEARER SETUP message in this test case is identical the message sub-type indicated by "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A.~~

~~8.2.1.10.5 Test requirement~~

~~After step 1 the UE shall transmit a RADIO BEARER SETUP COMPLETE message on the DCCH using AM RLC.~~

~~8.2.1.11 Radio Bearer Establishment for transition from CELL\_FACH to CELL\_DCH:  
Failure (Unsupported configuration)~~

~~8.2.1.11.1 Definition~~

~~8.2.1.11.2 Conformance requirement~~

~~The UE shall keep its old configuration when the UE receives a RADIO BEARER SETUP message which includes an unsupported configuration and then transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC, which sets value "configuration unsupported" in IE "failure cause".~~

~~Reference~~

~~3GPP TS 25.331 clause 8.2.1.~~

~~8.2.1.11.3 Test purpose~~

~~To confirm that the UE keeps its configuration and transmits a RADIO BEARER SETUP FAILURE message in case of it receiving a RADIO BEARER SETUP message, which includes parameters of an unsupported configuration.~~

~~8.2.1.11.4 Method of test~~

~~Initial Condition~~

~~System Simulator: 1 cell.~~

~~UE: PS-DCCH\_FACH (state 6-8) as specified in clause 7.4 of TS 34.108.~~

~~Test Procedure~~

~~The UE is in CELL\_FACH state. The SS transmits a RADIO BEARER SETUP message with a stated frequency that cannot be supported by the UE. After the UE receives this message, it shall transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC setting value "configuration unsupported" in IE "failure cause".~~

~~Expected sequence~~

| Step | Direction |    | Message                    | Comment                                                                                           |
|------|-----------|----|----------------------------|---------------------------------------------------------------------------------------------------|
|      | UE        | SS |                            |                                                                                                   |
| 1    |           | ←  | RADIO BEARER SETUP         | This message includes an unsupported configuration for the UE.                                    |
| 2    |           | →  | RADIO BEARER SETUP FAILURE | The UE shall transmit this message using RLC-AM mode and do not change the current configuration. |

~~Specific Message Contents~~

~~RADIO BEARER SETUP~~

~~The contents of RADIO BEARER SETUP message in this test case is indicated as "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:~~

**RADIO-BEARER SETUP (FDD)**

| Information Element     | Value/remark |
|-------------------------|--------------|
| Frequency info          |              |
| —— UARFCN uplink (Nu)   | 0            |
| —— UARFCN downlink (Nd) | 950          |

**RADIO-BEARER SETUP (TDD)**

| Information Element | Value/remark |
|---------------------|--------------|
| Frequency info      |              |
| —— CHOICE mode      | TDD          |
| —— UARFCN (Nt)      | 0            |

**RADIO-BEARER SETUP FAILURE**

The contents of RADIO-BEARER SETUP FAILURE message in this test case is the same as the RADIO-BEARER SETUP FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark              |
|---------------------|---------------------------|
| Message Type        |                           |
| Failure cause       | Configuration unsupported |

**8.2.1.11.5 — Test requirement**

After step 1 the UE shall transmit a RADIO-BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "configuration unsupported" in IE "failure cause".

**8.2.1.12 — Radio Bearer Establishment for transition from CELL\_FACH to CELL\_DCH: Failure (Physical channel Failure and successful reversion to old configuration)****8.2.1.12.1 — Definition****8.2.1.12.2 — Conformance requirement**

The UE shall attempt to revert to the old configuration when the UE fails to configure the new radio bearer before T312 expires and detects the same serving cell only. It shall transmit a RADIO-BEARER SETUP FAILURE message on the DCCH using AM RLC containing value "physical channel failure" in IE "failure cause".

**Reference**

3GPP TS 25.331 clause 8.2.1.

**8.2.1.12.3 — Test purpose**

To confirm that the UE reverts to the old configuration and transmits a RADIO-BEARER SETUP FAILURE message when the UE fails to configure the new radio bearer after it detects physical channel failure, followed by the T312 expiry.

**8.2.1.12.4 — Method of test****Initial Condition**

System Simulator: 1 cell.

UE: PS-DCCH\_FACH (state 6-8) as specified in clause 7.4 of TS 34.108.

## Test Procedure

The UE is in CELL\_FACH state. The SS transmits a RADIO BEARER SETUP message to the UE and keeps its old physical channel configuration. After T312 expiry, the UE shall perform cell reselection procedure and detect the same serving cell only. Then the UE shall transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC. The content of the message shall indicate "physical channel failure" in IE "failure cause".

## Expected sequence

| Step | Direction |    | Message                    | Comment                                                                            |
|------|-----------|----|----------------------------|------------------------------------------------------------------------------------|
|      | UE        | SS |                            |                                                                                    |
| 1    |           | ←  | RADIO BEARER SETUP         | The SS keep its old configuration.                                                 |
| 2    |           | →  | RADIO BEARER SETUP FAILURE | The UE does not configure a new radio bearer and reverts to the old configuration. |

## Specific Message Contents

### RADIO BEARER SETUP

The contents of RADIO BEARER SETUP message in this test case is identical the message sub-type indicated by "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A.

### RADIO BEARER SETUP FAILURE

The contents of RADIO BEARER SETUP FAILURE message in this test case is the same as the RADIO BEARER SETUP FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark             |
|---------------------|--------------------------|
| Message Type        |                          |
| Failure cause       | Physical channel failure |

### 8.2.1.12.5 — Test requirement

After step 1 the UE shall transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "physical channel failure" in IE "failure cause".

### 8.2.1.13 — Radio Bearer Establishment for transition from CELL\_FACH to CELL\_DCH: Failure (Physical channel Failure and reversion failure)

#### 8.2.1.13.1 — Definition

#### 8.2.1.13.2 — Conformance requirement

The UE shall perform a cell update procedure when the UE selects another cell after the detection of physical channel failure in the radio bearer establishment procedure. After the UE completes cell update procedure, the UE transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC which is set to "physical channel failure" in IE "failure cause".

## Reference

3GPP TS 25.331 clause 8.2.1.

#### 8.2.1.13.3 — Test purpose

To confirm that the UE transmit a RADIO BEARER SETUP FAILURE message after it completes a cell update for the physical channel failure in the radio bearer establishment procedure.

## 8.2.1.13.4 Method of test

## Initial Condition

System Simulator: 2 cells – Cell 1 and 2 are active.

UE: PS-DCCH\_FACH (state 6-8) as specified in clause 7.4 of TS 34.108 in cell 1.

## Test Procedure

Table 8.2.1.13

| Parameter              | Unit         | Cell 1 |     | Cell 2 |     |
|------------------------|--------------|--------|-----|--------|-----|
|                        |              | T0     | T1  | T0     | T1  |
| UTRA-RF Channel Number |              | Ch. 1  |     | Ch. 1  |     |
| CPICH Ec (FDD)         | dBm/3.84 MHz | -60    | -75 | -75    | -60 |
| P-CCPICH RSCP (TDD)    | dBm          | -60    | -75 | -75    | -60 |

Table 8.2.1.13 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution. SS switches the power settings between columns "T0" and "T1", whenever the description in multi-cell condition specifies reverse of the transmission power settings for cell 1 and cell 2.

The UE is in CELL\_FACH state in cell 1. The SS transmits a RADIO BEARER SETUP message to the UE. After transmitting the RADIO BEARER SETUP message, the SS shall not configure its DL dedicated physical channel in accordance with the setting in the message and release its current configuration. At the same time, the SS configures its downlink transmission power settings according to columns "T1" in table 8.2.1.13. The UE recognize that it cannot synchronize with the SS on the new radio bearer. The UE performs cell re-selection and transmits a CELL UPDATE message on uplink CCCH with IE "Cell update cause" which is set to "cell reselection". The SS shall transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving a CELL UPDATE message. The UE transmits a UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH using AM RLC and subsequently transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC, setting the value "physical channel failure" to IE "failure cause".

## Expected sequence

| Step | Direction |    | Message                            | Comment                                                                                                                                                                                                        |
|------|-----------|----|------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                    |                                                                                                                                                                                                                |
| 1    | ←         |    | RADIO BEARER SETUP                 |                                                                                                                                                                                                                |
| 2    |           |    |                                    | The SS does not configure the new radio bearer in accordance with the settings in the message and applies the downlink transmission power settings, according to the values in columns "T1" of table 8.2.1.13. |
| 3    |           |    | Void                               |                                                                                                                                                                                                                |
| 4    |           |    |                                    | The UE select the cell 2.                                                                                                                                                                                      |
| 5    | →         |    | CELL UPDATE                        | The value "cell reselection" shall be set in IE "Cell update cause".                                                                                                                                           |
| 6    | ←         |    | CELL UPDATE CONFIRM                | This message include IE "new U-RNTI" and IE "new C-RNTI".                                                                                                                                                      |
| 7    | →         |    | UTRAN MOBILITY INFORMATION CONFIRM |                                                                                                                                                                                                                |
| 8    | →         |    | RADIO BEARER SETUP FAILURE         | The IE "failure cause" shall be set to "physical channel failure"                                                                                                                                              |

### Specific Message Contents

#### RADIO BEARER SETUP (Step 1)

The contents of RADIO BEARER SETUP message in this test case is identical to the message sub-type "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A.

#### CELL UPDATE (Step 5)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark       |
|---------------------|--------------------|
| Cell Update Cause   | "cell reselection" |

#### CELL UPDATE CONFIRM (Step 6)

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM" message as found in Annex A with the following exceptions:

| Information Element | Value/remark                          |
|---------------------|---------------------------------------|
| U-RNTI              | Same as CELL UPDATE message in step 5 |
| New U-RNTI          |                                       |
| -SRNC Identity      |                                       |
| -S-RNTI             |                                       |
| New C-RNTI          | '0000-0000-0000-0001'                 |
|                     | Different from previous S-RNTI        |
|                     | Different from previous C-RNTI        |

#### RADIO BEARER SETUP FAILURE (Step 8)

The contents of RADIO BEARER SETUP FAILURE message in this test case is the same as the RADIO BEARER SETUP FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark                           |
|---------------------|----------------------------------------|
| Message Type        | "RADIO BEARER RECONFIGURATION FAILURE" |
| Failure cause       | "physical channel failure"             |

#### 8.2.1.13.5 Test requirement

After step 4 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "cell reselection".

After step 6 the UE shall transmit a UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH using AM RLC.

After step 7 the UE shall transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC, setting the IE "failure cause" to "physical channel failure".

#### 8.2.1.14 Radio Bearer Establishment for transition from CELL\_FACH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

##### 8.2.1.14.1 Definition

##### 8.2.1.14.2 Conformance requirement

If the UE receives a RADIO BEARER SETUP message during a reconfiguring procedure due to a radio bearer message other than RADIO BEARER SETUP message, it shall transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC.

## Reference

3GPP TS 25.331 clause 8.2.1, clause 8.6.3.11.

## 8.2.1.14.3 Test purpose

To confirm that if the UE receives a RADIO BEARER SETUP message during a reconfiguring procedure due to a radio bearer message other than RADIO BEARER SETUP, it shall keep its configuration as if the RADIO BEARER SETUP message had not been received and complete the reconfiguration procedure according to the previously received message.

## 8.2.1.14.4 Method of test

## Initial Condition

System Simulator: 1 cell

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

## Test Procedure

The UE is in CELL\_FACH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE. The SS transmits a RADIO BEARER SETUP message before the "activation time" indicated in the RADIO BEARER RECONFIGURATION message expires. When the UE receives the RADIO BEARER SETUP message, the UE shall keep its current configuration as if it had not received the RADIO BEARER SETUP message and shall transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC with IE "failure cause" set to "incompatible simultaneous reconfiguration". After the SS acknowledges the RADIO BEARER SETUP FAILURE message, the UE reconfigures the new physical channel parameters upon the specified activation time and transmits a RADIO BEARER RECONFIGURATION COMPLETE message on DCCH using AM RLC.

## Expected sequence

| Step | Direction |    | Message                               | Comment                                                                                                                                                                                 |
|------|-----------|----|---------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                                                                                                         |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION          | Including IE "Activation Time"                                                                                                                                                          |
| 2    |           | ←  | RADIO BEARER SETUP                    | The SS send this message before the expiry of activation time specified in the message of step 1.                                                                                       |
| 3    |           | →  | RADIO BEARER SETUP FAILURE            | The UE does not change the configuration because of the RADIO BEARER SETUP message, and transmit this message on its uplink DCCH using the same RLC-AM mode radio bearer before step 1. |
| 4    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE | This message is on DCCH using AM RLC.                                                                                                                                                   |

## Specific Message Contents

## RADIO BEARER RECONFIGURATION (Step 1) (FDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case are identical as "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element                          | Value/remark                        |
|----------------------------------------------|-------------------------------------|
| Activation Time                              | Current CFN-[current CFN mod 8 + 8] |
| Uplink DPCH Info<br>— Scrambling code number | 1                                   |



**RADIO BEARER RECONFIGURATION (Step 1) (TDD)**

The contents of RADIO BEARER RECONFIGURATION message in this test case are identical as "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element                                             | Value/remark                        |
|-----------------------------------------------------------------|-------------------------------------|
| Activation Time                                                 | Current CFN-[current CFN mod 8 + 8] |
| - Uplink DPCH timeslots and codes<br>- First timeslot code list | Assigned in step 1                  |

**RADIO BEARER SETUP (for Step 2) (FDD)**

For this message, use the message sub-type entitled "Packet to CELL\_DCH from CELL\_FACH in PS" in the default message content. Information element(s) to be changed are listed below:

| Information Element                          | Value/remark |
|----------------------------------------------|--------------|
| Activation Time                              | Not present  |
| Uplink DPCH Info<br>- Scrambling code number | 2            |

**RADIO BEARER SETUP (for Step 2) (TDD)**

For this message, use the message sub-type entitled "Packet to CELL\_DCH from CELL\_FACH in PS" in the default message content. Information element(s) to be changed are listed below:

| Information Element                                             | Value/remark                                         |
|-----------------------------------------------------------------|------------------------------------------------------|
| Activation Time                                                 | Not Present                                          |
| - Uplink DPCH timeslots and codes<br>- First timeslot code list | A different code combination to that used in step 1. |

**RADIO BEARER SETUP FAILURE**

The contents of RADIO BEARER SETUP FAILURE message in this test case is the same as the RADIO BEARER SETUP FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark                              |
|---------------------|-------------------------------------------|
| Message Type        |                                           |
| Failure cause       | Incompatible simultaneous reconfiguration |

**8.2.1.14.5 Test requirement**

After step 2 the UE shall transmit a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC with IE "failure cause" set to "Incompatible simultaneous reconfiguration".

After step 3 the UE shall configure the new configuration on the activation time and transmit a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

**8.2.1.15 Radio Bearer Establishment for transition from CELL\_FACH to CELL\_DCH: Failure (Invalid message reception and Invalid configuration)****8.2.1.15.1 Definition****8.2.1.15.2 Conformance requirement**

The UE shall keep its old configuration when the UE receives an invalid RADIO BEARER SETUP message, which does not includes any IEs except IE "Message Type". It shall transmit a RADIO BEARER SETUP FAILURE message which set value "protocol error" in IE "failure cause" and also value "ASN.1 violation or encoding error" in IE

"Protocol error cause". The UE shall keep the old configuration upon reception of a RADIO BEARER SETUP message, which includes some IEs set to give an invalid configuration, and then the UE shall transmit a RADIO BEARER SETUP FAILURE including IE "failure cause" set to "invalid configuration".

## Reference

3GPP TS 25.331 clause 8.2.1.

### 8.2.1.15.3 Test purpose

To confirm that the UE transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC if it receives an invalid RADIO BEARER SETUP message which does not include any IEs except IE "Message Type".

To confirm that the UE transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC if it receives a RADIO BEARER SETUP message including some IEs set to give an invalid configuration.

### 8.2.1.15.4 Method of test

## Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH\_FACH (state 6-8) as specified in clause 7.4 of TS 34.108.

## Test Procedure

The UE is in CELL\_FACH state. The SS transmits an invalid RADIO BEARER SETUP message to the UE which does not include all IEs except IE "Message Type". The UE keeps the old configuration and transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC. This message shall specify "protocol error" in IE "failure cause" and also set the value "ASN.1 violation or encoding error" in IE "Protocol error cause". The UE keeps current configuration after SS transmits RADIO BEARER SETUP message including some IEs set to give an invalid configuration. Then UE transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC, setting the value "invalid configuration" to IE "failure cause".

## Expected sequence

| Step | Direction |    | Message                    | Comment                                                        |
|------|-----------|----|----------------------------|----------------------------------------------------------------|
|      | UE        | SS |                            |                                                                |
| 1    |           | ←  | RADIO BEARER SETUP         | See specific message content.                                  |
| 2    |           | →  | RADIO BEARER SETUP FAILURE | The UE does not change the configuration.                      |
| 3    |           | ←  | RADIO BEARER SETUP         | This message includes IE set to give an invalid configuration. |
| 4    |           | →  | RADIO BEARER SETUP FAILURE | The UE does not change the configuration.                      |

## Specific Message Contents

### RADIO BEARER SETUP (Step 1)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

### RADIO BEARER SETUP FAILURE (Step 2)

The contents of RADIO BEARER SETUP FAILURE message in this test case is the same as the RADIO BEARER SETUP FAILURE message as found in Annex A, with the following exceptions:

| Information Element                   | Value/remark                      |
|---------------------------------------|-----------------------------------|
| <del>Failure-cause</del>              |                                   |
| <del>Failure-cause</del>              | Protocol-error                    |
| <del>Protocol-error information</del> |                                   |
| <del>Protocol-error cause</del>       | ASN.1-violation-or-encoding-error |

### ~~RADIO BEARER SETUP (Step 3)~~

The contents of RADIO BEARER SETUP message in this test case is identical as "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

### ~~RADIO BEARER SETUP (Step 3) (FDD)~~

| Information Element                  | Value/remark |
|--------------------------------------|--------------|
| <del>Default DPCH Offset Value</del> | 512          |
| <del>DPCH frame offset</del>         | 1024         |

### ~~RADIO BEARER SETUP (Step 3) (TDD)~~

| Information Element   | Value/remark |
|-----------------------|--------------|
| <del>PRACH TFCS</del> | Present      |

### ~~RADIO BEARER SETUP FAILURE (Step 4)~~

The contents of RADIO BEARER SETUP FAILURE message in this test case is the same as the RADIO BEARER SETUP FAILURE message as found in Annex A, with the following exceptions:

| Information Element      | Value/remark          |
|--------------------------|-----------------------|
| <del>Failure-cause</del> | Invalid-configuration |

### 8.2.1.15.5 ~~Test requirement~~

After step 1 the UE shall transmits a RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC. The message shall indicate the reason of failure as "protocol-error" in IE "failure-cause" and set the value "ASN.1-violation-or-encoding-error" in IE "Protocol-error-cause".

After step 3 the UE shall transmit RADIO BEARER SETUP FAILURE message on the DCCH using AM RLC, setting the value of IE "failure-cause" to "invalid-configuration".

### 8.2.1.16 ~~Radio Bearer Establishment for transition from CELL\_FACH to CELL\_FACH: Success~~

#### 8.2.1.16.1 ~~Definition~~

#### 8.2.1.16.2 ~~Conformance requirement~~

The UE shall correctly set up a radio access bearer according to a RADIO BEARER SETUP message and responds with a RADIO BEARER SETUP COMPLETE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.1.

#### 8.2.1.16.3 ~~Test purpose~~

To confirm that the UE establishes a new radio access bearer according to a RADIO BEARER SETUP message.

8.2.1.16.4 Method of test

Initial Condition

System Simulator: 1 cell.

UE: PS-DCH-FACH (state 6-8) as specified in clause 7.4 of TS 34.108.

Test Procedure

The UE is in CELL\_FACH state, after the test operator is being prompted to make an outgoing packet-switched call. The SS transmits a RADIO BEARER SETUP message to the UE. After the UE receives this message, it configures them and establishes a new radio access bearer. Finally the UE transmits a RADIO BEARER SETUP COMPLETE message on the DCH using AM RLC.

Expected sequence

| Step | Direction |    | Message                     | Comment                                             |
|------|-----------|----|-----------------------------|-----------------------------------------------------|
|      | UE        | SS |                             |                                                     |
| 1    |           | ←  | RADIO BEARER SETUP          |                                                     |
| 2    |           | →  | RADIO BEARER SETUP COMPLETE | The UE select PRACH and S-CCPCH using SIB5 or SIB6. |

Specific Message Contents

RADIO BEARER SETUP

For this message, use the message sub-type entitled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A.

8.2.1.16.5 Test requirement

After step 1, the UE shall transmit a RADIO BEARER SETUP COMPLETE message.

8.2.1.17 Radio Bearer Establishment for transition from CELL\_DCH to CELL\_DCH: success (Subsequently received)

8.2.1.17.1 Definition

8.2.1.17.2 Conformance requirement

If the UE receives a RADIO BEARER SETUP message before the UE completes the configuration of the radio bearers according to the previous RADIO BEARER SETUP message, the UE shall ignore the new RADIO BEARER SETUP message and configure according to the previous RADIO BEARER SETUP message. Finally, the UE shall transmit a RADIO BEARER SETUP COMPLETE message on the DCH using AM RLC.

Reference

3GPP TS 25.331 clause 8.2.1, clause 8.6.3.11.

8.2.1.17.3 Test purpose

To confirm that if the UE receives a new RADIO BEARER SETUP message before the UE completes the configuration of the radio bearer according to a previous RADIO BEARER SETUP message, it ignores the new RADIO BEARER SETUP message and configures according to the previous RADIO BEARER SETUP message received.

#### 8.2.1.17.4 Method of test

##### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH\_DCH (state 6-5) or PS-DCCH\_DCH (state 6-7) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

##### Test Procedure

The UE is in CELL\_DCH state. SS transmits a RADIO BEARER SETUP message to the UE before the UE completes the configuration of the radio bearer according to the RADIO BEARER SETUP message prior to this new message. The UE ignores the new RADIO BEARER SETUP message and configures according to the former RADIO BEARER SETUP message. On completion of radio bearer configuration, the UE shall transmit a RADIO BEARER SETUP COMPLETE message on the DCCH using AM RLC.

##### Expected sequence

| Step | Direction |    | Message                     | Comment                                                                                                                                                                                                                                             |
|------|-----------|----|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                                                                                                                                     |
| 1    |           | ←  | RADIO BEARER SETUP          | The "Secondary scrambling code is set to "1" for FDD mode.                                                                                                                                                                                          |
| 2    |           | ←  | RADIO BEARER SETUP          | SS send this message before the expiry of activation time specified in RADIO BEARER SETUP message of step 1. For TDD the IE "Secondary scrambling code" is set to "2" and for TDD mode a different code combination to that used in step 1 is used. |
| 3    |           | →  | RADIO BEARER SETUP COMPLETE | The UE ignores the RADIO BEARER SETUP message in step 2 and completes configuration according to the RADIO BEARER SETUP message in step 1.                                                                                                          |

##### Specific Message Contents

##### RADIO BEARER SETUP (Step 1) (FDD)

For RADIO BEARER SETUP in step 1, use the message sub-type indicated as "Non speech in CS" found in Annex A or the RADIO BEARER SETUP message as found in clause 9 of TS 34.108, with the exception of the following Information Elements:

| Information Element                               | Value/remark                                                                   |
|---------------------------------------------------|--------------------------------------------------------------------------------|
| Activation Time                                   | $[256 + \text{Current CFN} - [\text{current CFN mod } 8 + 8]] \text{MOD } 256$ |
| - Uplink DPCH Info<br>- Secondary scrambling code | 1                                                                              |

##### RADIO BEARER SETUP (Step 1) (TDD)

For RADIO BEARER SETUP in step 1, use the message sub-type indicated as "Non speech in CS" found in Annex A or the RADIO BEARER SETUP message as found in clause 9 of TS 34.108, with the exception of the following Information Elements:

| Information Element              | Value/remark                                     |
|----------------------------------|--------------------------------------------------|
| Activation-Time                  | [256+Current CFN-[current CFN mod 8 + 8]]MOD 256 |
| -Uplink DPCH timeslots and codes |                                                  |
| -First timeslot code list        | Assigned in step 1                               |

### RADIO BEARER SETUP (Step 2) (FDD)

For RADIO BEARER SETUP in step 2, use the message sub-type indicated as "Non speech in CS" found in Annex A or the RADIO BEARER SETUP message as found in clause 9 of TS 34.108, with the exception of the following:

| Information Element        | Value/remark |
|----------------------------|--------------|
| Activation-Time            | Not Present  |
| -Uplink DPCH Info          |              |
| -Secondary scrambling code | 2            |

### RADIO BEARER SETUP (Step 2) (TDD)

For RADIO BEARER SETUP in step 2, use the message sub-type indicated as "Non speech in CS" found in Annex A or the RADIO BEARER SETUP message as found in clause 9 of TS 34.108, with the exception of the following:

| Information Element              | Value/remark                                         |
|----------------------------------|------------------------------------------------------|
| Activation-Time                  | Not Present                                          |
| -Uplink DPCH timeslots and codes |                                                      |
| -First timeslot code list        | A different code combination to that used in step 1. |

#### 8.2.1.17.5 Test requirement

After step 2 the UE shall transmit a RADIO BEARER SETUP COMPLETE message on the DCCH using AM RLC.

### 8.2.1.18 Radio Bearer Establishment for transition from CELL\_FACH to CELL\_DCH: Success (Subsequently received)

#### 8.2.1.18.1 Definition

#### 8.2.1.18.2 Conformance requirement

If the UE receives a RADIO BEARER SETUP message before the UE completes the configuration of the radio bearers according to the previous RADIO BEARER SETUP message, the UE shall ignore the new RADIO BEARER SETUP message and configure according to the previous RADIO BEARER SETUP message. Finally, the UE shall transmit a RADIO BEARER SETUP COMPLETE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.1, clause 8.6.3.11.

#### 8.2.1.18.3 Test purpose

To confirm that if the UE receives a new RADIO BEARER SETUP message before the UE completes the configuration of the radio bearer according to a previous RADIO BEARER SETUP message, it ignores the new RADIO BEARER SETUP message and configures according to the previous RADIO BEARER SETUP message received.

#### 8.2.1.18.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH\_FACH (state 6-8) as specified in clause 7.4 of TS 34.108.

### Test Procedure

The UE is in CELL\_FACH state. The SS transmits a RADIO BEARER SETUP message, requesting the UE to setup radio bearers using DPCCH physical channels. SS transmits another RADIO BEARER SETUP message before the activation time specified in the first message has lapsed. The UE ignores the new RADIO BEARER SETUP message and configures the radio bearers according to the former RADIO BEARER SETUP message. On completion of radio bearer configuration, the UE shall transmit a RADIO BEARER SETUP COMPLETE message on the DCCH using AM RLC.

### Expected sequence

| Step | Direction |    | Message                     | Comment                                                                                                                                                                                                                                                  |
|------|-----------|----|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                                                                                                                                          |
| 1    |           | ←  | RADIO BEARER SETUP          | The "Secondary scrambling code is set to "1" for FDD mode.                                                                                                                                                                                               |
| 2    |           | ←  | RADIO BEARER SETUP          | SS send this message before the expiry of activation time specified in RADIO BEARER SETUP message of step 1. For FDD mode the IE "Secondary scrambling code" is set to "2" and for TDD mode a different code combination to that used in step 1 is used. |
| 3    |           | →  | RADIO BEARER SETUP COMPLETE | The UE ignores the RADIO BEARER SETUP message in step 2 and confirms configuration according to the RADIO BEARER SETUP message in step 1.                                                                                                                |

### Specific Message Contents

#### RADIO BEARER SETUP (Step 1) (FDD)

For this message, use the message sub-type entitled "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A.

Information element(s) to be changed are listed below:

| Information Element                                | Value/remark                                                                   |
|----------------------------------------------------|--------------------------------------------------------------------------------|
| Activation Time                                    | $[256 + \text{Current CFN} - [\text{current CFN mod } 8 + 8]] \text{MOD } 256$ |
| - Uplink DPCCH Info<br>- Secondary scrambling code | 1                                                                              |

#### RADIO BEARER SETUP (Step 1) (TDD)

For RADIO BEARER SETUP in step 1, use the message sub-type indicated as "Non speech in CS" found in Annex A or the RADIO BEARER SETUP message as found in clause 9 of TS 34.108, with the exception of the following Information Elements:

| Information Element                                              | Value/remark                                                                   |
|------------------------------------------------------------------|--------------------------------------------------------------------------------|
| Activation Time                                                  | $[256 + \text{Current CFN} - [\text{current CFN mod } 8 + 8]] \text{MOD } 256$ |
| - Uplink DPCCH timeslots and codes<br>- First timeslot code list | Assigned in step 1                                                             |

**RADIO-BEARER-SETUP (for Step 2) (FDD)**

For this message, use the message sub-type entitled "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A. Information element(s) to be changed are listed below:

| Information Element                               | Value/remark |
|---------------------------------------------------|--------------|
| Activation Time                                   | Not Present  |
| - Uplink DPCH Info<br>- Secondary scrambling code | 2            |

**RADIO-BEARER-SETUP (Step 2) (TDD)**

For RADIO-BEARER-SETUP in step 2, use the message sub-type indicated as "Non speech in CS" found in Annex A or the RADIO-BEARER-SETUP message as found in clause 9 of TS 34.108, with the exception of the following:

| Information Element                                             | Value/remark                                         |
|-----------------------------------------------------------------|------------------------------------------------------|
| Activation Time                                                 | Not Present                                          |
| - Uplink DPCH timeslots and codes<br>- First timeslot code list | A different code combination to that used in step 1. |

**8.2.1.18.5 — Test requirement**

After step 2 the UE shall transmit a RADIO-BEARER-SETUP COMPLETE message on the DCCH using AM RLC specified in step 1.

After step 3 the UE shall communicate with the SS on the radio bearer specified in the RADIO-BEARER-SETUP message in step 1.

**8.2.1.19 — Radio Bearer Establishment from CELL\_DCH to CELL\_PCH: Success****8.2.1.19.1 — Definition****8.2.1.19.2 — Conformance requirement**

The UE shall configure radio bearers so as to transit from CELL\_DCH state to CELL\_PCH state according to the received RADIO-BEARER-SETUP message and responds with a RADIO-BEARER-SETUP COMPLETE message on the DCCH using AM RLC.

**Reference**

3GPP TS 25.331 clause 8.2.1.

**8.2.1.19.3 — Test purpose**

To conform that the UE transmits a RADIO-BEARER-SETUP COMPLETE message and enters CELL\_PCH state after it received a RADIO-BEARER-SETUP message for the transition from CELL\_DCH to CELL\_PCH from SS.

**8.2.1.19.4 — Method of test****Initial Condition**

System Simulator: 1 cell.

UE: PS-DCCH\_DCH (state 6-7) as specified in clause 7.4 of TS 34.108.



## Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER SETUP message. The UE transmits RADIO BEARER SETUP COMPLETE message using AM RLC and enters CELL\_PCH state.

## Expected sequence

| Step | Direction |    | Message                     | Comment                      |
|------|-----------|----|-----------------------------|------------------------------|
|      | UE        | SS |                             |                              |
| 1    |           | ←  | RADIO BEARER SETUP          |                              |
| 2    |           | →  | RADIO BEARER SETUP COMPLETE |                              |
| 3    |           |    |                             | The UE is in CELL_PCH state. |

## Specific Message Contents

### RADIO BEARER SETUP (Step 1) (FDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with following exceptions:

| Information Element                                                                         | Value/remark |
|---------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                         | CELL_PCH     |
| Downlink information for each radio link<br>-Primary CPICH info<br>-Primary scrambling code | 100          |

### RADIO BEARER SETUP (Step 1) (TDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with following exceptions:

| Information Element                                                                     | Value/remark |
|-----------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                     | CELL_PCH     |
| Downlink information for each radio links<br>-Primary CCPCH info<br>-Cell parameters ID | 4            |

### 8.2.1.19.5 Test requirement

After step 1, the UE shall transmit a RADIO BEARER SETUP COMPLETE message on uplink DCCH using AM RLC.

After step 2, the UE shall enter CELL\_PCH state.

### 8.2.1.20 Radio Bearer Establishment from CELL\_DCH to URA\_PCH: Success

#### 8.2.1.20.1 Definition

#### 8.2.1.20.2 Conformance requirement

The UE shall configure radio bearers so as to transit from CELL\_DCH state to URA\_PCH state according to the received RADIO BEARER SETUP message and responds with a RADIO BEARER SETUP COMPLETE message on the DCCH using AM RLC.

## Reference

3GPP TS 25.331 clause 8.2.1.

**8.2.1.20.3 Test purpose**

To confirm that the UE transmits a RADIO BEARER SETUP COMPLETE message and enters URA\_PCH state after it received a RADIO BEARER SETUP message for the transition from CELL\_DCH to URA\_PCH from SS.

**8.2.1.20.4 Method of test****Initial Condition**

System Simulator: 1 cell.

UE: PS-DCCH\_DCH (state 6-7) as specified in clause 7.4 of TS 34.108.

**Test Procedure**

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER SETUP message. The UE transmits a RADIO BEARER SETUP COMPLETE message using AM RLC and enters URA\_PCH state.

**Expected sequence**

| Step | Direction |    | Message                     | Comment                     |
|------|-----------|----|-----------------------------|-----------------------------|
|      | UE        | SS |                             |                             |
| 1    |           | ←  | RADIO BEARER SETUP          |                             |
| 2    |           | →  | RADIO BEARER SETUP COMPLETE |                             |
| 3    |           |    |                             | The UE is in URA_PCH state. |

**Specific Message Contents****RADIO BEARER SETUP (Step 1) (FDD)**

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with following exceptions:

| Information Element                                                                           | Value/remark |
|-----------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                           | URA_PCH      |
| Downlink information for each radio link<br>- Primary CPICH info<br>- Primary scrambling code | 100          |

**RADIO BEARER SETUP (Step 1) (TDD)**

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with following exceptions:

| Information Element                                                                       | Value/remark |
|-------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                       | URA_PCH      |
| Downlink information for each radio links<br>- Primary CCPCH info<br>- Cell parameters ID | 4            |

**8.2.1.20.5 Test requirement**

After step 1, the UE shall transmit a RADIO BEARER SETUP COMPLETE message on uplink DCCH using AM RLC.

After step 2, the UE shall enter URA\_PCH state.

### ~~8.2.1.21 RRC connection establishment in CELL\_DCH on another frequency~~

#### ~~8.2.1.21.1 Definition~~

#### ~~8.2.1.21.2 Conformance requirement~~

- ~~1. The UE shall, in the transmitted RRC CONNECTION REQUEST message:~~

- ~~— set the IE "Establishment cause" to the value of the variable ESTABLISHMENT\_CAUSE;~~
- ~~— set the IE "Initial UE identity" to the value of the variable INITIAL\_UE\_IDENTITY;~~
- ~~— set the IE "Protocol error indicator" to the value of the variable PROTOCOL\_ERROR\_INDICATOR;~~
- ~~— include a measurement report in the IE "Measured results on RACH", as specified in the IE "Intra-frequency reporting quantity for RACH reporting" and the IE "Maximum number of reported cells on RACH" in System Information Block type 11.~~

- ~~2. The UE shall compare the value of the IE "Initial UE identity" in the received RRC CONNECTION SETUP message with the value of the variable INITIAL\_UE\_IDENTITY.~~

~~If the values are identical, the UE shall:~~

- ~~— perform the physical layer synchronization procedure~~

#### ~~Reference~~

~~3GPP TS 25.331 clauses 8.3.1.3, 8.3.1.6~~

#### ~~8.2.1.21.3 Test Purpose~~

~~To confirm that the UE manages to synchronize on another frequency when so required by UTRAN in the RRC CONNECTION SET UP message.~~

#### ~~8.2.1.21.4 Method of test~~

##### ~~Initial condition~~

~~System simulator: 2 cells — Cell 1 on UARFCN 1 and Cell 2 on UARFCN 2.~~

~~UE: "Registered idle mode on CS" (state 2) or "Registered idle mode on PS" (state 3) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE. If the UE supports both CS and PS domains, the initial state shall be "Registered idle mode on CS/PS" (state 7).~~

##### ~~Test procedure~~

~~The UE is initially in idle mode and is camping on cell 1. SIB 11 is broadcast in cell 1, and the parameters used are as specified below.~~

~~SS prompts the operator to make an outgoing call of a supported traffic class. The UE shall transmit an RRC CONNECTION REQUEST on the CCCH, and SS replies with the RRC CONNECTION SETUP, in which the IEs are set as described below. The UE shall send the RRC CONNECTION SETUP COMPLETE back to SS in cell 2 on the DPCH described in the RRC CONNECTION SET UP message received from the SS.~~

## Expected sequence

| Step | Direction |    | Message                       | Comment                                                                                |
|------|-----------|----|-------------------------------|----------------------------------------------------------------------------------------|
|      | UE        | SS |                               |                                                                                        |
| 1    | →         |    | RRC CONNECTION REQUEST        | By outgoing call operation                                                             |
| 2    | ←         |    | RRC CONNECTION SETUP          |                                                                                        |
| 3    |           |    |                               | The UE configures the layer 2 and layer 1.                                             |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE | This message is sent to on the frequency indicated in the RRC CONNECTION SETUP message |

## Specific message content

All messages indicated below shall use the same content as described in the default message content, with the following exceptions:

## System Information Block type 11

| Information Element                              | Value/Remark                        |
|--------------------------------------------------|-------------------------------------|
| SIB12 indicator                                  | FALSE                               |
| FACH measurement occasion info                   | Not Present                         |
| Measurement control system information           |                                     |
| — Intra-frequency measurement system information |                                     |
| — Intra-frequency measurement identity           | 1                                   |
| — Intra-frequency cell info list                 |                                     |
| — CHOICE intra-frequency cell removal            | Remove no intra-frequency cells     |
| — New intra-frequency info list                  |                                     |
| — Intra-frequency cell id                        | 1                                   |
| — Cell info                                      |                                     |
| — Cell individual offset                         | 0 dB                                |
| — Reference time difference to cell              | 256 chips                           |
| — Read SFN Indicator                             | FALSE                               |
| — CHOICE Mode                                    | FDD                                 |
| — Primary CPICH Info                             |                                     |
| — Primary Scrambling Code                        | Set to same code as used for cell 1 |
| — Primary CPICH TX power                         | Not Present                         |
| — TX Diversity Indicator                         | FALSE                               |
| — Cell selection and Re-selection                | Not present                         |
| — Cell for measurement                           | Not present                         |
| — Intra-frequency measurement quantity           | Not present                         |
| — Intra-frequency measurement for RACH reporting |                                     |
| — SFN-SFN observed time difference               | No report                           |
| — Reporting quantity                             | CPICH Ec/No                         |
| — Maximum number of reported cells on RACH       | Current Cell                        |
| — Reporting information for state CELL_DCH       | Not present                         |

## RRC CONNECTION REQUEST (Step 2)

Use the same message type found in clause 9 of TS 34.108, with the following exception:

| Information Element      | Value/remark                                     |
|--------------------------|--------------------------------------------------|
| Measured results on RACH | Check that the Ec/No for the cell 1 is reported. |

## RRC CONNECTION SETUP (Step 3)

Use the same message type found in clause 9 of TS 34.108, with the following exception:

| Information Element  | Value/remark              |
|----------------------|---------------------------|
| Frequency info       |                           |
| -UARFCN uplink(Nu)   | UARFCN uplink of cell 2   |
| -UARFCN downlink(Nd) | UARFCN downlink of cell 2 |

#### 8.2.1.21.5 Test requirement

In step 4, the UE shall send the RRC CONNECTION SETUP COMPLETE message on the frequency indicated in the RRC CONNECTION SETUP message.

### 8.2.2 Radio Bearer Reconfiguration

#### 8.2.2.1 Radio Bearer Reconfiguration from CELL\_DCH to CELL\_DCH: Success

##### 8.2.2.1.1 Definition

##### 8.2.2.1.2 Conformance requirement

The UE shall correctly reconfigure a radio bearer and L1 according to the RADIO BEARER RECONFIGURATION message, which specifies a hard handover to another UL scrambling code and responds with a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.2.

##### 8.2.2.1.3 Test purpose

To confirm that the UE reconfigures the radio bearers according to a RADIO BEARER RECONFIGURATION message, which indicates a hard handover to another UL scrambling code.

##### 8.2.2.1.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE, which commands a hard handover in the same cell to a new UL scrambling code to be performed. The UE reconfigures the new physical channel and transmits a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

## Expected sequence

| Step | Direction |    | Message                                  | Comment                         |
|------|-----------|----|------------------------------------------|---------------------------------|
|      | UE        | SS |                                          |                                 |
| 1    |           |    | Void                                     |                                 |
| 2    |           |    | Void                                     |                                 |
| 3    |           | ←  | RADIO-BEARER<br>RECONFIGURATION          | UL-scrambling-code is modified. |
| 4    |           | →  | RADIO-BEARER<br>RECONFIGURATION COMPLETE |                                 |

## Specific Message Contents

## RADIO-BEARER RECONFIGURATION (FDD)

The contents of RADIO-BEARER RECONFIGURATION message in this test case is identical to the message sub-type titled as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A, with the following exceptions:

| Information Element                                                                                               | Value/remark |
|-------------------------------------------------------------------------------------------------------------------|--------------|
| Uplink DPCH Info<br>—— Scrambling code number                                                                     | 1            |
| Downlink information common for all radio links<br>—— Downlink DPCH info common for all RL<br>—— Timing Indicator | Maintain     |

## RADIO-BEARER RECONFIGURATION (TDD)

The contents of RADIO-BEARER RECONFIGURATION message in this test case is identical to the message sub-type titled "Packet to CELL\_DCH from CELL\_DCH in PS" in Annex A, with the following exceptions:

| Information Element                                                                                               | Value/remark   |
|-------------------------------------------------------------------------------------------------------------------|----------------|
| Uplink DPCH timeslots and codes<br>—— First timeslot code list                                                    | Assigned by SS |
| Downlink information common for all radio links<br>—— Downlink DPCH info common for all RL<br>—— Timing Indicator | Maintain       |

## 8.2.2.1.5 ——— Test requirement

After step 3 the UE shall transmit a RADIO-BEARER RECONFIGURATION COMPLETE message on the new DPCH after the specified activation time has expired.

## 8.2.2.2 ——— Radio Bearer Reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Unsupported configuration)

## 8.2.2.2.1 ——— Definition

## 8.2.2.2.2 ——— Conformance requirement

The UE shall keep its old configuration when the UE receives a RADIO-BEARER RECONFIGURATION message which includes unsupported configuration parameters and transmit a RADIO-BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "configuration unsupported" in IE "failure cause."

## Reference

3GPP TS 25.331 clause 8.2.2.

### 8.2.2.2.3 Test purpose

To confirm that the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if the received RADIO BEARER RECONFIGURATION message includes unsupported configuration parameters.

### 8.2.2.2.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE, which includes unsupported configuration parameters for the UE. The UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "configuration unsupported" in IE "failure cause".

#### Expected sequence

| Step | Direction |    | Message                              | Comment                                       |
|------|-----------|----|--------------------------------------|-----------------------------------------------|
|      | UE        | SS |                                      |                                               |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION         | Including unsupported configuration by the UE |
| 2    |           | →  | RADIO BEARER RECONFIGURATION FAILURE | The UE does not change the radio bearer.      |

#### Specific Message Contents

##### RADIO BEARER RECONFIGURATION (FDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element     | Value/remark |
|-------------------------|--------------|
| Frequency info          |              |
| —— UARFCN uplink (Nu)   | 0            |
| —— UARFCN downlink (Nd) | 950          |

##### RADIO BEARER RECONFIGURATION (TDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| Frequency info      |              |
| —— UARFCN (Nt)      | 0            |

##### RADIO BEARER RECONFIGURATION FAILURE

The contents of RADIO BEARER RECONFIGURATION FAILURE message in this test case is the same as the RADIO BEARER RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark              |
|---------------------|---------------------------|
| Failure-cause       | Configuration unsupported |

#### 8.2.2.2.5 ~~Test requirement~~

After step 1 the UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC with the value "configuration unsupported" set in IE "failure cause".

#### 8.2.2.3 ~~Radio Bearer Reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Physical channel failure and reversion to old configuration)~~

##### 8.2.2.3.1 ~~Definition~~

##### 8.2.2.3.2 ~~Conformance requirement~~

The UE shall revert to the old configuration when the UE fails to reconfigure the new physical channel before timer T312 expires. UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "physical channel failure" in IE "failure cause".

#### Reference

3GPP TS 25.331 clause 8.2.2.

##### 8.2.2.3.3 ~~Test purpose~~

To confirm that the UE reverts to the old configuration and transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, if the UE fails to reconfigure the radio bearer expires according to the RADIO BEARER RECONFIGURATION message before timer T312.

##### 8.2.2.3.4 ~~Method of test~~

#### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message including the new radio bearer parameters to the UE but it keeps its current dedicated physical channel configuration. The UE shall revert to the old configuration. Then the UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting value "physical channel failure" in IE "failure cause".

#### Expected sequence

| Step | Direction |    | Message                              | Comment                                                                                                                            |
|------|-----------|----|--------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                      |                                                                                                                                    |
| 1    | ←         |    | RADIO BEARER RECONFIGURATION         |                                                                                                                                    |
| 2    |           |    |                                      | SS does not reconfigure L1.                                                                                                        |
| 3    | →         |    | RADIO BEARER RECONFIGURATION FAILURE | The UE shall detect a failure to reconfigure the new radio bearer, and send this message using the old radio bearer configuration. |



## Specific Message Contents

### RADIO BEARER RECONFIGURATION

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to the message sub-type titled as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A.

### RADIO BEARER RECONFIGURATION FAILURE

The contents of RADIO BEARER RECONFIGURATION FAILURE message in this test case is the same as the RADIO BEARER RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark             |
|---------------------|--------------------------|
| Failure-cause       | Physical-channel failure |

#### 8.2.2.3.5 ——— Test requirement

After step 2 the UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC setting value "physical channel failure" in IE "failure-cause".

#### 8.2.2.4 ——— Radio Bearer Reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Physical channel failure and reversion failure)

##### 8.2.2.4.1 ——— Definition

##### 8.2.2.4.2 ——— Conformance requirement

The UE shall perform a cell update when the UE fails to revert to the old configuration after the detection of physical channel failure in the radio bearer reconfiguration procedure. After the UE completes cell update procedure, the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set IE "failure-cause" to "physical channel failure".

## Reference

3GPP TS 25.331 clause 8.2.2.

##### 8.2.2.4.3 ——— Test purpose

To confirm that the UE transmits a RADIO BEARER SETUP FAILURE message after it completes a cell update procedure when the UE cannot reconfigure the new radio bearer and a subsequent failure to revert to the old configuration.

##### 8.2.2.4.4 ——— Method of test

## Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

## Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message, which includes the new radio bearer parameters, to the UE. After the reception of the acknowledgement for the RADIO BEARER RECONFIGURATION message in SS, the SS shall not reconfigure dedicated physical channel in accordance with the settings in the message and release the previous configuration. The UE discovers that it cannot reconfigure the new

radio-bearer and wants to revert to the old configuration, but the UE cannot revert to the old configuration. The UE transmits a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "radio link failure". The SS shall transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving a CELL UPDATE message. The UE transmits a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC and subsequently transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the value "physical channel failure" to IE "failure cause".

#### Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                                                                                                         |
|------|-----------|----|-------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                                                 |
| 1    | ←         |    | RADIO BEARER RECONFIGURATION              |                                                                                                                                                                 |
| 2    |           |    |                                           | The SS does not reconfigure the dedicated physical channel in accordance with the RADIO BEARER RECONFIGURATION message and shall release the old configuration. |
| 3    | →         |    | CELL UPDATE                               | The value "radio link failure" shall be set in IE "Cell update cause".                                                                                          |
| 4    |           |    |                                           | The SS configures the dedicated physical channel according to the IE "Physical channel information elements" included in the CELL UPDATE CONFIRM message.       |
| 5    | ←         |    | CELL UPDATE CONFIRM                       | This message include IE "Physical channel information elements".                                                                                                |
| 6    | →         |    | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                                                                 |
| 7    | →         |    | RADIO BEARER RECONFIGURATION FAILURE      | The IE "failure cause" shall be set to "physical channel failure"                                                                                               |

#### Specific Message Contents

##### RADIO BEARER RECONFIGURATION message (Step 1)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to the message sub-type titled as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as as found in Annex A.

##### CELL UPDATE (Step 3)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark         |
|---------------------|----------------------|
| Cell Update Cause   | "radio link failure" |

**CELL UPDATE CONFIRM (Step 5) (FDD)**

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A with the following exceptions:

| Information Element                       | Value/remark                                                         |
|-------------------------------------------|----------------------------------------------------------------------|
| RRC State indicator                       | CELL_DCH                                                             |
| UplinkDPCH Info                           | Same as RADIO BEARER SETUP message used to move to initial condition |
| Downlink information for each radio links | Same as RADIO BEARER SETUP message used to move to initial condition |

**CELL UPDATE CONFIRM (Step 5) (TDD)**

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A with the following exceptions:

| Information Element                       | Value/remark                                                         |
|-------------------------------------------|----------------------------------------------------------------------|
| RRC State Indicator                       | CELL_DCH                                                             |
| Uplink DPCH timeslots and codes           | Same as RADIO BEARER SETUP message used to move to initial condition |
| Downlink information for each radio links | Same as RADIO BEARER SETUP message used to move to initial condition |

**RADIO BEARER RECONFIGURATION FAILURE (Step 7)**

The contents of RADIO BEARER RECONFIGURATION FAILURE message in this test case is the same as the RADIO BEARER RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark               |
|---------------------|----------------------------|
| Failure cause       | "physical channel failure" |

**8.2.2.4.5 — Test requirement**

After step 2 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "radio link failure".

After step 5 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE on the uplink DCCH using AM RLC.

After step 6 the UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the IE "failure cause" to "physical channel failure".

**8.2.2.5 — Radio Bearer Reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)****8.2.2.5.1 — Definition****8.2.2.5.2 — Conformance requirement**

If the UE receives a RADIO BEARER RECONFIGURATION message during a reconfiguring procedure due to a radio bearer message other than RADIO BEARER RECONFIGURATION message, it shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC.

**Reference**

3GPP TS 25.331 clause 8.2.2, clause 8.6.3.11.

### 8.2.2.5.3 ~~Test purpose~~

To confirm that if the UE receives a RADIO BEARER RECONFIGURATION message during a reconfiguring procedure due to a radio bearer message other than RADIO BEARER RECONFIGURATION, it shall keep its configuration as if the RADIO BEARER RECONFIGURATION message had not been received and complete the reconfiguration procedure according to the previously received message.

### 8.2.2.5.4 ~~Method of test~~

#### Initial Condition

System Simulator: 1 cell.

UE: CS\_DCCH\_DCH (state 6-5) or PS\_DCCH\_DCH (state 6-7) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER SETUP message to the UE. The SS transmits a RADIO BEARER RECONFIGURATION message before the "activation time" indicated in the RADIO BEARER SETUP message expires. When the UE receives the RADIO BEARER RECONFIGURATION message, the UE shall keep its current configuration as if it had not received the RADIO BEARER RECONFIGURATION message and shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC with IE "failure cause" set to "incompatible simultaneous reconfiguration". After the SS acknowledges the RADIO BEARER RECONFIGURATION FAILURE message, the UE reconfigures the new physical channel parameters upon the specified activation time and transmits a RADIO BEARER SETUP COMPLETE message on DCCH using AM RLC.

#### Expected sequence

| Step | Direction |    | Message                              | Comment                                                                                                   |
|------|-----------|----|--------------------------------------|-----------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                      |                                                                                                           |
| 1    |           | ←  | RADIO BEARER SETUP                   |                                                                                                           |
| 2    |           | ←  | RADIO BEARER RECONFIGURATION         | Sent before the "activation time" in step 1 has elapsed                                                   |
| 3    |           | →  | RADIO BEARER RECONFIGURATION FAILURE | The UE does not change its configuration according to the RADIO BEARER RECONFIGURATION message in step 2. |
| 4    |           | →  | RADIO BEARER SETUP COMPLETE          | This message is on DCCH using AM RLC.                                                                     |

#### Specific Message Contents

##### RADIO BEARER SETUP (Step 1) (FDD)

For RADIO BEARER SETUP message in step 1, use the message sub-type indicated as "Non speech in CS" as found in Annex A or the RADIO BEARER SETUP message as found in clause 9 of TS 34.108, with following exceptions:

| Information Element                          | Value/remark                        |
|----------------------------------------------|-------------------------------------|
| Activation Time                              | Current CFN-[current CFN mod 8 + 8] |
| Uplink DPCH Info<br>— Scrambling code number | 1                                   |

##### RADIO BEARER SETUP (Step 1) (TDD)

For RADIO BEARER SETUP message in step 1, use the message sub-type indicated as "Non speech in CS" as found in Annex A or the RADIO BEARER SETUP message as found in clause 9 of TS 34.108, with following exceptions:

| Information Element                                            | Value/remark                        |
|----------------------------------------------------------------|-------------------------------------|
| Activation Time                                                | Current CFN-[current CFN mod 8 + 8] |
| Uplink DPCH timeslots and codes<br>—— First timeslot code list | Assigned by SS                      |

### RADIO BEARER RECONFIGURATION (Step 2)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to those in the default contents of layer 3 messages for RRC tests with the following exceptions as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with following exceptions:

| Information Element                           | Value/remark |
|-----------------------------------------------|--------------|
| Activation Time                               | Not Present. |
| Uplink DPCH Info<br>—— Scrambling code number | 2            |

### RADIO BEARER RECONFIGURATION FAILURE

The contents of RADIO BEARER RECONFIGURATION FAILURE message in this test case is the same as the RADIO BEARER RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark                              |
|---------------------|-------------------------------------------|
| Failure cause       | Incompatible simultaneous reconfiguration |

#### 8.2.2.5.5 ——— Test requirement

After step 2, the UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC with IE "failure cause" set to "Incompatible simultaneous reconfiguration".

After step 3, the UE shall transmit a RADIO BEARER SETUP COMPLETE message on the DCCH using AM RLC.

#### 8.2.2.6 ——— Radio Bearer Reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Invalid message reception and Invalid configuration)

##### 8.2.2.6.1 ——— Definition

##### 8.2.2.6.2 ——— Conformance requirement

The UE shall keep its old configuration when the UE receives an invalid RADIO BEARER RECONFIGURATION message, which does not includes any IEs except IE "Message Type". The UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message which is set to "protocol error" in IE "failure cause" and is set to "ASN.1 violation or encoding error" in IE "Protocol error cause".

The UE shall keep existing configuration upon reception of a RADIO BEARER RECONFIGURATION message, which includes some IEs set to give an invalid configuration, and then the UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message including IE "failure cause" set to "invalid configuration".

#### Reference

3GPP TS 25.331 clause 8.2.2.

##### 8.2.2.6.3 ——— Test purpose

To confirm that the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, if it receives an invalid RADIO BEARER RECONFIGURATION message which does not include any IEs except IE "Message Type".

To confirm that the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if it receives a RADIO BEARER RECONFIGURATION message including some IEs set to give an invalid configuration.

#### 8.2.2.6.4 Method of test

##### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

##### Test Procedure

The UE is in CELL\_DCH state. The SS transmits an invalid RADIO BEARER RECONFIGURATION message to the UE which does not include any IEs except IE "Message Type". The UE keeps the old configuration and transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "protocol error" in IE "failure cause" and is set to "ASN.1 violation or encoding error" in IE "Protocol error cause". The UE keeps current configuration after SS transmits a RADIO BEARER RECONFIGURATION message including some IEs set to give an invalid configuration. Then UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the value "invalid configuration" to IE "failure cause".

##### Expected sequence

| Step | Direction |    | Message                              | Comment                                                        |
|------|-----------|----|--------------------------------------|----------------------------------------------------------------|
|      | UE        | SS |                                      |                                                                |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION         | See specific message content.                                  |
| 2    |           | →  | RADIO BEARER RECONFIGURATION FAILURE | The UE does not change the configuration.                      |
| 3    |           | ←  | RADIO BEARER RECONFIGURATION         | This message includes IE set to give an invalid configuration. |
| 4    |           | →  | RADIO BEARER RECONFIGURATION FAILURE | The UE does not change the configuration.                      |

##### Specific Message Contents

##### RADIO BEARER RECONFIGURATION (Step 1)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

##### RADIO BEARER RECONFIGURATION FAILURE (Step 2)

The contents of RADIO BEARER RECONFIGURATION FAILURE message in this test case is the same as the RADIO BEARER RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element          | Value/remark                      |
|------------------------------|-----------------------------------|
| Failure cause                |                                   |
| → Failure cause              | Protocol error                    |
| → Protocol error information |                                   |
| → Protocol error cause       | ASN.1 violation or encoding error |

##### RADIO BEARER RECONFIGURATION (Step 3) (FDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" found in Annex A with following exceptions:

| Information Element                   | Value/remark |
|---------------------------------------|--------------|
| <del>Default DPCCH Offset Value</del> | 512          |
| <del>DPCCH frame offset</del>         | 1024         |

#### RADIO BEARER RECONFIGURATION (Step 3) (TDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" found in Annex A with following exceptions:

| Information Element   | Value/remark |
|-----------------------|--------------|
| <del>PRACH TFCS</del> | Present      |

#### RADIO BEARER RECONFIGURATION FAILURE (Step 5)

The contents of RADIO BEARER RECONFIGURATION FAILURE message in this test case is the same as the RADIO BEARER RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark          |
|---------------------|-----------------------|
| Failure cause       | Invalid configuration |

#### 8.2.2.6.5 ~~Test requirement~~

After step 1 the UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC stating the reason "protocol error" in IE "failure cause". The message shall contain the value "ASN.1 violation or encoding error" in IE "Protocol error cause".

After step 3 the UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the value "invalid configuration" to IE "failure cause".

#### 8.2.2.7 ~~Radio Bearer Reconfiguration from CELL\_DCH to CELL\_DCH: Success (Continue and stop)~~

##### 8.2.2.7.1 ~~Definition~~

##### 8.2.2.7.2 ~~Conformance requirement~~

If the IE "RB information to reconfigure" is included, the UE shall apply the following actions on the radio bearer identified with the value of the IE "RB identity". The UE shall:

...

- if the IE "RB stop/continue" is included; and
  - if the "RB identity" has a value greater than 2; and
    - if the value of the IE "RB stop/continue" is "stop":
      - configure the RLC entity for the radio bearer to stop;
      - set the IE "RB started" in the variable ESTABLISHED\_RABS to "stopped" for that radio bearer;
    - if the value of the IE "RB stop/continue" is "continue":
      - configure the RLC entity for the radio bearer to continue;
      - set the IE "RB started" in the variable ESTABLISHED\_RABS to "started" for that radio bearer;

## Reference

3GPP TS 25.331 clause 8.2.2, 8.6.4.5.

### 8.2.2.7.3 Test purpose

To confirm that the UE reconfigures new radio bearer and stop the transmission and reception of the RLC entity belonging to the RB identity specified in the RADIO BEARER RECONFIGURATION message.

To confirm that the UE reconfigures new radio bearer and restart the transmission and reception of the RLC entity belonging to the RB identity specified in the RADIO BEARER RECONFIGURATION message.

### 8.2.2.7.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message including IE "RB-stop/continue" set to "continue" for radio bearer with RB identity '3'. The UE reconfigures new radio bearer and transmits a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC. Then, the SS transmits an IDENTITY REQUEST message using AM RLC, the UE responds a IDENTITY RESPONSE message. The SS transmits a RADIO BEARER RECONFIGURATION message including IE "RB-stop/continue" set to "stop" for radio bearer with RB identity "3". The UE reconfigures new radio bearer and transmits a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC. Then, the SS transmits a IDENTITY REQUEST message using AM RLC, the UE does not acknowledge this message and also does not respond with a IDENTITY RESPONSE message.

#### Expected sequence

| Step | Direction |    | Message                               | Comment                                                       |
|------|-----------|----|---------------------------------------|---------------------------------------------------------------|
|      | UE        | SS |                                       |                                                               |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION          | This message include IE "RB stop/continue" set to "continue". |
| 2    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE |                                                               |
| 3    |           | ←  | IDENTITY REQUEST                      |                                                               |
| 3a   |           | →  | IDENTITY RESPONSE                     |                                                               |
| 4    |           | ←  | RADIO BEARER RECONFIGURATION          | This message include IE "RB stop/continue" set to "stop".     |
| 5    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE |                                                               |
| 6    |           | ←  | IDENTITY REQUEST                      |                                                               |
| 7    |           | →  |                                       | The SS shall not receive any data from the UE.                |

#### Specific Message Contents

##### RADIO BEARER RECONFIGURATION (Step 1)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" found in Annex A with the following exceptions:



| Information Element                                                                                          | Value/remark    |
|--------------------------------------------------------------------------------------------------------------|-----------------|
| RB information to reconfigure list<br>— RB information to reconfigure<br>— RB identity<br>— RB stop/continue | 3<br>"continue" |

#### RADIO BEARER RECONFIGURATION (Step 4)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element                                                                                          | Value/remark |
|--------------------------------------------------------------------------------------------------------------|--------------|
| RB information to reconfigure list<br>— RB information to reconfigure<br>— RB identity<br>— RB stop/continue | 3<br>"stop"  |

#### 8.2.2.7.5 Test requirement

After step 3 the UE shall respond with a IDENTITY RESPONSE message.

After step 6 the UE shall not respond with a IDENTITY RESPONSE message on the stopped RB.

#### 8.2.2.8 Radio Bearer Reconfiguration from CELL\_DCH to CELL\_FACH: Success

##### 8.2.2.8.1 Definition

##### 8.2.2.8.2 Conformance requirement

The UE shall correctly reconfigure radio bearers according to a RADIO BEARER RECONFIGURATION message, which invoke a transition from CELL\_DCH to CELL\_FACH in the same cell and responds with a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.2.

##### 8.2.2.8.3 Test purpose

To confirm that the UE establishes the reconfigured radio bearer(s) using common physical channel, after UE receives a RADIO BEARER RECONFIGURATION message.

##### 8.2.2.8.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message, which invoke a transition from CELL\_DCH to CELL\_FACH. The UE reconfigures the radio bearers and transmits a RADIO BEARER RECONFIGURATION COMPLETE message using AM RLC.

## Expected sequence

| Step | Direction |    | Message                               | Comment                                                                                     |
|------|-----------|----|---------------------------------------|---------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                             |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION          |                                                                                             |
| 2    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE | The UE selects PRACH and S-CCPCH indicated in SIB5 and SIB6 after entering CELL_FACH state. |

## Specific Message Contents

## RADIO BEARER RECONFIGURATION (Step 1)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with the following exception:

| Information Element | Value/remark         |
|---------------------|----------------------|
| New C-RNTI          | 0000 0000 0000 0001B |

## 8.2.2.8.5 — Test requirement

After step 1 the UE shall transmit a RADIO BEARER RECONFIGURATION message.

## 8.2.2.9 — Radio Bearer Reconfiguration from CELL\_DCH to CELL\_FACH: Success (Cell re-selection)

## 8.2.2.9.1 — Definition

## 8.2.2.9.2 — Conformance requirement

The UE shall initiate cell update procedure when the UE performs cell reselection during radio bearer reconfiguration procedure. After the UE completes cell update procedure, the UE shall continue to perform a radio bearer reconfiguration procedure and correctly reconfigure the radio bearer.

## Reference

3GPP TS 25.331 clause 8.2.2.

## 8.2.2.9.3 — Test purpose

To confirm that the UE transmits RADIO BEARER RECONFIGURATION COMPLETE message after it completes a cell update procedure.

## 8.2.2.9.4 — Method of test

## Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108.

## Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message, which includes IE "Primary CPICH info" and no dedicated physical channel information to transit from CELL\_DCH to CELL\_FACH. As the UE cannot detect the specified cell, the UE shall initial the cell update procedure. The UE transmits a CELL

UPDATE message on uplink CCCH with IE "Cell update cause" set to "cell reselection". The SS shall transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving a CELL UPDATE message. The UE transmits a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### Expected sequence

| Step | Direction |    | Message                               | Comment                                                              |
|------|-----------|----|---------------------------------------|----------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                      |
| 1    |           |    | Void                                  |                                                                      |
| 2    |           |    | Void                                  |                                                                      |
| 3    |           | ←  | RADIO BEARER RECONFIGURATION          | Assign a transition from CELL_DCH to CELL_FACH.                      |
| 4    |           | →  | CELL UPDATE                           | The value "cell reselection" shall be set in IE "Cell update cause". |
| 5    |           | ←  | CELL UPDATE CONFIRM                   |                                                                      |
| 6    |           |    | Void                                  |                                                                      |
| 7    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE |                                                                      |

#### Specific Message Contents

##### RADIO BEARER RECONFIGURATION (Step 3) (FDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Packet to CELL\_FACH from CELL\_DCH in PS" found in Annex A with the following exceptions:

| Information Element                                                                              | Value/remark |
|--------------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>—— Primary CPICH info<br>—— Primary scrambling code | 150          |

##### RADIO BEARER RECONFIGURATION (Step 3) (TDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Packet to CELL\_FACH from CELL\_DCH in PS" found in Annex A with the following exceptions:

| Information Element                                                                         | Value/remark |
|---------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>—— Primary CCPCH info<br>—— Cell parameters ID | 4            |

##### CELL UPDATE (Step 4)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark       |
|---------------------|--------------------|
| Cell Update Cause   | "Cell reselection" |

##### CELL UPDATE CONFIRM (Step 5)

The contents of CELL UPDATE CONFIRM message are same as "CELL UPDATE CONFIRM message" as found in Annex A.

#### 8.2.2.9.5 ——— Test requirement

After step 3, the UE shall transmit CELL UPDATE message on the CCCH with IE "Cell update cause" set to "cell reselection".

After step 5, the UE shall transmit RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### ~~8.2.2.10 Radio Bearer Reconfiguration: from CELL\_FACH to CELL\_DCH: Success~~

##### ~~8.2.2.10.1 Definition~~

##### ~~8.2.2.10.2 Conformance requirement~~

The UE shall correctly reconfigure radio bearers according to a RADIO BEARER RECONFIGURATION message, which invoke a transition from CELL\_FACH to CELL\_DCH in the same cell and responds with a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

##### Reference

3GPP TS 25.331 clause 8.2.2.

##### ~~8.2.2.10.3 Test purpose~~

To confirm that the UE reconfigures the radio bearers according to a RADIO BEARER RECONFIGURATION message.

##### ~~8.2.2.10.4 Method of test~~

##### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

##### Test Procedure

The UE is in CELL\_FACH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE. The UE reconfigures the radio bearers and transmits a RADIO BEARER RECONFIGURATION COMPLETE message using AM RLC.

##### Expected sequence

| Step | Direction |    | Message                               | Comment                                     |
|------|-----------|----|---------------------------------------|---------------------------------------------|
|      | UE        | SS |                                       |                                             |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION          | This message includes IE "Uplink DPCH Info" |
| 2    |           |    |                                       | Reconfiguration of radio bearer             |
| 3    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE |                                             |

##### Specific Message Contents

##### RADIO BEARER RECONFIGURATION (Step 1)

Use the same message sub-type titled "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A.

##### ~~8.2.2.10.5 Test requirement~~

After step 2 the UE shall transmit a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

### 8.2.2.11 ~~Radio Bearer Reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Unsupported configuration)~~

#### 8.2.2.11.1 ~~Definition~~

#### 8.2.2.11.2 ~~Conformance requirement~~

~~The UE shall keep its current configuration when the UE receives a RADIO BEARER RECONFIGURATION message which includes unsupported configuration parameters and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "configuration-unsupported" in IE "failure-cause"~~

#### Reference

3GPP TS 25.331 clause 8.2.2.

#### 8.2.2.11.3 ~~Test purpose~~

~~To confirm that the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if the received RADIO BEARER RECONFIGURATION message includes unsupported configuration parameters.~~

#### 8.2.2.11.4 ~~Method of test~~

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

~~The UE is in CELL\_FACH state. The SS transmits a RADIO BEARER RECONFIGURATION message, which includes unsupported configuration parameters, to the UE. The UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC and set "configuration-unsupported" in IE "failure-cause".~~

#### Expected sequence

| Step | Direction |    | Message                              | Comment                                                      |
|------|-----------|----|--------------------------------------|--------------------------------------------------------------|
|      | UE        | SS |                                      |                                                              |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION         | The message includes an unsupported configuration for the UE |
| 2    |           | →  | RADIO BEARER RECONFIGURATION FAILURE | The UE does not change the radio-bearer.                     |

#### Specific Message Contents

#### RADIO BEARER RECONFIGURATION (FDD)

~~The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:~~

| Information Element             | Value/remark |
|---------------------------------|--------------|
| Frequency info                  |              |
| <del>UARFCN uplink (Nu)</del>   | 0            |
| <del>UARFCN downlink (Nd)</del> | 950          |

### RADIO-BEARER RECONFIGURATION (TDD)

The contents of RADIO-BEARER RECONFIGURATION message in this test case is identical as "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element              | Value/remark |
|----------------------------------|--------------|
| Frequency info<br>—— UARFCN (Nt) | 0            |

### RADIO-BEARER RECONFIGURATION FAILURE

The contents of RADIO-BEARER RECONFIGURATION FAILURE message in this test case is the same as the RADIO-BEARER RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark              |
|---------------------|---------------------------|
| Failure cause       | Configuration unsupported |

#### 8.2.2.11.5 ——— Test requirement

After step 1 the UE shall transmit a RADIO-BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC stating "configuration unsupported" in IE "failure cause".

#### 8.2.2.12 ——— Radio Bearer Reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Physical channel failure and successful reversion to old configuration)

##### 8.2.2.12.1 ——— Definition

##### 8.2.2.12.2 ——— Conformance requirement

The UE shall revert to the old configuration when the UE fails to reconfigure the new physical channel before timer T312 expires and detects the same serving cell only. The UE shall transmit a RADIO-BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "physical channel failure" in IE "failure cause".

### Reference

3GPP TS 25.331 clause 8.2.2.

##### 8.2.2.12.3 ——— Test purpose

To confirm that the UE reverts to the old configuration and transmits a RADIO-BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if the UE fails to reconfigure the new radio bearer before timer T312 expires according to a RADIO-BEARER RECONFIGURATION message.

##### 8.2.2.12.4 ——— Method of test

### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

### Test Procedure

The UE is in CELL\_FACH state. The SS transmits a RADIO-BEARER RECONFIGURATION message, which includes the new radio bearer parameters, to the UE and keep its current physical channel configuration. Therefore, the UE cannot reconfigure the radio bearers and shall attempt cell reselection procedure after T312 expires. Then the UE shall detect the same serving cell only and transmit a RADIO-BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, with the value "physical channel failure" in IE "failure cause".

## Expected sequence

| Step | Direction |    | Message                              | Comment                                                                            |
|------|-----------|----|--------------------------------------|------------------------------------------------------------------------------------|
|      | UE        | SS |                                      |                                                                                    |
| 1    |           | ←  | RADIO-BEARER RECONFIGURATION         |                                                                                    |
| 2    |           | →  | RADIO-BEARER RECONFIGURATION FAILURE | The SS does not reconfigures L1 and the UE fails to reconfigure its radio-bearers. |

## Specific Message Contents

## RADIO-BEARER RECONFIGURATION

Use the same message sub-type titled "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A.

## RADIO-BEARER RECONFIGURATION FAILURE

The contents of RADIO-BEARER RECONFIGURATION FAILURE message in this test case is the same as the RADIO-BEARER RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark             |
|---------------------|--------------------------|
| Failure cause       | Physical channel failure |

## 8.2.2.12.5 — Test requirement

After step 1 the UE shall transmit a RADIO-BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting "physical channel failure" in IE "failure cause".

## 8.2.2.13 — Radio Bearer Reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Physical channel failure and reversion failure)

## 8.2.2.13.1 — Definition

## 8.2.2.13.2 — Conformance requirement

The UE shall perform a cell update procedure when the UE selects another cell after the detection of physical channel failure in the radio bearer reconfiguration procedure. After the UE completes cell update procedure, the UE transmits a RADIO-BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "physical channel failure" in IE "failure cause".

## Reference

3GPP TS 25.331 clause 8.2.2.

## 8.2.2.13.3 — Test purpose

To confirm that the UE transmits a RADIO-BEARER RECONFIGURATION FAILURE message after it completes a cell update procedure due to a physical channel failure in the radio bearer reconfiguration procedure.

## 8.2.2.13.4 — Method of test

## Initial Condition

System Simulator: 2 cells – Cell 1 and 2 are active.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108 in cell 1.

## Test Procedure

Table 8.2.2.13

| Parameter              | Unit           | Cell 1 |     | Cell 2       |     |
|------------------------|----------------|--------|-----|--------------|-----|
|                        |                | T0     | T1  | T0           | T1  |
| UTRA-RF Channel Number |                | Ch. 1  |     | Ch. 1        |     |
| CPICH-E <sub>c</sub>   | dBm / 3.84 MHz | -60    | -75 | -75          | -60 |
| P-CCPCH RSCP (TDD)     | dBm            | -60    | -75 | switched-off | -60 |

Table 8.2.2.13 illustrates the downlink power to be applied for the 2-cells at various time instants of the test execution. SS switches the power settings between columns "T0" and "T1", whenever the description in multi-cell condition specifies a reverse in the transmission power settings for cell 1 and cell 2.

The UE is in CELL\_FACH state in cell 1. The SS transmits a RADIO-BEARER RECONFIGURATION message, which includes the new radio bearer parameters, to the UE but SS does not reconfigure dedicated physical channel in accordance with the settings in the message. At the same time, the SS configures its downlink transmission power settings according to columns "T1" in table 8.2.2.13. The UE recognizes that it cannot synchronize with the SS on the new radio bearers. The UE performs cell reselection and transmits a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "cell reselection". The SS shall transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving a CELL UPDATE message. The UE transmits a RADIO-BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the value "physical channel failure" to IE "failure cause".

## Expected sequence

| Step | Direction |    | Message                              | Comment                                                                                                                                                                                                                                 |
|------|-----------|----|--------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                      |                                                                                                                                                                                                                                         |
| 1    |           | ←  | RADIO-BEARER RECONFIGURATION         |                                                                                                                                                                                                                                         |
| 2    |           |    |                                      | The SS does not reconfigure the dedicated physical channel in accordance with the RADIO-BEARER RECONFIGURATION message and applies the downlink transmission power settings, according to the values in columns "T1" of table 8.2.2.13. |
| 3    |           |    | Void                                 |                                                                                                                                                                                                                                         |
| 4    |           |    | Void                                 |                                                                                                                                                                                                                                         |
| 5    |           | →  | CELL UPDATE                          | The value "cell reselection" shall be set in IE "Cell update cause".                                                                                                                                                                    |
| 6    |           | ←  | CELL UPDATE CONFIRM                  |                                                                                                                                                                                                                                         |
| 7    |           |    | Void                                 |                                                                                                                                                                                                                                         |
| 8    |           | →  | RADIO-BEARER RECONFIGURATION FAILURE | The IE "failure cause" shall be set to "physical channel failure"                                                                                                                                                                       |

## Specific Message Contents

## RADIO-BEARER RECONFIGURATION (Step 1)

Use the same message sub-type titled "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A.

## CELL UPDATE (Step 5)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:



| Information Element                                        | Value/remark                                                                         |
|------------------------------------------------------------|--------------------------------------------------------------------------------------|
| U-RNTI<br>--SRNC Identity<br>--S-RNTI<br>Cell Update Cause | Assigned previously in cell 1<br>Assigned previously in cell 1<br>"cell reselection" |

#### CELL UPDATE CONFIRM (Step 6)

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A.

#### RADIO BEARER RECONFIGURATION FAILURE (Step 8)

The contents of RADIO BEARER RECONFIGURATION FAILURE message in this test case is the same as the RADIO BEARER RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark               |
|---------------------|----------------------------|
| Failure cause       | "physical channel failure" |

#### 8.2.2.13.5 Test requirement

After step 4 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "cell reselection".

After step 7 the UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the IE "failure cause" to "physical channel failure".

#### 8.2.2.14 Radio Bearer Reconfigure from CELL\_FACH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

##### 8.2.2.14.1 Definition

##### 8.2.2.14.2 Conformance requirement

If the UE receives a RADIO BEARER RECONFIGURATION message during a reconfiguring procedure due to a radio bearer message other than RADIO BEARER RECONFIGURATION message, it shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.2, clause 8.6.3.11.

##### 8.2.2.14.3 Test purpose

To confirm that if the UE receives a RADIO BEARER RECONFIGURATION message during a reconfiguring procedure due to a radio bearer message other than RADIO BEARER RECONFIGURATION, it shall keep its configuration as if the RADIO BEARER RECONFIGURATION message had not been received and complete the reconfiguration procedure according to the previously received message.

##### 8.2.2.14.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

## Test Procedure

The UE is in CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE. The SS transmits a RADIO BEARER RECONFIGURATION message before the "activation time" indicated in the PHYSICAL CHANNEL RECONFIGURATION message expires. When the UE receives the RADIO BEARER RECONFIGURATION message, the UE shall keep the configuration as if it had not received the RADIO BEARER RECONFIGURATION message and shall transmit a RADIO RECONFIGURATION SETUP FAILURE message on the DCCH using AM RLC with IE "failure cause" set to "incompatible simultaneous reconfiguration". After the SS acknowledges the RADIO BEARER RECONFIGURATION FAILURE message, the UE reconfigures the new physical channel parameters and transmits a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on DCCH using AM RLC.

## Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                                         |
|------|-----------|----|-------------------------------------------|-------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                 |
| 1    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          |                                                                                                 |
| 2    |           | ←  | RADIO BEARER RECONFIGURATION              | Sent before the elapse of the "Activation Time" indicated in the previous message.              |
| 3    |           | →  | RADIO BEARER RECONFIGURATION FAILURE      | The UE does not change its configuration according to the RADIO BEARER RECONFIGURATION message. |
| 4    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE | This message is on DCCH using AM RLC                                                            |

## Specific Message Contents

### PHYSICAL CHANNEL RECONFIGURATION (Step 1) (FDD)

For PHYSICAL CHANNEL RECONFIGURATION in step 1, use the message sub-type indicated as "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element      | Value/remark                        |
|--------------------------|-------------------------------------|
| Activation Time          | Current CFN-[current CFN mod 8 + 8] |
| Uplink DPCH Info         |                                     |
| → Scrambling code number | 1                                   |

### PHYSICAL CHANNEL RECONFIGURATION (Step 1) (TDD)

For PHYSICAL CHANNEL RECONFIGURATION in step 1, use the message sub-type indicated as "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element             | Value/remark                        |
|---------------------------------|-------------------------------------|
| Activation Time                 | Current CFN-[current CFN mod 8 + 8] |
| Uplink DPCH timeslots and codes |                                     |
| → First timeslot code list      | Assigned by SS                      |

### RADIO BEARER RECONFIGURATION (Step 2) (FDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element      | Value/remark |
|--------------------------|--------------|
| Activation Time          | Not Present  |
| Uplink DPCH Info         |              |
| → Scrambling code number | 2            |

### RADIO BEARER RECONFIGURATION (Step 2) (TDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element                                                               | Value/remark                                         |
|-----------------------------------------------------------------------------------|------------------------------------------------------|
| Activation Time<br>Uplink DPCH timeslots and codes<br>—— First timeslot code list | A different code combination to that used in step 1. |

### RADIO BEARER RECONFIGURATION FAILURE

The contents of RADIO BEARER RECONFIGURATION FAILURE message in this test case is the same as the RADIO BEARER RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark                              |
|---------------------|-------------------------------------------|
| Failure cause       | Incompatible simultaneous reconfiguration |

#### 8.2.2.14.5 ——— Test requirement

After step 2 the UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC with IE "failure cause" set to "Incompatible simultaneous reconfiguration".

After step 3 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### 8.2.2.15 ——— Radio Bearer Reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Invalid message reception and Invalid configuration)

##### 8.2.2.15.1 ——— Definition

##### 8.2.2.15.2 ——— Conformance requirement

The UE shall keep its old configuration when the UE receives an invalid RADIO BEARER RECONFIGURATION message, which does not include any IEs except IE "Message Type". Then it shall transmit a RADIO BEARER RECONFIGURATION FAILURE message setting "protocol error" in IE "failure cause" and also setting "ASN.1 violation error or encoding error" in IE "Protocol error cause". The UE shall keep its current configuration upon reception of a RADIO BEARER RECONFIGURATION message, which includes some IEs set to give an invalid configuration, and then the UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE including IE "failure cause" set to "invalid configuration".

#### Reference

3GPP TS 25.331 clause 8.2.2.

##### 8.2.2.15.3 ——— Test purpose

To confirm that the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if it receives an invalid RADIO BEARER RECONFIGURATION message which does not include any IEs except IE "Message Type".

To confirm that the UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC if it receives a RADIO BEARER RECONFIGURATION message including some IEs set to give an invalid configuration.

## 8.2.2.15.4 Method of test

## Initial Condition

System Simulator: 1 cell.

UE: PS-DCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

## Test Procedure

The UE is in CELL\_FACH state. The SS transmits an invalid RADIO BEARER RECONFIGURATION message to the UE which does not include all IEs except IE "Message Type". The UE shall keep the old configuration and transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC indicating "protocol error" in IE "failure cause" and also set "ASN.1 violation error or encoding error" in IE "Protocol error cause". The UE keeps current configuration when SS transmits RADIO BEARER RECONFIGURATION message including some IEs set to give an invalid configuration. The UE transmits a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the value "invalid configuration" to IE "failure cause".

## Expected sequence

| Step | Direction |    | Message                              | Comment                                       |
|------|-----------|----|--------------------------------------|-----------------------------------------------|
|      | UE        | SS |                                      |                                               |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION         | See specific message content.                 |
| 2    |           | →  | RADIO BEARER RECONFIGURATION FAILURE | The UE does not change the configuration.     |
| 3    |           | ←  | RADIO BEARER RECONFIGURATION         | This message includes IE set to invalid value |
| 4    |           | →  | RADIO BEARER RECONFIGURATION FAILURE | The UE does not change the configuration      |

## Specific Message Contents

## RADIO BEARER RECONFIGURATION (Step 1)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

## RADIO BEARER RECONFIGURATION FAILURE (Step 2)

The contents of RADIO BEARER RECONFIGURATION FAILURE message in this test case is the same as the RADIO BEARER RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element          | Value/remark                            |
|------------------------------|-----------------------------------------|
| Failure cause                |                                         |
| → Failure cause              | Protocol error                          |
| → Protocol error information |                                         |
| → Protocol error cause       | ASN.1 violation error or encoding error |

## RADIO BEARER RECONFIGURATION (Step 3) (FDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element         | Value/remark |
|-----------------------------|--------------|
| → Default DPCH Offset Value | 512          |
| → DPCH frame offset         | 1024         |

### RADIO BEARER RECONFIGURATION (Step 3) (TDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" found in Annex A with following exceptions:

| Information Element   | Value/remark |
|-----------------------|--------------|
| <del>PRACH TFCS</del> | Present      |

### RADIO BEARER RECONFIGURATION FAILURE (Step 4)

The contents of RADIO BEARER RECONFIGURATION FAILURE message in this test case is the same as the RADIO BEARER RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark          |
|---------------------|-----------------------|
| Failure-cause       | Invalid configuration |

#### 8.2.2.15.5 ~~Test requirement~~

After step 1 the UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, which includes the cause "protocol error" in IE "failure-cause" and "ASN.1 violation error or encoding error" in IE "Protocol error-cause".

After step 3 the UE shall transmit a RADIO BEARER RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the value "invalid configuration" to IE "failure-cause".

#### 8.2.2.16 ~~Void~~

#### 8.2.2.17 ~~Radio Bearer Reconfiguration from CELL\_FACH to CELL\_FACH: Success~~

##### 8.2.2.17.1 ~~Definition~~

##### 8.2.2.17.2 ~~Conformance requirement~~

The UE shall correctly reconfigure radio bearers and transit from CELL\_FACH in the current cell to CELL\_FACH in another cell according to a RADIO BEARER RECONFIGURATION message and responds with a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.2.

##### 8.2.2.17.3 ~~Test purpose~~

To confirm that the UE establishes radio bearers according to a RADIO BEARER RECONFIGURATION message.

##### 8.2.2.17.4 ~~Method of test~~

#### Initial Condition

System Simulator: 2 cells — Cell 1 and 2 are active.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108 in cell 1.

## Test Procedure

Table 8.2.2.17

| Parameter              | Unit         | Cell 1 |     | Cell 2 |     |
|------------------------|--------------|--------|-----|--------|-----|
|                        |              | T0     | T1  | T0     | T1  |
| UTRA—RF Channel Number |              | Ch. 1  |     | Ch. 1  |     |
| CPICH Ec (FDD)         | dBm/3.84 MHz | -60    | -75 | -75    | -60 |
| P-CCPCH (TDD)          | dBm          | -60    | -75 | -75    | -60 |

Table 8.2.2.17 illustrates the downlink power to be applied for the 2-cells at various time instants of the test execution. SS switches the power settings between columns "T0" and "T1", whenever the description in multi-cell condition specifies a reverse in the transmission power settings for cell 1 and cell 2.

The UE is in CELL\_FACH state in cell 1. The SS transmits a RADIO BEARER RECONFIGURATION message, which invoke a transition from CELL\_FACH in the current cell to CELL\_FACH in cell 2, to the UE. The SS configures its downlink transmission power settings according to columns "T1" in table 8.2.2.17. The UE moves to cell 2 and configures the common physical channel and transmits a RADIO BEARER RECONFIGURATION COMPLETE message using AM RLC.

## Expected sequence

| Step | Direction |    | Message                               | Comment                                                                                                             |
|------|-----------|----|---------------------------------------|---------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                                     |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION          |                                                                                                                     |
| 2    |           |    |                                       | The SS applies the downlink transmission power settings, according to the values in columns "T1" of table 8.2.2.17. |
| 3    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE |                                                                                                                     |

## Specific Message Contents

## RADIO BEARER RECONFIGURATION (Step 1) (FDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with the following exceptions.

| Information Element                                                                                | Value/remark |
|----------------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>——— Primary CPICH info<br>——— Primary scrambling code | 150          |

## RADIO BEARER RECONFIGURATION (Step 1) (TDD)

The contents of RADIO BEARER SETUP message in this test case is identical as "Packet to CELL\_FACH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element                                                                           | Value/remark |
|-----------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>——— Primary CCPCH info<br>——— Cell parameters ID | 4            |

**8.2.2.17.5** ——— **Test requirement**

After step 2 the UE shall transmit a RADIO BEARER RECONFIGURATION COMPLETE message using AM RLC in cell 2.

**8.2.2.18** ——— **Radio Bearer Reconfiguration from CELL\_FACH to CELL\_FACH: Success (Cell re-selection)****8.2.2.18.1** ——— **Definition****8.2.2.18.2** ——— **Conformance requirement**

The UE shall initiate the cell reselection procedure when the UE performs cell reselection during radio bearer reconfiguration procedure. After the UE completes cell update procedure, the UE shall continue to perform a radio bearer reconfiguration procedure and correctly reconfigure the radio bearer.

**Reference**

3GPP TS 25.331 clause 8.2.2.

**8.2.2.18.3** ——— **Test purpose**

To confirm that the UE transmits RADIO BEARER RECONFIGURATION COMPLETE message in cell 2 after it completes a cell update procedure instigated by a RADIO BEARER RECONFIGURATION message.

**8.2.2.18.4** ——— **Method of test****Initial Condition**

System Simulator: 2 cells – Cell 1 and 2 are active.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

**Test Procedure****Table 8.2.2.18**

| Parameter              | Unit         | Cell 1 |     | Cell 2 |     |
|------------------------|--------------|--------|-----|--------|-----|
|                        |              | T0     | T1  | T0     | T1  |
| UTRA RF Channel Number |              | Ch. 1  |     | Ch. 1  |     |
| CPICH Ec (FDD)         | dBm/3.84 MHz | -60    | -75 | -75    | -60 |
| P-CCPCH (TDD)          | dBm          | -60    | -75 | -75    | -60 |

Table 8.2.2.18 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution. SS switches the power settings between columns "T0" and "T1", whenever the description in multi-cell condition specifies a reverse in the transmission power settings for cell 1 and cell 2.

The UE is in CELL\_FACH state in cell 1. On transmitting a RADIO BEARER RECONFIGURATION message to the UE, the SS configures its downlink transmission power settings according to columns "T1" in table 8.2.2.18. The UE transmits a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "cell reselection". The SS shall transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving CELL UPDATE message. The UE transmits a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

## Expected sequence

| Step | Direction |    | Message                               | Comment                                                                                                            |
|------|-----------|----|---------------------------------------|--------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                                    |
| 1    | ←         |    | RADIO BEARER RECONFIGURATION          |                                                                                                                    |
| 2    |           |    |                                       | The SS applies the downlink transmission power settings, according to the values in columns "T1" of table 8.2.1.9. |
| 3    |           |    | Void                                  |                                                                                                                    |
| 4    | →         |    | CELL UPDATE                           | The value "cell reselection" shall be set in IE "cell update cause".                                               |
| 5    | ←         |    | CELL UPDATE CONFIRM                   |                                                                                                                    |
| 6    |           |    | Void                                  |                                                                                                                    |
| 7    | →         |    | RADIO BEARER RECONFIGURATION COMPLETE |                                                                                                                    |

## Specific Message Contents

## RADIO BEARER RECONFIGURATION (Step 1) (FDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with the following exceptions:

| Information Element                                                                                              | Value/remark |
|------------------------------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br><del>Primary CPICH info</del><br><del>Primary scrambling code</del> | Not Present  |

## RADIO BEARER RECONFIGURATION (Step 1) (TDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with the following exceptions:

| Information Element                                                                                         | Value/remark |
|-------------------------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br><del>Primary CCPCH info</del><br><del>Cell parameters ID</del> | Not present  |

## CELL UPDATE (Step 4)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark       |
|---------------------|--------------------|
| Cell Update Cause   | "cell reselection" |

## CELL UPDATE CONFIRM (Step 5)

The contents of CELL UPDATE CONFIRM message is same as "CELL UPDATE CONFIRM message" as found in Annex A.

## 8.2.18.5 Test requirement

After step 2 the UE shall transmit a CELL UPDATE message on the CCCH with IE "cell update cause" set to "cell reselection".

After step 6 UE shall transmit a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC



### ~~8.2.2.19 Radio Bearer Reconfiguration from CELL\_DCH to CELL\_DCH: Success (Subsequently received)~~

#### ~~8.2.2.19.1 Definition~~

#### ~~8.2.2.19.2 Conformance requirement~~

~~If the UE receives a RADIO BEARER RECONFIGURATION message before the UE configures the radio bearers according to the previous RADIO BEARER RECONFIGURATION message, the UE shall ignore the new RADIO BEARER RECONFIGURATION message and configure according to the previous RADIO BEARER RECONFIGURATION message. Finally, the UE shall transmit a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.~~

#### ~~Reference~~

~~3GPP TS 25.331 clause 8.2.2, clause 8.6.3.11.~~

#### ~~8.2.2.19.3 Test purpose~~

~~To confirm that if the UE receives a new RADIO BEARER RECONFIGURATION message before the UE configures the radio bearer according to a previous RADIO BEARER RECONFIGURATION message, it ignores the new RADIO BEARER RECONFIGURATION message and configures the radio bearer according to the previous RADIO BEARER RECONFIGURATION message received.~~

#### ~~8.2.2.19.4 Method of test~~

#### ~~Initial Condition~~

~~System Simulator: 1 cell.~~

~~UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.~~

#### ~~Test Procedure~~

~~The UE is in CELL\_DCH state. SS transmits a RADIO BEARER RECONFIGURATION message to the UE before the UE configures the radio bearer according to the RADIO BEARER RECONFIGURATION message prior to this new message. The UE ignores the new RADIO BEARER RECONFIGURATION message and configures according to the former RADIO BEARER RECONFIGURATION message. On completion of radio bearer configuration, the UE shall transmit a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.~~

## Expected sequence

| Step | Direction |    | Message                               | Comment                                                                                                                                                                                               |
|------|-----------|----|---------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                                                                                                                       |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION          | For FDD, the IE "Secondary scrambling code" is set to "1".<br>For TDD, the code combination is assigned by SS.                                                                                        |
| 2    |           | ←  | RADIO BEARER RECONFIGURATION          | Sent before the "activation time" in step 1 has elapsed. For FDD, the IE "Secondary scrambling code" is set to "2".<br>For TDD the code combination assigned is different to that assigned in step 1. |
| 3    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE | The UE ignores the RADIO BEARER RECONFIGURATION message in step 2 and performs configuration according to the RADIO BEARER RECONFIGURATION message in step 1.                                         |

## Specific Message Contents

## RADIO BEARER RECONFIGURATION (Step 1) (FDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element                                | Value/remark                                                                   |
|----------------------------------------------------|--------------------------------------------------------------------------------|
| Activation Time                                    | $[256 + \text{Current CFN} - [\text{current CFN mod } 8 + 8]] \text{MOD } 256$ |
| – Uplink DPCCH Info<br>– Secondary scrambling code | 1                                                                              |

## RADIO BEARER RECONFIGURATION (Step 1) (TDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element                                              | Value/remark                                                                   |
|------------------------------------------------------------------|--------------------------------------------------------------------------------|
| Activation Time                                                  | $[256 + \text{Current CFN} - [\text{current CFN mod } 8 + 8]] \text{MOD } 256$ |
| – Uplink DPCCH timeslots and codes<br>– First timeslot code list | Assigned by SS                                                                 |

## RADIO BEARER RECONFIGURATION (Step 2) (FDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element                                | Value/remark |
|----------------------------------------------------|--------------|
| Activation Time                                    | Not Present  |
| – Uplink DPCCH Info<br>– Secondary scrambling code | 2            |

### RADIO-BEARER RECONFIGURATION (Step 2) (TDD)

The contents of RADIO-BEARER RECONFIGURATION message in this test case is identical as "Packet to CELL\_DCH from CELL\_DCH in PS" found in Annex A with the following exceptions:

| Information Element                                             | Value/remark                                         |
|-----------------------------------------------------------------|------------------------------------------------------|
| Activation Time                                                 | Not Present                                          |
| ~ Uplink DPCH timeslots and codes<br>~ First timeslot code list | A different code combination to that used in step 1. |

#### 8.2.2.19.5 Test requirement

After step 2 the UE shall transmit a RADIO-BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

### 8.2.2.20 Radio Bearer Reconfigure from CELL\_FACH to CELL\_DCH: Success (Subsequently received)

#### 8.2.2.20.1 Definition

#### 8.2.2.20.2 Conformance requirement

If the UE receives a RADIO-BEARER RECONFIGURATION message before the UE configures the radio-bearer according to the previous RADIO-BEARER RECONFIGURATION message, the UE shall ignore the new RADIO-BEARER RECONFIGURATION message and configure according to the previous RADIO-BEARER RECONFIGURATION message. Finally, the UE shall transmit a RADIO-BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.2, clause 8.6.3.11.

#### 8.2.2.20.3 Test purpose

To confirm that if the UE receives a new RADIO-BEARER RECONFIGURATION message before the UE configures the radio-bearer according to a previous RADIO-BEARER RECONFIGURATION message, it ignores the new RADIO-BEARER RECONFIGURATION message and configures the radio-bearer according to the previous RADIO-BEARER RECONFIGURATION message received.

#### 8.2.2.20.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is in CELL\_FACH state. SS transmits a RADIO-BEARER RECONFIGURATION message to the UE before the UE configures the radio-bearer according to the RADIO-BEARER RECONFIGURATION message prior to this new message. The UE ignores the new RADIO-BEARER RECONFIGURATION message and configures the radio bearers according to the former RADIO-BEARER RECONFIGURATION message. On completion of radio-bearer configuration, the UE shall transmit a RADIO-BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

## Expected sequence

| Step        | Direction |    | Message                                    | Comment                                                                                                                                                                                                                                                            |
|-------------|-----------|----|--------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|             | UE        | SS |                                            |                                                                                                                                                                                                                                                                    |
| 1           | ←         |    | RADIO BEARER RECONFIGURATION               | For FDD, the IE "Secondary scrambling code" is set to "1".<br>For TDD, the code combination is assigned by SS.                                                                                                                                                     |
| 1a<br>(TDD) |           |    | A code combination is assigned for the SS. |                                                                                                                                                                                                                                                                    |
| 2           | ←         |    | RADIO BEARER RECONFIGURATION               | SS sends this message before the expiry of activation time specified in RADIO BEARER RECONFIGURATION message of step 1. For FDD, the IE "Secondary scrambling code" is set to "2". For TDD, the code combination assigned is different to that assigned in step 1. |
| 3           | →         |    | RADIO BEARER RECONFIGURATION COMPLETE      | The UE ignores the RADIO BEARER RECONFIGURATION message in step 2 and confirms configuration according to the RADIO BEARER RECONFIGURATION message in step 1.                                                                                                      |

## Specific Message Contents

## RADIO BEARER RECONFIGURATION (step 1) (FDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element        | Value/remark                                                              |
|----------------------------|---------------------------------------------------------------------------|
| Activation Time            | $[256 + \text{Current CFN} - [\text{current CFN} \bmod 8 + 8]] \bmod 256$ |
| ~Uplink DPCH Info          |                                                                           |
| ~Secondary scrambling code | 1                                                                         |

## RADIO BEARER RECONFIGURATION (Step 1) (TDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element              | Value/remark                                                              |
|----------------------------------|---------------------------------------------------------------------------|
| Activation Time                  | $[256 + \text{Current CFN} - [\text{current CFN} \bmod 8 + 8]] \bmod 256$ |
| ~Uplink DPCH timeslots and codes |                                                                           |
| ~First timeslot code list        | Assigned by SS                                                            |

## RADIO BEARER RECONFIGURATION (Step 2) (FDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element        | Value/remark |
|----------------------------|--------------|
| Activation Time            | Not Present  |
| ~Uplink DPCH Info          |              |
| ~Secondary scrambling code | 2            |

### RADIO-BEARER RECONFIGURATION (Step 2) (TDD)

The contents of RADIO-BEARER RECONFIGURATION message in this test case is identical as "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element                                             | Value/remark                                         |
|-----------------------------------------------------------------|------------------------------------------------------|
| Activation Time                                                 | Not Present                                          |
| - Uplink DPCH timeslots and codes<br>- First timeslot code list | A different code combination to that used in step 1. |

#### 8.2.2.20.5 Test requirement

After step 2 the UE shall transmit a RADIO-BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

### 8.2.2.21 Radio Bearer Reconfiguration from CELL\_DCH to CELL\_PCH: Success

#### 8.2.2.21.1 Definition

#### 8.2.2.21.2 Conformance requirement

The UE shall configure radio bearers so as to transit from CELL\_DCH state to CELL\_PCH state according to the received RADIO-BEARER RECONFIGURATION message.

#### Reference

3GPP TS 25.331 clause 8.2.2.

#### 8.2.2.21.3 Test purpose

To confirm that the UE transmits a RADIO-BEARER RECONFIGURATION COMPLETE message and enters CELL\_PCH state after it receives a RADIO-BEARER RECONFIGURATION, which invoke the UE to transit from CELL\_DCH to CELL\_PCH, from SS.

#### 8.2.2.21.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO-BEARER RECONFIGURATION message. The UE transmits a RADIO-BEARER RECONFIGURATION COMPLETE message using AM RLC and enters CELL\_PCH state. The SS transmits a PAGING TYPE 1 message, causing the UE to enter CELL\_FACH state and the UE shall transmit a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "paging response".

## Expected sequence

| Step | Direction |    | Message                               | Comment                                                    |
|------|-----------|----|---------------------------------------|------------------------------------------------------------|
|      | UE        | SS |                                       |                                                            |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION          |                                                            |
| 2    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE |                                                            |
| 3    |           |    |                                       | The UE is in CELL_PCH state.                               |
| 4    |           | ←  | PAGING TYPE 1                         | The SS transmits this message included a matched identity. |
| 5    |           | →  | CELL UPDATE                           | The UE is in CELL_FACH state.                              |

## Specific Message Contents

## RADIO BEARER RECONFIGURATION (Step 1) (FDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with following exceptions:

| Information Element                                                                           | Value/remark |
|-----------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                           | CELL_PCH     |
| Downlink information for each radio link<br>- Primary CPICH info<br>- Primary scrambling code | 100          |

## RADIO BEARER RECONFIGURATION (Step 1) (TDD)

The contents of RADIO BEARER SETUP message in this test case is identical as "Packet to CELL\_FACH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element                                                                       | Value/remark |
|-------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                       | CELL_PCH     |
| Downlink information for each radio links<br>- Primary CCPCH info<br>- Cell parameters ID | 4            |

## PAGING TYPE 1 (Step 4)

Use the same message sub-type titled "TM (Packet in PS)" in default message content of TS 34.108 with following exceptions:

| Information Element                                                                                             | Value/remark                                                                          |
|-----------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Paging record list<br>Paging record<br>- CHOICE Used paging identity<br>- U-RNTI<br>- SRNC Identity<br>- S-RNTI | UTRAN identity<br><br>Previously assigned SRNC identity<br>Previously assigned S-RNTI |

## CELL UPDATE (Step 5)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark      |
|---------------------|-------------------|
| Cell Update Cause   | "paging response" |

#### 8.2.2.21.5 ~~Test requirement~~

~~After step 1 the UE shall transmit a RADIO BEARER RECONFIGURATION COMPLETE message on uplink DCCH using AM RLC.~~

~~After step 4 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "paging response".~~

#### 8.2.2.22 ~~Radio Bearer Reconfiguration from CELL\_DCH to URA\_PCH: Success~~

##### 8.2.2.22.1 ~~Definition~~

##### 8.2.2.22.2 ~~Conformance requirement~~

~~The UE shall configure radio bearers so as to transit from CELL\_DCH state to URA\_PCH state according to received RADIO BEARER RECONFIGURATION message.~~

#### Reference

3GPP TS 25.331 clause 8.2.2.

##### 8.2.2.22.3 ~~Test purpose~~

~~To confirm that the UE transmits a RADIO BEARER RECONFIGURATION COMPLETE and enters URA\_PCH state after it received a RADIO BEARER RECONFIGURATION message, which invoke the UE to transit from CELL\_DCH to URA\_PCH, from SS.~~

##### 8.2.2.22.4 ~~Method of test~~

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

~~The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message. The UE transmits a RADIO BEARER RECONFIGURATION COMPLETE message using AM RLC and enters into URA\_PCH state. The SS transmits a PAGING TYPE 1 message and the UE shall enter the CELL\_FACH state after receiving this message. UE shall transmit a CELL UPDATE message with IE "Cell update cause" set to "paging response".~~

#### Expected sequence

| Step | Direction |    | Message                               | Comment                                                    |
|------|-----------|----|---------------------------------------|------------------------------------------------------------|
|      | UE        | SS |                                       |                                                            |
| 1    | ←         |    | RADIO BEARER RECONFIGURATION          |                                                            |
| 2    | →         |    | RADIO BEARER RECONFIGURATION COMPLETE |                                                            |
| 3    |           |    |                                       | The UE is in URA_PCH state.                                |
| 4    | ←         |    | PAGING TYPE 1                         | The SS transmits this message included a matched identity. |
| 5    | →         |    | CELL UPDATE                           | The UE is in CELL_FACH state.                              |

## Specific Message Contents

## RADIO BEARER RECONFIGURATION (Step 1)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with following exceptions:

| Information Element                                                                           | Value/remark |
|-----------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                           | URA_PCH      |
| Downlink information for each radio link<br>— Primary CPICH info<br>— Primary scrambling code | 100          |

## RADIO BEARER RECONFIGURATION (Step 1) (TDD)

The contents of RADIO BEARER SETUP message in this test case is identical as "Packet to CELL\_FACH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element                                                                       | Value/remark |
|-------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>— Primary CCPCH info<br>— Cell parameters ID | 4            |

## PAGING TYPE 1 (Step 4)

Use the same message sub-type titled "TM (Packet in PS)" in default message content of TS 34.108 with following exceptions:

| Information Element                                                                                             | Value/remark                                                                          |
|-----------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Paging record list<br>Paging record<br>— CHOICE Used paging identity<br>— U-RNTI<br>— SRNC Identity<br>— S-RNTI | UTRAN identity<br><br>Previously assigned SRNC identity<br>Previously assigned S-RNTI |

## CELL UPDATE (Step 5)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark      |
|---------------------|-------------------|
| Cell Update Cause   | "paging response" |

## 8.2.2.22.5 ——— Test requirement

After step 1 the UE shall transmit a RADIO BEARER RECONFIGURATION COMPLETE message on uplink DCCH using AM RLC.

After step 4 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "paging response".



~~8.2.2.23 Radio Bearer Reconfiguration from CELL\_FACH to CELL\_PCH: Success~~

~~8.2.2.23.1 Definition~~

~~8.2.2.23.2 Conformance requirement~~

~~The UE shall configure radio bearers so as to transit from CELL\_FACH state to CELL\_PCH state according to the received RADIO BEARER RECONFIGURATION message and responds with a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.~~

~~Reference~~

~~3GPP TS 25.331 clause 8.2.2.~~

~~8.2.2.23.3 Test purpose~~

~~To confirm that the UE transmits RADIO BEARER RECONFIGURATION COMPLETE message and enters CELL\_PCH state after it received a RADIO BEARER RECONFIGURATION message, which invoke the UE to transit from CELL\_FACH to CELL\_PCH.~~

~~8.2.2.23.4 Method of test~~

~~Initial Condition~~

~~System Simulator: 1 cell.~~

~~UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.~~

~~Test Procedure~~

~~The UE is in CELL\_FACH state. The SS transmits a RADIO BEARER RECONFIGURATION message. The UE transmits a RADIO BEARER RECONFIGURATION COMPLETE message using AM RLC and enters CELL\_PCH state. The SS transmits a PAGING TYPE 1 message, causing the UE to enter CELL\_FACH state and the UE shall transmit a CELL UPDATE message on uplink CCCH with IE "Cell update-cause" set to "paging response".~~

~~Expected sequence~~

| Step | Direction |    | Message                               | Comment                                                    |
|------|-----------|----|---------------------------------------|------------------------------------------------------------|
|      | UE        | SS |                                       |                                                            |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION          |                                                            |
| 2    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE |                                                            |
| 3    |           |    |                                       | The UE is in CELL_PCH state.                               |
| 4    |           | ←  | PAGING TYPE 1                         | The SS transmits this message included a matched identity. |
| 5    |           | →  | CELL UPDATE                           | The UE is in CELL_FACH state.                              |

~~Specific Message Contents~~

~~RADIO BEARER RECONFIGURATION (Step 1) (FDD)~~

~~Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with following exceptions:~~

| Information Element                                                                           | Value/remark |
|-----------------------------------------------------------------------------------------------|--------------|
| RRC-State Indicator                                                                           | CELL_PCH     |
| Downlink information for each radio link<br>— Primary CPICH info<br>— Primary scrambling code | 100          |

### RADIO BEARER RECONFIGURATION (Step 1) (TDD)

The contents of RADIO BEARER SETUP message in this test case is identical as "Packet to CELL\_FACH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element                                                                         | Value/remark |
|---------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>—— Primary CCPCH info<br>—— Cell parameters ID | 4            |

### PAGING TYPE 1 (Step 4)

Use the same message sub-type titled "TM (Packet in PS)" in default message content of TS 34.108 with following exceptions:

| Information Element                                                                                                 | Value/remark                                                                          |
|---------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Paging record list<br>Paging record<br>—— CHOICE Used-paging-identity<br>—— U-RNTI<br>—— SRNC-Identity<br>—— S-RNTI | UTRAN-identity<br><br>Previously-assigned-SRNC-identity<br>Previously-assigned-S-RNTI |

### CELL UPDATE (Step 5)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark      |
|---------------------|-------------------|
| Cell Update Cause   | "paging response" |

#### 8.2.2.23.5 — Test requirement

After step 1 the UE shall transmit a RADIO BEARER RECONFIGURATION COMPLETE message on uplink DCCH using AM RLC.

After step 4 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "paging response".

#### 8.2.2.24 — Radio Bearer Reconfiguration from CELL\_FACH to URA\_PCH: Success

##### 8.2.2.24.1 — Definition

##### 8.2.2.24.2 — Conformance requirement

The UE shall configure radio bearers so as to transit from CELL\_FACH state to URA\_PCH state according to the received RADIO BEARER RECONFIGURATION message and responds with a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

### Reference

3GPP TS 25.331 clause 8.2.2.

### 8.2.2.24.3 ~~Test purpose~~

To confirm that the UE transmits a RADIO BEARER RECONFIGURATION COMPLETE message and enters URA\_PCH state after it receives a RADIO BEARER RECONFIGURATION message, which invoke the UE to transit from CELL\_FACH to URA\_PCH.

### 8.2.2.24.4 ~~Method of test~~

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is in CELL\_FACH state. The SS transmits a RADIO BEARER RECONFIGURATION message. The UE transmits a RADIO BEARER RECONFIGURATION COMPLETE message using AM RLC and enters URA\_PCH state. The SS transmits a PAGING TYPE 1 message, causing the UE to enter CELL\_FACH state and the UE shall transmit a CELL UPDATE message on uplink CCCH with IE "Cell update-cause" set to "paging response".

#### Expected sequence

| Step | Direction |    | Message                               | Comment                                                    |
|------|-----------|----|---------------------------------------|------------------------------------------------------------|
|      | UE        | SS |                                       |                                                            |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION          |                                                            |
| 2    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE |                                                            |
| 3    |           |    |                                       | The UE is in URA_PCH state.                                |
| 4    |           | ←  | PAGING TYPE 1                         | The SS transmits this message included a matched identity. |
| 5    |           | →  | CELL UPDATE                           | The UE is in CELL_FACH state.                              |

#### Specific Message Contents

##### RADIO BEARER RECONFIGURATION (Step 1) (FDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with following exceptions:

| Information Element                                                                           | Value/remark |
|-----------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                           | URA_PCH      |
| Downlink information for each radio link<br>- Primary CPICH info<br>- Primary scrambling code | 100          |

##### RADIO BEARER RECONFIGURATION (Step 1) (TDD)

The contents of RADIO BEARER SETUP message in this test case is identical as "Packet to CELL\_FACH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element                                                                       | Value/remark |
|-------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>- Primary CCPCH info<br>- Cell parameters ID | 4            |

**PAGING TYPE 1 (Step 4)**

Use the same message sub-type titled "TM (Packet in PS)" in default message content of TS 34.108 with following exceptions:

| Information Element            | Value/remark                      |
|--------------------------------|-----------------------------------|
| Paging record list             |                                   |
| Paging record                  |                                   |
| —— CHOICE Used paging identity | UTRAN identity                    |
| —— U-RNTI                      |                                   |
| —— SRNC Identity               | Previously assigned SRNC identity |
| —— S-RNTI                      | Previously assigned S-RNTI        |

**CELL UPDATE (Step 5)**

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark      |
|---------------------|-------------------|
| Cell Update Cause   | "paging response" |

**8.2.2.24.5 ——— Test requirement**

After step 1 the UE shall transmit a RADIO BEARER RECONFIGURATION COMPLETE message on uplink DCCH using AM RLC.

After step 4 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "paging response".

**8.2.2.25 ——— Radio Bearer Reconfiguration for transition from CELL\_FACH to CELL\_DCH including modification of previously signalled CELL\_DCH configuration****8.2.2.25.1 ——— Definition****8.2.2.25.2 ——— Conformance requirement**

Upon receiving a RADIO BEARER RECONFIGURATION message including a request to move to CELL\_DCH, the UE shall apply a previously signalled configuration for CELL\_DCH, modify the parameters for which reconfiguration was requested in the RADIO BEARER RECONFIGURATION message and transmit a RADIO BEARER RECONFIGURATION COMPLETE message.

**Reference**

3GPP TS 25.331 clause 8.2.2.

**8.2.2.25.3 ——— Test purpose**

To confirm that the UE applies a previously signalled configuration for CELL\_DCH and in addition modifies the parameters for which reconfiguration is requested in the RADIO BEARER RECONFIGURATION message that is used to initiate transition from CELL\_FACH to CELL\_DCH.

**8.2.2.25.4 ——— Method of test****Initial Condition**

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

### Test Procedure

- a) The UE is in CELL\_FACH state.
- b) The SS transmits a RADIO BEARER RECONFIGURATION message including dedicated physical channel information to request the UE to transit from CELL\_FACH to CELL\_DCH. Upon receiving this message, the UE establishes the radio bearer and transport channel configuration for CELL\_DCH included in a previous RADIO BEARER SETUP message and modifies the parameters for which reconfiguration was requested in the RADIO BEARER RECONFIGURATION message.
- c) The UE transmits a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

### Expected sequence

| Step | Direction |    | Message                               | Comment                                             |
|------|-----------|----|---------------------------------------|-----------------------------------------------------|
|      | UE        | SS |                                       |                                                     |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION          | Initiates the transition from CELL_FACH to CELL_DCH |
| 2    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE |                                                     |

### Specific Message Contents

#### RADIO BEARER RECONFIGURATION (Step 1)

The contents of RADIO BEARER RECONFIGURATION message is identical as "RADIO BEARER RECONFIGURATION message" as found in Annex A with the following exceptions:

| Information Element                | Value/remark                       |
|------------------------------------|------------------------------------|
| RB information to reconfigure list |                                    |
| — RB information to reconfigure    | (AM-DCCH for RRC)                  |
| — RB identity                      | 2                                  |
| — PDCP info                        | Not Present                        |
| — PDCP SN info                     | Not Present                        |
| — RLC info                         |                                    |
| — CHOICE Uplink RLC mode           | AM-RLC                             |
| — Transmission RLC discard         |                                    |
| — SDU discard mode                 | No discard                         |
| — MAX_DAT                          | 15                                 |
| — Transmission window size         | 128                                |
| — Timer_RST                        | 300                                |
| — Max_RST                          | 1                                  |
| — Polling info                     |                                    |
| — Timer_poll                       | 100                                |
| — Poll_SDU                         | 1                                  |
| — Last transmission PDU poll       | TRUE                               |
| — Last retransmission PDU poll     | TRUE                               |
| — Poll_Windows                     | 99                                 |
| — CHOICE Downlink RLC mode         | AM-RLC                             |
| — In sequence delivery             | TRUE                               |
| — Receiving window size            | 128                                |
| — Downlink RLC status info         |                                    |
| — Timer_status_prohibit            | 100                                |
| — Missing PDU indicator            | TRUE                               |
| — RB mapping info                  | Not Present                        |
| — RB stop/continue                 | Not Present                        |
| — RB information to reconfigure    | (AM-DCCH for NAS_DT High-priority) |
| — RB identity                      | 3                                  |
| — PDCP info                        | Not Present                        |
| — PDCP SN info                     | Not Present                        |
| — RLC info                         | Same as for RB identity-2          |
| — RB mapping info                  | Not Present                        |
| — RB stop/continue                 | Not Present                        |
| — RB information to reconfigure    | (AM-DCCH for NAS_DT Low-priority)  |
| — RB identity                      | 4                                  |
| — PDCP info                        | Not Present                        |
| — PDCP SN info                     | Not Present                        |
| — RLC info                         | Same as for RB identity-2          |
| — RB mapping info                  | Not Present                        |
| — RB stop/continue                 | Not Present                        |

#### RADIO BEARER RECONFIGURATION COMPLETE (Step 2)

The contents of RADIO BEARER RECONFIGURATION COMPLETE message is identical as "RADIO BEARER RECONFIGURATION COMPLETE message" as found in Annex A.

#### 8.2.2.25.5 — Test requirement

After step 2 the UE shall transmit a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM-RLC.

## 8.2.3 Radio Bearer Release

### 8.2.3.1 Radio Bearer Release for transition from CELL\_DCH to CELL\_DCH: Success

#### 8.2.3.1.1 Definition

#### 8.2.3.1.2 Conformance requirement

The UE shall correctly release a radio bearer according to a RADIO BEARER RELEASE message and responds with a RADIO BEARER RELEASE COMPLETE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.3.

#### 8.2.3.1.3 Test purpose

To confirm that the UE releases the existing radio bearer according to a RADIO BEARER RELEASE message.

#### 8.2.3.1.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RELEASE message to the UE. The UE releases the radio access bearer and transmits a RADIO BEARER RELEASE COMPLETE message on the uplink DCCH using AM RLC.

#### Expected sequence

| Step | Direction |    | Message                       | Comment                   |
|------|-----------|----|-------------------------------|---------------------------|
|      | UE        | SS |                               |                           |
| 1    |           | ←  | RADIO BEARER RELEASE          |                           |
| 2    |           | →  | RADIO BEARER RELEASE COMPLETE | Release the radio bearer. |

#### Specific Message Contents

#### RADIO BEARER RELEASE

None.

#### 8.2.3.1.5 Test requirement

After step 2 the UE shall transmit a RADIO BEARER RELEASE COMPLETE message.

### 8.2.3.2 ~~Radio Bearer Release for transition from CELL\_DCH to CELL\_DCH: Failure (Unsupported configuration)~~

#### 8.2.3.2.1 ~~Definition~~

#### 8.2.3.2.2 ~~Conformance requirement~~

The UE shall keep its old configuration when the UE receives a RADIO BEARER RELEASE message which includes unsupported configuration parameters and transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting value "configuration unsupported" in IE "failure cause".

#### Reference

3GPP TS 25.331 clause 8.2.3.

#### 8.2.3.2.3 ~~Test purpose~~

To confirm that the UE keeps its current configuration and transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, if the received RADIO BEARER RELEASE message indicates an unsupported configuration parameters for the UE.

#### 8.2.3.2.4 ~~Method of test~~

#### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RELEASE message to the UE specifying a frequency which is not supported by the UE. The UE transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC indicating "configuration unsupported" in IE "failure cause".

#### Expected sequence

| Step | Direction |    | Message                      | Comment                                       |
|------|-----------|----|------------------------------|-----------------------------------------------|
|      | UE        | SS |                              |                                               |
| 1    |           | ←  | RADIO BEARER RELEASE         | Including unsupported configuration by the UE |
| 2    |           | →  | RADIO BEARER RELEASE FAILURE | The UE does not change the radio bearer.      |

#### Specific Message Contents

##### RADIO BEARER RELEASE (FDD)

The contents of RADIO BEARER RELEASE message in this test case is identical as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element     | Value/remark |
|-------------------------|--------------|
| Frequency info          |              |
| —— UARFCN uplink (Nu)   | 0            |
| —— UARFCN downlink (Nd) | 950          |



### RADIO BEARER RELEASE (TDD)

The contents of RADIO BEARER RELEASE message in this test case is identical as "Speech in CS" found in Annex A with the following exceptions:

| Information Element              | Value/remark |
|----------------------------------|--------------|
| Frequency info<br>—— UARFCN (Nt) | 0            |

### RADIO BEARER RELEASE FAILURE

The contents of RADIO BEARER RELEASE FAILURE message in this test case is the same as the RADIO BEARER RELEASE FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark              |
|---------------------|---------------------------|
| Failure cause       | Configuration unsupported |

#### 8.2.3.2.5 ——— Test requirement

After step 1 the UE shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC with the IE "failure cause" set to "configuration unsupported".

#### 8.2.3.3 ——— Radio Bearer Release for transition from CELL\_DCH to CELL\_DCH: Failure (Physical channel failure and reversion to old configuration)

##### 8.2.3.3.1 ——— Definition

##### 8.2.3.3.2 ——— Conformance requirement

The UE shall revert to the old configuration when the UE fails to reconfigure the radio bearers by timer T312 expiry and transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which is set to "physical channel failure" in IE "failure cause".

### Reference

3GPP TS 25.331 clause 8.2.3.

##### 8.2.3.3.3 ——— Test purpose

To confirm that the UE reverts to the old configuration and transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC if the UE fails to release the radio bearer according to a RADIO BEARER RELEASE message by timer T312 expiry.

##### 8.2.3.3.4 ——— Method of test

### Initial Condition

System Simulator: 1 cell

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RELEASE message but it keeps its current dedicated physical channel configuration. This causes the UE to fail to release the radio bearer, and after T312 expires the UE reverts to the old configuration. The UE then transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which specifies "physical channel failure" in IE "failure cause".

## Expected sequence

| Step | Direction |    | Message                      | Comment                                                                                                        |
|------|-----------|----|------------------------------|----------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                              |                                                                                                                |
| 1    | ←         |    | RADIO BEARER RELEASE         |                                                                                                                |
| 2    |           |    |                              | The SS keeps its current dedicated physical channel configuration.                                             |
| 3    | →         |    | RADIO BEARER RELEASE FAILURE | After T312 expires, the UE finds that it fails to release a radio bearer and reverts to the old configuration. |

## Specific Message Contents

## RADIO BEARER RELEASE

The contents of RADIO BEARER RELEASE message in this test case is identical as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in annex A.

## RADIO BEARER RELEASE FAILURE

The contents of RADIO BEARER RELEASE FAILURE message in this test case is the same as the RADIO BEARER RELEASE FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark             |
|---------------------|--------------------------|
| Failure cause       | Physical channel failure |

## 8.2.3.3.5 ——— Test requirement

After step 2 the UE shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which includes the value "physical channel failure" in IE "failure cause".

## 8.2.3.4 ——— Radio Bearer Release for transition from CELL\_DCH to CELL\_DCH: Failure (Physical channel failure and reversion failure)

## 8.2.3.4.1 ——— Definition

## 8.2.3.4.2 ——— Conformance requirement

The UE shall perform a cell update procedure when the UE fails to revert to the old configuration after the detection of physical channel failure in the radio bearer release procedure. After the UE completes cell update procedure, the UE transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which set IE "failure cause" to "physical channel failure".

## Reference

3GPP TS 25.331 clause 8.2.3.

## 8.2.3.4.3 ——— Test purpose

To confirm that the UE transmits a RADIO BEARER RELEASE FAILURE message after it completes a cell update procedure when the UE cannot revert to the old configuration after encountering a physical channel failure during the execution of a radio bearer release procedure.

#### 8.2.3.4.4 Method of test

##### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

##### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RELEASE message to the UE but does not configure dedicated physical channel in accordance with the settings in the message and release the previous configuration. As a result, the UE recognizes that it cannot reconfigure the radio bearers and wants to revert to the old configuration, but the UE cannot revert to the old configuration. The UE transmits a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "radio link failure". The SS shall transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving CELL UPDATE message. The UE transmits a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC and subsequently transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting IE "failure cause" to "physical channel failure".

##### Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                                                                                                   |
|------|-----------|----|-------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                                           |
| 1    | ←         |    | RADIO BEARER RELEASE                      |                                                                                                                                                           |
| 2    |           |    |                                           | The SS does not configure the dedicated physical channel in accordance with the RADIO BEARER RELEASE message and shall release the old configuration.     |
| 3    | →         |    | CELL UPDATE                               | This message includes the value "radio link failure" set in IE "Cell update cause".                                                                       |
| 4    | ←         |    | CELL UPDATE CONFIRM                       | This message includes IE "Physical channel information elements".                                                                                         |
| 5    |           |    |                                           | The SS configures the dedicated physical channel according to the IE "Physical channel information elements" included in the CELL UPDATE CONFIRM message. |
| 6    | →         |    | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                                                           |
| 7    | →         |    | RADIO BEARER RELEASE FAILURE              | The IE "failure cause" shall be set to "physical channel failure"                                                                                         |

##### Specific Message Contents

##### RADIO BEARER RELEASE

The contents of RADIO BEARER RELEASE message in this test case are identical as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A.

**CELL UPDATE (Step 3)**

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark                                           |
|---------------------|--------------------------------------------------------|
| U-RNTI              | Check to see if set to '0000 0000 0001'                |
| -SRNC Identity      | Check to see if set to '0000 0000 0000 0000 0000 0001' |
| -S-RNTI             | "radio-link failure"                                   |
| Cell Update Cause   |                                                        |

**CELL UPDATE CONFIRM (Step 4) (FDD)**

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A with the following exceptions:

| Information Element                       | Value/remark                                                         |
|-------------------------------------------|----------------------------------------------------------------------|
| U-RNTI                                    | Same as CELL UPDATE message in step 3                                |
| RRC State indicator                       | CELL_DCH                                                             |
| UplinkDPCH Info                           | Same as RADIO BEARER SETUP message used to move to initial condition |
| Downlink information for each radio links | Same as RADIO BEARER SETUP message used to move to initial condition |

**CELL UPDATE CONFIRM (Step 4) (TDD)**

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A with the following exceptions:

| Information Element                       | Value/remark                                                         |
|-------------------------------------------|----------------------------------------------------------------------|
| U-RNTI                                    | Same as CELL UPDATE message in step 3                                |
| RRC State indicator                       | CELL_DCH                                                             |
| UplinkDPCH timeslots and codes            | Same as RADIO BEARER SETUP message used to move to initial condition |
| Downlink information for each radio links | Same as RADIO BEARER SETUP message used to move to initial condition |

**RADIO BEARER RELEASE FAILURE (Step 7)**

The contents of RADIO BEARER RELEASE FAILURE message in this test case is the same as the RADIO BEARER RELEASE FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark               |
|---------------------|----------------------------|
| Failure cause       | "physical channel failure" |

**8.2.3.4.5 Test requirement**

After step 2 the UE shall transmit a CELL UPDATE message on the uplink CCCH with IE "Cell update cause" set to "radio-link failure".

After step 5 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC.

After step 6 the UE shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting the IE "failure cause" to "physical channel failure".

### 8.2.3.5 ~~Radio Bearer Release for transition from CELL\_DCH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)~~

#### 8.2.3.5.1 ~~Definition~~

#### 8.2.3.5.2 ~~Conformance requirement~~

If the UE receives a RADIO BEARER RELEASE message during a reconfiguring procedure due to a radio bearer message other than RADIO BEARER RELEASE message, it shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.3, clause 8.6.3.11.

#### 8.2.3.5.3 ~~Test purpose~~

To confirm that if the UE receives a RADIO BEARER RELEASE message during a reconfiguring procedure due to a radio bearer message other than RADIO BEARER RELEASE, it shall keep its configuration as if the RADIO BEARER RELEASE message had not been received and complete the reconfiguration procedure according to the previously received message.

#### 8.2.3.5.4 ~~Method of test~~

#### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE. The SS transmits a RADIO BEARER RELEASE message before the "activation time" indicated in the RADIO BEARER RECONFIGURATION message expires. When the UE receives the RADIO BEARER RELEASE message, the UE shall keep the configuration as if it had not received the RADIO BEARER RELEASE message and shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC with IE "failure cause" set to "incompatible simultaneous reconfiguration". When the activation time lapses, the UE reconfigures the new physical channel parameters and transmits a RADIO BEARER RECONFIGURATION COMPLETE message on DCCH using AM RLC.

#### Expected sequence

| Step | Direction |    | Message                               | Comment                                                                                        |
|------|-----------|----|---------------------------------------|------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION          |                                                                                                |
| 2    |           | ←  | RADIO BEARER RELEASE                  | Message sent before the "Activation time" indicated in the message of step 1 has elapsed.      |
| 3    |           | →  | RADIO BEARER RELEASE FAILURE          | The UE does not change the configuration due to the reception of RADIO BEARER RELEASE message. |
| 4    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE | This message is on DCCH using AM RLC.                                                          |

## Specific Message Contents

## RADIO BEARER RECONFIGURATION (Step 1) (FDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to the message sub-type title as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A, with the following exceptions:

| Information Element                                                                                               | Value/remark                         |
|-------------------------------------------------------------------------------------------------------------------|--------------------------------------|
| Activation Time                                                                                                   | Current CFN-[current CFN mod 8 + 8 ] |
| Uplink DPCH info<br>—— Scrambling code number                                                                     | 1                                    |
| Downlink information common for all radio links<br>—— Downlink DPCH info common for all RL<br>—— Timing Indicator | Maintain                             |

## RADIO BEARER RECONFIGURATION (TDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to the message sub-type titled "Packet to CELL\_DCH from CELL\_DCH in PS" in Annex A, with the following exceptions:

| Information Element                                                                                               | Value/remark   |
|-------------------------------------------------------------------------------------------------------------------|----------------|
| Uplink DPCH timeslots and codes<br>—— First timeslot code list                                                    | Assigned by SS |
| Downlink information common for all radio links<br>—— Downlink DPCH info common for all RL<br>—— Timing Indicator | Maintain       |

## RADIO BEARER RELEASE (Step 2) (FDD)

The contents of RADIO BEARER RELEASE message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_DCH in PS" found in Annex A with the following exceptions:

| Information Element                           | Value/remark                         |
|-----------------------------------------------|--------------------------------------|
| Activation Time Info                          | Current CFN-[current CFN mod 8 + 8 ] |
| Uplink DPCH Info<br>—— Scrambling code number | 2                                    |

## RADIO BEARER RECONFIGURATION (Step 2) (TDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical as "Packet to CELL\_DCH from CELL\_DCH in PS" found in Annex A with the following exceptions:

| Information Element                                             | Value/remark                                         |
|-----------------------------------------------------------------|------------------------------------------------------|
| Activation Time                                                 | Not Present                                          |
| — Uplink DPCH timeslots and codes<br>— First timeslot code list | A different code combination to that used in step 1. |

## RADIO BEARER RELEASE FAILURE

The contents of RADIO BEARER RELEASE FAILURE message in this test case is the same as the RADIO BEARER RELEASE FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark                              |
|---------------------|-------------------------------------------|
| Failure cause       | Incompatible simultaneous reconfiguration |

#### 8.2.3.5.5 ~~Test requirement~~

~~After step 2 the UE shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC with IE "failure cause" set to "Incompatible simultaneous reconfiguration".~~

~~After step 3 the UE shall transmit a RADIO BEARER RECONFIGURATION COMPLETE message.~~

#### 8.2.3.6 ~~Radio Bearer Release for transition from CELL\_DCH to CELL\_DCH: Failure (Invalid message reception and Invalid configuration)~~

##### 8.2.3.6.1 ~~Definition~~

##### 8.2.3.6.2 ~~Conformance requirement~~

~~The UE shall keep its old configuration when the UE receives an invalid RADIO BEARER RELEASE message which does not include any IEs except IE "Message Type". It shall transmit a RADIO BEARER RELEASE FAILURE message which includes value "protocol error" in IE "failure cause" and value "ASN.1 violation or encoding error" in IE "Protocol error cause". The UE shall keep existing configuration upon reception of a RADIO BEARER RELEASE message, which include some IEs set to give an invalid configuration, and then the UE shall transmit a RADIO BEARER RELEASE FAILURE including IE "failure cause" set to "invalid configuration".~~

#### Reference

3GPP TS 25.331 clause 8.2.3.

##### 8.2.3.6.3 ~~Test purpose~~

~~To confirm that the UE transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC if it receives an invalid RADIO BEARER RELEASE message, which does not include any IEs except IE "Message Type".~~

~~To confirm that the UE transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC if it receives a RADIO BEARER RELEASE message including some IEs set to give an invalid configuration.~~

##### 8.2.3.6.4 ~~Method of test~~

#### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits an invalid RADIO BEARER RELEASE message to the UE which does not any IEs except IE "Message Type". The UE keeps the old configuration and transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC. This message shall indicate "protocol error" in IE "failure cause" and also "ASN.1 violation or encoding error" in IE "Protocol error cause". SS transmits a RADIO BEARER RELEASE message including some IEs set to give an invalid configuration. The UE keeps current configuration and transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting IE "failure cause" to "invalid configuration".

## Expected sequence

| Step | Direction |    | Message                      | Comment                                                        |
|------|-----------|----|------------------------------|----------------------------------------------------------------|
|      | UE        | SS |                              |                                                                |
| 1    |           | ←  | RADIO BEARER RELEASE         | See specific message content.                                  |
| 2    |           | →  | RADIO BEARER RELEASE FAILURE | The UE shall not change the configuration.                     |
| 3    |           | ←  | RADIO BEARER RELEASE         | This message includes IE set to give an invalid configuration  |
| 4    |           |    |                              | The UE does not change the configuration                       |
| 5    |           | →  | RADIO BEARER RELEASE FAILURE | The IE "failure cause" shall be set to "invalid configuration" |

## Specific Message Contents

## RADIO BEARER RELEASE (Step1)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

## RADIO BEARER RELEASE FAILURE (Step 2)

The contents of RADIO BEARER RELEASE FAILURE message in this test case is the same as the RADIO BEARER RELEASE FAILURE message as found in Annex A, with the following exceptions:

| Information Element            | Value/remark                      |
|--------------------------------|-----------------------------------|
| Failure-cause                  |                                   |
| ——— Failure cause              | Protocol error                    |
| ——— Protocol error information |                                   |
| ——— Protocol error cause       | ASN.1 violation or encoding error |

## RADIO BEARER RELEASE (Step 3) (FDD)

The contents of RADIO BEARER RELEASE message in this test case is identical as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element           | Value/remark |
|-------------------------------|--------------|
| ——— Default DPCH Offset Value | 512          |
| ——— DPCH frame offset         | 1024         |

## RADIO BEARER RELEASE (Step 3) (TDD)

| Information Element | Value/remark |
|---------------------|--------------|
| ——— PRACH TFCS      | Present      |

## RADIO BEARER RELEASE FAILURE (Step 5)

The contents of RADIO BEARER RELEASE FAILURE message in this test case is the same as the RADIO BEARER RELEASE FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark          |
|---------------------|-----------------------|
| Failure-cause       | Invalid configuration |



### 8.2.3.6.5 ~~Test requirement~~

After step 1 the UE shall transmit a ~~RADIO BEARER RELEASE FAILURE~~ message on the DCCH using AM RLC, which is set to "protocol error" in IE "failure cause" and is set to "ASN.1 violation or encoding error" in IE "Protocol error cause".

After step 4 the UE shall transmit a ~~RADIO BEARER RELEASE FAILURE~~ message on the DCCH using AM RLC, setting the value "invalid configuration" to IE "failure cause".

## 8.2.3.7 ~~Radio Bearer Release for transition from CELL\_DCH to CELL\_FACH:~~ Success

### 8.2.3.7.1 ~~Definition~~

### 8.2.3.7.2 ~~Conformance requirement~~

The UE shall correctly release a radio bearer according to a ~~RADIO BEARER RELEASE~~ message and responds with a ~~RADIO BEARER RELEASE COMPLETE~~ message on the DCCH using AM RLC.

### Reference

3GPP TS 25.331 clause 8.2.3.

### 8.2.3.7.3 ~~Test purpose~~

To confirm that the UE release the existing the radio bearer according to a ~~RADIO BEARER RELEASE~~ message.

### 8.2.3.7.4 ~~Method of test~~

### Initial Condition

System Simulator: 1 cell.

UE: PS-DTCH+DCCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108.

### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a ~~RADIO BEARER RELEASE~~ message to the UE. The UE releases the radio access bearer and transmits a ~~RADIO BEARER RELEASE COMPLETE~~ message on the uplink DCCH using AM RLC.

### Expected sequence

| Step | Direction |    | Message                                  | Comment                                                                                                                                                                                                       |
|------|-----------|----|------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                          |                                                                                                                                                                                                               |
| 1    |           | ←  | <del>RADIO BEARER RELEASE</del>          | SS releases the radio bearer in the fashion specified in the message and allocate common channel resources to carry the remaining radio bearers.                                                              |
| 2    |           |    |                                          | The UE selects PRACH and S-CCPCH indicated in SIB5 and SIB6 after entering CELL_FACH state.<br>The UE shall release dedicated channels, and reconfigure the remaining radio bearers using the common channel. |
| 3    |           | →  | <del>RADIO BEARER RELEASE COMPLETE</del> |                                                                                                                                                                                                               |

## Specific Message Contents

### RADIO BEARER RELEASE (Step 1)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with the following exception:

| Information Element | Value/remark         |
|---------------------|----------------------|
| New C-RNTI          | 0000 0000 0000 0001B |

#### 8.2.3.7.5 Test requirement

After step 2 the UE shall transmit a RADIO BEARER RELEASE COMPLETE message.

### 8.2.3.8 Radio Bearer Release for transition from CELL\_DCH to CELL\_FACH: Success (Cell re-selection)

#### 8.2.3.8.1 Definition

#### 8.2.3.8.2 Conformance requirement

The UE shall initiate the cell update procedure when the UE performs cell reselection during a radio bearer release procedure. After the UE completes cell update procedure, the UE shall continue to perform the radio bearer release procedure and correctly release the radio bearer.

#### Reference

3GPP TS 25.331 clause 8.2.3.

#### 8.2.3.8.3 Test purpose

To confirm that the UE transmits a RADIO BEARER RELEASE COMPLETE message after the UE completes a cell update procedure.

#### 8.2.3.8.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RELEASE message to request the UE to transit from CELL\_DCH to CELL\_FACH. The UE initiates the cell update procedure because the UE cannot detect the specified cell in this message. The UE transmits a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "cell reselection". The SS shall transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving CELL UPDATE message. The UE transmits a RADIO BEARER RELEASE COMPLETE message on the DCCH using AM RLC.

## Expected sequence

| Step | Direction |    | Message                       | Comment                                                              |
|------|-----------|----|-------------------------------|----------------------------------------------------------------------|
|      | UE        | SS |                               |                                                                      |
| 1    |           |    | Void                          |                                                                      |
| 2    |           |    | Void                          |                                                                      |
| 3    |           | ←  | RADIO-BEARER-RELEASE          | Assigned the transition from CELL_DCH to CELL_FACH                   |
| 4    |           | →  | CELL-UPDATE                   | The value "cell reselection" shall be set in IE "cell update cause". |
| 5    |           | ←  | CELL-UPDATE-CONFIRM           |                                                                      |
| 6    |           |    | Void                          |                                                                      |
| 7    |           | →  | RADIO-BEARER-RELEASE-COMPLETE |                                                                      |

## Specific Message Contents

## RADIO-BEARER-RELEASE (Step 3) (FDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with the following exceptions:

| Information Element                                                                                | Value/remark |
|----------------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>——→ Primary CPICH info<br>——→ Primary scrambling code | 150          |

## RADIO-BEARER-RELEASE (Step 3) (TDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with the following exceptions:

| Information Element                                                                           | Value/remark |
|-----------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>——→ Primary CCPCH info<br>——→ Cell parameters-ID | 4            |

## CELL-UPDATE (Step 4)

The contents of CELL-UPDATE message is identical as "Contents of CELL-UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark       |
|---------------------|--------------------|
| Cell Update Cause   | "cell reselection" |

## CELL-UPDATE-CONFIRM (Step 5)

The contents of CELL-UPDATE-CONFIRM message is same as "CELL-UPDATE-CONFIRM message" as found in Annex A.

## 8.2.3.8.5 ———→ Test requirement

After step 3 the UE shall transmit a CELL-UPDATE message on the CCCH with IE "Cell update cause" set to "cell reselection".

After step 6 UE shall transmit a RADIO-BEARER-RELEASE-COMPLETE message on the DCCH using AM RLC.

~~8.2.3.9 Radio Bearer Release for transition from CELL\_FACH to CELL\_DCH: Success~~

~~8.2.3.9.1 Definition~~

~~8.2.3.9.2 Conformance requirement~~

~~The UE shall correctly release radio bearers according to a RADIO BEARER RELEASE message and responds with a RADIO BEARER RELEASE COMPLETE message on the DCCH using AM RLC.~~

~~Reference~~

~~3GPP TS 25.331 clause 8.2.3.~~

~~8.2.3.9.3 Test purpose~~

~~To confirm that an UE, in state CELL\_FACH, releases the radio access bearers using common physical channel. After the release, it shall access the affected radio bearers on the DPCH.~~

~~8.2.3.9.4 Method of test~~

~~Initial Condition~~

~~System Simulator: 1 cell.~~

~~UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.~~

~~Test Procedure~~

~~The UE is in CELL\_FACH state. The SS transmits a RADIO BEARER RELEASE message to the UE. In this message, SS commands the UE to release radio access bearers on common physical channel. At the same time, SS allocates DPCH to support the affected radio bearers. The UE shall release the indicated radio access bearers and transmit a RADIO BEARER RELEASE COMPLETE message on the uplink DCCH using AM RLC.~~

~~Expected sequence~~

| Step | Direction |    | Message                       | Comment                                                                       |
|------|-----------|----|-------------------------------|-------------------------------------------------------------------------------|
|      | UE        | SS |                               |                                                                               |
| 1    | ←         |    | RADIO BEARER RELEASE          |                                                                               |
| 2    |           |    |                               | UE shall release the radio access bearers carried by common physical channel. |
| 3    | →         |    | RADIO BEARER RELEASE COMPLETE |                                                                               |

~~Specific Message Contents~~

~~RADIO BEARER RELEASE (Step 1)~~

~~Use the same message sub-type titled "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A.~~

~~8.2.3.9.5 Test requirement~~

~~After step 2 the UE shall transmit a RADIO BEARER RELEASE COMPLETE message using the dedicated physical channel allocated.~~

### 8.2.3.10 Radio Bearer Release for transition from CELL\_FACH to CELL\_DCH: Failure (Unsupported configuration)

#### 8.2.3.10.1 Definition

#### 8.2.3.10.2 Conformance requirement

The UE shall keep its old configuration when it receives a RADIO BEARER RELEASE message which specifies unsupported configuration parameters for the UE. Then the UE shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which, setting value "configuration unsupported" in IE "failure cause".

#### Reference

3GPP TS 25.331 clause 8.2.3.

#### 8.2.3.10.3 Test purpose

To confirm that the UE keeps its configuration and transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC if the received RADIO BEARER RELEASE message requests for configuration unsupported by the UE.

#### 8.2.3.10.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is in CELL\_FACH state. The SS transmits a RADIO BEARER RELEASE message to the UE, referring to a frequency which cannot be supported by the UE. The UE shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC and set "configuration unsupported" in IE "failure cause".

#### Expected sequence

| Step | Direction |    | Message                      | Comment                                                      |
|------|-----------|----|------------------------------|--------------------------------------------------------------|
|      | UE        | SS |                              |                                                              |
| 1    |           | ←  | RADIO BEARER RELEASE         | The message contains a configuration not supported by the UE |
| 2    |           | →  | RADIO BEARER RELEASE FAILURE | The UE shall not change the radio bearer configuration.      |

#### Specific Message Contents

#### RADIO BEARER RELEASE (FDD)

The contents of RADIO BEARER RELEASE message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element     | Value/remark |
|-------------------------|--------------|
| Frequency info          |              |
| —— UARFCN uplink (Nu)   | 0            |
| —— UARFCN downlink (Nd) | 950          |

### RADIO-BEARER RELEASE (TDD)

The contents of RADIO-BEARER RELEASE message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element              | Value/remark |
|----------------------------------|--------------|
| Frequency info<br>—— UARFCN (Nt) | 0            |

### RADIO-BEARER RELEASE FAILURE

The contents of RADIO-BEARER RELEASE FAILURE message in this test case is the same as the RADIO-BEARER RELEASE FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark              |
|---------------------|---------------------------|
| Failure cause       | Configuration unsupported |

#### 8.2.3.10.5 ——— Test requirement

After step 1 the UE shall transmit a RADIO-BEARER RELEASE FAILURE message on the DCCH using AM RLC, stating the reason "configuration unsupported" in IE "failure cause".

#### 8.2.3.11 ——— Radio Bearer Release for transition from CELL\_FACH to CELL\_DCH: Failure (Physical channel failure and successful reversion to old configuration)

##### 8.2.3.11.1 ——— Definition

##### 8.2.3.11.2 ——— Conformance requirement

The UE shall revert to the old configuration when the UE fails to reconfigure the radio bearers before T312 timer expires and detects the same serving cell only. Then it shall transmit a RADIO-BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting the value "physical channel failure" in IE "failure cause" after it reverts to the old configuration.

### Reference

3GPP TS 25.331 clause 8.2.3.

##### 8.2.3.11.3 ——— Test purpose

To confirm that the UE reverts to the old configuration and transmits a RADIO-BEARER RELEASE FAILURE message on the DCCH using AM RLC if the UE fails to release the radio bearers in accordance with the specified settings in RADIO-BEARER RELEASE message before T312 timer expires.

##### 8.2.3.11.4 ——— Method of test

### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

## Test Procedure

The UE is in CELL\_FACH state. The SS transmits a RADIO BEARER RELEASE message and keeps its current physical channel configuration. The UE is expected to encounter a failure while releasing the radio bearer. After T312 timer expires, the UE shall revert to the old radio bearer configuration, so the UE transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which is set to "physical channel failure" in IE "failure cause".

## Expected sequence

| Step | Direction |    | Message                      | Comment                                                                                        |
|------|-----------|----|------------------------------|------------------------------------------------------------------------------------------------|
|      | UE        | SS |                              |                                                                                                |
| 1    |           | ←  | RADIO BEARER RELEASE         |                                                                                                |
| 2    |           |    |                              | The SS does not configure the specified L1.                                                    |
| 3    |           | →  | RADIO BEARER RELEASE FAILURE | After T312 expiry the UE fails to release a radio bearer and reverts to the old configuration. |

## Specific Message Contents

### RADIO BEARER RELEASE

Use the message sub-type titled "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A.

### RADIO BEARER RELEASE FAILURE

The contents of RADIO BEARER RELEASE FAILURE message in this test case is the same as the RADIO BEARER RELEASE FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark             |
|---------------------|--------------------------|
| Failure-cause       | Physical channel failure |

### 8.2.3.11.5 — Test requirement

After step 2 the UE shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting the value "physical channel failure" in IE "failure cause".

### 8.2.3.12 — Radio Bearer Release for transition from CELL\_FACH to CELL\_DCH: Failure (Physical channel failure and reversion failure)

#### 8.2.3.12.1 — Definition

#### 8.2.3.12.2 — Conformance requirement

The UE shall perform a cell update procedure when the UE selects another cell after the detection of physical channel failure during a radio bearer release procedure. After the UE completes cell update procedure, the UE transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC which is set IE "failure cause" to "physical channel failure".

## Reference

3GPP TS 25.331 clause 8.2.3.

#### 8.2.3.12.3 — Test purpose

To confirm that the UE transmits a RADIO BEARER RELEASE FAILURE message after it completes a cell update procedure following a physical channel failure during the radio bearer release procedure.

## 8.2.3.12.4 Method of test

## Initial Condition

System Simulator: 2 cells – Cell 1 and 2 are active.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

## Test Procedure

Table 8.2.3.12

| Parameter              | Unit         | Cell 1 |     | Cell 2 |     |
|------------------------|--------------|--------|-----|--------|-----|
|                        |              | T0     | T1  | T0     | T1  |
| UTRA-RF Channel Number |              | Ch. 1  |     | Ch. 1  |     |
| CPICH Ec (FDD)         | dBm/3.84 MHz | -60    | -75 | -75    | -60 |
| P-CCPCH RSCP (TDD)     | dBm          | -60    | -75 | -75    | -60 |

Table 8.2.3.12 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution. SS switches the power settings between columns "T0" and "T1", whenever the description in multi-cell condition specifies a reverse in the transmission power settings for cell 1 and cell 2.

The UE is in CELL\_FACH state in cell 1. The SS transmits a RADIO BEARER RELEASE message to the UE, but it does not configure the specified L1 in accordance with the settings in the message. This is expected to cause the UE to experience a failure to release the radio bearer and it subsequently tries to revert to the old configuration. The SS configures its downlink transmission power settings according to columns "T1" in table 8.2.3.12. The UE shall find cell 2 and transmits CELL\_UPDATE message on uplink CCCH with IE "Cell update cause" set to "cell reselection". The SS shall transmit a CELL\_UPDATE\_CONFIRM message on downlink CCCH after receiving CELL\_UPDATE message. The UE transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting IE "failure cause" to "physical channel failure".

## Expected sequence

| Step | Direction |    | Message                      | Comment                                                                                                                                                                                                    |
|------|-----------|----|------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                              |                                                                                                                                                                                                            |
| 1    | ←         |    | RADIO BEARER RELEASE         |                                                                                                                                                                                                            |
| 2    |           |    |                              | The SS does not configure the specified L1 in accordance with the settings in the message and applies the downlink transmission power settings, according to the values in columns "T1" of table 8.2.3.12. |
| 3    | ←         |    | Void                         |                                                                                                                                                                                                            |
| 4    | →         |    | CELL_UPDATE                  | The UE finds a new cell 2 and enter CELL_FACH state. This message includes the value "cell reselection" set in IE "Cell update cause".                                                                     |
| 5    | ←         |    | CELL_UPDATE_CONFIRM          |                                                                                                                                                                                                            |
| 6    |           |    | Void                         |                                                                                                                                                                                                            |
| 7    | →         |    | RADIO BEARER RELEASE FAILURE | The IE "failure cause" shall be set to "physical channel failure"                                                                                                                                          |



### Specific Message Contents

#### RADIO BEARER RELEASE (Step 1)

Use the message sub-type titled "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A.

#### CELL UPDATE (Step 4)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark                  |
|---------------------|-------------------------------|
| U-RNTI              | Assigned previously in cell 1 |
| -SRNC Identity      | Assigned previously in cell 1 |
| -S-RNTI             | Assigned previously in cell 1 |
| Cell Update Cause   | "cell reselection"            |

#### CELL UPDATE CONFIRM (Step 5)

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A.

#### RADIO BEARER RELEASE FAILURE (Step 7)

The contents of RADIO BEARER RELEASE FAILURE message in this test case is the same as the RADIO BEARER RELEASE FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark               |
|---------------------|----------------------------|
| Failure-cause       | "physical channel failure" |

#### 8.2.3.12.5 Test requirement

After step 3 the UE shall transmit a CELL UPDATE message on the uplink CCCH with IE "Cell update cause" set to "cell reselection".

After step 6 the UE shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting the IE "failure-cause" to "physical channel failure".

### 8.2.3.13 Radio Bearer Release for transition from CELL\_FACH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

#### 8.2.3.13.1 Definition

#### 8.2.3.13.2 Conformance requirement

If the UE receives a RADIO BEARER RELEASE message during a reconfiguring procedure due to a radio bearer message other than RADIO BEARER RELEASE message, it shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.3, clause 8.6.3.11.

#### 8.2.3.13.3 Test purpose

To confirm that if the UE receives a RADIO BEARER RELEASE message during a reconfiguring procedure due to a radio bearer message other than a RADIO BEARER RELEASE message, it shall keep its configuration as if the

RADIO BEARER RELEASE message had not been received and complete the reconfiguration procedure according to the previously received message.

#### 8.2.3.13.4 Method of test

##### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

##### Test Procedure

The UE is in CELL\_FACH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE. The SS transmits a RADIO BEARER RELEASE message before the "activation time" indicated in the RADIO BEARER RECONFIGURATION message expires. When the UE receives the RADIO BEARER RELEASE message, the UE shall keep the configuration as if it had not received the RADIO BEARER RELEASE message and shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCCH using AM RLC with IE "failure cause" set to "incompatible simultaneous reconfiguration". After the SS acknowledges the RADIO BEARER RELEASE FAILURE message, the UE reconfigures the new physical channel parameters upon the activation time and transmits a RADIO BEARER RECONFIGURATION COMPLETE message on DCCCH using AM RLC.

##### Expected sequence

| Step | Direction |    | Message                               | Comment                                                                                                |
|------|-----------|----|---------------------------------------|--------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                        |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION          | The UE receives any message other than RADIO BEARER RELEASE. (e.g. RADIO BEARER SETUP)                 |
| 2    |           | ←  | RADIO BEARER RELEASE                  | Sent before the expiry of IE "Activation Time" stated in message in step 1.                            |
| 3    |           | →  | RADIO BEARER RELEASE FAILURE          | The UE does not change the configuration due to the reception of RADIO BEARER RECONFIGURATION message. |
| 4    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE | This message is on DCCCH using AM RLC.                                                                 |

##### Specific Message Contents

##### RADIO BEARER RECONFIGURATION (Step 1) (FDD)

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A. Information element(s) to be changed are listed below:

| Information Element                          | Value/remark                        |
|----------------------------------------------|-------------------------------------|
| Activation Time                              | Current CFN-[current CFN mod 8 + 8] |
| Uplink DPCH Info<br>— Scrambling code number | 1                                   |

##### RADIO BEARER RECONFIGURATION (Step 1) (TDD)

The contents of RADIO BEARER SETUP message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A. Information element(s) to be changed are listed below:

| Information Element              | Value/remark                        |
|----------------------------------|-------------------------------------|
| Activation-Time                  | Current CFN-[current CFN mod 8 + 8] |
| —Uplink DPCH timeslots and codes |                                     |
| ——First timeslot code list       | Assigned by SS                      |

### RADIO BEARER RELEASE (Step 2) (FDD)

The contents of RADIO BEARER RELEASE message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element      | Value/remark |
|--------------------------|--------------|
| Activation-Time-Info     | Not Present  |
| Uplink-DPCH-Info         |              |
| ——Scrambling code number | 2            |

### RADIO BEARER RELEASE (Step 2) (TDD)

The contents of RADIO BEARER RELEASE message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element              | Value/remark                                         |
|----------------------------------|------------------------------------------------------|
| Activation-Time-Info             | Current CFN-[current CFN mod 8 + 8]                  |
| —Uplink DPCH timeslots and codes |                                                      |
| —First timeslot code list        | A different code combination to that used in step 1. |

### RADIO BEARER RELEASE FAILURE

The contents of RADIO BEARER RELEASE FAILURE message in this test case is the same as the RADIO BEARER RELEASE FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark                              |
|---------------------|-------------------------------------------|
| Failure-cause       | Incompatible simultaneous reconfiguration |

#### 8.2.3.13.5 ——— Test requirement

After step 2 the UE shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC with IE "failure-cause" set to "Incompatible simultaneous reconfiguration".

After step 3 the UE shall transmit a RADIO BEARER RECONFIGURATION COMPLETE message using the new physical channel parameters reconfigured as a result of the RADIO BEARER RECONFIGURATION message.

#### 8.2.3.14 ——— Radio Bearer Release for transition from CELL\_FACH to CELL\_DCH: Failure (Invalid message reception and Invalid configuration)

##### 8.2.3.14.1 ——— Definition

##### 8.2.3.14.2 ——— Conformance requirement

The UE shall keep its old configuration when the UE receives an invalid RADIO BEARER RELEASE message which does not include any IEs except IE "Message Type". It shall transmit a RADIO BEARER RELEASE FAILURE message which indicate the value "protocol error" in IE "failure-cause" and setting "ASN.1 violation or encoding error" in IE "Protocol error cause". The UE shall keep existing configuration upon reception of a RADIO BEARER RELEASE message, which includes some IEs set to give an invalid configuration, and then the UE shall transmit a RADIO BEARER RELEASE FAILURE including IE "failure-cause" set to "invalid configuration".

## Reference

3GPP TS 25.331 clause 8.2.3.

### 8.2.3.14.3 Test purpose

To confirm that the UE transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC if it receives an invalid RADIO BEARER RELEASE message which does not include any IEs except IE "Message Type".

To confirm that the UE transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC if it receives a RADIO BEARER RELEASE message including some IEs set to give an invalid configuration.

### 8.2.3.14.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: PS\_DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is in CELL\_FACH state. The SS transmits an invalid RADIO BEARER RELEASE message, which does not include any IEs except IE "Message Type", to the UE. The UE keeps the old configuration and transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, which shall indicate the value "protocol error" in IE "failure cause" and also "ASN.1 violation or encoding error" in IE "Protocol error cause". SS transmits a RADIO BEARER RELEASE message including some IEs set to give an invalid configuration. The UE keeps current configuration and transmits a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting the value "invalid configuration" to IE "failure cause".

#### Expected sequence

| Step | Direction |    | Message                      | Comment                                                        |
|------|-----------|----|------------------------------|----------------------------------------------------------------|
|      | UE        | SS |                              |                                                                |
| 1    |           | ←  | RADIO BEARER RELEASE         | See specific message content.                                  |
| 2    |           | →  | RADIO BEARER RELEASE FAILURE | The UE shall not change its current configuration.             |
| 3    |           | ←  | RADIO BEARER RELEASE         | This message includes IE set to give an invalid configuration. |
| 4    |           |    |                              | The UE does not change its configuration                       |
| 5    |           | →  | RADIO BEARER RELEASE FAILURE | The IE "failure cause" shall be set to "invalid configuration" |

#### Specific Message Contents

##### RADIO BEARER RELEASE (Step 1)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

##### RADIO BEARER RELEASE FAILURE (Step 2)

The contents of RADIO BEARER RELEASE FAILURE message in this test case is the same as the RADIO BEARER RELEASE FAILURE message as found in Annex A, with the following exceptions:

| Information Element            | Value/remark                      |
|--------------------------------|-----------------------------------|
| Failure-cause                  |                                   |
| ——— Failure-cause              | Protocol-error                    |
| ——— Protocol-error information |                                   |
| ——— Protocol-error cause       | ASN.1-violation-or-encoding-error |

### RADIO BEARER RELEASE (Step 3) (FDD)

The contents of RADIO BEARER RELEASE message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element           | Value/remark |
|-------------------------------|--------------|
| ——— Default DPCH Offset Value | 512          |
| ——— DPCH frame offset         | 1024         |

### RADIO BEARER RELEASE (Step 3) (TDD)

The contents of RADIO BEARER RELEASE message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| ——— PRACH TFCS      | Present      |

### RADIO BEARER RELEASE FAILURE (Step 5)

The contents of RADIO BEARER RELEASE FAILURE message in this test case is the same as the RADIO BEARER RELEASE FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark          |
|---------------------|-----------------------|
| Failure-cause       | Invalid-configuration |

#### 8.2.3.14.5 ——— Test requirement

After step 1 the UE shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting "protocol error" in IE "failure-cause" and also indicating "ASN.1 violation or encoding error" in IE "Protocol error cause".

After step 3 the UE shall transmit a RADIO BEARER RELEASE FAILURE message on the DCCH using AM RLC, setting IE "failure cause" to "invalid configuration".

### 8.2.3.15 ——— Radio Bearer Release for transition from CELL\_FACH to CELL\_FACH: Success

#### 8.2.3.15.1 ——— Definition

#### 8.2.3.15.2 ——— Conformance requirement

The UE shall correctly release a radio bearer according to the RADIO BEARER RELEASE message received and responds with a RADIO BEARER RELEASE COMPLETE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.3.

### 8.2.3.15.3 ~~Test purpose~~

~~To confirm that the UE releases the existing the radio bearer(s) according to the RADIO BEARER RELEASE message.~~

### 8.2.3.15.4 ~~Method of test~~

#### ~~Initial Condition~~

~~System Simulator: 1 cell.~~

~~UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.~~

#### ~~Test Procedure~~

~~The UE is in CELL\_FACH state. The SS transmits a RADIO BEARER RELEASE message to the UE. The UE releases the radio access bearer and transmits a RADIO BEARER RELEASE COMPLETE message on the uplink DCCH using AM RLC.~~

#### ~~Expected sequence~~

| Step | Direction |    | Message                       | Comment                                                                                                          |
|------|-----------|----|-------------------------------|------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                               |                                                                                                                  |
| 1    | ←         |    | RADIO BEARER RELEASE          |                                                                                                                  |
| 2    |           |    |                               | The UE selects PRACH and S-CCPCH indicated in SIB5 and SIB6.<br>The UE shall release the requested radio bearer. |
| 3    | →         |    | RADIO BEARER RELEASE COMPLETE |                                                                                                                  |

#### ~~Specific Message Contents~~

#### ~~RADIO BEARER RELEASE~~

~~Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A.~~

### 8.2.3.15.5 ~~Test requirement~~

~~After step 1 the UE shall transmit a RADIO BEARER RELEASE COMPLETE message using AM RLC on the common physical channel.~~

### 8.2.3.16 ~~Radio Bearer Release for transition from CELL\_DCH to CELL\_DCH: Success (Subsequently received)~~

#### 8.2.3.16.1 ~~Definition~~

#### 8.2.3.16.2 ~~Conformance requirement~~

~~If the UE receives a RADIO BEARER RELEASE message before the UE releases the radio bearer according to the previous RADIO BEARER RELEASE message, the UE shall ignore the new RADIO BEARER RELEASE message and releases according to the previous RADIO BEARER RELEASE message. Finally, the UE shall transmit a RADIO BEARER RELEASE COMPLETE message on the DCCH using AM RLC.~~

#### ~~Reference~~

~~3GPP TS 25.331 clause 8.2.3, clause 8.6.3.11.~~

### 8.2.3.16.3 Test purpose

To confirm that if the UE receives a new RADIO BEARER RELEASE message before the UE releases the radio bearer according to a previous RADIO BEARER RELEASE message it ignore the new RADIO BEARER RELEASE message and configures according to the previous RADIO BEARER RELEASE message received.

### 8.2.3.16.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. When the SS transmits a RADIO BEARER RELEASE message to the UE before the UE releases the radio access bearer, the UE ignores the second RADIO BEARER RELEASE message and releases the radio bearer according to the previous RADIO BEARER RELEASE message received. Finally, the UE shall transmit RADIO BEARER RELEASE COMPLETE message on the DCCH using AM RLC.

#### Expected sequence

| Step | Direction |    | Message                       | Comment                                                                                                                                                                                                                          |
|------|-----------|----|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                               |                                                                                                                                                                                                                                  |
| 1    |           | ←  | RADIO BEARER RELEASE          | For FDD, the SS sets its UL scrambling code to "1".                                                                                                                                                                              |
| 2    |           | ←  | RADIO BEARER RELEASE          | Message sent before the expiry of "activation time" specified in message in step 1. For FDD, the IE "Secondary scrambling code" is set to "2". For TDD the code combination assigned is different from that assigned in stage 1. |
| 3    |           | →  | RADIO BEARER RELEASE COMPLETE | The UE ignores the RADIO BEARER RELEASE message in step 2 and release radio bearer according to the RADIO BEARER RELEASE message in step 1.                                                                                      |

#### Specific Message Contents

##### RADIO BEARER RELEASE (Step 1) (FDD)

The contents of RADIO BEARER RELEASE message in this test case is identical to the message sub-type title "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A, with the following exceptions:

| Information Element                               | Value/remark                                     |
|---------------------------------------------------|--------------------------------------------------|
| Activation Time                                   | [256+Current CFN-[current CFN mod 8 + 8]]MOD 256 |
| - Uplink DPCH Info<br>- Secondary scrambling code | 1                                                |

##### RADIO BEARER RELEASE (Step 1) (TDD)

The contents of RADIO BEARER RELEASE message in this test case is identical to the message sub-type title "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A, with the following exceptions:

| Information Element                                           | Value/remark                                     |
|---------------------------------------------------------------|--------------------------------------------------|
| Activation-Time                                               | [256+Current CFN-[current CFN mod 8 + 8]]MOD 256 |
| Uplink-DPCH-timeslots-and-codes<br>——First timeslot-code-list | Assigned-by-SS                                   |

### RADIO-BEARER-RELEASE (Step 2) (FDD)

The contents of RADIO-BEARER-RELEASE message in this test case is identical to the message sub-type title "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A, with the following exceptions:

| Information Element                             | Value/remark |
|-------------------------------------------------|--------------|
| Activation-Time                                 | Not Present  |
| –Uplink-DPCH-Info<br>–Secondary-scrambling-code | 2            |

### RADIO-BEARER-RELEASE (Step 2) (TDD)

The contents of RADIO-BEARER-RELEASE message in this test case is identical to the message sub-type title "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A, with the following exceptions:

| Information Element                                           | Value/remark                                         |
|---------------------------------------------------------------|------------------------------------------------------|
| Activation-Time                                               | Not Present                                          |
| –Uplink-DPCH-timeslots-and-codes<br>–First-timeslot-code-list | A different code combination to that used in step 1. |

### 8.2.3.16.5 ——— Test requirement

After step 2 the UE shall transmit an RADIO-BEARER-RELEASE COMPLETE message on the DCCH using AM RLC.

### 8.2.3.17 ——— Radio-Bearer-Release for transition from CELL\_FACH to CELL\_DCH: Success (Subsequently received)

#### 8.2.3.17.1 ——— Definition

#### 8.2.3.17.2 ——— Conformance requirement

If the UE receives a RADIO-BEARER-RELEASE message before the UE releases the radio-bearer according to the previous RADIO-BEARER-RELEASE message, the UE shall ignore the new RADIO-BEARER-RELEASE message and releases the radio-bearers according to the previous RADIO-BEARER-RELEASE message. Finally, the UE shall transmit a RADIO-BEARER-RELEASE COMPLETE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.3, clause 8.6.3.11.

#### 8.2.3.17.3 ——— Test purpose

To confirm that if the UE receives a new RADIO-BEARER-RELEASE message before the UE releases the radio-bearer according to a previous RADIO-BEARER-RELEASE message, it ignores the new RADIO-BEARER-RELEASE message and configures according to the previous RADIO-BEARER-RELEASE message received.



#### 8.2.3.17.4 Method of test

##### Initial Condition

System Simulator: 1 cell.

UE: PS-DCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

##### Test Procedure

The UE is in CELL\_FACH state. When the SS transmits a RADIO BEARER RELEASE message to the UE before the UE releases the radio access bearer, the UE ignores the second RADIO BEARER RELEASE message and releases the radio bearers according to the previous RADIO BEARER RELEASE message received. Finally, the UE shall transmit a RADIO BEARER RELEASE COMPLETE message on the DCH using AM-RLC.

##### Expected sequence

| Step | Direction |    | Message                       | Comment                                                                                                                                                                                                                                       |
|------|-----------|----|-------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                               |                                                                                                                                                                                                                                               |
| 1    |           | ←  | RADIO BEARER RELEASE          | For FDD, the SS sets its UL scrambling code to "1".                                                                                                                                                                                           |
| 2    |           | ←  | RADIO BEARER RELEASE          | Sent before the expiry stated in IE "Activation Time" of RADIO BEARER RELEASE message in step 1. For TDD the IE "Secondary scrambling code" is set to "2". For TDD, the code combination assigned is different from that assigned in stage 1. |
| 3    |           | →  | RADIO BEARER RELEASE COMPLETE | The UE ignores the RADIO BEARER RELEASE message in step 2 and release radio bearers according to the RADIO BEARER RELEASE message in step 1.                                                                                                  |

##### Specific Message Contents

##### RADIO BEARER RELEASE (Step 1) (FDD)

The contents of RADIO BEARER RELEASE message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element       | Value/remark                                                                   |
|---------------------------|--------------------------------------------------------------------------------|
| Activation Time Info      | $[256 + \text{Current CFN} - [\text{current CFN mod } 8 + 8]] \text{MOD } 256$ |
| Uplink DPCCH Info         |                                                                                |
| Secondary scrambling code | 1                                                                              |

##### RADIO BEARER RELEASE (Step 1) (TDD)

The contents of RADIO BEARER RELEASE message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element              | Value/remark                                                                   |
|----------------------------------|--------------------------------------------------------------------------------|
| Activation Time Info             | $[256 + \text{Current CFN} - [\text{current CFN mod } 8 + 8]] \text{MOD } 256$ |
| Uplink DPCCH timeslots and codes |                                                                                |
| First timeslot code list         | Assigned by SS                                                                 |

##### RADIO BEARER RELEASE (Step 2) (FDD)

The contents of RADIO BEARER RELEASE message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element        | Value/remark |
|----------------------------|--------------|
| Activation Time            | Not Present  |
| ~Uplink DPCH Info          |              |
| ~Secondary scrambling code | 2            |

### RADIO BEARER RELEASE (Step 2) (TDD)

The contents of RADIO BEARER RELEASE message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element              | Value/remark                                         |
|----------------------------------|------------------------------------------------------|
| Activation Time                  | Not Present                                          |
| ~Uplink DPCH timeslots and codes |                                                      |
| ~First timeslot code list        | A different code combination to that used in step 1. |

#### 8.2.3.17.5 Test requirement

After step 2 the UE shall transmit an RADIO BEARER RELEASE COMPLETE message on the DCCH using AM RLC.

### 8.2.3.18 Radio Bearer Release from CELL\_DCH to CELL\_PCH: Success

#### 8.2.3.18.1 Definition

#### 8.2.3.18.2 Conformance requirement

The UE shall transmit a RADIO BEARER RELEASE COMPLETE message on uplink DCCH using AM RLC before it transits from CELL\_DCH to CELL\_PCH when UE receives a RADIO BEARER RELEASE message. And then, the UE shall release radio access bearers according to the RADIO BEARER RELEASE message.

#### Reference

3GPP TS 25.331 clause 8.2.2.

#### 8.2.3.18.3 Test purpose

To confirm that the UE transmits a RADIO BEARER RELEASE COMPLETE before entering CELL\_PCH state after it received a RADIO BEARER RELEASE message and released its radio access bearers.

#### 8.2.3.18.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RELEASE message. The UE transmits a RADIO BEARER RELEASE COMPLETE message using AM RLC and enters into CELL\_PCH state. The SS transmits a PAGING TYPE 1 message causing the UE to enter CELL\_FACH state and the UE shall transmit a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "paging response".

## Expected sequence

| Step | Direction |    | Message                          | Comment                                                         |
|------|-----------|----|----------------------------------|-----------------------------------------------------------------|
|      | UE        | SS |                                  |                                                                 |
| 1    |           | ←  | RADIO-BEARER<br>RELEASE          |                                                                 |
| 2    |           | →  | RADIO-BEARER<br>RELEASE COMPLETE | The UE sends this message before it completes state transition. |
| 3    |           | ←  | PAGING TYPE 1                    | The SS transmits this message with a matched identity.          |
| 4    |           | →  | CELL-UPDATE                      | The UE is in CELL_FACH state.                                   |

## Specific Message Contents

## RADIO-BEARER RELEASE (Step 1) (FDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with following exceptions:

| Information Element                                                                           | Value/remark |
|-----------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                           | CELL_PCH     |
| Downlink information for each radio link<br>- Primary CPICH info<br>- Primary scrambling code | 100          |

## RADIO-BEARER RELEASE (Step 1) (TDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with following exceptions:

| Information Element                                                                       | Value/remark |
|-------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                       | CELL_PCH     |
| Downlink information for each radio links<br>- Primary CCPCH info<br>- Cell parameters ID | 4            |

## PAGING TYPE 1 (Step 3)

Use the same message sub-type titled "TM (Packet in PS)" in default message content of TS 34.108 with following exceptions:

| Information Element                                                                                             | Value/remark                                                                          |
|-----------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Paging record list<br>Paging record<br>- CHOICE Used paging identity<br>- U-RNTI<br>- SRNC Identity<br>- S-RNTI | UTRAN identity<br><br>Previously assigned SRNC identity<br>Previously assigned S-RNTI |

## CELL-UPDATE (Step 4)

The contents of CELL-UPDATE message is identical as "Contents of CELL-UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark      |
|---------------------|-------------------|
| Cell Update Cause   | "paging response" |

**8.2.3.18.5** ————— **Test requirement**

After step 1 the UE transmits a RADIO BEARER RELEASE COMPLETE message on uplink DCCH using AM RLC.

After step 3 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "paging response".

**8.2.3.19** ————— **Radio Bearer Release from CELL\_DCH to URA\_PCH: Success****8.2.3.19.1** ————— **Definition****8.2.3.19.2** ————— **Conformance requirement**

The UE shall transmit a RADIO BEARER RELEASE COMPLETE message before it transits from CELL\_DCH to URA\_PCH when UE receives a RADIO BEARER RELEASE message. And then, the UE shall release radio access bearers according to the RADIO BEARER RELEASE message.

**Reference**

3GPP TS 25.331 clause 8.2.2.

**8.2.3.19.3** ————— **Test purpose**

To confirm that the UE transmits a RADIO BEARER RELEASE COMPLETE before entering URA\_PCH state after it received a RADIO BEARER RELEASE message and released its radio bearers.

**8.2.3.19.4** ————— **Method of test****Initial Condition**

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108.

**Test Procedure**

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RELEASE message. The UE transmits a RADIO BEARER RELEASE COMPLETE message using AM RLC and enters into URA\_PCH state. The SS transmits a PAGING TYPE 1 message, causing the UE to enter CELL\_FACH state and the UE shall transmit a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "paging response".

**Expected sequence**

| Step | Direction |    | Message                       | Comment                                                         |
|------|-----------|----|-------------------------------|-----------------------------------------------------------------|
|      | UE        | SS |                               |                                                                 |
| 1    |           | ←  | RADIO BEARER RELEASE          |                                                                 |
| 2    |           | →  | RADIO BEARER RELEASE COMPLETE | The UE sends this message before it completes state transition. |
| 3    |           | ←  | PAGING TYPE 1                 | The SS transmits this message with a matched identity.          |
| 4    |           | →  | CELL UPDATE                   | The UE is in CELL_FACH state.                                   |

## Specific Message Contents

## RADIO BEARER RELEASE (Step 1) (FDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with following exceptions:

| Information Element                                                                           | Value/remark |
|-----------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                           | URA_PCH      |
| Downlink information for each radio link<br>— Primary CPICH info<br>— Primary scrambling code | 100          |

## RADIO BEARER RELEASE (Step 1) (TDD)

| Information Element                                                                       | Value/remark |
|-------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                       | CELL_PCH     |
| Downlink information for each radio links<br>— Primary CCPCH info<br>— Cell parameters ID | 4            |

## PAGING TYPE 1 (Step 3)

Use the same message sub-type titled "TM (Packet in PS)" in default message content of TS 34.108 with following exceptions:

| Information Element                                                                                             | Value/remark                                                                          |
|-----------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Paging record list<br>Paging record<br>— CHOICE Used paging identity<br>— U-RNTI<br>— SRNC Identity<br>— S-RNTI | UTRAN identity<br><br>Previously assigned SRNC identity<br>Previously assigned S-RNTI |

## CELL UPDATE (Step 4)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark      |
|---------------------|-------------------|
| Cell Update Cause   | "paging response" |

## 8.2.3.19.5 — Test requirement

After step 1 the UE transmits a RADIO BEARER RELEASE COMPLETE message to the UE on uplink DCCH using AM RLC.

After step 3 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "paging response".

~~8.2.4 Transport channel reconfiguration~~

~~8.2.4.1 Transport channel reconfiguration from CELL\_DCH to CELL\_DCH: Success with no transport channel type switching~~

~~8.2.4.1.1 Definition~~

~~8.2.4.1.2 Conformance requirement~~

~~The UE shall transmit TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC after it correctly reconfigures the radio bearers according to the TRANSPORT CHANNEL RECONFIGURATION message, which specifies a hard handover by changing the scrambling code for the DPCCH.~~

~~Reference~~

~~3GPP TS 25.331 clause 8.2.4.~~

~~8.2.4.1.3 Test purpose~~

~~To confirm that the UE reconfigures the channel configuration according to a TRANSPORT CHANNEL RECONFIGURATION message, which also specifies a hard handover by changing the scrambling code for the DPCCH.~~

~~8.2.4.1.4 Method of test~~

~~Initial Condition~~

~~System Simulator: 1 cell~~

~~UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.~~

~~Test Procedure~~

~~The UE is in CELL\_DCH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE, which includes new configuration parameters. The UE shall reconfigure the new configuration and then transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC.~~

~~Expected sequence~~

| Step | Direction |    | Message                                    | Comment                         |
|------|-----------|----|--------------------------------------------|---------------------------------|
|      | UE        | SS |                                            |                                 |
| 1    |           |    | Void                                       |                                 |
| 2    |           |    | Void                                       |                                 |
| 3    |           | ←  | TRANSPORT CHANNEL RECONFIGURATION          | UL scrambling code is modified. |
| 4    |           |    | Void                                       |                                 |
| 5    |           | →  | TRANSPORT CHANNEL RECONFIGURATION COMPLETE |                                 |

~~Specific Message Contents~~

~~TRANSPORT CHANNEL RECONFIGURATION (FDD)~~

~~The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type titled as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A, with the following exceptions:~~

| Information Element                                                                                                 | Value/remark                        |
|---------------------------------------------------------------------------------------------------------------------|-------------------------------------|
| Uplink DPCH info<br>——— Scrambling code number                                                                      | Different value from previous value |
| Downlink information common for all radio links<br>——— Downlink DPCH info common for all RL<br>——— Timing Indicator | Maintain                            |

### TRANSPORT CHANNEL RECONFIGURATION (TDD)

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type titled "Packet to CELL\_DCH from CELL\_DCH in PS" in Annex A, with the following exceptions:

| Information Element                                                                                                                                                                    | Value/remark                                                                  |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------|
| — Uplink DPCH timeslots and codes<br>— First timeslot code list<br>Downlink information common for all radio links<br>——— Downlink DPCH info common for all RL<br>——— Timing Indicator | A different code combination to that used previously.<br><br><br><br>Maintain |

#### 8.2.4.1.5 ——— Test requirement

After step 3 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### 8.2.4.1a ——— Transport channel reconfiguration (Transmission Rate Modification with Timing Maintained) from CELL\_DCH to CELL\_DCH of the same cell: Success

##### 8.2.4.1a.1 ——— Definition

##### 8.2.4.1a.2 ——— Conformance requirement

The UE shall transmit TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC after it correctly reconfigures the radio bearers according to the TRANSPORT CHANNEL RECONFIGURATION message, which specifies a hard handover to modify the transmission rate by (1) changing physical channel information and (2) changing either TFCS and TFS or TFCS only.

#### Reference

3GPP TS 25.331 clause 8.2.4.

##### 8.2.4.1a.3 ——— Test purpose

To confirm that the UE reconfigures the physical channel and transport channel configuration according to a TRANSPORT CHANNEL RECONFIGURATION message, which specifies a hard handover by changing physical channel information and either TFCS and TFS or TFCS only.

##### 8.2.4.1a.4 ——— Method of test

#### Initial Condition

System Simulator: 1 cell

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108.

Note : Transmission rate shall be set to the maximum rate for the UE during the radio bearer establishment procedure.

### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE to modify the transmission rate which includes a new physical channel information and the TFCS is reconfigured to restrict the use of TFCI. The UE shall reconfigure the new configuration and then transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC. Next the SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE to modify the transmission rate which includes new physical channel information and new TFCS and TFS. The UE shall reconfigure the new configuration and then transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC.

### Expected sequence

| Step | Direction |    | Message                                    | Comment |
|------|-----------|----|--------------------------------------------|---------|
|      | UE        | SS |                                            |         |
| 1    |           | ←  | TRANSPORT CHANNEL RECONFIGURATION          |         |
| 2    |           | →  | TRANSPORT CHANNEL RECONFIGURATION COMPLETE |         |
| 3    |           | ←  | TRANSPORT CHANNEL RECONFIGURATION          |         |
| 4    |           | →  | TRANSPORT CHANNEL RECONFIGURATION COMPLETE |         |

### Specific Message Contents

#### TRANSPORT CHANNEL RECONFIGURATION (Step 1)

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type titled as "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A, with the following exceptions:

| Information Element                                               | Value/remark                                                                                                                                                                   |
|-------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| UL Transport channel information for all transport channels       | Not Present                                                                                                                                                                    |
| Added or Reconfigured UL TrCH information                         | Not Present                                                                                                                                                                    |
| DL Transport channel information common for all transport channel |                                                                                                                                                                                |
| → SCCPCH TFCS                                                     | Not Present                                                                                                                                                                    |
| → CHOICE mode                                                     | FDD                                                                                                                                                                            |
| → CHOICE DL parameters                                            | Explicit                                                                                                                                                                       |
| → DL DCH TFCS                                                     |                                                                                                                                                                                |
| → CHOICE TFCI Signalling                                          | Normal                                                                                                                                                                         |
| → TFCI Field 1 Information                                        |                                                                                                                                                                                |
| → CHOICE TFCS representation                                      | Complete reconfiguration                                                                                                                                                       |
| → TFCS complete reconfigure                                       |                                                                                                                                                                                |
| → CHOICE CTFC Size                                                | Number of bits used must be enough to cover all combinations of CTFC from TS34.108 clause 6.10 Parameter Set which is used in RADIO BEARER SETUP message in initial procedure. |
| → CTFC information                                                |                                                                                                                                                                                |
| → CTFC                                                            | This CTFC value is set as defined value to be restricted from the TFCS defined in RADIO BEARER SETUP message and repeated for TFC numbers.                                     |
| → Power offset information                                        | Not Present                                                                                                                                                                    |
| Added or Reconfigured DL TrCH information                         | Not Present                                                                                                                                                                    |

#### 8.2.4.1a.5 Test requirement

After step 1 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

After step 3 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.



## 8.2.4.2 ~~Transport channel reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Unsupported configuration)~~

### 8.2.4.2.1 ~~Definition~~

### 8.2.4.2.2 ~~Conformance requirement~~

The UE shall keep its old configuration when the UE receives a TRANSPORT CHANNEL RECONFIGURATION message which includes unsupported configuration parameters and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "configuration unsupported" in IE "failure cause".

### Reference

3GPP TS 25.331 clause 8.2.4.

### 8.2.4.2.3 ~~Test purpose~~

To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if the received TRANSPORT CHANNEL RECONFIGURATION message specifies unsupported configuration parameters.

### 8.2.4.2.4 ~~Method of test~~

### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message, which includes configuration parameters unsupported by the UE. The UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, reporting the event "configuration unsupported" in IE "failure cause".

### Expected sequence

| Step | Direction |    | Message                                   | Comment                                                              |
|------|-----------|----|-------------------------------------------|----------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                      |
| 1    |           | ←  | TRANSPORT CHANNEL RECONGURATION           | Including configuration unsupported by the UE                        |
| 2    |           | →  | TRANSPORT CHANNEL RECONFIGURATION FAILURE | The UE shall not change the settings used by the transport channels. |

### Specific Message Contents

#### TRANSPORT CHANNEL RECONFIGURATION (FDD)

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element                                                | Value/remark |
|--------------------------------------------------------------------|--------------|
| Frequency info<br>—— UARFCN uplink (Nu)<br>—— UARFCN downlink (Nd) | 0.<br>950    |

#### TRANSPORT CHANNEL RECONFIGURATION (TDD)

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element              | Value/remark |
|----------------------------------|--------------|
| Frequency info<br>—— UARFCN (Nt) | 0            |

#### TRANSPORT CHANNEL RECONFIGURATION FAILURE

The contents of TRANSPORT CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the TRANSPORT CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark              |
|---------------------|---------------------------|
| Failure cause       | Configuration unsupported |

#### 8.2.4.2.5 ——— Test requirement

After step 1 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, indicating "configuration unsupported" in IE "failure cause".

#### 8.2.4.3 ——— Transport channel reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Physical channel failure and reversion to old configuration)

##### 8.2.4.3.1 ——— Definition

##### 8.2.4.3.2 ——— Conformance requirement

The UE shall revert to the old configuration when the UE fails to reconfigure the new physical channel according to the received TRANSPORT CHANNEL RECONFIGURATION message and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "physical channel failure" in IE "failure cause".

### Reference

3GPP TS 25.331 clause 8.2.4.

8.2.4.3.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, if the UE fails to reconfigure the new configuration according to a TRANSPORT CHANNEL RECONFIGURATION message.

8.2.4.3.4 Method of test

Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

Test Procedure

The UE is in CELL\_DCH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE, which includes new configuration parameters but the SS does not configure the new physical channel specified in this message and keep its old configuration. Therefore, the UE cannot synchronise with the SS on the new physical channel and shall revert to the old configuration after T312 expires. Then the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting "physical channel failure" in IE "failure-cause".

Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                |
|------|-----------|----|-------------------------------------------|------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                        |
| 1    |           | ←  | TRANSPORT CHANNEL RECONGURATION           | Specifies a change in the TFS of the dedicated transport channel used. |
| 2    |           |    |                                           | The SS does not reconfigure the new configuration.                     |
| 3    |           | →  | TRANSPORT CHANNEL RECONFIGURATION FAILURE | The UE reverts to the old configuration and transmits this message.    |

Specific Message Contents

TRANSPORT CHANNEL RECONFIGURATION

Use the message sub-type titled as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A.

TRANSPORT CHANNEL RECONFIGURATION FAILURE

The contents of TRANSPORT CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the TRANSPORT CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark             |
|---------------------|--------------------------|
| Failure-cause       | Physical channel failure |

8.2.4.3.5 Test requirement

After step 2 the UE shall revert to the old configuration and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, and it shall set the value "physical channel failure" in IE "failure-cause".

#### ~~8.2.4.4 Transport channel reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Physical channel failure and reversion failure)~~

##### ~~8.2.4.4.1 Definition~~

##### ~~8.2.4.4.2 Conformance requirement~~

~~The UE shall perform a cell update when physical channel failure and reversion failure occur. After the UE completes cell update procedure, the UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which set IE "failure cause" to "physical channel failure".~~

##### ~~Reference~~

~~3GPP TS 25.331 clause 8.2.4.~~

##### ~~8.2.4.4.3 Test purpose~~

~~To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message after it completes a cell update procedure when the UE cannot synchronise with the SS on the new channel before T312 expires and fails to revert to the old configuration.~~

##### ~~8.2.4.4.4 Method of test~~

##### ~~Initial Condition~~

~~System Simulator: 1 cell.~~

~~UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.~~

##### ~~Test Procedure~~

~~The UE is in CELL\_DCH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE. The message specifies a new configuration but the SS does not reconfigure the new channel specified in this message and release the old configuration. The UE cannot synchronise with SS before T312 expires and shall attempt to revert to the old configuration. The UE cannot revert to the old configuration and then transmit a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "radio link failure". The SS shall transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving CELL UPDATE message. The UE transmits a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC and subsequently transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting IE "failure cause" to "physical channel failure".~~

## Expected sequence

| Step | Direction |    | Message                                      | Comment                                                                                                                                                |
|------|-----------|----|----------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                              |                                                                                                                                                        |
| 1    | ←         |    | TRANSPORT CHANNEL<br>RECONFIGURATION         |                                                                                                                                                        |
| 2    |           |    |                                              | The SS does not reconfigure L1 in accordance with TRANSPORT CHANNEL RECONFIGURATION message and release the old configuration.                         |
| 3    | →         |    | CELL UPDATE                                  | This message includes the value "radio-link failure" set in IE "Cell update cause".                                                                    |
| 4    | ←         |    | CELL UPDATE CONFIRM                          | This message includes IE "Physical channel information elements".                                                                                      |
| 5    |           |    |                                              | The SS changes physical channel configuration according to the IE "Physical channel information elements" included in the CELL UPDATE CONFIRM message. |
| 6    | →         |    | PHYSICAL CHANNEL<br>RECONFIGURATION COMPLETE |                                                                                                                                                        |
| 7    | →         |    | TRANSPORT CHANNEL<br>RECONFIGURATION FAILURE | The IE "failure cause" shall be set to "physical channel failure"                                                                                      |

## Specific Message Contents

## TRANSPORT CHANNEL RECONFIGURATION (Step 1)

Use the message sub-type titled as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A.

## CELL UPDATE (Step 3)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark                                           |
|---------------------|--------------------------------------------------------|
| U-RNTI              |                                                        |
| - SRNC Identity     | Check to see if set to '0000-0000-0001'                |
| - S-RNTI            | Check to see if set to '0000-0000-0000-0000-0000-0001' |
| Cell Update Cause   | "radio-link failure"                                   |

## CELL UPDATE CONFIRM (Step 4) (FDD)

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A with the following exceptions:

| Information Element                       | Value/remark                                                         |
|-------------------------------------------|----------------------------------------------------------------------|
| UplinkDPCH Info                           | Same as RADIO BEARER SETUP message used to move to initial condition |
| Downlink information for each radio links | Same as RADIO BEARER SETUP message used to move to initial condition |

#### CELL UPDATE CONFIRM (Step 4) (TDD)

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A with the following exceptions:

| Information Element                       | Value/remark                                                         |
|-------------------------------------------|----------------------------------------------------------------------|
| RRC State Indicator                       | CELL_DCH                                                             |
| Uplink DPCH timeslots and codes           | Same as RADIO BEARER SETUP message used to move to initial condition |
| Downlink information for each radio links | Same as RADIO BEARER SETUP message used to move to initial condition |

#### TRANSPORT CHANNEL RECONGURATION FAILURE (Step 7)

The contents of TRANSPORT CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the TRANSPORT CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark               |
|---------------------|----------------------------|
| Failure-cause       | "physical channel failure" |

#### 8.2.4.4.5 Test requirement

After step 2 the UE shall transmit a CELL UPDATE message on the uplink CCCH with IE "Cell update cause" set to "radio link failure".

After step 5 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC.

After step 6 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the IE "failure-cause" to "physical channel failure".

#### 8.2.4.5 Transport Channel Reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

##### 8.2.4.5.1 Definition

##### 8.2.4.5.2 Conformance requirement

If the UE receives a TRANSPORT CHANNEL RECONFIGURATION message during a reconfiguring procedure due to a radio bearer message other than TRANSPORT CHANNEL RECONFIGURATION message, it shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.4, clause 8.6.3.11.

##### 8.2.4.5.3 Test purpose

To confirm that if the UE receives a TRANSPORT CHANNEL RECONFIGURATION message during a reconfiguring procedure due to a radio bearer message other than a TRANSPORT CHANNEL RECONFIGURATION, it shall keep its configuration as if the TRANSPORT CHANNEL RECONFIGURATION message had not been received and complete the reconfiguration procedure according to the previously received message.

#### 8.2.4.5.4 Method of test

##### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

##### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message before the "activation time" indicated in the RADIO BEARER RECONFIGURATION message expires. When the UE receives the TRANSPORT CHANNEL RECONFIGURATION message, the UE shall keep the configuration as if it had not received the TRANSPORT CHANNEL RECONFIGURATION message and shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC with IE "failure-cause" set to "incompatible simultaneous reconfiguration". After the SS acknowledges the TRANSPORT CHANNEL RECONFIGURATION FAILURE message, the UE reconfigures the new physical configuration parameters upon the activation time and transmits a RADIO BEARER RECONFIGURATION COMPLETE message on DCCH using AM RLC.

##### Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                                                      |
|------|-----------|----|-------------------------------------------|--------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                              |
| 1    |           | ←  | RADIO BEARER RECONFIGURATION              | Including IE "Uplink DPCH info" for FDD mode                                                                 |
| 2    |           | ←  | TRANSPORT CHANNEL RECONFIGURATION         | Sent before the time specified in IE "Activation Time Info" of message in step 1 has elapsed.                |
| 3    |           | →  | TRANSPORT CHANNEL RECONFIGURATION FAILURE | The UE shall not change the configuration due to the reception of TRANSPORT CHANNEL RECONFIGURATION message. |
| 4    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE     | This message is on DCCH using AM RLC.                                                                        |

##### Specific Message Contents

##### RADIO BEARER RECONFIGURATION (Step 1) (FDD)

For RADIO BEARER RECONFIGURATION in step 1, use the message sub-type indicated as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element    | Value/remark                        |
|------------------------|-------------------------------------|
| Activation Time        | Current CFN-[current CFN mod 8 + 8] |
| Uplink DPCH info       |                                     |
| Scrambling code number | 1                                   |

##### RADIO BEARER RECONFIGURATION (Step 1) (TDD)

For RADIO BEARER RECONFIGURATION in step 1, use the message sub-type indicated as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element             | Value/remark                        |
|---------------------------------|-------------------------------------|
| Activation Time                 | Current CFN-[current CFN mod 8 + 8] |
| Uplink DPCH timeslots and codes |                                     |
| First timeslot code list        | Assigned by SS                      |

**TRANSPORT CHANNEL RECONFIGURATION (Step 2) (FDD)**

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type indicated as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element        | Value/remark                        |
|----------------------------|-------------------------------------|
| Activation Time            | Current CFN-[current CFN mod 8 + 8] |
| Uplink DPCH info           |                                     |
| ——— Scrambling code number | 2                                   |

**TRANSPORT CHANNEL RECONFIGURATION (Step 2) (TDD)**

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type indicated as as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element             | Value/remark                                       |
|---------------------------------|----------------------------------------------------|
| Activation Time                 | Current CFN-[current CFN mod 8 + 8]                |
| Uplink DPCH timeslots and codes |                                                    |
| ——— First timeslot code list    | A different code combination that used previously. |

**TRANSPORT CHANNEL RECONFIGURATION FAILURE**

The contents of TRANSPORT CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the TRANSPORT CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark                              |
|---------------------|-------------------------------------------|
| Failure cause       | Incompatible simultaneous reconfiguration |

**8.2.4.5.5 ——— Test requirement**

After step 2 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC with IE "failure cause" set to "Incompatible simultaneous reconfiguration".

After step 3 the UE transmit a RADIO BEARER RECONFIGURATION COMPLETE message on the new coniguration specified in step 1.

**8.2.4.6 ——— Transport channel reconfiguration from CELL\_DCH to CELL\_DCH: Failure (Invalid message reception and Invalid configuration)****8.2.4.6.1 ——— Definition****8.2.4.6.2 ——— Conformance requirement**

The UE shall keep its old configuration when the UE receives an invalid TRANSPORT CHANNEL RECONFIGURATION message which does not include any IEs except IE "Message Type". Then it shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message with the value "protocol error" set in IE "failure cause" and also "ASN.1 violation or encoding error" in IE "Protocol error cause". The UE shall keep existing configuration upon reception of a TRANSPORT CHANNEL RECONFIGURATION message, which includes some IEs set to give an invalid configuration, and then the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message including IE "failure cause" set to "invalid configuration".

**Reference**

3GPP TS 25.331 clause 8.2.4.



### 8.2.4.6.3 ————— Test purpose

To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, if the received TRANSPORT CHANNEL RECONFIGURATION message which does not include any IEs except IE "Message Type".

To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if it receives a TRANSPORT CHANNEL RECONFIGURATION message including some IEs set to give an invalid configuration..

### 8.2.4.6.4 ————— Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits an invalid TRANSPORT CHANNEL RECONFIGURATION message to the UE, which does not include any IEs except IE "Message Type". The UE shall keep the old configuration and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, specifying "protocol error" in IE "failure cause" and also indicating "ASN.1 violation or encoding error" in IE "Protocol error cause". SS transmits a TRANSPORT CHANNEL RECONFIGURATION message including some IEs set to give an invalid configuration. The UE keeps current configuration and transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the value "invalid configuration" to IE "failure cause".

#### Expected sequence

| Step | Direction |    | Message                                   | Comment                                                        |
|------|-----------|----|-------------------------------------------|----------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                |
| 1    |           | ←  | TRANSPORT CHANNEL RECONFIGURATION         | See specific message content.                                  |
| 2    |           | →  | TRANSPORT CHANNEL RECONFIGURATION FAILURE | The UE does not change its configuration.                      |
| 3    |           | ←  | TRANSPORT CHANNEL RECONFIGURATION         | This message includes IE set to give an invalid configuration  |
| 4    |           |    |                                           | The UE does not change its configuration                       |
| 5    |           | →  | TRANSPORT CHANNEL RECONFIGURATION FAILURE | The IE "failure cause" shall be set to "invalid configuration" |

#### Specific Message Contents

##### TRANSPORT CHANNEL RECONFIGURATION (Step 1)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

##### TRANSPORT CHANNEL RECONFIGURATION FAILURE (Step 2)

The contents of TRANSPORT CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the TRANSPORT CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element                      | Value/remark                      |
|------------------------------------------|-----------------------------------|
| <del>Failure cause</del>                 |                                   |
| <del>—— Failure cause</del>              | Protocol error                    |
| <del>—— Protocol error information</del> |                                   |
| <del>—— Protocol error cause</del>       | ASN.1 violation or encoding error |

#### ~~TRANSPORT CHANNEL RECONFIGURATION (Step 3) (FDD)~~

Use the message sub-type titled as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element                     | Value/remark |
|-----------------------------------------|--------------|
| <del>—— Default DPCH Offset Value</del> | 512          |
| <del>—— DPCH frame offset</del>         | 1024         |

#### ~~TRANSPORT CHANNEL RECONFIGURATION (Step 3) (TDD)~~

Use the message sub-type titled as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element      | Value/remark |
|--------------------------|--------------|
| <del>—— PRACH TFCS</del> | Present      |

#### ~~TRANSPORT CHANNEL RECONFIGURATION FAILURE (Step 5)~~

The contents of TRANSPORT CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the TRANSPORT CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element      | Value/remark          |
|--------------------------|-----------------------|
| <del>Failure cause</del> | Invalid configuration |

#### ~~8.2.4.6.5 — Test requirement~~

After step 1 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. The message shall specify "protocol error" in IE "failure cause" and set value "ASN.1 violation or encoding error" in IE "Protocol error cause".

After step 4 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting IE "failure cause" to "invalid configuration".

#### ~~8.2.4.7 — Transport channel reconfiguration from CELL\_DCH to CELL\_FACH: Success~~

##### ~~8.2.4.7.1 — Definition~~

##### ~~8.2.4.7.2 — Conformance requirement~~

The UE shall correctly reconfigure the channels according to TRANSPORT CHANNEL RECONFIGURATION message and transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### ~~Reference~~

3GPP TS 25.331 clause 8.2.4.

### 8.2.4.7.3 ~~Test purpose~~

~~To confirm that the UE reconfigures the channel according to a TRANSPORT CHANNEL RECONFIGURATION message.~~

### 8.2.4.7.4 ~~Method of test~~

#### ~~Initial Condition~~

~~System Simulator: 1 cell.~~

~~UE: PS-DCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108.~~

#### ~~Test Procedure~~

~~The UE is in CELL\_DCH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE and the UE performs a state transition from CELL\_DCH to CELL\_FACH in the same cell. The UE then reconfigures the new channels according to this message and system information messages. Finally, the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message using AM RLC.~~

#### ~~Expected sequence~~

| Step | Direction |    | Message                                       | Comment                                                                    |
|------|-----------|----|-----------------------------------------------|----------------------------------------------------------------------------|
|      | UE        | SS |                                               |                                                                            |
| 1    | ←         |    | TRANSPORT CHANNEL<br>RECONFIGURATION          | IE "Uplink-DPCH Info" and IE<br>"Downlink-DPCH Info" are not<br>specified. |
| 2    |           |    |                                               | UE shall perform the<br>reconfiguration                                    |
| 3    | →         |    | TRANSPORT CHANNEL<br>RECONFIGURATION COMPLETE |                                                                            |

#### ~~Specific Message Contents~~

#### ~~TRANSPORT CHANNEL RECONFIGURATION~~

~~Use the message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with the following exception:~~

| Information Element | Value/remark         |
|---------------------|----------------------|
| New C-RNTI          | 0000 0000 0000 0001B |

### 8.2.4.7.5 ~~Test requirement~~

~~After step 2 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the common physical channel.~~

~~8.2.4.8 Void~~~~8.2.4.9 Transport channel reconfiguration from CELL\_DCH to CELL\_FACH: Success (Cell re-selection)~~~~8.2.4.9.1 Definition~~~~8.2.4.9.2 Conformance requirement~~

~~The UE shall initiate a cell update procedure when the UE performs cell reselection during a transport channel reconfiguration procedure. After the UE completes a cell update procedure, the UE shall continue to perform the transport channel reconfiguration procedure and correctly reconfigure the channel.~~

~~Reference~~

~~3GPP TS 25.331 clause 8.2.4.~~

~~8.2.4.9.3 Test purpose~~

~~To confirm that the UE transmits TRANSPORT CHANNEL RECONFIGURATION COMPLETE message after it completes a cell update procedure.~~

~~8.2.4.9.4 Method of test~~~~Initial Condition~~

~~System Simulator: 1 cell.~~

~~UE: PS-DCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108.~~

~~Test Procedure~~

~~The UE is in CELL\_DCH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message, which includes IE "Primary CPICH info" and no dedicated physical channel information to transit from CELL\_DCH to CELL\_FACH, to the UE. As the UE cannot detect the specified cell, the UE shall initiate a cell re-selection procedure and transmits a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "cell reselection". The SS shall transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving a CELL UPDATE message. The UE transmits a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCH using AM RLC.~~

~~Expected sequence~~

| Step | Direction |    | Message                                       | Comment                                                                 |
|------|-----------|----|-----------------------------------------------|-------------------------------------------------------------------------|
|      | UE        | SS |                                               |                                                                         |
| 1    |           |    | Void                                          |                                                                         |
| 2    |           |    | Void                                          |                                                                         |
| 3    |           | ←  | TRANSPORT CHANNEL<br>RECONGURATION            | This message include IE<br>"Primary CPICH info".                        |
| 4    |           | →  | CELL UPDATE                                   | The value "cell reselection" shall<br>be set in IE "Cell update cause". |
| 5    |           | ←  | CELL UPDATE CONFIRM                           |                                                                         |
| 6    |           |    | Void                                          |                                                                         |
| 7    |           | →  | TRANSPORT CHANNEL<br>RECONFIGURATION COMPLETE |                                                                         |

## Specific Message Contents

### TRANSPORT CHANNEL RECONFIGURATION (Step 3) (FDD)

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with the following exceptions:

| Information Element                                                                              | Value/remark |
|--------------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>—— Primary CPICH info<br>—— Primary scrambling code | 150          |

### TRANSPORT CHANNEL RECONFIGURATION (Step 3) (TDD)

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with the following exceptions:

| Information Element                                                                         | Value/remark |
|---------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>—— Primary CCPCH info<br>—— Cell parameters ID | 4            |

### CELL UPDATE (Step 4)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark       |
|---------------------|--------------------|
| Cell Update Cause   | "cell reselection" |

### CELL UPDATE CONFIRM (Step 5)

The contents of CELL UPDATE CONFIRM message is same as "CELL UPDATE CONFIRM message" as found in Annex A.

#### 8.2.4.9.5 Test requirement

After step 3 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "cell reselection".

After step 6 UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

### 8.2.4.10 Transport channel reconfiguration from CELL\_FACH to CELL\_DCH: Success

#### 8.2.4.10.1 Definition

#### 8.2.4.10.2 Conformance requirement

The UE shall correctly reconfigure the channels according to a TRANSPORT CHANNEL RECONFIGURATION message, which trigger a state transition from CELL\_FACH to CELL\_DCH in the same cell.

#### Reference

3GPP TS 25.331 clause 8.2.4.

### 8.2.4.10.3 ~~Test purpose~~

To confirm that the UE reconfigures a new channel using dedicated physical channel according to a TRANSPORT CHANNEL RECONFIGURATION message.

### 8.2.4.10.4 ~~Method of test~~

#### ~~Initial Condition~~

System Simulator: 1 cell.

UE: PS-DCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

#### ~~Test Procedure~~

The UE is in CELL\_FACH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message, which includes IE "Uplink DPCH info" and IE "Downlink DPCH info" leading to a state transition from CELL\_FACH to CELL\_DCH in the same cell, to the UE. The UE shall reconfigure the new channel according to this message. Finally, the UE transmits a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message using AM RLC.

#### ~~Expected sequence~~

| Step | Direction |    | Message                                    | Comment                                                                         |
|------|-----------|----|--------------------------------------------|---------------------------------------------------------------------------------|
|      | UE        | SS |                                            |                                                                                 |
| 1    | ←         |    | TRANSPORT CHANNEL RECONFIGURATION          | Includes both IE "Uplink DPCH Info" and IE "Downlink DPCH Info" in the message. |
| 2    |           |    |                                            | Reconfiguration of transport channel                                            |
| 3    | →         |    | TRANSPORT CHANNEL RECONFIGURATION COMPLETE |                                                                                 |

#### ~~Specific Message Contents~~

#### ~~TRANSPORT CHANNEL RECONFIGURATION~~

Use the message sub-type titled "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A.

### 8.2.4.10.5 ~~Test requirement~~

After step 2 the UE shall transmit a TRANSPORT RECONFIGURATION COMPLETE message on the newly configured DPCH.

### 8.2.4.11 ~~Transport channel reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Unsupported configuration)~~

#### 8.2.4.11.1 ~~Definition~~

#### 8.2.4.11.2 ~~Conformance requirement~~

The UE shall keep its old configuration when the UE receives a TRANSPORT CHANNEL RECONFIGURATION message which includes unsupported configuration parameters and transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "configuration unsupported" in IE "failure cause".

#### ~~Reference~~

3GPP TS 25.331 clause 8.2.4

### 8.2.4.11.3 ~~Test purpose~~

To confirm that the UE transmits a ~~TRANSPORT CHANNEL RECONFIGURATION FAILURE~~ message on the DCCH using AM RLC when it receives a ~~TRANSPORT CHANNEL RECONFIGURATION~~ message which includes unsupported configuration parameters.

### 8.2.4.11.4 ~~Method of test~~

#### ~~Initial Condition~~

~~System Simulator: 1 cell.~~

~~UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.~~

#### ~~Test Procedure~~

The UE is in CELL\_FACH state. The SS transmits a ~~TRANSPORT CHANNEL RECONFIGURATION~~ message, which includes configuration parameters unsupported by the UE, to the UE. The UE shall transmit a ~~TRANSPORT CHANNEL RECONFIGURATION FAILURE~~ message on the DCCH using AM RLC, setting "configuration unsupported" in IE "failure cause".

#### ~~Expected sequence~~

| Step | Direction |    | Message                                              | Comment                                                  |
|------|-----------|----|------------------------------------------------------|----------------------------------------------------------|
|      | UE        | SS |                                                      |                                                          |
| 1    | ←         |    | <del>TRANSPORT CHANNEL RECONGURATION</del>           | The message includes configuration unsupported by the UE |
| 2    | →         |    | <del>TRANSPORT CHANNEL RECONFIGURATION FAILURE</del> | The UE shall not change its configuration.               |

#### ~~Specific Message Contents~~

##### ~~TRANSPORT CHANNEL RECONFIGURATION (FDD)~~

The contents of ~~TRANSPORT CHANNEL RECONFIGURATION~~ message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element             | Value/remark |
|---------------------------------|--------------|
| Frequency info                  |              |
| <del>UARFCN uplink (Nu)</del>   | 0            |
| <del>UARFCN downlink (Nd)</del> | 950          |

##### ~~TRANSPORT CHANNEL RECONFIGURATION (TDD)~~

The contents of ~~TRANSPORT CHANNEL RECONFIGURATION~~ message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element    | Value/remark |
|------------------------|--------------|
| Frequency info         |              |
| <del>UARFCN (Nt)</del> | 0            |

##### ~~TRANSPORT CHANNEL RECONFIGURATION FAILURE~~

The contents of ~~TRANSPORT CHANNEL RECONFIGURATION FAILURE~~ message in this test case is the same as the ~~TRANSPORT CHANNEL RECONFIGURATION FAILURE~~ message as found in Annex A, with the following exceptions:

| Information Element | Value/remark              |
|---------------------|---------------------------|
| Failure-cause       | Configuration unsupported |

#### 8.2.4.11.5 ——— Test requirement

After step 1 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. The UE shall set "configuration unsupported" in IE "failure-cause" of the message.

#### 8.2.4.12 ——— Transport channel reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Physical channel failure and successful reversion to old channel)

##### 8.2.4.12.1 ——— Definition

##### 8.2.4.12.2 ——— Conformance requirement

The UE shall revert to the old configuration when the UE has failed to reconfigure the new transport channel requested and detects the same serving cell only. The UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message to UTRAN.

#### Reference

3GPP TS 25.331 clause 8.2.4.

##### 8.2.4.12.3 ——— Test purpose

To confirm that the UE reverts to the old configuration and transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, if the UE fails to reconfigure the new channel according to a TRANSPORT CHANNEL RECONFIGURATION message.

##### 8.2.4.12.4 ——— Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is in CELL\_DCH state. SS transmits a TRANSPORT CHANNEL RECONFIGURATION message, which includes the new transport channel parameters, to the UE. However, SS keeps its current physical channel configuration.. Hence, the UE shall experience a failure in the reconfiguration process. After T312 expires, the UE shall revert to the old channel configuration. Then the UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, stating the reason "physical channel failure" in IE "failure-cause".

#### Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                                    |
|------|-----------|----|-------------------------------------------|--------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                            |
| 1    |           | ←  | TRANSPORT CHANNEL RECONGURATION           | Message includes IE "Downlink DPCCH Info" and IE "Uplink DPCCH Info"                       |
| 2    |           |    |                                           | SS does not reconfigure the channel causing the UE to detect a physical channel failure.   |
| 3    |           | →  | TRANSPORT CHANNEL RECONFIGURATION FAILURE | After T312 expires the UE shall revert to the old configuration and transmit this message. |



## Specific Message Contents

### TRANSPORT CHANNEL RECONFIGURATION

Use the message sub-type titled "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A.

### TRANSPORT CHANNEL RECONFIGURATION FAILURE

The contents of TRANSPORT CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the TRANSPORT CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark             |
|---------------------|--------------------------|
| Failure cause       | Physical channel failure |

#### 8.2.4.12.5 Test requirement

After step 2 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the value "physical channel failure" in IE "failure cause".

#### 8.2.4.13 Transport channel reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Physical channel failure and reversion failure)

##### 8.2.4.13.1 Definition

##### 8.2.4.13.2 Conformance requirement

The UE shall initiate a cell update procedure when it selects another cell, following a physical channel failure in the transport channel reconfiguration procedure. After the UE completes the cell update procedure, the UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "physical channel failure" in IE "failure cause".

## Reference

3GPP TS 25.331 clause 8.2.4.

##### 8.2.4.13.3 Test purpose

To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message after it completes a cell update procedure, when the UE cannot reconfigure the new channel before timer T312 expires.

##### 8.2.4.13.4 Method of test

## Initial Condition

System Simulator: 2 cells – Cell 1 and 2 are active.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108 in cell 1.

## Test Procedure

Table 8.2.4.13

| Parameter              | Unit         | Cell 1 |     | Cell 2 |     |
|------------------------|--------------|--------|-----|--------|-----|
|                        |              | T0     | T1  | T0     | T1  |
| UTRA-RF Channel Number |              | Ch. 1  |     | Ch. 1  |     |
| CPICH-Ec (FDD)         | dBm/3.84 MHz | -60    | -75 | -75    | -60 |
| P-CCPCH RSCP (TDD)     | dBm          | -60    | -75 | -75    | -60 |

Table 8.2.4.13 illustrates the downlink power to be applied for the 2-cells at various time instants of the test execution. SS switches the power settings between columns "T0" and "T1", whenever the description in multi-cell condition specifies a reverse in the transmission power settings for cell 1 and cell 2.

The UE is in CELL\_FACH state in cell 1. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE in cell 1. The message includes a new configuration parameters. However, the SS does not reconfigure the specified configuration. At the same time, the SS configures its downlink transmission power settings according to columns "T1" in table 8.2.4.13. As a result, the UE cannot synchronise with the SS on the new DPCH before T312 expires. The UE initiates the cell re-selection procedure transmits a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "cell reselection" in cell 2. The SS shall transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving a CELL UPDATE message. The UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM-RLC, setting the value "physical channel failure" to IE "failure cause".

## Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                                                                                                                                                               |
|------|-----------|----|-------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                                                                                                       |
| 1    |           | ←  | TRANSPORT CHANNEL RECONFIGURATION         |                                                                                                                                                                                                                       |
| 2    |           |    |                                           | The SS does not reconfigure L1 and transport channel in accordance with the settings in the message, and applies the downlink transmission power settings, according to the values in columns "T1" of table 8.2.4.13. |
| 3    |           |    | Void                                      |                                                                                                                                                                                                                       |
| 4    |           |    |                                           | The UE shall find cell 2, camp onto it,                                                                                                                                                                               |
| 5    |           | →  | CELL UPDATE                               | This message include the value "cell reselection" set in IE "Cell update cause".                                                                                                                                      |
| 6    |           | ←  | CELL UPDATE CONFIRM                       |                                                                                                                                                                                                                       |
| 7    |           |    | Void                                      |                                                                                                                                                                                                                       |
| 8    |           | →  | TRANSPORT CHANNEL RECONFIGURATION FAILURE | The IE "failure cause" shall be set to "physical channel failure"                                                                                                                                                     |

## Specific Message Contents

## TRANSPORT CHANNEL RECONFIGURATION (Step 1)

Use the message sub-type titled "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A.

### CELL UPDATE (Step 5)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark                  |
|---------------------|-------------------------------|
| U-RNTI              |                               |
| -SRNC Identity      | Assigned previously in cell 1 |
| -S-RNTI             | Assigned previously in cell 1 |
| Cell Update Cause   | "cell reselection"            |

### CELL UPDATE CONFIRM (Step 6)

The contents of CELL UPDATE CONFIRM message are identical as "CELL UPDATE CONFIRM message" as found in Annex A.

### TRANSPORT CHANNEL RECONFIGURATION FAILURE (Step 8)

The contents of TRANSPORT CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the TRANSPORT CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark               |
|---------------------|----------------------------|
| Failure-cause       | "physical channel failure" |

#### 8.2.4.13.5 — Test requirement

After step 4 the UE shall transmit a CELL UPDATE message on the uplink CCCH with IE "Cell update cause" set to "cell reselection" in cell 2.

After step 7 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the IE "failure-cause" to "physical channel failure".

#### 8.2.4.14 — Transport Channel Reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

##### 8.2.4.14.1 — Definition

##### 8.2.4.14.2 — Conformance requirement

If the UE receives a TRANSPORT CHANNEL RECONFIGURATION message during a reconfiguring procedure due to a radio bearer message other than TRANSPORT CHANNEL RECONFIGURATION message, it shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.4, clause 8.6.3.11.

##### 8.2.4.14.3 — Test purpose

To confirm that if the UE receives a TRANSPORT CHANNEL RECONFIGURATION message during a reconfiguring procedure due to a radio bearer message other than a TRANSPORT CHANNEL RECONFIGURATION, it shall keep its configuration as if the TRANSPORT CHANNEL RECONFIGURATION message had not been received and complete the reconfiguration procedure according to the previously received message.

#### 8.2.4.14.4 Method of test

##### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

##### Test Procedure

The UE is in CELL\_FACH state. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message before the "activation time" indicated in the RADIO BEARER RECONFIGURATION message expires. When the UE receives the TRANSPORT CHANNEL RECONFIGURATION message, the UE shall keep its current configuration as if it had not received the TRANSPORT CHANNEL RECONFIGURATION message and shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC with IE "failure cause" set to "incompatible simultaneous reconfiguration". After the SS acknowledges the TRANSPORT CHANNEL RECONFIGURATION FAILURE message, the UE reconfigures the new physical channel parameters upon the activation time and transmits a RADIO BEARER RECONFIGURATION COMPLETE message on DCCH using AM RLC.

##### Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                                 |
|------|-----------|----|-------------------------------------------|-----------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                         |
| 1    | ←         |    | RADIO BEARER RECONFIGURATION              |                                                                                         |
| 2    | ←         |    | TRANSPORT CHANNEL RECONFIGURATION         | Sent before the elapse of the Activation time specified in step 1.                      |
| 3    |           | →  | TRANSPORT CHANNEL RECONFIGURATION FAILURE | The UE does not reconfigure according to the TRANSPORT CHANNEL RECONFIGURATION message. |
| 4    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE     | This message is on DCCH using AM RLC.                                                   |

##### Specific Message Contents

##### RADIO BEARER RECONFIGURATION (Step 1) (FDD)

For RADIO BEARER RECONFIGURATION in step 1, use the message sub-type indicated as "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions

| Information Element    | Value/remark                        |
|------------------------|-------------------------------------|
| Activation Time Info   | Current CFN-[current CFN mod 8 + 8] |
| Uplink DPCH info       |                                     |
| Scrambling code number | 1                                   |

##### RADIO BEARER RECONFIGURATION (Step 1) (TDD)

For RADIO BEARER RECONFIGURATION in step 1, use the message sub-type indicated as "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions

| Information Element             | Value/remark                        |
|---------------------------------|-------------------------------------|
| Activation Time                 | Current CFN-[current CFN mod 8 + 8] |
| Uplink DPCH timeslots and codes |                                     |
| First timeslot code list        | Assigned by SS                      |

##### TRANSPORT CHANNEL RECONFIGURATION (Step 2) (FDD)

For TRANSPORT CHANNEL RECONFIGURATION in step 2, use the message sub-type indicated as "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element       | Value/remark |
|---------------------------|--------------|
| Activation-Time Info      | Not Present  |
| Uplink DPCH info          |              |
| ———Scrambling-code-number | 2            |

#### TRANSPORT CHANNEL RECONFIGURATION (Step 2) (TDD)

For TRANSPORT CHANNEL RECONFIGURATION in step 2, use the message sub-type indicated as "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element              | Value/remark                                       |
|----------------------------------|----------------------------------------------------|
| Activation-Time                  | Not Present                                        |
| -Uplink DPCH timeslots and codes |                                                    |
| -First timeslot code list        | A different code combination that used previously. |

#### TRANSPORT CHANNEL RECONFIGURATION FAILURE

The contents of TRANSPORT CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the TRANSPORT CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark                              |
|---------------------|-------------------------------------------|
| Failure-cause       | Incompatible simultaneous reconfiguration |

##### 8.2.4.14.5 ——— Test requirement

After step 2 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC with IE "failure-cause" set to "Incompatible simultaneous reconfiguration".

After step 3 the UE shall transmit a RADIO BEARER RECONFIGURATION COMPLETE message.

##### 8.2.4.15 ——— Transport channel reconfiguration from CELL\_FACH to CELL\_DCH: Failure (Invalid message reception and Invalid configuration)

###### 8.2.4.15.1 ——— Definition

###### 8.2.4.15.2 ——— Conformance requirement

The UE shall keep its old configuration when the UE receives an invalid TRANSPORT CHANNEL RECONFIGURATION message which does not includes any IEs except IE "Message Type". The UE shall then transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message, specifying "protocol error" in IE "failure-cause" and also "ASN.1 violation or encoding error" in IE "Protocol error cause". The UE shall keep existing configuration upon the reception of a TRANSPORT CHANNEL RECONFIGURATION message, which includes some IEs set to give an invalid configuration, and then the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE including IE "failure-cause" set to "invalid configuration".

#### Reference

3GPP TS 25.331 clause 8.2.4.

###### 8.2.4.15.3 ——— Test purpose

To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, if it receives an invalid TRANSPORT CHANNEL RECONFIGURATION message which does not include any IEs except IE "Message Type".

To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if it receives a TRANSPORT CHANNEL RECONFIGURATION message including some IEs set to give an invalid configuration.

#### 8.2.4.15.4 Method of test

##### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

##### Test Procedure

The UE is in CELL\_FACH state. The SS transmits an invalid TRANSPORT CHANNEL RECONFIGURATION message, which does not include any IEs except IE "Message Type", to the UE. The UE shall keep the old configuration and then transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. This message shall contain the value "protocol error" in IE "failure cause" and also "ASN.1 violation or encoding error" in IE "Protocol error cause". SS transmits TRANSPORT CHANNEL RECONFIGURATION message including some IEs set to give an invalid configuration. The UE keeps its current configuration and transmits a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting IE "failure cause" to "invalid configuration".

##### Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                 |
|------|-----------|----|-------------------------------------------|-------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                         |
| 1    |           | ←  | TRANSPORT CHANNEL RECONFIGURATION         | See specific message content.                                           |
| 2    |           | →  | TRANSPORT CHANNEL RECONFIGURATION FAILURE | The UE does not change its configuration.                               |
| 3    |           | ←  | TRANSPORT CHANNEL RECONFIGURATION         | This message includes IEs which is set to give an invalid configuration |
| 4    |           |    |                                           | The UE does not change its configuration.                               |
| 5    |           | →  | TRANSPORT CHANNEL RECONFIGURATION FAILURE | The IE "failure cause" shall be set to "invalid configuration"          |

##### Specific Message Contents

##### TRANSPORT CHANNEL RECONFIGURATION (Step 1)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

##### TRANSPORT CHANNEL RECONFIGURATION FAILURE (Step 2)

The contents of TRANSPORT CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the TRANSPORT CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element          | Value/remark                      |
|------------------------------|-----------------------------------|
| Failure cause                |                                   |
| → Failure cause              | Protocol error                    |
| → Protocol error information |                                   |
| → Protocol error cause       | ASN.1 violation or encoding error |

### TRANSPORT CHANNEL RECONFIGURATION (Step 3) (FDD)

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element                  | Value/remark |
|--------------------------------------|--------------|
| <del>Default DPCH Offset Value</del> | 512          |
| <del>DPCH frame offset</del>         | 1024         |

### TRANSPORT CHANNEL RECONFIGURATION (Step 3) (TDD)

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element   | Value/remark |
|-----------------------|--------------|
| <del>PRACH TFCS</del> | Present      |

### TRANSPORT CHANNEL RECONFIGURATION FAILURE (Step 5)

The contents of TRANSPORT CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the TRANSPORT CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark          |
|---------------------|-----------------------|
| Failure cause       | Invalid configuration |

#### 8.2.4.15.5 ~~Test requirement~~

After step 1 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. The content of the message shall specify "protocol error" in IE "failure cause" and also "ASN.1 violation or encoding error" in IE "Protocol error cause".

After step 4 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting IE "failure cause" to "invalid configuration".

#### 8.2.4.16 ~~Transport channel reconfiguration from CELL\_FACH to CELL\_FACH: Success with no transport channel type switching~~

##### 8.2.4.16.1 ~~Definition~~

##### 8.2.4.16.2 ~~Conformance requirement~~

The UE shall remain in CELL\_FACH state in another cell and transmit TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC after transition from CELL\_FACH in the current cell to CELL\_FACH in another cell as requested in the received TRANSPORT CHANNEL RECONFIGURATION message.

#### Reference

3GPP TS 25.331 clause 8.2.4.

##### 8.2.4.16.3 ~~Test purpose~~

To confirm that the UE transits from CELL\_FACH in the current cell to CELL\_FACH in another cell according to a TRANSPORT CHANNEL RECONFIGURATION message received from the SS.

8.2.4.16.4 Method of test

Initial Condition

System Simulator: 2 cells—Cell 1 and 2 are active.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

Test Procedure

Table 8.2.4.16

| Parameter              | Unit          | Cell 1 |     | Cell 2 |     |
|------------------------|---------------|--------|-----|--------|-----|
|                        |               | T0     | T1  | T0     | T1  |
| UTRA—RF Channel Number |               | Ch. 1  |     | Ch. 1  |     |
| CPICH Ec (FDD)         | dBm/ 3.84 MHz | -60    | -75 | -75    | -60 |
| P-CCPCH RSCP (TDD)     | dBm           | -60    | -75 | -75    | -60 |

Table 8.2.4.16 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution. SS switches the power settings between columns "T0" and "T1", whenever the description in multi-cell condition specifies a reverse in the transmission power settings for cell 1 and cell 2.

The UE is in CELL\_FACH state in cell 1. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message, which includes the parameters that invoke the UE to transit from CELL\_FACH in the current cell to CELL\_FACH in cell 2, to the UE. Then the SS configures its downlink transmission power settings according to columns "T1" in table 8.2.4.16. The UE moves to cell 2 and configures the new transport channels and the common physical channel according to the system information messages and transmits a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message using AM-RLC.

Expected sequence

| Step | Direction |    | Message                                    | Comment                                                                                                             |
|------|-----------|----|--------------------------------------------|---------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                            |                                                                                                                     |
| 1    | ←         |    | TRANSPORT CHANNEL RECONFIGURATION          |                                                                                                                     |
| 2    |           |    |                                            | The SS applies the downlink transmission power settings, according to the values in columns "T1" of table 8.2.4.16. |
| 3    | →         |    | TRANSPORT CHANNEL RECONFIGURATION COMPLETE |                                                                                                                     |

Specific Message Contents

TRANSPORT CHANNEL RECONFIGURATION (FDD)

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with the following exceptions:

| Information Element                                                                                | Value/remark |
|----------------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>——→ Primary CPICH info<br>——→ Primary scrambling code | 150          |



**TRANSPORT CHANNEL RECONFIGURATION (TDD)**

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with the following exceptions:

| Information Element                                                                                         | Value/remark |
|-------------------------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br><del>Primary CCPCH info</del><br><del>Cell parameters ID</del> | 4            |

**8.2.4.16.5 ~~Test requirement~~**

After step 2 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on DCCH using AM RLC in cell 2.

**8.2.4.17 ~~Transport channel reconfiguration from CELL\_FACH to CELL\_FACH: Success (Cell re-selection)~~****8.2.4.17.1 ~~Definition~~****8.2.4.17.2 ~~Conformance requirement~~**

The UE shall initiate the cell update procedure when the UE performs cell reselection during a transport channel reconfiguration procedure. After the UE complete cell update procedure, the UE shall continue to perform the transport channel reconfiguration procedure and correctly reconfigure the channel.

**Reference**

3GPP TS 25.331 clause 8.2.4.

**8.2.4.17.3 ~~Test purpose~~**

To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message after UE completes a cell update procedure indicated by a TRANSPORT CHANNEL RECONFIGURATION message.

**8.2.4.17.4 ~~Method of test~~****Initial Condition**

System Simulator: 2 cells – Cell 1 and 2 are active.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

**Test Procedure****Table 8.2.4.17**

| Parameter              | Unit         | Cell 1 |     | Cell 2 |     |
|------------------------|--------------|--------|-----|--------|-----|
|                        |              | T0     | T1  | T0     | T1  |
| UTRA-RF Channel Number |              | Ch. 1  |     | Ch. 1  |     |
| CPICH Ec (FDD)         | dBm/3.84 MHz | -60    | -75 | -75    | -60 |
| P-CCPCH RSCP (TDD)     | dBm          | -60    | -75 | -75    | -60 |

Table 8.2.4.17 illustrates the downlink power to be applied for the 2-cells at various time instants of the test execution. SS switches the power settings between columns "T0" and "T1", whenever the description in multi-cell condition specifies a reverse in the transmission-power settings for cell 1 and cell 2.

The UE is in CELL\_FACH state in cell 1. On transmitting a TRANSPORT CHANNEL RECONFIGURATION message, which does not include the IE "Primary CPICH info", the SS configures its downlink transmission power settings according to columns "T1" in table 8.2.4.17. The UE shall initiate the cell reselection procedure. The UE transmits a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "cell reselection" in cell 2. The SS shall transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving a CELL UPDATE message. The UE transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### Expected sequence

| Step | Direction |    | Message                                    | Comment                                                                                                             |
|------|-----------|----|--------------------------------------------|---------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                            |                                                                                                                     |
| 1    | ←         |    | TRANSPORT CHANNEL RECONFIGURATION          | This message does not include IE "Primary CPICH info"                                                               |
| 2    |           |    |                                            | The SS applies the downlink transmission-power settings, according to the values in columns "T1" of table 8.2.4.17. |
| 3    |           |    | Void                                       |                                                                                                                     |
| 4    | →         |    | CELL UPDATE                                | The value "cell reselection" shall be set in IE "Cell update cause".                                                |
| 5    | ←         |    | CELL UPDATE CONFIRM                        |                                                                                                                     |
| 6    |           |    | Void                                       |                                                                                                                     |
| 7    | →         |    | TRANSPORT CHANNEL RECONFIGURATION COMPLETE |                                                                                                                     |

#### Specific Message Contents

##### TRANSPORT CHANNEL RECONFIGURATION (Step 1) (FDD)

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with the following exceptions:

| Information Element                                                                            | Value/remark |
|------------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>→ Primary CPICH info<br>→ Primary scrambling code | Not Present  |

##### TRANSPORT CHANNEL RECONFIGURATION (Step 1) (TDD)

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with the following exceptions:

| Information Element                                                                       | Value/remark |
|-------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>→ Primary CCPCH info<br>→ Cell parameters ID | Not present  |

##### CELL UPDATE (Step 4)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A for FDD and Annex A for TDD.

### CELL UPDATE CONFIRM (Step 5)

The contents of CELL UPDATE CONFIRM message is same as "CELL UPDATE CONFIRM message" as found in Annex A.

#### 8.2.4.17.5 Test requirement

After step 3 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "cell reselection".

After step 6 UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

### 8.2.4.18 Transport Channel Reconfiguration from CELL\_DCH to CELL\_DCH: Success (Subsequently received)

#### 8.2.4.18.1 Definition

#### 8.2.4.18.2 Conformance requirement

If the UE receives a TRANSPORT CHANNEL RECONFIGURATION message before the UE configures the radio bearer according to the previous TRANSPORT CHANNEL RECONFIGURATION message, the UE shall ignore the new TRANSPORT CHANNEL RECONFIGURATION message and configure according to the first TRANSPORT CHANNEL RECONFIGURATION message received. Finally, the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.4, clause 8.6.3.11.

#### 8.2.4.18.3 Test purpose

To confirm that if the UE receives a TRANSPORT CHANNEL RECONFIGURATION message before the UE configures the radio bearer according to the previous TRANSPORT CHANNEL RECONFIGURATION message it ignores the second TRANSPORT CHANNEL RECONFIGURATION message and configures according to the previous TRANSPORT CHANNEL RECONFIGURATION message.

#### 8.2.4.18.4 Method of test

#### Initial Condition

System Simulator: 1 cell

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

## Test Procedure

The UE is in CELL\_DCH state. When the SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE before the activation time specified in the previous TRANSPORT CHANNEL RECONFIGURATION message elapses, the UE ignores the new TRANSPORT CHANNEL RECONFIGURATION message and configures according to the previous TRANSPORT CHANNEL RECONFIGURATION message. Finally, the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

## Expected sequence

| Step | Direction |    | Message                                    | Comment                                                                                                                                                                                                                                                         |
|------|-----------|----|--------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                            |                                                                                                                                                                                                                                                                 |
| 1    |           | ←  | TRANSPORT CHANNEL RECONFIGURATION          | For FDD, the "Secondary scrambling code is set to "1" and for TDD , the code combination is assigned by SS.                                                                                                                                                     |
| 2    |           | ←  | TRANSPORT CHANNEL RECONFIGURATION          | SS send this message before the expiry of "activation time" specified in TRANSPORT CHANNEL SETUP message of step 1. For FDD the IE "Secondary scrambling code" is set to "2". For TDD the code combination assigned is different from that assigned in stage 1. |
| 3    |           | →  | TRANSPORT CHANNEL RECONFIGURATION COMPLETE | The UE ignores the TRANSPORT CHANNEL RECONFIGURATION message in step 2 and configures according to the TRANSPORT CHANNEL RECONFIGURATION message in step 1.                                                                                                     |

## Specific Message Contents

### TRANSPORT CHANNEL RECONFIGURATION (Step 1) (FDD)

The contents of TRANSPORT CHANNEL RECONFIGURATION messages in this test case is identical to the message sub-type title as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element        | Value/remark                                     |
|----------------------------|--------------------------------------------------|
| Activation Time            | [256+Current CFN-[current CFN mod 8 + 8]]MOD 256 |
| ~Uplink DPCH Info          |                                                  |
| ~Secondary scrambling code | 1                                                |

### TRANSPORT CHANNEL RECONFIGURATION (Step 1) (TDD)

The contents of TRANSPORT CHANNEL RECONFIGURATION messages in this test case is identical to the message sub-type title as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element              | Value/remark                                     |
|----------------------------------|--------------------------------------------------|
| Activation Time                  | [256+Current CFN-[current CFN mod 8 + 8]]MOD 256 |
| ~Uplink DPCH timeslots and codes |                                                  |
| ~First timeslot code list        | Assigned in step 1                               |

### TRANSPORT CHANNEL RECONFIGURATION (Step 2)

The contents of TRANSPORT CHANNEL RECONFIGURATION messages in this test case is identical to the message sub-type title as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element        | Value/remark |
|----------------------------|--------------|
| Activation-Time            | Not Present  |
| ~Uplink DPCH Info          |              |
| ~Secondary scrambling code | 2            |

#### TRANSPORT CHANNEL RECONFIGURATION (Step 2) (TDD)

The contents of TRANSPORT CHANNEL RECONFIGURATION messages in this test case is identical to the message sub-type title as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element              | Value/remark                                         |
|----------------------------------|------------------------------------------------------|
| Activation-Time                  | Not Present                                          |
| ~Uplink DPCH timeslots and codes |                                                      |
| ~First timeslot code list        | A different code combination to that used in step 1. |

#### 8.2.4.18.5 Test requirement

After step 2 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### 8.2.4.19 Transport Channel Reconfiguration from CELL\_FACH to CELL\_DCH: Success (Subsequently received)

##### 8.2.4.19.1 Definition

##### 8.2.4.19.2 Conformance requirement

If the UE receives a TRANSPORT CHANNEL RECONFIGURATION message before the UE configures the radio bearer according to the previous TRANSPORT CHANNEL RECONFIGURATION message, the UE shall ignore the new TRANSPORT CHANNEL RECONFIGURATION message and configure according to the first TRANSPORT CHANNEL RECONFIGURATION message received. Finally, the UE shall transmit TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.4, clause 8.6.3.11.

##### 8.2.4.19.3 Test purpose

To confirm that if the UE receives a TRANSPORT CHANNEL RECONFIGURATION message before the UE configures the radio bearer according to the previous TRANSPORT CHANNEL RECONFIGURATION message it ignores the second TRANSPORT CHANNEL RECONFIGURATION message and configures according to the previous TRANSPORT CHANNEL RECONFIGURATION message.

##### 8.2.4.19.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is in CELL\_FACH state. When the SS transmits a TRANSPORT CHANNEL RECONFIGURATION message to the UE before the activation time specified in the previous TRANSPORT CHANNEL RECONFIGURATION message elapses, the UE ignores the new TRANSPORT CHANNEL RECONFIGURATION message and configures

according to the previous TRANSPORT CHANNEL RECONFIGURATION message. Finally, the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### Expected sequence

| Step | Direction |    | Message                                    | Comment                                                                                                                                                                                                   |
|------|-----------|----|--------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                            |                                                                                                                                                                                                           |
| 1    | ←         |    | TRANSPORT CHANNEL RECONFIGURATION          | For FDD, the "Secondary scrambling code" is set to "1" and for TDD, the code combination is assigned by SS.                                                                                               |
| 2    | ←         |    | TRANSPORT CHANNEL RECONFIGURATION          | Sent before the elapse of the activation time specified in step 1. For FDD the IE "Secondary scrambling code" is set to "2". For TDD the code combination assigned is different that assigned in stage 1. |
| 3    | →         |    | TRANSPORT CHANNEL RECONFIGURATION COMPLETE | The UE ignores the TRANSPORT CHANNEL RECONFIGURATION message in step 2 and configures according to the TRANSPORT CHANNEL RECONFIGURATION message in step 1.                                               |

#### Specific Message Contents

##### TRANSPORT CHANNEL RECONFIGURATION (Step 1) (FDD)

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element         | Value/remark                                                                   |
|-----------------------------|--------------------------------------------------------------------------------|
| Activation Time Info        | $[256 + \text{Current CFN} - [\text{current CFN mod } 8 + 8]] \text{MOD } 256$ |
| - Uplink DPCH Info          |                                                                                |
| - Secondary scrambling code | 1                                                                              |

##### TRANSPORT CHANNEL RECONFIGURATION (Step 1) (TDD)

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element               | Value/remark                                                                   |
|-----------------------------------|--------------------------------------------------------------------------------|
| Activation Time                   | $[256 + \text{Current CFN} - [\text{current CFN mod } 8 + 8]] \text{MOD } 256$ |
| - Uplink DPCH timeslots and codes |                                                                                |
| - First timeslot code list        | Assigned in step 1                                                             |

##### TRANSPORT CHANNEL RECONFIGURATION (Step 2) (FDD)

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element         | Value/remark |
|-----------------------------|--------------|
| Activation Time             | Not Present  |
| - Uplink DPCH Info          |              |
| - Secondary scrambling code | 2            |

### TRANSPORT CHANNEL RECONFIGURATION (Step 2) (TDD)

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element                                             | Value/remark                                         |
|-----------------------------------------------------------------|------------------------------------------------------|
| Activation Time                                                 | Not Present                                          |
| - Uplink DPCH timeslots and codes<br>- First timeslot code list | A different code combination to that used in step 1. |

#### 8.2.4.19.5 Test requirement

After step 2 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

### 8.2.4.20 Transport Channel Reconfiguration from CELL\_DCH to CELL\_PCH: Success

#### 8.2.4.20.1 Definition

#### 8.2.4.20.2 Conformance requirement

The UE shall transmit TRANSPORT CHANNEL RECONFIGURATION COMPLETE message after it receives a TRANSPORT CHANNEL RECONFIGURATION message which invoke the UE to transit from CELL\_DCH to CELL\_PCH. And then, the UE shall enter CELL\_PCH state.

#### Reference

3GPP TS 25.331 clause 8.2.4.

#### 8.2.4.20.3 Test purpose

To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message and enters CELL\_PCH state after it receives a TRANSPORT CHANNEL RECONFIGURATION message, which invoke the UE to transit from CELL\_DCH to CELL\_PCH.

#### 8.2.4.20.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message, which invoke the UE to transit from CELL\_DCH to CELL\_PCH. The UE transmits a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message using AM RLC and enters CELL\_PCH state. The SS transmits a PAGING TYPE 1 message, causing the UE to enter CELL\_FACH state and the UE shall transmit a CELL\_UPDATE message on uplink CCCH with IE "Cell update cause" set to "paging response".

## Expected sequence

| Step | Direction |    | Message                                    | Comment                                                    |
|------|-----------|----|--------------------------------------------|------------------------------------------------------------|
|      | UE        | SS |                                            |                                                            |
| 1    |           | ←  | TRANSPORT CHANNEL RECONFIGURATION          |                                                            |
| 2    |           | →  | TRANSPORT CHANNEL RECONFIGURATION COMPLETE |                                                            |
| 3    |           |    |                                            | The UE is in CELL_PCH state.                               |
| 4    |           | ←  | PAGING TYPE 1                              | The SS transmits this message included a matched identity. |
| 5    |           | →  | CELL UPDATE                                | The UE is in CELL_FACH state.                              |

## Specific Message Contents

## TRANSPORT CHANNEL RECONFIGURATION (Step 1) (FDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with following exceptions:

| Information Element                                                                           | Value/remark |
|-----------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                           | CELL_PCH     |
| Downlink information for each radio link<br>— Primary CPICH info<br>— Primary scrambling code | 100          |

## TRANSPORT CHANNEL RECONFIGURATION (Step 1) (TDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with following exceptions:

| Information Element                          | Value/remark |
|----------------------------------------------|--------------|
| RRC State Indicator                          | CELL_PCH     |
| — Primary CCPCH info<br>— Cell parameters ID | 4            |

## PAGING TYPE 1 (Step 4)

Use the same message sub-type titled "TM (Packet in PS)" in default message content of TS 34.108 with following exceptions:

| Information Element                                                                                             | Value/remark                                                                          |
|-----------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Paging record list<br>Paging record<br>— CHOICE Used paging identity<br>— U-RNTI<br>— SRNC Identity<br>— S-RNTI | UTRAN identity<br><br>Previously assigned SRNC identity<br>Previously assigned S-RNTI |

## CELL UPDATE (Step 5)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark      |
|---------------------|-------------------|
| Cell Update Cause   | "paging response" |



#### 8.2.4.20.5 ~~Test requirement~~

After step 1 the UE shall transmit TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on uplink DCCH using AM RLC.

After step 4 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "paging response".

#### 8.2.4.21 ~~Transport Channel Reconfiguration from CELL\_DCH to URA\_PCH: Success~~

##### 8.2.4.21.1 ~~Definition~~

##### 8.2.4.21.2 ~~Conformance requirement~~

The UE shall transmits TRANSPORT CHANNEL RECONFIGURATION COMPLETE message after it receives a TRANSPORT CHANNEL RECONFIGURATION message which invoke the UE to transits from CELL\_DCH to URA\_PCH. And then, the UE shall enter URA\_PCH state.

#### Reference

3GPP TS 25.331 clause 8.2.4.

##### 8.2.4.21.3 ~~Test purpose~~

To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message and enters URA\_PCH state after it received a TRANSPORT CHANNEL RECONFIGURATION message, which invoke the UE to transit from CELL\_DCH to URA\_PCH.

##### 8.2.4.21.4 ~~Method of test~~

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message, which invoke the UE to transit from CELL\_DCH to URA\_PCH. The UE transmits a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message using AM RLC and enters URA\_PCH state. The SS transmits a PAGING TYPE 1 message, causing the UE to enter CELL\_FACH state and the UE shall transmit a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "paging response".

#### Expected sequence

| Step | Direction |    | Message                                    | Comment                                                    |
|------|-----------|----|--------------------------------------------|------------------------------------------------------------|
|      | UE        | SS |                                            |                                                            |
| 1    |           | ←  | TRANSPORT CHANNEL RECONFIGURATION          |                                                            |
| 2    |           | →  | TRANSPORT CHANNEL RECONFIGURATION COMPLETE |                                                            |
| 3    |           |    |                                            | The UE is in URA_PCH state.                                |
| 4    |           | ←  | PAGING TYPE 1                              | The SS transmits this message included a matched identity. |
| 5    |           | →  | Cell UPDATE                                | The UE is in CELL_FACH state.                              |

## Specific Message Contents

### TRANSPORT CHANNEL RECONFIGURATION (Step 1) (FDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with following exceptions:

| Information Element                                                                           | Value/remark |
|-----------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                           | URA_PCH      |
| Downlink information for each radio link<br>— Primary CPICH info<br>— Primary scrambling code | 100          |

### TRANSPORT CHANNEL RECONFIGURATION (Step 1) (TDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex with following exceptions:

| Information Element                                                 | Value/remark |
|---------------------------------------------------------------------|--------------|
| RRC State Indicator<br>— Primary CCPCH info<br>— Cell parameters ID | URA_PCH<br>4 |

### PAGING TYPE 1 (Step 4)

Use the same message sub-type titled "TM (Packet in PS)" in default message content of TS 34.108 with following exceptions:

| Information Element                                                                                             | Value/remark                                                                          |
|-----------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Paging record list<br>Paging record<br>— CHOICE Used paging identity<br>— U-RNTI<br>— SRNC Identity<br>— S-RNTI | UTRAN identity<br><br>Previously assigned SRNC identity<br>Previously assigned S-RNTI |

### CELL UPDATE (Step 5)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark      |
|---------------------|-------------------|
| Cell Update Cause   | "paging response" |

#### 8.2.4.21.5 — Test requirement

After step 1 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on uplink DCCH using AM RLC.

After step 4 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "paging response".

#### 8.2.4.22 — Transport Channel Reconfiguration from CELL\_FACH to CELL\_PCH: Success

##### 8.2.4.22.1 — Definition

#### 8.2.4.22.2 ~~Conformance requirement~~

The UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message after it receives a TRANSPORT CHANNEL RECONFIGURATION message which invokes the UE to transit from CELL\_FACH to CELL\_PCH. And then, the UE shall enter CELL\_PCH state

#### Reference

3GPP TS 25.331 clause 8.2.4

#### 8.2.4.22.3 ~~Test purpose~~

To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message and enters CELL\_PCH state after it receives a TRANSPORT CHANNEL RECONFIGURATION message, which invokes the UE to transit from CELL\_FACH to CELL\_PCH state.

#### 8.2.4.22.4 ~~Method of test~~

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH(state 6-11) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is in CELL\_FACH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message, which invokes the UE to transit from CELL\_FACH to CELL\_PCH. The UE transmits a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message using AM RLC and enters CELL\_PCH state. The SS transmits a PAGING TYPE 1 message, causing the UE to enter CELL\_FACH state and the UE shall transmit a CELL UPDATE message on uplink CCCH with IE "Cell Update cause" set to "paging response".

#### Expected sequence

| Step | Direction |    | Message                                    | Comment                                                    |
|------|-----------|----|--------------------------------------------|------------------------------------------------------------|
|      | UE        | SS |                                            |                                                            |
| 1    |           | ←  | TRANSPORT CHANNEL RECONFIGURATION          |                                                            |
| 2    |           | →  | TRANSPORT CHANNEL RECONFIGURATION COMPLETE |                                                            |
| 3    |           |    |                                            | The UE is in CELL_PCH state.                               |
| 4    |           | ←  | PAGING TYPE 1                              | The SS transmits this message included a matched identity. |
| 5    |           | →  | CELL UPDATE                                | The UE is in CELL_FACH state.                              |

#### Specific Message Contents

##### TRANSPORT CHANNEL RECONFIGURATION (Step 1)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with following exceptions:

| Information Element          | Value/remark |
|------------------------------|--------------|
| RRC State Indicator          | CELL_PCH     |
| Physical channel information | Not Present  |

##### PAGING TYPE 1 (Step 4)

Use the same message sub-type titled "TM (Packet in PS)" in default message contents of TS 34.108 with following exceptions:

| Information Element           | Value/remark                      |
|-------------------------------|-----------------------------------|
| Paging record list            |                                   |
| Paging record                 |                                   |
| — CHOICE Used-paging identity | UTRAN-identity                    |
| — U-RNTI                      |                                   |
| — SRNC-Identity               | Previously assigned SRNC identity |
| — S-RNTI                      | Previously assigned S-RNTI        |

#### CELL UPDATE (step 5)

The contents of CELL UPDATE is identical to "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark      |
|---------------------|-------------------|
| Cell Update Cause   | "paging response" |

#### 8.2.4.22.5 Test requirement

After step 1 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on uplink DCCH using AM RLC.

After step 4 the UE shall transmit CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "paging response".

#### 8.2.4.23 Transport Channel Reconfiguration from CELL\_FACH to URA\_PCH: Success

##### 8.2.4.23.1 Definition

##### 8.2.4.23.2 Conformance requirement

The UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message after it receives a TRANSPORT CHANNEL RECONFIGURATION message which invokes the UE to and transits from CELL\_FACH to URA\_PCH. And then, the UE shall enter URA\_PCH state.

#### Reference

3GPP TS 25.331 clause 8.2.4

##### 8.2.4.23.3 Test purpose

To confirm that the UE transmits a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message and enters URA\_PCH state after it receives a TRANSPORT CHANNEL RECONFIGURATION message which invokes the UE to transit from CELL\_FACH to CELL\_PCH.

##### 8.2.4.23.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH(state 6-11) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is in CELL\_FACH state. The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message which invokes the UE to transit from CELL\_FACH to CELL\_PCH. The UE transmits a TRANSPORT CHANNEL

RECONFIGURATION COMPLETE message using AM RLC and enters URA\_PCH state. The SS transmits a PAGING TYPE 1 message, causing the UE to enter CELL\_FACH state and the UE shall transmit a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "paging response".

#### Expected sequence

| Step | Direction |    | Message                                    | Comment                                                    |
|------|-----------|----|--------------------------------------------|------------------------------------------------------------|
|      | UE        | SS |                                            |                                                            |
| 1    |           | ←  | TRANSPORT CHANNEL RECONFIGURATION          |                                                            |
| 2    |           | →  | TRANSPORT CHANNEL RECONFIGURATION COMPLETE |                                                            |
| 3    |           |    |                                            | The UE is in URA_PCH state.                                |
| 4    |           | ←  | PAGING TYPE 1                              | The SS transmits this message included a matched identity. |
| 5    |           | →  | CELL UPDATE                                | The UE is in CELL_FACH state.                              |

#### Specific Message Contents

##### TRANSPORT CHANNEL RECONFIGURATION (Step 1)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with following exceptions:

| Information Element          | Value/remark |
|------------------------------|--------------|
| RRC State Indicator          | URA_PCH      |
| Physical channel information | Not Present  |

##### PAGING TYPE 1 (Step 4)

Use the same message sub-type titled "TM (Packet in PS)" in default message contents of TS 34.108 with following exceptions:

| Information Element            | Value/remark                      |
|--------------------------------|-----------------------------------|
| Paging record list             |                                   |
| Paging record                  |                                   |
| —— CHOICE Used paging identity | UTRAN identity                    |
| ——→ U-RNTI                     |                                   |
| ——→ SRNC Identity              | Previously assigned SRNC identity |
| ——→ S-RNTI                     | Previously assigned S-RNTI        |

##### CELL UPDATE (step 5)

The contents of CELL UPDATE is identical to "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark      |
|---------------------|-------------------|
| Cell Update Cause   | "paging response" |

#### 8.2.4.23.5 ————— Test requirement

After step 1 the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE message on uplink DCCH using AM RLC.

After step 4 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "paging response".

## 8.2.5 Transport format combination control

### 8.2.5.1 Transport format combination control in CELL\_DCH: restriction

#### 8.2.5.1.1 Definition

#### 8.2.5.1.2 Conformance requirement

The UE shall change the subset of the allowed uplink transport format combination when the UE receives TRANSPORT FORMAT COMBINATION CONTROL message.

#### Reference

3GPP TS 25.331 clause 8.2.5.

#### 8.2.5.1.3 Test purpose

To confirm that the UE does not transmit any data on the DCH for the signalling radio bearer on the uplink, following the reception of TRANSPORT FORMAT COMBINATION CONTROL message sent from the SS, which is set to the value in IE "Restricted TrCH information".

#### 8.2.5.1.4 Method of test

#### Initial Condition

System Simulator: 1 cell

UE: DCCH+DTCH\_DCH (state 6-9 or state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a TRANSPORT FORMAT COMBINATION CONTROL message using AM\_RLC on the DCCH, which indicates that only TF0 is allowed on the uplink for DCH transport channel on the DCCH. The SS transmits a UE CAPABILITY ENQUIRY message using AM\_RLC on the downlink DCCH and wait for the reception of a STATUS PDU. The UE shall be restricted from transmitting the DCH carrying STATUS PDU and the SS does not receive the STATUS PDU.

#### Expected sequence

| Step | Direction |    | Message                              | Comment                                                                                                                                                  |
|------|-----------|----|--------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                      |                                                                                                                                                          |
| 1    |           |    |                                      | UE is in CELL_DCH state with a DCH for a signalling radio bearer and a DCH for a radio access bearer.                                                    |
| 2    |           | ←  | TRANSPORT FORMAT COMBINATION CONTROL | The SS indicates the UE that it is restricted to use the TFS defined in Restricted TrCH information IE as the DCH is not transmitted on the uplink DCCH. |
| 2a   |           | ←  | UE CAPABILITY ENQUIRY                | The SS transmits this message to make the UE send an uplink STATUS PDU.                                                                                  |
| 3    |           |    |                                      | The UE shall not transmit a STATUS PDU.                                                                                                                  |

## Specific Message Contents

### TRANSPORT FORMAT COMBINATION CONTROL

Use the same message sub-type titled "TRANSPORT FORMAT COMBINATION CONTROL" in Annex A with following exceptions:

| Information Element               | Value/remark |
|-----------------------------------|--------------|
| TrCH information elements         |              |
| →DPCH/PUSCH TFCS uplink in uplink |              |
| → Restricted TrCH information     |              |
| → Uplink transport channel type   | DCH          |
| → Restricted UL TrCH identity     | 5            |
| → Allowed TFI                     | 0            |

#### 8.2.5.1.5 Test requirement

After step 2a the UE shall not transmit a STATUS PDU on the uplink DCCH.

### 8.2.5.2 Transport format combination control in CELL\_DCH: release a restriction

#### 8.2.5.2.1 Definition

#### 8.2.5.2.2 Conformance requirement

The UE shall change the subset of allowed transport format combination of uplink when it receives TRANSPORT FORMAT COMBINATION CONTROL message, specifying that an existing restriction for the usage of TFCS be removed.

#### Reference

3GPP TS 25.331 clause 8.2.5.

#### 8.2.5.2.3 Test purpose

To confirm that the UE transmit DTCH on the uplink signalling radio bearer, following the reception of a TRANSPORT FORMAT COMBINATION CONTROL message which include IE "Full transport format combination set".

#### 8.2.5.2.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: DCCH+DTCH\_DCH (state 6-9 or state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a TRANSPORT FORMAT COMBINATION CONTROL message which indicates that only TF0 is allowed on the uplink for DCH transport channel on the DCCH. The SS transmits a TRANSPORT FORMAT COMBINATION CONTROL message which includes IE "Full transport format combination set" to remove the restriction for the uplink TFC. The SS transmits a UE CAPABILITY ENQUIRY message UE and UE shall transmit a UE CAPABILITY INFORMATION message on the uplink DCCH. The SS transmits a UE CAPABILITY INFORMATION CONFIRM.

## Expected sequence

| Step | Direction |    | Message                              | Comment                                                                                                                                             |
|------|-----------|----|--------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                      |                                                                                                                                                     |
| 1    |           |    |                                      | UE is in CELL_DCH state with a DCH for a signalling radio bearer and a DCH for a radio access bearer.                                               |
| 2    |           | ←  | TRANSPORT FORMAT COMBINATION CONTROL | The SS indicates to UE that it is restricted to the TFS defined in Restricted TrCH information IE as the DCH is not transmitted on the uplink DCCH. |
| 3    |           | ←  | TRANSPORT FORMAT COMBINATION CONTROL | The SS indicates the UE that it removes the restriction to use the TFS defined in Restricted TrCH information IE in step 2.                         |
| 4    |           | ←  | UE CAPABILITY ENQUIRY                | The SS transmits this message to make the UE send a response message.                                                                               |
| 5    |           | →  | UE CAPABILITY INFORMATION            |                                                                                                                                                     |
| 6    |           | ←  | UE CAPABILITY INFORMATION CONFIRM    |                                                                                                                                                     |

## Specific Message Contents

## TRANSPORT FORMAT COMBINATION CONTROL (Step 2)

Use the same message sub-type titled "TRANSPORT FORMAT COMBINATION CONTROL" in Annex A with following exceptions:

| Information Element                | Value/remark |
|------------------------------------|--------------|
| TrCH information elements          |              |
| → DPCH/PUSCH TFCS uplink in uplink |              |
| → Restricted TrCH information      |              |
| → Uplink transport channel type    | DCH          |
| → Restricted UL TrCH identity      | 5            |
| → Allowed TFI                      | 0            |

## TRANSPORT FORMAT COMBINATION CONTROL (Step 3)

Use the same message sub-type titled "TRANSPORT FORMAT COMBINATION CONTROL" in Annex A with following exceptions:

| Information Element                     | Value/remark |
|-----------------------------------------|--------------|
| TrCH information elements               |              |
| → DPCH/PUSCH TFCS uplink in uplink      |              |
| → Full transport format combination set | Null         |

## 8.2.5.2.5 Test requirement

After step 4 the UE shall transmit a UE CAPABILITY INFORMATION message on the uplink DCCH using AM RLC.

## 8.2.5.3 Void



### ~~8.2.5.4 Transport format combination control in CELL\_DCH: Failure (Invalid message reception and Invalid configuration)~~

#### ~~8.2.5.4.1 Definition~~

#### ~~8.2.5.4.2 Conformance requirement~~

~~The UE shall keep its current configuration when it receives an invalid TRANSPORT FORMAT COMBINATION CONTROL message. It shall then transmit a TRANSPORT FORMAT COMBINATION CONTROL FAILURE message, indicating "protocol error" in IE "failure cause" and "ASN.1 violation or encoding error" in IE "Protocol error cause". The UE shall keep existing configuration upon the reception of a TRANSPORT FORMAT COMBINATION CONTROL message, which includes some IEs set to give an invalid configuration, and then the UE shall transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE including IE "failure cause" set to "invalid configuration".~~

#### ~~Reference~~

~~3GPP TS 25.331 clause 8.2.5.~~

#### ~~8.2.5.4.3 Test purpose~~

~~To confirm after the UE receives an invalid TRANSPORT FORMAT COMBINATION CONTROL message, it transmits a TRANSPORT FORMAT COMBINATION CONTROL FAILURE message and keeps the TFC subset as if no TRANSPORT FORMAT COMBINATION CONTROL message has been received.~~

~~To confirm that the UE transmits a TRANSPORT FORMAT COMBINATION CONTROL FAILURE message on the DCCH using AM RLC if it receives a TRANSPORT FORMAT COMBINATION CONTROL message including some IEs set to give an invalid configuration.~~

#### ~~8.2.5.4.4 Method of test~~

#### ~~Initial Condition~~

~~System Simulator: 1 cell.~~

~~UE: DCCH+DTCH\_DCH (state 6-9 or state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.~~

#### ~~Test Procedure~~

~~The UE is in CELL\_DCH state. The SS transmits an invalid TRANSPORT FORMAT COMBINATION CONTROL message which does not include any IEs except IE "Message Type". The UE shall transmit a TRANSPORT FORMAT COMBINATION CONTROL FAILURE message which is set to "ASN.1 violation or encoding error" in IE "Protocol error cause". SS transmits a TRANSPORT FORMAT COMBINATION CONTROL message including some IEs set to get an invalid configuration. The UE keeps its current configuration and transmits a TRANSPORT FORMAT COMBINATION CONTROL FAILURE message on the DCCH using AM RLC, setting the value "invalid configuration" to IE "failure cause".~~

## Expected sequence

| Step | Direction |    | Message                                         | Comment                                                                                               |
|------|-----------|----|-------------------------------------------------|-------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                 |                                                                                                       |
| 1    |           |    |                                                 | UE is in CELL_DCH state with a DCH for a signalling radio bearer and a DCH for a radio access bearer. |
| 2    |           | ←  | TRANSPORT FORMAT<br>COMBINATION CONTROL         | See specific message content.                                                                         |
| 3    |           | →  | TRANSPORT FORMAT<br>COMBINATION CONTROL FAILURE | The UE shall not change its configuration                                                             |
| 4    |           | ←  | TRANSPORT FORMAT<br>COMBINATION CONTROL         | This message includes IEs set to give an invalid configuration.                                       |
| 5    |           | →  | TRANSPORT FORMAT<br>COMBINATION CONTROL FAILURE | The UE shall not change its configuration                                                             |

## Specific Message Contents

## TRANSPORT FORMAT COMBINATION CONTROL (Step 2)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

## TRANSPORT FORMAT COMBINATION CONTROL FAILURE (Step 3)

| Information Element        | Value/remark                                                                                                                                                                                                                                      |
|----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type               | "TRANSPORT FORMAT COMBINATION CONTROL FAILURE"                                                                                                                                                                                                    |
| RRC transaction identifier | Checked to see if it is set to identical value of the same IE in the downlink TRANSPORT FORMAT COMBINATION CONTROL message.                                                                                                                       |
| Integrity check info       | The presence of this IE is dependent on IXT statements in TS 34.123-2; if integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub IEs shall be absent. |
| Failure cause              | "protocol error"                                                                                                                                                                                                                                  |
| Protocol error information |                                                                                                                                                                                                                                                   |
| ———Protocol error cause    | ASN.1 violation or encoding error                                                                                                                                                                                                                 |

## TRANSPORT FORMAT COMBINATION CONTROL (Step 5)

Use the same message sub-type titled "TRANSPORT FORMAT COMBINATION CONTROL" in Annex A with following exceptions:

| Information Element               | Value/remark                              |
|-----------------------------------|-------------------------------------------|
| TrCH information elements         |                                           |
| →DPCH/PUSCH TFCS uplink in uplink |                                           |
| → Restricted TrCH information     |                                           |
| → Uplink transport channel type   | DCH                                       |
| → Restricted UL TrCH identity     | 15 ( for RACH transport channel identity) |
| → Allowed TFI                     | 0                                         |

**TRANSPORT FORMAT COMBINATION CONTROL FAILURE (Step 6)**

| Information Element        | Value/remark                                                                                                                                                                                                                                       |
|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type               | "TRANSPORT FORMAT COMBINATION CONTROL FAILURE"                                                                                                                                                                                                     |
| RRC-transaction identifier | Checked to see if it is set to identical value of the same IE in the downlink TRANSPORT FORMAT COMBINATION CONTROL message.                                                                                                                        |
| Integrity-check info       | The presence of this IE is dependent on IXIT statements in TS 34.123-2; if integrity protection is indicated to be active, this IE shall be present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| Failure-cause              | Invalid configuration                                                                                                                                                                                                                              |

**8.2.5.4.5 — Test requirement**

After step 2 the UE shall transmit a TRANSPORT FORMAT COMBINATION CONTROL FAILURE message on the DCCH using AM RLC. The UE shall set the value "protocol error" in IE "Failure-cause" and the value "ASN.1 violation or encoding error" in IE "protocol error information".

After step 4 the UE shall transmit a TRANSPORT FORMAT COMBINATION CONTROL FAILURE message on the DCCH using AM RLC, setting IE "failure-cause" to "invalid configuration".

**8.2.6 — Physical channel reconfiguration****8.2.6.1 — Physical channel reconfiguration for transition from CELL\_DCH to CELL\_DCH (code modification): Success****8.2.6.1.1 — Definition****8.2.6.1.2 — Conformance requirement**

The UE shall correctly reconfigure a physical channel according to the PHYSICAL CHANNEL RECONFIGURATION message, which indicates a hard handover procedure and transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

**Reference**

3GPP TS 25.331 clause 8.2.6.

**8.2.6.1.3 — Test purpose**

To confirm that the UE reconfigures the physical channel parameters according to a PHYSICAL CHANNEL RECONFIGURATION message received from the SS. After the reconfiguration, the UE shall be able to communicate with the SS on the new physical channel.

**8.2.6.1.4 — Method of test****Initial Condition**

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending to the CN domain(s) supported by the UE.

### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE, which includes a new UL scrambling code. The UE shall reconfigure the physical channel at the activation time specified in this message and transmits a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH AM RLC after its transition.

### Expected sequence

| Step | Direction |    | Message                                   | Comment                           |
|------|-----------|----|-------------------------------------------|-----------------------------------|
|      | UE        | SS |                                           |                                   |
| 1    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | Including new UL scrambling code. |
| 2    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                   |

### Specific Message Contents

#### PHYSICAL CHANNEL RECONFIGURATION (FDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type titled as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A, with the following exceptions:

| Information Element                                                                                                 | Value/remark                        |
|---------------------------------------------------------------------------------------------------------------------|-------------------------------------|
| Activation Time                                                                                                     | Current CFN-[current CFN mod 8 + 8] |
| Uplink DPCH info<br>——— Scrambling code number                                                                      | 1                                   |
| Downlink information common for all radio links<br>——— Downlink DPCH info common for all RL<br>——— Timing Indicator | Maintain                            |

#### PHYSICAL CHANNEL RECONFIGURATION (TDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type titled as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A, with the following exceptions:

| Information Element                                                                                                 | Value/remark                        |
|---------------------------------------------------------------------------------------------------------------------|-------------------------------------|
| Activation Time                                                                                                     | Current CFN-[current CFN mod 8 + 8] |
| — Uplink DPCH timeslots and codes<br>——— First timeslot code list                                                   | Assigned by SS                      |
| Downlink information common for all radio links<br>——— Downlink DPCH info common for all RL<br>——— Timing Indicator | Maintain                            |

#### 8.2.6.1.5 ——— Test requirement

After step 1 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC.

## 8.2.6.2 ~~Physical channel reconfiguration for transition from CELL\_DCH to CELL\_DCH (code modification): Failure (Unsupported configuration)~~

### 8.2.6.2.1 ~~Definition~~

### 8.2.6.2.2 ~~Conformance requirement~~

The UE shall keep its configuration when the UE receives a PHYSICAL CHANNEL RECONFIGURATION message which includes an unsupported configuration and transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, with the reason "configuration unsupported" in IE "failure-cause".

### Reference

3GPP TS 25.331 clause 8.2.6.

### 8.2.6.2.3 ~~Test purpose~~

To confirm that the UE keeps its configuration and transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if the received PHYSICAL CHANNEL RECONFIGURATION message includes unsupported configuration parameters for the UE.

### 8.2.6.2.4 ~~Method of test~~

### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE which includes configuration parameters unsupported by the UE. The UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "configuration unsupported" in IE "failure-cause".

### Expected sequence

| Step | Direction |    | Message                                  | Comment                                                                               |
|------|-----------|----|------------------------------------------|---------------------------------------------------------------------------------------|
|      | UE        | SS |                                          |                                                                                       |
| 1    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION         | Includes configuration unsupported by the UE                                          |
| 2    |           | →  | PHYSICAL CHANNEL RECONFIGURATION FAILURE | The UE shall not reconfigure and continue to communicate using the old configuration. |

## Specific Message Contents

### PHYSICAL CHANNEL RECONFIGURATION (FDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element    | Value/remark |
|------------------------|--------------|
| Frequency info         |              |
| ——UARFCN uplink (Nu)   | 0            |
| ——UARFCN downlink (Nd) | 950          |

### PHYSICAL CHANNEL RECONFIGURATION (TDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_DCH in PS" found in Annex A with the following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| Frequency info      |              |
| ——UARFCN (Nt)       | 0            |

### PHYSICAL CHANNEL RECONFIGURATION FAILURE

The contents of PHYSICAL CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the PHYSICAL CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark              |
|---------------------|---------------------------|
| Failure-cause       | Configuration unsupported |

#### 8.2.6.2.5 ——— Test requirement

After step 1 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC and set "configuration unsupported" in IE "failure-cause".

#### 8.2.6.3 ——— Physical channel reconfiguration for transition from CELL\_DCH to CELL\_DCH (code modification): Failure (Physical channel failure and reversion to old channel)

##### 8.2.6.3.1 ——— Definition

##### 8.2.6.3.2 ——— Conformance requirement

The UE shall revert to the old configuration when the UE fails to reconfigure the new physical channel before the expiry of timer T312, and then transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC indicating "physical channel failure" in IE "failure cause".

## Reference

3GPP TS 25.331 clause 8.2.6.

### 8.2.6.3.3 Test purpose

To confirm that the UE reverts to the old configuration and transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if the UE fails to reconfigure the new physical channel according to the received PHYSICAL CHANNEL RECONFIGURATION message before timer T312 expiry.

### 8.2.6.3.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE which includes new UL scrambling code. However, the SS keeps its current dedicated physical channel configuration. The UE fails to synchronise with the SS on the new physical channel and after T312 timer expires the UE shall revert to the old configuration. Finally, the UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC specifies "physical channel failure" in IE "failure cause".

#### Expected sequence

| Step | Direction |    | Message                                  | Comment                                                                                                           |
|------|-----------|----|------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                          |                                                                                                                   |
| 1    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION         | Including a new UL scrambling code for FDD and First timeslot code list for TDD.                                  |
| 2    |           |    |                                          | The SS does not reconfigure the physical channel so that the UE fails to synchronise on the new physical channel. |
| 3    |           | →  | PHYSICAL CHANNEL RECONFIGURATION FAILURE | After T312 expires, the UE shall revert to the old configuration and transmits this message.                      |

#### Specific Message Contents

##### PHYSICAL CHANNEL RECONFIGURATION (FDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type titled as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A, with the following exceptions:

| Information Element                             | Value/remark                        |
|-------------------------------------------------|-------------------------------------|
| Activation Time                                 | Current CFN [current CFN mod 8 + 8] |
| Uplink DPCH info                                |                                     |
| — Scrambling code number                        | 1                                   |
| Downlink information common for all radio links |                                     |
| — Downlink DPCH info common for all RL          |                                     |
| — Timing Indicator                              | Maintain                            |

##### PHYSICAL CHANNEL RECONFIGURATION (TDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type titled as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A, with the following exceptions:

| Information Element                             | Value/remark                        |
|-------------------------------------------------|-------------------------------------|
| Activation-Time                                 | Current CFN-[current CFN mod 8 + 8] |
| -Uplink DPCH timeslots and codes                |                                     |
| ——First timeslot code list                      | Assigned by SS                      |
| Downlink information common for all radio links |                                     |
| ——Downlink DPCH info common for all RL          |                                     |
| ——Timing Indicator                              | Maintain                            |

## PHYSICAL CHANNEL RECONFIGURATION FAILURE

The contents of PHYSICAL CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the PHYSICAL CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark             |
|---------------------|--------------------------|
| Failure-cause       | Physical channel failure |

### 8.2.6.3.5 Test requirement

After step 2 the UE shall revert to the old configuration and transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, with the value "physical channel failure" in IE "failure cause".

### 8.2.6.4 Physical channel reconfiguration for transition from CELL\_DCH to CELL\_DCH (code modification): Failure (Physical channel failure and reversion failure)

#### 8.2.6.4.1 Definition

#### 8.2.6.4.2 Conformance requirement

The UE shall perform a cell update procedure when the UE fails to revert to the old configuration, after the detection of physical channel failure during the course of executing a physical channel reconfiguration procedure. After the UE completes the cell update procedure, the UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set IE "failure cause" to "physical channel failure".

#### Reference

3GPP TS 25.331 clause 8.2.6.

#### 8.2.6.4.3 Test purpose

To confirm that the UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message after UE completes a cell update procedure when the UE fails synchronise on the old physical channel after the UE cannot synchronise on the new physical channel according to the received PHYSICAL CHANNEL RECONFIGURATION message.

#### 8.2.6.4.4 Method of test

#### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.



## Test Procedure

The UE is in CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE, which includes new UL scrambling code, but the SS does not configure the new physical channel and release the old configuration. The UE fails to synchronise on the new dedicated physical channel and tries to revert to the old configuration. But the SS already deleted the old physical channel configuration and the UE cannot revert to the old configuration. The UE transmits a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "radio link failure". The SS shall transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving CELL UPDATE message. The UE transmits a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC and subsequently transmits PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the value "physical channel failure" to IE "failure cause".

## Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                                                                                                                                                       |
|------|-----------|----|-------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                                                                                               |
| 1    |           |    | Void                                      |                                                                                                                                                                                                               |
| 2    |           |    | Void                                      |                                                                                                                                                                                                               |
| 3    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | The message includes new UL scrambling code for FDD and First timeslot code list for TDD.                                                                                                                     |
| 4    |           |    |                                           | SS does not configure any dedicated physical channel and at the same time, it deletes the old configuration so the UE cannot reconfigure the new physical channel and cannot revert to the old configuration. |
| 5    |           | →  | CELL UPDATE                               | This message includes the value "radio link failure" set in IE "Cell update cause".                                                                                                                           |
| 6    |           | ←  | CELL UPDATE CONFIRM                       | This message includes IE "Physical channel information elements".                                                                                                                                             |
| 7    |           |    |                                           | The SS configures the dedicated physical channel according to the IE "Physical channel information elements" included in the CELL UPDATE CONFIRM message.                                                     |
| 8    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                                                                                                               |
| 9    |           | →  | PHYSICAL CHANNEL RECONFIGURATION FAILURE  | The IE "failure cause" shall be set to "physical channel failure"                                                                                                                                             |

## Specific Message Contents

### PHYSICAL CHANNEL RECONFIGURATION (Step 3) (FDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type titled as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A, with the following exceptions:

| Information Element                             | Value/remark                        |
|-------------------------------------------------|-------------------------------------|
| Activation Time                                 | Current CFN-[current CFN mod 8 + 8] |
| Uplink DPCH info                                |                                     |
| ——— Scrambling code number                      | 1                                   |
| Downlink information common for all radio links |                                     |
| ——— Downlink DPCH info common for all RL        |                                     |
| ——— Timing Indicator                            | Maintain                            |

**PHYSICAL CHANNEL RECONFIGURATION (Step 3) (TDD)**

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type titled as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A, with the following exceptions:

| Information Element                             | Value/remark                        |
|-------------------------------------------------|-------------------------------------|
| Activation Time                                 | Current CFN-[current CFN mod 8 + 8] |
| - Uplink DPCH timeslots and codes               |                                     |
| —— First timeslot code list                     | Assigned by SS                      |
| Downlink information common for all radio links |                                     |
| —— Downlink DPCH info common for all RL         |                                     |
| —— Timing Indicator                             | Maintain                            |

**CELL UPDATE (Step 5)**

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A for FDD and Annex A for TDD with the following exceptions:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| - SRNC Identity     | Check to see if set to '0000-0000-0001'           |
| - S-RNTI            | Check to see if set to '0000-0000-0000-0000-0001' |
| Cell Update Cause   | "radio-link failure"                              |

**CELL UPDATE CONFIRM (Step 6) (FDD)**

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A with the following exceptions:

| Information Element                       | Value/remark                                                         |
|-------------------------------------------|----------------------------------------------------------------------|
| U-RNTI                                    | Same as CELL UPDATE message in step 4                                |
| RRC State indicator                       | CELL_DCH                                                             |
| Uplink DPCH Info                          | Same as RADIO BEARER SETUP message used to move to initial condition |
| Downlink information for each radio links | Same as RADIO BEARER SETUP message used to move to initial condition |

**CELL UPDATE CONFIRM (Step 6) (TDD)**

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A with the following exceptions:

| Information Element                       | Value/remark                                                         |
|-------------------------------------------|----------------------------------------------------------------------|
| U-RNTI                                    | Same as CELL UPDATE message in step 4                                |
| RRC State Indicator                       | CELL_DCH                                                             |
| Uplink DPCH timeslots and codes           | Same as RADIO BEARER SETUP message used to move to initial condition |
| Downlink information for each radio links | Same as RADIO BEARER SETUP message used to move to initial condition |

**PHYSICAL CHANNEL RECONGURATION FAILURE (Step 9)**

The contents of PHYSICAL CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the PHYSICAL CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark               |
|---------------------|----------------------------|
| Failure cause       | "physical-channel failure" |

#### 8.2.6.4.5 ~~Test requirement~~

~~After step 4 the UE shall transmit a CELL\_UPDATE message using RLC-TM mode on the uplink CCCH with IE "Cell update cause" set to "radio link failure".~~

~~After step 7 the UE shall transmit a PHYSICAL\_CHANNEL\_RECONFIGURATION\_COMPLETE message on the uplink DCCH using AM RLC.~~

~~After step 8 the UE shall transmit a PHYSICAL\_CHANNEL\_RECONFIGURATION\_FAILURE message on the DCCH using AM RLC, setting the IE "failure cause" to "physical channel failure".~~

#### 8.2.6.5 ~~Physical channel reconfiguration for transition from CELL\_DCH to CELL\_DCH (code modification): Failure (Incompatible simultaneous reconfiguration)~~

##### 8.2.6.5.1 ~~Definition~~

##### 8.2.6.5.2 ~~Conformance requirement~~

~~If the UE receives a PHYSICAL\_CHANNEL\_RECONFIGURATION message during a reconfiguring procedure due to a radio bearer message other than PHYSICAL\_CHANNEL\_RECONFIGURATION message, it shall transmit a PHYSICAL\_CHANNEL\_RECONFIGURATION\_FAILURE message on the DCCH using AM RLC.~~

#### Reference

~~3GPP TS 25.331 clause 8.2.6, clause 8.6.3.11.~~

##### 8.2.6.5.3 ~~Test purpose~~

~~To confirm that if the UE receives a PHYSICAL\_CHANNEL\_RECONFIGURATION message during a reconfiguring procedure due to a radio bearer message other than PHYSICAL\_CHANNEL\_RECONFIGURATION, it shall keep its configuration as if the PHYSICAL\_CHANNEL\_RECONFIGURATION message had not been received and complete the reconfiguration procedure according to the previously received message.~~

##### 8.2.6.5.4 ~~Method of test~~

#### Initial Condition

System Simulator: 1 cell

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a RADIO\_BEARER\_RECONFIGURATION message to the UE. The SS transmits a PHYSICAL\_CHANNEL\_RECONFIGURATION message before the "activation time" indicated in the RADIO\_BEARER\_RECONFIGURATION message expires. When the UE receives the PHYSICAL\_CHANNEL\_RECONFIGURATION message, the UE shall keep the configuration as if it had not received the PHYSICAL\_CHANNEL\_RECONFIGURATION message and shall transmit a PHYSICAL\_CHANNEL\_RECONFIGURATION\_FAILURE message on the DCCH using AM RLC with IE "failure cause" set to "incompatible simultaneous reconfiguration". After the SS acknowledges the PHYSICAL\_CHANNEL\_RECONFIGURATION\_FAILURE message, the UE reconfigures the new physical channel parameters upon the activation time and transmits a RADIO\_BEARER\_RECONFIGURATION\_COMPLETE message on DCCH using AM RLC.

## Expected sequence

| Step | Direction |    | Message                                  | Comment                                                                                                      |
|------|-----------|----|------------------------------------------|--------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                          |                                                                                                              |
| 1    |           | ←  | RADIO-BEARER-RECONFIGURATION             |                                                                                                              |
| 2    |           | ←  | PHYSICAL-CHANNEL-RECONFIGURATION         | Sent before the "activation time" specified in the message in step 1 has elapsed.                            |
| 3    |           | →  | PHYSICAL-CHANNEL-RECONFIGURATION-FAILURE | The UE does not change the configuration due to the reception of a PHYSICAL-CHANNEL-RECONFIGURATION message. |
| 4    |           | →  | RADIO-BEARER-RECONFIGURATION COMPLETE    | This message is on DCCH using AM RLC.                                                                        |

## Specific Message Contents

## RADIO-BEARER-RECONFIGURATION (Step 1) (FDD)

For RADIO-BEARER-RECONFIGURATION in step 1, use the message sub-type indicated as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element                             | Value/remark                        |
|-------------------------------------------------|-------------------------------------|
| Activation Time Info                            | Current CFN-[current CFN mod 8 + 8] |
| Uplink DPCH info                                |                                     |
| ——→ Scrambling code number                      | 1                                   |
| Downlink information common for all radio links |                                     |
| ——→ Downlink DPCH info common for all RL        |                                     |
| ——→ Timing Indicator                            | Maintain                            |

## RADIO-BEARER-RECONFIGURATION (Step 1) (TDD)

| Information Element                             | Value/remark                        |
|-------------------------------------------------|-------------------------------------|
| Activation Time                                 | Current CFN-[current CFN mod 8 + 8] |
| – Uplink DPCH timeslots and codes               |                                     |
| ——→ First timeslot code list                    | Assigned by SS                      |
| Downlink information common for all radio links |                                     |
| ——→ Downlink DPCH info common for all RL        |                                     |
| ——→ Timing Indicator                            | Maintain                            |

## PHYSICAL-CHANNEL-RECONFIGURATION (Step 2) (FDD)

The contents of PHYSICAL-CHANNEL-RECONFIGURATION message in this test case is identical to the message sub-type titled as "Speech in CS" or "Non speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A, with the following exceptions:

| Information Element                             | Value/remark |
|-------------------------------------------------|--------------|
| Activation Time                                 | Not Present  |
| Uplink DPCH info                                |              |
| ——→ Scrambling code number                      | 2            |
| Downlink information common for all radio links |              |
| ——→ Downlink DPCH info common for all RL        |              |
| ——→ Timing Indicator                            | Maintain     |

### PHYSICAL CHANNEL RECONFIGURATION (Step 2) (TDD)

| Information Element                             | Value/remark                        |
|-------------------------------------------------|-------------------------------------|
| Activation Time                                 | Current CFN-[current CFN mod 8 + 8] |
| — Uplink DPCCH timeslots and codes              |                                     |
| — First timeslot code list                      | Different as assigned in Step 1     |
| Downlink information common for all radio links |                                     |
| — Downlink DPCCH info common for all RL         |                                     |
| — Timing Indicator                              | Maintain                            |

### PHYSICAL CHANNEL RECONFIGURATION FAILURE (step 3)

The contents of PHYSICAL CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the PHYSICAL CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark                              |
|---------------------|-------------------------------------------|
| Failure cause       | Incompatible simultaneous reconfiguration |

#### 8.2.6.5.5 Test requirement

After step 2 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC with IE "failure cause" set to "Incompatible simultaneous reconfiguration".

After step 3 the UE shall transmit a RADIO BEARER RECONFIGURATION COMPLETE message using AM RLC on the DCCH.

#### 8.2.6.6 Physical channel reconfiguration for transition from CELL\_DCH to CELL\_DCH (code modification): Failure (Invalid message reception and Invalid configuration)

##### 8.2.6.6.1 Definition

##### 8.2.6.6.2 Conformance requirement

The UE shall keep its old configuration when the UE receives an invalid PHYSICAL CHANNEL RECONFIGURATION message, which does not include any IEs except IE "Message Type". It shall then transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message which contains the value "protocol error" in IE "failure cause" and also "ASN.1 violation or encoding error" in IE "Protocol error cause". The UE shall keep existing configuration upon reception of a PHYSICAL CHANNEL RECONFIGURATION message when the PHYSICAL CHANNEL RECONFIGURATION message that includes some IEs set to give an invalid configuration, and then the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE including IE "failure cause" set to "invalid configuration".

#### Reference

3GPP TS 25.331 clause 8.2.6.

##### 8.2.6.6.3 Test purpose

To confirm that the UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if it receives an invalid PHYSICAL CHANNEL RECONFIGURATION message which does not include any IEs except IE "Message Type".

To confirm that the UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if it receives a PHYSICAL CHANNEL RECONFIGURATION message including some IEs set to give an invalid configuration.

#### 8.2.6.6.4 Method of test

##### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

##### Test Procedure

The UE is in CELL\_DCH state. The SS transmits an invalid PHYSICAL CHANNEL RECONFIGURATION message to the UE, which does not include any IEs except IE "Message Type". The UE keeps the old configuration and transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, with a value "protocol error" in IE "failure cause" and also a value "ASN.1 violation or encoding error" in IE "Protocol error cause". SS transmits a PHYSICAL CHANNEL RECONFIGURATION message including some IEs which are set to give an invalid configuration. The UE keeps its initial configuration and transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the value "invalid configuration" to IE "failure cause".

##### Expected sequence

| Step | Direction |    | Message                                  | Comment                                                                 |
|------|-----------|----|------------------------------------------|-------------------------------------------------------------------------|
|      | UE        | SS |                                          |                                                                         |
| 1    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION         | See specific message content.                                           |
| 2    |           | →  | PHYSICAL CHANNEL RECONFIGURATION FAILURE | The UE does not change its configuration.                               |
| 3    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION         | This message includes IEs which is set to give an invalid configuration |
| 4    |           |    |                                          | The UE does not change its configuration                                |
| 5    |           | →  | PHYSICAL CHANNEL RECONFIGURATION FAILURE | The IE "failure cause" shall be set to "invalid configuration"          |

##### Specific Message Contents

##### PHYSICAL CHANNEL RECONFIGURATION (Step 1)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

##### PHYSICAL CHANNEL RECONFIGURATION FAILURE (Step 2)

The contents of PHYSICAL CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the PHYSICAL CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element          | Value/remark                      |
|------------------------------|-----------------------------------|
| Failure cause                |                                   |
| → Failure cause              | Protocol error                    |
| → Protocol error information |                                   |
| → Protocol error cause       | ASN.1 violation or encoding error |

##### PHYSICAL CHANNEL RECONFIGURATION (Step 3) (FDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_FACH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element                  | Value/remark |
|--------------------------------------|--------------|
| <del>Default DPCH Offset Value</del> | 512          |
| <del>DPCH frame offset</del>         | 1024         |

### PHYSICAL CHANNEL RECONFIGURATION (Step 3) (TDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_FACH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element   | Value/remark |
|-----------------------|--------------|
| <del>PRACH TFCS</del> | Present      |

### PHYSICAL CHANNEL RECONFIGURATION FAILURE (Step 5)

The contents of PHYSICAL CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the PHYSICAL CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark          |
|---------------------|-----------------------|
| Failure-cause       | Invalid configuration |

#### 8.2.6.6.5 ~~Test requirement~~

After step 1 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting value "protocol error" in IE "failure cause" and also setting value "ASN.1 violation or encoding error" in IE "Protocol error cause".

After step 4 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting IE "failure cause" to "invalid configuration".

### 8.2.6.7 ~~Physical channel reconfiguration for transition from CELL\_DCH to CELL\_FACH: Success~~

#### 8.2.6.7.1 ~~Definition~~

#### 8.2.6.7.2 ~~Conformance requirement~~

The UE shall correctly reconfigure a physical channel according to a PHYSICAL CHANNEL RECONFIGURATION message, which invoke the UE to transit from CELL\_DCH to CELL\_FACH and transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.6.

#### 8.2.6.7.3 ~~Test purpose~~

To confirm that the UE reconfigures a common physical channel according to the PHYSICAL CHANNEL RECONFIGURATION message, which invoke the UE to transit from CELL\_DCH to CELL\_FACH.

#### 8.2.6.7.4 ~~Method of test~~

#### Initial Condition

System Simulator: 1 cell

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108

### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE. The UE shall then reconfigure the specified common physical channel according to this message and the system information messages. Following this, it shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message using AM RLC on the DCCH.

### Expected sequence

| Step | Direction |    | Message                                   | Comment                                                              |
|------|-----------|----|-------------------------------------------|----------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                      |
| 1    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | IE "Uplink DPCH Info" and IE "Downlink DPCH Info" are not specified. |
| 2    |           |    |                                           | UE shall perform the reconfiguration.                                |
| 3    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                      |

### Specific Message Contents

#### PHYSICAL CHANNEL RECONFIGURATION

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with the following exception:

| Information Element | Value/remark         |
|---------------------|----------------------|
| New C-RNTI          | 0000 0000 0000 0001B |

#### 8.2.6.7.5 Test requirement

After step 2 the UE shall transit from CELL\_DCH to CELL\_FACH and transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the common physical channel.

#### 8.2.6.8 Physical channel reconfiguration for transition from CELL\_DCH to CELL\_FACH: Success (Cell re-selection)

##### 8.2.6.8.1 Definition

##### 8.2.6.8.2 Conformance requirement

The UE shall initiate the cell update procedure when the UE performs cell reselection during a physical channel reconfiguration procedure. After the UE completes cell update procedure, the UE shall continue to perform the physical channel reconfiguration procedure and correctly reconfigure the physical channel.

### Reference

3GPP TS 25.331 clause 8.2.6.

##### 8.2.6.8.3 Test purpose

To confirm that the UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message after the UE completes a cell update procedure.



## 8.2.6.8.4 Method of test

## Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108

## Test Procedure

The UE is in CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message, which includes IE "Primary CPICH info" and no dedicated physical channel information to invoke the UE to transit from CELL\_DCH to CELL\_FACH. As the UE cannot detect the specified cell, the UE shall initiate the cell update procedure. The UE transmits a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "cell reselection". The SS shall transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving a CELL UPDATE message. The UE transmits a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

## Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                              |
|------|-----------|----|-------------------------------------------|--------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                      |
| 1    |           |    | Void                                      |                                                                                      |
| 2    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | This message include IE "Primary CPICH info" for FDD and Primary CCPCH info for TDD. |
| 3    |           |    | Void                                      |                                                                                      |
| 4    |           | →  | CELL UPDATE                               | The value "cell reselection" shall be set in IE "Cell update cause".                 |
| 5    |           | ←  | CELL UPDATE CONFIRM                       |                                                                                      |
| 6    |           |    | Void                                      |                                                                                      |
| 7    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                      |

## Specific Message Contents

## PHYSICAL CHANNEL RECONFIGURATION (Step 3) (FDD)

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with the following exceptions:

| Information Element                                                                                | Value/remark |
|----------------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>——→ Primary CPICH info<br>——→ Primary scrambling code | 150          |

## PHYSICAL CHANNEL RECONFIGURATION (Step 3) (TDD)

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with the following exceptions:

| Information Element                                                                           | Value/remark |
|-----------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>——→ Primary CCPCH info<br>——→ Cell parameters ID | 4            |

### CELL UPDATE (Step 4)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A for FDD and Annex A for TDD with the following exceptions:

| Information Element | Value/remark       |
|---------------------|--------------------|
| Cell Update Cause   | "cell reselection" |

### CELL UPDATE CONFIRM (Step 5)

The contents of CELL UPDATE CONFIRM message is same as "CELL UPDATE CONFIRM message" as found in Annex A for FDD and Annex A for TDD.

#### 8.2.6.8.5 Test requirement

After step 3 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "cell reselection".

After step 6 UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

### 8.2.6.9 Physical channel reconfiguration for transition from CELL\_FACH to CELL\_DCH: Success

#### 8.2.6.9.1 Definition

#### 8.2.6.9.2 Conformance requirement

The UE shall correctly reconfigure a physical channel according to a PHYSICAL CHANNEL RECONFIGURATION message, which invoke UE to transit from CELL\_FACH to CELL\_DCH and shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.6.

#### 8.2.6.9.3 Test purpose

To confirm that the UE reconfigures a new physical channel according to a PHYSICAL CHANNEL RECONFIGURATION message, which invoke UE to transit from CELL\_FACH to CELL\_DCH.

#### 8.2.6.9.4 Method of test

##### Initial Condition

System Simulator: 1 cell

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108

##### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE to transit from CELL\_DCH to CELL\_FACH. The UE shall reconfigure the common physical channel correctly according to this message. To complete this procedure, the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message using AM RLC. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE to invoke the UE to transit from CELL\_FACH to CELL\_DCH. The UE shall reconfigure the new dedicated physical channel correctly according to this message. To complete this procedure, the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message using AM RLC.

## Expected sequence

| Step | Direction |    | Message                                   | Comment                                                              |
|------|-----------|----|-------------------------------------------|----------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                      |
| 1    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | IE "Uplink DPCH Info" and IE "Downlink DPCH Info" are not specified. |
| 2    |           |    |                                           | UE shall perform the reconfiguration.                                |
| 3    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                      |
| 4    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          |                                                                      |
| 5    |           |    |                                           | The UE shall configure the allocated dedicated physical channels.    |
| 6    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                      |

## Specific Message Contents

## PHYSICAL CHANNEL RECONFIGURATION (Step 1)

Use the message sub-type titled "Packet to CELL\_FACH" in Annex A for FDD and Annex A for TDD.

## PHYSICAL CHANNEL RECONFIGURATION (Step 4)

Use the message sub-type titled "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A.

## 8.2.6.9.5 Test requirement

After step 2 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION message on the common physical channel.

After step 5 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION message on the new dedicated physical channel.

## 8.2.6.10 Physical channel reconfiguration for transition from CELL\_FACH to CELL\_DCH: Failure (Unsupported configuration)

## 8.2.6.10.1 Definition

## 8.2.6.10.2 Conformance requirement

The UE shall keep its old configuration when it receives a PHYSICAL CHANNEL RECONFIGURATION message, which specifies configuration parameters unsupported by the UE. It shall then transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, reporting the cause "configuration unsupported" in IE "failure-cause".

## Reference

3GPP TS 25.331 clause 8.2.6

## 8.2.6.10.3 Test purpose

To confirm that the UE keeps its configuration and transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, if the received PHYSICAL CHANNEL RECONFIGURATION message includes unsupported configuration parameters.

8.2.6.10.4 ~~Method of test~~~~Initial Condition~~~~System Simulator: 1 cell~~~~UE: PS-DCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108~~~~Test Procedure~~

The UE is in CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE to invoke the UE to transit from CELL\_DCH to CELL\_FACH. The UE shall reconfigure the common physical channel correctly according to this message. To complete this procedure, the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message using AM RLC. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE, which includes unsupported frequency for the UE. The UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCH using AM RLC, setting "configuration unsupported" in IE "failure-cause".

~~Expected sequence~~

| Step | Direction |    | Message                                      | Comment                                                                                                             |
|------|-----------|----|----------------------------------------------|---------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                              |                                                                                                                     |
| 1    | ←         |    | PHYSICAL CHANNEL<br>RECONFIGURATION          | IE "Uplink DPCH Info" and IE "Downlink DPCH Info" are not specified.                                                |
| 2    |           |    |                                              | UE shall perform the reconfiguration                                                                                |
| 3    | →         |    | PHYSICAL CHANNEL<br>RECONFIGURATION COMPLETE |                                                                                                                     |
| 4    | ←         |    | PHYSICAL CHANNEL<br>RECONFIGURATION          | Includes unsupported frequencies for the UE                                                                         |
| 5    | →         |    | PHYSICAL CHANNEL<br>RECONFIGURATION FAILURE  | The UE shall not change the physical channel configuration; this message shall be sent using the old configuration. |

~~Specific Message Contents~~~~PHYSICAL CHANNEL RECONFIGURATION (Step 1)~~~~Use the message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A.~~~~PHYSICAL CHANNEL RECONFIGURATION (Step 3) (FDD)~~

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element             | Value/remark |
|---------------------------------|--------------|
| Frequency info                  |              |
| <del>UARFCN uplink (Nu)</del>   | 0            |
| <del>UARFCN downlink (Nd)</del> | 950          |

~~PHYSICAL CHANNEL RECONFIGURATION (Step 3) (TDD)~~

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element    | Value/remark |
|------------------------|--------------|
| Frequency info         |              |
| <del>UARFCN (Nt)</del> | 0            |

## PHYSICAL CHANNEL RECONFIGURATION FAILURE

The contents of PHYSICAL CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the PHYSICAL CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark              |
|---------------------|---------------------------|
| Failure-cause       | Configuration unsupported |

### 8.2.6.10.5 ——— Test requirement

After step 2 the UE shall transit from CELL\_DCH to CELL\_FACH and transmit a PHYSICAL CHANNEL RECONFIGURATION message on the common physical channel.

After step 4 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, the IE "failure-cause" shall be set to "configuration unsupported".

### 8.2.6.11 ——— Physical channel reconfiguration for transition from CELL\_FACH to CELL\_DCH: Failure (Physical channel failure and successful reversion to old configuration)

#### 8.2.6.11.1 ——— Definition

#### 8.2.6.11.2 ——— Conformance requirement

The UE shall revert to the old configuration when the UE fails to reconfigure the new physical channel before timer T312 expires and detects the same serving cell only. It shall report the failure by transmitting a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, indicating "physical channel failure" in IE "failure-cause".

#### Reference

3GPP TS 25.331 clause 8.2.6.

#### 8.2.6.11.3 ——— Test purpose

To confirm that the UE reverts to the old configuration and transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC if the UE fails to reconfigure the new physical channel according to a PHYSICAL CHANNEL RECONFIGURATION message before the T312 expiry.

#### 8.2.6.11.4 ——— Method of test

#### Initial Condition

System Simulator: 1 cell

UE: DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE to invoke the UE to transit from CELL\_DCH to CELL\_FACH. The UE shall reconfigure the common physical channel correctly according to this message. To complete this procedure, the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message using AM RLC. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE to invoke the UE to transit from CELL\_FACH to CELL\_DCH. However, the SS keeps its current physical channel configuration and then the UE cannot synchronise with the SS. After T312 expires, the UE attempt to revert to the old configuration. Then the UE shall transmit a PHYSICAL CHANNEL

RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set "physical channel failure" in IE "failure cause".

#### Expected sequence

| Step | Direction |    | Message                                       | Comment                                                                                                                           |
|------|-----------|----|-----------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                               |                                                                                                                                   |
| 1    |           | ←  | PHYSICAL CHANNEL<br>-RECONFIGURATION          | IE "Uplink DPCH Info" and IE "Downlink DPCH Info" are not specified.                                                              |
| 2    |           |    |                                               | UE shall perform the reconfiguration                                                                                              |
| 3    |           | →  | PHYSICAL CHANNEL<br>-RECONFIGURATION COMPLETE |                                                                                                                                   |
| 4    |           | ←  | PHYSICAL CHANNEL<br>-RECONFIGURATION          |                                                                                                                                   |
| 5    |           |    |                                               | The SS does not reconfigure the physical channel, hence the UE shall detect a failure to reconfigure to the new physical channel. |
| 6    |           | →  | PHYSICAL CHANNEL<br>-RECONFIGURATION FAILURE  | After T312 expires the UE reverts to the old configuration and transmits this message.                                            |

#### Specific Message Contents

##### PHYSICAL CHANNEL RECONFIGURATION (Step 1)

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A for FDD and Annex A for TDD.

##### PHYSICAL CHANNEL RECONFIGURATION (Step 4)

Use the message sub-type titled "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A for FDD and Annex A for TDD.

##### PHYSICAL CHANNEL RECONFIGURATION FAILURE

The contents of PHYSICAL CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the PHYSICAL CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark             |
|---------------------|--------------------------|
| Failure cause       | Physical channel failure |

#### 8.2.6.11.5 Test requirement

After step 2 the UE shall transit from CELL\_DCH to CELL\_FACH and transmit a PHYSICAL CHANNEL RECONFIGURATION message on the common physical channel.

After step 5 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, specifying "physical channel failure" in IE "failure cause".

### 8.2.6.12 ~~Physical channel reconfiguration for transition from CELL\_FACH to CELL\_DCH: Failure (Physical channel failure and reversion failure)~~

#### 8.2.6.12.1 ~~Definition~~

#### 8.2.6.12.2 ~~Conformance requirement~~

The UE shall perform a cell update procedure when the UE selects another cell after the detection of physical channel failure in the physical channel reconfiguration procedure. After the UE completes cell update procedure, the UE transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC which is set to "physical channel failure" in IE "failure-cause".

#### Reference

3GPP TS 25.331 clause 8.2.6

#### 8.2.6.12.3 ~~Test purpose~~

To confirm that the UE initiates a cell update procedure after it fails to reconfigure the new physical channel and selects another cell.

To confirm that UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message after UE completes cell update procedure.

#### 8.2.6.12.4 ~~Method of test~~

#### Initial Condition

System Simulator: 2 cells – Cell 1 and 2 are active.

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108 in cell 1

#### Test Procedure

**Table 8.2.6.12**

| Parameter              | Unit         | Cell 1 |     | Cell 2 |     |
|------------------------|--------------|--------|-----|--------|-----|
|                        |              | T0     | T1  | T0     | T1  |
| UTRA-RF Channel Number |              | Ch. 1  |     | Ch. 1  |     |
| CPICH Ec (FDD)         | dBm/3.84 MHz | -60    | -75 | -75    | -60 |
| P-CCPCH RSCP (TDD)     | dBm          | -60    | -75 | -75    | -60 |

Table 8.2.6.12 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution. SS switches the power settings between columns "T0" and "T1", whenever the description in multi-cell condition specifies a reverse in the transmission power settings for cell 1 and cell 2.

The UE is in CELL\_DCH state in cell 1. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE to invoke the UE to transit from CELL\_DCH to CELL\_FACH. The UE shall reconfigure the common physical channel correctly according to this message. To complete this procedure, the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message using AM RLC. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE, but the SS does not reconfigure L1 accordingly. The SS configures its downlink transmission power settings according to columns "T1" in table 8.2.6.12. As a result, the UE fails to synchronise on the new physical channel before timer T312 expires and reselect cell 2 and then the UE shall transmit a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "Cell reselection". The SS shall

transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving a CELL UPDATE message. The UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting IE "failure cause" to "physical channel failure".

#### Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                                                                                                                                                                      |
|------|-----------|----|-------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                                                                                                              |
| 1    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | IE "Uplink DPCH Info" and IE "Downlink DPCH Info" are not specified.                                                                                                                                                         |
| 2    |           |    |                                           | UE shall perform the reconfiguration                                                                                                                                                                                         |
| 3    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                                                                                                                              |
| 4    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          |                                                                                                                                                                                                                              |
| 5    |           |    |                                           | The SS does not configure the new dedicated physical channel in accordance with the settings in the message and applies the downlink transmission power settings, according to the values in columns "T1" of table 8.2.6.12. |
| 6    |           |    | Void                                      |                                                                                                                                                                                                                              |
| 7    |           | →  | CELL UPDATE                               | This message includes the value "cell reselection" set in IE "Cell update cause".                                                                                                                                            |
| 8    |           | ←  | CELL UPDATE CONFIRM                       |                                                                                                                                                                                                                              |
| 9    |           |    | Void                                      |                                                                                                                                                                                                                              |
| 10   |           | →  | PHYSICAL CHANNEL RECONGURATION FAILURE    | UE shall transmit this message in the cell 2.                                                                                                                                                                                |

#### Specific Message Contents

##### PHYSICAL CHANNEL RECONFIGURATION (Step 1)

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A for FDD and Annex A for TDD.

##### PHYSICAL CHANNEL RECONFIGURATION (Step 4)

Use the message sub-type titled "Packet to CELL\_DCH from CELL\_FACH in PS" in Annex A for FDD and Annex A for TDD.

##### CELL UPDATE (Step 7)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A for FDD and Annex A for TDD with the following exceptions:

| Information Element                                        | Value/remark                                                                         |
|------------------------------------------------------------|--------------------------------------------------------------------------------------|
| U-RNTI<br>- SRNC Identity<br>- S-RNTI<br>Cell Update Cause | Assigned previously in cell 1<br>Assigned previously in cell 1<br>"cell reselection" |

##### CELL UPDATE CONFIRM (Step 8)

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A.



### PHYSICAL CHANNEL RECONGURATION FAILURE (Step 10)

The contents of PHYSICAL CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the PHYSICAL CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark               |
|---------------------|----------------------------|
| Failure cause       | "physical channel failure" |

#### 8.2.6.12.5 ——— Test requirement

After step 2 the UE shall transit from CELL\_DCH to CELL\_FACH and transmit a PHYSICAL CHANNEL RECONFIGURATION message on the common physical channel.

After step 6 the UE shall transmit a CELL UPDATE message using RLC-TM mode on the uplink CCCH with IE "Cell update cause" set to "cell reselection" in cell 2.

After step 9 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the IE "failure cause" to "physical channel failure".

### 8.2.6.13 ——— Physical channel reconfiguration for transition from CELL\_FACH to CELL\_DCH: Failure (Incompatible simultaneous reconfiguration)

#### 8.2.6.13.1 ——— Definition

#### 8.2.6.13.2 ——— Conformance requirement

If the UE receives a PHYSICAL CHANNEL RECONFIGURATION message during a reconfiguring procedure due to a radio bearer message other than a PHYSICAL CHANNEL RECONFIGURATION message, it shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.6, clause 8.6.3.11.

#### 8.2.6.13.3 ——— Test purpose

To confirm that if the UE receives a PHYSICAL CHANNEL RECONFIGURATION message during a reconfiguring procedure due to a radio bearer message other than a PHYSICAL CHANNEL RECONFIGURATION, it shall keep its configuration as if the PHYSICAL CHANNEL RECONFIGURATION message had not been received and complete the reconfiguration procedure according to the previously received message.

#### 8.2.6.13.4 ——— Method of test

#### Initial Condition

System Simulator: 1 cell

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE to invoke the UE to transit from CELL\_DCH to CELL\_FACH. The UE shall reconfigure the common physical channel correctly according to this message. To complete this procedure, the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message using AM RLC. The SS transmits a RADIO BEARER RECONFIGURATION message to the UE. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message before the "activation time" indicated in the RADIO BEARER RECONFIGURATION message expires. When the UE receives the PHYSICAL CHANNEL RECONFIGURATION message, the UE shall keep its configuration as if

it had not received the PHYSICAL CHANNEL RECONFIGURATION message and shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC with IE "failure-cause" set to "incompatible simultaneous reconfiguration". After the UE transmits the PHYSICAL CHANNEL RECONFIGURATION FAILURE message, the UE reconfigures the new physical channel parameters upon the activation time and transmits a RADIO BEARER RECONFIGURATION COMPLETE message on DCCH using AM RLC.

#### Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                                                           |
|------|-----------|----|-------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                   |
| 1    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | IE "Uplink DPCH Info" and IE "Downlink DPCH Info" are not specified.                                              |
| 2    |           |    |                                           | UE shall perform the reconfiguration                                                                              |
| 3    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE | The UE enters CELL_FACH state.                                                                                    |
| 4    |           | ←  | RADIO BEARER RECONFIGURATION              |                                                                                                                   |
| 5    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | Sent before the elapse of the frame number specified in IE "Activation time" of the message dispatched in step 4. |
| 6    |           | →  | PHYSICAL CHANNEL RECONFIGURATION FAILURE  | The UE does not change the configuration due to the reception of PHYSICAL CHANNEL RECONFIGURATION message.        |
| 7    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE     | This message is on DCCH using AM RLC.                                                                             |

#### Specific Message Contents

##### PHYSICAL CHANNEL RECONFIGURATION (Step 1)

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A.

##### RADIO BEARER RECONFIGURATION (Step 4) (FDD)

For RADIO BEARER RECONFIGURATION in step 1, use the message sub-type indicated as "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element    | Value/remark                        |
|------------------------|-------------------------------------|
| Activation Time Info   | Current CFN-[current CFN mod 8 + 8] |
| Uplink DPCH info       |                                     |
| Scrambling code number | 1                                   |

##### RADIO BEARER RECONFIGURATION (Step 4) (TDD)

For RADIO BEARER RECONFIGURATION in step 1, use the message sub-type indicated as "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions

| Information Element               | Value/remark                        |
|-----------------------------------|-------------------------------------|
| Activation Time                   | Current CFN-[current CFN mod 8 + 8] |
| - Uplink DPCH timeslots and codes |                                     |
| - First timeslot code list        | Assigned by SS                      |

##### PHYSICAL CHANNEL RECONFIGURATION (Step 5) (FDD)

For PHYSICAL CHANNEL RECONFIGURATION in step 5, use the message sub-type indicated as "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element       | Value/remark |
|---------------------------|--------------|
| Activation-Time Info      | Not Present  |
| Uplink DPCH info          |              |
| ———Scrambling-code-number | 2            |

### PHYSICAL CHANNEL RECONFIGURATION (Step 5) (TDD)

For PHYSICAL CHANNEL RECONFIGURATION in step 5, use the message sub-type indicated as "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element              | Value/remark                     |
|----------------------------------|----------------------------------|
| Activation-Time                  | Not present                      |
| –Uplink DPCH timeslots and codes |                                  |
| –First timeslot code list        | Different as assigned previously |

### PHYSICAL CHANNEL RECONFIGURATION FAILURE (Step 6)

The contents of PHYSICAL CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the PHYSICAL CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark                              |
|---------------------|-------------------------------------------|
| Failure-cause       | Incompatible simultaneous reconfiguration |

#### 8.2.6.13.5 ——— Test requirement

After step 2 the UE shall transit from CELL\_DCH to CELL\_FACH and transmit a PHYSICAL CHANNEL RECONFIGURATION message on the common physical channel.

After step 5 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC with IE "failure-cause" set to "Incompatible simultaneous reconfiguration".

After step 6 the UE shall transmit a RADIO BEARER RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### 8.2.6.14 ——— Physical channel reconfiguration for transition from CELL\_FACH to CELL\_DCH: Failure (Invalid message reception and Invalid configuration)

##### 8.2.6.14.1 ——— Definition

##### 8.2.6.14.2 ——— Conformance requirement

The UE shall keep its old configuration when the UE receives an invalid PHYSICAL CHANNEL RECONFIGURATION message which does not includes any IEs except IE "Message Type". It shall then transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message, set "protocol error" in IE "failure-cause" and also set "ASN.1 violation or encoding error" in IE "Protocol error cause". The UE shall keep existing configuration upon reception of a PHYSICAL CHANNEL RECONFIGURATION message, which includes some IEs which are set to give an invalid configuration, and then the UE shall transmit PHYSICAL CHANNEL RECONFIGURATION FAILURE including IE "failure-cause" set to "invalid configuration"

#### Reference

3GPP TS 25.331 clause 8.2.6

### 8.2.6.14.3 ~~Test purpose~~

To confirm that the UE transmits a ~~PHYSICAL CHANNEL RECONFIGURATION FAILURE~~ message on the DCCH using AM RLC if the received message does not include any IEs except IE "Message Type".

To confirm that the UE transmits a ~~PHYSICAL CHANNEL RECONFIGURATION FAILURE~~ message on the DCCH using AM RLC if it receives a ~~PHYSICAL CHANNEL RECONFIGURATION~~ message including some IEs which are set to give an invalid configuration.

### 8.2.6.14.4 ~~Method of test~~

#### ~~Initial Condition~~

System Simulator: 1 cell

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108

#### ~~Test Procedure~~

The UE is in CELL\_DCH state. The SS transmits a ~~PHYSICAL CHANNEL RECONFIGURATION~~ message to the UE to invoke the UE to transit from CELL\_DCH to CELL\_FACH. The UE shall reconfigure the common physical channel correctly according to this message. To complete this procedure, the UE shall transmit a ~~PHYSICAL CHANNEL RECONFIGURATION COMPLETE~~ message using AM RLC. The SS transmits an invalid ~~PHYSICAL CHANNEL RECONFIGURATION~~ message to the UE which does not include any IEs except IE "Message Type". The UE keeps the old configuration and transmits a ~~PHYSICAL CHANNEL RECONFIGURATION FAILURE~~ message on the DCCH using AM RLC, setting "protocol error" in IE "failure cause" and also setting "ASN.1 violation or encoding error" in IE "Protocol error cause". SS transmits ~~PHYSICAL CHANNEL RECONFIGURATION~~ message including some IEs which are set to give an invalid configuration. The UE keeps current configuration and transmits a ~~PHYSICAL CHANNEL RECONFIGURATION FAILURE~~ message on the DCCH using AM RLC, setting IE "failure cause" to "invalid configuration".

#### ~~Expected sequence~~

| Step | Direction |    | Message                                              | Comment                                                                   |
|------|-----------|----|------------------------------------------------------|---------------------------------------------------------------------------|
|      | UE        | SS |                                                      |                                                                           |
| 1    |           | ←  | <del>PHYSICAL CHANNEL RECONFIGURATION</del>          | IE "Uplink DPCH Info" and IE "Downlink DPCH Info" are not specified.      |
| 2    |           |    |                                                      | UE shall perform the reconfiguration                                      |
| 3    |           | →  | <del>PHYSICAL CHANNEL RECONFIGURATION COMPLETE</del> | The UE enters CELL_FACH state.                                            |
| 4    |           | ←  | <del>PHYSICAL CHANNEL RECONFIGURATION</del>          | See specific message content.                                             |
| 5    |           | →  | <del>PHYSICAL CHANNEL RECONFIGURATION FAILURE</del>  | The UE does not change the configuration.                                 |
| 6    |           | ←  | <del>PHYSICAL CHANNEL RECONFIGURATION</del>          | This message includes IEs which are set to give an invalid configuration. |
| 7    |           |    |                                                      | The UE does not change the configuration                                  |
| 8    |           | →  | <del>PHYSICAL CHANNEL RECONFIGURATION FAILURE</del>  | The IE "failure cause" shall be set to "invalid configuration"            |

#### ~~Specific Message Contents~~

#### ~~PHYSICAL CHANNEL RECONFIGURATION (Step 1)~~

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A for FDD and Annex A for TDD.

**PHYSICAL CHANNEL RECONFIGURATION (Step 4)**

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

**PHYSICAL CHANNEL RECONFIGURATION FAILURE (Step 5)**

The contents of PHYSICAL CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the PHYSICAL CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element            | Value/remark                      |
|--------------------------------|-----------------------------------|
| Failure-cause                  |                                   |
| ——— Failure cause              | Protocol error                    |
| ——— Protocol error information |                                   |
| ——— Protocol error cause       | ASN.1 violation or encoding error |

**PHYSICAL CHANNEL RECONFIGURATION (Step 6) (FDD)**

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element           | Value/remark |
|-------------------------------|--------------|
| ——— Default DPCH Offset Value | 512          |
| ——— DPCH frame offset         | 1024         |

**PHYSICAL CHANNEL RECONFIGURATION (Step 6) (TDD)**

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| ——— PRACH TFCS      | Present      |

**PHYSICAL CHANNEL RECONFIGURATION FAILURE (Step 7)**

The contents of PHYSICAL CHANNEL RECONFIGURATION FAILURE message in this test case is the same as the PHYSICAL CHANNEL RECONFIGURATION FAILURE message as found in Annex A, with the following exceptions:

| Information Element | Value/remark          |
|---------------------|-----------------------|
| Failure-cause       | Invalid configuration |

**8.2.6.14.5 ——— Test requirement**

After step 2 the UE shall transit from CELL\_DCH to CELL\_FACH and transmit a PHYSICAL CHANNEL RECONFIGURATION message on the common physical channel.

After step 4 the UE shall keep its old configuration, transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC with "protocol error" in IE "failure-cause" and also "ASN.1 violation or encoding error" in IE "Protocol error cause".

After step 7 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting IE "failure-cause" to "invalid configuration".

**8.2.6.15** ~~Physical channel reconfiguration for transition from CELL\_FACH to CELL\_FACH: Success~~

**8.2.6.15.1** ~~Definition~~

**8.2.6.15.2** ~~Conformance requirement~~

The UE shall correctly reconfigure a common physical channel in another cell according to a PHYSICAL CHANNEL RECONFIGURATION message, which invokes the UE to transit from CELL\_FACH in a current cell to CELL\_FACH in the specified another cell.

**Reference**

3GPP TS 25.331 clause 8.2.6

**8.2.6.15.3** ~~Test purpose~~

To confirm that the UE reconfigures a new common physical channel in another cell according to the PHYSICAL CHANNEL RECONFIGURATION message received from the SS.

**8.2.6.15.4** ~~Method of test~~

**Initial Condition**

System Simulator: 2 cells—Cell 1 and 2 are active.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108

**Test Procedure**

**Table 8.2.6.15**

| Parameter              | Unit                | Cell 1 |     | Cell 2 |     |
|------------------------|---------------------|--------|-----|--------|-----|
|                        |                     | T0     | T1  | T0     | T1  |
| UTRA—RF Channel Number |                     | Ch. 1  |     | Ch. 1  |     |
| CPICH Ec               | dBm/<br>3.84<br>MHz | -60    | -75 | -75    | -60 |
| P-CCPCH RSCP (TDD)     | dBm                 | -60    | -75 | -75    | -60 |

Table 8.2.6.15 illustrates the downlink power to be applied for the 2-cells at various time instants of the test-execution. SS switches the power settings from columns "T0" to "T1", whenever the description in multi-cell condition specifies the transmission power settings for cell 1 and cell 2.

The UE is in the CELL\_FACH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message, which invoke the UE to transit from CELL\_FACH in the current cell to CELL\_FACH in cell 2, to the UE. The SS configures its downlink transmission power settings according to columns "T1" in table 8.2.6.15. The UE shall move to cell 2 and configure the common physical channel and transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message using AM RLC on the DCCH.

## Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                                                             |
|------|-----------|----|-------------------------------------------|---------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                     |
| 1    | ←         |    | PHYSICAL CHANNEL RECONFIGURATION          |                                                                                                                     |
| 2    |           |    |                                           | The SS applies the downlink transmission power settings, according to the values in columns "T1" of table 8.2.6.15. |
| 3    | →         |    | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                     |

## Specific Message Contents

## PHYSICAL CHANNEL RECONFIGURATION (FDD)

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with the following exceptions:

| Information Element                                                                                | Value/remark         |
|----------------------------------------------------------------------------------------------------|----------------------|
| New C-RNTI                                                                                         | 0000-0000-0000-0001B |
| Downlink information for each radio links<br>——→ Primary CPICH info<br>——→ Primary scrambling code | 150                  |

## PHYSICAL CHANNEL RECONFIGURATION (TDD)

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with the following exceptions:

| Information Element                                                                           | Value/remark |
|-----------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>——→ Primary CCPCH info<br>——→ Cell parameters ID | 4            |

## 8.2.6.15.5 ——— Test requirement

After step 2 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message in cell 2.

## 8.2.6.16 ——— Physical channel reconfiguration for transition from CELL\_FACH to CELL\_FACH: (Cell re-selection)

## 8.2.6.16.1 ——— Definition

## 8.2.6.16.2 ——— Conformance requirement

The UE shall initiate the cell reselection procedure when the UE performs cell reselection during a physical channel reconfiguration procedure. After the UE completes cell update procedure, the UE shall continue to perform the physical channel reconfiguration procedure and correctly reconfigure the physical channel.

## Reference

3GPP TS 25.331 clause 8.2.6

### 8.2.6.16.3 Test purpose

To confirm that the UE transmits a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message after the UE completes a cell update procedure indicated by a PHYSICAL CHANNEL RECONFIGURATION message.

### 8.2.6.16.4 Method of test

#### Initial Condition

System Simulator: 2 cells – Cell 1 and 2 are active.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108

#### Test Procedure

**Table 8.2.6.16**

| Parameter              | Unit         | Cell 1 |     | Cell 2 |     |
|------------------------|--------------|--------|-----|--------|-----|
|                        |              | T0     | T1  | T0     | T1  |
| UTRA RF Channel Number |              | Ch. 1  |     | Ch. 1  |     |
| CPICH Ec (FDD)         | dBm/3.84 MHz | -60    | -75 | -75    | -60 |
| P-CCPCH RSCP (TDD)     | dBm          | -60    | -75 | -75    | -60 |

Table 8.2.6.16 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution. SS switches the power settings between columns "T0" and "T1", whenever the description in multi-cell condition specifies a reverse in the transmission power settings for cell 1 and cell 2.

The UE is in CELL\_FACH state in cell 1. On transmitting a PHYSICAL CHANNEL RECONFIGURATION message, which does not include the IE "Primary CPICH info", the SS configures its downlink transmission power settings according to columns "T1" in table 8.2.6.16. The UE shall initiate the cell update procedure and transmits a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "cell reselection" in cell 2. The SS shall transmit a CELL UPDATE CONFIRM message on downlink CCCH after receiving CELL UPDATE message. The UE transmits a UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH using AM RLC and transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                                                                  |
|------|-----------|----|-------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                          |
| 1    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | This message does not include IE "Primary CPICH info" (FDD).                                                             |
| 2    |           |    |                                           | The UE shall detect a failure to transmission power settings, according to the values in columns "T1" of table 8.2.6.16. |
| 3    |           |    | Void                                      |                                                                                                                          |
| 4    |           | →  | CELL UPDATE                               | The value "cell reselection" shall be set in IE "Cell update cause".                                                     |
| 5    |           | ←  | CELL UPDATE CONFIRM                       |                                                                                                                          |
| 6    |           | →  | UTRAN MOBILITY INFORMATION CONFIRM        |                                                                                                                          |
| 7    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                          |



## Specific Message Contents

## PHYSICAL CHANNEL RECONFIGURATION (Step 1) (FDD)

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with the following exceptions:

| Information Element                                                                              | Value/remark |
|--------------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>—— Primary CPICH info<br>—— Primary scrambling code | Not Present  |

## PHYSICAL CHANNEL RECONFIGURATION (Step 1) (TDD)

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with the following exceptions:

| Information Element                                                                         | Value/remark |
|---------------------------------------------------------------------------------------------|--------------|
| Downlink information for each radio links<br>—— Primary CCPCH info<br>—— Cell parameters-ID | Not Present  |

## CELL UPDATE (Step 4)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A for FDD and Annex A for TDD with the following exceptions:

| Information Element                                        | Value/remark                                                                         |
|------------------------------------------------------------|--------------------------------------------------------------------------------------|
| U-RNTI<br>- SRNC Identity<br>- S-RNTI<br>Cell Update Cause | Assigned previously in cell 1<br>Assigned previously in cell 1<br>"cell reselection" |

## CELL UPDATE CONFIRM (Step 5)

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex A for FDD and Annex A for TDD, with the following exceptions:

| Information Element                                               | Value/remark                                                                                                                       |
|-------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
| U-RNTI<br>New U-RNTI<br>- SRNC Identity<br>- S-RNTI<br>New C-RNTI | Same as CELL UPDATE message in step 4<br>'0000-0000-0000-0001'<br>Different from previous S-RNTI<br>Different from previous C-RNTI |

## 8.2.6.16.5 — Test requirement

After step 3 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "cell reselection" in cell 2.

After step 5 the UE shall transmit UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH using AM RLC.

After step 6 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

### ~~8.2.6.17 Physical channel reconfiguration for transition from CELL\_DCH to CELL\_DCH (code modification): Success (Subsequently received)~~

#### ~~8.2.6.17.1 Definition~~

#### ~~8.2.6.17.2 Conformance requirement~~

~~If the UE receives a PHYSICAL CHANNEL RECONFIGURATION message before the UE reconfigures the radio bearer according to the previous PHYSICAL CHANNEL RECONFIGURATION message, the UE shall ignore the new PHYSICAL CHANNEL RECONFIGURATION message and reconfigure according to the previous PHYSICAL CHANNEL RECONFIGURATION message received. Finally, the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.~~

#### ~~Reference~~

~~3GPP TS 25.331 clause 8.2.6, clause 8.6.3.11.~~

#### ~~8.2.6.17.3 Test purpose~~

~~To confirm that if the UE receives a PHYSICAL CHANNEL RECONFIGURATION message before the UE reconfigures the radio bearer according to the previous PHYSICAL CHANNEL RECONFIGURATION message it ignores the new PHYSICAL CHANNEL RECONFIGURATION message and reconfigures according to the previous PHYSICAL CHANNEL RECONFIGURATION message.~~

#### ~~8.2.6.17.4 Method of test~~

#### ~~Initial Condition~~

~~System Simulator: 1 cell~~

~~UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.~~

#### ~~Test Procedure~~

~~The UE is in the CELL\_DCH state. When the SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE before the activation time specified in the previous PHYSICAL CHANNEL RECONFIGURATION message elapses, the UE ignores the new PHYSICAL CHANNEL RECONFIGURATION message and reconfigures according to the previous PHYSICAL CHANNEL RECONFIGURATION message received. Finally, the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.~~

## Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                                                                                                                                                                                                                  |
|------|-----------|----|-------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                                                                                                                                                          |
| 1    | ←         |    | PHYSICAL CHANNEL RECONFIGURATION          | For FDD mode the "Secondary scrambling code is set to "1". For TDD mode a code combination is assigned by SS.                                                                                                                                                            |
| 2    | ←         |    | PHYSICAL CHANNEL RECONFIGURATION          | SS send this message before the expiry of "activation time" specified in PHYSICAL CHANNEL RECONFIGURATION message of step 1. For FDD, the IE "Secondary scrambling code" is set to "2". For TDD, the code combination assigned is different to that assigned in stage 1. |
| 3    | →         |    | PHYSICAL CHANNEL RECONFIGURATION COMPLETE | The UE ignores the PHYSICAL CHANNEL RECONFIGURATION message in step 2 and confirms configuration according to the PHYSICAL CHANNEL RECONFIGURATION message in step 1.                                                                                                    |

## Specific Message Contents

## PHYSICAL CHANNEL RECONFIGURATION (Step 1) (FDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A for FDD and Annex A for TDD with the following exceptions:

| Information Element         | Value/remark                                                                   |
|-----------------------------|--------------------------------------------------------------------------------|
| Activation Time Info        | $[256 + \text{Current CFN} - [\text{current CFN mod } 8 + 8]] \text{MOD } 256$ |
| ~ Uplink DPCH info          |                                                                                |
| ~ Secondary scrambling code | 1                                                                              |

## PHYSICAL CHANNEL RECONFIGURATION (Step 1) (TDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element               | Value/remark                                                                   |
|-----------------------------------|--------------------------------------------------------------------------------|
| Activation Time                   | $[256 + \text{Current CFN} - [\text{current CFN mod } 8 + 8]] \text{MOD } 256$ |
| ~ Uplink DPCH timeslots and codes |                                                                                |
| ~ First timeslot code list        | Assigned in step 1                                                             |

## PHYSICAL CHANNEL RECONFIGURATION (Step 2) (FDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title as "Speech in CS" or "Non-speech in CS" or "Packet to CELL\_DCH from CELL\_DCH in PS" as found in Annex A with the following exceptions:

| Information Element         | Value/remark |
|-----------------------------|--------------|
| Activation Time             | Not Present  |
| ~ Uplink DPCH info          |              |
| ~ Secondary scrambling code | 2            |

### PHYSICAL CHANNEL RECONFIGURATION (Step2) (TDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_DCH in PS" found in Annex A with the following exceptions:

| Information Element                                             | Value/remark                                         |
|-----------------------------------------------------------------|------------------------------------------------------|
| Activation Time                                                 | Not Present                                          |
| ~ Uplink DPCH timeslots and codes<br>~ First timeslot code list | A different code combination to that used in step 1. |

#### 8.2.6.17.5 Test requirement

After step 2 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

### 8.2.6.18 Physical channel reconfiguration for transition from CELL\_FACH to CELL\_DCH: Success (Subsequently received)

#### 8.2.6.18.1 Definition

#### 8.2.6.18.2 Conformance requirement

If the UE receives a PHYSICAL CHANNEL RECONFIGURATION message before the UE reconfigures the radio bearer according to the previous PHYSICAL CHANNEL RECONFIGURATION message, the UE shall ignore the new PHYSICAL CHANNEL RECONFIGURATION message and reconfigure according to the previous PHYSICAL CHANNEL RECONFIGURATION message received. Finally, the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.2.6, clause 8.6.3.11.

#### 8.2.6.18.3 Test purpose

To confirm that if the UE receives a PHYSICAL CHANNEL RECONFIGURATION message before the UE reconfigures the radio bearer according to the previous PHYSICAL CHANNEL RECONFIGURATION message it ignores the new PHYSICAL CHANNEL RECONFIGURATION message and reconfigures according to the previous PHYSICAL CHANNEL RECONFIGURATION message.

#### 8.2.6.18.4 Method of test

#### Initial Condition

System Simulator: 1 cell

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108

#### Test Procedure

The UE is in CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE to invoke the UE to transit from CELL\_DCH to CELL\_FACH. The UE shall reconfigure the common physical channel correctly according to this message. To complete this procedure, the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message using AM RLC. When the SS transmits a PHYSICAL CHANNEL RECONFIGURATION message to the UE before the activation time specified in the previous PHYSICAL CHANNEL RECONFIGURATION message, the UE ignores the new PHYSICAL CHANNEL RECONFIGURATION message and reconfigures according to the previous PHYSICAL CHANNEL RECONFIGURATION message received. Finally, the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

## Expected sequence

| Step | Direction |    | Message                                   | Comment                                                                                                                                                                                                                                                                   |
|------|-----------|----|-------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                                                                                                                                                           |
| 1    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | IE "Uplink DPCH Info" and IE "Downlink DPCH Info" are not specified.                                                                                                                                                                                                      |
| 2    |           |    |                                           | UE shall perform the reconfiguration                                                                                                                                                                                                                                      |
| 3    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE | The UE enters CELL_FACH state.                                                                                                                                                                                                                                            |
| 4    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | The "Secondary scrambling code is set to "1" for FDD mode and A code combination is assigned by SS for TDD                                                                                                                                                                |
| 5    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | SS send this message before the expiry of "activation time" specified in PHYSICAL CHANNEL RECONFIGURATION message of step 4. For FDD the IE "Secondary scrambling code" is set to "2". For TDD, the code combination assigned is different from that assigned in stage 4. |
| 6    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE | The UE ignores the PHYSICAL CHANNEL RECONFIGURATION message in step 5 and confirms configuration according to the PHYSICAL CHANNEL RECONFIGURATION message in step 4.                                                                                                     |

## Specific Message Contents

## PHYSICAL CHANNEL RECONFIGURATION (Step 1)

Use the message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A.

## PHYSICAL CHANNEL RECONFIGURATION (Step 4) (FDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A for FDD and Annex A for TDD with the following exceptions:

| Information Element         | Value/remark                                                                   |
|-----------------------------|--------------------------------------------------------------------------------|
| Activation Time Info        | $[256 + \text{Current CFN} - [\text{current CFN mod } 8 + 8]] \text{MOD } 256$ |
| ~ Uplink DPCH info          |                                                                                |
| ~ Secondary scrambling code | 1                                                                              |

## PHYSICAL CHANNEL RECONFIGURATION (Step 4) (TDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" as found in Annex A with the following exceptions:

| Information Element               | Value/remark                                                                   |
|-----------------------------------|--------------------------------------------------------------------------------|
| Activation Time                   | $[256 + \text{Current CFN} - [\text{current CFN mod } 8 + 8]] \text{MOD } 256$ |
| ~ Uplink DPCH timeslots and codes |                                                                                |
| ~ First timeslot code list        | Assigned in step 1                                                             |

### PHYSICAL CHANNEL RECONFIGURATION (Step 5) (FDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element         | Value/remark |
|-----------------------------|--------------|
| Activation Time             | Not Present  |
| - Uplink DPCH info          |              |
| - Secondary scrambling code | 2            |

### PHYSICAL CHANNEL RECONFIGURATION (Step 5) (TDD)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_FACH in PS" found in Annex A with the following exceptions:

| Information Element               | Value/remark                                         |
|-----------------------------------|------------------------------------------------------|
| Activation Time                   | Not Present                                          |
| - Uplink DPCH timeslots and codes |                                                      |
| - First timeslot code list        | A different code combination to that used in step 1. |

#### 8.2.6.18.5 Test requirement

After step 2 the UE shall transit from CELL\_DCH to CELL\_FACH and transmit a PHYSICAL CHANNEL RECONFIGURATION message on the common physical channel.

After step 5 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

### 8.2.6.19 Physical Channel Reconfiguration from CELL\_DCH to CELL\_PCH: Success

#### 8.2.6.19.1 Definition

#### 8.2.6.19.2 Conformance requirement

The UE shall transmits a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message after it receives a PHYSICAL CHANNEL RECONFIGURATION message which invokes the UE to transit from CELL\_DCH to CELL\_PCH. And then, the UE shall enter CELL\_PCH state.

#### Reference

3GPP TS 25.331 clause 8.2.6.

#### 8.2.6.19.3 Test purpose

To confirm that the UE transmits a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message and enter CELL\_PCH state after it received a PHYSICAL CHANNEL RECONFIGURATION message, which invokes the UE to transit from CELL\_DCH to CELL\_PCH.

#### 8.2.6.19.4 Method of test

#### Initial Condition

System Simulator: 1 cell

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108

## Test Procedure

The UE is in CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message, which invokes the UE to transit from CELL\_DCH to CELL\_PCH. The UE transmits a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message using AM RLC and enters CELL\_PCH state. The SS transmits a PAGING TYPE 1 message, causing the UE to enter CELL\_FACH state and the UE shall transmit a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "paging response".

## Expected sequence

| Step | Direction |    | Message                                   | Comment                                                |
|------|-----------|----|-------------------------------------------|--------------------------------------------------------|
|      | UE        | SS |                                           |                                                        |
| 1    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          |                                                        |
| 2    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                        |
| 3    |           |    |                                           | The UE is in CELL_PCH state.                           |
| 4    |           | ←  | PAGING TYPE 1                             | The SS transmits this message with a matched identity. |
| 5    |           | →  | CELL UPDATE                               | The UE is in CELL_FACH state.                          |

## Specific Message Contents

### PHYSICAL CHANNEL RECONFIGURATION (Step 1) (FDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with following exceptions:

| Information Element                                                                           | Value/remark |
|-----------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                           | CELL_PCH     |
| Downlink information for each radio link<br>— Primary CPICH info<br>— Primary scrambling code | 100          |

### PHYSICAL CHANNEL RECONFIGURATION (Step 1) (TDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with following exceptions:

| Information Element                                                                         | Value/remark |
|---------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                         | CELL_PCH     |
| Downlink information for each radio links<br>—— Primary CCPCH info<br>—— Cell parameters ID | 4            |

### PAGING TYPE 1 (Step 4)

Use the same message sub-type titled "TM (Packet in PS)" in default message content of TS 34.108 with following exceptions:

| Information Element                                                                                                 | Value/remark                                                                          |
|---------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Paging record list<br>Paging record<br>—— CHOICE Used paging identity<br>—— U-RNTI<br>—— SRNC Identity<br>—— S-RNTI | UTRAN identity<br><br>Previously assigned SRNC identity<br>Previously assigned S-RNTI |

#### 8.2.6.19.5 ——— Test requirement

After step 1 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

After step 4 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "paging response".

#### 8.2.6.20 ——— Physical Channel Reconfiguration from CELL\_DCH to URA\_PCH: Success

##### 8.2.6.20.1 ——— Definition

##### 8.2.6.20.2 ——— Conformance requirement

The UE shall transmit PHYSICAL CHANNEL RECONFIGURATION COMPLETE message after it receives a PHYSICAL CHANNEL RECONFIGURATION message, which invokes the UE to transit from CELL\_DCH to URA\_PCH. And then, the UE shall reconfigure radio bearers according to the PHYSICAL CHANNEL RECONFIGURATION message and enter URA\_PCH state.

#### Reference

3GPP TS 25.331 clause 8.2.6.

##### 8.2.6.20.3 ——— Test purpose

To confirm that the UE transmits a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message and enter URA\_PCH state after it received a PHYSICAL CHANNEL RECONFIGURATION message, which invokes the UE to transit from CELL\_DCH to URA\_PCH.

##### 8.2.6.20.4 ——— Method of test

#### Initial Condition

System Simulator: 1 cell

UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108

#### Test Procedure

The UE is in the CELL\_DCH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message, which invoke the UE to transit from CELL\_DCH to URA\_PCH. The UE transmits a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message using AM RLC and enters URA\_PCH state. The SS transmits a PAGING TYPE 1 message, causing the UE to enter CELL\_FACH state and the UE shall transmit a CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "paging response".

#### Expected sequence

| Step | Direction |    | Message                                   | Comment                                                |
|------|-----------|----|-------------------------------------------|--------------------------------------------------------|
|      | UE        | SS |                                           |                                                        |
| 1    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          |                                                        |
| 2    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                        |
| 3    |           |    |                                           | The UE is in URA_PCH state.                            |
| 4    |           | ←  | PAGING TYPE 1                             | The SS transmits this message with a matched identity. |
| 5    |           | →  | CELL UPDATE                               | The UE is in CELL_FACH state.                          |



## Specific Message Contents

## PHYSICAL CHANNEL RECONFIGURATION (Step 1) (FDD)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_DCH in PS" in Annex A with following exceptions:

| Information Element                                                                           | Value/remark |
|-----------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                           | URA_PCH      |
| Downlink information for each radio link<br>— Primary CPICH info<br>— Primary scrambling code | 100          |

## PHYSICAL CHANNEL RECONFIGURATION (Step 1) (TDD)

| Information Element                                                                       | Value/remark |
|-------------------------------------------------------------------------------------------|--------------|
| RRC State Indicator                                                                       | URA_PCH      |
| Downlink information for each radio links<br>— Primary CCPCH info<br>— Cell parameters ID | 4            |

## PAGING TYPE 1 (Step 4)

Use the same message sub-type titled "TM (SMS in PS)" in Annex A for FDD and Annex A for TDD with following exceptions:

| Information Element                                                                                             | Value/remark                                                                          |
|-----------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Paging record list<br>Paging record<br>— CHOICE Used paging identity<br>— U-RNTI<br>— SRNC Identity<br>— S-RNTI | UTRAN identity<br><br>Previously assigned SRNC identity<br>Previously assigned S-RNTI |

## 8.2.6.20.5 — Test requirement

After step 1 the UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the DCCH using AM RLC.

After step 4 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "paging response".

## 8.2.6.21 — Physical Channel Reconfiguration from CELL\_FACH to URA\_PCH: Success

## 8.2.6.21.1 — Definition

## 8.2.6.21.2 — Conformance requirement

1. In case the procedure was triggered by reception of a PHYSICAL CHANNEL RECONFIGURATION message, the UE shall:
  - transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE as response message on the uplink DCCH using AM RLC;
2. If the new state is CELL\_PCH or URA\_PCH, the response message shall be transmitted using the old configuration before the state transition, but the new C-RNTI shall be used if the IE "New C-RNTI" was included in the received reconfiguration message, and the UE shall:
  - when RLC has confirmed the successful transmission of the response message;

- for each radio bearer in the variable PDCP\_SN\_INFO:
- if the IE "RB started" in the variable ESTABLISHED\_RABS is set to "started":
  - configure the RLC entity for that radio bearer to "continue";
- enter the new state (CELL\_PCH or URA\_PCH, respectively);

Reference

3GPP TS 25.331 clause 8.2.2.4

8.2.6.21.3 Test purpose

1. To verify that the UE, when receiving a PHYSICAL CHANNEL RECONFIGURATION message, responds by transmitting a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC.
2. To verify that the response message is transmitted using the old configuration before the state transition, and that the UE enters the URA\_PCH state.

8.2.6.21.4 Method of test

Initial Condition

System Simulator: 1 cell

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

Test Procedure

The UE is in the CELL\_FACH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message. The UE transmits PHYSICAL CHANNEL RECONFIGURATION COMPLETE message to the SS using AM RLC and enters into URA\_PCH state. The SS transmits a PAGING TYPE 1 message and the UE accepts it and enters the CELL\_FACH state again.

Expected sequence

| Step | Direction |    | Message                                   | Comment                                                     |
|------|-----------|----|-------------------------------------------|-------------------------------------------------------------|
|      | UE        | SS |                                           |                                                             |
| 1    | ←         |    | PHYSICAL CHANNEL RECONFIGURATION          |                                                             |
| 2    | →         |    | PHYSICAL CHANNEL RECONFIGURATION COMPLETE | The UE sends this message before start state transition.    |
| 3    |           |    |                                           | Reconfiguration of Physical Channel after state transition. |
| 4    | ←         |    | PAGING TYPE 1                             | The SS transmits this message included a matched identity.  |
| 5    | →         |    | CELL UPDATE                               | The UE is in CELL_FACH state.                               |

Specific Message Contents

PHYSICAL CHANNEL RECONFIGURATION (Step 1)

Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with following exceptions:

| Information Element                                                                                                                    | Value/remark               |
|----------------------------------------------------------------------------------------------------------------------------------------|----------------------------|
| RRC-State-Indicator<br>Downlink information for each radio-links<br>— Choice-mode<br>— Primary CPICH info<br>— Primary scrambling code | URA_PCH<br><br><br><br>100 |

#### PAGING-TYPE 1 (Step 4)

Use the same message sub-type titled "TM (SMS in PS)" in Annex A with following exceptions:

| Information Element                                                                                             | Value/remark                                                                              |
|-----------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|
| Paging record list<br>Paging record<br>— CHOICE Used-paging-identity<br>— U-RNTI<br>— SRNC-Identity<br>— S-RNTI | UTRAN-identity<br><br><br>Previously-assigned-SRNC-identity<br>Previously-assigned-S-RNTI |

#### 8.2.6.21.5 — Test requirement

- After step 1 the UE transmits PHYSICAL-CHANNEL RECONFIGURATION COMPLETE message to the UE on uplink DCCH using AM-RLC.
- In step 5 the UE shall transmit a CELL-UPDATE message.

#### 8.2.6.22 — Physical Channel Reconfiguration from CELL\_FACH to CELL\_PCH: Success

##### 8.2.6.22.1 — Definition

##### 8.2.6.22.2 — Conformance requirement

- In case the procedure was triggered by reception of a PHYSICAL-CHANNEL RECONFIGURATION message, the UE shall:
  - transmit a PHYSICAL-CHANNEL RECONFIGURATION COMPLETE as response message on the uplink DCCH using AM-RLC;
- If the new state is CELL\_PCH or URA\_PCH, the response message shall be transmitted using the old configuration before the state transition, but the new C-RNTI shall be used if the IE "New C-RNTI" was included in the received reconfiguration message, and the UE shall:
  - when RLC has confirmed the successful transmission of the response message:
    - for each radio-bearer in the variable PDCP\_SN\_INFO:
      - if the IE "RB-started" in the variable ESTABLISHED\_RABS is set to "started":
        - configure the RLC entity for that radio-bearer to "continue";
    - enter the new state (CELL\_PCH or URA\_PCH, respectively);

#### Reference

3GPP TS 25.331 clause 8.2.2.4

### 8.2.6.22.3 ~~Test purpose~~

1. ~~To verify that the UE, when receiving a PHYSICAL CHANNEL RECONFIGURATION message, responds by transmitting a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC.~~
2. ~~To verify that the response message is transmitted using the old configuration before the state transition, and that the UE enters the CELL\_PCH state.~~

### 8.2.6.22.4 ~~Method of test~~

#### ~~Initial Condition~~

~~System Simulator: 1 cell.~~

~~UE: PS-DCCH+DTCH\_FACH(state 6-11) as specified in clause 7.4 of TS 34.108.~~

#### ~~Test Procedure~~

~~The UE is in the CELL\_FACH state. The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message. The UE transmits PHYSICAL CHANNEL RECONFIGURATION COMPLETE message to the SS using AM RLC and enters into CELL\_PCH state. The SS transmits a PAGING TYPE 1 message and the UE accepts it and enters the CELL\_FACH state again.~~

#### ~~Expected sequence~~

| Step | Direction |    | Message                                   | Comment                                                     |
|------|-----------|----|-------------------------------------------|-------------------------------------------------------------|
|      | UE        | SS |                                           |                                                             |
| 1    | ←         |    | PHYSICAL CHANNEL RECONFIGURATION          |                                                             |
| 2    | →         |    | PHYSICAL CHANNEL RECONFIGURATION COMPLETE | The UE sends this message before start state transition.    |
| 3    |           |    |                                           | Reconfiguration of Physical Channel after state transition. |
| 4    | ←         |    | PAGING TYPE 1                             | The SS transmits this message included a matched identity.  |
| 5    | →         |    | CELL UPDATE                               | The UE is in CELL_FACH state.                               |

#### ~~Specific Message Contents~~

##### ~~PHYSICAL CHANNEL RECONFIGURATION (Step 1)~~

~~Use the same message sub-type titled "Packet to CELL\_FACH from CELL\_FACH in PS" in Annex A with following exceptions:~~

| Information Element                       | Value/remark |
|-------------------------------------------|--------------|
| RRC State Indicator                       | CELL_PCH     |
| Downlink information for each radio links |              |
| - Choice mode                             |              |
| - Primary CPICH info                      |              |
| → Primary scrambling code                 | 100          |

##### ~~PAGING TYPE 1 (Step 4)~~

~~Use the same message sub-type titled "TM (Packet in PS)" in default message content of TS34.108 with following exceptions:~~

| Information Element           | Value/remark                      |
|-------------------------------|-----------------------------------|
| Paging record list            |                                   |
| Paging record                 |                                   |
| — CHOICE Used-paging identity | UTRAN-identity                    |
| — U-RNTI                      |                                   |
| — SRNC-Identity               | Previously-assigned SRNC-identity |
| — S-RNTI                      | Previously-assigned S-RNTI        |

#### 8.2.6.22.5 Test requirement

1. After step 1 the UE transmits PHYSICAL CHANNEL RECONFIGURATION COMPLETE message to the UE on uplink DCCH using AM RLC.
2. In step 5 the UE shall transmit a CELL UPDATE message.

### 8.2.7 Physical Shared Channel Allocation [TDD only]

[Editor's note: This message is not included in Release99 so this is FFS.]

### 8.2.8 PUSCH capacity request [TDD only]

[Editor's note: This message is not included in Release99 so this is FFS.]

### 8.2.9 Void

## 8.3 RRC connection mobility procedure

### 8.3.1 Cell Update

#### 8.3.1.1 Cell Update: cell reselection in CELL\_FACH

##### 8.3.1.1.1 Definition

##### 8.3.1.1.2 Conformance requirement

This procedure is used to update UTRAN with the current cell of the UE after it has performed a cell reselection in CELL\_FACH state.

#### Reference

3GPP TS 25.331 clause 8.3.1

##### 8.3.1.1.3 Test purpose

To confirm that the UE executes a cell update procedure after the successful reselection of another UTRA cell. To confirm that the UE sends the correct uplink response message when executing cell update procedure due to cell reselection.

##### 8.3.1.1.4 Method of test

#### Initial Condition

System Simulator: 2 cells – Cell 1 and 2 are active.

UE: PS-DCCH+DTCH\_FACH (state 6-11) in cell 1 as specified in clause 7.4 of TS 34.108.

Test Procedure

Table 8.3.1.1

| Parameter              | Unit        | Cell 1 |     | Cell 2 |     |
|------------------------|-------------|--------|-----|--------|-----|
|                        |             | T0     | T1  | T0     | T1  |
| UTRA RF Channel Number |             | Ch. 1  |     | Ch. 1  |     |
| CPICH Ec               | dBm/3.84MHz | -60    | -75 | -75    | -60 |

Table 8.3.1.1 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution. Columns marked "T0" denote the initial conditions. SS switches the power settings repeatedly between columns "T1" and "T0", whenever the description below specifies that the transmission power settings for cell 1 and cell 2 be reversed.

The UE is in the CELL\_FACH state, camping onto cell 1. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.1.1. The UE shall find cell 2 to be more suitable for service and hence perform a cell reselection. After the completion of cell reselection, the UE shall transmit a CELL UPDATE message to the SS on the uplink CCCH of cell 2 and set IE "Cell update cause" to "Cell Reselection". After the SS receives this message, it transmits a CELL UPDATE CONFIRM message, which includes the IE "RRC State Indicator" set to "CELL\_FACH", to the UE on the downlink DCCH. SS verifies that the UE does not send any response to this message. UE shall stay in CELL\_FACH state. SS configures its downlink transmission power settings according to columns "T0" in table 8.3.1.1. The UE shall send a CELL UPDATE message on the uplink CCCH of cell 1. SS replies with CELL UPDATE CONFIRM message and allocates new C-RNTI and U-RNTI identities to the UE. The IE "RRC State Indicator" is set to "CELL\_FACH" in this message. The UE shall transmit UTRAN MOBILITY INFORMATION CONFIRM message. Following this, SS configures its downlink transmission power settings according to columns "T1" in table 8.3.1.1. The UE shall initiate a cell update procedure by transmitting a CELL UPDATE message and stating the cause as 'cell reselection'. SS replies with a CELL UPDATE CONFIRM message which contains IE "Physical channel information elements". The UE shall send PHYSICAL CHANNEL RECONFIGURATION COMPLETE message to acknowledge the change in physical resources. Then, SS configures its downlink transmission power settings according to columns "T0" in table 8.3.1.1. The UE shall send a CELL UPDATE message on the uplink CCCH of cell 1. SS replies with a CELL UPDATE CONFIRM message which contains IE "Transport channel information elements". The UE shall send TRANSPORT CHANNEL RECONFIGURATION COMPLETE message. Following this, SS configures its downlink transmission power settings according to columns "T1" in table 8.3.1.1. The UE shall send a CELL UPDATE message on the uplink CCCH of cell 2. SS replies with a CELL UPDATE CONFIRM message which contains IE "RB information to be affected list". The UE shall send RADIO BEARER RECONFIGURATION COMPLETE message. Then, SS configures its downlink transmission power settings according to columns "T0" in table 8.3.1.1. The UE shall send a CELL UPDATE message on the uplink CCCH of cell 1. SS replies with a CELL UPDATE CONFIRM message which contains IE "RB information to release list". The UE shall send RADIO BEARER RELEASE COMPLETE message. Finally, SS configures its downlink transmission power settings according to columns "T1" in table 8.3.1.1. The UE shall send a CELL UPDATE message on the uplink CCCH of cell 2. SS shall not respond to this message but SS configures its downlink transmission power settings according to columns "T0" in table 8.3.1.1. UE shall send a CELL UPDATE message on the uplink CCCH of cell 1. SS shall then send CELL UPDATE CONFIRM message to UE.

#### Expected sequence

| Step | Direction |    | Message             | Comment                                                                                                                                                                                                                                                                    |
|------|-----------|----|---------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                     |                                                                                                                                                                                                                                                                            |
| 1    |           |    |                     | The UE is in the CELL_FACH state in cell 1                                                                                                                                                                                                                                 |
| 2    |           |    | Void                | SS applies the downlink transmission power settings, according to the values in columns "T1" of table 8.3.1.1. The UE shall find that the cell 2 is better for service and perform a reselection. SS waits for the maximum duration required for the UE to camp to cell 2. |
| 3    | →         |    | CELL UPDATE         | Value "cell reselection" shall be indicated in IE "Cell update cause"                                                                                                                                                                                                      |
| 4    | ←         |    | CELL UPDATE CONFIRM | IE "RRC State Indicator" is set to "CELL_FACH". SS set k=0.                                                                                                                                                                                                                |
| 5    |           |    |                     | SS checks the uplink PRACH channel to verify that no response is sent by UE.                                                                                                                                                                                               |
| 6    |           |    |                     | SS reverses the transmission power level of cell 1 and cell 2.                                                                                                                                                                                                             |
| 7    | →         |    | CELL UPDATE         |                                                                                                                                                                                                                                                                            |
| 8    | ←         |    | CELL UPDATE CONFIRM | IE "RRC State Indicator" is set                                                                                                                                                                                                                                            |

|    |   |                                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|----|---|--------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    |   |                                            | to "CELL_FACH". If $k \geq 0$ , new C-RNTI and U-RNTI identities are assigned to the UE. If $k > 0$ , IE "Physical channel information elements" is included in this message. If $k > 1$ , IE "Transport channel information elements" is included in this message. If $k > 2$ , IE "RB information to be affected list" is included in this message. If $k > 3$ , IE "RB information to release list" is included in this message. Increment $k$ by 1. |
| 9  | → | UTRAN MOBILITY INFORMATION CONFIRM         | If $k=1$ when SS received this message, go to step 6. Else test fails. If this message is not received, proceed to next step.                                                                                                                                                                                                                                                                                                                           |
| 10 | → | PHYSICAL CHANNEL RECONFIGURATION COMPLETE  | If $k=2$ when SS received this message, go to step 6. Else test fails. If this message is not received, proceed to next step.                                                                                                                                                                                                                                                                                                                           |
| 11 | → | TRANSPORT CHANNEL RECONFIGURATION COMPLETE | If $k=3$ when SS received this message, go to step 6. Else test fails. If this message is not received, proceed to next step.                                                                                                                                                                                                                                                                                                                           |
| 12 | → | RADIO BEARER RECONFIGURATION COMPLETE      | If $k=4$ when SS received this message, go to step 6. Else test fails. If this message is not received, proceed to next step.                                                                                                                                                                                                                                                                                                                           |
| 13 | → | RADIO BEARER RELEASE COMPLETE              | If $k=5$ when SS received this message, proceed to next step. Else test fails. If this message is not received, test fails.                                                                                                                                                                                                                                                                                                                             |
| 14 |   |                                            | SS reverses the transmission power level of cell 1 and cell 2.                                                                                                                                                                                                                                                                                                                                                                                          |
| 15 | → | CELL UPDATE                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 16 |   |                                            | SS reverses the transmission power level of cell 1 and cell 2.                                                                                                                                                                                                                                                                                                                                                                                          |
| 17 | → | CELL UPDATE                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 18 | ← | CELL UPDATE CONFIRM                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

### Specific Message Contents

#### CELL UPDATE (Step 3, 7, 15 and 17)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element                 | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| U-RNTI<br>-SRNC Identity<br>-S-RNTI | Check to see if set to '0000 0000 0001'<br>In step 3, check to see if set to '0000 0000 0000 0000 0001'. In step 7 and when $k < 1$ , check to see if set to '0000 0000 0000 0000 0001'. In step 7 and when $k > 0$ , check to see if set to same string in IE "S-RNTI" in IE "New U-RNTI" of CELL UPDATE CONFIRM message in previous step 8. In step 15 and 17, check to see if set to same string in IE "S-RNTI" in IE "New U-RNTI" of CELL UPDATE CONFIRM message in previous step 8. |
| Cell Update Cause                   | Check to see if set to 'Cell Re-selection'                                                                                                                                                                                                                                                                                                                                                                                                                                               |



**CELL UPDATE CONFIRM (Step 4 and 18)**

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| RRC State Indicator | CELL_FACH    |

**CELL UPDATE CONFIRM (Step 8 and k = 0)**

Use the same message sub-type found in step 4, with the following exceptions:

| Information Element                     | Value/remark                                                                                                            |
|-----------------------------------------|-------------------------------------------------------------------------------------------------------------------------|
| New U-RNTI<br>-SRNC Identity<br>-S-RNTI | '0000-0000-0001'<br>An arbitrary 20-bits string which is different from original S-RNTI                                 |
| New C-RNTI                              | An arbitrary 16-bits string which is different from original C-RNTI assigned in RRC connection establishment procedure. |

**CELL UPDATE CONFIRM (Step 8 and k=1)**

Use the same message sub-type found in step 8 and k=0, with the following exceptions:

| Information Element             | Value/remark                                                                                               |
|---------------------------------|------------------------------------------------------------------------------------------------------------|
| Maximum allowed uplink TX power | 3 dB below the follow value:<br>Minimum of {33 dBm, maximum uplink power allowed under the UE power class} |

**CELL UPDATE CONFIRM (Step 8 and k=2)**

Use the same message sub-type found in step 8 and k=1, with the following exceptions:

| Information Element                             | Value/remark                                |
|-------------------------------------------------|---------------------------------------------|
| Added or Reconfigured uplink TrCH information   | Same as the system information block type 5 |
| Added or Reconfigured downlink TrCH information | Same as the system information block type 5 |

**CELL UPDATE CONFIRM (Step 8 and k=3)**

Use the same message sub-type found in step 8 and k=2, with the following exceptions:

| Information Element                                                                                                                   | Value/remark                                                           |
|---------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------|
| RB information to be reconfigure<br>-RB identity<br>-PDCP info<br>-PDCP SN info<br>-RLC info<br>-RB mapping info<br>-RB stop/continue | 20<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>Stop |

**CELL UPDATE CONFIRM (Step 8 and k=4)**

Use the same message sub-type found in step 8 and k=3, with the following exceptions:

| Information Element                        | Value/remark |
|--------------------------------------------|--------------|
| RB information to release<br>——RB identity | 4            |

#### 8.3.1.1.5 ~~Test requirement~~

~~After step 2 the UE shall reselect to cell 2 and then it shall transmit a CELL\_UPDATE message which, sets the value "cell reselection" in IE "Cell update cause".~~

~~After step 4 the UE shall not transmit any uplink message in response to the CELL\_UPDATE\_CONFIRMATION message received in step 4.~~

~~After step 6 the UE shall send a CELL\_UPDATE message to the cell with stronger transmitting power, in order to indicate that a cell reselection has taken place.~~

~~After step 8, if k=1, the UE shall transmit a UTRAN\_MOBILITY\_INFORMATION\_CONFIRM message to acknowledge that it has started to use the new RNTI identities allocated.~~

~~If k=2, the UE shall transmit a PHYSICAL\_CHANNEL\_RECONFIGURATION\_COMPLETE message on the new physical channel assigned.~~

~~If k=3, the UE shall transmit a TRANSPORT\_CHANNEL\_RECONFIGURATION\_COMPLETE message to acknowledge that it has reconfigured the transport channels.~~

~~If k=4, the UE shall transmit a RADIO\_BEARER\_RECONFIGURATION\_COMPLETE message to acknowledge that it has reconfigured the radio bearers.~~

~~If k=5, the UE shall transmit a RADIO\_BEARER\_RELEASE\_COMPLETE message to acknowledge that it has released its radio bearers.~~

~~After step 14 the UE shall transmit a CELL\_UPDATE message to the cell with stronger transmitting power, in order to indicate that a cell reselection has taken place.~~

~~After step 16 the UE shall transmit a CELL\_UPDATE message to the cell with stronger transmitting power, in order to indicate that a cell reselection has taken place.~~

### 8.3.1.2 ~~Cell Update: cell reselection in CELL\_PCH~~

#### 8.3.1.2.1 ~~Definition~~

#### 8.3.1.2.2 ~~Conformance requirement~~

~~This procedure is to update UTRAN with information of the current cell, after a cell reselection has occurred in CELL\_PCH state.~~

#### Reference

~~3GPP TS 25.331 clause 8.3.1.~~

#### 8.3.1.2.3 ~~Test purpose~~

~~To confirm that the UE, in CELL\_PCH state, executes a cell update procedure after the successful reselection of another UTRA cell.~~

#### 8.3.1.2.4 ~~Method of test~~

#### Initial Condition

System Simulator: 2 cells — Cell 1 and 2 are active.

UE: CELL\_PCH (state 6-12) in cell 1 as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is brought to CELL\_PCH state and is camped onto cell 1. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.1.1. When the UE detects the presence of cell 2, it moves to

CELL\_FACH state and transmits a CELL\_UPDATE message on the uplink CCCH. The value "cell reselection" shall be set in IE "Cell update cause" in CELL\_UPDATE message. Upon reception of CELL\_UPDATE message, SS replies with a CELL\_UPDATE\_CONFIRM message with the IE "RRC State Indicator" set to "CELL\_PCH". After receiving this message, the UE returns to CELL\_PCH state without transmitting any uplink message. The SS transmits a PAGING TYPE 1 message, causing the UE to enter CELL\_FACH state and the UE shall transmit a CELL\_UPDATE message on uplink CCCH with IE "Cell update cause" set to "paging response". SS shall respond with a CELL\_UPDATE\_CONFIRM message.

#### Expected sequence

| Step | Direction |    | Message             | Comment                                                                                                                                                                                               |
|------|-----------|----|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                     |                                                                                                                                                                                                       |
| 1    |           |    |                     | The UE is brought to CELL_PCH state in cell 1.                                                                                                                                                        |
| 2    |           |    |                     | SS applies the downlink transmission power settings, according to the values in columns "T1" of table 8.3.1.1. The UE shall find that the cell 2 is better and attempt to perform a cell reselection. |
| 3    |           | →  | CELL_UPDATE         | The UE moves to CELL_FACH state and transmits this message with the IE "Cell update cause" set to "cell reselection".                                                                                 |
| 4    |           | ←  | CELL_UPDATE_CONFIRM | IE "RRC State Indicator" is set to "CELL_PCH".                                                                                                                                                        |
| 5    |           |    |                     | The UE is in CELL_PCH state.                                                                                                                                                                          |
| 6    |           | ←  | PAGING TYPE 1       | The SS transmits this message with a matched identity.                                                                                                                                                |
| 7    |           | →  | CELL_UPDATE         | The UE is in CELL_FACH state.                                                                                                                                                                         |
| 8    |           | ←  | CELL_UPDATE_CONFIRM |                                                                                                                                                                                                       |

#### Specific Message Contents

##### CELL\_UPDATE (Steps 3 and 7)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element                 | Value/remark                                                                                                                                                                                                           |
|-------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| U-RNTI<br>-SRNC-Identity<br>-S-RNTI | Check to see if set to '0000-0000-0001'<br>Check to see if set to '0000-0000-0000-0000-0001'<br>Check to see if set to 'Cell Re-selection' when in step 3.<br>Check to see if set to "paging response" when in step 7. |
| Cell Update Cause                   |                                                                                                                                                                                                                        |

##### CELL\_UPDATE\_CONFIRM (Step 4)

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| RRC State Indicator | CELL_PCH     |

8.3.1.2.5 Test requirement

After step 2 the UE shall reselect to cell 2 and transmit a CELL\_UPDATE message, containing the IE "Cell update cause" set to "cell reselection".

After step 6 the UE shall transmit a CELL\_UPDATE message on the CCCH with IE "Cell update cause" set to "paging response".

8.3.1.3 Cell Update: periodical cell update in CELL\_FACH

8.3.1.3.1 Definition

8.3.1.3.2 Conformance requirement

This procedure is to update UTRAN with the current cell information, after the UE has remained in the service area in the CELL\_FACH state for a period exceeding the timer value T305.

Reference

3GPP TS 25.331 clause 8.3.1

8.3.1.3.3 Test purpose

To confirm that the UE executes a periodical cell update procedure following the expiry of timer T305.

8.3.1.3.4 Method of test

Initial Condition

System Simulator: 2 cells—Cell 1 and 2 are active.

UE: PS-DCCCH+DTCH\_FACH (state 6-11) in cell 1 as specified in clause 7.4 of TS 34.108.

Test Procedure

Table 8.3.1.3

| Parameter              | Unit         | Cell 1 |     | Cell 2 |     |
|------------------------|--------------|--------|-----|--------|-----|
|                        |              | T0     | T1  | T0     | T1  |
| UTRA—RF Channel Number |              | Ch. 1  |     | Ch. 1  |     |
| CPICH Ec               | dBm/3.84 MHz | -60    | -75 | -75    | -60 |

Table 8.3.1.3 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution.

The UE is in CELL\_FACH state. When the UE detects the expiry of timer T305 according to the settings in system information, the UE transmits a CELL\_UPDATE message to the SS on the uplink CCCH with a cause indicating periodical cell updating. SS replies with a CELL\_UPDATE\_CONFIRM message, and IE "RRC State Indicator" is set to "CELL\_FACH". SS verifies that the UE does not transmit any uplink message. SS then waits for T305 to expire again. The UE shall send another CELL\_UPDATE message to report periodic cell updating. After the SS receives this message, it transmits a CELL\_UPDATE\_CONFIRM message which includes the IEs "new C-RNTI", "new U-RNTI" to the UE on the downlink DCCH. Then the UE shall transmit an UTRAN MOBILITY INFORMATION\_CONFIRM message on the uplink DCCH to acknowledge the receipt of the new UE identities. Next, SS transmits UTRAN MOBILITY INFORMATION message, which includes IE "T305" set to "infinity", to UE. UE shall transmit UTRAN MOBILITY INFORMATION\_CONFIRM message. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.1.3, causing the UE to enter CELL\_FACH state in cell 2 and transmit a CELL\_UPDATE message on uplink CCCH with IE "Cell update cause" set to "cell reselection". Then SS shall transmit CELL\_UPDATE

CONFIRM. SS then monitors the uplink CCCH for a period up to the maximum possible value for timer T305 (720 minutes) and verifies that no CELL\_UPDATE message is received. After this, the SS transmits UTRAN MOBILITY INFORMATION message, which includes IE "T305" set to '5', to UE. UE shall transmit UTRAN MOBILITY INFORMATION CONFIRM message. SS configures its downlink transmission power settings according to columns "T0" in table 8.3.1.3, causing the UE to enter CELL\_FACH state in cell 1 and transmit a CELL\_UPDATE message on uplink CCCH with IE "Cell update cause" set to "cell reselection". Then SS shall transmit CELL\_UPDATE CONFIRM. UE shall resume periodic cell updating procedure and transmit CELL\_UPDATE message after T305 (5 minutes) expires.

#### Expected sequence

| Step | Direction |    | Message                            | Comment                                                                                                      |
|------|-----------|----|------------------------------------|--------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                    |                                                                                                              |
| 1    |           |    |                                    | The UE is in the CELL_FACH state. SS waits until T305 has expired.                                           |
| 2    | →         |    | CELL_UPDATE                        | IE "Cell update cause" shall be set to "periodical cell updating"                                            |
| 3    | ←         |    | CELL_UPDATE CONFIRM                | No RNTI identities are given. No information on PRACH and S-CCPCH are provided.                              |
| 4    |           |    |                                    | SS verifies that no uplink message is received from UE. SS waits for another period to allow T305 to expire. |
| 5    | →         |    | CELL_UPDATE                        | Set to "periodical cell update" in IE "Cell update cause" upon the expiry of timer T305.                     |
| 6    | ←         |    | CELL_UPDATE CONFIRM                | Including IEs "new C-RNTI", "new U-RNTI" and IE "RRC State Indicator" is set to "CELL_FACH"                  |
| 7    | →         |    | UTRAN MOBILITY INFORMATION CONFIRM |                                                                                                              |

|    |   |                                    |                                                                                                               |
|----|---|------------------------------------|---------------------------------------------------------------------------------------------------------------|
| 8  | ← | UTRAN-MOBILITY INFORMATION         | IE "T305" is set to 'infintiy'.                                                                               |
| 9  | → | UTRAN-MOBILITY INFORMATION CONFIRM |                                                                                                               |
| 10 |   |                                    | SS applies the downlink transmission power settings, according to the values in columns "T1" of table 8.3.1.3 |
| 11 | → | CELL UPDATE                        | IE "Cell update cause" shall be set to "cell reselection".                                                    |
| 12 | ← | CELL UPDATE CONFIRM                |                                                                                                               |
| 13 |   |                                    | SS waits for 720 minutes and checks that no CELL UPDATE message is transmitted on uplink PRACH channel.       |
| 14 | ← | UTRAN-MOBILITY INFORMATION         | IE "T305" is set to '5'.                                                                                      |
| 15 | → | UTRAN-MOBILITY INFORMATION CONFIRM |                                                                                                               |
| 16 |   |                                    | SS applies the downlink transmission power settings, according to the values in columns "T0" of table 8.3.1.3 |
| 17 | → | CELL UPDATE                        | IE "Cell update cause" shall be set to "cell reselection".                                                    |
| 18 | ← | CELL UPDATE CONFIRM                |                                                                                                               |
| 19 | → | CELL UPDATE                        | UE shall transmit this message with "cell update cause" set to "periodical cell updating" after T305 expires. |
| 20 | ← | CELL UPDATE CONFIRM                |                                                                                                               |

### Specific Message Contents

#### CELL UPDATE (Step 2 and 5)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| -SRNC-Identity      | Check to see if set to '0000-0000-0001'           |
| -S-RNTI             | Check to see if set to '0000-0000-0000-0000-0001' |
| Cell Update Cause   | Check to see if set to 'periodical cell updating' |

#### CELL UPDATE (Step 11 and 17)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                                                                                               |
|---------------------|----------------------------------------------------------------------------------------------------------------------------|
| U-RNTI              |                                                                                                                            |
| -SRNC-Identity      | Check to see if set to '0000-0000-0001'                                                                                    |
| →S-RNTI             | Check to see if set to same bit string as in IE "S-RNTI" in IE "U-RNTI" of the CELL UPDATE CONFIRM message sent in step 6. |
| Cell Update Cause   | Check to see if set to "cell reselection"                                                                                  |

**CELL UPDATE CONFIRM (Step 3, 12, 18 and 20)**

Use the same message sub-type found in Annex A.

**CELL UPDATE CONFIRM (Step 6)**

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element | Value/remark                                                         |
|---------------------|----------------------------------------------------------------------|
| New U-RNTI          | Set to '0000 0000 0001'                                              |
| - SRNC Identity     | Set to an arbitrary string different from '0000 0000 0000 0000 0001' |
| - S-RNTI            |                                                                      |

**CELL UPDATE (Step 19)**

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                                                                                               |
|---------------------|----------------------------------------------------------------------------------------------------------------------------|
| U-RNTI              | Check to see if set to '0000 0000 0001'                                                                                    |
| - SRNC Identity     | Check to see if set to same bit string as in IE "S-RNTI" in IE "U-RNTI" of the CELL UPDATE CONFIRM message sent in step 6. |
| - S-RNTI            | Check to see if set to 'periodical cell updating'                                                                          |
| Cell Update Cause   |                                                                                                                            |

**UTRAN MOBILITY INFORMATION (Step 8)**

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element                       | Value/remark |
|-------------------------------------------|--------------|
| New U-RNTI                                | Not Present  |
| New C-RNTI                                | Not Present  |
| UE Timers and constants in connected mode |              |
| -- T305                                   | infinity     |

**UTRAN MOBILITY INFORMATION (Step 14)**

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element                       | Value/remark |
|-------------------------------------------|--------------|
| New U-RNTI                                | Not Present  |
| New C-RNTI                                | Not Present  |
| UE Timers and constants in connected mode |              |
| -- T305                                   | 5            |

**8.3.1.3.5 Test requirement**

After step 1 the UE shall detect the expiry of timer T305 and then transmits a CELL UPDATE message setting value "periodical cell update" into IE "Cell update cause".

After step 3 the UE shall not send any uplink message as a response to CELL UPDATE CONFIRM message sent in step 3.

After step 4 the UE shall send a CELL UPDATE message, specifying the cell updating cause to be "periodical cell update".

After step 6 the UE shall transmit an UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH.

After step 8, the UE shall transmit a UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH using AM RLC.

After step 10, the UE shall transmit a CELL UPDATE message with IE "cell update cause" set to "cell reselection" on the uplink CCCH.

Between step 12 and 14, the UE shall not transmit any CELL UPDATE message.

After step 14, the UE shall transmit a UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH using AM RLC.

After step 16, the UE shall transmit a CELL UPDATE message with IE "cell update cause" set to "cell reselection" on the uplink CCCH.

After step 18, the UE shall transmit a CELL UPDATE message with IE "cell update cause" set to "periodical cell update" on the uplink CCCH.

8.3.1.4 Cell Update: periodical cell update in CELL\_PCH

8.3.1.4.1 Definition

8.3.1.4.2 Conformance requirement

This procedure is to update UTRAN with the information of the current cell when the UE detects that it is still in the service area, while residing in the CELL\_PCH state, after the expiry of timer T305.

Reference

3GPP TS 25.331 clause 8.3.1

8.3.1.4.3 Test purpose

To confirm that the UE, in CELL\_PCH state, executes a cell update procedure after the expiry of timer T305.

8.3.1.4.4 Method of test

Initial Condition

System Simulator: 2 cells—Cell 1 and 2 are active.

UE: CELL\_PCH (state 6-12) in cell 1 as specified in clause 7.4 of TS 34.108.

Test Procedure

Table 8.3.1.4

| Parameter              | Unit         | Cell 1 |     | Cell 2 |     |
|------------------------|--------------|--------|-----|--------|-----|
|                        |              | T0     | T1  | T0     | T1  |
| UTRA—RF Channel Number |              | Ch. 1  |     | Ch. 1  |     |
| CPICH-Ec               | dBm/3.84 MHz | -60    | -75 | -75    | -60 |

Table 8.3.1.4 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution.



The UE starts from CELL\_PCH state. When the UE detects the expiry of periodic cell updating timer T305 according to the system information, the UE moves to CELL\_FACH state. It shall transmit a CELL\_UPDATE message on the uplink CCCH and set the value "periodical cell update" into IE "Cell update cause". SS answers with a CELL\_UPDATE CONFIRM message. SS transmits UTRAN MOBILITY INFORMATION message, which includes IE "T305" set to "infinity", to UE. UE shall transmit UTRAN MOBILITY INFORMATION CONFIRM message. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.1.4, causing the UE to enter CELL\_FACH state in cell 2 and transmit a CELL\_UPDATE message on uplink CCCH with IE "Cell update cause" set to "cell reselection". Then SS shall transmit CELL\_UPDATE CONFIRM with IE "RRC state indicator" set to "CELL\_PCH". Then UE shall enter CELL\_PCH state. SS then monitors the uplink CCCH for a period up to the maximum possible value for timer T305 (720 minutes) and verifies that no CELL\_UPDATE message is received. SS then configures its downlink transmission power settings according to columns "T0" in table 8.3.1.4, causing the UE to enter CELL\_FACH state in cell 1 and transmit a CELL\_UPDATE message on uplink CCCH with IE "Cell update cause" set to "cell reselection". Then SS shall transmit CELL\_UPDATE CONFIRM. Next, SS transmits UTRAN MOBILITY INFORMATION message, which includes IE "T305" set to "5", to UE. UE shall transmit UTRAN MOBILITY INFORMATION CONFIRM message. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.1.4, causing the UE to enter CELL\_FACH state in cell 2 and transmit a CELL\_UPDATE message on uplink CCCH with IE "Cell update cause" set to "cell reselection". Then SS shall transmit CELL\_UPDATE CONFIRM with IE "RRC state indicator" set to "CELL\_PCH". Then UE shall enter CELL\_PCH state. After T305 expires, UE shall transmit CELL\_UPDATE message with IE "cell update cause" set to "periodical cell update". SS shall transmit CELL\_UPDATE CONFIRM message to end the procedure.

#### Expected sequence

| Step | Direction |    | Message                            | Comment                                                                                                                                                                                                                        |
|------|-----------|----|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                    |                                                                                                                                                                                                                                |
| 1    |           |    |                                    | The UE is in the CELL_PCH state. SS waits until T305 has expired. Wait for CELL_UPDATE message and then verify that the time of arrival of this message is in the range of T305 value +/- 10 % after it entered CELL_PCH state |
| 2    | →         |    | CELL_UPDATE                        | The UE shall move to CELL_FACH state and transmits this message with the IE "Cell update cause" set to "periodical cell update".                                                                                               |
| 3    | ←         |    | CELL_UPDATE_CONFIRM                |                                                                                                                                                                                                                                |
| 4    | ←         |    | UTRAN_MOBILITY_INFORMATION         | IE "T305" is set to 'infinity'.                                                                                                                                                                                                |
| 5    | →         |    | UTRAN_MOBILITY_INFORMATION_CONFIRM |                                                                                                                                                                                                                                |
| 6    |           |    |                                    | SS applies the downlink transmission power settings, according to the values in columns "T1" of table 8.3.1.4.                                                                                                                 |
| 7    | →         |    | CELL_UPDATE                        | The UE shall move to CELL_FACH state and transmits this message with the IE "Cell update cause" set to "cell reselection".                                                                                                     |
| 8    | ←         |    | CELL_UPDATE_CONFIRM                | UE enters CELL_PCH state after transmitting this message.                                                                                                                                                                      |
| 9    |           |    |                                    | SS waits for 720 minutes and checks that no CELL_UPDATE message is transmitted on uplink PRACH channel.                                                                                                                        |

| Step | Direction |    | Message                            | Comment                                                                                                                    |
|------|-----------|----|------------------------------------|----------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                    |                                                                                                                            |
| 10   |           |    |                                    | SS applies the downlink transmission power settings, according to the values in columns "T0" of table 8.3.1.4.             |
| 11   | →         |    | CELL UPDATE                        | The UE shall move to CELL_FACH state and transmits this message with the IE "Cell update cause" set to "cell reselection". |
| 12   | ←         |    | CELL UPDATE CONFIRM                |                                                                                                                            |
| 13   | ←         |    | UTRAN MOBILITY INFORMATION         | IE "T305" is set to '5'.                                                                                                   |
| 14   | →         |    | UTRAN MOBILITY INFORMATION CONFIRM |                                                                                                                            |
| 15   |           |    |                                    | SS applies the downlink transmission power settings, according to the values in columns "T1" of table 8.3.1.4.             |
| 16   | →         |    | CELL UPDATE                        | The UE shall move to CELL_FACH state and transmits this message with the IE "Cell update cause" set to "cell reselection". |
| 17   | ←         |    | CELL UPDATE CONFIRM                | UE enters CELL_PCH state after transmitting this message.                                                                  |
| 18   |           |    |                                    | SS wait for T305 timer to expire                                                                                           |
| 19   | →         |    | CELL UPDATE                        | IE "Cell update cause" shall be set to "periodical cell update".                                                           |
| 20   | ←         |    | CELL UPDATE CONFIRM                |                                                                                                                            |

### Specific Message Contents

#### CELL UPDATE (Step 2 and 19)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| -SRNC Identity      | Check to see if set to '0000-0000-0001'           |
| -S-RNTI             | Check to see if set to '0000-0000-0000-0000-0001' |
| Cell Update Cause   | Check to see if set to 'periodical cell updating' |

#### CELL UPDATE (Step 7, 11 and 16)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| -SRNC Identity      | Check to see if set to '0000-0000-0001'           |
| -S-RNTI             | Check to see if set to '0000-0000-0000-0000-0001' |
| Cell Update Cause   | Check to see if set to "cell reselection"         |

#### CELL UPDATE CONFIRM (Step 3, 12 and 20)

Use the same message sub-type found in Annex A.

**CELL UPDATE CONFIRM (Step 8 and 17)**

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| RRC-state indicator | CELL_PCH     |

**UTRAN MOBILITY INFORMATION (Step 4 and 13)**

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element                       | Value/remark                                   |
|-------------------------------------------|------------------------------------------------|
| New-U-RNTI                                | Not Present                                    |
| New-C-RNTI                                | Not Present                                    |
| UE-Timers and constants in connected mode |                                                |
| -T305                                     | Set to 'infinity' in step 4 and '5' in step 13 |

**8.3.1.4.5 Test requirement**

After step 1 the UE shall detect the expiry of timer T305, it shall then move to CELL\_FACH state and transmits a CELL UPDATE message with the IE "Cell update cause" set to "periodical cell update".

After step 4, the UE shall transmit a UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH using AM-RLC.

After step 6, the UE shall transmit a CELL UPDATE message with IE "cell update cause" set to "cell reselection" on the uplink CCCH.

After step 8 and before step 10, the UE shall not transmit any CELL UPDATE messages.

After step 10, the UE shall transmit a CELL UPDATE message with IE "cell update cause" set to "cell reselection" on the uplink CCCH.

After step 13, the UE shall transmit a UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH using AM-RLC.

After step 15, the UE shall transmit a CELL UPDATE message with IE "cell update cause" set to "cell reselection" on the uplink CCCH.

After step 18 the UE shall transmit a CELL UPDATE message stating the cell update cause to be periodic updating.

**8.3.1.5 Cell Update: UL data transmission in URA\_PCH****8.3.1.5.1 Definition****8.3.1.5.2 Conformance requirement**

This procedure is to update UTRAN with the current cell information if the UE wants to transmit uplink data while in URA\_PCH state.

**Reference**

3GPP TS 25.331 clause 8.3.1

**8.3.1.5.3 Test purpose**

To confirm that the UE executes a cell update procedure when the UE transmits uplink data if the UE is in URA\_PCH state.

#### 8.3.1.5.4 Method of test

##### Initial Condition

System Simulator: 1cell

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

##### Test Procedure

SS sends a MEASUREMENT CONTROL message to trigger UE to measure the CPICH RSCP in a intra frequency measurement and to report periodically by the MEASUREMENT REPORT message using UM RLC. UE shall send MEASUREMENT REPORT message to SS using UM RLC on DCCH. SS then transmit a RADIO BEARER RELEASE message with IE "RRC State Indicator" is set to "URA\_PCH". The UE shall reply with RADIO BEARER RELEASE COMPLETE message and move to URA\_PCH state. UE shall detect that the periodical timer for measurement reporting has elapsed and attempt to transmit a MEASUREMENT REPORT message. The UE then moves to CELL\_FACH state and transmits a CELL UPDATE message to the SS on the uplink CCCH, with the IE "Cell update-cause" set to value "uplink data transmission". After receiving such a message, SS transmits CELL UPDATE CONFIRM message. The UE shall stay in CELL\_FACH state and transmit MEASUREMENT REPORT message using UM RLC on DCCH.

##### Expected sequence

| Step | Direction |    | Message                       | Comment                                                                                                            |
|------|-----------|----|-------------------------------|--------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                               |                                                                                                                    |
| 1    |           |    |                               | The UE is brought to CELL_FACH state.                                                                              |
| 2    |           | ←  | MEASUREMENT CONTROL           |                                                                                                                    |
| 3    |           | →  | MEASUREMENT REPORT            |                                                                                                                    |
| 4    |           | ←  | RADIO BEARER RELEASE          | IE "RRC State Indicator" set to "URA_PCH"                                                                          |
| 5    |           | →  | RADIO BEARER RELEASE COMPLETE | UE moves to URA_PCH state.                                                                                         |
| 6    |           | →  | CELL UPDATE                   | The UE shall move to CELL_FACH state with the message set to "uplink data transmission" in IE "Cell update-cause". |
| 7    |           | ←  | CELL UPDATE CONFIRM           | Use default message content.                                                                                       |
| 8    |           | →  | MEASUREMENT REPORT            |                                                                                                                    |
|      |           |    |                               |                                                                                                                    |

##### Specific Message Contents

##### MEASUREMENT CONTROL (Step 2)

Use the same message sub-type found in Annex A with the following exceptions:

| Information Element                                  | Value/remark            |
|------------------------------------------------------|-------------------------|
| Measurement Reporting Mode                           |                         |
| → Measurement Report Transfer Mode                   | Unacknowledged mode RLC |
| → Measurement Reporting/Event Trigger Reporting Mode | Periodical              |

**RADIO BEARER RELEASE (Step 4)**

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element                                               | Value/remark                       |
|-------------------------------------------------------------------|------------------------------------|
| RRC State Indicator                                               | URA_PCH                            |
| RB information to release list                                    |                                    |
| – RB identity                                                     | 20 or 21 (for radio access bearer) |
| RB information to be affected list                                | Not Present                        |
| UL Transport channel information common for all transport channel | Not Present                        |
| Deleted TrCH information list                                     | Not Present                        |
| Added or Reconfigured UL TrCH information list                    | Not Present                        |
| DL Transport channel information common for all transport channel | Not Present                        |
| Deleted TrCH information list                                     | Not Present                        |
| Added or Reconfigured UL TrCH information list                    | Not Present                        |
| CHOICE channel requirement                                        | Not Present                        |
| Downlink information per radio link list                          | Not Present                        |

**CELL UPDATE (Step 6)**

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| – SRNC Identity     | Check to see if set to '0000-0000-0001'           |
| – S-RNTI            | Check to see if set to '0000-0000-0000-0000-0001' |
| Cell Update Cause   | Check to see if set to 'uplink data transmission' |

**CELL UPDATE CONFIRM (Step 7)**

Use the same message sub-type found in Annex A.

**MEASUREMENT REPORT (Step 3 and 8)**

Only the message type IE in this message will be checked.

**RADIO BEARER RELEASE COMPLETE (Step 5)**

Only the message type IE in this message will be checked.

**8.3.1.5.5 ————— Test requirement**

After step 2, UE shall transmit a MEASUREMENT REPORT message to SS using UM RLC on DCCH when 64 seconds has elapsed since the acknowledgement of MEASUREMENT CONTROL message.

After step 4, UE shall transmit a RADIO BEARER RELEASE COMPLETE message and move to URA\_PCH state.

After step 5, the UE shall move to CELL\_FACH state to initiate a cell update procedure and transmits a CELL UPDATE message which is set to "uplink data transmission" in IE "Cell update cause".

After step 7, UE shall transmit MEASUREMENT REPORT message to SS using AM RLC on DCCH.

### ~~8.3.1.6 Cell Update: UL data transmission in CELL\_PCH~~

#### ~~8.3.1.6.1 Definition~~

#### ~~8.3.1.6.2 Conformance requirement~~

~~This procedure is to update UTRAN with the current cell of the UE if the UE wants to transmit uplink data when the UE is in CELL\_PCH state.~~

#### ~~Reference~~

~~3GPP TS 25.331 clause 8.3.1~~

#### ~~8.3.1.6.3 Test purpose~~

~~To confirm that the UE executes a cell update procedure when the UE transmits uplink data if the UE is in CELL\_PCH state.~~

#### ~~8.3.1.6.4 Method of test~~

#### ~~Initial Condition~~

~~System Simulator: 1 cell~~

~~UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.~~

#### ~~Test Procedure~~

~~The UE is in the CELL\_FACH state. SS sends a MEASUREMENT CONTROL message to trigger UE to measure the CPICH RSCP in a intra-frequency measurement and to report periodically by the MEASUREMENT REPORT message using UM RLC. UE shall send a MEASUREMENT REPORT message to SS using UM RLC on DCCH. SS then transmits a RADIO BEARER RELEASE message with IE "RRC State Indicator" is set to "CELL\_PCH". The UE shall reply with RADIO BEARER RELEASE COMPLETE message and move to CELL\_PCH state. UE shall detect that the periodical timer for measurement reporting has elapsed and attempt to transmit a MEASUREMENT REPORT message. The UE then moves to CELL\_FACH state and transmits a CELL UPDATE message to the SS on the uplink CCCH, with the IE "Cell update-cause" set to value "uplink data transmission". After receiving such a message, SS transmits a CELL UPDATE CONFIRM message. The UE shall stay in CELL\_FACH state and transmit a MEASUREMENT REPORT message using UM RLC on DCCH.~~

## Expected sequence

| Step | Direction |    | Message                       | Comment                                                                                                                         |
|------|-----------|----|-------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                               |                                                                                                                                 |
| 1    |           |    |                               | The UE is brought to CELL_FACH state.                                                                                           |
| 2    |           | ←  | MEASUREMENT CONTROL           |                                                                                                                                 |
| 3    |           | →  | MEASUREMENT REPORT            |                                                                                                                                 |
| 4    |           | ←  | RADIO BEARER RELEASE          | IE "RRC State Indicator" set to "CELL_PCH"                                                                                      |
| 5    |           | →  | RADIO BEARER RELEASE COMPLETE | UE moves to CELL_PCH state.                                                                                                     |
| 6    |           | →  | CELL UPDATE                   | The UE moves to CELL_FACH state and transmit this message which is set to "uplink data transmission" in IE "Cell update cause". |
| 7    |           | ←  | CELL UPDATE CONFIRM           | Use default message content.                                                                                                    |
| 8    |           | →  | MEASUREMENT REPORT            |                                                                                                                                 |

## Specific Message Contents

## MEASUREMENT CONTROL (Step 2)

Use the same message sub-type found in Annex A with the following exceptions:

| Information Element                                    | Value/remark            |
|--------------------------------------------------------|-------------------------|
| Measurement Reporting Mode                             |                         |
| ——→ Measurement Report Transfer Mode                   | Unacknowledged mode RLC |
| ——→ Measurement Reporting/Event Trigger Reporting Mode | Periodical              |

## RADIO BEARER RELEASE (Step 4)

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element                                               | Value/remark                       |
|-------------------------------------------------------------------|------------------------------------|
| RRC State Indicator                                               | CELL_PCH                           |
| RB information to release list                                    |                                    |
| —RB identity                                                      | 20 or 21 (for radio access bearer) |
| RB information to be affected list                                | Not Present                        |
| UL Transport channel information common for all transport channel | Not Present                        |
| Deleted TrCH information list                                     | Not Present                        |
| Added or Reconfigured UL TrCH information list                    | Not Present                        |
| DL Transport channel information common for all transport channel | Not Present                        |
| Deleted TrCH information list                                     | Not Present                        |
| Added or Reconfigured UL TrCH information list                    | Not Present                        |
| CHOICE channel requirement                                        | Not Present                        |
| Downlink information per radio link list                          | Not Present                        |

## CELL UPDATE (Step 6)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| -SRNC Identity      | Check to see if set to '0000-0000-0001'           |
| -S-RNTI             | Check to see if set to '0000-0000-0000-0000-0001' |
| Cell Update Cause   | Check to see if set to 'uplink data transmission' |

#### ~~CELL UPDATE CONFIRM (Step 7)~~

Use the same message sub-type found in Annex A.

#### ~~MEASUREMENT REPORT (Step 3 and 8)~~

Only the message type IE in this message will be checked.

#### ~~RADIO BEARER RELEASE COMPLETE (Step 5)~~

Only the message type IE in this message will be checked.

#### ~~8.3.1.6.5 Test requirement~~

After step 2, UE shall transmit a MEASUREMENT REPORT message to SS using UM RLC on DCCH when 64 seconds has elapsed since the acknowledgement of MEASUREMENT CONTROL message.

After step 4, UE shall transmit a RADIO BEARER RELEASE COMPLETE message and move to CELL\_PCH state.

After step 5, the UE shall move to CELL\_FACH state to initiate a cell update procedure and transmits a CELL UPDATE message which is set to "uplink data transmission" in IE "Cell update cause".

After step 7, UE shall transmit a MEASUREMENT REPORT message to SS using UM RLC on DCCH.

#### ~~8.3.1.7 Void~~

#### ~~8.3.1.8 Void~~

#### ~~8.3.1.9 Cell Update: re-entering of service area after T305 expiry and being out of service area~~

##### ~~8.3.1.9.1 Definition~~

##### ~~8.3.1.9.2 Conformance requirement~~

When a UE detects that it's out of service area after experiencing a T305 timer expiry, it shall try to search for a suitable cell to camp on. At the same time, it shall start timer T307. If the UE subsequently re-enters the service area of a cell before T307 expires, it shall perform a cell update procedure.

#### ~~Reference~~

3GPP TS 25.331 clause 8.3.1

##### ~~8.3.1.9.3 Test purpose~~

To confirm that the UE performs a cell search after experiencing an "out of service area" condition following the expiry of timer T305. To confirm that the UE initiates cell updating procedure if it manages to re-enter the service area.



8.3.1.9.4 Method of test

Initial Condition

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

Test Procedure

Table 8.3.1.9

| Parameter              | Unit        | Cell 1 |     |
|------------------------|-------------|--------|-----|
|                        |             | T0     | T1  |
| UTRA-RF Channel Number |             | Ch. 1  |     |
| CPICH Ec               | dBm/3.84MHz | -60    | -80 |

Table 8.3.1.9 illustrates the downlink power to be applied at various time instants of the test execution. Columns marked "T0" denote the initial conditions.

The UE is in the CELL\_FACH state. The content of the SYSTEM INFORMATION BLOCK TYPE 3 and 4 is modified. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.1.9 so that  $S < 0$ . Following the expiry of periodic cell updating timer T305 according to the system information, the UE shall detect that it is out of service area. Within the time interval equivalent to T307 timer value, SS configures its downlink transmission power settings according to columns "T0" in table 8.3.1.9 so that  $S > 0$ . The UE shall find that it is back in service area, and transmit a CELL UPDATE message to the SS on the uplink CCCH. In this message, the IE "Cell update-cause" shall be set to "re-entered service area". After the SS receives this message, it transmits a CELL UPDATE CONFIRM message with the IE "RRC State Indicator" set "CELL\_PCH" on the downlink DCCH. The UE shall enter CELL\_PCH state. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.1.9 so that  $S < 0$ . Following the expiry of periodic cell updating timer T305 according to the system information, the UE shall detect that it is out of service area. Within the time interval equivalent to T307 timer value, SS configures its downlink transmission power settings according to columns "T0" in table 8.3.1.9 so that  $S > 0$ . The UE shall find that it is back in service area, move to CELL\_FACH and transmits a CELL UPDATE message to the SS on the uplink CCCH. In this message, the IE "Cell update-cause" shall be set to "re-entered service area". After the SS receives this message, it transmits a CELL UPDATE CONFIRM message on the downlink DCCH.

## Expected sequence

| Step | Direction |    | Message                                                              | Comment                                                                                                                                                               |
|------|-----------|----|----------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                      |                                                                                                                                                                       |
| 1    |           |    |                                                                      | The UE is in the CELL_FACH state of cell 1.                                                                                                                           |
| 1a   |           | ←  | MASTER INFORMATION BLOCK<br>SYSTEM INFORMATION BLOCK TYPE 3<br>and 4 | SS changes the contents of MASTER INFORMATION BLOCK and SYSTEM INFORMATION BLOCK (see specific message contents).                                                     |
| 1b   |           | ←  | SYSTEM INFORMATION CHANGE<br>INDICATION                              |                                                                                                                                                                       |
| 2    |           |    |                                                                      | SS configures its downlink transmission power settings according to columns "T1" in table 8.3.1.9 so that its S value falls below 0.                                  |
| 3    |           |    |                                                                      | The UE shall detect a "out of service" condition upon expiry of timer T305 and it shall search for other cells to camp on. (T307 timer starts)                        |
| 4    |           |    |                                                                      | SS configures its downlink transmission power settings according to columns "T0" in table 8.3.1.9.                                                                    |
| 5    |           | →  | CELL UPDATE                                                          | The value "re-entered service area" shall be found in IE "Cell update cause" in this message                                                                          |
| 6    |           | ←  | CELL UPDATE CONFIRM                                                  | "RRC State Indicator" is set to "CELL_PCH"                                                                                                                            |
| 7    |           |    |                                                                      | SS configures its downlink transmission power settings according to columns "T1" in table 8.3.1.9 so that its S value falls below 0 and waits until T305 has expired. |
| 8    |           |    |                                                                      | SS configures its downlink transmission power settings according to columns "T0" in table 8.3.1.9.                                                                    |
| 9    |           | →  | CELL UPDATE                                                          | UE shall move to CELL_FACH. It shall transmit this message with cell update cause set to "re-entered service area"                                                    |
| 10   |           | ←  | CELL UPDATE CONFIRM                                                  |                                                                                                                                                                       |

## Specific Message Contents

## MASTER INFORMATION BLOCK (Step 1a)

Use the same message sub-type found in clause 6.1 of TS 34.108, with the following exception:

| Information Element | Value/remark |
|---------------------|--------------|
| MIB Tag             | 2            |

## SYSTEM INFORMATION BLOCK TYPE 3 and 4 (Step 1a)

Use the same message sub-type found in clause 6.1 of TS 34.108, with the following exception:

| Information Element | Value/remark |
|---------------------|--------------|
| Qrxlevmin           | -70          |

#### SYSTEM INFORMATION CHANGE INDICATION (Step 1b)

| Information Element                                     | Value/remark |
|---------------------------------------------------------|--------------|
| Message Type<br>BCCH modification info<br>MIB Value tag | 2            |

#### CELL UPDATE (Step 5 and 9)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element                                      | Value/remark                                                                                                                                     |
|----------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| U-RNTI<br>-SRNC Identity<br>-S-RNTI<br>Cell Update Cause | Check to see if set to '0000-0000-0001'<br>Check to see if set to '0000-0000-0000-0000-0001'<br>Check to see if set to 're-entered service area' |

#### CELL UPDATE CONFIRM (Step 6 and 10)

Use the same message sub-type found in Annex A, with the following exception:

| Information Element | Value/remark |
|---------------------|--------------|
| RRC State Indicator | CELL_PCH     |

#### 8.3.1.9.5 Test requirement

After step 4 the UE shall transmit a CELL UPDATE message in which the IE "Cell update cause" is set to the value "re-entered service area".

After step 8 the UE shall move to CELL\_FACH and then transmit a CELL UPDATE message, with the IE "Cell Update Cause" set to "re-entered service area".

#### 8.3.1.10 Cell Update: expiry of T307 after T305 expiry and being out of service area

##### 8.3.1.10.1 Definition

##### 8.3.1.10.2 Conformance requirement

This procedure is required to cater for the case of a failure to update UTRAN with the current cell, after the expiry of T307. In this case, the UE shall return to idle mode and perform cell reselection if possible.

#### Reference

3GPP TS 25.331 clause 8.3.1

##### 8.3.1.10.3 Test purpose

To confirm that the UE moves to idle mode after the expiry of T307, indicating that it is out of service area when attempting to perform a periodic cell updating procedure.

8.3.1.10.4 Method of test

Initial Condition

System Simulator: 1 cell

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

Test Procedure

Table 8.3.1.10

| Parameter              | Unit        | Cell 1 |     |
|------------------------|-------------|--------|-----|
|                        |             | T0     | T1  |
| UTRA-RF Channel Number |             | Ch. 1  |     |
| CPICH Ec               | dBm/3.84MHz | -60    | -80 |

Table 8.3.1.10 illustrates the downlink power to be applied at various time instants of the test execution. Columns marked "T0" denote the initial conditions.

The UE is in CELL\_FACH state at the start of the test. Before the expiry of periodic cell updating timer T305, the content of the SYSTEM INFORMATION BLOCK TYPE 3 and 4 is modified. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.1.10 so that  $S < 0$  and this results in a "out of service area" condition. The SS continues to listen to the uplink channel to detect possible attempts to perform a cell updating procedure. The UE shall not send any CELL\_UPDATE message on the uplink DCCH, instead it triggers timer T307 and T305. After the expiry of timer T307 and SS configures its downlink transmission power settings according to columns "T0" in table 8.3.1.10 so that  $S > 0$ , the UE shall enter idle state. This is confirmed by the SS when it sends a PAGING TYPE 1 message to the UE using UE identity, and the UE shall respond to the message.

## Expected sequence

| Step | Direction |    | Message                                                              | Comment                                                                                                                                                                                                                                                                                        |
|------|-----------|----|----------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                      |                                                                                                                                                                                                                                                                                                |
| 1    |           |    |                                                                      | The UE is brought to CELL_FACH state.                                                                                                                                                                                                                                                          |
| 1a   |           | ←  | MASTER INFORMATION BLOCK<br>SYSTEM INFORMATION BLOCK TYPE 3<br>and 4 | SS changes the contents of MASTER INFORMATION BLOCK and SYSTEM INFORMATION BLOCK (see specific message contents).                                                                                                                                                                              |
| 1b   |           | ←  | SYSTEM INFORMATION CHANGE<br>INDICATION                              |                                                                                                                                                                                                                                                                                                |
| 2    |           |    |                                                                      | SS configures its downlink transmission power settings according to columns "T1" in table 8.3.1.10 so that the cell is no longer suitable for camping. The UE shall detect that it is out of service area and refrains from transmitting CELL UPDATE message due to periodic cell updating.    |
| 3    |           |    |                                                                      | The UE detects the expiry of timer T305 and it searches for other cells to camp on. After the expiry of timer T307, the UE shall enter idle mode. SS configures its downlink transmission power settings according to columns "T0" in table 8.3.1.10 so that the cell is suitable for camping. |
| 4    |           | ←  | PAGING TYPE 1                                                        | SS pages the UE at its assigned paging occasion using the allocated UE identity.                                                                                                                                                                                                               |
| 5    |           | →  | RRC CONNECTION REQUEST                                               | The UE shall respond to this page as it has already entered the idle mode.                                                                                                                                                                                                                     |

## Specific Message Contents

## MASTER INFORMATION BLOCK (Step 1a)

Use the same message sub-type found in clause 6.1 of TS 34.108, with the following exception.

| Information Element | Value/remark |
|---------------------|--------------|
| MIB-Tag             | 2            |

## SYSTEM INFORMATION BLOCK TYPE 3 and 4 (Step 1a)

Use the same message sub-type found in clause 6.1 of TS 34.108, with the following exception.

| Information Element | Value/remark |
|---------------------|--------------|
| Qrxlevmin           | -70          |

## SYSTEM INFORMATION CHANGE INDICATION (Step 1b)

| Information Element                                     | Value/remark |
|---------------------------------------------------------|--------------|
| Message Type<br>BCCH modification info<br>MIB Value tag | 2            |

## PAGING TYPE 1 (Step 4)

Use the same message type found in Annex A, with the following exception.

| Information Element                                                                                                                            | Value/remark                                                                                                                                                                                            |
|------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Paging record list<br>Paging record<br>CHOICE Used paging identity<br>— Paging cause<br>— CN domain identity<br>— CHOICE UE Identity<br>— IMSI | Only 1 entry<br><br>CN identity<br>Terminating Call with one of the supported services<br>Supported Domain (PS Domain or CS Domain)<br>IMSI<br>Set to the same IMSI value stored in the TEST USIM card. |

## 8.3.1.10.5 ——— Test requirement

After step 4 the UE shall transmit a RRC CONNECTION REQUEST message to respond to a PAGING TYPE 1 message.

## 8.3.1.11 ——— Cell Update: Success after T302 time-out

## 8.3.1.11.1 ——— Definition

## 8.3.1.11.2 ——— Conformance requirement

The UE transmits a CELL UPDATE message to the UTRAN when it needs to update the UTRAN with the current cell of the UE. When the UE does not receive a CELL UPDATE CONFIRM message upon expiry of timer T302, the UE transmits a CELL UPDATE message repeatedly until its internal counter V302 counter is greater than N302.

## Reference

3GPP TS 25.331 clause 8.3.1

## 8.3.1.11.3 ——— Test purpose

To confirm that the UE repeats the transmission of CELL UPDATE message after failing to receive any response from the SS before T302 timer expires.

## 8.3.1.11.4 ——— Method of test

## Initial Condition

System Simulator: 1 cell

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

## Test Procedure

At the start of the test, the UE is brought to CELL\_FACH state. When the UE detects the expiry of periodic cell updating timer T305 according to the system information, the UE transmits a CELL UPDATE message to the SS on the uplink CCCH. The IE "Cell update cause" in this message shall be set to "periodical cell update". SS ignores this message, and the UE shall then re-transmit a CELL UPDATE message after the expiry of timer T302. When the SS has

received (N302+1) such messages, it transmits a CELL UPDATE CONFIRM message with new values for "C-RNTI" to the UE. Finally, the UE shall transmit an UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH.

#### Expected sequence

| Step | Direction |    | Message                            | Comment                                                                                                                                                |
|------|-----------|----|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                    |                                                                                                                                                        |
| 1    |           |    |                                    | The UE starts from CELL_FACH state. SS initializes its internal counter K to 0 and waits until the expiry of T305 timer.                               |
| 2    |           | →  | CELL UPDATE                        | The value "periodical cell update" shall be set in IE "Cell update cause".                                                                             |
| 3    |           |    |                                    | If K is equal to N302 then proceeds to step 5.                                                                                                         |
| 4    |           |    |                                    | SS increments counter K, transmits no response to the UE and waits for an additional period equal to the value of timer T302. The next step is step 2. |
| 5    |           | ←  | CELL UPDATE CONFIRM                | The message includes IEs "new C-RNTI". The IE "RRC State Indicator" is set to "CELL_FACH".                                                             |
| 6    |           | →  | UTRAN MOBILITY INFORMATION CONFIRM |                                                                                                                                                        |

#### Specific Message Contents

##### CELL UPDATE (Step 2)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| -SRNC Identity      | Check to see if set to '0000-0000-0001'           |
| -S-RNTI             | Check to see if set to '0000-0000-0000-0000-0001' |
| Cell Update Cause   | Check to see if set to 'Periodic cell updating'   |

##### CELL UPDATE CONFIRM (Step 5)

Use the same message sub-type found in Annex A, with the following exception:

| Information Element | Value/remark                                                    |
|---------------------|-----------------------------------------------------------------|
| New C-RNTI          | Set to an arbitrary string different from '0000-0000-0000-0001' |

#### 8.3.1.11.5 Test requirement

After step 1 the UE shall detect the expiry of timer T305 then transmit a CELL UPDATE message on the uplink CCCH, setting "periodical cell update" into IE "Cell update cause".

After step 2 the UE shall re-transmits a CELL UPDATE message after the expiry of timer T302. A total of (N302+1) transmissions of CELL UPDATE message shall be detected in SS.

After step 5 the UE shall transmit an UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH and stay at CELL\_FACH state.

### ~~8.3.1.12 Cell Update: Failure (After Maximum Re-transmissions)~~

#### ~~8.3.1.12.1 Definition~~

#### ~~8.3.1.12.2 Conformance requirement~~

The UE transmits a CELL\_UPDATE message to the UTRAN when it needs to update UTRAN with information on the current cell of the UE. If the UE fails to receive a CELL\_UPDATE\_CONFIRM message, it re-transmits a CELL\_UPDATE message repeatedly upon the expiry of timer T302 until the value of V302 counter is greater than N302. If V302 is greater than N302, the UE stop the re-transmission and enters idle state.

#### Reference

3GPP TS 25.331 clause 8.3.1

#### ~~8.3.1.12.3 Test purpose~~

To confirm that the UE repeats the cell update procedure upon the expiry of timer T302 and moves to idle state when its internal counter V302 is greater than N302.

#### ~~8.3.1.12.4 Method of test~~

#### Initial Condition

System Simulator: 1 cell

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is initially in CELL\_FACH state. When the UE detects the expiry of periodic cell updating timer T305, the UE transmits a CELL\_UPDATE message to the SS on the uplink CCCH to perform a periodic cell updating procedure. The SS ignores this message, and the UE shall attempt to re-transmit a CELL\_UPDATE message up to a maximum of (N302+1) times after the expiry of timer T302. After (N302) attempts of retransmission, the UE shall return to idle state. SS transmits a PAGING TYPE 1 message with UE's identity. UE shall respond with a RRC CONNECTION REQUEST message.



## Expected sequence

| Step | Direction |    | Message     | Comment                                                                                                                                          |
|------|-----------|----|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |             |                                                                                                                                                  |
| 1    |           |    |             | The UE is in the CELL_FACH state. SS sets its internal counter K=0 and waits for a period equals to timer value T305.                            |
| 2    |           | →  | CELL UPDATE | The value "periodical cell update" shall be set in IE "Cell update cause".                                                                       |
| 3    |           |    |             | SS transmits no response to the UE and increments counter K.                                                                                     |
| 4    |           |    |             | SS waits for an additional period equal to T302 timer and if K is not greater than N302, then next step is step 2. Else the next step is step 5. |
| 5    |           |    |             | The UE shall enter idle mode state.                                                                                                              |

## Specific Message Contents

## CELL UPDATE (Step 2)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| -SRNC Identity      | Check to see if set to '0000-0000-0001'           |
| -S-RNTI             | Check to see if set to '0000-0000-0000-0000-0001' |
| Cell Update Cause   | Check to see if set to 'Periodic cell updating'   |

## 8.3.1.12.5 Test requirement

After step 1 the UE shall transmit a CELL UPDATE message on the uplink CCCH and set value "periodical cell update" into IE "Cell update cause".

After step 3 and if K is not greater than N302, the UE shall retry to transmit a CELL UPDATE message.

## 8.3.1.13 Cell Update: Reception of Invalid CELL UPDATE CONFIRM Message

## 8.3.1.13.1 Definition

## 8.3.1.13.2 Conformance Requirement

If the UE encounters an invalid CELL UPDATE CONFIRM message while executing a cell update procedure, it shall check the current value of its internal counter V302. If V302 is not greater than N302, the UE shall set contexts pertaining to protocol error, re-transmits a CELL UPDATE message on uplink CCCH, restart T302 timer and increments V302. It shall use the same "Cell Update Cause" as before receiving the invalid downlink message.

## 8.3.1.13.3 Test Purpose

To confirm that the UE retransmits a CELL UPDATE message when it receives an invalid CELL UPDATE CONFIRM message, before the number of retransmissions has reached the maximum allowed value.

### 8.3.1.13.4 Method of Test

#### Initial Condition

System Simulator: 1 cell

UE: CELL\_PCH (state 6-12) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is brought to CELL\_PCH state at the beginning of the test. SS pages the UE by sending a PAGING TYPE 1 message using the U-RNTI identity assigned during RRC connection establishment procedure. The UE shall transmit a CELL\_UPDATE message on the uplink CCCH. Upon receiving such a message, the SS replies with an invalid CELL\_UPDATE\_CONFIRM message on downlink DCCH using UM RLC. The UE shall detect the protocol error and re-transmit a CELL\_UPDATE message up to a maximum of N302 times. SS then transmit a valid CELL\_UPDATE\_CONFIRM message.

#### Expected Sequence

| Step | Direction |    | Message             | Comment                                                                                                                                                                                                                        |
|------|-----------|----|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                     |                                                                                                                                                                                                                                |
| 1    |           | ←  | PAGING TYPE 1       | The UE is in the CELL_PCH state. SS pages for the UE using the allocated connected mode identity (U-RNTI).                                                                                                                     |
| 2    |           | →  | CELL_UPDATE         | Check that the value "paging response" is set in IE "Cell update cause".                                                                                                                                                       |
| 3    |           | ←  | CELL_UPDATE_CONFIRM | See specific message content.                                                                                                                                                                                                  |
| 4    |           | →  | CELL_UPDATE         | Check that the value "paging response" is set in IE "Cell update cause", the value "protocol error" is set in IE "failure cause" and the value "ASN.1 violation and encoding error" is set in IE "Protocol error information". |
| 5    |           | ←  | CELL_UPDATE_CONFIRM | Use the default message found in Annex A.                                                                                                                                                                                      |

#### Specific Message Content

##### CELL\_UPDATE (Step 2)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| –SRNC Identity      | Check to see if set to '0000-0000-0001'           |
| –S-RNTI             | Check to see if set to '0000-0000-0000-0000-0001' |
| Cell Update Cause   | Check to see if set to 'Paging Response'          |

##### CELL\_UPDATE\_CONFIRM (Step 3)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

### CELL UPDATE (Step 4)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element         | Value/remark                                                      |
|-----------------------------|-------------------------------------------------------------------|
| U-RNTI                      | Check to see if set to '0000-0000-0001'                           |
| -SRNC Identity              | Check to see if set to '0000-0000-0000-0000-0001'                 |
| -S-RNTI                     | Check to see if set to 'Paging-Response'                          |
| Cell Update Cause           | Check to see if it is set to 'protocol-error'                     |
| Failure cause               | Check to see if it is set to "ASN.1 violation and encoding error" |
| —Protocol error information |                                                                   |

### PAGING TYPE 1 (Step 1)

Use the same message sub-type titled "TM (Packet in PS)" in default message content of TS 34.108 with following exceptions:

| Information Element          | Value/remark               |
|------------------------------|----------------------------|
| Page record list             |                            |
| -Paging record               |                            |
| -CHOICE Used paging identity | UTRAN-identity             |
| -U-RNTI                      |                            |
| -SRNC Identity               | '0000-0000-0001'           |
| -S-RNTI                      | '0000-0000-0000-0000-0001' |

### 8.3.1.13.5 — Test Requirement

After step 1 the UE shall transmit a CELL UPDATE message on the uplink CCCH, setting "paging response" into IE "Cell update cause".

After step 3 the UE shall transmit a CELL UPDATE message on the uplink CCCH, setting "paging response" into IE "Cell update cause", "protocol-error" into IE "failure cause" and "ASN.1 violation or encoding error" into IE "Protocol error information".

### 8.3.1.14 — Cell Update: Incompatible simultaneous reconfiguration

#### 8.3.1.14.1 — Definition

#### 8.3.1.14.2 — Conformance Requirement

If the UE encounters a CELL UPDATE CONFIRM message that includes "Physical channel information elements" and UE's variable ORDERED\_RECONFIGURATION is set to TRUE because of an ongoing Reconfiguration procedure, it shall check the current value of its internal counter V302. If V302 is not greater than N302, the UE shall set IE "failure cause" to "Incompatible simultaneous reconfiguration", re-transmits a CELL UPDATE message on uplink CCCH, restart T302 timer and increments V302. It shall use the same "Cell Update-Cause" as before receiving the downlink message.

#### 8.3.1.14.3 — Test Purpose

To confirm that the UE retransmits a CELL UPDATE message when it receives a CELL UPDATE CONFIRM message that includes "Physical channel information elements" and UE's variable ORDERED\_RECONFIGURATION is set to TRUE because of an ongoing Reconfiguration procedure, before the number of retransmissions has reached the maximum allowed value.

#### 8.3.1.14.4 Method of Test

##### Initial Condition

System Simulator: 1 cell

UE: CELL\_PCH (state 6-12) as specified in clause 7.4 of TS 34.108.

##### Test Procedure

The UE is brought to CELL\_PCH state at the beginning of the test. SS pages the UE by sending a PAGING TYPE 1 message using the U-RNTI identity assigned during RRC connection establishment procedure. The UE shall transmit a CELL UPDATE message on the uplink CCCH. Upon receiving such a message, the SS replies with a CELL UPDATE CONFIRM message contains IE "Physical channel information elements". Following that, SS immediately transmits another CELL UPDATE CONFIRM message contains IE "Physical channel information elements" before the "activation time" indicated in the previous CELL UPDATE CONFIRM message expires. The UE shall re-transmit a CELL UPDATE message with the same cause as the previous CELL UPDATE message and failure cause as "Incompatible simultaneous reconfiguration". SS then transmits a CELL UPDATE message to end the procedure.

##### Expected Sequence

| Step | Direction |    | Message             | Comment                                                                         |
|------|-----------|----|---------------------|---------------------------------------------------------------------------------|
|      | UE        | SS |                     |                                                                                 |
| 1    |           | ←  | PAGING TYPE 1       |                                                                                 |
| 2    |           | →  | CELL UPDATE         |                                                                                 |
| 3    |           | ←  | CELL UPDATE CONFIRM | SS transmits this message including IE "Physical channel information elements". |
| 4    |           | ←  | CELL UPDATE CONFIRM | Sent before the activation time specified in the message in step 3 has elapsed. |
| 5    |           | →  | CELL UPDATE         |                                                                                 |
| 6    |           | ←  | CELL UPDATE CONFIRM |                                                                                 |

##### Specific Message Content

##### CELL UPDATE (Step 2)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| -SRNC Identity      | Check to see if set to '0000-0000-0001'           |
| -S-RNTI             | Check to see if set to '0000-0000-0000-0000-0001' |
| Cell Update Cause   | Check to see if set to 'Paging Response'          |

##### CELL UPDATE (Step 5)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                                       |
|---------------------|--------------------------------------------------------------------|
| U-RNTI              |                                                                    |
| -SRNC Identity      | Check to see if set to '0000-0000-0001'                            |
| -S-RNTI             | Check to see if set to '0000-0000-0000-0000-0001'                  |
| Cell Update Cause   | Check to see if set to 'Paging Response'                           |
| Failure cause       | Check to see if set to 'Incompatible simultaneous reconfiguration' |

**CELL UPDATE CONFIRM (Step 3)**

Use the same message sub-type found in Annex A, with the following exception:

| Information Element         | Value/remark                        |
|-----------------------------|-------------------------------------|
| Activation Time Info        | Current CFN-[current CFN mod 8 + 8] |
| Maximum allowed UL TX power | 30dBm                               |

**CELL UPDATE CONFIRM (Step 4)**

Use the same message sub-type found in Annex A, with the following exception:

| Information Element         | Value/remark                        |
|-----------------------------|-------------------------------------|
| Activation Time Info        | Current CFN-[current CFN mod 8 + 8] |
| Maximum allowed UL TX power | 25dBm                               |

**PAGING TYPE 1 (Step 1)**

Use the same message sub-type titled "TM (Packet in PS)" in default message content of TS 34.108 with following exceptions:

| Information Element           | Value/remark               |
|-------------------------------|----------------------------|
| Page record list              |                            |
| → Paging record               |                            |
| → CHOICE Used paging identity | UTRAN identity             |
| → U-RNTI                      |                            |
| → SRNC Identity               | '0000-0000-0001'           |
| → S-RNTI                      | '0000-0000-0000-0000-0001' |

**8.3.1.14.5 ——— Test Requirement**

After step 1, UE shall transmit a CELL UPDATE message.

After step 4 the UE shall re-transmit a CELL UPDATE message with failure cause set to "Incompatible simultaneous reconfiguration".

**8.3.1.15 ——— Cell Update: Unrecoverable error in Acknowledged Mode RLC****8.3.1.15.1 ——— Definition****8.3.1.15.2 ——— Conformance Requirement**

In CELL\_FACH, the UE shall ensure that all AM RLC entities (both signalling and u-plane links) are operational. In the event that an unrecoverable error has occurred, the UE shall trigger cell update procedure to report this event. The UE shall send a CELL UPDATE message on the uplink CCCH and set the appropriate AM\_RLC error indicator IE(s) to TRUE. After receiving the CELL UPDATE CONFIRM message, the UE shall reset the affected AM RLC entities and then resume transmission and reception activities.

**Reference**

3GPP TS 25.331 clause 8.3.1

**8.3.1.15.3 ——— Test Purpose**

To confirm that the UE reports the occurrence of an unrecoverable error in a C-plane AM RLC entity by initiating cell update procedure. To confirm that the UE is able to resume normal C-plane data transmission and reception after the completion of cell update procedure.

#### 8.3.1.15.4 Method of Test

##### Initial Condition

System Simulator: 1 cell

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE

##### Test Procedure

The UE is initially in CELL\_DCH state. SS sends a UE CAPABILITY ENQUIRY message on the DCCH using AM mode. The UE shall reply with a UE CAPABILITY INFORMATION message, sent using AM RLC on the DCCH. SS does not acknowledge the AM PDUs carrying this message. The UE shall continue to re-transmit the AM PDU carrying UE CAPABILITY INFORMATION message until the maximum re-transmission count is reached. Thereafter, the UE shall start sending RESET PDUs to request that the AM RLC entity for RRC signalling be re-initialized. SS ignores the requests and wait for a duration equivalent to (MAX\_RST+1) times expiry of Timer\_RST. At this point, the UE shall initiate a cell update procedure by transmitting a CELL UPDATE message on the uplink CCCH. The CELL UPDATE message shall specify the value "TRUE" in IE "AM\_RLC error indicator (RB2 or RB3)" and "RLC unrecoverable error" as the cell update cause. SS replies with CELL UPDATE CONFIRM message with IE "RLC re-establish indicator (RB2 and RB3)" set to TRUE. SS then attempts to perform a local authentication by transmitting a UE CAPABILITY ENQUIRY message using AM RLC on DCCH. The UE shall respond by sending a UE CAPABILITY INFORMATION message on the uplink DCCH, verifying that the AM RLC entity for RRC signalling was successfully reset. SS shall transmit a UE CAPABILITY INFORMATION CONFIRM message to UE to end the test.

##### Expected Sequence

| Step | Direction |    | Message                           | Comment                                                                                                                                                                                    |
|------|-----------|----|-----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                   |                                                                                                                                                                                            |
| 1    |           |    |                                   | The UE is initially in CELL_DCH state.                                                                                                                                                     |
| 2    |           | ←  | UE CAPABILITY ENQUIRY             |                                                                                                                                                                                            |
| 3    |           | →  | UE CAPABILITY INFORMATION         | SS does not acknowledge this AM PDU. The UE shall re-transmit this AM PDU until the maximum number has been reached.                                                                       |
| 4    |           |    |                                   | UE shall start to transmit a RESET PDU. SS does not respond to any RESET PDU frames originated from the UE, and it waits for a period equivalent to (MAX_RST+1) times expiry of Timer_RST. |
| 5    |           | →  | CELL UPDATE                       | UE shall send this message on CCCH. IE "AM_RLC Error Indication (RB2 or RB3)" shall be set to "TRUE"                                                                                       |
| 6    |           | ←  | CELL UPDATE CONFIRM               | IE "RLC re-establish indicator (RB2 and RB3)" set to TRUE.                                                                                                                                 |
| 7    |           | ←  | UE CAPABILITY ENQUIRY             |                                                                                                                                                                                            |
| 8    |           | →  | UE CAPABILITY INFORMATION         | This message shall be transmitted using AM RLC for RRC signalling on the uplink DCCH.                                                                                                      |
| 9    |           | ←  | UE CAPABILITY INFORMATION CONFIRM |                                                                                                                                                                                            |

##### Specific Message Contents

##### UE CAPABILITY ENQUIRY (Step 2 and 7)

Use the same message found in Annex A.

**UE CAPABILITY INFORMATION (Step 3 and 8)**

Only the message type IE is checked for this message.

**CELL UPDATE (Step 5)**

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element                 | Value/remark                                      |
|-------------------------------------|---------------------------------------------------|
| U-RNTI                              |                                                   |
| -SRNC Identity                      | Check to see if set to '0000-0000-0001'           |
| -S-RNTI                             | Check to see if set to '0000-0000-0000-0000-0001' |
| AM_RLC error indicator (RB2 or RB3) | Check to see if set to 'TRUE'                     |
| Cell update cause                   | RLC unrecoverable error                           |

**CELL UPDATE CONFIRM (Step 6)**

Use the same message found in Annex A, with the following exception.

| Information Element                      | Value/remark |
|------------------------------------------|--------------|
| RLC re-establish indicator (RB2 and RB3) | 'TRUE'       |

**UE CAPABILITY INFORMATION CONFIRM (Step 9)**

Use the same message found in Annex A.

**8.3.1.15.5 ——— Test Requirement**

After step 4 the UE shall transmit a CELL UPDATE message on the uplink CCCH to report the occurrence of an unrecoverable error in AM RLC entity for RB2 or RB3 data as well as cell update cause set to "RLC unrecoverable error".

After step 7 the UE shall send a UE CAPABILITY INFORMATION message on the uplink DCCH. This message shall be sent using the AM RLC entity for RRC signalling.

**8.3.1.16 ——— Void****8.3.1.17 ——— Cell Update: Failure (UTRAN initiate an RRC connection release procedure on CCCH)****8.3.1.17.1 ——— Definition****8.3.1.17.2 ——— Conformance requirement**

The UE transmits a CELL UPDATE message to the UTRAN when it needs to update UTRAN with information on the current cell of the UE. If the UE receives a RRC CONNECTION RELEASE message on CCCH, it shall release all its radio resources and enter idle mode.

**Reference**

3GPP TS 25.331 clause 8.3.1

**8.3.1.17.3 ——— Test purpose**

To confirm that the UE moves to idle state upon the reception of RRC CONNECTION RELEASE message on DCCH.

#### 8.3.1.17.4 Method of test

##### Initial Condition

System Simulator: 1 cell

UE: PS-DCCH+DTCH\_FACH (state 6-11)

##### Test Procedure

The UE is initially in CELL\_FACH state. When the UE detects the expiry of periodic cell updating timer T305, the UE transmits a CELL\_UPDATE message to the SS on the uplink CCCH to perform a periodical cell updating procedure. The SS transmits a RRC CONNECTION RELEASE message on downlink CCCH. The UE shall return to idle mode after release of all current signalling flows and radio access bearers. SS verifies that UE is in idle mode state by paging the UE with CN identity, in which case the UE shall attempt to establish a RRC connection.

##### Expected sequence

| Step | Direction |    | Message                | Comment                                                                                                                             |
|------|-----------|----|------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                        |                                                                                                                                     |
| 1    |           | →  | CELL_UPDATE            | The value "periodical-cell update" shall be set in IE "Cell update-cause" and this message shall be sent upon expiry of timer T305. |
| 2    |           | ←  | RRC CONNECTION RELEASE | SS transmits a RRC CONNECTION RELEASE message to the UE.                                                                            |
| 3    |           |    | Void                   |                                                                                                                                     |
| 4    |           |    | Void                   |                                                                                                                                     |
| 5    |           | ←  | PAGING TYPE 1          | Page using TMSI for CS domain or P-TMSI for PS domain depending on CN domain supported by the UE.                                   |
| 6    |           | →  | RRC CONNECTION REQUEST |                                                                                                                                     |

##### Specific Message Contents

##### CELL\_UPDATE (Step 1)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| –SRNC-Identity      | Check to see if set to '0000-0000-0001'           |
| –S-RNTI             | Check to see if set to '0000-0000-0000-0000-0001' |
| Cell Update Cause   | Check to see if set to 'Periodic cell updating'   |

##### RRC CONNECTION RELEASE (Step 2)

Use the same message sub-type found in Annex A.

##### PAGING TYPE 1 (Step 5)

Use the same message type found in Annex A, with the following exception.



| Information Element         | Value/remark                                        |
|-----------------------------|-----------------------------------------------------|
| Paging record list          | Only 1 entry                                        |
| Paging record               |                                                     |
| CHOICE Used paging identity | CN identity                                         |
| → Paging cause              | Terminating Call with one of the supported services |
| → CN domain identity        | Supported Domain (PS Domain or CS Domain)           |
| → CHOICE UE Identity        | IMSI                                                |
| → IMSI                      | Set to the IMSI value stored in the TEST USIM card. |

#### 8.3.1.17.5 ——— Test requirement

In step 1 the UE shall transmit a CELL UPDATE message on the uplink CCCH and set value "periodical cell update" into IE "Cell update cause".

After step 5 the UE transmit a RRC CONNECTION REQUEST message.

#### 8.3.1.18 ——— Cell Update: Radio Link Failure (T314>0, T315=0)

##### 8.3.1.18.1 ——— Definition

##### 8.3.1.18.2 ——— Conformance requirement

When a UE loses the radio connection due to e.g. radio link failure in CELL\_DCH state, UE must release the radio bearer which is associated with T315 if T315 is set to 0. After a successful cell re-selection and subsequent transition to CELL\_FACH state, the UE transmits CELL UPDATE message on the uplink CCCH.

If the UE failed to establish the physical channel(s) indicated in the received CELL UPDATE CONFIRM message and the maximum allowable number of retransmission has not been reached, the UE shall select a suitable UTRA cell and transmit a CELL UPDATE message.

#### Reference

3GPP TS 25.331 clause 8.3.1

##### 8.3.1.18.3 ——— Test purpose

To confirm that the UE shall indicate to the non-access stratum the release of radio access bearer which is associated with T315 and try to find a new cell after detecting that a radio link failure has occurred.

To confirm that the UE performs a cell selection procedure when it fails to configure the physical channel(s) indicated in the CELL UPDATE CONFIRM message.

##### 8.3.1.18.4 ——— Method of test

#### Initial Condition

System Simulator: 2 cells (Cell 1 is active, Cell 2 is inactive).

UE: CS\_DCCH+DTCH\_DCH (state 6-9) or PS\_DCCH+DTCH\_DCH (state 6-10) in cell 1, depending on the CN domain(s) supported by the UE.

## Test Procedure

Table 8.3.1.18

| Parameter              | Unit        | Cell 1 |     | Cell 2 |     |
|------------------------|-------------|--------|-----|--------|-----|
|                        |             | T0     | T1  | T0     | T1  |
| UTRA-RF Channel Number |             | Ch. 1  |     | Ch. 1  |     |
| CPICH-Ec               | dBm/3.84MHz | -60    | OFF | -75    | -60 |

Table 8.3.1.18 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution. Columns marked "T0" denote the initial conditions.

The UE is brought to CELL\_DCH state in a cell 1 after making a successful outgoing call attempt. After the call has been established, SS transmits UTRAN MOBILITY INFORMATION message to UE to change to value of T315 timer. UE shall respond with a UTRAN MOBILITY INFORMATION CONFIRM message. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.1.18. The UE shall detect a radio link failure in cell 1 and indicate to the non-access stratum the release of the radio bearer which is associated with T315. Then it shall attempt to re-select to cell 2. After that, it shall then enter CELL\_FACH state and transmit CELL UPDATE on the uplink CCCH to SS. The SS transmits CELL UPDATE CONFIRM message which includes dedicated physical channel parameters. SS shall not configure according to this message and its downlink transmission power settings according to columns "T0" in table 8.3.1.18. UE shall fail to establish the dedicated channel in cell 2. UE shall re-select to cell 1 and transmit a CELL UPDATE message with IE "Cell update cause" set to "Radio link failure". Then SS responds with a CELL UPDATE CONFIRM message to end the procedure.

## Expected sequence

| Step | Direction |    | Message                            | Comment                                                                                                                                          |
|------|-----------|----|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                    |                                                                                                                                                  |
| 1    | ←         |    | UTRAN MOBILITY INFORMATION         | T315=0                                                                                                                                           |
| 2    | →         |    | UTRAN MOBILITY INFORMATION CONFIRM |                                                                                                                                                  |
| 3    |           |    | Void                               |                                                                                                                                                  |
| 4    |           |    |                                    | SS configures cell 1 and 2 according to column "T1" in table 8.3.1.18. SS starts to listen to the uplink CCCH of cell 2.                         |
| 5    |           |    | Void                               |                                                                                                                                                  |
| 6    |           |    |                                    | The UE detects the radio link failure which is associated with T315. The UE indicates to the non-access stratum the release of the radio bearer. |
| 7    | →         |    | CELL UPDATE                        | The UE shall find a new cell 2 and the value "radio link failure" shall be set in IE "Cell update cause".                                        |
| 8    | ←         |    | CELL UPDATE CONFIRM                | Including dedicated physical channel parameters.                                                                                                 |
| 9    |           |    |                                    | SS does not configure according to the message in step 8. SS configures cell 1 and 2 according to column "T0" in table 8.3.1.18.                 |
| 10   | →         |    | CELL UPDATE                        | UE shall select cell 1 and enter CELL_FACH state to transmit this message                                                                        |
| 11   | ←         |    | CELL UPDATE CONFIRM                |                                                                                                                                                  |

## Specific Message Contents

## UTRAN MOBILITY INFORMATION (Step 1)

The contents of UTRAN MOBILITY INFORMATION message in this test case is identical to those in Annex A with the following exceptions:

| Information Element                                   | Value/remark |
|-------------------------------------------------------|--------------|
| New U-RNTI                                            | Not Present  |
| New C-RNTI                                            | Not Present  |
| UE Timers and constants in connected mode<br>——→ T315 | 0            |

## CELL UPDATE (Step 7)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                     |
|---------------------|--------------------------------------------------|
| U-RNTI              |                                                  |
| ——→ SRNC Identity   | Check to see if set to value assigned in cell 2. |
| —S-RNTI             | Check to see if set to value assigned in cell 2. |
| Cell Update Cause   | Check to see if set to 'radio link failure'      |

## CELL UPDATE CONFIRM (Step 8)

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element        | Value/remark                                                                    |
|----------------------------|---------------------------------------------------------------------------------|
| CHOICE channel requirement | Same as the set defined in the RADIO BEARER SETUP message in initial condition. |

## CELL UPDATE (Step 10)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                     |
|---------------------|--------------------------------------------------|
| U-RNTI              |                                                  |
| ——→ SRNC Identity   | Check to see if set to value assigned in cell 1. |
| —S-RNTI             | Check to see if set to value assigned in cell 1. |
| Cell Update Cause   | Check to see if set to 'radio link failure'      |

## 8.3.1.18.5 ————— Test requirement

After step 1, the UE shall transmit UTRAN MOBILITY INFORMATION CONFIRM message.

After step 6, the UE shall detect the presence of cell 2, perform cell re-selection and transmit a CELL UPDATE message.

After step 9, the UE shall transmit a CELL UPDATE message with IE "Cell update cause" set to "Radio link failure".

~~8.3.1.19 Void~~~~8.3.1.20 Cell Update: Reception of CELL UPDATE CONFIRM Message that causes invalid configuration~~~~8.3.1.20.1 Definition~~~~8.3.1.20.2 Conformance Requirement~~

If the UE encounters a CELL UPDATE CONFIRM message that set the variable INVALID\_CONFIGURATION to TRUE while executing a cell update procedure, it shall check the current value of its internal counter V302. If V302 is not greater than N302, the UE shall set IE "failure cause" to "invalid configuration", re-transmit a CELL UPDATE message on uplink CCCH, restart T302 timer and increment V302. It shall use the same "Cell Update Cause" as before receiving the erroneous downlink message.

~~8.3.1.20.3 Test Purpose~~

To confirm that the UE retransmits a CELL UPDATE message when it receives a CELL UPDATE CONFIRM message that will trigger an invalid configuration in the UE, if the number of retransmissions has not reached the maximum allowed value.

~~8.3.1.20.4 Method of Test~~~~Initial Condition~~

System Simulator: 1 cell

UE: CELL\_PCH (state 6-12) as specified in clause 7.4 of TS 34.108.

~~Test Procedure~~

The UE is brought to CELL\_PCH state at the beginning of the test. SS pages the UE by sending a PAGING TYPE 1 message using the U-RNTI identity assigned during RRC connection establishment procedure. The UE shall transmit a CELL UPDATE message on the uplink CCCH. Upon receiving such a message, the SS replies with a CELL UPDATE CONFIRM message which is set to give an invalid configuration. The UE shall re-transmit CELL UPDATE message. SS responds with a valid CELL UPDATE CONFIRM message to end the procedure.

~~Expected Sequence~~

| Step | Direction |    | Message             | Comment                                                                                                      |
|------|-----------|----|---------------------|--------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                     |                                                                                                              |
| 1    | ←         |    | PAGING TYPE 1       | The UE is in the CELL_PCH state. SS pages for the UE using the allocated connected mode identity (U-RNTI).   |
| 2    | →         |    | CELL UPDATE         | If CELL UPDATE message is received, check that the value "paging response" is set in IE "Cell update cause". |
| 3    | ←         |    | CELL UPDATE CONFIRM | SS transmits an invalid message.                                                                             |
| 4    | →         |    | CELL UPDATE         | IE "failure cause" is set to "invalid configuration"                                                         |
| 5    | ←         |    | CELL UPDATE CONFIRM |                                                                                                              |

## Specific Message Content

## CELL UPDATE (Step 2)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| -SRNC Identity      | Check to see if set to '0000-0000-0001'           |
| -S-RNTI             | Check to see if set to '0000-0000-0000-0000-0001' |
| Cell Update Cause   | Check to see if set to 'Paging Response'          |

## CELL UPDATE CONFIRM (Step 3)

Use the same message sub-type found in Annex A, with the following exception:

| Information Element | Value/remark |
|---------------------|--------------|
| RRC State Indicator | CELL_DCH     |
| Uplink DPCH info    | Not Present  |

## CELL UPDATE (Step 4)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                         |
|---------------------|------------------------------------------------------|
| U-RNTI              |                                                      |
| -SRNC Identity      | Check to see if set to '0000-0000-0001'              |
| -S-RNTI             | Check to see if set to '0000-0000-0000-0000-0001'    |
| Cell Update Cause   | Check to see if set to 'Paging Response'             |
| Failure cause       | Check to see if it is set to 'invalid configuration' |

## PAGING TYPE 1 (Step 1)

Use the same message sub-type titled "TM (Packet in PS)" in default message content of TS 34.108 with following exceptions:

| Information Element          | Value/remark               |
|------------------------------|----------------------------|
| Page record list             |                            |
| -Paging record               |                            |
| -CHOICE Used paging identity | UTRAN identity             |
| -U-RNTI                      |                            |
| -SRNC Identity               | '0000-0000-0001'           |
| -S-RNTI                      | '0000-0000-0000-0000-0001' |

## 8.3.1.20.5 Test Requirement

After step 1 the UE shall transmit a CELL UPDATE message with IE "cell update cause" set to "paging response".

After step 3 the UE shall transmit a CELL UPDATE message with IE "cell update cause" set to "paging response" and IE "failure cause" set to "invalid configuration".

## 8.3.1.21 Cell Update: Cell reselection to cell of another PLMN belonging to the equivalent PLMN list

## 8.3.1.21.1 Definition

### 8.3.1.21.2 ~~Conformance requirement~~

~~A UE shall initiate the cell update procedure in the following cases:~~

~~1. Cell reselection:~~

- ~~— if none of the criteria for performing cell update with the causes specified above in the current clause is met; and~~
- ~~— if the UE is in CELL\_FACH or CELL\_PCH state; and~~
- ~~— if the UE performs cell re-selection or the variable C\_RNTI is empty:~~
  - ~~— perform cell update using the cause "cell reselection".~~

~~2. A "suitable cell" is a cell on which the UE may camp on to obtain normal service. Such a cell shall fulfil all the following requirements:~~

- ~~— The cell is part of the selected PLMN or, of a PLMN considered as equivalent by the UE according to the information provided by the NAS.~~
- ~~— The cell is not barred, see clause 5.3.4.1.~~
- ~~— The cell is not part of the list of "forbidden LAs for roaming" [9]~~
- ~~— The cell selection criteria are fulfilled, see clause 5.2.3.1.2.~~

~~3. The Mobile Equipment shall store a list of "equivalent PLMNs". This list is replaced or deleted at the end of each location update procedure, routing area update procedure and GPRS attach procedure. The stored list consists of a list of equivalent PLMNs as downloaded by the network plus the PLMN code of the network that downloaded the list. The stored list shall not be deleted when the MS is switched off. The stored list shall be deleted if the SIM is removed. The maximum number of possible entries in the stored list is six.~~

### Reference

~~3GPP TS 25.331 clause 8.3.1.2.~~

~~3GPP TS 25.304 clause 4.3.~~

~~3GPP TS 24.008 clause 4.4.1.~~

### 8.3.1.21.3 ~~Test purpose~~

- ~~1 To confirm that the UE executes a cell update procedure after a successful reselection of another UTRA cell with a PLMN identity different from the original cell but with a PLMN identity that is part of the equivalent PLMN list in the UE. To confirm that the UE sends the correct uplink response message when executing cell update procedure due to cell reselection.~~

~~NOTE: Verifies conformance requirement 1, 2 and 3.~~

- ~~2 To confirm that the UE refrains from executing a cell update procedure to a better UTRA cell with another PLMN identity when that PLMN identity is not part of the equivalent PLMN list in the UE.~~

~~NOTE: Verifies conformance requirement 1, 2 and 3.~~

~~NOTE: Test case in 8.3.1.1 is a test where the UE reselects to a cell with the same PLMN identity as the registered PLMN.~~

### 8.3.1.21.4 ~~Method of test~~

### Initial Condition

System Simulator: 3 cells – Cell 1 is active, with the downlink transmission power shown in column marked "T0" in table 8.3.1.1-1, while cell 2 and cell 3 is inactive.

UE: CS-CELL\_FACH\_Initial (state 6-2) or PS-CELL\_FACH\_Initial (state 6-4) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

UE: Shall have stored equivalent PLMN list containing PLMN-1 and PLMN-2. The equivalent PLMN list stored in the UE shall not contain PLMN-3.

### Test Procedure

The SS activates Cell 1-3 according table 8.3.1.21-1.

**Table 8.3.1.21-1**

| Parameter              | Unit | Cell 1 |     |     | Cell 2                 |     |     | Cell 3                 |                        |     |
|------------------------|------|--------|-----|-----|------------------------|-----|-----|------------------------|------------------------|-----|
|                        |      | T0     | T1  | T2  | T0                     | T1  | T2  | T0                     | T1                     | T2  |
| UTRA RF Channel Number |      | Ch. 1  |     |     | Ch. 1                  |     |     | Ch. 1                  |                        |     |
| PLMN identity          |      | PLMN-1 |     |     | PLMN-2                 |     |     | PLMN-3                 |                        |     |
| CPICH RSCP             | dBm  | -73    | -79 | -79 | Cell 2 is switched off | -73 | -79 | Cell 3 is switched off | Cell 3 is switched off | -73 |

Table 8.3.1.21-1 illustrates the downlink power to be applied for the 3 cells at various time instants of the test execution. Columns marked "T0" denote the initial conditions, while columns marked "T1" and "T2" are to be applied subsequently.

- At T0, the SS activates Cell 1.
- At T1, the SS activates Cell 2, and monitors Cell 2 for received messages from UE.
- UE re-selects to Cell 2, and sends a CELL UPDATE
- At T2, the SS activates Cell 3, and monitors Cell 3 for received messages from UE.

### Expected sequence

| Step | Direction |    | Message                            | Comment                                                                              |
|------|-----------|----|------------------------------------|--------------------------------------------------------------------------------------|
|      | UE        | SS |                                    |                                                                                      |
| 1    |           |    |                                    | At T0: UE is camped on Cell 1 and registered to PLMN1                                |
| 2    |           | →  | CELL UPDATE                        | At T1: Sent in Cell 2<br>The value "cell reselection" set in IE "Cell update cause". |
| 3    |           | ←  | CELL UPDATE CONFIRM                |                                                                                      |
| 4    |           | →  | UTRAN MOBILITY INFORMATION CONFIRM |                                                                                      |
| 5    |           |    |                                    | At T2: No message sent by UE                                                         |

### Specific Message Contents

#### CELL UPDATE CONFIRM (Step 4)

Use the same message sub-type titled "CELL UPDATE CONFIRM message" in Annex A with following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| - New C-RNTI        | Present      |
| - URA identity      | Not present  |

#### 8.3.1.21.5 Test requirement

The UE shall send a CELL UPDATE at T1 but refrain from sending a cell update (or any other message) after T2.

### ~~8.3.1.22 Cell update: Restricted cell reselection to a cell belonging to forbidden LA list (CELL\_FACH)~~

#### ~~8.3.1.22.1 Definition~~

#### ~~8.3.1.22.2 Conformance requirement~~

##### ~~1. Cell reselection:~~

- ~~— if none of the criteria for performing cell update with the causes specified above in the current clause is met; and~~
- ~~— if the UE is in CELL\_FACH or CELL\_PCH state; and~~
- ~~— if the UE performs cell re-selection or the variable C\_RNTI is empty:~~
  - ~~— perform cell update using the cause "cell reselection".~~

##### ~~2. A "suitable cell" is a cell on which the UE may camp on to obtain normal service. Such a cell shall fulfil all the following requirements.~~

- ~~— The cell is part of the selected PLMN or, of a PLMN considered as equivalent by the UE according to the information provided by the NAS.~~
- ~~— The cell is not barred, see clause 5.3.4.1.~~
- ~~— The cell is not part of the list of "forbidden LAs for roaming" [9]~~
- ~~— The cell selection criteria are fulfilled, see clause 5.2.3.1.2.~~

##### ~~3. The Mobile Equipment shall contain a list of "forbidden location areas for roaming", as well as a list of "forbidden location areas for regional provision of service". These lists shall be erased when the MS is switched off or when the SIM is removed, and periodically (with period in the range 12 to 24 hours). The location area identification received on the BCCH that triggered the location updating request shall be added to the suitable list whenever a location update reject message is received with the cause "Roaming not allowed in this location area" or with the cause "Location Area not allowed". The lists shall accommodate each 10 or more location area identifications. When the list is full and a new entry has to be inserted, the oldest entry shall be deleted.~~

#### Reference

3GPP TS 25.331 clause 8.3.1.2.

3GPP TS 25.304 clause 4.3.

3GPP TS 24.008 clause 4.4.1.

#### ~~8.3.1.22.3 Test purpose~~

To confirm that the UE executes a cell update procedure after a successful reselection of another UTRA cell with a LA identity that is not part of the list of LAs stored in the UE as "forbidden location areas for roaming". To confirm that if the UE get a release message and is moved to idle mode, performs a location registration where the LA list is updated and the UE again enters connected mode, that the UE refrains from selecting that same UTRA cell if that is part of the forbidden LA list.

NOTE: — Test case in 8.3.1.1 is a test where the UE reselects to a cell with the same LA identity as the LA identity in the original cell.

NOTE: — Test case in 8.1.3.2 is a test where normal RRC connection release on DCCH in CELL\_FACH state is tested.

NOTE: — Test case in 8.1.9 is a test where normal RRC connection request and location registration is tested.



#### 8.3.1.22.4 Method of test

##### Initial Condition

System Simulator: 2 cells – Cell 1 is active, with the downlink transmission power shown in column marked "T0" in table 8.3.2.1-1, while cell 2 is inactive.

UE: CS-CELL\_FACH\_Initial (state 6-2) or PS-CELL\_FACH\_Initial (state 6-4) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

UE: Shall have an empty list of LAs stored that are "forbidden location areas for roaming". The UE shall be registered to CS through cell 1 with LA-ID 1.

##### Test Procedure

**Table 8.3.1.22-1**

| Parameter              | Unit | Cell 1  |     | Cell 2                 |     |
|------------------------|------|---------|-----|------------------------|-----|
|                        |      | T0      | T1  | T0                     | T1  |
| UTRA-RF Channel Number |      | Ch. 1   |     | Ch. 1                  |     |
| LA identity            |      | LA-ID 1 |     | LA-ID 2                |     |
| CPICH RSCP             | dBm  | -73     | -79 | Cell 2 is switched-off | -73 |

Table 8.3.1.22-1 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution. Columns marked "T0" denote the initial conditions, while columns marked "T1" and "T2" are to be applied subsequently.

- At T1, verify that the UE reselects to cell 2 and sends a cell update.
- SS sends a RRC connection release message to the UE from cell2.
- The UE performs a location registration to cell 2 (RRC Connection request, setup, initial direct transfer, DL direct transfer (with LA forbidden for roaming), RRC connection release.)
- The UE reselects cell 1 again although this is not the best cell.
- The UE performs a location registration to cell 1 (RRC Connection request, setup, initial direct transfer, DL direct transfer (without LA forbidden for roaming)).
- Keep the UE in RRC Connected mode in CELL\_FACH state.
- Make sure the UE refrains from reselecting cell2 and sends a cell update (or any other message) in cell2.

## Expected sequence

| Step | Direction |    | Message                         | Comment                                                                                                    |
|------|-----------|----|---------------------------------|------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                            |
| 1    |           | →  | CELL UPDATE                     | At T1: Sent in Cell 2<br>The value "cell reselection" set in IE "Cell update cause".                       |
| 2    |           | ←  | RRC CONNECTION RELEASE          | The value "Normal event" is set in IE "Release cause"                                                      |
| 3    |           | →  | RRC CONNECTION RELEASE COMPLETE |                                                                                                            |
| 4    |           | →  | RRC CONNECTION REQUEST          | The value "Registration" is set in IE "Establishment cause"                                                |
| 5    |           | ←  | RRC CONNECTION SETUP            |                                                                                                            |
| 6    |           | →  | RRC CONNECTION SETUP COMPLETE   |                                                                                                            |
| 7    |           | →  | INITIAL DIRECT TRANSFER         | Includes MM message LOCATION UPDATING REQUEST                                                              |
| 8    |           | ←  | DOWNLINK DIRECT TRANSFER        | Includes MM message LOCATION UPDATING REJECT with reject cause "Roaming not allowed in this location area" |
| 9    |           | ←  | RRC CONNECTION RELEASE          | The value "Normal event" is set in IE "Release cause"                                                      |
| 10   |           | →  | RRC CONNECTION RELEASE COMPLETE | The value "Normal event" is set in IE "Release cause"                                                      |
| 11   |           | →  | RRC CONNECTION REQUEST          | Sent in Cell 1.<br>The value "Registration" is set in IE "Establishment cause"                             |
| 12   |           | ←  | RRC CONNECTION SETUP            |                                                                                                            |
| 13   |           | →  | RRC CONNECTION SETUP COMPLETE   |                                                                                                            |
| 14   |           | →  | INITIAL DIRECT TRANSFER         | Includes MM message LOCATION UPDATING REQUEST                                                              |
| 15   |           | ←  | DOWNLINK DIRECT TRANSFER        | Includes MM message LOCATION UPDATING ACCEPT                                                               |

## Specific Message Contents

## FFS

## 8.3.1.22.5 Test requirement

The UE shall send a CELL UPDATE in Cell 2 at T1, attempt Location registration in Cell 2, but, since the location registration is rejected in Cell 2, not send any more messages in Cell 2

## 8.3.1.23 Cell Update: HCS cell reselection in CELL\_FACH

## 8.3.1.23.1 Definition

## 8.3.1.23.2 Conformance requirement

This procedure is used to update UTRAN with the current cell of the UE after it has performed a cell reselection in CELL\_FACH state with HCS parameters applied.

## Reference

3GPP TS 25.331 clause 8.3.1.

3GPP TS 25.304 clause 5.2.6.1.4.

3GPP TS 25.304 clause 5.4.3.

### 8.3.1.23.3 ~~Test purpose~~

To confirm that the UE can read HCS related SIB information and act upon all HCS parameters. To confirm that the UE executes a cell update procedure after the successful reselection of another UTRA cell. To confirm that the UE sends the correct uplink response message when executing cell update procedure due to cell reselection.

### 8.3.1.23.4 ~~Method of test~~

#### Initial Condition

System Simulator: 3 cells—Cell 1 is active with downlink transmission power shown in Column To in Table 8.3.1.21-1. Cell 2 and 3 are switched off.

UE: CS-CELL\_FACH\_Initial (state 6-2) or PS-CELL\_FACH\_Initial (state 6-4) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE

#### Specific Message Content

For system information blocks 3, 4, 11 & 12 for Cell 1 (gives IE's which are different from defaults given in 34.108 sec 6.1) to be transmitted before idle update preamble.

#### Contents of System Information Block type 3 (FDD)

| Information Element                                        | Value/remark                        |
|------------------------------------------------------------|-------------------------------------|
| <del>→SIB4 indicator</del>                                 | TRUE                                |
| <del>→Cell identity</del>                                  | 0000-0000-0000-0000-0000-0000-0001B |
| <del>→Cell selection and re-selection info</del>           |                                     |
| <del>→Mapping info</del>                                   | Not Present                         |
| <del>→Cell selection_and_reselection_quality_measure</del> | CPICH RSCP                          |
| <del>→CHOICE mode</del>                                    | FDD                                 |
| <del>→Sintrasearch</del>                                   | 16 dB                               |
| <del>→Sintersearch</del>                                   | 16 dB                               |
| <del>→SsearchHCS</del>                                     | 53 dB                               |
| <del>→RAT List</del>                                       | This parameter is configurable      |
| <del>→RAT identifier</del>                                 | GSM                                 |
| <del>→Ssearch,RAT</del>                                    | -32 dB                              |
| <del>→SHCS,RAT</del>                                       | Not Present                         |
| <del>→Slimit,SearchRAT</del>                               | Not Present                         |
| <del>→Qqualmin</del>                                       | -20 dB                              |
| <del>→Qrxlevmin</del>                                      | -115 dBm                            |
| <del>→Qhyst1s</del>                                        | 10 (gives actual value of 20 dB)    |
| <del>→Qhyst2s</del>                                        | 0 dB                                |
| <del>→Treselections</del>                                  | 0 seconds                           |
| <del>→HCS Serving cell information</del>                   |                                     |
| <del>→HCS Priority</del>                                   | -6                                  |
| <del>→Q-HCS</del>                                          | 39 (results in actual value of -76) |
| <del>→TerMax</del>                                         | Not Present                         |

## Contents of System Information Block type 4 (FDD)

| Information Element                              | Value/remark                        |
|--------------------------------------------------|-------------------------------------|
| → Cell identity                                  | 0000 0000 0000 0000 0000 0000 0001B |
| → Cell selection and re-selection info           |                                     |
| → Mapping Info                                   | Not present                         |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                          |
| → CHOICE mode                                    | FDD                                 |
| → Sintrasearch                                   | 16 dB                               |
| → Sintersearch                                   | 16 dB                               |
| → SsearchHCS                                     | 53 dB                               |
| → RAT List                                       | This parameter is configurable      |
| → RAT identifier                                 | GSM                                 |
| → Ssearch,RAT                                    | -32 dB                              |
| → SHCS,RAT                                       | Not Present                         |
| → Slimit,SearchRAT                               | Not Present                         |
| → Qqualmin                                       | -20 dB                              |
| → Qrxlevmin                                      | -115 dBm                            |
| → Qhyst1s                                        | 10 (gives actual value of 20 dB)    |
| → Qhyst2s                                        | 0 dB                                |
| → Treselections                                  | 0 seconds                           |
| → HCS Serving cell information                   |                                     |
| → HCS Priority                                   | -6                                  |
| → Q-HCS                                          | 39 (results in actual value of -76) |
| → TcrMax                                         | Not Present                         |

## Contents of System Information Block type 11 (FDD) (Cell 1)

| Information Element                              | Value/remark                                                                |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Measurement control system information         | used                                                                        |
| → Use of HCS                                     | CPICH RSCP                                                                  |
| → Cell_selection_and_reselection_quality_measure |                                                                             |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.2 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20 dB                                                                      |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.3 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20dB                                                                       |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## Contents of System Information Block type 12 in connected mode (FDD) (Cell 1)

| Information Element                      | Value/remark |
|------------------------------------------|--------------|
| → Measurement control system information |              |

|                                                  |                                                                             |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Use of HCS                                     | used                                                                        |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                                                                  |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.2 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1 <sub>s,n</sub>                        | -20 dB                                                                      |
| → Qoffset2 <sub>s,n</sub>                        | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.3 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1 <sub>s,n</sub>                        | -20 dB                                                                      |
| → Qoffset2 <sub>s,n</sub>                        | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | 39 (results in actual value of -76)                                         |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## Test Procedure

Table 8.3.1.21-1

| Parameter              | Unit | Cell 1 |     |     | Cell 2 |     |     | Cell 3 |     |     |
|------------------------|------|--------|-----|-----|--------|-----|-----|--------|-----|-----|
|                        |      | T0     | T1  | T2  | T0     | T1  | T2  | T0     | T1  | T2  |
| UTRA RF Channel Number |      | Ch. 1  |     |     | Ch. 1  |     |     | Ch. 1  |     |     |
| CPICH RSCP             | dBm  | -61    | -61 | -61 | -80    | -80 | -67 | -80    | -73 | -73 |
| H* (After PenaltyTime) |      | 15     | 15  | 15  | -5     | -5  | 9   | -5     | 3   | 3   |
| R* (After PenaltyTime) |      | -41    | -41 | -41 | -60    | -60 | -47 | -60    | -53 | -53 |

\* this parameter is calculated internally in the UE and is only shown for clarification of the test procedure.

The UE is in the CELL\_FACH state, camping onto cell 1. SS configures Cell 2 and 3 with power levels given in column "T0" and starts to broadcast BCCH on the primary CCCH in cell 2 & 3. UE shall remain camped on the Cell 1 even after expiry of penalty time i.e. 40 seconds. SS sets downlink transmission power settings according to columns "T1" in table 8.3.1.21-1. The UE shall find cell 3 to be more suitable for service and hence perform a cell reselection to cell 3 after at least 40 Seconds (Penalty Time) after the power levels have been changed. After the completion of cell reselection, the UE shall transmit a CELL\_UPDATE message to the SS on the uplink CCCH of cell 3 and set IE "Cell update-cause" to "Cell Reselection". After the SS receives this message, it transmits a CELL\_UPDATE\_CONFIRM message, which includes the IE "RRC State Indicator" set to "CELL\_FACH", to the UE on the downlink DCCH. SS verifies that the UE does not send any response to this message. UE shall stay in CELL\_FACH state. SS then sets downlink transmission power settings according to columns "T2" in table 8.3.1.21-1. The UE shall find cell 2 to be more suitable for service and hence perform a cell reselection to cell 2 after at least 40 Seconds (Penalty Time) after the power levels have been changed. After the completion of cell reselection, the UE shall transmit a CELL\_UPDATE message to the SS on the uplink CCCH of cell 2 and set IE "Cell update-cause" to "Cell Reselection". After the SS receives this message, it transmits a CELL\_UPDATE\_CONFIRM message, which includes the IE "RRC State Indicator" set to "CELL\_FACH", to the UE on the downlink DCCH. SS verifies that the UE does not send any response to this message. UE shall stay in CELL\_FACH state.

## Expected sequence

| Step | Direction |    | Message             | Comment                                                                                                                                                                                                                                                                                                                                                                                                         |
|------|-----------|----|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                     |                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 1    |           |    |                     | The UE is in the CELL_FACH state in cell 1                                                                                                                                                                                                                                                                                                                                                                      |
| 2    |           | ←  | BCCH                | SS applies the downlink transmission power settings, according to the values in columns "T0" of table 8.3.1.1-1. The SS starts to broadcast BCCH on the primary CCPCCH in cell 2 and Cell 3. The UE shall find still find Cell 1 best for service even after penalty time of 40 seconds, and shall remain in Cell 1 in CELL_FACH State                                                                          |
| 3    |           |    |                     | SS changes the power levels as per column 'T1' in the table 8.3.1.21-1. For the time equal to Penalty time 40 Seconds, after the change in power levels, the UE shall still find Cell 1 as best for service and remain in cell 1. After Penalty time of 40 Seconds, UE shall find Cell 3 better for service and perform a reselection. SS waits for the maximum duration required for the UE to camp to cell 3. |
| 4    |           | →  | CELL UPDATE         | Value "cell reselection" shall be indicated in IE "Cell update cause" Received in Cell 3                                                                                                                                                                                                                                                                                                                        |
| 5    |           | ←  | CELL UPDATE CONFIRM | IE "RRC State Indicator" is set to "CELL_FACH".                                                                                                                                                                                                                                                                                                                                                                 |
| 6    |           |    |                     | SS checks the uplink PRACH channel to verify that no response is sent by UE.                                                                                                                                                                                                                                                                                                                                    |
| 7    |           |    |                     | SS changes the power levels as per column 'T2' in the table 8.3.1.21-1. For the time equal to Penalty time 40 Seconds, after the change in power levels, the UE shall still find Cell 3 as best for service and remain in cell 3. After Penalty time of 40 Seconds, UE shall find Cell 2 better for service and perform a reselection. SS waits for the maximum duration required for the UE to camp to cell 2. |
| 8    |           | →  | CELL UPDATE         | Received in Cell 2                                                                                                                                                                                                                                                                                                                                                                                              |
| 9    |           | ←  | CELL UPDATE CONFIRM | IE "RRC State Indicator" is set to "CELL_FACH".                                                                                                                                                                                                                                                                                                                                                                 |
| 10   |           |    |                     | SS checks the uplink PRACH channel to verify that no response is sent by UE.                                                                                                                                                                                                                                                                                                                                    |



## Specific Message Contents

## Contents of System Information Block type 3 (FDD) (Cell 2 and 3)

| Information Element                              | Value/remark                        |
|--------------------------------------------------|-------------------------------------|
| → SIB4 indicator                                 | TRUE                                |
| → Cell identity                                  | 0000 0000 0000 0000 0000 0000 0001B |
| → Cell selection and re-selection info           |                                     |
| → Mapping info                                   | Not Present                         |
| → Cell selection_and_reselection_quality_measure | CPICH RSCP                          |
| → CHOICE mode                                    | FDD                                 |
| → Sintrasearch                                   | 16 dB                               |
| → Sintersearch                                   | 16 dB                               |
| → SsearchHCS                                     | 53 dB                               |
| → RAT List                                       | This parameter is configurable      |
| → RAT identifier                                 | GSM                                 |
| → Ssearch,RAT                                    | -32 dB                              |
| → SHCS,RAT                                       | Not Present                         |
| → Slimit,SearchRAT                               | Not Present                         |
| → Qqualmin                                       | -20 dB                              |
| → Qrxlevmin                                      | -115 dBm                            |
| → Qhyst1s                                        | 10 (gives actual value of 20 dB)    |
| → Qhyst2s                                        | 0 dB                                |
| → Treselections                                  | 0 seconds                           |
| → HCS Serving cell information                   |                                     |
| → HCS Priority                                   | -7                                  |
| → Q-HCS                                          | 39 (results in actual value of -76) |
| → TerMax                                         | Not Present                         |

## Contents of System Information Block type 4 (FDD) (Cell 2 and 3)

| Information Element                              | Value/remark                        |
|--------------------------------------------------|-------------------------------------|
| → Cell identity                                  | 0000 0000 0000 0000 0000 0000 0001B |
| → Cell selection and re-selection info           |                                     |
| → Mapping Info                                   | Not present                         |
| → Cell selection_and_reselection_quality_measure | CPICH RSCP                          |
| → CHOICE mode                                    | FDD                                 |
| → Sintrasearch                                   | 16 dB                               |
| → Sintersearch                                   | 16 dB                               |
| → SsearchHCS                                     | 53 dB                               |
| → RAT List                                       | This parameter is configurable      |
| → RAT identifier                                 | GSM                                 |
| → Ssearch,RAT                                    | -32 dB                              |
| → SHCS,RAT                                       | Not Present                         |
| → Slimit,SearchRAT                               | Not Present                         |
| → Qqualmin                                       | -20 dB                              |
| → Qrxlevmin                                      | -115 dBm                            |
| → Qhyst1s                                        | 10 (gives actual value of 20 dB)    |
| → Qhyst2s                                        | 0 dB                                |
| → Treselections                                  | 0 seconds                           |
| → HCS Serving cell information                   |                                     |
| → HCS Priority                                   | -7                                  |
| → Q-HCS                                          | 39 (results in actual value of -76) |
| → TerMax                                         | Not Present                         |

## Contents of System Information Block type 11 (FDD) (Cell 2)

| Information Element                              | Value/remark                                                                |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Measurement control system information         |                                                                             |
| → Use of HCS                                     | used                                                                        |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                                                                  |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.3 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20dB                                                                       |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | -20dB                                                                       |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.1 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20 dB                                                                      |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -6                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## Contents of System Information Block type 12 in connected mode (FDD) (Cell 2)

| Information Element                      | Value/remark |
|------------------------------------------|--------------|
| → Measurement control system information |              |

|                                                  |                                                                             |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Use of HCS                                     | used                                                                        |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                                                                  |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.3 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1 <sub>s,n</sub>                        | -20 dB                                                                      |
| → Qoffset2 <sub>s,n</sub>                        | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.1 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1 <sub>s,n</sub>                        | -20 dB                                                                      |
| → Qoffset2 <sub>s,n</sub>                        | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -6                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## Contents of System Information Block type 11 (FDD) (Cell 3)

| Information Element                              | Value/remark                                                                |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Measurement control system information         |                                                                             |
| → Use of HCS                                     | used                                                                        |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                                                                  |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.1 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20 dB                                                                      |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -6                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.2 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20 dB                                                                      |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## Contents of System Information Block type 12 in connected mode (FDD) (Cell 3)

| Information Element                      | Value/remark |
|------------------------------------------|--------------|
| → Measurement control system information |              |

|                                                  |                                                                             |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Use of HCS                                     | used                                                                        |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                                                                  |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.1 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1 <sub>s,n</sub>                        | -20 dB                                                                      |
| → Qoffset2 <sub>s,n</sub>                        | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -6                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.2 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1 <sub>s,n</sub>                        | -20 dB                                                                      |
| → Qoffset2 <sub>s,n</sub>                        | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## CELL UPDATE

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element                                      | Value/remark                                                                                             |
|----------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| U-RNTI<br>-SRNC Identity<br>-S-RNTI<br>Cell Update Cause | Check to see if set to '0000-0000-0001'<br>In step 4 and 8<br>Check to see if set to 'Cell Re-selection' |

### CELL UPDATE CONFIRM (Step 5 and 9)

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| RRC State Indicator | CELL_FACH    |

### 8.3.1.23.5 Test requirement

After step 3 the UE shall reselect to cell 3 and then it shall transmit a CELL UPDATE message which, sets the value "cell reselection" in IE "Cell update cause".

After step 5 the UE shall not transmit any uplink message in response to the CELL UPDATE CONFIRMATION message received in step 4.

After step 7 the UE shall reselect to cell 2 and then it shall transmit a CELL UPDATE message which, sets the value "cell reselection" in IE "Cell update cause".

After step 9 the UE shall not transmit any uplink message in response to the CELL UPDATE CONFIRMATION message received in step 8.

### 8.3.1.24 Cell Update: HCS cell reselection in CELL\_PCH

#### 8.3.1.24.1 Definition

#### 8.3.1.24.2 Conformance requirement

This procedure is used to update UTRAN with the current cell of the UE after it has performed a cell reselection in CELL\_PCH state with HCS parameters applied.

#### Reference

3GPP TS 25.331 clause 8.3.1.

3GPP TS 25.304 clause 5.2.6.1.4.

3GPP TS 25.304 clause 5.4.3.

#### 8.3.1.24.3 Test purpose

To confirm that the UE can read HCS related SIB information and act upon all HCS parameters. To confirm that the UE executes a cell update procedure after the successful reselection of another UTRA cell. To confirm that the UE sends the correct uplink response message when executing cell update procedure due to cell reselection.

#### 8.3.1.24.4 Method of test

#### Initial Condition

System Simulator: 3 cells—Cell 1 is active with downlink transmission power shown in Column To in table 8.3.1.21-1. Cell 2 and 3 are switched off.

UE: CELL\_PCH (state 6-12) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

### Specific Message Content

For system information blocks 3, 4, 11 & 12 for Cell 1 (gives IE's which are different from defaults given in 34.108 sec 6.1) to be transmitted before idle update preamble.

### Contents of System Information Block type 3 (FDD)

| Information Element                              | Value/remark                        |
|--------------------------------------------------|-------------------------------------|
| → SIB4 indicator                                 | TRUE                                |
| → Cell identity                                  | 0000 0000 0000 0000 0000 0000 0001B |
| → Cell selection and re-selection info           |                                     |
| → Mapping info                                   | Not Present                         |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                          |
| → CHOICE mode                                    | FDD                                 |
| → Sintrasearch                                   | 16 dB                               |
| → Sintersearch                                   | 16 dB                               |
| → SsearchHCS                                     | 53 dB                               |
| → RAT List                                       | This parameter is configurable      |
| → RAT identifier                                 | GSM                                 |
| → Ssearch,RAT                                    | -32 dB                              |
| → SHCS,RAT                                       | Not Present                         |
| → Slimit,SearchRAT                               | Not Present                         |
| → Qqualmin                                       | -20 dB                              |
| → Qrxlevmin                                      | -115 dBm                            |
| → Qhyst1s                                        | 10 (gives actual value of 20 dB)    |
| → Qhyst2s                                        | 0 dB                                |
| → Treselections                                  | 0 seconds                           |
| → HCS Serving cell information                   |                                     |
| → HCS Priority                                   | -6                                  |
| → Q-HCS                                          | 39 (results in actual value of -76) |
| → TcrMax                                         | Not Present                         |

### Contents of System Information Block type 4 (FDD)

| Information Element                              | Value/remark                        |
|--------------------------------------------------|-------------------------------------|
| → Cell identity                                  | 0000 0000 0000 0000 0000 0000 0001B |
| → Cell selection and re-selection info           |                                     |
| → Mapping Info                                   | Not present                         |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                          |
| → CHOICE mode                                    | FDD                                 |
| → Sintrasearch                                   | 16 dB                               |
| → Sintersearch                                   | 16 dB                               |
| → SsearchHCS                                     | 53 dB                               |
| → RAT List                                       | This parameter is configurable      |
| → RAT identifier                                 | GSM                                 |
| → Ssearch,RAT                                    | -32 dB                              |
| → SHCS,RAT                                       | Not Present                         |
| → Slimit,SearchRAT                               | Not Present                         |
| → Qqualmin                                       | -20 dB                              |
| → Qrxlevmin                                      | -115 dBm                            |
| → Qhyst1s                                        | 10 (gives actual value of 20 dB)    |
| → Qhyst2s                                        | 0 dB                                |
| → Treselections                                  | 0 seconds                           |
| → HCS Serving cell information                   |                                     |
| → HCS Priority                                   | -6                                  |
| → Q-HCS                                          | 39 (results in actual value of -76) |
| → TcrMax                                         | Not Present                         |

## Contents of System Information Block type 11 (FDD) (Cell 1)

| Information Element                              | Value/remark                                                                |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Measurement control system information         | used                                                                        |
| → Use of HCS                                     | CPICH RSCP                                                                  |
| → Cell_selection_and_reselection_quality_measure |                                                                             |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.2 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20 dB                                                                      |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.3 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20dB                                                                       |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## Contents of System Information Block type 12 in connected mode (FDD) (Cell 1)

| Information Element                      | Value/remark |
|------------------------------------------|--------------|
| → Measurement control system information |              |



|                                                  |                                                                             |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Use of HCS                                     | used                                                                        |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                                                                  |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.2 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1 <sub>s,n</sub>                        | -20 dB                                                                      |
| → Qoffset2 <sub>s,n</sub>                        | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.3 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1 <sub>s,n</sub>                        | -20 dB                                                                      |
| → Qoffset2 <sub>s,n</sub>                        | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | 39 (results in actual value of -76)                                         |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## Test Procedure

Table 8.3.1.21-1

| Parameter               | Unit | Cell 1 |     |     | Cell 2 |     |     | Cell 3 |     |     |
|-------------------------|------|--------|-----|-----|--------|-----|-----|--------|-----|-----|
|                         |      | T0     | T1  | T2  | T0     | T1  | T2  | T0     | T1  | T2  |
| UTRA RF Channel Number  |      | Ch. 1  |     |     | Ch. 1  |     |     | Ch. 1  |     |     |
| CPICH RSCP              | dBm  | -61    | -61 | -61 | -80    | -80 | -67 | -80    | -73 | -73 |
| H* (After Penalty Time) |      | 15     | 15  | 15  | -5     | -5  | 9   | -5     | 3   | 3   |
| R* (After Penalty Time) |      | -41    | -41 | -41 | -60    | -60 | -47 | -60    | -53 | -53 |

\* this parameter is calculated internally in the UE and is only shown for clarification of the test procedure.

The UE is in the CELL\_PCH state, camping onto cell 1. SS configures Cell 2 and 3 with power levels given in column "T0" and starts to broadcast BCCH on the primary CCCH in cell 2 & 3. UE shall remain camped on the Cell 1 even after expiry of penalty time i.e. 40 seconds. SS sets downlink transmission power settings according to columns "T1" in table 8.3.1.22-1. The UE shall find cell 3 to be more suitable for service and hence perform a cell reselection to cell 3 after at least 40 Seconds (Penalty Time) after the power levels have been changed. After the completion of cell reselection, the UE shall move to CELL\_FACH state and transmit a CELL\_UPDATE message to the SS on the uplink CCCH of cell 3 and set IE "Cell update cause" to "Cell Reselection". After SS receives this message, it transmits a CELL\_UPDATE\_CONFIRM message, which includes the IE "RRC State Indicator" set to "CELL\_PCH", to the UE on the downlink DCCH. UE shall return to CELL\_PCH state in Cell 3 and will not transmit anything on PRACH. SS then sets downlink transmission power settings according to columns "T2" in table 8.3.1.22-1. The UE shall find cell 2 to be more suitable for service and hence perform a cell reselection to cell 2 after at least 40 Seconds (Penalty Time) after the power levels have been changed. After the completion of cell reselection, the UE shall move to CELL\_FACH state and transmit a CELL\_UPDATE message to the SS on the uplink CCCH of cell 2 and set IE "Cell update cause" to "Cell Reselection". After the SS receives this message, it transmits a CELL\_UPDATE\_CONFIRM message, which includes the IE "RRC State Indicator" set to "CELL\_PCH", to the UE on the downlink DCCH. UE shall return to CELL\_PCH state in Cell 2 and will not transmit anything on PRACH.

## Expected sequence

| Step | Direction |    | Message             | Comment                                                                                                                                                                                                                                                                                                                                                                                                         |
|------|-----------|----|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                     |                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 1    |           |    |                     | The UE is in the CELL_PCH state in cell 1                                                                                                                                                                                                                                                                                                                                                                       |
| 2    |           | ←  | BCCH                | SS applies the downlink transmission power settings, according to the values in columns "T0" of table 8.3.1.1-1. The SS starts to broadcast BCCH on the primary CCPCCH in cell 2 and Cell 3. The UE shall find still find Cell 1 best for service even after penalty time of 40 seconds, and shall remain in Cell 1 in CELL_PCH State                                                                           |
| 3    |           |    |                     | SS changes the power levels as per column 'T1' in the table 8.3.1.21-1. For the time equal to Penalty time 40 Seconds, after the change in power levels, the UE shall still find Cell 1 as best for service and remain in cell 1. After Penalty time of 40 Seconds, UE shall find Cell 3 better for service and perform a reselection. SS waits for the maximum duration required for the UE to camp to cell 3. |
| 4    |           | →  | CELL UPDATE         | The UE moves to CELL_FACH state and transmits this message with the IE "Cell update cause" set to "cell reselection". Received in Cell 3                                                                                                                                                                                                                                                                        |
| 5    |           | ←  | CELL UPDATE CONFIRM | IE "RRC State Indicator" is set to "CELL_PCH".                                                                                                                                                                                                                                                                                                                                                                  |
| 7    |           |    |                     | SS changes the power levels as per column 'T2' in the table 8.3.1.21-1. For the time equal to Penalty time 40 Seconds, after the change in power levels, the UE shall still find Cell 3 as best for service and remain in cell 3. After Penalty time of 40 Seconds, UE shall find Cell 2 better for service and perform a reselection. SS waits for the maximum duration required for the UE to camp to cell 2. |
| 8    |           | →  | CELL UPDATE         | The UE moves to CELL_FACH state and transmits this message with the IE "Cell update cause" set to "cell reselection". Received in Cell 2                                                                                                                                                                                                                                                                        |
| 9    |           | ←  | CELL UPDATE CONFIRM | IE "RRC State Indicator" is set to "CELL_PCH".                                                                                                                                                                                                                                                                                                                                                                  |

## Specific Message Contents

## Contents of System Information Block type 3 (FDD) (Cell 2 and 3)

| Information Element                              | Value/remark                        |
|--------------------------------------------------|-------------------------------------|
| → SIB4 indicator                                 | TRUE                                |
| → Cell identity                                  | 0000 0000 0000 0000 0000 0000 0001B |
| → Cell selection and re-selection info           |                                     |
| → Mapping info                                   | Not Present                         |
| → Cell selection_and_reselection_quality_measure | CPICH RSCP                          |
| → CHOICE mode                                    | FDD                                 |
| → Sintrasearch                                   | 16 dB                               |
| → Sintersearch                                   | 16 dB                               |
| → SsearchHCS                                     | 53 dB                               |
| → RAT List                                       | This parameter is configurable      |
| → RAT identifier                                 | GSM                                 |
| → Ssearch,RAT                                    | -32 dB                              |
| → SHCS,RAT                                       | Not Present                         |
| → Slimit,SearchRAT                               | Not Present                         |
| → Qqualmin                                       | -20 dB                              |
| → Qrxlevmin                                      | -115 dBm                            |
| → Qhyst1s                                        | 10 (gives actual value of 20 dB)    |
| → Qhyst2s                                        | 0 dB                                |
| → Treselections                                  | 0 seconds                           |
| → HCS Serving cell information                   |                                     |
| → HCS Priority                                   | -7                                  |
| → Q HCS                                          | 39 (results in actual value of -76) |
| → TerMax                                         | Not Present                         |

## Contents of System Information Block type 4 (FDD) (Cell 2 and 3)

| Information Element                              | Value/remark                        |
|--------------------------------------------------|-------------------------------------|
| → Cell identity                                  | 0000 0000 0000 0000 0000 0000 0001B |
| → Cell selection and re-selection info           |                                     |
| → Mapping Info                                   | Not present                         |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                          |
| → CHOICE mode                                    | FDD                                 |
| → Sintrasearch                                   | 16 dB                               |
| → Sintersearch                                   | 16 dB                               |
| → SsearchHCS                                     | 53 dB                               |
| → RAT List                                       | This parameter is configurable      |
| → RAT identifier                                 | GSM                                 |
| → Ssearch,RAT                                    | -32 dB                              |
| → SHCS,RAT                                       | Not Present                         |
| → Slimit,SearchRAT                               | Not Present                         |
| → Qqualmin                                       | -20 dB                              |
| → Qrxlevmin                                      | -115 dBm                            |
| → Qhyst1s                                        | 10 (gives actual value of 20 dB)    |
| → Qhyst2s                                        | 0 dB                                |
| → Treselections                                  | 0 seconds                           |
| → HCS Serving cell information                   |                                     |
| → HCS Priority                                   | -7                                  |
| → Q HCS                                          | 39 (results in actual value of -76) |
| → TerMax                                         | Not Present                         |

## Contents of System Information Block type 11 (FDD) (Cell 2)

| Information Element                              | Value/remark                                                                |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Measurement control system information         |                                                                             |
| → Use of HCS                                     | used                                                                        |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                                                                  |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.3 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20dB                                                                       |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | -20dB                                                                       |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.1 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20 dB                                                                      |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -6                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## Contents of System Information Block type 12 in connected mode (FDD) (Cell 2)

| Information Element                      | Value/remark |
|------------------------------------------|--------------|
| → Measurement control system information |              |

|                                                  |                                                                             |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Use of HCS                                     | used                                                                        |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                                                                  |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.3 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1 <sub>s,n</sub>                        | -20 dB                                                                      |
| → Qoffset2 <sub>s,n</sub>                        | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.1 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1 <sub>s,n</sub>                        | -20 dB                                                                      |
| → Qoffset2 <sub>s,n</sub>                        | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -6                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## Contents of System Information Block type 11 (FDD) (Cell 3)

| Information Element                              | Value/remark                                                                |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Measurement control system information         |                                                                             |
| → Use of HCS                                     | used                                                                        |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                                                                  |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.1 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20 dB                                                                      |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -6                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.2 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20 dB                                                                      |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## Contents of System Information Block type 12 in connected mode (FDD) (Cell 3)

| Information Element                      | Value/remark |
|------------------------------------------|--------------|
| → Measurement control system information |              |

|                                                  |                                                                             |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Use of HCS                                     | used                                                                        |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                                                                  |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.1 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20 dB                                                                      |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -6                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.2 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20 dB                                                                      |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## CELL UPDATE

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:



| Information Element                                      | Value/remark                                                                                             |
|----------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| U-RNTI<br>-SRNC Identity<br>-S-RNTI<br>Cell Update Cause | Check to see if set to '0000-0000-0001'<br>In step 4 and 7<br>Check to see if set to 'Cell Re-selection' |

### CELL UPDATE CONFIRM (Step 5 and 8)

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| RRC State Indicator | CELL_PCH     |

#### 8.3.1.24.5 Test requirement

After step 3 the UE shall reselect to cell 3 and then it shall transmit a CELL UPDATE message which, sets the value "cell reselection" in IE "Cell update cause".

After step 6 the UE shall reselect to cell 2 and then it shall transmit a CELL UPDATE message which, sets the value "cell reselection" in IE "Cell update cause".

## 8.3.2 URA Update

### 8.3.2.1 URA Update: Change of URA

#### 8.3.2.1.1 Definition

#### 8.3.2.1.2 Conformance requirement

This procedure is to update UTRAN with the current URA of the UE after a change of URA has occurred in URA\_PCH state. It may also be used for supervision of the RRC connection, even if no change of URA takes place.

#### Reference

3GPP TS 25.331 clause 8.3.1

#### 8.3.2.1.3 Test purpose

To confirm that the UE executes an URA update procedure after the successful change of URA. To confirm UE responds correctly when it re-selects to a new cell while waiting for URA UPDATE CONFIRM message from SS.

#### 8.3.2.1.4 Method of test

#### Initial Condition

System Simulator: 3 cells – Cell 1 and 2 are active with URA-ID 1 and the downlink transmission power shown in column marked "T0" in table 8.3.2.1, while cell 3 is active with URA-ID 2.

UE: URA\_PCH (state 6-13) as specified in clause 7.4 of TS 34.108, with URA-ID 1 from the list of URA-ID in cell 1.

Test Procedure

Table 8.3.2.1

| Parameter              | Unit        | Cell 1 |     |     | Cell 2 |     |     | Cell 3 |     |     |
|------------------------|-------------|--------|-----|-----|--------|-----|-----|--------|-----|-----|
|                        |             | T0     | T1  | T2  | T0     | T1  | T2  | T0     | T1  | T2  |
| UTRA RF Channel Number |             | Ch. 1  |     |     | Ch. 1  |     |     | Ch. 1  |     |     |
| CPICH Ec               | dBm/3.84MHz | -60    | -75 | -75 | -75    | -60 | -75 | -75    | -75 | -60 |

The test begins with the downlink power transmission of all cells set according to 'T0' column in table 8.3.2.1. The UE is in the URA\_PCH state and assigned with only 1 URA identity in cell 1: URA-ID 1. The SS then adjusts the transmission power again according to 'T1' column. This is expected to cause the UE to perform a cell reselection to cell 2. Since same URA identity is broadcasted in cell 1 and 2, the UE shall not perform any URA update procedure due to the change of URA. Next SS adjusts the transmission power according to 'T2' column. UE shall perform a cell reselection to cell 3 and when the UE finds that its current URA-ID 1 is not in the new broadcasted list of URA-IDs, it moves to CELL\_FACH state and transmits a URA UPDATE message on the uplink CCCH. After the SS receives this message, it transmits a URA UPDATE CONFIRM message, which includes the IEs "RRC State Indicator" and IE "URA-ID" to the UE on the downlink DCCH. The IE "RRC State Indicator" is set to "URA\_PCH". UE returns to URA\_PCH state in cell 3 without sending any uplink response message. Next SS adjusts the transmission power according to 'T1' column. UE shall re-select to cell 2 and transmit a URA UPDATE message to SS. However, SS do not acknowledge but adjusts the transmission power according to 'T0' column. UE shall perform cell re-selection to cell 1 and then sent a URA UPDATE message to SS. Finally SS shall transmit URA UPDATE CONFIRM message to UE.

## Expected sequence

| Step | Direction |    | Message            | Comment                                                                                                                                                                                                                                  |
|------|-----------|----|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                                                                                                                          |
| 1    |           |    |                    | The UE is updated with only 1 URA identity carried currently by cell 1. The starting state of the UE is URA_PCH                                                                                                                          |
| 2    |           |    |                    | SS set the power transmission of all cells according to column 'T1' of table 8.3.2.1.                                                                                                                                                    |
| 3    |           |    |                    | UE shall perform a cell reselection but shall not transmit URA UPDATE message with the update cause of "change of URA".                                                                                                                  |
| 4    |           |    |                    | SS set the power transmission of all cells according to column 'T2' of table 8.3.2.1.                                                                                                                                                    |
| 5    |           | →  | URA UPDATE         | The UE shall perform a cell reselection first and when it finds that its current URA-ID-1 is not in the newly broadcasted list of URA-IDs, it shall then transmit this message and set value "change of URA" into IE "URA update cause". |
| 6    |           | ←  | URA UPDATE CONFIRM | Message comprises IE "RRC State Indicator" set "URA_PCH", and also IE "URA Identity" equals to "URA-ID-2".                                                                                                                               |
| 7    |           |    |                    | SS set the power transmission of all cells according to column 'T1' of table 8.3.2.1.                                                                                                                                                    |
| 8    |           | →  | URA UPDATE         |                                                                                                                                                                                                                                          |
| 9    |           |    |                    | SS do not respond to the URA UPDATE message from UE and set the power transmission of all cells according to column 'T0' of table 8.3.2.1.                                                                                               |
| 10   |           | →  | URA UPDATE         |                                                                                                                                                                                                                                          |
| 11   |           | ←  | URA UPDATE CONFIRM |                                                                                                                                                                                                                                          |

## Specific Message Contents

## URA UPDATE (Step 5, 8 and 10)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| - SRNC Identity     | Check to see if set to '0000 0000 0001'           |
| - S-RNTI            | Check to see if set to '0000 0000 0000 0000 0001' |
| URA Update Cause    | Check to see if set to 'change of URA'            |

## URA UPDATE CONFIRM (Step 6)

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| URA identity        | URA-ID 2     |

### URA UPDATE CONFIRM (Step 11)

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| URA identity        | URA-ID 1     |

#### 8.3.2.1.5 Test requirement

After step 2 the UE shall not transmit a URA UPDATE message.

After step 4 the UE shall find that URA-ID 2 is not in its maintained list of URA-IDs. After cell reselection, the UE shall move to CELL\_FACH state and transmit a URA UPDATE message setting value "change of URA" into IE "URA update cause".

After step 7 the UE shall find that URA-ID 1 is not in its maintained list of URA-IDs. After cell reselection, the UE shall move to CELL\_FACH state and transmit a URA UPDATE message setting value "change of URA" into IE "URA update cause".

After step 9 the UE shall find the new cell and transmit a URA UPDATE message setting value "change of URA" into IE "URA update cause".

### 8.3.2.2 URA Update: Periodical URA update and Reception of Invalid message

#### 8.3.2.2.1 Definition

#### 8.3.2.2.2 Conformance requirement

This procedure is to update UTRAN with the current URA of the UE when the UE detects that it is still within the service area after the expiry of periodic URA updating timer T305.

#### Reference

3GPP TS 25.331 clause 8.3.1

#### 8.3.2.2.3 Test purpose

To confirm that the UE executes a URA update procedure after the expiry of timer T305. To verify that the UE handles an invalid URA UPDATE CONFIRM message correctly when executing the URA update procedure.

#### 8.3.2.2.4 Method of test

#### Initial Condition

System Simulator: 1 cell

UE: URA\_PCH (state 6-13) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is in URA\_PCH state. When the UE detects the expiry of timer T305, set according to the value specified in system information, the UE moves to CELL\_FACH state and transmits a URA UPDATE message to the SS on the uplink CCCH. The message shall indicate the cause to be "periodic URA update" in IE "URA update cause". SS replies with an invalid URA UPDATE CONFIRM message sent on downlink CCCH, and check to see if the UE handles this event properly. The UE shall attempt to retransmit the identical URA UPDATE message. After the SS receives the

second URA UPDATE message, it transmits a correct URA UPDATE CONFIRM message, which includes the IE "new U-RNTI", to the UE on the downlink DCCH. Then the UE shall then transmit an UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH. The UE returns to CELL\_FACH state.

#### Expected sequence

| Step | Direction |    | Message                            | Comment                                                                                        |
|------|-----------|----|------------------------------------|------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                    |                                                                                                |
| 1    |           |    |                                    | The UE is in URA_PCH state. SS wait until T305 timer has expired.                              |
| 2    |           | →  | URA UPDATE                         | UE shall transmit this message and set value "periodic URA update" into IE "URA update cause". |
| 3    |           | ←  | URA UPDATE CONFIRM                 | See specific message content.                                                                  |
| 4    |           | →  | URA UPDATE                         | UE shall not return to idle mode immediately, but attempts to re-transmit this message.        |
| 5    |           | ←  | URA UPDATE CONFIRM                 | Including IE "new U-RNTI"                                                                      |
| 6    |           | →  | UTRAN MOBILITY INFORMATION CONFIRM |                                                                                                |

#### Specific Message Contents

##### URA UPDATE (Step 2)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| —SRNC Identity      | Check to see if set to '0000-0000-0001'           |
| —S-RNTI             | Check to see if set to '0000-0000-0000-0000-0001' |
| URA Update Cause    | Check to see if set to 'Periodic URA update'      |

##### URA UPDATE (Step 4)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element        | Value/remark                                                                    |
|----------------------------|---------------------------------------------------------------------------------|
| U-RNTI                     |                                                                                 |
| —SRNC Identity             | Check to see if set to '0000-0000-0001'                                         |
| —S-RNTI                    | Check to see if set to '0000-0000-0000-0000-0001'                               |
| RRC Transaction identifier | Check to see if set to the value given in URA UPDATE CONFIRM message in step 3. |
| URA Update Cause           | Check to see if set to 'Periodic URA update'                                    |
| Protocol error indicator   | TRUE                                                                            |
| Protocol error information |                                                                                 |
| — Protocol error cause     | ASN.1 violation or encoding error                                               |

##### URA UPDATE CONFIRM (Step 3)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

### URA UPDATE CONFIRM (Step 5)

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element | Value/remark               |
|---------------------|----------------------------|
| New U-RNTI          |                            |
| SRNC Identity       | '0000 0000 0001'           |
| S-RNTI              | '0000 0000 0000 0000 1111' |

### UTRAN MOBILITY INFORMATION CONFIRM (Step 6)

Only the message type IE of this message is checked.

#### 8.3.2.2.5 Test requirement

After step 1 the UE shall detect the expiry of timer T305, move to CELL\_FACH state, and transmit a URA UPDATE message which sets the value "periodical cell update" into IE "URA update-cause".

After step 3 the UE shall re-transmit URA UPDATE message with IE "Protocol error indicator" set to 'TRUE' and IE "Protocol error information" set to "ASN.1 violation and encoding error".

After step 5 the UE shall transmit an UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH and returns to the CELL\_FACH state.

### 8.3.2.3 URA Update: re-entering of service area after T305 expiry

#### 8.3.2.3.1 Definition

#### 8.3.2.3.2 Conformance requirement

This procedure is to update UTRAN with the current URA of the UE if the UE detects that it is out of service area after the expiry of timer T305, and then subsequently re-enters the service area before the expiry of T307.

#### Reference

3GPP TS 25.331 clause 8.3.1

#### 8.3.2.3.3 Test purpose

To confirm that the UE executes a URA update procedure when the UE re-enters the service area before the expiry of timer T307, after being out of service area at the expiry of timer T305.

#### 8.3.2.3.4 Method of test

#### Initial Condition

System Simulator: 1 cell with URA-ID 1 and the downlink transmission power shown in column marked "T0" in table 8.3.2.3.

UE: URA\_PCH (state 6-13) as specified in clause 7.4 of TS 34.108, with URA-ID 1 in the list of URA-ID.

## Test Procedure

Table 8.3.2.3

| Parameter              | Unit        | Cell 1 |     |
|------------------------|-------------|--------|-----|
|                        |             | T0     | T1  |
| UTRA RF Channel Number |             | Ch. 1  |     |
| CPICH Ec               | dBm/3.84MHz | -60    | -80 |

Table 8.3.2.3 illustrates the downlink power to be applied at various time instants of the test execution. Columns marked "T0" denote the initial conditions.

The UE is initially in URA\_PCH state. The content of the SYSTEM INFORMATION BLOCK TYPE 3 and 4 is modified. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.2.3 so that  $S < 0$ . When the UE detects the expiry of timer T305 according to the system information, the UE finds that it is out of service area. The UE is expected to search for cell to camp. Then SS configures its downlink transmission power settings according to columns "T0" in table 8.3.2.3 so that  $S > 0$ . The UE shall detect that it returns to normal service before T307 expires. The UE shall move to CELL\_FACH state and starts transmitting a URA UPDATE message which contains the value "re-entered service area" in IE "URA update cause" to the SS on the uplink CCCH. After the SS receives this message, it transmits a URA UPDATE CONFIRM message which includes the IE "new C-RNTI", and "new U-RNTI" to the UE on the downlink DCCH. Then the UE shall transmit an UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH.

## Expected sequence

| Step | Direction |    | Message                                                              | Comment                                                                                                                                                                            |
|------|-----------|----|----------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                      |                                                                                                                                                                                    |
| 1    |           |    |                                                                      | The UE starts operating from URA_PCH state.                                                                                                                                        |
| 1a   |           | ←  | MASTER INFORMATION BLOCK<br>SYSTEM INFORMATION BLOCK TYPE 3<br>and 4 | SS changes the contents of MASTER INFORMATION BLOCK and SYSTEM INFORMATION BLOCK (see specific message contents).                                                                  |
| 1b   |           | ←  | PAGING TYPE 1                                                        | Include IE "BCCH modification info"                                                                                                                                                |
| 2    |           |    |                                                                      | SS configures its downlink transmission power settings according to columns "T1" in table 8.3.2.3 such that the cell 1 is no longer suitable for camping i.e. $S < 0$ .            |
| 3    |           |    |                                                                      | The UE shall attempt to perform a URA update upon the expiry of timer T305. It shall discover that it is out of service and starts searching for cell to camp. (T307 timer starts) |
| 4    |           |    |                                                                      | SS configures its downlink transmission power settings according to columns "T0" in table 8.3.2.3 before T307 expires.                                                             |
| 5    |           | →  | URA UPDATE                                                           | Value "re-entered service area" shall be set in IE "URA update cause"                                                                                                              |
| 6    |           | ←  | URA UPDATE CONFIRM                                                   | The message includes IEs "new C-RNTI", and "new U-RNTI"                                                                                                                            |
| 7    |           | →  | UTRAN MOBILITY INFORMATION CONFIRM                                   |                                                                                                                                                                                    |

## Specific Message Contents

### MASTER INFORMATION BLOCK (Step 1a)

Use the same message sub-type found in clause 6.1 of TS 34.108, with the following exception.

| Information Element | Value/remark |
|---------------------|--------------|
| MIB-Tag             | 2            |

### SYSTEM INFORMATION BLOCK TYPE 3 and 4 (Step 1a)

Use the same message sub-type found in clause 6.1 of TS 34.108, with the following exception.

| Information Element | Value/remark |
|---------------------|--------------|
| Qrxlevmin           | -70          |

### PAGING TYPE 1 (Step 1b)

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element      | Value/remark |
|--------------------------|--------------|
| Paging record list       | Not Present  |
| BCCH modification info   |              |
| — MIB-Value tag          | 2            |
| — BCCH modification time | Not present  |

### URA UPDATE (Step 5)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| — SRNC-Identity     | Check to see if set to '0000-0000-0001'           |
| — S-RNTI            | Check to see if set to '0000-0000-0000-0000-0001' |
| URA-Update-Cause    | Check to see if set to 're-entered service area'  |

### URA UPDATE CONFIRM (Step 6)

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element | Value/remark                                                                                    |
|---------------------|-------------------------------------------------------------------------------------------------|
| New U-RNTI          |                                                                                                 |
| — SRNC-Identity     | '0000-0000-0001'                                                                                |
| — S-RNTI            | '0000-0000-0000-1111-1111'                                                                      |
| New C-RNTI          | Arbitrary 16-bit string which is different the assigned C-RNTI in RRC CONNECTION SETUP message. |

### 8.3.2.3.5 ——— Test requirement

After step 2 the UE shall detect that it is out of service area and shall not send a URA UPDATE on the uplink CCCH channel.

After step 4 the UE shall transmit a URA UPDATE message which sets value "re-entered service area" into IE "URA update-cause".



After step 6 the UE shall transmit an UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH.

**8.3.2.4 URA Update: loss of service after expiry of timers T307 and T305**

**8.3.2.4.1 Definition**

**8.3.2.4.2 Conformance requirement**

This procedure is required to handle the case when the UE fails to update UTRAN with the current URA of after expiry of timers T307 and T305 consecutively. The UE shall move to idle mode subsequently.

**Reference**

3GPP TS 25.331 clause 8.3.1

**8.3.2.4.3 Test purpose**

To confirm that the UE moves to idle mode after the expiry of timer T307, following an expiry of timer T305 when it discovers that it is out of service area.

**8.3.2.4.4 Method of test**

**Initial Condition**

System Simulator: 1 cell

UE: URA\_PCH (state 6-13) as specified in clause 7.4 of TS 34.108.

**Test Procedure**

**Table 8.3.2.4**

| Parameter              | Unit        | Cell 1 |     |
|------------------------|-------------|--------|-----|
|                        |             | T0     | T1  |
| UTRA RF Channel Number |             | Ch. 1  |     |
| CPICH Ec               | dBm/3.84MHz | -60    | -80 |

Table 8.3.2.4 illustrates the downlink power to be applied at various time instants of the test execution. Columns marked "T0" denote the initial conditions.

The UE is in URA\_PCH state. The content of the SYSTEM INFORMATION BLOCK TYPE 3 and 4 is modified. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.2.3 so that  $S < 0$ . When the UE detects the expiry of periodic URA updating timer T305 according to the system information, the UE detects that it is out of service area. After the expiry of timer T307, the UE moves to the idle state. SS configures its downlink transmission power settings according to columns "T0" in table 8.3.2.3 so that  $S > 0$ . SS verifies that UE is in idle mode state by sending a PAGING TYPE 1 message to the UE using UE identity. UE shall respond to this message.

## Expected sequence

| Step | Direction |    | Message                                                              | Comment                                                                                                                                                                          |
|------|-----------|----|----------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                      |                                                                                                                                                                                  |
| 1    |           |    |                                                                      | Initially, the UE is in the URA_PCH state.                                                                                                                                       |
| 1a   |           | ←  | MASTER INFORMATION BLOCK<br>SYSTEM INFORMATION BLOCK TYPE 3<br>and 4 | SS changes the contents of MASTER INFORMATION BLOCK and SYSTEM INFORMATION BLOCK (see specific message contents).                                                                |
| 1b   |           | ←  | PAGING TYPE 1                                                        | Include IE "BCCH modification info"                                                                                                                                              |
| 2    |           |    |                                                                      | SS configures its downlink transmission power settings according to columns "T1" in table 8.3.2.4 so that the UE detects that it is out of service area.                         |
| 3    |           |    |                                                                      | Upon the expiry of timer T305, the UE shall search for cell to camp and triggers T307 timer. SS listens to the uplink CCCH to verify that URA UPDATE message is not transmitted. |
| 4    |           |    |                                                                      | After the expiry of timer T307, the UE enters idle state.                                                                                                                        |

## Specific Message Contents

## MASTER INFORMATION BLOCK (Step 1a)

Use the same message sub-type found in clause 6.1 of TS 34.108, with the following exception:

| Information Element | Value/remark |
|---------------------|--------------|
| MIB Tag             | 2            |

## SYSTEM INFORMATION BLOCK TYPE 3 and 4 (Step 1a)

Use the same message sub-type found in clause 6.1 of TS 34.108, with the following exception:

| Information Element | Value/remark |
|---------------------|--------------|
| Qrxlevmin           | -70          |

## PAGING TYPE 1 (Step 1b)

Use the same message sub-type found in Annex A, with the following exceptions:

| Information Element      | Value/remark |
|--------------------------|--------------|
| Paging record list       | Not Present  |
| BCCH modification info   |              |
| – MIB Value tag          | 2            |
| – BCCH modification time | Not present  |

## 8.3.2.4.5 ————— Test requirement

After step 2 the UE shall not transmit any URA UPDATE message on the uplink CCCH.

After step 5, UE shall enter idle mode state.

### ~~8.3.2.5 URA Update: Success after Confirmation error of URA-ID list~~

#### ~~8.3.2.5.1 Definition~~

#### ~~8.3.2.5.2 Conformance requirement~~

~~UE transmits a URA UPDATE message to the UTRAN when it needs to update UTRAN with the current URA of the UE. UTRAN shall respond to the URA UPDATE message by sending a URA UPDATE CONFIRM message. When the indicated URA-ID in the received URA UPDATE CONFIRM message is not found in the list of URA-IDs that is broadcasted in system information block type 2, the UE transmits a URA UPDATE message repeatedly until its internal counter V302 is greater than N302.~~

#### ~~Reference~~

~~3GPP TS 25.331 clause 8.3.1~~

#### ~~8.3.2.5.3 Test purpose~~

~~To confirm that the UE retries to perform the URA update procedure following a confirmation error of URA-ID list.~~

#### ~~8.3.2.5.4 Method of test~~

#### ~~Initial Condition~~

~~System Simulator: 1 cell~~

~~UE: URA\_PCH (state 6-13) as specified in clause 7.4 of TS 34.108.~~

#### ~~Test Procedure~~

~~At the start of this test, the UE is brought to URA\_PCH state and assigned a URA with URA-ID 1. When the UE detects the expiry of timer T305 according to the system information, the UE moves to CELL\_FACH state and transmits a URA UPDATE message to the SS on the uplink CCCH. The reason for performing URA updating shall be set to "periodic URA update" in IE "URA update cause". After the SS receives this message, it transmits a URA UPDATE CONFIRM message which includes the IE "RRC state indicator" set to "URA\_PCH" and IE "URA identity" set to "URA-ID 2" to the UE on the downlink DCCH. The UE finds that the indicated URA-ID is not included in the list of URA-IDs broadcasted in system information block type 2, and then the UE shall retry to transmit a URA UPDATE message for a confirmation error of URA-ID list. SS continue to send the same URA UPDATE CONFIRM message until N302+1 URA UPDATE messages have been received. Then SS transmits a URA UPDATE CONFIRM message to the UE which includes IE "URA Identity" set to "URA-ID 1" and IE "new U-RNTI". The UE shall find this URA-ID in its URA-ID list and transmits an UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH.~~

## Expected sequence

| Step | Direction |    | Message                            | Comment                                                                                                                                  |
|------|-----------|----|------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                    |                                                                                                                                          |
| 1    |           |    |                                    | The UE is URA_PCH state.<br>SS initializes counter K to 0                                                                                |
| 2    |           | →  | URA UPDATE                         | This message shall contain value "periodic URA update" set in IE "URA update cause" after expiry of timer T305.                          |
| 3    |           |    |                                    | SS increments K by 1. If K is not greater than N302, proceed to step 4. If K is greater than N302, SS proceeds to step 5.                |
| 4    |           | ←  | URA UPDATE CONFIRM                 | SS transmits this message, setting the value "URA-ID 2" to IE "URA Identity".<br>SS waits for T302 to expire and then returns to step 2. |
| 5    |           | ←  | URA UPDATE CONFIRM                 | SS transmits this message, setting IE "URA Identity" to "URA-ID 1". This message also comprises IE "New U-RNTI".                         |
| 6    |           | →  | UTRAN MOBILITY INFORMATION CONFIRM |                                                                                                                                          |

## Specific Message Contents

## URA UPDATE (Step 2)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| —SRNC Identity      | Check to see if set to '0000-0000-0001'           |
| —S-RNTI             | Check to see if set to '0000-0000-0000-0000-0001' |
| URA Update Cause    | Check to see if set to 'Periodic URA update'      |

## URA UPDATE CONFIRM (Step 4)

Use the same message sub-type as specified in Annex A, with the following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| URA Identity        | 2            |

## URA UPDATE CONFIRM (Step 5)

Use the same message sub-type as specified in Annex A, with the following exceptions:

| Information Element | Value/remark               |
|---------------------|----------------------------|
| New U-RNTI          |                            |
| —SRNC Identity      | '0000-0000-0001'           |
| —S-RNTI             | '0000-0000-0000-0101-0101' |
| URA Identity        | 1                          |

## UTRAN MOBILITY INFORMATION CONFIRM (Step 6)

Only the message type IE in this message is checked.

### 8.3.2.5.5 Test requirement

After step 1 the UE shall detect the expiry of timer T305, move to CELL\_FACH state, transmit a URA UPDATE message on the uplink CCCH and set value "periodic URA update" into IE "URA update cause".

After step 4 the UE shall re-transmit a URA UPDATE message after it detects a confirmation error of URA-ID list for the URA-ID indicated in the URA UPDATE CONFIRM message. A total of (N302+1) URA UPDATE messages shall be received by the SS.

After step 5 the UE shall transmit an UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH.

### 8.3.2.6 URA Update: Failure (V302 is greater than N302: Confirmation error of URA-ID list)

#### 8.3.2.6.1 Definition

#### 8.3.2.6.2 Conformance requirement

UE transmits a URA UPDATE message to the UTRAN when it needs to update UTRAN with the current URA of the UE. When the indicated URA-ID in the received URA UPDATE CONFIRM message is not in the list of URA-IDs that is broadcasted in system information block type 2, the UE transmits URA UPDATE messages repeatedly until its internal counter V302 is greater than N302. If V302 is greater than N302 then the UE enters idle state.

#### Reference

3GPP TS 25.331 clause 8.3.1

#### 8.3.2.6.3 Test purpose

To confirm that the UE make repeated attempts to perform the URA update procedure following a detection of a confirmation error of URA-ID list. It then moves to idle state when internal counter V302 is greater than N302.

#### 8.3.2.6.4 Method of test

#### Initial Condition

System Simulator: 1 cell

UE: URA\_PCH (state 6-13) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

The UE is originally in URA\_PCH state updated with URA-ID 1. When the UE detects the expiry of timer T305 according to the system information, the UE shall move to CELL\_FACH state and transmit a URA UPDATE message to the SS on the uplink CCCH. In this message, the value "periodic URA update" shall be set in IE "URA update cause". After the SS receives this message, it transmits a URA UPDATE CONFIRM message which includes the IE "RRC state indicator" set to "URA\_PCH" and indicating the IE "URA Identity" to be "URA-ID 2" to the UE on the downlink DCCH. The UE finds that the indicated URA-ID is not included in the list of URA-IDs broadcasted. Then the UE shall retry to transmit a URA UPDATE message for N302 times and each time the SS responds with the URA UPDATE CONFIRM message similar to the previous one. After that, the UE shall enter idle state.

Expected sequence

| Step | Direction |    | Message            | Comment                                                                                                                                                                     |
|------|-----------|----|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                                                             |
| 1    |           |    |                    | The UE is in URA_PCH state at the start of the test. SS sets internal counter K to 0.                                                                                       |
| 2    |           | →  | URA UPDATE         | The message shall indicate "periodic URA update" in IE "URA update-cause". This message is sent following the expiry of timer T305. SS increments counter K by 1.           |
| 3    |           | ←  | URA UPDATE CONFIRM | The SS transmit this message and set IE "URA Identity" to "URA-ID 2". When K is greater than N302 proceeds to step 4, else SS waits for T302 to expire and executes step 2. |
| 4    |           |    | Void               | The UE shall enter idle state.                                                                                                                                              |

Specific Message Contents

URA UPDATE CONFIRM (Step 3)

Use the same message sub-type defined in Annex A, with the following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| URA Identity        | 2            |

8.3.2.6.5 ——— Test requirement

After step 1 the UE shall detect the expiry of timer T305, then it shall move to CELL\_FACH state and transmit a URA UPDATE message on the uplink CCCH, setting value "periodic URA update" in IE "URA update-cause".

After step 3 and if K is not greater than N302, the UE shall retry to transmit a URA UPDATE message after it detects the confirmation error of URA-ID list for the URA-ID included in the URA UPDATE CONFIRM message.

After step 3 and if K is greater than N302, the UE shall stop transmitting URA UPDATE message and then enters idle state.

8.3.2.7 ——— URA Update: Success after T302 timeout

8.3.2.7.1 ——— Definition

8.3.2.7.2 ——— Conformance requirement

The UE transmits an URA UPDATE message to the UTRAN when it needs to update UTRAN with the current URA identity stored the UE. When the UE fails to receive any URA UPDATE CONFIRM message after T302 timer expires, it transmits a URA UPDATE message repeatedly at an interval of T302 timer value until its internal counter V302 is greater than N302.

Reference

3GPP TS 25.331 clause 8.3.1

8.3.2.7.3 ——— Test purpose

To confirm that the UE attempts to repeat the URA update procedure upon the expiry of timer T302.

~~8.3.2.7.4 Method of test~~

~~Initial Condition~~

~~System Simulator: 1 cell~~

~~UE: URA\_PCH (state 6-13) as specified in clause 7.4 of TS 34.108.~~

~~Test Procedure~~

~~The UE is in URA\_PCH. When the UE detects the expiry of timer T305 according to the system information, the UE moves to CELL\_FACH state and transmits a URA UPDATE message to the SS on the uplink CCCH, setting value "periodic URA update" into IE "URA update cause". The SS ignores this message. The UE shall then retry to transmit a URA UPDATE message after the expiry of timer T302. SS transmits a URA UPDATE CONFIRM message to the UE to end the procedure.~~

~~Expected sequence~~

| Step | Direction |    | Message            | Comment                                                                                                             |
|------|-----------|----|--------------------|---------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                     |
| 1    |           |    |                    | The UE is in URA_PCH state at the beginning of test. SS waits for T305 to expire.                                   |
| 2    |           | →  | URA UPDATE         | This message shall contain value "periodic URA update" in IE "URA update cause" sent upon the expiry of timer T305. |
| 3    |           |    |                    | SS shall not reply.                                                                                                 |
| 4    |           | →  | URA UPDATE         | This message shall contain value "periodic URA update" in IE "URA update cause" sent upon the expiry of timer T302. |
| 5    |           | ←  | URA UPDATE CONFIRM |                                                                                                                     |

~~Specific Message Contents~~

~~URA UPDATE CONFIRM (Step 5)~~

~~Use the same message sub-type as in Annex A.~~

~~8.3.2.7.5 Test requirement~~

~~After step 1 the UE shall detect the expiry of timer T305, then it shall move to CELL\_FACH state and transmit a URA UPDATE message on the uplink CCCH. The updating cause shall be set to "periodic URA update" in IE "URA update cause".~~

~~After step 3 the UE shall retry to transmit a URA UPDATE message at the expiry of timer T302.~~

~~8.3.2.8 Void~~

~~8.3.2.9 URA Update: Failure (UTRAN initiate an RRC connection release procedure on CCCH)~~

~~8.3.2.9.1 Definition~~

~~8.3.2.9.2 Conformance requirement~~

~~The UE transmits a URA UPDATE message to the UTRAN when it needs to update UTRAN with information on the current URA of the UE. If the UE receives a RRC CONNECTION RELEASE message on downlink CCCH, it shall enter idle state.~~

## Reference

3GPP TS 25.331 clause 8.3.1

## 8.3.2.9.3 Test purpose

To confirm that the UE moves to idle state upon the reception of RRC CONNECTION RELEASE message on downlink CCCH during a URA update procedure.

## 8.3.2.9.4 Method of test

## Initial Condition

System Simulator: 1 cell

UE: URA\_PCH (state 6-13) as specified in clause 7.4 of TS 34.108.

## Test Procedure

The UE is in URA\_PCH state. When the UE detects the expiry of periodic URA updating timer T305, the UE moves to CELL\_FACH state and transmits a URA UPDATE message to the SS on the uplink CCCH. The message shall indicate the cause to be "periodic URA update" in IE "URA update cause". The SS transmits RRC CONNECTION RELEASE message on downlink CCCH. The UE shall return to idle mode after release of all current signalling flows and radio access bearers.

## Expected sequence

| Step | Direction |    | Message                | Comment                                                                                        |
|------|-----------|----|------------------------|------------------------------------------------------------------------------------------------|
|      | UE        | SS |                        |                                                                                                |
| 1    |           |    |                        | The UE is in the URA_PCH state. SS wait until T305 timer has expired.                          |
| 2    |           | →  | URA UPDATE             | UE shall transmit this message and set value "periodic URA update" into IE "URA update cause". |
| 3    |           | ←  | RRC CONNECTION RELEASE | SS transmits RRC CONNECTION RELEASE message to the UE on the downlink CCCH.                    |
| 4    |           |    |                        | The UE releases L2 signalling radio bearer and radio resources then the UE goes to idle mode.  |

## Specific Message Contents

## URA UPDATE (Step 2)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| - SRNC Identity     | Check to see if set to '0000-0000-0001'           |
| - S-RNTI            | Check to see if set to '0000-0000-0000-0000-0001' |
| URA Update Cause    | Check to see if set to 'Periodic URA update'      |

## RRC CONNECTION RELEASE (Step 3)

Use the same message sub-type found in Annex A



### 8.3.2.9.5 ——— Test requirement

After step 1 the UE shall transmit a URA UPDATE message on the uplink CCCH and set value "periodic URA update" into IE "Cell update cause".

After step 3 the UE shall enter idle state.

### 8.3.2.10 ——— URA Update: Reception of URA UPDATE CONFIRM message that causes invalid configuration

#### 8.3.2.10.1 ——— Definition

#### 8.3.2.10.2 ——— Conformance Requirement

If the UE encounters a URA UPDATE CONFIRM message that set the variable INVALID\_CONFIGURATION to TRUE while executing a URA update procedure, it shall check the current value of its internal counter V302. If V302 is not greater than N302, the UE shall re-transmits URA UPDATE message on uplink CCCH, restart T302 timer and increments V302. On the other hand, if V302 is greater than N302, the UE shall abandon cell update procedure and enters idle mode.

#### 8.3.2.10.3 ——— Test Purpose

To confirm that the UE retransmits a URA UPDATE message when it receives a URA UPDATE CONFIRM message that will trigger an invalid configuration in the UE, if the number of retransmissions has not reached the maximum allowed value.

#### 8.3.2.10.4 ——— Method of Test

##### Initial Condition

System Simulator: 1 cell

UE: URA\_PCH (state 6-13) as specified in clause 7.4 of TS 34.108.

##### Test Procedure

The UE is in URA\_PCH state. When the UE detects the expiry of timer T305 according to the system information, the UE moves to CELL\_FACH state and transmits a URA UPDATE message to the SS on the uplink CCCH. This message shall contain value "periodical URA update" in IE "URA update cause". Upon receiving such a message, the SS replies with a URA UPDATE CONFIRM message with IE "RRC State Indicator" set to "CELL\_DCH". The UE shall detect its variable "invalid configuration" is set and re-transmit URA UPDATE message. SS then transmit a valid URA UPDATE CONFIRM UPDATE message to end the procedure.

## Expected Sequence

| Step | Direction |    | Message            | Comment                                                                                                                                  |
|------|-----------|----|--------------------|------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                          |
| 1    |           |    |                    | The UE is in the URA_PCH state. SS wait until T305 timer has expired.                                                                    |
| 2    |           | →  | URA UPDATE         | UE shall transmit this message and set value "periodic URA update" into IE "URA update cause".                                           |
| 3    |           | ←  | URA UPDATE CONFIRM |                                                                                                                                          |
| 4    |           | →  | URA UPDATE         | IE "Protocol error indicator" is set to TRUE and IE "Protocol error information" is set to "Information element value not comprehended". |
| 5    |           |    | Void               |                                                                                                                                          |
| 6    |           |    | Void               |                                                                                                                                          |
| 7    |           | ←  | URA UPDATE CONFIRM |                                                                                                                                          |

## URA UPDATE (Step 2)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| - SRNC Identity     | Check to see if set to '0000-0000-0001'           |
| - S-RNTI            | Check to see if set to '0000-0000-0000-0000-0001' |
| URA Update Cause    | Check to see if set to 'Periodic URA update'      |

## URA UPDATE (Step 4)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element        | Value/remark                                      |
|----------------------------|---------------------------------------------------|
| U-RNTI                     |                                                   |
| - SRNC Identity            | Check to see if set to '0000-0000-0001'           |
| - S-RNTI                   | Check to see if set to '0000-0000-0000-0000-0001' |
| URA Update Cause           | Check to see if set to 'Periodic URA update'      |
| Protocol error indicator   | TRUE                                              |
| Protocol error information |                                                   |
| → Protocol error cause     | Information element value not comprehended        |

## URA UPDATE CONFIRM (Step 3)

Use the same message sub-type found in Annex A, with the following exception:

| Information Element | Value/remark |
|---------------------|--------------|
| RRC State Indicator | CELL_DCH     |

## 8.3.2.10.5 ——— Test Requirement

After step 1 the UE shall detect the expiry of timer T305, then it shall move to CELL\_FACH state and transmit a URA UPDATE message on the uplink CCCH, setting value "periodic URA update" into IE "URA update cause".

After step 3 the UE shall transmit a URA UPDATE message on the uplink CCCH, setting value "TRUE" in IE "URA update cause" and value "Information element value not comprehended" in "Protocol error cause".

### ~~8.3.2.11 URA Update: Cell reselection to cell of another PLMN belonging to the equivalent PLMN list~~

#### ~~8.3.2.11.1 Definition~~

#### ~~8.3.2.11.2 Conformance requirement~~

~~1. A UE in URA\_PCH state shall initiate the URA update procedure in the following cases:~~

~~— URA reselection:~~

- ~~— if the UE detects that the current URA assigned to the UE, stored in the variable URA\_IDENTITY, is not present in the list of URA identities in system information block type 2; or~~
- ~~— if the list of URA identities in system information block type 2 is empty; or~~
- ~~— if the system information block type 2 can not be found:~~
  - ~~— perform URA update using the cause "change of URA".~~

~~2. A "suitable cell" is a cell on which the UE may camp on to obtain normal service. Such a cell shall fulfil all the following requirements:~~

- ~~— The cell is part of the selected PLMN or, of a PLMN considered as equivalent by the UE according to the information provided by the NAS.~~
- ~~— The cell is not barred, see clause 5.3.4.1.~~
- ~~— The cell is not part of the list of "forbidden LAs for roaming" [9]~~
- ~~— The cell selection criteria are fulfilled, see clause 5.2.3.1.2.~~

~~3. The Mobile Equipment shall store a list of "equivalent PLMNs". This list is replaced or deleted at the end of each location update procedure, routing area update procedure and GPRS attach procedure. The stored list consists of a list of equivalent PLMNs as downloaded by the network plus the PLMN code of the network that downloaded the list. The stored list shall not be deleted when the MS is switched off. The stored list shall be deleted if the SIM is removed. The maximum number of possible entries in the stored list is six.~~

#### Reference

3GPP TS 25.331 clause 8.3.1.2.

3GPP TS 25.304 clause 4.3.

3GPP TS 24.008 clause 4.4.1.

#### ~~8.3.2.11.3 Test purpose~~

~~1. To confirm that the UE executes a URA update procedure after a successful reselection of another UTRA cell with a URA identity that is not the URA of the UE and with a PLMN identity different from the original cell but with a PLMN that is part of the equivalent PLMN list in the UE. To confirm that the UE sends the correct uplink response message when executing cell update procedure due to cell reselection.~~

~~NOTE: Verifies conformance requirements 1, 2 and 3.~~

~~2. To confirm that the UE refrains from executing a URA update procedure to a better UTRA cell with another PLMN identity when that PLMN identity is not part of the equivalent PLMN list in the UE.~~

~~NOTE: Test case in 8.3.2.1 is a test where the UE reselects to a cell with the same PLMN identity as the registered PLMN.~~

#### 8.3.2.11.4 Method of test

##### Initial Condition

System Simulator: 3 cells – Cell 1 is active, with the downlink transmission power shown in column marked "T0" in table 8.3.2.1-1, while cell 2 and cell 3 is inactive.

UE: URA\_PCH (state 6-13) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

UE: Shall have stored equivalent PLMN list containing PLMN-1 and PLMN-2. The equivalent PLMN list stored in the UE shall not contain PLMN-3. The UE shall also have stored the URA identity URA-ID 1 from the list of URA-IDs in cell 1.

##### Test Procedure

**Table 8.3.2.11-1**

| Parameter              | Unit | Cell 1   |     |     | Cell 2                 |     |     | Cell 3                 |                        |     |
|------------------------|------|----------|-----|-----|------------------------|-----|-----|------------------------|------------------------|-----|
|                        |      | T0       | T1  | T2  | T0                     | T1  | T2  | T0                     | T1                     | T2  |
| UTRA-RF Channel Number |      | Ch. 1    |     |     | Ch. 1                  |     |     | Ch. 1                  |                        |     |
| PLMN identity          |      | PLMN-1   |     |     | PLMN-2                 |     |     | PLMN-3                 |                        |     |
| URA identity           |      | URA-ID 1 |     |     | URA-ID 2               |     |     | URA-ID 3               |                        |     |
| CPICH RSCP             | dBm  | -73      | -79 | -79 | Cell 2 is switched off | -73 | -79 | Cell 3 is switched off | Cell 3 is switched off | -73 |

Table 8.3.2.11-1 illustrates the downlink power to be applied for the 3 cells at various time instants of the test execution. Columns marked "T0" denote the initial conditions, while columns marked "T1" and "T2" are to be applied subsequently.

- At T0, the SS activates Cell 1.
- At T1, the SS activates Cell 2, and monitors Cell 2 for received messages from UE.
- UE re-selects to Cell 2, and sends a URA UPDATE message
- At T2, the SS activates Cell 3, and monitors Cell 3 for received messages from UE.

##### Expected sequence

| Step | Direction |    | Message                            | Comment                                                                          |
|------|-----------|----|------------------------------------|----------------------------------------------------------------------------------|
|      | UE        | SS |                                    |                                                                                  |
| 1    |           |    |                                    | At T0: UE is camped on Cell 1 and registered to PLMN1                            |
| 2    |           | →  | URA UPDATE                         | At T1: Sent in Cell 2<br>The value "change of URA" set in IE "URA update cause". |
| 3    |           | ←  | URA UPDATE CONFIRM                 |                                                                                  |
| 4    |           | →  | UTRAN-MOBILITY INFORMATION CONFIRM |                                                                                  |

##### Specific Message Contents

FFS

#### 8.3.2.11.5 ~~Test requirement~~

The UE shall send a URA UPATE message after T1 and refrain from sending a URA update (or any other message) after T2.

#### 8.3.2.12 ~~Restricted cell reselection to a cell belonging to forbidden LA list (URA\_PCH)~~

##### 8.3.2.12.1 ~~Definition~~

##### 8.3.2.12.2 ~~Conformance requirement~~

1. A UE in URA\_PCH state shall initiate the URA update procedure in the following cases:

— URA reselection:

- if the UE detects that the current URA assigned to the UE, stored in the variable URA\_IDENTITY, is not present in the list of URA identities in system information block type 2; or
- if the list of URA identities in system information block type 2 is empty; or
- if the system information block type 2 can not be found:
  - perform URA update using the cause "change of URA".

2. A "suitable cell" is a cell on which the UE may camp on to obtain normal service. Such a cell shall fulfil all the following requirements:

- The cell is part of the selected PLMN or, of a PLMN considered as equivalent by the UE according to the information provided by the NAS.
- The cell is not barred, see clause 5.3.4.1.
- The cell is not part of the list of "forbidden LAs for roaming" [9]
- The cell selection criteria are fulfilled, see clause 5.2.3.1.2.

3. The Mobile Equipment shall contain a list of "forbidden location areas for roaming", as well as a list of "forbidden location areas for regional provision of service". These lists shall be erased when the MS is switched off or when the SIM is removed, and periodically (with period in the range 12 to 24 hours). The location area identification received on the BCCH that triggered the location updating request shall be added to the suitable list whenever a location update reject message is received with the cause "Roaming not allowed in this location area" or with the cause "Location Area not allowed". The lists shall accommodate each 10 or more location area identifications. When the list is full and a new entry has to be inserted, the oldest entry shall be deleted.

#### Reference

3GPP TS 25.331 clause 8.3.1.2.

3GPP TS 25.304 clause 4.3.

3GPP TS 24.008 clause 4.4.1.

#### 8.3.2.12.3 ~~Test purpose~~

To confirm that the UE refrains from selects a UTRA cell and performs a URA update if that cell has a LA identity that is part of the list of LAs stored in the UE as "forbidden location areas for roaming".

NOTE: — Test case in 8.3.2.1 is a test where the UE reselects to a cell with the same LA identity as the LA identity in the original cell.

#### 8.3.2.12.4 Method of test

##### Initial Condition

System Simulator: 2 cells – Cell 1 is active, with the downlink transmission power shown in column marked "T0" in table 8.3.2.1-1, while cell 2 is inactive.

UE: URA\_PCH (state 6-13) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE.

UE: Shall have stored LA-ID 2 into the list of "forbidden location areas for roaming". The UE shall also have stored the URA identity URA-ID 1 from the list of URA-IDs in cell 1.

##### Test Procedure

**Table 8.3.2.12-1**

| Parameter              | Unit | Cell 1   |     | Cell 2                 |     |
|------------------------|------|----------|-----|------------------------|-----|
|                        |      | T0       | T1  | T0                     | T1  |
| UTRA-RF Channel Number |      | Ch. 1    |     | Ch. 1                  |     |
| URA identity           |      | URA-ID 1 |     | URA-ID 2               |     |
| LA identity            |      | LA-ID 1  |     | LA-ID 2                |     |
| CPICH RSCP             | dBm  | -73      | -79 | Cell 2 is switched-off | -73 |

Table 8.3.2.12-1 illustrates the downlink power to be applied for the 2-cells at various time instants of the test execution. Columns marked "T0" denote the initial conditions, while columns marked "T1" and "T2" are to be applied subsequently.

- a) At T1, verify that the UE does not reselect to cell 2 and not send a URA update in cell 2, although cell 2 is the best cell.

##### Expected sequence

-

##### Specific Message Contents

-

#### 8.3.2.12.5 Test requirement

The UE shall not send a URA UPDATE (or any other message) in Cell 2 after T1.

### 8.3.2.13 URA Update: Change of URA due to HCS Cell Reselection

#### 8.3.2.13.1 Definition

#### 8.3.2.13.2 Conformance requirement

This procedure is to update UTRAN with the current URA of the UE after a change of URA has occurred in URA\_PCH state with HCS parameter applied. It may also be used for supervision of the RRC connection, even if no change of URA takes place.

##### Reference

3GPP TS 25.331 clause 8.3.1.

3GPP TS 25.304 clause 5.2.6.1.4.

3GPP TS 25.304 clause 5.4.3.

### 8.3.2.13.3 ~~Test purpose~~

~~To confirm that the UE can read HCS related SIB information and act upon all HCS parameters. To confirm that the UE executes an URA update procedure after the successful change of URA due to HCS Cell Reselection. To confirm UE responds correctly when it re-selects to a new cell while waiting from URA UPDATE CONFIRM message from SS.~~

### 8.3.2.13.4 ~~Method of test~~

#### Initial Condition

System Simulator: 3 cells – Cell 1 is active with URA-ID 1 and downlink transmission power shown in column marked "T0" in table 8.3.2.11-1. Cell2 with URA-ID 1 and Cell 3 with URA-ID 2 are switched off

UE: URA\_PCH (state 6-13) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE, with URA-ID 1 from the list of URA-ID in cell 1

#### Specific Message Content

For system information blocks 3, 4, 11 & 12 for Cell 1 (gives IE's which are different from defaults given in 34.108 sec 6.1) to be transmitted before idle update preamble.

#### Contents of System Information Block type 3 (FDD)

| Information Element                              | Value/remark                        |
|--------------------------------------------------|-------------------------------------|
| → SIB4 indicator                                 | TRUE                                |
| → Cell identity                                  | 0000-0000-0000-0000-0000-0000-0001B |
| → Cell selection and re-selection info           |                                     |
| → Mapping info                                   | Not Present                         |
| → Cell selection_and_reselection_quality_measure | CPICH RSCP                          |
| → CHOICE mode                                    | FDD                                 |
| → Sintrasearch                                   | 16 dB                               |
| → Sintersearch                                   | 16 dB                               |
| → SsearchHCS                                     | 53 dB                               |
| → RAT List                                       | This parameter is configurable      |
| → RAT identifier                                 | GSM                                 |
| → Ssearch,RAT                                    | -32 dB                              |
| → SHCS,RAT                                       | Not Present                         |
| → Slimit,SearchRAT                               | Not Present                         |
| → Qqualmin                                       | -20 dB                              |
| → Qrxlevmin                                      | -115 dBm                            |
| → Qhyst1s                                        | 10 (gives actual value of 20 dB)    |
| → Qhyst2s                                        | 0 dB                                |
| → Treselections                                  | 0 seconds                           |
| → HCS Serving cell information                   |                                     |
| → HCS Priority                                   | -6                                  |
| → Q-HCS                                          | 39 (results in actual value of -76) |
| → TerMax                                         | Not Present                         |

## Contents of System Information Block type 4 (FDD)

| Information Element                              | Value/remark                        |
|--------------------------------------------------|-------------------------------------|
| → Cell identity                                  | 0000 0000 0000 0000 0000 0000 0001B |
| → Cell selection and re-selection info           |                                     |
| → Mapping Info                                   | Not present                         |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                          |
| → CHOICE mode                                    | FDD                                 |
| → Sintrasearch                                   | 16 dB                               |
| → Sintersearch                                   | 16 dB                               |
| → SsearchHCS                                     | 53 dB                               |
| → RAT List                                       | This parameter is configurable      |
| → RAT identifier                                 | GSM                                 |
| → Ssearch,RAT                                    | -32 dB                              |
| → SHCS,RAT                                       | Not Present                         |
| → Slimit,SearchRAT                               | Not Present                         |
| → Qqualmin                                       | -20 dB                              |
| → Qrxlevmin                                      | -115 dBm                            |
| → Qhyst1s                                        | 10 (gives actual value of 20 dB)    |
| → Qhyst2s                                        | 0 dB                                |
| → Treselections                                  | 0 seconds                           |
| → HCS Serving cell information                   |                                     |
| → HCS Priority                                   | -6                                  |
| → Q-HCS                                          | 39 (results in actual value of -76) |
| → TcrMax                                         | Not Present                         |



## Contents of System Information Block type 11 (FDD) (Cell 1)

| Information Element                              | Value/remark                                                                |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Measurement control system information         | used                                                                        |
| → Use of HCS                                     | CPICH RSCP                                                                  |
| → Cell_selection_and_reselection_quality_measure |                                                                             |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.2 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20 dB                                                                      |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.3 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20dB                                                                       |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## Contents of System Information Block type 12 in connected mode (FDD) (Cell 1)

| Information Element                      | Value/remark |
|------------------------------------------|--------------|
| → Measurement control system information |              |

|                                                  |                                                                             |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Use of HCS                                     | used                                                                        |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                                                                  |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.2 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1 <sub>s,n</sub>                        | -20 dB                                                                      |
| → Qoffset2 <sub>s,n</sub>                        | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.3 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1 <sub>s,n</sub>                        | -20 dB                                                                      |
| → Qoffset2 <sub>s,n</sub>                        | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | 39 (results in actual value of -76)                                         |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## Test Procedure

Table 8.3.2.13-1

| Parameter              | Unit | Cell 1 |     |     | Cell 2 |     |     | Cell 3 |     |     |
|------------------------|------|--------|-----|-----|--------|-----|-----|--------|-----|-----|
|                        |      | T0     | T1  | T2  | T0     | T1  | T2  | T0     | T1  | T2  |
| UTRA RF Channel Number |      | Ch. 1  |     |     | Ch. 1  |     |     | Ch. 1  |     |     |
| CPICH RSCP             | dBm  | -61    | -61 | -61 | -80    | -80 | -67 | -80    | -73 | -73 |
| H* (After PenaltyTime) |      | 15     | 15  | 15  | -5     | -5  | 9   | -5     | 3   | 3   |
| R* (After PenaltyTime) |      | -41    | -41 | -41 | -60    | -60 | -47 | -60    | -53 | -53 |

\* this parameter is calculated internally in the UE and is only shown for clarification of the test procedure.

The UE is in the URA\_PCH state and assigned with only 1 URA identity in cell 1: URA-ID 1. SS configures Cell 2 and 3 with power level given in column "T0", and URA-Id 1 and 2 respectively and starts broadcast of BCCH on the primary CCCH in cells 2 and 3. UE shall remain camped on the Cell 1 even after expiry of penalty time i.e. 40 seconds. SS sets downlink transmission power settings according to columns "T1" in table 8.3.2.13-1. SS then adjusts the transmission power again according to 'T1' column. This is expected to cause the UE to perform a cell reselection to cell 3 after at least 40 Seconds (Penalty Time) after the power levels have been changed. UE on performing cell reselection to cell 3 finds that its current URA-ID 1 is not in the new broadcasted list of URA-IDs, it moves to CELL\_FACH state and transmits a URA UPDATE message on the uplink CCCH. After the SS receives this message, it transmits URA UPDATE CONFIRM message which includes the IEs "RRC State Indicator" and "URA-ID" to the UE on the downlink DCCH. The "RRC State Indicator" is set to "URA\_PCH". UE returns to URA\_PCH state in cell 3 without sending a uplink response message. Next SS adjusts the transmission power according to 'T2' column. UE shall re-select to cell 2 after atleast penalty time of 40 seconds, and transmit URA UPDATE message to SS. However, SS do not acknowledge but adjusts the transmission power according to 'T0' column. UE shall perform cell re-selection to cell 1 and then sent URA UPDATE message to SS. Finally SS shall transmit URA UPDATE CONFIRM message to UE.

## Expected sequence

| Step | Direction |    | Message            | Comment                                                                                                                                                                                                                                                                 |
|------|-----------|----|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                                                                                                                                                         |
| 1    |           |    |                    | The UE is updated with only 1 URA identity carried currently by cell 1. The starting state of the UE is URA_PCH                                                                                                                                                         |
| 2    |           | ←  | BCCH               | SS configures cell 2 (with URA-ID 1) and Cell 3 (with URA-ID 2) and power levels as given in column T0 of table 8.3.2.13-1 and starts transmission of BCCH.                                                                                                             |
| 3    |           |    |                    | UE shall Remain camped on Cell 1 and in URA_PCH state even after expiry of Penalty time.                                                                                                                                                                                |
| 4    |           |    |                    | SS set the power transmission of all cells according to column 'T1' of table 8.3.2.13-1.                                                                                                                                                                                |
| 5    |           | →  | URA UPDATE         | The UE shall perform a cell reselection first after the penalty time to cell 3 and when it finds that its current URA-ID 1 is not in the new broadcasted list of URA-IDs, it shall then transmit this message and set value "change of URA" into IE "URA update cause". |
| 6    |           | ←  | URA UPDATE CONFIRM | Message comprises IE "RRC State Indicator" set "URA_PCH", and also IE "URA Identity" equals to "URA-ID 2".                                                                                                                                                              |
| 7    |           |    |                    | SS set the power transmission of all cells according to column 'T2' of table 8.3.2.13-1.                                                                                                                                                                                |
| 8    |           | →  | URA UPDATE         | In Cell 2                                                                                                                                                                                                                                                               |
| 9    |           |    |                    | SS do not respond to the URA UPDATE message from UE and set the power transmission of all cells according to column 'T0' of table 8.3.2.13-1.                                                                                                                           |
| 10   |           | →  | URA UPDATE         |                                                                                                                                                                                                                                                                         |
| 11   |           | ←  | URA UPDATE CONFIRM |                                                                                                                                                                                                                                                                         |

## Specific Message Contents

## Contents of System Information Block type 3 (FDD) (Cell 2 and 3)

| Information Element                              | Value/remark                        |
|--------------------------------------------------|-------------------------------------|
| → SIB4 indicator                                 | TRUE                                |
| → Cell identity                                  | 0000 0000 0000 0000 0000 0000 0001B |
| → Cell selection and re-selection info           |                                     |
| → Mapping info                                   | Not Present                         |
| → Cell selection_and_reselection_quality_measure | CPICH RSCP                          |
| → CHOICE mode                                    | FDD                                 |
| → Sintrasearch                                   | 16 dB                               |
| → Sintersearch                                   | 16 dB                               |
| → SsearchHCS                                     | 53 dB                               |
| → RAT List                                       | This parameter is configurable      |
| → RAT identifier                                 | GSM                                 |
| → Ssearch,RAT                                    | -32 dB                              |
| → SHCS,RAT                                       | Not Present                         |
| → Slimit,SearchRAT                               | Not Present                         |
| → Qqualmin                                       | -20 dB                              |
| → Qrxlevmin                                      | -115 dBm                            |
| → Qhyst1s                                        | 10 (gives actual value of 20 dB)    |
| → Qhyst2s                                        | 0 dB                                |
| → Treselections                                  | 0 seconds                           |
| → HCS Serving cell information                   |                                     |
| → HCS Priority                                   | -7                                  |
| → Q-HCS                                          | 39 (results in actual value of -76) |
| → TerMax                                         | Not Present                         |

## Contents of System Information Block type 4 (FDD) (Cell 2 and 3)

| Information Element                              | Value/remark                        |
|--------------------------------------------------|-------------------------------------|
| → Cell identity                                  | 0000 0000 0000 0000 0000 0000 0001B |
| → Cell selection and re-selection info           |                                     |
| → Mapping Info                                   | Not present                         |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                          |
| → CHOICE mode                                    | FDD                                 |
| → Sintrasearch                                   | 16 dB                               |
| → Sintersearch                                   | 16 dB                               |
| → SsearchHCS                                     | 53 dB                               |
| → RAT List                                       | This parameter is configurable      |
| → RAT identifier                                 | GSM                                 |
| → Ssearch,RAT                                    | -32 dB                              |
| → SHCS,RAT                                       | Not Present                         |
| → Slimit,SearchRAT                               | Not Present                         |
| → Qqualmin                                       | -20 dB                              |
| → Qrxlevmin                                      | -115 dBm                            |
| → Qhyst1s                                        | 10 (gives actual value of 20 dB)    |
| → Qhyst2s                                        | 0 dB                                |
| → Treselections                                  | 0 seconds                           |
| → HCS Serving cell information                   |                                     |
| → HCS Priority                                   | -7                                  |
| → Q-HCS                                          | 39 (results in actual value of -76) |
| → TerMax                                         | Not Present                         |

## Contents of System Information Block type 11 (FDD) (Cell 2)

| Information Element                              | Value/remark                                                                |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Measurement control system information         | used                                                                        |
| → Use of HCS                                     | CPICH RSCP                                                                  |
| → Cell_selection_and_reselection_quality_measure |                                                                             |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.3 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20dB                                                                       |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | -20dB                                                                       |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.1 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20 dB                                                                      |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -6                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## Contents of System Information Block type 12 in connected mode (FDD) (Cell 2)

| Information Element                      | Value/remark |
|------------------------------------------|--------------|
| → Measurement control system information |              |

|                                                  |                                                                             |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Use of HCS                                     | used                                                                        |
| → Cell_selection_and_reselection_quality_measure | CPICH RSCP                                                                  |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.3 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1 <sub>s,n</sub>                        | -20 dB                                                                      |
| → Qoffset2 <sub>s,n</sub>                        | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.1 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1 <sub>s,n</sub>                        | -20 dB                                                                      |
| → Qoffset2 <sub>s,n</sub>                        | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -6                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## Contents of System Information Block type 11 (FDD) (Cell 3)

| Information Element                              | Value/remark                                                                |
|--------------------------------------------------|-----------------------------------------------------------------------------|
| → Measurement control system information         | used                                                                        |
| → Use of HCS                                     | CPICH RSCP                                                                  |
| → Cell_selection_and_reselection_quality_measure |                                                                             |
| → Intra-frequency measurement system information |                                                                             |
| → Intra-frequency measurement identity           | 1                                                                           |
| → Intra-frequency cell info list                 |                                                                             |
| → CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| → New intra-frequency cells                      |                                                                             |
| → Intra-frequency cell id                        | 1                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.1 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20 dB                                                                      |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -6                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | 40                                                                          |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |
| → Intra-frequency cell id                        | 2                                                                           |
| → Cell info                                      |                                                                             |
| → Cell individual offset                         | 0dB                                                                         |
| → Reference time difference to cell              | Not Present                                                                 |
| → CHOICE mode                                    | FDD                                                                         |
| → Primary CPICH info                             |                                                                             |
| → Primary scrambling code                        | Refer to clause titled "Default settings for cell No.2 (FDD)" in clause 6.1 |
| → Primary CPICH TX power                         | Not Present                                                                 |
| → Read SFN indicator                             | TRUE                                                                        |
| → TX Diversity indicator                         | FALSE                                                                       |
| → Cell Selection and Re-selection info           |                                                                             |
| → Qoffset1s,n                                    | -20 dB                                                                      |
| → Qoffset2s,n                                    | Not Present                                                                 |
| → Maximum allowed UL TX power                    | 33 dBm                                                                      |
| → HCS neighbouring cell information              | Present                                                                     |
| → HCS_Priority                                   | -7                                                                          |
| → Q_HCS                                          | -39 (results in actual value of -76)                                        |
| → HCS Cell Reselection Information               |                                                                             |
| → Penalty Time                                   | -40                                                                         |
| → Temporary Offset                               | -10                                                                         |
| → CHOICE mode                                    | FDD                                                                         |
| → Qqualmin                                       | -20 dB                                                                      |
| → Qrxlevmin                                      | -115 dBm                                                                    |

## Contents of System Information Block type 12 in connected mode (FDD) (Cell 3)

| Information Element                      | Value/remark |
|------------------------------------------|--------------|
| → Measurement control system information |              |
| → Use of HCS                             | used         |



|                                                 |                                                                             |
|-------------------------------------------------|-----------------------------------------------------------------------------|
| →Cell_selection_and_reselection_quality_measure | CPICH RSCP                                                                  |
| →Intra-frequency measurement system information |                                                                             |
| →Intra-frequency measurement identity           | 1                                                                           |
| →Intra-frequency cell info list                 |                                                                             |
| →CHOICE intra-frequency cell removal            | Remove no intra-frequency cells                                             |
| →New intra-frequency cells                      |                                                                             |
| →Intra-frequency cell id                        | 1                                                                           |
| →Cell info                                      |                                                                             |
| →Cell individual offset                         | 0dB                                                                         |
| →Reference time difference to cell              | Not Present                                                                 |
| →CHOICE mode                                    | FDD                                                                         |
| →Primary CPICH info                             |                                                                             |
| →Primary scrambling code                        | Refer to clause titled "Default settings for cell No.1 (FDD)" in clause 6.1 |
| →Primary CPICH TX power                         | Not Present                                                                 |
| →Read SFN indicator                             | TRUE                                                                        |
| →TX Diversity indicator                         | FALSE                                                                       |
| →Cell Selection and Re-selection info           |                                                                             |
| →Qoffset1s,n                                    | -20 dB                                                                      |
| →Qoffset2s,n                                    | Not Present                                                                 |
| →Maximum allowed UL TX power                    | 33 dBm                                                                      |
| →HCS neighbouring cell information              | Present                                                                     |
| →HCS_Priority                                   | -6                                                                          |
| →Q_HCS                                          | -39 (results in actual value of -76)                                        |
| →HCS Cell Reselection Information               |                                                                             |
| →Penalty Time                                   | 40                                                                          |
| →Temporary Offset                               | -10                                                                         |
| →CHOICE mode                                    | FDD                                                                         |
| →Qqualmin                                       | -20 dB                                                                      |
| →Qrxlevmin                                      | -115 dBm                                                                    |
| →Intra-frequency cell id                        | 2                                                                           |
| →Cell info                                      |                                                                             |
| →Cell individual offset                         | 0dB                                                                         |
| →Reference time difference to cell              | Not Present                                                                 |
| →CHOICE mode                                    | FDD                                                                         |
| →Primary CPICH info                             |                                                                             |
| →Primary scrambling code                        | Refer to clause titled "Default settings for cell No.2 (FDD)" in clause 6.1 |
| →Primary CPICH TX power                         | Not Present                                                                 |
| →Read SFN indicator                             | TRUE                                                                        |
| →TX Diversity indicator                         | FALSE                                                                       |
| →Cell Selection and Re-selection info           |                                                                             |
| →Qoffset1s,n                                    | -20 dB                                                                      |
| →Qoffset2s,n                                    | Not Present                                                                 |
| →Maximum allowed UL TX power                    | 33 dBm                                                                      |
| →HCS neighbouring cell information              | Present                                                                     |
| →HCS_Priority                                   | -7                                                                          |
| →Q_HCS                                          | -39 (results in actual value of -76)                                        |
| →HCS Cell Reselection Information               |                                                                             |
| →Penalty Time                                   | 40                                                                          |
| →Temporary Offset                               | -10                                                                         |
| →CHOICE mode                                    | FDD                                                                         |
| →Qqualmin                                       | -20 dB                                                                      |
| →Qrxlevmin                                      | -115 dBm                                                                    |

## URA UPDATE (Step 5, 8 and 10)

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| -SRNC Identity      | Check to see if set to '0000-0000-0001'           |
| -S-RNTI             | Check to see if set to '0000-0000-0000-0000-0001' |
| URA Update Cause    | Check to see if set to 'change of URA'            |

## URA UPDATE CONFIRM (Step 6)

Use the same message sub-type found in Annex A, with the following exceptions::

| Information Element | Value/remark |
|---------------------|--------------|
| URA identity        | URA-ID-2     |

## URA UPDATE CONFIRM (Step 11)

Use the same message sub-type found in Annex A, with the following exceptions::

| Information Element | Value/remark |
|---------------------|--------------|
| URA identity        | URA-ID-1     |

## 8.3.2.13.5 Test requirement

After step 4 the UE shall find that URA-ID 2 is not in its maintained list of URA-IDs. After cell reselection, the UE shall move to CELL\_FACH state and transmit URA UPDATE message setting value "change of URA" into IE "URA update cause".

After step 7 the UE shall find that URA-ID 1 is not in its maintained list of URA-IDs. After cell reselection, the UE shall move to CELL\_FACH state and transmit URA UPDATE message setting value "change of URA" into IE "URA update cause".

## 8.3.3. UTRAN Mobility Information

## 8.3.3.1 UTRAN Mobility Information: Success

## 8.3.3.1.1 Definition

## 8.3.3.1.2 Conformance requirement

This procedure is used by the network to assign a new RNTI identity to the UE. It is initiated by the UTRAN when it sends a UTRAN MOBILITY INFORMATION message, which includes a new C-RNTI and/or U-RNTI on the downlink DCCH. The UE starts to use the new identities and transmits an UTRAN MOBILITY INFORMATION CONFIRM message to the UTRAN on the uplink DCCH.

## Reference

3GPP TS 25.331 clause 8.3.3

## 8.3.3.1.3 Test purpose

To confirm that the UE starts to use the new identities after it receives a UTRAN MOBILITY INFORMATION message from the SS.

### 8.3.3.1.4 Method of test

#### Initial Condition

System Simulator: 1 cell

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

#### Test Procedure

Initially, the UE is in CELL\_FACH state and it has been assigned a C-RNTI and U-RNTI. The SS transmits an UTRAN MOBILITY INFORMATION message which includes new C-RNTI and U-RNTI to the UE. Then the UE shall transmit a UTRAN MOBILITY INFORMATION CONFIRM message as confirmation. SS waits for UE to perform periodic cell updating. When SS received a CELL UPDATE message, SS checks that UE uses the new U-RNTI in the CELL UPDATE message and the new C-RNTI in the MAC header. Then SS sends CELL UPDATE CONFIRM. SS waits for UE to perform periodic cell updating. When SS received a CELL UPDATE message, SS sends CELL UPDATE CONFIRM to end the test procedure.

#### Expected sequence

| Step | Direction |    | Message                            | Comment                                                                                                                                  |
|------|-----------|----|------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                    |                                                                                                                                          |
| 1    |           |    |                                    | The initial state of the UE is CELL_FACH state. UE has been allocated both C-RNTI and U-RNTI during RRC connection establishment phase.  |
| 2    |           | ←  | UTRAN MOBILITY INFORMATION         | Contains new C-RNTI and U-RNTI identities and a value for T305 that is different from the value defined in the system information.       |
| 3    |           | →  | UTRAN MOBILITY INFORMATION CONFIRM |                                                                                                                                          |
| 4    |           |    |                                    | SS wait for T305 (same as the value defined in system information) to expire.                                                            |
| 5    |           | →  | CELL UPDATE                        | UE shall trigger cell updating. The message shall indicate the same U-RNTI assigned in the UTRAN MOBILITY INFORMATION message in step 2. |
| 6    |           | ←  | CELL UPDATE CONFIRM                |                                                                                                                                          |
| 7    |           |    |                                    | SS wait for T305 (the new value as specified in step 2) to expire.                                                                       |
| 8    |           | →  | CELL UPDATE                        | UE shall trigger cell updating. The message shall indicate the same U-RNTI assigned in the UTRAN MOBILITY INFORMATION message in step 2. |
| 9    |           | ←  | CELL UPDATE CONFIRM                |                                                                                                                                          |

#### Specific Message Content

##### UTRAN MOBILITY INFORMATION (Step 2)

Use the same message sub-type as in Annex A, with the following exceptions:

| Information Element                                         | Value/remark                                                            |
|-------------------------------------------------------------|-------------------------------------------------------------------------|
| New U-RNTI<br>——→ SRNC Identity<br>——→ S-RNTI<br>New C-RNTI | '0000 0000 0001'<br>'0101 0101 0101 0101 0101'<br>'1010 1010 1010 1010' |
| UE Timers and constants in connected mode<br>——→ T305       | 5 minutes                                                               |

### UTRAN MOBILITY INFORMATION CONFIRM (Step 3)

Only the message type IE is checked in this message.

### CELL UPDATE (Step 5 and 8)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element                                            | Value/remark                                                                                                                                      |
|----------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| U-RNTI<br>——→ SRNC Identity<br>——→ S-RNTI<br>Cell Update Cause | Check to see if set to '0000 0000 0001'<br>Check to see if set to '0101 0101 0101 0101 0101'<br>Check to see if set to 'periodical cell updating' |

### CELL UPDATE CONFIRM (Step 6 and 9)

Use the same message sub-type as in Annex A.

#### 8.3.3.1.5 Test requirement

After step 2 the UE shall transmit a UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH.

After step 4 and 7 the UE shall transmit a CELL UPDATE message on the uplink CCCH with IE "Cell update cause" set to "periodical cell updating". The IE "U-RNTI" shall be identical to the IE "New RNTI" found in UTRAN MOBILITY INFORMATION message sent by the SS in step 2.

### 8.3.3.2 UTRAN Mobility Information: Failure (Invalid message reception)

#### 8.3.3.2.1 Definition

#### 8.3.3.2.2 Conformance Requirements

When the UE receives an invalid UTRAN MOBILITY INFORMATION message, it shall transmit a UTRAN MOBILITY INFORMATION FAILURE message on the DCCH using AM RLC and set the value "protocol error" in the IE "failure cause". The IE "protocol error information" in this message shall also be set to an appropriate value. The UE shall not utilize any identities relayed in the erroneous message, and it shall resume normal operations.

#### 8.3.3.2.3 Test Purpose

To confirm that the UE ignore the erroneous UTRAN MOBILITY INFORMATION message and report this event to the UTRAN by sending UTRAN MOBILITY INFORMATION FAILURE message, stating the appropriate failure cause and information.

#### 8.3.3.2.4 Method of test

#### Initial Conditions

System Simulator: 1 cell.

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108.

### Test Procedure

The UE is brought to CELL\_FACH state. SS transmits a UTRAN MOBILITY INFORMATION message to the UE on the DCCH using AM-RLC mode. In this message, the all IEs except "Message Type" are not present. The UE shall respond by transmitting the UTRAN MOBILITY INFORMATION FAILURE message, indicating "protocol error" in IE "failure cause" and also "ASN.1 violation and encoding error" in IE "Protocol error information". After receiving the UTRAN MOBILITY INFORMATION FAILURE message, SS waits for T305 to expire. The UE shall transmit a CELL UPDATE message with the original U-RNTI identity assigned. SS sends CELL UPDATE CONFIRM message to the UE on the downlink DCCH.

### Expected Sequence

| Step | Direction |    | Message                            | Comment                                                                                                                                          |
|------|-----------|----|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                    |                                                                                                                                                  |
| 1    |           |    |                                    | The initial state of the UE is CELL_FACH state.                                                                                                  |
| 2    |           | ←  | UTRAN MOBILITY INFORMATION         | See specific message content.                                                                                                                    |
| 3    |           | →  | UTRAN MOBILITY INFORMATION FAILURE | UE shall transmit this message to report the error in UTRAN MOBILITY INFORMATION message. It shall include the appropriate cause in the message. |
| 4    |           |    |                                    | SS waits for a period up to timer T305 to allow the UE to start performing a cell updating procedure.                                            |
| 5    |           | →  | CELL UPDATE                        |                                                                                                                                                  |
| 6    |           | ←  | CELL UPDATE CONFIRM                |                                                                                                                                                  |

### Specific Message Content

#### UTRAN MOBILITY INFORMATION (Step 2)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

#### UTRAN MOBILITY INFORMATION FAILURE (Step 3)

| Information Element                                                | Value/remark                                                                                                                                                                                                                                                        |
|--------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier<br>Integrity check info | Not checked.<br>The presence of this IE is dependent on I-XIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| Failure Cause<br>- Failure Cause<br>- Protocol Error Information   | Check to see if set to 'Protocol error'<br>Check to see if set to 'ASN.1 violation and encoding error'                                                                                                                                                              |

#### CELL UPDATE (Step 5)

The same message found in Annex A shall be transmitted by the UE on the uplink CCCH, with the exception of the following IEs:

| Information Element | Value/remark                                       |
|---------------------|----------------------------------------------------|
| U-RNTI              |                                                    |
| ——→ SRNC Identity   | Check to see if set to '0000-0000-0001'B           |
| ——→ S-RNTI          | Check to see if set to '0000-0000-0000-0000-0001'B |
| Cell update-cause   | Check to see if set to 'periodical-cell-updating'  |

### CELL UPDATE CONFIRM (Step 6)

Use the same message sub-type as in Annex A.

#### 8.3.3.2.5 ————— Test Requirement

After step 2 the UE shall transmit UTRAN MOBILITY INFORMATION FAILURE message, indicating the value "protocol error" in IE "failure-cause" and also "ASN.1 violation and encoding error" in IE "protocol error information".

After step 4 the UE shall initiate a periodic cell updating procedure by transmitting CELL UPDATE message on the CCCH. In this message, the U-RNTI identity shall be set to the same value as assigned during the RRC connection establishment procedure.

### 8.3.4 — Active set update in soft handover

#### 8.3.4.1 — Active set update in soft handover: Radio Link addition

##### 8.3.4.1.1 ————— Definition

##### 8.3.4.1.2 ————— Conformance requirement

Radio link addition is triggered in the network's RRC layer. The RRC entity in the network first configures the new radio link. Transmission and reception then begin immediately. This procedure is to update the active set of the connection between the UE and UTRAN. The UTRAN then transmits an ACTIVE SET UPDATE message to the UE. The UE configures layer 1 to begin reception for the additional radio link. After the UE receives confirmation from the physical layer in the UE, an ACTIVE SET UPDATE COMPLETE message is sent to the UTRAN.

#### Reference

3GPP TS 25.331 clause 8.3.4

##### 8.3.4.1.3 ————— Test purpose

To confirm that the UE continues to communicate with the SS on both the additional radio link and an already existing radio link after the radio link addition.

##### 8.3.4.1.4 ————— Method of test

#### Initial Condition

System Simulator: 2 cells – Cell 1 and 2 are active

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE.

Test Procedure

Table 8.3.4.1

| Parameter                    | Unit                | Cell 1 |     |     |     | Cell 2 |     |     |     |
|------------------------------|---------------------|--------|-----|-----|-----|--------|-----|-----|-----|
|                              |                     | T0     | T1  | T2  | T3  | T0     | T1  | T2  | T3  |
| UTRA—RF<br>Channel<br>Number |                     | Ch. 1  |     |     |     | Ch. 1  |     |     |     |
| CPICH Ec                     | dBm/<br>3.84<br>MHz | -60    | -60 | OFF | -60 | -75    | -60 | -60 | OFF |

Table 8.3.4.1 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution.

Initially, the UE establishes a radio-access bearer in CELL\_DCH state in cell 1. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.4.1. UE shall be triggered to transmit a MEASUREMENT REPORT message which includes the primary scrambling code for cell 2 according to IE "Intra-frequency event identity", which is set to '1a' in the SYSTEM INFORMATION BLOCK TYPE 11. After the MEASUREMENT REPORT message is received, the SS begins to configure the new radio link to be added from cell 2 and then the SS transmits to the UE an ACTIVE SET UPDATE message in cell 1 on DCCH using AM RLC which includes the IE "Radio Link Addition Information" (e.g. Downlink DPCH information and other optional parameters relevant for the additional radio links with Primary CPICH info used for the reference ID). When the UE receives this message, the UE shall configure layer 1 to begin reception without affecting the current uplink and downlink activities of existing radio links. The UE shall transmit an ACTIVE SET UPDATE COMPLETE message to the SS on the uplink DCCH using AM RLC. SS configures its downlink transmission power settings according to columns "T2" in table 8.3.4.1. UE shall not detect the DPCH from cell 1 but continue to communicate through the another DPCH from cell 2. SS shall transmit a UE CAPABILITY ENQUIRY message to confirm that the UE can respond this message through the DPCH in cell 2. The UE shall transmit a UE CAPABILITY ENQUIRY INFORMATION message. Then SS transmits a UE CAPABILITY INFORMATION CONFIRM message. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.4.1. UE shall detect DPCH from cell 1 and 2. And then SS configures its downlink transmission power settings according to columns "T3" in table 8.3.4.1. UE shall not detect the DPCH from cell 2 but continue to communicate through another DPCH from cell 1. SS shall transmit a UE CAPABILITY ENQUIRY message to confirm that the UE can respond this message through the DPCH in cell 1. The UE shall transmit a UE CAPABILITY ENQUIRY INFORMATION message. Then SS transmits a UE CAPABILITY INFORMATION CONFIRM message.

#### Expected sequence

| Step | Direction |    | Message                           | Comment                                                                                                                                                                                                                                                                                          |
|------|-----------|----|-----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                   |                                                                                                                                                                                                                                                                                                  |
| 1    |           |    |                                   | SS configures its downlink transmission power settings according to columns "T1" in table 8.3.4.1.                                                                                                                                                                                               |
| 2    | →         |    | MEASUREMENT REPORT                |                                                                                                                                                                                                                                                                                                  |
| 3    |           | ←  | ACTIVE SET UPDATE                 | SS transmits this message in cell 1 on downlink DCCH using AM RLC. The message includes IE "Radio Link Addition Information". (e.g. Downlink DPCH information and other optional parameters relevant for the additional radio links with Primary CPICH info used for the reference ID in cell 2) |
| 4    | →         |    | ACTIVE SET UPDATE COMPLETE        | The UE shall configure a new radio link to cell 2, without interfering with existing connections on the radio link in cell 1.                                                                                                                                                                    |
| 5    |           |    |                                   | SS configures its downlink transmission power settings according to columns "T2" in table 8.3.4.1                                                                                                                                                                                                |
| 6    | ←         |    | UE CAPABILITY ENQUIRY             | Use default message.                                                                                                                                                                                                                                                                             |
| 7    | →         |    | UE CAPABILITY INFORMATION         | Use default message.                                                                                                                                                                                                                                                                             |
| 8    | ←         |    | UE CAPABILITY INFORMATION CONFIRM | Use default message.                                                                                                                                                                                                                                                                             |
| 9    |           |    |                                   | SS configures its downlink transmission power settings according to columns "T1" in table 8.3.4.1                                                                                                                                                                                                |
| 10   |           |    |                                   | Wait 15 seconds and SS configures its downlink transmission power settings according to columns "T3" in table 8.3.4.1                                                                                                                                                                            |
| 11   | ←         |    | UE CAPABILITY ENQUIRY             | Use default message.                                                                                                                                                                                                                                                                             |
| 12   | →         |    | UE CAPABILITY INFORMATION         | Use default message.                                                                                                                                                                                                                                                                             |



|    |   |                                   |                      |
|----|---|-----------------------------------|----------------------|
| 13 | ← | UE CAPABILITY INFORMATION CONFIRM | Use default message. |
|----|---|-----------------------------------|----------------------|

## Specific Message Content

### MEASUREMENT REPORT

| Information Element                 | Value/remark                                                                                                                                                                                                                                        |
|-------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                        |                                                                                                                                                                                                                                                     |
| Integrity check info                | The presence of this IE is dependent on I-XIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| —— Message authentication code      | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                          |
| —— RRC Message sequence number      | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                    |
| Measurement identity                | 1                                                                                                                                                                                                                                                   |
| Measured Results                    |                                                                                                                                                                                                                                                     |
| —— Intra-frequency measured results |                                                                                                                                                                                                                                                     |
| —— Cell measured results            |                                                                                                                                                                                                                                                     |
| —— Cell Identity                    | 0000-0000-0000-0000-0000-0000-0010                                                                                                                                                                                                                  |
| —— SFN-SFN observed time difference | Checked that this IE is absent                                                                                                                                                                                                                      |
| —— Cell synchronisation information | Checked that this IE is present                                                                                                                                                                                                                     |
| —— Primary CPICH info               |                                                                                                                                                                                                                                                     |
| —— Primary scrambling code          | 150                                                                                                                                                                                                                                                 |
| —— CPICH Ec/NO                      | Checked that this IE is absent                                                                                                                                                                                                                      |
| —— CPICH RSCP                       | Checked that this IE is present                                                                                                                                                                                                                     |
| —— Pathloss                         | Checked that this IE is absent                                                                                                                                                                                                                      |
| Measured results on RACH            | Checked that this IE is absent                                                                                                                                                                                                                      |
| Additional measured results         | Checked that this IE is absent                                                                                                                                                                                                                      |
| Event results                       | Checked that this IE is absent                                                                                                                                                                                                                      |

### ACTIVE SET UPDATE

The message to be used in this test is defined in Annex A, with the following exceptions:

| Information Element               | Value/remark                                       |
|-----------------------------------|----------------------------------------------------|
| Radio link addition information   |                                                    |
| —— Primary CPICH Info             |                                                    |
| —— Primary Scrambling Code        | 150                                                |
| —— Downlink DPCH info for each RL |                                                    |
| —— DPCH frame offset              | Calculated value from COUNT-C-SFN frame difference |

#### 8.3.4.1.5 Test requirement

After step 1 the UE shall transmit a MEASUREMENT REPORT message on the uplink DCCH using AM RLC.

After step 3 the UE shall transmit an ACTIVE SET UPDATE COMPLETE message on the uplink DCCH using AM RLC to acknowledge the completion of the active set additional procedure.

After step 6 the UE shall transmit a UE CAPABILITY INFORMATION message.

After step 11 the UE shall transmit a UE CAPABILITY INFORMATION message.

~~8.3.4.2 Active set update in soft handover: Radio Link removal~~

~~8.3.4.2.1 Definition~~

~~8.3.4.2.2 Conformance requirement~~

~~This procedure is to update the active set of the connections between the UE and the UTRAN after the UTRAN has commanded a removal of a radio link from the current active set. The UTRAN RRC transmits an ACTIVE SET UPDATE message to the UE RRC. The UE RRC requests UE L1 to terminate transmission and reception of the radio link to be removed. The UE shall continue to communicate normally with the UTRAN using the new active set, without losing the connection link. After this the UE acknowledges the radio link removal by sending an ACTIVE SET UPDATE COMPLETE message to the UTRAN on DCCH using AM RLC.~~

~~Reference~~

~~3GPP TS 25.331 clause 8.3.4~~

~~8.3.4.2.3 Test purpose~~

~~To confirm that the UE continues to communicate with the SS on the remaining radio link after radio link removal on the active set.~~

~~8.3.4.2.4 Method of test~~

~~Initial Condition~~

~~System Simulator: 2 cells – both Cell 1 and Cell 2 are active~~

~~UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE.~~

~~Test Procedure~~

**Table 8.3.4.2**

| Parameter              | Unit        | Cell 1 |     |     |     | Cell 2 |     |     |     |
|------------------------|-------------|--------|-----|-----|-----|--------|-----|-----|-----|
|                        |             | T0     | T1  | T2  | T3  | T0     | T1  | T2  | T3  |
| UTRA RF Channel Number |             | Ch. 1  |     |     |     | Ch. 1  |     |     |     |
| CPICH-Ec               | dBm/3.84MHz | -60    | -60 | -75 | -60 | -75    | -60 | -60 | OFF |

Table 8.3.4.2 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution.

At the start of the test, the UE establishes a radio access bearer service in the CELL\_DCH state in cell 1. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.4.2. UE shall be triggered to transmit a MEASUREMENT REPORT message which includes the primary scrambling code for cell 2 according to IE "Intra-frequency event identity", which is set to '1a' in the SYSTEM INFORMATION BLOCK TYPE 11. After the MEASUREMENT REPORT message is received, the SS begins to configure the new radio link to be added from cell 2 and then the SS transmits to the UE an ACTIVE SET UPDATE message in cell 1 on DCCH using AM RLC which includes the IE "Radio Link Addition Information" (e.g. Downlink DPCH information and other optional parameters relevant for the additional radio links with Primary CPICH info used for the reference ID). When the UE receives this message, the UE shall configure layer 1 to begin reception without affecting the current uplink and downlink activities of existing radio links. The UE shall transmit an ACTIVE SET UPDATE COMPLETE message to the SS on the uplink DCCH using AM RLC. SS configures its downlink transmission power settings according to columns "T2" in table 8.3.4.2. UE shall transmit a MEASUREMENT REPORT message which includes the primary scrambling code for cell 1 according to IE "Intra-frequency event identity", which is set to '1b' in the SYSTEM INFORMATION BLOCK TYPE 11. After the MEASUREMENT REPORT message is received, the SS remove the radio link from cell 1 and then

SS transmits an ACTIVE SET UPDATE message, which includes IE "Radio Link Removal Information" and specifying the P-CPICH information of the cell to be removed. When the UE receives this message, the UE RRC entity shall request UE L1 entity to terminate transmission and reception of the radio link from cell 1. Then the UE transmits an ACTIVE SET UPDATE COMPLETE message to the SS on the uplink DCCH using AM RLC. SS shall transmit a UE CAPABILITY ENQUIRY message to confirm that the UE can respond this message through the DPCH in cell 2. The UE shall transmit a UE CAPABILITY ENQUIRY INFORMATION message. Then SS transmits a UE CAPABILITY INFORMATION CONFIRM message. SS configures its downlink transmission power settings according to columns "T3" in table 8.3.4.2 so as to generate a radio link failure condition. The UE shall detect the radio link failure and transmit a CELL UPDATE message to re-establish an RRC CONNECTION.

#### Expected sequence

| Step | Direction |    | Message                           | Comment                                                                                                                                                                                                                                                                                          |
|------|-----------|----|-----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                   |                                                                                                                                                                                                                                                                                                  |
| 1    |           |    |                                   | SS configures its downlink transmission power settings according to columns "T1" in table 8.3.4.2                                                                                                                                                                                                |
| 2    |           | →  | MEASUREMENT REPORT                |                                                                                                                                                                                                                                                                                                  |
| 3    |           | ←  | ACTIVE SET UPDATE                 | SS transmits this message in cell 1 on downlink DCCH using AM RLC. The message includes IE "Radio Link Addition Information". (e.g. Downlink DPCH information and other optional parameters relevant for the additional radio links with Primary CPICH info used for the reference ID in cell 2) |
| 4    |           | →  | ACTIVE SET UPDATE COMPLETE        | The UE shall configure a new radio link to cell 2, without interfering with existing connections on the radio link in cell 1.                                                                                                                                                                    |
| 5    |           |    |                                   | SS configures its downlink transmission power settings according to columns "T2" in table 8.3.4.2                                                                                                                                                                                                |
| 6    |           | →  | MEASUREMENT REPORT                |                                                                                                                                                                                                                                                                                                  |
| 7    |           | ←  | ACTIVE SET UPDATE                 | The SS transmits this message on downlink DCCH using AM RLC which includes IE "Radio Link Removal Information".                                                                                                                                                                                  |
| 8    |           | →  | ACTIVE SET UPDATE COMPLETE        | The UE shall remove the radio link associated with cell 1.                                                                                                                                                                                                                                       |
| 9    |           | ←  | UE CAPABILITY ENQUIRY             | Use default message.                                                                                                                                                                                                                                                                             |
| 10   |           | →  | UE CAPABILITY INFORMATION         | Use default message.                                                                                                                                                                                                                                                                             |
| 11   |           | ←  | UE CAPABILITY INFORMATION CONFIRM | Use default message.                                                                                                                                                                                                                                                                             |
| 12   |           |    |                                   | SS configures its downlink transmission power settings according to columns "T3" in table 8.3.4.2                                                                                                                                                                                                |
| 13   |           | →  | CELL UPDATE                       | UE sends this message in cell 1.                                                                                                                                                                                                                                                                 |

## Specific Message Contents

## MEASUREMENT REPORT (Step 2)

| Information Element                | Value/remark                                                                                                                                                                                                                                       |
|------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                       | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| Integrity check info               |                                                                                                                                                                                                                                                    |
| — Message authentication code      | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| — RRC Message sequence number      | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Measurement identity               | 1                                                                                                                                                                                                                                                  |
| Measured Results                   |                                                                                                                                                                                                                                                    |
| — Intra-frequency measured results |                                                                                                                                                                                                                                                    |
| — Cell measured results            |                                                                                                                                                                                                                                                    |
| — Cell Identity                    | 0000-0000-0000-0000-0000-0000-0010                                                                                                                                                                                                                 |
| — SFN-SFN observed time difference | Checked that this IE is absent                                                                                                                                                                                                                     |
| — Cell synchronisation information | Checked that this IE is present                                                                                                                                                                                                                    |
| — Primary CPICH info               |                                                                                                                                                                                                                                                    |
| — Primary scrambling code          | 150                                                                                                                                                                                                                                                |
| — CPICH Ec/NO                      | Checked that this IE is absent                                                                                                                                                                                                                     |
| — CPICH RSCP                       | Checked that this IE is present                                                                                                                                                                                                                    |
| — Pathloss                         | Checked that this IE is absent                                                                                                                                                                                                                     |
| Measured results on RACH           | Checked that this IE is absent                                                                                                                                                                                                                     |
| Additional measured results        | Checked that this IE is absent                                                                                                                                                                                                                     |
| Event results                      | Checked that this IE is absent                                                                                                                                                                                                                     |

## ACTIVE SET UPDATE (Step 3)

The message to be used in this test is defined in Annex.A, with the following exceptions:

| Information Element              | Value/remark                                       |
|----------------------------------|----------------------------------------------------|
| Radio link addition information  |                                                    |
| — Primary CPICH Info             |                                                    |
| — Primary Scrambling Code        | 150                                                |
| — Downlink DPCH info for each RL |                                                    |
| — DPCH frame offset              | Calculated value from COUNT-C-SFN frame difference |

**MEASUREMENT REPORT (Step 6)**

| Information Element                 | Value/remark                                                                                                                                                                                                                                       |
|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                        | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub IEs shall be absent. |
| Integrity check info                |                                                                                                                                                                                                                                                    |
| —— Message authentication code      |                                                                                                                                                                                                                                                    |
| —— RRC Message sequence number      |                                                                                                                                                                                                                                                    |
| Measurement identity                | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS. This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.<br>1                                   |
| Measured Results                    |                                                                                                                                                                                                                                                    |
| —— Intra-frequency measured results |                                                                                                                                                                                                                                                    |
| —— Cell measured results            |                                                                                                                                                                                                                                                    |
| —— Cell Identity                    | 0000 0000 0000 0000 0000 0000 0001                                                                                                                                                                                                                 |
| —— SFN-SFN observed time difference | Checked that this IE is absent                                                                                                                                                                                                                     |
| —— Cell synchronisation information | Checked that this IE is present                                                                                                                                                                                                                    |
| —— Primary CPICH info               | 100                                                                                                                                                                                                                                                |
| —— Primary scrambling code          |                                                                                                                                                                                                                                                    |
| —— CPICH Ec/NO                      |                                                                                                                                                                                                                                                    |
| —— CPICH RSCP                       |                                                                                                                                                                                                                                                    |
| —— Pathloss                         | Checked that this IE is absent                                                                                                                                                                                                                     |
| Measured results on RACH            | Checked that this IE is absent                                                                                                                                                                                                                     |
| Additional measured results         | Checked that this IE is absent                                                                                                                                                                                                                     |
| Event results                       | Checked that this IE is absent                                                                                                                                                                                                                     |

**ACTIVE SET UPDATE (Step 7)**

The message to be used in this test is the same as the message sub-type found in Annex A, with the following exceptions:

| Information Element            | Value/remark                                                |
|--------------------------------|-------------------------------------------------------------|
| Radio link removal information | 1 radio link to be removed                                  |
| —— Primary CPICH info          | Set to the same P-CPICH scrambling code assigned for cell 1 |
| —— Primary scrambling code     |                                                             |

**CELL UPDATE (Step 13)**

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark         |
|---------------------|----------------------|
| Cell Update Cause   | "radio link failure" |

**8.3.4.2.5 Test requirement**

After step 1 the UE shall transmit a MEASUREMENT REPORT message on the uplink DCCH using AM RLC.

After step 3 the UE shall transmit an ACTIVE SET UPDATE COMPLETE message on the uplink DCCH using AM RLC to acknowledge the completion of the active set additional procedure.

After step 5 the UE shall transmit a MEASUREMENT REPORT message on the uplink DCCH using AM RLC.

After step 7 the UE shall remove the radio link from cell 1 and it shall transmit an ACTIVE SET UPDATE COMPLETE message on the uplink DCCH using AM RLC.

After step 10 the UE shall transmit a UE CAPABILITY INFORMATION message.

After step 12 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "radio link failure".

~~8.3.4.3 Active set update in soft handover: Combined radio link addition and removal~~

~~8.3.4.3.1 Definition~~

~~8.3.4.3.2 Conformance requirement~~

~~When radio links are to be replaced, the UTRAN RRC first configures the UTRAN L1 to activate the radio link(s) that are being added. The UTRAN RRC then transmits an ACTIVE SET UPDATE message to the UE RRC, which shall configure the UE L1 to terminate transmission and reception on the removed radio link(s) and begin transmission and reception on the added radio link(s). At the completion of the reconfiguration of radio links, the UE shall acknowledge the replacement with an ACTIVE SET UPDATE COMPLETE message.~~

Reference

3GPP TS 25.331 clause 8.3.4

~~8.3.4.3.3 Test purpose~~

~~To confirm that the UE continues to communicate with the SS on the added radio link and removes radio link which exists prior to the execution of active set update procedure.~~

~~8.3.4.3.4 Method of test~~

Initial Condition

System Simulator: 2 cells- Both Cell 1 and Cell 2 are active

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE [Active set is not full.]

Test Procedure

Table 8.3.4.3

| Parameter              | Unit        | Cell 1 |     |     | Cell 2 |     |     |
|------------------------|-------------|--------|-----|-----|--------|-----|-----|
|                        |             | T0     | T1  | T2  | T0     | T1  | T2  |
| UTRA RF Channel Number |             | Ch. 1  |     |     | Ch. 1  |     |     |
| CPICH Ec               | dBm/3.84MHz | -60    | -60 | -60 | -75    | -60 | OFF |

Table 8.3.4.3 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution:

The UE establishes a radio access bearer in the CELL\_DCH state in cell 1. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.4.3. UE shall be triggered to transmit a MEASUREMENT REPORT message which includes the primary scrambling code for cell 2 according to IE "Intra-frequency event identity", which is set to '1a' in the SYSTEM INFORMATION BLOCK TYPE 11. After the MEASUREMENT REPORT message is received, the SS begins to configure the new radio link to be added from cell 2 and then the SS transmits to the UE in cell 1 an ACTIVE SET UPDATE message which includes IE "Radio Link Addition Information" and IE "Radio Link Removal Information", indicating the removal of cell 1 and addition of cell 2 into the active set, on DCCH using AM RLC. When the UE receives this message, the UE shall configure layer 1 to begin reception without affecting the current uplink and downlink activities of existing radio links and then the UE removes the radio link specified in an ACTIVE SET UPDATE message. The UE shall transmit an ACTIVE SET UPDATE COMPLETE message to the SS on the uplink DCCH using AM RLC. SS removes the radio link in cell 1. SS shall transmit a UE CAPABILITY ENQUIRY message to confirm that the UE can respond this message through the DPCCH in cell 2. The

UE shall transmit a UE CAPABILITY ENQUIRY INFORMATION message. Then SS transmits a UE CAPABILITY INFORMATION CONFIRM message. SS configures its downlink transmission power settings according to columns "T2" in table 8.3.4.3 so as to generate a radio link failure condition. The UE shall detect the radio link failure and transmit a CELL UPDATE message to re-establish an RRC CONNECTION.

#### Expected sequence

| Step | Direction |    | Message                           | Comment                                                                                                                                                                       |
|------|-----------|----|-----------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                   |                                                                                                                                                                               |
| 1    |           |    |                                   | SS configures its downlink transmission power settings according to columns "T1" in table 8.3.4.3                                                                             |
| 2    |           | →  | MEASUREMENT REPORT                |                                                                                                                                                                               |
| 3    |           | ←  | ACTIVE SET UPDATE                 | The SS transmit this message on downlink DCCH using AM RLC which includes IE "Radio Link Addition Information" for cell 2 and IE "Radio Link Removal Information" for cell 1. |
| 4    |           | →  | ACTIVE SET UPDATE COMPLETE        | The UE shall configure a new radio link in cell 2 and removes the old radio link in cell 1.                                                                                   |
| 5    |           | ←  | UE CAPABILITY ENQUIRY             | Use default message.                                                                                                                                                          |
| 6    |           | →  | UE CAPABILITY INFORMATION         | Use default message.                                                                                                                                                          |
| 7    |           | ←  | UE CAPABILITY INFORMATION CONFIRM | Use default message.                                                                                                                                                          |
| 8    |           |    |                                   | SS configures its downlink transmission power settings according to columns "T2" in table 8.3.4.3                                                                             |
| 9    |           | →  | CELL UPDATE                       |                                                                                                                                                                               |

## Specific Message Content

## MEASUREMENT REPORT (Step 2)

| Information Element                 | Value/remark                                                                                                                                                                                                                                       |
|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                        | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| Integrity check info                |                                                                                                                                                                                                                                                    |
| —— Message authentication code      |                                                                                                                                                                                                                                                    |
| —— RRC Message sequence number      |                                                                                                                                                                                                                                                    |
| Measurement identity                | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS. This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                        |
| Measured Results                    |                                                                                                                                                                                                                                                    |
| —— Intra-frequency measured results |                                                                                                                                                                                                                                                    |
| —— Cell measured results            |                                                                                                                                                                                                                                                    |
| —— Cell Identity                    | 0000-0000-0000-0000-0000-0000-0010<br>Checked that this IE is absent                                                                                                                                                                               |
| —— SFN-SFN observed time difference |                                                                                                                                                                                                                                                    |
| —— Cell synchronisation information |                                                                                                                                                                                                                                                    |
| —— Primary CPICH info               |                                                                                                                                                                                                                                                    |
| —— Primary scrambling code          | 150<br>Checked that this IE is absent                                                                                                                                                                                                              |
| —— CPICH Ec/No                      |                                                                                                                                                                                                                                                    |
| —— CPICH RSCP                       |                                                                                                                                                                                                                                                    |
| —— Pathloss                         |                                                                                                                                                                                                                                                    |
| Measured results on RACH            | Checked that this IE is absent                                                                                                                                                                                                                     |
| Additional measured results         | Checked that this IE is absent                                                                                                                                                                                                                     |
| Event results                       | Checked that this IE is absent                                                                                                                                                                                                                     |

## ACTIVE SET UPDATE (Step 3)

The message to be used in this test is defined in Annex A, with the following exceptions:

| Information Element               | Value/remark                                       |
|-----------------------------------|----------------------------------------------------|
| Radio link addition information   | Set to same code as assigned for cell 2            |
| —— Primary CPICH Info             |                                                    |
| —— Primary Scrambling Code        |                                                    |
| —— Downlink DPCH info for each RL |                                                    |
| —— DPCH frame offset              | Calculated value from COUNT-C-SFN frame difference |
| Radio link removal information    | Set to same code as assigned for cell 1            |
| —— Primary CPICH Info             |                                                    |
| —— Primary Scrambling Code        |                                                    |

## CELL UPDATE (Step 9)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex A with the following exceptions:

| Information Element | Value/remark         |
|---------------------|----------------------|
| Cell Update Cause   | "radio link failure" |

## 8.3.4.3.5 ——— Test requirement

After step 1 the UE shall transmit a MEASUREMENT REPORT message on the uplink DCCH using AM RLC.

After step 3 the UE shall transmit an ACTIVE SET UPDATE COMPLETE message on the uplink DCCH.

After step 5 the UE shall a UE CAPABILITY INFORMATION message.



After step 8 the UE shall transmit a CELL UPDATE message on the CCCH with IE "Cell update cause" set to "radio link failure".

~~8.3.4.4 Active set update in soft handover: Invalid Configuration~~

~~8.3.4.4.1 Definition~~

~~8.3.4.4.2 Conformance requirement~~

If the UTRAN attempts to add a radio link but the additional radio link is specified in both IE "Radio Link Addition Information" and IE "Radio Link Removal Information", the UE transmits an ACTIVE SET UPDATE FAILURE message on the DCCH using AM RLC and maintain its current communication status with the radio links.

Reference

3GPP TS 25.331 clause 8.3.4

~~8.3.4.4.3 Test purpose~~

To confirm that the UE transmits an ACTIVE SET UPDATE FAILURE message on the DCCH using AM RLC, if the received ACTIVE SET UPDATE message includes a radio link which is specified in both IE "Radio Link Addition Information" and IE "Radio Link Removal Information".

~~8.3.4.4.4 Method of test~~

Initial Condition

System Simulator: 2 cells – Cell 1 and 2 are active.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE.

Test Procedure

Table 8.3.4.4

| Parameter              | Unit         | Cell 1 |     | Cell 2 |     |
|------------------------|--------------|--------|-----|--------|-----|
|                        |              | T0     | T1  | T0     | T1  |
| UTRA RF Channel Number |              | Ch. 1  |     | Ch. 1  |     |
| CPICH E <sub>c</sub>   | dBm/3.84 MHz | -60    | -75 | -60    | -60 |

Table 8.3.4.4 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution.

The UE establishes a radio access bearer in the CELL\_DCH state in cell 1. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.4.4. UE shall be triggered to transmit a MEASUREMENT REPORT message which includes the primary scrambling code for cell 2 according to IE "Intra-frequency event identity", which is set to '1a' in the SYSTEM INFORMATION BLOCK TYPE 11. SS then transmits an ACTIVE SET UPDATE message in cell 1 on DCCH using AM RLC which includes the same primary scrambling code in IE "Primary CPICH Info" of both IE "Radio Link Addition Information" and IE "Radio Link Removal Information". When the UE receives this message, it transmits an ACTIVE SET UPDATE FAILURE message which is set to "Invalid configuration" in IE "failure cause" on the uplink DCCH using AM RLC to the SS.

## Expected sequence

| Step | Direction |    | Message                   | Comment                                                                                                                                                                                                                      |
|------|-----------|----|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                           |                                                                                                                                                                                                                              |
| 1    |           |    |                           | SS configures its downlink transmission power settings according to columns "T1" in table 8.3.4.4                                                                                                                            |
| 2    |           | →  | MEASUREMENT REPORT        |                                                                                                                                                                                                                              |
| 3    |           | ←  | ACTIVE SET UPDATE         | The SS transmits this message on downlink DCCH using AM RLC which includes the same primary scrambling code in IE "Primary CPICH Info" of both IE "Radio Link Addition Information" and IE "Radio Link Removal Information". |
| 4    |           | →  | ACTIVE SET UPDATE FAILURE | The message shall state "Invalid configuration" in IE "failure cause".                                                                                                                                                       |

## Specific Message Contents

## ACTIVE SET UPDATE (Step 3)

The message to be used in this test is defined in the default message content clause, with the following exceptions:

| Information Element                                                                                          | Value/remark                                                                                                                |
|--------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| Radio link addition information<br>→ Primary CPICH Info<br>→ Primary Scrambling Code<br>→ DPCCH frame offset | Set to same code as assigned for cell 2<br>Calculated value from COUNT-C-SFN frame difference<br>1 radio link to be removed |
| Radio link removal information<br>→ Primary CPICH info<br>→ Primary scrambling code                          | Set to same code as assigned for cell 2                                                                                     |

## ACTIVE SET UPDATE FAILURE (Step 4)

| Information Element  | Value/remark                                        |
|----------------------|-----------------------------------------------------|
| Integrity check info | Not Checked                                         |
| Failure cause        | Check to see if it's set to 'Invalid configuration' |

## 8.3.4.4.5 → Test requirement

After step 1 the UE shall transmit a MEASUREMENT REPORT message on the uplink DCCH using AM RLC.

After step 3 the UE shall transmit an ACTIVE SET UPDATE FAILURE message, setting "Invalid configuration" in IE "failure cause" and sent on the uplink DCCH using AM RLC.

## 8.3.4.5 → Active set update in soft handover: Reception of an ACTIVE SET UPDATE message in wrong state

## 8.3.4.5.1 → Definition

## 8.3.4.5.2 → Conformance requirement

If the UE is in another state than CELL\_DCH state upon reception of the ACTIVE SET UPDATE message, the UE shall transmit an ACTIVE SET UPDATE FAILURE message on the uplink DCCH using AM RLC.

## Reference

3GPP TS 25.331 clause 8.3.4

## 8.3.4.5.3 Test purpose

To confirm that the UE transmit an ACTIVE SET UPDATE FAILURE message when it receives an ACTIVE SET UPDATE message in any state other than CELL\_DCH.

## 8.3.4.5.4 Method of test

## Initial Condition

System Simulator: 2 cells — Cell 1 and 2 are active.

UE: PS-DCCCH+DTCH\_FACH (state 6-11) in cell 1 as specified in clause 7.4 of TS 34.108.

## Test Procedure

Table 8.3.4.5

| Parameter                | Unit         | Cell 1 |     | Cell 2 |     |
|--------------------------|--------------|--------|-----|--------|-----|
|                          |              | T0     | T1  | T0     | T1  |
| UTRA — RF Channel Number |              | Ch. 1  |     | Ch. 1  |     |
| CPICH Ec                 | dBm/3.84 MHz | -60    | -75 | -60    | -60 |

Table 8.3.4.5 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution.

At the start of the test, the UE establishes a radio access bearer service in the CELL\_FACH state in cell 1. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.4.2. SS begins to configure the new radio link to be added from cell 2 and then the SS transmits to the UE an ACTIVE SET UPDATE message in cell 1 on DCCH using AM RLC which includes the IE "Radio Link Addition Information" indicating the addition of cell 2 into the active set. When the UE receives this message, UE shall transmit ACTIVE SET UPDATE FAILURE message, with the IE "failure cause" set to the cause value "protocol error" and includes the IE "Protocol error information" with the IE "Protocol error cause" set to "Message not compatible with receiver state", on the uplink DCCH using AM RLC.

## Expected sequence

| Step | Direction |    | Message                   | Comment                                                                                                                                                                                             |
|------|-----------|----|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                           |                                                                                                                                                                                                     |
| 1    |           |    |                           | SS configures its downlink transmission power settings according to columns "T1" in table 8.3.4.5                                                                                                   |
| 2    |           |    | Void                      |                                                                                                                                                                                                     |
| 3    |           | ←  | ACTIVE SET UPDATE         | The SS transmit this message on downlink DCCH using AM RLC which includes IE "Radio Link Addition Information".                                                                                     |
| 4    |           | →  | ACTIVE SET UPDATE FAILURE | IE "failure cause" set to the cause value "protocol error" and includes the IE "Protocol error information" with the IE "Protocol error cause" set to "Message not compatible with receiver state". |

## Specific Message Content

### ACTIVE SET UPDATE

The message to be used in this test is defined in Annex A, with the following exceptions:

| Information Element                        | Value/remark |
|--------------------------------------------|--------------|
| <del>Radio link addition information</del> |              |
| <del>Primary CPICH Info</del>              |              |
| <del>Primary Scrambling Code</del>         | 150          |
| <del>Downlink DPCH info for each RL</del>  |              |
| <del>DPCH frame offset</del>               | 0            |

#### 8.3.4.5.5 ~~Test requirement~~

After step 1, the UE shall not transmit MEASUREMENT REPORT message.

After step 3 the UE shall transmit an ACTIVE SET UPDATE FAILURE message on the DCCH. In this message, the value "Message not compatible with receiver state" shall be set in IE "Protocol Error Information".

#### 8.3.4.6 ~~Void~~

#### 8.3.4.7 ~~Active set update in soft handover: Invalid Message Reception~~

##### 8.3.4.7.1 ~~Definition~~

##### 8.3.4.7.2 ~~Conformance Requirement~~

The UE shall keep its old configuration when the UE receives an ACTIVE SET UPDATE message, which does not include any IEs except IE "Message Type" and transmit an ACTIVE SET UPDATE FAILURE message which set value "protocol error" in IE "failure cause" and also value "ASN.1 violation or encoding error" in IE "Protocol error cause".

### Reference

3GPP TS 25.331 clause 8.3.4

##### 8.3.4.7.3 ~~Test Purpose~~

To confirm that the UE retains its active set list and transmits an ACTIVE SET UPDATE FAILURE message when it receives an invalid ACTIVE SET UPDATE message.

##### 8.3.4.7.4 ~~Method of test~~

### Initial Condition

System Simulator: 2 cells — both cell 1 and cell 2 are active.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE (Integrity protection algorithm is not applied at the start of test)

## Test Procedure

Table 8.3.4.7

| Parameter              | Unit         | Cell 1 |     | Cell 2 |     |
|------------------------|--------------|--------|-----|--------|-----|
|                        |              | T0     | T1  | T0     | T1  |
| UTRA—RF Channel Number |              | Ch. 1  |     | Ch. 1  |     |
| CPICH Ec               | dBm/3.84 MHz | -60    | -75 | -60    | -60 |

Table 8.3.4.7 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution.

The UE establishes a radio access bearer in CELL\_DCH in cell 1. SS configures its downlink transmission power settings according to columns "T1" in table 8.3.4.7. UE shall be triggered to transmit a MEASUREMENT REPORT message which includes the primary scrambling code for cell 2 according to IE "Intra-frequency event identity", which is set to '1a' in the SYSTEM INFORMATION BLOCK TYPE 11. SS transmits an ACTIVE SET UPDATE message which does not include any IEs except IE "Message Type". The UE shall transmit an ACTIVE SET UPDATE FAILURE message, stating the reason "ASN.1 violation or encoding error" in the IE "Protocol error information".

## Expected Sequence

| Step | Direction |    | Message                   | Comment                                                                                                             |
|------|-----------|----|---------------------------|---------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                           |                                                                                                                     |
| 1    |           |    |                           | SS configures its downlink transmission power settings according to columns "T1" in table 8.3.4.7                   |
| 2    | →         |    | MEASUREMENT REPORT        |                                                                                                                     |
| 3    | ←         |    | ACTIVE SET UPDATE         | The SS transmits this message on downlink DCCH using AM RLC which does not include any IEs except IE "Message Type" |
| 4    | →         |    | ACTIVE SET UPDATE FAILURE | The message shall state "ASN.1 violation error or encoding error" in IE "protocol error information".               |

## Specific Message Contents

## ACTIVE SET UPDATE (Step 3)

| Information Element | Value/remark |
|---------------------|--------------|
| All IEs             | Not Present  |

## ACTIVE SET UPDATE FAILURE (Step 4)

| Information Element                                  | Value/remark                      |
|------------------------------------------------------|-----------------------------------|
| Protocol Error Information<br>→ Protocol Error Cause | ASN.1 violation or encoding error |

## 8.3.4.7.5 ——— Test Requirement

After step 1 the UE shall transmit a MEASUREMENT REPORT message on the uplink DCCH using AM RLC.

After step 3 the UE shall transmit an ACTIVE SET UPDATE FAILURE message on the DCCH. In this message, the value "ASN.1 violation or encoding error" shall be set in IE "Protocol Error Information".

### ~~8.3.5 Hard Handover~~

~~[Editor's note: This test is included in the "Physical channel reconfiguration", "Radio bearer establishment", "Radio bearer reconfiguration", "Radio bearer release" and "Transport channel reconfiguration".]~~

### ~~8.3.6 Inter-system hard handover from GSM to UTRAN~~

~~The content of this clause has been moved to 3GPP TS 51.010-1, clause 60.~~

### ~~8.3.7 Inter-system hard handover from UTRAN to GSM~~

~~Clauses 8.3.7 contains test procedures to be used for executing Inter-system Handover from UTRAN to GSM tests. Table 8.3.7-1 contains a summary of the different combinations of parameters being tested, together with a reference to the appropriate generic test procedure. If a test uses a parameter which the UE under test does not support, the test shall be skipped. Test cases in this clause are applicable only to the UE supporting both UTRAN and GSM. The test TEST USIM shall support service 27 to carry out these test cases.~~

Table 8.3.7-1

| From                                                                                                        | To                       | State of call | Ref. clause | Exec counter | Remark                    |
|-------------------------------------------------------------------------------------------------------------|--------------------------|---------------|-------------|--------------|---------------------------|
| UTRAN-AMR<br>(conversational/speech/<br>uplink:12.2-DL:12.2 kbps/CS<br>RAB +<br>uplink:3.4-DL3.4 kbps-SRBS) | GSM-AMR                  | U10           | 8.3.7.1     | 1            | call active state         |
| UTRAN-AMR<br>(conversational/speech/<br>uplink:12.2-DL:12.2 kbps/CS<br>RAB +<br>uplink:3.4-DL3.4 kbps-SRBS) | GSM-EFR                  | U10           | 8.3.7.1     | 2            | call active state         |
| UTRAN-AMR<br>(conversational/speech/<br>uplink:12.2-DL:12.2 kbps/CS<br>RAB +<br>uplink:3.4-DL3.4 kbps-SRBS) | GSM-FR                   | U10           | 8.3.7.1     | 3            | call active state         |
| UTRAN-AMR<br>(conversational/speech/<br>uplink:12.2-DL:12.2 kbps/CS<br>RAB +<br>uplink:3.4-DL3.4 kbps-SRBS) | GSM-HR                   | U10           | 8.3.7.1     | 4            | call active state         |
| UTRAN<br>(Streaming/unknown/<br>uplink:14.4-DL:14.4 kbps/CS<br>RAB +<br>uplink:3.4-DL:3.4 kbps-SRBS)        | GSM<br>14.4 kbps-CS data | U10           | 8.3.7.2     | 1            | Same data rate            |
| UTRAN<br>(Streaming/unknown/<br>uplink:28.8-DL:28.8 kbps/CS<br>RAB +<br>uplink:3.4-DL:3.4 kbps-SRBS)        | GSM<br>28.8 kbps-CS data | U10           | 8.3.7.2     | 2            | Same data rate            |
| UTRAN<br>(Streaming/unknown/<br>uplink:57.6-DL:57.6 kbps/CS<br>RAB +<br>uplink:3.4-DL:3.4 kbps-SRBS)        | GSM<br>57.6 kbps-CS data | U10           | 8.3.7.2     | 3            | Same data rate            |
| UTRAN<br>(Streaming/unknown/<br>uplink:28.8-DL:28.8 kbps/CS<br>RAB +<br>uplink:3.4-DL:3.4 kbps-SRBS)        | GSM<br>14.4 kbps-CS data | U10           | 8.3.7.3     | 1            | Data rate down-grading    |
| UTRAN<br>(Streaming/unknown/<br>uplink:57.6-DL:57.6 kbps/CS<br>RAB +<br>uplink:3.4-DL:3.4 kbps-SRBS)        | GSM<br>14.4 kbps-CS data | U10           | 8.3.7.3     | 2            | Data rate down-grading    |
| UTRAN<br>(Streaming/unknown/<br>uplink:57.6-DL:57.6 kbps/CS<br>RAB +<br>uplink:3.4-DL:3.4 kbps-SRBS)        | GSM<br>28.8 kbps-CS data | U10           | 8.3.7.3     | 3            | Data rate down-grading    |
| UTRAN-AMR<br>(conversational/speech/<br>uplink:12.2-DL:12.2 kbps/CS<br>RAB +<br>uplink:3.4-DL3.4 kbps-SRBS) | GSM-FR                   | U1            | 8.3.7.4     | 1            | During call establishment |
| UTRAN-AMR<br>(conversational/speech/<br>uplink:12.2-DL:12.2 kbps/CS<br>RAB +<br>uplink:3.4-DL3.4 kbps-SRBS) | GSM-FR                   | U10           | 8.3.7.5     | 1            | failure case              |

|                                                                                                             |        |     |          |   |                             |
|-------------------------------------------------------------------------------------------------------------|--------|-----|----------|---|-----------------------------|
| UTRAN-AMR<br>(conversational/speech/<br>uplink:12.2-DL:12.2-kbps/CS<br>RAB +<br>uplink:3.4-DL3.4-kbps-SRBS) | GSM-FR | U10 | 8.3.7.6  | 1 | failure-case                |
| UTRAN-AMR<br>(conversational/speech/<br>uplink:12.2-DL:12.2-kbps/CS<br>RAB +<br>uplink:3.4-DL3.4-kbps-SRBS) | GSM-FR | U10 | 8.3.7.7  | 1 | failure-case                |
| UTRAN-AMR<br>(conversational/speech/<br>uplink:12.2-DL:12.2-kbps/CS<br>RAB +<br>uplink:3.4-DL3.4-kbps-SRBS) | GSM-FR | U10 | 8.3.7.8  | 1 | failure-case                |
| UTRAN-AMR<br>(conversational/speech/<br>uplink:12.2-DL:12.2-kbps/CS<br>RAB +<br>uplink:3.4-DL3.4-kbps-SRBS) | GSM-FR | U10 | 8.3.7.9  | 1 | failure-case                |
| UTRAN-AMR<br>(conversational/speech/<br>uplink:12.2-DL:12.2-kbps/CS<br>RAB +<br>uplink:3.4-DL3.4-kbps-SRBS) | GSM-FR | U10 | 8.3.7.10 | 1 | failure-case                |
| UTRAN-AMR<br>(conversational/speech/<br>uplink:12.2-DL:12.2-kbps/CS<br>RAB +<br>uplink:3.4-DL3.4-kbps-SRBS) | GSM-FR | U10 | 8.3.7.11 | 1 | failure-case                |
| UTRAN-AMR<br>(conversational/speech/<br>uplink:12.2-DL:12.2-kbps/CS<br>RAB +<br>uplink:3.4-DL3.4-kbps-SRBS) | GSM-FR | U10 | 8.3.7.12 | 1 | failure-case                |
| UTRAN-AMR<br>(conversational/speech/<br>uplink:12.2-DL:12.2-kbps/CS<br>RAB +<br>uplink:3.4-DL3.4-kbps-SRBS) | GSM-FR | U1  | 8.3.7.13 | 1 | call-under<br>establishment |

### ~~8.3.7.1 Inter system handover from UTRAN/To GSM/Speech/Success~~

#### ~~8.3.7.1.1 Definition~~

#### ~~8.3.7.1.2 Conformance requirement~~

When the UE receives an ~~HANDOVER FROM UTRAN COMMAND~~ message from UTRAN the UE shall take the following actions:

- ~~— Establish the connection to the other radio access system, by using the contents of the IE "Inter-system message". This IE contains candidate/ target cell identifier(s) and radio parameters relevant for the other radio access system.~~
- ~~— For each IE "Remaining radio access bearer", associate the radio access bearer given by the IE "RAB info" to the radio resources in the target system given by the IE "Inter-system message". Other information for making the association may be included in the IE "Inter-system message" and requirements may be stated in the specifications relevant for the target system [FFS].~~
- ~~— Switch the current connection to the other radio access system.~~

~~NOTE 1: Requirements concerning the establishment of the radio connection towards the other radio access system and the signalling procedure are outside the scope of the present document.~~



~~NOTE 2: The release of the UMTS radio resources is initiated by the other system.~~

~~NOTE 3: Currently only one radio access bearer can be associated with the IE "Inter-system message", and this association is limited to the radio access bearers in the CS domain. It is assumed that all the radio access bearers in the PS domain, if any, remain after the handover.~~

#### Reference(s)

TS 25.331 clause 8.3.7.3.

#### 8.3.7.1.3 ~~Test purpose~~

To test that the UE supporting both GSM and UTRAN handovers from a UTRAN serving cell to the indicated channel of GSM target cell when the UE is in the speech call active state and receives an HANDOVER FROM UTRAN COMMAND.

#### 8.3.7.1.4 ~~Method of test~~

#### Initial conditions

System Simulator : 2 cells – Cell 1 is UTRAN, Cell 2 is GSM. GSM 51.010 clause 26.6.5.1 shall be referenced for the default parameters of cell 2.

UE : CC State U10 in cell 1

#### Related ICS/IXIT statement(s)

- ~~— UE supports both GSM and UTRAN Radio Access Technologies,~~
- ~~— UE supports GSM ARM,~~
- ~~— UE supports GSM EFR,~~
- ~~— UE supports GSM HR,~~
- ~~— UE supports GSM-P, GSM-E, GSM-DCS, GSM-450, GSM-480.~~

#### Foreseen final state of the UE

The UE is in CC state U10 on cell 2.

#### Test Procedure

The SS starts the UTRAN cell and brings the UE into call active state (CC state U10) with AMR. The SS starts GSM cell and configures a traffic channel, then sends HANDOVER FROM UTRAN COMMAND indicating the traffic channel of the target GSM cell to the UE through DCCH of the serving UTRAN cell. After the UE receives the command it shall configure itself accordingly and switch to the new channel of the UTRAN cell. The SS checks whether the handover is performed by checking that the UE transmits the HANDOVER COMPLETE message to the SS through GSM cell.

Depending on the PIXIT parameters the above procedure is executed maximum four times, each time with different target channel in the GSM cell.

#### Expected sequence

This sequence is performed for a maximum execution counter M = 1, 2, 3, 4, depending on the PIXIT parameters.

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                                  |
|------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                           |
| 1    | UE        |    |                                 | The SS bring the UE into UTRAN-U10 state in cell 1                                                                                                                                                                                        |
| 2    | SS        |    |                                 | The SS configures cell 2 as a GSM cell with a traffic channel:<br>for GSM-AMR (M = 1); or<br>for GSM-EFR (M = 2); or<br>for GSM-FR (M = 3); or<br>for GSM-HR (M = 4).                                                                     |
| 3    | ←         |    | HANDOVER FROM UTRAN COMMAND-GSM | Send on cell 1 (UTRAN-cell) and the message indicates:<br>the target channel for GSM-AMR (M = 1); or<br>the target channel for GSM-EFR (M = 2); or<br>the target channel for GSM-FR (M = 3); or<br>the target channel for GSM-HR (M = 4). |
| 4    | UE        |    |                                 | The UE accepts the handover command and switches to the GSM traffic channel specified in the HANDOVER FROM UTRAN COMMAND-GSM                                                                                                              |
| 5    | →         |    | HANDOVER ACCESS                 | The SS receives this burst on the traffic channel of cell 2 (GSM-cell) It implies that the UE has switched to GSM cell.                                                                                                                   |
| 6    | →         |    | HANDOVER ACCESS                 |                                                                                                                                                                                                                                           |
| 7    | →         |    | HANDOVER ACCESS                 |                                                                                                                                                                                                                                           |
| 8    | →         |    | HANDOVER ACCESS                 |                                                                                                                                                                                                                                           |
| 9    | ←         |    | PHYSICAL INFORMATION            |                                                                                                                                                                                                                                           |
| 10   | →         |    | SABM                            |                                                                                                                                                                                                                                           |
| 11   | ←         |    | UA                              |                                                                                                                                                                                                                                           |
| 12   | →         |    | HANDOVER COMPLETE               | The SS receives the message on the traffic channel of GSM cell.                                                                                                                                                                           |

### Specific message contents

For execution:

### HANDOVER FROM UTRAN COMMAND-GSM

| Information Element                                                                                                                                                                                                                                                           | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier<br>Integrity check info<br><br>→ Message authentication code<br><br>→ RRC Message sequence number<br>Activation time<br>RAB Info<br>Inter-system message<br>→ System type<br>→ Frequency Band<br>→ CHOICE-GSM message<br>→ Message | Arbitrarily selects one integer between 0 to 3<br>The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted.<br>SS calculates the value of MAC-I for this message and writes to this IE.<br>SS provides the value of this IE, from its internal counter.<br>now<br>Not present<br><br>GSM<br>GSM/DCS-1800-Band<br>Single-GSM message<br>GSM-HANDOVER-COMMAND formatted as Variable Length-BIT-STRING without Length Indicator. The contents of the HANDOVER-COMMAND see next table. |

### HANDOVER COMMAND

Same as the HANDOVER COMMAND for M = 2 in clause 26.6.5.1 of GSM 51.010, except that the CHANNEL MODE IE is included with value = speech full rate or half rate version 3

For execution 2:

#### HANDOVER FROM UTRAN COMMAND-GSM

| Information Element                                                                                                                                                                                                                                                                 | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier<br>Integrity check info<br><br>—→ Message authentication code<br><br>—→ RRC Message sequence number<br>Activation time<br>RAB Info<br>Inter-system message<br>—→ System type<br>—→ Frequency Band<br>—→ CHOICE GSM message<br>—→ Message | Arbitrarily selects one integer between 0 to 3<br>The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted.<br>SS calculates the value of MAC-I for this message and writes to this IE.<br>SS provides the value of this IE, from its internal counter.<br>now<br>Not present<br><br>GSM<br>GSM/DCS 1800 Band<br>Single GSM message<br>GSM HANDOVER COMMAND formatted as Variable Length BIT STRING without Length Indicator. The contents of the HANDOVER COMMAND see next table. |

#### HANDOVER COMMAND

Same as the HANDOVER COMMAND for M = 2 in clause 26.6.5.1 of GSM 51.010, except that the CHANNEL MODE IE is included with value = speech full rate or half rate version 2

For execution 3:

#### HANDOVER FROM UTRAN COMMAND-GSM

| Information Element                                                                                                                                                                                                                                                        | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier<br>Integrity check info<br><br>—→ Message authentication code<br><br>—→ Message sequence number<br>Activation time<br>RAB Info<br>Inter-system message<br>—→ System type<br>—→ Frequency Band<br>—→ CHOICE system<br>—→ Message | Arbitrarily selects one integer between 0 to 3<br>The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted.<br>SS calculates the value of MAC-I for this message and writes to this IE.<br>SS provides the value of this IE, from its internal counter.<br>now<br>Not present<br><br>GSM<br>GSM/DCS 1800 Band<br>Single GSM message<br>GSM HANDOVER COMMAND formatted as BIT STRING(1..512). The contents of the HANDOVER COMMAND see next table. |

#### HANDOVER COMMAND

Same as the HANDOVER COMMAND for M = 2 in clause 26.6.5.1 of GSM 51.010, except that the CHANNEL MODE IE is included with value = speech full rate or half rate version 1

For execution 4:

#### HANDOVER FROM UTRAN COMMAND-GSM

| Information Element            | Value/remark                                                                                                                                                                                                                             |
|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                   | Arbitrarily selects one integer between 0 to 3                                                                                                                                                                                           |
| RRC transaction identifier     | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| Integrity check info           | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                 |
| —— Message authentication code | SS provides the value of this IE, from its internal counter.                                                                                                                                                                             |
| —— RRC Message sequence number | now                                                                                                                                                                                                                                      |
| Activation time                | Not present                                                                                                                                                                                                                              |
| RAB Info                       |                                                                                                                                                                                                                                          |
| Inter-system message           |                                                                                                                                                                                                                                          |
| —— System type                 | GSM                                                                                                                                                                                                                                      |
| —— Frequency Band              | GSM/DCS 1800 Band                                                                                                                                                                                                                        |
| —— CHOICE system               | Single GSM message                                                                                                                                                                                                                       |
| —— Message                     | GSM HANDOVER COMMAND formatted as Variable Length BIT STRING without Length Indicator. The contents of the HANDOVER COMMAND see next table.                                                                                              |

#### HANDOVER COMMAND

Same as the HANDOVER COMMAND for M = 4 in clause 26.6.5.1 of GSM 51.010, except that the CHANNEL MODE IE is included with value = speech full rate or half rate version 1

#### 8.3.7.1.5 ——— Test requirement

After step 12 the ongoing call shall be continued on the GSM cell.

#### 8.3.7.2 ——— Inter system handover from UTRAN/To GSM/Data/Same data rate/Success

##### 8.3.7.2.1 ——— Definition

##### 8.3.7.2.2 ——— Conformance requirement

When the UE receives an HANDOVER FROM UTRAN COMMAND message from UTRAN the UE shall take the following actions:

- Establish the connection to the other radio access system, by using the contents of the IE "Inter system message". This IE contains candidate/ target cell identifier(s) and radio parameters relevant for the other radio access system.
- For each IE "Remaining radio access bearer", associate the radio access bearer given by the IE "RAB info" to the radio resources in the target system given by the IE "Inter system message". Other information for making the association may be included in the IE "Inter system message" and requirements may be stated in the specifications relevant for the target system [FFS].
- Switch the current connection to the other radio access system.

NOTE 1: Requirements concerning the establishment of the radio connection towards the other radio access system and the signalling procedure are outside the scope of the present document.

NOTE 2: The release of the UMTS radio resources is initiated by the other system.

NOTE 3: Currently only one radio access bearer can be associated with the IE "Inter-system message", and this association is limited to the radio access bearers in the CS domain. It is assumed that all the radio access bearers in the PS domain, if any, remain after the handover.

#### Reference(s)

TS 25.331 Clause 8.3.7.3.

#### 8.3.7.2.3 Test purpose

To test that the UE handovers to the indicated channel of same data rate in the GSM target cell when it is in the data call active state in the UTRAN serving cell and receives an HANDOVER FROM UTRAN COMMAND.

#### 8.3.7.2.4 Method of test

#### Initial conditions

System Simulator : 2 cells – Cell 1 is UTRAN, Cell 2 is GSM. GSM 51.010 clause 26.6.5.1 or clause 26.13.1.3 (for HSCSD) shall be referenced for the default parameters of cell 2.

UE : CC State U10 in cell 1

#### Related ICS/IXIT statement(s)

- UE supports both GSM and UTRAN Radio Access Technologies;
- UE supports UTRAN Streaming/unknown/uplink:14.4 DL:14.4 kbps/CS RAB + uplink:3.4 DL:3.4 kbps SRBs;
- UE supports UTRAN Streaming/unknown/uplink:28.8 DL:28.8 kbps/CS RAB + uplink:3.4 DL:3.4 kbps SRBs;
- UE supports UTRAN Streaming/unknown/uplink:57.6 DL:57.6 kbps/CS RAB + uplink:3.4 DL:3.4 kbps SRBs;
- UE supports GSM 14.4 kbps data (HSCSD or full rate traffic channel for 14.4 kbit/s user data (TCH/F14.4));
- UE supports GSM 28.8 kbps data (HSCSD or enhanced circuit switched full rate traffic channel for 28.8 kbit/s user data (E-TCH/F28.8));
- UE supports GSM 57.6 kbps data;
- UE supports GSM-P, GSM-E, GSM-DCS, GSM-450, GSM-480.

#### Foreseen final state of the UE

The UE is in CC state U10 on cell 2.

#### Test Procedure

The SS starts the UTRAN cell and brings the UE into data call active state (CC state U10) with a suitable configuration (e.g. Streaming/unknown/uplink:14.4 DL:14.4 kbps/CS RAB + uplink:3.4 DL:3.4 kbps SRBs for M = 1). The SS starts GSM cell and configures a traffic channel (e.g. 14.4 kbps data channel for M = 1), then sends HANDOVER FROM UTRAN COMMAND indicating the traffic channel of the target GSM cell to the UE through DCCH of the serving UTRAN cell. After the UE receives the command it shall configure itself accordingly and switch to the new channel of the GSM cell. The SS checks whether the handover is performed by checking that the UE transmits the HANDOVER COMPLETE message to the SS in GSM cell.

Depending on the PIXIT parameters the above procedure is executed maximum three times, each time with different target channel in the GSM cell.

#### Expected sequence

This sequence is performed for a maximum execution counter M = 1, 2, 3, depending on the PIXIT parameters.

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                                                                                                                  |
|------|-----------|----|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                           |
| 1    | UE        |    |                                 | The SS bring the UE into UTRAN-U10 state in cell 1, the configuration is:<br>Streaming/unknown/uplink:14.4 DL:14.4 kbps/CS RAB + uplink:3.4 DL:3.4 kbps SRBs (for M = 1);<br>Streaming/unknown/uplink:28.8 DL:28.8 kbps/CS RAB + uplink:3.4 DL:3.4 kbps SRBs (for M = 2);<br>Streaming/unknown/uplink:57.6 DL:57.6 kbps/CS RAB + uplink:3.4 DL:3.4 kbps SRBs (for M = 3). |
| 2    |           | SS |                                 | The SS configures cell 2 as a GSM cell with a traffic channel:<br>for GSM 14.4 kbps data (M = 1); or<br>for GSM 28.8 kbps data (M = 2); or<br>for GSM 57.6 kbps data (M = 3).                                                                                                                                                                                             |
| 3    |           | ←  | HANDOVER FROM UTRAN COMMAND-GSM | Send on cell 1 (UTRAN-cell) and the message indicates: the target channel<br>for GSM 14.4 kbps data (M = 1); or<br>for GSM 28.8 kbps data (M = 2); or<br>for GSM 57.6 kbps data (M = 3).                                                                                                                                                                                  |
| 4    | UE        |    |                                 | The UE accepts the handover command and switches to the GSM traffic channel specified in the HANDOVER FROM UTRAN COMMAND-GSM                                                                                                                                                                                                                                              |
| 5    |           | →  | HANDOVER ACCESS                 | The SS receives this burst on the traffic channel of cell 2 (GSM-cell). It implies that the UE has switched to GSM cell.                                                                                                                                                                                                                                                  |
| 6    |           | →  | HANDOVER ACCESS                 |                                                                                                                                                                                                                                                                                                                                                                           |
| 7    |           | →  | HANDOVER ACCESS                 |                                                                                                                                                                                                                                                                                                                                                                           |
| 8    |           | →  | HANDOVER ACCESS                 |                                                                                                                                                                                                                                                                                                                                                                           |
| 9    |           | ←  | PHYSICAL INFORMATION            |                                                                                                                                                                                                                                                                                                                                                                           |
| 10   |           | →  | SABM                            |                                                                                                                                                                                                                                                                                                                                                                           |
| 11   |           | ←  | UA                              |                                                                                                                                                                                                                                                                                                                                                                           |
| 12   |           | →  | HANDOVER COMPLETE               | The SS receives the message on the traffic channel of GSM cell.                                                                                                                                                                                                                                                                                                           |

### Specific message contents

For execution-:

### HANDOVER FROM UTRAN COMMAND-GSM

| Information Element                                                                                                                                                                                                                                                           | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier<br>Integrity check info<br><br>→ Message authentication code<br><br>→ RRC Message sequence number<br>Activation time<br>RAB-Info<br>Inter-system message<br>→ System type<br>→ Frequency Band<br>→ CHOICE-GSM message<br>→ Message | Arbitrarily selects one integer between 0 to 3<br>The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted.<br>SS calculates the value of MAC-I for this message and writes to this IE.<br>SS provides the value of this IE, from its internal counter.<br>now<br>Not present<br><br>GSM<br>GSM/DCS 1800-Band<br>Single-GSM message<br>GSM-HANDOVER COMMAND formatted as-BIT STRING(1..512). The contents of the HANDOVER COMMAND see next table. |

If the UE supports 14.4 kbps single slot:

**HANDOVER COMMAND**

Same as the HANDOVER COMMAND for M = 2 in clause 26.6.5.1 of GSM 51.010, except that the CHANNEL MODE IE is included with value = data, 14.5 kbit/s radio interface rate (14.4 kbit/s user data (TCH/F14.4))

If the UE supports HSCSD:

**HANDOVER COMMAND**

Same as the HANDOVER COMMAND in clause 26.13.3.1 of GSM 51.010, except that the Description of a multi-slot configuration supporting 14.4 kbps user data.

For execution 2:

**HANDOVER FROM UTRAN COMMAND-GSM**

| Information Element            | Value/remark                                                                                                                                                                                                                             |
|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                   | Arbitrarily selects one integer between 0 to 3                                                                                                                                                                                           |
| RRC transaction identifier     | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| Integrity check info           | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                 |
| —→ Message authentication code | SS provides the value of this IE, from its internal counter.                                                                                                                                                                             |
| —→ RRC Message sequence number | now                                                                                                                                                                                                                                      |
| Activation time                | Not present                                                                                                                                                                                                                              |
| RAB Info                       |                                                                                                                                                                                                                                          |
| Inter-system message           |                                                                                                                                                                                                                                          |
| —→ System type                 | GSM                                                                                                                                                                                                                                      |
| —→ Frequency Band              | GSM/DCS 1800 Band                                                                                                                                                                                                                        |
| —→ CHOICE GSM message          | Single GSM message                                                                                                                                                                                                                       |
| —→ Message                     | GSM HANDOVER COMMAND formatted as Variable Length BIT STRING without Length Indicator. The contents of the HANDOVER COMMAND see next table.                                                                                              |

If the UE supports enhanced circuit switched full rate traffic channel for 28.8 kbps user data:

**HANDOVER COMMAND**

Same as the HANDOVER COMMAND for M = 2 in clause 26.6.5.1 of GSM 51.010, except that the CHANNEL MODE IE is included with value = data, 29.0 kbit/s radio interface rate (28.8 kbit/s user data (E-TCH/F28.8))

If the UE supports HSCSD:

**HANDOVER COMMAND**

Same as the HANDOVER COMMAND in clause 26.13.3.1 of GSM 51.010, except that the Description of a multi-slot configuration supporting 28.8 kbps user data.

For execution 3:

#### HANDOVER FROM UTRAN COMMAND-GSM

| Information Element            | Value/remark                                                                                                                                                                                                                             |
|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                   | Arbitrarily selects one integer between 0 to 3                                                                                                                                                                                           |
| RRC transaction identifier     | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| Integrity check info           | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                 |
| —— Message authentication code | SS provides the value of this IE, from its internal counter.                                                                                                                                                                             |
| —— RRC Message sequence number | now                                                                                                                                                                                                                                      |
| Activation time                | Not present                                                                                                                                                                                                                              |
| RAB Info                       |                                                                                                                                                                                                                                          |
| Inter-system message           |                                                                                                                                                                                                                                          |
| —— System type                 | GSM                                                                                                                                                                                                                                      |
| —— Frequency Band              | GSM/DCS 1800 Band                                                                                                                                                                                                                        |
| —— CHOICE GSM message          | Single GSM message                                                                                                                                                                                                                       |
| —— Message                     | GSM HANDOVER COMMAND formatted as Variable Length BIT STRING without Length Indicator. The contents of the HANDOVER COMMAND see next table.                                                                                              |

#### HANDOVER COMMAND

Same as the HANDOVER COMMAND in clause 26.13.3.1 of GSM 51.010, except that the Description of a multi-slot configuration supporting 57.6 kbps user data.

#### 8.3.7.2.5 ——— Test requirement

After step 12 the ongoing call shall be continued on the GSM cell.

#### 8.3.7.3 ——— Inter system handover from UTRAN/To GSM/Data/Data rate down grading/Success

##### 8.3.7.3.1 ——— Definition

##### 8.3.7.3.2 ——— Conformance requirement

When the UE receives an HANDOVER FROM UTRAN COMMAND message from UTRAN the UE shall take the following actions:

- Establish the connection to the other radio access system, by using the contents of the IE "Inter system message". This IE contains candidate/ target cell identifier(s) and radio parameters relevant for the other radio access system.
- For each IE "Remaining radio access bearer", associate the radio access bearer given by the IE "RAB info" to the radio resources in the target system given by the IE "Inter system message". Other information for making the association may be included in the IE "Inter system message" and requirements may be stated in the specifications relevant for the target system [FFS].
- Switch the current connection to the other radio access system.

NOTE 1: Requirements concerning the establishment of the radio connection towards the other radio access system and the signalling procedure are outside the scope of the present document.

NOTE 2: The release of the UMTS radio resources is initiated by the other system.



NOTE 3: Currently only one radio access bearer can be associated with the IE "Inter-system message", and this association is limited to the radio access bearers in the CS domain. It is assumed that all the radio access bearers in the PS domain, if any, remain after the handover.

#### Reference(s)

TS 25.331 Clause 8.3.7.3.

#### 8.3.7.3.3 ————— Test purpose

To test that the UE handovers to the indicated channel of lower data rate in the GSM target cell when it is in the data call active state in the UTRAN serving cell and receives an HANDOVER FROM UTRAN COMMAND.

#### 8.3.7.3.4 ————— Method of test

#### Initial conditions

System Simulator : 2 cells – Cell 1 is UTRAN, Cell 2 is GSM. GSM 51.010 clause 26.6.5.1 or clause 26.13.1.3 (for HSCSD) shall be referenced for the default parameters of cell 2.

UE: CC State U10 in cell 1

#### Related ICS/IXIT statement(s)

- UE supports both GSM and UTRAN Radio Access Technologies;
- UE supports UTRAN Streaming/unknown/uplink:28.8 DL:28.8 kbps/CS RAB + uplink:3.4 DL:3.4 kbps SRBs;
- UE supports UTRAN Streaming/unknown/uplink:57.6 DL:57.6 kbps/CS RAB + uplink:3.4 DL:3.4 kbps SRBs;
- UE supports GSM 14.4 kbps data (HSCSD or full rate traffic channel for 14.4 kbit/s user data (TCH/F14.4));
- UE supports GSM 28.8 kbps data (HSCSD or enhanced circuit switched full rate traffic channel for 28.8 kbit/s user data (E-TCH/F28.8));
- UE supports GSM-P, GSM-E, GSM-DCS, GSM-450, GSM-480.

#### Foreseen final state of the UE

The UE is in CC state U10 on cell 2.

#### Test Procedure

The SS starts the UTRAN cell and brings the UE into data call active state (CC state U10) with a suitable configuration (e.g. Streaming/unknown/uplink:28.8 DL:28.8 kbps/CS RAB + uplink:3.4 DL:3.4 kbps SRBs for  $M = 1$ ). The SS starts GSM cell and configures a traffic channel (e.g. 14.4 kbps data channel for  $M = 1$ ), then sends HANDOVER FROM UTRAN COMMAND indicating the traffic channel of the target GSM cell to the UE through DCCH of the serving UTRAN cell. After the UE receives the command it shall configure itself accordingly and switch to the new channel of the GSM cell. The SS checks whether the handover is performed by checking that the UE transmits the HANDOVER COMPLETE message to the SS in GSM cell.

Depending on the PIXIT parameters the above procedure is executed maximum three times, each time with different target channel in the GSM cell.

### Expected sequence

This sequence is performed for a maximum execution counter  $M = 1, 2, 3$ , depending on the PIXIT parameters.

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                             |
|------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                                                                      |
| 1    |           | UE |                                 | The SS bring the UE into UTRAN U10 state in cell 1, the configuration is:<br>Streaming/unknown/uplink:28.8 DL:28.8 kbps/CS-RAB + uplink:3.4 DL:3.4 kbps-SRBs (for $M = 1$ );<br>Streaming/unknown/uplink:57.6 DL:57.6 kbps/CS-RAB + uplink:3.4 DL:3.4 kbps-SRBs (for $M = 2$ and 3). |
| 2    |           | SS |                                 | The SS configures cell 2 as a GSM cell with a traffic channel:<br>for GSM 14.4 kbps data ( $M = 1$ and 2); or<br>for GSM 28.8 kbps data ( $M = 3$ ).                                                                                                                                 |
| 3    |           | ←  | HANDOVER FROM UTRAN COMMAND-GSM | Send on cell 1 (UTRAN cell) and the message indicates: the target channel<br>for GSM 14.4 kbps data ( $M = 1$ and 2); or<br>for GSM 28.8 kbps data ( $M = 3$ ).                                                                                                                      |
| 4    |           | UE |                                 | The UE accepts the handover command and switches to the GSM traffic channel specified in the HANDOVER FROM UTRAN COMMAND-GSM                                                                                                                                                         |
| 5    |           | →  | HANDOVER ACCESS                 | The SS receives this burst on the traffic channel of cell 2 (GSM cell). It implies that the UE has switched to GSM cell.                                                                                                                                                             |
| 6    |           | →  | HANDOVER ACCESS                 |                                                                                                                                                                                                                                                                                      |
| 7    |           | →  | HANDOVER ACCESS                 |                                                                                                                                                                                                                                                                                      |
| 8    |           | →  | HANDOVER ACCESS                 |                                                                                                                                                                                                                                                                                      |
| 9    |           | ←  | PHYSICAL INFORMATION            |                                                                                                                                                                                                                                                                                      |
| 10   |           | →  | SABM                            |                                                                                                                                                                                                                                                                                      |
| 11   |           | ←  | UA                              |                                                                                                                                                                                                                                                                                      |
| 12   |           | →  | HANDOVER COMPLETE               | The SS receives the message on the traffic channel of GSM cell.                                                                                                                                                                                                                      |

### Specific message contents

For execution 1:

Same as the message contents of clause 8.3.7.2 for  $M = 1$ .

For execution 2:

Same as the message contents of clause 8.3.7.2 for  $M = 1$ .

For execution 3:

Same as the message contents of clause 8.3.7.2 for  $M = 2$ .

#### 8.3.7.3.5 Test requirement

After step 12 the ongoing call shall be continued on the GSM cell.

### 8.3.7.4 Inter system handover from UTRAN/To GSM/Speech/Establishment/Success

#### 8.3.7.4.1 Definition

#### 8.3.7.4.2 Conformance requirement

When the UE receives an HANDOVER FROM UTRAN COMMAND message from UTRAN the UE shall take the following actions:

- Establish the connection to the other radio access system, by using the contents of the IE "Inter system message". This IE contains candidate/ target cell identifier(s) and radio parameters relevant for the other radio access system.
- For each IE "Remaining radio access bearer", associate the radio access bearer given by the IE "RAB info" to the radio resources in the target system given by the IE "Inter system message". Other information for making the association may be included in the IE "Inter system message" and requirements may be stated in the specifications relevant for the target system [FFS].
- Switch the current connection to the other radio access system.

NOTE 1: Requirements concerning the establishment of the radio connection towards the other radio access system and the signalling procedure are outside the scope of the present document.

NOTE 2: The release of the UMTS radio resources is initiated by the other system.

NOTE 3: Currently only one radio access bearer can be associated with the IE "Inter system message", and this association is limited to the radio access bearers in the CS domain. It is assumed that all the radio access bearers in the PS domain, if any, remain after the handover.

### Reference(s)

TS 25.331 Clause 8.3.7.3.

#### 8.3.7.4.3 — Test purpose

To test that the UE handovers to the indicated channel in the GSM target cell when it is in the call establishment phase in the UTRAN serving cell and receives an HANDOVER FROM UTRAN COMMAND.

#### 8.3.7.4.4 — Method of test

#### Initial conditions

System Simulator : 2 cells – Cell 1 is UTRAN, Cell 2 is GSM. GSM 51.010 clause 26.6.5.1 shall be referenced for the default parameters of cell 2.

UE : CC State U1 in cell 1

#### Related ICS/IXIT statement(s)

- UE supports both GSM and UTRAN Radio Access Technologies,
- UE supports UTRAN AMR,
- UE supports GSM FR,
- UE supports GSM-P, GSM-E, GSM-DCS, GSM-450, GSM-480.

#### Foreseen final state of the UE

The UE is in CC state U1 on cell 2.

#### Test Procedure

The SS starts the UTRAN cell and the UE is triggered to initialise an MO speech call. During the call establishment phase, after the SS receives SETUP message the SS starts GSM cell and configures a dedicated channel, then sends the UE an HANDOVER FROM UTRAN COMMAND indicating the dedicated channel in the target GSM cell. After the UE receives the command it shall configure itself accordingly and switch to the new channel of the GSM cell. The SS checks whether the handover is performed by checking that the UE transmits the HANDOVER COMPLETE message to the SS in GSM cell.

## Expected sequence

| Step | Direction |    | Message                            | Comments                                                                                                                       |
|------|-----------|----|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                    |                                                                                                                                |
| 1    | UE        |    |                                    | To trigger the UE to initialise an MO call                                                                                     |
| 2    | →         |    | SETUP                              | U1                                                                                                                             |
| 3    |           | SS |                                    | The SS starts the GSM cell and configure a dedicated channel SDCCH.                                                            |
| 4    | ←         |    | HANDOVER FROM UTRAN<br>COMMAND-GSM | Send on cell 1 (UTRAN cell) and the message indicates: the dedicated channel SDCCH.                                            |
| 5    | UE        |    |                                    | The UE accepts the handover command and switches to the GSM dedicated channel specified in the HANDOVER FROM UTRAN COMMAND-GSM |
| 6    | →         |    | HANDOVER ACCESS                    | The SS receives this burst on the dedicated channel of cell 2 (GSM cell) It implies that the UE has switched to GSM cell.      |
| 7    | →         |    | HANDOVER ACCESS                    |                                                                                                                                |
| 8    | →         |    | HANDOVER ACCESS                    |                                                                                                                                |
| 9    | →         |    | HANDOVER ACCESS                    |                                                                                                                                |
| 10   | ←         |    | PHYSICAL INFORMATION               |                                                                                                                                |
| 11   | →         |    | SABM                               |                                                                                                                                |
| 12   | ←         |    | UA                                 |                                                                                                                                |
| 13   | →         |    | HANDOVER COMPLETE                  | The SS receives the message on the dedicated channel of GSM cell.                                                              |

## Specific message contents

## HANDOVER FROM UTRAN COMMAND-GSM

| Information Element                                                                                                                                                                                                                                                                 | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier<br>Integrity check info<br><br>—→ Message authentication code<br><br>—→ RRC Message sequence number<br>Activation time<br>RAB-Info<br>Inter-system message<br>—→ System type<br>—→ Frequency Band<br>—→ CHOICE GSM message<br>—→ Message | Arbitrarily selects one integer between 0 to 3<br>The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted.<br>SS calculates the value of MAC-I for this message and writes to this IE.<br>SS provides the value of this IE, from its internal counter.<br>now<br>Not present<br><br>GSM<br>GSM/DCS-1800-Band<br>Single GSM message<br>GSM HANDOVER COMMAND formatted as Variable Length BIT STRING without Length Indicator. The contents of the HANDOVER COMMAND see next table. |

## HANDOVER COMMAND

Same as the HANDOVER COMMAND for M = 4 in clause 26.6.5.2 of GSM 51.010 version 8.2.0 Release 1999

## 8.3.7.4.5 ——— Test requirement

At step 13 the SS shall receive HANDOVER COMPLETE message on the dedicated channel of the GSM cell.

### ~~8.3.7.5 Inter system handover from UTRAN/To GSM/Speech/Failure~~

#### ~~8.3.7.5.1 Definition~~

#### ~~8.3.7.5.2 Conformance requirement~~

~~If the UE does not succeed to establish the connection to the other radio access technology, it shall~~

- ~~— resume the connection to UTRAN using the resources used before receiving the HANDOVER FROM UTRAN COMMAND message; and~~
- ~~— transmit the INTER-SYSTEM HANDOVER FAILURE message on uplink DCCH using AM RLC. When the successful delivery of the INTER-SYSTEM FAILURE message has been confirmed by RLC, the procedure ends.~~

#### ~~Reference(s)~~

~~TS 25.331 Clause 8.3.7.5.~~

#### ~~8.3.7.5.3 Test purpose~~

~~To test that the UE reactivates the old channel and transmits HANDOVER FROM UTRAN FAILURE message to the network on the old channel in UTRAN cell when it receives an HANDOVER FROM UTRAN COMMAND and the connection to GSM for handover can not be established.~~

#### ~~8.3.7.5.4 Method of test~~

#### ~~Initial conditions~~

~~System Simulator : 2 cells – Cell 1 is UTRAN, Cell 2 is GSM. GSM 51.010 clause 26.6.5.1 shall be referenced for the default parameters of cell 2.~~

~~UE: CC State U10 in cell 1~~

#### ~~Related ICS/IXIT statement(s)~~

- ~~— UE supports both GSM and UTRAN Radio Access Technologies,~~
- ~~— UE supports GSM-FR,~~
- ~~— UE supports UTRAN-AMR,~~
- ~~— UE supports GSM-P, GSM-E, GSM-DCS, GSM-450, GSM-480.~~

#### ~~Foreseen final state of the UE~~

~~The UE is in CC state U10 on cell 1.~~

#### ~~Test Procedure~~

~~The SS starts the UTRAN cell and brings the UE into call active state (CC state U10) with AMR. The SS starts GSM cell without activating any dedicated channel in the cell, then sends HANDOVER FROM UTRAN COMMAND indicating a dedicated channel of the target GSM cell to the UE through DCCH of the serving UTRAN cell. The UE receives the command and configures itself accordingly but can not complete the handover. The SS checks that the handover is failed by checking that the UE transmits the HANDOVER FROM UTRAN FAILURE message to the SS in UTRAN cell.~~

## Expected sequence

| Step | Direction |    | Message                            | Comments                                                                                                                     |
|------|-----------|----|------------------------------------|------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                    |                                                                                                                              |
| 1    | UE        |    |                                    | The SS bring the UE into UTRAN U10 state in cell 1                                                                           |
| 2    | SS        |    |                                    | The SS configures cell 2 as a GSM cell but without any traffic channel.                                                      |
| 3    | ←         |    | HANDOVER FROM UTRAN<br>COMMAND-GSM | Send on cell 1 (UTRAN cell) and the message indicates: the target channel for GSM FR which does not exist in the GSM cell.   |
| 4    | UE        |    |                                    | The UE accepts the handover command and switches to the GSM traffic channel specified in the HANDOVER FROM UTRAN COMMAND-GSM |
| 5    | →         |    | HANDOVER FROM UTRAN<br>FAILURE     | The SS receives the message on the old channel of UTRAN cell.                                                                |

## Specific message contents

Same as the message contents of clause 8.3.7.1 for  $M = 3$ .

## HANDOVER FROM UTRAN FAILURE

| Information Element               | Value/remark                                                                                                                                                                                                                                       |
|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                      |                                                                                                                                                                                                                                                    |
| RRC transaction identifier        | Checked to see if it matches the same value used in the corresponding downlink HANDOVER FROM UTRAN COMMAND—GSM message                                                                                                                             |
| Integrity check info              | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| —→ Message authentication code    | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| —→ RRC Message sequence number    | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Inter-RAT handover failure        |                                                                                                                                                                                                                                                    |
| —Inter-RAT handover failure cause | physical channel failure                                                                                                                                                                                                                           |
| Inter-system message              | Not Checked                                                                                                                                                                                                                                        |

## 8.3.7.5.5 ————— Test requirement

After step  $n+1$  the SS shall receive HANDOVER FROM UTRAN FAILURE message on the old channel of the UTRAN cell.

## 8.3.7.6 ————— Inter system handover from UTRAN/To GSM/Speech/Failure (L2 Establishment)

## 8.3.7.6.1 ————— Definition

## 8.3.7.6.2 ————— Conformance requirement

If the UE does not succeed to establish the connection to the other radio access technology, as is unable to obtain L2 establishment it shall

- resume the connection to UTRAN using the resources used before receiving the HANDOVER FROM UTRAN COMMAND message; and
- transmit the HANDOVER FROM UTRAN FAILURE message on uplink DCCH using AM RLC.

### Reference(s)

3GPP TS 25.331 clause 8.3.7

TS 04.06 Clause 5.4.1.3

TS 04.08 Clause 3.1.5

### 8.3.7.6.3 ————— Test purpose

To Test that the UE shall keep its old configuration and transmit a HANDOVER FROM UTRAN FAILURE message, which is set to “physical channel failure” in IE “Inter\_RAT HO failure cause”, when it receives a HANDOVER FROM UTRAN COMMAND and the connection to GSM for handover cannot be established due to failure in L2 establishment.

### 8.3.7.6.4 ————— Method of test

#### Initial conditions

System Simulator : 2 cells – Cell 1 is UTRAN, Cell 2 is GSM. GSM 51010-1 section 26.6.5.1 shall be referenced for the default parameters of cell 2.

UE: CC State U10 in cell 1

#### Related ICS/IXIT statement(s)

UE supports both GSM and UTRAN Radio Access Technologies,

UE supports GSM-FR,

UE supports UTRAN-AMR,

UE supports GSM-P, GSM-E, GSM-DCS, GSM-450, GSM-480.

#### Foreseen final state of the UE

The UE is in CC state U10 on cell 1.

#### Test Procedure

The SS starts the UTRAN cell and brings the UE into call active state (CC state U10) with AMR. SS activates a dedicated GSM traffic channel then sends HANDOVER FROM UTRAN COMMAND indicating a dedicated channel of the target GSM cell to the UE through DCCH of the serving UTRAN cell. When the UE does not succeed in establishing the connection to the target radio access technology it shall revert back to UTRA configuration establish the UTRA physical channel(s) used at the time for reception of HANDOVER FROM UTRAN COMMAND transmit the HANDOVER FROM UTRAN FAILURE.

## Expected sequence

| Step | Direction |    | Message                            | Comments                                                                                                                                                                                                                                                                           |
|------|-----------|----|------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                    |                                                                                                                                                                                                                                                                                    |
| 1    | UE        |    |                                    | The SS brings the UE into UTRAN U10 state in cell 1                                                                                                                                                                                                                                |
| 2    | SS        |    |                                    | The SS configures cell 2 as a GSM cell with traffic channel.                                                                                                                                                                                                                       |
| 3    | ←         |    | HANDOVER FROM UTRAN<br>COMMAND-GSM | Send on cell 1 (UTRAN cell) and the message indicates:<br>The target channel.                                                                                                                                                                                                      |
| 4    | UE        |    |                                    | The UE accepts the handover command and switches to<br>the GSM traffic channel specified in the HANDOVER<br>FROM UTRAN COMMAND-GSM                                                                                                                                                 |
| 5    | →         |    | HANDOVER ACCESS                    | The SS receives this burst on the traffic channel of cell 2<br>(GSM cell). It implies that the UE has switched to GSM<br>cell.                                                                                                                                                     |
| 6    | →         |    | HANDOVER ACCESS                    |                                                                                                                                                                                                                                                                                    |
| 7    | →         |    | HANDOVER ACCESS                    |                                                                                                                                                                                                                                                                                    |
| 8    | →         |    | HANDOVER ACCESS                    |                                                                                                                                                                                                                                                                                    |
| 9    | ←         |    | PHYSICAL INFORMATION               | Allows a proper transmission by the MS.<br>Sent in unacknowledged mode as soon as the SS has<br>detected a HANDOVER ACCESS.<br>As soon as MS detects it then it stops T3124.<br>On SS side T3105 could be started N times at the<br>maximum as long as the step 8 is not performed |
| 10   | →         |    | SABM                               | To establish L2 connection                                                                                                                                                                                                                                                         |
| 11   | SS        |    |                                    | SS does not sent UA frame                                                                                                                                                                                                                                                          |
| 12   | UE        |    |                                    | On T200 expiration, SS sends N200 times the SABM<br>frame (steps 10)<br>Then MS deactivates new channels and reactivates old<br>UTRA resources it had before receiving the handover<br>command                                                                                     |
| 13   | →         |    | HANDOVER FROM UTRAN<br>FAILURE     | The SS receives the message on the old channel of<br>UTRAN cell. Sent in acknowledge mode<br>The cause in the IE "inter-RAT change failure" is set to<br>"physical channel failure"                                                                                                |

## Specific message contents

Same as the message contents of clause 8.3.7.1 for M = 3.

## HANDOVER FROM UTRAN FAILURE

| Information Element                                              | Value/remark                                                                                                                                                                                                                                                   |
|------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier                       | Checked to see if it matches the same value used in the<br>corresponding downlink HANDOVER FROM UTRAN<br>COMMAND—GSM message                                                                                                                                   |
| Integrity check info                                             | The presence of this IE is dependent on IXIT statements<br>in TS 34.123-2. If integrity protection is indicated to be<br>active, this IE shall be present with the values of the sub<br>IEs as stated below. Else, this IE and the sub-IEs shall be<br>absent. |
| — Message authentication code                                    | This IE is checked to see if it is present. The value is<br>compared against the XMAC-I value computed by SS.                                                                                                                                                  |
| — RRC Message sequence number                                    | This IE is checked to see if it is present. The value is used<br>by SS to compute the XMAC-I value.                                                                                                                                                            |
| Inter-RAT handover failure<br>— Inter-RAT handover failure cause | physical channel failure                                                                                                                                                                                                                                       |
| Inter-system message                                             | Not Checked                                                                                                                                                                                                                                                    |



#### 8.3.7.6.5 ~~Test requirement~~

~~The SS shall receive HANDOVER FROM UTRAN FAILURE message on the old channel of the UTRAN cell.~~

#### 8.3.7.7 ~~Inter system handover from UTRAN/To GSM/Speech/Failure (L1 Synchronization)~~

##### 8.3.7.7.1 ~~Definition~~

##### 8.3.7.7.2 ~~Conformance requirement~~

~~If the UE does not succeed to establish the connection to the other radio access technology, as is unable to obtain L1 synchronization it shall~~

- ~~— resume the connection to UTRAN using the resources used before receiving the HANDOVER FROM UTRAN COMMAND message; and~~
- ~~— transmit the HANDOVER FROM UTRAN FAILURE message on uplink DCCH using AM RLC.~~

#### Reference(s)

TS 25.331 Clause 8.3.7.5

TS 04.06 Clause 5.4.1

##### 8.3.7.7.3 ~~Test purpose~~

~~To Test that the UE shall keep its old configuration and transmit a HANDOVER FROM UTRAN FAILURE message, which is set to “physical channel failure” in IE “Inter\_RAT HO failure cause”, when it receives a HANDOVER FROM UTRAN COMMAND and the connection to GSM for handover cannot be established due failure in L1 Synchronization.~~

##### 8.3.7.7.4 ~~Method of test~~

#### Initial conditions

System Simulator : 2 cell – Cell 1 is UTRAN, Cell 2 is GSM. GSM 51.010 version 4.4.0 section 26.6.5.1 shall be referenced for the default parameters of cell 2.

UE : CC State U10 in cell 1

#### Related ICS/IXIT statement(s)

UE supports both GSM and UTRAN Radio Access Technologies,

UE supports GSM FR,

UE supports UTRAN AMR,

UE supports GSM-P, GSM-E, GSM-DCS, GSM-450, GSM-480.

#### Foreseen final state of the UE

The UE is in CC state U10 on cell 1.

#### Test Procedure

The SS starts the UTRAN cell and brings the UE into call active state (CC state U10). The SS starts GSM cell activating dedicated channel in the cell, then sends HANDOVER FROM UTRAN COMMAND indicating a dedicated channel of the target GSM cell to the UE through DCCH of the serving UTRAN cell. The power level of target GSM cell is kept at very low level. The UE receives the command and configures itself accordingly but cannot complete the

handover. The SS checks that the handover is failed by checking that the UE transmits the HANDOVER FROM UTRAN FAILURE message to the SS in UTRAN cell.

#### Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                             |
|------|-----------|----|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                      |
| 1    | UE        |    |                                 | The SS brings the UE into UTRAN U10 state in cell 1.                                                                                                 |
| 2    | SS        |    |                                 | The SS configures cell 2 as a GSM cell with a traffic channel.                                                                                       |
| 3    | ←         |    | HANDOVER FROM UTRAN COMMAND-GSM | Send on cell 1 (UTRAN cell) and the message indicates: The target channel for GSM-FR in GSM-Cell.                                                    |
| 4    | UE        |    |                                 | The UE accepts the handover command and switches to the GSM traffic channel specified in the HANDOVER FROM UTRAN COMMAND-GSM                         |
| 5    | →         |    | HANDOVER ACCESS                 | The SS receives this burst on the traffic channel of cell 2 (GSM cell) It implies that the UE has switched to GSM cell.                              |
| 6    | →         |    | HANDOVER ACCESS                 |                                                                                                                                                      |
| 7    | SS        |    |                                 | The target GSM Traffic Channel is Switched off                                                                                                       |
| 8    | →         |    | HANDOVER FROM UTRAN FAILURE     | The SS receives the message on the old channel of UTRAN cell.<br>The cause in the IE "inter-RAT change failure" is set to "physical channel failure" |

#### Specific message contents

Same as the message contents of clause 8.3.7.1 for M = 3.

#### HANDOVER FROM UTRAN FAILURE

| Information Element               | Value/remark                                                                                                                                                                                                                                       |
|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                      |                                                                                                                                                                                                                                                    |
| RRC transaction identifier        | Checked to see if it matches the same value used in the corresponding downlink HANDOVER FROM UTRAN COMMAND-GSM message                                                                                                                             |
| Integrity check info              | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| —→ Message authentication code    | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| —→ RRC Message sequence number    | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Inter-RAT handover failure        |                                                                                                                                                                                                                                                    |
| —Inter-RAT handover failure cause | physical channel failure                                                                                                                                                                                                                           |
| Inter-system message              | Not Checked                                                                                                                                                                                                                                        |

#### 8.3.7.7.5 ————— Test requirement

The SS shall receive HANDOVER FROM UTRAN FAILURE message on the old channel of the UTRAN cell.

### ~~8.3.7.8 Inter system handover from UTRAN/To GSM/Speech/Failure (Invalid Inter-RAT message)~~

#### ~~8.3.7.8.1 Definition~~

#### ~~8.3.7.8.2 Conformance requirement~~

~~If the UE does not succeed to establish the connection to the other radio access technology, as the Inter-RAT message received is invalid, it shall~~

- ~~— resume the connection to UTRAN using the resources used before receiving the INTER-SYSTEM HANDOVER COMMAND message; and~~
- ~~— transmit the INTER-SYSTEM HANDOVER FAILURE message on uplink DCCH using AM RLC. When the successful delivery of the INTER-SYSTEM FAILURE message has been confirmed by RLC, the procedure ends.~~

#### Reference

3GPP TS 25.331 clause 8.3.7.6

#### ~~8.3.7.8.3 Test purpose~~

~~To Test that the UE shall keep its old configuration and transmit a HANDOVER FROM UTRAN FAILURE message, which is set to "Inter-RAT protocol error" in IE "Inter\_RAT HO failure cause", when it receives a Handover From UTRAN message, with the IE "Inter-RAT message" received within the HANDOVER FROM UTRAN COMMAND message not including a valid inter-RAT handover message in accordance with the protocol specifications for the target RAT.~~

#### ~~8.3.7.8.4 Method of test~~

#### Initial conditions

System Simulator : 1 UTRAN cell.

UE : CC State U10 in cell 1

#### Related ICS/IXIT statement(s)

UE supports both GSM and UTRAN Radio Access Technologies,

UE supports GSM-FR,

UE supports UTRAN-AMR,

UE supports GSM-P, GSM-E, GSM-DCS, GSM-450, GSM-480.

#### Foreseen final state of the UE

The UE is in CC state U10 on cell 1.

#### Test Procedure

The SS starts the UTRAN cell and brings the UE into call active state (CC state U10) with AMR. The SS then sends an HANDOVER FROM UTRAN COMMAND message not including a valid inter RAT handover message in accordance with the protocol specifications for the target RAT, to the UE through DCCH of the serving UTRAN cell. The UE receives the command and finds that the Inter Rat message is Invalid. The SS checks that the handover is failed by checking that the UE transmits the INTER-SYSTEM HANDOVER FAILURE message to the SS in UTRAN cell.

## Expected sequence

| Step | Direction |    | Message                       | Comments                                                                                       |
|------|-----------|----|-------------------------------|------------------------------------------------------------------------------------------------|
|      | UE        | SS |                               |                                                                                                |
| 1    | UE        |    |                               | The SS brings the UE into UTRAN U10 state in cell 1                                            |
| 2    | ←         |    | HandoverFromUTRAN-Command-GSM | Send on cell 1 (UTRAN-cell) and the message carries an Invalid HANDOVER FROM UTRAN COMMAND-GSM |
| 3    | →         |    | InterSystemHandoverFailure    | The SS receives the message on the old channel of UTRAN cell.                                  |

## Specific message contents

## HANDOVER FROM UTRAN COMMAND-GSM

| Information Element             | Value/remark                                                                                                                                                                                                                             |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                    | Arbitrarily selects one integer between 0 to 3                                                                                                                                                                                           |
| RRC transaction identifier      | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| Integrity check info            | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                 |
| ——→ Message authentication code | SS provides the value of this IE, from its internal counter.                                                                                                                                                                             |
| ——→ RRC Message sequence number | Now                                                                                                                                                                                                                                      |
| Activation time                 | Not present                                                                                                                                                                                                                              |
| RAB-Info                        |                                                                                                                                                                                                                                          |
| Inter-system message            |                                                                                                                                                                                                                                          |
| ——→ System type                 | GSM                                                                                                                                                                                                                                      |
| ——→ Frequency Band              | GSM/DCS-1800-Band                                                                                                                                                                                                                        |
| ——→ CHOICE-GSM message          | Single GSM message                                                                                                                                                                                                                       |
| ——→ Message                     | GSM HANDOVER COMMAND formatted as Variable Length BIT STRING without Length Indicator. The contents of the HANDOVER COMMAND see next table.                                                                                              |

## HANDOVER COMMAND

|                                       |
|---------------------------------------|
| Contains an Invalid Handover Command. |
|---------------------------------------|

## HANDOVER FROM UTRAN FAILURE

| Information Element               | Value/remark                                                                                                                                                                                                                                       |
|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                      | Checked to see if it matches the same value used in the corresponding downlink HANDOVER FROM UTRAN COMMAND-GSM message                                                                                                                             |
| RRC transaction identifier        | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| Integrity check info              | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| ——→ Message authentication code   | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| ——→ RRC Message sequence number   |                                                                                                                                                                                                                                                    |
| Inter-RAT handover failure        | Inter-RAT protocol error                                                                                                                                                                                                                           |
| →Inter-RAT handover failure cause | Not checked                                                                                                                                                                                                                                        |
| Inter-system message              |                                                                                                                                                                                                                                                    |

#### 8.3.7.8.5 ~~Test requirement~~

~~In step 3 the SS shall receive INTER-SYSTEM HANDOVER FAILURE message on the old channel of the UTRAN cell.~~

#### 8.3.7.9 ~~Inter system handover from UTRAN/To GSM/Speech/Failure (Unsupported configuration)~~

##### 8.3.7.9.1 ~~Definition~~

##### 8.3.7.9.2 ~~Conformance requirement:~~

~~If the UE does not succeed to establish the connection to the other radio access technology, as the configuration specified in the Inter-RAT message is not supported, it shall~~

- ~~— resume the connection to UTRAN using the resources used before receiving the INTER-SYSTEM HANDOVER COMMAND message; and~~
- ~~— transmit the INTER-SYSTEM HANDOVER FAILURE message on uplink DCCH using AM RLC. When the successful delivery of the INTER-SYSTEM FAILURE message has been confirmed by RLC, the procedure ends.~~

#### Reference

3GPP TS 25.331 clause 8.3.7.8

##### 8.3.7.9.3 ~~Test purpose~~

~~To Test that the UE shall keep its old configuration and transmit a HANDOVER FROM UTRAN FAILURE message, which is set to “configuration unsupported” in IE “Inter\_RAT HO failure cause”, when it receives a Handover From UTRAN message, with the IE "Inter-RAT message" received within the HANDOVER FROM UTRAN COMMAND message including a Configuration not Supported by the UE.~~

##### 8.3.7.9.4 ~~Method of test~~

#### ~~Initial conditions~~

~~System Simulator : 1 UTRAN cell.~~

~~UE : CC State U10 in cell 1~~

#### Related ICS/IXIT statement(s)

UE supports both GSM and UTRAN Radio Access Technologies,

UE supports GSM-FR,

UE supports UTRAN-AMR,

UE supports GSM-P, GSM-E, GSM-DCS, GSM-450, GSM-480.

#### Foreseen final state of the UE

The UE is in CC state U10 on cell 1.

#### Test Procedure

The SS starts the UTRAN cell and brings the UE into call active state (CC state U10) with AMR. The SS then sends an HANDOVER FROM UTRAN COMMAND message including a Configuration not Supported by the UE in inter RAT handover message, to the UE through DCCH of the serving UTRAN cell. The UE receives the command and

finds that the configuration given in Inter-Rat message is not supported. The SS checks that the handover is failed by checking that the UE transmits the INTER-SYSTEM HANDOVER FAILURE message to the SS in UTRAN cell.

#### Expected sequence

| Step | Direction |    | Message                       | Comments                                                                          |
|------|-----------|----|-------------------------------|-----------------------------------------------------------------------------------|
|      | UE        | SS |                               |                                                                                   |
| 1    | UE        |    |                               | The SS brings the UE into UTRAN U10 state in cell 1                               |
| 2    | ←         |    | HandoverFromUTRAN Command-GSM | Send on cell 1 (UTRAN cell) and the message carries an unsupported configuration. |
| 3    | →         |    | InterSystemHandoverFailure    | The SS receives the message on the old channel of UTRAN cell.                     |

#### Specific message contents

##### HANDOVER FROM UTRAN COMMAND-GSM

| Information Element            | Value/remark                                                                                                                                                                                                                            |
|--------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                   | Arbitrarily selects one integer between 0 to 3                                                                                                                                                                                          |
| RRC transaction identifier     | The presence of this IE is dependent on IXT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| Integrity-check info           | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                |
| —→ Message authentication code | SS provides the value of this IE, from its internal counter.                                                                                                                                                                            |
| —→ RRC Message sequence number | Now                                                                                                                                                                                                                                     |
| Activation time                | Not present                                                                                                                                                                                                                             |
| RAB Info                       |                                                                                                                                                                                                                                         |
| Inter-system message           |                                                                                                                                                                                                                                         |
| —→ System type                 | GSM                                                                                                                                                                                                                                     |
| —→ Frequency Band              | GSM/DCS-1800-Band                                                                                                                                                                                                                       |
| —→ CHOICE GSM message          | Single GSM message                                                                                                                                                                                                                      |
| —→ Message                     | GSM HANDOVER COMMAND formatted as Variable Length BIT STRING without Length Indicator. The contents of the HANDOVER COMMAND see next table.                                                                                             |

##### HANDOVER COMMAND

|                                                                                               |
|-----------------------------------------------------------------------------------------------|
| Contains a Configuration not supported By the UE (Handover to a Band not supported by the UE) |
|-----------------------------------------------------------------------------------------------|

##### HANDOVER FROM UTRAN FAILURE

| Information Element                 | Value/remark                                                                                                                                                                                                                                      |
|-------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                        | Checked to see if it matches the same value used in the corresponding downlink HANDOVER FROM UTRAN COMMAND—GSM message                                                                                                                            |
| RRC transaction identifier          | The presence of this IE is dependent on IXT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| Integrity-check info                | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                        |
| —→ Message authentication code      | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                  |
| —→ RRC Message sequence number      |                                                                                                                                                                                                                                                   |
| Inter-RAT handover failure          |                                                                                                                                                                                                                                                   |
| —→ Inter-RAT handover failure cause | configuration-unsupported                                                                                                                                                                                                                         |

|                      |             |
|----------------------|-------------|
| Inter-system-message | Not checked |
|----------------------|-------------|

#### 8.3.7.9.5 ——— Test requirement

In step 3 the SS shall receive INTER-SYSTEM HANDOVER FAILURE message on the old channel of the UTRAN cell.

#### 8.3.7.10 ——— Inter system handover from UTRAN/To GSM/Speech/Failure (Reception by UE in CELL\_FACH)

##### 8.3.7.10.1 ——— Definition

##### 8.3.7.10.2 ——— Conformance requirement

If the UE does not succeed to establish the connection to the other radio access technology, as the Message received is not compatible with receiver state, it shall

- resume the connection to UTRAN using the resources used before receiving the INTER-SYSTEM HANDOVER COMMAND message; and
- transmit the INTER-SYSTEM HANDOVER FAILURE message on uplink DCCH using AM RLC. When the successful delivery of the INTER-SYSTEM FAILURE message has been confirmed by RLC, the procedure ends.

#### Reference

3GPP TS 25.331 clause 8.3.7.8a

##### 8.3.7.10.3 ——— Test purpose

The UE shall keep its old configuration when the UE receives a HANDOVER FROM UTRAN COMMAND message when in CELL\_FACH state and then transmit a HANDOVER FROM UTRAN COMMAND FAILURE message on the DCCH using AM RLC, which sets value “protocol-error” in IE “Inter\_RAT HO failure-cause” and is set to “Message not compatible with receiver state” in IE “Protocol error-cause”.

##### 8.3.7.10.4 ——— Method of test

#### Initial conditions

System Simulator : 1 UTRAN Cell

UE : RRC State CS-DCCH\_FACH (state 6-6) as specified in clause 7.4 of TS 34.108, on Cell 1

#### Related ICS/IXIT statement(s)

UE supports both GSM and UTRAN Radio Access Technologies,

UE supports GSM-FR,

UE supports UTRAN-AMR,

UE supports GSM-P, GSM-E, GSM-DCS, GSM-450, GSM-480.

#### Foreseen final state of the UE

The UE is in RRC is in State CS-DCCH\_FACH (state 6-6) as specified in clause 7.4 of TS 34.108, on cell 1.

## Test Procedure

The SS starts the UTRAN cell and brings the UE into RRC Cell\_FACH\_DTCH. It then Transmits Radio Bearer reconfiguration PDU to move UE to Cell\_FACH state. The SS starts GSM cell without activating any dedicated channel in the cell, then sends INTER-SYSTEM HANDOVER COMMAND indicating a dedicated channel of the target GSM cell to the UE through DCCH of the serving UTRAN cell. The UE receives the command and configures itself accordingly but cannot complete the handover. The SS checks that the handover is failed by checking that the UE transmits the INTER-SYSTEM HANDOVER FAILURE message to the SS in UTRAN cell.

## Expected sequence

| Step | Direction |    | Message                        | Comments                                                                          |
|------|-----------|----|--------------------------------|-----------------------------------------------------------------------------------|
|      | UE        | SS |                                |                                                                                   |
| 1    |           | UE |                                | The SS brings the UE into CS-DCCH_FACH (state 6-6) _FACH state in cell 1          |
| 2    |           | ←  | InterSystemHandoverCommand-GSM | Send on cell 1 (UTRAN cell) and the message indicates: The target channel for GSM |
| 3    |           | →  | InterSystemHandoverFailure     | The SS receives the message on the old channel of UTRAN cell.                     |

## Specific message contents

Same as the message contents of clause 8.3.7.1 for M = 3.

## HANDOVER FROM UTRAN FAILURE

| Information Element                 | Value/remark                                                                                                                                                                                                                                       |
|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                        | Checked to see if it matches the same value used in the corresponding downlink HANDOVER FROM UTRAN COMMAND-GSM message                                                                                                                             |
| RRC transaction identifier          |                                                                                                                                                                                                                                                    |
| Integrity check info                |                                                                                                                                                                                                                                                    |
| —→ Message authentication code      |                                                                                                                                                                                                                                                    |
| —→ RRC Message sequence number      | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub IEs shall be absent. |
| Inter-RAT handover failure          |                                                                                                                                                                                                                                                    |
| —→ Inter-RAT handover failure cause |                                                                                                                                                                                                                                                    |
| ——→ Diagnostics Type                |                                                                                                                                                                                                                                                    |
| ——→ Protocol Error Cause            | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| Inter-system message                |                                                                                                                                                                                                                                                    |
|                                     | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
|                                     | Protocol Error                                                                                                                                                                                                                                     |
|                                     | Type1                                                                                                                                                                                                                                              |
|                                     | Message Not Compatible With Receiver State                                                                                                                                                                                                         |
|                                     | Not Checked                                                                                                                                                                                                                                        |

### 8.3.7.10.5 ————— Test requirement

After step 2 the SS shall receive INTER-SYSTEM HANDOVER FAILURE message on the old channel of the UTRAN cell.

### 8.3.7.11 ————— Inter system handover from UTRAN/To GSM/Speech/Failure (Invalid message reception)

#### 8.3.7.11.1 ————— Definition

#### 8.3.7.11.2 ————— Conformance requirement:

If the UE does not succeed to establish the connection to the other radio access technology, as the Handover Message received is short to decode into a valid message, it shall



- resume the connection to UTRAN using the resources used before receiving the INTER-SYSTEM HANDOVER COMMAND message; and
- transmit the INTER-SYSTEM HANDOVER FAILURE message on uplink DCCH using AM RLC. When the successful delivery of the INTER-SYSTEM FAILURE message has been confirmed by RLC, the procedure ends.

## Reference

3GPP TS 25.331 clause 8.3.7

### 8.3.7.11.3 Test purpose

The UE shall keep its old configuration when the UE receives a Handover From UTRAN message, which will be short to decode into a valid Handover From UTRAN message. It shall then transmit an RRC STATUS message on the uplink DCCH. The IE "Protocol error information" shall contain an IE "Protocol error cause" set to "ASN.1 violation or encoding error";

### 8.3.7.11.4 Method of test

#### Initial conditions

System Simulator : 1 UTRAN cell.

UE : CC State U10 in cell 1

#### Related ICS/IXIT statement(s)

UE supports both GSM and UTRAN Radio Access Technologies,

UE supports GSM-FR,

UE supports UTRAN-AMR,

UE supports GSM-P, GSM-E, GSM-DCS, GSM-450, GSM-480.

#### Foreseen final state of the UE

The UE is in CC state U10 on cell 1.

#### Test Procedure

The SS starts the UTRAN cell and brings the UE into call active state (CC state U10) with AMR. The SS then sends an HANDOVER FROM UTRAN COMMAND message, which will be short to decode into a valid Handover From UTRAN message, to the UE through DCCH of the serving UTRAN cell. The SS checks that the handover is failed by checking that the UE transmits an RRC STATUS message on the uplink DCCH. The IE "Protocol error information" shall contain an IE "Protocol error cause" set to "ASN.1 violation or encoding error";

#### Expected sequence

| Step | Direction |    | Message                       | Comments                                                                                                              |
|------|-----------|----|-------------------------------|-----------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                               |                                                                                                                       |
| 1    | UE        |    |                               | The SS brings the UE into UTRAN U10 state in cell 1                                                                   |
| 2    |           | ←  | HandoverFromUTRAN Command-GSM | Send on cell 1 (UTRAN cell) and the message is short in length to be decoded into a valid Handover From UTRAN command |
| 3    |           | →  | RRCStatus                     | The SS receives the message on the old channel of UTRAN cell.                                                         |

### Specific message contents

#### HANDOVER FROM UTRAN COMMAND-GSM

A Short Message that shall not result in a valid Handover From UTRAN Command shall be sent.

#### RRC STATUS (Step 3)

| Information Element        | Value/remark                                                 |
|----------------------------|--------------------------------------------------------------|
| Protocol error information | Checked to see if set to "ASN.1 Violation or Encoding error" |

#### 8.3.7.11.5 ~~Test requirement~~

In step 3 the SS shall receive RRC Status message in the UTRAN cell.

#### 8.3.7.12 ~~Inter system handover from UTRAN/To GSM/Speech/Failure (Physical channel Failure and Reversion Failure)~~

##### 8.3.7.12.1 ~~Definition~~

##### 8.3.7.12.2 ~~Conformance requirement:~~

If the UE does not succeed to establish the connection to the other radio access technology and fail to resume the connection to UTRAN using the resources used before receiving the INTER-SYSTEM HANDOVER COMMAND message, it shall

- ~~perform a cell update procedure; and~~
- ~~transmit the INTER-SYSTEM HANDOVER FAILURE message on uplink DCCH using AM RLC. When the successful delivery of the INTER-SYSTEM FAILURE message has been confirmed by RLC, the procedure ends.~~

#### Reference

3GPP TS 25.331 clause 8.3.7.5

##### 8.3.7.12.3 ~~Test purpose~~

The UE shall perform a cell update when the UE fails to revert to the old configuration after the detection of physical channel failure in the target RAT cell as given in HANDOVER FROM UTRAN procedure. After the UE completes cell update procedure, the UE transmit HANDOVER FROM UTRAN FAILURE message on the DCCH using AM RLC, which is set IE "failure-cause" to "physical channel failure".

##### 8.3.7.12.4 ~~Method of test~~

#### Initial conditions

System Simulator : 2 cells – Cell 1 is UTRAN, Cell 2 is GSM. GSM 11.10-1 section 26.6.5.1 shall be referenced for the default parameters of cell 2.

UE : CC State U10 in cell 1

#### Related ICS/IXIT statement(s)

UE supports both GSM and UTRAN Radio Access Technologies,

UE supports GSM-FR,

UE supports UTRAN-AMR,

UE supports GSM-P, GSM-E, GSM-DCS, GSM-450, GSM-480.

#### Foreseen final state of the UE

The UE is in CC state U10 on cell 1.

#### Test Procedure

The SS starts the UTRAN cell and brings the UE into call active state (CC state U10) with AMR. The SS starts GSM cell without activating any dedicated channel in the cell, then sends INTER-SYSTEM HANDOVER COMMAND indicating a dedicated channel of the target GSM cell to the UE through DCCH of the serving UTRAN cell. The UE receives the command and configures itself accordingly but cannot complete the handover and wants to revert to the old configuration, but the UE cannot revert to the old configuration because the SS shall not use the old configuration. The UE transmit CELL UPDATE message on uplink CCCH with IE "Cell update cause" set to "radio link failure". The SS shall transmit CELL UPDATE CONFIRM message on downlink CCCH after receiving CELL UPDATE message. The UE transmits PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC and subsequently transmits the INTER-SYSTEM HANDOVER FAILURE message to the SS in UTRAN cell, on the DCCH using AM RLC, setting the value of IE "failure cause" to "physical channel failure".

#### Expected sequence

| Step | Direction |    | Message                                   | Comments                                                                                                                                                 |
|------|-----------|----|-------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                                          |
| 1    | UE        |    |                                           | The SS brings the UE into UTRAN U10 state in cell 1                                                                                                      |
| 2    |           | SS |                                           | The SS configures cell 2 as a GSM cell but without any traffic channel.                                                                                  |
| 3    |           | ←  | HandoverFromUTRAN Command-GSM             | Send on cell 1 (UTRAN cell) and the message indicates: The target channel for GSM-FR, which does not exist in the GSM cell.                              |
| 4    | UE        |    |                                           | The UE accepts the handover command and switches to the GSM traffic channel specified in the InterSystemHandoverCommand-GSM                              |
| 5    |           | SS |                                           | SS removes the Physical channel (DPCH) allocated to the mobile before handover command transmission                                                      |
| 6    |           | →  | CELL UPDATE                               | The value "radio link failure" shall be set in IE "Cell update cause".                                                                                   |
| 7    |           | ←  | CELL UPDATE CONFIRM                       | This message include IE "Physical channel information elements".                                                                                         |
| 8    |           |    |                                           | The SS configure the dedicated physical channel according to the IE "Physical channel information elements" included in the CELL UPDATE CONFIRM message. |
| 9    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                                                          |
| 10   |           | →  | InterSystemHandoverFailure                | The IE "failure cause" shall be set to "physical channel failure"                                                                                        |

#### Specific message contents

Same as the message contents of clause 8.3.7.1 for M = 3.

#### CELL UPDATE (Step n+1)

The contents of CELL UPDATE message is identical as "Contents of CELL UPDATE message" as found in Annex with the following exceptions:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| U-RNTI              |                                                   |
| ~SRNC Identity      | Check to see if set to '0000 0000 0001'           |
| ~S-RNTI             | Check to see if set to '0000 0000 0000 0000 0001' |
| Cell Update Cause   | "radio link failure"                              |

### CELL UPDATE CONFIRM (Step n+2)

The contents of CELL UPDATE CONFIRM message is identical as "CELL UPDATE CONFIRM message" as found in Annex with the following exceptions:

| Information Element                           | Value/remark                                                |
|-----------------------------------------------|-------------------------------------------------------------|
| U-RNTI                                        | Same as CELL UPDATE message in step 3                       |
| RRC-State indicator                           | CELL_DCH                                                    |
| Frequency info                                |                                                             |
| ——>UARFCN uplink (Nu)                         | Reference to TS34.108 clause 5.1 Test frequencies           |
| ——>UARFCN downlink (Nd)                       | Reference to TS34.108 clause 5.1 Test frequencies           |
| Maximum allowed UL TX power                   | 33dBm                                                       |
| CHOICE Mode                                   | FDD                                                         |
| Downlink information for each radio links     |                                                             |
| ——>Primary CPICH info                         |                                                             |
| ——>Primary scrambling code                    | 100                                                         |
| ——>PDSCH with SHO DCH info                    | Not Present                                                 |
| ——>PDSCH code mapping                         | Not Present                                                 |
| ——>Downlink DPCH info for each RL             |                                                             |
| ——>Primary CPICH usage for channel estimation | Primary CPICH may be used                                   |
| ——>DPCH frame offset                          | 0 chips                                                     |
| ——>Secondary CPICH info                       | Not Present                                                 |
| ——>DL channelisation code                     |                                                             |
| ——>Secondary scrambling code                  | 2                                                           |
| ——>Spreading factor                           | Reference to TS34.108 clause 6.10 Parameter Set             |
| ——>Code number                                | SF-1(SF is reference to TS34.108 clause 6.10 Parameter Set) |
| ——>Scrambling code change                     | No change                                                   |
| ——>TPC combination index                      | 0                                                           |
| ——>SSDT Cell Identity                         | -a                                                          |
| ——>Closed loop timing adjustment mode         | Not Present                                                 |
| ——>SCCPCH information for FACH                | Not Present                                                 |

### HANDOVER FROM UTRAN FAILURE

| Information Element                 | Value/remark                                                                                                                                                                                                                                       |
|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                        |                                                                                                                                                                                                                                                    |
| RRC transaction identifier          | Checked to see if it matches the same value used in the corresponding downlink HANDOVER FROM UTRAN COMMAND—GSM message                                                                                                                             |
| Integrity check info                | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| ——>Message authentication code      | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| ——>RRC Message sequence number      | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Inter-RAT handover failure          |                                                                                                                                                                                                                                                    |
| ——>Inter-RAT handover failure cause | physical channel failure                                                                                                                                                                                                                           |
| Inter-system message                | Not Checked                                                                                                                                                                                                                                        |

#### 8.3.7.12.5 ————— Test requirement

In step 3 the SS shall receive RRC-Status message in the UTRAN cell.

### ~~8.3.7.13 Inter system handover from UTRAN/To GSM/ success / call under establishment~~

#### ~~8.3.7.13.1 Definition~~

#### ~~8.3.7.13.2 Conformance requirement:~~

~~When the UE receives an HANDOVER FROM UTRAN COMMAND message from UTRAN the UE shall take the following actions:~~

- ~~— Establish the connection to the other radio access system, by using the contents of the IE "Inter system message". This IE contains candidate/ target cell identifier(s) and radio parameters relevant for the other radio access system.~~
- ~~— For each IE "Remaining radio access bearer", associate the radio access bearer given by the IE "RAB info" to the radio resources in the target system given by the IE "Inter system message". Other information for making the association may be included in the IE "Inter system message" and requirements may be stated in the specifications relevant for the target system [FFS].~~
- ~~— Switch the current call under establishment to the other radio access system.~~

#### ~~Reference~~

~~3GPP TS 25.331 clause 8.3.7.3~~

#### ~~Test purpose~~

~~To test that the UE supporting both GSM and UTRAN handovers from a UTRAN serving cell to the indicated channel of GSM target cell when the UE is in call establishment phase and receives an HANDOVER FROM UTRAN COMMAND.~~

~~To Test that the UE continues the call in GSM cell, after Succesful completion of the Handover.~~

#### ~~8.3.7.13.4 Method of test~~

##### ~~Initial conditions~~

~~System Simulator : 1 UTRAN cell.~~

~~UE : CC State U10 in cell 1.~~

##### ~~Related ICS/IXIT statement(s)~~

~~UE supports both GSM and UTRAN Radio Access Technologies,~~

~~UE supports GSM-FR,~~

~~UE supports UTRAN-AMR,~~

~~UE supports GSM-P, GSM-E, GSM-DCS, GSM-450, GSM-480.~~

##### ~~Foreseen final state of the UE~~

~~The UE is in CC state U10 on cell 1.~~

#### ~~Test Procedure~~

~~The SS activates the UTRAN cell and GSM Cell. The UE is triggered to initialise an MO speech call. During the call establishment phase, the SS is configured to not transmit the RLC Acknowledgment for SETUP message. SS configures a dedicated channel in GSM Cell, then sends the UE an HANDOVER FROM UTRAN COMMAND indicating the~~

dedicated channel in the target GSM cell. After the UE receives the command it shall configure itself accordingly and switch to the new channel of the GSM cell. The SS checks whether the handover is performed by checking that the UE transmits the HANDOVER COMPLETE message to the SS in GSM cell. The SS checks MS correctly retransmits GC SETUP message, that was not acknowledged by UTRAN RLC Layer before the Handover, following completion of the handover to GSM cell.

#### Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                       |
|------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                |
| 1    | UE        |    |                                 | To trigger the UE to initialise an MO call                                                                                     |
| 2    | →         |    | SETUP                           | SS does not Acknowledge it                                                                                                     |
| 3    |           | SS |                                 | The SS starts the GSM cell and configure a dedicated channel SDCCH.                                                            |
| 4    | ←         |    | HANDOVER FROM UTRAN COMMAND GSM | Send on cell 1 (UTRAN cell) and the message indicates: the dedicated channel SDCCH.                                            |
| 5    | UE        |    |                                 | The UE accepts the handover command and switches to the GSM dedicated channel specified in the HANDOVER FROM UTRAN COMMAND GSM |
| 6    | →         |    | HANDOVER ACCESS                 | The SS receives this burst on the dedicated channel of cell 2 (GSM cell) It implies that the UE has switched to GSM cell.      |
| 7    | →         |    | HANDOVER ACCESS                 |                                                                                                                                |
| 8    | →         |    | HANDOVER ACCESS                 |                                                                                                                                |
| 9    | →         |    | HANDOVER ACCESS                 |                                                                                                                                |
| 10   | ←         |    | PHYSICAL INFORMATION            |                                                                                                                                |
| 11   | →         |    | SABM                            |                                                                                                                                |
| 12   | ←         |    | UA                              |                                                                                                                                |
| 13   | →         |    | HANDOVER COMPLETE               | The SS receives the message on the dedicated channel of GSM cell.                                                              |
| 14   | →         |    | SETUP                           | The SS receives the message on the dedicated channel of GSM cell.                                                              |
| 15   | ←         |    | CHANNEL RELEASE                 |                                                                                                                                |

#### Specific message contents

##### HANDOVER FROM UTRAN COMMAND-GSM

| Information Element                                                                                                                                                                                                                                                                 | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier<br>Integrity check info<br><br>—→ Message authentication code<br><br>—→ RRC Message sequence number<br>Activation time<br>RAB Info<br>Inter-system message<br>—→ System type<br>—→ Frequency Band<br>—→ CHOICE GSM message<br>—→ Message | Arbitrarily selects one integer between 0 to 3<br>The presence of this IE is dependent on IXT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted.<br>SS calculates the value of MAC-I for this message and writes to this IE.<br>SS provides the value of this IE, from its internal counter.<br>now<br>Not present<br><br>GSM<br>GSM/DCS 1800 Band<br>Single GSM message<br>GSM HANDOVER COMMAND formatted as Variable Length BIT STRING without Length Indicator. The contents of the HANDOVER COMMAND see next table. |

## HANDOVER COMMAND

Same as the HANDOVER COMMAND for M = 4 in clause 26.6.5.2 of GSM 11.10-1 version 8.2.0 Release 1999

### 8.3.7.13.5 Test requirement

~~At step 14 the SS shall receive SETUP message on the dedicated channel of the GSM cell, and at step 8.3.8 Inter system cell reselection to UTRAN~~

[Editor's note: This test is FFS until R2000 core specification will be defined.]

### 8.3.9 Inter system cell reselection from UTRAN

[Editor's note: This test is FFS until R2000 core specification will be defined.]

## 8.4 Measurement procedure

### 8.4.1 Measurement Control and Report

#### 8.4.1.1 Measurement Control and Report: Intra-frequency measurement for transition from idle mode to CELL\_DCH state

##### 8.4.1.1.1 Definition

##### 8.4.1.1.2 Conformance requirement

Upon a state transition from idle mode to CELL\_DCH state, the UE shall begin or continue to monitor the list of cells assigned in the IE "intra-frequency cell info list" which is specified in System Information Block type 11 or 12 messages on BCCH. When entering CELL\_DCH state, the UE shall send MEASUREMENT REPORT message(s) when the condition(s) in "intra-frequency measurement reporting criteria" IE received are fulfilled. In CELL\_DCH state, if the UE receives a MEASUREMENT CONTROL message, which contains a "measurement identity" IE similar in value to the "intra-frequency measurement identity" in System Information Block Type 11 or 12 message, it shall terminate existing monitoring activities for the neighbouring cells previously known from System Information Block type 11 or 12 messages. It shall perform the measurement and reporting tasks based on the latest MEASUREMENT CONTROL message received.

#### Reference

3GPP TS 25.331 clause 8.4.1.8.1, 8.4.1.3

##### 8.4.1.1.3 Test Purpose

To confirm that the UE continues to monitor intra-frequency measurement quantity of the cells listed in System Information Block type 11 or 12 messages, after it has entered CELL\_DCH state from idle mode. When the intra-frequency measurement reporting criteria specified in System Information Block type 11 or 12 messages have been met, it shall report the measurements using MEASUREMENT REPORT message(s). To confirm that the UE terminates monitoring and reporting activities for the cells listed in "intra-frequency cell info list" IE in System Information Block type 11 or 12 messages, after it has received a MEASUREMENT CONTROL message that specifies the measurement type to be "intra-frequency measurement" with the same measurement identity in System Information Block Type 11 or 12 messages. To confirm that the UE reconfigures the monitoring and reporting activities based on the last MEASUREMENT CONTROL message received.

#### 8.4.1.1.4 Method of test

##### Initial Condition

System Simulator: 2 cells—Cell 1 and cell 2 are active.

UE: "Registered idle mode on CS" (state 2) or "Registered idle mode on PS" (state 3) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE. If the UE supports both CS and PS domains, the initial UE state shall be "Registered idle mode on CS/PS" (state 7).

##### Test Procedure

Table 8.4.1.1-1 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution. Column marked "T0" denotes the initial conditions, while columns marked "T1" are to be applied subsequently. The exact instants on which these values shall be applied are described in the texts in this clause.

**Table 8.4.1.1-1**

| Parameter              | Unit                | Cell 1 |     |     | Cell 2 |     |     |
|------------------------|---------------------|--------|-----|-----|--------|-----|-----|
|                        |                     | T0     | T1  | T2  | T0     | T1  | T2  |
| UTRA RF Channel Number |                     | Ch. 1  |     |     | Ch. 1  |     |     |
| CPICH Ec               | dBm/<br>3.84<br>MHz | -60    | -60 | -60 | -70    | -80 | -60 |

The UE is initially at idle mode and has selected cell 1 for camping. The System Information Block type 11 messages are modified with respect to the default settings to prevent reporting of "Cell synchronisation information" and also to include cell 2 into the monitored neighbour cell list. The key measurement parameters in the modified System Information Block message are as follow: measurement type = "intra-frequency measurement", measurement quantity = "CPICH RSCP", report criteria = "periodic reporting criteria", reporting interval = "64 seconds".

SS prompts the operator to make an outgoing call of a supported traffic class. SS and UE shall execute procedure P3 (for CS service) or P5 (for PS service). Next SS and UE shall execute procedure P7 (for CS service) or P9 (for PS service). Then SS and UE shall execute procedure P11 (for CS service) or P13 (for PS service). The UE shall send a MEASUREMENT REPORT message after reaching CELL\_DCH state, reporting cell 2's CPICH RSCP value. After 64 seconds has passed since SS receives the first MEASUREMENT REPORT message, the UE shall transmit a second MEASUREMENT REPORT message.

SS sends a MEASUREMENT CONTROL message on the downlink DCCH. In this message, SS assigns an intra-frequency measurement type with the measurement quantity based on cell 2's CPICH RSCP value. Parameters used in this message are: measurement identity = "1", report criteria = "event-trigger", event identity = "1f", reporting threshold = "-70 dBm". SS checks to see that no MEASUREMENT REPORT messages are sent within the next 64 seconds (which is due to periodic reporting). SS reconfigures the downlink transmission power settings according to values in column "T1" in table 8.4.1.1-1. The UE shall transmit a MEASUREMENT REPORT message when it detects that the CPICH RSCP of cell 2 has reached the threshold value specified in MEASUREMENT CONTROL message.

SS reconfigures the downlink transmission power settings according to values in column "T2" in table 8.4.1.1-1. SS sends a new MEASUREMENT CONTROL message on the downlink DCCH. In this message, SS assigns an intra-frequency measurement type with the measurement quantity based on cell 2's CPICH RSCP value. Parameters used in this message are:

-measurement identity = "1", report criteria = "event-trigger", event identity = "1B", Reporting range 8db. SS reconfigures the downlink transmission power settings according to values in column "T0" in table 8.4.1.1-1. The UE shall transmit a MEASUREMENT REPORT message when it detects that the condition for event 1b is fulfilled.



## Expected Sequence

| Step | Direction |    | Message                                                                                      | Comment                                                                                                                                                                                                                         |
|------|-----------|----|----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                                              |                                                                                                                                                                                                                                 |
| 1    |           | ←  | System Information Block type 11                                                             | The UE is idle mode and camped onto cell 1. The System Information Block type 11 messages to be transmitted are different from the default settings (see specific message contents)                                             |
| 2    |           | ↔  | SS executes procedure P3 (clause 7.4.2.1.2) or P5 (clause 7.4.2.2.2) specified in TS 34.108. |                                                                                                                                                                                                                                 |
| 3    |           | ↔  | SS executes procedure P7 (clause 7.4.2.3.2) or P9 (clause 7.4.2.4.2) specified in TS 34.108. |                                                                                                                                                                                                                                 |
| 4    |           | ↔  | SS executes procedure P3 (clause 7.4.2.1.2) or P5 (clause 7.4.2.2.2) specified in TS 34.108. |                                                                                                                                                                                                                                 |
| 5    |           | →  | Void                                                                                         |                                                                                                                                                                                                                                 |
| 6    |           | →  | MEASUREMENT REPORT                                                                           | SS waits 64 seconds                                                                                                                                                                                                             |
| 6a   |           | →  | MEASUREMENT REPORT                                                                           | SS shall receive consecutive MEASUREMENT REPORT messages at 64 seconds interval.                                                                                                                                                |
| 7    |           | ←  | MEASUREMENT CONTROL                                                                          | A measurement with "measurement identity" IE set to "1" is assigned, with the IE "CHOICE reporting criteria" set to "intra-frequency measurement reporting criteria". See specific message content for the rest of the message. |
| 8    |           |    |                                                                                              | SS waits for 64 seconds and verifies that no further MEASUREMENT REPORT messages are detected on the uplink DCCH.                                                                                                               |
| 9    |           |    |                                                                                              | SS re-adjusts the downlink transmission power settings according to columns "T1" in table 8.4.1.1-1.                                                                                                                            |
| 10   |           | →  | MEASUREMENT REPORT                                                                           | SS verifies that UE transmits a MEASUREMENT REPORT message to report the CPICH RSCP value of cell 2.                                                                                                                            |
| 11   |           |    |                                                                                              | SS re-adjusts the downlink transmission power settings according to columns "T1" in table 8.4.1.1-2.                                                                                                                            |
| 12   |           | ←  | MEASUREMENT CONTROL                                                                          | A measurement with "measurement identity" IE set to "1" is assigned, with the IE "CHOICE reporting criteria" set to "intra-frequency measurement reporting criteria". See specific message content for the rest of the message. |
| 13   |           |    |                                                                                              | SS re-adjusts the downlink transmission power settings according to columns "T1" in table 8.4.1.1-3 and awaits 5 seconds.                                                                                                       |

| Step | Direction |    | Message            | Comment                                                                                      |
|------|-----------|----|--------------------|----------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                              |
| 14   | →         |    | MEASUREMENT REPORT | SS verifies that UE transmits a MEASUREMENT REPORT message to report occurrence of event 1b. |

Specific Message Contents

All messages indicated below shall use the same content as described in default message content, with the following exceptions:

## System Information Block type 11 (Step 1)

| Information Element                                    | Value/Remark                        |
|--------------------------------------------------------|-------------------------------------|
| SIB12 indicator                                        | FALSE                               |
| FACH measurement occasion info                         | Not Present                         |
| Measurement control system information                 |                                     |
| — Intra-frequency measurement system information       |                                     |
| — Intra-frequency measurement identity                 | 1                                   |
| — Intra-frequency cell info list                       |                                     |
| — CHOICE intra-frequency cell removal                  | Remove no intra-frequency cells     |
| — New intra-frequency info list                        |                                     |
| — Intra-frequency cell id                              | 2                                   |
| — Cell info                                            |                                     |
| — Cell individual offset                               | 0 dB                                |
| — Reference time difference to cell                    | 256 chips                           |
| — Read-SFN Indicator                                   | FALSE                               |
| — CHOICE Mode                                          | FDD                                 |
| — Primary CPICH Info                                   |                                     |
| — Primary Scrambling Code                              | Set to same code as used for cell 2 |
| — Primary CPICH TX power                               | Not Present                         |
| — TX Diversity Indicator                               | FALSE                               |
| — Cell selection and Re-selection                      |                                     |
| — Qoffset <sub>s,n</sub>                               | 0 dB                                |
| — Maximum allowed UL TX power                          | +33 dBm                             |
| — HCS neighbouring cell information                    | Not Present                         |
| — Qqualmin                                             | -20 dB                              |
| — Qrxlevmin                                            | -115 dBm                            |
| — Cells for measurement                                | Not Present                         |
| — Intra-frequency measurement quantity                 |                                     |
| — Filter Coefficient                                   | 0                                   |
| — Measurement quantity                                 | CPICH RSCP                          |
| — Intra-frequency measurement for RACH reporting       | Not Present                         |
| — Maximum number of reported cells on RACH             | Not Present                         |
| — Reporting information for state CELL_DCH             |                                     |
| — Intra-frequency reporting quantity                   |                                     |
| — Reporting quantities for active set cells            |                                     |
| — SFN-SFN observed time difference reporting indicator | No report                           |
| — Cell synchronisation information reporting indicator | FALSE                               |
| — Cell identity reporting indicator                    | FALSE                               |
| — CPICH Ec/No reporting indicator                      | FALSE                               |
| — CPICH RSCP reporting indicator                       | FALSE                               |
| — Pathloss reporting indicator                         | FALSE                               |
| — Reporting quantities for monitored set cells         |                                     |
| — SFN-SFN observed time difference reporting indicator | No report                           |
| — Cell synchronisation information reporting indicator | FALSE                               |
| — Cell identity reporting indicator                    | TRUE                                |
| — CPICH Ec/No reporting indicator                      | FALSE                               |
| — CPICH RSCP reporting indicator                       | TRUE                                |
| — Pathloss reporting indicator                         | FALSE                               |
| — Reporting quantities for detected cells              | Not present                         |
| — Measurement Reporting Mode                           |                                     |
| — Measurement Report Transfer Mode                     | Acknowledged mode RLC               |
| — Periodical Reporting / Event Trigger Reporting Mode  | Periodical reporting                |
| — CHOICE report criteria                               | Periodic reporting criteria         |
| — Amount of reporting                                  | Infinity                            |
| — Reporting interval                                   | 64 seconds                          |
| — Inter-frequency measurement system information       | Not present                         |
| — Inter-RAT measurement system information             | Not Present                         |
| — Traffic volume measurement system information        | Not Present                         |

|                                                          |             |
|----------------------------------------------------------|-------------|
| <del>——</del> UE internal measurement system information | Not Present |
|----------------------------------------------------------|-------------|

## MEASUREMENT REPORT (Step 6 and 6a)

| Information Element                               | Value/Remarks                                                  |
|---------------------------------------------------|----------------------------------------------------------------|
| Measurement identity                              | Check to see if set to 1                                       |
| Measured Results                                  |                                                                |
| <del>——</del> CHOICE measurement                  | Check to see if set to "Intra-frequency measured results list" |
| <del>——</del> Intra-frequency measurement results |                                                                |
| <del>——</del> Cell measured results               |                                                                |
| <del>——</del> Cell Identity                       | Check to see if it is absent                                   |
| <del>——</del> SFN-SFN observed time difference    | Check to see if this IE is absent                              |
| <del>——</del> Cell synchronisation information    | Check to see if this IE is absent                              |
| <del>——</del> Primary CPICH Info                  |                                                                |
| <del>——</del> Primary Scrambling Code             | Check to see if it's the same code for cell 2                  |
| <del>——</del> CPICH Ec/No                         | Check to see if this IE is absent                              |
| <del>——</del> CPICH RSCP                          | Check to see if this IE is present                             |
| <del>——</del> Pathloss                            | Check to see if this IE is absent                              |
| Measured Results on RACH                          | Check to see if this IE is absent                              |
| Event Results                                     | Check to see if this IE is absent                              |

## MEASUREMENT CONTROL (Step 7)

| Information Element                                    | Value/Remark                                    |
|--------------------------------------------------------|-------------------------------------------------|
| Measurement Identity                                   | 1                                               |
| Measurement Command                                    | Setup                                           |
| Measurement Reporting Mode                             |                                                 |
| — Measurement Reporting Transfer Mode                  | Acknowledged Mode RLC                           |
| — Periodic Reporting / Event Trigger Reporting Mode    | Event Trigger                                   |
| Additional measurements list                           | Not Present                                     |
| CHOICE measurement type                                | Intra-frequency measurement                     |
| — Intra-frequency cell info list                       |                                                 |
| — CHOICE intra-frequency cell removal                  | Remove no intra-frequency cells                 |
| — New intra-frequency info list                        |                                                 |
| — Intra-frequency cell id                              | 2                                               |
| — Cell info                                            |                                                 |
| — Cell individual offset                               | 0 dB                                            |
| — Reference time difference to cell                    | 256 chips                                       |
| — Read SFN Indicator                                   | FALSE                                           |
| — CHOICE mode                                          | FDD                                             |
| — Primary CPICH Info                                   |                                                 |
| — Primary Scrambling Code                              | Set to same code as used for cell 2             |
| — Primary CPICH TX power                               | Not Present                                     |
| — TX Diversity Indicator                               | FALSE                                           |
| — Cell for measurement                                 |                                                 |
| — Intra-frequency cell id                              | Set to id of cell 2                             |
| — Intra-frequency measurement quantity                 |                                                 |
| — Filter Coefficient                                   | 0                                               |
| — Measurement quantity                                 | CPICH RSCP                                      |
| — Intra-frequency reporting quantity                   |                                                 |
| — Reporting quantities for active set cells            | Same as in default message content              |
| — SFN-SFN observed time difference reporting indicator | No report                                       |
| — Cell synchronisation information reporting indicator | FALSE                                           |
| — Cell identity reporting indicator                    | FALSE                                           |
| — CPICH Ec/No reporting indicator                      | FALSE                                           |
| — CPICH RSCP reporting indicator                       | FALSE                                           |
| — Pathloss reporting indicator                         | FALSE                                           |
| — Reporting quantities for monitored set cells         |                                                 |
| — SFN-SFN observed time difference reporting indicator | No report                                       |
| — Cell synchronisation information reporting indicator | FALSE                                           |
| — Cell identity reporting indicator                    | TRUE                                            |
| — CPICH Ec/No reporting indicator                      | FALSE                                           |
| — CPICH RSCP reporting indicator                       | TRUE                                            |
| — Pathloss reporting indicator                         | FALSE                                           |
| — Reporting quantities for detected cells              | Not present                                     |
| — Reporting cell status                                | Not Present                                     |
| — Measurement validity                                 | Not present                                     |
| — CHOICE report criteria                               | Intra-frequency measurement reporting criteria  |
| — Parameters required for each events                  |                                                 |
| — Intra-frequency event identity                       |                                                 |
| — Triggering condition 1                               | 1f                                              |
| — Triggering condition 2                               | Monitored set cells                             |
| — Reporting range                                      | Not Present                                     |
| — Cells forbidden to affect reporting range            | Not Present                                     |
| — W                                                    | Not Present                                     |
| — Hysteresis                                           | Not Present                                     |
| — Threshold used frequency                             | 1 dB                                            |
| — Reporting deactivation threshold                     | -70 dBm                                         |
| — Replacement activation threshold                     | Not Present                                     |
| — Time to trigger                                      | Not Present                                     |
| — Amount of reporting                                  | 0 msec                                          |
| — Reporting interval                                   | Not Present                                     |
| — Reporting cell status                                | Not Present                                     |
| — CHOICE reported cell                                 | Report cells within active and/or monitored set |

| Information Element                                                                        | Value/Remark                                                                                                                       |
|--------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
| <del>Maximum number of reported cells</del><br><del>DPCH compressed mode status info</del> | <del>on used frequency or within active and/or monitored set on non-used frequency</del><br><del>2</del><br><del>Not Present</del> |

## MEASUREMENT REPORT (Step 10)

| Information Element                            | Value/Remarks                                                                 |
|------------------------------------------------|-------------------------------------------------------------------------------|
| Measurement identity                           | Check to see if set to 1                                                      |
| Measured Results                               |                                                                               |
| <del>CHOICE measurement</del>                  | Check to see if set to "Intra-frequency measured results list"                |
| <del>Intra-frequency measurement results</del> |                                                                               |
| <del>Cell measured results</del>               |                                                                               |
| <del>Cell Identity</del>                       | Check to see if it is absent                                                  |
| <del>SFN-SFN observed time difference</del>    | Check to see if this IE is absent                                             |
| <del>Cell synchronisation information</del>    | Check to see if this IE is absent                                             |
| <del>Primary CPICH Info</del>                  |                                                                               |
| <del>Primary Scrambling Code</del>             | Check to see if it's the same code for cell 2                                 |
| <del>CPICH Ec/No</del>                         | Check to see if this IE is absent                                             |
| <del>CPICH RSCP</del>                          | Check to see if this IE is present                                            |
| <del>Pathloss</del>                            | Check to see if this IE is absent                                             |
| Measured Results on RACH                       | Check to see if this IE is absent                                             |
| Additional Measured Results                    | Check to see if this IE is absent                                             |
| Event Results                                  |                                                                               |
| <del>CHOICE event result</del>                 | Check to see if this IE is set to "Intra-frequency measurement event results" |
| <del>Intra-frequency event identity</del>      | Check to see if this IE is set to "1f"                                        |
| <del>Cell measured event results</del>         |                                                                               |
| <del>CHOICE mode</del>                         | Check to see if this IE is set to "FDD"                                       |
| <del>Primary CPICH info</del>                  |                                                                               |
| <del>Primary Scrambling Code</del>             | Check to see if it's the same code for cell 2                                 |

## MEASUREMENT CONTROL (Step 12)

| Information Element                                             | Value/Remark                                   |
|-----------------------------------------------------------------|------------------------------------------------|
| Measurement Identity                                            | 1                                              |
| Measurement Command                                             | Setup                                          |
| Measurement Reporting Mode                                      |                                                |
| <del>Measurement Reporting Transfer Mode</del>                  | Acknowledged Mode RLC                          |
| <del>Periodic Reporting / Event Trigger Reporting Mode</del>    | Event Trigger                                  |
| Additional measurements list                                    | Not Present                                    |
| CHOICE measurement type                                         | Intra-frequency measurement                    |
| <del>Intra-frequency cell info list</del>                       |                                                |
| <del>CHOICE intra-frequency cell removal</del>                  | Remove no intra-frequency cells                |
| <del>New intra-frequency info list</del>                        |                                                |
| <del>Intra-frequency cell id</del>                              | 2                                              |
| <del>Cell info</del>                                            |                                                |
| <del>Cell individual offset</del>                               | 0 dB                                           |
| <del>Reference time difference to cell</del>                    | 256 chips                                      |
| <del>Read SFN Indicator</del>                                   | FALSE                                          |
| <del>CHOICE mode</del>                                          | FDD                                            |
| <del>Primary CPICH Info</del>                                   |                                                |
| <del>Primary Scrambling Code</del>                              | Set to same code as used for cell 2            |
| <del>Primary CPICH TX power</del>                               | Not Present                                    |
| <del>TX Diversity Indicator</del>                               | FALSE                                          |
| <del>Cells for measurement</del>                                |                                                |
| <del>Intra-frequency cell id</del>                              | Set to id of cell 2                            |
| <del>Intra-frequency measurement quantity</del>                 |                                                |
| <del>Filter Coefficient</del>                                   | 0                                              |
| <del>Measurement quantity</del>                                 | CPICH RSCP                                     |
| <del>Intra-frequency reporting quantity</del>                   |                                                |
| <del>Reporting quantities for active set cells</del>            | Same as in default message content             |
| <del>SFN-SFN observed time difference reporting indicator</del> | No report                                      |
| <del>Cell synchronisation information reporting indicator</del> | FALSE                                          |
| <del>Cell identity reporting indicator</del>                    | FALSE                                          |
| <del>CPICH Ec/No reporting indicator</del>                      | FALSE                                          |
| <del>CPICH RSCP reporting indicator</del>                       | FALSE                                          |
| <del>Pathloss reporting indicator</del>                         | FALSE                                          |
| <del>Reporting quantities for monitored set cells</del>         |                                                |
| <del>SFN-SFN observed time difference reporting indicator</del> | No report                                      |
| <del>Cell synchronisation information reporting indicator</del> | FALSE                                          |
| <del>Cell identity reporting indicator</del>                    | FALSE                                          |
| <del>CPICH Ec/No reporting indicator</del>                      | FALSE                                          |
| <del>CPICH RSCP reporting indicator</del>                       | FALSE                                          |
| <del>Pathloss reporting indicator</del>                         | FALSE                                          |
| <del>Reporting quantities for detected cells</del>              | Not present                                    |
| <del>Reporting cell status</del>                                | Not Present                                    |
| <del>Measurement validity</del>                                 | Not present                                    |
| <del>CHOICE report criteria</del>                               | Intra-frequency measurement reporting criteria |
| <del>Parameters required for each events</del>                  |                                                |
| <del>Intra-frequency event identity</del>                       | 1b                                             |
| <del>Triggering condition 1</del>                               | Monitored Cells                                |
| <del>Triggering condition 2</del>                               | Not Present                                    |
| <del>Reporting range</del>                                      | 8 dB                                           |
| <del>Cells forbidden to affect reporting range</del>            | Not Present                                    |
| <del>W</del>                                                    | 0                                              |
| <del>Hysteresis</del>                                           | 0 dB                                           |
| <del>Threshold used frequency</del>                             | Not Present                                    |
| <del>Reporting deactivation threshold</del>                     | Not Present                                    |
| <del>Replacement activation threshold</del>                     | Not Present                                    |
| <del>Time to trigger</del>                                      | 5000 msec                                      |
| <del>Amount of reporting</del>                                  | Not Present                                    |
| <del>Reporting interval</del>                                   | Not Present                                    |
| <del>Reporting cell status</del>                                | Not Present                                    |
| <del>DPCH compressed mode status info</del>                     | Not Present                                    |

| Information Element | Value/Remark |
|---------------------|--------------|
|                     |              |

#### MEASUREMENT REPORT (Step 14)

| Information Element            | Value/Remarks                                 |
|--------------------------------|-----------------------------------------------|
| Measurement identity           | Check to see if set to 1                      |
| Measured Results               | Check to see if this IE is absent             |
| Measured Results on RACH       | Check to see if this IE is absent             |
| Additional Measured Results    | Check to see if this IE is absent             |
| Event Results                  |                                               |
| CHOICE event result            |                                               |
| Intra-frequency event identity | Check to see if this IE is set to "1b"        |
| Cell measured event results    |                                               |
| CHOICE mode                    | Check to see if this IE is set to "FDD"       |
| Primary CPICH info             |                                               |
| Primary Scrambling Code        | Check to see if it's the same code for cell 2 |

#### 8.4.1.1.5 Test Requirement

After step 5 the UE shall start to transmit 2 MEASUREMENT REPORT messages at 64 seconds interval. The measurement quantity "CPICH RSCP" of cell 2 shall be reported in these messages.

After step 7 the UE shall not transmit any MEASUREMENT REPORT messages within 64 seconds after SS has transmitted the MEASUREMENT CONTROL message in step 7.

After step 9 the UE shall transmit a MEASUREMENT REPORT message on the uplink DCCH, to report that the CPICH RSCP value for cell 2 has dropped below the threshold stated in the MEASUREMENT CONTROL message transmitted by the SS in step 7. This MEASUREMENT REPORT message shall also contain IE "Event results", indicating the triggering of event '1f'.

In step 12 SS transmits a new Measurement Control message. In the following the UE shall transmit a MEASUREMENT REPORT message depending on the re-adjustment of CPICH downlink transmission power in both cells containing IE "Event results", indicating the triggering of event '1b'.

#### 8.4.1.2 Measurement Control and Report: Inter-frequency measurement for transition from idle mode to CELL\_DCH state

##### 8.4.1.2.1 Definition

##### 8.4.1.2.2 Conformance requirement

After entering CELL\_DCH state from idle mode, the UE shall stop monitoring the list of cells assigned in the IE "inter-frequency cell info" IE in System Information Block 11 or 12 messages. In CELL\_DCH state, when the UE receives a MEASUREMENT CONTROL message requesting for a measurement of inter-frequency measurement type to be setup, it shall start inter-frequency measurement and the associated reporting activities if "DPCH compressed mode status info" IE in the message simultaneously activates at least one compressed mode pattern sequence. When the UE receives a MEASUREMENT CONTROL message with "Reporting cell status" IE omitted, it shall not include "Cell measured results" IE for any cells in MEASUREMENT REPORT messages sent on uplink DCCH.

#### Reference

3GPP TS 25.331 clauses 8.4.1.3, 8.4.1.8.2 and 8.6.7.9

##### 8.4.1.2.3 Test Purpose

To confirm that the UE stops monitoring the list of cells assigned in the IE "inter-frequency cell info" in System Information Block type 11 messages, after it enters CELL\_DCH state from idle mode. To confirm that the UE starts to



perform inter-frequency measurement and related reporting activities, when it receives a MEASUREMENT CONTROL message with the "DPCCH compress mode status info" IE indicating that a stored compressed mode pattern sequence be simultaneously activated. To confirm that the UE excludes the IE "cell measured results" for any cells in the MEASUREMENT REPORT messages, after it receives a MEASUREMENT CONTROL message with "Reporting cell status" IE omitted.

#### 8.4.1.2.4 Method of test

##### Initial Condition

System Simulator: 2 cells — Cell 1 and cell 4 are active..

UE: "Registered idle mode on CS" (state 2) or "Registered idle mode on PS" (state 3) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE. If the UE supports both CS and PS domains, the initial UE state shall be "Registered idle mode on CS/PS" (state 7).

##### Test Procedure

Table 8.4.1.2-1 illustrates the downlink power to be applied for the 2 cells.

**Table 8.4.1.2-1**

| Parameter              | Unit                | Cell 1 | Cell 4 |
|------------------------|---------------------|--------|--------|
| UTRA RF Channel Number |                     | Ch. 1  | Ch. 2  |
| CPICH Ec               | dBm/<br>3.84<br>MHz | -60    | -75    |

The UE is initially at idle mode and has selected cell 1 for camping. The System Information Block type 11 messages are modified with respect to the default settings to prevent reporting of "Cell synchronisation information", and also to include cell 4 into "inter-frequency cells info list" IE.

SS prompts the operator to make an outgoing call for one of the traffic classes supported by the UE. SS and UE shall execute procedure P3 (for CS service) or P5 (for PS service). The RRC CONNECTION SETUP message used in procedure P3 or P5 should contain IE "DPCCH compressed mode info", activating the transmission pattern gap sequence with TGPSI=1. Next SS and UE shall execute procedure P7 (for CS service) or P9 (for PS service). Then SS and UE shall execute procedure P11 (for CS service) or P13 (for PS service). The UE shall not transmit any MEASUREMENT REPORT messages, which pertain to measurement readings for cells listed in the IE "inter-frequency cell info list" in System Information Type 11.

SS sends PHYSICAL CHANNEL RECONFIGURATION message on the downlink DCCH, specifying that compressed mode sequence pattern with TGPSI=1 be deactivated. The UE shall reply with PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH. It shall stop compressed mode operations at the activation time stated in PHYSICAL CHANNEL RECONFIGURATION message. After the activation time has elapsed, SS sends MEASUREMENT CONTROL message on the downlink DCCH. In this message, SS requests UE to perform inter-frequency measurement with periodic reporting of CPICH RSCP values for cell 4. The "DPCCH compressed status info" IE in this message activates the transmission gap pattern sequence with TGPSI=1. The UE shall start inter-frequency measurement and reporting for cell 4's CPICH RSCP values. It shall report this measurement result by transmitting MEASUREMENT REPORT messages on uplink DCCH periodically at 16 seconds interval.

SS sends MEASUREMENT CONTROL message on the downlink DCCH omitting the IE "Reporting cell status". The UE shall send MEASUREMENT REPORT messages on the uplink DCCH, with the IE "Cell measured results" excluded in these messages.

## Expected Sequence

| Step | Direction |    | Message                                                                                      | Comment                                                                                                                                                                                                                     |
|------|-----------|----|----------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                                              |                                                                                                                                                                                                                             |
| 1    |           | ←  | System Information Block type 11                                                             | The UE is idle mode and camped onto cell 1. System Information Block Type 11 to be transmitted is different from the default settings (see specific message contents)                                                       |
| 2    |           | ↔  | SS executes procedure P3 (clause 7.4.2.1.2) or P5 (clause 7.4.2.2.2) specified in TS 34.108. | SS prompts the operator to make an outgoing call.                                                                                                                                                                           |
| 3    |           | ↔  | SS executes procedure P7 (clause 7.4.2.3.2) or P9 (clause 7.4.2.4.2) specified in TS 34.108. |                                                                                                                                                                                                                             |
| 4    |           | ↔  | SS executes procedure P3 (clause 7.4.2.1.2) or P5 (clause 7.4.2.2.2) specified in TS 34.108. |                                                                                                                                                                                                                             |
| 5    |           |    | Void                                                                                         |                                                                                                                                                                                                                             |
| 6    |           |    |                                                                                              | SS checks to see that no MEASUREMENT REPORT messages are received.                                                                                                                                                          |
| 7    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION                                                             | Existing compressed mode sequence pattern is deactivated in this message.                                                                                                                                                   |
| 8    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE                                                    | UE shall remain in CELL_DCH state.                                                                                                                                                                                          |
| 9    |           | ←  | MEASUREMENT CONTROL                                                                          | SS requests UE to start inter-frequency measurement for cell 4, and performing periodic reporting for cell 4's CPICH RSCP. "DPCH compressed mode status info" IE is set to simultaneously activate compressed mode pattern. |
| 10   |           | →  | MEASUREMENT REPORT                                                                           | UE shall report cell 4's CPICH RSCP reading periodically.                                                                                                                                                                   |
| 11   |           | ←  | MEASUREMENT CONTROL                                                                          | SS changes the reporting criteria of cell 4 to 'event 2c'. "Reporting cell status" IE in this message is omitted.                                                                                                           |
| 12   |           | →  | MEASUREMENT REPORT                                                                           | SS monitors the uplink DCCH to make sure that only 1 such message is received 32 seconds after step 11. This message shall not contain IE "Inter-frequency cell measured results"                                           |

## Specific Message Content

All messages indicated below shall use the same content as described in default message content, with the following exceptions:

## System Information Block type 11 (Step 1)

| Information Element                              | Value/Remark                         |
|--------------------------------------------------|--------------------------------------|
| SIB12 indicator                                  | FALSE                                |
| FACH measurement occasion info                   | Not Present                          |
| Measurement control system information           |                                      |
| — Intra-frequency measurement system information | Not Present                          |
| — Inter-frequency measurement system information |                                      |
| — Inter-frequency cell info list                 |                                      |
| — CHOICE inter-frequency cell removal            | No inter-frequency cells removed     |
| — New inter-frequency info list                  |                                      |
| — Inter-frequency cell id                        | 4                                    |
| — Frequency info                                 |                                      |
| — UARFCN uplink (Nu)                             | Set to the uplink UARFCN of cell 4   |
| — UARFCN downlink (Nd)                           | Set to the downlink UARFCN of cell 4 |
| — Cell info                                      |                                      |
| — Cell individual offset                         | 0 dB                                 |
| — Reference time difference to cell              | 0 chips                              |
| — Read SFN Indicator                             | FALSE                                |
| — CHOICE mode                                    | FDD                                  |
| — Primary CPICH Info                             |                                      |
| — Primary Scrambling Code                        | Set to same code as used for cell 4  |
| — Primary CPICH TX power                         | Not Present                          |
| — TX Diversity Indicator                         | FALSE                                |
| — Cell selection and re-selection info           |                                      |
| — Qoffset <sub>s,n</sub>                         | 0 dB                                 |
| — Maximum allowed UL TX power                    | 0 dBm                                |
| — HCS neighbouring cell information              | Not Present                          |
| — Qqualmin                                       | -20 dB                               |
| — Qrxlevmin                                      | -115dBm                              |
| — Cells for measurement                          | Not Present                          |
| — Inter-RAT measurement system information       | Not Present                          |
| — Traffic volume measurement system information  | Not Present                          |
| — UE internal measurement system information     | Not Present                          |

## RRC CONNECTION SETUP (Step 2)

Use the message found in TS 34.108 clause 9, with the following exceptions:

| Information Element                                        | Value/Remarks                                                       |
|------------------------------------------------------------|---------------------------------------------------------------------|
| Downlink information common for all radio links            |                                                                     |
| Downlink DPCH info common for all RL                       |                                                                     |
| Timing Indication                                          | Maintain                                                            |
| CFN-targetSFN frame offset                                 | Not Present                                                         |
| Downlink DPCH power control information                    |                                                                     |
| DPC mode                                                   | Single-TPC                                                          |
| CHOICE Mode                                                | FDD                                                                 |
| Power offset $P_{\text{Pilot-DPCH}}$                       | 0                                                                   |
| DL rate matching restriction information                   | Not Present                                                         |
| Spreading factor                                           | Refer to the parameter set in TS 34.108                             |
| Fixed or flexible position                                 | Flexible                                                            |
| TFCI existence                                             | FALSE                                                               |
| Number of bits for Pilot bits (SF=128, 256)                | Refer to the parameter set in TS 34.108                             |
| DPCH compressed mode info                                  |                                                                     |
| TGPSI                                                      | 1                                                                   |
| TGPS Status Flag                                           | Active                                                              |
| TGCFN                                                      | $(\text{Current CFN} + (256 - \text{TTI}/10\text{msec})) \bmod 256$ |
| Transmission gap pattern sequence configuration parameters |                                                                     |
| TGMP                                                       | FDD-Measurement                                                     |
| TGPRC                                                      | 62                                                                  |
| TGSN                                                       | 4                                                                   |
| TGL1                                                       | 7                                                                   |
| TGL2                                                       | Not Present                                                         |
| TGD                                                        | 0                                                                   |
| TGPL1                                                      | 3                                                                   |
| TGPL2                                                      | Not Present                                                         |
| RPP                                                        | Mode 0                                                              |
| ITP                                                        | Mode 0                                                              |
| CHOICE UL/DL Mode                                          | UL and DL                                                           |
| Downlink compressed mode method                            | SF/2                                                                |
| Uplink compressed mode method                              | SF/2                                                                |
| Downlink frame type                                        | B                                                                   |
| DeltaSIR1                                                  | 2.0                                                                 |
| DeltaSIRAfter1                                             | 1.0                                                                 |
| DeltaSIR2                                                  | Not Present                                                         |
| DeltaSIR2After2                                            | Not Present                                                         |
| N identify abort                                           | Not Present                                                         |
| T Reconfirm abort                                          | Not Present                                                         |
| TX Diversity Mode                                          | None                                                                |
| SSDT information                                           | Not Present                                                         |
| Default DPCH Offset Value                                  | 0                                                                   |

## PHYSICAL CHANNEL RECONFIGURATION (Step 7)

Use the same message sub-type in Annex A titled "Speech in CS", with the following exceptions:

| Information Element                                        | Value/remark                                    |
|------------------------------------------------------------|-------------------------------------------------|
| <b>CHOICE channel requirement</b>                          | Uplink DPCH info                                |
| Uplink DPCH power control info                             |                                                 |
| DPCCH power offset                                         | -6dB                                            |
| PC Preamble                                                | 1 frame                                         |
| SRB delay                                                  | 7 frames                                        |
| Power Control Algorithm                                    | Algorithm1                                      |
| TPC step size                                              | 1dB                                             |
| Scrambling code type                                       | Long                                            |
| Scrambling code number                                     | 0                                               |
| Number of DPDCH                                            | Not Present (Use default value of 1)            |
| Spreading factor                                           | SF is reference to TS34.108 clause 6.10         |
| TFCI existence                                             | Parameter Set                                   |
| Number of FBI bit                                          | TRUE                                            |
| Puncturing Limit                                           | Not Present (Use default value of 0)            |
| <b>CHOICE Mode</b>                                         | Reference to TS34.108 clause 6.10 Parameter Set |
| Downlink PDSCH information                                 | FDD                                             |
| Downlink information common for all radio links            | Not Present                                     |
| Downlink DPCH info common for all RL                       |                                                 |
| Timing Indication                                          | Maintain                                        |
| Downlink DPCH power control information                    |                                                 |
| DPC mode                                                   | 0 (single)                                      |
| CHOICE mode                                                | FDD                                             |
| Power offset $P_{Pilot-DPCH}$                              | 0                                               |
| DL rate matching restriction information                   | Not Present                                     |
| Spreading factor                                           | Reference to TS34.108 clause 6.10 Parameter Set |
| Fixed or Flexible Position                                 | Flexible                                        |
| TFCI existence                                             | TRUE                                            |
| Number of bits for Pilot bits (SF=128,256)                 | Not Present                                     |
| DPCH compressed mode info                                  |                                                 |
| Transmission gap pattern sequence                          |                                                 |
| TGPSI                                                      | 1                                               |
| TPGS status Flag                                           | Inactive                                        |
| TGCFN                                                      | Not Present                                     |
| Transmission gap pattern sequence configuration parameters | Not Present                                     |
| TX Diversity mode                                          | None                                            |
| SSDT information                                           | Not Present                                     |
| Default DPCH Offset Value                                  | 0                                               |
| Downlink information per radio link list                   | Not Present                                     |

## MEASUREMENT CONTROL (Step-9)

| Information Element                                    | Value/Remark                                                                                                                 |
|--------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------|
| Measurement Identity                                   | 1                                                                                                                            |
| Measurement Command                                    | Setup                                                                                                                        |
| Measurement Reporting Mode                             |                                                                                                                              |
| — Measurement Reporting Transfer Mode                  | Acknowledged Mode RLC                                                                                                        |
| — Periodic Reporting / Event Trigger Reporting Mode    | Event Trigger                                                                                                                |
| Additional measurements list                           | Not Present                                                                                                                  |
| CHOICE measurement type                                | Inter-frequency measurement                                                                                                  |
| — Inter-frequency cell info list                       |                                                                                                                              |
| — CHOICE inter-frequency cell removal                  | No inter-frequency cells removed                                                                                             |
| — New inter-frequency info list                        |                                                                                                                              |
| — Inter-frequency cell id                              | 4                                                                                                                            |
| — Frequency info                                       |                                                                                                                              |
| — UARFCN uplink (Nu)                                   | UARFCN of the uplink frequency for cell 4                                                                                    |
| — UARFCN downlink (Nd)                                 | UARFCN of the downlink frequency for cell 4                                                                                  |
| — Cell info                                            |                                                                                                                              |
| — Cell individual offset                               | 0 dB                                                                                                                         |
| — Reference time difference to cell                    | 0 chips                                                                                                                      |
| — Read SFN Indicator                                   | FALSE                                                                                                                        |
| — CHOICE mode                                          | FDD                                                                                                                          |
| — Primary CPICH Info                                   |                                                                                                                              |
| — Primary Scrambling Code                              | Set to same code as used for cell 4                                                                                          |
| — Primary CPICH TX power                               | Not Present                                                                                                                  |
| — TX Diversity Indicator                               | FALSE                                                                                                                        |
| — Cells for measurement                                |                                                                                                                              |
| — Inter-frequency cell id                              | 4                                                                                                                            |
| — Inter-frequency measurement quantity                 |                                                                                                                              |
| — CHOICE reporting criteria                            | Inter-frequency reporting criteria                                                                                           |
| — Filter Coefficient                                   | 0                                                                                                                            |
| — Measurement quantity for frequency quality estimate  | CPICH RSCP                                                                                                                   |
| — Inter-frequency reporting quantity                   |                                                                                                                              |
| — UTRA Carrier RSSI                                    | FALSE                                                                                                                        |
| — Frequency quality estimate                           | FALSE                                                                                                                        |
| — Non-frequency related cell reporting quantities      |                                                                                                                              |
| — SFN-SFN observed time difference reporting indicator | No report                                                                                                                    |
| — Cell synchronisation information reporting indicator | FALSE                                                                                                                        |
| — Cell Identity reporting indicator                    | FALSE                                                                                                                        |
| — CPICH Ec/No reporting indicator                      | FALSE                                                                                                                        |
| — CPICH RSCP reporting indicator                       | TRUE                                                                                                                         |
| — Pathloss reporting indicator                         | FALSE                                                                                                                        |
| — Reporting cell status                                |                                                                                                                              |
| — CHOICE reported cell                                 | Report cell within active and/or monitored set on used frequency or within active and/or monitored set on non-used frequency |
| — Maximum number of reported cells                     | 2                                                                                                                            |
| — Measurement validity                                 | Not present                                                                                                                  |
| — Inter-frequency set update                           | Not present                                                                                                                  |
| — CHOICE report criteria                               | Periodic reporting criteria                                                                                                  |
| — Amount of reporting                                  | Infinity                                                                                                                     |
| — Reporting interval                                   | 16 seconds                                                                                                                   |
| DPCH compressed mode status info                       |                                                                                                                              |
| TGPS reconfiguration CFN                               | (Current CFN + (256 — TTI/10msec))mod 256                                                                                    |
| Transmission gap pattern sequence                      |                                                                                                                              |
| — TGPSI                                                | 1                                                                                                                            |
| — TGPS Status Flag                                     | Active                                                                                                                       |
| — TGCFN                                                | (Current CFN + (256 — TTI/10msec))mod 256                                                                                    |

## MEASUREMENT REPORT (Step 10)

| Information Element                      | Value/Remarks                                                          |
|------------------------------------------|------------------------------------------------------------------------|
| Measurement identity                     | Check to see if set to 1                                               |
| Measured Results                         |                                                                        |
| CHOICE measurement                       | Check to see if set to "Inter-frequency measured results list"         |
| Inter-frequency measurement results      |                                                                        |
| Frequency info                           |                                                                        |
| UARFCN (uplink)                          | Check to see if set to the UARFCN of the uplink frequency for cell 4   |
| UARFCN (downlink)                        | Check to see if set to the UARFCN of the downlink frequency for cell 4 |
| UTRA carrier RSSI                        | Check to see if it is absent                                           |
| Inter-frequency cell measurement results |                                                                        |
| Cell measured results                    |                                                                        |
| Cell Identity                            | Check to see if it is absent                                           |
| SFN-SFN observed time difference         | Check to see if it is absent                                           |
| Cell synchronisation information         | Check to see if it is absent                                           |
| Primary CPICH Info                       |                                                                        |
| Primary Scrambling Code                  | Check to see if set to the same code for cell 4                        |
| CPICH Ec/No                              | Check to see if it is absent                                           |
| CPICH RSCP                               | Check to see if it is present                                          |
| Pathloss                                 | Check to see if it is absent                                           |
| Measured Results on RACH                 | Check to see if it is absent                                           |
| Additional Measured results              | Check to see if it is absent                                           |
| Event Results                            | Check to see if it is absent                                           |

## MEASUREMENT CONTROL (Step 11)

| Information Element                                    | Value/Remark                                   |
|--------------------------------------------------------|------------------------------------------------|
| Measurement Identity                                   | 1                                              |
| Measurement Command                                    | Modify                                         |
| Measurement Reporting Mode                             |                                                |
| — Measurement Reporting Transfer Mode                  | Acknowledged Mode RLC                          |
| — Periodic Reporting / Event Trigger Reporting Mode    | Event Trigger                                  |
| Additional measurements list                           | Not Present                                    |
| CHOICE measurement type                                | Inter-frequency measurement                    |
| — Inter-frequency cell info list                       |                                                |
| — CHOICE inter-frequency cell removal                  | No inter-frequency cells removed               |
| — New inter-frequency info list                        |                                                |
| — Inter-frequency cell id                              | 4                                              |
| — Frequency info                                       |                                                |
| — UARFCN uplink (Nu)                                   | UARFCN of the uplink frequency for cell 4      |
| — UARFCN downlink (Nd)                                 | UARFCN of the downlink frequency for cell 4    |
| — Cell info                                            |                                                |
| — Cell individual offset                               | 0 dB                                           |
| — Reference time difference to cell                    | 0 chips                                        |
| — Read SFN Indicator                                   | FALSE                                          |
| — CHOICE mode                                          | FDD                                            |
| — Primary CPICH Info                                   |                                                |
| — Primary Scrambling Code                              | Set to same code as used for cell 4            |
| — Primary CPICH TX power                               | Not Present                                    |
| — TX Diversity Indicator                               | FALSE                                          |
| — Cells for measurement                                |                                                |
| — Inter-frequency cell id                              | 4                                              |
| — Inter-frequency measurement quantity                 |                                                |
| — CHOICE reporting criteria                            | Inter-frequency reporting criteria             |
| — Filter Coefficient                                   | 0                                              |
| — Measurement quantity for frequency quality estimate  | CPICH RSCP                                     |
| — Inter-frequency reporting quantity                   |                                                |
| — UTRA Carrier RSSI                                    | FALSE                                          |
| — Frequency quality estimate                           | FALSE                                          |
| — Non-frequency related cell reporting quantities      |                                                |
| — SFN-SFN observed time difference reporting indicator | No report                                      |
| — Cell synchronisation information reporting indicator | FALSE                                          |
| — Cell Identity reporting indicator                    | FALSE                                          |
| — CPICH Ec/No reporting indicator                      | FALSE                                          |
| — CPICH RSCP reporting indicator                       | TRUE                                           |
| — Pathloss reporting indicator                         | FALSE                                          |
| — Reporting cell status                                | Not Present                                    |
| — Measurement validity                                 | Not present                                    |
| — Inter-frequency set update                           | Not present                                    |
| — CHOICE report criteria                               | Inter-frequency measurement reporting criteria |
| — Parameters required for each event                   |                                                |
| — Inter-frequency event identity                       | 2c                                             |
| — Threshold used frequency                             | Not Present                                    |
| — W used frequency                                     | Not Present                                    |
| — Hysteresis                                           | 0.5 dB                                         |
| — Time to trigger                                      | 0 milliseconds                                 |
| — Reporting cell status                                | Not Present                                    |
| — Parameters required for each non-used frequency      |                                                |
| — Threshold non-used frequency                         | -85 dBm                                        |
| — W non-used frequency                                 | 0                                              |
| DPCH compressed mode status info                       | Not Present                                    |



## MEASUREMENT REPORT (Step 12)

| Information Element                                | Value/Remarks                                                                 |
|----------------------------------------------------|-------------------------------------------------------------------------------|
| Measurement identity                               | Check to see if set to 1                                                      |
| Measured Results                                   |                                                                               |
| —— CHOICE measurement                              | Check to see if set to "Inter-frequency measured results list"                |
| —— Inter-frequency measurement results             |                                                                               |
| —— Frequency info                                  |                                                                               |
| —— UARFCN (uplink)                                 | Check to see if set to the UARFCN of the uplink frequency for cell 4          |
| —— UARFCN (downlink)                               | Check to see if set to the UARFCN of the downlink frequency for cell 4        |
| —— UTRA carrier RSSI                               | Check to see if it is absent                                                  |
| —— Inter-frequency cell measurement results        | Check to see if it is absent                                                  |
| Measured Results on RACH                           | Check to see if it is absent                                                  |
| Additional Measured Results                        | Check to see if it is absent                                                  |
| Event Results                                      |                                                                               |
| —— CHOICE event result                             | Check to see if this IE is set to "Intra-frequency measurement event results" |
| —— Inter-frequency event identity                  | Check to see if this IE is set to "2c"                                        |
| —— Inter-frequency cells                           |                                                                               |
| —— Frequency info                                  |                                                                               |
| —— UARFCN (uplink)                                 | Check to see if set to the UARFCN of the uplink frequency for cell 4          |
| —— UARFCN (downlink)                               | Check to see if set to the UARFCN of the downlink frequency for cell 4        |
| —— Non frequency related measurement event results |                                                                               |
| —— CHOICE Mode                                     | Check to see if set to "FDD"                                                  |
| —— Primary CPICH info                              |                                                                               |
| —— Primary Scrambling Code                         | Check to see if set to the same code as cell 4                                |

## 8.4.1.2.5 Test Requirement

After step 5 the UE shall not transmit any MEASUREMENT REPORT messages pertaining to the measurement of CPICH RSCP of cell 4.

After step 9 the UE shall transmit MEASUREMENT REPORT messages on uplink DCCH, reporting cell 4's CPICH RSCP value at periodic time interval of 16 seconds in "inter-frequency cell measurement results" IE.

After step 11 the UE shall transmit only 1 MEASUREMENT REPORT message on the uplink DCCH. In this message, IE "inter-frequency cell measured results" shall be absent.

## 8.4.1.3 Measurement Control and Report: Intra-frequency measurement for transition from idle mode to CELL\_FACH state

## 8.4.1.3.1 Definition

## 8.4.1.3.2 Conformance requirement

The UE shall begin monitoring cells listed in the IE "intra-frequency cell info list" received in System Information Block type 11 or 12 messages, upon a transition from idle mode to CELL\_FACH state. If IE "intra-frequency measurement reporting criteria" is specified in System Information Block Type 11 or 12 messages, the UE shall store this information and shall apply these reporting rules in a subsequent transition to CELL\_DCH state. If the UE receives IE "Intra-frequency reporting for RACH reporting" and IE "Maximum number of Reported cells on RACH" in System Information Block type 11 or 12 messages, the UE shall use these measurement information and report the measured results when sending messages on RACH.

## Reference

3GPP TS 25.331, clause 8.4.1.9.1, 8.4.1.7.1

8.4.1.3.3 Test Purpose

To confirm that the UE begins or continues to monitor cells listed in IE "intra-frequency cell info list" of System Information Block type 11 or 12 messages after it has entered CELL\_FACH state from idle mode. To confirm that the UE applies the reporting criteria stated in "intra-frequency measurement reporting criteria" IE in System Information Block Type 11 or 12 in a subsequent transition to CELL\_DCH state. To confirm that the UE reports measured results on RACH messages, if it receives IE "Intra-frequency reporting quantity for RACH reporting" and IE "Maximum number of reported cells on RACH" from System Information Block Type 11 or 12 upon a transition from idle mode to CELL\_FACH state.

8.4.1.3.4 Method of test

Initial Condition

System Simulator: 2 cells. Cell 1 and cell 2 are active.

UE: "Registered idle mode on PS" (state 3) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE. If the UE supports both CS and PS domains, the initial UE state shall be "Registered idle mode on CS/PS" (state 7).

Test Procedure

Table 8.4.1.3-1 illustrates the downlink power to be applied for the 2 cells in this test case.

Table 8.4.1.3-1

| Parameter              | Unit                | Cell 1 | Cell 2 |
|------------------------|---------------------|--------|--------|
| UTRA RF Channel Number |                     | Ch. 1  | Ch. 1  |
| CPICH Ec               | dBm/<br>3.84<br>MHz | -60    | -70    |

The UE is initially at idle mode and has selected cell 1 for camping. The System Information Block type 11 messages are modified with respect to the default settings to prevent reporting of "Cell synchronisation information" and also to include cell 2 into the IE "intra-frequency cell info list". The key measurement parameters are as follow: measurement type = "intra-frequency measurement", measurement quantity = "CPICH RSCP", report criteria = "periodic reporting criteria", reporting interval = "12 seconds". In the System Information type 11 messages, reporting of CPICH RSCP is also required for intra-frequency reporting when transmitting RACH messages on cell 1.

SS prompts the operator to make an outgoing call for one of the traffic classes supported by the UE. SS and UE shall execute procedure P6. Next SS and UE shall execute procedure P10. Then SS and UE shall execute procedure P14. SS starts timer T305 and waits until timer T305 expires, the UE shall send a CELL\_UPDATE message on the CCCH which includes the measurement reading of cell 1's CPICH RSCP values in IE "Measured results on RACH". SS then replies with CELL\_UPDATE\_CONFIRM message on the downlink DCCH, without changing the physical channel resources.

SS transmits PHYSICAL\_CHANNEL\_RECONFIGURATION message, and allocates dedicated physical channels to the UE. The UE shall transit to CELL\_DCH state and then send a MEASUREMENT\_REPORT message, correctly stating the measurement identity. The measurement identity indicated shall match the value that was previously broadcasted on System Information Block type 11 messages when the UE was still in idle mode. The IE "Measured results" in the MEASUREMENT\_REPORT messages shall contain measured values of cell 2's CPICH RSCP.

## Expected Sequence

| Step | Direction |    | Message                                                              | Comment                                                                                                                                                                         |
|------|-----------|----|----------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                      |                                                                                                                                                                                 |
| 1    |           | ←  | System Information Block type 1,<br>System Information Block type 11 | The UE is idle mode and camped onto cell 1. System Information Block type 1 and 11 to be transmitted are different from the default settings (see specific message contents)    |
| 2    |           | ↔  | SS executes procedure P6 (clause 7.4.2.2.2) specified in TS 34.108.  | SS prompts the test operator to make an outgoing call.                                                                                                                          |
| 3    |           | ↔  | SS executes procedure P10 (clause 7.4.2.4.2) specified in TS 34.108. |                                                                                                                                                                                 |
| 4    |           | ↔  | SS executes procedure P6 (clause 7.4.2.2.2) specified in TS 34.108.  |                                                                                                                                                                                 |
| 5    |           |    | Void                                                                 |                                                                                                                                                                                 |
| 6    |           |    |                                                                      | SS monitors the uplink DCCH to confirm that no MEASUREMENT REPORT messages are detected. SS waits for 5 minutes (for the expiry of T305 timer).                                 |
| 7    |           | →  | CELL UPDATE                                                          | This message shall contain IE "Measured results on RACH" reporting the readings of CPICH-RSCP for cell 1.                                                                       |
| 8    |           | ←  | CELL UPDATE CONFIRM                                                  | SS does not change the physical channel configurations.                                                                                                                         |
| 9    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION                                     | SS assigns dedicated physical resources.                                                                                                                                        |
| 10   |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE                            | UE shall transit to CELL_DCH state.                                                                                                                                             |
| 11   |           | →  | MEASUREMENT REPORT                                                   | UE shall begin to report cell 2's CPICH-RSCP value periodically at 16 seconds interval. The measurement identity shall match measurement contexts transmitted on BCCH in step 1 |

## Specific Message Content

## System Information Block type 1 (Step 1)

| Information Element                                 | Value/Remarks |
|-----------------------------------------------------|---------------|
| UE Timers and constants in connected mode<br>→ T305 | 5 minutes.    |

## System Information Block type 11 (Step 1)

| Information Element                                    | Value/Remark                        |
|--------------------------------------------------------|-------------------------------------|
| SIB12 indicator                                        | FALSE                               |
| FACH measurement occasion info                         |                                     |
| → FACH Measurement occasion cycle length coefficient   | 2                                   |
| → Inter-frequency FDD measurement indicator            | FALSE                               |
| → Inter-frequency TDD measurement indicator            | FALSE                               |
| → Inter-RAT measurement indicators                     | Not Present                         |
| Measurement control system information                 |                                     |
| → Intra-frequency measurement system information       |                                     |
| → Intra-frequency measurement identity                 | 5                                   |
| → Intra-frequency cell info list                       |                                     |
| → CHOICE intra-frequency cell removal                  | Remove no intra-frequency cells     |
| → New intra-frequency info list                        |                                     |
| → Intra-frequency cell id                              | 2                                   |
| → Cell info                                            |                                     |
| → Cell individual offset                               | 0 dB                                |
| → Reference time difference to cell                    | 0 chips                             |
| → Read SFN Indicator                                   | FALSE                               |
| → CHOICE mode                                          | FDD                                 |
| → Primary CPICH Info                                   |                                     |
| → Primary Scrambling Code                              | Set to same code as used for cell 2 |
| → Primary CPICH TX power                               | Not Present                         |
| → TX Diversity Indicator                               | FALSE                               |
| → Cell selection and Re-selection info                 |                                     |
| → Qoffset <sub>s,n</sub>                               | 0 dB                                |
| → Maximum allowed UL TX power                          | 0 dBm                               |
| → HCS neighbouring cell information                    | Not Present                         |
| → Qqualmin                                             | -20dB                               |
| → Qrxlevmin                                            | -115dBm                             |
| → Cells for measurement                                | Not Present                         |
| → Intra-frequency Measurement quantity                 |                                     |
| → Filter Coefficient                                   | 0                                   |
| → Measurement quantity                                 | CPICH RSCP                          |
| → Intra-frequency measurement for RACH reporting       |                                     |
| → SFN-SFN observed time difference                     | No report                           |
| → Reporting quantity                                   | CPICH RSCP                          |
| → Maximum number of reported cells on RACH             | Current cell                        |
| → Reporting information for state CELL_DCH             |                                     |
| → Intra-frequency reporting quantity                   |                                     |
| → Reporting quantities for active set cells            |                                     |
| → SFN-SFN observed time difference reporting indicator | No report                           |
| → Cell synchronisation information reporting indicator | FALSE                               |
| → Cell identity reporting indicator                    | FALSE                               |
| → CPICH Ec/No reporting indicator                      | FALSE                               |
| → CPICH RSCP reporting indicator                       | FALSE                               |
| → Pathloss reporting indicator                         | FALSE                               |
| → Reporting quantities for monitored set cells         |                                     |
| → SFN-SFN observed time difference reporting indicator | No report                           |
| → Cell synchronisation information reporting indicator | FALSE                               |
| → Cell identity reporting indicator                    | TRUE                                |
| → CPICH Ec/No reporting indicator                      | FALSE                               |
| → CPICH RSCP reporting indicator                       | TRUE                                |
| → Pathloss reporting indicator                         | FALSE                               |
| → Reporting quantities for detected set cells          | Not present                         |
| → Measurement Reporting Mode                           |                                     |
| → Measurement Reporting Transfer Mode                  | Acknowledged mode RLC               |
| → Periodic Reporting/Event Trigger Reporting Mode      | Periodic Reporting                  |
| → CHOICE report criteria                               | Intra-frequency measurement         |

| Information Element                            | Value/Remark                                                                                                                  |
|------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Parameters required for each event             | reporting-criteria                                                                                                            |
| Intra-frequency event identity                 |                                                                                                                               |
| Triggering condition 1                         | 1a                                                                                                                            |
| Triggering condition 2                         | Not Present                                                                                                                   |
| Reporting Range Constant                       | Active set cells                                                                                                              |
| Cells forbidden to affect reporting range      | 920.0 dB                                                                                                                      |
| CHOICE mode                                    | Not Present                                                                                                                   |
| Primary CPICH info                             | FDD                                                                                                                           |
| Primary Scrambling Code                        |                                                                                                                               |
| W                                              | Set to same code as used for cell 2                                                                                           |
| Hysteresis                                     | 0.0                                                                                                                           |
| Threshold used frequency                       | 1.0 dB                                                                                                                        |
| Reporting deactivation threshold               | -85 dBm                                                                                                                       |
| Replacement activation threshold               | 0                                                                                                                             |
| Time to trigger                                | Not Present                                                                                                                   |
| Amount of reporting                            | 0msec                                                                                                                         |
| Reporting interval                             | Infinity                                                                                                                      |
| Reporting Cell Status                          | 16 seconds                                                                                                                    |
| CHOICE reported cell                           | Report cells within active and/or monitored set on used frequency or within active and/or monitored set on non-used frequency |
| Maximum number of reported cells               | 2                                                                                                                             |
| Inter-frequency measurement system information | Not Present                                                                                                                   |
| Traffic volume measurement system information  | Not Present                                                                                                                   |
| UE internal measurement system information     | Not Present                                                                                                                   |

#### CELL UPDATE (Step 7)

| Information Element                     | Value/Remarks                                                                       |
|-----------------------------------------|-------------------------------------------------------------------------------------|
| U-RNTI                                  | Check to see if set to same U-RNTI value assigned in the execution of procedure P6. |
| Cell update cause                       | Check to see if set to 'Periodic cell updating'                                     |
| Protocol error indicator                | Check to see if set to 'FALSE'                                                      |
| Measured results on RACH                |                                                                                     |
| Measurement result for current cell     |                                                                                     |
| CHOICE measurement quantity             | Check to see if set to 'CPICH RSCP'                                                 |
| CPICH RSCP                              | Checked to see if set to within an acceptable range.                                |
| Measurement results for monitored cells | Checked to see if this IE is absent.                                                |
| Protocol error information              | Check to see if set to 'FALSE'                                                      |

#### PHYSICAL CHANNEL RECONFIGURATION (Step 9)

Use the same message sub-type found in Annex A, which is entitled "Packet to CELL\_DCH from CELL\_FACH".

## MEASUREMENT REPORT (Step 11)

| Information Element                    | Value/Remarks                                                      |
|----------------------------------------|--------------------------------------------------------------------|
| Measurement identity                   | Check to see if set to 5                                           |
| Measured Results                       |                                                                    |
| —— CHOICE measurement                  | Check to see if set to "Intra-frequency measured results list"     |
| —— Intra-frequency measurement results |                                                                    |
| —— Cell measured results               |                                                                    |
| —— Cell Identity                       | Check to see if it is absent                                       |
| —— SFN-SFN observed time difference    | Check to see if this IE is absent                                  |
| —— Cell synchronisation information    | Check to see if this IE is absent                                  |
| —— Primary CPICH Info                  |                                                                    |
| —— Primary Scrambling Code             | Check to see if it's the same code for cell 2                      |
| —— CPICH Ec/No                         | Check to see if this IE is absent                                  |
| —— CPICH RSCP                          | Check to see if this IE is present                                 |
| —— Pathloss                            | Check to see if this IE is absent                                  |
| Measured Results on RACH               | Check to see if this IE is absent                                  |
| Event Results                          |                                                                    |
| —— CHOICE event result                 | Check to see if set to "Intra-frequency measurement event results" |
| —— Intra-frequency event identity      | Check to see if set to "1a"                                        |
| —— Cell measurement event results      |                                                                    |
| —— CHOICE Mode                         | Check to see if set to "FDD"                                       |
| —— Primary CPICH info                  |                                                                    |
| —— Primary Scrambling Code             | Check to see if set to the scrambling code of cell 2               |

## 8.4.1.3.5 Test Requirement

After step 5 the UE shall not transmit any MEASUREMENT REPORT messages on the uplink DCCH.

After step 6 the UE shall initiate cell update procedure by transmitting CELL UPDATE message on CCCH. In this message, IE "cell update cause" shall be set to "periodic cell updating". It shall include IE "measured results on RACH", containing the measurement value for cell 1's CPICH RSCP.

After step 10 the UE shall transmit MEASUREMENT REPORT messages at 16 seconds interval. In these messages, cell 2's CPICH RSCP value shall be reported in IE "Measured results". The IE "measurement identity" in this message shall match the IE "Intra-frequency measurement identity" found in System Information Block type 11 messages transmitted in step 1. The MEASUREMENT REPORT messages shall also contain IE "Event results", indicating that intra-frequency event "1a" has triggered in the UE.

## 8.4.1.4 Measurement Control and Report: Inter-frequency measurement for transition from idle mode to CELL\_FACH state

## 8.4.1.4.1 Definition

## 8.4.1.4.2 Conformance requirement

After entering CELL\_FACH state from idle mode, the UE shall start to monitor the cells listed in IE "inter-frequency cell info list" assigned in the System Information Block type 11 or 12 messages.

## Reference

3GPP TS 25.331, clause 8.4.1.9.2

## 8.4.1.4.3 Test Purpose

To confirm that the UE begins to monitor the list of cells assigned in the IE "inter-frequency cell info list" in System Information Block type 11 or 12 messages, after it enters CELL\_FACH state from idle mode. However, it shall not transmit any MEASUREMENT REPORT messages to report measured results for inter-frequency cells.

#### 8.4.1.4.4 Method of test

##### Initial Condition

System Simulator: 2 cells—Cell 1 and cell 4 are active.

UE: "Registered idle mode on PS" (state 3) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE. If the UE supports both CS and PS domains, the initial UE state shall be "Registered idle mode on CS/PS" (state 7).

##### Test Procedure

Table 8.4.1.4-1 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution. Columns marked "T0" denote the initial conditions, while columns marked "T1" are to be applied subsequently. The exact instants on which these values shall be applied are described in the texts in this clause.

**Table 8.4.1.4-1**

| Parameter              | Unit                | Cell 1 |     | Cell 4 |     |
|------------------------|---------------------|--------|-----|--------|-----|
|                        |                     | T0     | T1  | T0     | T1  |
| UTRA RF Channel Number |                     | Ch. 1  |     | Ch. 2  |     |
| CPICH Ec               | dBm/<br>3.84<br>MHz | -60    | -75 | -75    | -60 |

The UE is initially at idle mode and has selected cell 1 for camping. The System Information Block type 11 messages are modified with respect to the default settings to prevent reporting of "Cell synchronisation information" and also to include cell 4 into the "inter-frequency cell list" IE.

SS prompts the operator to make an outgoing call of a supported traffic class. SS and UE shall execute procedure P6. Next SS and UE shall execute procedure P10. Then SS and UE shall execute procedure P14. The UE shall not transmit any MEASUREMENT REPORT messages, which pertain to measurement readings for inter-frequency cells belonging to the monitored set. SS re-adjusts its downlink power settings according to columns marked "T1" in table 8.4.1.4-1. This is expected to trigger a cell reselection in the UE. The UE shall send CELL UPDATE message to cell 4 in order to report this event. Upon receiving this message, SS replies with the default CELL UPDATE CONFIRM message on the downlink DCCH.

##### Expected Sequence

| Step | Direction |    | Message                          | Comment                                                                                                                                                                                                 |
|------|-----------|----|----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                  |                                                                                                                                                                                                         |
| 1    | ←         |    | System Information Block type 11 | The UE is PS-DCCH+DTCH_FACH (state 6-11) in idle mode and camped onto cell 1. System Information Block type 11 to be transmitted is different from the default settings (see specific message contents) |
| 2    |           |    | Void                             |                                                                                                                                                                                                         |
| 3    | →         |    | Void                             |                                                                                                                                                                                                         |
| 4    | ←         |    | Void                             |                                                                                                                                                                                                         |
| 5    | →         |    | Void                             |                                                                                                                                                                                                         |

| Step | Direction |    | Message             | Comment                                                                                                         |
|------|-----------|----|---------------------|-----------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                     |                                                                                                                 |
| 6    |           |    |                     | SS checks to see that no MEASUREMENT REPORT messages are received.                                              |
| 7    |           |    |                     | SS reconfigures the downlink transmission power, according to columns "T1" of table 8.4.1.4-1.                  |
| 8    | →         |    | CELL UPDATE         | UE shall detect that cell 4 has become stronger than cell 1. It sends this message after re-selecting to cell 4 |
| 9    |           | ←  | CELL UPDATE CONFIRM | Use default message.                                                                                            |

### Specific Message Content

All messages indicated below shall use the same content as described in default message content, with the following exceptions:

### System Information Block type 11 (Step 1)

| Information Element                                  | Value/Remark                         |
|------------------------------------------------------|--------------------------------------|
| SIB12 Indicator                                      | FALSE                                |
| FACH measurement occasion info                       |                                      |
| — FACH Measurement occasion cycle length coefficient | 2                                    |
| — Inter-frequency FDD measurement indicator          | TRUE                                 |
| — Inter-frequency TDD measurement indicator          | FALSE                                |
| — Inter-RAT measurement indicators                   | Not Present                          |
| Measurement control system information               |                                      |
| — Intra-frequency measurement system information     | Not Present                          |
| — Inter-frequency measurement system information     |                                      |
| — Inter-frequency cell info list                     |                                      |
| — CHOICE inter-frequency cell removal                | No inter-frequency cells removed     |
| — New inter-frequency info list                      |                                      |
| — Inter-frequency cell id                            | 4                                    |
| — Frequency info                                     |                                      |
| — UARFCN uplink (Nu)                                 | Set to uplink UARFCN of cell 4       |
| — UARFCN downlink (Nd)                               | Set to the downlink UARFCN of cell 4 |
| — Cell info                                          |                                      |
| — Cell individual offset                             | 0 dB                                 |
| — Reference time difference to cell                  | 0 chips                              |
| — Read SFN Indicator                                 | FALSE                                |
| — CHOICE mode                                        | FDD                                  |
| — Primary CPICH Info                                 |                                      |
| — Primary Scrambling Code                            | Set to same code as used for cell 4  |
| — Primary CPICH TX power                             | Not Present                          |
| — TX Diversity Indicator                             | FALSE                                |
| — Cell selection and re-selection info               |                                      |
| — Qoffset <sub>s,n</sub>                             | 0 dB                                 |
| — Maximum allowed UL TX power                        | 0 dBm                                |
| — HCS neighbouring cell information                  | Not Present                          |
| — Qqualmin, Qrxlevmin                                | -20dB, -115dBm                       |
| — Cells for measurement                              | Not Present                          |
| — Inter-RAT measurement system information           | Not Present                          |
| — Traffic volume measurement system information      | Not Present                          |
| — UE internal measurement system information         | Not Present                          |



**CELL UPDATE (Step 8)**

| Information Element        | Value/Remarks                                                                     |
|----------------------------|-----------------------------------------------------------------------------------|
| U-RNTI                     | Check to see if set to same U-RNTI assigned during the execution of procedure P6. |
| Cell update cause          | Check to see if it is set to "Cell Reselection"                                   |
| Protocol error info        | Check to see if it is absent or set to FALSE                                      |
| Measured results on RACH   | Check to see if it is absent                                                      |
| Protocol error information | Check to see if it is absent                                                      |

**CELL UPDATE CONFIRM (Step 9)**

Use the message sub-type in default message content defined in Annex A.

**8.4.1.4.5 — Test Requirement**

After step 5 the UE shall not transmit any MEASUREMENT REPORT messages pertaining to any measurement quantities for cell 4.

After step 7 the UE shall reselect to cell 4 and transmit a CELL UPDATE message on the uplink CCCH of cell 4.

**8.4.1.5 — Measurement Control and Report: Intra-frequency measurement for transition from CELL\_DCH to CELL\_FACH state****8.4.1.5.1 — Definition****8.4.1.5.2 — Conformance requirement**

After entering CELL\_FACH state from CELL\_DCH state, the UE shall stop intra-frequency type measurement reporting assigned in a MEASUREMENT CONTROL message. After transition to CELL\_FACH state, the UE shall start to monitor cells listed in the IE "intra-frequency cell info" received in System Information Block type 11 or 12. If no intra-frequency measurements applicable to CELL\_DCH are stored in the UE, and that the UE receives "intra frequency reporting criteria" IE in System Information Block type 11 or 12 messages received whilst in CELL\_FACH state, it shall apply these reporting criteria after a subsequent return to CELL\_DCH state. If the UE receives the IE "Intra-frequency reporting quantity for RACH reporting" and the IE "Maximum number of reported cells on RACH" in System Information Block Type 11 or 12 during a transition from CELL\_DCH to CELL\_FACH, the UE shall append the measured results when transmitting uplink RACH messages.

**Reference**

3GPP TS 25.331, clause 8.4.1.6.1, 8.4.1.7.1

**8.4.1.5.3 — Test Purpose**

To confirm that the UE stops performing intra-frequency measurement reporting specified in a MEASUREMENT CONTROL message, when it moves from CELL\_DCH state to CELL\_FACH state. To confirm that the UE reads the System Information Block type 11 or 12 messages when it enters CELL\_FACH state from CELL\_DCH state, and starts to monitor the cells listed in the IE "intra-frequency cell info". To confirm that the UE performs measurements on uplink RACH transmissions and appends the measured results in RACH messages, when it receives IE "intra-frequency reporting quantity for RACH reporting" and IE "Maximum number of reported cells on RACH" in the System Information Block type 11 or 12 messages. To confirm that the UE applies the reporting criteria in IE "intra-frequency reporting criteria" in System Information Block Type 11 or 12 messages following a state transition from CELL\_FACH to CELL\_DCH, if no intra-frequency measurements applicable to CELL\_DCH are stored.

**8.4.1.5.4 — Method of test****Initial Condition**

System Simulator: 3 cells — Cell 1 and cell 2 are active, while cell 3 is switched off..

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE.

Test Procedure

Table 8.4.1.5-1 illustrates the downlink power to be applied for the 3 cells at various time instants of the test execution. Columns marked "T0" denote the initial conditions, while columns marked "T1" are to be applied subsequently. The exact instants on which these values shall be applied are described in the texts in this clause.

Table 8.4.1.5-1

| Parameter              | Unit                | Cell 1 |     | Cell 2 |     | Cell 3 |     |
|------------------------|---------------------|--------|-----|--------|-----|--------|-----|
|                        |                     | T0     | T1  | T0     | T1  | T0     | T1  |
| UTRA RF Channel Number |                     | Ch. 1  |     | Ch. 1  |     | Ch. 1  |     |
| CPICH Ec               | dBm/<br>3.84<br>MHz | -60    | -60 | -80    | -85 | -122   | -70 |

The UE is initially in CELL\_DCH state. The System Information Block type 11 message is modified with respect to the default message contents, in order to prevent the reporting of "Cell synchronisation information". No measurement requirements are specified for the UE in any of the System Information Block type 11 or 12 messages.

SS sends a MEASUREMENT CONTROL message to UE. In this message, the SS requests the establishment of an intra-frequency measurement task for the measurement of cell 2's CPICH RSCP. At the same time, reporting of cell 2's CPICH RSCP is commanded with the reporting criteria set to "periodic reporting" and "reporting interval" set to 16 seconds. The UE shall start transmitting MEASUREMENT REPORT messages at 16 seconds interval corresponding to the requested reporting event.

SS transmits PHYSICAL CHANNEL RECONFIGURATION message, and configures RACH and FACH channels in the uplink and downlink directions respectively. After receiving this message, the UE shall reconfigure itself and reply with a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on RACH. SS acknowledges this message and the UE shall move to CELL\_FACH state. SS monitors the uplink channels to verify that no MEASUREMENT REPORT messages are received.

SS reconfigures itself according to the settings in columns marked "T1" in table 8.4.1.5-1. SS transmits System Information Block type 12 messages in cell 1, which include cell 3 into the IE "intra-frequency cell info". IEs "Intra-frequency reporting quantity for RACH Reporting" and IE "Maximum number of Reported cells on RACH" are also specified in the System Information Type 12 messages. Event type 1a reporting criterion is specified for intra-frequency measurements. SS transmit SYSTEM INFORMATION CHANGE INDICATION message to UE. SS waits until T305 has expired. The UE shall respond with a CELL UPDATE message, which comprises IE "Measured results on RACH" to report the readings of CPICH RSCP for cell 1 and cell 3. SS replies with CELL UPDATE CONFIRM message on the downlink DCCH. This message does not change the physical resources nor allocate any new RNTI identities. SS transmits PHYSICAL CHANNEL RECONFIGURATION message again, and configures dedicated physical channel for both uplink and downlink directions. The UE shall send PHYSICAL CHANNEL RECONFIGURATION COMPLETE message and return to CELL\_DCH state. SS listens to the uplink DCCH for MEASUREMENT REPORT messages. SS shall receive the MEASUREMENT REPORT messages with IE "Event results" at 8 seconds interval.

#### Expected Sequence

| Step | Direction |    | Message                                                      | Comment                                                                                                                                                                                                                                                                            |
|------|-----------|----|--------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                                                                                                                                    |
| 1    |           | ←  | Master Information Block<br>System Information Block type 11 | UE is in CS-DCCH+DTCH_DCH (state 6-9) or PS-DCCH+DTCH_DCH (state 6-10) in cell 1. System Information Block Type 11 to be broadcasted specifies no measurement type to be configured in UE.                                                                                         |
| 2    |           |    | Void                                                         |                                                                                                                                                                                                                                                                                    |
| 3    |           |    | Void                                                         |                                                                                                                                                                                                                                                                                    |
| 4    |           |    | Void                                                         |                                                                                                                                                                                                                                                                                    |
| 5    |           | ←  | MEASUREMENT CONTROL                                          | SS requests for measurement and reporting of cell 2's CPICH RSCP value.                                                                                                                                                                                                            |
| 6    |           | →  | MEASUREMENT REPORT                                           | UE shall send periodic report at 16 seconds interval.                                                                                                                                                                                                                              |
| 7    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION                             | SS configures common physical channels.                                                                                                                                                                                                                                            |
| 8    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE                    | UE shall reconfigure its uplink channel to RACH and downlink channel to FACH, before transiting to CELL_FACH state.                                                                                                                                                                |
| 9    |           | ←  | Master Information Block<br>System Information Block type 12 | SS reconfigures itself according to the settings stated in column "T1" of table 8.4.1.5-1. SIB type 12 indicates that cell 3 is included in the IE "intra-frequency cell info". SS waits for 1 minute and verifies that no MEASUREMENT REPORT messages are detected on the uplink. |
| 10   |           | ←  | SYSTEM INFORMATION CHANGE INDICATION                         | SS waits until T305 has expired.                                                                                                                                                                                                                                                   |
| 11   |           | →  | CELL UPDATE                                                  | UE shall transmit this message with measured results on RACH channels for cell 1 and cell 3 present in this message.                                                                                                                                                               |
| 12   |           | ←  | CELL UPDATE CONFIRM                                          | No changes in physical resource allocation and RNTI identities.                                                                                                                                                                                                                    |
| 13   |           | ←  | PHYSICAL CHANNEL RECONFIGURATION                             | SS configures dedicated physical channels.                                                                                                                                                                                                                                         |
| 14   |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE                    | UE shall transit to CELL_DCH state.                                                                                                                                                                                                                                                |

| Step | Direction |    | Message            | Comment                                                                                                                         |
|------|-----------|----|--------------------|---------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                 |
| 15   | ←         |    | MEASUREMENT REPORT | UE shall report cell 2's CPICH RSCP value in IE "Cell measured results" and the triggering of event "1a" in IE "Event results". |

### Specific Message Content

#### MASTER INFORMATION BLOCK (Step 1)

Use the same message sub-type found in clause 6.1 of TS 34.108, with the following exception:

| Information Element | Value/Remarks |
|---------------------|---------------|
| MIB Value Tag       | 1             |

#### System Information Block type 11 (Step 1)

| Information Element                              | Value/Remark |
|--------------------------------------------------|--------------|
| SIB12 indicator                                  | FALSE        |
| FACH measurement occasion info                   | Not Present  |
| Measurement control system information           |              |
| — Intra-frequency measurement system information | Not Present  |
| — Inter-frequency measurement system information | Not Present  |
| — Inter-RAT measurement system information       | Not Present  |
| — Traffic volume measurement system information  | Not Present  |
| — UE internal measurement system information     | Not Present  |

## MEASUREMENT CONTROL (Step 5)

| Information Element                                             | Value/Remark                                                                                                                  |
|-----------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Measurement Identity                                            | 5                                                                                                                             |
| Measurement Command                                             | Setup                                                                                                                         |
| Measurement Reporting Mode                                      |                                                                                                                               |
| <del>Measurement Reporting Transfer Mode</del>                  | Acknowledged Mode RLC                                                                                                         |
| <del>Periodic Reporting / Event Trigger Reporting Mode</del>    | Periodical Reporting                                                                                                          |
| Additional measurements list                                    | Not Present                                                                                                                   |
| CHOICE measurement type                                         | Intra-frequency measurement                                                                                                   |
| <del>Intra-frequency cell info list</del>                       |                                                                                                                               |
| <del>CHOICE intra-frequency cell removal</del>                  | Remove no intra-frequency cells                                                                                               |
| <del>New intra-frequency info list</del>                        |                                                                                                                               |
| <del>Intra-frequency cell id</del>                              | 2                                                                                                                             |
| <del>Cell info</del>                                            |                                                                                                                               |
| <del>Cell individual offset</del>                               | 0 dB                                                                                                                          |
| <del>Reference time difference to cell</del>                    | 0 chips                                                                                                                       |
| <del>Read SFN Indicator</del>                                   | FALSE                                                                                                                         |
| <del>CHOICE mode</del>                                          | FDD                                                                                                                           |
| <del>Primary CPICH Info</del>                                   |                                                                                                                               |
| <del>Primary Scrambling Code</del>                              | Set to same code as used for cell 2                                                                                           |
| <del>Primary CPICH TX power</del>                               | Not Present                                                                                                                   |
| <del>TX Diversity Indicator</del>                               | FALSE                                                                                                                         |
| <del>Cells for measurement</del>                                |                                                                                                                               |
| <del>Intra-frequency cell id</del>                              | 2                                                                                                                             |
| <del>Intra-frequency measurement quantity</del>                 |                                                                                                                               |
| <del>Filter Coefficient</del>                                   | 0                                                                                                                             |
| <del>Measurement quantity</del>                                 | CPICH RSCP                                                                                                                    |
| <del>Intra-frequency reporting quantity</del>                   |                                                                                                                               |
| <del>Reporting quantities for active set cells</del>            |                                                                                                                               |
| <del>SFN-SFN observed time difference reporting indicator</del> | No report                                                                                                                     |
| <del>Cell synchronisation information reporting indicator</del> | FALSE                                                                                                                         |
| <del>Cell identity reporting indicator</del>                    | FALSE                                                                                                                         |
| <del>CPICH Ec/No reporting indicator</del>                      | FALSE                                                                                                                         |
| <del>CPICH RSCP reporting indicator</del>                       | FALSE                                                                                                                         |
| <del>Pathloss reporting indicator</del>                         | FALSE                                                                                                                         |
| <del>Reporting quantities for monitored set cells</del>         |                                                                                                                               |
| <del>SFN-SFN observed time difference reporting indicator</del> | No report                                                                                                                     |
| <del>Cell synchronisation information reporting indicator</del> | FALSE                                                                                                                         |
| <del>Cell identity reporting indicator</del>                    | TRUE                                                                                                                          |
| <del>CPICH Ec/No reporting indicator</del>                      | FALSE                                                                                                                         |
| <del>CPICH RSCP reporting indicator</del>                       | TRUE                                                                                                                          |
| <del>Pathloss reporting indicator</del>                         | FALSE                                                                                                                         |
| <del>Reporting quantities for detected cells</del>              | Not present                                                                                                                   |
| <del>Reporting cell status</del>                                |                                                                                                                               |
| <del>CHOICE reported cell</del>                                 | Report cells within active and/or monitored set on used frequency or within active and/or monitored set on non-used frequency |
| <del>Maximum number of reported cells</del>                     | 2                                                                                                                             |
| <del>Measurement validity</del>                                 | Not present                                                                                                                   |
| <del>CHOICE report criteria</del>                               | Periodical reporting criteria                                                                                                 |
| <del>Amount of reporting</del>                                  | Infinity                                                                                                                      |
| <del>Reporting interval</del>                                   | 16 seconds                                                                                                                    |
| DPCH compressed mode status info                                | Not Present                                                                                                                   |

## MEASUREMENT REPORT (Step 6)

| Information Element                   | Value/Remarks                                                  |
|---------------------------------------|----------------------------------------------------------------|
| Measurement identity                  | Check to see if set to 5                                       |
| Measured Results                      |                                                                |
| → CHOICE measurement                  | Check to see if set to "Intra-frequency measured results list" |
| → Intra-frequency measurement results |                                                                |
| → Cell measured results               |                                                                |
| → Cell Identity                       | Check to see if it is absent                                   |
| → SFN-SFN observed time difference    | Check to see if this IE is absent                              |
| → Cell synchronisation information    | Check to see if this IE is absent                              |
| → Primary CPICH Info                  |                                                                |
| → Primary Scrambling Code             | Check to see if it's the same code for cell 2                  |
| → CPICH Ec/No                         | Check to see if this IE is absent                              |
| → CPICH RSCP                          | Check to see if this IE is present                             |
| → Pathloss                            | Check to see if this IE is absent                              |
| Measured Results on RACH              | Check to see if this IE is absent                              |
| Additional measured result list       | Check to see if this IE is absent                              |
| Event results                         | Check to see if this IE is absent                              |

## PHYSICAL CHANNEL RECONFIGURATION (Step 7)

Use the same message sub-type found in Annex A, which is entitled "(Packet to CELL\_FACH from CELL\_DCH in PS)"

## MASTER INFORMATION BLOCK (Step 9)

Use the same message sub-type found in clause 6.1 of TS 34.108, with the following exception:

| Information Element | Value/Remarks |
|---------------------|---------------|
| MIB Value Tag       | 2             |

## System Information Block type 12 (Step 9)

| Information Element                                    | Value/Remark                                   |
|--------------------------------------------------------|------------------------------------------------|
| FACH measurement occasion info                         | Not Present                                    |
| Measurement control system information                 |                                                |
| — Intra-frequency measurement system information       |                                                |
| — Intra-frequency measurement identity                 | 6                                              |
| — Intra-frequency cell info list                       |                                                |
| — CHOICE intra-frequency cell removal                  | Remove no intra-frequency cells                |
| — New intra-frequency info list                        |                                                |
| — Intra-frequency cell id                              | 3                                              |
| — Cell info                                            |                                                |
| — Cell individual offset                               | 0 dB                                           |
| — Reference time difference to cell                    | 0 chips                                        |
| — Read SFN Indicator                                   | FALSE                                          |
| — CHOICE mode                                          | FDD                                            |
| — Primary CPICH Info                                   |                                                |
| — Primary Scrambling Code                              | Set to same code as used for cell 3            |
| — Primary CPICH TX power                               | Not Present                                    |
| — TX Diversity Indicator                               | FALSE                                          |
| — Cell selection and Re-selection info                 |                                                |
| — $Q_{offset_{s,n}}$                                   | 0 dB                                           |
| — Maximum allowed UL TX power                          | 0 dBm                                          |
| — HCS neighbouring cell information                    | Not Present                                    |
| — $Q_{qualmin}$ , $Q_{rxlevmin}$                       | -20 dB, -115 dBm                               |
| — Cells for measurement                                | Not Present                                    |
| — Intra-frequency measurement quantity                 |                                                |
| — Filter Coefficient                                   | 0                                              |
| — Measurement quantity                                 | CPICH RSCP                                     |
| — Intra-frequency measurement for RACH reporting       |                                                |
| — SFN-SFN observed time difference                     | No report                                      |
| — Reporting quantity                                   | CPICH RSCP                                     |
| — Maximum number of reported cells on RACH             | Current cell + best neighbour                  |
| — Reporting information for state CELL_DCH             |                                                |
| — Intra-frequency reporting quantity                   |                                                |
| — Reporting quantities for active set cells            |                                                |
| — SFN-SFN observed time difference reporting indicator | No report                                      |
| — Cell synchronisation information reporting indicator | FALSE                                          |
| — Cell identity reporting indicator                    | TRUE                                           |
| — CPICH Ec/No reporting indicator                      | FALSE                                          |
| — CPICH RSCP reporting indicator                       | TRUE                                           |
| — Pathloss reporting indicator                         | FALSE                                          |
| — Reporting quantities for monitored set cells         |                                                |
| — SFN-SFN observed time difference reporting indicator | No report                                      |
| — Cell synchronisation information reporting indicator | FALSE                                          |
| — Cell identity reporting indicator                    | TRUE                                           |
| — CPICH Ec/No reporting indicator                      | FALSE                                          |
| — CPICH RSCP reporting indicator                       | TRUE                                           |
| — Pathloss reporting indicator                         | FALSE                                          |
| — Reporting quantities for detected cells              | Not present                                    |
| — CHOICE report criteria                               | Intra-frequency measurement reporting criteria |
| — Parameter required for each event                    |                                                |
| — Intra-frequency event identity                       | 1a                                             |
| — Triggering condition 1                               | Not Present                                    |
| — Triggering condition 2                               | Monitored set cells                            |
| — Reporting range                                      | 20.0 dB                                        |
| — Cells forbidden to affect reporting                  | Not present                                    |
| — $W$                                                  | 0.0                                            |
| — Hysteresis                                           | 1.0 dB                                         |
| — Threshold used frequency                             | Not Present                                    |
| — Reporting deactivation threshold                     | 7                                              |
| — Replacement activation threshold                     | Not Present                                    |

| Information Element                            | Value/Remark                                                                                                                  |
|------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Time to trigger                                | 0                                                                                                                             |
| Amount of reporting                            | Infinity                                                                                                                      |
| Reporting Interval                             | 8 seconds                                                                                                                     |
| Reporting cell status                          | Report cells within active and/or monitored set on used frequency or within active and/or monitored set on non-used frequency |
| Maximum number of reported cells               | 3                                                                                                                             |
| Inter-frequency measurement system information | Not present                                                                                                                   |
| Inter-RAT measurement system information       | Not present                                                                                                                   |
| Traffic volume measurement system information  | Not present                                                                                                                   |
| UE internal measurement system information     | Not present                                                                                                                   |

#### SYSTEM INFORMATION CHANGE INDICATION (Step 10)

| Information Element                     | Value/Remarks |
|-----------------------------------------|---------------|
| BCCH modification info<br>MIB Value tag | 2             |

#### CELL UPDATE (Step 11)

| Information Element                     | Value/Remarks                                                                              |
|-----------------------------------------|--------------------------------------------------------------------------------------------|
| U-RNTI                                  | Check to see if set to the same value assigned during the execution of procedure P3 or P5. |
| Cell update cause                       | Check to see if it is set to "Periodical cell update"                                      |
| Protocol error info                     | Check to see if it is absent or set to FALSE                                               |
| Measured results on RACH                |                                                                                            |
| Measurement result for current cell     |                                                                                            |
| CHOICE measurement quantity             | Check to see if set to "CPICH RSCP"                                                        |
| CPICH RSCP                              | Check to see if it is present                                                              |
| Measurement results for monitored cells |                                                                                            |
| SFN-SFN observed time difference        | Not Checked                                                                                |
| Primary CPICH info                      |                                                                                            |
| Primary scrambling code                 | Check to see if the same as cell 3's code.                                                 |
| CHOICE measurement quantity             | Check to see if set to "CPICH RSCP"                                                        |
| CPICH RSCP                              | Check to see if it is present                                                              |
| Protocol error information              | Check to see if it is absent                                                               |

#### PHYSICAL CHANNEL RECONFIGURATION (Step 13)

Use the same message sub-type found in Annex A, which is entitled "(Packet to CELL\_DCH from CELL\_FACH in PS)".



## MEASUREMENT REPORT (Step 15)

| Information Element                 | Value/Remarks                                                           |
|-------------------------------------|-------------------------------------------------------------------------|
| Measurement identity                | Check to see if set to 6                                                |
| Measured Results                    |                                                                         |
| CHOICE measurement                  | Check to see if set to "Intra-frequency measured results list"          |
| Intra-frequency measurement results |                                                                         |
| Cell measured results               |                                                                         |
| Cell Identity                       | Check to see if it is absent                                            |
| SFN-SFN observed time difference    | Check to see if this IE is absent                                       |
| Cell synchronisation information    | Check to see if this IE is absent                                       |
| Primary CPICH Info                  |                                                                         |
| Primary Scrambling Code             | Check to see if it's the same code for cell 1                           |
| CPICH Ec/No                         | Check to see if this IE is absent                                       |
| CPICH RSCP                          | Check to see if this IE is present                                      |
| Pathloss                            | Check to see if this IE is absent                                       |
| Cell measured results               |                                                                         |
| Cell Identity                       | Check to see if it is absent                                            |
| SFN-SFN observed time difference    | Check to see if this IE is absent                                       |
| Cell synchronisation information    | Check to see if this IE is absent                                       |
| Primary CPICH Info                  |                                                                         |
| Primary Scrambling Code             | Check to see if it's the same code for cell 2                           |
| CPICH Ec/No                         | Check to see if this IE is absent                                       |
| CPICH RSCP                          | Check to see if this IE is present                                      |
| Pathloss                            | Check to see if this IE is absent                                       |
| Cell measured results               |                                                                         |
| Cell Identity                       | Check to see if it is absent                                            |
| SFN-SFN observed time difference    | Check to see if this IE is absent                                       |
| Cell synchronisation information    | Check to see if this IE is absent                                       |
| Primary CPICH Info                  |                                                                         |
| Primary Scrambling Code             | Check to see if it's the same code for cell 3                           |
| CPICH Ec/No                         | Check to see if this IE is absent                                       |
| CPICH RSCP                          | Check to see if this IE is present                                      |
| Pathloss                            | Check to see if this IE is absent                                       |
| Measured Results on RACH            | Check to see if this IE is absent                                       |
| Event results                       | Check to see if this set to 'Intra-frequency measurement event results' |
| Intra-frequency event identity      | Check to see if set to '1a'                                             |
| Cell measurement event results      |                                                                         |
| CHOICE Mode                         | Check to see if set to 'FDD'                                            |
| Primary CPICH info                  |                                                                         |
| Primary Scrambling Code             | Check to see if set to the same code for cell 3                         |

## 8.4.1.5.5 Test Requirement

After step 5, the UE shall start to transmit MEASUREMENT REPORT messages at 16 seconds interval. The message shall contain IE "measured result" to report cell 2's CPICH RSCP value.

After step 8, the UE shall not send any MEASUREMENT REPORT messages containing reporting quantities requested in MEASUREMENT CONTROL messages in step 5.

After step 10, the UE shall perform a cell update procedure and transmit a CELL UPDATE message. In this message, measured values CPICH RSCP for cell 1 and cell 3 shall be included in the IE "measured results on RACH".

After step 15, the UE shall apply the intra-frequency measurement reporting criteria" received in System Information Block type 12 messages of step 9. It shall send MEASUREMENT REPORT messages at 8 seconds interval. In these messages, triggering of event '1a' shall be reported in IE "Event results" with IE "Primary CPICH info" containing the primary scrambling code for cell 3.

### 8.4.1.6 Measurement Control and Report: Inter-frequency measurement for transition from CELL\_DCH to CELL\_FACH state

#### 8.4.1.6.1 Definition

#### 8.4.1.6.2 Conformance requirement

When transiting from CELL\_DCH state to CELL\_FACH state, the UE shall stop all measurement reporting activities related to inter-frequency measurements assigned in a MEASUREMENT CONTROL message. After a transition from CELL\_DCH state to CELL\_FACH state, the UE shall begin to monitor cells listed in the IE "inter-frequency cell info" in the System Information Block type 11 or 12 messages.

#### Reference

3GPP TS 25.331, clause 8.4.1.6.2

#### 8.4.1.6.3 Test Purpose

To confirm that UE ceases inter-frequency type measurement reporting assigned in MEASUREMENT CONTROL message when moving from CELL\_DCH state to CELL\_FACH. To confirm that the UE begins to monitor the cells listed in "inter-frequency cell info" received in System Information Block type 11 or 12 messages, following a state transition from CELL\_DCH state to CELL\_FACH state.

#### 8.4.1.6.4 Method of test

##### Initial Condition

System Simulator: 2 cells — Cell 1 and cell 2 are active.

UE: CS-DCCH+DTCH\_DCH (state 6-9) or PS-DCCH+DTCH\_DCH (state 6-10) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE.

##### Test Procedure

Table 8.4.1.6-1 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution. Columns marked "T0" denote the initial conditions, while columns marked "T1" are to be applied subsequently. The exact instants on which these values shall be applied are described in the texts in this clause.

**Table 8.4.1.6-1**

| Parameter              | Unit                | Cell 1 |     | Cell 4 |     |
|------------------------|---------------------|--------|-----|--------|-----|
|                        |                     | T0     | T1  | T0     | T1  |
| UTRA RF Channel Number |                     | Ch. 1  |     | Ch. 2  |     |
| CPICH-Ec               | dBm/<br>3.84<br>MHz | -60    | -75 | -75    | -60 |

The UE is initially in CELL\_DCH state. The System Information Block type 11 message is modified with respect to the default settings, so that no measurement tasks are required of the UE. SS transmits PHYSICAL CHANNEL RECONFIGURATION message. In this message, IE "DPCH compressed mode info" is present, which indicates that the UE shall apply the given parameters for compressed mode operations. The UE shall return a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message to acknowledge that compressed mode mechanism can be exercised.

SS sends a MEASUREMENT CONTROL message to the UE, including cell 4 into the IE "inter-frequency cell info". The IE "CHOICE reporting criteria" in this message is set to "periodic reporting criteria". SS waits for 8 seconds to allow the periodic timer to expire. The UE shall send a MEASUREMENT REPORT message containing IE "inter-frequency cell measurement results" to report cell 4's RSCP value. SS transmits PHYSICAL CHANNEL

RECONFIGURATION message again and reconfigures common physical channels. The UE shall return a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message and then move to CELL\_FACH state.

SS modifies the contents of Master Information Block (MIB) and System Information Block (SIB) type 11. In SIB 11, cell 4 is added to the cells listed in the "inter-frequency cell info" IE. SS transmit SYSTEM INFORMATION CHANGE INDICATION message to UE. SS waits for 8 seconds to detect any uplink MEASUREMENT REPORT messages. SS verifies that no MEASUREMENT REPORT message(s) are received as a result of inter-frequency measurements. SS then reconfigures the downlink transmission power settings of cell 1 and cell 4 according to the values stated in columns "T1" of table 8.4.1.6-1. SS waits for [x] seconds to allow the UE to perform cell re-selection. The UE shall transmit a CELL UPDATE message on the uplink CCCH of cell 4, specifying the "cell update cause" IE as "cell re-selection". SS replies with CELL UPDATE CONFIRM message on the downlink DCCH to complete the cell update procedure.

## Expected Sequence

| Step | Direction |    | Message                                                    | Comment                                                                                                                                                                                                                                  |
|------|-----------|----|------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                            |                                                                                                                                                                                                                                          |
| 1    |           | ←  | System Information Block type 11                           | UE is CS-DCCH+DTCH_DCH (state 6-9) or PS-DCCH+DTCH_DCH (state 6-10) in cell 1. System Information Block type 11 is modified with respect to the default settings. All measurement and reporting activities are disabled in this message. |
| 2    |           |    | Void                                                       |                                                                                                                                                                                                                                          |
| 3    |           | →  | Void                                                       |                                                                                                                                                                                                                                          |
| 4    |           | ←  | Void                                                       |                                                                                                                                                                                                                                          |
| 5    |           | →  | Void                                                       |                                                                                                                                                                                                                                          |
| 6    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION                           | SS instructs UE to begin compressed mode operation.                                                                                                                                                                                      |
| 7    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE                  | UE shall remain in CELL_DCH state.                                                                                                                                                                                                       |
| 8    |           | ←  | MEASUREMENT CONTROL                                        | SS indicates that the CPICH RSCP of cell 4 shall be monitored and reported. SS waits for 8 seconds for the reception of MEASUREMENT REPORT message.                                                                                      |
| 9    |           | →  | MEASUREMENT REPORT                                         | UE shall transmit this message to report cell 4's CPICH RSCP value.                                                                                                                                                                      |
| 10   |           | ←  | PHYSICAL CHANNEL RECONFIGURATION                           | SS configures common physical channels.                                                                                                                                                                                                  |
| 11   |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE                  | UE shall move to CELL_FACH state.                                                                                                                                                                                                        |
| 12   |           | ←  | Master Information Block, System Information Block type 11 | SS modifies MIB and SIB 11. Cell 4 is included in the IE "inter-frequency cell info"                                                                                                                                                     |
| 13   |           | ←  | SYSTEM INFORMATION CHANGE INDICATION                       | SS waits for 8 seconds to verify that no MEASUREMENT REPORT messages are detected on the uplink DCCH.                                                                                                                                    |
| 14   |           |    |                                                            | SS changes the power settings for cell 1 and cell 4 according to columns marked "T1" of table 8.4.1.6-1, and then waits for [x] seconds to allow the UE to re-select to a new cell.                                                      |
| 15   |           | →  | CELL UPDATE                                                | UE shall perform cell re-selection and transmit this message on the new cell.                                                                                                                                                            |
| 16   |           | ←  | CELL UPDATE CONFIRM                                        |                                                                                                                                                                                                                                          |

NOTE:—The value [x] seconds is to be calculated from TS 25.133 clause 5.5.2. The maximum allowable time for cell re-selection duration is governed by the requirements in TS 25.304 and TS 25.133.

## Specific Message Content

### System Information Block Type 11 (Step 1)

| Information Element                                  | Value/Remark |
|------------------------------------------------------|--------------|
| References to other system information blocks        | Not Present  |
| FACH measurement occasion info                       |              |
| — FACH Measurement occasion cycle length coefficient | 2            |
| — Inter-frequency FDD measurement indicator          | FALSE        |
| — Inter-frequency TDD measurement indicator          | FALSE        |
| — Inter-RAT measurement indicators                   | Not Present  |
| Measurement control system information               |              |
| — Intra-frequency measurement system information     | Not Present  |
| — Inter-frequency measurement system information     | Not Present  |
| — Inter-RAT measurement system information           | Not Present  |
| — Traffic volume measurement system information      | Not Present  |
| — UE Internal measurement system information         | Not Present  |

### RRC CONNECTION SETUP (Step 4)

Use the same message sub-type found in Clause 9 of TS 34.108, which is entitled "Transition to CELL\_DCH"

### PHYSICAL CHANNEL RECONFIGURATION (Step 6)

Use the same message sub-type found in Annex A, which is entitled "(Packet to CELL\_DCH from CELL\_DCH in PS)", with the following exceptions in the IE(s) concerned:

| Information Element                                          | Value/Remarks                           |
|--------------------------------------------------------------|-----------------------------------------|
| Downlink information common for all radio links              |                                         |
| → Downlink DPCH info common for all RL                       |                                         |
| → Timing Indication                                          | Maintain                                |
| → Downlink DPCH power control information                    |                                         |
| → DPC mode                                                   | 0 (Single)                              |
| → CHOICE Mode                                                | FDD                                     |
| → Power offset PPilot-DPDCH                                  | 0                                       |
| → DL rate matching restriction information                   | Not Present                             |
| → Spreading factor                                           | Refer to the parameter set in TS 34.108 |
| → Fixed or flexible position                                 | Flexible                                |
| → TFCI existence                                             | FALSE                                   |
| → Number of bits for Pilot bits (SF=128, 256)                | Not Present                             |
| → DPCH compressed mode info                                  |                                         |
| → TGPSI                                                      | 1                                       |
| → TGPS Status Flag                                           | Active                                  |
| → TGCFN                                                      | (Current CFN+(256—TTI/10msec)) mod 256  |
| → Transmission gap pattern sequence configuration parameters |                                         |
| → TGMP                                                       | FDD Measurement                         |
| → TGPRC                                                      | 62                                      |
| → TGSN                                                       | 4                                       |
| → TGL1                                                       | 7                                       |
| → TGL2                                                       | Not Present                             |
| → TGD                                                        | 0                                       |
| → TGPL1                                                      | 3                                       |
| → TGPL2                                                      | Not Present                             |
| → RPP                                                        | Mode 0                                  |
| → ITP                                                        | Mode 0                                  |
| → CHOICE UL/DL Mode                                          | UL and DL                               |
| → Downlink compressed mode method                            | SF/2                                    |
| → Uplink compressed mode method                              | SF/2                                    |
| → Downlink frame type                                        | B                                       |
| → DeltaSIR1                                                  | 2.0                                     |
| → DeltaSIRAfter1                                             | 1.0                                     |
| → DeltaSIR2                                                  | Not Present                             |
| → DeltaSIRAfter2                                             | Not Present                             |
| → N identify abort                                           | Not Present                             |
| → T Reconfirm abort                                          | Not Present                             |
| → TX Diversity Mode                                          | None                                    |
| → SSDT information                                           | Not Present                             |
| → Default DPCH Offset Value                                  | 0                                       |

## MEASUREMENT CONTROL (Step 8)

| Information Element                                    | Value/Remark                                                                                                                  |
|--------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Measurement Identity                                   | 15                                                                                                                            |
| Measurement Command                                    | Setup                                                                                                                         |
| Measurement Reporting Mode                             |                                                                                                                               |
| — Measurement Reporting Transfer Mode                  | Acknowledged Mode RLC                                                                                                         |
| — Periodic Reporting / Event Trigger Reporting Mode    | Periodical Reporting                                                                                                          |
| Additional measurements list                           | Not Present                                                                                                                   |
| CHOICE measurement type                                | Inter-frequency measurement                                                                                                   |
| — Inter-frequency cell info list                       |                                                                                                                               |
| — CHOICE inter-frequency cell removal                  | No inter-frequency cells removed                                                                                              |
| — New inter-frequency info list                        |                                                                                                                               |
| — Inter-frequency cell id                              | 4                                                                                                                             |
| — Frequency info                                       |                                                                                                                               |
| — UARFCN uplink (Nu)                                   | UARFCN of the uplink frequency for cell 4                                                                                     |
| — UARFCN downlink (Nd)                                 | UARFCN of the downlink frequency for cell 4                                                                                   |
| — Cell info                                            |                                                                                                                               |
| — Cell individual offset                               | 0 dB                                                                                                                          |
| — Reference time difference to cell                    | 0 chips                                                                                                                       |
| — Read SFN Indicator                                   | FALSE                                                                                                                         |
| — CHOICE Mode                                          | FDD                                                                                                                           |
| — Primary CPICH Info                                   |                                                                                                                               |
| — Primary Scrambling Code                              | Set to same code as used for cell 4                                                                                           |
| — Primary CPICH TX power                               | Not Present                                                                                                                   |
| — TX Diversity Indicator                               | FALSE                                                                                                                         |
| — Cells for measurement                                |                                                                                                                               |
| — Inter-frequency cell id                              | 4                                                                                                                             |
| — Inter-frequency measurement quantity                 |                                                                                                                               |
| — CHOICE reporting criteria                            | Inter-frequency reporting criteria                                                                                            |
| — Filter Coefficient                                   | 0                                                                                                                             |
| — Measurement quantity for frequency quality estimate  | CPICH RSCP                                                                                                                    |
| — Inter-frequency reporting quantity                   |                                                                                                                               |
| — UTRA Carrier RSSI                                    | FALSE                                                                                                                         |
| — Frequency quality estimate                           | FALSE                                                                                                                         |
| — Non-frequency related cell reporting quantities      |                                                                                                                               |
| — SFN-SFN observed time difference reporting indicator | No report                                                                                                                     |
| — Cell synchronisation information reporting indicator | FALSE                                                                                                                         |
| — Cell Identity reporting indicator                    | FALSE                                                                                                                         |
| — CPICH Ec/No reporting indicator                      | FALSE                                                                                                                         |
| — CPICH RSCP reporting indicator                       | TRUE                                                                                                                          |
| — Pathloss reporting indicator                         | FALSE                                                                                                                         |
| — Reporting cell status                                |                                                                                                                               |
| — CHOICE reported cell                                 | Report cells within active and/or monitored set on used frequency or within active and/or monitored set on non-used frequency |
| — Maximum number of reported cells                     | 2                                                                                                                             |
| — Measurement validity                                 |                                                                                                                               |
| — UE state                                             | CELL_DCH                                                                                                                      |
| — Inter-frequency set update                           | Not Present                                                                                                                   |
| — CHOICE report criteria                               | Periodic reporting criteria                                                                                                   |
| — Amount of reporting                                  | Infinity                                                                                                                      |
| — Reporting interval                                   | 8 seconds                                                                                                                     |
| DPCH compressed mode status info                       | Not Present                                                                                                                   |

## MEASUREMENT REPORT (Step 9)

| Information Element                         | Value/Remarks                                                          |
|---------------------------------------------|------------------------------------------------------------------------|
| Measurement identity                        | Check to see if set to 15                                              |
| Measured Results                            |                                                                        |
| —— CHOICE measurement                       | Check to see if set to "Inter-frequency measured results list"         |
| —— Inter-frequency measurement results      |                                                                        |
| —— Frequency info                           |                                                                        |
| —— UARFCN (uplink)                          | Check to see if set to the UARFCN of the uplink frequency for cell 4   |
| —— UARFCN (downlink)                        | Check to see if set to the UARFCN of the downlink frequency for cell 4 |
| —— UTRA carrier RSSI                        | Check to see if it is absent                                           |
| —— Inter-frequency cell measurement results |                                                                        |
| —— Cell measured results                    |                                                                        |
| —— Cell Identity                            | Check to see if it is absent                                           |
| —— SFN-SFN observed time difference         | Check to see if it is absent                                           |
| —— Cell synchronisation information         | Check to see if it is absent                                           |
| —— Primary CPICH Info                       |                                                                        |
| —— Primary Scrambling Code                  | Check to see if set to the same code for cell 4                        |
| —— CPICH Ec/No                              | Check to see if it is absent                                           |
| —— CPICH RSCP                               | Check to see if it is present                                          |
| —— Pathloss                                 | Check to see if it is absent                                           |
| Measured Results on RACH                    | Check to see if it is absent                                           |
| Event Results                               | Check to see if it is absent                                           |

## PHYSICAL CHANNEL RECONFIGURATION (Step 10)

Use the same message sub-type found in Annex A, which is entitled "(Packet to CELL\_FACH from CELL\_DCH in PS)".

## Master Information Block (Step 12)

| Information Element | Value/Remarks |
|---------------------|---------------|
| MIB value tag       | 2             |



## System Information Block type 11 (Step 12)

| Information Element                            | Value/Remarks                        |
|------------------------------------------------|--------------------------------------|
| Measurement control system information         |                                      |
| Use of HCS                                     | Not used                             |
| Cell selection and reselection quality measure | CPICH_Ec/No                          |
| Intra-frequency measurement system information | Not Present                          |
| Inter-frequency measurement system information |                                      |
| Inter-frequency cell info list                 |                                      |
| CHOICE Inter-frequency cell removal            | No inter-frequency cells removed     |
| New inter-frequency cells                      |                                      |
| Inter-frequency cell id                        | 4                                    |
| Frequency info                                 |                                      |
| CHOICE mode                                    | FDD                                  |
| UARFCN uplink (Nu)                             | Set to uplink UARFCN for cell 4      |
| UARFCN downlink (Nd)                           | Set to downlink UARFCN for cell 4    |
| Cell info                                      |                                      |
| Cell individual offset                         | Not Present                          |
| Reference time difference to cell              | Not Present                          |
| Read SFN indicator                             | FALSE                                |
| CHOICE Mode                                    | FDD                                  |
| Primary CPICH info                             |                                      |
| Primary scrambling code                        | Set to the scrambling code of cell 4 |
| Primary CPICH Tx power                         | Not Present                          |
| TX diversity indicator                         | FALSE                                |
| Cells for measurement                          | Not Present                          |
| Cell selection and re-selection info           | Not Present                          |
| Inter-RAT measurement system information       | Not Present                          |
| Traffic volume measurement system information  | Not Present                          |
| UE Internal measurement system information     | Not Present                          |

## SYSTEM INFORMATION CHANGE INDICATION (Step 13)

| Information Element    | Value/Remarks |
|------------------------|---------------|
| BCCH modification info |               |
| MIB Value tag          | 2             |

## CELL UPDATE (Step 15)

| Information Element        | Value/Remarks                                      |
|----------------------------|----------------------------------------------------|
| U-RNTI                     | Check to see if same to value assigned in P3 or P5 |
| Cell update cause          | Check to see if it is set to "Cell Reselection"    |
| Protocol error info        | Check to see if it is absent or set to FALSE       |
| Measured results on RACH   | Check to see if it is absent                       |
| Protocol error information | Check to see if it is absent                       |

## CELL UPDATE CONFIRM (Step 16)

Use the same message sub-type found in Annex A.

## 8.4.1.6.5 Test Requirement

After step 8 the UE shall transmit MEASUREMENT REPORT message to report cell 4's RSCP value in the IE "inter-frequency cell measured results".

After step 11 the UE shall stop sending MEASUREMENT REPORT messages, which contain inter-frequency measured results for cell 4's CPICH RSCP value.

After step 14 the UE shall transmit CELL\_UPDATE message on the uplink CCCH of cell 4, and the "cell update cause" IE shall be set to "cell reselection".

#### ~~8.4.1.7 Measurement Control and Report: Intra-frequency measurement for transition from CELL\_FACH to CELL\_DCH state~~

##### ~~8.4.1.7.1 Definition~~

##### ~~8.4.1.7.2 Conformance requirement~~

After transiting from CELL\_FACH state to CELL\_DCH state, the UE shall retrieve each set of measurement control information of measurement type "intra-frequency", if the measurement control information has "measurement validity" IE set to "CELL\_DCH". If the UE has performed a cell reselection whilst out of CELL\_DCH state and that the cell reselection has occurred after the storage of measurement control information, the UE shall delete the stored intra-frequency measurement information.

If the UE has no stored intra-frequency measurements applicable to CELL\_DCH state, it shall continue to monitor the list of cells in IE "intra-frequency cell info" stated in System Information Block type 11 or 12 messages. It shall transmit MEASUREMENT REPORT messages when the reporting criteria in IE "intra-frequency measurement reporting criteria" in System Information Block type 11 or 12 messages are fulfilled. When in CELL\_DCH state, the UE shall override existing measurement and reporting contexts obtained from System Information Block type 11 or 12 messages, if a MEASUREMENT CONTROL message is received. The UE shall start to use the new measurement and reporting parameters received in the MEASUREMENT CONTROL message.

#### Reference

3GPP TS 25.331, clause 8.4.1.7.1

##### ~~8.4.1.7.3 Test Purpose~~

To confirm that UE retrieves stored measurement control information for intra-frequency measurement measurement type with "measurement validity" assigned to "CELL\_DCH", after it enters CELL\_DCH state from CELL\_FACH state. To confirm that the UE continues to monitor the neighbouring cells listed "intra-frequency cell info" IE in the System Information Block type 11 or 12 messages, if no intra-frequency measurements applicable to CELL\_DCH are stored. To confirm that the UE transmits MEASUREMENT REPORT messages if reporting criteria stated in IE "intra-frequency measurement reporting criteria" in System Information Block type 11 or 12 messages are fulfilled. To confirm that a MEASUREMENT CONTROL message received in CELL\_DCH state overrides the measurement and associated reporting contexts maintained in the UE by virtue of System Information Block type 11 or 12 messages.

##### ~~8.4.1.7.4 Method of test~~

#### ~~Initial Condition~~

System Simulator: 3 cells—Cell 1, cell 2 and cell 3 are active.

UE: PS-DGCH+DTCH\_FACH (state 6-11).

#### Test Procedure

Table 8.4.1.7-1 illustrates the downlink power to be applied for the 3 cells at various time instants of the test execution. Column marked "T0" denotes the initial conditions, while columns marked "T1" are to be applied subsequently. The exact instants on which these values shall be applied are described in the text in this clause.

Table 8.4.1.7-1

| Para-meter                   | Unit                | Cell-1 |      | Cell-2 |     | Cell-3 |     |
|------------------------------|---------------------|--------|------|--------|-----|--------|-----|
|                              |                     | T0     | T1   | T0     | T1  | T0     | T1  |
| UTRA-RF<br>Channel<br>Number |                     | Ch. 1  |      | Ch. 1  |     | Ch. 1  |     |
| CPICH-Ec                     | dBm<br>/3.84<br>MHz | -60    | -122 | -70    | -60 | -80    | -80 |

The UE is brought to CELL\_FACH state in cell 1. System Information Block type 12 message is changed with respect to the default message contents, with cell 2 included in the IE "intra-frequency cell info". Event 1e is selected in IE "Reporting information for state CELL\_DCH", and "Intra-frequency measurement quantity" is set to CPICH RSCP.

SS send a RADIO BEARER RECONFIGURATION message to UE, and configures dedicated physical channels on both uplink and downlink directions. The UE shall move to CELL\_DCH state and then return RADIO BEARER RECONFIGURATION COMPLETE message. The UE shall send MEASUREMENT REPORT messages containing IE "Measured results" to report cell 2's CPICH RSCP value and IE "event results" to report triggering of event type "1e". After receiving the MEASUREMENT REPORT messages, SS transmits a MEASUREMENT CONTROL message with only cell 3 included in the IE "intra-frequency cell info" and IE "CHOICE reporting criteria" set to "periodic reporting". After receiving such a message, the UE shall transmit another set of MEASUREMENT REPORT messages. SS verifies that only measurement readings for cell 3's CPICH RSCP are report in IE "cell measured results" in these messages.

Next, SS sends PHYSICAL CHANNEL RECONFIGURATION message. SS configures common physical channels for both the uplink and the downlink directions. The UE shall transit to CELL\_FACH state and then reply with a PHYSICAL CHANNEL RECONFIGURATION COMPLETE. SS waits for 16 seconds and checks the uplink RACH to confirm that no MEASUREMENT REPORT messages are received. SS transmits MEASUREMENT CONTROL message on the downlink DCCH. The key parameters specified in this message are: measurement command = 'setup', measurement type = 'intra-frequency measurement', measurement object = 'cell 2', reporting criteria = 'periodic reporting', measurement validity IE is present and "UE state" = "CELL\_DCH". SS waits for 16 seconds, verifies that no MEASUREMENT REPORT messages are detected on the uplink DCCH. SS sends RADIO BEARER RECONFIGURATION message and configures dedicated physical channels. The UE shall return to CELL\_DCH state, transmit a RADIO BEARER RECONFIGURATION COMPLETE message and start to monitor cell 2. The UE shall also resume periodic reporting of cell 2's CPICH RSCP measured results by sending MEASUREMENT REPORT messages. Following the reception of the MEASUREMENT REPORT message, SS commands the UE using MEASUREMENT CONTROL message to release measurement control information stored in "measurement identity" = 12. Thereafter, SS verifies that no MEASUREMENT REPORT messages are detected on the uplink DCCH. After this requirement is satisfied, SS sends MEASUREMENT CONTROL on the downlink DCCH once more. This message is identical to the one sent in step 5 (see specific message content).

SS transmits a PHYSICAL CHANNEL RECONFIGURATION message on the downlink DCCH and configures common physical channel. The UE shall transit to CELL\_FACH state and then respond with a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message. SS monitor the uplink DCCH once more to verify that no MEASUREMENT REPORT messages are detected. SS modifies the contents of Master Information Block and System Information Block type 12 messages, and then send SYSTEM INFORMATION CHANGE INDICATION message to UE. This is followed by a reconfiguration of the downlink transmission power of the respect cells according to the settings in columns "T1" in table 8.4.1.7-1. SS starts timer T305 and then waits for it to expire. The UE shall discover an "out-of-service" condition and initiate a cell re-selection procedure. This is verified in the SS when a CELL UPDATE message is received on the uplink CCCH with the "cell update cause" IE set to "cell reselection". SS transmits a CELL UPDATE CONFIRM message on the DCCH to end the cell update procedure. Next, SS sends a RADIO BEARER RECONFIGURATION message on the downlink DCCH, assigning dedicated physical channels in both uplink and downlink directions. The UE shall respond with a RADIO BEARER RECONFIGURATION COMPLETE message and then return to CELL\_DCH state. SS checks that the UE does not generate any MEASUREMENT REPORT messages on the uplink DCCH.

## Expected Sequence

| Step | Direction |    | Message                                   | Comment                                                                                                                                                                                                                       |
|------|-----------|----|-------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                                                                                                               |
| 1    |           | ←  | System Information Block type 12          | UE is initially in PS-DCCCH+DTCH_FACH (state 6-11) in cell 1. System Information Block type 12 messages are changed with respect to the default contents according to the descriptions in "Specific Message Contents" clause. |
| 2    |           | ←  | RADIO BEARER RECONFIGURATION              | SS configures dedicated physical channels.                                                                                                                                                                                    |
| 3    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE     | UE shall move to CELL_DCH state.                                                                                                                                                                                              |
| 4    |           | →  | MEASUREMENT REPORT                        | Reports cell 2's CPICH RSCP measurement value.                                                                                                                                                                                |
| 5    |           | ←  | MEASUREMENT CONTROL                       | Only cell 3 is included in the IE "intra-frequency cell info".                                                                                                                                                                |
| 6    |           | →  | MEASUREMENT REPORT                        | UE shall report cell 3's CPICH RSCP reading in IE "cell measured results".                                                                                                                                                    |
| 7    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | SS configures PRACH and S-CCPCH physical channels.                                                                                                                                                                            |
| 8    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE | UE shall move to CELL_FACH state.                                                                                                                                                                                             |
| 9    |           |    |                                           | SS waits for 16 seconds and checks that no MEASUREMENT REPORT messages are sent by UE.                                                                                                                                        |
| 10   |           | ←  | MEASUREMENT CONTROL                       | SS instructs the UE to setup intra-frequency measurement and reporting for cell 2. Measurement validity IE is set to CELL_DCH state.                                                                                          |
| 11   |           |    |                                           | SS waits for 16 seconds and verifies that no MEASUREMENT REPORT messages are sent by UE.                                                                                                                                      |
| 12   |           | ←  | RADIO BEARER RECONFIGURATION              | SS configures dedicated physical channels.                                                                                                                                                                                    |
| 13   |           | →  | RADIO BEARER RECONFIGURATION COMPLETE     | UE shall return to CELL_DCH state.                                                                                                                                                                                            |
| 14   |           | →  | MEASUREMENT REPORT                        | UE begins to report cell 2's measured results for CPICH RSCP.                                                                                                                                                                 |
| 15   |           | ←  | MEASUREMENT CONTROL                       | Terminate all the intra-frequency measurement and reporting activities related to "measurement identity" = 12.                                                                                                                |
| 16   |           |    |                                           | SS waits for 16 seconds and verifies that UE stop transmitting MEASUREMENT REPORT messages.                                                                                                                                   |
| 17   |           | ←  | MEASUREMENT CONTROL                       | This message is the same as in step 5                                                                                                                                                                                         |
| 18   |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | Allocates common physical channels.                                                                                                                                                                                           |
| 19   |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE | UE shall move to CELL_FACH state.                                                                                                                                                                                             |
| 20   |           |    |                                           | SS checks that no MEASUREMENT REPORT messages are received.                                                                                                                                                                   |

| Step | Direction |    | Message                                                      | Comment                                                                                                                                                                         |
|------|-----------|----|--------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                                 |
| 21   |           | ←  | Master Information Block<br>System Information Block type 12 | System Information Block type 12 messages are modified to include cell 2 and cell 3 into neighbouring cells list for intra-frequency type measurements.                         |
| 21a  |           | ←  | SYSTEM INFORMATION CHANGE INDICATION                         | SS reconfigures the downlink transmission power settings for cell 1 to cell 3 according to columns "T1" in table 8.4.1.7-1, runs timer T305, and then waits until T305 expires. |
| 22   |           | →  | CELL UPDATE                                                  | UE shall re-selects to cell 2 and then perform a cell update procedure.                                                                                                         |
| 23   |           | ←  | CELL UPDATE CONFIRM                                          | UE shall stay in CELL_FACH state.                                                                                                                                               |
| 24   |           | →  | RADIO BEARER RECONFIGURATION                                 | Dedicated physical channels are assigned to the UE in this message.                                                                                                             |
| 25   |           | ←  | RADIO BEARER RECONFIGURATION COMPLETE                        | UE shall return to CELL_DCH state.                                                                                                                                              |
| 26   |           |    |                                                              | SS checks that no MEASUREMENT REPORT messages are received on uplink DCCH.                                                                                                      |

## Specific Message Content

## System Information Block type 12 (Step 1)

| Information Element                                    | Value/Remark                                   |
|--------------------------------------------------------|------------------------------------------------|
| FACH measurement occasion info                         | Not Present                                    |
| Measurement control system information                 |                                                |
| — Intra-frequency measurement system information       |                                                |
| — Intra-frequency measurement identity                 | 10                                             |
| — Intra-frequency cell info list                       |                                                |
| — CHOICE intra-frequency cell removal                  | Remove no intra-frequency cells                |
| — New intra-frequency info list                        |                                                |
| — Intra-frequency cell id                              | 2                                              |
| — Cell info                                            |                                                |
| — Cell individual offset                               | 0 dB                                           |
| — Reference time difference to cell                    | 0 chips                                        |
| — Read SFN Indicator                                   | FALSE                                          |
| — CHOICE mode                                          | FDD                                            |
| — Primary CPICH Info                                   |                                                |
| — Primary Scrambling Code                              | Set to same code as used for cell 2            |
| — Primary CPICH TX power                               | Not Present                                    |
| — TX Diversity Indicator                               | FALSE                                          |
| — Cell selection and Re-selection info                 | Not Present                                    |
| — Cells for measurement                                | Not Present                                    |
| — Intra-frequency measurement quantity                 | 0                                              |
| — Filter Coefficient                                   | CPICH RSCP                                     |
| — Measurement quantity                                 | Not Present                                    |
| — Intra-frequency measurement for RACH reporting       | No report                                      |
| — Maximum number of reported cells on RACH             |                                                |
| — Reporting information for state CELL_DCH             |                                                |
| — Intra-frequency reporting quantity                   |                                                |
| — Reporting quantities for active set cells            | No report                                      |
| — SFN-SFN observed time difference reporting indicator | FALSE                                          |
| — Cell synchronisation information reporting indicator | FALSE                                          |
| — Cell identity reporting indicator                    | FALSE                                          |
| — CPICH Ec/No reporting indicator                      | FALSE                                          |
| — CPICH RSCP reporting indicator                       | FALSE                                          |
| — Pathloss reporting indicator                         |                                                |
| — Reporting quantities for monitored set cells         | No report                                      |
| — SFN-SFN observed time difference reporting indicator | FALSE                                          |
| — Cell synchronisation information reporting indicator | TRUE                                           |
| — Cell identity reporting indicator                    | FALSE                                          |
| — CPICH Ec/No reporting indicator                      | TRUE                                           |
| — CPICH RSCP reporting indicator                       | FALSE                                          |
| — Pathloss reporting indicator                         | Not present                                    |
| — Reporting quantities for detected cells              | Intra-frequency measurement reporting criteria |
| — CHOICE report criteria                               |                                                |
| — Parameter required for each event                    | 1e                                             |
| — Intra-frequency event identity                       | Not Present                                    |
| — Triggering condition 1                               | Monitored set cells                            |
| — Triggering condition 2                               | Not present                                    |
| — Reporting range                                      | Not present                                    |
| — Cells forbidden to affect reporting                  | FDD                                            |
| — CHOICE Mode                                          |                                                |
| — Primary CPICH Info                                   |                                                |
| — Primary scrambling code                              | Set to the scrambling code of cell 2           |
| — W                                                    | Not present                                    |
| — Hysteresis                                           | 0 dB                                           |
| — Threshold used frequency                             | -80 dBm                                        |
| — Reporting deactivation threshold                     | Not present                                    |
| — Replacement activation threshold                     | Not present                                    |

| Information Element                            | Value/Remark                                              |
|------------------------------------------------|-----------------------------------------------------------|
| Time to trigger                                | 0                                                         |
| Amount of reporting                            | Infinity                                                  |
| Reporting Interval                             | 16 seconds                                                |
| Reporting cell status                          |                                                           |
| CHOICE reported cells                          | Report cells within monitored set cells on used frequency |
| Maximum number of reported cells               | 1                                                         |
| Inter-frequency measurement system information | Not Present                                               |
| Inter-RAT measurement system information       | Not Present                                               |
| Traffic volume measurement system information  | Not Present                                               |
| UE internal measurement system information     | Not Present                                               |

## RADIO BEARER RECONFIGURATION (Step 2, Step 12 and Step 24)

Use the same message type found in Annex A, with condition set to A4.

## MEASUREMENT REPORT (Step 4)

| Information Element                 | Value/Remarks                                                           |
|-------------------------------------|-------------------------------------------------------------------------|
| Measurement identity                | Check to see if set to 10                                               |
| Measured Results                    |                                                                         |
| CHOICE measurement                  | Check to see if set to "Intra-frequency measured results list"          |
| Intra-frequency measurement results |                                                                         |
| Cell measured results               |                                                                         |
| Cell Identity                       | Check to see if it is present and set to cell identity of cell 2        |
| SFN-SFN observed time difference    | Check to see if this IE is absent                                       |
| Cell synchronisation information    | Check to see if this IE is absent                                       |
| Primary CPICH Info                  |                                                                         |
| Primary Scrambling Code             | Check to see if it's the same code for cell 2                           |
| CPICH Ec/No                         | Check to see if this IE is absent                                       |
| CPICH RSCP                          | Check to see if this IE is present                                      |
| Pathloss                            | Check to see if this IE is absent                                       |
| Measured Results on RACH            | Check to see if this IE is absent                                       |
| Additional measured results         | Check to see if this IE is absent                                       |
| Event Results                       |                                                                         |
| CHOICE event result                 | Check to see if it's set to 'Intra-frequency measurement event results' |
| Intra-frequency event identity      | Check to see if this IE is set to '1e'                                  |
| Cell measurement event results      |                                                                         |
| Primary CPICH info                  |                                                                         |
| Primary scrambling code             | Check to see if it's the same code for cell 2                           |

## MEASUREMENT CONTROL (Step 5 and Step 17)

| Information Element                                    | Value/Remark                               |
|--------------------------------------------------------|--------------------------------------------|
| Measurement Identity                                   | 10                                         |
| Measurement Command                                    | Setup                                      |
| Measurement Reporting Mode                             |                                            |
| — Measurement Reporting Transfer Mode                  | Acknowledged Mode RLC                      |
| — Periodic Reporting / Event Trigger Reporting Mode    | Event Trigger                              |
| Additional measurements list                           | Not Present                                |
| CHOICE measurement type                                | Intra-frequency measurement                |
| — Intra-frequency cell info list                       |                                            |
| — CHOICE intra-frequency cell removal                  | Remove no intra-frequency cells            |
| — New intra-frequency info list                        |                                            |
| — Intra-frequency cell id                              | 3                                          |
| — Cell info                                            |                                            |
| — Cell individual offset                               | 0 dB                                       |
| — Reference time difference to cell                    | 0 chips                                    |
| — Read SFN Indicator                                   | FALSE                                      |
| — CHOICE mode                                          | FDD                                        |
| — Primary CPICH Info                                   |                                            |
| — Primary Scrambling Code                              | Set to same code as used for cell 3        |
| — Primary CPICH TX power                               | Not Present                                |
| — TX Diversity Indicator                               | FALSE                                      |
| — Cells selection and Re-selection info                | Not Present                                |
| — Cells for measurement                                |                                            |
| — Intra-frequency cell id                              | 3                                          |
| — Intra-frequency measurement quantity                 |                                            |
| — Filter Coefficient                                   | 0                                          |
| — Measurement quantity                                 | CPICH RSCP                                 |
| — Intra-frequency reporting quantity                   |                                            |
| — Reporting quantities for active set cells            |                                            |
| — SFN-SFN observed time difference reporting indicator | No report                                  |
| — Cell synchronisation information reporting indicator | FALSE                                      |
| — Cell identity reporting indicator                    | FALSE                                      |
| — CPICH Ec/No reporting indicator                      | FALSE                                      |
| — CPICH RSCP reporting indicator                       | FALSE                                      |
| — Pathloss reporting indicator                         | FALSE                                      |
| — Reporting quantities for monitored set cells         |                                            |
| — SFN-SFN observed time difference reporting indicator | No report                                  |
| — Cell synchronisation information reporting indicator | FALSE                                      |
| — Cell identity reporting indicator                    | TRUE                                       |
| — CPICH Ec/No reporting indicator                      | FALSE                                      |
| — CPICH RSCP reporting indicator                       | TRUE                                       |
| — Pathloss reporting indicator                         | FALSE                                      |
| — Reporting quantities for detected cells              | Not present                                |
| — Reporting cell status                                | Not present                                |
| — Measurement validity                                 | Not present                                |
| — CHOICE report criteria                               | Intra-frequency measurement criteria       |
| — Parameters required for each event                   |                                            |
| — Intra-frequency event identity                       | 1e                                         |
| — Triggering condition 1                               | Not Present                                |
| — Triggering condition 2                               | Monitored set cells                        |
| — Reporting Range                                      | Not Present                                |
| — Cells forbidden to affect Reporting range            | Not Present                                |
| — CHOICE Mode                                          | FDD                                        |
| — Primary CPICH Info                                   |                                            |
| — Primary Scrambling Code                              | Set to the same scrambling code for cell 3 |
| — W                                                    | Not Present                                |
| — Hysteresis                                           | 0 dB                                       |
| — Reporting deactivation threshold                     | Not Present                                |
| — Replacement activation threshold                     | Not Present                                |
| — Threshold used frequency                             | -90 dBm                                    |
| — Time to Trigger                                      | 0                                          |



| Information Element                | Value/Remark                                              |
|------------------------------------|-----------------------------------------------------------|
| → Amount of reporting              | Infinity                                                  |
| → Reporting interval               | 16 seconds                                                |
| → Reporting cell status            |                                                           |
| → CHOICE reported cells            | Report cells within monitored set cells on used frequency |
| → Maximum number of reported cells | 1                                                         |
| DPCH compressed mode status info   | Not Present                                               |

#### MEASUREMENT REPORT (Step 6)

| Information Element                   | Value/Remarks                                                           |
|---------------------------------------|-------------------------------------------------------------------------|
| Measurement identity                  | Check to see if set to 10                                               |
| Measured Results                      |                                                                         |
| → CHOICE measurement                  | Check to see if set to "Intra-frequency measured results list"          |
| → Intra-frequency measurement results |                                                                         |
| → Cell measured results               |                                                                         |
| → Cell Identity                       | Check to see if it is present and set to cell identity of cell 3        |
| → SFN-SFN observed time difference    | Check to see if this IE is absent                                       |
| → Cell synchronisation information    | Check to see if this IE is absent                                       |
| → Primary CPICH Info                  |                                                                         |
| → Primary Scrambling Code             | Check to see if it's the same code for cell 3                           |
| → CPICH Ec/No                         | Check to see if this IE is absent                                       |
| → CPICH RSCP                          | Check to see if this IE is present                                      |
| → Pathloss                            | Check to see if this IE is absent                                       |
| Measured Results on RACH              | Check to see if this IE is absent                                       |
| Additional measured results           | Check to see if this IE is absent                                       |
| Event Results                         | Check to see if it's set to 'Intra-frequency measurement event results' |
| → CHOICE event result                 | Check to see if this IE is set to '1e'                                  |
| → Intra-frequency event identity      |                                                                         |
| → Cell measurement event results      |                                                                         |
| → Primary CPICH info                  | Check to see if it's the same code for cell 3                           |
| → Primary scrambling code             |                                                                         |

#### PHYSICAL CHANNEL RECONFIGURATION (Step 7 and 18)

Use the same message sub-type found in Annex A, which is entitled "Packet to CELL\_FACH from CELL\_DCH in PS".

## MEASUREMENT CONTROL (Step 10)

| Information Element                                  | Value/Remark                               |
|------------------------------------------------------|--------------------------------------------|
| Measurement Identity                                 | 12                                         |
| Measurement Command                                  | Setup                                      |
| Measurement Reporting Mode                           |                                            |
| Measurement Reporting Transfer Mode                  | Acknowledged Mode RLC                      |
| Periodic Reporting / Event Trigger Reporting Mode    | Event Trigger                              |
| Additional measurements list                         | Not Present                                |
| CHOICE measurement type                              | Intra-frequency measurement                |
| Intra-frequency cell info list                       |                                            |
| CHOICE intra-frequency cell removal                  | Remove no intra-frequency cells            |
| New intra-frequency info list                        |                                            |
| Intra-frequency cell id                              | 2                                          |
| Cell info                                            |                                            |
| Cell individual offset                               | 0 dB                                       |
| Reference time difference to cell                    | 0 chips                                    |
| Read SFN Indicator                                   | FALSE                                      |
| CHOICE Mode                                          | FDD                                        |
| Primary CPICH Info                                   |                                            |
| Primary Scrambling Code                              | Set to same code as used for cell 2        |
| Primary CPICH TX power                               | Not Present                                |
| TX Diversity Indicator                               | FALSE                                      |
| Cell selection and Re-selection info                 | Not Present                                |
| Cells for measurement                                |                                            |
| Intra-frequency cell id                              | cell 2                                     |
| Intra-frequency measurement quantity                 |                                            |
| Filter Coefficient                                   | 0                                          |
| Measurement quantity                                 | CPICH RSCP                                 |
| Intra-frequency reporting quantity                   |                                            |
| Reporting quantities for active set cells            |                                            |
| SFN-SFN observed time difference reporting indicator | No report                                  |
| Cell synchronisation information reporting indicator | FALSE                                      |
| Cell identity reporting indicator                    | FALSE                                      |
| CPICH Ec/No reporting indicator                      | FALSE                                      |
| CPICH RSCP reporting indicator                       | FALSE                                      |
| Pathloss reporting indicator                         | FALSE                                      |
| Reporting quantities for monitored set cells         |                                            |
| SFN-SFN observed time difference reporting indicator | No report                                  |
| Cell synchronisation information reporting indicator | FALSE                                      |
| Cell identity reporting indicator                    | TRUE                                       |
| CPICH Ec/No reporting indicator                      | FALSE                                      |
| CPICH RSCP reporting indicator                       | TRUE                                       |
| Pathloss reporting indicator                         | FALSE                                      |
| Reporting quantities for detected cells              | Not present                                |
| Reporting cell status                                | Not present                                |
| Measurement validity                                 |                                            |
| UE state                                             | CELL_DCH                                   |
| CHOICE report criteria                               | Intra-frequency measurement criteria       |
| Parameters required for each event                   |                                            |
| Intra-frequency event identity                       | 1e                                         |
| Triggering condition 1                               | Not Present                                |
| Triggering condition 2                               | Monitored set cells                        |
| Reporting Range                                      | Not Present                                |
| Cells forbidden to affect Reporting range            | Not Present                                |
| Primary CPICH Info                                   |                                            |
| Primary Scrambling Code                              | Set to the same scrambling code for cell 2 |
| W                                                    | Not Present                                |
| Hysteresis                                           | 0 dB                                       |
| Reporting deactivation threshold                     | Not Present                                |
| Replacement activation threshold                     | Not Present                                |
| Threshold Used Frequency                             | -80 dBm                                    |
| Time to Trigger                                      | 0                                          |

| Information Element              | Value/Remark                                              |
|----------------------------------|-----------------------------------------------------------|
| Amount of reporting              | Infinity                                                  |
| Reporting interval               | 16 seconds                                                |
| Reporting cell status            |                                                           |
| CHOICE reported cell             | Report cells within monitored set cells on used frequency |
| Maximum number of reported cells | 1                                                         |
| DPCH compressed mode status info | Not Present                                               |

## MEASUREMENT REPORT (Step 14)

| Information Element                 | Value/Remarks                                                           |
|-------------------------------------|-------------------------------------------------------------------------|
| Measurement identity                | Check to see if set to 12                                               |
| Measured Results                    |                                                                         |
| CHOICE measurement                  | Check to see if set to "Intra-frequency measured results list"          |
| Intra-frequency measurement results |                                                                         |
| Cell measured results               |                                                                         |
| Cell Identity                       | Check to see if it is present and set to cell identity of cell 2        |
| SFN-SFN observed time difference    | Check to see if this IE is absent                                       |
| Cell synchronisation information    | Check to see if this IE is absent                                       |
| Primary CPICH Info                  |                                                                         |
| Primary Scrambling Code             | Check to see if it's the same code for cell 2                           |
| CPICH Ec/No                         | Check to see if this IE is absent                                       |
| CPICH RSCP                          | Check to see if this IE is present                                      |
| Pathloss                            | Check to see if this IE is absent                                       |
| Measured Results on RACH            | Check to see if this IE is absent                                       |
| Additional measured results         | Check to see if this IE is absent                                       |
| Event Results                       |                                                                         |
| CHOICE event result                 | Check to see if it's set to 'Intra-frequency measurement event results' |
| Intra-frequency event identity      | Check to see if this IE is set to '1e'                                  |
| Cell measurement event results      |                                                                         |
| Primary CPICH info                  |                                                                         |
| Primary scrambling code             | Check to see if it's the same code for cell 2                           |

## MEASUREMENT CONTROL (Step 15)

| Information Element              | Value/Remarks |
|----------------------------------|---------------|
| Measurement Identity             | 12            |
| Measurement Command              | Release       |
| Measurement Reporting Mode       | Not Present   |
| Additional measurements list     | Not Present   |
| CHOICE Measurement type          | Not Present   |
| DPCH compressed mode status info | Not Present   |

## Master Information Block (Step 21)

| Information Element | Value/Remarks |
|---------------------|---------------|
| MIB Value Tag       | 2             |

## System Information Block type 12 (Step 21)

| Information Element                                          | Value/Remark                        |
|--------------------------------------------------------------|-------------------------------------|
| FACH measurement occasion info                               | Not Present                         |
| Measurement control system information                       |                                     |
| <del>Use of HCS</del>                                        | Not used                            |
| <del>Cell selection and reselection quality measure</del>    | CPICH_Ec/No                         |
| <del>Intra-frequency measurement system information</del>    |                                     |
| <del>Intra-frequency measurement identity</del>              | 13                                  |
| <del>Intra-frequency cell info list</del>                    | <i>Cell 2 and Cell 3 are added</i>  |
| <del>CHOICE intra-frequency cell removal</del>               | Remove no intra-frequency cells     |
| <del>New intra-frequency info list</del>                     |                                     |
| <del>Intra-frequency cell id</del>                           | Set to id of cell 2                 |
| <del>Cell info</del>                                         |                                     |
| <del>Cell individual offset</del>                            | 0 dB                                |
| <del>Reference time difference to cell</del>                 | 0 chips                             |
| <del>Read SFN Indicator</del>                                | FALSE                               |
| <del>CHOICE Mode</del>                                       | FDD                                 |
| <del>Primary CPICH Info</del>                                |                                     |
| <del>Primary Scrambling Code</del>                           | Set to same code as used for cell 2 |
| <del>Primary CPICH TX power</del>                            | Not Present                         |
| <del>TX Diversity Indicator</del>                            | FALSE                               |
| <del>Cell selection and Re-selection info</del>              | Not Present—use default values      |
| <del>Intra-frequency cell id</del>                           | Set to id of cell 3                 |
| <del>Cell info</del>                                         |                                     |
| <del>Cell individual offset</del>                            | 0 dB                                |
| <del>Reference time difference to cell</del>                 | 0 chips                             |
| <del>Read SFN Indicator</del>                                | FALSE                               |
| <del>CHOICE Mode</del>                                       | FDD                                 |
| <del>Primary CPICH Info</del>                                |                                     |
| <del>Primary Scrambling Code</del>                           | Set to same code as used for cell 3 |
| <del>Primary CPICH TX power</del>                            | Not Present                         |
| <del>TX Diversity Indicator</del>                            | FALSE                               |
| <del>Cell selection and Re-selection info</del>              | Not Present—use default values      |
| <del>Cells for measurement</del>                             | Not Present                         |
| <del>Intra-frequency measurement quantity</del>              |                                     |
| <del>Filter Coefficient</del>                                | 0                                   |
| <del>Measurement quantity</del>                              | CPICH RSCP                          |
| <del>Intra-frequency measurement for RACH reporting</del>    | Not Present                         |
| <del>Maximum number of reported cells on RACH</del>          | No report                           |
| <del>Reporting information for state CELL_DCH</del>          |                                     |
| <del>Intra-frequency reporting quantity</del>                | CPICH RSCP                          |
| <del>Measurement reporting mode</del>                        |                                     |
| <del>Measurement Reporting Transfer Mode</del>               | Acknowledged mode RLC               |
| <del>Periodic Reporting / Event Triggering Report Mode</del> | Periodic Reporting                  |
| <del>CHOICE report criteria</del>                            | Periodical reporting criteria       |
| <del>Amount of reporting</del>                               | Infinity                            |
| <del>Reporting interval</del>                                | 250 msec                            |
| <del>Inter-frequency measurement system information</del>    | Not Present                         |
| <del>Inter-RAT measurement system information</del>          | Not Present                         |
| <del>Traffic volume measurement system information</del>     | Not Present                         |
| <del>UE internal measurement system information</del>        | Not Present                         |

**CELL UPDATE (Step 22)**

| Information Element        | Value/Remarks                                     |
|----------------------------|---------------------------------------------------|
| U-RNTI                     |                                                   |
| -SRNC Identity             | Check to see if set to '0000-0000-0001'           |
| -S-RNTI                    | Check to see if set to '0000-0000-0000-0000-0001' |
| Cell Update Cause          | Check to see if set to 'Cell Re-selection'        |
| Protocol error indicator   | Check to see if it is absent or set to 'FALSE'    |
| Measured results on RACH   | Check to see if it is absent                      |
| Protocol error information | Check to see if it is absent                      |

**CELL UPDATE CONFIRM (Step 23)**

Use the default message content of the same message type in Annex A.

**8.4.1.7.5 Test Requirement**

After step 3 the UE shall report cell 2's CPICH RSCP value by transmitting MEASUREMENT REPORT messages.

After step 5 the UE shall delete all measurement and reporting contexts obtained from System Information Block type 12 messages. It shall transmit MEASUREMENT REPORT messages which contain measured results of cell 3's CPICH RSCP value only

After step 9 and step 11 the UE shall not transmit MEASUREMENT REPORT messages, which pertain to intra-frequency type measurement reporting.

After step 13 the UE shall resume the measurement and reporting activities as specified in MEASUREMENT CONTROL message received in step 10. The UE shall transmit MEASUREMENT REPORT messages, containing measured results of cell 2's CPICH RSCP value.

After step 15 the UE shall stop measurement activities pertaining to periodic reporting of cell 2's CPICH RSCP, no MEASUREMENT REPORT messages shall be detectable by the SS on the uplink DCCH.

After step 21 the UE shall re-select to cell 2 and initiate a cell update procedure. SS shall receive a CELL UPDATE message on the uplink CCCH of cell 2, with the "cell update cause" IE stated as "cell re-selection".

After step 25 the UE shall not resume measurements and any associated reporting activities for cell 3's CPICH RSCP, no MEASUREMENT REPORT messages shall be detectable by the SS in the uplink DCCH.

**8.4.1.8 Measurement Control and Report: Inter-frequency measurement for transition from CELL\_FACH to CELL\_DCH state****8.4.1.8.1 Definition****8.4.1.8.2 Conformance requirement**

When transiting from CELL\_FACH state to CELL\_DCH state, the UE shall stop monitoring the list of cells assigned in the IE "inter-frequency cell info" in System Information Block type 11 or 12 messages. If the UE has stored measurement control information of type "inter-frequency" for which the IE "measurement validity" is present and the IE "UE state for reporting" has been assigned to "CELL\_DCH", it shall resume the stored measurement reporting activities after it has re-entered CELL\_DCH state from CELL\_FACH state. The UE shall activate or deactivate inter-frequency measurements by decoding the "DPCH compressed mode status info" IE in MEASUREMENT CONTROL messages.

**Reference**

3GPP TS 25.331 clause 8.4.1.7.2, 8.4.1.3

### 8.4.1.8.3 Test Purpose

To confirm that the UE stops monitoring the list of cells assigned in the IE "inter-frequency cell info" in System Information Block type 11 or 12 when it transits from CELL\_FACH state to CELL\_DCH state. To confirm that the UE resumes inter-frequency measurements and reporting stored for which the measurement control information has IE "measurement validity" assigned to the value "CELL\_DCH", after it re-enters CELL\_DCH state from CELL\_FACH state. To confirm that the UE resumes inter-frequency measurement and reporting activities after it has received a MEASUREMENT CONTROL message specifying that a stored compressed mode pattern sequence be re-activated.

### 8.4.1.8.4 Method of test

#### Initial Condition

System Simulator: 3 cells—Cells 1, cell 4 and cell 5 are active.

UE: CS-DCCH+DTCH\_DCH (State 6-9) or PS-DCCH+DTCH\_DCH (State 6-10) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE.

#### Test Procedure

Table 8.4.1.8-1 illustrates the downlink power to be applied for the 3 cells in this test.

**Table 8.4.1.8-1**

| Para-meter             | Unit         | Cell 1 | Cell 4 | Cell 5 |
|------------------------|--------------|--------|--------|--------|
| UTRA-RF Channel Number |              | Ch. 1  | Ch. 2  | Ch. 2  |
| CPICH Ec               | dBm/3.84 MHz | -60    | -75    | -75    |

The UE is in CELL\_DCH state in cell 1. SS transmits MEASUREMENT CONTROL message to add cell 5 into the IE "inter-frequency cell info". In the MEASUREMENT CONTROL message, the parameters of the IE "inter-frequency measurement reporting criteria" are as follow: event-triggered with event identity='2c', reporting quantity = "CPICH RSCP", threshold for non-used frequency = '-85 dBm', hysteresis = '1.0dB', time to trigger = '10 seconds', amount of reporting = '1' and reporting interval = '0'. In the same message, IE "Measurement validity" is present and "UE state" is assigned the value 'CELL\_DCH'. SS checks that no MEASUREMENT REPORT messages are detected on the uplink DCCH after it has transmitted the MEASUREMENT CONTROL message.

SS sends a PHYSICAL CHANNEL RECONFIGURATION message on the downlink DCCH and configures PRACH and S-CCPCH physical channels. The UE shall reconfigure itself to receive and transmit using the new common physical channels assigned, and send PHYSICAL CHANNEL RECONFIGURATION COMPLETE on the uplink DCCH. SS modifies the content of Master Information Block and System Information Block type 12 messages, such that cell 4 is added in the list of cells assigned in the IE "inter-frequency cell info". SS transmits SYSTEM INFORMATION CHANGE INDICATION message to UE. Once again, SS verifies that the UE does not transmit MEASUREMENT REPORT messages in the uplink direction.

SS sends PHYSICAL CHANNEL RECONFIGURATION message, and configures dedicated physical. In this message, SS commands the UE to start applying compressed mode mechanism for DPCH. The UE shall move to CELL\_DCH state and then reply with PHYSICAL CHANNEL RECONFIGURATION COMPLETE message. SS waits for 10 seconds. The UE shall transmit 1 MEASUREMENT REPORT message, containing the selected frequency quality estimate (in this case CPICH RSCP) of cell 5. The UE shall also report the triggering of event '2c' in the IE "Event results" of MEASUREMENT REPORT message. SS verifies that this message does not contain measured results for cell 4.

SS transmits a MEASUREMENT CONTROL message on the downlink DCCH using AM-RLC. In this message, SS modifies the measurement control information for measurement identity = "14" and set IE "CHOICE reporting criteria" to "periodic reporting criteria". The UE shall transmit MEASUREMENT REPORT messages at 2 seconds interval. SS transmits a PHYSICAL CHANNEL RECONFIGURATION message and deactivates the compressed mode pattern sequence with "TGPSI" IE set to 1. The UE shall respond by sending PHYSICAL CHANNEL RECONFIGURATION COMPLETE message and also stop the periodic reporting activities. Following this, SS sends a MEASUREMENT CONTROL message and re-activates the compressed mode pattern sequence by using the "DPCH compressed mode status" IE. SS confirms that the UE has reconfigured itself to start measurement reporting again. The SS shall be able to receive MEASUREMENT REPORT messages continuously at 2 seconds interval.

#### Expected Sequence

| Step | Direction |    | Message                                                      | Comment                                                                                                                                                |
|------|-----------|----|--------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                        |
| 1    |           |    |                                                              | The initial state of UE is in CELL_DCH state of cell 1.                                                                                                |
| 2    |           | ←  | MEASUREMENT CONTROL                                          | SS specifies inter-frequency measurement and reporting parameters for cell 5, with "measurement validity" IE present and "UE state" set to "CELL_DCH". |
| 3    |           |    |                                                              | SS checks that no MEASUREMENT REPORT messages are detected on the uplink DCCH.                                                                         |
| 4    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION                             | SS configures PRACH and S-CCPCH physical resources.                                                                                                    |
| 5    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE                    | UE shall move to CELL_FACH state.                                                                                                                      |
| 6    |           | ←  | Master Information Block<br>System Information Block type 12 | SS modifies MIB and SIB 12 in order to include cell 4 into the list of cells in IE "inter-frequency cell info".                                        |
| 7    |           | ←  | SYSTEM INFORMATION CHANGE INDICATION                         | After SS transmits this message, SS confirms that there are no transmissions of MEASUREMENT REPORT message in the uplink direction.                    |
| 8    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION                             | SS configures dedicated physical channels with compressed mode parameters                                                                              |
| 9    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE                    | UE shall move to CELL_DCH state.                                                                                                                       |
| 10   |           | →  | MEASUREMENT REPORT                                           | UE shall resume inter-frequency measurement task for cell 5 and report the measured CPICH RSCP value for cell 5.                                       |
| 11   |           | ←  | MEASUREMENT CONTROL                                          | SS changes the reporting criteria for cell 5 to 'periodic reporting'                                                                                   |
| 12   |           | →  | MEASUREMENT REPORT                                           | UE shall begin to transmit this message at 2 seconds interval.                                                                                         |
| 13   |           | ←  | PHYSICAL CHANNEL RECONFIGURATION                             | SS deactivates the currently used pattern sequence for compressed mode operation.                                                                      |
| 14   |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE                    | UE stays in CELL_DCH state. SS verifies that no MEASUREMENT REPORT messages are received.                                                              |
| 15   |           | ←  | MEASUREMENT CONTROL                                          | SS activates the pattern sequence stored by the UE.                                                                                                    |

| Step | Direction |    | Message            | Comment                                                                        |
|------|-----------|----|--------------------|--------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                |
| 16   | →         |    | MEASUREMENT REPORT | SS checks that MEASUREMENT REPORT messages are received at 2 seconds interval. |



Specific Message Content

MEASUREMENT CONTROL (Step 2)

| Information Element | Value/Remark |
|---------------------|--------------|
|---------------------|--------------|

|                                                        |                                                                                                                               |
|--------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Measurement Identity                                   | 14                                                                                                                            |
| Measurement Command                                    | Setup                                                                                                                         |
| Measurement Reporting Mode                             |                                                                                                                               |
| — Measurement Reporting Transfer Mode                  | Acknowledged Mode RLC                                                                                                         |
| — Periodic Reporting / Event Trigger Reporting Mode    | Event Trigger                                                                                                                 |
| Additional measurements list                           | Not Present                                                                                                                   |
| CHOICE measurement type                                | Inter-frequency measurement                                                                                                   |
| — Inter-frequency cell info list                       |                                                                                                                               |
| — CHOICE inter-frequency cell removal                  | No inter-frequency cells removed                                                                                              |
| — New inter-frequency info list                        |                                                                                                                               |
| — Inter-frequency cell id                              |                                                                                                                               |
| — Frequency info                                       | 5                                                                                                                             |
| — UARFCN uplink (Nu)                                   | UARFCN of the uplink frequency for cell 5                                                                                     |
| — UARFCN downlink (Nd)                                 | UARFCN of the downlink frequency for cell 5                                                                                   |
| — Cell info                                            |                                                                                                                               |
| — Cell individual offset                               | 0 dB                                                                                                                          |
| — Reference time difference to cell                    | 0 chips                                                                                                                       |
| — Read SFN Indicator                                   | FALSE                                                                                                                         |
| — CHOICE Mode                                          | FDD                                                                                                                           |
| — Primary CPICH Info                                   |                                                                                                                               |
| — Primary Scrambling Code                              | Set to same code as used for cell 5                                                                                           |
| — Primary CPICH TX power                               | Not Present                                                                                                                   |
| — TX Diversity Indicator                               | FALSE                                                                                                                         |
| — Cells for measurement                                |                                                                                                                               |
| — Inter-frequency cell id                              | 5                                                                                                                             |
| — Inter-frequency measurement quantity                 |                                                                                                                               |
| — CHOICE reporting criteria                            | Inter-frequency reporting criteria                                                                                            |
| — Filter Coefficient                                   | 0                                                                                                                             |
| — Measurement quantity for frequency quality estimate  | CPICH RSCP                                                                                                                    |
| — Inter-frequency reporting quantity                   |                                                                                                                               |
| — UTRA Carrier RSSI                                    | FALSE                                                                                                                         |
| — Frequency quality estimate                           | FALSE                                                                                                                         |
| — Non frequency related cell reporting quantities      |                                                                                                                               |
| — SFN-SFN observed time difference reporting indicator | No report                                                                                                                     |
| — Cell synchronisation information reporting indicator | FALSE                                                                                                                         |
| — Cell Identity reporting indicator                    | TRUE                                                                                                                          |
| — CPICH Ec/No reporting indicator                      | FALSE                                                                                                                         |
| — CPICH RSCP reporting indicator                       | TRUE                                                                                                                          |
| — Pathloss reporting indicator                         | FALSE                                                                                                                         |
| — Reporting cell status                                | Not present                                                                                                                   |
| — Measurement validity                                 |                                                                                                                               |
| — UE State                                             | CELL_DCH                                                                                                                      |
| — Inter-frequency set update                           | Not Present                                                                                                                   |
| — CHOICE report criteria                               | Inter-frequency measurement reporting criteria                                                                                |
| — Parameters required for each event                   |                                                                                                                               |
| — Inter-frequency event identity                       | 2c                                                                                                                            |
| — Threshold used frequency                             | Not Present                                                                                                                   |
| — W used frequency                                     | Not Present                                                                                                                   |
| — Hysteresis                                           | 1.0 dB                                                                                                                        |
| — Time to trigger                                      | 10 seconds                                                                                                                    |
| — Reporting cell status                                |                                                                                                                               |
| — CHOICE reported cell                                 | Report cells within active and/or monitored set on used frequency or within active and/or monitored set on non-used frequency |
| — Maximum number of reported cells                     | 2                                                                                                                             |
| — Parameters required for each non-used frequency      |                                                                                                                               |
| — Threshold non used frequency                         | -85 dBm                                                                                                                       |
| — W non-used frequency                                 | 0.0                                                                                                                           |
| DPCH compressed mode status info                       | Not Present                                                                                                                   |

**PHYSICAL CHANNEL RECONFIGURATION (Step 4)**

Use the same message sub-type found in Annex A titled "(Packet to CELL\_FACH from CELL\_DCH in PS)".

**Master Information Block (Step 6)**

| Information Element | Value/Remark |
|---------------------|--------------|
| Value Tag           | 2            |

**System Information Block type 12 (Step 6)**

| Information Element                                | Value/Remark                        |
|----------------------------------------------------|-------------------------------------|
| FACH measurement occasion info                     |                                     |
| FACH Measurement occasion cycle length coefficient | 2                                   |
| Inter-frequency FDD measurement indicator          | TRUE                                |
| Inter-frequency TDD measurement indicator          | FALSE                               |
| Inter-RAT measurement indicators                   | Not Present                         |
| Measurement control system information             |                                     |
| Intra-frequency measurement system information     | Not Present                         |
| Inter-frequency measurement system information     |                                     |
| Inter-frequency cell info list                     |                                     |
| CHOICE inter-frequency cells removal               | No inter-frequency cells removed    |
| New inter-frequency info list                      |                                     |
| Inter-frequency cell id                            | Set to id of cell 4                 |
| Cell info                                          |                                     |
| Cell individual offset                             | 0 dB                                |
| Reference time difference to cell                  | 0 chips                             |
| Read SFN Indicator                                 | FALSE                               |
| CHOICE Mode                                        | FDD                                 |
| Primary CPICH Info                                 |                                     |
| Primary Scrambling Code                            | Set to same code as used for cell 4 |
| Primary CPICH TX power                             | Not Present                         |
| TX Diversity Indicator                             | FALSE                               |
| Cell selection and Re-selection info               | Not Present — use default values    |
| Cells for measurement                              | Not Present                         |
| Inter-RAT measurement system information           | Not Present                         |
| Traffic volume measurement system information      | Not Present                         |
| UE internal measurement system information         | Not Present                         |

**PHYSICAL CHANNEL RECONFIGURATION (Step 8)**

Use the same message sub-type found in Annex A, which is entitled "(Packet to CELL\_DCH from CELL\_FACH in PS)", with the following exceptions in the IE(s) concerned:

| Information Element                                          | Value/Remarks                                                       |
|--------------------------------------------------------------|---------------------------------------------------------------------|
| Downlink information common for all radio links              |                                                                     |
| → Downlink DPCH info common for all RL                       |                                                                     |
| → Timing Indication                                          | Maintain                                                            |
| → Downlink DPCH power control information                    |                                                                     |
| → DPC mode                                                   | 0 (Single)                                                          |
| → CHOICE Mode                                                | FDD                                                                 |
| → Power offset $P_{\text{Pilot-DPCH}}$                       | 0                                                                   |
| → DL rate matching restriction information                   | Not Present                                                         |
| → Spreading factor                                           | Refer to the parameter set in TS 34.108                             |
| → Fixed or flexible position                                 | Flexible                                                            |
| → TFCI existence                                             | FALSE                                                               |
| → Number of bits for Pilot bits (SF=128, 256)                | Not Present                                                         |
| → DPCH compressed mode info                                  |                                                                     |
| → TGPSI                                                      | 1                                                                   |
| → TGPS Status Flag                                           | Active                                                              |
| → TGCFN                                                      | $(\text{Current CFN} + (256 - \text{TTI}/10\text{msec})) \bmod 256$ |
| → Transmission gap pattern sequence configuration parameters |                                                                     |
| → TGMP                                                       | FDD Measurement                                                     |
| → TGPRC                                                      | 62                                                                  |
| → TGSN                                                       | 4                                                                   |
| → TGL1                                                       | 7                                                                   |
| → TGL2                                                       | Not Present                                                         |
| → TGD                                                        | 0                                                                   |
| → TGPL1                                                      | 3                                                                   |
| → TGPL2                                                      | Not Present                                                         |
| → RPP                                                        | Mode 0                                                              |
| → ITP                                                        | Mode 0                                                              |
| → CHOICE UL/DL Mode                                          | UL and DL                                                           |
| → Downlink compressed mode method                            | SF/2                                                                |
| → Uplink compressed mode method                              | SF/2                                                                |
| → Downlink frame type                                        | B                                                                   |
| → DeltaSIR1                                                  | 2.0                                                                 |
| → DeltaSIRAfter1                                             | 1.0                                                                 |
| → DeltaSIR2                                                  | Not Present                                                         |
| → DeltaSIRAfter2                                             | Not Present                                                         |
| → N identify abort                                           | Not Present                                                         |
| → T Reconfirm abort                                          | Not Present                                                         |
| → TX Diversity Mode                                          | None                                                                |
| → SSDT information                                           | Not Present                                                         |
| → Default DPCH Offset Value                                  | 0                                                                   |

## MEASUREMENT REPORT (Step 10)

| Information Element                             | Value/Remarks                                                          |
|-------------------------------------------------|------------------------------------------------------------------------|
| Measurement identity                            | Check to see if set to 14                                              |
| Measured Results                                |                                                                        |
| CHOICE measurement                              | Check to see if set to "Inter-frequency measured results list"         |
| Inter-frequency measurement results             |                                                                        |
| Frequency info                                  |                                                                        |
| UARFCN (uplink)                                 | Check to see if set to the UARFCN of the uplink frequency for cell 5   |
| UARFCN (downlink)                               | Check to see if set to the UARFCN of the downlink frequency for cell 5 |
| UTRA carrier RSSI                               | Check to see if it is absent                                           |
| Inter-frequency cell measurement results        | Check to see if it is absent                                           |
| Cell measured results                           | Check to see if it is absent                                           |
| Cell Identity                                   | Check to see if it is absent                                           |
| SFN-SFN observed time difference                | Check to see if it is absent                                           |
| Cell synchronisation information                | Check to see if it is absent                                           |
| Primary CPICH Info                              |                                                                        |
| Primary Scrambling Code                         | Check to see if set to the same code for cell 5                        |
| CPICH Ec/No                                     | Check to see if it is absent                                           |
| CPICH RSCP                                      | Check to see if it is present                                          |
| Pathloss                                        | Check to see if it is absent                                           |
| Measured Results on RACH                        | Check to see if it is absent                                           |
| Event Results                                   |                                                                        |
| CHOICE event result                             | Inter-frequency event results                                          |
| Inter-frequency event identity                  | Check to see if it's set to '2c'                                       |
| Inter-frequency cells                           |                                                                        |
| Frequency Info                                  |                                                                        |
| UARFCN (uplink)                                 | Check to see if set to the UARFCN of the uplink frequency for cell 5   |
| UARFCN (downlink)                               | Check to see if set to the UARFCN of the downlink frequency for cell 5 |
| Non frequency related measurement event results |                                                                        |
| Primary CPICH Info                              |                                                                        |
| Primary Scrambling Code                         | Check to see if set to the same code for cell 5                        |

## MEASUREMENT CONTROL (Step 11)

| Information Element                                    | Value/Remark                                                                                                                  |
|--------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Measurement Identity                                   | 14                                                                                                                            |
| Measurement Command                                    | Modify                                                                                                                        |
| Measurement Reporting Mode                             |                                                                                                                               |
| — Measurement Reporting Transfer Mode                  | Acknowledged Mode RLC                                                                                                         |
| — Periodic Reporting / Event Trigger Reporting Mode    | Event Trigger                                                                                                                 |
| Additional measurements list                           | Not Present                                                                                                                   |
| CHOICE measurement type                                | Inter-frequency measurement                                                                                                   |
| — Inter-frequency cell info list                       |                                                                                                                               |
| — CHOICE inter-frequency cell removal                  | No inter-frequency cells removed                                                                                              |
| — New inter-frequency info list                        |                                                                                                                               |
| — Inter-frequency cell id                              | 5                                                                                                                             |
| — Frequency info                                       |                                                                                                                               |
| — UARFCN uplink (Nu)                                   | UARFCN of the uplink frequency for cell 5                                                                                     |
| — UARFCN downlink (Nd)                                 | UARFCN of the downlink frequency for cell 5                                                                                   |
| — Cell info                                            |                                                                                                                               |
| — Cell individual offset                               | 0 dB                                                                                                                          |
| — Reference time difference to cell                    | 0 chips                                                                                                                       |
| — Read SFN Indicator                                   | FALSE                                                                                                                         |
| — CHOICE Mode                                          | FDD                                                                                                                           |
| — Primary CPICH Info                                   |                                                                                                                               |
| — Primary Scrambling Code                              | Set to same code as used for cell 5                                                                                           |
| — Primary CPICH TX power                               | Not Present                                                                                                                   |
| — TX Diversity Indicator                               | FALSE                                                                                                                         |
| — Cells for measurement                                |                                                                                                                               |
| — Inter-frequency cell id                              | 5                                                                                                                             |
| — Inter-frequency measurement quantity                 |                                                                                                                               |
| — CHOICE reporting criteria                            | Inter-frequency reporting criteria                                                                                            |
| — Filter Coefficient                                   | 0                                                                                                                             |
| — Measurement quantity for frequency quality estimate  | CPICH RSCP                                                                                                                    |
| — Inter-frequency reporting quantity                   |                                                                                                                               |
| — UTRA Carrier RSSI                                    | FALSE                                                                                                                         |
| — Frequency quality estimate                           | FALSE                                                                                                                         |
| — Non-frequency related cell reporting quantities      |                                                                                                                               |
| — SFN-SFN observed time difference reporting indicator | No report                                                                                                                     |
| — Cell synchronisation information reporting indicator | FALSE                                                                                                                         |
| — Cell Identity reporting indicator                    | TRUE                                                                                                                          |
| — CPICH Ec/No reporting indicator                      | FALSE                                                                                                                         |
| — CPICH RSCP reporting indicator                       | TRUE                                                                                                                          |
| — Pathloss reporting indicator                         | FALSE                                                                                                                         |
| — Reporting cell status                                |                                                                                                                               |
| — CHOICE reported cell                                 | Report cells within active and/or monitored set on used frequency or within active and/or monitored set on non-used frequency |
| — Maximum number of reported cells                     | 2                                                                                                                             |
| — Measurement validity                                 | Not Present                                                                                                                   |
| — Inter-frequency set update                           | Not Present                                                                                                                   |
| — CHOICE report criteria                               | Periodic reporting criteria                                                                                                   |
| — Amount of reporting                                  | Infinity                                                                                                                      |
| — Reporting interval                                   | 2000 milliseconds                                                                                                             |
| DPCH compressed mode status info                       | Not Present                                                                                                                   |

## MEASUREMENT REPORT (Step 12, 16)

| Information Element                         | Value/Remarks                                                          |
|---------------------------------------------|------------------------------------------------------------------------|
| Measurement identity                        | Check to see if set to 14                                              |
| Measured Results                            |                                                                        |
| —— CHOICE measurement                       | Check to see if set to "Inter-frequency measured results list"         |
| —— Inter-frequency measurement results      |                                                                        |
| —— Frequency info                           |                                                                        |
| —— UARFCN (uplink)                          | Check to see if set to the UARFCN of the uplink frequency for cell 5   |
| —— UARFCN (downlink)                        | Check to see if set to the UARFCN of the downlink frequency for cell 5 |
| —— UTRA carrier RSSI                        | Check to see if it is absent                                           |
| —— Inter-frequency cell measurement results |                                                                        |
| —— Cell measured results                    |                                                                        |
| —— Cell Identity                            | Check to see if is absent                                              |
| —— SFN-SFN observed time difference         | Check to see if it is absent                                           |
| —— Cell synchronisation information         | Check to see if it is absent                                           |
| —— Primary CPICH Info                       |                                                                        |
| —— Primary Scrambling Code                  | Check to see if set to the same code for cell 5                        |
| —— CPICH Ec/No                              | Check to see if it is absent                                           |
| —— CPICH RSCP                               | Check to see if it is present                                          |
| —— Pathloss                                 | Check to see if it is absent                                           |
| —— CFN-SFN observed time difference         | Check to see if it is absent                                           |
| Measured Results on RACH                    | Check to see if it is absent                                           |
| Event Results                               | Check to see if it is absent                                           |

## PHYSICAL CHANNEL RECONFIGURATION (Step 13)

Use the same message transmitted in step 8 with the following modifications:

| Information Element                                           | Value/Remarks |
|---------------------------------------------------------------|---------------|
| Downlink information common for all radio links               |               |
| —— DPCCH compressed mode info                                 |               |
| —— TGPSI                                                      | 1             |
| —— TGPS Status Flag                                           | Inactive      |
| —— TGCFN                                                      | Not Present   |
| —— Transmission gap pattern sequence configuration parameters | Not Present   |

## MEASUREMENT CONTROL (Step 15)

| Information Element                  | Value/Remark                           |
|--------------------------------------|----------------------------------------|
| Measurement Identity                 | 14                                     |
| Measurement Command                  | Modify                                 |
| Measurement Reporting Mode           | Not Present                            |
| Additional measurements list         | Not Present                            |
| CHOICE measurement type              | Not Present                            |
| DPCCH compressed mode status info    |                                        |
| —— TGPS reconfiguration CFN          | (Current CFN+(256—TTI/10msec)) mod 256 |
| —— Transmission gap pattern sequence |                                        |
| —— TGPSI                             | 1                                      |
| —— TGPS Flag                         | Active                                 |
| —— TGCFN                             | (Current CFN+(256—TTI/10msec)) mod 256 |

## 8.4.1.8.5 Test Requirement

After step 2 the UE shall not send any MEASUREMENT REPORT messages on the uplink DCCH of cell 1.

After step 9 the UE shall transmit a MEASUREMENT REPORT message, containing the IE "measured results" reporting cell 5's CPICH RSCP value. The UE shall also report the triggering of event '2c' by including IE "Event

results" in the MEASUREMENT REPORT message. The UE shall not transmit any MEASUREMENT REPORT messages pertaining to cell 4's measurements.

After step 11 the UE shall send MEASUREMENT REPORT messages, containing cell 5's CPICH RSCP measured value in IE "Measured results" at 2 seconds interval. The "Event results" IE shall be omitted in these messages.

After step 14 the UE shall not transmit any MEASUREMENT REPORT messages.

After step 15 the UE shall resume the transmission of MEASUREMENT REPORT messages with identical contents as in those received after step 11.

#### ~~8.4.1.9 Measurement Control and Report: Unsupported measurement in the UE~~

##### ~~8.4.1.9.1 Definition~~

##### ~~8.4.1.9.2 Conformance requirement~~

If the UTRAN instructs the UE to perform a measurement that is not supported by the UE, the UE shall keep the measurement configuration that was valid before the MEASUREMENT CONTROL message was received. Then the UE shall transmit a MEASUREMENT CONTROL FAILURE message on the DCCH using AM RLC.

#### Reference

3GPP TS 25.331 clause 8.4.1.4

##### ~~8.4.1.9.3 Test purpose~~

To confirm that the UE transmits a MEASUREMENT CONTROL FAILURE message, with the value "unsupported measurement" in IE "failure cause" when the SS instructs the UE to perform an unsupported measurement by sending a MEASUREMENT CONTROL message. To confirm that the UE retains its existing valid measurement configuration, after receiving a MEASUREMENT CONTROL message containing an unsupported measurement.

##### ~~8.4.1.9.4 Method of test~~

#### Initial Condition

System Simulator: 1cell

UE: CS-DCCH+DTCH\_DCH (State 6-9) or PS-DCCH+DTCH\_DCH (State 6-10) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE.

[Editor's note: It is assumed in this test that the UE under test does not possess any inter-RAT measurement capability. The mandatory type(s) of measurement capability that shall be implemented by the UE is to be discussed]

#### Test Procedure

The UE is in the CELL\_DCH state. SS sends MEASUREMENT CONTROL message to command the UE to perform internal measurement and reporting for UE transmitted power. The UE shall transmit MEASUREMENT REPORT messages on DCCH at 1 second interval. The SS transmits a MEASUREMENT CONTROL message to configure inter-RAT measurements. The UE shall transmit a MEASUREMENT CONTROL FAILURE message on the uplink DCCH using AM RLC. SS verifies that the UE continues to transmit MEASUREMENT REPORT messages on uplink DCCH.



## Expected sequence

| Step | Direction |    | Message                     | Comment                                                           |
|------|-----------|----|-----------------------------|-------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                   |
| 1    |           |    |                             | The UE is in the CELL_DCH state.                                  |
| 2    |           | ←  | MEASUREMENT CONTROL         | UE internal measurement and reporting is requested.               |
| 3    |           | →  | MEASUREMENT REPORT          | Contains estimated reading for UE transmitted power.              |
| 4    |           | ←  | MEASUREMENT CONTROL         | Inter-RAT measurements are requested in this message              |
| 5    |           | →  | MEASUREMENT CONTROL FAILURE | The value "unsupported measurement" is set in IE "failure-cause". |
| 6    |           | →  | MEASUREMENT REPORT          | SS verifies that UE continue to send this message on uplink DCCH. |

## Specific Message Content

## MEASUREMENT CONTROL (Step 2)

| Information Element                                 | Value/Remark                  |
|-----------------------------------------------------|-------------------------------|
| Measurement Identity                                | 1                             |
| Measurement Command                                 | Setup                         |
| Measurement Reporting Mode                          |                               |
| → Measurement Reporting Transfer Mode               | Acknowledged Mode RLC         |
| → Periodic Reporting / Event Trigger Reporting Mode | Periodical Reporting          |
| Additional measurements list                        | Not Present                   |
| CHOICE measurement type                             | UE internal measurement       |
| → UE internal measurement quantity                  |                               |
| → CHOICE mode                                       | FDD                           |
| → Measurement quantity                              | UE Transmitted Power          |
| → Filter Coefficient                                | 0                             |
| → UE internal reporting quantity                    |                               |
| → UE Transmitted Power                              | TRUE                          |
| → CHOICE mode                                       | FDD                           |
| → UE Rx-Tx time difference                          | FALSE                         |
| → CHOICE report criteria                            | Periodical reporting criteria |
| → Amount of reporting                               | Infinity                      |
| → Reporting interval                                | 1000 msec                     |
| DPCH compressed mode status                         | Not Present                   |

## MEASUREMENT REPORT (Step 3 and Step 6)

| Information Element         | Value/Remark                                                   |
|-----------------------------|----------------------------------------------------------------|
| Measurement Identity number | Check to see if it's set to '1'                                |
| Measured Results            |                                                                |
| → CHOICE measurement        | Check to see if it's set to "UE internal measured results"     |
| → CHOICE mode               | Check to see if it's set to "FDD"                              |
| → UE Transmitted Power      | Check to see if the reported power is compatible with RF class |
| → UE Rx-Tx report entries   | Check to see if it is absent                                   |
| Measured Results on RACH    | Check to see if it is absent                                   |
| Additional Measured results | Check to see if it is absent                                   |
| Event results               | Check to see if it is absent                                   |

## MEASUREMENT CONTROL (Step 4)

| Information Element                  | Value/Remark                                |
|--------------------------------------|---------------------------------------------|
| RRC transaction identifier           | Select an arbitrary integer between 0 and 3 |
| Measurement Identity                 | 2                                           |
| Measurement Command                  | Setup                                       |
| Measurement Reporting Mode           | Not Present                                 |
| Additional measurements list         | Not Present                                 |
| CHOICE measurement type              | Inter-RAT measurement                       |
| Inter-RAT cell info list             |                                             |
| CHOICE inter-RAT cell removal        | Remove no inter-RAT cells                   |
| New inter-RAT cells                  |                                             |
| Inter-RAT cell id                    | 1                                           |
| CHOICE Radio Access Technology       | GSM                                         |
| Cell individual offset               | 0                                           |
| Cell selection and re-selection info | Not Present                                 |
| BSIC                                 | Set to the BSIC code of cell 2              |
| BSIC ARFCN                           | Set to the ARFCN assigned to cell 2         |
| Output power                         | Not Present                                 |
| Cells for measurement                |                                             |
| Inter-RAT cell id                    | 2                                           |
| Inter-RAT measurement quantity       |                                             |
| CHOICE system                        | GSM                                         |
| Measurement quantity                 | GSM Carrier RSSI                            |
| Filter Coefficient                   | 0                                           |
| BSIC verification required           | Not required                                |
| Inter-RAT reporting quantity         |                                             |
| UTRAN estimate quantity              | FALSE                                       |
| CHOICE system                        | GSM                                         |
| Pathloss                             | FALSE                                       |
| Observed time difference to GSM cell | FALSE                                       |
| GSM Carrier RSSI                     | TRUE                                        |
| Reporting cell status                | Not Present                                 |
| CHOICE report criteria               | No reporting                                |
| DPCH compressed mode status info     | Not Present                                 |

## MEASUREMENT CONTROL FAILURE (Step 5)

| Information Element        | Value/Remarks                                                                                          |
|----------------------------|--------------------------------------------------------------------------------------------------------|
| RRC transaction identifier | Check if it is set to the same value of the same IE in the MEASUREMENT CONTROL message sent in Step 4. |
| Failure cause              | Check if it is set to "Unsupported measurement"                                                        |

## 8.4.1.9.5 Test requirement

After step 2 the UE shall transmit a MEASUREMENT REPORT messages at 1 second interval. In these messages, the IE "CHOICE measurement" shall be set to "UE internal measured results", and it shall contain the measured UL transmitted power reading in IE "UE Transmitted Power".

After step 4 the UE shall transmit a MEASUREMENT CONTROL FAILURE message. In this message, the value "unsupported measurement" shall be specified in IE "failure cause".

After step 5 the UE shall continue to transmit MEASUREMENT REPORT messages on the uplink DCCH, with the contents of the messages identical to that received by SS after step 2.

### 8.4.1.10 ~~Measurement Control and Report: Failure (Invalid Message Reception)~~

#### 8.4.1.10.1 ~~Definition~~

#### 8.4.1.10.2 ~~Conformance requirement~~

When the UE received an invalid MEASUREMENT CONTROL message it shall reply with a MEASUREMENT CONTROL FAILURE message stating the appropriate protocol error information. It shall continue its ongoing processes and procedures as if the MEASUREMENT CONTROL message has not been received.

#### Reference

3GPP TS 25.331 clauses 8.4.1.5 and 9.2

#### 8.4.1.10.3 ~~Test Purpose~~

To confirm that the UE continues its ongoing processes and procedures after it has received an invalid MEASUREMENT CONTROL message. To confirm that the UE transmits MEASUREMENT CONTROL FAILURE message, after it has received an invalid MEASUREMENT CONTROL message.

#### 8.4.1.10.4 ~~Method of test~~

#### Initial Condition

System Simulator: 1 cell.

UE: CS-DCCH+DTCH\_DCH (State 6-9) or PS-DCCH+DTCH\_DCH (State 6-10) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE.

#### Test Procedure

The UE is initially brought to CELL\_DCH. SS transmits a MEASUREMENT CONTROL message to the UE, commanding it to start transmitting report messages for the reporting quantity "UE Transmitted Power". SS waits for the UE to transmit MEASUREMENT RERORT message on the uplink DCCH. After the MEASUREMENT REPORT message is received, SS transmits an invalid MEASUREMENT CONTROL message again. The UE shall reply with MEASURMENT CONTROL FAILURE message as it has detected a protocol error. It shall continue to report its UL transmission power level using MEASUREMENT REPORT messages.

#### Expected Sequence

| Step | Direction |    | Message             | Comment                                                                                                           |
|------|-----------|----|---------------------|-------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                     |                                                                                                                   |
| 1    |           |    |                     | The UE is CELL_DCH state in cell 1.                                                                               |
| 2    |           | ←  | MEASUREMENT CONTROL | SS transmits this message on downlink DCCH to instruct UE to start reporting the quantity "UE transmitted power". |
| 3    |           | →  | MEASUREMENT REPORT  | UE shall send this message periodically at 32 seconds interval                                                    |
| 4    |           | ←  | MEASURMENT CONTROL  | See message content.                                                                                              |

| Step | Direction |    | Message                     | Comment                                                                                                      |
|------|-----------|----|-----------------------------|--------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                              |
| 5    | →         |    | MEASUREMENT-CONTROL-FAILURE | UE shall continue its current measurement and reporting processes and procedures after sending this message. |
| 6    | →         |    | MEASUREMENT-REPORT          | UE shall continue to transmit this message to the SS at 32 seconds interval.                                 |

### Specific Message Content

#### MEASUREMENT-CONTROL (Step-2)

| Information Element                                 | Value/Remark                  |
|-----------------------------------------------------|-------------------------------|
| Measurement Identity                                | 3                             |
| Measurement Command                                 | Setup                         |
| Measurement Reporting Mode                          |                               |
| → Measurement Reporting Transfer Mode               | Acknowledged Mode-RLC         |
| → Periodic Reporting / Event Trigger Reporting Mode | Periodical Reporting          |
| Additional measurements list                        | Not Present                   |
| CHOICE measurement type                             | UE internal measurement       |
| → UE internal measurement quantity                  |                               |
| → Measurement quantity                              | UE Transmitted Power          |
| → Filter coefficient                                | 0                             |
| → UE internal reporting quantity                    |                               |
| → UE Transmitted Power                              | TRUE                          |
| → UE Rx-Tx time difference                          | FALSE                         |
| CHOICE report criteria                              | Periodical reporting criteria |
| → Amount of reporting                               | Infinity                      |
| → Reporting interval                                | 32 seconds                    |
| DPCH compressed mode status info                    | Not Present                   |

#### MEASUREMENT-REPORT (Step-3 and Step-6)

| Information Element         | Value/Remarks                                                  |
|-----------------------------|----------------------------------------------------------------|
| Measurement identity        | Check to see if set to 3                                       |
| Measured Results            |                                                                |
| → CHOICE measurement        | Check to see if set to "UE internal measurement results"       |
| → CHOICE mode               | Check to see if it's set to "FDD"                              |
| → UE Transmitted Power      | Check to see if the reported power is compatible with RF class |
| → UE Rx-Tx report entries   | Check to see if this IE is absent                              |
| Measured Results on RACH    | Check to see if this IE is absent                              |
| Additional Measured results | Check to see if this IE is absent                              |
| Event Results               | Check to see if this IE is absent                              |

#### MEASUREMENT-CONTROL (Step-4)

| Information Element | Value/Remark |
|---------------------|--------------|
| All IEs             | Not Present  |

**MEASUREMENT CONTROL FAILURE (Step 5)**

| Information Element        | Value/Remark                                               |
|----------------------------|------------------------------------------------------------|
| Failure cause              | Check to see if set to "protocol error"                    |
| Protocol error information | Check to see if set to "ASN.1 violation or encoding error" |

**8.4.1.10.5 — Test Requirement**

After step 4 the UE shall transmit MEASUREMENT CONTROL FAILURE message, stating the IE "failure cause" as "protocol error" and IE "protocol error information" as "ASN.1 violation or encoding error".

After step 5 the UE shall continue to send MEASUREMENT REPORT, with the measurement identity number set to 3 and "measured results" IE containing measured readings of UE Tx power, at 32 seconds interval.

**8.4.1.11 — Measurement Control and Report: Compressed Mode Configuration Failure during radio bearer reconfiguration procedure****8.4.1.11.1 — Definition****8.4.1.11.2 — Conformance requirement**

During a radio bearer reconfiguration procedure, the UTRAN might request the activation of a new transmission gap pattern sequence configuration. If the UE detects a runtime error due to overlapping compressed mode configuration, it shall delete the transmission gap pattern sequence configuration associated with highest value of TGPSI. The UE shall also terminate any inter-frequency / inter-RAT measurements corresponding to the deleted transmission gap pattern sequence. The UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM-RLC, with the IE "failure cause" set to "compressed mode runtime error".

**Reference**

3GPP TS 25.331 clause 8.2.2, clause 8.2.11.2, clause 8.6.6.15

**8.4.1.11.3 — Test purpose**

To confirm that the UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the uplink DCCH using AM-RLC, if it receives a RADIO BEARER RECONFIGURATION message which includes IE "DPCH compressed mode info" that causes an illegal overlap involving more than one parallel transmission gap pattern sequences. To confirm that the UE terminate any inter-frequency measurements corresponding to the deleted transmission gap pattern sequence.

**8.4.1.11.4 — Method of test****Initial Condition**

System Simulator: 2 cells — Cell 1 and cell 4 are active.

UE: CS-DCCH+DTCH\_DCH (State 6-9) or PS-DCCH+DTCH\_DCH (State 6-10) as specified in TS34.108 clause 7.4, depending on the CN domain supported.

**Test Procedure**

Table 8.4.1.11-1 illustrates the downlink power to be applied for the 2 cells in this test case.

**Table 8.4.1.11-1**

| Parameter              | Unit                | Cell 1 | Cell 4 |
|------------------------|---------------------|--------|--------|
| UTRA-RF Channel Number |                     | Ch. 1  | Ch. 2  |
| CPICH Ec               | dBm/<br>3.84<br>MHz | -60    | -70    |

The UE is in the CELL\_DCH state in cell 1. SS sends a MEASUREMENT CONTROL message on the downlink DCCH to request the UE to start inter-frequency measurement for cell 4's CPICH Ec/No value, and also to report the UTRA RSSI in the UARFCN in which cell 4 resides. Simultaneously, the stored transmission gap pattern sequence configuration associated with TGPSI=1 is indicated to be activated in this message. The UE shall transmit MEASUREMENT REPORT messages periodically at 16 seconds interval to report the RSSI value of UTRA carrier in which cell 4 resides. Next, SS sends a second MEASUREMENT CONTROL message. In this message, a new measurement task is to be established for the measurement and reporting of "GSM carrier RSSI" on a periodic basis. A deactivated transmission pattern gap sequence configuration (with TGPSI=2) is associated with this new measurement task.

The SS transmits a RADIO BEARER RECONFIGURATION message and commands the activation of transmission gap pattern sequence with TGPSI=2. The UE then shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC. In this message, the value of IE "failure cause" shall be set to "compressed mode runtime error". The UE shall terminate all inter-RAT measurement tasks associated with TGPSI=2. The UE shall continue to send MEASUREMENT REPORT messages to report the UTRA RSSI in the UARFCN in which cell 4 resides.

#### Expected sequence

| Step | Direction |    | Message                                  | Comment                                                                                                                                                                                             |
|------|-----------|----|------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                          |                                                                                                                                                                                                     |
| 1    |           |    |                                          | UE is initially in CELL_DCH state.                                                                                                                                                                  |
| 2    |           | ←  | MEASUREMENT CONTROL                      | SS starts inter-frequency measurements for cell 4's CPICH Ec/No using transmission gap pattern sequence with TGPSI=1. SS commands UE to report the UTRA RSSI in the UARFCN in which cell 4 resides. |
| 3    |           | →  | MEASUREMENT REPORT                       | UE reports UTRA RSSI for the UARFCN of cell 4 periodically.                                                                                                                                         |
| 4    |           | ←  | MEASUREMENT CONTROL                      | SS assigns inter-RAT measurements for "GSM carrier RSSI". This measurement task is associated with transmission gap pattern sequence with TGPSI=2. The IE "TGPS status flag" is set to "Inactive".  |
| 5    |           | ←  | RADIO BEARER RECONFIGURATION             | SS specifies the parameters for transmission gap pattern sequence with TGPSI=2 and activates it simultaneously.                                                                                     |
| 6    |           |    |                                          | UE shall delete transmission gap pattern sequence configuration associated with TGPSI=2.                                                                                                            |
| 7    |           | →  | PHYSICAL CHANNEL RECONFIGURATION FAILURE | IE "Failure cause" shall be set to "Compressed mode runtime error".                                                                                                                                 |
| 8    |           | →  | MEASUREMENT REPORT                       | The contents shall be the same as that in step 3.                                                                                                                                                   |

## Specific Message Contents

## MEASUREMENT CONTROL (Step 2)

| Information Element                                    | Value/Remark                                                                                                                  |
|--------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Measurement Identity                                   | 1                                                                                                                             |
| Measurement Command                                    | Setup                                                                                                                         |
| Measurement Reporting Mode                             |                                                                                                                               |
| — Measurement Reporting Transfer Mode                  | Acknowledged Mode RLC                                                                                                         |
| — Periodic Reporting / Event Trigger Reporting Mode    | Periodical Reporting                                                                                                          |
| Additional measurements list                           | Not Present                                                                                                                   |
| CHOICE measurement type                                | Inter-frequency measurement                                                                                                   |
| — Inter-frequency cell info list                       |                                                                                                                               |
| — CHOICE inter-frequency cell removal                  | No inter-frequency cells removed                                                                                              |
| — New inter-frequency info list                        |                                                                                                                               |
| — Inter-frequency cell id                              | 4                                                                                                                             |
| — Frequency info                                       |                                                                                                                               |
| — UARFCN uplink (Nu)                                   | UARFCN of the uplink frequency for cell 4                                                                                     |
| — UARFCN downlink (Nd)                                 | UARFCN of the downlink frequency for cell 4                                                                                   |
| — Cell info                                            |                                                                                                                               |
| — Cell individual offset                               | 0 dB                                                                                                                          |
| — Reference time difference to cell                    | 0 chips                                                                                                                       |
| — Read SFN Indicator                                   | FALSE                                                                                                                         |
| — CHOICE Mode                                          | FDD                                                                                                                           |
| — Primary CPICH Info                                   |                                                                                                                               |
| — Primary Scrambling Code                              | Set to same code as used for cell 4                                                                                           |
| — Primary CPICH TX power                               | Not Present                                                                                                                   |
| — TX Diversity Indicator                               | FALSE                                                                                                                         |
| — Cells for measurement                                |                                                                                                                               |
| — Inter-frequency cell id                              | 4                                                                                                                             |
| — Inter-frequency measurement quantity                 |                                                                                                                               |
| — CHOICE reporting criteria                            | Inter-frequency reporting criteria                                                                                            |
| — Filter Coefficient                                   | 0                                                                                                                             |
| — Measurement quantity for frequency quality estimate  | CPICH Ec/No                                                                                                                   |
| — Inter-frequency reporting quantity                   |                                                                                                                               |
| — UTRA Carrier RSSI                                    | TRUE                                                                                                                          |
| — Frequency quality estimate                           | FALSE                                                                                                                         |
| — Non frequency related cell reporting quantities      |                                                                                                                               |
| — SFN-SFN observed time difference reporting indicator | No report                                                                                                                     |
| — Cell synchronisation reporting indicator             | FALSE                                                                                                                         |
| — Cell Identity reporting indicator                    | FALSE                                                                                                                         |
| — CPICH Ec/No reporting indicator                      | FALSE                                                                                                                         |
| — CPICH RSCP reporting indicator                       | FALSE                                                                                                                         |
| — Pathloss reporting indicator                         | FALSE                                                                                                                         |
| — Reporting cell status                                |                                                                                                                               |
| — CHOICE reported cell                                 | Report cells within active and/or monitored set on used frequency or within active and/or monitored set on non-used frequency |
| — Maximum number of reported cells                     | 2                                                                                                                             |
| — Measurement validity                                 | Not present                                                                                                                   |
| — Inter-frequency set update                           | Not present                                                                                                                   |
| — CHOICE report criteria                               | Periodic reporting criteria                                                                                                   |
| — Amount of reporting                                  | Infinity                                                                                                                      |
| — Reporting interval                                   | 16 seconds                                                                                                                    |
| DPCH compressed mode status info                       |                                                                                                                               |
| — TGPS reconfiguration CFN                             | (Current CFN+(256—TTI/10msec)) mod 256                                                                                        |
| — Transmission gap pattern sequence                    |                                                                                                                               |
| — TGP SI                                               | 1                                                                                                                             |
| — TGPS Status Flag                                     | Active                                                                                                                        |
| — TGCFN                                                | (Current CFN+(256—TTI/10msec)) mod 256                                                                                        |

## MEASUREMENT REPORT (Step 3 and Step 8)

| Information Element                      | Value/Remarks                                                          |
|------------------------------------------|------------------------------------------------------------------------|
| Measurement identity                     | Check to see if set to "1"                                             |
| Measured Results                         |                                                                        |
| CHOICE measurement                       | Check to see if set to "Inter-frequency measured results list"         |
| Inter-frequency measurement results      |                                                                        |
| Frequency info                           |                                                                        |
| UARFCN (uplink)                          | Check to see if set to the UARFCN of the uplink frequency for cell 4   |
| UARFCN (downlink)                        | Check to see if set to the UARFCN of the downlink frequency for cell 4 |
| UTRA carrier RSSI                        | Check to see if it is present                                          |
| Inter-frequency cell measurement results |                                                                        |
| Cell measured results                    |                                                                        |
| Cell Identity                            | Check to see if it is absent                                           |
| SFN-SFN observed time difference         | Check to see if it is absent                                           |
| Cell synchronisation information         | Check to see if it is absent                                           |
| Primary CPICH Info                       |                                                                        |
| Primary Scrambling Code                  | Check to see if set to the same code for cell 4                        |
| CPICH Ec/No                              | Check to see if it is absent                                           |
| CPICH RSCP                               | Check to see if it is absent                                           |
| Pathloss                                 | Check to see if it is absent                                           |
| Measured Results on RACH                 | Check to see if it is absent                                           |
| Event Results                            | Check to see if it is absent                                           |



## MEASUREMENT CONTROL (Step 4)

| Information Element                            | Value/Remark                                                        |
|------------------------------------------------|---------------------------------------------------------------------|
| Measurement Identity                           | 2                                                                   |
| Measurement Command                            | Setup                                                               |
| Measurement Reporting Mode                     |                                                                     |
| — Measurement Reporting Transfer Mode          | Acknowledged Mode RLC                                               |
| - Periodic Reporting / Event Trigger Reporting | Periodical reporting                                                |
| - Mode                                         |                                                                     |
| Additional measurements list                   | Not Present                                                         |
| CHOISE measurement type                        |                                                                     |
| - inter-RAT measurement                        |                                                                     |
| — inter-RAT measurement object list            |                                                                     |
| — CHOISE Inter-RAT Cell Removal                | Remove no inter-RAT cells                                           |
| - inter-RAT cell id                            | 7                                                                   |
| CHOISE Radio Access Technology                 | GSM                                                                 |
| - Cell individual offset                       | 0                                                                   |
| - Cell selection and re-selection info         | Not present                                                         |
| — BSIC                                         | BSIC1                                                               |
| - Band indicator                               | DCS 1800 band used                                                  |
| - BCCH ARFCN                                   | 1                                                                   |
| — Cell for measurement                         | Not present                                                         |
| - inter-RAT measurement quantity               |                                                                     |
| — Measurement quantity for UTRAN quality       | Not present                                                         |
| — estimate                                     |                                                                     |
| — CHOISE system                                | GSM                                                                 |
| - Measurement quantity                         | GSM carrier RSSI                                                    |
| - Filter coefficient                           | 0                                                                   |
| - BSIC verification required                   | not required                                                        |
| - inter-RAT reporting quantity                 |                                                                     |
| — CHOISE system                                | GSM                                                                 |
| - Observed time difference to to GSM           | FALSE                                                               |
| - cell reporting indicator                     |                                                                     |
| - GSM carrier RSSI reporting indicator         | TRUE                                                                |
| - Reporting cell status                        |                                                                     |
| — CHOISE reported cell                         |                                                                     |
| - Reported cells within active set or within   |                                                                     |
| - virtual active set or of the other RAT       |                                                                     |
| - Maximum number of reported cells             | 6                                                                   |
| — CHOISE report criteria                       |                                                                     |
| - Periodical reporting criteria                |                                                                     |
| - Amount of reporting                          | infinity                                                            |
| - Reporting interval                           | 1000                                                                |
| Physical channel information elements          |                                                                     |
| - DPCH compressed mode status info             |                                                                     |
| - TGPS reconfiguration CFN                     | $(\text{Current CFN} + (256 - \text{TTI}/10\text{msec})) \bmod 256$ |
| - Transmission gap pattern sequence            |                                                                     |
| - TGPSI                                        | 2                                                                   |
| - TGPS status flag                             | inactive                                                            |
| - TGCFN                                        | Not present                                                         |

**RADIO BEARER RECONFIGURATION (Step 5)**

The contents of RADIO BEARER RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_DCH in PS" found in Annex A with the following exceptions:

| Information Element                                          | Value/remark                               |
|--------------------------------------------------------------|--------------------------------------------|
| → DPCCH compressed mode info                                 | 2                                          |
| → TGPSI                                                      | Active                                     |
| → TGCFN                                                      | (Current CFN + (256 – TTI/10msec)) mod 256 |
| → Transmission gap pattern sequence configuration parameters | GSM Carrier RSSI Measurement               |
| → TGMP                                                       | 62                                         |
| → TGPRC                                                      | 4                                          |
| → TGSN                                                       | 7                                          |
| → TGL1                                                       | 5                                          |
| → TGL2                                                       | 0                                          |
| → TGD                                                        | 3                                          |
| → TGPL1                                                      | 5                                          |
| → TGPL2                                                      | Mode 0                                     |
| → RPP                                                        | Mode 0                                     |
| → ITP                                                        | UL and DL                                  |
| → CHOICE UL/DL Mode                                          | SF/2                                       |
| → Downlink compressed mode method                            | SF/2                                       |
| → Uplink compressed mode method                              | B                                          |
| → Downlink frame type                                        | 2.0                                        |
| → DeltaSIR1                                                  | 1.0                                        |
| → DeltaSIRafter1                                             | Not Present                                |
| → DeltaSIR2                                                  | Not Present                                |
| → DeltaSIRafter2                                             | Not Present                                |
| → N-identify abort                                           | Not Present                                |
| → T-Reconfirm abort                                          | Not Present                                |

**PHYSICAL CHANNEL RECONFIGURATION FAILURE (Step 7)**

| Information Element          | Value/remark                                             |
|------------------------------|----------------------------------------------------------|
| Failure-cause                | Checked to see if set to "compressed mode runtime error" |
| → Protocol error information | Checked to see if it is absent                           |
| → Deleted TGPSI              | Checked to see if it is set to "2"                       |

**8.4.1.11.5 → Test requirement**

After step 6 the UE shall keep transmission gap pattern sequence configuration associated with TGPSI=1. It shall delete the transmission gap pattern sequence configuration associated with TGPSI=2, and delete the inter-RAT measurements corresponding to it. It shall transmit PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the uplink DCCH, with the IE "Failure-cause" set to "Compressed mode runtime error".

After step 7 the UE shall continue to send MEASUREMENT REPORT messages periodically, to report the UTRA RSSI value for the UARFCN in which cell 4 resides. The MEASUREMENT REPORT messages sent by the UE shall not contain CPICH RSCP readings for cell 4.

### ~~8.4.1.12 Measurement Control and Report: Compressed Mode Configuration Failure during transport channel reconfiguration procedure~~

#### ~~8.4.1.12.1 Definition~~

#### ~~8.4.1.12.2 Conformance requirement~~

~~During a transport channel reconfiguration procedure, the UTRAN might request the activation of a new transmission gap pattern sequence configuration. If the UE detects a runtime error due to overlapping compressed mode configuration, it shall delete the transmission gap pattern sequence configuration associated with highest value of TGPSI. The UE shall also terminate any inter-frequency / inter-RAT measurements corresponding to the deleted transmission gap pattern sequence. The UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM-RLC, with the cause value in IE "failure cause" set to "compressed mode runtime error".~~

#### ~~Reference~~

~~3GPP TS 25.331 clause 8.2.2, clause 8.2.11.2, clause 8.6.6.15~~

#### ~~8.4.1.12.3 Test purpose~~

~~To confirm that the UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the uplink DCCH using AM-RLC, if it receives a TRANSPORT CHANNEL RECONFIGURATION message which includes IE "DPCH compressed mode info" that causes an illegal overlap involving more than one parallel transmission gap pattern sequences. To confirm that the UE terminate any measurements corresponding to the deleted transmission gap pattern sequence.~~

#### ~~8.4.1.12.4 Method of test~~

#### ~~Initial Condition~~

~~System Simulator: 2 cells—Cell 1 and cell 4 are active.~~

~~UE: CS-DCCH+DTCH\_DCH (State 6-9) or PS-DCCH+DTCH\_DCH (State 6-10) as specified in TS34.108 clause 7.4, depending on the CN domain supported.~~

#### ~~Test Procedure~~

~~For this test case, the downlink transmission power settings shall follow that specified in table 8.4.1.11-1 in clause 8.4.1.11.4.~~

~~The UE is in the CELL\_DCH state in cell 1. SS sends a MEASUREMENT CONTROL message on the downlink DCCH to request the UE to start inter-frequency measurement for cell 4's CPICH Ec/No value, and also to report the UTRA RSSI in the UARFCN in which cell 4 resides. Simultaneously, the stored transmission gap pattern sequence configuration associated with TGPSI=1 is indicated to be activated in this message. The UE shall transmit MEASUREMENT REPORT messages periodically at 16 seconds interval to report the RSSI value of UTRA carrier in which cell 4 resides. Next, SS sends a second MEASUREMENT CONTROL message. In this message, a new measurement task is to be established for the measurement and reporting of "GSM carrier RSSI" on a periodic basis. A deactivated transmission pattern gap sequence configuration (with TGPSI=2) is associated with this new measurement task.~~

~~The SS transmits a TRANSPORT CHANNEL RECONFIGURATION message and commands the activation of transmission gap pattern sequence with TGPSI=2. The UE then shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM-RLC. In this message, the value of IE "failure cause" shall be set to "compressed mode runtime error". The UE shall terminate all inter-RAT measurement tasks associated with TGPSI=2. The UE shall continue to send MEASUREMENT REPORT messages to report the UTRA RSSI in the UARFCN in which cell 4 resides.~~

## Expected sequence

| Step | Direction |    | Message                                  | Comment                                                                                                                                                                                            |
|------|-----------|----|------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                          |                                                                                                                                                                                                    |
| 1    |           |    |                                          | UE is initially in CELL_DCH state.                                                                                                                                                                 |
| 2    |           | ←  | MEASUREMENT CONTROL                      | SS starts inter-frequency measurements for cell 4's CPICH Ec/No using transmission gap pattern sequence with TGPSI=1. Report the UTRA RSSI in the UARFCN in which cell 4 resides.                  |
| 3    |           | →  | MEASUREMENT REPORT                       | UE reports UTRA RSSI for the UARFCN of cell 4 periodically.                                                                                                                                        |
| 4    |           | ←  | MEASUREMENT CONTROL                      | SS assigns inter-RAT measurements for "GSM carrier RSSI". This measurement task is associated with transmission gap pattern sequence with TGPSI=2. The IE "TGPS status flag" is set to "Inactive". |
| 5    |           | ←  | TRANSPORT CHANNEL RECONFIGURATION        | SS specifies the parameters for transmission gap pattern sequence with TGPSI=2 and activates it simultaneously.                                                                                    |
| 6    |           |    |                                          | UE shall delete transmission gap pattern sequence configuration associated with TGPSI=2.                                                                                                           |
| 7    |           | →  | PHYSICAL CHANNEL RECONFIGURATION FAILURE | IE "Failure cause" shall be set to "Compressed mode runtime error".                                                                                                                                |
| 8    |           | →  | MEASUREMENT REPORT                       | The contents shall be the same as that in step 3.                                                                                                                                                  |

## Specific Message Contents

## MEASUREMENT CONTROL (Step 2)

| Information Element                                    | Value/Remark                                                                                                                  |
|--------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Measurement Identity                                   | 1                                                                                                                             |
| Measurement Command                                    | Setup                                                                                                                         |
| Measurement Reporting Mode                             |                                                                                                                               |
| — Measurement Reporting Transfer Mode                  | Acknowledged Mode RLC                                                                                                         |
| — Periodic Reporting / Event Trigger Reporting Mode    | Periodical Reporting                                                                                                          |
| Additional measurements list                           | Not Present                                                                                                                   |
| CHOICE measurement type                                | Inter-frequency measurement                                                                                                   |
| — Inter-frequency cell info list                       |                                                                                                                               |
| — CHOICE inter-frequency cell removal                  | No inter-frequency cells removed                                                                                              |
| — New inter-frequency info list                        |                                                                                                                               |
| — Inter-frequency cell id                              | 4                                                                                                                             |
| — Frequency info                                       |                                                                                                                               |
| — UARFCN uplink (Nu)                                   | UARFCN of the uplink frequency for cell 4                                                                                     |
| — UARFCN downlink (Nd)                                 | UARFCN of the downlink frequency for cell 4                                                                                   |
| — Cell info                                            |                                                                                                                               |
| — Cell individual offset                               | 0 dB                                                                                                                          |
| — Reference time difference to cell                    | 0 chips                                                                                                                       |
| — Read SFN Indicator                                   | FALSE                                                                                                                         |
| — CHOICE Mode                                          | FDD                                                                                                                           |
| — Primary CPICH Info                                   |                                                                                                                               |
| — Primary Scrambling Code                              | Set to same code as used for cell 4                                                                                           |
| — Primary CPICH TX power                               | Not Present                                                                                                                   |
| — TX Diversity Indicator                               | FALSE                                                                                                                         |
| — Cells for measurement                                |                                                                                                                               |
| — Inter-frequency cell id                              | 4                                                                                                                             |
| — Inter-frequency measurement quantity                 |                                                                                                                               |
| — CHOICE reporting criteria                            | Inter-frequency reporting criteria                                                                                            |
| — Filter Coefficient                                   | 0                                                                                                                             |
| — Measurement quantity for frequency quality estimate  | CPICH Ec/No                                                                                                                   |
| — Inter-frequency reporting quantity                   |                                                                                                                               |
| — UTRA Carrier RSSI                                    | TRUE                                                                                                                          |
| — Frequency quality estimate                           | FALSE                                                                                                                         |
| — Non frequency related cell reporting quantities      |                                                                                                                               |
| — SFN-SFN observed time difference reporting indicator | No report                                                                                                                     |
| — Cell synchronisation information reporting indicator | FALSE                                                                                                                         |
| — Cell Identity reporting indicator                    | FALSE                                                                                                                         |
| — CPICH Ec/No reporting indicator                      | FALSE                                                                                                                         |
| — CPICH RSCP reporting indicator                       | FALSE                                                                                                                         |
| — Pathloss reporting indicator                         | FALSE                                                                                                                         |
| — Reporting cell status                                |                                                                                                                               |
| — CHOICE reported cell                                 | Report cells within active and/or monitored set on used frequency or within active and/or monitored set on non-used frequency |
| — Maximum number of reported cells                     | 2                                                                                                                             |
| — Measurement validity                                 | Not present                                                                                                                   |
| — Inter-frequency set update                           | Not present                                                                                                                   |
| — CHOICE report criteria                               | Periodic reporting criteria                                                                                                   |
| — Amount of reporting                                  | Infinity                                                                                                                      |
| — Reporting interval                                   | 16 seconds                                                                                                                    |
| DPCH compressed mode status info                       |                                                                                                                               |
| — TGPS reconfiguration CFN                             | (Current CFN+(256—TTI/10msec)) mod 256                                                                                        |
| — Transmission gap pattern sequence                    |                                                                                                                               |
| — TGPSI                                                | 1                                                                                                                             |
| — TGPS Status Flag                                     | Active                                                                                                                        |
| — TGCFN                                                | (Current CFN+(256—TTI/10msec)) mod 256                                                                                        |

## MEASUREMENT REPORT (Step 3 and Step 8)

| Information Element                      | Value/Remarks                                                          |
|------------------------------------------|------------------------------------------------------------------------|
| Measurement identity                     | Check to see if set to "1"                                             |
| Measured Results                         |                                                                        |
| CHOICE measurement                       | Check to see if set to "Inter-frequency measured results list"         |
| Inter-frequency measurement results      |                                                                        |
| Frequency info                           |                                                                        |
| UARFCN (uplink)                          | Check to see if set to the UARFCN of the uplink frequency for cell 4   |
| UARFCN (downlink)                        | Check to see if set to the UARFCN of the downlink frequency for cell 4 |
| UTRA carrier RSSI                        | Check to see if it is present                                          |
| Inter-frequency cell measurement results |                                                                        |
| Cell measured results                    |                                                                        |
| Cell Identity                            | Check to see if it is absent                                           |
| SFN-SFN observed time difference         | Check to see if it is absent                                           |
| Cell synchronisation information         | Check to see if it is absent                                           |
| Primary CPICH Info                       |                                                                        |
| Primary Scrambling Code                  | Check to see if set to the same code for cell 4                        |
| CPICH Ec/No                              | Check to see if it is absent                                           |
| CPICH RSCP                               | Check to see if it is absent                                           |
| Pathloss                                 | Check to see if it is absent                                           |
| Measured Results on RACH                 | Check to see if it is absent                                           |
| Event Results                            | Check to see if it is absent                                           |

## MEASUREMENT CONTROL (Step 4)

| Information Element                            | Value/Remark                              |
|------------------------------------------------|-------------------------------------------|
| Measurement Identity                           | 2                                         |
| Measurement Command                            | Setup                                     |
| Measurement Reporting Mode                     |                                           |
| — Measurement Reporting Transfer Mode          | Acknowledged Mode RLC                     |
| - Periodic Reporting / Event Trigger Reporting | Periodical reporting                      |
| - Mode                                         |                                           |
| Additional measurements list                   | Not Present                               |
| CHOICE measurement type                        |                                           |
| - inter-RAT measurement                        |                                           |
| — inter-RAT measurement object list            |                                           |
| — CHOICE Inter-RAT Cell Removal                | Remove no inter-RAT cells                 |
| - inter-RAT cell id                            | 7                                         |
| CHOICE Radio Access Technology                 | GSM                                       |
| - Cell individual offset                       | 0                                         |
| - Cell selection and re-selection info         | Not present                               |
| — BSIC                                         | BSIC1                                     |
| - Band indicator                               | DCS 1800 band used                        |
| - BCCH ARFCN                                   | 1                                         |
| — Cell for measurement                         | Not present                               |
| - inter-RAT measurement quantity               |                                           |
| — Measurement quantity for UTRAN quality       | Not present                               |
| — estimate                                     |                                           |
| — CHOICE system                                | GSM                                       |
| - Measurement quantity                         | GSM carrier RSSI                          |
| - Filter coefficient                           | 0                                         |
| - BSIC verification required                   | not required                              |
| - inter-RAT reporting quantity                 |                                           |
| — CHOICE system                                | GSM                                       |
| - Observed time difference to to GSM           | FALSE                                     |
| - cell reporting indicator                     |                                           |
| - GSM carrier RSSI reporting indicator         | TRUE                                      |
| - Reporting cell status                        |                                           |
| — CHOICE reported cell                         |                                           |
| - Reported cells within active set or within   |                                           |
| — virtual active set or of the other RAT       |                                           |
| - Maximum number of reported cells             | 6                                         |
| — CHOICE report criteria                       |                                           |
| - Periodical reporting criteria                |                                           |
| - Amount of reporting                          | infinity                                  |
| - Reporting interval                           | 1000                                      |
| Physical channel information elements          |                                           |
| - DPCH compressed mode status info             |                                           |
| - TGPS reconfiguration CFN                     | (Current CFN + (256 — TTI/10msec))mod 256 |
| - Transmission gap pattern sequence            |                                           |
| - TGPSI                                        | 2                                         |
| - TGPS status flag                             | inactive                                  |
| - TGCFN                                        | Not present                               |

## TRANSPORT CHANNEL RECONFIGURATION

The contents of TRANSPORT CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_DCH in PS" found in Annex A with the following exceptions:

| Information Element                                          | Value/remark                               |
|--------------------------------------------------------------|--------------------------------------------|
| → DPCCH compressed mode info                                 | 2                                          |
| → TGPSI                                                      | Active                                     |
| → TGPS Status Flag                                           | (Current CFN + (256 – TTI/10msec)) mod 256 |
| → TGCFN                                                      |                                            |
| → Transmission gap pattern sequence configuration parameters |                                            |
| → TGMP                                                       | GSM Carrier RSSI Measurement               |
| → TGPRC                                                      | 62                                         |
| → TGSN                                                       | 4                                          |
| → TGL1                                                       | 7                                          |
| → TGL2                                                       | 5                                          |
| → TGD                                                        | 0                                          |
| → TGPL1                                                      | 3                                          |
| → TGPL2                                                      | 5                                          |
| → RPP                                                        | Mode 0                                     |
| → ITP                                                        | Mode 0                                     |
| → CHOICE UL/DL Mode                                          | UL and DL                                  |
| → Downlink compressed mode method                            | SF/2                                       |
| → Uplink compressed mode method                              | SF/2                                       |
| → Downlink frame type                                        | B                                          |
| → DeltaSIR1                                                  | 2.0                                        |
| → DeltaSIRafter1                                             | 1.0                                        |
| → DeltaSIR2                                                  | Not Present                                |
| → DeltaSIRafter2                                             | Not Present                                |
| → N-identify abort                                           | Not Present                                |
| → T-Reconfirm abort                                          | Not Present                                |

#### PHYSICAL CHANNEL RECONFIGURATION FAILURE (Step 7)

| Information Element          | Value/remark                                             |
|------------------------------|----------------------------------------------------------|
| Failure-cause                | Checked to see if set to "compressed mode runtime error" |
| → Protocol error information | Checked to see if it is absent                           |
| → Deleted TGPSI              | Checked to see if it is set to "2"                       |

#### 8.4.1.12.5 → Test requirement

After step 6 the UE shall keep transmission gap pattern sequence configuration associated with TGPSI=1. It shall delete the transmission gap pattern sequence configuration associated with TGPSI=2, and delete the inter-RAT measurements corresponding to it. It shall transmit PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the uplink DCCH, with the IE "Failure-cause" set to "Compressed mode runtime error".

After step 7 the UE shall continue to send MEASUREMENT REPORT messages periodically, to report the UTRA RSSI value for the UARFCN in which cell 4 resides. The, MEASUREMENT REPORT messages sent by the UE shall not contain CPICH RSCP readings for cell 4.



### 8.4.1.13 Measurement Control and Report: Compressed Mode Configuration Failure during physical channel reconfiguration procedure

#### 8.4.1.13.1 Definition

#### 8.4.1.13.2 Conformance requirement

During a physical channel reconfiguration procedure, the UTRAN might request the activation of a new transmission gap pattern sequence configuration. If the UE detects a runtime error due to overlapping compressed mode configuration, it shall delete the transmission gap pattern sequence configuration associated with highest value of TGPSI. The UE shall also terminate any inter-frequency / inter-RAT measurements corresponding to the deleted transmission gap pattern sequence. The UE shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM-RLC, with the IE "failure cause" set to "compressed mode runtime error".

#### Reference

3GPP TS 25.331 clause 8.2.2, clause 8.2.11.2, clause 8.6.6.14

#### 8.4.1.13.3 Test purpose

To confirm that the UE transmits a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the uplink DCCH using AM-RLC, if it receives a PHYSICAL CHANNEL RECONFIGURATION message which includes IE "DPCH compressed mode info" that causes an illegal overlap involving more than one parallel transmission gap pattern sequences. To confirm that the UE terminate any inter-frequency measurements corresponding to the deleted transmission gap pattern sequence

#### 8.4.1.13.4 Method of test

##### Initial Condition

System Simulator: 2 cells—Cell 1 and cell 4 are active.

UE: CS-DCCH+DTCH\_DCH (State 6-9) or PS-DCCH+DTCH\_DCH (State 6-10) as specified in TS34.108 clause 7.4, depending on the CN domain supported.

##### Test Procedure

For this test case, the downlink transmission power settings shall follow that specified in table 8.4.1.11-1 in clause 8.4.1.11.4.

The UE is in the CELL\_DCH state in cell 1. SS sends a MEASUREMENT CONTROL message on the downlink DCCH to request the UE to start inter-frequency measurement for cell 4's CPICH Ec/No value, and also to report the UTRA RSSI in the UARFCN in which cell 4 resides. Simultaneously, the stored transmission gap pattern sequence configuration associated with TGPSI=1 is indicated to be activated in this message. The UE shall transmit MEASUREMENT REPORT messages periodically at 16 seconds interval to report the RSSI value of UTRA carrier in which cell 4 resides. Next, SS sends a second MEASUREMENT CONTROL message. In this message, a new measurement task is to be established for the measurement and reporting of "GSM carrier RSSI" value on a periodic basis. A deactivated transmission pattern gap sequence configuration (with TGPSI=2) is associated with this new measurement task.

The SS transmits a PHYSICAL CHANNEL RECONFIGURATION message and commands the activation of transmission gap pattern sequence with TGPSI=2. The UE then shall transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM-RLC. In this message, the value of IE "failure cause" shall be set to "compressed mode runtime error". The UE shall terminate all inter-RAT measurement tasks associated with TGPSI=2. The UE shall continue to send MEASUREMENT REPORT messages to report the UTRA RSSI in the UARFCN in which cell 4 resides.

## Expected sequence

| Step | Direction |    | Message                                  | Comment                                                                                                                                                                                                  |
|------|-----------|----|------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                          |                                                                                                                                                                                                          |
| 1    |           |    |                                          | UE is initially in CELL_DCH state.                                                                                                                                                                       |
| 2    |           | ←  | MEASUREMENT CONTROL                      | SS starts inter-frequency measurements for cell 4's CPICH Ec/No using transmission gap pattern sequence with TGPSI=1. SS commands UE to report the UTRA RSSI in the UARFCN in which cell 4 resides.      |
| 3    |           | →  | MEASUREMENT REPORT                       | UE reports UTRA RSSI for the UARFCN of cell 4 periodically.                                                                                                                                              |
| 4    |           | ←  | MEASUREMENT CONTROL                      | SS assigns inter-frequency measurements for "GSM carrier RSSI". This measurement task is associated with transmission gap pattern sequence with TGPSI=2. The IE "TGPS status flag" is set to "Inactive". |
| 5    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION         | SS specifies the parameters for transmission gap pattern sequence with TGPSI=2 and activates it simultaneously                                                                                           |
| 6    |           |    |                                          | UE shall delete transmission gap pattern sequence configuration associated with TGPSI=2.                                                                                                                 |
| 7    |           | →  | PHYSICAL CHANNEL RECONFIGURATION FAILURE | IE "Failure cause" shall be set to "Compressed mode runtime error"                                                                                                                                       |
| 8    |           | →  | MEASUREMENT REPORT                       | The contents shall be the same as that in step 3.                                                                                                                                                        |

## Specific Message Contents

## MEASUREMENT CONTROL (Step 2)

| Information Element                                    | Value/Remark                                                                                                                  |
|--------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Measurement Identity                                   | 1                                                                                                                             |
| Measurement Command                                    | Setup                                                                                                                         |
| Measurement Reporting Mode                             |                                                                                                                               |
| — Measurement Reporting Transfer Mode                  | Acknowledged Mode RLC                                                                                                         |
| — Periodic Reporting / Event Trigger Reporting Mode    | Periodical Reporting                                                                                                          |
| Additional measurements list                           | Not Present                                                                                                                   |
| CHOICE measurement type                                | Inter-frequency measurement                                                                                                   |
| — Inter-frequency cell info list                       |                                                                                                                               |
| — CHOICE inter-frequency cell removal                  | No inter-frequency cells removed                                                                                              |
| — New inter-frequency info list                        |                                                                                                                               |
| — Inter-frequency cell id                              | 4                                                                                                                             |
| — Frequency info                                       |                                                                                                                               |
| — UARFCN uplink (Nu)                                   | UARFCN of the uplink frequency for cell 4                                                                                     |
| — UARFCN downlink (Nd)                                 | UARFCN of the downlink frequency for cell 4                                                                                   |
| — Cell info                                            |                                                                                                                               |
| — Cell individual offset                               | 0 dB                                                                                                                          |
| — Reference time difference to cell                    | 0 chips                                                                                                                       |
| — Read SFN Indicator                                   | FALSE                                                                                                                         |
| — CHOICE Mode                                          | FDD                                                                                                                           |
| — Primary CPICH Info                                   |                                                                                                                               |
| — Primary Scrambling Code                              | Set to same code as used for cell 4                                                                                           |
| — Primary CPICH TX power                               | Not Present                                                                                                                   |
| — TX Diversity Indicator                               | FALSE                                                                                                                         |
| — Cells for measurement                                |                                                                                                                               |
| — Inter-frequency cell id                              | 4                                                                                                                             |
| — Inter-frequency measurement quantity                 |                                                                                                                               |
| — CHOICE reporting criteria                            | Inter-frequency reporting criteria                                                                                            |
| — Filter Coefficient                                   | 0                                                                                                                             |
| — Measurement quantity for frequency quality estimate  | CPICH Ec/No                                                                                                                   |
| — Inter-frequency reporting quantity                   |                                                                                                                               |
| — UTRA Carrier RSSI                                    | TRUE                                                                                                                          |
| — Frequency quality estimate                           | FALSE                                                                                                                         |
| — Non frequency related cell reporting quantities      |                                                                                                                               |
| — SFN-SFN observed time difference reporting indicator | No report                                                                                                                     |
| — Cell synchronisation information reporting indicator | FALSE                                                                                                                         |
| — Cell Identity reporting indicator                    | FALSE                                                                                                                         |
| — CPICH Ec/No reporting indicator                      | FALSE                                                                                                                         |
| — CPICH RSCP reporting indicator                       | FALSE                                                                                                                         |
| — Pathloss reporting indicator                         | FALSE                                                                                                                         |
| — Reporting cell status                                |                                                                                                                               |
| — CHOICE reported cell                                 | Report cells within active and/or monitored set on used frequency or within active and/or monitored set on non-used frequency |
| — Maximum number of reported cells                     | 2                                                                                                                             |
| — Measurement validity                                 | Not present                                                                                                                   |
| — Inter-frequency set update                           | Not present                                                                                                                   |
| — CHOICE report criteria                               | Periodic reporting criteria                                                                                                   |
| — Amount of reporting                                  | Infinity                                                                                                                      |
| — Reporting interval                                   | 16 seconds                                                                                                                    |
| DPCH compressed mode status info                       |                                                                                                                               |
| — TGPS reconfiguration CFN                             | (Current CFN+(256—TTI/10msec)) mod 256                                                                                        |
| — Transmission gap pattern sequence                    |                                                                                                                               |
| — TGPSI                                                | 1                                                                                                                             |
| — TGPS Status Flag                                     | Active                                                                                                                        |
| — TGCFN                                                | (Current CFN+(256—TTI/10msec)) mod 256                                                                                        |

## MEASUREMENT REPORT (Step 3 and Step 8)

| Information Element                      | Value/Remarks                                                          |
|------------------------------------------|------------------------------------------------------------------------|
| Measurement identity                     | Check to see if set to "1"                                             |
| Measured Results                         |                                                                        |
| CHOICE measurement                       | Check to see if set to "Inter-frequency measured results list"         |
| Inter-frequency measurement results      |                                                                        |
| Frequency info                           |                                                                        |
| UARFCN (uplink)                          | Check to see if set to the UARFCN of the uplink frequency for cell 4   |
| UARFCN (downlink)                        | Check to see if set to the UARFCN of the downlink frequency for cell 4 |
| UTRA carrier RSSI                        | Check to see if it is present                                          |
| Inter-frequency cell measurement results |                                                                        |
| Cell measured results                    |                                                                        |
| Cell Identity                            | Check to see if it is absent                                           |
| SFN-SFN observed time difference         | Check to see if it is absent                                           |
| Cell synchronisation information         | Check to see if it is absent                                           |
| Primary CPICH Info                       |                                                                        |
| Primary Scrambling Code                  | Check to see if set to the same code for cell 4                        |
| CPICH Ec/No                              | Check to see if it is absent                                           |
| CPICH RSCP                               | Check to see if it is absent                                           |
| Pathloss                                 | Check to see if it is absent                                           |
| Measured Results on RACH                 | Check to see if it is absent                                           |
| Event Results                            | Check to see if it is absent                                           |

## MEASUREMENT CONTROL (Step 4)

| Information Element                            | Value/Remark                              |
|------------------------------------------------|-------------------------------------------|
| Measurement Identity                           | 2                                         |
| Measurement Command                            | Setup                                     |
| Measurement Reporting Mode                     |                                           |
| — Measurement Reporting Transfer Mode          | Acknowledged Mode RLC                     |
| - Periodic Reporting / Event Trigger Reporting | Periodical reporting                      |
| - Mode                                         |                                           |
| Additional measurements list                   | Not Present                               |
| CHOISE measurement type                        |                                           |
| - inter-RAT measurement                        |                                           |
| — inter-RAT measurement object list            |                                           |
| — CHOISE Inter-RAT Cell Removal                | Remove no inter-RAT cells                 |
| - inter-RAT cell id                            | 7                                         |
| CHOISE Radio Access Technology                 | GSM                                       |
| - Cell individual offset                       | 0                                         |
| - Cell selection and re-selection info         | Not present                               |
| — BSIC                                         | BSIC1                                     |
| - Band indicator                               | DCS 1800 band used                        |
| - BCCH ARFCN                                   | 1                                         |
| — Cell for measurement                         | Not present                               |
| - inter-RAT measurement quantity               |                                           |
| — Measurement quantity for UTRAN quality       | Not present                               |
| — estimate                                     |                                           |
| — CHOISE system                                | GSM                                       |
| - Measurement quantity                         | GSM carrier RSSI                          |
| - Filter coefficient                           | 0                                         |
| - BSIC verification required                   | not required                              |
| - inter-RAT reporting quantity                 |                                           |
| — CHOISE system                                | GSM                                       |
| - Observed time difference to to GSM           | FALSE                                     |
| - cell reporting indicator                     |                                           |
| - GSM carrier RSSI reporting indicator         | TRUE                                      |
| - Reporting cell status                        |                                           |
| — CHOISE reported cell                         |                                           |
| - Reported cells within active set or within   |                                           |
| - virtual active set or of the other RAT       |                                           |
| - Maximum number of reported cells             | 6                                         |
| — CHOISE report criteria                       |                                           |
| - Periodical reporting criteria                |                                           |
| - Amount of reporting                          | infinity                                  |
| - Reporting interval                           | 1000                                      |
| Physical channel information elements          |                                           |
| - DPCH compressed mode status info             |                                           |
| - TGPS reconfiguration CFN                     | (Current CFN + (256 — TTI/10msec))mod 256 |
| - Transmission gap pattern sequence            |                                           |
| - TGPSI                                        | 2                                         |
| - TGPS status flag                             | inactive                                  |
| - TGCFN                                        | Not present                               |

### PHYSICAL CHANNEL RECONFIGURATION (Step 5)

The contents of PHYSICAL CHANNEL RECONFIGURATION message in this test case is identical to the message sub-type title "Packet to CELL\_DCH from CELL\_DCH in PS" found in Annex A with the following exceptions:

| Information Element                                          | Value/remark                               |
|--------------------------------------------------------------|--------------------------------------------|
| → DPCCH compressed mode info                                 | 2                                          |
| → TGPSI                                                      | Active                                     |
| → TGCFN                                                      | (Current CFN + (256 – TTI/10msec)) mod 256 |
| → Transmission gap pattern sequence configuration parameters | FDD-Measurement                            |
| → TGMP                                                       | 62                                         |
| → TGPRC                                                      | 4                                          |
| → TGSN                                                       | 7                                          |
| → TGL1                                                       | 5                                          |
| → TGL2                                                       | 0                                          |
| → TGD                                                        | 3                                          |
| → TGPL1                                                      | 5                                          |
| → TGPL2                                                      | Mode-0                                     |
| → RPP                                                        | Mode-0                                     |
| → ITP                                                        | UL and DL                                  |
| → CHOICE UL/DL Mode                                          | SF/2                                       |
| → Downlink compressed mode method                            | SF/2                                       |
| → Uplink compressed mode method                              | B                                          |
| → Downlink frame type                                        | 2.0                                        |
| → DeltaSIR1                                                  | 1.0                                        |
| → DeltaSIRafter1                                             | Not Present                                |
| → DeltaSIR2                                                  | Not Present                                |
| → DeltaSIRafter2                                             | Not Present                                |
| → N identify abort                                           | Not Present                                |
| → T-Reconfirm abort                                          | Not Present                                |

### PHYSICAL CHANNEL RECONFIGURATION FAILURE (Step 7)

| Information Element          | Value/remark                                             |
|------------------------------|----------------------------------------------------------|
| Failure-cause                | Checked to see if set to "compressed mode runtime error" |
| → Protocol error information | Checked to see if it is absent                           |
| → Deleted TGPSI              | Checked to see if it is set to "2"                       |

#### 8.4.1.13.5 → Test requirement

After step 6 the UE shall keep transmission gap pattern sequence configuration associated with TGPSI=1. It shall delete the transmission gap pattern sequence configuration associated with TGPSI=2, and delete the inter-RAT measurements corresponding to it. It shall transmit PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the uplink DCCH, with the IE "Failure-cause" set to "Compressed mode runtime error".

After step 7 the UE shall continue to send MEASUREMENT REPORT messages periodically, to report the UTRA RSSI value for the UARFCN in which cell 4 resides. The MEASUREMENT REPORT messages sent by the UE shall not contain the CPICH RSCP readings for cell 4.

#### 8.4.1.14 ~~Measurement Control and Report: Cell forbidden to affect reporting range~~

##### 8.4.1.14.1 ~~Definition~~

##### 8.4.1.14.2 ~~Conformance requirement~~

When event 1A is ordered by the UTRAN in a MEASUREMENT CONTROL message, the UE shall send a MEASUREMENT REPORT message when a primary CPICH measured has entered the specified reporting range. The UTRAN can request that a certain primary CPICH be forbidden to affect the reporting range used for event 1A measurement reporting. However, the UE shall ignore such a request from the UTRAN if two conditions are fulfilled – (a) the primary CPICH concerned is included in the active set, and (b) all cells in the active set are defined as primary CPICHs forbidden to affect the reporting range.

##### Reference

3GPP TS 25.331 clause 14.1.2.1, clause 14.1.5.4

##### 8.4.1.14.3 ~~Test Purpose~~

To confirm that the UE reports the triggering of event 1A to the SS, if a primary CPICH currently measured by the UE enters the reporting range. To confirm that the UE ignores that a primary CPICH is forbidden to affect the reporting range when (a) the primary CPICH concerned is included in active set and (b) all cells in the active set are defined as primary CPICHs forbidden to affect the reporting range.

##### 8.4.1.14.4 ~~Method of test~~

##### Initial Condition

System Simulator: 3 cells – Cell 1, cell 2 and cell 3 are active.

UE: CS-DCCH+DTCH\_DCH (State 6-9) or PS-DCCH+DTCH\_DCH (State 6-10) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE.

##### Test Procedure

Table 8.4.1.14-1 illustrates the downlink power to be applied for the 3 cells at various time instants of the test execution. Column marked "T0" denotes the initial conditions, while columns marked "T1", "T2" and "T3" are to be applied subsequently. The exact instants on which these values shall be applied are described in the text in this clause.

**Table 8.4.1.14-1**

| Parameter              | Unit          | Cell 1 |     |     |     | Cell 2 |     |     |     | Cell 3 |     |     |     |
|------------------------|---------------|--------|-----|-----|-----|--------|-----|-----|-----|--------|-----|-----|-----|
|                        |               | T0     | T1  | T2  | T3  | T0     | T1  | T2  | T3  | T0     | T1  | T2  | T3  |
| UTRA RF Channel Number |               | Ch. 1  |     |     |     | Ch. 1  |     |     |     | Ch. 1  |     |     |     |
| CPICH Ec               | dBm /3.84 MHz | -60    | -60 | -85 | -60 | -85    | -70 | -60 | -85 | -70    | -70 | -85 | -70 |

The UE is initially in CELL\_DCH state of cell 1.

SS sends a MEASUREMENT CONTROL message with cell 1, cell 2 and cell 3 listed in IE "intra-frequency cell info list". In this message the IE "CHOICE reporting criteria" is set to "intra-frequency measurement report criteria", with the IE "intra-frequency event identity" set to "1A". The IE "reporting range" is set to 5 dB in the MEASUREMENT CONTROL message. The UE shall send a MEASUREMENT REPORT on the uplink DCCH, which contains the IE "Event results" to report that intra-frequency event 1A is triggered by cell 3.

SS executes the active set update procedure, requesting that cell 3 be added to the active set. The UE shall respond with ACTIVE SET UPDATE COMPLETE message on the uplink DCCH and then include cell 3 into its current active set. SS configures itself according to the values in columns "T1" shown above. The UE shall transmit a MEASUREMENT REPORT message on the uplink DCCH to report the triggering of intra-frequency event 1A. In these messages, the IE "Events results" shall indicate that intra-frequency event 1A is triggered by cell 2. Upon reception of MEASUREMENT REPORT message, SS sends ACTIVE SET UPDATE message to request cell 2 to be added to the active set. The UE shall respond with ACTIVE SET UPDATE COMPLETE message on the uplink DCCH and then include cell 2 into its current active set.

SS sends a MEASUREMENT CONTROL message to command that all cells in the active set are forbidden to update the reporting range for event 1A. SS configures itself according to the values in columns "T2" shown above. The UE shall not transmit a MEASUREMENT REPORT message on the uplink to report the triggering of intra-frequency reporting event 1A. SS reconfigures itself according to the values in column "T3" shown in table 8.4.1.14-1 above. The UE shall transmit MEASUREMENT REPORT message to report triggering intra-frequency event identity 1A, and also to report the CPICH RSCP readings for cell 1, cell 2 and cell 3 in IE "Measured results".



## Expected sequence

| Step | Direction |    | Message                    | Comment                                                                                                                                                                                                                                                                   |
|------|-----------|----|----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                            |                                                                                                                                                                                                                                                                           |
| 1    |           |    |                            | UE is initially in CELL_DCH state in cell 1.                                                                                                                                                                                                                              |
| 2    |           |    | Void                       |                                                                                                                                                                                                                                                                           |
| 3    |           |    | Void                       |                                                                                                                                                                                                                                                                           |
| 4    |           |    | Void                       |                                                                                                                                                                                                                                                                           |
| 5    |           | ←  | MEASUREMENT CONTROL        | Cell 1, cell 2 and cell 3 are listed in IE "Intra-frequency cell info list". The IE "CHOICE reporting criteria" is set to "Intra-frequency measurement reporting criteria" and IE "Intra-frequency event identity" is set to "1A", with IE "reporting range" set to 5 dB. |
| 6    |           | →  | MEASUREMENT REPORT         | UE shall report that cell 3 has entered the reporting range for intra-frequency reporting event 1A.                                                                                                                                                                       |
| 7    |           | ←  | ACTIVE SET UPDATE          | UE shall add cell 3 into the active set                                                                                                                                                                                                                                   |
| 8    |           | →  | ACTIVE SET UPDATE COMPLETE |                                                                                                                                                                                                                                                                           |
| 9    |           |    |                            | SS configures itself according to the settings stated in column "T1" of table 8.4.1.14-1.                                                                                                                                                                                 |
| 10   |           | →  | MEASUREMENT REPORT         | UE shall report that cell 2 has entered the reporting range for intra-frequency reporting event 1A.                                                                                                                                                                       |
| 10a  |           | ←  | ACTIVE SET UPDATE          | UE shall add cell 2 into the active set                                                                                                                                                                                                                                   |
| 10b  |           | →  | ACTIVE SET UPDATE COMPLETE |                                                                                                                                                                                                                                                                           |
| 11   |           | ←  | MEASUREMENT CONTROL        | SS forbids all cells in active list to affect the reporting range                                                                                                                                                                                                         |
| 12   |           |    |                            | SS configures itself according to the settings stated in column "T2" of table 8.4.1.14-1.                                                                                                                                                                                 |
| 13   |           |    |                            | SS verifies that no MEASUREMENT REPORT messages are received in the uplink direction                                                                                                                                                                                      |
| 14   |           |    |                            | SS configures itself according to the settings stated in column "T3" of table 8.4.1.14-1.                                                                                                                                                                                 |
| 15   |           | →  | MEASUREMENT REPORT         | UE shall report that cell 3 has entered the reporting range for intra-frequency reporting event 1A.                                                                                                                                                                       |

## Specific Message Contents

## MEASUREMENT CONTROL (Step 5)

The contents of MEASUREMENT CONTROL message for this test step is identical to the same message found in Annex A with the following exceptions:

| Information Element                                    | Value/Remark                        |
|--------------------------------------------------------|-------------------------------------|
| RRC transaction identifier                             | 1                                   |
| Measurement Identity                                   | 1                                   |
| Measurement Command                                    | Setup                               |
| Measurement Reporting Mode                             |                                     |
| — Measurement Reporting Transfer Mode                  | Acknowledged Mode RLC               |
| — Periodic Reporting / Event Trigger Reporting Mode    | Event Trigger                       |
| Additional measurements list                           | Not Present                         |
| CHOICE measurement type                                | Intra-frequency measurement         |
| — Intra-frequency cell info list                       |                                     |
| — CHOICE intra-frequency cell removal                  | Remove no intra-frequency           |
| — New intra-frequency info list                        |                                     |
| — Intra-frequency cell id                              | 1                                   |
| — Cell info                                            |                                     |
| — Cell individual offset                               | 0 dB                                |
| — Reference time difference to cell                    | 0 chips                             |
| — Read SFN Indicator                                   | FALSE                               |
| — CHOICE Mode                                          | FDD                                 |
| — Primary CPICH Info                                   |                                     |
| — Primary Scrambling Code                              | Set to same code as used for cell 1 |
| — Primary CPICH TX power                               | Not Present                         |
| — TX Diversity Indicator                               | FALSE                               |
| — Intra-frequency cell id                              | 2                                   |
| — Cell info                                            |                                     |
| — Cell individual offset                               | 0 dB                                |
| — Reference time difference to cell                    | 0 chips                             |
| — Read SFN Indicator                                   | FALSE                               |
| — CHOICE Mode                                          | FDD                                 |
| — Primary CPICH Info                                   |                                     |
| — Primary Scrambling Code                              | Set to same code as used for cell 2 |
| — Primary CPICH TX power                               | Not Present                         |
| — TX Diversity Indicator                               | FALSE                               |
| — Intra-frequency cell id                              | 3                                   |
| — Cell info                                            |                                     |
| — Cell individual offset                               | 0 dB                                |
| — Reference time difference to cell                    | 0 chips                             |
| — Read SFN Indicator                                   | FALSE                               |
| — CHOICE Mode                                          | FDD                                 |
| — Primary CPICH Info                                   |                                     |
| — Primary Scrambling Code                              | Set to same code as used for cell 3 |
| — Primary CPICH TX power                               | Not Present                         |
| — TX Diversity Indicator                               | FALSE                               |
| — Cell for measurement                                 |                                     |
| — Intra-frequency cell id                              | 1, 2 and 3                          |
| — Intra-frequency measurement quantity                 |                                     |
| — Filter Coefficient                                   | 0                                   |
| — Measurement quantity                                 | CPICH RSCP                          |
| — Intra-frequency reporting quantity                   |                                     |
| — Reporting quantities for active set cells            |                                     |
| — SFN-SFN observed time difference reporting indicator | No report                           |
| — Cell synchronisation information reporting indicator | FALSE                               |
| — Cell identity reporting indicator                    | FALSE                               |
| — CPICH Ec/No reporting indicator                      | FALSE                               |
| — CPICH RSCP reporting indicator                       | FALSE                               |
| — Pathloss reporting indicator                         | FALSE                               |
| — Reporting quantities for monitored set cells         |                                     |
| — SFN-SFN observed time difference reporting indicator | No report                           |
| — Cell synchronisation information reporting indicator | FALSE                               |
| — Cell identity reporting indicator                    | FALSE                               |
| — CPICH Ec/No reporting indicator                      | FALSE                               |
| — CPICH RSCP reporting indicator                       | TRUE                                |
| — Pathloss reporting indicator                         | FALSE                               |
| — Reporting quantities for detected cells              | Not present                         |

| Information Element                         | Value/Remark                                        |
|---------------------------------------------|-----------------------------------------------------|
| → Reporting cell status                     | Not present                                         |
| → Measurement validity                      | Not present                                         |
| → CHOICE report criteria                    | Intra-frequency measurement reporting criteria      |
| → Parameters required for each events       |                                                     |
| → Intra-frequency event identity            | 1a                                                  |
| → Triggering conditions 1                   | Not Present                                         |
| → Triggering conditions 2                   | Active set cells and monitored set cells            |
| → Reporting range                           | 16.0 dB                                             |
| → Cells forbidden to affect reporting range | Not Present                                         |
| → W                                         | 0                                                   |
| → Hysteresis                                | 0 dB                                                |
| → Threshold used frequency                  | Not Present                                         |
| → Reporting deactivation threshold          | 3                                                   |
| → Replacement activation threshold          | Not Present                                         |
| → Time to trigger                           | 0 msec                                              |
| → Amount of reporting                       | 1                                                   |
| → Reporting interval                        | 0                                                   |
| → Reporting cell status                     |                                                     |
| → CHOICE reported cells                     | Report cells within monitored set on used frequency |
| → Maximum number of reported cells          | e3                                                  |
| DPCH compressed mode status info            | Not Present                                         |

## MEASUREMENT REPORT (Step 6)

| Information Element                   | Value/Remarks                                                      |
|---------------------------------------|--------------------------------------------------------------------|
| RRC transaction identifier            | Check to see if set to 1                                           |
| Measurement identity                  | Check to see if set to 1                                           |
| Measured Results                      |                                                                    |
| → CHOICE measurement                  | Check to see if set to "Intra-frequency measured results list"     |
| → Intra-frequency measurement results |                                                                    |
| → Cell measured results               |                                                                    |
| → Cell Identity                       | Check to see if it is absent                                       |
| → SFN-SFN observed time difference    | Check to see if this IE is absent                                  |
| → Cell synchronisation information    | Check to see if this IE is absent                                  |
| → Primary CPICH Info                  |                                                                    |
| → Primary Scrambling Code             | Check to see if it's the same code for cell 3                      |
| → CPICH Ec/No                         | Check to see if this IE is absent                                  |
| → CPICH RSCP                          | Check to see if this IE is present                                 |
| → Pathloss                            | Check to see if this IE is absent                                  |
| → Cell measured results               |                                                                    |
| → Cell Identity                       | Check to see if it is absent                                       |
| → SFN-SFN observed time difference    | Check to see if this IE is absent                                  |
| → Cell synchronisation information    | Check to see if this IE is absent                                  |
| → Primary CPICH Info                  |                                                                    |
| → Primary Scrambling Code             | Check to see if it's the same code for cell 2                      |
| → CPICH Ec/No                         | Check to see if this IE is absent                                  |
| → CPICH RSCP                          | Check to see if this IE is present                                 |
| → Pathloss                            | Check to see if this IE is absent                                  |
| Measured Results on RACH              | Check to see if this IE is absent                                  |
| Additional Measured Results           | Check to see if this IE is absent                                  |
| Event Results                         | Check to see if set to 'Intra-frequency measurement event results' |
| → Intra-frequency event identity      | Check to see if set to '1a'                                        |
| → Cell measurement event results      |                                                                    |
| → CHOICE Mode                         | Check to see if set to 'FDD'                                       |
| → Primary CPICH info                  |                                                                    |
| → Primary Scrambling Code             | Check to see if set to the same code for cell 3                    |

**ACTIVE SET UPDATE (Step 7)**

The contents of ACTIVE SET UPDATE message for this test step is identical to the same message found in Annex A with the following exceptions:

| Information Element                          | Value/remark                                                                    |
|----------------------------------------------|---------------------------------------------------------------------------------|
| RRC transaction identifier                   | 0                                                                               |
| Radio link addition information              |                                                                                 |
| — Primary CPICH Info                         |                                                                                 |
| — Primary Scrambling Code                    | Set to same code as assigned for cell 3                                         |
| — Downlink DPCH info for each RL             |                                                                                 |
| — Primary CPICH usage for channel estimation | P-CPICH can be used.                                                            |
| — DPCH frame offset                          | 0 chips                                                                         |
| — Secondary CPICH info                       | Not Present                                                                     |
| — DL channelisation code                     | This IE is repeated for all existing downlink DPCHs allocated to the UE         |
| — Secondary scrambling code                  | Not Present                                                                     |
| — Spreading factor                           | 512                                                                             |
| — Code Number                                | For each DPCH, assign the same code number in the current code given in cell 1. |
| — Scrambling code change                     | Not Present                                                                     |
| — TPC Combination Index                      | 0                                                                               |
| — SSDT Cell Identity                         | Not Present                                                                     |
| — Close loop timing adjustment mode          | Not Present                                                                     |
| — TFCI Combining Indicator                   | Not Present                                                                     |
| — SCCPCH information for FACH                | Not Present                                                                     |
| Radio link removal information               | Not Present                                                                     |

**ACTIVE SET UPDATE COMPLETE (Step 8 and Step 10b)**

| Information Element        | Value/remark                   |
|----------------------------|--------------------------------|
| RRC transaction identifier | Check to see if it is set to 0 |

**MEASUREMENT REPORT (Step 10)**

| Information Element                   | Value/Remarks                                                      |
|---------------------------------------|--------------------------------------------------------------------|
| RRC transaction identifier            | Check to see if set to 1                                           |
| Measurement identity                  | Check to see if set to 1                                           |
| Measured Results                      |                                                                    |
| — CHOICE measurement                  | Check to see if set to "Intra-frequency measured results list"     |
| — Intra-frequency measurement results |                                                                    |
| — Cell measured results               |                                                                    |
| — Cell Identity                       | Check to see if it is absent                                       |
| — SFN-SFN observed time difference    | Check to see if this IE is absent                                  |
| — Cell synchronisation information    | Check to see if this IE is absent                                  |
| — Primary CPICH Info                  |                                                                    |
| — Primary Scrambling Code             | Check to see if it's the same code for cell 2                      |
| — CPICH Ec/No                         | Check to see if this IE is absent                                  |
| — CPICH RSCP                          | Check to see if this IE is present                                 |
| — Pathloss                            | Check to see if this IE is absent                                  |
| Measured Results on RACH              | Check to see if this IE is absent                                  |
| Additional Measured Results           | Check to see if this IE is absent                                  |
| Event Results                         | Check to see if set to 'Intra-frequency measurement event results' |
| — Intra-frequency event identity      | Check to see if set to '1a'                                        |
| — Cell measurement event results      |                                                                    |
| — CHOICE Mode                         | Check to see if set to 'FDD'                                       |
| — Primary CPICH info                  |                                                                    |
| — Primary Scrambling Code             | Check to see if set to the same code for cell 2                    |

**ACTIVE SET UPDATE (Step 10a)**

The contents of ACTIVE SET UPDATE message for this test step is identical to the same message found in Annex A with the following exceptions:

| Information Element                          | Value/remark                                                                    |
|----------------------------------------------|---------------------------------------------------------------------------------|
| RRC transaction identifier                   | 0                                                                               |
| Radio link addition information              |                                                                                 |
| → Primary CPICH Info                         |                                                                                 |
| → Primary Scrambling Code                    | Set to same code as assigned for cell 2                                         |
| → Downlink DPCH info for each RL             |                                                                                 |
| → Primary CPICH usage for channel estimation | P-CPICH can be used.                                                            |
| → DPCH frame offset                          | 0 chips                                                                         |
| → Secondary CPICH info                       | Not Present                                                                     |
| → DL channelisation code                     | This IE is repeated for all existing downlink DPCHs allocated to the UE         |
| → Secondary scrambling code                  | Not Present                                                                     |
| → Spreading factor                           | 512                                                                             |
| → Code Number                                | For each DPCH, assign the same code number in the current code given in cell 1. |
| → Scrambling code change                     | Not Present                                                                     |
| → TPC Combination Index                      | 0                                                                               |
| → SSDT Cell Identity                         | Not Present                                                                     |
| → Close loop timing adjustment mode          | Not Present                                                                     |
| → TFCI Combining Indicator                   | Not Present                                                                     |
| → SCCPCH information for FACH                | Not Present                                                                     |
| Radio link removal information               | Not Present                                                                     |

**MEASUREMENT CONTROL (Step 11)**

The contents of MEASUREMENT CONTROL message for this test step is identical to the same message found in Annex A with the following exceptions:

| Information Element                                 | Value/Remark                                   |
|-----------------------------------------------------|------------------------------------------------|
| RRC transaction identifier                          | 1                                              |
| Measurement Identity                                | 1                                              |
| Measurement Command                                 | Modify                                         |
| Measurement Reporting Mode                          |                                                |
| — Measurement Reporting Transfer Mode               | Acknowledged Mode RLC                          |
| — Periodic Reporting / Event Trigger Reporting Mode | Event Trigger                                  |
| Additional measurements list                        | Not Present                                    |
| CHOICE measurement type                             | Intra-frequency measurement                    |
| — Intra-frequency cell info list                    | Not Present                                    |
| — Intra-frequency measurement quantity              | Not Present                                    |
| — Intra-frequency reporting quantity                | Not Present                                    |
| — CHOICE report criteria                            | Intra-frequency measurement reporting criteria |
| — Parameters required for each events               | <i>Only 1 event is specified</i>               |
| — Intra-frequency event identity                    | 1a                                             |
| — Triggering conditions 1                           | Not Present                                    |
| — Triggering conditions 2                           | Active set cells                               |
| — Reporting range                                   | 16.0 dB                                        |
| — Cells forbidden to affect reporting range         |                                                |
| — CHOICE Mode                                       | FDD                                            |
| — Primary CPICH info                                |                                                |
| — Primary scrambling code                           | Set to the same code as in cell 1              |
| — CHOICE Mode                                       | FDD                                            |
| — Primary CPICH info                                |                                                |
| — Primary scrambling code                           | Set to the same code as in cell 2              |
| — CHOICE Mode                                       | FDD                                            |
| — Primary CPICH info                                |                                                |
| — Primary scrambling code                           | Set to the same code as in cell 3              |
| — W                                                 | 0                                              |
| — Hysteresis                                        | 0 dB                                           |
| — Threshold used frequency                          | Not Present                                    |
| — Reporting deactivation threshold                  | 3                                              |
| — Replacement activation threshold                  | Not Present                                    |
| — Time to trigger                                   | 0 msec                                         |
| — Amount of reporting                               | 1                                              |
| — Reporting interval                                | 0                                              |
| — Reporting cell status                             |                                                |
| — CHOICE reported cells                             | Report cells within active set                 |
| — Maximum number of reported cells                  | e3                                             |
| DPCH compressed mode status info                    | Not Present                                    |

## MEASUREMENT REPORT (Step 15)

| Information Element                 | Value/Remarks                                                      |
|-------------------------------------|--------------------------------------------------------------------|
| RRC transaction identifier          | Check to see if set to 1                                           |
| Measurement identity                | Check to see if set to 1                                           |
| Measured Results                    |                                                                    |
| CHOICE measurement                  | Check to see if set to "Intra-frequency measured results list"     |
| Intra-frequency measurement results |                                                                    |
| Cell measured results               |                                                                    |
| Cell Identity                       | Check to see if it is absent                                       |
| SFN-SFN observed time difference    | Check to see if this IE is absent                                  |
| Cell synchronisation information    | Check to see if this IE is absent                                  |
| Primary CPICH Info                  |                                                                    |
| Primary Scrambling Code             | Check to see if it's the same code for cell 1                      |
| CPICH Ec/No                         | Check to see if this IE is absent                                  |
| CPICH RSCP                          | Check to see if this IE is present                                 |
| Pathloss                            | Check to see if this IE is absent                                  |
| Cell measured results               |                                                                    |
| Cell Identity                       | Check to see if it is absent                                       |
| SFN-SFN observed time difference    | Check to see if this IE is absent                                  |
| Cell synchronisation information    | Check to see if this IE is absent                                  |
| Primary CPICH Info                  |                                                                    |
| Primary Scrambling Code             | Check to see if it's the same code for cell 3                      |
| CPICH Ec/No                         | Check to see if this IE is absent                                  |
| CPICH RSCP                          | Check to see if this IE is present                                 |
| Pathloss                            | Check to see if this IE is absent                                  |
| Cell measured results               |                                                                    |
| Cell Identity                       | Check to see if it is absent                                       |
| SFN-SFN observed time difference    | Check to see if this IE is absent                                  |
| Cell synchronisation information    | Check to see if this IE is absent                                  |
| Primary CPICH Info                  |                                                                    |
| Primary Scrambling Code             | Check to see if it's the same code for cell 2                      |
| CPICH Ec/No                         | Check to see if this IE is absent                                  |
| CPICH RSCP                          | Check to see if this IE is present                                 |
| Pathloss                            | Check to see if this IE is absent                                  |
| Measured Results on RACH            | Check to see if this IE is absent                                  |
| Additional Measured Results         | Check to see if this IE is absent                                  |
| Event Results                       | Check to see if set to 'Intra-frequency measurement event results' |
| Intra-frequency event identity      | Check to see if set to '1a'                                        |
| Cell measurement event results      |                                                                    |
| CHOICE Mode                         | Check to see if set to 'FDD'                                       |
| Primary CPICH info                  |                                                                    |
| Primary Scrambling Code             | Check to see if set to the same code for cell 3                    |

## 8.4.1.14.5 Test requirement

After step 5, the UE shall send a MEASUREMENT REPORT message on the uplink DCCH. The message shall contain the IE "Event results" to report that cell 3 has triggered intra-frequency event 1A.

After step 9, the UE shall transmit MEASUREMENT REPORT message on the uplink DCCH. The message shall contain IE "Event results" to report that cell 2 has triggered intra-frequency event 1A.

After step 12, the UE shall not send MEASUREMENT REPORT message on the uplink DCCH to report the triggering of intra-frequency event identity 1A.

After step 14, the UE shall send a MEASUREMENT REPORT message on the uplink DCCH. The message shall contain IE "Event results" to report that cell 3 has triggered intra-frequency event 1A.

### ~~8.4.1.15 Measurement Control and Report: Configuration Incomplete~~

#### ~~8.4.1.15.1 Definition~~

#### ~~8.4.1.15.2 Conformance requirement~~

~~When the UE received a MEASUREMENT CONTROL message which results in an "configuration incomplete" condition to be detected, the UE shall retain the measurement configuration that was valid before the MEASUREMENT CONTROL message was received. It shall also send MEASUREMENT CONTROL FAILURE, with the IE "RRC transaction identifier" set to the value of the same IE in the received MEASUREMENT CONTROL message, and also the "failure-cause" IE set to "incomplete configuration".~~

#### ~~Reference~~

~~3GPP TS 25.331 clause 8.4.1.4a, 8.6.7.10, 8.6.7.13, 8.6.7.14, 8.6.7.16, 8.6.7.17, 8.6.7.18~~

#### ~~8.4.1.15.3 Test Purpose~~

~~To confirm that the UE sends a MEASUREMENT CONTROL FAILURE message, after receiving a MEASUREMENT CONTROL message with IE "Measurement command" set to "Setup" and the following contents:~~

- ~~— "CHOICE measurement type" IE is set to "Intra-frequency measurement" and "Intra-frequency measurement quantity" is omitted; or~~
- ~~— "CHOICE measurement type" IE is set to "Inter-frequency measurement" and "Inter-frequency reporting quantity" is omitted; or~~
- ~~— "Reporting mode" IE is omitted. or~~
- ~~— "CHOICE measurement type" IE is set to "Quality measurement" and IE "Quality reporting quantity" is omitted or~~
- ~~— "CHOICE measurement type" IE is set to "UE internal measurement" and IE "UE internal measurement quantity" is omitted or~~
- ~~— "CHOICE measurement type" IE is set to "UE internal measurement" and IE "UE internal reporting quantity" is omitted or~~
- ~~— "CHOICE measurement type" IE is set to "Traffic volume measurement" and IE "Traffic volume measurement quantity" is omitted or~~
- ~~— "CHOICE measurement type" IE is set to "Traffic volume measurement" and IE "Traffic volume reporting quantity" is omitted~~

~~To confirm that the UE set the "failure-cause" IE to value "incomplete configuration" in the uplink MEASUREMENT CONTROL FAILURE message.~~

#### ~~8.4.1.15.4 Method of test~~

##### ~~Initial Condition~~

~~System Simulator: 1 cell.~~

~~UE: CS-DCCH\_DCH (State 6-5) or PS-DCCH\_DCH (State 6-7) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE.~~

##### ~~Test Procedure~~

~~The UE is initially brought to CELL\_DCH. SS transmits a MEASUREMENT CONTROL message to the UE, commanding it to start an intra-frequency measurement and reporting task. However, IE "Intra-frequency measurement quantity" is absent in the message. The UE shall not establish the intra-frequency measurement. It shall send a MEASUREMENT CONTROL FAILURE message to report that a "configuration incomplete" error has been detected.~~



Next, SS sends the MEASUREMENT CONTROL message once more. In this message, SS commands the establishment of an inter-frequency measurement and reporting task, but IE "Inter-frequency reporting quantity" is omitted in this message. The UE shall not establish the intra-frequency measurement. It shall send a MEASUREMENT CONTROL FAILURE message to report that a "configuration incomplete" error has been detected.

Next, SS sends a third MEASUREMENT CONTROL message. In this message, SS commands the establishment of an intra-frequency measurement and reporting task, but IE "Measurement reporting mode" is omitted in this message. The UE shall not establish the intra-frequency measurement. It shall send a MEASUREMENT CONTROL FAILURE message to report that a "configuration incomplete" error has been detected.

Next, SS sends a fourth MEASUREMENT CONTROL message. In this message, SS commands the establishment of a quality measurement and reporting task, but IE "Quality reporting quantity" is omitted in this message. The UE shall not establish the quality measurement. It shall send a MEASUREMENT CONTROL FAILURE message to report that a "configuration incomplete" error has been detected.

Next, SS sends a fifth MEASUREMENT CONTROL message. In this message, SS commands the establishment of UE internal measurement and reporting task, but IE "UE internal measurement quantity" is omitted in this message. The UE shall not establish the UE internal measurement. It shall send a MEASUREMENT CONTROL FAILURE message to report that a "configuration incomplete" error has been detected.

Next, SS sends a sixth MEASUREMENT CONTROL message. In this message, SS commands the establishment of UE internal measurement and reporting task, but IE "UE internal reporting quantity" is omitted in this message. The UE shall not establish the UE internal measurement. It shall send a MEASUREMENT CONTROL FAILURE message to report that a "configuration incomplete" error has been detected.

Next, SS sends a seventh MEASUREMENT CONTROL message. In this message, SS commands the establishment of a traffic volume measurement and reporting task, but IE "Traffic volume measurement quantity" is omitted in this message. The UE shall not establish the traffic volume measurement. It shall send a MEASUREMENT CONTROL FAILURE message to report that a "configuration incomplete" error has been detected.

In the final sequence, SS sends an eight MEASUREMENT CONTROL message. In this message, SS commands the establishment of a traffic volume measurement and reporting task, but IE "Traffic volume reporting quantity" is omitted in this message. The UE shall not establish the traffic volume measurement. It shall send a MEASUREMENT CONTROL FAILURE message to report that a "configuration incomplete" error has been detected.

#### Expected Sequence

| Step | Direction |    | Message                     | Comment                                                                                                                          |
|------|-----------|----|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                  |
| 1    |           |    |                             | The UE is CELL_DCH state in cell 1.                                                                                              |
| 2    |           | ←  | MEASUREMENT CONTROL         | SS commands the start of an intra-frequency measurement and reporting task. IE "Intra-frequency measurement quantity" is absent. |
| 3    |           | →  | MEASUREMENT CONTROL FAILURE | UE reports the occurrence of "incomplete configuration"                                                                          |
| 4    |           | ←  | MEASUREMENT CONTROL         | SS commands the start of an inter-frequency measurement and reporting task. IE "Inter-frequency reporting quantity" is absent.   |
| 5    |           | →  | MEASUREMENT CONTROL FAILURE | UE reports the occurrence of "incomplete configuration"                                                                          |
| 6    |           | ←  | MEASUREMENT CONTROL         | SS commands the start of an inter-frequency measurement and reporting task. IE "Measurement reporting mode" is absent.           |
| 7    |           | →  | MEASUREMENT CONTROL FAILURE | UE reports the occurrence of "incomplete configuration"                                                                          |

|    |   |                             |                                                                                                                               |
|----|---|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| 8  | ← | MEASUREMENT CONTROL         | SS commands the start of a Quality measurement and reporting task. IE "Quality reporting quantity" is absent.                 |
| 9  | → | MEASUREMENT CONTROL FAILURE | UE reports the occurrence of "incomplete configuration"                                                                       |
| 10 | ← | MEASUREMENT CONTROL         | SS commands the start of an UE internal measurement and reporting task. IE "UE internal measurement quantity" is absent.      |
| 11 | → | MEASUREMENT CONTROL FAILURE | UE reports the occurrence of "incomplete configuration"                                                                       |
| 12 | ← | MEASUREMENT CONTROL         | SS commands the start of an UE internal measurement and reporting task. IE "UE internal reporting quantity" is absent.        |
| 13 | → | MEASUREMENT CONTROL FAILURE | UE reports the occurrence of "incomplete configuration"                                                                       |
| 14 | ← | MEASUREMENT CONTROL         | SS commands the start of a Traffic volume measurement and reporting task. IE "Traffic volume measurement quantity" is absent. |
| 15 | → | MEASUREMENT CONTROL FAILURE | UE reports the occurrence of "incomplete configuration"                                                                       |
| 16 | ← | MEASUREMENT CONTROL         | SS commands the start of a Traffic volume measurement and reporting task. IE "Traffic volume reporting quantity" is absent.   |
| 17 | → | MEASUREMENT CONTROL FAILURE | UE reports the occurrence of "incomplete configuration"                                                                       |

## Specific Message Content

## MEASUREMENT CONTROL (Step 2)

| Information Element                                    | Value/Remark                         |
|--------------------------------------------------------|--------------------------------------|
| Measurement Identity                                   | 1                                    |
| RRC transaction Identifier                             | Arbitrarily selected between 0 and 3 |
| Measurement Command                                    | Setup                                |
| Measurement Reporting Mode                             |                                      |
| — Measurement Report Transfer Mode                     | Acknowledged mode RLC                |
| — Periodical Reporting/Event Trigger Reporting Mode    | Periodical reporting                 |
| Additional measurements list                           | Not Present                          |
| CHOICE measurement type                                | Intra-frequency measurement          |
| — Intra-frequency cell info list                       |                                      |
| — CHOICE intra-frequency cell removal                  | Remove no intra-frequency cells      |
| — New intra-frequency cell                             | Not Present                          |
| — Cell for measurement                                 |                                      |
| — Intra-frequency cell id                              | Set to id of cell 1                  |
| — Intra-frequency measurement quantity                 | Not Present                          |
| — Intra-frequency reporting quantity                   |                                      |
| — Reporting quantities for active set cells            |                                      |
| — SFN-SFN onseved time difference reporting indicator  | No report                            |
| — Cell synchronization information reporting indicator | FALSE                                |
| — Cell identity reporting indicator                    | FALSE                                |
| — CHOICE mode                                          | FDD                                  |
| — CPICH Ec/No reporting indicator                      | FALSE                                |
| — CPICH RSCP reporting indicator                       | TRUE                                 |
| — Pathloss reporting indicator                         | FALSE                                |
| — Reporting quantities for monitored set cells         |                                      |
| — SFN-SFN onseved time difference reporting indicator  | No report                            |
| — Cell synchronization information reporting indicator | FALSE                                |
| — Cell identity reporting indicator                    | FALSE                                |
| — CHOICE mode                                          | FDD                                  |
| — CPICH Ec/No reporting indicator                      | FALSE                                |
| — CPICH RSCP reporting indicator                       | TRUE                                 |
| — Pathloss reporting indicator                         | FALSE                                |
| — Reporting cell status                                |                                      |
| — CHOICE reported cell                                 | Report cells within active set       |
| — Maximum number of reported cells                     | 1                                    |
| — Measurement validity                                 | CELL_DCH                             |
| — CHOICE report criteria                               | Periodical reporting criteria        |
| — Amount of reporting                                  | Infinity                             |
| — Reporting interval                                   | 32 seconds                           |
| DPCH compressed mode status info                       | Not Present                          |

## MEASUREMENT CONTROL FAILURE (Step 3)

| Information Element        | Value/Remark                                                                                          |
|----------------------------|-------------------------------------------------------------------------------------------------------|
| RRC transaction identifier | Check if it is set to the same value of the same IE in the MEASUREMENT CONTROL message sent in Step 2 |
| Failure cause              | Check to see if set to "incomplete configuration"                                                     |

## MEASUREMENT CONTROL (Step 4) (Note 1)

| Information Element                                   | Value/Remark                                                |
|-------------------------------------------------------|-------------------------------------------------------------|
| Measurement Identity                                  | 2                                                           |
| RRC transaction Identifier                            | Arbitrarily selected between 0 and 3                        |
| Measurement Command                                   | Setup                                                       |
| Measurement Reporting Mode                            |                                                             |
| → Measurement Report Transfer Mode                    | Acknowledged mode RLC                                       |
| → Periodical Reporting/Event Trigger Reporting Mode   | Periodical reporting                                        |
| Additional measurements list                          | Not Present                                                 |
| CHOICE measurement type                               | Inter-frequency measurement                                 |
| → Inter-frequency cell info list                      |                                                             |
| → CHOICE inter-frequency cell removal                 | No inter-frequency cells removed                            |
| → New inter-frequency cell                            |                                                             |
| → Inter-frequency cell id                             | Set to id of cell 4                                         |
| → Frequency info                                      |                                                             |
| → CHOICE Mode                                         | FDD                                                         |
| → UARFCN uplink (Nu)                                  | Set to the same UARFCN as cell 4 in clause 6.1 of TS 34.108 |
| → UARFCN downlink (Nu)                                | Set to the same UARFCN as cell 4 in clause 6.1 of TS 34.108 |
| → Cell info                                           |                                                             |
| → Cell individual offset                              | 0 dB                                                        |
| → Reference time difference to cell                   | 0 chips                                                     |
| → Read SFN Indicator                                  | FALSE                                                       |
| → CHOICE mode                                         | FDD                                                         |
| → Primary CPICH Info                                  |                                                             |
| → Primary Scrambling Code                             | Set to same code as used for cell 4                         |
| → Primary CPICH TX power                              | Not Present                                                 |
| → TX Diversity Indicator                              | FALSE                                                       |
| → Cell selection and re-selection info                | Not Present                                                 |
| → Cell for measurement                                |                                                             |
| → Inter-frequency cell id                             | Set to id of cell 4                                         |
| → Inter-frequency measurement quantity                |                                                             |
| → CHOICE reporting criteria                           | Inter-frequency reporting criteria                          |
| → Filter coefficients                                 | 0                                                           |
| → CHOICE mode                                         | FDD                                                         |
| → Measurement quantity for frequency quality estimate | CPICH RSCP                                                  |
| → Inter-frequency reporting quantity                  | Not Present                                                 |
| → Reporting cell status                               |                                                             |
| → CHOICE reported cell                                | Report cells within monitored set on non-used frequency     |
| → Maximum number of reported cells                    | 1                                                           |
| → Measurement validity                                | CELL_DCH                                                    |
| → CHOICE report criteria                              | Periodical reporting criteria                               |
| → Amount of reporting                                 | Infinity                                                    |
| → Reporting interval                                  | 32 seconds                                                  |
| → Inter-frequency set update                          | Not Present                                                 |
| DPCH compressed mode status info                      | Not Present                                                 |

## MEASUREMENT CONTROL FAILURE (Step 5)

| Information Element        | Value/Remark                                                                                          |
|----------------------------|-------------------------------------------------------------------------------------------------------|
| RRC transaction identifier | Check if it is set to the same value of the same IE in the MEASUREMENT CONTROL message sent in Step 4 |
| Failure cause              | Check to see if set to "incomplete configuration"                                                     |

## MEASUREMENT CONTROL (Step 6)

| Information Element                                    | Value/Remark                         |
|--------------------------------------------------------|--------------------------------------|
| Measurement Identity                                   | 3                                    |
| RRC transaction Identifier                             | Arbitrarily selected between 0 and 3 |
| Measurement Command                                    | Setup                                |
| Measurement Reporting Mode                             | Not Present                          |
| Additional measurements list                           | Not Present                          |
| CHOICE measurement type                                | Intra-frequency measurement          |
| → Intra-frequency cell info list                       |                                      |
| → CHOICE intra-frequency cell removal                  | Remove no intra-frequency cells      |
| → New intra-frequency cell                             | Not Present                          |
| → Cell for measurement                                 |                                      |
| → Intra-frequency cell id                              | Set to id of cell 1                  |
| → Intra-frequency measurement quantity                 |                                      |
| → Filter coefficient                                   | 0                                    |
| → CHOICE mode                                          | FDD                                  |
| → Measurement quantity                                 | CPICH RSCP                           |
| → Intra-frequency reporting quantity                   |                                      |
| → Reporting quantities for active set cells            |                                      |
| → SFN-SFN observed time difference reporting indicator | No report                            |
| → Cell synchronization information reporting indicator | FALSE                                |
| → Cell identity reporting indicator                    | FALSE                                |
| → CHOICE mode                                          | FDD                                  |
| → CPICH Ec/No reporting indicator                      | FALSE                                |
| → CPICH RSCP reporting indicator                       | TRUE                                 |
| → Pathloss reporting indicator                         | FALSE                                |
| → Reporting quantities for monitored set cells         |                                      |
| → SFN-SFN observed time difference reporting indicator | No report                            |
| → Cell synchronization information reporting indicator | No report                            |
| → Cell identity reporting indicator                    | FALSE                                |
| → CHOICE mode                                          | FDD                                  |
| → CPICH Ec/No reporting indicator                      | FALSE                                |
| → CPICH RSCP reporting indicator                       | TRUE                                 |
| → Pathloss reporting indicator                         | FALSE                                |
| → Reporting cell status                                |                                      |
| → CHOICE reported cell                                 | Report cells within active set       |
| → Maximum number of reported cells                     | 1                                    |
| → Measurement validity                                 | CELL_DCH                             |
| → CHOICE report criteria                               | Periodical reporting criteria        |
| → Amount of reporting                                  | Infinity                             |
| → Reporting interval                                   | 32 seconds                           |
| DPCH compressed mode status info                       | Not Present                          |

## MEASUREMENT CONTROL FAILURE (Step 7)

| Information Element        | Value/Remark                                                                                          |
|----------------------------|-------------------------------------------------------------------------------------------------------|
| RRC transaction identifier | Check if it is set to the same value of the same IE in the MEASUREMENT CONTROL message sent in Step 6 |
| Failure cause              | Check to see if set to "incomplete configuration"                                                     |

## MEASUREMENT CONTROL (Step 8)

| Information Element           | Value/Remark                  |
|-------------------------------|-------------------------------|
| Measurement identity          | 16                            |
| Measurement command           | Setup                         |
| → CHOICE measurement type     | Quality measurement           |
| → Quality reporting quantity  | Not present                   |
| → Reporting criteria          | Periodical reporting criteria |
| → Reporting amount            | Infinity                      |
| → Reporting interval          | 64 sec                        |
| Measurement reporting mode    |                               |
| → Transfer Mode               | Acknowledged mode             |
| → Periodical or event trigger | Periodic                      |
| Additional measurement list   | Not Present                   |
| DPCH compressed mode status   | Not Present                   |

## MEASUREMENT CONTROL FAILURE (Step 9)

| Information Element        | Value/Remark                                                                                          |
|----------------------------|-------------------------------------------------------------------------------------------------------|
| RRC transaction identifier | Check if it is set to the same value of the same IE in the MEASUREMENT CONTROL message sent in Step 8 |
| Failure cause              | Check to see if set to "incomplete configuration"                                                     |

## MEASUREMENT CONTROL (Step 10)

| Information Element                | Value/Remark                  |
|------------------------------------|-------------------------------|
| Measurement Identity               | 1                             |
| Measurement Command                | Setup                         |
| CHOICE measurement type            | UE internal measurement       |
| → UE internal measurement quantity | Not present                   |
| → UE internal reporting quantity   |                               |
| → UE Transmitted Power             | TRUE                          |
| → CHOICE mode                      | FDD                           |
| → UE Rx-Tx time difference         | FALSE                         |
| → CHOICE report criteria           | Periodical reporting criteria |
| → Amount of reporting              | Infinity                      |
| → Reporting interval               | 1000 msec                     |
| Measurement Reporting Mode         | Not Present                   |
| Additional measurements list       | Not Present                   |
| DPCH compressed mode status        | Not Present                   |

## MEASUREMENT CONTROL FAILURE (Step 11)

| Information Element        | Value/Remark                                                                                           |
|----------------------------|--------------------------------------------------------------------------------------------------------|
| RRC transaction identifier | Check if it is set to the same value of the same IE in the MEASUREMENT CONTROL message sent in Step 10 |
| Failure cause              | Check to see if set to "incomplete configuration"                                                      |

## MEASUREMENT CONTROL (Step 12)

| Information Element                | Value/Remark                  |
|------------------------------------|-------------------------------|
| Measurement Identity               | 1                             |
| Measurement Command                | Setup                         |
| CHOICE measurement type            | UE internal measurement       |
| → UE internal measurement quantity |                               |
| → CHOICE mode                      | FDD                           |
| → Measurement quantity             | UE Transmitted Power          |
| → Filter Coefficient               | 0                             |
| → UE internal reporting quantity   | Not present                   |
| → CHOICE report criteria           | Periodical reporting criteria |
| → Amount of reporting              | Infinity                      |
| → Reporting interval               | 1000 msec                     |
| Measurement Reporting Mode         | Not Present                   |
| Additional measurements list       | Not Present                   |
| DPCH compressed mode status        | Not Present                   |

## MEASUREMENT CONTROL FAILURE (Step 13)

| Information Element        | Value/Remark                                                                                           |
|----------------------------|--------------------------------------------------------------------------------------------------------|
| RRC transaction identifier | Check if it is set to the same value of the same IE in the MEASUREMENT CONTROL message sent in Step 12 |
| Failure cause              | Check to see if set to "incomplete configuration"                                                      |

## MEASUREMENT CONTROL (Step 14)

| Information Element                      | Value/Remark                  |
|------------------------------------------|-------------------------------|
| Measurement Identity                     | 1                             |
| Measurement Command                      | Setup                         |
| → CHOICE measurement type                | Traffic Volume Measurement    |
| → Traffic volume measurement object list | Not Present                   |
| → Traffic volume measurement quantity    | Not present                   |
| → Traffic volume reporting quantity      |                               |
| → RB buffer payload                      | True                          |
| → RB buffer payload average              | False                         |
| → RB buffer payload variance             | False                         |
| → Measurement validity                   | Not Present                   |
| → Report criteria                        | Periodical Reporting Criteria |
| → Reporting amount                       | 8                             |
| → Reporting interval                     | 8 Sec                         |
| Measurement reporting mode               |                               |
| → Transfer Mode                          | Acknowledged mode             |
| → Periodical or event trigger            | Periodic                      |
| Additional measurement list              | Not Present                   |
| DPCH compressed mode status              | Not Present                   |

## MEASUREMENT CONTROL FAILURE (Step 15)

| Information Element        | Value/Remark                                                                                           |
|----------------------------|--------------------------------------------------------------------------------------------------------|
| RRC transaction identifier | Check if it is set to the same value of the same IE in the MEASUREMENT CONTROL message sent in Step 14 |
| Failure cause              | Check to see if set to "incomplete configuration"                                                      |

**MEASUREMENT CONTROL (Step 16)**

| Information Element                      | Value/Remark                  |
|------------------------------------------|-------------------------------|
| Measurement Identity                     | 1                             |
| Measurement Command                      | Setup                         |
| → CHOICE measurement type                | Traffic Volume Measurement    |
| → Traffic volume measurement object list | Not Present                   |
| → Traffic volume measurement quantity    | RLC Buffer Payload            |
| → Traffic volume reporting quantity      | Not present                   |
| → Measurement validity                   | Not Present                   |
| → Report criteria                        | Periodical Reporting Criteria |
| → Reporting amount                       | 8                             |
| → Reporting interval                     | 8 Sec                         |
| Measurement reporting mode               |                               |
| → Transfer Mode                          | Acknowledged mode             |
| → Periodical or event trigger            | Periodic                      |
| Additional measurement list              | Not Present                   |
| DPCH compressed mode status              | Not Present                   |

**MEASUREMENT CONTROL FAILURE (Step 17)**

| Information Element        | Value/Remark                                                                                           |
|----------------------------|--------------------------------------------------------------------------------------------------------|
| RRC transaction identifier | Check if it is set to the same value of the same IE in the MEASUREMENT CONTROL message sent in Step 16 |
| Failure cause              | Check to see if set to "incomplete configuration"                                                      |

NOTE: For the MEASUREMENT CONTROL message in step 4, cell 4 is signalled to be added as a new cell into the UE's inter-frequency cell list. However, SS does not need to transmit cell 4 in the downlink, as the UE is not expected to perform measurement and reporting for this cell.

**8.4.1.15.5 Test Requirement**

After step 2, 4, 6, 8, 10, 12, 14 and step 16, the UE shall transmit MEASUREMENT CONTROL FAILURE message, stating the IE "failure-cause" as "incomplete configuration". The UE shall not transmit any MEASUREMENT REPORT messages during the execution of this test case.

**8.4.1.16 Measurement Control and Report: Traffic volume measurement for transition from idle mode to CELL\_FACH state****8.4.1.16.1 Definition****8.4.1.16.2 Conformance requirement**

Upon transition from idle mode to CELL\_FACH state, the UE shall store the measurement control information from the IE "Traffic volume measurements system information" received in System Information Block type 11 or System Information Block type 12. UE shall begin traffic volume measurement reporting according to the assigned information.

**Reference**

3GPP TS 25.331 clause 8.4.1.9.4

**8.4.1.16.3 Test Purpose**

To confirm that after a state transition from idle mode to CELL\_FACH state, the UE shall begin a traffic volume type measurement, as specified in System Information Block type 11 or 12 messages on BCCH. To confirm that in CELL\_FACH state, the UE shall send a MEASUREMENT REPORT message when reporting criteria is satisfied. During CELL\_FACH state, if the UE receives a MEASUREMENT CONTROL message, it shall perform the measurement and reporting tasks based on the MEASUREMENT CONTROL message received.



#### 8.4.1.16.4 Method of test

##### Initial Condition

System Simulator: 1cell

UE: "Registered idle mode on CS" (state 2) or "Registered idle mode on PS" (state 3) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE. If the UE supports both CS and PS domains, the initial UE state shall be "Registered idle mode on CS/PS" (state 7).

##### Test Procedure

The UE is initially in idle mode. The System Information Block type 11 message is modified with respect to the default settings to request UE to perform traffic volume measurements. Key measurement parameters are as follows: measurement quantity = "RLC Buffer Payload", report criteria = "periodic reporting criteria", reporting interval = "6 seconds", reporting amount = 'infinity'. The System Information type 12 message is not broadcasted.

SS prompts the operator to make an outgoing call for one of the traffic classes supported by the UE. The UE shall transmit a RRC CONNECTION REQUEST message on the uplink CCCH, SS replies with RRC CONNECTION SETUP message and allocates PRACH and S-CCPCH physical channels for uplink and downlink usage. UE shall then enter CELL\_FACH state.

UE shall begin traffic volume measurements, and shall send MEASUREMENT REPORT message after completing first measurement. UE shall send second MEASUREMENT REPORT message 6 seconds after first MEASUREMENT REPORT message.

SS sends MEASUREMENT CONTROL message to the UE. This message overwrites measurement information saved from System information type 11. Key measurement parameters are as follow: measurement type = "traffic volume measurement", measurement quantity = "RLC Buffer Payload", report criteria = "Event triggered, event 4B: Transport Channel Traffic Volume becomes smaller than an absolute threshold", Time to trigger = "5 seconds", pending time after trigger = "16 seconds", "reporting threshold = '4K'". Since there is no uplink traffic, UE shall send MEASUREMENT REPORT message after 5 seconds (time to trigger interval).

##### Expected Sequence

| Step | Direction |    | Message                          | Comment                                                                                                                                                               |
|------|-----------|----|----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                  |                                                                                                                                                                       |
| 1    |           | ←  | System Information Block type 11 | The UE is idle mode and camped onto cell 1. System Information Block type 11 to be transmitted is different from the default settings (see specific message contents) |
| 2    |           |    |                                  | SS prompts the test operator to make an outgoing call.                                                                                                                |
| 3    |           | →  | RRC CONNECTION REQUEST           |                                                                                                                                                                       |
| 4    |           | ←  | RRC CONNECTION SETUP             | SS allocates common physical channels to UE.                                                                                                                          |
| 5    |           | →  | RRC CONNECTION COMPLETE          | UE shall enter CELL_FACH state, and transmit this message to acknowledge the RRC CONNECTION SETUP message.                                                            |
| 6    |           | →  | MEASUREMENT REPORT               |                                                                                                                                                                       |
| 7    |           | →  | MEASUREMENT REPORT               | Time difference between earlier and this MEASUREMENT REPORT message should be 6 Seconds.                                                                              |

|    |   |                     |                                                                                                       |
|----|---|---------------------|-------------------------------------------------------------------------------------------------------|
| 8  | ← | MEASUREMENT CONTROL | Traffic volume measurement reporting is requested if measurement is below threshold.                  |
| 9  |   |                     | SS monitors the uplink DCCH to confirm that no MEASUREMENT REPORT messages are received in 5 seconds. |
| 10 | → | MEASUREMENT REPORT  | Measurement report because event 4b is triggered                                                      |

### Specific Message Content

#### System Information Block type 11 (Step 1)

| Information Element                              | Value/Remarks                 |
|--------------------------------------------------|-------------------------------|
| SIB12 indicator                                  | FALSE                         |
| FACH measurement occasion info                   | Not Present                   |
| Measurement control system information           |                               |
| → Use of HCS                                     | Not used                      |
| → Cell_selection_and_reselection_quality         | GPICH RSCP                    |
| → Intra-frequency measurement system information | Not Present                   |
| → Inter-frequency measurement system information | Not Present                   |
| → Inter-RAT measurement system information       | Not Present                   |
| → Traffic volume measurement system information  |                               |
| → Traffic volume measurement ID                  | 4                             |
| → Traffic volume measurement object list         | Rach                          |
| → Traffic volume measurement quantity            | RLC Buffer Payload            |
| → Traffic volume reporting quantity              |                               |
| → RB buffer payload                              | True                          |
| → RB buffer payload average                      | False                         |
| → RB buffer payload variance                     | False                         |
| → Traffic volume measurement reporting criteria  | Not Present                   |
| → Measurement validity                           | All States except CELL_DCH    |
| → Measurement reporting mode                     |                               |
| → Measurement report transfer mode               | Acknowledged Mode             |
| → Periodical or event trigger                    | Periodical                    |
| → Report criteria system Information             | Periodical reporting criteria |
| → Reporting amount                               | Infinity                      |
| → Reporting interval                             | 6 seconds                     |
| → UE internal measurement system information     | Not Present                   |

#### RRC CONNECTION REQUEST (Step 3)

| Information Element      | Value/Remarks                                                                                 |
|--------------------------|-----------------------------------------------------------------------------------------------|
| Initial UE Identity      | Check to see if it is the same as the IMSI in USIM card, TMSI or P-TMSI previously allocated. |
| Establishment cause      | Check to see if set to originating call of the compatible traffic classes supported by the UE |
| Measured results on RACH | Check to see if IE is absent                                                                  |

**RRC CONNECTION SETUP (Step 4)**

Use the same message sub-type found in Annex A, which is titled "Transition to CELL\_FACH".

**MEASUREMENT REPORT (Step 6,7)**

| Information Element                | Value/Remarks                                                 |
|------------------------------------|---------------------------------------------------------------|
| Measurement identity               | Check to see if set to 4                                      |
| Measured Results                   |                                                               |
| CHOICE measurement                 | Check to see if set to "traffic volume measured results list" |
| Traffic volume measurement results |                                                               |
| RB identity                        | 0                                                             |
| RLC buffer payload                 | Check to see if this IE is present                            |
| RLC buffer payload average         | Check to see if this IE is absent                             |
| RLC buffer payload variance        | Check to see if this IE is absent                             |
| RB identity                        | 1                                                             |
| RLC buffer payload                 | Check to see if this IE is present                            |
| RLC buffer payload average         | Check to see if this IE is absent                             |
| RLC buffer payload variance        | Check to see if this IE is absent                             |
| RB identity                        | 2                                                             |
| RLC buffer payload                 | Check to see if this IE is present                            |
| RLC buffer payload average         | Check to see if this IE is absent                             |
| RLC buffer payload variance        | Check to see if this IE is absent                             |
| RB identity                        | 3                                                             |
| RLC buffer payload                 | Check to see if this IE is present                            |
| RLC buffer payload average         | Check to see if this IE is absent                             |
| RLC buffer payload variance        | Check to see if this IE is absent                             |
| RB identity                        | 4                                                             |
| RLC buffer payload                 | Check to see if this IE is present                            |
| RLC buffer payload average         | Check to see if this IE is absent                             |
| RLC buffer payload variance        | Check to see if this IE is absent                             |
| RB identity                        | 4                                                             |
| RLC buffer payload                 | Check to see if this IE is present                            |
| RLC buffer payload average         | Check to see if this IE is absent                             |
| RLC buffer payload variance        | Check to see if this IE is absent                             |
| Measured results on RACH           | Check to see if this IE is absent                             |
| Additional measured results        | Check to see if this IE is absent                             |
| Event results                      | Check to see if this IE is absent                             |

**MEASUREMENT CONTROL (Step 8)**

| Information Element                    | Value/Remark                      |
|----------------------------------------|-----------------------------------|
| Measurement Identity                   | 4                                 |
| Measurement Command                    | Setup                             |
| CHOICE measurement type                | Traffic Volume Measurement        |
| Traffic volume measurement object list | Not Present                       |
| Traffic volume measurement quantity    | RLC Buffer Payload                |
| Traffic volume reporting quantity      |                                   |
| RB buffer payload                      | True                              |
| RB buffer payload average              | False                             |
| RB buffer payload variance             | False                             |
| Measurement validity                   | Not Present                       |
| Report criteria                        | Traffic Volume Reporting Criteria |
| UL transport channel id                | Rach Null                         |
| Event specific parameters              |                                   |
| Event id                               | 4B                                |
| Reporting threshold                    | 4K                                |
| Time to trigger                        | 5000 ms                           |
| Pending time after trigger             | 16000 ms                          |
| Tx interruption after trigger          | Not Present                       |
| Measurement reporting mode             |                                   |
| Transfer Mode                          | Acknowledged mode                 |
| Periodical or event trigger            | Event trigger                     |
| Additional measurement list            | Not Present                       |
| DPCH compressed mode status            | Not Present                       |

## MEASUREMENT REPORT (Step 10)

| Information Element                  | Value/Remarks                        |
|--------------------------------------|--------------------------------------|
| Measurement identity                 | 4                                    |
| Measured Results                     |                                      |
| → CHOICE measurement                 | Traffic volume measured results list |
| → Traffic volume measurement results |                                      |
| → RB identity                        | 0                                    |
| → RLC buffer payload                 | Check to see if this IE is present   |
| → RLC buffer payload average         | Check to see if this IE is absent    |
| → RLC buffer payload variance        | Check to see if this IE is absent    |
| → RB identity                        | 1                                    |
| → RLC buffer payload                 | Check to see if this IE is present   |
| → RLC buffer payload average         | Check to see if this IE is absent    |
| → RLC buffer payload variance        | Check to see if this IE is absent    |
| → RB identity                        | 2                                    |
| → RLC buffer payload                 | Check to see if this IE is present   |
| → RLC buffer payload average         | Check to see if this IE is absent    |
| → RLC buffer payload variance        | Check to see if this IE is absent    |
| → RB identity                        | 3                                    |
| → RLC buffer payload                 | Check to see if this IE is present   |
| → RLC buffer payload average         | Check to see if this IE is absent    |
| → RLC buffer payload variance        | Check to see if this IE is absent    |
| → RB identity                        | 4                                    |
| → RLC buffer payload                 | Check to see if this IE is present   |
| → RLC buffer payload average         | Check to see if this IE is absent    |
| → RLC buffer payload variance        | Check to see if this IE is absent    |
| Measured results on RACH             | Check to see if this IE is absent    |
| Additional measured results          | Check to see if this IE is absent    |
| Event results                        | Traffic Volume Event Results         |
| → UL transport channel causing event | Rach Null                            |
| → Traffic volume event identity      | 4B                                   |

## 8.4.1.16.5 Test Requirement

After step 5 the UE shall send MEASUREMENT REPORT messages on the uplink DCCH containing RLC buffer payload information for all SRBs. After 6 seconds UE shall send second MEASUREMENT REPORT messages containing RLC buffer payload information for all SRBs.

After step 8 the UE shall overwrite measurement information received from system information type 11 with measurement information in MEASUREMENT CONTROL message. The UE shall not send MEASUREMENT REPORT message within time to trigger interval. After step 9 the UE shall transmit MEASUREMENT REPORT messages with event identity 4B.

## 8.4.1.17 Measurement Control and Report: Traffic volume measurement for transition from idle mode to CELL\_DCH state

## 8.4.1.17.1 Definition

## 8.4.1.17.2 Conformance requirement

Upon transition from idle mode to CELL\_DCH state, the UE shall begin a traffic volume type measurement, assigned in System Information Block type 11 or System Information Block type 12.

## Reference

3GPP TS 25.331 clause 8.4.1.8.4

### 8.4.1.17.3 Test Purpose

To confirm that after a state transition from idle mode to CELL\_DCH state, the UE begin a traffic volume type measurement, as specified in System Information Block type 11 or 12 messages on BCCH. When entering CELL\_DCH state, the UE shall send a MEASUREMENT REPORT message when reporting criteria is satisfied. During CELL\_DCH state, if the UE receives a MEASUREMENT CONTROL message, it shall perform the measurement and reporting tasks based on the MEASUREMENT CONTROL message received.

### 8.4.1.17.4 Method of test

#### Initial Condition

System Simulator: 1cell

UE: "Registered idle mode on CS" (state 2) or "Registered idle mode on PS" (state 3) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE. If the UE supports both CS and PS domains, the initial UE state shall be "Registered idle mode on CS/PS" (state 7).

#### Test Procedure

The UE is initially in idle mode. The System Information Block type 11 message is modified with respect to the default settings to request UE to perform traffic volume measurements. Key measurement parameters are as follows: measurement quantity = "Average RLC Buffer Payload", report criteria = "Event triggered, event 4B", reporting threshold = "8K", report transfer mode = "Unacknowledged mode". The System Information type 12 message is not broadcasted.

SS prompts the operator to make an outgoing call for one of the traffic classes supported by the UE. Dedicated resources are allocated to the UE during RRC connection establishment procedure.

UE shall begin traffic volume measurements after entering in CELL\_DCH state. The UE shall send MEASUREMENT REPORT message because uplink traffic is below threshold.

SS sends MEASUREMENT CONTROL message to the UE. This message reconfigures measurement information saved from System information type 11. Key measurement parameters are as follow: measurement type = "traffic volume measurement", measurement quantity = "RLC Buffer Payload", report criteria = "Periodic reporting criteria", reporting interval = "8 seconds", reporting amount = "8". The UE shall periodically send MEASUREMENT REPORT message to report RLC Buffer Payload for each RB.

SS sends MEASUREMENT CONTROL message to release traffic volume measurement. UE shall not send measurement report after receiving this message.

#### Expected Sequence

| Step | Direction |    | Message                          | Comment                                                                                                                                                               |
|------|-----------|----|----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                  |                                                                                                                                                                       |
| 1    |           | ←  | System Information Block type 11 | The UE is idle mode and camped onto cell 1. System Information Block type 11 to be transmitted is different from the default settings (see specific message contents) |
| 2    |           |    |                                  | SS prompts the test operator to make an outgoing call.                                                                                                                |
| 3    |           | →  | RRC CONNECTION REQUEST           |                                                                                                                                                                       |
| 4    |           | ←  | RRC CONNECTION SETUP             | SS allocates dedicated physical channels to UE.                                                                                                                       |
| 5    |           | →  | RRC CONNECTION COMPLETE          | UE shall enter CELL_DCH state.                                                                                                                                        |

|    |   |                     |                                                                                          |
|----|---|---------------------|------------------------------------------------------------------------------------------|
| 6  | → | MEASUREMENT REPORT  | Event 4B is triggered. This message should come on RB1.                                  |
| 7  | ← | MEASUREMENT CONTROL | Periodic Traffic volume measurement reporting is requested.                              |
| 8  | → | MEASUREMENT REPORT  | This message should come on RB2.                                                         |
| 9  | → | MEASUREMENT REPORT  | Time difference between earlier and this MEASUREMENT REPORT message should be 8 Seconds. |
| 10 | ← | MEASUREMENT CONTROL | Release traffic volume measurement.                                                      |
| 11 |   |                     | Wait for 8 Seconds to confirm that UE does not send measurement report message.          |

## Specific Message Content

## System Information Block type 11 (Step 1)

| Information Element                              | Value/Remarks                     |
|--------------------------------------------------|-----------------------------------|
| SIB12 indicator                                  | FALSE                             |
| FACH measurement occasion info                   | Not Present                       |
| Measurement control system information           |                                   |
| → Use of HCS                                     | Not used                          |
| → Cell selection and reselection quality         | CPICH-RSCP                        |
| → Intra-frequency measurement system information | Not Present                       |
| → Inter-frequency measurement system information | Not Present                       |
| → Inter-RAT measurement system information       | Not Present                       |
| → Traffic volume measurement system information  |                                   |
| → Traffic volume measurement ID                  | 2                                 |
| → Traffic volume measurement object list         | Not Present                       |
| → Traffic volume measurement quantity            | Average RLC Buffer Payload        |
| → Time Interval to take an average               | 200 msec                          |
| → Traffic volume reporting quantity              |                                   |
| → RB-buffer payload                              | False                             |
| → RB-buffer payload average                      | True                              |
| → RB-buffer payload variance                     | False                             |
| → Traffic volume measurement reporting criteria  | Not Present                       |
| → Measurement validity                           | CELL_DCH                          |
| → Measurement reporting mode                     |                                   |
| → Measurement report transfer mode               | Unacknowledged Mode               |
| → Periodical or event trigger                    | Event Trigger                     |
| → Report criteria system Information             | Traffic Volume Reporting Criteria |
| → UL transport channel id                        | Not Present                       |
| → Event specific parameters                      |                                   |
| → Event id                                       | 4B                                |
| → Reporting threshold                            | 8K                                |
| → Time to trigger                                | Not Present                       |
| → Pending time after trigger                     | Not Present                       |
| → Tx interruption after trigger                  | Not Present                       |
| → UE internal measurement system information     | Not Present                       |

## RRC CONNECTION REQUEST (Step 3)

| Information Element      | Value/Remarks                                                                                 |
|--------------------------|-----------------------------------------------------------------------------------------------|
| Initial UE Identity      | Check to see if it is the same as the IMSI in USIM card, TMSI or P-TMSI previously allocated. |
| Establishment cause      | Check to see if set to originating call of the compatible traffic classes supported by the UE |
| Measured results on RACH | Check to see if IE is absent                                                                  |

## RRC CONNECTION SETUP (Step 4)

Use the same message sub-type found in Annex A, which is titled "Transition to CELL\_DCH".

## MEASUREMENT REPORT (Step 6)

| Information Element                | Value/Remarks                                                 |
|------------------------------------|---------------------------------------------------------------|
| Measurement identity               | Check to see if set to 2                                      |
| Measured Results                   |                                                               |
| CHOICE measurement                 | Check to see if set to "traffic volume measured results list" |
| Traffic volume measurement results |                                                               |
| RB identity                        | 0                                                             |
| RLC buffer payload                 | Check to see if this IE is absent                             |
| RLC buffer payload average         | Check to see if this IE is present                            |
| RLC buffer payload variance        | Check to see if this IE is absent                             |
| RB identity                        | 1                                                             |
| RLC buffer payload                 | Check to see if this IE is absent                             |
| RLC buffer payload average         | Check to see if this IE is present                            |
| RLC buffer payload variance        | Check to see if this IE is absent                             |
| RB identity                        | 2                                                             |
| RLC buffer payload                 | Check to see if this IE is absent                             |
| RLC buffer payload average         | Check to see if this IE is present                            |
| RLC buffer payload variance        | Check to see if this IE is absent                             |
| RB identity                        | 3                                                             |
| RLC buffer payload                 | Check to see if this IE is absent                             |
| RLC buffer payload average         | Check to see if this IE is present                            |
| RLC buffer payload variance        | Check to see if this IE is absent                             |
| RB identity                        | 4                                                             |
| RLC buffer payload                 | Check to see if this IE is absent                             |
| RLC buffer payload average         | Check to see if this IE is present                            |
| RLC buffer payload variance        | Check to see if this IE is absent                             |
| Measured results on RACH           | Check to see if this IE is absent                             |
| Additional measured results        | Check to see if this IE is absent                             |
| Event results                      |                                                               |
| UL transport channel causing event | DCH-5                                                         |
| Traffic volume event identity      | 4B                                                            |

## MEASUREMENT CONTROL (Step 7)

| Information Element                    | Value/Remark                  |
|----------------------------------------|-------------------------------|
| Measurement Identity                   | 2                             |
| Measurement Command                    | Reconfigure                   |
| CHOICE measurement type                | Traffic Volume Measurement    |
| Traffic volume measurement object list | DCH-5                         |
| Traffic volume measurement quantity    | RLC Buffer Payload            |
| Traffic volume reporting quantity      |                               |
| RB buffer payload                      | True                          |
| RB buffer payload average              | False                         |
| RB buffer payload variance             | False                         |
| Measurement validity                   | Not Present                   |
| Report criteria                        | Periodical Reporting Criteria |
| Reporting amount                       | 8                             |
| Reporting interval                     | 8 Sec                         |
| Measurement reporting mode             |                               |
| Transfer Mode                          | Acknowledged mode             |
| Periodical or event trigger            | Periodic                      |
| Additional measurement list            | Not Present                   |
| DPCH compressed mode status            | Not Present                   |



**MEASUREMENT REPORT (Step 8,9)**

| Information Element                  | Value/Remarks                        |
|--------------------------------------|--------------------------------------|
| Measurement identity                 | 2                                    |
| Measured Results                     |                                      |
| — CHOICE measurement                 | Traffic volume measured results list |
| — Traffic volume measurement results |                                      |
| — RB identity                        | 0                                    |
| — RLC buffer payload                 | Check to see if this IE is present   |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer payload variance        | Check to see if this IE is absent    |
| — RB identity                        | 1                                    |
| — RLC buffer payload                 | Check to see if this IE is present   |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer payload variance        | Check to see if this IE is absent    |
| — RB identity                        | 2                                    |
| — RLC buffer payload                 | Check to see if this IE is present   |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer payload variance        | Check to see if this IE is absent    |
| — RB identity                        | 3                                    |
| — RLC buffer payload                 | Check to see if this IE is present   |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer payload variance        | Check to see if this IE is absent    |
| — RB identity                        | 4                                    |
| — RLC buffer payload                 | Check to see if this IE is present   |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer payload variance        | Check to see if this IE is absent    |
| Measured results on RACH             | Check to see if this IE is absent    |
| Additional measured results          | Check to see if this IE is absent    |
| Event results                        | Check to see if this IE is absent    |

**MEASUREMENT CONTROL (Step 10)**

| Information Element         | Value/Remark |
|-----------------------------|--------------|
| Measurement Identity        | 2            |
| Measurement Command         | Release      |
| Measurement reporting mode  | Not Present  |
| Additional measurement list | Not Present  |
| DPCH compressed mode status | Not Present  |

**8.4.1.17.5 — Test Requirement**

After step 5, due to triggering of event 4B, the UE shall send MEASUREMENT REPORT message using unacknowledged mode of RLC. After step 7, UE shall send MEASUREMENT REPORT message using Acknowledged mode of RLC. After 8 seconds UE shall send second MEASUREMENT REPORT message. After step 10, the UE shall not send MEASUREMENT REPORT message.

**8.4.1.18 — Measurement Control and Report: Traffic volume measurement for transition from CELL\_FACH state to CELL\_DCH state****8.4.1.18.1 — Definition****8.4.1.18.2 — Conformance requirement**

Upon transition from CELL\_FACH to CELL\_DCH state, the UE shall:

- retrieve each set of measurement control information of measurement type "traffic volume" stored;
- if the optional IE "measurement validity" for this measurement has not been included;
- delete the measurement;

- if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states except CELL\_DCH":
  - stop measurement reporting; and
  - save the measurement to be used after the next transition to CELL\_FACH state;
- if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states":
  - continue measurement reporting;
- if the IE "measurement validity" has been included and the IE "UE state" has been assigned to value "CELL\_DCH":
  - resume this measurement and associated reporting;
- if no traffic volume type measurement has been assigned to the UE with a MEASUREMENT CONTROL message when transiting to CELL\_DCH state:
  - continue an ongoing traffic volume type measurement, assigned in System Information Block type 11 or System Information Block type 12.

## Reference

3GPP TS 25.331 clause 8.4.1.7.4

### 8.4.1.18.3 ————— Test Purpose

To confirm that the UE performs traffic volume measurements and the associated reporting when it enters CELL\_DCH state from CELL\_FACH state, and that such measurement contexts (and optionally, the reporting context) valid for CELL\_DCH state have been previously stored.

To confirm that the UE shall continue to perform traffic volume measurement listed in the System Information Block type 11 or 12 messages, if no previously assigned measurements are present. The UE shall transmit MEASUREMENT REPORT messages if reporting conditions stated in System Information Block type 11 or 12 messages have been satisfied.

### 8.4.1.18.4 ————— Method of test

#### Initial Condition

System Simulator: 1 cell

UE: PS-DCCH+DTCH\_FACH (state 6-11) as specified in clause 7.4 of TS 34.108

#### Test Procedure

Initially the UE is in CELL\_FACH state. MEASUREMENT CONTROL message is sent to the UE to establish traffic volume measurement context with optional IE "measurement validity" is not present. The UE shall perform measurement and reporting as assigned in MEASUREMENT CONTROL message. RADIO BEARER RECONFIGURATION procedure is used to take the UE from CELL\_FACH state to CELL\_DCH state. While entering CELL\_DCH state from CELL\_FACH state, the UE shall delete traffic volume measurement contexts if optional IE "measurement validity" is not present. So, in CELL\_DCH state UE shall not perform traffic volume measurement and reporting. UE is taken to the CELL\_FACH state from CELL\_DCH state using RADIO BEARER RECONFIGURATION procedure. The UE shall not send MEASUREMENT REPORT message as measurement context is already deleted.

Similarly behavior of the UE when moved from CELL\_FACH state to CELL\_DCH state and assigned traffic volume measurement context is present with IE "measurement validity" is set to "All But CELL\_DCH state" or "CELL\_DCH state" or "All states" is tested.

When the UE is in CELL\_FACH state, System Information is modified to assign traffic volume measurement and reporting to the UE. No previously assigned traffic volume measurement contexts are present in the UE. The UE is taken to CELL\_DCH state from CELL\_FACH state using RADIO BEARER RECONFIGURATION procedure. In CELL\_DCH state the UE shall continue traffic volume measurement and reporting as assigned in System Information. Traffic volume measurement and reporting is released by sending MEASUREMENT CONTROL message.

#### Expected Sequence

| Step | Direction |    | Message                               | Comment                                                                                                                                       |
|------|-----------|----|---------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                                                               |
| 1    |           | ←  | MEASUREMENT CONTROL                   | Optional IE "measurement validity" is not included.                                                                                           |
| 2    |           | →  | MEASUREMENT REPORT                    |                                                                                                                                               |
| 3    |           | ←  | RADIO BEARER RECONFIGURATION          |                                                                                                                                               |
| 4    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE | While entering in CELL_DCH state from CELL_FACH state UE shall delete measurement context setup by MEASUREMENT CONTROL message (Step 1).      |
| 5    |           |    |                                       | SS waits for 8 seconds to confirm that there is no MEASUREMENT REPORT message from UE.                                                        |
| 6    |           | ←  | RADIO BEARER RECONFIGURATION          |                                                                                                                                               |
| 7    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE | UE is in CELL_FACH state.                                                                                                                     |
| 8    |           |    |                                       | SS waits for 8 seconds to confirm that there is no MEASUREMENT REPORT message from UE.                                                        |
| 9    |           | ←  | MEASUREMENT CONTROL                   | IE "measurement validity" is set to "All But CELL_DCH".                                                                                       |
| 10   |           | →  | MEASUREMENT REPORT                    | ✓                                                                                                                                             |
| 11   |           | ←  | RADIO BEARER RECONFIGURATION          |                                                                                                                                               |
| 12   |           | →  | RADIO BEARER RECONFIGURATION COMPLETE | While entering in CELL_DCH state from CELL_FACH state UE shall stop traffic volume measurement setup by MEASUREMENT CONTROL message (Step 9). |
| 13   |           |    |                                       | SS waits for 8 seconds to confirm that there is no MEASUREMENT REPORT message from UE.                                                        |
| 14   |           | ←  | MEASUREMENT CONTROL                   | UE shall release measurement context setup by MEASUREMENT CONTROL message (Step 9).                                                           |
| 15   |           | ←  | RADIO BEARER RECONFIGURATION          |                                                                                                                                               |

|    |   |                                       |                                                                                                                                                    |
|----|---|---------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| 16 | → | RADIO BEARER RECONFIGURATION COMPLETE | UE is in CELL_FACH state.                                                                                                                          |
| 17 | ← | MEASUREMENT CONTROL                   | IE "measurement validity" is set to "CELL_DCH".                                                                                                    |
| 18 |   |                                       | SS waits for 8 seconds to confirm that there is no MEASUREMENT REPORT message from UE.                                                             |
| 19 | ← | RADIO BEARER RECONFIGURATION          |                                                                                                                                                    |
| 20 | → | RADIO BEARER RECONFIGURATION COMPLETE | While entering in CELL_DCH state from CELL_FACH state UE shall start traffic volume measurement setup by MEASUREMENT CONTROL message (Step 17).    |
| 21 | → | MEASUREMENT REPORT                    |                                                                                                                                                    |
| 22 | ← | MEASUREMENT CONTROL                   | UE shall release measurement context setup by MEASUREMENT CONTROL message (Step 17)                                                                |
| 23 | ← | RADIO BEARER RECONFIGURATION          |                                                                                                                                                    |
| 24 | → | RADIO BEARER RECONFIGURATION COMPLETE | UE is in CELL_FACH state.                                                                                                                          |
| 25 | ← | MEASUREMENT CONTROL                   | IE "measurement validity" is set to "All states".                                                                                                  |
| 26 | → | MEASUREMENT REPORT                    |                                                                                                                                                    |
| 27 | ← | RADIO BEARER RECONFIGURATION          |                                                                                                                                                    |
| 28 | → | RADIO BEARER RECONFIGURATION COMPLETE | While entering in CELL_DCH state from CELL_FACH state UE shall continue traffic volume measurement setup by MEASUREMENT CONTROL message (Step 25). |
| 29 | → | MEASUREMENT REPORT                    |                                                                                                                                                    |
| 30 | ← | MEASUREMENT CONTROL                   | UE shall release measurement context setup by MEASUREMENT CONTROL message (Step 25)                                                                |
| 31 | ← | RADIO BEARER RECONFIGURATION          |                                                                                                                                                    |
| 32 | → | RADIO BEARER RECONFIGURATION COMPLETE | UE is in CELL_FACH state.                                                                                                                          |

|    |   |                                       |                                                                                                                                              |
|----|---|---------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| 33 | ← | SIB11-modified                        | Traffic volume measurements and reporting is assigned to Ues                                                                                 |
| 34 | → | MEASUREMENT REPORT                    |                                                                                                                                              |
| 35 | ← | RADIO BEARER RECONFIGURATION          |                                                                                                                                              |
| 36 | → | RADIO BEARER RECONFIGURATION COMPLETE | While entering in CELL_DCH state from CELL_FACH state UE shall continue traffic volume measurement assigned in System Information (Step 33). |
| 37 | → | MEASUREMENT REPORT                    |                                                                                                                                              |
| 38 | ← | MEASUREMENT CONTROL                   | UE shall release measurement context assigned in System Information (Step 33).                                                               |

### Specific Message Content

#### MEASUREMENT CONTROL (Step 1)

| Information Element                      | Value/Remark                  |
|------------------------------------------|-------------------------------|
| Measurement Identity                     | 1                             |
| Measurement Command                      | Setup                         |
| → CHOICE measurement type                | Traffic Volume Measurement    |
| → Traffic volume measurement object list | Not Present                   |
| → Traffic volume measurement quantity    | RLC Buffer Payload            |
| → Traffic volume reporting quantity      |                               |
| → RB buffer payload                      | True                          |
| → RB buffer payload average              | False                         |
| → RB buffer payload variance             | False                         |
| → Measurement validity                   | Not Present                   |
| → Report criteria                        | Periodical Reporting Criteria |
| → Reporting amount                       | 8                             |
| → Reporting interval                     | 8-Sec                         |
| → Measurement reporting mode             |                               |
| → Transfer Mode                          | Acknowledged mode             |
| → Periodical or event trigger            | Periodic                      |
| Additional measurement list              | Not Present                   |
| DPCH compressed mode status              | Not Present                   |

**MEASUREMENT REPORT (Step 2)**

| Information Element                  | Value/Remarks                        |
|--------------------------------------|--------------------------------------|
| Measurement identity                 | 1                                    |
| Measured Results                     |                                      |
| → CHOICE measurement                 | Traffic volume measured results list |
| → Traffic volume measurement results |                                      |
| → RB identity                        | 0                                    |
| → RLC buffer payload                 | Check to see if this IE is present   |
| → RLC buffer payload average         | Check to see if this IE is absent    |
| → RLC buffer variance                | Check to see if this IE is absent    |
| → RB identity                        | 1                                    |
| → RLC buffer payload                 | Check to see if this IE is present   |
| → RLC buffer payload average         | Check to see if this IE is absent    |
| → RLC buffer payload variance        | Check to see if this IE is absent    |
| → RB identity                        | 2                                    |
| → RLC buffer payload                 | Check to see if this IE is present   |
| → RLC buffer payload average         | Check to see if this IE is absent    |
| → RLC buffer payload variance        | Check to see if this IE is absent    |
| → RB identity                        | 3                                    |
| → RLC buffer payload                 | Check to see if this IE is present   |
| → RLC buffer payload average         | Check to see if this IE is absent    |
| → RLC buffer payload variance        | Check to see if this IE is absent    |
| → RB identity                        | 4                                    |
| → RLC buffer payload                 | Check to see if this IE is present   |
| → RLC buffer payload average         | Check to see if this IE is absent    |
| → RLC buffer payload variance        | Check to see if this IE is absent    |
| → RB identity                        | 20                                   |
| → RLC buffer payload                 | Check to see if this IE is present   |
| → RLC buffer payload average         | Check to see if this IE is absent    |
| → RLC buffer payload variance        | Check to see if this IE is absent    |
| Measured results on RACH             | Check to see if this IE is absent    |
| Additional measured results          | Check to see if this IE is absent    |
| Event results                        | Check to see if this IE is absent    |

**RADIO BEARER RECONFIGURATION (Step 3, 11, 19, 27, and 35)**

Use the same message type found in Annex A with condition set to A4.

**RADIO BEARER RECONFIGURATION (Step 6, 15, 23, and 31)**

Use the same message type found in Annex A with condition set to A5.

**MEASUREMENT CONTROL (Step 9)**

The contents of this message are identical to MEASUREMENT CONTROL (Step 1) message with the following exceptions:

| Information Element       | Value/Remark               |
|---------------------------|----------------------------|
| Measurement Identity      | 2                          |
| Measurement Command       | Setup                      |
| → CHOICE measurement type | Traffic Volume Measurement |
| → Measurement validity    | All But CELL_DCH           |

**MEASUREMENT REPORT (Step 10)**

The contents of this message are identical to MEASUREMENT REPORT (Step 2) message with the following exceptions:

| Information Element  | Value/Remarks |
|----------------------|---------------|
| Measurement identity | 2             |

**MEASUREMENT CONTROL (Step 14)**

| Information Element         | Value/Remark |
|-----------------------------|--------------|
| Measurement Identity        | 2            |
| Measurement Command         | Release      |
| Measurement reporting mode  | Not Present  |
| Additional measurement list | Not Present  |
| DPCH compressed mode status | Not Present  |

**MEASUREMENT CONTROL (Step 17)**

The contents of this message are identical to MEASUREMENT CONTROL (Step 1) message with the following exceptions:

| Information Element      | Value/Remark               |
|--------------------------|----------------------------|
| Measurement Identity     | 3                          |
| Measurement Command      | Setup                      |
| –CHOICE measurement type | Traffic Volume Measurement |
| – Measurement validity   | CELL_DCH                   |

**MEASUREMENT REPORT (Step 21)**

The contents of this message are identical to MEASUREMENT REPORT (Step 2) message with the following exceptions:

| Information Element  | Value/Remarks |
|----------------------|---------------|
| Measurement identity | 3             |

**MEASUREMENT CONTROL (Step 22)**

The contents of this message are identical to MEASUREMENT CONTROL (Step 14) message with the following exceptions:

| Information Element  | Value/Remark |
|----------------------|--------------|
| Measurement Identity | 3            |

**MEASUREMENT CONTROL (Step 25)**

The contents of this message are identical to MEASUREMENT CONTROL (Step 1) message with the following exceptions:

| Information Element                      | Value/Remark               |
|------------------------------------------|----------------------------|
| Measurement Identity                     | 4                          |
| Measurement Command                      | Setup                      |
| –CHOICE measurement type                 | Traffic Volume Measurement |
| – Traffic volume measurement object list |                            |
| – UL transport channel identity          | RACH                       |
| – UL transport channel identity          | DCH :1                     |
| – UL transport channel identity          | DCH : 5                    |
| – Measurement validity                   | All States                 |

**MEASUREMENT REPORT (Step 26, and 29)**

The contents of this message are identical to MEASUREMENT REPORT (Step 2) message with the following exceptions:

| Information Element  | Value/Remarks |
|----------------------|---------------|
| Measurement identity | 4             |

**MEASUREMENT CONTROL (Step 30)**

The contents of this message are identical to MEASUREMENT CONTROL (Step 14) message with the following exceptions:

| Information Element  | Value/Remark |
|----------------------|--------------|
| Measurement Identity | 4            |

**System Information Block type 11 (Step 33)**

| Information Element                              | Value/Remarks                 |
|--------------------------------------------------|-------------------------------|
| SIB12 indicator                                  | FALSE                         |
| FACH measurement occasion info                   | Not Present                   |
| Measurement control system information           |                               |
| → Use of HCS                                     | Not used                      |
| → Cell selection and reselection quality         | GPICH-RSCP                    |
| → Intra-frequency measurement system information | Not Present                   |
| → Inter-frequency measurement system information | Not Present                   |
| → Inter-RAT measurement system information       | Not Present                   |
| → Traffic volume measurement system information  |                               |
| → Traffic volume measurement ID                  | 5                             |
| → Traffic volume measurement object list         | Not Present                   |
| → Traffic volume measurement quantity            | RLC Buffer Payload            |
| → Traffic volume reporting quantity              |                               |
| → RB buffer payload                              | True                          |
| → RB buffer payload average                      | False                         |
| → RB buffer payload variance                     | False                         |
| → Traffic volume measurement reporting criteria  | Not Present                   |
| → Measurement validity                           | Not Present                   |
| → Measurement reporting mode                     |                               |
| → Measurement report transfer mode               | Acknowledged Mode             |
| → Periodical or event trigger                    | Periodical                    |
| → Report criteria system information             | Periodical reporting criteria |
| → Reporting amount                               | Infinity                      |
| → Reporting interval                             | 8 seconds                     |
| → UE internal measurement system information     | Not Present                   |

**MEASUREMENT REPORT (Step 34, and 37)**

The contents of this message are identical to MEASUREMENT REPORT (Step 2) message with the following exceptions:

| Information Element  | Value/Remarks |
|----------------------|---------------|
| Measurement identity | 5             |



### MEASUREMENT CONTROL (Step 38)

The contents of this message are identical to MEASUREMENT CONTROL (Step 14) message with the following exceptions:

| Information Element  | Value/Remark |
|----------------------|--------------|
| Measurement Identity | 5            |

#### 8.4.1.18.5 ——— Test Requirement

The UE shall send MEASUREMENT REPORT message in steps 21, 29 and 37. The UE shall not send MEASUREMENT REPORT message in steps 5, 8, and 13.

### ~~8.4.1.19 ——— Measurement Control and Report: Traffic volume measurement for transition from CELL\_DCH to CELL\_FACH state~~

#### ~~8.4.1.19.1 ——— Definition~~

#### ~~8.4.1.19.2 ——— Conformance requirement~~

Upon transition from CELL\_DCH to CELL\_FACH state, the UE shall:

- retrieve each set of measurement control information of measurement type "traffic volume" stored in the UE; and
- if the optional IE "measurement validity" for this measurement has not been included:
  - delete the associated measurement;
- if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "CELL\_DCH":
  - stop measurement reporting;
  - save the associated measurement to be used after the next transition to CELL\_DCH state;
- if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states":
  - continue measurement reporting;
- if the IE "measurement validity" has been included and the IE "UE state" has been assigned to value "all states except CELL\_DCH":
  - resume this measurement and associated reporting;
- if no traffic volume type measurements applicable to CELL\_FACH states are stored in the UE:
  - store the measurement control information from the IE "Traffic volume measurement system information" received in System Information Block type 12 or System Information Block type 11;
  - begin traffic volume measurement reporting according to the assigned information.

#### ~~8.4.1.19.3 ——— Test Purpose~~

The UE shall performs traffic volume measurements and the associated reporting when it enters CELL\_FACH state from CELL\_DCH state, and that such measurement contexts (and optionally, the reporting context) valid for CELL\_FACH state have been previously stored.

The UE shall perform traffic volume measurement listed in the System Information Block type 11 or 12 messages, if no previously assigned measurements are present. The UE shall transmit MEASUREMENT REPORT messages if reporting conditions has been satisfied.

## Reference

3GPP TS 25.331 clause 8.4.1.6.6

## 8.4.1.19.4 Method of test

### Initial Condition

System Simulator: 1 cell

UE: PS-DCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108

### Test Procedure

Initially the UE is in CELL\_DCH state. MEASUREMENT CONTROL message is sent to the UE to establish traffic volume measurement context with optional IE "measurement validity" is not present. The UE shall perform measurement and reporting as assigned in MEASUREMENT CONTROL message. RADIO BEARER RECONFIGURATION procedure is used to take the UE from CELL\_DCH state to CELL\_FACH state. While entering CELL\_FACH state from CELL\_DCH state, the UE shall delete traffic volume measurement contexts if optional IE "measurement validity" is not present. So, in CELL\_FACH state UE shall not perform traffic volume measurement and reporting. UE is taken to the CELL\_DCH state from CELL\_FACH state using RADIO BEARER RECONFIGURATION procedure. The UE shall not send MEASUREMENT REPORT message as measurement context is already deleted.

Similarly behavior of the UE when moved from CELL\_DCH state to CELL\_FACH state and assigned traffic volume measurement context is present with IE "measurement validity" is set to "All But CELL\_DCH state" or "CELL\_DCH state" or "All states" is tested.

When the UE is in CELL\_DCH state, System Information is modified to assign traffic volume measurement and reporting to the UE. No previously assigned traffic volume measurement contexts are present in the UE. The UE is taken to CELL\_FACH state from CELL\_DCH state using RADIO BEARER RECONFIGURATION procedure. In CELL\_FACH state the UE shall perform traffic volume measurement and reporting as assigned in System Information. Traffic volume measurement and reporting is released by sending MEASUREMENT CONTROL message.

### Expected Sequence

| Step | Direction |    | Message                               | Comment                                                                                                                                  |
|------|-----------|----|---------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                                                          |
| 1    |           | ←  | MEASUREMENT CONTROL                   | Optional IE "measurement validity" is not included.                                                                                      |
| 2    |           | →  | MEASUREMENT REPORT                    |                                                                                                                                          |
| 3    |           | ←  | RADIO BEARER RECONFIGURATION          |                                                                                                                                          |
| 4    |           | →  | RADIO BEARER RECONFIGURATION COMPLETE | While entering in CELL_FACH state from CELL_DCH state UE shall delete measurement context setup by MEASUREMENT CONTROL message (Step 1). |
| 5    |           |    |                                       | SS waits for 8 seconds to confirm that there is no MEASUREMENT REPORT message from UE.                                                   |
| 6    |           | ←  | RADIO BEARER RECONFIGURATION          |                                                                                                                                          |

|    |   |                                       |                                                                                                                                                |
|----|---|---------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| 7  | → | RADIO BEARER RECONFIGURATION COMPLETE | UE is in CELL_DCH state.                                                                                                                       |
| 8  |   |                                       | SS waits for 8 seconds to confirm that there is no MEASUREMENT REPORT message from UE.                                                         |
| 9  | ← | MEASUREMENT CONTROL                   | IE "measurement validity" is set to "All But CELL_DCH".                                                                                        |
| 10 |   |                                       | SS waits for 8 seconds to confirm that there is no MEASUREMENT REPORT message from UE.                                                         |
| 11 | ← | RADIO BEARER RECONFIGURATION          |                                                                                                                                                |
| 12 | → | RADIO BEARER RECONFIGURATION COMPLETE | While entering in CELL_FACH state from CELL_DCH state UE shall start traffic volume measurement setup by MEASUREMENT CONTROL message (Step 9). |
| 13 | → | MEASUREMENT REPORT                    |                                                                                                                                                |
| 14 | ← | MEASUREMENT CONTROL                   | UE shall release measurement context setup by MEASUREMENT CONTROL message (Step 9).                                                            |
| 15 | ← | RADIO BEARER RECONFIGURATION          |                                                                                                                                                |
| 16 | → | RADIO BEARER RECONFIGURATION COMPLETE | UE is in CELL_DCH state.                                                                                                                       |
| 17 | ← | MEASUREMENT CONTROL                   | IE "measurement validity" is set to "CELL_DCH".                                                                                                |
| 18 | → | MEASUREMENT REPORT                    |                                                                                                                                                |
| 19 | ← | RADIO BEARER RECONFIGURATION          |                                                                                                                                                |
| 20 | → | RADIO BEARER RECONFIGURATION COMPLETE | While entering in CELL_FACH state from CELL_DCH state UE shall stop traffic volume measurement setup by MEASUREMENT CONTROL message (Step 17). |
| 21 |   |                                       | SS waits for 8 seconds to confirm that there is no                                                                                             |
| 22 | ← | MEASUREMENT CONTROL                   | UE shall release measurement context setup by MEASUREMENT CONTROL message (Step 17)                                                            |
| 23 | ← | RADIO BEARER RECONFIGURATION          |                                                                                                                                                |

|    |   |                                       |                                                                                                                                                    |
|----|---|---------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| 24 | → | RADIO BEARER RECONFIGURATION COMPLETE | UE is in CELL_DCH state.                                                                                                                           |
| 25 | ← | MEASUREMENT CONTROL                   | IE "measurement validity" is set to "All states".                                                                                                  |
| 26 | → | MEASUREMENT REPORT                    |                                                                                                                                                    |
| 27 | ← | RADIO BEARER RECONFIGURATION          |                                                                                                                                                    |
| 28 | → | RADIO BEARER RECONFIGURATION COMPLETE | While entering in CELL_FACH state from CELL_DCH state UE shall continue traffic volume measurement setup by MEASUREMENT CONTROL message (Step 25). |
| 29 | → | MEASUREMENT REPORT                    |                                                                                                                                                    |
| 30 | ← | MEASUREMENT CONTROL                   | UE shall release measurement context setup by MEASUREMENT CONTROL message (Step 25)                                                                |
| 31 | ← | RADIO BEARER RECONFIGURATION          |                                                                                                                                                    |
| 32 | → | RADIO BEARER RECONFIGURATION COMPLETE | UE is in CELL_DCH state.                                                                                                                           |
| 33 | ← | SIB12 modified                        | Traffic volume measurements and reporting is assigned to UEs                                                                                       |
| 34 | ← | RADIO BEARER RECONFIGURATION          |                                                                                                                                                    |
| 35 | → | RADIO BEARER RECONFIGURATION COMPLETE | While entering in CELL_FACH state from CELL_DCH state UE shall start traffic volume measurement as assigned in System Information (Step 33).       |
| 36 | → | MEASUREMENT REPORT                    |                                                                                                                                                    |
| 37 | ← | MEASUREMENT CONTROL                   | UE shall release measurement context assigned in System Information (Step 33).                                                                     |

## Specific Message Content

## MEASUREMENT CONTROL (Step 1)

| Information Element                      | Value/Remark                  |
|------------------------------------------|-------------------------------|
| Measurement Identity                     | 1                             |
| Measurement Command                      | Setup                         |
| → CHOICE measurement type                | Traffic Volume Measurement    |
| → Traffic volume measurement object list | Not Present                   |
| → Traffic volume measurement quantity    | RLC Buffer Payload            |
| → Traffic volume reporting quantity      |                               |
| → RB buffer payload                      | True                          |
| → RB buffer payload average              | False                         |
| → RB buffer payload variance             | False                         |
| → Measurement validity                   | Not Present                   |
| → Report criteria                        | Periodical Reporting Criteria |
| → Reporting amount                       | 8                             |
| → Reporting interval                     | 8-Sec                         |
| → Measurement reporting mode             |                               |
| → Transfer Mode                          | Acknowledged mode             |
| → Periodical or event trigger            | Periodic                      |
| Additional measurement list              | Not Present                   |
| DPCH compressed mode status              | Not Present                   |

## MEASUREMENT REPORT (Step 2)

| Information Element                  | Value/Remarks                        |
|--------------------------------------|--------------------------------------|
| Measurement identity                 | 1                                    |
| Measured Results                     |                                      |
| → CHOICE measurement                 | Traffic volume measured results list |
| → Traffic volume measurement results |                                      |
| →→ RB identity                       | 0                                    |
| →→ RLC buffer payload                | Check to see if this IE is present   |
| →→ RLC buffer payload average        | Check to see if this IE is absent    |
| →→ RLC buffer variance               | Check to see if this IE is absent    |
| →→ RB identity                       | 1                                    |
| →→ RLC buffer payload                | Check to see if this IE is present   |
| →→ RLC buffer payload average        | Check to see if this IE is absent    |
| →→ RLC buffer payload variance       | Check to see if this IE is absent    |
| →→ RB identity                       | 2                                    |
| →→ RLC buffer payload                | Check to see if this IE is present   |
| →→ RLC buffer payload average        | Check to see if this IE is absent    |
| →→ RLC buffer payload variance       | Check to see if this IE is absent    |
| →→ RB identity                       | 3                                    |
| →→ RLC buffer payload                | Check to see if this IE is present   |
| →→ RLC buffer payload average        | Check to see if this IE is absent    |
| →→ RLC buffer payload variance       | Check to see if this IE is absent    |
| →→ RB identity                       | 4                                    |
| →→ RLC buffer payload                | Check to see if this IE is present   |
| →→ RLC buffer payload average        | Check to see if this IE is absent    |
| →→ RLC buffer payload variance       | Check to see if this IE is absent    |
| →→ RB identity                       | 20                                   |
| →→ RLC buffer payload                | Check to see if this IE is present   |
| →→ RLC buffer payload average        | Check to see if this IE is absent    |
| →→ RLC buffer payload variance       | Check to see if this IE is absent    |
| Measured results on RACH             | Check to see if this IE is absent    |
| Additional measured results          | Check to see if this IE is absent    |
| Event results                        | Check to see if this IE is absent    |

## RADIO BEARER RECONFIGURATION (Step 3, 11, 19, 27, and 34)

Use the same message type found in Annex A with condition set to A5.

**RADIO-BEARER RECONFIGURATION (Step 6, 15, 23, and 31)**

Use the same message type found in Annex A with condition set to A4.

**MEASUREMENT CONTROL (Step 9)**

The contents of this message are identical to MEASUREMENT CONTROL (Step 1) message with the following exceptions:

| Information Element      | Value/Remark               |
|--------------------------|----------------------------|
| Measurement Identity     | 2                          |
| Measurement Command      | Setup                      |
| -CHOICE measurement type | Traffic Volume Measurement |
| → Measurement validity   | All But CELL_DCH           |

**MEASUREMENT REPORT (Step 13)**

The contents of this message are identical to MEASUREMENT REPORT (Step 2) message with the following exceptions:

| Information Element  | Value/Remarks |
|----------------------|---------------|
| Measurement identity | 2             |

**MEASUREMENT CONTROL (Step 14)**

| Information Element         | Value/Remark |
|-----------------------------|--------------|
| Measurement Identity        | 2            |
| Measurement Command         | Release      |
| Measurement reporting mode  | Not Present  |
| Additional measurement list | Not Present  |
| DPCH compressed mode status | Not Present  |

**MEASUREMENT CONTROL (Step 17)**

The contents of this message are identical to MEASUREMENT CONTROL (Step 1) message with the following exceptions:

| Information Element      | Value/Remark               |
|--------------------------|----------------------------|
| Measurement Identity     | 3                          |
| Measurement Command      | Setup                      |
| -CHOICE measurement type | Traffic Volume Measurement |
| → Measurement validity   | CELL_DCH                   |

**MEASUREMENT REPORT (Step 18)**

The contents of this message are identical to MEASUREMENT REPORT (Step 2) message with the following exceptions:

| Information Element  | Value/Remarks |
|----------------------|---------------|
| Measurement identity | 3             |

**MEASUREMENT CONTROL (Step 22)**

The contents of this message are identical to MEASUREMENT CONTROL (Step 14) message with the following exceptions:

| Information Element  | Value/Remark |
|----------------------|--------------|
| Measurement Identity | 3            |

#### MEASUREMENT CONTROL (Step 25)

The contents of this message are identical to MEASUREMENT CONTROL (Step 1) message with the following exceptions:

| Information Element                      | Value/Remark               |
|------------------------------------------|----------------------------|
| Measurement Identity                     | 4                          |
| Measurement Command                      | Setup                      |
| -CHOICE measurement type                 | Traffic Volume Measurement |
| — Traffic volume measurement object list |                            |
| -UL transport channel identity           | RACH                       |
| -UL transport channel identity           | DCH :1                     |
| -UL transport channel identity           | DCH : 5                    |
| — Measurement validity                   | All States                 |

#### MEASUREMENT REPORT (Step 26, and 29)

The contents of this message are identical to MEASUREMENT REPORT (Step 2) message with the following exceptions:

| Information Element  | Value/Remarks |
|----------------------|---------------|
| Measurement identity | 4             |

#### MEASUREMENT CONTROL (Step 30)

The contents of this message are identical to MEASUREMENT CONTROL (Step 14) message with the following exceptions:

| Information Element  | Value/Remark |
|----------------------|--------------|
| Measurement Identity | 4            |

## System Information Block type 12 (Step 33)

| Information Element                              | Value/Remarks                 |
|--------------------------------------------------|-------------------------------|
| FACH measurement occasion info                   | Not Present                   |
| Measurement control system information           |                               |
| → Use of HCS                                     | Not used                      |
| → Cell selection and reselection quality         | CPICH RSCP                    |
| → Intra-frequency measurement system information | Not Present                   |
| → Inter-frequency measurement system information | Not Present                   |
| → Inter-RAT measurement system information       | Not Present                   |
| → Traffic volume measurement system information  |                               |
| → Traffic volume measurement ID                  | 5                             |
| → Traffic volume measurement object list         | Not Present                   |
| → Traffic volume measurement quantity            | RLC Buffer Payload            |
| → Traffic volume reporting quantity              |                               |
| → RB buffer payload                              | True                          |
| → RB buffer payload average                      | False                         |
| → RB buffer payload variance                     | False                         |
| → Traffic volume measurement reporting criteria  | Not Present                   |
| → Measurement validity                           | Not Present                   |
| → Measurement reporting mode                     |                               |
| → Measurement report transfer mode               | Acknowledged Mode             |
| → Periodical or event trigger                    | Periodical                    |
| → Report criteria system Information             | Periodical reporting criteria |
| → Reporting amount                               | Infinity                      |
| → Reporting interval                             | 8 seconds                     |
| → UE internal measurement system information     | Not Present                   |

## MEASUREMENT REPORT (Step 36)

The contents of this message are identical to MEASUREMENT REPORT (Step 2) message with the following exceptions:

| Information Element  | Value/Remarks |
|----------------------|---------------|
| Measurement identity | 5             |

## MEASUREMENT CONTROL (Step 37)

The contents of this message are identical to MEASUREMENT CONTROL (Step 14) message with the following exceptions:

| Information Element  | Value/Remark |
|----------------------|--------------|
| Measurement Identity | 5            |

## 8.4.1.19.5 ——— Test Requirement

The UE shall send MEASUREMENT REPORT message in steps 13, 29 and 36. The UE shall not send MEASUREMENT REPORT message in steps 5, 8, and 21.



### ~~8.4.1.20 Measurement Control and Report: Traffic volume measurement in CELL\_PCH state~~

#### ~~8.4.1.20.1 Definition~~

#### ~~8.4.1.20.2 Conformance requirement~~

~~In CELL\_PCH state, when the reporting criteria is fulfilled for any traffic volume measurement which is being performed in the UE, the UE shall first perform the cell update procedure with the cause "uplink data transmission", in order to transit to CELL\_FACH state and then transmit a MEASUREMENT REPORT message on the uplink DCCH~~

#### ~~8.4.1.20.3 Test Purpose~~

~~To confirm that in CELL\_PCH state, UE performs assigned traffic volume measurement. When reporting criteria for ongoing traffic volume measurement is fulfilled, the UE shall first perform cell update procedure and then transmit MEASUREMENT REPORT message.~~

#### ~~Reference~~

~~3GPP TS 25.331 clause 8.4.2.2~~

#### ~~8.4.1.20.4 Method of test~~

#### ~~Initial Condition~~

~~System Simulator: 1 cell~~

~~UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108~~

#### ~~Test Procedure~~

~~Initially the UE is in CELL\_DCH state. System Information block type 12 message is modified to assign traffic volume measurement and reporting. RADIO BEARER RECONFIGURATION procedure is used to take UE from CELL\_DCH state to CELL\_PCH state. While entering in CELL\_PCH state from CELL\_DCH state UE should start traffic volume measurement as assigned in System Information. When reporting criteria for traffic volume measurement is satisfied the UE shall change state to CELL\_FACH and perform CELL UPDATE procedure. After successful completion of CELL UPDATE procedure, UE shall transmit MEASUREMENT REPORT message.~~

## Expected Sequence

| Step | Direction |    | Message                               | Comment                                                                                                                                    |
|------|-----------|----|---------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                                                            |
| 1    |           | ←  | SIB12-modified                        | Traffic volume measurements and reporting is assigned to UEs                                                                               |
| 2    |           | ←  | RADIO-BEARER RECONFIGURATION          | IE "RRC-State-Indicator" is set to "CELL_PCH"                                                                                              |
| 3    |           | →  | RADIO-BEARER RECONFIGURATION COMPLETE | While entering in CELL_PCH state from CELL_DCH state UE shall start traffic volume measurement as assigned in System Information (Step 1). |
| 4    |           | →  | CELL UPDATE                           | The UE shall move to CELL_FACH state with the message set to "uplink data transmission" in IE "Cell update-cause".                         |
| 5    |           | ←  | CELL UPDATE CONFIRM                   |                                                                                                                                            |
| 6    |           | →  | MEASUREMENT REPORT                    |                                                                                                                                            |

## Specific Message Content

## System Information Block type 12 (Step 1)

| Information Element                              | Value/Remarks                  |
|--------------------------------------------------|--------------------------------|
| FACH measurement occasion info                   | Not Present                    |
| Measurement control system information           |                                |
| → Use of HCS                                     | Not used                       |
| → Cell_selection_and_reselection_quality         | CPICH-RSCP                     |
| → Intra-frequency measurement system information | Not Present                    |
| → Inter-frequency measurement system information | Not Present                    |
| → Inter-RAT measurement system information       | Not Present                    |
| → Traffic volume measurement system information  |                                |
| → Traffic volume measurement ID                  | 1                              |
| → Traffic volume measurement object list         |                                |
| → UL transport channel identity                  | RACH                           |
| → UL transport channel identity                  | DCH : 5                        |
| → Traffic volume measurement quantity            | Variance of RLC-Buffer Payload |
| → Time Interval to take an average               | 200 msec                       |
| → Traffic volume reporting quantity              |                                |
| → RB-buffer payload                              | False                          |
| → RB-buffer payload average                      | False                          |
| → RB-buffer payload variance                     | True                           |
| → Traffic volume measurement reporting criteria  | Not Present                    |
| → Measurement validity                           | All States                     |
| → Measurement reporting mode                     |                                |
| → Measurement report transfer mode               | Acknowledged-Mode              |
| → Periodical or event trigger                    | Periodical                     |
| → Report criteria system information             | Periodical reporting criteria  |
| → Reporting amount                               | Infinity                       |
| → Reporting interval                             | 8 seconds                      |
| → UE internal measurement system information     | Not Present                    |

## RADIO-BEARER RECONFIGURATION (Step 2)

Use the same message type found in Annex A with condition set to A5 except following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| RRC State Indicator | CELL_PCH     |

#### CELL UPDATE (Step 4)

Use the same message type found in Annex A with condition set to A5 except following exceptions:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| Cell Update Cause   | Check to see if set to "Uplink data transmission" |

#### MEASUREMENT REPORT (Step 6)

| Information Element                  | Value/Remarks                        |
|--------------------------------------|--------------------------------------|
| Measurement identity                 | 1                                    |
| Measured Results                     |                                      |
| — CHOICE measurement                 | Traffic volume measured results list |
| — Traffic volume measurement results |                                      |
| — RB identity                        | 0                                    |
| — RLC buffer payload                 | Check to see if this IE is absent    |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer variance                | Check to see if this IE is present   |
| — RB identity                        | 1                                    |
| — RLC buffer payload                 | Check to see if this IE is absent    |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer payload variance        | Check to see if this IE is present   |
| — RB identity                        | 2                                    |
| — RLC buffer payload                 | Check to see if this IE is absent    |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer payload variance        | Check to see if this IE is present   |
| — RB identity                        | 3                                    |
| — RLC buffer payload                 | Check to see if this IE is absent    |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer payload variance        | Check to see if this IE is present   |
| — RB identity                        | 4                                    |
| — RLC buffer payload                 | Check to see if this IE is absent    |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer payload variance        | Check to see if this IE is present   |
| — RB identity                        | 20                                   |
| — RLC buffer payload                 | Check to see if this IE is absent    |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer payload variance        | Check to see if this IE is present   |
| Measured results on RACH             | Check to see if this IE is absent    |
| Additional measured results          | Check to see if this IE is absent    |
| Event results                        | Check to see if this IE is absent    |

#### 8.4.1.20.5 — Test Requirement

The UE shall send CELL UPDATE message with cause "Uplink data transfer" in step 4 and MEASUREMENT REPORT message in 6.

### ~~8.4.1.21 Measurement Control and Report: Traffic volume measurement in URA\_PCH state~~

#### ~~8.4.1.21.1 Definition~~

#### ~~8.4.1.21.2 Conformance requirement~~

~~In URA\_PCH state, when the reporting criteria is fulfilled for any traffic volume measurement which is being performed in the UE, the UE shall first perform the cell update procedure with the cause "uplink data transmission", in order to transit to CELL\_FACH state and then transmit a MEASUREMENT REPORT message on the uplink DCCH~~

#### ~~8.4.1.21.3 Test Purpose~~

~~To confirm that in URA\_PCH state, UE performs assigned traffic volume measurement. When reporting criteria for ongoing traffic volume measurement is fulfilled, the UE shall first perform cell update procedure and then transmit MEASUREMENT REPORT message.~~

#### ~~Reference~~

~~3GPP TS 25.331 clause 8.4.2.2~~

#### ~~8.4.1.21.4 Method of test~~

#### ~~Initial Condition~~

~~System Simulator: 1 cell~~

~~UE: PS-DCCH+DTCH\_DCH (state 6-10) as specified in clause 7.4 of TS 34.108~~

#### ~~Test Procedure~~

~~Initially the UE is in CELL\_DCH state. MEASUREMENT CONTROL message is sent to UE to assign traffic volume measurement and reporting to be performed in all states except CELL\_DCH. The UE is requested to perform periodic reporting of measurements with IE "Reporting amount" is set to 1. RADIO BEARER RECONFIGURATION procedure is used to take UE from CELL\_DCH state to URA\_PCH state. While entering in URA\_PCH state from CELL\_DCH state UE should start traffic volume measurement as assigned by MEASUREMENT CONTROL message. When reporting criteria for traffic volume measurement is satisfied the UE shall change state to CELL\_FACH and perform CELL UPDATE procedure. After successful completion of CELL UPDATE procedure, UE shall transmit MEASUREMENT REPORT message. The UE shall not send second MEASUREMENT REPORT message after reporting interval, because IE "Reporting amount" in MEASUREMENT CONTROL message is set to 1.~~

## Expected Sequence

| Step | Direction |    | Message                               | Comment                                                                                                                                   |
|------|-----------|----|---------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                                                           |
| 1    |           | ←  | MEASUREMENT-CONTROL                   | IE "Reporting amount" is set to 1.                                                                                                        |
| 2    |           | ←  | RADIO-BEARER RECONFIGURATION          | IE "RRC State Indicator" is set to "URA_PCH"                                                                                              |
| 3    |           | →  | RADIO-BEARER RECONFIGURATION COMPLETE | While entering in URA_PCH state from CELL_DCH state UE shall start traffic volume measurement as assigned in System Information (Step 1). |
| 4    |           | →  | CELL-UPDATE                           | The UE shall move to CELL_FACH state with the message set to "uplink data transmission" in IE "Cell update cause".                        |
| 5    |           | ←  | CELL-UPDATE CONFIRM                   |                                                                                                                                           |
| 6    |           | →  | MEASUREMENT REPORT                    |                                                                                                                                           |
| 7    |           |    |                                       | SS waits for 8 Sec to confirm that UE does not send second MEASUREMENT REPORT message                                                     |

## Specific Message Content

## MEASUREMENT-CONTROL (Step 1)

| Information Element                      | Value/Remark                   |
|------------------------------------------|--------------------------------|
| Measurement Identity                     | 15                             |
| Measurement Command                      | Setup                          |
| → CHOICE measurement type                | Traffic Volume Measurement     |
| → Traffic volume measurement object list | RACH                           |
| → Traffic volume measurement quantity    | Variance of RLC Buffer Payload |
| → Time Interval to take an average       | 200 msec                       |
| → Traffic volume reporting quantity      |                                |
| → RB buffer payload                      | False                          |
| → RB buffer payload average              | False                          |
| → RB buffer payload variance             | True                           |
| → Measurement validity                   | All but CELL_DCH State         |
| → Report criteria                        | Periodical Reporting Criteria  |
| → Reporting amount                       | 1                              |
| → Reporting interval                     | 8 Sec                          |
| Measurement reporting mode               |                                |
| → Transfer Mode                          | Acknowledged mode              |
| → Periodical or event trigger            | Periodic                       |
| Additional measurement list              | Not Present                    |
| DPCH compressed mode status              | Not Present                    |

## RADIO-BEARER RECONFIGURATION (Step 2)

Use the same message type found in Annex A with condition set to A5 except following exceptions:

| Information Element | Value/remark |
|---------------------|--------------|
| RRC State Indicator | URA_PCH      |

**CELL UPDATE (Step 4)**

Use the same message type found in Annex A with condition set to A5 except following exceptions:

| Information Element | Value/remark                                      |
|---------------------|---------------------------------------------------|
| Cell Update Cause   | Check to see if set to "Uplink data transmission" |

**MEASUREMENT REPORT (Step 6)**

| Information Element                  | Value/Remarks                        |
|--------------------------------------|--------------------------------------|
| Measurement identity                 | 15                                   |
| Measured Results                     |                                      |
| — CHOICE measurement                 | Traffic volume measured results list |
| — Traffic volume measurement results |                                      |
| — RB identity                        | 0                                    |
| — RLC buffer payload                 | Check to see if this IE is absent    |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer variance                | Check to see if this IE is present   |
| — RB identity                        | 1                                    |
| — RLC buffer payload                 | Check to see if this IE is absent    |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer payload variance        | Check to see if this IE is present   |
| — RB identity                        | 2                                    |
| — RLC buffer payload                 | Check to see if this IE is absent    |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer payload variance        | Check to see if this IE is present   |
| — RB identity                        | 3                                    |
| — RLC buffer payload                 | Check to see if this IE is absent    |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer payload variance        | Check to see if this IE is present   |
| — RB identity                        | 4                                    |
| — RLC buffer payload                 | Check to see if this IE is absent    |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer payload variance        | Check to see if this IE is present   |
| — RB identity                        | 20                                   |
| — RLC buffer payload                 | Check to see if this IE is absent    |
| — RLC buffer payload average         | Check to see if this IE is absent    |
| — RLC buffer payload variance        | Check to see if this IE is present   |
| Measured results on RACH             | Check to see if this IE is absent    |
| Additional measured results          | Check to see if this IE is absent    |
| Event results                        | Check to see if this IE is absent    |

**8.4.1.21.5 — Test Requirement**

The UE shall send CELL UPDATE message with cause "Uplink data transfer" in step 4 and MEASUREMENT REPORT message in 6. The UE shall not send MEASUREMENT REPORT message in step 7.

**8.4.1.22 — Measurement Control and Report: Quality measurements****8.4.1.22.1 — Definition****8.4.1.22.2 — Conformance requirement**

In CELL\_DCH state, the UE shall send MEASUREMENT REPORT message when reporting criteria is fulfilled for any ongoing quality measurements.

## Reference

3GPP TS 25.331 clause 8.4

8.4.1.22.3 ~~Test Purpose~~

To confirm that the UE performs quality measurement as specified in MEASUREMENT CONTROL message received. In CELL\_DCH state, the UE shall send MEASUREMENT REPORT message when the reporting criteria is fulfilled for any ongoing quality measurement.

8.4.1.22.4 ~~Method of test~~

## Initial Condition

System Simulator: 1 cell

UE: CELL\_DCH state (state 6-1 or state 6-3) as specified in clause 7.4 of TS 34.108, depending on the CN domain(s) supported by the UE

## Test Procedure

The UE is in CELL\_DCH state. MEASUREMENT CONTROL message is sent to UE to assign quality measurement and reporting. As assigned in MEASUREMENT CONTROL message, the UE shall periodically send MEASUREMENT REPORT message reporting BLER of downlink transport channel(s).

## Expected Sequence

| Step | Direction |    | Message             | Comment                                                           |
|------|-----------|----|---------------------|-------------------------------------------------------------------|
|      | UE        | SS |                     |                                                                   |
| 1    |           | ←  | MEASUREMENT CONTROL | The UE is requested to perform "Quality measurements"             |
| 2    |           | →  | MEASUREMENT REPORT  |                                                                   |
| 3    |           | →  | MEASUREMENT REPORT  | UE shall send second MEASUREMENT REPORT message after 64 seconds. |

## Specific Message Content

## MEASUREMENT CONTROL (Step 1)

| Information Element           | Value/Remark                  |
|-------------------------------|-------------------------------|
| Measurement identity          | 16                            |
| Measurement command           | Setup                         |
| → CHOICE measurement type     | Quality measurement           |
| → Quality reporting quantity  |                               |
| → DL transport channel BLER   | True                          |
| → Transport channel ID list   | Not present                   |
| → Mode specific Info          | fdd : Null                    |
| → Reporting criteria          | Periodical reporting criteria |
| → Reporting amount            | Infinity                      |
| → Reporting interval          | 64 sec                        |
| Measurement reporting mode    |                               |
| → Transfer Mode               | Acknowledged mode             |
| → Periodical or event trigger | Periodic                      |
| Additional measurement list   | Not Present                   |
| DPCH compressed mode status   | Not Present                   |

## MEASUREMENT REPORT (Step 2,3)

| Information Element             | Value/Remarks                      |
|---------------------------------|------------------------------------|
| Measurement identity            | 16                                 |
| Measured Results                | Quality measurement                |
| → CHOICE measurement            |                                    |
| → BLER measurement results list | 10                                 |
| → Transport channel identity    | Check to see if this IE is present |
| → DL transport channel BLER     | fd: Null                           |
| → Mode specific info            | Check to see if this IE is absent  |
| Measured results on RACH        | Check to see if this IE is absent  |
| Additional measured results     | Check to see if this IE is absent  |
| Event results                   | Check to see if this IE is absent  |

## 8.4.1.22.5 Test Requirement

In step 2 and 3, the UE shall send MEASUREMENT REPORT message to report BLER for downlink DCH transport channel.

## 8.4.1.23 Measurement Control and Report: Intra-frequency measurement for events 1C and 1D

## 8.4.1.23.1 Definition

## 8.4.1.23.2 Conformance requirement

1. When event 1C is configured in the UE, the UE shall:

- if "Measurement quantity" is "pathloss" and Equation 1 below is fulfilled for a primary CPICH, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 2 below is fulfilled for a primary CPICH:
- if the equations have been fulfilled during the time "Time to trigger", and if the primary CPICH that is better is not included in the active set but the other primary CPICH is any of the primary CPICHs included in the active set, and if that primary CPICH is not included in the "cells triggered" in the variable TRIGGERED\_1C\_EVENTS:
- include that primary CPICH in the "cells triggered" in the variable TRIGGERED\_1C\_EVENTS;
- if the value of "Replacement activation threshold" for this event is lower than the current number of cells in the active set or equal to 0:
- if "Reporting interval" for this event is not equal to 0:
  - start a timer for that primary CPICH with the value of "Reporting interval" for this event;
  - set "sent reports" for that primary CPICH in the variable TRIGGERED\_1C\_EVENTS;
  - send a measurement report with IEs set as below:
    - in "intra-frequency event results": "Intrafrequency event identity" to "1c" and the first entry in "cell measurement event results" to the CPICH info of the primary CPICH not in the active set that triggered the report; and
    - the second entry in "cell measurement event results" to the CPICH info of the primary CPICH in the active set that now is worse than the new primary CPICH and has the best measured value (lowest measured result for pathloss and highest measured result for other measurements); and



- the rest of the entries to other primary CPICHs that are now worse than this new primary CPICH in the order of their measured value;
- "measured results" and possible "additional measured results" according to 8.4.2;

2. When event 1D is configured in the UE, the UE shall:

- if "Measurement quantity" is "pathloss" and Equation 1 below is fulfilled for a primary CPICH that is not stored in "Best cell" in variable BEST\_CELL\_1D\_EVENT, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 2 below is fulfilled for a primary CPICH that is not stored in "Best cell" in variable BEST\_CELL\_1D\_EVENT:
- if the equations have been fulfilled during the time "Time to trigger":
  - set "best cell" in the variable BEST\_CELL\_1D\_EVENT to that primary CPICH that triggered the event;
  - send a measurement report with IEs set as below:
    - in "intra-frequency event results"; "Intrafrequency event identity" to "1d" and "cell measurement event results" to the CPICH info of the primary CPICH that triggered the report;
    - "measured results" and possible "additional measured results" according to 8.4.2;

## Reference

3GPP TS 25.331 clause 14.1.2.3, 14.1.2.4.

### 8.4.1.23.3 ————— Test Purpose

- 1.A To confirm that the UE sends MEASUREMENT REPORT message if event 1C is configured, and number of cells in active set is greater than or equal to 'Replacement activation threshold' parameter, and if monitored or detected primary CPICH on same frequency becomes better than a primary CPICH in active set.
- 1.B To confirm that the UE does not send MEASUREMENT REPORT message indicating event 1C if number of cells in active set is less than 'Replacement activation threshold' parameter, and if monitored or detected primary CPICH on same frequency becomes better than a primary CPICH in active set.
- 1.C To confirm that the UE stops periodic reporting of event 1C if the cell that triggered event 1C is added into active set.
- 2. To confirm that the UE sends MEASUREMENT REPORT message if event 1D is configured and intra-frequency measurement indicates change in best cell.

### 8.4.1.23.4 ————— Method of test

#### Initial Condition

System Simulator: 3 cells—The initial configurations of the 3 cells in the SS shall follow the values indicated in the column marked "T0" in table 8.4.1.23-1. The table is found in "Test Procedure" clause.

UE: CS-DCCH\_DCH\_Initial (State 6-1) or PS-DCCH\_DCH\_Initial (State 6-3) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE.

#### Test Procedure

Table 8.4.1.23-1 illustrates the downlink power to be applied for the 3 cells at various time instants of the test execution. Column marked "T0" denotes the initial conditions, while columns marked "T1" and "T2" are to be applied subsequently. The exact instants on which these values shall be applied are described in the text in this clause.

**Table 8.4.1.23-1**

| Parameter              | Unit | Cell 1 |     |     | Cell 2 |     |              | Cell 3       |     |     |
|------------------------|------|--------|-----|-----|--------|-----|--------------|--------------|-----|-----|
|                        |      | T0     | T1  | T2  | T0     | T1  | T2           | T0           | T1  | T2  |
| UTRA RF Channel Number |      | Ch. 1  |     |     | Ch. 1  |     |              | Ch. 1        |     |     |
| CPICH Ec               | dBm  | -60    | -60 | -66 | -70    | -70 | Switched off | Switched off | -70 | -60 |

The UE is initially in CELL\_DCH state of cell 1. SS then performs a soft handover procedure by sending ACTIVE SET UPDATE message on the downlink DCCH. The UE shall reply with an ACTIVE SET UPDATE COMPLETE message on the uplink DCCH, and include cell 2 to the active set when the activation time specified has elapsed.

SS then ask the UE to perform Intra-frequency measurement and report event 1C and event 1D. In MEASUREMENT CONTROL message, IE 'Replacement activation threshold' is set to 3 and IE 'Cell individual offset' is set to +6 dBm for Cell 3. SS configures itself according to the values in columns "T1" shown above. Cell 3 becomes better than Cell 2 that is in active set of the UE, due to parameter 'Cell Individual offset' for Cell 3. However the UE shall not send MEASUREMENT REPORT message indicating event 1C because number of cells in active set is less than parameter 'Replacement Activation Threshold'.

SS then sends MEASUREMENT CONTROL message to the UE to modify earlier configured intra-frequency measurement. Now, IE 'Replacement activation threshold' is set to 1. MEASUREMENT CONTROL message contains only those IEs that are modified and the UE shall continue to use current values of parameters that are not modified. The UE sends MEASUREMENT REPORT message reporting event 1C, monitored Cell 3 is better than Cell 2 that is in active set. The UE sends second MEASUREMENT REPORT message reporting event 1C after 4 seconds, equals to parameter 'Reporting interval'.

SS then performs soft handover procedure by sending ACTIVE SET UPDATE message on the downlink DCCH. In this message SS commands UE to add Cell 3 and remove Cell 2 from active set. The UE shall reply with an ACTIVE SET UPDATE COMPLETE message. The UE shall also stop periodic reporting of event 1C because the Cell that triggered it is added into active set. SS then configures itself according to the values in columns "T2" shown above. This triggers event 1D and the UE sends MEASUREMENT REPORT message indicating Cell 3 as a best cell.

## Expected Sequence

| Step | Direction |    | Message                    | Comment                                                                                                |
|------|-----------|----|----------------------------|--------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                            |                                                                                                        |
| 1    |           | ←  | ACTIVE SET UPDATE          | SS command the UE to add Cell 2 in active set.                                                         |
| 2    |           | →  | ACTIVE SET UPDATE COMPLETE |                                                                                                        |
| 3    |           | ←  | MEASUREMENT CONTROL        | Event 1C and 1D are configured. IE "Replacement activation threshold" is set to 3.                     |
| 4    |           |    |                            | SS re-adjusts the downlink transmission power settings according to columns "T1" in table 8.4.1.23-1.  |
| 5    |           |    |                            | Check for 10 seconds, the UE shall not send MEASUREMENT REPORT message.                                |
| 6    |           | ←  | MEASUREMENT CONTROL        | Measurement configured in step 3 is modified to set parameter 'replacement activation threshold' to 1. |
| 7    |           | →  | MEASUREMENT REPORT         | Event 1C is triggered. The UE shall report that Cell 3 is better than Cell 2.                          |
| 8    |           | →  | MEASUREMENT REPORT         | The UE shall send second report after 4 seconds (Reporting interval)                                   |
| 9    |           | ←  | ACTIVE SET UPDATE          | SS command the UE to replace Cell 2 in active set by Cell 3.                                           |
| 10   |           | →  | ACTIVE SET UPDATE COMPLETE |                                                                                                        |
| 11   |           |    |                            | Check for 10 seconds, the UE shall not send MEASUREMENT REPORT message.                                |
| 12   |           |    |                            | SS re-adjusts the downlink transmission power settings according to columns "T2" in table 8.4.1.23-1.  |
| 13   |           | →  | MEASUREMENT REPORT         | The UE shall report event 1D change of best cell                                                       |

## Specific Message Contents

All messages indicated below shall use the same content as described in default message content, with the following exceptions:

## ACTIVE SET UPDATE (Step 1)

| Information Element                          | Value/Remark                                                                    |
|----------------------------------------------|---------------------------------------------------------------------------------|
| Radio link addition information              |                                                                                 |
| → Primary CPICH Info                         |                                                                                 |
| → Primary scrambling code                    | Primary scrambling code of Cell 2                                               |
| → Downlink DPCH info for each RL             |                                                                                 |
| → Primary CPICH usage for channel estimation | P-CPICH may be used.                                                            |
| → DPCH frame offset                          | 0 chips                                                                         |
| → Secondary CPICH info                       | Not present                                                                     |
| → DL channelisation code                     | This IE is repeated for all existing downlink DPCHs allocated to the UE         |
| → Secondary scrambling code                  | Not present                                                                     |
| → Spreading factor                           | Refer to the parameter set in TS 34.108                                         |
| → Code number                                | For each DPCH, assign the same code number in the current code given in cell 1. |
| → Scrambling code change                     | Not present                                                                     |
| → TPC combination index                      | 0                                                                               |
| → SSDT cell identity                         | Not present                                                                     |
| → Close loop timing adjustment mode          | Not present                                                                     |
| → TFCI combining indicator                   | Not present                                                                     |
| → SCCPCH information for FACH                | Not present                                                                     |
| Radio link removal information               | Not present                                                                     |

## MEASUREMENT CONTROL (Step 3)

| Information Element                                    | Value/Remark                                   |
|--------------------------------------------------------|------------------------------------------------|
| Measurement identity                                   | 1                                              |
| Measurement command                                    | Setup                                          |
| → CHOICE measurement type                              | Intra-frequency measurement                    |
| → Intra-frequency cell info list                       |                                                |
| → Intra-frequency cell removal                         | Not present                                    |
| → New intra-frequency info list                        |                                                |
| → Intra-frequency cell id                              | Id of Cell 3                                   |
| → Cell info                                            |                                                |
| → Cell individual offset                               | 6 dBm                                          |
| → Reference time difference to cell                    | Not present                                    |
| → CHOICE mode                                          | FDD                                            |
| → Read SFN Indicator                                   | FALSE                                          |
| → Primary CPICH Info                                   |                                                |
| → Primary scrambling code                              | Primary scrambling code of Cell 3              |
| → Primary CPICH TX power                               | Not present                                    |
| → TX Diversity Indicator                               | FALSE                                          |
| → Cell for measurement                                 |                                                |
| → Intra-frequency cell id list                         | Set to id of cell 1, 2 and 3.                  |
| → Intra-frequency measurement quantity                 |                                                |
| → Filter Coefficient                                   | 0                                              |
| → Measurement quantity                                 | CPICH RSCP                                     |
| → Intra-frequency reporting quantity                   |                                                |
| → Reporting quantities for active set cells            | Same as in default message content             |
| → SFN-SFN observed time difference reporting indicator | No report                                      |
| → Cell synchronisation information reporting indicator | FALSE                                          |
| → Cell identity reporting indicator                    | FALSE                                          |
| → CPICH Ec/No reporting indicator                      | FALSE                                          |
| → CPICH RSCP reporting indicator                       | FALSE                                          |
| → Pathloss reporting indicator                         | FALSE                                          |
| → Reporting quantities for monitored set cells         |                                                |
| → SFN-SFN observed time difference reporting indicator | No report                                      |
| → Cell synchronisation information reporting indicator | FALSE                                          |
| → Cell identity reporting indicator                    | FALSE                                          |
| → CPICH Ec/No reporting indicator                      | FALSE                                          |
| → CPICH RSCP reporting indicator                       | FALSE                                          |
| → Pathloss reporting indicator                         | FALSE                                          |
| → Reporting quantities for detected cells              | Not present                                    |
| → Measurement validity                                 | Not present                                    |
| → CHOICE report criteria                               | Intra-frequency measurement reporting criteria |
| → Parameters required for each events                  |                                                |
| → Intra-frequency event identity                       | 1C                                             |
| → Replacement activation threshold                     | 3                                              |
| → Reporting amount                                     | 16                                             |
| → Reporting interval                                   | 4 seconds                                      |
| → Hysteresis                                           | 4                                              |
| → Time to trigger                                      | 10 mSec                                        |
| → Reporting cell status                                | Not present                                    |
| → Intra-frequency event identity                       | 1D                                             |
| → Hysteresis                                           | 4                                              |
| → Time to trigger                                      | 10 mSec                                        |
| → Reporting cell status                                | Not present                                    |
| Measurement reporting mode                             |                                                |
| → Measurement reporting transfer mode                  | Acknowledged mode RLC                          |
| → Periodic reporting / Event trigger reporting mode    | Event trigger                                  |
| Additional measurement list                            | Not present                                    |
| DPCH compressed mode status info                       | Not present                                    |

## MEASUREMENT CONTROL (Step 6)

| Information Element                    | Value/Remark                                   |
|----------------------------------------|------------------------------------------------|
| Measurement identity                   | 1                                              |
| Measurement command                    | Modify                                         |
| → CHOICE measurement type              | Intra-frequency measurement                    |
| → Intra-frequency cell info list       | Not present                                    |
| → Intra-frequency measurement quantity | Not present                                    |
| → Intra-frequency reporting quantity   | Not present                                    |
| → Measurement validity                 | Not present                                    |
| → CHOICE report criteria               | Intra-frequency measurement reporting criteria |
| → Parameters required for each events  |                                                |
| → Intra-frequency event identity       | 1G                                             |
| → Replacement activation threshold     | 1                                              |
| → Reporting amount                     | 16                                             |
| → Reporting interval                   | 4 seconds                                      |
| → Hysteresis                           | 4                                              |
| → Time to trigger                      | 10 mSec                                        |
| → Reporting cell status                | Not present                                    |
| → Intra-frequency event identity       | 1D                                             |
| → Hysteresis                           | 4                                              |
| → Time to trigger                      | 10 mSec                                        |
| → Reporting cell status                | Not present                                    |
| Measurement reporting mode             | Not present                                    |
| Additional measurement list            | Not present                                    |
| DPCH compressed mode status info       | Not present                                    |

## MEASUREMENT REPORT (Step 7 and 8)

| Information Element              | Value/Remarks                     |
|----------------------------------|-----------------------------------|
| Measurement identity             | 1                                 |
| Measured results                 | Check to see if this IE is absent |
| Measured results on RACH         | Check to see if this IE is absent |
| Additional Measured results      | Check to see if this IE is absent |
| Event results                    | Intra-Frequency Event results     |
| → Event ID                       | 1G                                |
| → Cell measurement event results |                                   |
| → Primary scrambling code        | Primary scrambling code of Cell 3 |
| → Primary scrambling code        | Primary scrambling code of Cell 2 |

## ACTIVE SET UPDATE (Step 9)

| Information Element                          | Value/Remark                                                                    |
|----------------------------------------------|---------------------------------------------------------------------------------|
| Radio-link addition information              |                                                                                 |
| → Primary CPICH Info                         |                                                                                 |
| → Primary scrambling code                    | Primary scrambling code of Cell 3                                               |
| → Downlink DPCH info for each RL             |                                                                                 |
| → Primary CPICH usage for channel estimation | P-CPICH may be used.                                                            |
| → DPCH frame offset                          | 0 chips                                                                         |
| → Secondary CPICH info                       | Not present                                                                     |
| → DL channelisation code                     | This IE is repeated for all existing downlink DPCHs allocated to the UE         |
| → Secondary scrambling code                  | Not present                                                                     |
| → Spreading factor                           | Refer to the parameter set in TS 34.108                                         |
| → Code Number                                | For each DPCH, assign the same code number in the current code given in cell 1. |
| → Scrambling code change                     | Not present                                                                     |
| → TPC Combination Index                      | 0                                                                               |
| → SSDT Cell Identity                         | Not present                                                                     |
| → Close loop timing adjustment mode          | Not present                                                                     |
| → TFCI Combining Indicator                   | Not present                                                                     |
| → SCCPCH information for FACH                | Not present                                                                     |
| Radio-link removal information               |                                                                                 |
| → Primary CPICH Info                         |                                                                                 |
| → Primary scrambling code                    | Primary scrambling code of Cell 2                                               |

## MEASUREMENT REPORT (Step 13)

| Information Element              | Value/Remarks                     |
|----------------------------------|-----------------------------------|
| Measurement identity             | 1                                 |
| Measured results                 | Check to see if this IE is absent |
| Measured results on RACH         | Check to see if this IE is absent |
| Additional Measured results      | Check to see if this IE is absent |
| Event results                    | Intra-frequency event results     |
| → Event ID                       | 1D                                |
| → Cell measurement event results |                                   |
| → Primary scrambling code        | Primary scrambling code of Cell 3 |

## 8.4.1.23.5 Test Requirement

- 1.A In steps 7 and 8 the UE shall send MEASUREMENT REPORT message indicating event 1C. IE 'Cell measurement event results' in MEASUREMENT REPORT message shall contain primary scrambling code of Cell 3 and Cell 2 in that order.
- 1.B In step 5 the UE shall not send MEASUREMENT REPORT message.
- 1.C In step 11 the UE shall not send MEASUREMENT REPORT message.
2. In step 13 the UE shall send MEASUREMENT REPORT message indicating event 1D. IE 'Cell measurement event results' in MEASUREMENT REPORT message shall contain primary scrambling code of Cell 3.

## 8.4.1.24 Measurement Control and Report: Inter-frequency measurement for event 2A

## 8.4.1.24.1 Definition

## 8.4.1.24.2 Conformance requirement

- 1.If any of the non-used frequencies quality estimate becomes better than the currently used frequency quality estimate, and event 2A has been ordered by UTRAN then this event shall trigger a report to be sent from the

UE when the hysteresis and time to trigger conditions is fulfilled. The corresponding report contains (at least) the best primary CPICH on the non-used frequency that triggered the event.

## Reference

3GPP TS 25.331 clause 14.2.1.1

### 8.4.1.24.3 Test Purpose

- 1.A To confirm that the UE sends MEASUREMENT REPORT message if event 2A is configured, and if any of the non-used frequencies quality estimate becomes better than the currently used frequency quality estimate.
- 1.B To confirm that the UE does not send MEASUREMENT REPORT message indicating event 2A if hysteresis condition is not fulfilled.
- 1.C To confirm that the UE does not send MEASUREMENT REPORT message indicating event 2A if time to trigger condition is not fulfilled.

### 8.4.1.24.4 Method of test

#### Initial Condition

System Simulator: 2 cells—The initial configurations of the 2 cells in the SS shall follow the values indicated in the column marked "T0" in table 8.4.1.24-1. The table is found in "Test Procedure" clause.

UE: CS-DGCH-DCH\_Initial (State 6-1) or PS-DGCH-DCH\_Initial (State 6-3) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE.

#### Test Procedure

Table 8.4.1.24-1 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution. Column marked "T0" denotes the initial conditions, while columns marked "T1", "T2", "T3", "T4" and "T5" are to be applied subsequently. The exact instants on which these values shall be applied are described in the text in this clause.

**Table 8.4.1.24-1**

| Parameter              | Unit | Cell 1 |     |     |     |     |     | Cell 4 |     |     |     |     |     |
|------------------------|------|--------|-----|-----|-----|-----|-----|--------|-----|-----|-----|-----|-----|
|                        |      | T0     | T1  | T2  | T3  | T4  | T5  | T0     | T1  | T2  | T3  | T4  | T5  |
| UTRA RF Channel Number |      | Ch. 1  |     |     |     |     |     | Ch. 2  |     |     |     |     |     |
| CPICH-Ec               | dBm  | -66    | -66 | -66 | -66 | -66 | -66 | -75    | -60 | -75 | -60 | -75 | -60 |

The UE is initially in CELL\_DCH state of cell 1. SS commands the UE to perform measurements of transmitted power using MEASUREMENT CONTROL message. This measurement is setup to confirm that while sending MEASUREMENT REPORT message, the UE sets IE "Additional measured results" correctly. SS then performs PHYSICAL CHANNEL RECONFIGURATION procedure to activate compressed mode. SS then commands the UE to perform Inter-frequency measurements and report event 2A by sending MEASUREMENT CONTROL message. In MEASUREMENT CONTROL message, IE "Hysteresis" is set to 10 dB and IE "Additional measurement list" is set to id of "UE Internal measurements" configured earlier. SS then configures itself according to the values in columns "T1" shown above. Even though quality estimate for Cell 4 has become better than that of Cell 1, event 2A will not be triggered since hysteresis condition is not fulfilled. SS then configures itself according to the values in columns "T2" shown above.

SS sends MEASUREMENT CONTROL message to modify parameter "Hysteresis" of Inter-frequency measurements to 1 dB. SS then raises power level of Cell 4 according to columns "T3" for short duration (less than 5 seconds), and again configures itself according to columns "T4" shown above. The UE will not send MEASUREMENT REPORT message because time to trigger condition is not fulfilled. SS then configures itself according to the values in columns "T5" shown above. The UE sends MEASUREMENT REPORT message reporting even 2A as well as measurement of transmitted power.



**Important Note:** Duration between time instant "T3" and "T4" (between steps 9 and 10 of expected sequence) must be less than 5 seconds.

#### Expected Sequence

| Step | Direction |    | Message                                   | Comment                                                                                                                                                                       |
|------|-----------|----|-------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                                                               |
| 1    |           | ←  | MEASUREMENT CONTROL                       | To setup UE Internal measurement.                                                                                                                                             |
| 2    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | SS instructs UE to begin compressed mode operation.                                                                                                                           |
| 3    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                                                                               |
| 4    |           | ←  | MEASUREMENT CONTROL                       | SS commands the UE to perform Inter-frequency measurements and to report event 2A.                                                                                            |
| 5    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T1" in table 8.4.1.24-1.                                                                         |
| 6    |           |    |                                           | Check for 10 seconds, the UE shall not send MEASUREMENT REPORT message, as hysteresis condition is not fulfilled.                                                             |
| 7    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T2" in table 8.4.1.24-1.                                                                         |
| 8    |           | ←  | MEASUREMENT CONTROL                       | Modify hysteresis parameter for event 2A.                                                                                                                                     |
| 9    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T3" in table 8.4.1.24-1.                                                                         |
| 10   |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T4" in table 8.4.1.24-1. This step should be completed within 5 seconds after completing step 9. |
| 11   |           |    |                                           | Check for 10 seconds, the UE shall not send MEASUREMENT REPORT message, as time to trigger condition is not fulfilled.                                                        |
| 12   |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T5" in table 8.4.1.24-1.                                                                         |
| 13   |           | →  | MEASUREMENT REPORT                        | This message should come at least 5 seconds later after changing power setting of Cell 4.                                                                                     |

#### Specific Message Contents

All messages indicated below shall use the same content as described in default message content, with the following exceptions:

## MEASUREMENT CONTROL (Step 1)

| Information Element                | Value/Remark            |
|------------------------------------|-------------------------|
| Measurement identity               | 1                       |
| Measurement command                | Setup                   |
| CHOICE measurement type            | UE internal measurement |
| → UE internal measurement quantity |                         |
| → Measurement quantity             | UE transmitted power    |
| → Filter Coefficient               | 4                       |
| → UE internal reporting quantity   |                         |
| → UE Transmitted Power             | TRUE                    |
| → CHOICE mode                      | FDD                     |
| → UE Rx-Tx time difference         | FALSE                   |
| → CHOICE report criteria           | No reporting            |
| Measurement reporting mode         | Not present             |
| Additional measurements list       | Not present             |
| DPCH compressed mode status        | Not present             |

## PHYSICAL CHANNEL RECONFIGURATION (Step 2)

Use the same message sub-type found in Annex A, which is entitled "(Packet to CELL\_DCH from CELL\_DCH in PS)", with the following exceptions in the IE(s) concerned:

| Information Element                                          | Value/Remarks                           |
|--------------------------------------------------------------|-----------------------------------------|
| Downlink information common for all radio links              |                                         |
| → Downlink DPCH info common for all RL                       |                                         |
| → Timing Indication                                          | Maintain                                |
| → Downlink DPCH power control information                    |                                         |
| → DPC mode                                                   | 0 (Single)                              |
| → CHOICE Mode                                                | FDD                                     |
| → Power offset PPilot-DPDCH                                  | TBD                                     |
| → DL rate matching restriction information                   | Not present                             |
| → Spreading factor                                           | Refer to the parameter set in TS 34.108 |
| → Fixed or flexible position                                 | Flexible                                |
| → TFCI existence                                             | FALSE                                   |
| → Number of bits for Pilot bits (SF=128, 256)                | Not present                             |
| → DPCH compressed mode info                                  |                                         |
| → TGPSI                                                      | 1                                       |
| → TGPS status flag                                           | Active                                  |
| → TGCFN                                                      | (Current CFN+(256—TTI/10msec)) mod 256  |
| → Transmission gap pattern sequence configuration parameters |                                         |
| → TGMP                                                       | FDD Measurement                         |
| → TGPRC                                                      | 62                                      |
| → TGSN                                                       | 8                                       |
| → TGL1                                                       | 10                                      |
| → TGL2                                                       | 5                                       |
| → TGD                                                        | 15                                      |
| → TGPL1                                                      | 35                                      |
| → TGPL2                                                      | 35                                      |
| → RPP                                                        | Mode 1                                  |
| → ITP                                                        | Mode 1                                  |
| → CHOICE UL/DL mode                                          | DL                                      |
| → Downlink compressed mode method                            | SF/2                                    |
| → Downlink frame type                                        | A                                       |
| → DeltaSIR1                                                  | 2.0                                     |
| → DeltaSIRAfter1                                             | 1.0                                     |
| → DeltaSIR2                                                  | Not present                             |
| → DeltaSIRAfter2                                             | Not present                             |
| → N identify abort                                           | Not present                             |
| → T Reconfirm abort                                          | Not present                             |
| → TX diversity mode                                          | None                                    |
| → SSDT information                                           | Not present                             |
| → Default DPCH offset value                                  | 0                                       |

## MEASUREMENT CONTROL (Step 4)

| Information Element                                    | Value/Remark                                   |
|--------------------------------------------------------|------------------------------------------------|
| Measurement identity                                   | 2                                              |
| Measurement command                                    | Setup                                          |
| → CHOICE measurement type                              | Inter-frequency measurement                    |
| → Inter-frequency cell info list                       |                                                |
| → Inter-frequency cell removal                         | Not present                                    |
| → New inter-frequency info list                        |                                                |
| → Inter-frequency cell id                              | Id of Cell 4                                   |
| → Frequency Information                                | Frequency of Cell 4                            |
| → Cell info                                            |                                                |
| → Cell individual offset                               | Not present                                    |
| → Reference time difference to cell                    | Not present                                    |
| → CHOICE mode                                          | FDD                                            |
| → Read SFN Indicator                                   | FALSE                                          |
| → Primary CPICH Info                                   |                                                |
| → Primary scrambling code                              | Primary scrambling code of Cell 4              |
| → Primary CPICH TX power                               | Not present                                    |
| → TX Diversity Indicator                               | FALSE                                          |
| → Cell for measurement                                 | Not present                                    |
| → Inter-frequency measurement quantity                 |                                                |
| → Filter Coefficient                                   | 0                                              |
| → Frequency quality estimate quantity                  | CPICH RSCP                                     |
| → Inter-frequency reporting quantity                   |                                                |
| → UTRAN carrier RSSI                                   | FALSE                                          |
| → Frequency quality estimate                           | FALSE                                          |
| → Non-frequency related quantities                     |                                                |
| → SFN-SFN observed time difference                     | No report                                      |
| reporting indicator                                    |                                                |
| → Cell synchronisation information reporting indicator | FALSE                                          |
| → Cell identity reporting indicator                    | FALSE                                          |
| → CPICH Ec/No reporting indicator                      | FALSE                                          |
| → CPICH RSCP reporting indicator                       | FALSE                                          |
| → Pathloss reporting indicator                         | FALSE                                          |
| → Measurement validity                                 | CELL_DCH state                                 |
| → UE autonomous update mode                            | Not present                                    |
| → CHOICE report criteria                               | Inter-frequency measurement reporting criteria |
| → Parameters required for each events                  |                                                |
| → Inter-frequency event identity                       | 2A                                             |
| → Used frequency threshold                             | -72 dBm                                        |
| → Used frequency W                                     | 0                                              |
| → Hysteresis Inter-frequency                           | 10 dB                                          |
| → Time to trigger                                      | 5000 mSec                                      |
| → Reporting cell status                                | Not present                                    |
| → Non-used frequency parameter list                    |                                                |
| → Non-used frequency threshold                         | -72 dBm                                        |
| → Non-used frequency W                                 | 0                                              |
| Measurement reporting mode                             |                                                |
| → Measurement reporting transfer mode                  | Acknowledged mode RLC                          |
| → Periodic reporting / Event trigger reporting mode    | Event trigger                                  |
| Additional measurement list                            |                                                |
| → Measurement identity                                 | 1                                              |
| DPCH compressed mode status info                       | Not present                                    |

## MEASUREMENT CONTROL (Step 8)

| Information Element                    | Value/Remark                                   |
|----------------------------------------|------------------------------------------------|
| Measurement identity                   | 2                                              |
| Measurement command                    | Modify                                         |
| → CHOICE measurement type              | Inter-frequency measurement                    |
| → Inter-frequency cell info list       |                                                |
| → Inter-frequency cell removal         | Not present                                    |
| → New inter-frequency info list        | Not present                                    |
| → Cell for measurement                 | Not present                                    |
| → Intra-frequency measurement quantity | Not present                                    |
| → Inter-frequency reporting quantity   | Not present                                    |
| → Measurement validity                 | Not present                                    |
| → UE autonomous update mode            | Not present                                    |
| → CHOICE report criteria               | Inter-frequency measurement reporting criteria |
| → Parameters required for each events  |                                                |
| → Inter-frequency event identity       | 2A                                             |
| - Used frequency threshold             | -72 dBm                                        |
| - Used frequency W                     | 0                                              |
| - Hysteresis Inter-Frequency           | 1 dB                                           |
| → Time to trigger                      | 5000 mSec                                      |
| → Reporting cell status                | Not present                                    |
| - Non-used frequency parameter list    |                                                |
| - Non-used frequency threshold         | -72 dBm                                        |
| - Non-used frequency W                 | 0                                              |
| Measurement reporting mode             | Not present                                    |
| Additional measurement list            | Not present                                    |
| DPCH compressed mode status info       | Not present                                    |

## MEASUREMENT REPORT (Step 13)

| Information Element              | Value/Remarks                     |
|----------------------------------|-----------------------------------|
| Measurement identity             | Check to see if set to 2          |
| Measured results                 | Check to see if it is absent      |
| Measured results on RACH         | Check to see if it is absent      |
| Additional measured results      |                                   |
| - Measured results               | UE internal measured results      |
| - UE transmitted power           | Check to see if it is present     |
| - UE RX-TX report entry list     | Check to see if it is absent      |
| Event results                    | Inter-frequency event results,    |
| → Event ID                       | 2A                                |
| → Cell measurement event results |                                   |
| - Frequency info                 | Frequency of Cell 4               |
| - Primary CPICH info             |                                   |
| - Primary scrambling code        | Primary scrambling code of Cell 4 |

## 8.4.1.24.5 Test Requirement

- 1.A In step 13 the UE shall send MEASUREMENT REPORT message indicating event 2A. IE 'Cell measurement event results' in MEASUREMENT REPORT message shall contain frequency information and primary scrambling code of Cell 4.
- 1.B In step 6, the UE shall not send MEASUREMENT REPORT message.
- 1.C In step 11, the UE shall not send MEASUREMENT REPORT message.

### 8.4.1.25 Measurement Control and Report: Inter-frequency measurement for events 2B and 2E

#### 8.4.1.25.1 Definition

#### 8.4.1.25.2 Conformance requirement

1. When event 2E is ordered by UTRAN in a MEASUREMENT CONTROL message the UE shall send a report when the estimated quality of a non-used frequency is below the value of the IE "Threshold non-used frequency" and the hysteresis and time to trigger conditions are fulfilled. The corresponding report contains at least the best primary CPICH on the non-used frequency.
2. When event 2B is ordered by UTRAN in a MEASUREMENT CONTROL message the UE shall send a report when the estimated quality of the currently used frequency is below the value of the IE "Threshold used frequency" and the estimated quality of a non-used frequency is above the value of the IE "Threshold non-used frequency" and the hysteresis and time to trigger conditions are fulfilled. The corresponding report contains at least the best primary CPICH on the non-used frequency that triggered the event.

#### Reference

3GPP TS 25.331 clause 14.2.1.2, 14.2.1.5.

#### 8.4.1.25.3 Test Purpose

1. To confirm that the UE sends MEASUREMENT REPORT message when event 2E is configured and the estimated quality of a non-used frequency is below the value of the IE "Threshold non-used frequency". This MEASUREMENT REPORT message shall contain at least the best primary CPICH on the non-used frequency that triggered the event.
2. To confirm that the UE sends MEASUREMENT REPORT message when event 2B is configured and estimated quality of the currently used frequency is below the value of the IE "Threshold used frequency" and the estimated quality of a non-used frequency is above the value of the IE "Threshold non-used frequency". This MEASUREMENT REPORT message shall contain at least the best primary CPICH on the non-used frequency that triggered the event.

#### 8.4.1.25.4 Method of test

##### Initial Condition

System Simulator: 2 cells—The initial configurations of the 2 cells in the SS shall follow the values indicated in the column marked "T0" in table 8.4.1.24-1. The table is found in "Test Procedure" clause.

UE: CS-DCCH\_DCH\_Initial (State 6-1) or PS-DCCH\_DCH\_Initial (State 6-3) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE.

##### Test Procedure

Table 8.4.1.25-1 illustrates the downlink power to be applied for the 2 cells at various time instants of the test execution. Column marked "T0" denotes the initial conditions, while columns marked "T1" and "T2" are to be applied subsequently. The exact instants on which these values shall be applied are described in the text in this clause.

Table 8.4.1.25-1

| Parameter              | Unit | Cell 1 |     |     | Cell 4 |     |     |
|------------------------|------|--------|-----|-----|--------|-----|-----|
|                        |      | T0     | T1  | T2  | T0     | T1  | T2  |
| UTRA RF Channel Number |      | Ch. 1  |     |     | Ch. 2  |     |     |
| CPICH-Ec               | dBm  | -60    | -63 | -74 | -74    | -60 | -60 |

The UE is initially in CELL\_DCH state of cell 1. SS commands the UE to perform Inter-frequency measurements and report event 2B and event 2E by sending MEASUREMENT CONTROL message. SS then performs PHYSICAL CHANNEL RECONFIGURATION procedure to activate compressed mode. Since quality estimate of non-used frequency is below threshold, the UE sends MEASUREMENT REPORT message indicating event 2E. SS then configures itself according to the values in columns "T1" shown above. Now quality estimate of used and non-used frequency is above threshold and hence neither event 2B nor event 2E will be triggered. SS then configures itself according to the values in columns "T2" shown above. Quality estimate for used frequency is now below threshold, while that of non-used frequency is above threshold, the UE sends MEASUREMENT REPORT message to report event 2B.

#### Expected Sequence

| Step | Direction |    | Message                                   | Comment                                                                                                                                                         |
|------|-----------|----|-------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                                                 |
| 1    |           | ←  | MEASUREMENT CONTROL                       | SS commands the UE to perform Inter-frequency measurements and to report event 2B and 2E.                                                                       |
| 2    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | SS instructs UE to begin compressed mode operation.                                                                                                             |
| 3    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                                                                 |
| 4    |           | →  | MEASUREMENT REPORT                        | The UE shall report event 2E. Time duration between activation of compressed mode and reception of this message should be at least 5 seconds.                   |
| 5    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T1" in table 8.4.1.25-1.                                                           |
| 6    |           |    |                                           | Check for 10 seconds the UE shall not send measurement report message.                                                                                          |
| 7    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T2" in table 8.4.1.25-1.                                                           |
| 8    |           | →  | MEASUREMENT REPORT                        | The UE shall report event 2B. Time duration between changing power levels according to columns "T2" and reception of this message should be at least 5 seconds. |

#### Specific Message Contents

All messages indicated below shall use the same content as described in default message content, with the following exceptions:

## MEASUREMENT CONTROL (Step 1)

| Information Element                                    | Value/Remark                                   |
|--------------------------------------------------------|------------------------------------------------|
| Measurement identity                                   | 4                                              |
| Measurement command                                    | Setup                                          |
| → CHOICE measurement type                              | Inter-frequency measurement                    |
| → Inter-frequency cell info list                       |                                                |
| → Inter-frequency cell removal                         | Not present                                    |
| → New inter-frequency info list                        |                                                |
| → Inter-frequency cell id                              | Id of Cell 4                                   |
| → Frequency Information                                | Frequency of Cell 4                            |
| → Cell info                                            |                                                |
| → Cell individual offset                               | Not present                                    |
| → Reference time difference to cell                    | Not present                                    |
| → CHOICE mode                                          | FDD                                            |
| → Read SFN Indicator                                   | FALSE                                          |
| → Primary CPICH Info                                   |                                                |
| → Primary scrambling code                              | Primary scrambling code of Cell 4              |
| → Primary CPICH TX power                               | Not present                                    |
| → TX Diversity Indicator                               | FALSE                                          |
| → Cell for measurement                                 | Not present                                    |
| → Inter-frequency measurement quantity                 |                                                |
| → Filter Coefficient                                   | 4                                              |
| → Frequency quality estimate quantity                  | CPICH RSCP                                     |
| → Inter-frequency reporting quantity                   |                                                |
| → UTRAN Carrier RSSI                                   | FALSE                                          |
| → Frequency quality estimate                           | FALSE                                          |
| → Non frequency related quantities                     |                                                |
| → SFN-SFN observed time difference                     | No report                                      |
| reporting indicator                                    |                                                |
| → Cell synchronisation information reporting indicator | FALSE                                          |
| → Cell identity reporting indicator                    | FALSE                                          |
| → CPICH Ec/No reporting indicator                      | FALSE                                          |
| → CPICH RSCP reporting indicator                       | TRUE                                           |
| → Pathloss reporting indicator                         | FALSE                                          |
| → Measurement validity                                 | Not present                                    |
| → UE autonomous update mode                            | Not present                                    |
| → CHOICE report criteria                               | Inter-frequency measurement reporting criteria |
| → Parameters required for each events                  |                                                |
| → Inter-frequency event identity                       | 2E                                             |
| → Hysteresis Inter-Frequency                           | 1 dB                                           |
| → Time to trigger                                      | 5000 mSec                                      |
| → Reporting cell status                                | Not present                                    |
| → Non used frequency parameter list                    |                                                |
| → Non used frequency threshold                         | -66 dBm                                        |
| → Non used frequency W                                 | 0                                              |
| → Inter-frequency event identity                       | 2B                                             |
| → Used frequency threshold                             | -68 dBm                                        |
| → Used frequency W                                     | 4                                              |
| → Hysteresis Inter-Frequency                           | 1 dB                                           |
| → Time to trigger                                      | 5000 mSec                                      |
| → Reporting cell status                                | Within monitored set non-used frequency        |
| → Maximum number of reporting cells                    | 1                                              |
| → Non used frequency parameter list                    |                                                |
| → Non used frequency threshold                         | -66 dBm                                        |
| → Non used frequency W                                 | 0                                              |
| Measurement reporting mode                             |                                                |
| → Measurement reporting transfer mode                  | Unacknowledged Mode RLC                        |
| → Periodic reporting / Event trigger reporting mode    | Event trigger                                  |
| Additional measurement list                            | Not present                                    |
| DPCH compressed mode status info                       | Not present                                    |

## PHYSICAL CHANNEL RECONFIGURATION (Step 2)

Use the same message sub-type found in Annex A, which is entitled "(Packet to CELL\_DCH from CELL\_DCH in PS)", with the following exceptions in the IE(s) concerned:

| Information Element                                        | Value/Remarks                           |
|------------------------------------------------------------|-----------------------------------------|
| Downlink information common for all radio links            |                                         |
| Downlink DPCCH info common for all RL                      |                                         |
| Timing Indication                                          | Maintain                                |
| Downlink DPCCH power control information                   |                                         |
| DPC mode                                                   | 0 (Single)                              |
| CHOICE Mode                                                | FDD                                     |
| Power offset PPilot-DPCCH                                  | TBD                                     |
| DL rate matching restriction information                   | Not present                             |
| Spreading factor                                           | Refer to the parameter set in TS 34.108 |
| Fixed or flexible position                                 | Flexible                                |
| TFCI existence                                             | FALSE                                   |
| Number of bits for Pilot bits (SF=128, 256)                | Not present                             |
| DPCCH compressed mode info                                 |                                         |
| TGPSI                                                      | 1                                       |
| TGPS status flag                                           | Active                                  |
| TGCFN                                                      | (Current CFN+(256—TTI/10msec)) mod 256  |
| Transmission gap pattern sequence configuration parameters |                                         |
| TGMP                                                       | FDD Measurement                         |
| TGPRC                                                      | 62                                      |
| TGSN                                                       | 8                                       |
| TGL1                                                       | 10                                      |
| TGL2                                                       | 5                                       |
| TGD                                                        | 15                                      |
| TGPL1                                                      | 35                                      |
| TGPL2                                                      | 35                                      |
| RPP                                                        | Mode 1                                  |
| ITP                                                        | Mode 1                                  |
| CHOICE UL/DL mode                                          | DL                                      |
| Downlink compressed mode method                            | SF/2                                    |
| Downlink frame type                                        | A                                       |
| DeltaSIR1                                                  | 2.0                                     |
| DeltaSIRAfter1                                             | 1.0                                     |
| DeltaSIR2                                                  | Not present                             |
| DeltaSIRAfter2                                             | Not present                             |
| N-identify abort                                           | Not present                             |
| T-Reconfirm abort                                          | Not present                             |
| TX diversity mode                                          | None                                    |
| SSDT information                                           | Not present                             |
| Default DPCCH offset value                                 | 0                                       |

## MEASUREMENT REPORT (Step 4)

| Information Element            | Value/Remarks                     |
|--------------------------------|-----------------------------------|
| Measurement identity           | Check to see if set to 4          |
| Measured results               | Check to see if it is absent      |
| Measured results on RACH       | Check to see if it is absent      |
| Additional measured results    | Check to see if it is absent      |
| Event results                  | Inter-frequency event results;    |
| Event ID                       | 2E                                |
| Cell measurement event results |                                   |
| Frequency info                 | Frequency of Cell 4               |
| Primary CPICH info             |                                   |
| Primary scrambling code        | Primary scrambling code of Cell 4 |



## MEASUREMENT REPORT (Step 8)

| Information Element                     | Value/Remarks                      |
|-----------------------------------------|------------------------------------|
| Measurement identity                    | 4                                  |
| Measured results                        | Inter-frequency measured results   |
| - Frequency information                 | Frequency of Cell 4                |
| - UTRA carrier RSSI                     | Check to see if it is absent       |
| - Inter-frequency cell measured results |                                    |
| - Cell Identity                         | Check to see if it is absent       |
| - SFN-SFN Observed Time Difference      | Check to see if this IE is absent  |
| - Cell synchronisation information      | Check to see if this IE is absent  |
| - Mode Specific Info                    | FDD                                |
| - Primary CPICH Info                    |                                    |
| - Primary scrambling code               | Primary scrambling code for cell 4 |
| - CPICH Ec/No                           | Check to see if it is absent       |
| - CPICH RSCP                            | Check to see if it is present      |
| - Pathloss                              | Check to see if it is absent       |
| Measured results on RACH                | Check to see if it is absent       |
| Additional measured results             | Check to see if it is absent       |
| Event results                           | Inter-frequency event results;     |
| - Event ID                              | 2B                                 |
| - Cell measurement event results        |                                    |
| - Frequency info                        | Frequency of Cell 4                |
| - Primary CPICH info                    |                                    |
| - Primary scrambling code               | Primary scrambling code of Cell 4  |

## 8.4.1.25.5 Test Requirement

1. In step 4 the UE shall send MEASUREMENT REPORT message indicating event 2E. IE "Cell measurement event results" in this message shall contain frequency information and primary scrambling code of Cell 4.
2. In step 8 the UE shall send MEASUREMENT REPORT message indicating event 2B. IE "Cell measurement event results" in this message shall contain frequency information and primary scrambling code of Cell 4.

## 8.4.1.26 Measurement Control and Report: Inter-frequency measurement for events 2D and 2F

## 8.4.1.26.1 Definition

## 8.4.1.26.2 Conformance requirement

1. When event 2F is ordered by UTRAN in a MEASUREMENT CONTROL message the UE shall send a report when the estimated quality of the currently used frequency is above the value of the IE "Threshold-used frequency" and the hysteresis and time to trigger conditions are fulfilled. The corresponding report contains at least the best primary CPICH on the used frequency.
2. When event 2D is ordered by UTRAN in a MEASUREMENT CONTROL message the UE shall send a report when the estimated quality of the currently used frequency is below the value of the IE "Threshold-used frequency" and the hysteresis and time to trigger conditions are fulfilled. The corresponding report contains at least the best primary CPICH on the used frequency.

## Reference

3GPP TS 25.331 clause 14.2.1.4, 14.2.1.6

### 8.4.1.26.3 Test Purpose

1. To confirm that the UE sends MEASUREMENT REPORT message when event 2F is configured and estimated quality of the currently used frequency is above the value of the IE "Threshold used frequency". This MEASUREMENT REPORT message shall contain at least the best primary CPICH on the used frequency.
2. To confirm that the UE sends MEASUREMENT REPORT message when event 2D is configured and estimated quality of the currently used frequency is below the value of the IE "Threshold used frequency". This MEASUREMENT REPORT message shall contain at least the best primary CPICH on the used frequency.

### 8.4.1.26.4 Method of test

#### Initial Condition

System Simulator: 1 cells—The initial configurations of the cell in the SS shall follow the values indicated in the column marked "T0" in table 8.4.1.26-1. The table is found in "Test Procedure" clause.

UE: CS-DCCH\_DCH\_Initial (State 6-1) or PS-DCCH\_DCH\_Initial (State 6-3) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE.

#### Test Procedure

Table 8.4.1.26-1 illustrates the downlink power to be applied for the cell at various time instants of the test execution. Column marked "T0" denotes the initial conditions, while columns marked "T1" is to be applied subsequently. The exact instant on which these values shall be applied is described in the text in this clause.

**Table 8.4.1.26-1**

| Parameter              | Unit | Cell 1 |     |
|------------------------|------|--------|-----|
|                        |      | T0     | T1  |
| UTRA RF Channel Number |      | Ch. 1  |     |
| CPICH $E_c$            | dBm  | -60    | -72 |

The UE is initially in CELL\_DCH state of cell 1. SS performs PHYSICAL CHANNEL RECONFIGURATION procedure to activate compressed mode. SS commands the UE to perform Inter-frequency measurements and report event 2D and/or event 2F by sending MEASUREMENT CONTROL message. Since quality estimate of used frequency is above threshold, the UE sends MEASUREMENT REPORT message indicating event 2F. SS then configures itself according to the values in columns "T1" shown above. Quality estimate for used frequency is now below threshold, the UE sends MEASUREMENT REPORT message to report it.

#### Expected Sequence

| Step | Direction |    | Message                                   | Comment                                                                                               |
|------|-----------|----|-------------------------------------------|-------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                       |
| 1    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | SS instructs UE to begin compressed mode operation.                                                   |
| 2    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                       |
| 3    |           | ←  | MEASUREMENT CONTROL                       | SS commands the UE to perform Inter-frequency measurements and to report event 2D and 2F.             |
| 4    |           | →  | MEASUREMENT REPORT                        | The UE shall report event 2F                                                                          |
| 5    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T1" in table 8.4.1.26-1. |
| 6    |           | →  | MEASUREMENT REPORT                        | The UE shall report event 2D.                                                                         |

## Specific Message Contents

All messages indicated below shall use the same content as described in default message content, with the following exceptions:

### PHYSICAL CHANNEL RECONFIGURATION (Step 1)

Use the same message sub-type found in Annex A, which is entitled "(Packet to CELL\_DCH from CELL\_DCH in PS)", with the following exceptions in the IE(s) concerned:

| Information Element                                        | Value/Remarks                           |
|------------------------------------------------------------|-----------------------------------------|
| Downlink information common for all radio links            |                                         |
| Downlink DPCH info common for all RL                       |                                         |
| Timing Indication                                          | Maintain                                |
| Downlink DPCH power control information                    |                                         |
| DPC mode                                                   | 0 (Single)                              |
| CHOICE Mode                                                | FDD                                     |
| Power offset PPilot-DPDCH                                  | TBD                                     |
| DL rate matching restriction information                   | Not present                             |
| Spreading factor                                           | Refer to the parameter set in TS 34.108 |
| Fixed or flexible position                                 | Flexible                                |
| TFCI existence                                             | FALSE                                   |
| Number of bits for Pilot bits (SF=128, 256)                | Not present                             |
| DPCH compressed mode info                                  |                                         |
| TGPSI                                                      | 1                                       |
| TGPS status flag                                           | Active                                  |
| TGCFN                                                      | (Current CFN+(256—TTI/10msec)) mod 256  |
| Transmission gap pattern sequence configuration parameters |                                         |
| TGMP                                                       | FDD Measurement                         |
| TGPRC                                                      | 62                                      |
| TGSN                                                       | 8                                       |
| TGL1                                                       | 10                                      |
| TGL2                                                       | 5                                       |
| TGD                                                        | 15                                      |
| TGPL1                                                      | 35                                      |
| TGPL2                                                      | 35                                      |
| RPP                                                        | Mode 1                                  |
| ITP                                                        | Mode 1                                  |
| CHOICE UL/DL mode                                          | DL                                      |
| Downlink compressed mode method                            | SF/2                                    |
| Downlink frame type                                        | A                                       |
| DeltaSIR1                                                  | 2.0                                     |
| DeltaSIRAfter1                                             | 1.0                                     |
| DeltaSIR2                                                  | Not present                             |
| DeltaSIRAfter2                                             | Not present                             |
| N identify abort                                           | Not present                             |
| T Reconfirm abort                                          | Not present                             |
| TX Diversity Mode                                          | None                                    |
| SSDT information                                           | Not present                             |
| Default DPCH Offset Value                                  | 0                                       |

## MEASUREMENT CONTROL (Step 3)

| Information Element                                    | Value/Remark                                   |
|--------------------------------------------------------|------------------------------------------------|
| Measurement identity                                   | 10                                             |
| Measurement command                                    | Setup                                          |
| → CHOICE measurement type                              | Inter-frequency measurement                    |
| → Inter-frequency cell info list                       |                                                |
| → Inter-frequency cell removal                         | Not present                                    |
| → New inter-frequency info list                        |                                                |
| → Inter-frequency cell id                              | Any valid identity other than that of Cell 1   |
| → Frequency Information                                | Any valid frequency other than that of Cell 1  |
| → Cell info                                            | Not present                                    |
| → Cell individual offset                               | Not present                                    |
| → Reference time difference to cell                    | FDD                                            |
| → CHOICE mode                                          | FALSE                                          |
| → Read SFN Indicator                                   |                                                |
| → Primary CPICH Info                                   | Any value of Primary scrambling code           |
| → Primary scrambling code                              | Not present                                    |
| → Primary CPICH TX power                               | FALSE                                          |
| → TX Diversity Indicator                               | Not present                                    |
| → Cell for measurement                                 |                                                |
| → Inter-frequency measurement quantity                 | 4                                              |
| → Filter Coefficient                                   | CPICH RSCP                                     |
| → Frequency quality estimate quantity                  |                                                |
| → Inter-frequency reporting quantity                   | FALSE                                          |
| → UTRAN Carrier RSSI                                   | FALSE                                          |
| → Frequency quality estimate                           |                                                |
| → Non-frequency related quantities                     | No report                                      |
| → SFN-SFN observed time difference                     |                                                |
| reporting indicator                                    | FALSE                                          |
| → Cell synchronisation information reporting indicator | FALSE                                          |
| → Cell identity reporting indicator                    | FALSE                                          |
| → CPICH Ec/No reporting indicator                      | FALSE                                          |
| → CPICH RSCP reporting indicator                       | FALSE                                          |
| → Pathloss reporting indicator                         | CELL_DCH state                                 |
| → Measurement validity                                 | Not present                                    |
| → UE autonomous update mode                            | Inter-frequency measurement reporting criteria |
| → CHOICE report criteria                               |                                                |
| → Parameters required for each events                  | 2D                                             |
| → Inter-frequency event identity                       | -66 dBm                                        |
| → Used frequency threshold                             | 0                                              |
| → Used frequency W                                     | 1 dB                                           |
| → Hysteresis Inter-Frequency                           | 5000-mSec                                      |
| → Time to trigger                                      | Not present                                    |
| → Reporting cell status                                | 2F                                             |
| → Inter-frequency event identity                       | -66 dBm                                        |
| → Used frequency threshold                             | 0                                              |
| → Used frequency W                                     | 1 dB                                           |
| → Hysteresis Inter-Frequency                           | 5000-mSec                                      |
| → Time to trigger                                      | Not present                                    |
| → Reporting cell status                                |                                                |
| Measurement reporting mode                             | Unacknowledged-Mode-RLC                        |
| → Measurement reporting transfer mode                  | Event trigger                                  |
| → Periodic reporting / Event trigger reporting mode    | Not present                                    |
| Additional measurement list                            | Not present                                    |
| DPCH compressed mode status info                       |                                                |

**MEASUREMENT REPORT (Step 4)**

| Information Element              | Value/Remarks                     |
|----------------------------------|-----------------------------------|
| Measurement identity             | Check to see if set to 10         |
| Measured results                 | Check to see if it is absent      |
| Measured results on RACH         | Check to see if it is absent      |
| Additional measured results      | Check to see if it is absent      |
| Event results                    | Inter-frequency event results,    |
| → Event ID                       | 2F                                |
| → Cell measurement event results |                                   |
| - Frequency info                 | Frequency of Cell 1               |
| - Primary CPICH info             |                                   |
| - Primary scrambling code        | Primary scrambling code of Cell 1 |

**MEASUREMENT REPORT (Step 6)**

| Information Element              | Value/Remarks                     |
|----------------------------------|-----------------------------------|
| Measurement identity             | Check to see if set to 10         |
| Measured results                 | Check to see if it is absent      |
| Measured results on RACH         | Check to see if it is absent      |
| Additional measured results      | Check to see if it is absent      |
| Event results                    | Inter-frequency event results,    |
| → Event ID                       | 2D                                |
| → Cell measurement event results |                                   |
| - Frequency info                 | Frequency of Cell 1               |
| - Primary CPICH info             |                                   |
| - Primary scrambling code        | Primary scrambling code of Cell 1 |

**8.4.1.26.5 Test Requirement**

1. In step 4 the UE shall send MEASUREMENT REPORT message indicating event 2F. IE 'Cell measurement event results' in this message shall contain frequency information and primary scrambling code of Cell 1.
2. In step 6 the UE shall send MEASUREMENT REPORT message indicating event 2D. IE 'Cell measurement event results' in this message shall contain frequency information and primary scrambling code of Cell 1.

**8.4.1.27 Measurement Control and Report: UE internal measurement for events 6A and 6B****8.4.1.27.1 Definition****8.4.1.27.2 Conformance requirement**

When in CELL\_DCH state, the UE shall start to use the new measurement and reporting parameters for UE internal measurement received in the MEASUREMENT CONTROL message. It shall transmit MEASUREMENT REPORT message, which include the measured quantity and event identity, when the reporting criteria is met.

**Reference**

3GPP TS 25.331, clauses 14.6.2.1 and 14.6.2.2.

**8.4.1.27.3 Test Purpose**

To confirm that the UE performs UE internal measurements and reporting for events 6A and 6B, when requested by the UTRAN to do so in the MEASUREMENT CONTROL message.

#### 8.4.1.27.4 Method of test

##### Initial Condition

System Simulator: 1 cell, cell 1.

UE: CS-DCCH+DTCH\_DCH (State 6-9) or PS-DCCH+DTCH\_DCH (State 6-10) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE.

##### Test Procedure

The UE is in CELL\_DCH state in cell 1, after successfully executing procedures P11 or P13 as specified in clause 7.4 of TS 34.108. Next, SS transmits MEASUREMENT CONTROL message to request the UE to perform UE internal measurements and reporting for events 6A and 6B.

SS increases the UE Tx power above the threshold set to event 6A. After 'time to trigger' UE sends MEASUREMENT REPORT, triggered by event 6A, to SS.

SS decreases the UE Tx power below the threshold set to event 6B. After 'time to trigger' UE sends MEASUREMENT REPORT, triggered by event 6B, to SS.

##### Expected Sequence

| Step | Direction |    | Message             | Comment                                                        |
|------|-----------|----|---------------------|----------------------------------------------------------------|
|      | UE        | SS |                     |                                                                |
| 1    |           |    |                     | UE is initially in CELL_DCH state in cell 1.                   |
| 2    |           | ←  | MEASUREMENT CONTROL | SS requests for measurement and reporting of events 6A and 6B. |
| 3    |           |    |                     | SS sets the UE transmission power above 18 dBm.                |
| 4    |           | →  | MEASUREMENT REPORT  | UE shall send 6A event measurement report.                     |
| 5    |           |    |                     | SS sets the UE transmission power below 15 dBm.                |
| 6    |           | →  | MEASUREMENT REPORT  | UE shall send 6B event measurement report.                     |

## Specific Message Content

## MEASUREMENT CONTROL (Step 2)

| Information Element                                      | Value/Remark                               |
|----------------------------------------------------------|--------------------------------------------|
| Measurement Identity                                     | 5                                          |
| Measurement Command                                      | Setup                                      |
| Measurement Reporting Mode                               |                                            |
| — Measurement Reporting Transfer Mode                    | Acknowledged Mode RLC                      |
| — Periodic Reporting / Event Trigger Reporting Mode      | Event Trigger Reporting                    |
| Additional measurements list                             | Not Present                                |
| CHOICE measurement type                                  | UE internal measurement                    |
| — UE internal measurement                                |                                            |
| — UE internal measurement quantity                       | Present                                    |
| — CHOICE mode                                            | FDD                                        |
| — UE internal measurement quantity                       | UE Transmitted Power                       |
| — Filter coefficient                                     | 0                                          |
| — UE internal reporting quantity                         | Present                                    |
| — UE Transmitted Power                                   | TRUE                                       |
| — CHOICE mode                                            | FDD                                        |
| — UE Rx-Tx time difference                               | FALSE                                      |
| — CHOICE report criteria                                 | UE internal measurement reporting criteria |
| — Parameters sent for each UE internal measurement event |                                            |
| — UE internal event identity                             | 6A                                         |
| — Time-to-trigger                                        | 100 milliseconds                           |
| — UE Transmitted Power Tx power threshold                | 18 dBm                                     |
| — UE internal event identity                             | 6B                                         |
| — Time-to-trigger                                        | 100 milliseconds                           |
| — UE Transmitted Power Tx power threshold                | 15 dBm                                     |
| DPCH compressed mode status info                         | Not Present                                |

## MEASUREMENT REPORT (Step 4)

| Information Element             | Value/Remarks                                                  |
|---------------------------------|----------------------------------------------------------------|
| Measurement identity            | Check to see if set to 5                                       |
| Measured Results                |                                                                |
| —— CHOICE measurement           | Check to see if set to "UE Internal-measured results"          |
| —— UE internal-measured results |                                                                |
| —— CHOICE mode                  | Check to see if set to "FDD"                                   |
| —— UE Transmitted Power         | Check to see if present and value is reasonable                |
| Measured Results on RACH        | Check to see if this IE is absent                              |
| Event results                   |                                                                |
| —— CHOICE event result          | Check to see if set to "UE internal measurement event results" |
| —— UE internal event identity   | Check to see if set to "6A"                                    |
| —— CHOICE mode                  | Check to see if set to "FDD"                                   |
| —— Primary CPICH info           | Check to see if this IE is absent                              |

## MEASUREMENT REPORT (Step 6)

| Information Element             | Value/Remarks                                                  |
|---------------------------------|----------------------------------------------------------------|
| Measurement identity            | Check to see if set to 5                                       |
| Measured Results                |                                                                |
| —— CHOICE measurement           | Check to see if set to "UE Internal-measured results"          |
| —— UE internal-measured results |                                                                |
| —— CHOICE mode                  | Check to see if set to "FDD"                                   |
| —— UE Transmitted Power         | Check to see if present and value is reasonable                |
| Measured Results on RACH        | Check to see if this IE is absent                              |
| Event results                   |                                                                |
| —— CHOICE event result          | Check to see if set to "UE internal measurement event results" |
| —— UE internal event identity   | Check to see if set to "6B"                                    |
| —— CHOICE mode                  | Check to see if set to "FDD"                                   |
| —— Primary CPICH info           | Check to see if this IE is absent                              |

## 8.4.1.27.5 — Test Requirement

After step 3, the UE shall transmit MEASUREMENT REPORT message, containing measured results for UE transmitted power. The 'Event results' IE contains event identity 6A.

After step 5, the UE shall transmit MEASUREMENT REPORT message, containing measured results for UE transmitted power. The 'Event results' IE contains event identity 6B.

## 8.4.1.28 — Measurement Control and Report: UE internal measurement for events 6F and 6G

## 8.4.1.28.1 — Definition

## 8.4.1.28.2 — Conformance requirement

When in CELL\_DCH state, the UE shall start to use the new measurement and reporting parameters for UE internal measurement received in the MEASUREMENT CONTROL message. It shall transmit MEASUREMENT REPORT message, which include the measured quantity and event identity, when the reporting criteria is met.



## Reference

3GPP TS 25.331, clauses 14.6.2.6 and 14.6.2.7.

### 8.4.1.28.3 Test Purpose

To confirm that the UE performs UE internal measurements and reporting for events 6F and 6G, when requested by the UTRAN to do so in the MEASUREMENT CONTROL message.

### 8.4.1.28.4 Method of test

#### Initial Condition

System Simulator: 1 cell – The initial configuration of the cell 1 in the SS shall follow the values indicated in table 6.1.2 of TS 34.108.

UE: CS-DCCH+DTCH\_DCH (State 6-9) or PS-DCCH+DTCH\_DCH (State 6-10) in cell 1 as specified in clause 7.4 of TS 34.108, depending on the CN domain supported by the UE.

#### Test Procedure

Table 6.1.2 of TS 34.108 specifies the radio conditions to be applied for the cells in this test.

The UE is in CELL\_DCH state in cell 1, after successfully executing procedures P11 or P13 as specified in clause 7.4 of TS 34.108.

SS then performs an active set update procedure by sending ACTIVE SET UPDATE REQUEST message on the downlink DCCH. Cell 2 is to be added to the active set, according to the content of this downlink message. The UE shall reply with an ACTIVE SET UPDATE COMPLETE message on the uplink DCCH, and include cell 2 to the active set when the activation time specified has elapsed.

Next, SS transmits MEASUREMENT CONTROL message to request the UE to perform UE internal measurements and reporting for events 6F and 6G.

SS adjusts the Tx timing of cell 2 above the threshold set to event 6F. After 'time to trigger' UE sends MEASUREMENT REPORT, triggered by event 6F, to SS.

SS adjusts the Tx timing of cell 2 below the threshold set to event 6G. After 'time to trigger' UE sends MEASUREMENT REPORT, triggered by event 6G, to SS.

#### Expected Sequence

| Step | Direction |    | Message                    | Comment                                                                          |
|------|-----------|----|----------------------------|----------------------------------------------------------------------------------|
|      | UE        | SS |                            |                                                                                  |
| 1    |           |    |                            | UE is initially in CELL_DCH state in cell 1.                                     |
| 2    | ←         |    | ACTIVE SET UPDATE          | SS asks UE to add cell 2 into the active set.                                    |
| 3    | →         |    | ACTIVE SET UPDATE COMPLETE |                                                                                  |
| 4    | ←         |    | MEASUREMENT CONTROL        | SS requests for measurement and reporting of events 6F and 6G.                   |
| 5    |           |    |                            | SS switches Tx timing of cell 2 to a delay of –192 chips with respect to cell 1. |
| 6    | →         |    | MEASUREMENT REPORT         | UE shall send 6F event measurement report.                                       |
| 7    |           |    |                            | SS switches Tx timing of cell 2 to a delay of 192 chips with respect to cell 1.  |
| 8    | →         |    | MEASUREMENT REPORT         | UE shall send 6G event measurement report.                                       |

## Specific Message Content

## ACTIVE SET UPDATE (Step 2)

The contents of ACTIVE SET UPDATE message for this test step is identical to the same message found in Annex A with the following exceptions:

| Information Element                          | Value/remark                                                                    |
|----------------------------------------------|---------------------------------------------------------------------------------|
| RRC transaction identifier                   | 0                                                                               |
| Radio link addition information              |                                                                                 |
| → Primary CPICH Info                         |                                                                                 |
| → Primary Scrambling Code                    | Set to same code as assigned for cell 2                                         |
| → Downlink DPCH info for each RL             |                                                                                 |
| → Primary CPICH usage for channel estimation | P-CPICH can be used.                                                            |
| → DPCH frame offset                          | 0 chips                                                                         |
| → Secondary CPICH info                       | Not Present                                                                     |
| → DL channelisation code                     | This IE is repeated for all existing downlink DPCHs allocated to the UE         |
| → Secondary scrambling code                  | Not Present                                                                     |
| → Spreading factor                           | Reference to TS34.108 clause 6.10                                               |
| → Code Number                                | Parameter Set                                                                   |
| → Scrambling code change                     | For each DPCH, assign the same code number in the current code given in cell 1. |
| → TPC Combination Index                      | Not Present                                                                     |
| → SSDT Cell Identity                         | 0                                                                               |
| → Close loop timing adjustment mode          | Not Present                                                                     |
| → TFCI Combining Indicator                   | Not Present                                                                     |
| → SCCPCH information for FACH                | Not Present                                                                     |
| Radio link removal information               | Not Present                                                                     |

## ACTIVE SET UPDATE COMPLETE (Step 3)

| Information Element        | Value/remark                   |
|----------------------------|--------------------------------|
| RRC transaction identifier | Check to see if it is set to 0 |

## MEASUREMENT CONTROL (Step 4)

| Information Element                                      | Value/Remark                               |
|----------------------------------------------------------|--------------------------------------------|
| Measurement Identity                                     | 5                                          |
| Measurement Command                                      | Setup                                      |
| Measurement Reporting Mode                               |                                            |
| — Measurement Reporting Transfer Mode                    | Acknowledged Mode RLC                      |
| — Periodic Reporting / Event Trigger Reporting Mode      | Event Trigger Reporting                    |
| Additional measurements list                             | Not Present                                |
| CHOICE measurement type                                  | UE internal measurement                    |
| — UE internal measurement                                |                                            |
| — UE Internal measurement quantity                       | Present                                    |
| — CHOICE mode                                            | FDD                                        |
| — Measurement quantity                                   | UE Rx-Tx time difference                   |
| — Filter coefficient                                     | 0                                          |
| — UE internal reporting quantity                         | Present                                    |
| — UE Transmitted Power                                   | FALSE                                      |
| — CHOICE mode                                            | FDD                                        |
| — UE Rx-Tx time difference                               | TRUE                                       |
| — CHOICE report criteria                                 | UE internal measurement reporting criteria |
| — Parameters sent for each UE internal measurement event |                                            |
| — UE internal event identity                             | 6F                                         |
| — Time-to-trigger                                        | 0 milliseconds                             |
| — UE Rx-Tx time difference threshold                     | 1174                                       |
| — UE internal event identity                             | 6G                                         |
| — Time-to-trigger                                        | 0 milliseconds                             |
| — UE Rx-Tx time difference threshold                     | 874                                        |
| DPCH compressed mode status info                         | Not Present                                |

## MEASUREMENT REPORT (Step 6)

| Information Element               | Value/Remarks                                                  |
|-----------------------------------|----------------------------------------------------------------|
| Measurement identity              | Check to see if set to 5                                       |
| Measured Results                  |                                                                |
| — CHOICE measurement              | Check to see if set to "UE Internal-measured results"          |
| — UE internal-measured results    |                                                                |
| — CHOICE mode                     | Check to see if set to "FDD"                                   |
| — UE Rx-Tx report entries         |                                                                |
| — Primary CPICH info              |                                                                |
| — Primary scrambling code         | Check to see if set to codes assigned for cell 1 & cell 2.     |
| — UE Rx-Tx time difference type 1 | Check to see if present and value is reasonable                |
| Measured Results on RACH          | Check to see if this IE is absent                              |
| Event results                     |                                                                |
| — CHOICE event result             | Check to see if set to "UE internal measurement event results" |
| — UE internal event identity      | Check to see if set to "6F"                                    |
| — CHOICE mode                     | Check to see if set to "FDD"                                   |
| — Primary CPICH info              |                                                                |
| — Primary scrambling code         | Check to see if set to code assigned for cell 2.               |

## MEASUREMENT REPORT (Step 8)

| Information Element             | Value/Remarks                                                  |
|---------------------------------|----------------------------------------------------------------|
| Measurement identity            | Check to see if set to 5                                       |
| Measured Results                |                                                                |
| CHOICE measurement              | Check to see if set to "UE Internal-measured results"          |
| UE internal-measured results    |                                                                |
| CHOICE mode                     | Check to see if set to "FDD"                                   |
| UE Rx-Tx report entries         |                                                                |
| Primary CPICH info              |                                                                |
| Primary scrambling code         | Check to see if set to codes assigned for cell 1 & cell 2.     |
| UE Rx-Tx time difference type 1 | Check to see if present and value is reasonable                |
| Measured Results on RACH        | Check to see if this IE is absent                              |
| Event results                   |                                                                |
| CHOICE event result             | Check to see if set to "UE internal measurement event results" |
| UE internal event identity      | Check to see if set to "6G"                                    |
| CHOICE mode                     | Check to see if set to "FDD"                                   |
| Primary CPICH info              |                                                                |
| Primary scrambling code         | Check to see if set to code assigned for cell 2.               |

## 8.4.1.28.5 Test Requirement

After step 5, the UE shall transmit MEASUREMENT REPORT message, containing measured results for UE Rx-Tx time difference. The 'Event results' IE contains event identity 6F.

After step 7, the UE shall transmit MEASUREMENT REPORT message, containing measured results for UE Rx-Tx time difference. The 'Event results' IE contains event identity 6G.

## 8.4.1.29 Measurement Control and Report: Event based Traffic Volume measurement in CELL\_FACH state.

## 8.4.1.29.1 Definition

## 8.4.1.29.2 Conformance requirement

Event based transport channel traffic volume measurement compares sum of buffer occupancies of RBs multiplexed onto a transport channel to the threshold, which UE receives from the network. When transport channel traffic volume exceeds threshold UE sends RRC: Measurement Report towards network. Message includes at least indication of measurement identity. In CELL\_FACH state UE has only RACH transport channel.

## Reference

3GPP TS 25.331, clause 14.4.

## 8.4.1.29.3 Test Purpose

To verify that in CELL\_FACH state when event 4a triggers UE sends RRC: Measurement Report with correct measurement identity and indication of UL transport channel type, radio-bearer identities and corresponding RLC buffer payloads in number of bytes.

## 8.4.1.29.4 Method of test

## Initial Condition

System Simulator: 1 cell

UE: CELL\_FACH state, state 6-11 as specified in clause 7.4 of TS 34.108.

System Information Block type 11 nor 12 does not include Traffic Volume measurement system information.

### Test Procedure

The UE is brought to the CELL\_FACH state after a successful incoming call attempt. The SS follows the procedure in TS 34.108 clause 7.1.3 (Mobile Terminated), to set up a user RAB, but with the default RAB replaced by the one described in 34.108, clause 6.10.2.4.3.2: Interactive/Background 32 kbps PS RAB + SRBs for CCCH + SRB for DCCH + SRB for BCCH for DL and 6.10.2.4.4.1: Interactive/Background 32 kbps PS RAB + SRB for CCCH + SRB for DCCH for UL. The radio bearer is placed into UE test loop mode 1 described in 34.109 clause 5.3. SS sends to UE RRC: MEASUREMENT CONTROL message, which includes traffic volume measurement control parameters eg: uplink transport channel type and reporting threshold. Transport channel traffic volume exceeds threshold and after 'time to trigger' UE sends RRC: MEASUREMENT REPORT to SS. SS does not respond and after 'pending time after trigger' UE sends again same RRC: MEASUREMENT REPORT.

### Expected Sequence

| Step | Direction |    | Message             | Comment                                                           |
|------|-----------|----|---------------------|-------------------------------------------------------------------|
|      | UE        | SS |                     |                                                                   |
| 1    |           |    |                     | The UE is brought to the CELL_FACH state in the cell 1.           |
| 2    |           | ←  | MEASUREMENT CONTROL | SS provides Traffic Volume measurement criterias to UE.           |
| 3    |           | →  | MEASUREMENT REPORT  | UE reports that Traffic Volume measurement event 4A is triggered. |
| 4    |           | →  | MEASUREMENT REPORT  | UE repeats message after 1000 ms.                                 |

### Specific Message Content

#### MEASUREMENT CONTROL (Step 2)

| Information Element                                 | Value/Remark          |
|-----------------------------------------------------|-----------------------|
| Measurement Identity                                | 15                    |
| Measurement Command                                 | Setup                 |
| Measurement Reporting Mode                          |                       |
| → Measurement Reporting Transfer Mode               | Acknowledged Mode RLC |
| - Periodic Reporting / Event Trigger Reporting Mode | Event Trigger         |
| Additional measurements list                        | Not Present           |
| CHOICE measurement type                             |                       |
| → Traffic volume measurement object                 |                       |
| → Uplink transport channel type                     | RACH                  |
| → Traffic volume measurement quantity               |                       |
| → Measurement quantity                              | RLC buffer payload    |
| → Traffic volume reporting quantity                 |                       |
| → RLC Buffer Payload for each RB                    | TRUE                  |
| → Measurement validity                              |                       |
| → UE state                                          | All states            |
| - Traffic volume measurement reporting criteria     |                       |
| → Traffic volume event identity                     | 4a                    |
| → Reporting threshold                               | 8                     |
| → Time to trigger                                   | 100                   |
| → Pending time after trigger                        | 1000                  |
| → Tx interruption after trigger                     | 250                   |

**MEASUREMENT REPORT (Step 3 and step 4)**

| Information Element                               | Value/Remarks                                                 |
|---------------------------------------------------|---------------------------------------------------------------|
| Measurement identity                              | Check to see if set to 15                                     |
| Measured Results                                  |                                                               |
| — CHOICE measurement                              | Check to see if set to "Traffic volume measured results list" |
| — Traffic volume measurement results              |                                                               |
| — RB identity                                     | Check that value is correct                                   |
| — RLC buffers payload                             | Check that value is reasonable                                |
| Measured Results on RACH                          | Not checked                                                   |
| Additional Measured results                       | Not checked                                                   |
| Event Results                                     |                                                               |
| — Uplink transport channel type causing the event | Check to see if set to "RACH"                                 |
| — UL transport channel identity                   | Check to see that is not set                                  |
| — Traffic volume event identity                   | Check to see if set to "4a"                                   |

**8.4.1.29.5 — Test Requirement**

In step 3 UE sends RRC: MEASUREMENT REPORT with correct measurement identity indication. RB identity and RLC buffers payload has reasonable values.

In step 4 UE repeats message sent in step 3.

After step 3 UE is not allowed to send user data during the 'Tx interruption after trigger' timer is running.

**8.4.1.30 — Measurement Control and Report: Event based Traffic Volume measurement in CELL\_DCH state.****8.4.1.30.1 — Definition****8.4.1.30.2 — Conformance requirement**

Event based transport channel traffic volume measurement compares sum of buffer occupancies of RBs multiplexed onto a transport channel to the threshold, which UE receives from the network. When transport channel traffic volume exceeds threshold UE sends RRC: Measurement Report towards network. Message includes at least indication of measurement identity. In CELL\_DCH state each DCH may have own measurement activated with own threshold.

**Reference**

3GPP TS 25.331, clause 14.4.

**8.4.1.30.3 — Test Purpose**

To verify that in CELL\_DCH state when event 4a or 4b triggers UE sends RRC: Measurement Report with correct measurement identity and indication of uplink transport channel type and identity, radio bearer identities and corresponding RLC buffer payloads in number of bytes.

**8.4.1.30.4 — Method of test****Initial Condition**

System Simulator: 1 cell

UE: CELL\_DCH state, state 6-10 as specified in clause 7.4 of TS 34.108.

System Information Block type 11 nor 12 does not include Traffic Volume measurement system information.

## Test Procedure

The UE is brought to the CELL\_DCH state after a successful incoming call attempt. The SS follows the procedure in TS 34.108 clause 7.1.3 (Mobile Terminated), to set up a user RAB, but with the default RAB replaced by the one described in 34.108, clause 6.10.2.4.1.26: Interactive or background / UL: 64 kbps / PS RAB + UL: 3.4 DL: 3.4 kbps SRBs for DCCH. The radio bearer is placed into UE test loop mode 1 described in 34.109 clause 5.3. SS sends to UE RRC: MEASUREMENT CONTROL messages, which includes in addition to measurement identity traffic volume measurement control parameters eg. uplink transport channel type and identity and reporting threshold for both events 4a and 4b. Transport channel traffic volume exceeds threshold and after 'time to trigger' UE sends RRC: MEASUREMENT REPORT to SS. SS does not respond and after 'pending time after trigger' UE sends again same RRC: MEASUREMENT REPORT. UE's transport channel load decreases to zero, event 4b triggers and previous signaling procedure repeats.

## Expected Sequence

| Step | Direction |    | Message             | Comment                                                                                                                    |
|------|-----------|----|---------------------|----------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                     |                                                                                                                            |
| 1    |           |    |                     | The UE is brought to the CELL_DCH state in the cell 1.                                                                     |
| 2    |           | ←  | MEASUREMENT CONTROL | SS provides Traffic Volume measurement criterias (event 4a) to UE.                                                         |
| 3    |           | ←  | MEASUREMENT CONTROL | SS provides Traffic Volume measurement criterias (event 4b) to UE.                                                         |
| 4    |           | →  | MEASUREMENT REPORT  | UE's transport channel is loaded. UE reports that Traffic Volume measurement event 4A is triggered.                        |
| 5    |           | →  | MEASUREMENT REPORT  | UE repeats message after 2000 ms.                                                                                          |
| 6    |           | →  | MEASUREMENT REPORT  | UE's transport channel traffic volume decreases to zero. UE reports that Traffic Volume measurement event 4B is triggered. |
| 7    |           | →  | MEASUREMENT REPORT  | UE repeats message after 2000 ms.                                                                                          |

## Specific Message Content

## MEASUREMENT CONTROL (Step 2)

| Information Element                             | Value/Remark          |
|-------------------------------------------------|-----------------------|
| Measurement Identity                            | 15                    |
| Measurement Command                             | Setup                 |
| Measurement Reporting Mode                      |                       |
| — Measurement Reporting Transfer Mode           | Acknowledged Mode RLC |
| - Periodic Reporting / Event Trigger Reporting  | Event Trigger         |
| - Mode                                          |                       |
| Additional measurements list                    | Not Present           |
| CHOICE measurement type                         |                       |
| — Traffic volume measurement objects            |                       |
| — Uplink transport channel type                 | DCH                   |
| — UL target transport channel ID                | 1                     |
| — Traffic volume measurement quantity           |                       |
| — Measurement quantity                          | RLC buffer payload    |
| — Traffic volume reporting quantity             |                       |
| — RLC Buffer Payload for each RB                | TRUE                  |
| — Measurement validity                          |                       |
| — UE state                                      | CELL_DCH              |
| — Traffic volume measurement reporting criteria |                       |
| — Traffic volume event identity                 | 4a                    |
| — Reporting threshold                           | 256                   |
| — Time to trigger                               | 100                   |
| — Pending time after trigger                    | 2000                  |
| — Tx interruption after trigger                 | Not present           |

## MEASUREMENT CONTROL (Step 3)

| Information Element                             | Value/Remark          |
|-------------------------------------------------|-----------------------|
| Measurement Identity                            | 14                    |
| Measurement Command                             | Setup                 |
| Measurement Reporting Mode                      |                       |
| — Measurement Reporting Transfer Mode           | Acknowledged Mode RLC |
| - Periodic Reporting / Event Trigger Reporting  | Event Trigger         |
| - Mode                                          |                       |
| Additional measurements list                    | Not Present           |
| CHOICE measurement type                         |                       |
| — Traffic volume measurement objects            |                       |
| — Uplink transport channel type                 | DCH                   |
| — UL target transport channel ID                | 1                     |
| — Traffic volume measurement quantity           |                       |
| — Measurement quantity                          | RLC buffer payload    |
| — Traffic volume reporting quantity             |                       |
| — RLC Buffer Payload for each RB                | TRUE                  |
| — Measurement validity                          |                       |
| — UE state                                      | CELL_DCH              |
| — Traffic volume measurement reporting criteria |                       |
| — Traffic volume event identity                 | 4b                    |
| — Reporting threshold                           | 32                    |
| — Time to trigger                               | 100                   |
| — Pending time after trigger                    | 2000                  |
| — Tx interruption after trigger                 | Not present           |



**MEASUREMENT REPORT (Step 4 and step 5)**

| Information Element                               | Value/Remarks                                                 |
|---------------------------------------------------|---------------------------------------------------------------|
| Measurement identity                              | Check to see if set to 15                                     |
| Measured Results                                  |                                                               |
| — CHOICE measurement                              | Check to see if set to "Traffic volume measured results list" |
| —— Traffic volume measurement results             |                                                               |
| ——— RB identity                                   | Check that value is correct                                   |
| ——— RLC buffers payload                           | Check that value is reasonable                                |
| Measured Results on RACH                          | Not checked                                                   |
| Additional Measured results                       | Not checked                                                   |
| Event Results                                     |                                                               |
| — Uplink transport channel type causing the event | Check to see if set to "DCH"                                  |
| — UL transport channel identity                   | Check to see if set to "1"                                    |
| — Traffic volume event identity                   | Check to see if set to "4a"                                   |

**MEASUREMENT REPORT (Step 6 and step 7)**

| Information Element                               | Value/Remarks                                                 |
|---------------------------------------------------|---------------------------------------------------------------|
| Measurement identity                              | Check to see if set to 14                                     |
| Measured Results                                  |                                                               |
| — CHOICE measurement                              | Check to see if set to "Traffic volume measured results list" |
| —— Traffic volume measurement results             |                                                               |
| ——— RB identity                                   | Check that value is correct                                   |
| ——— RLC buffers payload                           | Check that value is reasonable                                |
| Measured Results on RACH                          | Not checked                                                   |
| Additional Measured results                       | Not checked                                                   |
| Event Results                                     |                                                               |
| — Uplink transport channel type causing the event | Check to see if set to "DCH"                                  |
| — UL transport channel identity                   | Check to see if set to "1"                                    |
| — Traffic volume event identity                   | Check to see if set to "4b"                                   |

**8.4.1.30.5 — Test Requirement**

In steps 4, 5, 6 and 7 UE sends RRC: MEASUREMENT REPORT with correct measurement identity indication. RB identity and RLC buffers payload has correct values. Measurement identity, transport channel type, transport channel identity and event identity has to match with set values.

**8.4.1.31 — Measurement Control and Report: Inter-RAT measurement in CELL\_DCH state.****8.4.1.31.1 — Definition****8.4.1.31.2 — Conformance requirement**

The UE shall perform GSM-RSSI measurements in the gaps of compressed mode pattern sequence specified for GSM-RSSI measurement purpose.

The UE shall perform GSM Initial BSIC identification in compressed mode pattern sequence specified for Initial BSIC identification measurement purpose.

**Reference**

3GPP TS 25.331, clause 14.3.2.

#### 8.4.1.31.3 ~~Test Purpose~~

~~Purpose of this test is to verify that UE is capable to perform GSM RSSI and GSM Initial BSIC identification measurements in compressed mode.~~

#### 8.4.1.31.4 ~~Method of test~~

##### ~~Initial Condition~~

~~System Simulator: 1 UTRAN FDD cell and 2 GSM cells.~~

| Parameter       | Unit | Cell 1<br>(GSM) | Cell 2<br>(GSM) |
|-----------------|------|-----------------|-----------------|
| Test Channel    | #    | 1               | 2               |
| RF Signal Level | dBm  | -80             | -85             |
| BCCH ARFCN      | #    | 1               | 7               |
| CELL identity   | #    | 0               | 1               |
| BSIC            | #    | BSIC1           | BSIC2           |

~~UE: CELL\_DCH state, state 6-9 as specified in clause 7.4 of TS 34.108.~~

~~System Information Block type 11 nor 12 does not include Inter-RAT measurement system information.~~

##### ~~Test Procedure~~

~~The UE is brought to the CELL\_DCH state after a successful outgoing call attempt. SS provides compressed mode pattern sequence parameters to UE by using physical channel reconfiguration procedure. Depending on UE's measurement capability uplink and/or downlink compressed mode is requested. Compressed mode method is SF/2 with 7 slot gap in single frame. Two normal frames is between gapped frames. First RRC: MEASUREMENT CONTROL message is used to provide measurement control parameters (GSM RSSI) to UE and to start compressed mode for measurement. UE replies according to request by sending RRC: MEASUREMENT REPORT messages periodically to SS. Reporting period is 1000 ms. After two RRC: MEASUREMENT REPORT messages, SS sends second RRC: MEASUREMENT CONTROL message to start GSM Initial BSIC identification measurement. UE replies similarly as in GSM RSSI measurement case.~~

## Expected Sequence

| Step | Direction |    | Message                                   | Comment                                                                                                                                                       |
|------|-----------|----|-------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                                               |
| 1    |           |    |                                           | The UE is brought to the CELL_DCH state in the cell 1.                                                                                                        |
| 2    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | Compressed mode pattern sequence parameters are loaded to UE.                                                                                                 |
| 3    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                                                               |
| 4    |           | ←  | MEASUREMENT CONTROL                       | SS provides GSM RSSI measurement control parameters to UE. Compressed mode for GSM RSSI measurement is started.                                               |
| 5    |           | →  | MEASUREMENT REPORT                        | UE reports measurement results of GSM RSSI measurement to SS.                                                                                                 |
| 6    |           | →  | MEASUREMENT REPORT                        | Next periodical measurement report.                                                                                                                           |
| 7    |           | ←  | MEASUREMENT CONTROL                       | SS provides GSM Initial BSIC identification measurement control parameters to UE. Compressed mode for GSM Initial BSIC identification measurement is started. |
| 8    |           | →  | MEASUREMENT REPORT                        | UE reports measurement results of GSM Initial BSIC identification measurement to SS.                                                                          |
| 9    |           | →  | MEASUREMENT REPORT                        | Next periodical measurement report.                                                                                                                           |

## Specific Message Content

## PHYSICAL CHANNEL RECONFIGURATION (Step 2)

Use the same message sub-type in Annex A titled "Speech in CS", with the following exceptions:

| Information Element                                                   | Value/Remarks                                      |
|-----------------------------------------------------------------------|----------------------------------------------------|
| Downlink information common for all radio links                       |                                                    |
| <del>DPCH compressed mode info</del>                                  |                                                    |
| <del>TGPSI</del>                                                      | 1                                                  |
| <del>TGPS Status Flag</del>                                           | Inactive                                           |
| <del>TGCFN</del>                                                      | Not present                                        |
| <del>Transmission gap pattern sequence configuration parameters</del> |                                                    |
| <del>TGMP</del>                                                       | GSM Carrier RSSI Measurement                       |
| <del>TGPRC</del>                                                      | Infinity                                           |
| <del>TGSN</del>                                                       | 4                                                  |
| <del>TGL1</del>                                                       | 7                                                  |
| <del>TGL2</del>                                                       | Not present                                        |
| <del>TGD</del>                                                        | 0                                                  |
| <del>TGPL1</del>                                                      | 3                                                  |
| <del>TGPL2</del>                                                      | Not present                                        |
| <del>RPP</del>                                                        | Mode 1                                             |
| <del>ITP</del>                                                        | Mode 1                                             |
| CHOICE UL/DL Mode                                                     | UL and DL (depends on UE's Measurement capability) |
| <del>Downlink compressed mode method</del>                            | SF/2                                               |
| <del>Uplink compressed mode method</del>                              | SF/2                                               |
| <del>Downlink frame type</del>                                        | A                                                  |
| <del>DeltaSIR1</del>                                                  | 2.0                                                |
| <del>DeltaSIRAfter1</del>                                             | 1.0                                                |
| <del>DeltaSIR2</del>                                                  | Not Present                                        |
| <del>DeltaSIR2After2</del>                                            | Not Present                                        |
| <del>N identify abort</del>                                           | Not Present                                        |
| <del>T Reconfirm abort</del>                                          | Not Present                                        |
| <del>TGPSI</del>                                                      | 2                                                  |
| <del>TGPS Status Flag</del>                                           | Inactive                                           |
| <del>TGCFN</del>                                                      | Not present                                        |
| <del>Transmission gap pattern sequence configuration parameters</del> |                                                    |
| <del>TGMP</del>                                                       | GSM Initial BSIC identification                    |
| <del>TGPRC</del>                                                      | Infinity                                           |
| <del>TGSN</del>                                                       | 4                                                  |
| <del>TGL1</del>                                                       | 7                                                  |
| <del>TGL2</del>                                                       | Not present                                        |
| <del>TGD</del>                                                        | 0                                                  |
| <del>TGPL1</del>                                                      | 3                                                  |
| <del>TGPL2</del>                                                      | Not present                                        |
| <del>RPP</del>                                                        | Mode 1                                             |
| <del>ITP</del>                                                        | Mode 1                                             |
| CHOICE UL/DL Mode                                                     | UL and DL (depends on UE's Measurement capability) |
| <del>Downlink compressed mode method</del>                            | SF/2                                               |
| <del>Uplink compressed mode method</del>                              | SF/2                                               |
| <del>Downlink frame type</del>                                        | A                                                  |
| <del>DeltaSIR1</del>                                                  | 2.0                                                |
| <del>DeltaSIRAfter1</del>                                             | 1.0                                                |
| <del>DeltaSIR2</del>                                                  | Not Present                                        |
| <del>DeltaSIR2After2</del>                                            | Not Present                                        |
| <del>N identify abort</del>                                           | 128                                                |
| <del>T Reconfirm abort</del>                                          | Not Present                                        |

## MEASUREMENT CONTROL (Step 4)

| Information Element | Value/Remark |
|---------------------|--------------|
|---------------------|--------------|

|                                                |                                                                     |
|------------------------------------------------|---------------------------------------------------------------------|
| Measurement Identity                           | 15                                                                  |
| Measurement Command                            | Setup                                                               |
| Measurement Reporting Mode                     |                                                                     |
| — Measurement Reporting Transfer Mode          | Acknowledged Mode RLC                                               |
| — Periodic Reporting / Event Trigger Reporting | Periodical reporting                                                |
| — Mode                                         |                                                                     |
| Additional measurements list                   | Not Present                                                         |
| CHOICE measurement type                        |                                                                     |
| — inter-RAT measurement                        |                                                                     |
| — inter-RAT measurement object list            |                                                                     |
| — CHOICE Inter-RAT Cell Removal                | Remove no inter-RAT cells                                           |
| — inter-RAT cell id                            | 0                                                                   |
| CHOICE Radio Access Technology                 | GSM                                                                 |
| — Cell individual offset                       | 0                                                                   |
| — Cell selection and re-selection info         | Not present                                                         |
| — BSIC                                         | BSIC1                                                               |
| — Band indicator                               | DCS 1800 band used                                                  |
| — BCCH ARFCN                                   | 1                                                                   |
| — inter-RAT cell id                            | 1                                                                   |
| CHOICE Radio Access Technology                 | GSM                                                                 |
| — Cell individual offset                       | 0                                                                   |
| — Cell selection and re-selection info         | Not present                                                         |
| — BSIC                                         | BSIC2                                                               |
| — Band indicator                               | DCS 1800 band used                                                  |
| — BCCH ARFCN                                   | 7                                                                   |
| — Cell for measurement                         | Not present                                                         |
| — inter-RAT measurement quantity               |                                                                     |
| — Measurement quantity for UTRAN quality       | Not present                                                         |
| — estimate                                     |                                                                     |
| — CHOICE system                                | GSM                                                                 |
| — Measurement quantity                         | GSM carrier RSSI                                                    |
| — Filter coefficient                           | 0                                                                   |
| — BSIC verification required                   | not required                                                        |
| — inter-RAT reporting quantity                 |                                                                     |
| — UTRAN estimated quality                      | FALSE                                                               |
| — CHOICE system                                | GSM                                                                 |
| — Observed time difference to to GSM           | FALSE                                                               |
| — cell reporting indicator                     |                                                                     |
| — GSM carrier RSSI reporting indicator         | TRUE                                                                |
| — Reporting cell status                        |                                                                     |
| — CHOICE reported cell                         |                                                                     |
| — Reported cells within active set or within   |                                                                     |
| — virtual active set or of the other RAT       |                                                                     |
| — Maximum number of reported cells             | 6                                                                   |
| — CHOICE report criteria                       |                                                                     |
| — Periodical reporting criteria                |                                                                     |
| — Amount of reporting                          | infinity                                                            |
| — Reporting interval                           | 1000                                                                |
| Physical channel information elements          |                                                                     |
| — DPCH compressed mode status info             |                                                                     |
| — TGPS reconfiguration CFN                     | $(\text{Current CFN} + (256 - \text{TTI}/10\text{msec})) \bmod 256$ |
| — Transmission gap pattern sequence            |                                                                     |
| — TGPSI                                        | 1                                                                   |
| — TGPS status flag                             | active                                                              |
| — TGCFN                                        | $(\text{Current CFN} + (256 - \text{TTI}/10\text{msec})) \bmod 256$ |
| — TGPSI                                        | 2                                                                   |
| — TGPS status flag                             | inactive                                                            |
| — TGCFN                                        | Not present                                                         |

## MEASUREMENT REPORT (Step 5 and step 6)

| Information Element                    | Value/Remarks                                            |
|----------------------------------------|----------------------------------------------------------|
| Measurement identity                   | Check to see if set to 15                                |
| Measured Results                       |                                                          |
| — CHOICE measurement                   | Check to see if set to "Inter-RAT-measured results list" |
| - Inter-RAT-measured result list       |                                                          |
| - CHOICE system                        | GSM                                                      |
| - Measured GSM cells                   |                                                          |
| - GSM carrier RSSI                     | Check to see if present                                  |
| CHOICE BSIC                            | Non-verified BSIC                                        |
| - BCCH ARFCN                           | Check that is set to "0"                                 |
| - Observed time difference to GSM cell | Check that not present                                   |
| - GSM carrier RSSI                     | Check that measurement result is reasonable              |
| CHOICE BSIC                            | Non-verified BSIC                                        |
| - BCCH ARFCN                           | Check that is set to "7"                                 |
| - Observed time difference to GSM cell | Check that not present                                   |
| Measured results on RACH               | Check that not present                                   |
| Additional Measured results            | Check that not present                                   |
| Event results                          | Check that not present                                   |

## MEASUREMENT CONTROL (Step 7)

| Information Element                            | Value/Remark                                                        |
|------------------------------------------------|---------------------------------------------------------------------|
| Measurement Identity                           | 15                                                                  |
| Measurement Command                            | Modify                                                              |
| Measurement Reporting Mode                     |                                                                     |
| — Measurement Reporting Transfer Mode          | Acknowledged Mode RLC                                               |
| - Periodic Reporting / Event Trigger Reporting | Periodical reporting                                                |
| - Mode                                         |                                                                     |
| Additional measurements list                   | Not Present                                                         |
| CHOISE measurement type                        |                                                                     |
| - inter-RAT measurement                        |                                                                     |
| — inter-RAT measurement object list            | Not present                                                         |
| - inter-RAT measurement quantity               |                                                                     |
| — Measurement quantity for UTRAN quality       | Not present                                                         |
| — estimate                                     |                                                                     |
| — CHOISE system                                | GSM                                                                 |
| - Measurement quantity                         | GSM carrier RSSI                                                    |
| - Filter coefficient                           | 0                                                                   |
| - BSIC verification required                   | required                                                            |
| - inter-RAT reporting quantity                 |                                                                     |
| — UTRAN estimated quality                      | FALSE                                                               |
| — CHOISE system                                | GSM                                                                 |
| - Observed time difference to to GSM           | FALSE                                                               |
| - cell reporting indicator                     |                                                                     |
| - GSM carrier RSSI reporting indicator         | TRUE                                                                |
| - Reporting cell status                        |                                                                     |
| — CHOISE reported cell                         |                                                                     |
| - Reported cells within active set or within   |                                                                     |
| - virtual active set or of the other RAT       |                                                                     |
| - Maximum number of reported cells             | 6                                                                   |
| — CHOISE report criteria                       |                                                                     |
| - Periodical reporting criteria                |                                                                     |
| - Amount of reporting                          | infinity                                                            |
| - Reporting interval                           | 1000                                                                |
| Physical channel information elements          |                                                                     |
| - DPCH compressed mode status info             |                                                                     |
| - TGPS reconfiguration CFN                     | $(\text{Current CFN} + (256 - \text{TTI}/10\text{msec})) \bmod 256$ |
| - Transmission gap pattern sequence            |                                                                     |
| - TGPSI                                        | 1                                                                   |
| - TGPS status flag                             | inactive                                                            |
| - TGCFN                                        | Not present                                                         |
| - TGPSI                                        | 2                                                                   |
| - TGPS status flag                             | active                                                              |
| - TGCFN                                        | $(\text{Current CFN} + (256 - \text{TTI}/10\text{msec})) \bmod 256$ |

## MEASUREMENT REPORT (Step 8 and step 9)

| Information Element                    | Value/Remarks                                            |
|----------------------------------------|----------------------------------------------------------|
| Measurement identity                   | Check to see if set to 15                                |
| Measured Results                       |                                                          |
| — CHOICE measurement                   | Check to see if set to "Inter-RAT-measured results-list" |
| — Inter-RAT-measured result-list       |                                                          |
| — CHOISE system                        | GSM                                                      |
| — Measured GSM cells                   |                                                          |
| — GSM carrier RSSI                     | Check to see if present                                  |
| CHOISE BSIC                            | Verified BSIC                                            |
| — Inter-RAT cell id                    | Check that is set to "0"                                 |
| — Observed time difference to GSM cell | Check that not present                                   |
| — GSM carrier RSSI                     | Check that measurement result is reasonable              |
| CHOISE BSIC                            | Verified BSIC                                            |
| — Inter-RAT cell id                    | Check that is set to "1"                                 |
| — Observed time difference to GSM cell | Check that not present                                   |
| Measured results on RACH               | Check that not present                                   |
| Additional Measured results            | Check that not present                                   |
| Event results                          | Check that not present                                   |

## 8.4.1.31.5 — Test Requirement

In step 5 and step 6 UE reports correctly GSM RSSI values.

In step 8 and step 9 UE reports correctly BSIC values.

Reporting period is the requested one.

## 8.4.1.32 — Void

## 8.4.1.33 — Measurement Control and Report: Inter-RAT measurement, event 3a

## 8.4.1.33.1 — Definition

## 8.4.1.33.2 — Conformance requirement

- When this event is ordered by UTRAN in a MEASUREMENT CONTROL message the UE shall send a report when the estimated quality of the currently used frequency is below the value of the IE "Threshold own system" and the hysteresis and time to trigger conditions are fulfilled and the estimated quality of the other system is above the value of the IE "Threshold other system" and the hysteresis and time to trigger conditions are fulfilled.
- If the IE "DPCCH Compressed Mode Status Info" is present, [in the MEASUREMENT CONTROL message]:
  - after the time indicated by IE "TGPS reconfiguration CFN" has elapsed:
    - activate the pattern sequence stored in the variable TGPS\_IDENTITY corresponding to each IE "TGPSI" for which the "TGPS status flag" is set to "active" at the time indicated by IE "TGCFN"; and
    - begin the inter-frequency and/or inter-RAT measurements corresponding to the pattern sequence measurement purpose of each activated pattern sequence;
    - if the values of IE "TGPS reconfiguration CFN" and IE "TGCFN" are equal:
      - start the concerned pattern sequence immediately at that CFN;
    - not alter pattern sequences stored in variable TGPS\_IDENTITY, but not identified in IE "TGPSI"
- The UE shall perform GSM RSSI measurements in the gaps of compressed mode pattern sequence specified for GSM RSSI measurement purpose. The UE shall perform Initial BSIC identification in compressed mode pattern sequence specified for Initial BSIC identification measurement purpose. The UE shall be able to measure the



"Observed time difference to GSM cell" during a compressed mode pattern sequence configured for this purpose. The UE shall perform BSIC re-confirmation in compressed mode pattern sequence specified for BSIC re-confirmation measurement purpose.

4. If the IE "Inter-RAT measurement quantity" is received in a MEASUREMENT CONTROL message and CHOICE system is GSM, the UE shall:
  - if IE "BSIC verification required" is set to "required", for cells that match any of the BCCH ARFCN and BSIC combinations in the list of inter-RAT cells that the UE has received in IE "Inter-RAT cell info list", and that has a "verified" BSIC:
    - report measurement quantities according to IE "inter-RAT reporting quantity" taking into account the restrictions defined in clause 8.6.7.6;
    - trigger inter-RAT events according to IE "inter-RAT measurement reporting criteria"; and
  - perform event evaluation for event-triggered reporting after BSIC has been verified for a GSM cell
  - indicate non-verified BSIC for a GSM cell in the "Inter-RAT measured results list" IE
5. The UE shall include measured results in MEASUREMENT REPORT as specified in the IE "Inter-RAT reporting quantity".
6. If IE "Observed time difference to GSM cell" is set to "TRUE" [, the UE shall]:
  - include optional IE "Observed time difference to GSM cell" with the value set to the time difference to that GSM cell for the GSM cells that have a BSIC that is "verified", and that match any of the BCCH ARFCN and BSIC combinations in the list of inter-RAT cells that the UE has received in IE "Inter-RAT cell info list".
  - if IE "GSM Carrier RSSI" is set to "TRUE"[, the UE shall]:
    - include optional IE "GSM Carrier RSSI" with a value set to the measured RXLEV to that GSM cell in IE "Inter-RAT measured results list".
  - if the BSIC of reported GSM cell is "verified"[, the UE shall]:
    - set the CHOICE BSIC to "Verified BSIC" and IE "inter-RAT cell id" to the value that GSM cell had in the IE "Inter-RAT cell info list";
7. If the IE "Reporting Cell Status" is received, the UE shall set the IE "Measured Results" in MEASUREMENT REPORT as follows:
  - the maximum number of the IE "Cell Measured Results" to be included in the IE "Measured Results" is the number specified in "Reporting Cell Status".

## Reference

3GPP TS 25.331 clauses 8.4.1.3, 8.6.7.5, 8.6.7.6, 8.6.7.9, 14.3.1.1, 14.3.2.1, 14.3.2.2, 14.3.2.3.

### 8.4.1.33.3 ————— Test Purpose

1. To confirm that the UE starts compressed mode and inter-RAT measurements when so required by the network in a MEASUREMENT CONTROL message.
2. To confirm that the UE sends MEASUREMENT REPORT message if event 3a is configured, if the quality of the currently used UTRAN frequency is below a given threshold and the estimated quality of the other system is above a certain threshold.
3. To confirm that the hysteresis and time to trigger behaviours for event 3a are correctly implemented.
4. To confirm that the UE verifies the BSIC of the cell triggering the event if so required by UTRAN and if the proper compressed mode patterns have been configured in the UE by UTRAN.
5. To confirm that the content of the MEASUREMENT REPORT sent by the UE is according to what was required by UTRAN.

NOTE:—Test purpose 1 verifies conformance requirement 1 and 2.

NOTE:—Test purpose 2 and 3 verifies conformance requirement 1.

NOTE:—Test purpose 4 verifies conformance requirement 2, 3 and 4.

NOTE:—Test purpose 5 verifies conformance requirement 4, 5, 6 and 7.

#### 8.4.1.33.4 Method of test

##### Initial Condition

System simulator: 1 UTRAN FDD cell and 3 GSM cells. The initial configurations of the 3 cells in the SS shall follow the values indicated in the column marked T0. The table is found in "Test procedure".

UE: CELL\_DCH state, state 6-9 as specified in clause 7.4 of TS 34.108.

##### Test procedure

**Table 8.4.1.33.4-1**

| Parameter       | Unit | Cell 1<br>(GSM) |     |     |     |     | Cell 2<br>(GSM) |     |     |     |     | Cell 3<br>(GSM) |     |     |     |     |
|-----------------|------|-----------------|-----|-----|-----|-----|-----------------|-----|-----|-----|-----|-----------------|-----|-----|-----|-----|
|                 |      | T0              | T1  | T2  | T3  | T4  | T0              | T1  | T2  | T3  | T4  | T0              | T1  | T2  | T3  | T4  |
| Test Channel    | #    | GSM-Ch.1        |     |     |     |     | GSM-Ch.2        |     |     |     |     | GSM-Ch.3        |     |     |     |     |
| BCCH ARFCN      | #    | 1               |     |     |     |     | 7               |     |     |     |     | 2               |     |     |     |     |
| CELL identity   | #    | 0               |     |     |     |     | 1               |     |     |     |     | 2               |     |     |     |     |
| BSIC            | #    | BSIC-1          |     |     |     |     | BSIC-2          |     |     |     |     | BSIC-3          |     |     |     |     |
| RF Signal Level | dBm  | -85             | -85 | -70 | -82 | -70 | -85             | -85 | -85 | -77 | -77 | -90             | -90 | -90 | -90 | -90 |

**Table 8.4.1.33.4-2**

| Parameter              | Unit | Cell 1<br>(UTRA) |     |     |     |
|------------------------|------|------------------|-----|-----|-----|
|                        |      | T0               | T1  | T2  | T3  |
| UTRA-RF Channel Number |      | Ch.1             |     |     |     |
| CPICH Ec/No            | dB   | -5               | -20 | -20 | -20 |

The two tables above illustrate the downlink power to be applied for the two cells at various instants of the test execution. Column marked "T0" denotes the initial conditions, while columns marked "T1", "T2" and "T3" indicate the values to be applied subsequently.

The UE is initially in CELL\_DCH, state 6-9 as specified in clause 7.4 of TS 34.108. UTRA cell 1 is the only cell in the active set of the UE. The SS sends a PHYSICAL CHANNEL RECONFIGURATION message to the UE to configure the compressed mode pattern sequence parameters to the UE. Three compressed mode patterns are configured, according to the message specified below. When the PHYSICAL CHANNEL RECONFIGURATION COMPLETE is received from the UE, the SS sends a MEASUREMENT CONTROL message to the UE, to set up inter-RAT measurements. Event 3a is set up in this message, and compressed mode is activated.

At instant T1, the CPICH Ec/No drops as described in table 8.4.1.33.4-2.

At instant T2, the RF signal for GSM cell 1 increases, and crosses the threshold for the other system defined for event 3a.

After reception of the MEASUREMENT REPORT message, at instant T3, the RF signal strength for GSM cell 2 increases above the threshold for the other system for event 3a. During that time, the RF signal strength for GSM cell 1 has dropped above the threshold for the other system for event 3a, but remains above threshold-hysteresis for event 3a.

At instant T4, the RF signal strength for GSM cell 1 increases above the threshold for the other system for event 3a+hysteresis.

#### Expected Sequence

| Step | Direction |    | Message                                   | Comment                                                                                                                   |
|------|-----------|----|-------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                           |
| 1    |           |    |                                           | The UE is brought to the CELL_DCH state in the cell 1.                                                                    |
| 2    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | Compressed mode pattern sequence parameters are loaded to UE.                                                             |
| 3    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                           |
| 4    |           | ←  | MEASUREMENT CONTROL                       | SS configures event 3a in the UE. Compressed mode is started.                                                             |
| 5    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T1" in tables 8.4.1.33.4-1 and 8.4.1.33.4-2. |
| 6    |           |    |                                           | SS waits for approximately 10 seconds and verifies that no MEASUREMENT REPORT messages are detected on uplink DCCH.       |
| 7    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T2" in tables 8.4.1.33.4-1 and 8.4.1.33.4-2. |
| 8    |           | →  | MEASUREMENT REPORT                        | After about 640 ms, the UE sends a MEASUREMENT REPORT to SS triggered by event 3a.                                        |
| 9    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T3" in tables 8.4.1.33.4-1 and 8.4.1.33.4-2. |
| 10   |           |    |                                           | SS waits for approximately 10 seconds and verifies that no MEASUREMENT REPORT messages are detected on uplink DCCH.       |
| 11   |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T4" in tables 8.4.1.33.4-1 and 8.4.1.33.4-2. |
| 12   |           |    |                                           | SS waits for approximately 10 seconds and verifies that no MEASUREMENT REPORT messages are detected on uplink DCCH.       |

## Specific Message Content

## PHYSICAL CHANNEL RECONFIGURATION (Step 2)

Use the same message sub-type in Annex A titled "Speech in CS", with the following exceptions:

| Information Element                                          | Value/Remarks                                      |
|--------------------------------------------------------------|----------------------------------------------------|
| Downlink information common for all radio links              |                                                    |
| — DPCH compressed mode info                                  |                                                    |
| — TGPSI                                                      | 1                                                  |
| — TGPS Status Flag                                           | Inactive                                           |
| — TGCFN                                                      | Not present                                        |
| — Transmission gap pattern sequence configuration parameters |                                                    |
| — TGMP                                                       | GSM Carrier RSSI Measurement                       |
| — TGPRC                                                      | Infinity                                           |
| — TGSN                                                       | 4                                                  |
| — TGL1                                                       | 7                                                  |
| — TGL2                                                       | Not present                                        |
| — TGD                                                        | 0                                                  |
| — TGPL1                                                      | 8                                                  |
| — TGPL2                                                      | Not present                                        |
| — RPP                                                        | Mode 1                                             |
| — ITP                                                        | Mode 0                                             |
| CHOICE UL/DL Mode                                            | UL and DL (depends on UE's Measurement capability) |
| — Downlink compressed mode method                            | SF/2                                               |
| — Uplink compressed mode method                              | SF/2                                               |
| — Downlink frame type                                        | A                                                  |
| — DeltaSIR1                                                  | 1.0                                                |
| — DeltaSIRAfter1                                             | 0.5                                                |
| — DeltaSIR2                                                  | Not Present                                        |
| — DeltaSIR2After2                                            | Not Present                                        |
| — N identify abort                                           | Not Present                                        |
| — T Reconfirm abort                                          | Not Present                                        |
| — DPCH compressed mode info                                  |                                                    |
| — TGPSI                                                      | 2                                                  |
| — TGPS Status Flag                                           | Inactive                                           |
| — TGCFN                                                      | Not present                                        |
| — Transmission gap pattern sequence configuration parameters |                                                    |
| — TGMP                                                       | GSM BSIC identification                            |
| — TGPRC                                                      | Infinity                                           |
| — TGSN                                                       | 4                                                  |
| — TGL1                                                       | 7                                                  |
| — TGL2                                                       | Not present                                        |
| — TGD                                                        | 0                                                  |
| — TGPL1                                                      | 8                                                  |
| — TGPL2                                                      | Not present                                        |
| — RPP                                                        | Mode 1                                             |
| — ITP                                                        | Mode 0                                             |
| CHOICE UL/DL Mode                                            | UL and DL (depends on UE's Measurement capability) |
| — Downlink compressed mode method                            | SF/2                                               |
| — Uplink compressed mode method                              | SF/2                                               |
| — Downlink frame type                                        | A                                                  |
| — DeltaSIR1                                                  | 1.0                                                |
| — DeltaSIRAfter1                                             | 0.5                                                |
| — DeltaSIR2                                                  | Not Present                                        |
| — DeltaSIR2After2                                            | Not Present                                        |
| — N identify abort                                           | 12                                                 |
| — T Reconfirm abort                                          | Not Present                                        |
| — TGPSI                                                      | 3                                                  |
| — TGPS Status Flag                                           | Inactive                                           |
| — TGCFN                                                      | Not present                                        |
| — Transmission gap pattern sequence                          |                                                    |

|                                   |                          |
|-----------------------------------|--------------------------|
| configuration parameters          |                          |
| → TGMP                            | GSM-BSIC re-confirmation |
| → TGPRC                           | Infinity                 |
| → TGSN                            | 4                        |
| → TGL1                            | 7                        |
| → TGL2                            | Not present              |
| → TGD                             | 0                        |
| → TGPL1                           | 8                        |
| → TGPL2                           | Not present              |
| → RPP                             | Mode 1                   |
| → ITP                             | Mode 0                   |
| CHOICE UL/DL Mode                 | UL and DL                |
| → Downlink compressed mode method | SF/2                     |
| → Uplink compressed mode method   | SF/2                     |
| → Downlink frame type             | A                        |
| → DeltaSIR1                       | 1.0                      |
| → DeltaSIRAfter1                  | 0.5                      |
| → DeltaSIR2                       | Not Present              |
| → DeltaSIR2After2                 | Not Present              |
| → N identify abort                | Not Present              |
| → T Reconfirm abort               | 5 s                      |

MEASUREMENT CONTROL (Step 4)

|                     |              |
|---------------------|--------------|
| Information Element | Value/Remark |
|---------------------|--------------|

|                                                |                                           |
|------------------------------------------------|-------------------------------------------|
| Measurement Identity                           | 3                                         |
| Measurement Command                            | Setup                                     |
| Measurement Reporting Mode                     |                                           |
| — Measurement Reporting Transfer Mode          | Acknowledged Mode RLC                     |
| — Periodic Reporting / Event Trigger Reporting | Event triggered                           |
| — Mode                                         |                                           |
| Additional measurements list                   | Not Present                               |
| CHOICE measurement type                        |                                           |
| — inter-RAT measurement                        |                                           |
| — inter-RAT measurement object list            |                                           |
| — CHOICE Inter-RAT Cell Removal                | Remove all inter-RAT cells                |
| — Remove all inter-RAT cells                   | (No Data)                                 |
| — New inter-RAT cells (1 to <MaxCellMeas>)     | MaxCellMeas=3                             |
| — inter-RAT cell id                            | 0                                         |
| CHOICE Radio Access Technology                 | GSM                                       |
| — Cell individual offset                       | 0                                         |
| — Cell selection and re-selection info         | Not present                               |
| — BSIC                                         | BSIC1                                     |
| — Band indicator                               | DCS 1800 band used                        |
| — BCCH ARFCN                                   | 1                                         |
| — inter-RAT cell id                            | 1                                         |
| CHOICE Radio Access Technology                 | GSM                                       |
| — Cell individual offset                       | 0                                         |
| — Cell selection and re-selection info         | Not present                               |
| — BSIC                                         | BSIC2                                     |
| — Band indicator                               | DCS 1800 band used                        |
| — BCCH ARFCN                                   | 7                                         |
| — inter-RAT cell id                            | 2                                         |
| CHOICE Radio Access Technology                 | GSM                                       |
| — Cell individual offset                       | 0                                         |
| — Cell selection and re-selection info         | Not present                               |
| — BSIC                                         | BSIC3                                     |
| — Band indicator                               | DCS 1800 band used                        |
| — BCCH ARFCN                                   | 2                                         |
| — Cell for measurement                         | Not present                               |
| — inter-RAT measurement quantity               |                                           |
| — Measurement quantity for UTRAN quality       |                                           |
| — estimate                                     |                                           |
| — Intra-frequency measurement quantity         |                                           |
| — Filter coefficient                           | 0                                         |
| — CHOICE mode                                  | FDD                                       |
| — Measurement quantity                         | Ec/No                                     |
| — CHOICE system                                | GSM                                       |
| — Measurement quantity                         | GSM carrier RSSI                          |
| — Filter coefficient                           | 0                                         |
| — BSIC verification required                   | required                                  |
| — inter-RAT reporting quantity                 |                                           |
| — CHOICE system                                | GSM                                       |
| — Observed time difference to to-GSM           | TRUE                                      |
| — cell reporting indicator                     |                                           |
| — GSM carrier RSSI reporting indicator         | TRUE                                      |
| — CHOICE report criteria                       |                                           |
| — Inter-RAT measurements reporting criteria    |                                           |
| — Parameters required for each event           |                                           |
| (1 to <maxMeasEvent>)                          | <MaxMeasEvent>=1                          |
| — Inter-RAT event identity                     | 3a                                        |
| — Threshold own system                         | -12                                       |
| — W                                            | 0                                         |
| — Threshold other system                       | -80                                       |
| — Hysteresis                                   | 5                                         |
| — Time to Trigger                              | 640 ms                                    |
| — Reporting cell status                        | 2-cells                                   |
| Physical channel information elements          |                                           |
| — DPCH compressed mode status info             |                                           |
| — TGPS reconfiguration CFN                     | Not present                               |
| — Transmission gap pattern sequence (1 to      |                                           |
| <MaxTGPS>)                                     | <MaxTGPS>=3                               |
| — TGPSI                                        | 1                                         |
| — TGPS status flag                             | active                                    |
| — TGCFN                                        | (Current CFN + (252 — TTI/10msec))mod 256 |
| — TGPSI                                        |                                           |

## MEASUREMENT REPORT (Step 8)

| Information Element                   | Value/Remarks                                                                                                                                                          |
|---------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Measurement identity                  | Check to see if set to 3                                                                                                                                               |
| Measured Results                      |                                                                                                                                                                        |
| — CHOICE measurement                  | Check to see if set to "Inter-RAT measured results list"                                                                                                               |
| -Inter-RAT measured result list       |                                                                                                                                                                        |
| -CHOICE system                        | GSM                                                                                                                                                                    |
| -Measured GSM cells                   | Check that measurement results for two GSM cells are included                                                                                                          |
| -GSM carrier RSSI                     | Check that measurement result is reasonable                                                                                                                            |
| CHOICE BSIC                           | Check it is set to verified BSIC                                                                                                                                       |
| -inter-RAT cell id                    | Check that it is set to either 0 or 1.                                                                                                                                 |
| -Observed time difference to GSM cell | Check that the IE is present and that the reported value is reasonable                                                                                                 |
| -GSM carrier RSSI                     | Check that measurement result is reasonable                                                                                                                            |
| CHOICE BSIC                           | Verified BSIC                                                                                                                                                          |
| -inter-RAT cell id                    | Check that is set to 1 or 0 depending on the value of the previous inter-RAT cell id. (The value here shall be the one not chosen for the previous inter-RAT cell id). |
| -Observed time difference to GSM cell | Check that the IE is present and that the reported value is reasonable                                                                                                 |
| Measured results on RACH              | Check that not present                                                                                                                                                 |
| Additional Measured results           | Check that not present                                                                                                                                                 |
| Event results                         | Check that the IE is included                                                                                                                                          |
| -CHOICE event result                  | Check that this is set to inter-RAT measurement event results                                                                                                          |
| -Inter-RAT event identity             | Check that this is set to 3a                                                                                                                                           |
| -Cells to report (1 to <maxCellMeas>) | Check that <maxCellMeas> is set to 1                                                                                                                                   |
| -CHOICE BSIC                          | Check that this is set to verified BSIC                                                                                                                                |
| -Inter-RAT cell id                    | Check that this is set to 0.                                                                                                                                           |

## 8.4.1.33.5 — Test requirement

The UE shall not send any measurement report between instants T1 and T2.

Event 3a shall be triggered in the UE (i.e. the transmission of the MEASUREMENT REPORT) about 0.64 s after instant T2.

Between instants T2 and T3, no MEASUREMENT REPORT message shall be received from the UE (since the hysteresis condition for triggering event 3a is not fulfilled).

No MEASUREMENT REPORT message shall be received from the UE after instant T4 (since the signal strength for cell 1 has not dropped under Threshold for event 3a hysteresis).

## 8.4.1.34 — Measurement Control and Report: Inter-RAT measurement, event 3b

## 8.4.1.34.1 — Definition

## 8.4.1.34.2 — Conformance requirement

1. When this event is ordered by UTRAN in a measurement control message the UE shall send a report when the estimated quality of the other system is below the value of the IE "Threshold other system" and the hysteresis and time to trigger conditions are fulfilled. The corresponding report contains information specific for the other system.

2. If the IE "Inter-RAT cell info list" is received in a MEASUREMENT CONTROL message, the UE shall update the variable CELL\_INFO\_LIST accordingly and in the following order. The UE shall:

- if the IE "Removed Inter-RAT cells" is received, at the position indicated by the IE "Inter-RAT cell id":
  - clear the cell information stored in the variable CELL\_INFO\_LIST; and
  - mark the position "vacant";
- if the IE "New Inter-RAT cells" is received, for each cell, and in the same order as the cells appear in the IE:
  - update the variable CELL\_INFO\_LIST as follows:
    - if the IE "Inter-RAT cell id" is received:
      - store received cell information at this position in the Inter-RAT cell info list in the variable CELL\_INFO\_LIST, possibly overwriting any existing information in this position; and
      - mark the position "occupied";
    - if the IE "Inter-RAT cell id" is not received:
      - store the received cell information at the first vacant position in ascending order in the Inter-RAT cell info list in the variable CELL\_INFO\_LIST; and
  - mark the position as "occupied";

## Reference

3GPP TS 25.331 clause 8.6.7.3, 14.3.1.2

### 8.4.1.34.3 Test Purpose

- 1—To confirm that the UE sends MEASUREMENT REPORT message if event 3b is configured, if the estimated quality of the other system is below a given threshold.
- 2—To confirm that the hysteresis and time to trigger behaviours for event 3b are correctly implemented. To confirm that the UE updates the list of inter-RAT cells it stores according to what is ordered in the MEASUREMENT CONTROL messages received from UTRAN.

### 8.4.1.34.4 Method of test

#### Initial Condition

System simulator: 1 UTRAN FDD cell and 3 GSM cells. The initial configurations of the 4 cells in the SS shall follow the values indicated in the column marked T0. The table is found in "Test procedure".

UE: CELL\_DCH state, state 6-9 as specified in clause 7.4 of TS 34.108.

#### Test procedure

**Table 8.4.1.34.4-1**

| Parameter       | Unit | Cell 1<br>(GSM) |     | Cell 2<br>(GSM) |     | Cell 3<br>(GSM) |     |
|-----------------|------|-----------------|-----|-----------------|-----|-----------------|-----|
|                 |      | T0              | T1  | T0              | T1  | T0              | T1  |
| Test Channel    | #    | GSM Ch.1        |     | GSM Ch.2        |     | GSM Ch.3        |     |
| BCCCH ARFCN     | #    | 1               |     | 7               |     | 2               |     |
| CELL identity   | #    | 0               |     | 1               |     | 2               |     |
| BSIC            | #    | BSIC 1          |     | BSIC 2          |     | BSIC 3          |     |
| RF Signal Level | dBm  | -70             | -90 | -70             | -70 | -90             | -90 |



The two tables above illustrate the downlink power to be applied for the two cells at various instants of the test execution. Column marked "T0" denotes the initial conditions, while column marked "T1" indicates the values to be applied subsequently.

The UE is initially in CELL\_DCH, state 6-9 as specified in clause 7.4 of TS 34.108. UTRA cell 1 is the only cell in the active set of the UE. The SS sends a PHYSICAL CHANNEL RECONFIGURATION message to the UE to configure the compressed mode pattern sequence parameters to the UE. Three compressed mode patterns are configured, according to the message specified below. When the PHYSICAL CHANNEL RECONFIGURATION COMPLETE is received from the UE, the SS sends a MEASUREMENT CONTROL message to the UE, to set up inter-RAT measurements. Event 3b is set up in this message, and compressed mode is activated. The monitored GSM cells at measurement establishment are GSM cells 1 and 2.

At instant T1, the RF signal strength for GSM cell 1 drops as described in table 8.4.1.34.4-1.

When the MEASUREMENT REPORT has been received by the SS, a MEASUREMENT CONTROL message is sent to the UE, to add GSM cell 3 to the monitored GSM cells.

A second MEASUREMENT REPORT triggered by event 3b shall be received shortly after by the SS.

#### Expected Sequence

| Step | Direction |    | Message                                   | Comment                                                                                                             |
|------|-----------|----|-------------------------------------------|---------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                     |
| 1    |           |    |                                           | The UE is brought to the CELL_DCH state in the cell 1.                                                              |
| 2    | ←         |    | PHYSICAL CHANNEL RECONFIGURATION          | Compressed mode pattern sequence parameters are loaded to UE.                                                       |
| 3    | →         |    | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                     |
| 4    | ←         |    | MEASUREMENT CONTROL                       | SS configures event 3b in the UE. Compressed mode is started.                                                       |
| 5    |           |    |                                           | SS waits for approximately 10 seconds and verifies that no MEASUREMENT REPORT messages are detected on uplink DCCH. |
| 6    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T1" in tables 8.4.1.34.4-1.            |
| 7    | →         |    | MEASUREMENT REPORT                        | After about 60 ms, the UE sends a MEASUREMENT REPORT to SS triggered by event 3b.                                   |
| 8    | ←         |    | MEASUREMENT CONTROL                       | SS adds GSM cell 3 to the list of the monitored GSM cells.                                                          |
| 9    | →         |    | MEASUREMENT REPORT                        | After about 60 ms, the UE sends a MEASUREMENT REPORT to SS triggered by event 3b.                                   |

## Specific Message Content

## PHYSICAL CHANNEL RECONFIGURATION (Step 2)

Use the same message sub-type in Annex A titled "Speech in CS", with the following exceptions:

| Information Element                                          | Value/Remarks                                      |
|--------------------------------------------------------------|----------------------------------------------------|
| Downlink information common for all radio links              |                                                    |
| — DPCH compressed mode info                                  |                                                    |
| — TGPSI                                                      | 1                                                  |
| — TGPS Status Flag                                           | Inactive                                           |
| — TGCFN                                                      | Not present                                        |
| — Transmission gap pattern sequence configuration parameters |                                                    |
| — TGMP                                                       | GSM Carrier-RSSI Measurement                       |
| — TGPRC                                                      | Infinity                                           |
| — TGSN                                                       | 4                                                  |
| — TGL1                                                       | 7                                                  |
| — TGL2                                                       | Not present                                        |
| — TGD                                                        | 0                                                  |
| — TGPL1                                                      | 8                                                  |
| — TGPL2                                                      | Not present                                        |
| — RPP                                                        | Mode 1                                             |
| — ITP                                                        | Mode 0                                             |
| CHOICE UL/DL Mode                                            | UL and DL (depends on UE's Measurement capability) |
| — Downlink compressed mode method                            | SF/2                                               |
| — Uplink compressed mode method                              | SF/2                                               |
| — Downlink frame type                                        | A                                                  |
| — DeltaSIR1                                                  | 1.0                                                |
| — DeltaSIRAfter1                                             | 0.5                                                |
| — DeltaSIR2                                                  | Not Present                                        |
| — DeltaSIR2After2                                            | Not Present                                        |
| — N identify abort                                           | Not Present                                        |
| — T Reconfirm abort                                          | Not Present                                        |
| — DPCH compressed mode info                                  |                                                    |
| — TGPSI                                                      | 2                                                  |
| — TGPS Status Flag                                           | Inactive                                           |
| — TGCFN                                                      | Not present                                        |
| — Transmission gap pattern sequence configuration parameters |                                                    |
| — TGMP                                                       | GSM-BISIC identification                           |
| — TGPRC                                                      | Infinity                                           |
| — TGSN                                                       | 4                                                  |
| — TGL1                                                       | 7                                                  |
| — TGL2                                                       | Not present                                        |
| — TGD                                                        | 0                                                  |
| — TGPL1                                                      | 8                                                  |
| — TGPL2                                                      | Not present                                        |
| — RPP                                                        | Mode 1                                             |
| — ITP                                                        | Mode 0                                             |
| CHOICE UL/DL Mode                                            | UL and DL (depends on UE's Measurement capability) |
| — Downlink compressed mode method                            | SF/2                                               |
| — Uplink compressed mode method                              | SF/2                                               |
| — Downlink frame type                                        | A                                                  |
| — DeltaSIR1                                                  | 1.0                                                |
| — DeltaSIRAfter1                                             | 0.5                                                |
| — DeltaSIR2                                                  | Not Present                                        |
| — DeltaSIR2After2                                            | Not Present                                        |
| — N identify abort                                           | 12                                                 |
| — T Reconfirm abort                                          | Not Present                                        |
| — TGPSI                                                      | 3                                                  |
| — TGPS Status Flag                                           | Inactive                                           |
| — TGCFN                                                      | Not present                                        |
| — Transmission gap pattern sequence                          |                                                    |

|                                   |                                                   |
|-----------------------------------|---------------------------------------------------|
| configuration parameters          |                                                   |
| → TGMP                            | GSM-BSIC re-confirmation                          |
| → TGPRC                           | Infinity                                          |
| → TGSN                            | 4                                                 |
| → TGL1                            | 7                                                 |
| → TGL2                            | Not present                                       |
| → TGD                             | 0                                                 |
| → TGPL1                           | 8                                                 |
| → TGPL2                           | Not present                                       |
| → RPP                             | Mode 1                                            |
| → ITP                             | Mode 0                                            |
| CHOICE UL/DL Mode                 | UL and DL(depends on UE's Measurement capability) |
| → Downlink compressed mode method | SF/2                                              |
| → Uplink compressed mode method   | SF/2                                              |
| → Downlink frame type             | A                                                 |
| → DeltaSIR1                       | 1.0                                               |
| → DeltaSIRAfter1                  | 0.5                                               |
| → DeltaSIR2                       | Not Present                                       |
| → DeltaSIR2After2                 | Not Present                                       |
| → N identify abort                | Not Present                                       |
| → T Reconfirm abort               | 5 s                                               |

MEASUREMENT CONTROL (Step 4)

| Information Element | Value/Remark |
|---------------------|--------------|
|---------------------|--------------|

|                                                            |                                           |
|------------------------------------------------------------|-------------------------------------------|
| Measurement Identity                                       | 3                                         |
| Measurement Command                                        | Setup                                     |
| Measurement Reporting Mode                                 |                                           |
| — Measurement Reporting Transfer Mode                      | Acknowledged Mode RLC                     |
| — Periodic Reporting / Event Trigger Reporting Mode        | Event triggered                           |
| Additional measurements list                               | Not Present                               |
| CHOICE measurement type                                    |                                           |
| — inter-RAT measurement                                    |                                           |
| — inter-RAT measurement object list                        |                                           |
| — CHOICE Inter-RAT Cell Removal                            | Remove all inter-RAT cells                |
| — Remove all inter-RAT cells                               | (No Data)                                 |
| — New inter-RAT cells (1 to <MaxCellMeas>)                 | MaxCellMeas=2                             |
| — inter-RAT cell id                                        | 0                                         |
| CHOICE Radio Access Technology                             | GSM                                       |
| — Cell individual offset                                   | 0                                         |
| — Cell selection and re-selection info                     | Not present                               |
| — BSIC                                                     | BSIC1                                     |
| — Band indicator                                           | DCS 1800 band used                        |
| — BCCH ARFCN                                               | 1                                         |
| — inter-RAT cell id                                        | 1                                         |
| CHOICE Radio Access Technology                             | GSM                                       |
| — Cell individual offset                                   | 0                                         |
| — Cell selection and re-selection info                     | Not present                               |
| — BSIC                                                     | BSIC2                                     |
| — Band indicator                                           | DCS 1800 band used                        |
| — BCCH ARFCN                                               | 7                                         |
| — Cell for measurement                                     | Not present                               |
| — inter-RAT measurement quantity                           |                                           |
| — Measurement quantity for UTRAN quality estimate          | Not included                              |
| CHOICE system                                              | GSM                                       |
| — Measurement quantity                                     | GSM carrier RSSI                          |
| — Filter coefficient                                       | 0                                         |
| — BSIC verification required                               | required                                  |
| — inter-RAT reporting quantity                             |                                           |
| — CHOICE system                                            | GSM                                       |
| — Observed time difference to to GSM                       | FALSE                                     |
| — cell reporting indicator                                 |                                           |
| — GSM carrier RSSI reporting indicator                     | TRUE                                      |
| CHOICE report criteria                                     |                                           |
| — Inter-RAT measurements reporting criteria                |                                           |
| — Parameters required for each event (1 to <maxMeasEvent>) | <MaxMeasEvent>=1                          |
| — Inter-RAT event identity                                 | 3b                                        |
| — Threshold own system                                     | Not included                              |
| — W                                                        | Not included                              |
| — Threshold other system                                   | -80                                       |
| — Hysteresis                                               | 2                                         |
| — Time to Trigger                                          | 60 ms                                     |
| — Reporting cell status                                    | 3 cells                                   |
| Physical channel information elements                      |                                           |
| — DPCH compressed mode status info                         |                                           |
| — TGPS reconfiguration CFN                                 | Not present                               |
| — Transmission gap pattern sequence (1 to <MaxTGPS>)       | <MaxTGPS>=3                               |
| — TGPSI                                                    | 1                                         |
| — TGPS status flag                                         | active                                    |
| — TGCFN                                                    | (Current CFN + (252 — TTI/10msec))mod 256 |
| — TGPSI                                                    | 2                                         |
| — TGPS status flag                                         | active                                    |
| — TGCFN                                                    | (Current CFN + (254 — TTI/10msec))mod 256 |
| — TGPSI                                                    | 3                                         |
| — TGPS status flag                                         | active                                    |
| — TGCFN                                                    | (Current CFN + (256 — TTI/10msec))mod 256 |

## MEASUREMENT REPORT (Step 7)

| Information Element                   | Value/Remarks                                                                                                      |
|---------------------------------------|--------------------------------------------------------------------------------------------------------------------|
| Measurement identity                  | Check to see if set to 3                                                                                           |
| Measured Results                      |                                                                                                                    |
| — CHOICE measurement                  | Check to see if set to "Inter-RAT-measured results list"                                                           |
| -Inter-RAT-measured result list       |                                                                                                                    |
| -CHOICE system                        | GSM                                                                                                                |
| -Measured GSM cells                   | Check that measurement results for two GSM cells are included                                                      |
| -GSM carrier RSSI                     | Check that measurement result is reasonable                                                                        |
| CHOICE BSIC                           | Check it is set to verified BSIC                                                                                   |
| -inter-RAT cell id                    | Check that it is set to either 0 or 1                                                                              |
| -Observed time difference to GSM cell | Check that the IE is not included                                                                                  |
| -GSM carrier RSSI                     | Check that measurement result is reasonable                                                                        |
| CHOICE BSIC                           | Verified BSIC                                                                                                      |
| -inter-RAT cell id                    | Check that is set to 1 if the previous inter-RAT cell id was set to 0 or to 0 if the previous cell id was set to 1 |
| -Observed time difference to GSM cell | Check that the IE is not present                                                                                   |
| Measured results on RACH              | Check that not present                                                                                             |
| Additional Measured results           | Check that not present                                                                                             |
| Event results                         | Check that the IE is included                                                                                      |
| -CHOICE event result                  | Check that this is set to inter-RAT measurement event results                                                      |
| -Inter-RAT event identity             | Check that this is set to 3b                                                                                       |
| -Cells to report (1 to <maxCellMeas>) | Check that <maxCellMeas> is set to 1                                                                               |
| -CHOICE BSIC                          | Check that this is set to verified BSIC                                                                            |
| -Inter-RAT cell id                    | Check that this is set to 0                                                                                        |

## MEASUREMENT CONTROL (Step 8)

| Information Element                            | Value/Remark              |
|------------------------------------------------|---------------------------|
| Measurement Identity                           | 3                         |
| Measurement Command                            | Modify                    |
| Measurement Reporting Mode                     |                           |
| — Measurement Reporting Transfer Mode          | Not present               |
| - Periodic Reporting / Event Trigger Reporting | Not present               |
| - Mode                                         |                           |
| Additional measurements list                   | Not Present               |
| CHOICE measurement type                        |                           |
| - inter-RAT measurement                        |                           |
| — inter-RAT measurement object list            |                           |
| — CHOICE Inter-RAT Cell Removal                | Remove no inter-RAT cells |
| — New inter-RAT cells (1 to <MaxCellMeas>)     | MaxCellMeas=1             |
| - inter-RAT cell id                            | Not present               |
| CHOICE Radio Access Technology                 | GSM                       |
| - Cell individual offset                       | 0                         |
| - Cell selection and re-selection info         | Not present               |
| — BSIC                                         | BSIC3                     |
| - Band indicator                               | DCS 1800 band used        |
| - BCCH ARFCN                                   | 2                         |
| - Cell for measurement                         | Not present               |
| - inter-RAT measurement quantity               | Not present               |
| — CHOICE report criteria                       |                           |
| - Inter-RAT measurements reporting criteria    |                           |
| - Parameters required for each event           |                           |
| (1 to <maxMeasEvent>)                          | <MaxMeasEvent>=1          |
| - Inter-RAT event identity                     | 3b                        |
| - Threshold own system                         | Not present               |
| - W                                            | Not present               |
| - Threshold other system                       | -80                       |
| - Hysteresis                                   | 2                         |
| - Time to Trigger                              | 60 ms                     |
| - Reporting cell status                        | Not present               |
| Physical channel information elements          | Not present               |

## MEASUREMENT REPORT (Step 9)

| Information Element                   | Value/Remarks                                                                                                        |
|---------------------------------------|----------------------------------------------------------------------------------------------------------------------|
| Measurement identity                  | Check to see if set to 3                                                                                             |
| Measured Results                      |                                                                                                                      |
| — CHOICE measurement                  | Check to see if set to "Inter-RAT-measured results-list"                                                             |
| -Inter-RAT-measured-result-list       |                                                                                                                      |
| -CHOICE system                        | GSM                                                                                                                  |
| -Measured-GSM-cells                   | Check that measurement results for three GSM-cells are included                                                      |
| -GSM-carrier-RSSI                     | Check that measurement result is reasonable                                                                          |
| CHOICE-BSIC                           | Check it is set to verified-BSIC                                                                                     |
| -inter-RAT-cell-id                    | Check that it is set to either 0, 1 or 2                                                                             |
| -Observed-time-difference-to-GSM-cell | Check that the IE is not included                                                                                    |
| -GSM-carrier-RSSI                     | Check that measurement result is reasonable                                                                          |
| CHOICE-BSIC                           | Verified-BSIC                                                                                                        |
| -inter-RAT-cell-id                    | Check that is set to 0, 1 or 2 and that this inter-RAT-cell-id is different from the previous inter-RAT-cell-id.     |
| -Observed-time-difference-to-GSM-cell | Check that the IE is not present                                                                                     |
| -GSM-carrier-RSSI                     | Check that measurement result is reasonable                                                                          |
| CHOICE-BSIC                           | Verified-BSIC                                                                                                        |
| -inter-RAT-cell-id                    | Check that is set to 0, 1 or 2 and that this inter-RAT-cell-id is different from the two previous inter-RAT-cell-id. |
| -Observed-time-difference-to-GSM-cell | Check that the IE is not present                                                                                     |
| Measured results on RACH              | Check that not present                                                                                               |
| Additional Measured results           | Check that not present                                                                                               |
| Event results                         | Check that the IE is included                                                                                        |
| -CHOICE event result                  | Check that this is set to inter-RAT measurement event results                                                        |
| -Inter-RAT event identity             | Check that this is set to 3b                                                                                         |
| -Cells to report (1 to <maxCellMeas>) | Check that <maxCellMeas> is set to 1                                                                                 |
| -CHOICE-BSIC                          | Check that this is set to verified-BSIC                                                                              |
| -Inter-RAT-cell-id                    | Check that this is set to 2.                                                                                         |

## 8.4.1.34.5 — Test requirement

Between instants T0 and T1, the UE shall not send any MEASUREMENT REPORT message to the SS.

Event 3b shall be triggered in the UE (i.e. the transmission of the first MEASUREMENT REPORT message shall begin) about 60 ms after instant T1.

About 60 ms after the reception by the UE of the second MEASUREMENT CONTROL message, the UE shall begin to transmit the second MEASUREMENT REPORT message (since the signal strength for GSM cell 3 is below the threshold for triggering event 3b).

## 8.4.1.35 — Measurement Control and Report: Inter-RAT measurement, event 3c

## 8.4.1.35.1 — Definition

## 8.4.1.35.2 — Conformance requirement

When this event is ordered by UTRAN in a measurement control message the UE shall send a report when the estimated quality of the other system is above the value of the IE "Threshold other system" and the hysteresis and time to trigger conditions are fulfilled. The corresponding report contains information specific for the other system. For the measurement, which triggered the MEASUREMENT REPORT message, the UE shall set the IE "measured results" to include measurements according to the IE "reporting quantity" of that measurement.



## Reference

3GPP TS 25.331 clauses 14.3.1.3, 8.4.2.2.

### 8.4.1.35.3 Test Purpose

- 1—To confirm that the UE sends MEASUREMENT REPORT message if event 3c is configured, and if the quality of the other system becomes better than the given threshold for event 3c.
- 2—To confirm that no other UE MEASUREMENT REPORT message is sent by the UE for a cell that has already triggered event 3c as long as the hysteresis condition for triggering once again event 3c has not been fulfilled.

### 8.4.1.35.4 Method of test

#### Initial Condition

System simulator: 1 UTRAN FDD cell and 2 GSM cells. The initial configurations of the 4 cells in the SS shall follow the values indicated in the column marked T0. The table is found in "Test procedure".

UE: CELL\_DCH state, state 6-9 as specified in clause 7.4 of TS 34.108.

#### Test procedure

**Table 8.4.1.35.4-1**

| Parameter       | Unit | Cell 1 (GSM) |     |     |     | Cell 2 (GSM) |     |     |     |
|-----------------|------|--------------|-----|-----|-----|--------------|-----|-----|-----|
|                 |      | T0           | T1  | T2  | T3  | T0           | T1  | T2  | T3  |
| Test Channel    | #    | GSM-Ch.1     |     |     |     | GSM-Ch.2     |     |     |     |
| BCCH ARFCN      | #    | 1            |     |     |     | 7            |     |     |     |
| CELL identity   | #    | 0            |     |     |     | 1            |     |     |     |
| BSIC            | #    | BSIC 1       |     |     |     | BSIC 2       |     |     |     |
| RF Signal Level | dBm  | -90          | -80 | -90 | -80 | -80          | -80 | -80 | -80 |

The two tables above illustrate the downlink power to be applied for the two cells at various instants of the test execution. Column marked "T0" denotes the initial conditions, while column marked "T1", "T2" and "T3" indicate the values to be applied subsequently.

The UE is initially in CELL\_DCH, state 6-9 as specified in clause 7.4 of TS 34.108. UTRA cell 1 is the only cell in the active set of the UE. The SS sends a PHYSICAL CHANNEL RECONFIGURATION message to the UE to configure the compressed mode pattern sequence parameters to the UE. Three compressed mode patterns are configured, according to the message specified below. When the PHYSICAL CHANNEL RECONFIGURATION COMPLETE is received from the UE, the SS sends a MEASUREMENT CONTROL message to the UE, to set up inter-RAT measurements. Event 3c is set up in this message, and compressed mode is activated.

At instant T1, the RF signal strength for GSM cell 1 increases as described in table 8.4.1.35.4-1.

At instant T2, the RF signal strength for GSM cell 2 drops as described in table 8.4.1.35.4-1, and at instant T3, it increases again to its previous level.

## Expected Sequence

| Step | Direction |    | Message                                   | Comment                                                                                                             |
|------|-----------|----|-------------------------------------------|---------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                     |
| 1    |           |    |                                           | The UE is brought to the CELL_DCH state in the cell 1.                                                              |
| 2    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | Compressed mode pattern sequence parameters are loaded to UE.                                                       |
| 3    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                     |
| 4    |           | ←  | MEASUREMENT CONTROL                       | SS configures event 3c in the UE. Compressed mode is started.                                                       |
| 5    |           |    |                                           | SS waits for approximately 10 seconds and verifies that no MEASUREMENT REPORT messages are detected on uplink DCCH. |
| 6    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T1" in tables 8.4.1.35.4-1.            |
| 7    |           | →  | MEASUREMENT REPORT                        | After about 100 ms, the UE sends a MEASUREMENT REPORT to SS triggered by event 3b.                                  |
| 8    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T2" in tables 8.4.1.35.4-1.            |
| 9    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T3" in tables xxxx and xxxx.           |
| 10   |           |    |                                           | SS waits for approximately 10 seconds and verifies that no MEASUREMENT REPORT messages are detected on uplink DCCH. |

## Specific Message Content

## PHYSICAL CHANNEL RECONFIGURATION (Step 2)

Use the same message sub-type in Annex A titled "Speech in CS", with the following exceptions:

| Information Element                                          | Value/Remarks                                      |
|--------------------------------------------------------------|----------------------------------------------------|
| Downlink information common for all radio links              |                                                    |
| — DPCH compressed mode info                                  |                                                    |
| — TGPSI                                                      | 1                                                  |
| — TGPS Status Flag                                           | Inactive                                           |
| — TGCFN                                                      | Not present                                        |
| — Transmission gap pattern sequence configuration parameters |                                                    |
| — TGMP                                                       | GSM Carrier RSSI Measurement                       |
| — TGPRC                                                      | Infinity                                           |
| — TGSN                                                       | 4                                                  |
| — TGL1                                                       | 7                                                  |
| — TGL2                                                       | Not present                                        |
| — TGD                                                        | 0                                                  |
| — TGPL1                                                      | 8                                                  |
| — TGPL2                                                      | Not present                                        |
| — RPP                                                        | Mode 1                                             |
| — ITP                                                        | Mode 0                                             |
| CHOICE UL/DL Mode                                            | UL and DL (depends on UE's Measurement capability) |
| — Downlink compressed mode method                            | SF/2                                               |
| — Uplink compressed mode method                              | SF/2                                               |
| — Downlink frame type                                        | A                                                  |
| — DeltaSIR1                                                  | 1.0                                                |
| — DeltaSIRAfter1                                             | 0.5                                                |
| — DeltaSIR2                                                  | Not Present                                        |
| — DeltaSIR2After2                                            | Not Present                                        |
| — N identify abort                                           | Not Present                                        |
| — T Reconfirm abort                                          | Not Present                                        |
| — DPCH compressed mode info                                  |                                                    |
| — TGPSI                                                      | 2                                                  |
| — TGPS Status Flag                                           | Inactive                                           |
| — TGCFN                                                      | Not present                                        |
| — Transmission gap pattern sequence configuration parameters |                                                    |
| — TGMP                                                       | GSM BSIC identification                            |
| — TGPRC                                                      | Infinity                                           |
| — TGSN                                                       | 4                                                  |
| — TGL1                                                       | 7                                                  |
| — TGL2                                                       | Not present                                        |
| — TGD                                                        | 0                                                  |
| — TGPL1                                                      | 8                                                  |
| — TGPL2                                                      | Not present                                        |
| — RPP                                                        | Mode 1                                             |
| — ITP                                                        | Mode 0                                             |
| CHOICE UL/DL Mode                                            | UL and DL (depends on UE's Measurement capability) |
| — Downlink compressed mode method                            | SF/2                                               |
| — Uplink compressed mode method                              | SF/2                                               |
| — Downlink frame type                                        | A                                                  |
| — DeltaSIR1                                                  | 1.0                                                |
| — DeltaSIRAfter1                                             | 0.5                                                |
| — DeltaSIR2                                                  | Not Present                                        |
| — DeltaSIR2After2                                            | Not Present                                        |
| — N identify abort                                           | 12                                                 |
| — T Reconfirm abort                                          | Not Present                                        |
| — TGPSI                                                      | 3                                                  |
| — TGPS Status Flag                                           | Inactive                                           |
| — TGCFN                                                      | Not present                                        |
| — Transmission gap pattern sequence                          |                                                    |

|                                   |                                                   |
|-----------------------------------|---------------------------------------------------|
| configuration parameters          |                                                   |
| → TGMP                            | GSM-BSIC re-confirmation                          |
| → TGPRC                           | Infinity                                          |
| → TGSN                            | 4                                                 |
| → TGL1                            | 7                                                 |
| → TGL2                            | Not present                                       |
| → TGD                             | 0                                                 |
| → TGPL1                           | 8                                                 |
| → TGPL2                           | Not present                                       |
| → RPP                             | Mode 1                                            |
| → ITP                             | Mode 0                                            |
| CHOICE UL/DL Mode                 | UL and DL(depends on UE's Measurement capability) |
| → Downlink compressed mode method | SF/2                                              |
| → Uplink compressed mode method   | SF/2                                              |
| → Downlink frame type             | A                                                 |
| → DeltaSIR1                       | 1.0                                               |
| → DeltaSIRAfter1                  | 0.5                                               |
| → DeltaSIR2                       | Not Present                                       |
| → DeltaSIR2After2                 | Not Present                                       |
| → N identify abort                | Not Present                                       |
| → T Reconfirm abort               | 5-s                                               |

MEASUREMENT CONTROL (Step 4)

|                     |              |
|---------------------|--------------|
| Information Element | Value/Remark |
|---------------------|--------------|

|                                                            |                                           |
|------------------------------------------------------------|-------------------------------------------|
| Measurement Identity                                       | 3                                         |
| Measurement Command                                        | Setup                                     |
| Measurement Reporting Mode                                 |                                           |
| — Measurement Reporting Transfer Mode                      | Acknowledged Mode RLC                     |
| — Periodic Reporting / Event Trigger Reporting Mode        | Event triggered                           |
| Additional measurements list                               | Not Present                               |
| CHOICE measurement type                                    |                                           |
| — inter-RAT measurement                                    |                                           |
| — inter-RAT measurement object list                        |                                           |
| — CHOICE Inter-RAT Cell Removal                            | Remove all inter-RAT cells                |
| — Remove all inter-RAT cells                               | (No Data)                                 |
| — New inter-RAT cells (1 to <MaxCellMeas>)                 | MaxCellMeas=2                             |
| — inter-RAT cell id                                        | 0                                         |
| CHOICE Radio Access Technology                             | GSM                                       |
| — Cell individual offset                                   | 10                                        |
| — Cell selection and re-selection info                     | Not present                               |
| — BSIC                                                     | BSIC1                                     |
| — Band indicator                                           | DCS 1800 band used                        |
| — BCCH ARFCN                                               | 1                                         |
| — inter-RAT cell id                                        | 1                                         |
| CHOICE Radio Access Technology                             | GSM                                       |
| — Cell individual offset                                   | 0                                         |
| — Cell selection and re-selection info                     | Not present                               |
| — BSIC                                                     | BSIC2                                     |
| — Band indicator                                           | DCS 1800 band used                        |
| — BCCH ARFCN                                               | 7                                         |
| — Cell for measurement                                     | Not present                               |
| — inter-RAT measurement quantity                           |                                           |
| — Measurement quantity for UTRAN quality estimate          | Not included                              |
| CHOICE system                                              | GSM                                       |
| — Measurement quantity                                     | GSM carrier RSSI                          |
| — Filter coefficient                                       | 0                                         |
| — BSIC verification required                               | required                                  |
| — inter-RAT reporting quantity                             |                                           |
| — CHOICE system                                            | GSM                                       |
| — Observed time difference to to GSM                       | FALSE                                     |
| — cell reporting indicator                                 |                                           |
| — GSM carrier RSSI reporting indicator                     | TRUE                                      |
| CHOICE report criteria                                     |                                           |
| — Inter-RAT measurements reporting criteria                |                                           |
| — Parameters required for each event (1 to <maxMeasEvent>) | <MaxMeasEvent>=1                          |
| — Inter-RAT event identity                                 | 3c                                        |
| — Threshold own system                                     | Not included                              |
| — W                                                        | Not included                              |
| — Threshold other system                                   | -80                                       |
| — Hysteresis                                               | 5                                         |
| — Time to Trigger                                          | 100 ms                                    |
| — Reporting cell status                                    | 2-cells                                   |
| Physical channel information elements                      |                                           |
| — DPCH compressed mode status info                         |                                           |
| — TGPS reconfiguration CFN                                 | Not present                               |
| — Transmission gap pattern sequence (1 to <MaxTGPS>)       | <MaxTGPS>=3                               |
| — TGPSI                                                    | 1                                         |
| — TGPS status flag                                         | active                                    |
| — TGCFN                                                    | (Current CFN + (252 — TTI/10msec))mod 256 |
| — TGPSI                                                    | 2                                         |
| — TGPS status flag                                         | active                                    |
| — TGCFN                                                    | (Current CFN + (254 — TTI/10msec))mod 256 |
| — TGPSI                                                    | 3                                         |
| — TGPS status flag                                         | active                                    |
| — TGCFN                                                    | (Current CFN + (256 — TTI/10msec))mod 256 |

## MEASUREMENT REPORT (Step 7)

| Information Element                   | Value/Remarks                                                                                                      |
|---------------------------------------|--------------------------------------------------------------------------------------------------------------------|
| Measurement identity                  | Check to see if set to 3                                                                                           |
| Measured Results                      |                                                                                                                    |
| — CHOICE measurement                  | Check to see if set to "Inter-RAT-measured results-list"                                                           |
| -Inter-RAT-measured-result-list       |                                                                                                                    |
| -CHOICE system                        | GSM                                                                                                                |
| -Measured-GSM-cells                   | Check that measurement results for two GSM cells are included                                                      |
| -GSM-carrier-RSSI                     | Check that measurement result is reasonable                                                                        |
| CHOICE-BSIC                           | Check it is set to verified-BSIC                                                                                   |
| -inter-RAT-cell-id                    | Check that it is set to either 0 or 1                                                                              |
| -Observed-time-difference-to-GSM-cell | Check that the IE is not included                                                                                  |
| -GSM-carrier-RSSI                     | Check that measurement result is reasonable                                                                        |
| CHOICE-BSIC                           | Verified-BSIC                                                                                                      |
| -inter-RAT-cell-id                    | Check that is set to 1 if the previous inter-RAT cell id was set to 0 or to 0 if the previous cell id was set to 1 |
| -Observed-time-difference-to-GSM-cell | Check that the IE is not present                                                                                   |
| Measured results on RACH              | Check that not present                                                                                             |
| Additional Measured results           | Check that not present                                                                                             |
| Event results                         | Check that the IE is included                                                                                      |
| -CHOICE event result                  | Check that this is set to inter-RAT measurement event results                                                      |
| -Inter-RAT event identity             | Check that this is set to 3c                                                                                       |
| -Cells to report (1 to <maxCellMeas>) | Check that <maxCellMeas> is set to 1                                                                               |
| -CHOICE BSIC                          | Check that this is set to verified-BSIC                                                                            |
| -Inter-RAT-cell-id                    | Check that this is set to 0                                                                                        |

## 8.4.1.35.4 — Test requirement

About 100 ms after instant T1, since the cell individual offset for GSM cell 1 is +10 dB, event 3c shall be triggered in the UE, i.e the UE shall begin to transmit a MEASUREMENT REPORT to the SS. Note that GSM cell 2 has not triggered event 3c even though the RF signal strength for GSM cell 2 is the same as for cell 1, because the cell individual offset for GSM cell 2 is 0 dB.

After instant T2, no MEASUREMENT REPORT shall be received from the UE, since GSM cell 1 has already triggered event 3c, and since the RF signal strength has not dropped enough for it to trigger the event once again.

## 8.4.1.36 — Measurement Control and Report: Inter-RAT measurement, event 3d

## 8.4.1.36.1 — Definition

## 8.4.1.36.2 — Conformance requirement

If any of the quality estimates for the cells in the other system becomes better than the quality estimate for the currently best cell in the other system, and event 3d has been ordered by UTRAN then this event shall trigger a report to be sent from the UE when the hysteresis and time to trigger conditions is fulfilled. The corresponding report contains (at least) information the best cell in the other system.

## Reference

3GPP TS 25.331 clause 14.3.1.4.

## 8.4.1.36.3 — Test Purpose

To confirm that the UE sends MEASUREMENT REPORT message if event 3d is configured, and if the best cell changes in the other system. To confirm that no other UE MEASUREMENT REPORT message is sent by the UE for a

cell that has already triggered event 3d as long as the hysteresis condition for triggering once again event 3d has not been fulfilled.

#### 8.4.1.36.4 Method of test

##### Initial Condition

System simulator: 1 UTRAN FDD cell and 2 GSM cells. The initial configurations of the 4 cells in the SS shall follow the values indicated in the column marked T0. The table is found in "Test procedure".

UE: CELL\_DCH state, state 6-9 as specified in clause 7.4 of TS 34.108.

##### Test procedure

**Table 8.4.1.36.4-1**

| Parameter       | Unit | Cell 1<br>(GSM) |     | Cell 2<br>(GSM) |     |
|-----------------|------|-----------------|-----|-----------------|-----|
|                 |      | T0              | T2  | T0              | T1  |
| Test Channel    | #    | GSM Ch.1        |     | GSM Ch.2        |     |
| BCCH ARFCN      | #    | 1               |     | 7               |     |
| CELL identity   | #    | 0               |     | 1               |     |
| BSIC            | #    | BSIC 1          |     | BSIC 2          |     |
| RF Signal Level | dBm  | -70             | -90 | -90             | -70 |

The two tables above illustrate the downlink power to be applied for the two cells at various instants of the test execution. Column marked "T0" denotes the initial conditions, while column marked "T1", "T2" and "T3" indicate the values to be applied subsequently.

The UE is initially in CELL\_DCH, state 6-9 as specified in clause 7.4 of TS 34.108. UTRA cell 1 is the only cell in the active set of the UE. The SS sends a PHYSICAL CHANNEL RECONFIGURATION message to the UE to configure the compressed mode pattern sequence parameters to the UE. Three compressed mode patterns are configured, according to the message specified below. When the PHYSICAL CHANNEL RECONFIGURATION COMPLETE is received from the UE, the SS sends a MEASUREMENT CONTROL message to the UE, to set up inter-RAT measurements. Event 3d is set up in this message, and compressed mode is activated.

At instant T1, the RF signal strength for GSM cell 1 increases while the RF signal strength for GSM cell 2 decreases as described in table 8.4.1.36.4-1.

A MEASUREMENT CONTROL is then sent to the UE that releases the inter-RAT measurement, and deactivates compressed mode.

## Expected Sequence

| Step | Direction |    | Message                                   | Comment                                                                                                                        |
|------|-----------|----|-------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                |
| 1    |           |    |                                           | The UE is brought to the CELL_DCH state in the cell 1.                                                                         |
| 2    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | Compressed mode pattern sequence parameters are loaded to UE.                                                                  |
| 3    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                                |
| 4    |           | ←  | MEASUREMENT CONTROL                       | SS configures event 3d in the UE. Compressed mode is started.                                                                  |
| 5    |           | →  | MEASUREMENT REPORT                        | The UE sends a MEASUREMENT REPORT to UTRAN indicating which is the best GSM cells just after the initiation of the measurement |
| 6    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T1" in tables 8.4.1.36.4-1.                       |
| 7    |           | →  | MEASUREMENT REPORT                        | After about 200 ms, the UE sends a MEASUREMENT REPORT to SS triggered by event 3b.                                             |
| 8    |           | ←  | MEASUREMENT CONTROL                       | SS releases the inter-RAT measurements, and deactivates compressed mode.                                                       |
| 9    |           |    |                                           | SS checks that the UE has deactivated compressed mode.                                                                         |



## Specific Message Content

## PHYSICAL CHANNEL RECONFIGURATION (Step 2)

Use the same message sub-type in Annex A titled "Speech in CS", with the following exceptions:

| Information Element                                          | Value/Remarks                                      |
|--------------------------------------------------------------|----------------------------------------------------|
| Downlink information common for all radio links              |                                                    |
| - DPCH compressed mode info                                  |                                                    |
| - TGPSI                                                      | 1                                                  |
| - TGPS Status Flag                                           | Inactive                                           |
| - TGCFN                                                      | Not present                                        |
| - Transmission gap pattern sequence configuration parameters |                                                    |
| - TGMP                                                       | GSM Carrier RSSI Measurement                       |
| - TGPRC                                                      | Infinity                                           |
| - TGSN                                                       | 4                                                  |
| - TGL1                                                       | 7                                                  |
| - TGL2                                                       | Not present                                        |
| - TGD                                                        | 0                                                  |
| - TGPL1                                                      | 8                                                  |
| - TGPL2                                                      | Not present                                        |
| - RPP                                                        | Mode 1                                             |
| - ITP                                                        | Mode 0                                             |
| - CHOICE UL/DL Mode                                          | UL and DL (depends on UE's Measurement capability) |
| - Downlink compressed mode method                            | SF/2                                               |
| - Uplink compressed mode method                              | SF/2                                               |
| - Downlink frame type                                        | A                                                  |
| - DeltaSIR1                                                  | 1.0                                                |
| - DeltaSIRAfter1                                             | 0.5                                                |
| - DeltaSIR2                                                  | Not Present                                        |
| - DeltaSIR2After2                                            | Not Present                                        |
| - N identify abort                                           | Not Present                                        |
| - T Reconfirm abort                                          | Not Present                                        |
| - DPCH compressed mode info                                  |                                                    |
| - TGPSI                                                      | 2                                                  |
| - TGPS Status Flag                                           | Inactive                                           |
| - TGCFN                                                      | Not present                                        |
| - Transmission gap pattern sequence configuration parameters |                                                    |
| - TGMP                                                       | GSM BSIC identification                            |
| - TGPRC                                                      | Infinity                                           |
| - TGSN                                                       | 4                                                  |
| - TGL1                                                       | 7                                                  |
| - TGL2                                                       | Not present                                        |
| - TGD                                                        | 0                                                  |
| - TGPL1                                                      | 8                                                  |
| - TGPL2                                                      | Not present                                        |
| - RPP                                                        | Mode 1                                             |
| - ITP                                                        | Mode 0                                             |
| - CHOICE UL/DL Mode                                          | UL and DL (depends on UE's Measurement capability) |
| - Downlink compressed mode method                            | SF/2                                               |
| - Uplink compressed mode method                              | SF/2                                               |
| - Downlink frame type                                        | A                                                  |
| - DeltaSIR1                                                  | 1.0                                                |
| - DeltaSIRAfter1                                             | 0.5                                                |
| - DeltaSIR2                                                  | Not Present                                        |
| - DeltaSIR2After2                                            | Not Present                                        |
| - N identify abort                                           | 12                                                 |
| - T Reconfirm abort                                          | Not Present                                        |
| - TGPSI                                                      | 3                                                  |
| - TGPS Status Flag                                           | Inactive                                           |
| - TGCFN                                                      | Not present                                        |
| - Transmission gap pattern sequence                          |                                                    |

|                                   |                                                   |
|-----------------------------------|---------------------------------------------------|
| configuration parameters          |                                                   |
| → TGMP                            | GSM-BSIC re-confirmation                          |
| → TGPRC                           | Infinity                                          |
| → TGSN                            | 4                                                 |
| → TGL1                            | 7                                                 |
| → TGL2                            | Not present                                       |
| → TGD                             | 0                                                 |
| → TGPL1                           | 8                                                 |
| → TGPL2                           | Not present                                       |
| → RPP                             | Mode 1                                            |
| → ITP                             | Mode 0                                            |
| CHOICE UL/DL Mode                 | UL and DL(depends on UE's Measurement capability) |
| → Downlink compressed mode method | SF/2                                              |
| → Uplink compressed mode method   | SF/2                                              |
| → Downlink frame type             | A                                                 |
| → DeltaSIR1                       | 1.0                                               |
| → DeltaSIRAfter1                  | 0.5                                               |
| → DeltaSIR2                       | Not Present                                       |
| → DeltaSIR2After2                 | Not Present                                       |
| → N identify abort                | Not Present                                       |
| → T Reconfirm abort               | 5-s                                               |

MEASUREMENT CONTROL (Step 4)

|                     |              |
|---------------------|--------------|
| Information Element | Value/Remark |
|---------------------|--------------|

|                                                            |                                           |
|------------------------------------------------------------|-------------------------------------------|
| Measurement Identity                                       | 3                                         |
| Measurement Command                                        | Setup                                     |
| Measurement Reporting Mode                                 |                                           |
| — Measurement Reporting Transfer Mode                      | Acknowledged Mode RLC                     |
| — Periodic Reporting / Event Trigger Reporting Mode        | Event triggered                           |
| Additional measurements list                               | Not Present                               |
| CHOICE measurement type                                    |                                           |
| — inter-RAT measurement                                    |                                           |
| — inter-RAT measurement object list                        |                                           |
| — CHOICE Inter-RAT Cell Removal                            | Remove all inter-RAT cells                |
| — Remove all inter-RAT cells                               | (No Data)                                 |
| — New inter-RAT cells (1 to <MaxCellMeas>)                 | MaxCellMeas=2                             |
| — inter-RAT cell id                                        | Not present                               |
| CHOICE Radio Access Technology                             | GSM                                       |
| — Cell individual offset                                   | 0                                         |
| — Cell selection and re-selection info                     | Not present                               |
| — BSIC                                                     | BSIC1                                     |
| — Band indicator                                           | DCS 1800 band used                        |
| — BCCH ARFCN                                               | 1                                         |
| — inter-RAT cell id                                        | Not present                               |
| CHOICE Radio Access Technology                             | GSM                                       |
| — Cell individual offset                                   | 0                                         |
| — Cell selection and re-selection info                     | Not present                               |
| — BSIC                                                     | BSIC2                                     |
| — Band indicator                                           | DCS 1800 band used                        |
| — BCCH ARFCN                                               | 7                                         |
| — Cell for measurement                                     | Not present                               |
| — inter-RAT measurement quantity                           |                                           |
| — Measurement quantity for UTRAN quality estimate          | Not included                              |
| CHOICE system                                              | GSM                                       |
| — Measurement quantity                                     | GSM carrier RSSI                          |
| — Filter coefficient                                       | 0                                         |
| — BSIC verification required                               | required                                  |
| — inter-RAT reporting quantity                             |                                           |
| — CHOICE system                                            | GSM                                       |
| — Observed time difference to to GSM                       | FALSE                                     |
| — cell reporting indicator                                 |                                           |
| — GSM carrier RSSI reporting indicator                     | TRUE                                      |
| CHOICE report criteria                                     |                                           |
| — Inter-RAT measurements reporting criteria                |                                           |
| — Parameters required for each event (1 to <maxMeasEvent>) | <MaxMeasEvent>=1                          |
| — Inter-RAT event identity                                 | 3d                                        |
| — Threshold own system                                     | Not present                               |
| — W                                                        | Not present                               |
| — Threshold other system                                   | Not present                               |
| — Hysteresis                                               | 5                                         |
| — Time to Trigger                                          | 200 ms                                    |
| — Reporting cell status                                    | 2 cells                                   |
| Physical channel information elements                      |                                           |
| — DPCH compressed mode status info                         |                                           |
| — TGPS reconfiguration CFN                                 | Not present                               |
| — Transmission gap pattern sequence (1 to <MaxTGPS>)       | <MaxTGPS>=3                               |
| — TGPSI                                                    | 1                                         |
| — TGPS status flag                                         | active                                    |
| — TGCFN                                                    | (Current CFN + (252 — TTI/10msec))mod 256 |
| — TGPSI                                                    | 2                                         |
| — TGPS status flag                                         | active                                    |
| — TGCFN                                                    | (Current CFN + (254 — TTI/10msec))mod 256 |
| — TGPSI                                                    | 3                                         |
| — TGPS status flag                                         | active                                    |
| — TGCFN                                                    | (Current CFN + (256 — TTI/10msec))mod 256 |

## MEASUREMENT REPORT (Step 5)

| Information Element                   | Value/Remarks                                                                                                       |
|---------------------------------------|---------------------------------------------------------------------------------------------------------------------|
| Measurement identity                  | Check to see if set to 3                                                                                            |
| Measured Results                      |                                                                                                                     |
| — CHOICE measurement                  | Check to see if set to "Inter-RAT-measured results-list"                                                            |
| -Inter-RAT-measured-result-list       |                                                                                                                     |
| -CHOICE system                        | GSM                                                                                                                 |
| -Measured-GSM-cells                   | Check that measurement results for two GSM cells are included                                                       |
| -GSM-carrier-RSSI                     | Check that measurement result is reasonable                                                                         |
| CHOICE-BSIC                           | Check it is set to verified-BSIC                                                                                    |
| -inter-RAT-cell-id                    | Check that it is set to either 0 or 1                                                                               |
| -Observed-time-difference-to-GSM-cell | Check that the IE is not included                                                                                   |
| -GSM-carrier-RSSI                     | Check that measurement result is reasonable                                                                         |
| CHOICE-BSIC                           | Verified-BSIC                                                                                                       |
| -inter-RAT-cell-id                    | Check that is set to 1 if the previous inter-RAT cell-id was set to 0 or to 0 if the previous cell-id was set to 1- |
| -Observed-time-difference-to-GSM-cell | Check that the IE is not present                                                                                    |
| Measured results on RACH              | Check that not present                                                                                              |
| Additional Measured results           | Check that not present                                                                                              |
| Event results                         | Check that the IE is included                                                                                       |
| -CHOICE event result                  | Check that this is set to inter-RAT measurement event results                                                       |
| -Inter-RAT event identity             | Check that this is set to 3d                                                                                        |
| -Cells to report (1 to <maxCellMeas>) | Check that <maxCellMeas> is set to 1                                                                                |
| -CHOICE BSIC                          | Check that this is set to verified-BSIC                                                                             |
| -Inter-RAT-cell-id                    | Check that this is set to 0-                                                                                        |

## MEASUREMENT REPORT (Step 7)

| Information Element                   | Value/Remarks                                                                                                       |
|---------------------------------------|---------------------------------------------------------------------------------------------------------------------|
| Measurement identity                  | Check to see if set to 3                                                                                            |
| Measured Results                      |                                                                                                                     |
| — CHOICE measurement                  | Check to see if set to "Inter-RAT-measured results-list"                                                            |
| -Inter-RAT-measured-result-list       |                                                                                                                     |
| -CHOICE system                        | GSM                                                                                                                 |
| -Measured-GSM-cells                   | Check that measurement results for two GSM cells are included                                                       |
| -GSM-carrier-RSSI                     | Check that measurement result is reasonable                                                                         |
| CHOICE-BSIC                           | Check it is set to verified-BSIC                                                                                    |
| -inter-RAT-cell-id                    | Check that it is set to either 0 or 1                                                                               |
| -Observed-time-difference-to-GSM-cell | Check that the IE is not included                                                                                   |
| -GSM-carrier-RSSI                     | Check that measurement result is reasonable                                                                         |
| CHOICE-BSIC                           | Verified-BSIC                                                                                                       |
| -inter-RAT-cell-id                    | Check that is set to 1 if the previous inter-RAT cell-id was set to 0 or to 0 if the previous cell-id was set to 1- |
| -Observed-time-difference-to-GSM-cell | Check that the IE is not present                                                                                    |
| Measured results on RACH              | Check that not present                                                                                              |
| Additional Measured results           | Check that not present                                                                                              |
| Event results                         | Check that the IE is included                                                                                       |
| -CHOICE event result                  | Check that this is set to inter-RAT measurement event results                                                       |
| -Inter-RAT event identity             | Check that this is set to 3d                                                                                        |
| -Cells to report (1 to <maxCellMeas>) | Check that <maxCellMeas> is set to 1                                                                                |
| -CHOICE BSIC                          | Check that this is set to verified-BSIC                                                                             |
| -Inter-RAT-cell-id                    | Check that this is set to 1-                                                                                        |

**MEASUREMENT CONTROL (Step 8)**

| Information Element                                 | Value/Remark                              |
|-----------------------------------------------------|-------------------------------------------|
| Measurement Identity                                | 3                                         |
| Measurement Command                                 | Release                                   |
| Physical channel information elements               |                                           |
| -DPCH compressed mode status info                   |                                           |
| -TGPS reconfiguration CFN                           | (Current CFN + (256 – TTI/10msec))mod 256 |
| -Transmission gap pattern sequence (1 to <MaxTGPS>) | <MaxTGPS>=3                               |
| -TGPSI                                              | 1                                         |
| -TGPS status flag                                   | Inactive                                  |
| -TGCFN                                              | Not present                               |
| -TGPSI                                              | 2                                         |
| -TGPS status flag                                   | Inactive                                  |
| -TGCFN                                              | Not present                               |
| -TGPSI                                              | 3                                         |
| -TGPS status flag                                   | Inactive                                  |
| -TGCFN                                              | Not present                               |

**8.4.1.35.4 Test requirement**

Shortly after the UE has received the first MEASUREMENT CONTROL message it shall transmit a MEASUREMENT REPORT to the SS.

About 200 ms after instant T1, the UE shall begin to transmit a MEASUREMENT REPORT triggered by event 3d to the SS.

After receiving the second MEASUREMENT CONTROL message, the UE shall then stop running compressed mode.

**8.4.1.37 Measurement Control and Report: UE internal measurement, event 6c****8.4.1.37.1 Definition****8.4.1.37.2 Conformance requirement**

When this event is ordered by UTRAN in a measurement control message, the UE shall send a measurement report when the UE Tx power reaches its minimum value.

**Reference**

3GPP TS 25.331 clause 14.6.2.3.

**8.4.1.37.3 Test Purpose**

To confirm that the UE sends a measurement report for event 6c when the UE Tx power reaches its minimum value when event 6c has been configured in the UE through a MEASUREMENT CONTROL message.

**8.4.1.37.4 Method of test****Initial Condition**

System simulator: 1 UTRAN FDD cell.

UE: CELL\_DCH state, state 6-9 as specified in clause 7.4 of TS 34.108.

**Test procedure**

The UE is initially in CELL\_DCH, state 6-9 as specified in clause 7.4 of TS 34.108.

The SS sends a MEASUREMENT CONTROL message to the UE that configures event 6c.

The SS sends TPC\_cmd equal to -1 until the transmitter power of the UE reaches its minimum value.

#### Expected sequence

| Step | Direction |    | Message             | Comment                                                                                                                         |
|------|-----------|----|---------------------|---------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                     |                                                                                                                                 |
| 1    |           |    |                     | The UE is brought to the CELL_DCH state in the cell 1.                                                                          |
| 2    |           | ←  | MEASUREMENT CONTROL | SS configures event 6c in the UE.                                                                                               |
| 3    |           | ←  |                     | The SS sends TPC_cmd equal to -1 until the transmitter power of the UE reaches its minimum value, which shall be below -50 dBm. |
| 4    |           | →  | MEASUREMENT REPORT  | The UE sends a MEASUREMENT REPORT to SS triggered by event 6c.                                                                  |

#### Specific message content

##### MEASUREMENT CONTROL (Step 2)

| Information Element                                      | Value/Remark          |
|----------------------------------------------------------|-----------------------|
| Measurement Identity                                     | 6                     |
| Measurement Command                                      | Setup                 |
| Measurement Reporting Mode                               |                       |
| — Measurement Reporting Transfer Mode                    | Acknowledged Mode RLC |
| — Periodic Reporting / Event Trigger Reporting           | Event triggered       |
| — Mode                                                   |                       |
| Additional measurements list                             | Not Present           |
| CHOICE measurement type                                  |                       |
| — UE internal measurement                                |                       |
| — UE internal measurement quantity                       | UE Transmitter Power  |
| — Filter coefficient                                     | 0                     |
| — UE internal reporting quantity                         |                       |
| — UE Transmitted power                                   | TRUE                  |
| — CHOICE mode                                            |                       |
| — UE Rx-Tx time difference                               | FALSE                 |
| — CHOICE report criteria                                 |                       |
| — UE internal measurement reporting criteria             |                       |
| — Parameters sent for each UE internal measurement event | 1 event               |
| — UE internal event identity                             | event 6c              |
| — Time to trigger                                        | 0                     |

## MEASUREMENT REPORT (Step 4)

| Information Element             | Value/Remarks                                                      |
|---------------------------------|--------------------------------------------------------------------|
| Measurement identity            | Check to see if set to 6                                           |
| Measured Results                |                                                                    |
| CHOICE measurement              | Check to see if set to "UE internal measurement"                   |
| -UE internal measured results   |                                                                    |
| -UE Transmitted Power           | Check that this IE is set a value that is below -50 dBm.           |
| -UE Rx-Tx report entities       | Check that this IE is not included                                 |
| Measured results on RACH        | Check that this IE is not included                                 |
| Additional measured results     | Check that this IE is not included                                 |
| Event Results                   |                                                                    |
| CHOICE event result             | Check that this IE is set to UE internal measurement event results |
| UE internal measurement results |                                                                    |
| UE internal event identity      | Check that this IE is set to 6c                                    |
| CHOICE mode                     |                                                                    |
| Primary CPICH info              | This IE should not be included                                     |

## 8.4.1.37.5 Test requirement

The UE shall then begin transmitting a MEASUREMENT REPORT message to SS triggered by event 6c when its transmit power has reached its minimum output power. The minimum transmitted power of the UE shall be less than -50dBm.

## 8.4.1.38 Measurement Control and Report: UE internal measurement, event 6d

## 8.4.1.38.1 Definition

## 8.4.1.38.2 Conformance requirement

When this event is ordered by UTRAN in a measurement control message, the UE shall send a measurement report when the UE Tx power reaches its maximum value.

## Reference

3GPP TS 25.331 clause 14.6.2.4

## 8.4.1.38.3 Test Purpose

To confirm that the UE sends a measurement report for event 6d when the UE Tx power reaches its maximum value when event 6d has been configured in the UE through a MEASUREMENT CONTROL message.

## 8.4.1.38.4 Method of test

## Initial Condition

System simulator: 1 UTRAN FDD cell.

UE: CELL\_DCH state, state 6-9 as specified in clause 7.4 of TS 34.108.

## Test procedure

The UE is initially in CELL\_DCH, state 6-9 as specified in clause 7.4 of TS 34.108.

The SS sends TPC\_cmd equal to +1 until the transmitter power of the UE reaches its maximum value.

## Expected sequence

| Step | Direction |    | Message             | Comment                                                                                           |
|------|-----------|----|---------------------|---------------------------------------------------------------------------------------------------|
|      | UE        | SS |                     |                                                                                                   |
| 1    |           |    |                     | The UE is brought to the CELL_DCH state in the cell 1.                                            |
| 2    |           | ←  | MEASUREMENT CONTROL | SS configures event 6d in the UE.                                                                 |
| 3    |           | ←  |                     | The SS sends TPC_cmd equal to +1 until the transmitter power of the UE reaches its maximum value. |
| 4    |           | →  | MEASUREMENT REPORT  | After about 200 ms, the UE sends a MEASUREMENT REPORT to SS triggered by event 6d.                |

## MEASUREMENT CONTROL (Step 1)

| Information Element                                      | Value/Remark          |
|----------------------------------------------------------|-----------------------|
| Measurement Identity                                     | 6                     |
| Measurement Command                                      | Setup                 |
| Measurement Reporting Mode                               |                       |
| — Measurement Reporting Transfer Mode                    | Acknowledged Mode RLC |
| — Periodic Reporting / Event Trigger Reporting           | Event triggered       |
| — Mode                                                   |                       |
| Additional measurements list                             | Not Present           |
| CHOICE measurement type                                  |                       |
| — UE internal measurement                                |                       |
| — UE internal measurement quantity                       | UE Transmitter Power  |
| — Filter coefficient                                     | 0                     |
| — UE internal reporting quantity                         |                       |
| — UE Transmitted power                                   | TRUE                  |
| — CHOICE mode                                            |                       |
| — UE Rx-Tx time difference                               | FALSE                 |
| — CHOICE report criteria                                 |                       |
| — UE internal measurement reporting criteria             |                       |
| — Parameters sent for each UE internal measurement event | 1 event               |
| — UE internal event identity                             | event 6d              |
| — Time to trigger                                        | 200                   |

## MEASUREMENT REPORT (Step 3)

| Information Element             | Value/Remarks                                                      |
|---------------------------------|--------------------------------------------------------------------|
| Measurement identity            | Check to see if set to 6                                           |
| Measured Results                |                                                                    |
| — CHOICE measurement            | Check to see if set to "UE internal measurement"                   |
| — UE internal measured results  |                                                                    |
| — UE Transmitted Power          | Check that this IE is set to the maximum outpower of the UE.       |
| — UE Rx-Tx report entities      | Check that this IE is not included                                 |
| Measured results on RACH        | Check that this IE is not included                                 |
| Additional measured results     | Check that this IE is not included                                 |
| Event Results                   |                                                                    |
| CHOICE event result             | Check that this IE is set to UE internal measurement event results |
| UE internal measurement results |                                                                    |
| UE internal event identity      | Check that this IE is set to 6d                                    |
| CHOICE mode                     |                                                                    |
| Primary CPICH info              | This IE should not be included                                     |



**8.4.1.38.5** ——— **Test requirement**

The UE shall then begin transmitting a MEASUREMENT REPORT message to SS triggered by event 6d when its transmit power has reached its maximum. The maximum transmitted power of the UE shall be according to the class of the UE.

**8.4.1.39** ——— **Measurement Control and Report: UE internal measurement, event 6e****8.4.1.39.1** ——— **Definition****8.4.1.39.2** ——— **Conformance requirement**

When this event is ordered by UTRAN in a measurement control message, the UE shall send a measurement report when the UE RSSI reaches the UE's dynamic receiver range.

**Reference**

3GPP TS 25.331 clause 14.6.2.5

**8.4.1.39.3** ——— **Test Purpose**

To confirm that the UE sends a measurement report for event 6e when the UE RSSI reaches the UE's dynamic receiver range when event 6e has been configured in the UE through a MEASUREMENT CONTROL message.

**8.4.1.39.4** ——— **Method of test****Initial Condition**

System simulator: 1 UTRAN FDD cell.

UE: CELL\_DCH state, state 6-9 as specified in clause 7.4 of TS 34.108.

**Test procedure**

The UE is initially in CELL\_DCH, state 6-9 as specified in clause 7.4 of TS 34.108.

The SS increases its output power by 0.5 dB step until the UE RSSI reaches the UE's receiver dynamic range.

**Expected sequence**

| Step | Direction |    | Message             | Comment                                                                                                      |
|------|-----------|----|---------------------|--------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                     |                                                                                                              |
| 1    |           |    |                     | The UE is brought to the CELL_DCH state in the cell 1.                                                       |
| 2    |           | ←  | MEASUREMENT CONTROL | SS configures event 6e in the UE.                                                                            |
| 3    |           | ←  |                     | The SS increases its output power by 0.5 dB steps until the UE RSSI reaches the UE's receiver dynamic range. |
| 4    |           | →  | MEASUREMENT REPORT  | The UE sends a MEASUREMENT REPORT to SS triggered by event 6e.                                               |

## MEASUREMENT CONTROL (Step 1)

| Information Element                                      | Value/Remark          |
|----------------------------------------------------------|-----------------------|
| Measurement Identity                                     | 6                     |
| Measurement Command                                      | Setup                 |
| Measurement Reporting Mode                               |                       |
| — Measurement Reporting Transfer Mode                    | Acknowledged Mode RLC |
| — Periodic Reporting / Event Trigger Reporting           | Event triggered       |
| — Mode                                                   |                       |
| Additional measurements list                             | Not Present           |
| CHOICE measurement type                                  |                       |
| — UE internal measurement                                |                       |
| — UE internal measurement quantity                       | UTRA Carrier RSSI     |
| — Filter coefficient                                     | 0                     |
| — UE internal reporting quantity                         | Not included          |
| — CHOICE report criteria                                 |                       |
| — UE internal measurement reporting criteria             |                       |
| — Parameters sent for each UE internal measurement event | 1 event               |
| — UE internal event identity                             | event 6e              |
| — Time to trigger                                        | 0                     |

## MEASUREMENT REPORT (Step 3)

| Information Element               | Value/Remarks                                                      |
|-----------------------------------|--------------------------------------------------------------------|
| Measurement identity              | Check to see if set to 6                                           |
| Measured Results                  | Check that this IE is not included                                 |
| Measured results on RACH          | Check that this IE is not included                                 |
| Additional measured results       | Check that this IE is not included                                 |
| Event Results                     |                                                                    |
| — CHOICE event result             | Check that this IE is set to UE internal measurement event results |
| — UE internal measurement results |                                                                    |
| — UE internal event identity      | Check that this IE is set to 6e                                    |
| — CHOICE mode                     |                                                                    |
| — Primary CPICH info              | This IE should not be included                                     |

## 8.4.1.39.5 ——— Test requirement

The UE shall then begin transmitting a MEASUREMENT REPORT message to SS triggered by event 6e when the UE RSSI reaches the UE's receiver dynamic range.

## 8.4.1.40 ——— Measurement Control and Report: Inter-RAT measurement, event 3C, in CELL\_DCH state using sparse compressed mode pattern

## 8.4.1.40.1 ——— Definition

## 8.4.1.40.2 ——— Conformance requirement

1. Upon reception of a MEASUREMENT CONTROL message the UE shall perform actions specified in 3GPP TS 25.331 clause 8.6 unless otherwise specified below.

The UE shall:

- read the IE "Measurement command";
- if the IE "measurement command" has the value "setup":

- store this measurement in the variable MEASUREMENT\_IDENTITY according to the IE "measurement identity", possibly overwriting the measurement previously stored with that identity;
  - for measurement types "inter-RAT measurement" or "inter-frequency measurement":
    - if, according to its measurement capabilities, the UE requires compressed mode to perform the measurements and a compressed mode pattern sequence with an appropriate measurement purpose is simultaneously activated by the IE "DPCH compressed mode status info"; or
    - if, according to its measurement capabilities, the UE does not require compressed mode to perform the measurements:
    - begin measurements according to the stored control information for this measurement identity;
2. Event 3c: The estimated quality of other system is above a certain threshold. When this event is ordered by UTRAN in a measurement control message the UE shall send a report when the estimated quality of the other system is above the value of the IE "Threshold other system" and the hysteresis and time to trigger conditions are fulfilled. The corresponding report contains information specific for the other system.

## Reference

3GPP TS 25.331 clause 8.4.1.3, 14.3.1.3.

### 8.4.1.40.3 Test Purpose

1. To verify that the UE performs Inter-RAT measurement using a sparse compressed mode pattern as specified in the MEASUREMENT CONTROL message.
2. To verify that the UE send MEASUREMENT REPORT message when event 3C is triggered, and if the quality of the other system becomes better than the given threshold for event 3c.
3. To confirm that no other UE MEASUREMENT REPORT message is sent by the UE for a cell that has already triggered event 3c as long as the hysteresis condition for triggering once again event 3c has not been fulfilled.

### 8.4.1.40.4 Method of test

**Table 8.4.1.40.4.1 Sparse compressed mode pattern for Inter.RAT measurement**

| TGMP                            | TGCFN  | TGPRC | TGSN | TGL1 | TGL2     | TGD | TGPL1 | TGPL2 | Comment                                                                                              |
|---------------------------------|--------|-------|------|------|----------|-----|-------|-------|------------------------------------------------------------------------------------------------------|
| GSM carrier RSSI measurement    | Note 1 | Inf.  | 4    | 7    | Not sent | 0   | 16    | 16    | Set-up to monitor 12 GSM neighbours every second measurement period, i.e. every second 480ms period. |
| GSM Initial BSIC identification | Note 1 | Inf.  | 8    | 14   | Not sent | 0   | 24    | 24    | Equal to Pattern 6 in TS 25.133 table 8.7.                                                           |
| GSM BSIC re-confirmation        | Note 1 | Inf.  | 8    | 14   | Not sent | 0   | 24    | 24    | Equal to Pattern 12 in TS 25.133 table 8.8.                                                          |

NOTE 1: TGCFN can be found in the MEASUREMENT CONTROL message.

## Initial Condition

System simulator: 1 UTRAN FDD cell and 2 GSM cells. The initial configurations of the 2 cells in the SS shall follow the values indicated in the column marked T0. The table is found in "Test procedure".

UE: CELL\_DCH state, state 6-9 as specified in clause 7.4 of TS 34.108.

## Test procedure

Table 8.4.1.40.4.2 Inter-RAT cell specific data

| Parameter       | Unit | Cell 1<br>(GSM) |     |     |     | Cell 2<br>(GSM) |     |     |     |
|-----------------|------|-----------------|-----|-----|-----|-----------------|-----|-----|-----|
|                 |      | T0              | T1  | T2  | T3  | T0              | T1  | T2  | T3  |
| Test Channel    | #    | GSM Ch.1        |     |     |     | GSM Ch.2        |     |     |     |
| BCCH ARFCN      | #    | 1               |     |     |     | 3               |     |     |     |
| CELL identity   | #    | 0               |     |     |     | 1               |     |     |     |
| BSIC            | #    | BSIC 1          |     |     |     | BSIC 2          |     |     |     |
| RF Signal Level | dBm  | -90             | -80 | -90 | -80 | -80             | -80 | -80 | -80 |

GSM cell 3 to 12 as indicated in the a MEASUREMENT CONTROL message shall not be active in the test, i.e. no BCCH carrier shall be transmitted for GSM cell 3 to 12 in this test.

The table above illustrate the downlink power to be applied for the two cells at various instants of the test execution. Column marked "T0" denotes the initial conditions, while column marked "T1", "T2" and "T3" indicate the values to be applied subsequently.

The UE is initially in CELL\_DCH, state 6-9 as specified in clause 7.4 of TS 34.108. UTRA cell 1 is the only cell in the active set of the UE. The SS sends a PHYSICAL CHANNEL RECONFIGURATION message to the UE to configure the compressed mode pattern sequence parameters to the UE. Three compressed mode patterns are configured, according to the message specified below. When the PHYSICAL CHANNEL RECONFIGURATION COMPLETE is received from the UE, the SS sends a MEASUREMENT CONTROL message to the UE, to set up inter-RAT measurements on 12 GSM cells. Event 3c is set up in this message, and compressed mode is activated.

At instant T1, the RF signal strength for GSM cell 1 increases as described in table 8.4.1.40.4.2, since the cell individual offset for GSM cell 1 is 10 dB, event 3c shall be triggered in the UE. A MEASUREMENT REPORT shall be sent to the SS. Note that GSM cell 2 has not triggered event 3c even though the RF signal strength for GSM cell 2 is the same as for cell 1, because the cell individual offset for GSM cell 2 is 0 dB.

At instant T2, the RF signal strength for GSM cell 1 drops as described in table 8.4.1.40.4.2, and at instant T3, it increases again to its previous level. No MEASUREMENT REPORT shall be received from the UE, since GSM cell 1 has already triggered event 3c, and since the RF signal strength has not dropped enough for it to trigger the event once again.

## Expected Sequence

| Step | Direction |    | Message                                   | Comment                                                                                                             |
|------|-----------|----|-------------------------------------------|---------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                     |
| 1    |           |    |                                           | The UE is brought to the CELL_DCH state in the cell 1.                                                              |
| 2    |           | ←  | PHYSICAL CHANNEL RECONFIGURATION          | Compressed mode pattern sequence parameters are loaded to UE.                                                       |
| 3    |           | →  | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |                                                                                                                     |
| 4    |           | ←  | MEASUREMENT CONTROL                       | SS configures event 3c in the UE. Compressed mode is started.                                                       |
| 5    |           |    |                                           | SS waits for approximately 10 seconds and verifies that no MEASUREMENT REPORT messages are detected on uplink DCCH. |
| 6    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T1" in table 8.4.1.40.4.2.             |
| 7    |           | →  | MEASUREMENT REPORT                        | After about 2 s, the UE sends a MEASUREMENT REPORT to SS triggered by event 3c.                                     |
| 8    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T2" in table 8.4.1.40.4.2.             |
| 9    |           |    |                                           | SS re-adjusts the downlink transmission power settings according to columns "T3" in table 8.4.1.40.4.2.             |
| 10   |           |    |                                           | SS waits for approximately 10 seconds and verifies that no MEASUREMENT REPORT messages are detected on uplink DCCH. |

## Specific Message Content

## PHYSICAL CHANNEL RECONFIGURATION (Step 2)

Use the same message sub-type in Annex A titled "Speech in CS", with the following exceptions:

| Information Element                                          | Value/Remarks                |
|--------------------------------------------------------------|------------------------------|
| Downlink information common for all radio links              |                              |
| → DPCH compressed mode info                                  | 1                            |
| → TGPSI                                                      | Inactive                     |
| → TGPS Status Flag                                           | Not present                  |
| → TGCFN                                                      |                              |
| → Transmission gap pattern sequence configuration parameters |                              |
| → TGMP                                                       | GSM Carrier RSSI Measurement |
| → TGPRC                                                      | Infinity                     |
| → TGSN                                                       | 4                            |
| → TGL1                                                       | 7                            |
| → TGL2                                                       | Not present                  |
| → TGD                                                        | 0                            |
| → TGPL1                                                      | 16                           |
| → TGPL2                                                      | Not present                  |
| → RPP                                                        | Mode 1                       |
| → ITP                                                        | Mode 0                       |
| CHOICE UL/DL Mode                                            | UL and DL                    |
| → Downlink compressed mode method                            | SF/2                         |

|                                                              |                          |
|--------------------------------------------------------------|--------------------------|
| — Uplink compressed mode method                              | SF/2                     |
| — Downlink frame type                                        | A                        |
| — DeltaSIR1                                                  | 1.0                      |
| — DeltaSIRAfter1                                             | 0.5                      |
| — DeltaSIR2                                                  | Not Present              |
| — DeltaSIR2After2                                            | Not Present              |
| — N identify abort                                           | Not Present              |
| — T Reconfirm abort                                          | Not Present              |
| — DPCCH compressed mode info                                 |                          |
| — TGPSI                                                      | 2                        |
| — TGPS Status Flag                                           | Inactive                 |
| — TGCFN                                                      | Not present              |
| — Transmission gap pattern sequence configuration parameters |                          |
| — TGMP                                                       | GSM-BSIC identification  |
| — TGPRC                                                      | Infinity                 |
| — TGSN                                                       | 8                        |
| — TGL1                                                       | 14                       |
| — TGL2                                                       | Not present              |
| — TGD                                                        | 0                        |
| — TGPL1                                                      | 24                       |
| — TGPL2                                                      | Not present              |
| — RPP                                                        | Mode 1                   |
| — ITP                                                        | Mode 0                   |
| CHOICE UL/DL Mode                                            | UL and DL                |
| — Downlink compressed mode method                            | SF/2                     |
| — Uplink compressed mode method                              | SF/2                     |
| — Downlink frame type                                        | A                        |
| — DeltaSIR1                                                  | 1.0                      |
| — DeltaSIRAfter1                                             | 0.5                      |
| — DeltaSIR2                                                  | Not Present              |
| — DeltaSIR2After2                                            | Not Present              |
| — N identify abort                                           | 21                       |
| — T Reconfirm abort                                          | Not Present              |
| — TGPSI                                                      | 3                        |
| — TGPS Status Flag                                           | Inactive                 |
| — TGCFN                                                      | Not present              |
| — Transmission gap pattern sequence configuration parameters |                          |
| — TGMP                                                       | GSM-BSIC re-confirmation |
| — TGPRC                                                      | Infinity                 |
| — TGSN                                                       | 8                        |
| — TGL1                                                       | 14                       |
| — TGL2                                                       | Not present              |
| — TGD                                                        | 0                        |
| — TGPL1                                                      | 24                       |
| — TGPL2                                                      | Not present              |
| — RPP                                                        | Mode 1                   |
| — ITP                                                        | Mode 0                   |
| CHOICE UL/DL Mode                                            | UL and DL                |
| — Downlink compressed mode method                            | SF/2                     |
| — Uplink compressed mode method                              | SF/2                     |
| — Downlink frame type                                        | A                        |
| — DeltaSIR1                                                  | 1.0                      |
| — DeltaSIRAfter1                                             | 0.5                      |
| — DeltaSIR2                                                  | Not Present              |
| — DeltaSIR2After2                                            | Not Present              |
| — N identify abort                                           | Not Present              |
| — T Reconfirm abort                                          | 4.8 s                    |

## MEASUREMENT CONTROL (Step 4)

| Information Element | Value/Remark |
|---------------------|--------------|
|---------------------|--------------|

|                                                |                            |
|------------------------------------------------|----------------------------|
| Measurement Identity                           | 3                          |
| Measurement Command                            | Setup                      |
| Measurement Reporting Mode                     |                            |
| — Measurement Reporting Transfer Mode          | Acknowledged Mode RLC      |
| — Periodic Reporting / Event Trigger Reporting | Event triggered            |
| — Mode                                         |                            |
| Additional measurements list                   | Not Present                |
| CHOICE measurement type                        |                            |
| — inter-RAT measurement                        |                            |
| — inter-RAT measurement object list            |                            |
| — CHOICE Inter-RAT Cell Removal                | Remove all inter-RAT cells |
| — Remove all inter-RAT cells                   | (No Data)                  |
| — New inter-RAT cells (1 to <MaxCellMeas>)     | MaxCellMeas=12             |
| — inter-RAT cell id                            | 0                          |
| CHOICE Radio Access Technology                 | GSM                        |
| — Cell individual offset                       | 10                         |
| — Cell selection and re-selection info         | Not present                |
| — BSIC                                         | BSIC1                      |
| — Band indicator                               | DCS 1800 band used         |
| — BCCH ARFCN                                   | 1                          |
| — inter-RAT cell id                            | 1                          |
| CHOICE Radio Access Technology                 | GSM                        |
| — Cell individual offset                       | 0                          |
| — Cell selection and re-selection info         | Not present                |
| — BSIC                                         | BSIC2                      |
| — Band indicator                               | DCS 1800 band used         |
| — BCCH ARFCN                                   | 3                          |
| — inter-RAT cell id                            | 1                          |
| CHOICE Radio Access Technology                 | GSM                        |
| — Cell individual offset                       | 0                          |
| — Cell selection and re-selection info         | Not present                |
| — BSIC                                         | BSIC2                      |
| — Band indicator                               | DCS 1800 band used         |
| — BCCH ARFCN                                   | 7                          |
| — inter-RAT cell id                            | 2                          |
| CHOICE Radio Access Technology                 | GSM                        |
| — Cell individual offset                       | 0                          |
| — Cell selection and re-selection info         | Not present                |
| — BSIC                                         | BSIC3                      |
| — Band indicator                               | DCS 1800 band used         |
| — BCCH ARFCN                                   | 5                          |
| — inter-RAT cell id                            | 3                          |
| CHOICE Radio Access Technology                 | GSM                        |
| — Cell individual offset                       | 0                          |
| — Cell selection and re-selection info         | Not present                |
| — BSIC                                         | BSIC4                      |
| — Band indicator                               | DCS 1800 band used         |
| — BCCH ARFCN                                   | 7                          |
| — inter-RAT cell id                            | 4                          |
| CHOICE Radio Access Technology                 | GSM                        |
| — Cell individual offset                       | 0                          |
| — Cell selection and re-selection info         | Not present                |
| — BSIC                                         | BSIC5                      |
| — Band indicator                               | DCS 1800 band used         |
| — BCCH ARFCN                                   | 9                          |
| — inter-RAT cell id                            | 5                          |
| CHOICE Radio Access Technology                 | GSM                        |
| — Cell individual offset                       | 0                          |
| — Cell selection and re-selection info         | Not present                |
| — BSIC                                         | BSIC6                      |
| — Band indicator                               | DCS 1800 band used         |
| — BCCH ARFCN                                   | 11                         |
| — inter-RAT cell id                            | 6                          |
| CHOICE Radio Access Technology                 | GSM                        |
| — Cell individual offset                       | 0                          |
| — Cell selection and re-selection info         | Not present                |
| — BSIC                                         | BSIC7                      |
| — Band indicator                               | DCS 1800 band used         |
| — BCCH ARFCN                                   | 13                         |
| — inter-RAT cell id                            | 7                          |
| CHOICE Radio Access Technology                 | GSM                        |
| — Cell individual offset                       |                            |

## MEASUREMENT REPORT (Step 7)

| Information Element                   | Value/Remarks                                                                                                       |
|---------------------------------------|---------------------------------------------------------------------------------------------------------------------|
| Measurement identity                  | Check to see if set to 3                                                                                            |
| Measured Results                      |                                                                                                                     |
| — CHOICE measurement                  | Check to see if set to "Inter-RAT measured results list"                                                            |
| -Inter-RAT measured result list       |                                                                                                                     |
| -CHOICE system                        | GSM                                                                                                                 |
| -Measured GSM cells                   | Check that measurement results for two GSM cells are included                                                       |
| -GSM carrier RSSI                     | Check that measurement result is reasonable                                                                         |
| CHOICE BSIC                           | Check it is set to verified BSIC                                                                                    |
| -inter-RAT cell id                    | Check that it is set to either 0 or 1                                                                               |
| -Observed time difference to GSM cell | Check that the IE is not included                                                                                   |
| -GSM carrier RSSI                     | Check that measurement result is reasonable                                                                         |
| CHOICE BSIC                           | Verified BSIC                                                                                                       |
| -inter-RAT cell id                    | Check that is set to 1 if the previous inter-RAT cell id was set to 0 or to 0 if the previous cell id was set to 1. |
| -Observed time difference to GSM cell | Check that the IE is not present                                                                                    |
| Measured results on RACH              | Check that not present                                                                                              |
| Additional Measured results           | Check that not present                                                                                              |
| Event results                         | Check that the IE is included                                                                                       |
| -CHOICE event result                  | Check that this is set to inter-RAT measurement event results                                                       |
| -Inter-RAT event identity             | Check that this is set to 3c                                                                                        |
| -Cells to report (1 to <maxCellMeas>) | Check that <maxCellMeas> is set to 1                                                                                |
| -CHOICE BSIC                          | Check that this is set to verified BSIC                                                                             |
| -Inter-RAT cell id                    | Check that this is set to 0.                                                                                        |

## 8.4.1.40.5 ——— Test Requirement

About 2 s after instant T1, since the cell individual offset for GSM cell 1 is +10 dB, event 3c shall be triggered in the UE, i.e the UE shall begin to transmit a MEASUREMENT REPORT to the SS. Note that GSM cell 2 has not triggered event 3c even though the RF signal strength for GSM cell 2 is the same as for cell 1, because the cell individual offset for GSM cell 2 is 0 dB.

After instant T2, no MEASUREMENT REPORT shall be received from the UE, since GSM cell 1 has already triggered event 3c, and since the RF signal strength has not dropped enough for it to trigger the event once again.



## ~~9 Elementary procedures of mobility management~~

~~The tests are based on TS 24.008.~~

~~In this clause, when the expected sequence require that "a mobile-originated CM connection is attempted", it shall be for a service other than emergency call.~~

~~In this clause, a initial CM message is either a SETUP message, a REGISTER message or a CP-DATA message (in that case the acknowledged mode of operation on SAPI 3 will have be established and this message will be sent on SAPI 3).~~

### ~~9.1 TMSI reallocation~~

~~The intention of the TMSI Reallocation procedure is to assign a new temporary identity for the UE. If the message is not understood by the UE, the network could not establish a link to the UE. As this is a common MM procedure, it can be initiated at any time.~~

#### ~~9.1.1 Definition~~

#### ~~9.1.2 Conformance requirement~~

- ~~1) A UE shall acknowledge a new TMSI when explicitly allocated during a location updating procedure or an incoming call.~~
- ~~2) The TMSI shall be updated on the USIM when the UE is correctly deactivated in accordance with the manufacturer's instructions.~~
- ~~3) A UE shall answer paging with this TMSI and includes it in the PAGING RESPONSE message.~~

#### ~~Reference(s)~~

~~TS 24.008 clause 4.3.1.~~

#### ~~9.1.3 Test purpose~~

~~To verify that the UE is able to receive and acknowledge a new TMSI by means of an explicit TMSI reallocation procedure.~~

~~To verify that the UE has stored the TMSI in a non-volatile memory.~~

~~The implicit reallocation procedure is tested in clause 9.4.1.~~

#### ~~9.1.4 Method of test~~

##### ~~Initial conditions~~

- ~~— System Simulator:~~
  - ~~— two cells A and B, belonging to different location areas a and b, default parameters.~~
- ~~— User Equipment:~~
  - ~~— the UE has valid TMSI (= TMSI1), CKSN, CK, IK. It is "idle updated" on cell B.~~

##### ~~Related ICS/IXIT statement(s)~~

~~Switch-off button Yes/No.~~

~~Way to bring the UE into service.~~

### Test Procedure

The UE is paged in cell B and the security mode is established. An explicit TMSI reallocation procedure is performed. The RRC CONNECTION is released. The UE is switched off and then its power supply is interrupted for 10 s. The power supply is resumed and then the UE is switched on and allowed sufficient time to guarantee that the UE is in service (listening to its paging subchannel). The system simulator then checks, by paging, whether the UE has stored the received TMSI.

The UE is made to select cell A. A normal location updating procedure is performed in cell A. An explicit TMSI reallocation procedure is performed and then the location updating procedure is accepted by the SS. The system simulator checks, by paging, whether the UE has stored the allocated TMSI.

## Expected sequence

| Step                                                             | Direction |    | Message                                                      | Comments                                                                                                                                                                                                    |
|------------------------------------------------------------------|-----------|----|--------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                  | UE        | SS |                                                              |                                                                                                                                                                                                             |
| The following messages are sent and shall be received on cell B. |           |    |                                                              |                                                                                                                                                                                                             |
| 1                                                                | ←         |    | Mobile terminated establishment of Radio Resource Connection | See TS 34.108 clause 7.1.2<br>"Initial UE identity" = TMSI1.<br>Establishment Cause: Terminating Conversation Call.<br>"Mobile identity" =TMSI1                                                             |
| 2                                                                | →         |    | PAGING RESPONSE                                              |                                                                                                                                                                                                             |
| 2a                                                               | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                                                                                                                                             |
| 2b                                                               | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                                                                                                                                             |
| 3                                                                | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                             |
| 4                                                                | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                                             |
| 5                                                                | ←         |    | TMSI REALLOCATION COMMAND                                    | "Mobile identity" = new TMSI (TMSI2) different from TMSI 1.                                                                                                                                                 |
| 6                                                                | →         |    | TMSI REALLOCATION COMPLETE                                   |                                                                                                                                                                                                             |
| 7                                                                | ←         |    | RRC CONNECTION RELEASE                                       | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                          |
| 8                                                                | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                             |
| 9                                                                | UE        |    |                                                              | If possible (see ICS), the UE is switched off.                                                                                                                                                              |
| 9a                                                               | UE        |    |                                                              | The power supply is interrupted for 10 s.                                                                                                                                                                   |
| 10                                                               | UE        |    |                                                              | The UE is switched on.                                                                                                                                                                                      |
| 11                                                               | SS        |    |                                                              | The SS waits an amount of time which is enough to guarantee that the UE is in service (listening to its paging subchannel).                                                                                 |
| 12                                                               | ←         |    | Mobile terminated establishment of Radio Resource Connection | See TS 34.108 clause 7.1.2<br>"Initial UE identity" = TMSI2.<br>Establishment Cause: Terminating Conversation Call.<br>"Mobile identity" =TMSI2.                                                            |
| 13                                                               | →         |    | PAGING RESPONSE                                              |                                                                                                                                                                                                             |
| 14                                                               | ←         |    | RRC CONNECTION RELEASE                                       | After the sending of this message, the SS waits for the disconnection of the main signalling link. The following messages are sent and shall be received on cell A                                          |
| 15                                                               | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                             |
| 16                                                               | SS        |    |                                                              | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "non-suitable cell" (see note)                                                                                     |
| 17                                                               | →         |    | RRC CONNECTION REQUEST                                       | Establishment cause: Registration.                                                                                                                                                                          |
| 18                                                               | ←         |    | RRC CONNECTION SETUP                                         |                                                                                                                                                                                                             |
| 19                                                               | →         |    | RRC CONNECTION SETUP COMPLETE                                |                                                                                                                                                                                                             |
| 20                                                               | →         |    | LOCATION UPDATING REQUEST                                    | location updating type = normal, "ciphering key sequence number" = CKSN, LAI = b, "mobile identity" = TMSI2.                                                                                                |
| 20a                                                              | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                                                                                                                                             |
| 20b                                                              | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                                                                                                                                             |
| 20c                                                              | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                             |
| 20d                                                              | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                                             |
| 21                                                               | ←         |    | TMSI REALLOCATION COMMAND                                    | TMSI = TMSI1.                                                                                                                                                                                               |
| 22                                                               | →         |    | TMSI REALLOCATION COMPLETE                                   |                                                                                                                                                                                                             |
| 23                                                               | ←         |    | LOCATION UPDATING ACCEPT                                     | This message does not contain the optional Mobile Identity field.                                                                                                                                           |
| 24                                                               | ←         |    | RRC CONNECTION RELEASE                                       | After the sending of this message, the SS waits for the disconnection of the main signalling link. The SS waits an amount of time which is enough to guarantee that the UE is "idle updated" on cell A.     |
| 25                                                               | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                             |
| 26                                                               | ←         |    | Mobile terminated establishment of Radio Resource Connection | See TS 34.108 clause 7.1.2<br>"Initial UE identity" IE contains the new TMSI (= TMSI1).<br>"Establishment cause": Terminating Conversational Call.<br>"Mobile identity" IE contains the new TMSI (= TMSI1). |
| 27                                                               | →         |    | PAGING RESPONSE                                              |                                                                                                                                                                                                             |
| 28                                                               | ←         |    | RRC CONNECTION RELEASE                                       | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                          |

| Step                                                                                                                                                                | Direction |    | Message                         | Comments |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|----------|
|                                                                                                                                                                     | UE        | SS |                                 |          |
| 29                                                                                                                                                                  | →         |    | RRC CONNECTION RELEASE COMPLETE |          |
| NOTE: The definitions for "Serving cell" and "non-suitable cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |          |

### Specific message contents

None.

#### 9.1.5 Test requirement

At step 5 the UE shall receive and acknowledge a new TMSI (TMSI2) and has stored that in the USIM, and the UE is switched off and on after step 9 and 10.

At step 13 the UE shall transmit a new TMSI2 and includes it in the PAGING RESPONSE message.

At step 27 the UE shall answer paging with this TMSI1 and includes it in the PAGING RESPONSE message.

## 9.2 Authentication

The purpose of this procedure is to verify the user identity. A correct response is essential to guarantee the establishment of the connection. If not, the connection will drop.

The SS shall be able to handle vectors of AUTN, RAND, CK, IK, AUTS and XRES in a similar way as the MSC/BSS entities. The SS and test USIM shall incorporate a test algorithm for generating RES and CK, IK from RAND, AUTN and IK which operates as described in TS 34.108 clause 8.1.2.

### 9.2.1 Authentication accepted

#### 9.2.1.1 Definition

#### 9.2.1.2 Conformance requirement

- 1) A UE shall correctly respond to an AUTHENTICATION REQUEST message by sending an AUTHENTICATION RESPONSE message with the RES information field set to the same value as the one produced by the authentication algorithm in the network.
- 2) A UE shall indicate in a PAGING RESPONSE message the ciphering key sequence number which was allocated to it through the authentication procedure.

#### Reference(s)

TS 24.008 clauses 4.3.2.2 and 4.3.2.4.

#### 9.2.1.3 Test purpose

- 1) To check that a UE correctly responds to an AUTHENTICATION REQUEST message by sending an AUTHENTICATION RESPONSE message with the RES information field set to the same value as the one produced by the authentication algorithm in the network.
- 2) To check that a UE indicates in a PAGING RESPONSE message the ciphering key sequence number which was allocated to it through the authentication procedure.

#### 9.2.1.4 Method of test

##### Initial conditions

- System Simulator:
- 1 cell, default parameters.
- User Equipment:
- the UE has valid TMSI, CKSN (CKSN1), CK, IK. It is "idle updated" on the cell.

##### Related ICS/IXIT statement(s)

None.

##### Test Procedure

The UE is paged. After the UE has sent a PAGING RESPONSE message to the SS, the SS initiates an authentication procedure and checks the value RES sent by the UE in the AUTHENTICATION RESPONSE message. The RRC CONNECTION is released. The UE is paged and the SS checks the value of the ciphering key sequence number sent by the UE in the PAGING RESPONSE message.

##### Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                                                                                  |
|------|-----------|----|--------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                                                                           |
| 1    |           |    | Mobile terminated establishment of Radio Resource Connection | See TS 34.108 clause 7.1.2<br>Establishment Cause: Terminating Conversational Call.<br>CKSN = CKSN1                                                                                                                       |
| 2    | →         |    | PAGING RESPONSE                                              |                                                                                                                                                                                                                           |
| 3    |           | ←  | AUTHENTICATION REQUEST                                       | The SS initiates authentication with CKSN2 different from CKSN1.<br>"Auth. parameter RES" IE shall be bit exact with the value as produced by the authentication algorithm.                                               |
| 4    | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                                                                                                                                                           |
| 5    |           | ←  | RRC CONNECTION RELEASE                                       | After the sending of this message, the SS waits for the disconnection of the main signalling link. The SS waits an amount of time which is enough to guarantee that the UE is in service.                                 |
| 6    | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                           |
| 7    |           |    | Mobile terminated establishment of Radio Resource Connection | See TS 34.108 clause 7.1.2<br>Establishment Cause: Terminating Conversational Call.<br>"Ciphering key sequence number" shall be the same as the value that was sent in the last AUTHENTICATION REQUEST message (= CKSN2). |
| 8    | →         |    | PAGING RESPONSE                                              |                                                                                                                                                                                                                           |
| 9    |           | ←  | RRC CONNECTION RELEASE                                       | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                                        |
| 10   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                           |

##### Specific message contents

None.

#### 9.2.1.5 Test requirement

- 1) At step 4 the UE shall send an AUTHENTICATION RESPONSE message with the RES information field set to the same value as the XRES calculated by the SS.
- 2) At step 8 the UE shall indicate in a PAGING RESPONSE message the ciphering key sequence number which was allocated to it through the authentication procedure.

## ~~9.2.2 Authentication rejected by the network~~

### ~~9.2.2.1 Definition~~

### ~~9.2.2.2 Conformance requirement~~

- ~~1) After reception of an AUTHENTICATION REJECT message the UE shall:
  - ~~1.1 not perform normal location updating;~~
  - ~~1.2 not perform periodic location updating;~~
  - ~~1.3 not respond to paging with TMSI;~~
  - ~~1.4 reject any request from CM entity for MM connection except for emergency call;~~
  - ~~1.5 not perform IMSI detach if deactivated.~~~~
- ~~2) After reception of an AUTHENTICATION REJECT message the UE, if it supports speech, shall accept a request for an emergency call by sending a RRC CONNECTION REQUEST message with the establishment cause set to "emergency call" and include an IMEI as mobile identity in the CM SERVICE REQUEST message.~~
- ~~3) After reception of an AUTHENTICATION REJECT message the UE shall delete the stored LAI, CKSN and TMSI.~~

### Reference(s)

TS 24.008 clause 4.3.2.5.

### ~~9.2.2.3 Test purpose~~

- ~~1) To check that ,after reception of an AUTHENTICATION REJECT message, the UE:
  - ~~1.1 does not perform normal location updating;~~
  - ~~1.2 does not perform periodic location updating;~~
  - ~~1.3 does not respond to paging with TMSI;~~
  - ~~1.4 rejects any request from CM entity for MM connection except for emergency call;~~
  - ~~1.5 does not perform IMSI detach if deactivated.~~~~
- ~~2) To check that, after reception of an AUTHENTICATION REJECT message the UE, if it supports speech, accepts a request for an emergency call by sending a RRC CONNECTION REQUEST message with the establishment cause set to "emergency call" and includes an IMEI as mobile identity in the CM SERVICE REQUEST message.~~
- ~~3) To check that, after reception of an AUTHENTICATION REJECT message and after having been deactivated and reactivated, the UE performs location updating using its IMEI as mobile identity and indicates deleted LAI and CKSN.~~

### ~~9.2.2.4 Method of test~~

### Initial conditions

- ~~— System Simulator:~~
  - ~~— two cells: A and B, belonging to different location areas a and b;~~
  - ~~— IMSI attach/detach is allowed in both cells;~~
  - ~~— the T3212 time-out value is 1/10 hour in both cells.~~

—User Equipment:

—the UE has valid TMSI, CKSN (CKSN2), CK and IK. It is "idle updated" on cell B.

#### Related ICS/IXIT statement(s)

USIM removal possible while UE is powered Yes/No.

Switch off on button Yes/No.

Support of speech Yes/No.

#### Test procedure

The SS rejects an authentication. The RRC CONNECTION is released. The SS checks that the UE has entered the state MM IDLE substate NO IMSI, i.e. does not perform normal location updating, does not perform periodic updating, does not respond to paging, rejects any requests from CM entities except emergency calls and does not perform IMSI detach if USIM detachment is performed, switch off is performed, or the power is removed, depending on the UE (see ICS/IXIT).

## Expected sequence

| Step                                                             | Direction |    | Message                                                      | Comments                                                                                                                                                                                                                  |
|------------------------------------------------------------------|-----------|----|--------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                  | UE        | SS |                                                              |                                                                                                                                                                                                                           |
| The following messages are sent and shall be received on cell B  |           |    |                                                              |                                                                                                                                                                                                                           |
| 1                                                                |           |    | Mobile terminated establishment of Radio Resource Connection | See TS 34.108 clause 7.1.2<br>Establishment Cause: Terminating Conversational Call.<br>"Ciphering key sequence number" shall be the same as the value that was sent in the last AUTHENTICATION REQUEST message (= CKSN2). |
| 2                                                                | →         |    | PAGING RESPONSE                                              |                                                                                                                                                                                                                           |
| 3                                                                | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                                                                                                                                                           |
| 4                                                                | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                                                                                                                                                           |
| 5                                                                | ←         |    | AUTHENTICATION REJECT                                        |                                                                                                                                                                                                                           |
| 6                                                                | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                           |
| 7                                                                | →         |    | RRC CONNECTION RELEASE COMPLETE                              | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                                        |
| 8                                                                | ←         |    | PAGING TYPE 1                                                |                                                                                                                                                                                                                           |
| 9                                                                | UE        |    |                                                              | The UE is paged in cell B. "UE identity " IE contains TMSI. Paging Cause: Terminating Conversational Call.<br>The UE shall ignore this message. This is verified during 3 s.                                              |
| 10                                                               | SS        |    |                                                              |                                                                                                                                                                                                                           |
| 11                                                               | UE        |    |                                                              |                                                                                                                                                                                                                           |
| 12                                                               | UE        |    |                                                              | The SS waits for at least for 15 s.<br>A MO-CM connection is attempted.<br>The UE shall not initiate an RRC connection establishment on cell A or cell B. This is checked during 3 s.                                     |
| 13                                                               | UE        |    |                                                              |                                                                                                                                                                                                                           |
| 14                                                               | →         |    | RRC CONNECTION REQUEST                                       | If the UE supports speech (see ICS), an emergency call is attempted.<br>"Establishment cause": Emergency call.                                                                                                            |
| 15                                                               | ←         |    | RRC CONNECTION SETUP                                         |                                                                                                                                                                                                                           |
| 16                                                               | →         |    | RRC CONNECTION SETUP COMPLETE                                |                                                                                                                                                                                                                           |
| 17                                                               | →         |    | CM SERVICE REQUEST                                           | "CM service type": Emergency call establishment.<br>"Mobile identity": type of identity is set to IMEI.                                                                                                                   |
| 18                                                               | ←         |    | CM SERVICE ACCEPT                                            |                                                                                                                                                                                                                           |
| 19                                                               | →         |    | EMERGENCY SETUP                                              | "Cause" = unassigned number.<br>After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                        |
| 20                                                               | ←         |    | RELEASE COMPLETE                                             |                                                                                                                                                                                                                           |
| 21                                                               | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                           |
| 22                                                               | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                           |
| The following messages are sent and shall be received on cell A: |           |    |                                                              |                                                                                                                                                                                                                           |
| 23                                                               | SS        |    |                                                              | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "non-suitable cell". (see note)                                                                                                  |
| 24                                                               | UE        |    |                                                              |                                                                                                                                                                                                                           |
| 25                                                               | SS        |    |                                                              | The UE performs cell reselection according to procedure as specified in (this however is not checked until step 29).<br>The UE shall not initiate an RRC connection establishment on cell A or on cell B.                 |
| 26                                                               | UE        |    |                                                              |                                                                                                                                                                                                                           |
| 27                                                               | UE        |    |                                                              | The SS waits at least 7 minutes for a possible periodic updating.<br>The UE shall not initiate an RRC connection establishment on cell A or on cell B.                                                                    |
| 28                                                               | UE        |    |                                                              |                                                                                                                                                                                                                           |
| 29                                                               | UE        |    |                                                              | If possible (see ICS) USIM detachment is performed.<br>Otherwise if possible (see ICS) switch-off is performed.<br>Otherwise the power is removed.                                                                        |
| 30                                                               | →         |    | RRC CONNECTION REQUEST                                       |                                                                                                                                                                                                                           |
| 31                                                               | ←         |    | RRC CONNECTION SETUP                                         | The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 3 s.<br>Depending on what has been performed in step 26 the UE is brought back to operation.                     |
| 32                                                               | →         |    | RRC CONNECTION SETUP COMPLETE                                |                                                                                                                                                                                                                           |
|                                                                  |           |    |                                                              | "Establishment cause": Registration.                                                                                                                                                                                      |



| Step                                                                                                                                                                 | Direction |    | Message                         | Comments                                                                                                                                                                       |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                      | UE        | SS |                                 |                                                                                                                                                                                |
| 33                                                                                                                                                                   | →         |    | LOCATION-UPDATING REQUEST       | "location-updating-type" = normal, "CKSN" = no key available, "Mobile-Identity" = IMSI, "LAI" = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE). |
| 34                                                                                                                                                                   | ←         |    | AUTHENTICATION-REQUEST          | "CKSN" = CKSN1.                                                                                                                                                                |
| 35                                                                                                                                                                   | →         |    | AUTHENTICATION-RESPONSE         |                                                                                                                                                                                |
| 36                                                                                                                                                                   | ←         |    | LOCATION-UPDATING-ACCEPT        | "Mobile-Identity" = TMSI.                                                                                                                                                      |
| 37                                                                                                                                                                   | →         |    | TMSI-REALLOCATION COMPLETE      |                                                                                                                                                                                |
| 38                                                                                                                                                                   | ←         |    | RRC-CONNECTION-RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                             |
| 39                                                                                                                                                                   | →         |    | RRC-CONNECTION-RELEASE COMPLETE |                                                                                                                                                                                |
| NOTE: —The definitions for "Serving cell" and "non-suitable cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                                                |

### Specific message contents

None.

#### 9.2.2.5 Test requirement

1)-

1.1 At step 24 the UE shall not send any RRC CONNECTION REQUEST on cell A or on cell B.

1.2 At step 25 the UE shall not send any RRC CONNECTION REQUEST on cell A or on cell B.

1.3 At step 9 the UE shall not respond to paging.

1.4 At step 12 the UE shall not send any RRC CONNECTION REQUEST on cell A or on cell B.

1.5 At step 28 the UE shall not send any RRC CONNECTION REQUEST on cell A or on cell B.

2)- At step 14 the UE shall send a RRC CONNECTION REQUEST message with the establishment cause set to "emergency call"; and at step 17 the UE shall send a CM SERVICE REQUEST message with the "CM service type" set to "Emergency call establishment".

3)- At step 33 the UE shall perform location updating using its IMSI as mobile identity and indicates deleted LAI and CKSN.

### 9.2.3 Authentication rejected by the UE (MAC code failure)

#### 9.2.3.1 Definition

Following a UMTS authentication challenge, the UE may reject the core network, on the grounds of an incorrect AUTN parameter (see TS 33.102).

If the UE considers the MAC code (supplied by the core network in the AUTN parameter) to be invalid, it shall send an AUTHENTICATION FAILURE message to the network, with the reject cause 'MAC failure'.

#### 9.2.3.2 Conformance requirement

1)- A UE shall correctly respond to an AUTHENTICATION REQUEST message by sending an AUTHENTICATION FAILURE message with the reject cause 'MAC failure'. A UE shall correctly respond to an AUTHENTICATION REQUEST message with correct AUTN parameter by sending AUTHENTICATION RESPONSE message after identification procedure.

2)- Upon reception of an IDENTITY REQUEST message, the UE shall identify itself by sending an IDENTITY RESPONSE message including the IMSI to the network.

- 3) Upon receiving the second AUTHENTICATION REQUEST message from the network, the UE shall stop the timer T3214, if running, and then process the challenge information as normal. Upon successfully validating the network (an AUTHENTICATION REQUEST that contains a valid MAC is received), the UE shall send the AUTHENTICATION RESPONSE message to the network and shall start any retransmission timers (e.g. T3210, T3220 or T3230), if they were running and stopped when the UE received the first AUTHENTICATION REQUEST message containing an invalid MAC.

#### Reference(s)

TS 24.008 clauses 4.3.2.5.1 and 4.3.2.6 (c)

#### 9.2.3.3 ————— Test purpose

- 1) To check that a UE shall correctly respond to an AUTHENTICATION REQUEST message by sending an AUTHENTICATION FAILURE message with the reject cause 'MAC failure'. A UE shall correctly respond to an AUTHENTICATION REQUEST message with correct AUTN parameter by sending AUTHENTICATION RESPONSE message after identification procedure.
- 2) To verify that upon reception of an IDENTIFY REQUEST message the UE identifies itself by sending an IDENTIFY RESPONSE message including the IMSI to the network.
- 3) To verify that upon receiving the second AUTHENTICATION REQUEST message from the network, the UE shall stop the timer T3214, if running, and then process the challenge information as normal. To verify that upon successfully validating the network (an AUTHENTICATION REQUEST that contains a valid MAC is received), the UE sends the AUTHENTICATION RESPONSE message to the network.

#### 9.2.3.4 ————— Method of test

##### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE has valid TMSI, CKSN (CKSN1), CK, IK. It is "idle updated" on the cell.

##### Related ICS/IXIT statement(s)

None.

##### Test procedure

The UE rejects an authentication. The AUTHENTICATION FAILURE is sent by UE. Upon receipt of the AUTHENTICATION FAILURE message. The SS initiates identification procedure. The UE responded to the SS by sending IDENTIFY RESPONSE message. The SS sends AUTHENTICATION REQUEST message with correct AUTN parameter.

## Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                                                                                                                                                                                                                           |
|------|-----------|----|--------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                                                                                                                                                                                                                    |
| 1    |           |    | Mobile-terminated-establishment of Radio-Resource Connection | See TS 34.108 clause 7.1.2<br>Establishment-Cause: Terminating-Conversational-Call.<br>CKSN = CKSN1<br>with the AUTN-parameter having an invalid MAC-code<br>with reject cause "MAC failure"<br><br>with the AUTN-parameter having a correct MAC-code<br>"Auth.parameter RES" IE shall be bit exact with the value<br>as produced by the authentication algorithm. |
| 2    | →         |    | PAGING-RESPONSE                                              |                                                                                                                                                                                                                                                                                                                                                                    |
| 3    | ←         |    | AUTHENTICATION-REQUEST                                       |                                                                                                                                                                                                                                                                                                                                                                    |
| 4    | →         |    | AUTHENTICATION-FAILURE                                       |                                                                                                                                                                                                                                                                                                                                                                    |
| 5    | ←         |    | IDENTITY-REQUEST                                             |                                                                                                                                                                                                                                                                                                                                                                    |
| 6    | →         |    | IDENTITY-RESPONSE(IMSI)                                      |                                                                                                                                                                                                                                                                                                                                                                    |
| 7    | ←         |    | AUTHENTICATION-REQUEST                                       |                                                                                                                                                                                                                                                                                                                                                                    |
| 8    | →         |    | AUTHENTICATION-RESPONSE                                      |                                                                                                                                                                                                                                                                                                                                                                    |
| 9    | ←         |    | RRC-CONNECTION-RELEASE                                       |                                                                                                                                                                                                                                                                                                                                                                    |
| 10   | →         |    | RRC-CONNECTION-RELEASE COMPLETE                              |                                                                                                                                                                                                                                                                                                                                                                    |

## Specific message contents

None.

## 9.2.3.5 ————— Test requirement

- 1) At step 4 the UE shall send AUTHENTICATION-FAILURE message with reject cause set to "MAC failure".
- 2) At step 6 the UE shall send an IDENTITY-RESPONSE message including the IMSI.
- 3) At step 8 the UE shall send an AUTHENTICATION-RESPONSE message.

## 9.2.4 — Authentication rejected by the UE (SQN failure)

## 9.2.4.1 ————— Definition

Following a UMTS authentication challenge, the UE may reject the core network, on the grounds of an incorrect AUTN parameter (see TS 33.102).

If the UE considers the SQN (supplied by the core network in the AUTN parameter) to be out of range, it shall send an AUTHENTICATION-FAILURE message to the network, with the reject cause 'Synch failure' and a re-synchronisation token AUTS provided by the USIM (see TS 33.102).

## 9.2.4.2 ————— Conformance requirement

- 1) A UE shall correctly respond to an AUTHENTICATION-REQUEST message by sending an AUTHENTICATION-FAILURE message with the reject cause 'Synch failure' and parameter (AUTS) provided by the USIM (see TS 33.102).
- 2) Upon successfully validating the network (a second AUTHENTICATION-REQUEST is received which contains a valid SQN) while T3216 is running, the UE shall send the AUTHENTICATION-RESPONSE message to the network and shall start any retransmission timers (e.g. T3210, T3220 or T3230), if they were running and stopped when the UE received the first AUTHENTICATION-REQUEST message containing an invalid SQN.

## Reference(s)

TS 24.008 clause 4.3.2.5.1, 4.3.2.6 (d)

## 9.2.4.3 ————— Test purpose

- 1) To check that a UE shall correctly respond to an AUTHENTICATION-REQUEST message by sending an AUTHENTICATION-FAILURE message with the reject cause 'Synch failure' and parameter (AUTS) provided by the USIM (see TS 33.102).

- 2) To check that upon successfully validating the network (a second AUTHENTICATION REQUEST is received which contains a valid SQN) while T3216 is running, the UE shall send the AUTHENTICATION RESPONSE message to the network.

#### 9.2.4.4 Method of test

##### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE has valid TMSI, CKSN (CKSN1), CK, IK. It is "idle updated" on the cell.

##### Related ICS/IXIT statement(s)

None.

##### Test procedure

The SS sends an AUTHENTICATION REQUEST having an invalid SQN code (i.e. uses the predefined  $AMF_{RESYNCH}$  value to trigger the SQN re-synchronisation procedure, see TS 34.108 clause 8.1.2.2) to the UE. The SS verifies that the UE rejects the authentication.

The SS sends a second AUTHENTICATION REQUEST with a valid SQN code (i.e. uses an AMF value different from  $AMF_{RESYNCH}$  value, see TS 34.108 clause 8.1.2.2). The SS checks that the UE accepts the authentication request.

##### Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                       |
|------|-----------|----|--------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                |
| 1    |           |    | Mobile terminated establishment of Radio Resource Connection | See TS 34.108 clause 7.1.2<br>Establishment Cause: Terminating Conversational Call;                                                                            |
| 2    | →         |    | PAGING-RESPONSE                                              | CKSN = CKSN1                                                                                                                                                   |
| 3    | ←         |    | AUTHENTICATION REQUEST                                       | with the AMF information field set to $AMF_{RESYNCH}$ value to trigger SQN re-synchronisation procedure in test USIM, see TS 34.108 clause 8.1.2.2.            |
| 4    | →         |    | AUTHENTICATION FAILURE                                       | including the AUTS parameter and with the reject cause set to 'Synch failure'                                                                                  |
| 5    | ←         |    | AUTHENTICATION REQUEST                                       | with the AMF information field set to value different from $AMF_{RESYNCH}$ value to cause test USIM to treat SQN value as valid, see TS 34.108 clause 8.1.2.2. |
| 6    | →         |    | AUTHENTICATION RESPONSE                                      | "Auth. parameter RES" IE shall be bit exact with the value as produced by the authentication algorithm.                                                        |
| 7    | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                |
| 8    | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                |

##### Specific message contents

None.

#### 9.2.4.5 Test requirement

- 1) At step 4 the UE shall reject an authentication and the AUTHENTICATION FAILURE is sent to SS with reject cause "Synch failure".
- 2) At step 6 the UE shall send an AUTHENTICATION RESPONSE message with the RES information field set to the same value as the XRES calculated by SS.

## 9.3 Identification

The purpose of this procedure is to check that the UE gives its identity as requested by the network. If this procedure does not work, it will not be possible for the network to rely on the identity claimed by the UE.

### 9.3.1 General Identification

#### 9.3.1.1 Definition

#### 9.3.1.2 Conformance requirement

- 1) When requested by the network the UE shall send its IMSI.
- 2) When requested by the network the UE shall send the TMSI which it was previously allocated.
- 3) When requested by the network the UE shall send its IMEI as stored in the UE.
- 4) When requested by the network the UE shall send its IMEISV as stored in the UE.

#### Reference(s)

TS 24.008 clause 4.3.3.

#### 9.3.1.3 Test purpose

- 1) To verify that the UE sends identity information as requested by the system in the following cases: IMSI and TMSI are requested in non-security mode, IMEI is requested in security mode.
- 2) To verify that the UE sends its IMEI, when requested to do so, in non-security mode.
- 3) To verify that the UE sends its IMEISV, when requested to do so, in non-security mode.

#### 9.3.1.4 Method of test

##### 9.3.1.4.1 Identification / test 1

#### Initial conditions

- System Simulator:
  - 1 cell, default values.
- User Equipment:
  - the UE has a valid TMSI. It is "idle-updated" on the cell.

#### Related ICS/IXIT statement(s)

IMEI of the UE.

#### Test Procedure

The SS requests identity information from the UE:

- IMSI in non-security mode;
- allocated TMSI in non-security mode;
- IMEI in security mode.

## Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                           |
|------|-----------|----|--------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                    |
| 1    |           | ←  | Mobile-terminated-establishment of Radio Resource Connection | See TS 34.108 clause 7.1.2<br>Establishment Cause: Terminating Conversational Call.                |
| 2    |           | →  | PAGING RESPONSE                                              |                                                                                                    |
| 3    |           | ←  | IDENTITY REQUEST                                             | "Identity type" IE is IMSI.                                                                        |
| 4    |           | →  | IDENTITY RESPONSE                                            | "Mobile identity" IE specifies the IMSI of the UE.                                                 |
| 5    |           | ←  | IDENTITY REQUEST                                             | "Identity type" IE is TMSI.                                                                        |
| 6    |           | →  | IDENTITY RESPONSE                                            | "Mobile identity" IE specifies the allocated TMSI of the UE.                                       |
| 7    |           | ←  | SECURITY MODE COMMAND                                        |                                                                                                    |
| 8    |           | →  | SECURITY MODE COMPLETE                                       |                                                                                                    |
| 9    |           | ←  | IDENTITY REQUEST                                             | "Identity type" IE is IMEI.                                                                        |
| 10   |           | →  | IDENTITY RESPONSE                                            | "Mobile identity" IE specifies the IMEI stored in the UE.                                          |
| 11   |           | ←  | RRC CONNECTION RELEASE                                       | After the sending of this message, the SS waits for the disconnection of the main signalling link. |
| 12   |           | →  | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                    |

## Specific message contents

None.

## 9.3.1.4.2 Identification / test 2

## Initial conditions

— System Simulator:

— 1 cell, default values.

— User Equipment:

— the UE has a valid TMSI. It is in "idle updated".

## Related ICS/IXIT statement(s)

IMEI of the UE.

IMEISV of the UE.

## Test Procedure

The SS requests identity information from the UE:

— IMEI in non-security mode;

— IMEISV in non-security mode.

## Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                                                                                                                                                                                                                                    |
|------|-----------|----|--------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                                                                                                                                                                                                                             |
| 1    |           | ←  | Mobile-terminated establishment of Radio-Resource Connection | See TS 34.108 clause 7.1.2<br>Establishment Cause: Terminating Conversational Call.<br><br>"Identity type" IE is IMEI.<br>"Mobile identity" IE specifies the IMEI of the UE.<br>"Identity type" IE is IMEISV.<br>"Mobile identity" IE specifies the IMEISV of the UE.<br>After the sending of this message, the SS waits for the disconnection of the main signalling link. |
| 2    |           | →  | PAGING RESPONSE                                              |                                                                                                                                                                                                                                                                                                                                                                             |
| 3    |           | ←  | IDENTITY REQUEST                                             |                                                                                                                                                                                                                                                                                                                                                                             |
| 4    |           | →  | IDENTITY RESPONSE                                            |                                                                                                                                                                                                                                                                                                                                                                             |
| 5    |           | ←  | IDENTITY REQUEST                                             |                                                                                                                                                                                                                                                                                                                                                                             |
| 6    |           | →  | IDENTITY RESPONSE                                            |                                                                                                                                                                                                                                                                                                                                                                             |
| 7    |           | ←  | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                                                                                                                                                                             |
| 8    |           | →  | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                                                                                                                                                                             |

## Specific message contents

None.

## 9.3.1.5 Test requirement

- 1) At step 4 in test 1 and test 2 the UE shall send its IMSI.
- 2) At step 6 in test 1 the UE shall send the TMSI which it was previously allocated.
- 3) At step 10 in test 1 the UE shall send its IMEI as stored in the UE.
- 4) At step 6 in test 2 the UE shall send its IMEISV as stored in the UE.

## 9.3.2 Handling of IMSI shorter than the maximum length

## 9.3.2.1 Definition

## 9.3.2.2 Conformance requirement

The UE shall be capable of handling an IMSI that is not of the maximum length.

## Reference(s)

TS 24.008 clause 10.5.1.4.

## 9.3.2.3 Test purpose

To check that the UE behaves correctly when activated with an IMSI of length less than the maximum length.

In this condition, the UE shall:

- perform location updating;
- answer to paging with IMSI;
- give the correct IMSI when asked by an IDENTITY REQUEST;
- attempt CM connection establishment when requested to;
- attempt call re-establishment when needed;
- attempt IMSI detach when needed;
- erase its TMSI when the IMSI is sent by the network in a LOCATION UPDATING ACCEPT or a TMSI REALLOCATION COMMAND message.

### 9.3.2.4 ~~Method of test~~

#### ~~Initial conditions~~

- ~~— System Simulator:~~
  - ~~— 1 cell, default values;~~
  - ~~— IMSI attach/detach bit set to "1".~~
- ~~— User Equipment:~~
  - ~~— the UE has no valid TMSI;~~
  - ~~— it is "idle-updated";~~
  - ~~— the IMSI has the value 001011234.~~

#### ~~Related ICS/IXIT statement(s)~~

~~On/Off switch – Yes/No.~~

#### ~~Foreseen final state of UE~~

~~The UE has no valid TMSI. It is in "idle-updated".~~

#### ~~Test Procedure~~

~~The UE is paged with its IMSI. The UE shall answer to paging and include the correct IMSI in the PAGING RESPONSE message. During call establishment, the SS asks for the IMSI of the UE. The UE shall answer by an IDENTITY RESPONSE message including the correct IMSI. During the active phase of the call, the SS modifies the scrambling code of DL DPCH. The UE performs call re-establishment. The UE shall include the correct IMSI in the CM-RE-ESTABLISHMENT message, a TMSI REALLOCATION COMMAND including a TMSI is sent to the UE. The UE acknowledges this message. The call is release.~~

~~The UE is paged with its TMSI. The UE shall answer to paging and includes its TMSI in the PAGING RESPONSE message. During call establishment, the SS sends a TMSI REALLOCATION COMMAND including the IMSI to the UE. The UE shall acknowledge this message. The UE shall erase its TMSI. The call is released.~~

~~The UE is switched off or has its power source removed. The UE performs IMSI detach. The UE shall include the correct IMSI in the IMSI DETACH INDICATION message.~~

~~The UE is switched on or powered on. The UE performs IMSI attach. The UE shall include the correct IMSI in the LOCATION UPDATING REQUEST message. A TMSI is allocated to the UE.~~

~~The LAC of the cell is changed. The UE performs location updating. The SS includes the IMSI in the LOCATION UPDATING ACCEPT message.~~

~~A mobile-originated CM connection is attempted. The UE shall include the correct IMSI in the CM SERVICE REQUEST message.~~



## Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                                                             |
|------|-----------|----|--------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                      |
| 1    |           | ←  | Mobile terminated establishment of Radio Resource Connection | See TS 34.108 clause 7.1.2<br>"Initial UE identity" IE contains IMSI of UE.<br>Establishment cause: Terminating Conversational Call. |
| 2    |           | →  | PAGING RESPONSE                                              | "mobile identity" contains the IMSI of the UE.                                                                                       |
| 3    |           | ←  | IDENTITY REQUEST                                             | "identity type" IE is IMSI.                                                                                                          |
| 4    |           | →  | IDENTITY RESPONSE                                            | "mobile identity" IE contains the IMSI of the UE.                                                                                    |
| 5    |           |    |                                                              | The call is established using the sequence of the generic terminating call set-up procedure.                                         |
| 6    |           | SS |                                                              | The SS modifies the scrambling code of DL-DPCH for generating lower layer failure.                                                   |
| 6a   |           | →  | CELL UPDATE                                                  | CCCH.                                                                                                                                |
| 6b   |           | ←  | RRC CONNECTION RELEASE                                       | CCCH.                                                                                                                                |
| 6c   |           | SS |                                                              | The SS re-modifies the scrambling code of DL-DPCH to the original one.                                                               |
| 7    |           | →  | RRC CONNECTION REQUEST                                       |                                                                                                                                      |
| 8    |           | ←  | RRC CONNECTION SETUP                                         |                                                                                                                                      |
| 9    |           | →  | RRC CONNECTION SETUP COMPLETE                                |                                                                                                                                      |
| 10   |           | →  | CM REESTABLISHMENT REQUEST                                   | "mobile identity" IE contains IMSI of the UE.                                                                                        |
| 10a  |           | ←  | AUTHENTICATION REQUEST                                       |                                                                                                                                      |
| 10b  |           | →  | AUTHENTICATION RESPONSE                                      |                                                                                                                                      |
| 10c  |           | ←  | SECURITY MODE COMMAND                                        |                                                                                                                                      |
| 10d  |           | →  | SECURITY MODE COMPLETE                                       |                                                                                                                                      |
| 11   |           | ←  | TMSI REALLOCATION COMMAND                                    | "mobile identity" contains a TMSI.                                                                                                   |
| 12   |           | →  | TMSI REALLOCATION COMPLETE                                   |                                                                                                                                      |
| 13   |           | ←  | RRC CONNECTION RELEASE                                       | After sending this message, the SS waits for the disconnection of the main signalling link.                                          |
| 14   |           | →  | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                      |
| 15   |           | ←  | Mobile terminated establishment of Radio Resource Connection | See TS 34.108 clause 7.1.2<br>"Initial UE identity" IE contains TMSI of UE.<br>Establishment cause: Terminating Conversational Call. |
| 16   |           | →  | PAGING RESPONSE                                              | "mobile identity" contains the TMSI of the UE.                                                                                       |
| 17   |           | ←  | AUTHENTICATION REQUEST                                       |                                                                                                                                      |
| 18   |           | →  | AUTHENTICATION RESPONSE                                      |                                                                                                                                      |
| 18a  |           | ←  | SECURITY MODE COMMAND                                        |                                                                                                                                      |
| 18b  |           | →  | SECURITY MODE COMPLETE                                       |                                                                                                                                      |
| 19   |           | ←  | TMSI REALLOCATION COMMAND                                    | "mobile identity" contains a IMSI of UE.                                                                                             |
| 20   |           | →  | TMSI REALLOCATION COMPLETE                                   |                                                                                                                                      |
| 21   |           | ←  | RRC CONNECTION RELEASE                                       |                                                                                                                                      |
| 22   |           | →  | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                      |
| 23   | UE        |    |                                                              | If possible (see ICS) the UE is switched off, otherwise the UE has its power source removed.                                         |
| 24   |           | →  | RRC CONNECTION REQUEST                                       | If the UE was switched off it performs IMSI detach.<br>"Establishment cause": Detach                                                 |
| 25   |           | ←  | RRC CONNECTION SETUP                                         |                                                                                                                                      |
| 26   |           | →  | RRC CONNECTION SETUP COMPLETE                                |                                                                                                                                      |
| 27   |           | →  | IMSI DETACH INDICATION                                       | "mobile identity" contains IMSI of UE.                                                                                               |
| 28   |           | ←  | RRC CONNECTION RELEASE                                       |                                                                                                                                      |
| 29   |           | →  | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                      |
| 30   | UE        |    |                                                              | The UE is switched on or has power restored.                                                                                         |
| 31   |           | →  | RRC CONNECTION REQUEST                                       |                                                                                                                                      |
| 32   |           | ←  | RRC CONNECTION SETUP                                         |                                                                                                                                      |
| 33   |           | →  | RRC CONNECTION SETUP COMPLETE                                |                                                                                                                                      |

| Step | Direction |    | Message                         | Comments                                           |
|------|-----------|----|---------------------------------|----------------------------------------------------|
|      | UE        | SS |                                 |                                                    |
| 34   | →         |    | LOCATION-UPDATING REQUEST       | "mobile identity" contains IMSI of UE.             |
| 35   | ←         |    | LOCATION-UPDATING-ACCEPT        | "mobile identity" contains a TMSI.                 |
| 36   | →         |    | TMSI-REALLOCATION COMPLETE      |                                                    |
| 37   | ←         |    | RRC-CONNECTION-RELEASE          |                                                    |
| 38   | →         |    | RRC-CONNECTION-RELEASE COMPLETE |                                                    |
| 39   |           | SS |                                 | The SS changes the LAC of the cell.                |
| 40   | →         |    | RRC-CONNECTION-REQUEST          | Shall be sent within 35s of the LAC being changed. |
| 41   | ←         |    | RRC-CONNECTION-SETUP            |                                                    |
| 42   | →         |    | RRC-CONNECTION-SETUP COMPLETE   |                                                    |
| 43   | →         |    | LOCATION-UPDATING REQUEST       | "mobile identity" contains TMSI of the UE.         |
| 44   | ←         |    | LOCATION-UPDATING-ACCEPT        | "mobile identity" contains IMSI of the UE.         |
| 45   | ←         |    | RRC-CONNECTION-RELEASE          |                                                    |
| 46   | →         |    | RRC-CONNECTION-RELEASE COMPLETE |                                                    |
| 47   |           | UE |                                 | a mobile-originated CM connection is attempted.    |
| 48   | →         |    | RRC-CONNECTION-REQUEST          |                                                    |
| 49   | ←         |    | RRC-CONNECTION-SETUP            |                                                    |
| 50   | →         |    | RRC-CONNECTION-SETUP COMPLETE   |                                                    |
| 51   | →         |    | CM-SERVICE-REQUEST              | "mobile identity" contains IMSI of the UE.         |
| 52   | ←         |    | RRC-CONNECTION-RELEASE          |                                                    |
| 53   | →         |    | RRC-CONNECTION-RELEASE COMPLETE |                                                    |

### Specific message contents

None.

#### 9.3.2.5 Test requirement

At step 34 the UE shall perform location updating.

At step 2 the UE shall answer to paging with IMSI.

At step 4 the UE shall answer the correct IMSI to the SS by an IDENTITY RESPONSE message.

At step 51 the UE shall attempt CM connection establishment and include the correct IMSI in the CM SERVICE REQUEST message.

At step 10 the UE shall perform call re-establishment with the correct IMSI in the CM RE-ESTABLISHMENT message.

At step 19 the IMSI is sent by the network in a TMSI REALLOCATION COMMAND message, at step 27 the UE shall attempt IMSI detach.

At step 44 the IMSI is sent by the network in a LOCATION-UPDATING-ACCEPT message, at step 51 the UE shall attempt IMSI detach.

## 9.4 Location updating

This procedure is used to register the UE in the network. If it is not performed correctly, no call can be established.

## ~~9.4.1 Location updating / accepted~~

### ~~9.4.1.1 Definition~~

### ~~9.4.1.2 Conformance requirement~~

~~1.~~

~~1.1 if the network accepts a location updating from the UE and reallocates a TMSI in the LOCATION UPDATING ACCEPT message the UE shall acknowledge the reception of the new TMSI;~~

~~1.2 the UE shall answer to paging with this TMSI and include it in a PAGING RESPONSE message.~~

~~2 If the network accepts a location updating from the UE and the LOCATION UPDATING ACCEPT message contains neither TMSI nor IMSI, the UE shall answer to paging when addressed with the last allocated TMSI and include it in the PAGING RESPONSE message.~~

~~3.~~

~~3.1 if the network accepts a location updating from the UE by use of a LOCATION UPDATING ACCEPT message containing the IMSI of the UE, the UE shall not answer paging with the last allocated TMSI;~~

~~3.2 the UE shall still answer paging with IMSI.~~

### Reference(s)

TS 24.008 clause 4.4.4.6.

### ~~9.4.1.3 Test purpose~~

~~1) To test the behaviour of the UE if the network accepts the location updating of the UE.~~

For the network response three different cases are identified:

~~1.1) TMSI is allocated;~~

~~1.2) location updating accept contains neither TMSI nor IMSI;~~

~~1.3) location updating accept contains IMSI.~~

### ~~9.4.1.4 Method of test~~

~~Initial conditions:~~

~~— System Simulator:~~

~~— two cells, A and B, belonging to different location areas with location area identification a and b of the same PLMN;~~

~~— IMSI attach/detach is allowed in both cells;~~

~~— the T3212 time-out value is 1/10 hour in both cells.~~

~~— User Equipment:~~

~~— the UE has a valid TMSI (=TMSI1) and CKSN (=CKSN1). It is "idle updated" on cell A.~~

Related ICS/IXIT statement(s)

None.

## Test Procedure

The UE is made to select cell B. A normal location updating with TMSI reallocation is performed in cell B. The RRC CONNECTION is released. The SS checks, by paging, that the UE has stored the newly allocated TMSI. The RRC CONNECTION is released. The UE is made to select cell A. A normal location updating is performed in cell A. The LOCATION UPDATING ACCEPT message contains neither IMSI nor TMSI. The SS checks, by paging, that the UE has kept the old TMSI. The RRC CONNECTION is released. The UE is made to select cell B. A normal location updating is performed in cell B. The LOCATION UPDATING ACCEPT message contains an IMSI. The SS checks, by paging, that the UE has deleted its TMSI and responds to paging with IMSI.

## Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                                                  |
|------|-----------|----|--------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                                           |
| 1    |           | SS |                                                              | Set the cell type of cell B to the "Serving cell".<br>Set the cell type of cell A to the "non-suitable cell".<br>(see note)                                                               |
| 2    | →         |    | RRC CONNECTION REQUEST                                       | "Establishment cause": Registration.                                                                                                                                                      |
| 3    | ←         |    | RRC CONNECTION SETUP                                         |                                                                                                                                                                                           |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE                                |                                                                                                                                                                                           |
| 5    | →         |    | LOCATION UPDATING REQUEST                                    | "location-updating type" = normal, "CKSN" = CKSN1,<br>"location-area identification" = a, "mobile station classmark 1" as given by the ICS and "mobile-identity" = TMSI1.                 |
| 5a   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                                           |
| 5b   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                           |
| 6    | ←         |    | LOCATION UPDATING ACCEPT                                     | "Mobile identity" = new TMSI (=TMSI2), LAI = b.                                                                                                                                           |
| 7    | →         |    | TMSI REALLOCATION COMPLETE                                   |                                                                                                                                                                                           |
| 8    | ←         |    | RRC CONNECTION RELEASE                                       | After the sending of this message, the SS waits for the disconnection of the main signalling link. The SS waits an amount of time which is enough to guarantee that the UE is in service. |
| 9    | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                           |
| 10   | ←         |    | Mobile-terminated establishment of Radio-Resource Connection | See TS 34.108 clause 7.1.2                                                                                                                                                                |
| 11   | →         |    | PAGING RESPONSE                                              | "Initial UE identity" IE contains the new TMSI (= TMSI2).<br>Establishment Cause: Terminating Conversational Call.                                                                        |
| 12   | ←         |    | RRC CONNECTION RELEASE                                       | "Mobile identity" IE contains the new TMSI (= TMSI2).<br>After the sending of this message, the SS waits for the disconnection of the main signalling link.                               |
| 13   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                           |
| 14   |           | SS |                                                              | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "non-suitable cell".<br>(see note)                                                               |
| 15   | →         |    | RRC CONNECTION REQUEST                                       | "Establishment cause": Registration                                                                                                                                                       |
| 16   | ←         |    | RRC CONNECTION SETUP                                         |                                                                                                                                                                                           |
| 17   | →         |    | RRC CONNECTION SETUP COMPLETE                                |                                                                                                                                                                                           |
| 18   | →         |    | LOCATION UPDATING REQUEST                                    | "location-updating type" = normal, "CKSN" = CKSN1,<br>"location-area identification" = b, "mobile station classmark 1" as given by the ICS and "mobile-identity" = TMSI2.                 |
| 19   | ←         |    | LOCATION UPDATING ACCEPT                                     | "Mobile identity" IE not included.                                                                                                                                                        |
| 20   | ←         |    | RRC CONNECTION RELEASE                                       | After the sending of this message, the SS waits for the disconnection of the main signalling link. The SS waits an amount of time which is enough to guarantee that the UE is in service. |
| 21   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                           |
| 22   | ←         |    | Mobile-terminated establishment of Radio-Resource Connection | See TS 34.108 clause 7.12.2                                                                                                                                                               |
| 23   | →         |    | PAGING RESPONSE                                              | "Initial UE identity" IE contains the TMSI (= TMSI2).<br>Establishment Cause: Terminating Conversational Call.<br>"Mobile identity" IE contains the TMSI (=TMSI2).                        |

| Step                                                                                                                                                                 | Direction |    | Message                                                      | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|--------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                      | UE        | SS |                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 24                                                                                                                                                                   | ←         |    | RRC CONNECTION RELEASE                                       | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 25                                                                                                                                                                   | →         |    | RRC CONNECTION RELEASE COMPLETE                              | Set the cell type of cell B to the "Serving cell".<br>Set the cell type of cell A to the "non-suitable cell".<br>(see note)<br>"Establishment cause": Registration.<br><br>"location-updating type" = normal, "CKSN" = CKSN1,<br>"location-area identification" = a, "mobile station classmark 1" as given by the ICS and "mobile identity" = TMSI2.<br>"Mobile identity" IE contains IMSI.<br>After the sending of this message, the SS waits for the disconnection of the main signalling link. The SS waits an amount of time which is enough to guarantee that the UE is in-service. |
| 26                                                                                                                                                                   | SS        |    |                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 27                                                                                                                                                                   | →         |    | RRC CONNECTION REQUEST                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 28                                                                                                                                                                   | ←         |    | RRC CONNECTION SETUP                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 29                                                                                                                                                                   | →         |    | RRC CONNECTION SETUP COMPLETE                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 30                                                                                                                                                                   | →         |    | LOCATION UPDATING REQUEST                                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 31                                                                                                                                                                   | ←         |    | LOCATION UPDATING ACCEPT                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 32                                                                                                                                                                   | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 33                                                                                                                                                                   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 34                                                                                                                                                                   | ←         |    | PAGING TYPE 1                                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 35                                                                                                                                                                   | UE        |    | Mobile terminated establishment of Radio Resource Connection |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 36                                                                                                                                                                   | ←         |    |                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 37                                                                                                                                                                   | →         |    |                                                              | PAGING RESPONSE                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 38                                                                                                                                                                   | ←         |    |                                                              | RRC CONNECTION RELEASE                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| 39                                                                                                                                                                   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| NOTE: —The definitions for "Serving cell" and "non-suitable cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

### Specific message contents

None.

### 9.4.1.5 Test requirement

At step 7 the UE shall acknowledge the reception of the new TMSI (TMSI2).

At step 11 the UE shall answer to paging with this TMSI (TMSI2).

At step 23 the UE shall answer to paging with the last allocated TMSI (TMSI2).

At step 35 the UE shall not answer paging with the last allocated TMSI, but at step 37 the UE shall still answer paging with IMSI.

## 9.4.2 Location updating / rejected

### 9.4.2.1 Location updating / rejected / IMSI invalid

#### 9.4.2.1.1 Definition

#### 9.4.2.1.2 Conformance requirement

- 1) If the network rejects a location updating from the UE with the cause "IMSI unknown in HLR", "Illegal MS" or "Illegal ME" the UE shall:
  - 1.1 not perform normal location updating;
  - 1.2 not perform periodic location updating;
  - 1.3 not respond to paging with IMSI;
  - 1.4 not respond to paging with TMSI;
  - 1.5 reject any request from CM entity for MM connection other than for emergency call;
  - 1.6 not perform IMSI detach if it is switched off or has its power source removed.
- 2) If the network rejects a location updating from the UE with the cause "IMSI unknown in HLR", "Illegal MS" or "Illegal ME" the UE, if it supports speech, shall accept a request for an emergency call by sending a RRC CONNECTION Request message with the establishment cause set to "emergency call" and include an IMEI as mobile identity in the CM SERVICE REQUEST message.
- 3) If the network rejects a location updating from the UE with the cause "IMSI unknown in HLR", "Illegal MS" or "Illegal ME" the UE shall delete the stored LAI, CKSN and TMSI.

#### Reference(s)

TS 24.008 clause 4.4.4.7.

#### 9.4.2.1.3 Test purpose

To test the behaviour of the UE if the network rejects the location updating of the UE with the cause "IMSI unknown in HLR", "illegal MS" or "Illegal ME".

#### 9.4.2.1.4 Method of test

##### Initial conditions

- System Simulator:
  - two cells: A and B, belonging to different location areas of the same PLMN;
  - IMSI attach/detach is allowed in both cells;
  - the T3212 time-out value is 1/10 hour in both cells.
- User Equipment:
  - the UE has valid TMSI, CKSN and CK, IK. It is "idle updated" on cell A.

##### Related ICS/IXIT statement(s)

USIM removal possible while the UE is powered Yes/No.

Switch off on button Yes/No.

Support for speech Yes/No.

### Test Procedure

The SS rejects a normal location updating with the cause value "IMSI unknown in HLR". The RRC CONNECTION is released. The SS checks that the UE has entered the state MM IDLE and the substate NO IMSI, i.e. does not perform normal location updating when a new cell of the same or another PLMN is entered, does not perform periodic updating, does not respond to paging, rejects any requests from CM entities except emergency calls and does not perform IMSI detach if it is switched off or has its power source removed.

The test is repeated with cause value "Illegal MS" and with cause value "Illegal ME".

## Expected sequence

The sequence is executed for execution-counter  $k = 1, 2, 3$ .

| Step                            | Direction |    | Message                         | Comments                                                                                                                                                                                                  |
|---------------------------------|-----------|----|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                 | UE        | SS |                                 |                                                                                                                                                                                                           |
| 1                               |           | SS |                                 | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell B to the "Serving cell".<br>Set the cell type of cell A to the "non-suitable cell".<br>(see note)           |
| 2                               | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.                                                                                                                                                                      |
| 3                               | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                           |
| 4                               | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                           |
| 5                               | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                           |
| 6                               | ←         |    | LOCATION UPDATING REJECT        | "Reject cause" IE is "IMSI unknown in HLR" for $k = 1$ , "Illegal MS" for $k = 2$ , "Illegal ME" for $k = 3$ .                                                                                            |
| 7                               | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                        |
| 8                               | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                           |
| 9                               |           | SS |                                 | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "non-suitable cell".<br>(see note)           |
| 10                              |           | UE |                                 | The UE performs cell reselection according to procedure as specified in (this however is not checked until step 23).<br>The UE shall not initiate an RRC connection establishment on cell A or on cell B. |
| 11                              |           | SS |                                 | The SS waits at least 7 minutes for a possible periodic updating.                                                                                                                                         |
| 12                              |           | UE |                                 | The UE shall not initiate an RRC connection establishment on cell A or on cell B.                                                                                                                         |
| 13                              | ←         |    | PAGING TYPE 1                   | The UE is paged in cell A. "UE identity" IE contains IMSI.<br>Paging Cause: Terminating Conversational Call.                                                                                              |
| 14                              |           | UE |                                 | The UE shall ignore this message. This is verified during 3 s.                                                                                                                                            |
| 15                              | ←         |    | PAGING TYPE 1                   | The UE is paged in cell A. "UE identity" IE contains TMSI.<br>Paging Cause: Terminating Conversational Call.                                                                                              |
| 16                              |           | UE |                                 | The UE shall ignore this message. This is verified during 3 s.                                                                                                                                            |
| 17                              |           | UE |                                 | A MO-CM connection is attempted.                                                                                                                                                                          |
| 18                              |           | UE |                                 | The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 3 s.                                                                                             |
| 19                              |           | UE |                                 | If the UE supports speech (see ICS), it is made to perform an emergency call.                                                                                                                             |
| 20                              | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Emergency call.                                                                                                                                                                    |
| This message is sent in cell A. |           |    |                                 |                                                                                                                                                                                                           |
| 21                              | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                           |
| 22                              | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                           |
| 23                              | →         |    | CM SERVICE REQUEST              | "CM service type": Emergency call establishment.<br>"Mobile identity": type of identity is set to IMEI.                                                                                                   |
| 24                              | ←         |    | CM SERVICE ACCEPT               |                                                                                                                                                                                                           |
| 25                              | →         |    | EMERGENCY SETUP                 |                                                                                                                                                                                                           |
| 26                              | ←         |    | RELEASE COMPLETE                | "Cause" = unassigned number.                                                                                                                                                                              |
| 27                              | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                        |
| 28                              | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                           |
| 29                              |           | UE |                                 | If possible (see ICS) USIM detachment is performed.<br>Otherwise if possible (see ICS) switch-off is performed.<br>Otherwise the power is removed.                                                        |



| Step                                                                                                                                                                  | Direction |    | Message                         | Comments                                                                                                                                                                                                                         |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                       | UE        | SS |                                 |                                                                                                                                                                                                                                  |
| 30                                                                                                                                                                    | UE        |    |                                 | The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 3 s.                                                                                                                    |
| 31                                                                                                                                                                    | UE        |    |                                 | Depending on what has been performed in step 31 the UE is brought back to operation.                                                                                                                                             |
| 32                                                                                                                                                                    | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.                                                                                                                                                                                             |
| 33                                                                                                                                                                    | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                  |
| 34                                                                                                                                                                    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                  |
| 35                                                                                                                                                                    | →         |    | LOCATION UPDATING REQUEST       | "location-updating-type" = normal, "CKSN" = no key available, "mobile-station-classmark-1" as given by the ICS, "Mobile-Identity" = IMSI, "LAI" = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE). |
| 36                                                                                                                                                                    | ←         |    | AUTHENTICATION REQUEST          | "CKSN" = CKSN1.                                                                                                                                                                                                                  |
| 37                                                                                                                                                                    | →         |    | AUTHENTICATION RESPONSE         |                                                                                                                                                                                                                                  |
| 38                                                                                                                                                                    | ←         |    | LOCATION UPDATING ACCEPT        | "Mobile-Identity" = TMSI.                                                                                                                                                                                                        |
| 39                                                                                                                                                                    | →         |    | TMSI REALLOCATION COMPLETE      |                                                                                                                                                                                                                                  |
| 40                                                                                                                                                                    | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                                               |
| 41                                                                                                                                                                    | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                  |
| NOTE: — The definitions for "Serving cell" and "non-suitable cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                                                                                                  |

#### Specific message contents

None.

#### 9.4.2.1.5 — Test requirement

- 1) 1.1 At step 10 the UE shall not perform normal location updating.
- 1.2 At step 12 the UE shall not perform periodic location updating.
- 1.3 At step 14 the UE shall not respond to paging with IMSI.
- 1.4 At step 16 the UE shall not respond to paging with TMSI.
- 1.5 At step 18 the UE shall reject a MO-CM connection.
- 1.6 At step 30 the UE shall not initiate an RRC connection establishment on cell A or on cell B.
- 2) At step 20 the UE shall accept a request for an emergency call with the establishment cause set to "Emergency call".
- 3) At step 35 the UE shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the LAI "deleted LAI".

#### 9.4.2.2 — Location updating / rejected / PLMN not allowed

##### 9.4.2.2.1 — Definition

##### 9.4.2.2.2 — Conformance requirement

- 1) If the network reject a location updating from the UE with the cause "PLMN not allowed" the UE shall:
  - 1.1 not perform periodic updating;
  - 1.2 not perform IMSI detach when switched off;

- ~~1.3 not perform IMSI attach when switched on in the same location area;~~
- ~~1.4 not perform normal location updating when in the same PLMN and when that PLMN is not selected manually;~~
- ~~1.5 reject any request from CM entity for MM connection other than for emergency call.~~
- ~~2) If the network rejects a location updating from the UE with the cause "PLMN not allowed" the UE shall:~~
  - ~~2.1 perform normal location updating when a new PLMN is entered;~~
  - ~~2.2 accept a request for an emergency call, if it supports speech, by sending a RRC CONNECTION REQUEST message with the establishment cause set to "emergency call".~~
- ~~3) If the network rejects a location updating from the UE with the cause "PLMN not allowed" and if after that the PLMN from which this rejection was received, is manually selected, the UE shall perform a normal location updating procedure.~~

#### Reference(s)

TS 24.008 clause 4.4.4.7.

#### ~~9.4.2.2.3 Test purpose~~

~~To test the behaviour of the UE if the network rejects the location updating of the UE with the cause "PLMN not allowed".~~

#### ~~9.4.2.2.4 Method of test~~

#### ~~9.4.2.2.4.1 Location updating / rejected / PLMN not allowed / test 1~~

#### Initial conditions

- ~~— System Simulator:~~
  - ~~— one cell: C, belonging to PLMN1;~~
  - ~~— two cells: A and B, belonging to different location areas a and b and belonging to PLMN2. PLMN2 is different from HPLMN and from PLMN1;~~
  - ~~— IMSI attach/detach is allowed in cells A and B but not in cell C;~~
  - ~~— the T3212 time-out value is 1/10 hour in cells A and B.~~
- ~~— User Equipment:~~
  - ~~— the UE has a valid TMSI. It is "idle-updated" on cell C;~~
  - ~~— the UE is in manual mode for PLMN selection.~~

#### Related ICS/IXIT statement(s)

~~USIM removal possible while the UE is powered Yes/No.~~

~~Switch-off on button Yes/No.~~

~~The UE is automatically in automatic mode after switch-on Yes/No.~~

~~Support for speech Yes/No.~~

#### Test Procedure

~~The SS rejects a normal location updating with the cause value "PLMN not allowed". The RRC CONNECTION is released. The SS checks that the UE does not perform periodic updating, does not perform IMSI detach, does not~~

perform IMSI attach if activated in the same location area, rejects any request for CM connection establishment other than emergency call, accepts a request for an emergency call and performs normal location updating only when a new PLMN is entered.

#### Expected sequence

| Step   | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|--------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        | UE        | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 1<br>2 | UE<br>SS  |    |                                 | <p>The following messages are sent and shall be received on cell B.</p> <p>The UE is switched off (or power is removed).</p> <p>Set the cell type of cell B to the "Serving cell".</p> <p>Set the cell type of cell A to the "Suitable neighbor cell".</p> <p>Set the cell type of cell C to the "non-suitable cell". (see note)</p> <p>The UE is switched on. (or power is reapplied) If necessary the UE is put in manual selection mode. The UE shall offer the new PLMN as available to the user. The PLMN is manually selected.</p> <p>"Establishment cause": Registration.</p> |
| 3      | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 4      | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 5      | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 6      | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 7      | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 8      | ←         |    | LOCATION UPDATING REJECT        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 9      | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 10     | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 11     | SS        |    |                                 | <p>The SS waits for a possible periodic updating for 7 minutes.</p> <p>The UE shall not initiate an RRC connection establishment on cell A or on cell B.</p>                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 12     | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 13     | UE        |    |                                 | <p>If possible (see ICS) USIM detachment is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.</p> <p>The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 3 s.</p>                                                                                                                                                                                                                                                                                                             |
| 14     | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 15     | UE        |    |                                 | <p>Depending on what has been performed in step 13 the UE is brought back to operation. The UE is not made to select PLMN 2.</p> <p>The UE shall not initiate an RRC connection establishment. This is checked during 3 s.</p>                                                                                                                                                                                                                                                                                                                                                       |
| 16     | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 17     | SS        |    |                                 | <p>The following message are sent and shall be received on cell A.</p> <p>Set the cell type of cell A to the "Serving cell".</p> <p>Set the cell type of cell B to the "Suitable neighbor cell". (see note)</p> <p>No access to the network shall be registered by the SS within one minute.</p>                                                                                                                                                                                                                                                                                     |
| 18     | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 19     | UE        |    |                                 | <p>If the UE supports speech (see ICS) it is made to perform an emergency.</p> <p>"Establishment cause": Emergency Call.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 20     | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 21     | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 22     | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 23     | →         |    | CM SERVICE REQUEST              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 24     | ←         |    | CM SERVICE ACCEPT               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 25     | →         |    | EMERGENCY SETUP                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 26     | ←         |    | RELEASE COMPLETE                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 27     | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 28     | →         |    | RRC CONNECTION RELEASE COMPLETE | <p>Cause IE: "unassigned number".</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                      |

| Step                                                                                                                                                                                            | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                              |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                                                 | UE        | SS |                                 |                                                                                                                                                                                                                                                                                       |
| 29<br>30                                                                                                                                                                                        | UE<br>UE  |    |                                 | A MO-CM connection is attempted.<br>The UE shall not initiate an RRC connection establishment. This is checked during 3 s.                                                                                                                                                            |
| 31<br>32                                                                                                                                                                                        | UE<br>SS  |    |                                 | The following messages are sent and shall be received on cell C.<br>The UE is switched off.<br>Set the cell type of cell C to the "Serving cell".<br>Set the cell type of cell A to the "non-suitable cell".<br>Set the cell type of cell B to the "non-suitable cell".<br>(see note) |
| 33                                                                                                                                                                                              | UE        |    |                                 | The UE is switched on. If necessary the UE is placed into the automatic mode.                                                                                                                                                                                                         |
| 34                                                                                                                                                                                              | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.                                                                                                                                                                                                                                                  |
| 35                                                                                                                                                                                              | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                       |
| 36                                                                                                                                                                                              | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                       |
| 37                                                                                                                                                                                              | →         |    | LOCATION UPDATING REQUEST       | "location-updating type" = normal, "CKSN" = no key available, "LAI" = deleted LAI (the MCC and MNC hold the values of PLMN1, the LAC is coded FFFE) "mobile identity" = IMSI.                                                                                                         |
| 38                                                                                                                                                                                              | ←         |    | LOCATION UPDATING ACCEPT        | "Mobile identity" = TMSI.                                                                                                                                                                                                                                                             |
| 39                                                                                                                                                                                              | →         |    | TMSI REALLOCATION COMPLETE      |                                                                                                                                                                                                                                                                                       |
| 40                                                                                                                                                                                              | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                                                                                                    |
| 41                                                                                                                                                                                              | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                       |
| NOTE: — The definitions for "Serving cell", "Suitable neighbor cell" and "non-suitable cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                                                                                                                                                       |

## Specific message contents:

None.

## 9.4.2.2.4.2 Location updating / rejected / PLMN not allowed / test 2

## Initial conditions

## — System Simulator:

- one cell C, belonging to PLMN1;
- two cells A and B, belonging to different location areas a and b and belonging to PLMN2. PLMN2 is different from HPLMN;
- IMSI attach/detach is allowed in cells A and B but not in cell C;
- the T3212 time-out value is 1/10 hour in cells A and B.

## — User Equipment:

- the UE has a valid TMSI. It is "idle-updated" on cell C.

## Related ICS/IXIT statement(s)

USIM removal possible while UE is powered Yes/No:

Switch off on button Yes/No:

The UE is automatically in automatic mode after switch on Yes/No:

### Test Procedure

The SS rejects a normal location updating with the cause value "PLMN not allowed". The RRC CONNECTION is released. Then the PLMN from which this rejection was received is manually selected and the SS checks that a normal location updating is performed.

## Expected sequence

| Step                                                                                                                                                                                            | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                                                         |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                                                 | UE        | SS |                                 |                                                                                                                                                                                                                                                                                                                  |
| 1                                                                                                                                                                                               | UE        |    |                                 | The following messages are sent and shall be received on cell B.<br>The UE is switched off (or power is removed).<br>Set the cell type of cell B to the "Serving cell".<br>Set the cell type of cell A to the "Suitable neighbor cell".<br>Set the cell type of cell C to the "non-suitable cell".<br>(see note) |
| 2                                                                                                                                                                                               | SS        |    |                                 |                                                                                                                                                                                                                                                                                                                  |
| 3                                                                                                                                                                                               | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                  |
| 3a                                                                                                                                                                                              | UE        |    |                                 | The UE is switched on (or power is reapplied).<br>If the UE is in manual mode, it shall offer the new PLMN as available to the user. In this case the PLMN is manually selected.                                                                                                                                 |
| 4                                                                                                                                                                                               | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.                                                                                                                                                                                                                                                                             |
| 5                                                                                                                                                                                               | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                  |
| 6                                                                                                                                                                                               | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                  |
| 7                                                                                                                                                                                               | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                  |
| 8                                                                                                                                                                                               | ←         |    | LOCATION UPDATING REJECT        | "Reject cause" = PLMN not allowed.                                                                                                                                                                                                                                                                               |
| 9                                                                                                                                                                                               | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                                                                                                                               |
| 10                                                                                                                                                                                              | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                  |
| 11                                                                                                                                                                                              | UE        |    |                                 | The UE is made to search for PLMNs and the PLMN indicated by the SS is manually selected.                                                                                                                                                                                                                        |
| 12                                                                                                                                                                                              | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.                                                                                                                                                                                                                                                                             |
| 13                                                                                                                                                                                              | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                  |
| 14                                                                                                                                                                                              | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                  |
| 15                                                                                                                                                                                              | →         |    | LOCATION UPDATING REQUEST       | "location updating type" = normal, "CKSN" = no key available, "LAI" = deleted LAI (the MCC and MNC hold the values of PLMN1, the LAC is coded FFFE) "mobile identity" = IMSI.                                                                                                                                    |
| 16                                                                                                                                                                                              | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                                                                                                                               |
| 17                                                                                                                                                                                              | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                  |
| The following messages are sent and shall be received on cell C.                                                                                                                                |           |    |                                 |                                                                                                                                                                                                                                                                                                                  |
| 18                                                                                                                                                                                              | UE        |    |                                 | The UE is switched off.<br>Set the cell type of cell C to the "Serving cell".<br>Set the cell type of cell A to the "non-suitable cell".<br>Set the cell type of cell B to the "non-suitable cell".<br>(see note)                                                                                                |
| 19                                                                                                                                                                                              | SS        |    |                                 |                                                                                                                                                                                                                                                                                                                  |
| 20                                                                                                                                                                                              | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                  |
| 21                                                                                                                                                                                              | →         |    | RRC CONNECTION REQUEST          | The UE is switched on. If necessary, the UE is put into the automatic mode.                                                                                                                                                                                                                                      |
| 22                                                                                                                                                                                              | ←         |    | RRC CONNECTION SETUP            | "Establishment cause": Registration.                                                                                                                                                                                                                                                                             |
| 23                                                                                                                                                                                              | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                  |
| 24                                                                                                                                                                                              | →         |    | LOCATION UPDATING REQUEST       | "location updating type" = normal, "CKSN" = no key available, "LAI" = deleted LAI (the MCC and MNC hold the values of PLMN1, the LAC is coded FFFE) "mobile identity" = IMSI.                                                                                                                                    |
| 25                                                                                                                                                                                              | ←         |    | LOCATION UPDATING ACCEPT        | "Mobile identity" = TMSI.                                                                                                                                                                                                                                                                                        |
| 26                                                                                                                                                                                              | →         |    | TMSI REALLOCATION COMPLETE      |                                                                                                                                                                                                                                                                                                                  |
| 27                                                                                                                                                                                              | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                                                                                                                               |
| 28                                                                                                                                                                                              | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                  |
| NOTE: — The definitions for "Serving cell", "Suitable neighbor cell" and "non-suitable cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                                                                                                                                                                                  |

### Specific message contents

None.

#### 9.4.2.2.5 ~~Test requirement~~

- 1) ~~1.1 At step 12 in test 1 the UE shall not perform periodic updating.~~
  - 1.2 ~~At step 14 in test 1 the UE shall not initiate an RRC connection establishment (IMSI detach).~~
  - 1.3 ~~At step 16 in test 1 the UE shall not initiate an RRC connection establishment (IMSI attach).~~
  - 1.4 ~~At step 16 in test 1 the UE shall not perform normal location updating.~~
  - 1.5 ~~At step 30 in test 1 the UE shall reject a MO CM connection.~~
- 2) ~~2.1 At step 37 in test 1 the UE shall perform normal location updating.~~
  - 2.2 ~~At step 20 in test 1 the UE shall accept a request for an emergency call with the establishment cause set to "Emergency call".~~
- 3) ~~At step 11 in test 2 the UE is made to search for PLMNs and the PLMN indicated by the SS is manually selected, and at step 15 the UE shall perform a normal location updating procedure.~~

#### 9.4.2.3 ~~Location updating / rejected / location area not allowed~~

##### 9.4.2.3.1 ~~Definition~~

##### 9.4.2.3.2 ~~Conformance requirement~~

- 1) ~~If the network rejects a location updating from the UE with the cause "Location Area not allowed" the UE shall:~~
  - 1.1 ~~not perform periodic updating;~~
  - 1.2 ~~not respond to paging with TMSI;~~
  - 1.3 ~~reject any request from CM entity for MM connection other than for emergency call;~~
  - 1.4 ~~not perform IMSI detach.~~
- 2) ~~If the network rejects a location updating from the UE with the cause "Location Area not allowed" the UE shall:~~
  - 2.1 ~~perform normal location updating when a new location area is entered;~~
  - 2.2 ~~accept a request for an emergency call, if it supports speech, by sending a RRC CONNECTION REQUEST message with the establishment cause set to "emergency call";~~
  - 2.3 ~~delete the list of forbidden LAs after switch off (power off).~~

### Reference(s)

TS 24.008 clause 4.4.4.7.

#### 9.4.2.3.3 ~~Test purpose~~

~~To test the behaviour of the UE if the network rejects the location updating of the UE with the cause "Location Area not allowed".~~

~~To test that the UE deletes the list of forbidden LAs after switch off (power off).~~

#### 9.4.2.3.4 ~~Method of test~~

##### ~~Initial conditions~~

- ~~— System Simulator:~~
  - ~~— two cells: A and B, belonging to different location areas a and b;~~
  - ~~— IMSI attach/detach is allowed in both cells;~~
  - ~~— the T3212 time-out value is 1/10 hour in both cells.~~
- ~~— User Equipment:~~
  - ~~— the UE has a valid TMSI. It is "idle updated" on cell A.~~

##### ~~Related ICS/IXIT statement(s)~~

~~Switch off on button Yes/No.~~

~~Support for speech Yes/No.~~

~~Method to clear the list of forbidden location areas periodically.~~

##### ~~Test Procedure~~

~~The SS rejects a normal location updating with the cause value "Location Area not allowed". The RRC CONNECTION is released. The SS checks that the UE does not perform periodic updating, does not respond to paging with TMSI, rejects any requests from CM entities for MM-connections except emergency calls, does not perform IMSI detach, performs normal location updating when a new location area is entered and deletes the list of forbidden LAs when switched off.~~

~~Different types of UE may use different methods to periodically clear the list of forbidden location areas (e.g. every day at 12am). If the list is cleared while the test is being run, it may be necessary to re-run the test.~~



## Expected sequence

| Step                                                             | Direction |    | Message                         | Comments                                                                                                                                                                                         |
|------------------------------------------------------------------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                  | UE        | SS |                                 |                                                                                                                                                                                                  |
| 1                                                                |           | SS |                                 | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell B to the "Serving cell".<br>Set the cell type of cell A to the "non-suitable cell".<br>(see note). |
| 2                                                                | →         |    | RRC-CONNECTION-REQUEST          | "Establishment cause": Registration.                                                                                                                                                             |
| 3                                                                | ←         |    | RRC-CONNECTION-SETUP            |                                                                                                                                                                                                  |
| 4                                                                | →         |    | RRC-CONNECTION-SETUP COMPLETE   |                                                                                                                                                                                                  |
| 5                                                                | →         |    | LOCATION-UPDATING REQUEST       |                                                                                                                                                                                                  |
| 6                                                                | ←         |    | LOCATION-UPDATING-REJECT        | "Reject cause" = "Location Area not allowed".                                                                                                                                                    |
| 7                                                                | ←         |    | RRC-CONNECTION-RELEASE          | After the sending of this message, the SS waits for the disconnection of the mainsignalling link.                                                                                                |
| 8                                                                | →         |    | RRC-CONNECTION-RELEASE COMPLETE |                                                                                                                                                                                                  |
| 9                                                                |           | SS |                                 | SS waits for a possible location updating for 7 minutes.                                                                                                                                         |
| 10                                                               |           | UE |                                 | The UE shall not initiate an RRC-connection establishment either on cell A or cell B.                                                                                                            |
| 11                                                               | ←         |    | PAGING-TYPE-1                   | The UE is paged in cell B. "UE identity" = TMSI.<br>-Paging Cause: Terminating Conversational Call.                                                                                              |
| 12                                                               |           | UE |                                 | The UE shall ignore this message. This is checked during 3 s.                                                                                                                                    |
| 13                                                               |           | UE |                                 | A MO-CM-connection is attempted.                                                                                                                                                                 |
| 14                                                               |           | UE |                                 | The UE shall not initiate an RRC-connection establishment on cell A or cell B. This is checked during 3 s.                                                                                       |
| 15                                                               |           | UE |                                 | If the UE supports speech (see ICS), it is made to perform an emergency call.                                                                                                                    |
| 16                                                               | →         |    | RRC-CONNECTION-REQUEST          | "Establishment cause": Emergency call.                                                                                                                                                           |
| 17                                                               | ←         |    | RRC-CONNECTION-SETUP            |                                                                                                                                                                                                  |
| 18                                                               | →         |    | RRC-CONNECTION-SETUP COMPLETE   |                                                                                                                                                                                                  |
| 19                                                               | →         |    | CM-SERVICE-REQUEST              | "CM service type": Emergency call-establishment.                                                                                                                                                 |
| 20                                                               | ←         |    | CM-SERVICE-ACCEPT               |                                                                                                                                                                                                  |
| 21                                                               | →         |    | EMERGENCY-SETUP                 |                                                                                                                                                                                                  |
| 22                                                               | ←         |    | RELEASE-COMPLETE                | Cause: "unassigned number".                                                                                                                                                                      |
| 23                                                               | ←         |    | RRC-CONNECTION-RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                               |
| 24                                                               | →         |    | RRC-CONNECTION-RELEASE COMPLETE |                                                                                                                                                                                                  |
| 25                                                               |           | UE |                                 | If possible (see ICS) switch-off is performed. Otherwise the power is removed.                                                                                                                   |
| 26                                                               |           | UE |                                 | The UE shall not initiate an RRC-connection establishment on cell A or on cell B (check for IMSI detach) This is checked during 3 s.                                                             |
| 27                                                               |           | UE |                                 | Depending on what has been performed in step 25 the UE is brought back to operation.                                                                                                             |
| 28                                                               | →         |    | RRC-CONNECTION-REQUEST          | "Establishment cause": Registration.                                                                                                                                                             |
| 29                                                               | ←         |    | RRC-CONNECTION-SETUP            |                                                                                                                                                                                                  |
| 30                                                               | →         |    | RRC-CONNECTION-SETUP COMPLETE   |                                                                                                                                                                                                  |
| 31                                                               | →         |    | LOCATION-UPDATING REQUEST       | "location-updating type" = normal, "CKSN" = no key available, "LAI" = deleted LAI, "mobile identity" = IMSI (This checks the deletion of the forbidden lists)                                    |
| 32                                                               | ←         |    | LOCATION-UPDATING-REJECT        | "Reject cause" = "Location Area not allowed".                                                                                                                                                    |
| 33                                                               | ←         |    | RRC-CONNECTION-RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                               |
| 34                                                               | →         |    | RRC-CONNECTION-RELEASE COMPLETE |                                                                                                                                                                                                  |
| The following messages are sent and shall be received on cell A. |           |    |                                 |                                                                                                                                                                                                  |
| 35                                                               |           | SS |                                 | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "non-suitable cell".<br>(see note).                                                                     |

| Step                                                                                                                                                                 | Direction |    | Message                         | Comments                                                                                                                          |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                      | UE        | SS |                                 |                                                                                                                                   |
| 36                                                                                                                                                                   | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.                                                                                              |
| 37                                                                                                                                                                   | ←         |    | RRC CONNECTION SETUP            | Mobile identity = TMSI.<br><br>After the sending of this message, the SS waits for the disconnection of the main signalling link. |
| 38                                                                                                                                                                   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                   |
| 39                                                                                                                                                                   | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                   |
| 40                                                                                                                                                                   | ←         |    | AUTHENTICATION REQUEST          |                                                                                                                                   |
| 41                                                                                                                                                                   | →         |    | AUTHENTICATION RESPONSE         |                                                                                                                                   |
| 42                                                                                                                                                                   | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                   |
| 43                                                                                                                                                                   | →         |    | TMSI REALLOCATION COMPLETE      |                                                                                                                                   |
| 44                                                                                                                                                                   | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                   |
| 45                                                                                                                                                                   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                   |
| NOTE: —The definitions for “Serving cell” and “non-suitable cell” are specified in TS 34.108 clause 6.1 “Reference Radio Conditions for signalling test cases only”. |           |    |                                 |                                                                                                                                   |

### Specific message contents

None.

#### 9.4.2.3.5 Test requirement

- 1) 1.1 At step 10 the UE shall not perform periodic updating.
- 1.2 At step 12 the UE shall not respond to paging with TMSI.
- 1.3 At step 14 the UE shall not initiate an RRC connection establishment.
- 1.4 At step 26 the UE shall not initiate an RRC connection establishment (IMSI detach).
- 2) 2.1 At step 39 the UE shall perform normal location updating.
- 2.2 At step 16 the UE shall accept a request for an emergency call.
- 2.3 At step 31 the UE shall send a LOCATION UPDATING REQUEST message with the LAI "deleted LAI".

#### 9.4.2.4 Location updating / rejected / roaming not allowed in this location area

##### 9.4.2.4.1 Definition

##### 9.4.2.4.2 Conformance requirement

- 1) If the network rejects a location updating from the UE with the cause "Roaming not allowed in this location area" the UE shall:
  - 1.1 not perform periodic updating;
  - 1.2 not respond to paging with TMSI;
  - 1.3 reject any request from CM entity for MM connection other than for emergency call;
  - 1.4 not perform IMSI detach.
- 2) If the network rejects a location updating from the UE with the cause "Roaming not allowed in this location area" the UE shall:
  - 2.1 perform normal location updating when a new location area is entered;

2.2 accept a request for an emergency call, if it supports speech, by sending a RRC CONNECTION Request message with the establishment cause set to "emergency call";

2.3 periodically search for its HPLMN.

3) The UE shall reset the list of "Forbidden location areas for roaming" when it is switched off or has its power source removed or when the USIM is removed.

4) The UE shall contain a list of "forbidden location areas for roaming". The location area identification received on the BCCH that triggered the location updating request shall be added to the suitable list whenever a LOCATION UPDATE REJECT message is received with the cause "Roaming not allowed in this location area". The lists shall accommodate each 10 or more location area identifications.

#### Reference(s)

TS 24.008 clause 4.4.4.7.

#### 9.4.2.4.3 ————— Test purposes

##### Test purpose 1

To test that on receipt of a rejection using the Roaming cause code, the UE ceases trying to update on that cell, that this situation continues for at least one periodic location interval period, and that the corresponding list is re-set by switching off the UE or removing its power source.

##### Test purpose 2

To test that if no cell is available, the UE does not answer to paging with TMSI, rejects a request from CM entity other than for emergency calls.

##### Test purpose 3

To test that at least 6 entries can be held in the list of "forbidden location areas for roaming" (the requirement in is to store at least 10 entries. This is not fully tested by the third procedure).

##### Test purpose 4

To test that if a cell of the Home PLMN is available then the UE returns to it in preference to any other available cell.

##### Test purpose 5

To test that if the USIM is removed the list of "forbidden location areas for roaming" is cleared.

#### 9.4.2.4.4 ————— Method of test

#### Initial conditions

The initial conditions shall be met before each of the different procedures.

##### — System Simulator:

- for procedures 1, 2, 3 and 5: Two cells A and B, belonging to different location areas of the same PLMN with LAI a and b. The MCC of that PLMN is the same as that of the HPLMN. The MNC of that PLMN is different from that of the HPLMN;
- for procedure 4: three cells A, B, C of the same PLMN which is not the HPLMN with 3 different location area codes. Cells should differ in signal strength by 10 dB with cell A being the strongest and cell C the weakest. There should be a 20 dB range between A and C. A should be set to a level of -40 dBm;
- IMSI attach/detach is allowed in every cell;
- the T3212 time-out value is 1/10 hour in every cell.

— User Equipment:

- procedures 1, 2, 3 and 5: The UE has valid TMSI, CKSN and CK, IK. It is "idle updated" on cell B;
- procedure 4: The UE has valid TMSI, CKSN and CK, IK. It is "idle updated" on cell A;
- the list of "forbidden location areas for roaming" shall be empty (this may be achieved by either removing the USIM or switching the UE OFF then ON or removing the UE power source depending on ICS).

Related ICS/IXIT statement(s)

USIM removal possible while UE is powered Yes/No.

Switch-off on button Yes/No.

Support of speech Yes/No.

Method to clear the list of location areas for roaming periodically.

The UE is automatically in automatic mode after switch-on Yes/No.

Test Procedures

Procedure 1:

- The SS rejects a normal location updating with the cause value "Roaming not allowed in this location area". The RRC CONNECTION is released. The SS checks that the UE does not perform periodic location updating procedure. The UE is turned off and then on. The SS checks that the UE performs location updating on the cell on which its location update request had been rejected (this checks that the LA is not the forbidden list after switch on). This procedure is performed another time but the deletion of the list is checked while removing the USIM (instead of turning off the UE).

Procedure 2:

- The SS rejects a normal location updating with the cause value "Roaming not allowed in this location area". The RRC CONNECTION is released. The SS checks that the UE does not answer to a paging message with TMSI, rejects a request from CM entity but supports an emergency call.

Procedure 3:

- The SS rejects a normal location updating with the cause value "Roaming not allowed in this location area". This is done for 6 different location areas. Then the SS checks that the UE does not attempt to begin a location updating procedure on the non-allowed location areas.

Procedure 4:

- The SS accepts a periodic location updating on a cell not belonging to the HPLMN. Then when the UE attempts to perform a periodic location updating to this cell, the SS rejects this location updating with the cause value "Roaming not allowed in this location area". Two cells are then available, one belonging to the HPLMN but with the weakest level. It is checked that the UE returns to its HPLMN.

Procedure 5: If USIM removal is possible while UE is powered:

- The SS rejects a normal location updating with the cause value "Roaming not allowed in this location area". The RRC CONNECTION is released. The SS checks that the UE does not perform periodic location updating procedure. The USIM is removed and inserted in the UE. The SS checks that the UE performs location updating on the cell on which its location update request had been rejected (this checks that the LA is not the forbidden list after switch on).

Different types of UE may use different methods to periodically clear the list of forbidden areas (e.g. every day at 12am) for roaming. If the list is cleared while the test is being run, it may be necessary to re-run the test.

## Expected sequence

The following procedure is used during the test:

—change\_LAI(x):

—the purpose of this procedure is to change the value of Location Area Identifier of cell x;

—the Location Area Identifier of cell x shall be changed. The code shall be chosen arbitrarily but shall be different from any previously used in this procedure. The code shall have the same MCC as the Home PLMN and shall not have the same MNC as the Home PLMN.

## Procedure 1

| Step                                                                                                                                                                 | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                      | UE        | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 1                                                                                                                                                                    |           | SS |                                 | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "non-suitable cell".<br>(see note).<br>"Establishment cause": Registration.<br><br>Location Updating Type = normal.<br><br>"Reject cause" IE is "Roaming not allowed in this location area".<br>After the sending of this message, the SS waits for the disconnection of the main signalling link. |
| 2                                                                                                                                                                    | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 3                                                                                                                                                                    | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 4                                                                                                                                                                    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 5                                                                                                                                                                    | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 6                                                                                                                                                                    | ←         |    | LOCATION UPDATING REJECT        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 7                                                                                                                                                                    | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 8                                                                                                                                                                    | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 9                                                                                                                                                                    |           | SS |                                 | The SS waits at least 7 minutes for a possible location updating.<br>The UE shall not initiate an RRC connection establishment on cell A or on cell B.                                                                                                                                                                                                                                                                                                          |
| 10                                                                                                                                                                   |           | UE |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 11                                                                                                                                                                   |           | UE |                                 | If possible (see ICS) the UE is switched off. Otherwise if possible the power is removed.<br>Depending on what has been performed in step 11 the UE is brought back to operation and placed in an automatic mode.<br>"Establishment cause": Registration.<br><br>Location Updating Type = normal.<br><br>"Mobile Identity" not IE included.<br>After the sending of this message, the SS waits for the disconnection of the main signalling link.               |
| 12                                                                                                                                                                   |           | UE |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 13                                                                                                                                                                   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 14                                                                                                                                                                   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 15                                                                                                                                                                   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 16                                                                                                                                                                   | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 17                                                                                                                                                                   | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 18                                                                                                                                                                   | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 19                                                                                                                                                                   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| NOTE: —The definitions for "Serving cell" and "non-suitable cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

## Procedure 2

| Step                                                                                                                                                                       | Direction |    | Message                         | Comments                                                                                                                                                                                           |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                            | UE        | SS |                                 |                                                                                                                                                                                                    |
| 1                                                                                                                                                                          |           | SS |                                 | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbor cell". (see note). |
| 2                                                                                                                                                                          | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.<br>This message is sent on cell A.                                                                                                                            |
| 3                                                                                                                                                                          | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                    |
| 4                                                                                                                                                                          | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                    |
| 5                                                                                                                                                                          | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                    |
| 6                                                                                                                                                                          | ←         |    | LOCATION UPDATING REJECT        | "Reject cause" IE is "Roaming not allowed in this location area".                                                                                                                                  |
| 7                                                                                                                                                                          | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                 |
| 8                                                                                                                                                                          | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                    |
| 9                                                                                                                                                                          | →         |    | RRC CONNECTION REQUEST          | The following messages are sent and shall be received on cell B.<br>"Establishment cause": Registration.                                                                                           |
| 10                                                                                                                                                                         | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                    |
| 11                                                                                                                                                                         | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                    |
| 12                                                                                                                                                                         | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                    |
| 13                                                                                                                                                                         | ←         |    | LOCATION UPDATING REJECT        | "Reject cause" IE is "Roaming not allowed in this location area".                                                                                                                                  |
| 14                                                                                                                                                                         | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                 |
| 15                                                                                                                                                                         | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                    |
| 16                                                                                                                                                                         |           | SS |                                 | The SS waits for a possible location updating procedure on both cells A and B for 2 minutes.                                                                                                       |
| 17                                                                                                                                                                         |           | UE |                                 | The UE shall not initiate an RRC connection establishment on cell A or on cell B within 2 minutes after the end of step 15.                                                                        |
| 18                                                                                                                                                                         | ←         |    | PAGING TYPE 1                   | "UE identity" = TMSI. This message is sent on cell A and on cell B.                                                                                                                                |
| 19                                                                                                                                                                         |           | UE |                                 | Paging Cause: Terminating Conversational Call.<br>The UE shall not initiate an RRC connection on cell A or on cell B. This is checked during 3 s.                                                  |
| 20                                                                                                                                                                         |           | UE |                                 | A MO CM connection is attempted.                                                                                                                                                                   |
| 21                                                                                                                                                                         |           | UE |                                 | The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 3 s.                                                                                      |
| The following messages are sent and shall be received on cell A.<br>Steps 22 to 31 are performed if the UE supports speech.                                                |           |    |                                 |                                                                                                                                                                                                    |
| 22                                                                                                                                                                         |           | UE |                                 | An emergency call is attempted.                                                                                                                                                                    |
| 23                                                                                                                                                                         | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Emergency Call.                                                                                                                                                             |
| 24                                                                                                                                                                         | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                    |
| 25                                                                                                                                                                         | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                    |
| 26                                                                                                                                                                         | →         |    | CM SERVICE REQUEST              | "CM service type": Emergency call establishment.                                                                                                                                                   |
| 27                                                                                                                                                                         | ←         |    | CM SERVICE ACCEPT               |                                                                                                                                                                                                    |
| 28                                                                                                                                                                         | →         |    | EMERGENCY SETUP                 |                                                                                                                                                                                                    |
| 29                                                                                                                                                                         | ←         |    | RELEASE COMPLETE                | "Cause" = unassigned number.                                                                                                                                                                       |
| 30                                                                                                                                                                         | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                 |
| 31                                                                                                                                                                         | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                    |
| NOTE: — The definitions for "Serving cell" and "Suitable neighbor cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                                                                    |

## Procedure 3

| Step                                                             | Direction |    | Message                            | Comments                                                                                                                         |
|------------------------------------------------------------------|-----------|----|------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
|                                                                  | UE        | SS |                                    |                                                                                                                                  |
| The following messages are sent and shall be received on cell A  |           |    |                                    |                                                                                                                                  |
| 1                                                                |           | SS |                                    | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbor cell".<br>(see note) |
| 2                                                                | →         |    | RRC CONNECTION REQUEST             | "Establishment cause": Registration.                                                                                             |
| 3                                                                | ←         |    | RRC CONNECTION SETUP               |                                                                                                                                  |
| 4                                                                | →         |    | RRC CONNECTION SETUP<br>COMPLETE   |                                                                                                                                  |
| 5                                                                | →         |    | LOCATION UPDATING<br>REQUEST       |                                                                                                                                  |
| 6                                                                | ←         |    | LOCATION UPDATING REJECT           | "Reject cause" IE is "Roaming not allowed in this location<br>area".                                                             |
| 7                                                                | ←         |    | RRC CONNECTION RELEASE             | After the sending of this message, the SS waits for the<br>disconnection of the main signalling link.                            |
| 8                                                                | →         |    | RRC CONNECTION RELEASE<br>COMPLETE |                                                                                                                                  |
| The following messages are sent and shall be received on cell B. |           |    |                                    |                                                                                                                                  |
| 9                                                                | →         |    | RRC CONNECTION REQUEST             | "Establishment cause": Registration.                                                                                             |
| 10                                                               | ←         |    | RRC CONNECTION SETUP               |                                                                                                                                  |
| 11                                                               | →         |    | RRC CONNECTION SETUP<br>COMPLETE   |                                                                                                                                  |
| 12                                                               | →         |    | LOCATION UPDATING<br>REQUEST       |                                                                                                                                  |
| 13                                                               | ←         |    | LOCATION UPDATING REJECT           | "Reject cause" IE is "Roaming not allowed in this location<br>area".                                                             |
| 14                                                               | ←         |    | RRC CONNECTION RELEASE             | After the sending of this message, the SS waits for the<br>disconnection of the main signalling link.                            |
| 15                                                               | →         |    | RRC CONNECTION RELEASE<br>COMPLETE |                                                                                                                                  |
| 16                                                               |           | SS |                                    | Change LAI (A) within 5 s after step 13.                                                                                         |
| The following messages are sent and shall be received on cell A. |           |    |                                    |                                                                                                                                  |
| 17                                                               | →         |    | RRC CONNECTION REQUEST             | "Establishment cause": Registration.                                                                                             |
| 18                                                               | ←         |    | RRC CONNECTION SETUP               |                                                                                                                                  |
| 19                                                               | →         |    | RRC CONNECTION SETUP<br>COMPLETE   |                                                                                                                                  |
| 20                                                               | →         |    | LOCATION UPDATING<br>REQUEST       |                                                                                                                                  |
| 21                                                               | ←         |    | LOCATION UPDATING REJECT           | "Reject cause" IE is "Roaming not allowed in this location<br>area".                                                             |
| 22                                                               | ←         |    | RRC CONNECTION RELEASE             | After the sending of this message, the SS waits for the<br>disconnection of the main signalling link.                            |
| 23                                                               | →         |    | RRC CONNECTION RELEASE<br>COMPLETE |                                                                                                                                  |
| 24                                                               |           | SS |                                    | Change LAI (B) within 5 s after step 21.                                                                                         |
| The following messages are sent and shall be received on cell B. |           |    |                                    |                                                                                                                                  |
| 25                                                               | →         |    | RRC CONNECTION REQUEST             | "Establishment cause": Registration.                                                                                             |
| 26                                                               | ←         |    | RRC CONNECTION SETUP               |                                                                                                                                  |
| 27                                                               | →         |    | RRC CONNECTION SETUP<br>COMPLETE   |                                                                                                                                  |
| 28                                                               | →         |    | LOCATION UPDATING<br>REQUEST       |                                                                                                                                  |
| 29                                                               | ←         |    | LOCATION UPDATING REJECT           | "Reject cause" IE is "Roaming not allowed in this location<br>area".                                                             |
| 30                                                               | ←         |    | RRC CONNECTION RELEASE             | After the sending of this message, the SS waits for the<br>disconnection of the main signalling link.                            |
| 31                                                               | →         |    | RRC CONNECTION RELEASE<br>COMPLETE |                                                                                                                                  |
| 32                                                               |           | SS |                                    | Change LAI (A) within 5 s after step 29.                                                                                         |
| The following messages are sent and shall be received on cell A. |           |    |                                    |                                                                                                                                  |
| 33                                                               | →         |    | RRC CONNECTION REQUEST             | "Establishment cause": Registration.                                                                                             |
| 34                                                               | ←         |    | RRC CONNECTION SETUP               |                                                                                                                                  |
| 35                                                               | →         |    | RRC CONNECTION SETUP<br>COMPLETE   |                                                                                                                                  |

| Step                                                                                                                                                                       | Direction |    | Message                         | Comments                                                                                                                                                                                                                |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                            | UE        | SS |                                 |                                                                                                                                                                                                                         |
| 36                                                                                                                                                                         | →         |    | LOCATION-UPDATING REQUEST       | "Reject cause" IE is "Roaming not allowed in this location area".<br>After the sending of this message, the SS waits for the disconnection of the main signalling link.<br><br>Change LAI (B) within 5 s after step 37. |
| 37                                                                                                                                                                         | ←         |    | LOCATION-UPDATING REJECT        |                                                                                                                                                                                                                         |
| 38                                                                                                                                                                         | ←         |    | RRC-CONNECTION RELEASE          |                                                                                                                                                                                                                         |
| 39                                                                                                                                                                         | →         |    | RRC-CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                         |
| 40                                                                                                                                                                         | SS        |    |                                 |                                                                                                                                                                                                                         |
| The following messages are sent and shall be received on cell B.                                                                                                           |           |    |                                 |                                                                                                                                                                                                                         |
| 41                                                                                                                                                                         | →         |    | RRC-CONNECTION REQUEST          | "Establishment cause": Registration.                                                                                                                                                                                    |
| 42                                                                                                                                                                         | ←         |    | RRC-CONNECTION SETUP            |                                                                                                                                                                                                                         |
| 43                                                                                                                                                                         | →         |    | RRC-CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                         |
| 44                                                                                                                                                                         | →         |    | LOCATION-UPDATING REQUEST       |                                                                                                                                                                                                                         |
| 45                                                                                                                                                                         | ←         |    | LOCATION-UPDATING REJECT        |                                                                                                                                                                                                                         |
| 46                                                                                                                                                                         | ←         |    | RRC-CONNECTION RELEASE          | "Reject cause" IE is "Roaming not allowed in this location area".<br>After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                 |
| 47                                                                                                                                                                         | →         |    | RRC-CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                         |
| 48                                                                                                                                                                         | SS        |    |                                 |                                                                                                                                                                                                                         |
| 49                                                                                                                                                                         | UE        |    |                                 |                                                                                                                                                                                                                         |
|                                                                                                                                                                            |           |    |                                 |                                                                                                                                                                                                                         |
| NOTE: — The definitions for "Serving cell" and "Suitable neighbor cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                                                                                         |



## Procedure 4

| Step                                                             | Direction |    | Message                         | Comments                                                                                                                            |
|------------------------------------------------------------------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
|                                                                  | UE        | SS |                                 |                                                                                                                                     |
| The following messages are sent and shall be received on cell A: |           |    |                                 |                                                                                                                                     |
| 1                                                                |           | SS |                                 | The SS waits for a periodic location updating procedure on cell A for 7 minutes after the initial conditions have been established. |
| 2                                                                | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.                                                                                                |
| 3                                                                | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                     |
| 4                                                                | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                     |
| 5                                                                | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                     |
| 6                                                                | ←         |    | LOCATION UPDATING ACCEPT        | "Mobile Identity" not IE included.                                                                                                  |
| 7                                                                | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                  |
| 8                                                                | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                     |
| 9                                                                |           | SS |                                 | The location area identity of cell C shall be changed to that of a location area in the Home PLMN.                                  |
| 10                                                               |           | SS |                                 | The SS waits for a periodic location updating procedure on cell A for 7 minutes.                                                    |
| 11                                                               | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.<br>This message is sent on cell A within 7 minutes after the end of step 8.                    |
| 12                                                               | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                     |
| 13                                                               | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                     |
| 14                                                               | →         |    | LOCATION UPDATING REQUEST       | "Location updating type" = periodic.                                                                                                |
| 15                                                               | ←         |    | LOCATION UPDATING REJECT        | "Reject cause" IE is "Roaming not allowed in this location area".                                                                   |
| 16                                                               | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                  |
| 17                                                               | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                     |
| The following messages are sent and shall be received on cell C: |           |    |                                 |                                                                                                                                     |
| 18                                                               | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.                                                                                                |
| 19                                                               | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                     |
| 20                                                               | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                     |
| 21                                                               | →         |    | LOCATION UPDATING REQUEST       | "Location updating type" = periodic.                                                                                                |
| 22                                                               | ←         |    | LOCATION UPDATING ACCEPT        | "Mobile Identity" not IE included.                                                                                                  |
| 23                                                               | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                  |
| 24                                                               | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                     |

## Procedure 5

| Step                                                                                                                                                                     | Direction |    | Message                            | Comments                                                                                                                    |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                          | UE        | SS |                                    |                                                                                                                             |
| The following messages are sent and shall be received on cell A:                                                                                                         |           |    |                                    |                                                                                                                             |
| 1                                                                                                                                                                        | SS        |    |                                    | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "non-suitable cell".<br>(see note) |
| 2                                                                                                                                                                        | →         |    | RRC CONNECTION REQUEST             | "Establishment cause": Registration.                                                                                        |
| 3                                                                                                                                                                        | ←         |    | RRC CONNECTION SETUP               |                                                                                                                             |
| 4                                                                                                                                                                        | →         |    | RRC CONNECTION SETUP<br>COMPLETE   |                                                                                                                             |
| 5                                                                                                                                                                        | →         |    | LOCATION UPDATING<br>REQUEST       |                                                                                                                             |
| 6                                                                                                                                                                        | ←         |    | LOCATION UPDATING REJECT           | "Reject cause" IE is "Roaming not allowed in this location<br>area".                                                        |
| 7                                                                                                                                                                        | ←         |    | RRC CONNECTION RELEASE             | After the sending of this message, the SS waits for the<br>disconnection of the main signalling link.                       |
| 8                                                                                                                                                                        | →         |    | RRC CONNECTION RELEASE<br>COMPLETE |                                                                                                                             |
| 9                                                                                                                                                                        | SS        |    |                                    | The SS waits at least 7 minutes for a possible location<br>updating.                                                        |
| 10                                                                                                                                                                       | UE        |    |                                    | The UE shall not initiate an RRC connection<br>establishment on cell A or on cell B.                                        |
| 11                                                                                                                                                                       | UE        |    |                                    | The USIM is removed.                                                                                                        |
| 12                                                                                                                                                                       | UE        |    |                                    | The USIM is inserted into the ME.                                                                                           |
| 13                                                                                                                                                                       | →         |    | RRC CONNECTION REQUEST             | "Establishment cause": Registration.                                                                                        |
| 14                                                                                                                                                                       | ←         |    | RRC CONNECTION SETUP               |                                                                                                                             |
| 15                                                                                                                                                                       | →         |    | RRC CONNECTION SETUP<br>COMPLETE   |                                                                                                                             |
| 16                                                                                                                                                                       | →         |    | LOCATION UPDATING<br>REQUEST       |                                                                                                                             |
| 17                                                                                                                                                                       | ←         |    | LOCATION UPDATING ACCEPT           | "Mobile Identity" not IE included.                                                                                          |
| 18                                                                                                                                                                       | ←         |    | RRC CONNECTION RELEASE             | After the sending of this message, the SS waits for the<br>disconnection of the main signalling link.                       |
| 19                                                                                                                                                                       | →         |    | RRC CONNECTION RELEASE<br>COMPLETE |                                                                                                                             |
| NOTE: — The definitions for "Serving cell" and "non-suitable cell" are specified in TS 34.108 clause 6.1 "Reference<br>Radio Conditions for signalling test cases only". |           |    |                                    |                                                                                                                             |

## Specific message contents

None.

## 9.4.2.4.5 — Test requirement

- 1) 1.1 At step 10 in Procedure 1 the UE shall not perform periodic updating.
- 1.2 At step 19 in Procedure 2 the UE shall not respond to paging with TMSI.
- 1.3 At step 21 in procedure 2 the UE shall not initiate an RRC connection establishment.
- 1.4 After step 13 in Procedure 5 the UE shall perform location updating (at step 16; not perform IMSI detach).
- 2) 2.1 After step 9 in Procedure 2 the UE perform normal location updating (at step 12).
- 2.2 At step 23 in Procedure 2 the UE shall initiate a RRC CONNECTION REQUEST message with the establishment cause set to "Emergency call";
- 2.3 After step 14 in Procedure 4 the UE shall attempt to location updating with location updating type "periodic" (at step 21; periodically search for its HPLMN).
- 3) After step 12 in Procedure 5 the UE shall perform location updating (at step 16) when the USIM is removed.
- 4) At step 49 in Procedure 3 the UE shall not attempt to begin a location updating procedure.

### ~~9.4.2.5 Location updating / rejected / No Suitable Cells In Location Area~~

#### ~~9.4.2.5.1 Definition~~

#### ~~9.4.2.5.2 Conformance requirement~~

- ~~1) If the network rejects a location updating from the UE with the cause "No Suitable Cells In Location Area" the UE shall:~~
  - ~~1.1 perform normal location updating at a suitable cell in another location area in the same PLMN;~~
  - ~~1.2 delete the stored CKSN, LAI and TMSI.~~

#### Reference(s)

TS 24.008 clause 4.4.4.7.

#### ~~9.4.2.5.3 Test purpose~~

To test the behaviour of the UE if the network rejects the location updating of the UE with the cause "No Suitable Cells In Location Area".

#### ~~9.4.2.5.4 Method of test~~

#### Initial conditions

- ~~— System Simulator:~~
  - ~~— two cells: A and B, belonging to different location areas a and b and belonging to PLMN1;~~
  - ~~— one cell: C, belonging to PLMN2;~~
  - ~~— IMSI attach/detach is allowed in cells A, B and C;~~
- ~~— User Equipment:~~
  - ~~— the UE has a valid TMSI(= TMSI1) and CKSN(= CKSN1). It is "idle-updated" on cell A.~~

#### Related ICS/IXIT statement(s)

None.

#### Test Procedure

The SS rejects a normal location updating with the cause value "No Suitable Cells In Location Area". The RRC CONNECTION is released. The SS checks that the UE shall search for a suitable cell in a different location area on the same PLMN, and shall perform normal location updating procedure in that cell

## Expected sequence

| Step                                                                                                                                                                      | Direction |    | Message                         | Comments                                                                                                                                                                                         |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                           | UE        | SS |                                 |                                                                                                                                                                                                  |
| The following messages are sent and shall be received on cell B:                                                                                                          |           |    |                                 |                                                                                                                                                                                                  |
| 1                                                                                                                                                                         |           | SS |                                 | Set the cell type of cell B to the "Serving cell".<br>Set the cell type of cell A to the "Suitable neighbor cell".<br>Set the cell type of cell C to the "Suitable neighbor cell".<br>(see note) |
| 2                                                                                                                                                                         | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.                                                                                                                                                             |
| 3                                                                                                                                                                         | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                  |
| 4                                                                                                                                                                         | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                  |
| 5                                                                                                                                                                         | →         |    | LOCATION UPDATING REQUEST       | "location-updating type" = normal, "CKSN" = CKSN1,<br>"LAI" = a, "mobile station classmark 1" as given by the ICS and "Mobile Identity" = TMSI1.                                                 |
| 6                                                                                                                                                                         | ←         |    | LOCATION UPDATING REJECT        | "Reject cause" = "No Suitable Cells In Location Area".                                                                                                                                           |
| 7                                                                                                                                                                         | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                               |
| 8                                                                                                                                                                         | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                  |
| The following messages are sent and shall be received on cell A:                                                                                                          |           |    |                                 |                                                                                                                                                                                                  |
| 9                                                                                                                                                                         | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.                                                                                                                                                             |
| 10                                                                                                                                                                        | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                  |
| 11                                                                                                                                                                        | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                  |
| 12                                                                                                                                                                        | →         |    | LOCATION UPDATING REQUEST       | "location-updating type" = normal, "CKSN" = no key available, "LAI" = deleted LAI, "mobile station classmark 1" as given by the ICS, "Mobile Identity" = IMSI.                                   |
| 13                                                                                                                                                                        | ←         |    | AUTHENTICATION REQUEST          | "CKSN" = CKSN2                                                                                                                                                                                   |
| 14                                                                                                                                                                        | →         |    | AUTHENTICATION RESPONSE         |                                                                                                                                                                                                  |
| 15                                                                                                                                                                        | ←         |    | SECURITY MODE COMMAND           |                                                                                                                                                                                                  |
| 16                                                                                                                                                                        | →         |    | SECURITY MODE COMPLETE          |                                                                                                                                                                                                  |
| 17                                                                                                                                                                        | ←         |    | LOCATION UPDATING ACCEPT        | Mobile identity = TMSI, LAI = a.                                                                                                                                                                 |
| 18                                                                                                                                                                        | →         |    | TMSI REALLOCATION COMPLETE      |                                                                                                                                                                                                  |
| 19                                                                                                                                                                        | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                               |
| 20                                                                                                                                                                        | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                  |
| NOTE: —The definitions for "Serving cell" and "Suitable neighbor cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                                                                  |

## Specific message contents

None.

## 9.4.2.5.5 — Test requirement

At step 12 the UE shall perform normal location updating with CKSN IE set to "no key available", LAI IE set to "deleted LAI" and Mobile Identity IE set to its IMSI.

### 9.4.3 Location updating / abnormal cases

#### 9.4.3.1 Void

#### 9.4.3.2 Location updating / abnormal cases / attempt counter less or equal to 4, LAI different

##### 9.4.3.2.1 Definition

##### 9.4.3.2.2 Conformance requirement

- 1) When a failure such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 has occurred during a normal location updating procedure, if the attempt counter is smaller than 4 and after expiry of T3211, the UE shall resend its LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating Type IE set to "normal location updating".
- 2) When a failure such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 has occurred during a normal location updating procedure the UE shall:
  - 2.1 not answer to paging with the previously allocated TMSI;
  - 2.2 not perform the IMSI detach procedure, when switched off.
- 3) When a failure such as case e) of clause 4.4.4.9 of TS 24.008 has occurred during a normal location updating procedure and when an emergency call establishment is requested by the user the UE, if it supports speech, shall send a CM SERVICE REQUEST message with CM Service Type IE set to "emergency call establishment", CKSN IE set to "no key available" and Mobile Identity IE set to its IMSI and after acceptance by the network it shall send an EMERGENCY SETUP message.
- 4) When a failure such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 has occurred during a normal location updating procedure the UE shall use a request from CM entity other than emergency call as a trigger for a normal location updating procedure and shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating Type IE set to "normal location updating".
- 5) When a failure such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 has occurred during a normal location updating procedure the UE shall answer to paging with IMSI and shall send a PAGING RESPONSE message with CKSN IE set to "no key available" and Mobile Identity IE set to its IMSI.
- 6) When a failure such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 has occurred during a normal location updating procedure the UE shall perform a normal location updating procedure as soon as it enters a new cell.

#### References

TS 24.008 clauses 4.4.4.2, 4.4.4.9.

##### 9.4.3.2.3 Test purpose

To verify that the UE performs normal location updating procedures when its attempt counter is smaller than 4.

To check that the UE does not perform the IMSI detach procedure when "idle not updated".

To verify that when "idle not updated" the UE can perform an emergency call.

To verify that when "idle not updated" the UE uses requests from CM layer other than emergency call as triggering of a normal location updating procedure.

To verify that the UE performs a normal location updating procedure if it enters a new cell while being "idle not updated".

#### 9.4.3.2.4 ~~Method of test~~

##### ~~Initial conditions~~

- ~~— System Simulator:~~
  - ~~— two cells: A and B of the same PLMN, belonging to different location areas with LAI a and b;~~
  - ~~— ATT flag shall be set to IMSI attach/detach allowed.~~
- ~~— User Equipment:~~
  - ~~— the UE is "idle updated" on cell A. A valid CKSN value is stored in the USIM and is noted "initial CKSN". A TMSI is allocated.~~

##### ~~Related ICS/IXIT statements~~

~~USIM removal possible while UE is powered Yes/No.~~

~~Switch off on button Yes/No.~~

~~Support for speech Yes/No.~~

##### ~~Test Procedure~~

~~The UE is made to perform a normal location updating procedure. Five types of failure cases are triggered:~~

- ~~— sending of a Location Updating Reject with cause randomly chosen between all defined cause values except 2, 3, 6, 11, 12 and 13 (which trigger a different action) (case g of TS 24.008 clause 4.4.4.9);~~
- ~~— RRC connection failure (case d);~~
- ~~— sending of a RRC CONNECTION RELEASE message before the normal end of the procedure (case f);~~
- ~~— T3210 time-out (case e);~~
- ~~— RR connection establishment failure (case h).~~

~~As there is no stored LAI or the stored LAI is different from the broadcast LAI, and the attempt counter in the UE shall be lower than 4, the UE enters the state MM IDLE and substate ATTEMPTING TO UPDATE and waits for T3211 seconds before trying again a location updating procedure.~~

~~Then the behaviour of the UE in the MM IDLE state and ATTEMPTING TO UPDATE substate is checked, that is:~~

- ~~— not answer to paging with TMSI;~~
- ~~— not perform an IMSI detach procedure;~~
- ~~— support request for emergency call;~~
- ~~— use requests from CM layer other than emergency call as triggering of a normal location updating procedure;~~
- ~~— perform normal location updating procedure when a new cell is entered.~~

## Expected sequence

| Step                                                             | Direction |    | Message                            | Comments                                                                                                                                                                        |
|------------------------------------------------------------------|-----------|----|------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                  | UE        | SS |                                    |                                                                                                                                                                                 |
| The following messages are sent and shall be received on cell B: |           |    |                                    |                                                                                                                                                                                 |
| 1                                                                |           | SS |                                    | Set the cell type of cell B to the "Serving cell".<br>Set the cell type of cell A to the "non-suitable cell".<br>(see note)                                                     |
| 2                                                                | →         |    | RRC CONNECTION REQUEST             | Establishment cause: Registration.                                                                                                                                              |
| 3                                                                | ←         |    | RRC CONNECTION SETUP               |                                                                                                                                                                                 |
| 4                                                                | →         |    | RRC CONNECTION SETUP<br>COMPLETE   |                                                                                                                                                                                 |
| 5                                                                | →         |    | LOCATION UPDATING<br>REQUEST       | location-updating type = normal, CKSN = initial value, LAI<br>= a, mobile station classmark 1 as given by the ICS and<br>mobile identity = TMSI.                                |
| 6                                                                | ←         |    | LOCATION UPDATING REJECT           | IE Reject cause is set to #X in table 10.5.95 of TS<br>24.008, causes #2, #3, #6, #11, #12, #13 and #15 being<br>excluded.                                                      |
| 7                                                                | ←         |    | RRC CONNECTION RELEASE             | After the sending of this message, the SS waits for the<br>disconnection of the main signalling link.                                                                           |
| 8                                                                | →         |    | RRC CONNECTION RELEASE<br>COMPLETE |                                                                                                                                                                                 |
| 9                                                                |           | UE |                                    | The UE shall not initiate an RRC connection<br>establishment on cell A or on cell B during T3211<br>seconds at least after the RRC connection is released.                      |
| 8                                                                | →         |    | RRC CONNECTION REQUEST             | Establishment cause: Registration.                                                                                                                                              |
| 9                                                                | ←         |    | RRC CONNECTION SETUP               |                                                                                                                                                                                 |
| 12                                                               | →         |    | RRC CONNECTION SETUP<br>COMPLETE   |                                                                                                                                                                                 |
| 13                                                               | →         |    | LOCATION UPDATING<br>REQUEST       | location-updating type = normal, CKSN = no key<br>available, LAI = deleted LAI (the MCC and MNC hold the<br>previous values, the LAC is coded FFFE), Mobile Identity<br>= IMSI. |
| 14                                                               |           | SS |                                    | The SS modifies the scrambling code of DL DPCH for<br>generating lower layer failure.                                                                                           |
| 15                                                               |           |    | (void)                             |                                                                                                                                                                                 |
| 15a                                                              | →         |    | CELL UPDATE                        | CCCH.                                                                                                                                                                           |
| 15b                                                              | ←         |    | RRC CONNECTION RELEASE             | CCCH.                                                                                                                                                                           |
| 15c                                                              |           | SS |                                    | The SS re-modifies the scrambling code of DL DPCH to<br>the original one.                                                                                                       |
| 15d                                                              |           | UE |                                    | The UE shall not initiate an RRC connection<br>establishment on cell A or on cell B during T3211<br>seconds at least after the RRC connection is released.                      |
| 16                                                               | →         |    | RRC CONNECTION REQUEST             | Establishment cause: Registration.                                                                                                                                              |
| 17                                                               | ←         |    | RRC CONNECTION SETUP               |                                                                                                                                                                                 |
| 18                                                               | →         |    | RRC CONNECTION SETUP<br>COMPLETE   |                                                                                                                                                                                 |
| 19                                                               | →         |    | LOCATION UPDATING<br>REQUEST       | location-updating type = normal, CKSN = no key<br>available, LAI = deleted LAI (the MCC and MNC hold the<br>previous values, the LAC is coded FFFE), Mobile Identity<br>= IMSI. |
| 20                                                               | ←         |    | RRC CONNECTION RELEASE             | After the sending of this message, the SS waits for the<br>disconnection of the main signalling link.                                                                           |
| 21                                                               | →         |    | RRC CONNECTION RELEASE<br>COMPLETE |                                                                                                                                                                                 |
| 22                                                               |           | UE |                                    | The UE shall not initiate an RRC connection<br>establishment on cell A or on cell B during T3211<br>seconds at least after the RRC connection is released.                      |
| 23                                                               | →         |    | RRC CONNECTION REQUEST             | Establishment cause: Registration.                                                                                                                                              |
| 24                                                               | ←         |    | RRC CONNECTION SETUP               |                                                                                                                                                                                 |
| 25                                                               | →         |    | RRC CONNECTION SETUP<br>COMPLETE   |                                                                                                                                                                                 |
| 26                                                               | →         |    | LOCATION UPDATING<br>REQUEST       | location-updating type = normal, CKSN = no key<br>available, LAI = deleted LAI (the MCC and MNC hold the<br>previous values, the LAC is coded FFFE), Mobile Identity<br>= IMSI. |
| 27                                                               | ←         |    | AUTHENTICATION REQUEST             | CKSN = initial CKSN.                                                                                                                                                            |
| 28                                                               | →         |    | AUTHENTICATION RESPONSE            |                                                                                                                                                                                 |

| Step                                                             | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------------------------------------------------------------------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                  | UE        | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 28a                                                              | ←         |    | SECURITY MODE COMMAND           | IE mobile Identity = new TMSI.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 28b                                                              | →         |    | SECURITY MODE COMPLETE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 29                                                               | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 30                                                               | →         |    | TMSI REALLOCATION COMPLETE      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 31                                                               | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link. UE is now "idle updated" in cell B.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 32                                                               | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| The following messages are sent and shall be received on cell A. |           |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 33                                                               |           | SS |                                 | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "non-suitable cell".<br>(see note)<br>Establishment cause: Registration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| 34                                                               | →         |    | RRC CONNECTION REQUEST          | location updating type = normal, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.<br>performs step 6 with reject cause #100 and step 7.<br>performs step8.<br>UE identity = old TMSI of the UE.<br>This message is sent continuously to the UE during 8 s.<br>Paging Cause: Terminating Conversational Call.<br>The SS checks that there is no answer from the UE during 12 s.<br>If during steps 39 and 40 the UE attempts to perform a location updating procedure the SS will perform step 38 and then continue the procedure.<br>If possible (see ICS) USIM detachment is performed.<br>Otherwise if possible (see ICS) mobile switch off is performed. Otherwise the power is removed.<br>The UE shall not initiate an RRC connection establishment on cell A or on cell B during 30 s.<br>Depending on what has been performed in step 42 the UE is brought back to operation.<br>Establishment cause: Registration. |
| 35                                                               | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 36                                                               | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 37                                                               | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 38                                                               |           | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 38a                                                              | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 39                                                               | ←         |    | PAGING TYPE 1                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 40                                                               |           | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 41                                                               |           | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 42                                                               | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 43                                                               | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 44                                                               | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 45                                                               | →         |    | RRC CONNECTION REQUEST          | location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.<br>CKSN = initial CKSN.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 46                                                               | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 47                                                               | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 48                                                               | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 49                                                               | ←         |    | AUTHENTICATION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 50                                                               | →         |    | AUTHENTICATION RESPONSE         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 50a                                                              | ←         |    | SECURITY MODE COMMAND           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 50b                                                              | →         |    | SECURITY MODE COMPLETE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 51                                                               | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 52                                                               | →         |    | TMSI REALLOCATION COMPLETE      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 53                                                               | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link. UE is now "idle updated" in cell A.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 54                                                               | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| The following messages are sent and shall be received on cell B. |           |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 55                                                               |           | SS |                                 | Set the cell type of cell B to the "Serving cell".<br>Set the cell type of cell A to the "non-suitable cell".<br>(see note).<br>Establishment cause: Registration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 56                                                               | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 57                                                               | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 58                                                               | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |



| Step                                                             | Direction |    | Message                         | Comments                                                                                                                                                                    |
|------------------------------------------------------------------|-----------|----|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                  | UE        | SS |                                 |                                                                                                                                                                             |
| 59                                                               | →         |    | LOCATION-UPDATING REQUEST       | location-updating type = normal, CKSN = initial value, LAI = a, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.                                  |
| 60                                                               | ←         |    | AUTHENTICATION REQUEST          | Steps 60 and 61 are performed N times. N shall be chosen in such a way that T3210 expires.                                                                                  |
| 61                                                               | →         |    | AUTHENTICATION RESPONSE         |                                                                                                                                                                             |
| 62                                                               | UE        |    |                                 | The UE shall cease transmission and then shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the expiry of T3210. |
| 63                                                               | UE        |    |                                 | If the UE supports speech it is made to perform an emergency call.                                                                                                          |
| 64                                                               | →         |    | RRC-CONNECTION REQUEST          | Establishment cause: Emergency call.                                                                                                                                        |
| 65                                                               | ←         |    | RRC-CONNECTION SETUP            |                                                                                                                                                                             |
| 66                                                               | →         |    | RRC-CONNECTION SETUP COMPLETE   |                                                                                                                                                                             |
| 67                                                               | →         |    | CM SERVICE REQUEST              | CM service type = Emergency call establishment; CKSN = no key available; Mobile Identity = IMSI.                                                                            |
| 68                                                               | ←         |    | CM SERVICE ACCEPT               | Cause = unassigned number.                                                                                                                                                  |
| 69                                                               | →         |    | EMERGENCY SETUP                 |                                                                                                                                                                             |
| 70                                                               | ←         |    | RELEASE COMPLETE                |                                                                                                                                                                             |
| 71                                                               | ←         |    | RRC-CONNECTION RELEASE          |                                                                                                                                                                             |
| 72                                                               | →         |    | RRC-CONNECTION RELEASE COMPLETE | The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC connection is released.                        |
| 72a                                                              | UE        |    |                                 |                                                                                                                                                                             |
| 73                                                               | →         |    | RRC-CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                          |
| 74                                                               | ←         |    | RRC-CONNECTION SETUP            |                                                                                                                                                                             |
| 75                                                               | →         |    | RRC-CONNECTION SETUP COMPLETE   |                                                                                                                                                                             |
| 76                                                               | →         |    | LOCATION-UPDATING REQUEST       | location-updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.      |
| 77                                                               | ←         |    | AUTHENTICATION REQUEST          | CKSN = initial CKSN.                                                                                                                                                        |
| 78                                                               | →         |    | AUTHENTICATION RESPONSE         | IE mobile Identity = new TMSI.                                                                                                                                              |
| 78a                                                              | ←         |    | SECURITY MODE COMMAND           |                                                                                                                                                                             |
| 78b                                                              | →         |    | SECURITY MODE COMPLETE          |                                                                                                                                                                             |
| 79                                                               | ←         |    | LOCATION-UPDATING ACCEPT        |                                                                                                                                                                             |
| 80                                                               | →         |    | TMSI REALLOCATION COMPLETE      | After the sending of this message, the SS waits for the disconnection of the main signalling link. UE is now "idle updated" in cell B.                                      |
| 81                                                               | ←         |    | RRC-CONNECTION RELEASE          |                                                                                                                                                                             |
| 82                                                               | →         |    | RRC-CONNECTION RELEASE COMPLETE |                                                                                                                                                                             |
| The following messages are sent and shall be received on cell A: |           |    |                                 |                                                                                                                                                                             |
| 83                                                               | SS        |    |                                 | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "non-suitable cell". (see note).                                                   |
| 84                                                               | →         |    | RRC-CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                          |
| 85                                                               | ←         |    | RRC-CONNECTION SETUP            |                                                                                                                                                                             |
| 86                                                               | →         |    | RRC-CONNECTION SETUP COMPLETE   | location-updating type = normal, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.                                  |
| 87                                                               | →         |    | LOCATION-UPDATING REQUEST       |                                                                                                                                                                             |
| 88                                                               | SS        |    |                                 | performs step 14.                                                                                                                                                           |
| 88a                                                              |           |    | (void)                          | CCCH.                                                                                                                                                                       |
| 88b                                                              | →         |    | CELL UPDATE                     |                                                                                                                                                                             |
| 88c                                                              | ←         |    | RRC-CONNECTION RELEASE          | CCCH.                                                                                                                                                                       |
| 88d                                                              | SS        |    |                                 | performs step 15c.                                                                                                                                                          |
| 89                                                               | UE        |    |                                 | A MO CM connection is attempted before T3211 expiry.                                                                                                                        |
| 90                                                               | →         |    | RRC-CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                          |

| Step                                                             | Direction |    | Message                                                      | Comments                                                                                                                                                                                                                 |
|------------------------------------------------------------------|-----------|----|--------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                  | UE        | SS |                                                              |                                                                                                                                                                                                                          |
| 91                                                               | ←         |    | RRC CONNECTION SETUP                                         | location-updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.<br>IE mobile Identity = new TMSI.                 |
| 92                                                               | →         |    | RRC CONNECTION SETUP COMPLETE                                |                                                                                                                                                                                                                          |
| 93                                                               | →         |    | LOCATION UPDATING REQUEST                                    |                                                                                                                                                                                                                          |
| 94                                                               | ←         |    | LOCATION UPDATING ACCEPT                                     |                                                                                                                                                                                                                          |
| 95                                                               | →         |    | TMSI REALLOCATION COMPLETE                                   |                                                                                                                                                                                                                          |
| 96                                                               | ←         |    | RRC CONNECTION RELEASE                                       | Steps 98 to 103 are optional as the UE may have memorized the request for CM connection attempt.                                                                                                                         |
| 97                                                               | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                          |
| 97a                                                              | SS        |    |                                                              | Wait 10 s to decide whether to go directly to step 104.<br>Establishment cause: Not checked.                                                                                                                             |
| 98                                                               | →         |    | RRC CONNECTION REQUEST                                       |                                                                                                                                                                                                                          |
| 99                                                               | ←         |    | RRC CONNECTION SETUP                                         |                                                                                                                                                                                                                          |
| 100                                                              | →         |    | RRC CONNECTION SETUP COMPLETE                                |                                                                                                                                                                                                                          |
| 101                                                              | →         |    | CM SERVICE REQUEST                                           | CKSN = no key available, Mobile identity = TMSI.<br>After the sending of this message, the SS waits for the disconnection of the main signalling link. UE is now "idle updated" in cell A.                               |
| 102                                                              | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                          |
| 103                                                              | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                          |
| The following messages are sent and shall be received on cell B. |           |    |                                                              |                                                                                                                                                                                                                          |
| 104                                                              |           | SS |                                                              | Set the cell type of cell B to the "Serving cell".<br>Set the cell type of cell A to the "non-suitable cell". (see note).                                                                                                |
| 105                                                              | →         |    | RRC CONNECTION REQUEST                                       | Establishment cause: Registration.                                                                                                                                                                                       |
| 106                                                              | ←         |    | RRC CONNECTION SETUP                                         |                                                                                                                                                                                                                          |
| 107                                                              | →         |    | RRC CONNECTION SETUP COMPLETE                                |                                                                                                                                                                                                                          |
| 108                                                              | →         |    | LOCATION UPDATING REQUEST                                    | location-updating type = normal, CKSN = no key available LAI = a, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.                                                                             |
| 109                                                              | SS        |    |                                                              |                                                                                                                                                                                                                          |
| 109a                                                             |           |    | (void)                                                       | performs step 14.                                                                                                                                                                                                        |
| 109b                                                             | →         |    | CELL UPDATE                                                  |                                                                                                                                                                                                                          |
| 109c                                                             | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                          |
| 109d                                                             | SS        |    |                                                              |                                                                                                                                                                                                                          |
| The following messages are sent and shall be received on cell A. |           |    |                                                              |                                                                                                                                                                                                                          |
| 110                                                              |           | SS |                                                              | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "non-suitable cell". (see note).                                                                                                |
| 110a                                                             | →         |    | RRC CONNECTION REQUEST                                       | Establishment cause: Registration.                                                                                                                                                                                       |
| 110b                                                             | ←         |    | RRC CONNECTION SETUP                                         |                                                                                                                                                                                                                          |
| 110c                                                             | →         |    | RRC CONNECTION SETUP COMPLETE                                |                                                                                                                                                                                                                          |
| 110d                                                             | →         |    | LOCATION UPDATING REQUEST                                    | location-updating type = normal, CKSN = no key available LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), mobile station classmark 1 as given by the ICS and mobile identity = IMSI. |
| 110e                                                             | SS        |    |                                                              |                                                                                                                                                                                                                          |
| 110f                                                             | →         |    | CELL UPDATE                                                  | performs step 14.                                                                                                                                                                                                        |
| 110g                                                             | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                          |
| 110h                                                             | SS        |    |                                                              |                                                                                                                                                                                                                          |
| 111                                                              | ←         |    | Mobile terminated establishment of Radio Resource Connection |                                                                                                                                                                                                                          |
| 112                                                              | →         |    | PAGING RESPONSE                                              | See TS 34.108 clause 7.1.2<br>"Initial UE identity" = IMSI.<br>Establishment Cause: Terminating Conversation Call.<br>"Mobile identity" = IMSI, CKSN = no key available.                                                 |
| 113                                                              | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                          |
| 114                                                              | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                          |

| Step                                                                                                                                                                 | Direction |    | Message | Comments |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------|----------|
|                                                                                                                                                                      | UE        | SS |         |          |
| NOTE: —The definitions for “Serving cell” and “non-suitable cell” are specified in TS 34.108 clause 6.1 “Reference Radio Conditions for signalling test cases only”. |           |    |         |          |

### Specific message contents

None.

#### 9.4.3.2.5 Test requirement

- 1) At step 13 the UE shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key available" and the Location Updating Type IE set to "normal location updating".
- 2)
  - 2.1 At step 40 the UE shall not answer to paging with the previously allocated TMSI.
  - 2.2 At step 43 the UE shall not perform the IMSI detach procedure.
- 3) At step 67 the UE shall send a CM SERVICE REQUEST message with CM Service Type IE set to "emergency call establishment", CKSN IE set to "no key available" and Mobile Identity IE set to its IMSI.  
At step 69 the UE shall send an EMERGENCY SETUP message.
- 4) At step 93 the UE shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating Type IE set to "normal location updating".
- 5) At step 112 the UE shall send a PAGING RESPONSE message with CKSN IE set to "no key available" and Mobile Identity IE set to its IMSI.
- 6) At step 110d the UE shall perform a normal location updating procedure.

#### 9.4.3.3 Location updating / abnormal cases / attempt counter equal to 4

##### 9.4.3.3.1 Definition

##### 9.4.3.3.2 Conformance requirement

- 1) When four failures such as cases d) to h) of clause 4.4.4.9 of TS 24.008 have occurred during a normal location updating procedure the UE shall:
  - 1.1 perform location updating after T3212 expiry by sending a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating Type set to "normal location updating";
  - 1.2 if the T3212 initiated location updating was unsuccessful, then after T3211 expiry the UE shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating Type IE set to "normal location updating".

- 2) When four failures such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 have occurred during a normal location-updating procedure the UE shall not perform the IMSI detach procedure, when switched off.
- 3) When four failures such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 have occurred during a normal location-updating procedure the UE, if it supports speech, shall be able to perform an emergency call i.e. the UE is able to send a CM SERVICE REQUEST message with the CM Service Type IE set to "emergency call establishment", CKSN IE set to "no key is available" and Mobile Identity IE set to its IMSI and then send an EMERGENCY SETUP message.
- 4) When four failures such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 have occurred during a normal location-updating procedure:
- 4.1 the UE shall use a request from CM entity for MM connection for a service other than emergency call as a trigger for a normal location updating procedure and shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating Type IE set to "normal location updating";
- 4.2 after a location updating triggered by a request from the CM layer which was unsuccessful, after T3211 expiry the UE shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating Type IE set to "normal location updating".
- 5) When four failures such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 have occurred during a normal location-updating procedure:
- 5.1 the UE shall perform a normal location-updating procedure if it enters a new cell;
- 5.2 if this location-updating is unsuccessful, after T3211 expiry the UE shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type IE set to "normal location updating".

## References

TS 24.008 clause 4.4.4.9.

### 9.4.3.3.3 ——— Test purpose

To verify that the UE performs normal location-updating procedures after T3212 expiry, when its attempt counter has reached value 4 and that the UE reset its attempt counter after a timer T3212 expiry.

To verify that the UE still follows the MM IDLE state and ATTEMPTING TO UPDATE substate requirements after its attempt counter has reached value 4.

To verify that the attempt counter is reset in the cases where it has to be done.

### 9.4.3.3.4 ——— Method of test

#### Initial conditions

— System Simulator:

- two cells: A and B, belonging to different location areas a and b;
- IMSI attach/detach is allowed in both cells;
- T3212 is set to 6 minutes.

— User Equipment:

- the UE is "Idle updated" on cell B with a valid CKSN and a TMSI.

#### Related ICS/IXIT statements

USIM removal possible while UE is powered Yes/No.

Switch-off on button Yes/No.

Support of speech Yes/No.

### Test Procedure

The UE is made to perform a normal location updating. The SS triggers a failure in this procedure by modifying scrambling code of DL-DPCH. After T3211 expiry the UE will try again the location updating procedure. The SS triggers again a failure by modifying it. This is done again 2 times. At this point the attempt counter shall be equal to 4. It is then checked that T3212 has been started and that at its expiry the UE will try a normal location updating procedure. It is verified that the UE has reset its attempt counter after timer T3212 expiry.

Then it is checked that, when the attempt counter has reached the value of 4, the UE is in the MM-IDLE state and ATTEMPTING-TO-UPDATE substate, that is:

- not perform an IMSI detach procedure;
- support request for emergency call;
- use requests from CM layer other than emergency call as triggering of a normal location updating procedure;
- perform normal location updating procedure when a new cell is entered.

## Expected sequence

| Step                                                             | Direction |        | Message                         | Comments                                                                                                                                                                    |
|------------------------------------------------------------------|-----------|--------|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                  | UE        | SS     |                                 |                                                                                                                                                                             |
| The following messages are sent and shall be received on cell A: |           |        |                                 |                                                                                                                                                                             |
| 1                                                                |           | SS     |                                 | Set the cell type of cell A to the “Serving cell”.<br>Set the cell type of cell B to the “non-suitable cell”.<br>(see note).                                                |
| 2                                                                | →         |        | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                          |
| 3                                                                | ←         |        | RRC CONNECTION SETUP            |                                                                                                                                                                             |
| 4                                                                | →         |        | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                             |
| 5                                                                | →         |        | LOCATION UPDATING REQUEST       | location-updating type = normal, CKSN = initial value, LAI = b, mobile station-classmark 1 as given by the ICS and mobile identity = TMSI.                                  |
| 6                                                                | ←         |        | LOCATION UPDATING REJECT        | IE Reject cause is set to #22 in table 10.5.95 of TS 24.008, causes #2, #3, #6, #11, #12, #13 and #15 being excluded.                                                       |
| 7                                                                | ←         |        | RRC CONNECTION RELEASE          | The SS waits for the disconnection of the main signalling link.                                                                                                             |
| 8                                                                | →         |        | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                             |
| 9                                                                |           | UE     |                                 | The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC connection is released.                        |
| 10                                                               | →         |        | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                          |
| 11                                                               | ←         |        | RRC CONNECTION SETUP            |                                                                                                                                                                             |
| 12                                                               | →         |        | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                             |
| 13                                                               | →         |        | LOCATION UPDATING REQUEST       | location-updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.      |
| 14                                                               |           | SS     |                                 | The SS modifies the scrambling code of DL-DPCH for generating lower-layer failure.                                                                                          |
| 15                                                               |           | (void) |                                 |                                                                                                                                                                             |
| 15a                                                              | →         |        | CELL UPDATE                     | CCCH.                                                                                                                                                                       |
| 15b                                                              | ←         |        | RRC CONNECTION RELEASE          | CCCH.                                                                                                                                                                       |
| 15c                                                              |           | SS     |                                 | The SS re-modifies the scrambling code of DL-DPCH to the original one.                                                                                                      |
| 15d                                                              |           | UE     |                                 | The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC connection is released.                        |
| 16                                                               | →         |        | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                          |
| 17                                                               | ←         |        | RRC CONNECTION SETUP            |                                                                                                                                                                             |
| 18                                                               | →         |        | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                             |
| 19                                                               | →         |        | LOCATION UPDATING REQUEST       | location-updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.      |
| 20                                                               | ←         |        | AUTHENTICATION REQUEST          | Steps 20 and 21 are performed N times. N shall be chosen in such a way that T3210 expires.                                                                                  |
| 21                                                               | →         |        | AUTHENTICATION RESPONSE         |                                                                                                                                                                             |
| 22                                                               |           | UE     |                                 | The UE shall cease transmission and then shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the expiry of T3210. |
| 23                                                               | →         |        | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                          |
| 24                                                               | ←         |        | RRC CONNECTION SETUP            |                                                                                                                                                                             |
| 25                                                               | →         |        | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                             |
| 26                                                               | →         |        | LOCATION UPDATING REQUEST       | location-updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.      |
| 27                                                               | ←         |        | RRC CONNECTION RELEASE          | The SS waits for the disconnection of the main signalling link.                                                                                                             |

| Step                                                             | Direction |    | Message                         | Comments                                                                                                                                                                                                                                         |
|------------------------------------------------------------------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                  | UE        | SS |                                 |                                                                                                                                                                                                                                                  |
| 28                                                               | →         |    | RRC CONNECTION RELEASE COMPLETE | The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3212 (tolerance -15s; 45s) at least after the RRC connection is released.<br>Establishment cause: Registration.                                         |
| 29                                                               | UE        |    |                                 |                                                                                                                                                                                                                                                  |
| 30                                                               | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                  |
| 31                                                               | ←         |    | RRC CONNECTION SETUP            | location-updating type: "normal location update" CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station-classmark 1 as given by the ICS and mobile identity = IMSI.         |
| 32                                                               | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                  |
| 33                                                               | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                  |
| 34                                                               | ←         |    | LOCATION UPDATING REJECT        | IE Reject cause = #17 "network failure".<br>The SS waits for the disconnection of the main signalling link.                                                                                                                                      |
| 35                                                               | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                  |
| 36                                                               | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                  |
| 37                                                               | UE        |    |                                 | The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC connection is released.<br>Establishment cause: Registration.                                                       |
| 38                                                               | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                  |
| 39                                                               | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                  |
| 40                                                               | →         |    | RRC CONNECTION SETUP COMPLETE   | location-updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station-classmark 1 as given by the ICS and mobile identity = IMSI.<br>CKSN = initial CKSN. |
| 41                                                               | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                  |
| 42                                                               | ←         |    | AUTHENTICATION REQUEST          |                                                                                                                                                                                                                                                  |
| 43                                                               | →         |    | AUTHENTICATION RESPONSE         | IE mobile Identity = new TMSI.                                                                                                                                                                                                                   |
| 43a                                                              | ←         |    | SECURITY MODE COMMAND           |                                                                                                                                                                                                                                                  |
| 43b                                                              | →         |    | SECURITY MODE COMPLETE          |                                                                                                                                                                                                                                                  |
| 44                                                               | ←         |    | LOCATION UPDATING ACCEPT        | After the sending of this message, the SS waits for the disconnection of the main signalling link. UE is now "idle, updated" in cell A.                                                                                                          |
| 45                                                               | →         |    | TMSI REALLOCATION COMPLETE      |                                                                                                                                                                                                                                                  |
| 46                                                               | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                  |
| 47                                                               | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                  |
| The following messages are sent and shall be received on cell B. |           |    |                                 |                                                                                                                                                                                                                                                  |
| 48                                                               |           | SS |                                 | Set the cell type of cell B to the "Serving cell".<br>Set the cell type of cell A to the "non-suitable cell". (see note).<br>Establishment cause: Registration.                                                                                  |
| 49                                                               | →         |    | RRC CONNECTION REQUEST          | location-updating type = normal, CKSN = initial value, LAI = a, mobile station-classmark 1 as given by the ICS and mobile identity = TMSI.                                                                                                       |
| 50                                                               | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                  |
| 51                                                               | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                  |
| 52                                                               | →         |    | LOCATION UPDATING REQUEST       | IE Reject cause is set to #X in table 10.5.95 of TS 24.008, causes #2, #3, #6, #11, #12, #13 and #15 being excluded.<br>The SS waits for the disconnection of the main signalling link.                                                          |
| 53                                                               | ←         |    | LOCATION UPDATING REJECT        |                                                                                                                                                                                                                                                  |
| 54                                                               | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                  |
| 55                                                               | →         |    | RRC CONNECTION RELEASE COMPLETE | The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC connection is released.<br>Establishment cause: Registration.                                                       |
| 56                                                               | UE        |    |                                 |                                                                                                                                                                                                                                                  |
| 57                                                               | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                  |

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------|-----------|----|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 58   | ←         |    | RRC CONNECTION SETUP            | location-updating-type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.<br>The SS modifies the scrambling-code of DL-DPCH for generating lower layer failure.                                                                                                                                                                                                                                                                                                        |
| 59   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 60   | →         |    | LOCATION-UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 61   |           | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 61a  |           |    | (void)                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 61b  | →         |    | CELL UPDATE                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 61c  | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 61d  |           | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 61e  |           | UE |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 62   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 63   | ←         |    | RRC CONNECTION SETUP            | CCCH.<br>CCCH.<br>The SS re-modifies the scrambling-code of DL-DPCH to the original one.<br>The UE shall not initiate an RRC-connection establishment on cell A or on cell B during T3211 seconds at least after the RRC-connection is released.<br>Establishment cause: Registration.                                                                                                                                                                                                                                                                              |
| 64   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 65   | →         |    | LOCATION-UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 66   | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 67   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 68   |           | UE |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 69   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 70   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 71   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 72   | →         |    | LOCATION-UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 73   |           | SS |                                 | location-updating-type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI.<br>performs step 53 and 54.<br>performs step 55.<br>If the UE supports speech, it is made to perform an emergency call.<br>Establishment cause: Emergency call.                                                                                                                                                                            |
| 74   |           | UE |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 75   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 76   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 77   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 78   | →         |    | CM SERVICE REQUEST              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 79   | ←         |    | CM SERVICE ACCEPT               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 80   | →         |    | EMERGENCY SETUP                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 81   | ←         |    | RELEASE COMPLETE                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 82   | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 83   | →         |    | RRC CONNECTION RELEASE COMPLETE | CM service type = Emergency call establishment; CKSN = no key available; Mobile Identity = IMSI.<br><br>Cause = unassigned-number.<br>The SS waits for the disconnection of the main signalling link.<br><br>If possible (see ICS) USIM detachment is performed. Otherwise if possible (see ICS) switch-off is performed. Otherwise the power is removed.<br>The UE shall not initiate an RRC-connection establishment on cell A or on cell B. This is checked during 30 s.<br>Depending on what has been performed in step 84 the UE is brought back to operation. |
| 84   |           | UE |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 85   |           | UE |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 86   |           | UE |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |



| Step                                                             | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                                                                                                                                                                      |
|------------------------------------------------------------------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                  | UE        | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 87                                                               | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.<br><br>location-updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.<br>CKSN = initial CKSN.<br><br>IE mobile Identity = new TMSI.<br><br>After the sending of this message, the SS waits for the disconnection of the main signalling link. UE is now "idle, updated" in cell B. |
| 88                                                               | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 89                                                               | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 90                                                               | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 91                                                               | ←         |    | AUTHENTICATION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 92                                                               | →         |    | AUTHENTICATION RESPONSE         |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 92a                                                              | ←         |    | SECURITY MODE COMMAND           |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 92b                                                              | →         |    | SECURITY MODE COMPLETE          |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 93                                                               | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 94                                                               | →         |    | TMSI REALLOCATION COMPLETE      |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 95                                                               | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 96                                                               | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| The following messages are sent and shall be received on cell A. |           |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 97                                                               |           | SS |                                 | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "non-suitable cell". (see note).                                                                                                                                                                                                                                                                                                     |
| 98                                                               | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.<br><br>location-updating type = normal, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.                                                                                                                                                                                                                                          |
| 99                                                               | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 100                                                              | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 101                                                              | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 102                                                              | ←         |    | LOCATION UPDATING REJECT        | IE Reject cause is set to #38 in table 10.5.95 of TS 24.008, causes #2, #3, #6, #11, #12, #13 and #15 being excluded.                                                                                                                                                                                                                                                                                                         |
| 103                                                              | ←         |    | RRC CONNECTION RELEASE          | The SS waits for the disconnection of the main signalling link.                                                                                                                                                                                                                                                                                                                                                               |
| 104                                                              | →         |    | RRC CONNECTION RELEASE COMPLETE | The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC connection is released.                                                                                                                                                                                                                                                                          |
| 105                                                              | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 106                                                              | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 107                                                              | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 108                                                              | →         |    | RRC CONNECTION SETUP COMPLETE   | location-updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.<br>The SS modifies the scrambling code of DL DPCH for generating lower layer failure.                                                                                                                                                                  |
| 109                                                              | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 110                                                              |           | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 111                                                              |           |    | (void)                          |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 111a                                                             | →         |    | CELL UPDATE                     | CCCH.                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 111b                                                             | ←         |    | RRC CONNECTION RELEASE          | CCCH.                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 111c                                                             |           | SS |                                 | The SS re-modifies the scrambling code of DL DPCH to the original one.                                                                                                                                                                                                                                                                                                                                                        |
| 111d                                                             | UE        |    |                                 | The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC connection is released.                                                                                                                                                                                                                                                                          |
| 112                                                              | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                                                                                                                                                                                                                                                                            |
| 113                                                              | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 114                                                              | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                               |

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                         |
|------|-----------|----|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                  |
| 115  | →         |    | LOCATION-UPDATING REQUEST       | location-updating-type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile-Identity = IMSI.                                                           |
| 116  | ←         |    | RRC-CONNECTION-RELEASE          | The SS waits for the disconnection of the main signalling link.                                                                                                                                                                  |
| 117  | →         |    | RRC-CONNECTION-RELEASE COMPLETE |                                                                                                                                                                                                                                  |
| 118  | UE        |    |                                 |                                                                                                                                                                                                                                  |
| 119  | →         |    | RRC-CONNECTION-REQUEST          | The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC connection is released. Establishment cause: Registration.                                          |
| 120  | ←         |    | RRC-CONNECTION-SETUP            |                                                                                                                                                                                                                                  |
| 121  | →         |    | RRC-CONNECTION-SETUP COMPLETE   |                                                                                                                                                                                                                                  |
| 122  | →         |    | LOCATION-UPDATING REQUEST       | location-updating-type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile-identity = IMSI.         |
| 123  |           |    | (void)                          | performs step 61a.                                                                                                                                                                                                               |
| 123a | UE        |    |                                 |                                                                                                                                                                                                                                  |
| 123b | →         |    | CELL-UPDATE                     |                                                                                                                                                                                                                                  |
| 123c | ←         |    | RRC-CONNECTION-RELEASE          | performs step 61d.                                                                                                                                                                                                               |
| 123d | SS        |    |                                 |                                                                                                                                                                                                                                  |
| 124  | UE        |    |                                 |                                                                                                                                                                                                                                  |
| 125  | →         |    | RRC-CONNECTION-REQUEST          | A MO-CM-connection is attempted before T3212 expiry. Establishment cause: Registration.                                                                                                                                          |
| 126  | ←         |    | RRC-CONNECTION-SETUP            |                                                                                                                                                                                                                                  |
| 127  | →         |    | RRC-CONNECTION-SETUP COMPLETE   |                                                                                                                                                                                                                                  |
| 128  | →         |    | LOCATION-UPDATING REQUEST       | location-updating-type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile-Identity = IMSI.                                                           |
| 129  |           |    | (void)                          | performs step 61a.                                                                                                                                                                                                               |
| 129a | UE        |    |                                 |                                                                                                                                                                                                                                  |
| 129b | →         |    | CELL-UPDATE                     |                                                                                                                                                                                                                                  |
| 129c | ←         |    | RRC-CONNECTION-RELEASE          | performs step 61d.                                                                                                                                                                                                               |
| 129d | SS        |    |                                 |                                                                                                                                                                                                                                  |
| 130  | UE        |    |                                 |                                                                                                                                                                                                                                  |
| 131  | →         |    | RRC-CONNECTION-REQUEST          | The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC connection is released. Establishment cause: Registration.                                          |
| 132  | ←         |    | RRC-CONNECTION-SETUP            |                                                                                                                                                                                                                                  |
| 133  | →         |    | RRC-CONNECTION-SETUP COMPLETE   |                                                                                                                                                                                                                                  |
| 134  | →         |    | LOCATION-UPDATING REQUEST       | location-updating-type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile-Identity = IMSI.                                                           |
| 135  | ←         |    | AUTHENTICATION-REQUEST          | CKSN = initial-CKSN.                                                                                                                                                                                                             |
| 136  | →         |    | AUTHENTICATION-RESPONSE         |                                                                                                                                                                                                                                  |
| 136a | ←         |    | SECURITY-MODE-COMMAND           |                                                                                                                                                                                                                                  |
| 136b | →         |    | SECURITY-MODE-COMplete          | IE mobile-Identity = new TMSI.                                                                                                                                                                                                   |
| 137  | ←         |    | LOCATION-UPDATING-ACCEPT        |                                                                                                                                                                                                                                  |
| 138  | →         |    | TMSI-REALLOCATION COMPLETE      |                                                                                                                                                                                                                                  |
| 139  | ←         |    | RRC-CONNECTION-RELEASE          | UE is now "idle, updated" in cell A. The UE may or may not have memorised the request for CM connection. The steps 141 to 147 are therefore optional for the UE. The SS waits 10 s whether to decide to go directly to step 148. |
| 140  | →         |    | RRC-CONNECTION-RELEASE COMPLETE |                                                                                                                                                                                                                                  |
| 141  | →         |    | RRC-CONNECTION-REQUEST          |                                                                                                                                                                                                                                  |
| 142  | ←         |    | RRC-CONNECTION-SETUP            |                                                                                                                                                                                                                                  |

| Step                                                             | Direction |    | Message                         | Comments                                                                                                                                                               |
|------------------------------------------------------------------|-----------|----|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                  | UE        | SS |                                 |                                                                                                                                                                        |
| 143                                                              | →         |    | RRC CONNECTION SETUP COMPLETE   | CKSN = initial value, Mobile identity = TMSI.<br>cause #17 (network failure).<br>The SS waits for the disconnection of the main signalling link.                       |
| 144                                                              | →         |    | CM SERVICE REQUEST              |                                                                                                                                                                        |
| 145                                                              | ←         |    | CM SERVICE REJECT               |                                                                                                                                                                        |
| 146                                                              | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                        |
| 147                                                              | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                        |
| The following messages are sent and shall be received on cell B. |           |    |                                 |                                                                                                                                                                        |
| 148                                                              |           | SS |                                 | Set the cell type of cell B to the "Serving cell".<br>Set the cell type of cell A to the "non-suitable cell".<br>(see note).<br>Establishment cause: Registration.     |
| 149                                                              | →         |    | RRC CONNECTION REQUEST          | location updating type = normal, CKSN = initial value, LAI = a, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.                             |
| 150                                                              | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                        |
| 151                                                              | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                        |
| 152                                                              | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                        |
| 153                                                              | ←         |    | LOCATION UPDATING REJECT        | IE Reject cause is set to #38 in table 10.5.95 of TS 24.008, causes #2, #3, #6, #11, #12, #13 and #15 being excluded.                                                  |
| 154                                                              | ←         |    | RRC CONNECTION RELEASE          | The SS waits for the disconnection of the main signalling link                                                                                                         |
| 155                                                              | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                        |
| 156                                                              | UE        |    |                                 | The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC connection is released.                   |
| 157                                                              | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                     |
| 158                                                              | ←         |    | RRC CONNECTION SETUP            | location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI. |
| 159                                                              | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                        |
| 160                                                              | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                        |
| 161                                                              |           | SS |                                 |                                                                                                                                                                        |
| 162                                                              |           |    | (void)                          | The SS modifies the scrambling code of DL-DPCH for generating lower layer failure.                                                                                     |
| 162a                                                             | →         |    | CELL UPDATE                     | CCCH.                                                                                                                                                                  |
| 162b                                                             | ←         |    | RRC CONNECTION RELEASE          | CCCH.                                                                                                                                                                  |
| 162c                                                             |           | SS |                                 | The SS re-modifies the scrambling code of DL-DPCH to the original one.                                                                                                 |
| 162d                                                             | UE        |    |                                 | The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC connection is released.                   |
| 163                                                              | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                     |
| 164                                                              | ←         |    | RRC CONNECTION SETUP            | location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI. |
| 165                                                              | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                        |
| 166                                                              | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                        |
| 167                                                              | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                        |
| 168                                                              | →         |    | RRC CONNECTION RELEASE COMPLETE | The SS waits for the disconnection of the main signalling link.                                                                                                        |
| 169                                                              | UE        |    |                                 | The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC connection is released.                   |
| 170                                                              | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                     |
| 171                                                              | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                        |
| 172                                                              | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                        |

| Step                                                                                                                                                                | Direction |    | Message                         | Comments                                                                                                                                                                                                                 |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                     | UE        | SS |                                 |                                                                                                                                                                                                                          |
| 173                                                                                                                                                                 | →         |    | LOCATION-UPDATING REQUEST       | location-updating-type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI. |
| 174                                                                                                                                                                 | ←         |    | LOCATION-UPDATING-REJECT        | IE Reject cause = "retry upon entry into a new cell".                                                                                                                                                                    |
| 174a                                                                                                                                                                | ←         |    | RRC-CONNECTION-RELEASE          | The SS waits for the disconnection of the main signalling link.                                                                                                                                                          |
| 174b                                                                                                                                                                | →         |    | RRC-CONNECTION-RELEASE COMPLETE |                                                                                                                                                                                                                          |
| The following messages are sent and shall be received on cell A.                                                                                                    |           |    |                                 |                                                                                                                                                                                                                          |
| 175                                                                                                                                                                 |           | SS |                                 | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "non-suitable cell". (see note).                                                                                                |
| 176                                                                                                                                                                 | →         |    | RRC-CONNECTION-REQUEST          | Establishment cause: Registration.                                                                                                                                                                                       |
| 177                                                                                                                                                                 | ←         |    | RRC-CONNECTION-SETUP            |                                                                                                                                                                                                                          |
| 178                                                                                                                                                                 | →         |    | RRC-CONNECTION-SETUP COMPLETE   |                                                                                                                                                                                                                          |
| 179                                                                                                                                                                 | →         |    | LOCATION-UPDATING REQUEST       | location-updating-type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI. |
| 180                                                                                                                                                                 |           | SS |                                 | performs the step 61.                                                                                                                                                                                                    |
| 181                                                                                                                                                                 |           |    | (void)                          |                                                                                                                                                                                                                          |
| 181a                                                                                                                                                                | →         |    | CELL-UPDATE                     | CCCH.                                                                                                                                                                                                                    |
| 181b                                                                                                                                                                | ←         |    | RRC-CONNECTION-RELEASE          | CCCH.                                                                                                                                                                                                                    |
| 181c                                                                                                                                                                |           | SS |                                 | The SS re-modifies the scrambling code of DL-DPCH to the original one.                                                                                                                                                   |
| 181d                                                                                                                                                                |           | UE |                                 | The UE shall not initiate an RRC connection establishment on cell A or on cell B during T3211 seconds at least after the RRC connection is released.                                                                     |
| 182                                                                                                                                                                 | →         |    | RRC-CONNECTION-REQUEST          | Establishment cause: Registration.                                                                                                                                                                                       |
| 183                                                                                                                                                                 | ←         |    | RRC-CONNECTION-SETUP            |                                                                                                                                                                                                                          |
| 184                                                                                                                                                                 | →         |    | RRC-CONNECTION-SETUP COMPLETE   |                                                                                                                                                                                                                          |
| 185                                                                                                                                                                 | →         |    | LOCATION-UPDATING REQUEST       | location-updating-type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE), Mobile Identity = IMSI.                                                   |
| 186                                                                                                                                                                 | ←         |    | AUTHENTICATION-REQUEST          | CKSN = initial CKSN.                                                                                                                                                                                                     |
| 187                                                                                                                                                                 | →         |    | AUTHENTICATION-RESPONSE         |                                                                                                                                                                                                                          |
| 187a                                                                                                                                                                | ←         |    | SECURITY-MODE-COMMAND           |                                                                                                                                                                                                                          |
| 187b                                                                                                                                                                | →         |    | SECURITY-MODE-COMplete          |                                                                                                                                                                                                                          |
| 188                                                                                                                                                                 | ←         |    | LOCATION-UPDATING-ACCEPT        | IE mobile Identity = new TMSI.                                                                                                                                                                                           |
| 189                                                                                                                                                                 | →         |    | TMSI-REALLOCATION COMPLETE      |                                                                                                                                                                                                                          |
| 190                                                                                                                                                                 | ←         |    | RRC-CONNECTION-RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link. UE is now "idle, updated" in cell A.                                                                                  |
| 191                                                                                                                                                                 | →         |    | RRC-CONNECTION-RELEASE COMPLETE |                                                                                                                                                                                                                          |
| NOTE: The definitions for "Serving cell" and "non-suitable cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                                                                                          |

## Specific message contents

None.

## 9.4.3.3.5 Test requirement

- 1) 1.1 At step 33 the UE shall perform location-updating procedure.

- 1.2 At step 41 the UE shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type IE set to "normal location updating".
- 2) At step 85 the UE shall not perform the IMSI detach procedure.
- 3) At step 78 the UE shall send a CM SERVICE REQUEST message with the CM Service Type IE set to "emergency call establishment", CKSN IE set to "no key is available" and Mobile Identity IE set to its IMSI.
- At step 80 the UE shall send an EMERGENCY SETUP message.
- 4) —
- 4.1 At step 128 the UE shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type IE set to "normal location updating";
- 4.2 At step 134 the UE shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type IE set to "normal location updating".
- 5) —
- 5.1 At step 179 the UE shall perform a normal location updating procedure if it enters a new cell;
- 5.2 At step 185 the UE shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type IE set to "normal location updating".

#### ~~9.4.3.4 Location updating / abnormal cases / attempt counter less or equal to 4, stored LAI equal to broadcast LAI~~

##### ~~9.4.3.4.1 Definition~~

##### ~~9.4.3.4.2 Conformance requirement~~

- 1) When a failure such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 has occurred during a periodic location updating procedure (the broadcast LAI is equal to the stored LAI):
- 1.1 the UE shall be able to establish an MM connection i.e. send a RRC CONNECTION REQUEST message and then a CM SERVICE REQUEST message, CKSN and LAI set to those which have been allocated to the UE, Mobile Identity IE set to the TMSI which has been allocated to the UE;
- 1.2 then the UE shall not attempt a location updating procedure.
- 2) When a failure such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 has occurred during an IMSI attach procedure (the broadcast LAI is equal to the stored LAI):
- 2.1 the UE shall be able to establish an MM connection i.e. send a RRC CONNECTION REQUEST message and then a CM SERVICE REQUEST message, CKSN and LAI set to those which have been allocated to the UE, Mobile Identity IE set to the TMSI which has been allocated to the UE;
- 2.2 then the UE shall not attempt a location updating procedure.
- 3) When a failure such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 has occurred during a periodic location updating procedure and the attempt counter is smaller than 4 the UE shall send, after T3211 expiry, a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to the TMSI which has been allocated to the UE, CKSN IE and LAI set to those which have been allocated to the UE and the Location Updating Type IE set to "periodic updating".
- 3.1 When the UE's attempt counter reaches the value 4 (four failures such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 have occurred during a periodic location updating procedure) after T3212 expiry it shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating Type IE set to "normal".

- 4) When the UE's attempt counter reaches the value 4 (four failures such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 have occurred during a periodic location updating procedure) it shall use a request for a CM connection other than emergency call as a trigger for a location updating procedure.
- 5) When a failure such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 has occurred during an IMSI attach procedure and the attempt counter is smaller than 4 the UE shall send, after T3211 expiry, a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to the TMSI which has been allocated to the UE, CKSN IE and LAI set to those which have been allocated to the UE and the Location Updating type set to "IMSI attach".
- 5.1 When the UE's attempt counter reaches the value 4 (four failures such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 have occurred during an IMSI attach procedure) after T3212 expiry it shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type set to "normal".
- 6) When the UE's attempt counter reaches the value 4 (four failures such as cases d), f), g) and h) of clause 4.4.4.9 of TS 24.008 have occurred during an IMSI attach procedure) it shall use a request for a CM connection other than emergency call as a trigger for a location updating procedure.

## References

TS 24.008 clause 4.4.4.9.

### 9.4.3.4.3 ————— Test purpose

To verify that in the case when the attempt counter is smaller than 4 and the broadcast LAI is equal to the stored LAI, the UE is in the MM IDLE state and NORMAL SERVICE substate. To verify that timer T3211 is stopped after a MM connection establishment.

To verify that the UE uses the T3211 timer, and that it enters the MM IDLE state and NORMAL SERVICE substate when its attempt counter reaches value 4 even in the case where the stored LAI is equal to the broadcast LAI.

### 9.4.3.4.4 ————— Method of test

#### Initial conditions

- System Simulator:
  - one cell: B, belonging to location area b;
  - IMSI attach/detach is allowed;
  - T3212 is set to 6 minutes.
- User Equipment:
  - the UE is "Idle updated" on cell B with a valid CKSN and a TMSI.

#### Related ICS/IXIT statements

USIM removal possible while UE is powered Yes/No.

Switch off on button Yes/No.

#### Test Procedure

A failure during the periodic location updating is triggered: as the broadcast LAI is equal to the stored LAI, the UE is still in the MM IDLE state and NORMAL SERVICE substate and timer T3211 is started. A CM connection other than for emergency call is attempted. It is checked that this is possible and that T3211 is stopped. Same test is performed with a failure during an IMSI attach procedure.

Then failures are triggered during the periodic location updating to let the attempt counter to reach the value of 4. The UE shall enter the MM IDLE state and ATTEMPTING TO UPDATE substate and delete any TMSI, stored LAI, ciphering key sequence number and ciphering key. When the attempt counter reaches the value of 4, timer T3212 shall be started. At timer T3212 expiry a location updating procedure is started. A request for CM connection other for than emergency call shall trigger a location updating procedure.

Same tests are performed when the failures are triggered during an IMSI attach procedure.

#### Expected sequence

| Step                         | Direction |    | Message                         | Comments                                                                                                                                                                                                                                         |
|------------------------------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                              | UE        | SS |                                 |                                                                                                                                                                                                                                                  |
| 1                            |           | SS |                                 | The SS shall wait at most T3212 + 45 s.<br>Establishment cause: Registration.                                                                                                                                                                    |
| 2                            | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                  |
| 3                            | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                  |
| 4                            | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                  |
| 5                            | →         |    | LOCATION UPDATING REQUEST       | location updating type = periodic, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.<br>performs step 6, of 9.4.3.2 with cause #17 and step 7 of 9.4.3.2.<br>performs step 8 of 9.4.3.2. |
| 6                            |           | SS |                                 |                                                                                                                                                                                                                                                  |
| 6a                           |           | UE |                                 |                                                                                                                                                                                                                                                  |
| 7                            |           | UE |                                 |                                                                                                                                                                                                                                                  |
| 8                            | →         |    | RRC CONNECTION REQUEST          | A MO-CM connection is attempted before T3211 expiry.                                                                                                                                                                                             |
| 9                            | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                  |
| 10                           | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                  |
| 11                           | →         |    | CM SERVICE REQUEST              |                                                                                                                                                                                                                                                  |
| 12                           | ←         |    | CM SERVICE ACCEPT               | CKSN = initial CKSN, Mobile Identity = TMSI.                                                                                                                                                                                                     |
| 13                           | →         |    | An initial CM message           |                                                                                                                                                                                                                                                  |
| 14                           | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                  |
| 15                           | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                  |
| 16                           |           | SS |                                 | The SS waits for the disconnection of the main signalling link.                                                                                                                                                                                  |
| 17                           |           | UE |                                 | The UE shall not initiate an RRC connection establishment. This is checked during T3211.                                                                                                                                                         |
| Steps 18 to 23 are optional. |           |    |                                 |                                                                                                                                                                                                                                                  |
| 18                           | →         |    | RRC CONNECTION REQUEST          | If possible (see ICS) USIM detachment is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.                                                                                                     |
| 19                           | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                  |
| 20                           | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                  |
| 21                           | →         |    | IMSI DETACH INDICATION          |                                                                                                                                                                                                                                                  |
| 22                           | ←         |    | RRC CONNECTION RELEASE          | Establishment Cause: Detach                                                                                                                                                                                                                      |
| 23                           | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                  |
| 24                           |           | UE |                                 |                                                                                                                                                                                                                                                  |
| 25                           | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                  |
| 26                           | ←         |    | RRC CONNECTION SETUP            | Depending on what has been performed in step 17 the UE is brought back to operation.<br>Establishment cause: Registration.                                                                                                                       |
| 27                           | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                  |
| 28                           | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                  |
| 29                           |           | SS |                                 |                                                                                                                                                                                                                                                  |
| 29a                          |           |    | (void)                          | location updating type = IMSI attach, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.<br>performs step 14 of 9.4.3.2.                                                                  |
| 29b                          | →         |    | CELL UPDATE                     |                                                                                                                                                                                                                                                  |
| 29c                          | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                  |
| 29d                          |           | SS |                                 |                                                                                                                                                                                                                                                  |
| 30                           |           | UE |                                 | CCCH.<br>CCCH.<br>performs step 15c of 9.4.3.2.<br>A MO-CM connection is attempted before T3211 expiry.                                                                                                                                          |
| 31                           | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                  |
| 32                           | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                  |

| Step                             | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                       |
|----------------------------------|-----------|----|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                  | UE        | SS |                                 |                                                                                                                                                                                                                                                                |
| 33                               | →         |    | RRC CONNECTION SETUP COMPLETE   | <p>CKSN = initial CKSN, Mobile Identity = TMSI.</p> <p>The SS waits for the disconnection of the main signalling link.</p> <p>The UE shall not initiate an RRC connection establishment. This is checked during T3211 UE is "idle, updated" in cell B.</p>     |
| 34                               | →         |    | CM SERVICE REQUEST              |                                                                                                                                                                                                                                                                |
| 35                               | ←         |    | SECURITY MODE COMMAND           |                                                                                                                                                                                                                                                                |
| 36                               | →         |    | SECURITY MODE COMPLETE          |                                                                                                                                                                                                                                                                |
| 37                               | →         |    | An initial CM message           |                                                                                                                                                                                                                                                                |
| 38                               | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                |
| 39                               | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                |
| 40                               |           | SS |                                 |                                                                                                                                                                                                                                                                |
| 40/1                             | UE        |    |                                 | If possible (see ICS) USIM detachment is performed. Otherwise if possible (see ICS) switch-off is performed. Otherwise the power is removed.                                                                                                                   |
| Steps 40/2 to 40/7 are optional. |           |    |                                 |                                                                                                                                                                                                                                                                |
| 40/2                             | →         |    | RRC CONNECTION REQUEST          | Establishment Cause: Detach                                                                                                                                                                                                                                    |
| 40/3                             | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                |
| 40/4                             | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                |
| 40/5                             | →         |    | IMSI DETACH INDICATION          |                                                                                                                                                                                                                                                                |
| 40/6                             | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                |
| 40/7                             | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                |
| 40/8                             |           | UE |                                 |                                                                                                                                                                                                                                                                |
| 40/9                             | →         |    | RRC CONNECTION REQUEST          | <p>Depending on what has been performed in step 40/1, the UE is brought back to operation.</p> <p>Establishment cause: Registration.</p>                                                                                                                       |
| 40/10                            | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                |
| 40/11                            | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                |
| 40/12                            | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                |
| 40/13                            | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                                                                                                                                                |
| 40/14                            | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                |
| 40/15                            | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                |
| 41                               |           | SS |                                 | <p>The SS shall wait at most T3212 + 15 s.</p> <p>Establishment cause: Registration.</p>                                                                                                                                                                       |
| 42                               | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                |
| 43                               | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                |
| 44                               | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                |
| 45                               | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                |
| 46                               |           | SS |                                 |                                                                                                                                                                                                                                                                |
| 46a                              |           |    | (void)                          |                                                                                                                                                                                                                                                                |
| 46b                              | →         |    | CELL UPDATE                     | <p>CCCH.</p> <p>CCCH.</p> <p>performs step 15c of 9.4.3.2.</p> <p>The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC connection is released.</p> <p>Establishment cause: Registration.</p>                          |
| 46c                              | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                |
| 46d                              |           | SS |                                 |                                                                                                                                                                                                                                                                |
| 47                               |           | UE |                                 |                                                                                                                                                                                                                                                                |
| 48                               | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                |
| 49                               | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                |
| 50                               | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                |
| 51                               | →         |    | LOCATION UPDATING REQUEST       | <p>location-updating type = periodic, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.</p> <p>performs step 6 of 9.4.3.2 with cause #17 and step 7 of 9.4.3.2.</p> <p>performs step 8 of 9.4.3.2.</p> |
| 52                               |           | SS |                                 |                                                                                                                                                                                                                                                                |
| 52a                              |           | UE |                                 |                                                                                                                                                                                                                                                                |



| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                 |
|------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                          |
| 53   |           | UE |                                 | The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC connection is released.                                                                                                    |
| 54   | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                                                                       |
| 55   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                          |
| 56   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                          |
| 57   | →         |    | LOCATION UPDATING REQUEST       | location-updating type = periodic, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.                                                                             |
| 58   |           | SS |                                 | performs step 14 of 9.4.3.2.                                                                                                                                                                                             |
| 59   |           |    | (void)                          |                                                                                                                                                                                                                          |
| 59a  | →         |    | CELL UPDATE                     | CCCH.                                                                                                                                                                                                                    |
| 59b  | ←         |    | RRC CONNECTION RELEASE          | CCCH.                                                                                                                                                                                                                    |
| 59c  |           | SS |                                 | The SS re-modifies the scrambling code of DL DPCH to the original one.                                                                                                                                                   |
| 59d  |           | UE |                                 | The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC connection is released.                                                                                                    |
| 60   | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                                                                       |
| 61   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                          |
| 62   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                          |
| 63   | →         |    | LOCATION UPDATING REQUEST       | location-updating type = periodic, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.                                                                             |
| 64   |           | SS |                                 | performs step 14 of 9.4.3.2.                                                                                                                                                                                             |
| 64a  |           |    | (void)                          |                                                                                                                                                                                                                          |
| 64b  | →         |    | CELL UPDATE                     | CCCH.                                                                                                                                                                                                                    |
| 64c  | ←         |    | RRC CONNECTION RELEASE          | CCCH.                                                                                                                                                                                                                    |
| 64d  |           | SS |                                 | performs step 15c of 9.4.3.2.                                                                                                                                                                                            |
| 65   |           | UE |                                 | The UE shall not initiate an RRC connection establishment during T3212 seconds at least after the RRC connection is released.                                                                                            |
| 66   | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                                                                       |
| 67   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                          |
| 68   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                          |
| 69   | →         |    | LOCATION UPDATING REQUEST       | location-updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI. |
| 70   | ←         |    | AUTHENTICATION REQUEST          | CKSN = initial CKSN.                                                                                                                                                                                                     |
| 71   | →         |    | AUTHENTICATION RESPONSE         |                                                                                                                                                                                                                          |
| 71a  | ←         |    | SECURITY MODE COMMAND           |                                                                                                                                                                                                                          |
| 71b  | →         |    | SECURITY MODE COMPLETE          |                                                                                                                                                                                                                          |
| 72   |           |    | (void)                          |                                                                                                                                                                                                                          |
| 72a  | ←         |    | LOCATION UPDATING ACCEPT        | IE mobile Identity = TMSI.                                                                                                                                                                                               |
| 72b  | →         |    | TMSI REALLOCATION COMPLETE      |                                                                                                                                                                                                                          |
| 73   | ←         |    | RRC CONNECTION RELEASE          | The SS waits for the disconnection of the main signalling link.                                                                                                                                                          |
| 74   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                          |
| 75   |           | UE |                                 | The UE shall not initiate an RRC connection establishment during than T3212 seconds at least after the RRC connection is released.                                                                                       |
| 76   | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                                                                       |
| 77   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                          |
| 78   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                          |
| 79   | →         |    | LOCATION UPDATING REQUEST       | location-updating type = periodic, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.                                                                             |

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                 |
|------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                          |
| 80   |           | SS |                                 | performs step 6 of 9.4.3.2 with cause #17 and step 7 of 9.4.3.2.                                                                                                                                                         |
| 80a  | UE        |    |                                 | performs step 8 of 9.4.3.2.                                                                                                                                                                                              |
| 81   | UE        |    |                                 | The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC connection is released.                                                                                                    |
| 82   | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                                                                       |
| 83   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                          |
| 84   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                          |
| 85   | →         |    | LOCATION UPDATING REQUEST       | location-updating type = periodic, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.                                                                             |
| 86   |           | SS |                                 | performs step 14 of 9.4.3.2.                                                                                                                                                                                             |
| 87   |           |    | (void)                          |                                                                                                                                                                                                                          |
| 87a  | →         |    | CELL UPDATE                     | CCCH.                                                                                                                                                                                                                    |
| 87b  | ←         |    | RRC CONNECTION RELEASE          | CCCH.                                                                                                                                                                                                                    |
| 87c  |           | SS |                                 | The SS re-modifies the scrambling code of DL DPCH to the original one.                                                                                                                                                   |
| 87d  | UE        |    |                                 | The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC connection is released.                                                                                                    |
| 88   | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                                                                       |
| 89   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                          |
| 90   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                          |
| 91   | →         |    | LOCATION UPDATING REQUEST       | location-updating type = periodic, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.                                                                             |
| 92   |           | SS |                                 | performs step 14 of 9.4.3.2.                                                                                                                                                                                             |
| 92a  |           |    | (void)                          |                                                                                                                                                                                                                          |
| 92b  | →         |    | CELL UPDATE                     | CCCH.                                                                                                                                                                                                                    |
| 92c  | ←         |    | RRC CONNECTION RELEASE          | CCCH.                                                                                                                                                                                                                    |
| 92d  |           | SS |                                 | performs step 15c of 9.4.3.2.                                                                                                                                                                                            |
| 93   | UE        |    |                                 | The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC connection is released.                                                                                                    |
| 94   | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                                                                       |
| 95   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                          |
| 96   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                          |
| 97   | →         |    | LOCATION UPDATING REQUEST       | location-updating type = periodic, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.                                                                             |
| 98   |           | SS |                                 | performs step 6 of 9.4.3.2 with cause #17 and step 7 of 9.4.3.2.                                                                                                                                                         |
| 98a  | UE        |    |                                 | performs step 8 of 9.4.3.2.                                                                                                                                                                                              |
| 99   | UE        |    |                                 | A MO-CM connection is attempted before T3212 expiry.                                                                                                                                                                     |
| 100  | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                                                                                       |
| 101  | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                          |
| 102  | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                          |
| 103  | →         |    | LOCATION UPDATING REQUEST       | location-updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI. |
| 104  | ←         |    | LOCATION UPDATING ACCEPT        | IE mobile identity = TMSI.                                                                                                                                                                                               |
| 105  | →         |    | TMSI REALLOCATION COMPLETE      |                                                                                                                                                                                                                          |
| 106  | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                          |
| 107  | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                          |

Steps 108 to 114 are optional. Wait 10 s to decide whether to go directly to step 115.

| Step                           | Direction |    | Message                         | Comments                                                                                                                                           |
|--------------------------------|-----------|----|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
|                                | UE        | SS |                                 |                                                                                                                                                    |
| 108                            | →         |    | RRC CONNECTION REQUEST          | CKSN = no key available, Mobile identity = TMSI cause #17 (network failure).                                                                       |
| 109                            | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                    |
| 110                            | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                    |
| 111                            | →         |    | CM SERVICE REQUEST              |                                                                                                                                                    |
| 112                            | ←         |    | CM SERVICE REJECT               |                                                                                                                                                    |
| 113                            | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                    |
| 114                            | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                    |
| 115                            |           | UE |                                 | If possible (see ICS) USIM detachment is performed. Otherwise if possible (see ICS) switch-off is performed. Otherwise the power is removed.       |
| Steps 116 to 121 are optional. |           |    |                                 |                                                                                                                                                    |
| 116                            | →         |    | RRC CONNECTION REQUEST          | Establishment Cause: Detach                                                                                                                        |
| 117                            | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                    |
| 118                            | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                    |
| 119                            | →         |    | IMSI DETACH INDICATION          |                                                                                                                                                    |
| 120                            | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                    |
| 121                            | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                    |
| 122                            |           | UE |                                 | Depending on what has been performed in step 115 the UE is brought back to operation.                                                              |
| 123                            | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                 |
| 124                            | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                    |
| 125                            | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                    |
| 126                            | →         |    | LOCATION UPDATING REQUEST       | location updating type = IMSI attach, CKSN = no key available, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI. |
| 127                            |           | SS | (void)                          | performs step 14 of 9.4.3.2.                                                                                                                       |
| 128a                           | →         |    | CELL UPDATE                     | CCCH.                                                                                                                                              |
| 128b                           | ←         |    | RRC CONNECTION RELEASE          | CCCH.                                                                                                                                              |
| 128c                           |           | SS |                                 | The SS re-modifies the scrambling code of DL DPCH to the original one.                                                                             |
| 128d                           |           | UE |                                 | The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC connection is released.                              |
| 129                            | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                 |
| 130                            | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                    |
| 131                            | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                    |
| 132                            | →         |    | LOCATION UPDATING REQUEST       | location updating type = IMSI attach, CKSN = no key available, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI. |
| 133                            | ←         |    | RRC CONNECTION RELEASE          | After the sending of the message the SS waits for the disconnection of the main signalling link.                                                   |
| 134                            | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                    |
| 135                            |           | UE |                                 | The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC connection is released.                              |
| 136                            | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.                                                                                                                 |
| 137                            | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                    |
| 138                            | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                    |
| 139                            | →         |    | LOCATION UPDATING REQUEST       | location updating type = IMSI attach, CKSN = no key available, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI. |
| 140                            |           |    | (void)                          |                                                                                                                                                    |
| 140a                           | ←         |    | LOCATION UPDATING REJECT        | IE Reject cause is set to #X in table 10.5.95 of TS 24.008, causes #2, #3, #6, #11, #12, #13 and #15 being excluded.                               |
| 140b                           | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                 |

| Step                           | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|--------------------------------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                | UE        | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 141                            | →         |    | RRC CONNECTION RELEASE COMPLETE | <p>The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC connection is released.</p> <p>Establishment cause: Registration.</p> <p>location updating type = IMSI attach, CKSN = no key available, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.</p> <p>performs step 14 of 9.4.3.2.</p> <p>CCCH.</p> <p>CCCH.</p> <p>performs step 15c of 9.4.3.2.</p> <p>The UE shall not initiate an RRC connection establishment during T3212 seconds at least after the RRC connection is released.</p> <p>Establishment cause: Registration.</p> |
| 142                            | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 143                            | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 144                            | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 145                            | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 146                            | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 147                            | SS        |    | (void)                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 147a                           | →         |    | CELL UPDATE                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 147b                           | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 147c                           | SS        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 148                            | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 149                            | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 150                            | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 151                            | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 152                            | →         |    | LOCATION UPDATING REQUEST       | <p>location updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI.</p> <p>CKSN = initial CKSN.</p> <p>IE mobile Identity = TMSI.</p>                                                                                                                                                                                                                                                                                                                      |
| 153                            | ←         |    | AUTHENTICATION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 154                            | →         |    | AUTHENTICATION RESPONSE         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 154a                           | ←         |    | SECURITY MODE COMMAND           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 154b                           | →         |    | SECURITY MODE COMPLETE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 155                            | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 156                            | →         |    | TMSI REALLOCATION COMPLETE      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 157                            | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 158                            | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 159                            | UE        |    |                                 | <p>If possible (see ICS) USIM detachment is performed.</p> <p>Otherwise if possible (see ICS) switch-off is performed.</p> <p>Otherwise the power is removed.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Steps 160 to 165 are optional. |           |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 160                            | →         |    | RRC CONNECTION REQUEST          | Establishment Cause: Detach                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| 161                            | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 162                            | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 163                            | →         |    | IMSI DETACH INDICATION          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 164                            | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 165                            | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 166                            | UE        |    |                                 | <p>Depending on what has been performed in step 159 the UE is brought back to operation.</p> <p>Establishment cause: Registration.</p> <p>location updating type = IMSI attach, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.</p> <p>performs step 14 of 9.4.3.2.</p> <p>CCCH.</p> <p>CCCH.</p> <p>performs step 15c of 9.4.3.2.</p>                                                                                                                                                                                                                   |
| 167                            | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 168                            | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 169                            | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 170                            | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 171                            | SS        |    | (void)                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 171a                           | →         |    | CELL UPDATE                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 171b                           | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 171c                           | SS        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 171d                           | SS        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 172  | UE        |    |                                 | The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC connection is released.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 173  | →         |    | RRC CONNECTION REQUEST          | Establishment cause: Registration.<br><br>location-updating type = IMSI attach, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.<br>performs step 6 of 9.4.3.2 with cause #17 and step 7 of 9.4.3.2.<br>performs step 8 of 9.4.3.2.<br><br>The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC connection is released.<br>Establishment cause: Registration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 174  | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 175  | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 176  | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 177  |           | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 177a |           | UE |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 178  |           | UE |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 179  | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 180  | ←         |    | RRC CONNECTION SETUP            | location-updating type = IMSI attach, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.<br>performs step 14 of 9.4.3.2.<br><br>CCCH.<br>CCCH.<br>The SS re-modifies the scrambling code of DL DPCH to the original one.<br>The UE shall not initiate an RRC connection establishment during T3211 at least after the RRC connection is released.<br>Establishment cause: Registration.<br><br>location-updating type = IMSI attach, CKSN = initial value, LAI = b, mobile station classmark 1 as given by the ICS and mobile identity = TMSI.<br>performs step 14 of 9.4.3.2.<br><br>CCCH.<br>CCCH.<br>performs step 15c of 9.4.3.2.<br>A MO-CM connection id attempted before T3212 expiry<br>Establishment cause: Registration.<br><br>location-updating type = normal, CKSN = no key available, LAI = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE) mobile station classmark 1 as given by the ICS and mobile identity = IMSI.<br>CKSN = initial CKSN.<br><br>IE mobile Identity = TMSI. |
| 181  | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 182  | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 183  |           | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 184  |           |    | (void)                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 184a | →         |    | CELL UPDATE                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 184b | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 184c |           | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 184d |           | UE |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 185  | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 186  | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 187  | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 188  | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 189  |           | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 189a |           |    | (void)                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 189b | →         |    | CELL UPDATE                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 189c | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 189d |           | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 190  |           | UE |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 191  | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 192  | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 193  | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 194  | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 195  | ←         |    | AUTHENTICATION REQUEST          | IE mobile Identity = TMSI.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 196  | →         |    | AUTHENTICATION RESPONSE         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 196a | ←         |    | SECURITY MODE COMMAND           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 196b | →         |    | SECURITY MODE COMPLETE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 197  | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 198  | →         |    | TMSI REALLOCATION COMPLETE      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 199  | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 200  | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |

| Step                           | Direction |    | Message                            | Comments                                                                      |
|--------------------------------|-----------|----|------------------------------------|-------------------------------------------------------------------------------|
|                                | UE        | SS |                                    |                                                                               |
| Steps 202 to 208 are optional. |           |    |                                    |                                                                               |
| 201                            |           |    | (void)                             | CKSN = initial value, Mobile identity = TMSI.<br>cause #17 (network failure). |
| 202                            | →         |    | RRC CONNECTION REQUEST             |                                                                               |
| 203                            | ←         |    | RRC CONNECTION SETUP               |                                                                               |
| 204                            | →         |    | RRC CONNECTION SETUP<br>COMPLETE   |                                                                               |
| 205                            | →         |    | CM SERVICE REQUEST                 |                                                                               |
| 206                            | ←         |    | CM SERVICE REJECT                  |                                                                               |
| 207                            | ←         |    | RRC CONNECTION RELEASE             |                                                                               |
| 208                            | →         |    | RRC CONNECTION RELEASE<br>COMPLETE |                                                                               |

### Specific message contents

None.

#### 9.4.3.4.5 Test requirement

1)-

1.1 At step 8 the UE shall send a RRC CONNECTION REQUEST message and at step 11 the UE shall send a CM SERVICE REQUEST message, CKSN and LAI set to those which have been allocated to the UE, Mobile Identity IE set to the TMSI which has been allocated to the UE;

1.2 At step 11 the UE shall not attempt a location updating procedure.

2)-

2.1 At step 31 the UE shall send a RRC CONNECTION REQUEST message and at step 34 the UE shall send a CM SERVICE REQUEST message, CKSN and LAI set to those which have been allocated to the UE, Mobile Identity IE set to the TMSI which has been allocated to the UE;

2.2 At step 39 the UE shall not attempt a location updating procedure.

3)- At step 51 the UE shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to the TMSI which has been allocated to the UE, CKSN IE and LAI set to those which have been allocated to the UE and the Location Updating Type IE set to "periodic updating".

3.1 At step 69 the UE shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating Type IE set to "normal".

4)- At step 103 the UE shall send a LOCATION UPDATING REQUEST message.

5)- At step 132 the UE shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to the TMSI which has been allocated to the UE, CKSN IE and LAI set to those which have been allocated to the UE and the Location Updating Type IE set to "IMSI attach".

5.1 At step 152 the UE shall send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating Type IE set to "normal".

6)- At step 194 the UE shall send a LOCATION UPDATING REQUEST message.

### 9.4.4 Location updating / release / expiry of T3240

#### 9.4.4.1 Definition

#### 9.4.4.2 Conformance requirement

The UE receiving a LOCATION UPDATING ACCEPT message shall start T3240: it shall abort the RRC connection at the expiry of timer T3240.

## References

TS 24.008 clauses 4.4.4.8 and 11.2.

## 9.4.4.3 Test purpose

To verify that the UE aborts the RRC connection at the expiry of timer T3240.

## 9.4.4.4 Method of test

## Initial conditions

- System Simulator:
  - two cells: A and B, belonging to different location areas a and b.
- User Equipment:
  - the UE has a valid TMSI. It is "idle-updated" on cell A.

## Related ICS/IXIT statements

None.

## Test Procedure

A normal location updating procedure is performed. The RRC connection is not released by the SS within the timer T3240. It is checked that the UE aborts the RRC connection.

## Expected sequence

| Step                                                                                                                                                                                                                                                                      | Direction |    | Message                               | Comments                                                                                                                      |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                                                                                                                           | UE        | SS |                                       |                                                                                                                               |
| 1                                                                                                                                                                                                                                                                         |           | SS |                                       | Set the cell type of cell B to the "Serving cell".<br>Set the cell type of cell A to the "non-suitable cell".<br>(see note 1) |
| 2                                                                                                                                                                                                                                                                         | →         |    | RRC CONNECTION REQUEST                | "Establishment cause": Registration.                                                                                          |
| 3                                                                                                                                                                                                                                                                         | ←         |    | RRC CONNECTION SETUP                  |                                                                                                                               |
| 4                                                                                                                                                                                                                                                                         | →         |    | RRC CONNECTION SETUP COMPLETE         |                                                                                                                               |
| 5                                                                                                                                                                                                                                                                         | →         |    | LOCATION UPDATING REQUEST             |                                                                                                                               |
| 6                                                                                                                                                                                                                                                                         | ←         |    | LOCATION UPDATING ACCEPT              |                                                                                                                               |
| 7                                                                                                                                                                                                                                                                         |           | SS |                                       | The SS waits T3240 expiry.                                                                                                    |
| 8                                                                                                                                                                                                                                                                         | →         |    | SIGNALLING CONNECTION RELEASE REQUEST | The UE shall abort the RRC connection.<br>(see note 2)                                                                        |
| 9                                                                                                                                                                                                                                                                         | ←         |    | RRC CONNECTION RELEASE                | SS disconnect the connection established.                                                                                     |
| 10                                                                                                                                                                                                                                                                        | →         |    | RRC CONNECTION RELEASE COMPLETE       | Send only if RRC Connection Release is send.                                                                                  |
| NOTE1: The definitions for "Serving cell" and "non-suitable cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only".                                                                                                      |           |    |                                       |                                                                                                                               |
| NOTE2: At the expiration of T3240, as per TS 24.008, RR connection shall be aborted. In UMTS, UE cannot release RRC connection on its own. Instead, UE can send a Signalling Connection Release Request to the UTRAN, in order to initiate the release of RRC connection. |           |    |                                       |                                                                                                                               |

## Specific message contents

None.

## 9.4.4.5 Test requirement

At step 10 the UE shall abort the RRC connection.

## ~~9.4.5 Location updating / periodic~~

### ~~9.4.5.1 Location updating / periodic spread~~

#### ~~9.4.5.1.1 Definition~~

#### ~~9.4.5.1.2 Conformance requirement~~

- ~~1) The UEs shall perform spreading of the time before performing a periodic location updating when the location updating timer value is reduced.~~
- ~~2) The UE shall reset timer T3212 when the UE is deactivated, and shall start with a value between zero and the broadcasted value when reactivated in the same cell, IMSI attach being forbidden.~~
- ~~3) When activated the UE shall start timer T3212 with a value randomly drawn in the allowed range.~~

~~NOTE: This conformance requirement is not covered by a test purpose. It is intended to be covered by a manufacturer declaration.~~

#### References

TS 24.008 clause 4.4.2.

#### ~~9.4.5.1.3 Test purpose~~

- ~~1) To check that when the location updating timer is reduced, the timer running in the UE is started with a value depending on the current timer value and the new broadcasted T3212 value.~~
- ~~2) To verify that when the UE is reactivated in the same cell (as the one in which it was deactivated), IMSI attach being forbidden, the UE starts the timer T3212 with a value between zero and the broadcasted value.~~

~~NOTE: It is not tested that the value is random.~~

#### ~~9.4.5.1.4 Method of test~~

##### Initial conditions

— System Simulator:

- one cell, T3212 is set to 30 minutes;
- IMSI attach is allowed in the cell;

— User Equipment:

- the UE is deactivated. The stored MCC, MNC and LAC correspond to the broadcasted values. The stored update status is "updated".

##### Related ICS/IXIT statements

None.

##### Test procedure

The UE is activated. It performs IMSI attach. 3 minutes after the end of the IMSI attach procedure, the value of T3212 is set to 6 minutes. The UE shall perform periodic location updating 6 minutes after the end of the IMSI attach procedure.

Then, the IMSI attach/detach is forbidden. T3212 is still set to 6 minutes.

The UE is deactivated. The UE is reactivated. It is checked that the UE performs a periodic location updating during the 6 minutes following activation.



## Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                             |
|------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                      |
| 1    | UE        |    |                                 | The UE is activated.                                                                                                                 |
| 2    | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.                                                                                                 |
| 3    | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                      |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                      |
| 5    | →         |    | LOCATION UPDATING REQUEST       | "location-updating type": IMSI attach.                                                                                               |
| 6    | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                      |
| 7    | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                   |
| 8    | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                      |
| 9    | SS        |    |                                 | 3 minutes after step 8 the value of T3212 is set to 6 minutes.                                                                       |
| 10   | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.<br>This message shall be sent by the UE between 5 minutes 45 s and 6 minutes 15 s after step 8. |
| 11   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                      |
| 12   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                      |
| 13   | →         |    | LOCATION UPDATING REQUEST       | "location-updating type": periodic updating.                                                                                         |
| 14   | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                      |
| 15   | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                   |
| 16   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                      |
| 17   | SS        |    |                                 | IMSI attach/detach is not allowed.                                                                                                   |
| 18   | UE        |    |                                 | The UE is deactivated.                                                                                                               |
| 19   | UE        |    |                                 | The UE is activated.                                                                                                                 |
| 20   | SS        |    |                                 | The SS waits until the periodic location updating.                                                                                   |
| 21   | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.<br>This message shall arrive during the 6 minutes following the UE activation.                  |
| 22   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                      |
| 23   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                      |
| 24   | →         |    | LOCATION UPDATING REQUEST       | "Location-updating type" = periodic.                                                                                                 |
| 25   | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                      |
| 26   | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                   |
| 27   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                      |

## Specific message contents

None.

## 9.4.5.1.5 ——— Test requirement

At step 10 the UE shall send an RRC CONNECTION REQUEST for a periodic location updating.

At step 21 the UE shall send an RRC CONNECTION REQUEST for a periodic location updating.

### ~~9.4.5.2 Location updating / periodic normal / test 1~~

#### ~~9.4.5.2.1 Definition~~

#### ~~9.4.5.2.2 Conformance requirement~~

- ~~1—The UE shall stop and reset the timer T3212 of the periodic location updating procedure when the first MM message is received or SECURITY mode setting is completed in the case of MM connection establishment.~~
- ~~2—The UE shall stop and reset the timer T3212 of the periodic location updating procedure when the UE has responded to paging and thereafter has received the first correct L3 message that is not an RRC message.~~

#### ~~References~~

~~TS 24.008 clause 4.4.2.~~

#### ~~9.4.5.2.3 Test purpose~~

~~To verify that the UE stops and resets the timer T3212 of the periodic location updating procedure when:~~

- ~~—the first MM message is received in the case of MM connection establishment, security mode being not set;~~
- ~~—the UE has responded to paging and the first correct L3 message that is not an RRC message is received.~~

~~NOTE:—T3212 is stopped when the MM idle state is left and restarted when the MM sublayer returns to that state, substate NORMAL SERVICE or ATTEMPTING TO UPDATE. As a consequence, the exact time when T3212 is reset between those two events cannot be tested.~~

#### ~~9.4.5.2.4 Method of test~~

##### ~~Initial conditions~~

- ~~—System Simulator:~~
  - ~~—1 cell, default parameters;~~
  - ~~—IMSI attach/detach is not allowed;~~
  - ~~—the T3212 time-out value is 2/10 hour.~~
- ~~—User Equipment:~~
  - ~~—the UE has a valid TMSI. It is "idle updated".~~

##### ~~Related ICS/IXIT statements~~

~~None.~~

##### ~~Test procedure~~

~~An UE originated MM connection is established and cleared. The RRC CONNECTION is released. It is checked that the UE performs a periodic location updating 12 minutes after the release of the RRC CONNECTION.~~

~~One minute after the periodic location updating, the UE is paged, it sends a RRC CONNECTION REQUEST message and the SS responds with an RRC CONNECTION SETUP message, a call is established and then cleared. It is checked that the UE performs a periodic location updating 12 minutes after the release of the link.~~

## Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|------|-----------|----|--------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 1    |           | UE |                                                              | <p>A MO-CM connection is attempted.</p> <p>cause #17 (network failure).</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p> <p>The SS waits until the periodic location updating.</p> <p>"Establishment cause": Registration.</p> <p>This message shall arrive between 11 minutes 45 s and 12 minutes 15 s after the last release of the RRC connection by the SS.</p> <p>"Location updating type" = periodic.</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p>                                                                                     |
| 2    | →         |    | RRC CONNECTION REQUEST                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 3    | ←         |    | RRC CONNECTION SETUP                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 5    | →         |    | CM SERVICE REQUEST                                           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 6    | ←         |    | CM SERVICE REJECT                                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 7    | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 8    | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 9    |           | SS |                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 10   | →         |    | RRC CONNECTION REQUEST                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 11   | ←         |    | RRC CONNECTION SETUP                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 12   | →         |    | RRC CONNECTION SETUP COMPLETE                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 13   | →         |    | LOCATION UPDATING REQUEST                                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 14   | ←         |    | LOCATION UPDATING ACCEPT                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 15   | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 16   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 17   |           | SS |                                                              | <p>The SS waits 1 minute.</p> <p>See TS 34.108 clause 7.1.2</p> <p>"Mobile identity" = IMSI.</p> <p>"Establishment cause": Terminating Conversational Call.</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p> <p>The SS waits until the periodic location updating.</p> <p>"Establishment cause": Registration.</p> <p>This message shall arrive between 11 minutes 45 s and 12 minutes 15 s after the last release of the RRC connection by the SS.</p> <p>"Location updating type" = periodic.</p> <p>After the sending of this message, the SS waits for the disconnection of the main signalling link.</p> |
| 18   | ←         |    | Mobile terminated establishment of Radio Resource Connection |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 19   | →         |    | PAGING RESPONSE                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 20   | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 21   | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 22   | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 23   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 24   |           | SS |                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 25   | →         |    | RRC CONNECTION REQUEST                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 26   | ←         |    | RRC CONNECTION SETUP                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 27   | →         |    | RRC CONNECTION SETUP COMPLETE                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 28   | →         |    | LOCATION UPDATING REQUEST                                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 29   | ←         |    | LOCATION UPDATING ACCEPT                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 30   | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 31   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |

## Specific message contents

None.

## 9.4.5.2.5 Test requirement

At step 10 the UE shall initiate an RRC CONNECTION REQUEST 12 minutes after the release of the RRC CONNECTION (at step 7).

At step 25 the UE shall initiate an RRC CONNECTION REQUEST 12 minutes after the release of the RRC CONNECTION (at step 22).

### ~~9.4.5.3 Location updating / periodic normal / test 2~~

#### ~~9.4.5.3.1 Definition~~

#### ~~9.4.5.3.2 Conformance requirement~~

When a LOCATION UPDATING ACCEPT or a LOCATION UPDATING REJECT message is received, the timer T3212 is stopped and reset and the UE shall perform a periodic location updating after T3212 expiry.

#### References

TS 24.008 clause 4.4.2.

#### ~~9.4.5.3.3 Test purpose~~

To verify that the UE stops and resets the timer T3212 of the periodic location updating procedure when a LOCATION UPDATING ACCEPT message is received.

NOTE: T3212 is stopped when the MM idle state is left and restarted when the MM sublayer returns to that state, substate NORMAL SERVICE or ATTEMPTING TO UPDATE. As a consequence, the exact time when T3212 is reset between those two events cannot be tested.

#### ~~9.4.5.3.4 Method of test~~

#### Initial conditions

- System Simulator:
  - 2 cells, IMSI attach/detach is allowed in both cells;
  - T3212 is set to 6 minutes.
- User Equipment:
  - the UE has a valid TMSI. It is "idle updated" on cell A.

#### Related ICS/IXIT statements

USIM removal possible while UE is powered Yes/No.

Switch off on button yes/No.

#### Test procedure

A normal location updating is performed. The RRC CONNECTION is released. One minute later, the UE is deactivated, then reactivated in the same cell. It is checked that the UE performs an IMSI attach and a periodic location updating 6 minutes after the IMSI attach.

## Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                        |
|------|-----------|----|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                 |
| 1    |           | SS |                                 | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell B to the "Serving cell".<br>Set the cell type of cell A to the "non-suitable cell".<br>(see note)                                 |
| 2    | →         |    | RRC CONNECTION REQUEST          | "establishment cause": Registration.                                                                                                                                                                                            |
| 3    | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                 |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                 |
| 5    | →         |    | LOCATION UPDATING REQUEST       | "location-updating type" = normal.                                                                                                                                                                                              |
| 6    | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                                                                                                                 |
| 7    | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                                              |
| 8    | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                 |
| 9    |           | SS |                                 | The SS waits until the periodic location updating.                                                                                                                                                                              |
| 10   | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.<br>This message shall arrive between 5 minutes 45s and 6 minutes 15 s after the last release of the RRC connection by the SS.                                                              |
| 11   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                 |
| 12   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                 |
| 13   | →         |    | LOCATION UPDATING REQUEST       | "Location-updating type" = periodic.                                                                                                                                                                                            |
| 14   | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                                                                                                                 |
| 15   | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                                              |
| 16   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                 |
| 17   |           | UE |                                 | If possible (see ICS) USIM removal is performed.<br>Otherwise if possible (see ICS) switch off is performed.<br>Otherwise the power is removed. steps 18 to 23 may be performed or not depending on the action made in step 17. |
| 18   | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Detach                                                                                                                                                                                                   |
| 19   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                 |
| 20   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                 |
| 21   | →         |    | IMSI DETACH INDICATION          |                                                                                                                                                                                                                                 |
| 22   | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                                              |
| 23   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                 |
| 24   |           | UE |                                 | Depending on what has been performed in step 17 the UE is brought back to operation.                                                                                                                                            |
| 25   | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.                                                                                                                                                                                            |
| 26   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                 |
| 27   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                 |
| 28   | →         |    | LOCATION UPDATING REQUEST       | "Location-updating type" = IMSI attach.                                                                                                                                                                                         |
| 29   | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                                                                                                                 |
| 30   | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                                              |
| 31   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                 |
| 32   |           | SS |                                 | The SS waits until the periodic location updating.                                                                                                                                                                              |
| 33   | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.<br>This message shall arrive between 5 minutes 45 s and 6 minutes 15s after the last release of the RRC connection by the SS.                                                              |
| 34   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                 |

| Step                                                                                                                                                                  | Direction |    | Message                         | Comments                                                                                                                                       |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                       | UE        | SS |                                 |                                                                                                                                                |
| 35                                                                                                                                                                    | →         |    | RRC CONNECTION SETUP COMPLETE   | "Location-updating-type" = periodic.<br><br>After the sending of this message, the SS waits for the disconnection of the main signalling link. |
| 36                                                                                                                                                                    | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                |
| 37                                                                                                                                                                    | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                                |
| 38                                                                                                                                                                    | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                |
| 39                                                                                                                                                                    | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                |
| NOTE: — The definitions for "Serving cell" and "non-suitable cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                |

### Specific message contents

None.

#### 9.4.5.3.5 Test requirement

After step 28 the UE shall performs an IMSI attach.

After step 33 the UE shall performs periodic location updating 6 minutes after step 28.

### 9.4.5.4 Location updating / periodic search for higher priority PLMN when in VPLMN

#### 9.4.5.4.1 Location updating / periodic search for higher priority PLMN / UE waits time T

##### 9.4.5.4.1.1 Definition

##### 9.4.5.4.1.2 Conformance requirement

1. If the MS is in a VPLMN, the MS shall periodically attempt to obtain service on its HPLMN or higher priority PLMN listed in "user controlled PLMN-selector" or "operator controlled PLMN-selector".
2. In the case that the mobile has a stored "Equivalent PLMNs" list the mobile shall only select a PLMN if it is of a higher priority than those of the same country as the current serving PLMN which are stored in the "Equivalent PLMNs" list.
3. For this purpose, a value T minutes may be stored in the SIM, T is either in the range 6 minutes to 8 hours in 6 minute steps or it indicates that no periodic attempts shall be made. If no value is stored in the SIM, a default value of 60 minutes is used.
4. The attempts to access the HPLMN or higher priority PLMN shall be as specified below:
  - a) The periodic attempts shall only be performed in automatic mode when the MS is roaming;
  - b) After switch-on, a period of at least 2 minutes and at most T minutes shall elapse before the first attempt is made;
  - c) The MS shall make an attempt if the MS is on the VPLMN at time T after the last attempt;
  - d) Periodic attempts shall only be performed by the MS while in idle mode;
  - e) If the HPLMN or higher priority PLMN is not found, the MS shall remain on the VPLMN;
  - f) In steps i), ii) and iii) the MS shall limit its attempts to access higher priority PLMNs to PLMNs of the same country as the current serving VPLMN;
  - g) Only the priority levels of Equivalent PLMNs of the same country as the current serving VPLMN shall be taken into account to compare with the priority level of a selected PLMN.

References

TS 22.011 clause 3.2.2.5. and TS 23.122 4.4.3.3.

9.4.5.4.1.3 Test purpose

To verify that when a cell of a higher priority PLMN the HPLMN becomes available, following the successful location request on a VPLMN and after the first search the mobile has failed to find a higher priority PLMN, that the UE shall perform a location update request on a higher priority PLMN after time T. Where T is the Search Period stored in the USIM.

9.4.5.4.1.4 Method of test

Initial conditions

- System Simulator:
  - four cells A, B, C and D, belonging to different location areas with location identification a, b, c and d. Their country codes and mobile network codes are defined as follows:

| Cell | MCC | MNC |
|------|-----|-----|
| A    | 001 | 001 |
| B    | 022 | 002 |
| C    | 001 | 010 |
| D    | 001 | 100 |

Initially Cells A, B and C shall not be broadcasting. IMSI attach/detach is not allowed on any of other cells.

- User Equipment:
  - the UE is switched off. The HPLMN Search Period on the USIM shall be set to 6 minutes. The location area information on the USIM is "deleted".
  - The following USIM fields are configured:

| USIM field               | Priority        | PLMN |
|--------------------------|-----------------|------|
| EF <sub>HPLMNWA</sub> CT | 1 <sup>st</sup> | A    |
| EF <sub>PLMNWA</sub> CT  | 1 <sup>st</sup> | B    |
|                          | 2 <sup>nd</sup> | E    |
| EF <sub>OPLMNWA</sub> CT | 1 <sup>st</sup> | C    |
|                          | 2 <sup>nd</sup> | D    |

In the table PLMN X is the PLMN code from cell X (see above). PLMN E is defined as MCC=001, MNC=030.

Related ICS/IXIT statements

Switch on/off button Yes/No.

Test Procedure

Only Cell D shall be broadcasting. The UE shall be switched on either by using the Power Switch or by applying power. A normal location updating is performed on Cell D. The SS shall include the PLMN E in the list of equivalent PLMNs that is sent in the Location Update Accept message. Cells B and C shall be made available after 8 minutes, thus ensuring the UE fails to find any higher priority PLMN during its first attempt. It is verified that the UE does not perform a location update request on Cell B or C (waiting for at least 6 minutes after broadcasting of Cells B and C). Then Cell A is also made available, and it is verified that the UE performs a location update request on Cell A within 6 minutes after broadcasting of Cell A.

## Expected sequence

| Step                                                                                                                                                    | Direction |    | Message                                                                                                                                                                                                                 | Contents                                                                                                                                                                             |
|---------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                         | UE        | SS |                                                                                                                                                                                                                         |                                                                                                                                                                                      |
| 1                                                                                                                                                       | UE        |    | RRC CONNECTION REQUEST<br>RRC CONNECTION SETUP<br>RRC CONNECTION SETUP COMPLETE<br>LOCATION UPDATING REQUEST<br>LOCATION UPDATING ACCEPT<br>RRC CONNECTION RELEASE<br>RRC CONNECTION RELEASE COMPLETE                   | The following messages shall be sent and received on Cell-D:<br>The UE is switched on by either using the Power Switch or by applying power.<br>"Establishment cause": Registration. |
| 2                                                                                                                                                       | →         |    |                                                                                                                                                                                                                         | "Location Update Type": Normal.                                                                                                                                                      |
| 3                                                                                                                                                       | ←         |    |                                                                                                                                                                                                                         |                                                                                                                                                                                      |
| 4                                                                                                                                                       | →         |    |                                                                                                                                                                                                                         |                                                                                                                                                                                      |
| 5                                                                                                                                                       | →         |    |                                                                                                                                                                                                                         |                                                                                                                                                                                      |
| 6                                                                                                                                                       | ←         |    |                                                                                                                                                                                                                         | After sending this message the SS waits for the disconnection of the main signalling link.                                                                                           |
| 7                                                                                                                                                       | ←         |    |                                                                                                                                                                                                                         |                                                                                                                                                                                      |
| 8                                                                                                                                                       | →         |    |                                                                                                                                                                                                                         |                                                                                                                                                                                      |
| 8a                                                                                                                                                      | SS        |    |                                                                                                                                                                                                                         |                                                                                                                                                                                      |
| 8b                                                                                                                                                      | SS        |    | The SS waits a period of 8 minutes, this allowing the UE to make its first periodic search.                                                                                                                             |                                                                                                                                                                                      |
| 9                                                                                                                                                       | SS        |    | Set the cell type of cell B to the "Suitable neighbor cell".<br>Set the cell type of cell C to the "Suitable neighbor cell". (see note)<br>The SS shall wait for 7 minutes during which no messages should be received. |                                                                                                                                                                                      |
| 10                                                                                                                                                      | →         |    | Set the cell type of cell A to the "Suitable neighbor cell". (see note)<br>Within 6 minutes after step 9, the following messages shall be sent and received on Cell A:<br>"Establishment cause": Registration.          |                                                                                                                                                                                      |
| 11                                                                                                                                                      | ←         |    |                                                                                                                                                                                                                         |                                                                                                                                                                                      |
| 12                                                                                                                                                      | →         |    |                                                                                                                                                                                                                         |                                                                                                                                                                                      |
| 13                                                                                                                                                      | →         |    |                                                                                                                                                                                                                         | "Location Update Type": normal.                                                                                                                                                      |
| 14                                                                                                                                                      | ←         |    |                                                                                                                                                                                                                         |                                                                                                                                                                                      |
| 15                                                                                                                                                      | ←         |    |                                                                                                                                                                                                                         | After sending this message the SS waits for the disconnection of the main signalling link.                                                                                           |
| 16                                                                                                                                                      | →         |    |                                                                                                                                                                                                                         |                                                                                                                                                                                      |
| NOTE: — The definitions for "Suitable neighbor cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                                                                                                                                                                                                         |                                                                                                                                                                                      |

## Specific message contents

None.

## 9.4.5.4.1.5 Test requirement

At step 9, the UE shall not send any LOCATION UPDATING REQUEST on cell B or C.

At step 13 the UE shall send a LOCATION UPDATING REQUEST message on Cell A.

## 9.4.5.4.2 Location updating / search for higher priority PLMN / UE in manual mode

## 9.4.5.4.2.1 Definition

## 9.4.5.4.2.2 Conformance requirement

The periodic attempts shall only be performed if in automatic mode when the UE is in a VPLMN.



## References

TS 22.011 clause 3.2.2.5. and TS 23.122 clause 4.4.3.3.

## 9.4.5.4.2.3 ——— Test purpose

To verify that no Search for Higher Priority PLMN is performed when the UE is not in automatic mode.

## 9.4.5.4.2.4 ——— Method of test

## Initial conditions

—— System Simulator:

—— two cells A and B, belonging to different location areas with location identification a and b. Cell A shall be a cell of the HPLMN and Cell B shall be a cell of the VPLMN with a Country Code the same as that of Cell A. Initially Cell A shall not be broadcasting. IMSI attach/detach is not allowed on either cell.

—— User Equipment:

—— the UE is switched off. The HPLMN Search Period on the USIM shall be set to 6 minutes. The location area information on the USIM is "deleted".

## Related ICS/IXIT statements

Switch on/off button Yes/No.

## Test Procedure

Only Cell B shall be broadcasting. The UE shall be switched on either by using the Power Switch or by applying power. A normal location updating is performed on Cell B. The UE is forced into manual selection mode. Cell A is made available. It is verified that the UE does not attempt to perform a location update on Cell A.

## Expected sequence

| Step                                                                                                                                                    | Direction |    | Message                                                                                                                                                                                               | Contents                                                                                                                                                                             |
|---------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                         | UE        | SS |                                                                                                                                                                                                       |                                                                                                                                                                                      |
| 1                                                                                                                                                       | UE        |    | RRC CONNECTION REQUEST<br>RRC CONNECTION SETUP<br>RRC CONNECTION SETUP COMPLETE<br>LOCATION UPDATING REQUEST<br>LOCATION UPDATING ACCEPT<br>RRC CONNECTION RELEASE<br>RRC CONNECTION RELEASE COMPLETE | The following messages shall be sent and received on Cell B:<br>The UE is switched on by either using the Power Switch or by applying power.<br>"Establishment cause": Registration. |
| 2                                                                                                                                                       | →         |    |                                                                                                                                                                                                       | "Location Update Type": Normal.                                                                                                                                                      |
| 3                                                                                                                                                       | ←         |    |                                                                                                                                                                                                       |                                                                                                                                                                                      |
| 4                                                                                                                                                       | →         |    |                                                                                                                                                                                                       | After sending this message the SS waits for the disconnection of the main signalling link.                                                                                           |
| 5                                                                                                                                                       | →         |    |                                                                                                                                                                                                       |                                                                                                                                                                                      |
| 6                                                                                                                                                       | ←         |    |                                                                                                                                                                                                       |                                                                                                                                                                                      |
| 7                                                                                                                                                       | ←         |    |                                                                                                                                                                                                       |                                                                                                                                                                                      |
| 8                                                                                                                                                       | →         |    |                                                                                                                                                                                                       |                                                                                                                                                                                      |
| 9                                                                                                                                                       | UE        |    |                                                                                                                                                                                                       | The UE is forced into manual selection mode.                                                                                                                                         |
| 10                                                                                                                                                      | SS        |    |                                                                                                                                                                                                       | Set the cell type of cell A to the "Suitable neighbor cell". (see note)                                                                                                              |
| 11                                                                                                                                                      | SS        |    |                                                                                                                                                                                                       | The SS waits a period of 6 minutes. During this time no messages shall be received on Cell A.                                                                                        |
| NOTE: — The definitions for "Suitable neighbor cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                                                                                                                                                                                       |                                                                                                                                                                                      |

## Specific message contents

None.

#### ~~9.4.5.4.2.5 Test requirement~~

~~At step 11 the UE shall not attempt to perform a location update.~~

#### ~~9.4.5.4.3 Location updating / search for higher priority PLMN / UE waits at least two minutes and at most T minutes~~

##### ~~9.4.5.4.3.1 Definition~~

##### ~~9.4.5.4.3.2 Conformance requirement~~

~~After switch on, the UE waits at least 2 minutes and at most T minutes before the first Search for higher priority PLMN is attempted.~~

#### ~~References~~

~~TS 22.011 clause 3.2.2.5. and TS 23.122 4.4.3.3.~~

##### ~~9.4.5.4.3.3 Test purpose~~

~~To verify that the UE waits at least 2 minutes and at most T minutes before attempting its first Search for higher priority PLMN.~~

##### ~~9.4.5.4.3.4 Method of test~~

#### ~~Initial Conditions~~

##### ~~— System Simulator:~~

- ~~— two cells A and B, belonging to different location areas with location identification a and b. Cell A shall be a cell of the HPLMN and Cell B shall be a cell of the VPLMN with a Country Code the same as that of Cell A. Initially Cell A shall not be broadcasting. IMSI attach/detach is not allowed on either cell.~~

##### ~~— User Equipment:~~

- ~~— the UE is switched off. The HPLMN Search Period on the USIM shall be set to 6 minutes. The location area information on the USIM is "deleted".~~

#### ~~Related ICS/IXIT statements~~

~~Switch on/off button Yes/No.~~

#### ~~Test Procedure~~

~~Only Cell B shall be broadcasting. The UE shall be switched on either by using the Power Switch or by applying power. A normal location updating is performed on Cell B. Cell A is made available. It is verified that the UE attempts to perform a location update on Cell A, after at least 2 minutes and at most T minutes have passed following power on.~~

## Expected sequence

| Step                                                                                                                                                    | Direction |    | Message                                                                                                                                                                                               | Contents                                                                                                                                                                                                                                                                                         |
|---------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                         | UE        | SS |                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                  |
| 1                                                                                                                                                       | UE        |    | RRC CONNECTION REQUEST<br>RRC CONNECTION SETUP<br>RRC CONNECTION SETUP COMPLETE<br>LOCATION UPDATING REQUEST<br>LOCATION UPDATING ACCEPT<br>RRC CONNECTION RELEASE<br>RRC CONNECTION RELEASE COMPLETE | The following messages shall be sent and received on Cell B.<br>The UE is switched on by either using the Power Switch or by applying power.<br>"Establishment cause": Registration.                                                                                                             |
| 2                                                                                                                                                       | →         |    |                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                  |
| 3                                                                                                                                                       | ←         |    |                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                  |
| 4                                                                                                                                                       | →         |    |                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                  |
| 5                                                                                                                                                       | →         |    |                                                                                                                                                                                                       | "Location Update Type": Normal.                                                                                                                                                                                                                                                                  |
| 6                                                                                                                                                       | ←         |    |                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                  |
| 7                                                                                                                                                       | ←         |    |                                                                                                                                                                                                       | After sending this message the SS waits for the disconnection of the main signalling link.                                                                                                                                                                                                       |
| 8                                                                                                                                                       | →         |    |                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                  |
| 9                                                                                                                                                       | SS        |    | RRC CONNECTION REQUEST<br>RRC CONNECTION SETUP<br>RRC CONNECTION SETUP COMPLETE<br>LOCATION UPDATING REQUEST<br>LOCATION UPDATING ACCEPT<br>RRC CONNECTION RELEASE<br>RRC CONNECTION RELEASE COMPLETE | Set the cell type of cell A to the "Suitable neighbor cell". (see note)                                                                                                                                                                                                                          |
| 10                                                                                                                                                      | SS        |    |                                                                                                                                                                                                       | The SS waits a period of 2 minutes after the UE is switched on. During this time no messages shall be received on Cell A. The following messages shall be sent and received on cell A. Within 6 minutes after the UE is switched on the following messages shall be sent and received on cell A. |
| 11                                                                                                                                                      | →         |    |                                                                                                                                                                                                       | "Establishment cause": Registration. This message shall be sent between 2 and 6 minutes after step 1                                                                                                                                                                                             |
| 12                                                                                                                                                      | ←         |    |                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                  |
| 13                                                                                                                                                      | →         |    |                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                  |
| 14                                                                                                                                                      | →         |    |                                                                                                                                                                                                       | "Location Update Type": normal.                                                                                                                                                                                                                                                                  |
| 15                                                                                                                                                      | ←         |    |                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                  |
| 16                                                                                                                                                      | ←         |    |                                                                                                                                                                                                       | After sending this message the SS waits for the disconnection of the main signalling link.                                                                                                                                                                                                       |
| 17                                                                                                                                                      | →         |    |                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                  |
| NOTE: — The definitions for "Suitable neighbor cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                  |

## Specific message contents

None.

## 9.4.5.4.3.5 Test requirement

At step 11 the UE shall attempt to perform a location update.

## 9.4.6 Location updating / interworking of attach and periodic

## 9.4.6.1 Definition

## 9.4.6.2 Conformance requirement

- 1) If the UE is in service state NO CELL AVAILABLE, LIMITED SERVICE, PLMN SEARCH or PLMN SEARCH-NORMAL SERVICE when the timer T3212 expires the location updating procedure is delayed until this service state is left.
- 2) The T3212 time-out value shall not be changed in the NO CELL AVAILABLE, LIMITED SERVICE, PLMN SEARCH and PLMN SEARCH-NORMAL SERVICE states.

- 3) If the selected cell is in the location area where the UE is registered and IMSI ATTACH is not required and timer T3212 has not expired, then the state is NORMAL SERVICE.

## References

- 1) ~~TS 24.008 clause 4.4.2.~~
- 2) ~~TS 24.008 clause 4.4.2.~~
- 3) ~~TS 24.008 clause 4.2.1.1.~~

## 9.4.6.3 Test purpose

- 1) ~~To check that if the PLU timer expires while the UE is out of coverage, the UE informs the network of its return to coverage.~~
- 2) ~~To check that the PLU timer is not disturbed by cells of forbidden PLMNs.~~
- 3) ~~To check that if the PLU timer does not expire while out of coverage and if the mobile returns to the LA where it is updated, the UE does not inform the network of its return to coverage.~~

## 9.4.6.4 Method of test

### Initial conditions

- ~~— System Simulator:~~
  - ~~— two cells, a and b, of different PLMNs;~~
  - ~~— T3212 is set to 12 minutes on cell a;~~
  - ~~— T3212 is set to 6 minutes on cell b;~~
  - ~~— IMSI attach is allowed in both cells.~~
- ~~— User Equipment:~~
  - ~~— the UE is deactivated. The PLMN of cell b is entered in the USIM's forbidden PLMN list.~~

### Related ICS/IXIT statements

~~None.~~

### Test procedure

~~The UE is activated and placed in automatic network selection mode. It performs IMSI attach. 1 minute after the end of the IMSI attach procedure, cell a is switched off. The UE shall not location update on cell b. 8 minutes after the end of the IMSI attach procedure, cell a is switched on. The UE shall not location update on cell a before 11,75 minutes after the end of the IMSI attach procedure. The UE shall perform a periodic location update on cell a between 11,75 minutes and 12,25 minutes after the end of the IMSI attach procedure.~~

~~3 minutes after the end of the periodic location updating procedure, cell a is switched off. The UE shall not location update on cell b. 14 minutes after the end of the periodic location updating procedure, cell a is switched on and cell b is switched off. The UE shall perform a location update on cell a before 17 minutes after the end of the periodic location updating procedure.~~

## Expected sequence

| Step                                                                                                                                                         | Direction |    | Message                         | Comments                                                                                                                                                     |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                              | UE        | SS |                                 |                                                                                                                                                              |
|                                                                                                                                                              |           |    |                                 | The following messages are sent and shall be received on cell A.                                                                                             |
| 1                                                                                                                                                            | UE        |    |                                 | The UE is activated in automatic network selection mode.<br>"Establishment cause": Registration.                                                             |
| 2                                                                                                                                                            | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                              |
| 3                                                                                                                                                            | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                              |
| 4                                                                                                                                                            | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                              |
| 5                                                                                                                                                            | →         |    | LOCATION UPDATING REQUEST       | "location-updating type": IMSI attach.                                                                                                                       |
| 6                                                                                                                                                            | ←         |    | LOCATION UPDATING ACCEPT        | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                           |
| 7                                                                                                                                                            | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                              |
| 8                                                                                                                                                            | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                              |
| 9                                                                                                                                                            | SS        |    |                                 |                                                                                                                                                              |
| 10                                                                                                                                                           | SS        |    |                                 | The SS waits 1 minute after step 8.<br>Set the cell type of cell A to the "Off cell".<br>(see note)                                                          |
| 11                                                                                                                                                           | →         |    | RRC CONNECTION REQUEST          | The SS waits 8 minutes after step 8.<br>Set the cell type of cell A to the "Serving cell".<br>(see note)                                                     |
| 12                                                                                                                                                           | ←         |    | RRC CONNECTION SETUP            | This message shall be sent by the UE between 11 minutes 45s and 12 minutes 15s after step 8.                                                                 |
| 13                                                                                                                                                           | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                              |
| 14                                                                                                                                                           | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                              |
| 15                                                                                                                                                           | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                                              |
| 16                                                                                                                                                           | ←         |    | RRC CONNECTION RELEASE          | "location-updating type": periodic.                                                                                                                          |
| 17                                                                                                                                                           | →         |    | RRC CONNECTION RELEASE COMPLETE | -After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                          |
| 18                                                                                                                                                           | SS        |    |                                 | The SS waits 3 minutes after step 17.<br>Set the cell type of cell A to the "Off cell".<br>(see note)                                                        |
| 19                                                                                                                                                           | SS        |    |                                 |                                                                                                                                                              |
| 20                                                                                                                                                           | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                              |
| 21                                                                                                                                                           | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                              |
| 22                                                                                                                                                           | →         |    | RRC CONNECTION SETUP COMPLETE   | The SS waits 14 minutes after step 17.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note) |
| 23                                                                                                                                                           | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                              |
| 24                                                                                                                                                           | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                                              |
| 25                                                                                                                                                           | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                              |
| 26                                                                                                                                                           | →         |    | RRC CONNECTION RELEASE COMPLETE | This message shall be sent by the UE before 17 minutes after step 17.                                                                                        |
| 27                                                                                                                                                           | UE        |    |                                 | "Location-updating type" = periodic.                                                                                                                         |
|                                                                                                                                                              |           |    |                                 | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                           |
|                                                                                                                                                              |           |    |                                 | The UE shall not initiate an RRC connection establishment. This is checked during 12 minutes.                                                                |
| NOTE: — The definitions for "Serving cell" and "Off cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                              |

## Specific message contents

None.

#### 9.4.6.5 ~~Test requirement~~

- ~~1) At step 20 the UE shall send an RRC CONNECTION REQUEST and at step 23 the UE shall attempt to perform a location update.~~
- ~~2) At step 11 the UE shall send an RRC CONNECTION REQUEST and at step 14 the UE shall attempt to perform a location update.~~
- ~~3) At step 27 the UE shall not initiate an RRC connection during 12minutes.~~

### 9.4.7 Location Updating / accept with deletion of Equivalent PLMN list

#### 9.4.7.1 ~~Definition~~

~~Test to verify that the UE removes its stored Equivalent PLMN list when no Equivalent PLMN list is included in the LOCATION UPDATING ACCEPT message from the network during a Location Update.~~

#### 9.4.7.2 ~~Conformance requirement~~

~~The network may also send a list of "equivalent PLMNs" in the LOCATION UPDATING ACCEPT message. Each entry of the list contains a PLMN code (MCC+MNC). The mobile station shall store the list, as provided by the network, except that any PLMN code that is already in the "forbidden PLMN list" shall be removed from the "equivalent PLMNs" list before it is stored by the mobile station. In addition the mobile station shall add to the stored list the PLMN code of the network that sent the list. All PLMNs in the stored list shall be regarded as equivalent to each other for PLMN selection, cell selection/re-selection and handover. The stored list in the mobile station shall be replaced on each occurrence of the LOCATION UPDATING ACCEPT message. If no list is contained in the message, then the stored list in the mobile station shall be deleted. The list shall be stored in the mobile station while switched off so that it can be used for PLMN selection after switch-on.~~

#### References

TS 24.008 4.4.4.6

#### 9.4.7.3 ~~Test purpose~~

~~The UE shall delete its stored Equivalent PLMN list if no Equivalent PLMN list is contained in the LOCATION UPDATING ACCEPT message received from the network during Location Update.~~

#### 9.4.7.4 ~~Method of test~~

~~Initial conditions:~~

~~Cell\_selection\_and\_reselection\_quality\_measure is CPICH\_RSCP (FDD).~~

| Cell   | CPICH_RSCP / RF signal level [dBm] (FDD) | P-CCPCH_RSCP / RF signal level [dBm] (TDD) | Test Channel | PLMN   |
|--------|------------------------------------------|--------------------------------------------|--------------|--------|
| Cell 1 | -72                                      | -61                                        | 1            | PLMN 1 |
| Cell 2 | -48                                      | -48                                        | 2            | PLMN 2 |

#### Test procedure

- ~~a) The SS activates cell 1 and monitors the cell for random access requests from the UE.~~
- ~~b) The UE is switched on.~~
- ~~c) The SS waits for random access requests from the UE~~
- ~~d) A LOCATION UPDATE ACCEPT message shall be sent on reception of a LOCATION UPDATE message from the UE on cell 1. The LOCATION UPDATE ACCEPT message shall include PLMN 2 in the equivalent PLMN list.~~

- e) The SS activates cell 2 and monitors the cell for random access requests from the UE.
- f) A LOCATION UPDATE ACCEPT message shall be sent on reception of a LOCATION UPDATE message from the UE on cell 2. The LOCATION UPDATE ACCEPT message shall include PLMN 1 in the equivalent PLMN list.
- g) Cell 2 is switched off.
- h) The SS waits for random access requests from the UE.
- i) A LOCATION UPDATE ACCEPT message shall be sent on reception of a LOCATION UPDATE message from the UE on cell 1. The LOCATION UPDATE ACCEPT message shall include no equivalent PLMN list.
- j) The SS activates cell 2 and monitors the cell for random access requests from the UE.
- k) The SS waits for random access requests from the UE.

#### 9.4.7.5 Test requirements

- 1) After step c) the UE will perform a Location Update in Cell 1 that will be accepted by the SS.
- 2) After step d) the displayed PLMN in the UE shall be PLMN 1.
- 3) After step e) the UE will perform a Location Update in Cell 2 that will be accepted by the SS.
- 4) After step f) the displayed PLMN in the UE shall be PLMN 2.
- 5) After step h) the UE will perform a Location Update in Cell 1 that will be accepted by the SS.
- 6) After step i) the displayed PLMN in the UE shall be PLMN 1.
- 7) After step k) there shall be no random access request from the UE on cell 2.

### 9.4.8 Location Updating after UE power off

#### 9.4.8.1 Definition

Test to verify that the UE stores the Equivalent PLMN list at UE power off and uses the stored Equivalent PLMN list after UE switch on.

#### 9.4.8.2 Conformance requirement

The network may also send a list of "equivalent PLMNs" in the LOCATION UPDATING ACCEPT message. Each entry of the list contains a PLMN code (MCC+MNC). The mobile station shall store the list, as provided by the network, except that any PLMN code that is already in the "forbidden PLMN list" shall be removed from the "equivalent PLMNs" list before it is stored by the mobile station. In addition the mobile station shall add to the stored list the PLMN code of the network that sent the list. All PLMNs in the stored list shall be regarded as equivalent to each other for PLMN selection, cell selection/re-selection and handover. The stored list in the mobile station shall be replaced on each occurrence of the LOCATION UPDATING ACCEPT message. If no list is contained in the message, then the stored list in the mobile station shall be deleted. The list shall be stored in the mobile station while switched off so that it can be used for PLMN selection after switch on.

#### References

TS 24.008 4.4.4.6

#### 9.4.8.3 Test purpose

The Equivalent PLMN list shall be stored in the mobile station while switched off so that it can be used for PLMN selection after switch on.

#### 9.4.8.4 ~~Method of test~~

##### ~~Initial conditions~~

~~The UE is in automatic PLMN selection mode.~~

~~The UE is equipped with a USIM containing default values except for those listed below.~~

| USIM field              | Priority        | PLMN   |
|-------------------------|-----------------|--------|
| EF <sub>LOGI</sub>      |                 | PLMN 1 |
| EF <sub>HPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN 1 |
| EF <sub>PLMNwAcT</sub>  | Empty           |        |
| EF <sub>OPLMNwAcT</sub> | 1 <sup>st</sup> | PLMN 3 |
|                         | 2 <sup>nd</sup> | PLMN 2 |

~~The SS simulates three cells as listed below.~~

| Cell   | Test Channel | PLMN   |
|--------|--------------|--------|
| Cell 1 | 1            | PLMN 1 |
| Cell 2 | 2            | PLMN 2 |
| Cell 3 | 3            | PLMN 3 |

##### ~~Test procedure~~

- ~~The SS activates cell 1 and monitors the cell for random access requests from the UE.~~
- ~~The UE is switched on.~~
- ~~The SS waits for random access requests from the UE.~~
- ~~A LOCATION UPDATE ACCEPT message shall be sent on reception of a LOCATION UPDATE message from the UE on cell 1. The LOCATION UPDATE ACCEPT message shall include PLMN 2 in the equivalent PLMN list.~~
- ~~The UE is switched off.~~
- ~~The SS deactivates cell 1 and activates cell 2 and cell 3.~~
- ~~The UE is switched on.~~
- ~~The SS waits for random access requests from the UE.~~

#### 9.4.8.5 ~~Test requirements~~

- ~~After step c) the UE will perform a Location Update in Cell 1 that will be accepted by the SS.~~
- ~~After step d) the displayed PLMN in the UE will be PLMN 1.~~
- ~~After step h) the UE shall perform a Location Update in Cell 2 that will be accepted by the SS.~~

### 9.4.9 ~~Location Updating/ Accept Storage of Equivalent PLMN list.~~

#### 9.4.9.1 ~~Definition~~

~~Test to verify that, before storing the ‘equivalent PLMN list’ received from the network during a Location Update, the UE removes any PLMN already included in the ‘forbidden PLMN list’. Consequently the UE shall not select a PLMN Equivalent to the registered PLMN if it is included in the ‘forbidden PLMN list’ in the USIM.~~



#### 9.4.9.2 ~~Conformance requirement~~

- ~~1. If a "PLMN not allowed" message is received by an MS in response to an LR request from a VPLMN, that VPLMN is added to a list of "forbidden PLMNs" in the SIM and thereafter that VPLMN will not be accessed by the MS when in automatic mode. A PLMN is removed from the "forbidden PLMNs" list if, after a subsequent manual selection of that PLMN, there is a successful LR. This list is retained when the MS is switched off or the SIM is removed. The HPLMN shall not be stored on the list of "forbidden PLMNs".~~
- ~~2. At switch on, or following recovery from lack of coverage, the MS selects the registered PLMN or equivalent PLMN (if it is available) using all access technologies that the MS is capable of and if necessary (in the case of recovery from lack of coverage, see subclause 4.5.2) attempts to perform a Location Registration.~~
- ~~3. Automatic Network Selection Mode Procedure~~
  - ~~— The MS selects and attempts registration on other PLMNs, if available and allowable, in the following order:~~
    - ~~i) HPLMN (if not previously selected);~~
    - ~~ii) each PLMN in the "User Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);~~
    - ~~iii) each PLMN in the "Operator Controlled PLMN Selector with Access Technology" data field in the SIM (in priority order);~~
    - ~~iv) other PLMN/access technology combinations with received high quality signal in random order;~~
    - ~~v) other PLMN/access technology combinations in order of decreasing signal quality.~~
- ~~4. Allowable PLMN: In the case of a MS operating in MS operation mode A or B, this is a PLMN which is not in the list of "forbidden PLMNs" in the MS.~~
- ~~5. The network may also send a list of "equivalent PLMNs" in the LOCATION UPDATING ACCEPT message. Each entry of the list contains a PLMN code (MCC+MNC). The mobile station shall store the list, as provided by the network, except that any PLMN code that is already in the "forbidden PLMN list" shall be removed from the "equivalent PLMNs" list before it is stored by the mobile station. In addition the mobile station shall add to the stored list the PLMN code of the network that sent the list. All PLMNs in the stored list shall be regarded as equivalent to each other for PLMN selection, cell selection/re-selection and handover. The stored list in the mobile station shall be replaced on each occurrence of the LOCATION UPDATING ACCEPT message. If no list is contained in the message, then the stored list in the mobile station shall be deleted. The list shall be stored in the mobile station while switched off so that it can be used for PLMN selection after switch on.~~

#### References

- ~~1. TS 23.122, 3.1~~
- ~~2. TS 23.122, 4.4.3.1~~
- ~~3. TS 23.122, 4.4.3.1.1~~
- ~~4. TS 23.122, 1.2~~
- ~~5. 24.008, 4.4.4.6~~

#### 9.4.9.3 ~~Test purpose~~

- ~~1. The UE shall not select a forbidden PLMN even though it is included in the equivalent PLMN list provided by the network (a forbidden PLMN shall not be stored in the mobile's list even if it is indicated by the network).~~

#### 9.4.9.4 ~~Method of test~~

##### Initial conditions

The UE is in automatic PLMN selection mode.

All Radio Access Technology USIM fields and cells are UTRAN.

| Cell   | Test Channel | PLMN   |
|--------|--------------|--------|
| Cell 1 | 1            | PLMN 1 |
| Cell 2 | 2            | PLMN 2 |

The UE is equipped with a USIM containing default values except for those listed below.

| USIM field              | Priority        | PLMN   |
|-------------------------|-----------------|--------|
| EF <sub>LOCI</sub>      |                 | PLMN 1 |
| EF <sub>HPLMNwACT</sub> | 1 <sup>st</sup> | PLMN 3 |
| EF <sub>PLMNwACT</sub>  | 1 <sup>st</sup> | PLMN 2 |
| EF <sub>FPLMN</sub>     | PLMN 2          |        |

## Test procedure

- The SS activates cells 1 and 2 and monitors the cells for random access requests from the UE
- The UE is switched on
- The SS waits for random access requests from the UE
- A LOCATION UPDATE ACCEPT message shall be sent on reception of a LOCATION UPDATE REQUEST message from the UE. The Location Update Accept message shall include PLMN 2 in the equivalent PLMN list.
- Cell 1 is switched off
- The SS waits for random access requests from the UE

### 9.4.9.5 Test requirements

After step c) the UE will perform a Location Update in Cell 1 that will be accepted by the SS.

After step d), The displayed PLMN in the UE shall be PLMN 1.

In step f), the UE shall inform that only limited service is possible.

## 9.5 MM connection

### 9.5.1 Introduction

[tbd]

### 9.5.2 MM connection / establishment in security mode

#### 9.5.2.1 Definition

#### 9.5.2.2 Conformance requirement

- The UE shall be able to correctly set up an MM connection in a Mobile Originating CM connection attempt and send a CM SERVICE REQUEST message with CKSN information element as stored in the USIM and Mobile Identity information element set to the TMSI.
- The UE shall be able to interpret security mode setting as acceptance of its CM service request i.e. send a CM message.

## References

TS 24.008 clause 4.5.1.1.

**9.5.2.3** ~~Test purpose~~

To verify that the UE can correctly set up an MM connection in an origination and interpret security mode setting as acceptance of its CM service request.

**9.5.2.4** ~~Method of test~~~~Initial conditions~~

- ~~— System Simulator:~~
  - ~~— 1 cell, default parameters.~~
- ~~— User Equipment:~~
  - ~~— the UE has a valid TMSI. It is "idle updated".~~

~~Related ICS/IXIT statements~~

~~None.~~

~~Test Procedure~~

A mobile-originating CM connection is initiated. After the UE has sent the CM SERVICE REQUEST message to the SS, an authentication procedure and a security mode setting procedure are performed. Then, the UE sends a CM message and the SS clears the call and releases the RRC CONNECTION.

~~Expected sequence~~

| Step | Direction |    | Message                         | Comments                                                                                           |
|------|-----------|----|---------------------------------|----------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                    |
| 1    | UE        |    |                                 | A MO CM connection is attempted.                                                                   |
| 2    | →         |    | RRC CONNECTION REQUEST          |                                                                                                    |
| 3    | ←         |    | RRC CONNECTION SETUP            |                                                                                                    |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                    |
| 5    | →         |    | CM SERVICE REQUEST              |                                                                                                    |
| 6    | ←         |    | AUTHENTICATION REQUEST          |                                                                                                    |
| 7    | →         |    | AUTHENTICATION RESPONSE         |                                                                                                    |
| 8    | ←         |    | SECURITY MODE COMMAND           |                                                                                                    |
| 9    | →         |    | SECURITY MODE COMPLETE          |                                                                                                    |
| A10  | →         |    | SETUP                           | "Cause" IE: "unassigned number".                                                                   |
| A11  | ←         |    | RELEASE COMPLETE                |                                                                                                    |
| B10  | →         |    | REGISTER                        |                                                                                                    |
| B11  | ←         |    | RELEASE COMPLETE                |                                                                                                    |
| C10  | →         |    | CP-DATA                         |                                                                                                    |
| C11  | ←         |    | CP-ACK                          |                                                                                                    |
| C12  | ←         |    | CP-DATA                         |                                                                                                    |
| C13  | →         |    | CP-ACK                          |                                                                                                    |
| 14   | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link. |
| 15   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                    |

~~Specific message contents~~

~~None.~~

**9.5.2.5** ~~Test requirement~~

At step 5 the UE shall send the CM SERVICE REQUEST message to the SS.

At step A10 or B10 or C10 the UE shall send a CM message and the SS shall release the RRC connection (step 14).

### 9.5.3 ~~MM connection / establishment in non-security mode~~

#### 9.5.3.1 ~~Definition~~

#### 9.5.3.2 ~~Conformance requirement~~

Upon reception of the CM SERVICE ACCEPT message, the UE shall send a CM message.

#### References

TS 24.008 clause 4.5.1.1.

#### 9.5.3.3 ~~Test purpose~~

To verify that the UE can correctly set up an MM connection in an originating CM connection establishment when security mode setting is not required.

#### 9.5.3.4 ~~Method of test~~

#### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE has a valid TMSI. It is "idle updated".

#### Related ICS/IXIT statements

None.

#### Test Procedure

A mobile-originating CM connection is attempted. The MM connection is established without invoking the security mode setting procedure.

Then, the UE sends a CM message and the SS releases the RRC CONNECTION.

#### Expected sequence

| Step | Direction |    | Message                                                                                                                    | Comments                                                                                           |
|------|-----------|----|----------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                                                                            |                                                                                                    |
| 1    | →         | UE | RRC CONNECTION REQUEST<br>RRC CONNECTION SETUP<br>RRC CONNECTION SETUP COMPLETE<br>CM SERVICE REQUEST<br>CM SERVICE ACCEPT | A MO CM connection is attempted.                                                                   |
| 2    | ←         |    |                                                                                                                            |                                                                                                    |
| 3    | →         |    |                                                                                                                            |                                                                                                    |
| 4    | ←         |    |                                                                                                                            |                                                                                                    |
| 5    | →         |    |                                                                                                                            |                                                                                                    |
| 6    | ←         |    |                                                                                                                            |                                                                                                    |
| A7   | →         |    | SETUP                                                                                                                      |                                                                                                    |
| B7   | →         |    | REGISTER                                                                                                                   |                                                                                                    |
| C7   | →         |    | CP-DATA                                                                                                                    |                                                                                                    |
| C8   | ←         |    | CP-ACK                                                                                                                     |                                                                                                    |
| C9   | ←         |    | CP-DATA                                                                                                                    |                                                                                                    |
| C10  | →         |    | CP-ACK                                                                                                                     |                                                                                                    |
| 11   | ←         |    | RRC CONNECTION RELEASE                                                                                                     | After the sending of this message, the SS waits for the disconnection of the main signalling link. |
| 12   | →         |    | RRC CONNECTION RELEASE COMPLETE                                                                                            |                                                                                                    |

~~Specific message contents~~

~~None.~~

#### ~~9.5.3.5 Test requirement~~

~~At step 5 the UE shall send the CM SERVICE REQUEST message to the SS.~~

~~At step A7 or B7 or C7 the UE shall send a CM message and the SS shall release the RRC connection (step 12).~~

### ~~9.5.4 MM connection / establishment rejected~~

#### ~~9.5.4.1 Definition~~

#### ~~9.5.4.2 Conformance requirement~~

~~Upon reception of a CM SERVICE REJECT message, the UE shall not send any layer 3 message, start timer T3240 and enter the "wait for network command" state.~~

#### ~~References~~

~~TS 24.008 clause 4.5.1.1.~~

#### ~~9.5.4.3 Test purpose~~

~~To verify that the UE does not send a layer 3 message when the service request is rejected by the SS.~~

#### ~~9.5.4.4 Method of test~~

#### ~~Initial conditions~~

- ~~— System Simulator:~~
  - ~~— 1 cell, default parameters.~~
- ~~— User Equipment:~~
  - ~~— the UE has a valid TMSI. It is "idle updated".~~

#### ~~Related ICS/IXIT statements~~

~~None.~~

#### ~~Test Procedure~~

~~A mobile originating CM connection is attempted. After the UE has sent the CM SERVICE REQUEST message to the SS, the SS responds with a CM SERVICE REJECT message with reject cause "requested service option not subscribed". It is checked that the UE does not send a layer 3 message.~~

## Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                                    |
|------|-----------|----|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                             |
| 1    | →         | UE |                                 | A MO-CM connection is attempted                                                                                                                                                                                                             |
| 2    | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                             |
| 3    | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                             |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                             |
| 5    | →         |    | CM SERVICE REQUEST              | "Reject cause" IE: "requested service option not subscribed".<br>The UE shall not send a layer 3 message. This is checked during 5 s.<br>After the sending of this message, the SS waits for the disconnection of the main signalling link. |
| 6    | ←         |    | CM SERVICE REJECT               |                                                                                                                                                                                                                                             |
| 7    |           | SS |                                 |                                                                                                                                                                                                                                             |
| 8    | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                             |
| 9    | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                             |

## Specific message contents

None.

## 9.5.4.5 Test requirement

The UE shall attempt MO-CM connection (step 1).

At step 7 the UE shall not send a layer 3 message and at step 9 the UE shall send an RRC CONNECTION RELEASE COMPLETE message.

## 9.5.5 MM connection / establishment rejected cause 4

## 9.5.5.1 Definition

## 9.5.5.2 Conformance requirement

- 1) The UE shall be able to correctly set up an MM connection in a Mobile Originating CM connection attempt and send a CM SERVICE REQUEST message with CKSN information element as stored in the USIM and Mobile Identity information element set to the TMSI.
- 2) The UE, when receiving a CM SERVICE REJECT message with reject cause "IMSI unknown in VLR" shall wait for the network to release the RRC connection.
- 3) The UE shall then be able to perform a location updating procedure.

## References

TS 24.008 clause 4.5.1.1.

## 9.5.5.3 Test purpose

To verify that the UE can correctly accept a CM SERVICE REJECT message with reject cause "IMSI unknown in VLR".

## 9.5.5.4 Method of test

## Initial conditions

— System Simulator:

— 1 cell, default parameters.

—User Equipment:

—the UE has a valid TMSI. It is "idle updated".

#### Related ICS/IXIT statements

None.

#### Test Procedure

A mobile-originating CM connection is attempted. After the UE has sent the CM SERVICE REQUEST message to the SS, the SS responds with a CM SERVICE REJECT message with reject cause "IMSI unknown in VLR". On receipt of this message, the UE shall delete any TMSI, LAI, cipher key and cipher key sequence number. The RRC CONNECTION is released. It is checked that the UE performs a normal location updating procedure.

#### Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                           |
|------|-----------|----|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                    |
| 1    |           | UE |                                 | A MO-CM connection is attempted.                                                                                                                                                                   |
| 2    | →         |    | RRC-CONNECTION-REQUEST          |                                                                                                                                                                                                    |
| 3    | ←         |    | RRC-CONNECTION-SETUP            |                                                                                                                                                                                                    |
| 4    | →         |    | RRC-CONNECTION-SETUP COMPLETE   |                                                                                                                                                                                                    |
| 5    | →         |    | CM-SERVICE-REQUEST              | CKSN = initial value, Mobile identity = TMSI.<br>"Reject cause" = "IMSI unknown in VLR".<br>After the sending of this message, the SS waits for the disconnection of the main signalling link.     |
| 6    | ←         |    | CM-SERVICE-REJECT               |                                                                                                                                                                                                    |
| 7    | ←         |    | RRC-CONNECTION-RELEASE          |                                                                                                                                                                                                    |
| 8    | →         |    | RRC-CONNECTION-RELEASE COMPLETE | "Establishment cause": Registration.                                                                                                                                                               |
| 9    | →         |    | RRC-CONNECTION-REQUEST          |                                                                                                                                                                                                    |
| 10   | ←         |    | RRC-CONNECTION-SETUP            |                                                                                                                                                                                                    |
| 11   | →         |    | RRC-CONNECTION-SETUP COMPLETE   |                                                                                                                                                                                                    |
| 12   | →         |    | LOCATION-UPDATING REQUEST       | "Ciphering key sequence number" = "No key is available". "Mobile identity" = IMSI. "Location area identification" = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE). |
| 13   | ←         |    | AUTHENTICATION-REQUEST          |                                                                                                                                                                                                    |
| 14   | →         |    | AUTHENTICATION-RESPONSE         |                                                                                                                                                                                                    |
| 14a  | ←         |    | SECURITY-MODE-COMMAND           |                                                                                                                                                                                                    |
| 14b  | →         |    | SECURITY-MODE-COMplete          | "Mobile identity" = new TMSI.                                                                                                                                                                      |
| 15   | ←         |    | LOCATION-UPDATING-ACCEPT        |                                                                                                                                                                                                    |
| 16   | →         |    | TMSI-REALLOCATION COMPLETE      |                                                                                                                                                                                                    |
| 17   | ←         |    | RRC-CONNECTION-RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                 |
| 18   | →         |    | RRC-CONNECTION-RELEASE COMPLETE |                                                                                                                                                                                                    |

#### Specific message contents

None.

#### 9.5.5.5 ————— Test requirement

- 1) The UE shall attempt MO-CM connection (at step 1) and at step 5 the UE shall send a CM SERVICE REQUEST message with CKSN information element as stored in the USIM and Mobile Identity information element set to the TMSI.
- 2) At step 6 the SS should send a CM SERVICE REJECT message with reject cause "IMSI unknown in VLR", and at step 8 the UE shall send an RRC CONNECTION RELEASE message.

- 3) At step 12 the UE send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type set to "deleted LAI".

## 9.5.6 MM connection / expiry T3230

### 9.5.6.1 Definition

### 9.5.6.2 Conformance requirement

At T3230 expiry (i.e. no response is given but an RRC connection is available) the MM connection establishment shall be aborted.

### References

TS 24.008 clauses 4.5.1.2 and 11.2.

### 9.5.6.3 Test purpose

To verify that at T3230 expiry, the UE aborts the MM connection establishment.

### 9.5.6.4 Method of test

#### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE has a valid TMSI. It is "idle-updated".

#### Related ICS/IXIT statements

None.

#### Test Procedure

A mobile-originating CM connection is attempted. After the UE has sent the CM SERVICE REQUEST message to the SS, the SS waits for expiry of timer T3230. It is checked that the UE send a MM STATUS message and waits for the release of the RRC connection.

#### Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                      |
|------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                               |
| 1    |           | UE |                                 | A MO-CM connection is attempted.                                                                                                                                              |
| 2    | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                               |
| 3    | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                               |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                               |
| 5    | →         |    | CM SERVICE REQUEST              | The SS waits for expiry of timer T3230.                                                                                                                                       |
| 6    |           | SS |                                 |                                                                                                                                                                               |
| 7    | ←         |    | CM SERVICE ACCEPT               | "Reject cause" IE is "message type not compatible with protocol state".<br>After the sending of this message, the SS waits for the disconnection of the main signalling link. |
| 8    | →         |    | MM STATUS                       |                                                                                                                                                                               |
| 9    | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                               |
| 10   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                               |



### Specific message contents

None.

#### 9.5.6.5 Test requirement

The UE shall attempt MO-CM connection (step 1).

At step 8 the UE shall send a MM-STATUS message.

### 9.5.7 MM connection / abortion by the network

#### 9.5.7.1 MM connection / abortion by the network / cause #6

##### 9.5.7.1.1 Definition

##### 9.5.7.1.2 Conformance requirement

- 1) Upon reception of an ABORT message, the UE shall release any ongoing MM connection and enter the "wait for network command" state.
- 2) If the cause in the ABORT message was cause #6, the UE shall:
  - 2.1 not perform normal location updating;
  - 2.2 not perform periodic location updating;
  - 2.3 not respond to paging with TMSI;
  - 2.4 reject any request for Mobile-Originating call establishment except Emergency call;
  - 2.5 not perform IMSI detach if deactivated.
- 3) After reception of an ABORT message with cause #6, the UE, if it supports speech, shall accept a request for an emergency call by sending a RRC-CONNECTION Request message with the establishment cause set to "emergency call".
- 4) After reception of an ABORT message with cause #6, the UE shall delete the stored LAI, CKSN and TMSI.

### Reference(s)

TS 24.008 clause 4.3.5.

##### 9.5.7.1.3 Test purpose

To check that upon reception of an ABORT message with cause #6 during call establishment:

- the UE does not send any layer 3 message;
- after reception of an ABORT message and after having been deactivated and reactivated, the UE performs location updating using its IMSI as mobile identity and indicates deleted LAI and CKSN;
- the UE does not perform location updating, does not answer to paging with TMSI, rejects any request for mobile originating call except emergency call, does not perform IMSI detach;
- the UE accepts a request for emergency call.

##### 9.5.7.1.4 Method of test

### Initial Conditions

- System Simulator:

- 2 cells, default parameters.
- User Equipment:
  - the UE has a valid TMSI, CKSN and CK, IK. It is "idle-updated" on cell B.

#### Related ICS/IXIT Statement(s)

USIM removal possible while UE is powered Yes/No.

Switch off on button Yes/No.

Support of speech Yes/No.

#### Test procedure

A mobile-originating CM connection is attempted. Upon reception of the AUTHENTICATION RESPONSE message, the SS sends an ABORT message with cause #6. The SS waits for 5 s. The UE shall not send any layer 3 message. The SS releases the RRC connection.

The SS checks that the UE has entered the state MM IDLE substate NO IMSI, i.e. does not perform normal location updating, does not perform periodic updating, does not respond to paging, rejects any requests from CM entities except emergency calls and does not perform IMSI detach if deactivated.

#### Expected Sequence

| Step                                                             | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                                                                                 |
|------------------------------------------------------------------|-----------|----|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                  | UE        | SS |                                 |                                                                                                                                                                                                                                                                                                                                          |
| The following messages are sent and shall be received on cell B  |           |    |                                 |                                                                                                                                                                                                                                                                                                                                          |
| 1                                                                | UE        |    |                                 | A mobile-originating CM connection is attempted.<br><br>"reject cause" = #6.<br>The SS waits for 5 s.<br>The UE shall not send any layer 3 message during that time.<br>After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                               |
| 2                                                                | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                          |
| 3                                                                | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                          |
| 4                                                                | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                          |
| 5                                                                | →         |    | CM SERVICE REQUEST              |                                                                                                                                                                                                                                                                                                                                          |
| 6                                                                | ←         |    | AUTHENTICATION REQUEST          |                                                                                                                                                                                                                                                                                                                                          |
| 7                                                                | →         |    | AUTHENTICATION RESPONSE         |                                                                                                                                                                                                                                                                                                                                          |
| 8                                                                | ←         |    | ABORT                           |                                                                                                                                                                                                                                                                                                                                          |
| 9                                                                | SS        |    |                                 |                                                                                                                                                                                                                                                                                                                                          |
| 10                                                               | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                          |
| 11                                                               | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                          |
| 12                                                               | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                                          |
| The following messages are sent and shall be received on cell A. |           |    |                                 |                                                                                                                                                                                                                                                                                                                                          |
| 13                                                               | SS        |    |                                 | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "non-suitable cell".<br>(see note)<br>The UE performs cell reselection according to procedure as specified in (this however is not checked until step 27).<br>The UE shall not initiate an RRC connection establishment on cell A or on cell B. |
| 14                                                               | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                          |
| 15                                                               | SS        |    |                                 | The SS waits at least 7 minutes for a possible periodic updating.<br>The UE shall not initiate an RRC connection establishment on cell A or on cell B.                                                                                                                                                                                   |
| 16                                                               | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                          |
| 17                                                               | ←         |    | PAGING TYPE 1                   | "UE identity" IE contains TMSI.<br>-Paging Cause: Terminating Conversational Call.<br>The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is verified during 3 s.                                                                                                                                     |
| 18                                                               | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                          |
| 19                                                               | UE        |    |                                 | A MO CM connection is attempted.                                                                                                                                                                                                                                                                                                         |

| Step                                                                                                                                                                  | Direction |    | Message                         | Comments                                                                                                                                                                                                     |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                       | UE        | SS |                                 |                                                                                                                                                                                                              |
| 20                                                                                                                                                                    | UE        |    |                                 | The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 3 s.                                                                                                |
| 21                                                                                                                                                                    | UE        |    |                                 | If the UE supports speech (see ICS), an emergency call is attempted.                                                                                                                                         |
| 22                                                                                                                                                                    | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Emergency call.                                                                                                                                                                       |
| 23                                                                                                                                                                    | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                              |
| 24                                                                                                                                                                    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                              |
| 25                                                                                                                                                                    | →         |    | CM SERVICE REQUEST              |                                                                                                                                                                                                              |
| 26                                                                                                                                                                    | ←         |    | CM SERVICE ACCEPT               | "CM service type": Emergency call establishment.                                                                                                                                                             |
| 27                                                                                                                                                                    | →         |    | EMERGENCY SETUP                 | "Cause" = unassigned number.<br>After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                           |
| 28                                                                                                                                                                    | ←         |    | RELEASE COMPLETE                |                                                                                                                                                                                                              |
| 29                                                                                                                                                                    | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                              |
| 30                                                                                                                                                                    | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                              |
| 31                                                                                                                                                                    | UE        |    |                                 | If possible (see ICS) USIM detachment is performed.                                                                                                                                                          |
| 32                                                                                                                                                                    | UE        |    |                                 | Otherwise if possible (see ICS) switch off is performed.<br>Otherwise the power is removed.<br>The UE shall not initiate an RRC connection establishment on cell A or on cell B. This is checked during 3 s. |
| 33                                                                                                                                                                    | UE        |    |                                 | Depending on what has been performed in step 31 the UE is brought back to operation.                                                                                                                         |
| 34                                                                                                                                                                    | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.                                                                                                                                                                         |
| 35                                                                                                                                                                    | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                              |
| 36                                                                                                                                                                    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                              |
| 37                                                                                                                                                                    | →         |    | LOCATION UPDATING REQUEST       |                                                                                                                                                                                                              |
| 38                                                                                                                                                                    | ←         |    | AUTHENTICATION REQUEST          | "location updating type" = normal, "CKSN" = no key available, "Mobile Identity" = IMSI, "LAI" = deleted LAI (the MCC and MNC hold the previous values, the LAC is coded FFFE).                               |
| 39                                                                                                                                                                    | →         |    | AUTHENTICATION RESPONSE         | "CKSN" = CKSN1.                                                                                                                                                                                              |
| 40                                                                                                                                                                    | ←         |    | LOCATION UPDATING ACCEPT        | "Mobile Identity" = TMSI.                                                                                                                                                                                    |
| 41                                                                                                                                                                    | →         |    | TMSI REALLOCATION COMPLETE      |                                                                                                                                                                                                              |
| 42                                                                                                                                                                    | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                           |
| 43                                                                                                                                                                    | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                              |
| NOTE: — The definitions for “Serving cell” and “non-suitable cell” are specified in TS 34.108 clause 6.1 “Reference Radio Conditions for signalling test cases only”. |           |    |                                 |                                                                                                                                                                                                              |

### Specific message contents

None.

#### 9.5.7.1.5 — Test requirement

- 1) At step 10 the UE shall not send any layer 3 message and at step 12 the UE shall send an RRC CONNECTION RELEASE COMPLETE message.
- 2)
  - 2.1 At step 14 the UE shall not initiate an RRC connection establishment (not perform normal location updating).
  - 2.2 At step 16 the UE shall not initiate an RRC connection establishment (not perform periodic location updating).
  - 2.3 At step 18 the UE shall not initiate an RRC connection establishment (not respond to paging with TMSI).

~~2.4 At step 20 the UE shall not initiate an RRC connection establishment (reject any request for Mobile Originating call establishment).~~

~~2.5 At step 32 the UE shall not initiate an RRC connection establishment. (not perform IMSI detach).~~

~~3) At step 22 the UE shall send an RRC CONNECTION REQUEST message with the establishment cause set to "emergency call".~~

~~4) At step 37 the UE send a LOCATION UPDATING REQUEST message with the Mobile Identity IE set to its IMSI, CKSN IE set to "no key is available" and the Location Updating type set to "deleted LAI".~~

### ~~9.5.7.2 MM connection / abortion by the network / cause not equal to #6~~

#### ~~9.5.7.2.1 Definition~~

#### ~~9.5.7.2.2 Conformance requirement~~

~~Upon reception of an ABORT message, the UE shall release any ongoing MM connection and enter the "wait for network command" state.~~

#### ~~Reference(s)~~

~~TS 24.008 clause 4.3.5.~~

#### ~~9.5.7.2.3 Test purpose~~

~~To check that when multiple MM connections are established, the UE releases all MM connections upon reception of an ABORT message, in the case when the two MM connections are established for a mobile terminating call and a non call related supplementary service operation.~~

#### ~~9.5.7.2.4 Method of test~~

#### ~~Initial Conditions~~

~~— System Simulator:~~

~~— 1 cell, default parameters.~~

~~— User Equipment:~~

~~— the UE is in state U10 of a mobile terminating call.~~

#### ~~Related ICS/IXIT Statement(s)~~

~~The UE supports a non-call related supplementary service operation during an active call Yes/No.~~

#### ~~Test procedure~~

~~A non-call related supplementary service operation is attempted at the UE. Upon reception of the REGISTER message, the SS sends an ABORT message with cause #17. The SS sends a DISCONNECT using the TI of the mobile terminating call. Upon reception of the RELEASE message, the SS send a RELEASE COMPLETE message with the PD and TI of the DISCONNECT message and with cause #81. The SS releases the RRC connection.~~

## Expected Sequence

This procedure is performed if the UE supports non-call-related supplementary service operation.

| Step | Direction |    | Message                         | Comments                                                                                                                                                       |
|------|-----------|----|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                |
| 1    |           | UE |                                 | A non-call-related supplementary service operation is attempted at the UE.<br>"Establishment cause": Originating Background Call.                              |
| 2    | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                |
| 3    | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                |
| 5    | →         |    | CM SERVICE REQUEST              | "reject cause" = #17.<br>with the TI of the mobile terminating call.                                                                                           |
| 6    | ←         |    | CM SERVICE ACCEPT               |                                                                                                                                                                |
| 7    | →         |    | REGISTER                        |                                                                                                                                                                |
| 8    | ←         |    | ABORT                           |                                                                                                                                                                |
| 9    | ←         |    | DISCONNECT                      | "cause" = #81. Same PD and TI as the DISCONNECT message.<br>After the sending of this message, the SS waits for the disconnection of the main signalling link. |
| 9a   | →         |    | RELEASE                         |                                                                                                                                                                |
| 10   | ←         |    | RELEASE COMPLETE                |                                                                                                                                                                |
| 11   | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                |
| 12   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                |

## Specific message contents

None.

### 9.5.7.2.5 Test requirement

At step 10 the SS shall send a RELEASE COMPLETE message and at step 12 the UE shall send an RRC CONNECTION RELEASE COMPLETE message.

## 9.5.8 MM connection / follow-on request pending

### 9.5.8.1 MM connection / follow-on request pending / test 1

#### 9.5.8.1.1 Definition

#### 9.5.8.1.2 Conformance requirement

The UE shall not attempt to establish a new MM connection after location updating on the same RRC connection if not allowed by the network.

## Reference(s)

TS 24.008 clause 4.4.4.6.

#### 9.5.8.1.3 Test purpose

To check that when the network does not include the follow-on-proceed IE in a LOCATION UPDATING ACCEPT message, a UE that has a CM application request pending does not attempt to establish a new MM connection on that RRC connection.

#### 9.5.8.1.4 Method of test

##### Initial Conditions

— System Simulator:

— 1 cell, ATT flag is set to "MSs in the cell shall apply IMSI attach and detach procedure".

— User Equipment:

— the UE has a valid TMSI and is deactivated.

##### Related ICS/IXIT Statement(s)

None.

##### Test procedure

The UE is activated and a CM connection is attempted during the location updating procedure. The SS does not include the follow on proceed information element in the LOCATION UPDATING ACCEPT message. The SS waits for at least 8 s. The UE shall not send any layer 3 message for 8 s.

##### Expected Sequence

| Step | Direction |    | Message                         | Comments                                                                                                             |
|------|-----------|----|---------------------------------|----------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                      |
| 1    |           | UE |                                 | The UE is activated.                                                                                                 |
| 2    | →         |    | RRC CONNECTION REQUEST          | "Establishment cause": Registration.                                                                                 |
| 3    | ←         |    | RRC CONNECTION SETUP            |                                                                                                                      |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                      |
| 5    | →         |    | LOCATION UPDATING REQUEST       | location-updating type = IMSI attach.<br>Then the SS waits for 15 s. During this delay a CM connection is attempted. |
| 6    | ←         |    | LOCATION UPDATING ACCEPT        | follow on proceed IE not included.                                                                                   |
| 7    |           | SS |                                 | The SS wait for at least 8 s.                                                                                        |
| 8    |           | UE |                                 | The UE shall not send any layer 3 message for 8 s after reception of the LOCATION UPDATING ACCEPT message.           |
| 9    | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                   |
| 10   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                      |

##### Specific message contents

None.

#### 9.5.8.1.5 Test requirement

After step 8 the UE shall not send any layer 3 messages.

### 9.5.8.2 MM connection / follow-on request pending / test 2

#### 9.5.8.2.1 Definition

#### 9.5.8.2.2 Conformance requirement

A UE supporting the follow-on request procedure and having a CM connection request pending shall correctly establish an MM connection following a location update when allowed by the network.

## Reference(s)

TS 24.008 clause 4.4.4.6.

### 9.5.8.2.3 ~~Test purpose~~

To check that when the network includes the follow on proceed IE in a LOCATION-UPDATING-ACCEPT message, a UE that supports the follow on request procedure and that has a CM application request pending establishes successfully a new MM connection on that RRC connection.

### 9.5.8.2.4 ~~Method of test~~

#### Initial Conditions

- ~~— System Simulator:~~
  - ~~— 1 cell, ATT flag is set to "MSs in the cell shall apply IMSI attach and detach procedure".~~
- ~~— User Equipment:~~
  - ~~— the UE has a valid TMSI and is deactivated.~~

#### Related ICS/IXIT Statement(s)

UE supports the follow on request procedure Yes/No.

#### Test procedure

The UE is activated and a CM connection is attempted during the location updating procedure. The SS includes the follow on proceed information element in the LOCATION-UPDATING-ACCEPT message. The SS waits for at least 8 s.

If the UE supports the follow on request procedure:

- ~~— the UE shall send a CM SERVICE REQUEST. Upon reception of that message, the SS sends a CM SERVICE ACCEPT message. The UE shall send an initial CM message. Upon reception of that message, the SS releases the RRC connection.~~

If the UE does not support the follow on request procedure:

- ~~— the UE shall not send any layer 3 message for 8 s.~~

## Expected Sequence

| Step | Direction |    | Message                                                                            | Comments                                                                                                                                                  |
|------|-----------|----|------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                                    |                                                                                                                                                           |
| 1    | →         | UE | RRC-CONNECTION-REQUEST<br>RRC-CONNECTION-SETUP<br>RRC-CONNECTION-SETUP<br>COMPLETE | The UE is activated.<br>"Establishment cause": Registration.                                                                                              |
| 2    | ←         |    |                                                                                    |                                                                                                                                                           |
| 3    | →         |    |                                                                                    |                                                                                                                                                           |
| 4    | →         |    |                                                                                    |                                                                                                                                                           |
| 5    | →         |    | LOCATION-UPDATING<br>REQUEST                                                       | Location-updating type = IMSI attach.<br>Then the SS waits for 15 s. During this delay a CM<br>connection is attempted.<br>follow on proceed IE included. |
| 6    | ←         |    | LOCATION-UPDATING-ACCEPT                                                           |                                                                                                                                                           |
|      |           |    |                                                                                    | If the UE supports the follow-on request procedure (see<br>ICS) steps A7 to A9 are performed, otherwise steps B7<br>to B8 are performed.                  |
| A7   | →         |    | CM-SERVICE-REQUEST                                                                 |                                                                                                                                                           |
| A8   | ←         |    | CM-SERVICE-ACCEPT                                                                  |                                                                                                                                                           |
| A9   | →         |    | An initial CM message                                                              |                                                                                                                                                           |
| B7   |           | SS |                                                                                    | The SS wait for at least 8 s.<br>The UE shall not send any layer 3 message for 8 s after<br>reception of the LOCATION-UPDATING-ACCEPT<br>message.         |
| B8   |           | UE |                                                                                    |                                                                                                                                                           |
| 10   | ←         |    | RRC-CONNECTION-RELEASE                                                             | After the sending of this message, the SS waits for the<br>disconnection of the main signalling link.                                                     |
| 11   | →         |    | RRC-CONNECTION-RELEASE<br>COMPLETE                                                 |                                                                                                                                                           |

## Specific message contents

None.

## 9.5.8.2.5 — Test requirement

After step 6:

The UE shall send a CM-SERVICE-REQUEST if the UE supports the follow-on request procedure.

The UE shall not send any layer 3 message if the UE does not support the follow-on request procedure.

## 9.5.8.3 — MM connection / follow-on request pending / test 3

## 9.5.8.3.1 — Definition

## 9.5.8.3.2 — Conformance requirement

- 1) The UE shall not set the follow-on proceed IE in a LOCATION-UPDATING-REQUEST message if no MM connection request is pending.
- 2) When the network includes the follow-on proceed IE in a LOCATION-UPDATING-ACCEPT message, a UE that has no CM application request pending shall not attempt to establish a new MM connection on that RRC connection.
- 3) The UE shall correctly handle a CM connection established by the network on the RRC connection that was used for the location updating procedure.

## Reference(s)

TS 24.008 clause 4.4.4.6.



### 9.5.8.3.3 ————— Test purpose

- 1) To check that a UE that has no CM application request pending sets the follow-on-proceed IE to No follow-on request pending in a LOCATION UPDATING REQUEST message.
- 2) To check that when the network includes the follow-on-proceed IE in a LOCATION UPDATING ACCEPT message, a UE that has no CM application request pending does not attempt to establish a new MM connection on that RRC connection.
- 3) To check that the UE accepts establishment by the network of a new MM connection on the existing RRC connection.

### 9.5.8.3.4 ————— Method of test

#### Initial Conditions

— System Simulator:

— 1 cell, ATT flag is set to "MSs in the cell shall apply IMSI attach and detach procedure".

— User Equipment:

— the UE has a valid TMSI and is deactivated.

#### Related ICS/IXIT Statement(s)

Supported services on TCH.

#### Test procedure

The UE is activated. The UE performs location updating. The UE shall set the follow-on-proceed IE to No follow-on request pending in the LOCATION UPDATING REQUEST message. The SS includes the follow-on-proceed IE in the LOCATION UPDATING ACCEPT message. The SS waits for 5 s. The UE shall not send any layer 3 message for 5 s. The SS sends a SETUP message to the UE requesting a basic service supported by the UE. The UE shall send either a CALL CONFIRMED message if it supports a service on TCH or a RELEASE COMPLETE with cause #88.

#### Expected Sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                               |
|------|-----------|----|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                                                        |
| 1    |           | UE |                                 | The UE is activated.<br>"Establishment cause": Registration.                                                                                                                                                                                                           |
| 2    | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                        |
| 3    | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                        |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                        |
| 5    | →         |    | LOCATION UPDATING REQUEST       | "Location updating type" = IMSI attach. The FOR bit is set to No follow-on request pending.<br>follow-on-proceed IE is included.<br>The SS wait for 5 s.<br>The UE shall not send any layer 3 message for 5 s after reception of the LOCATION UPDATING ACCEPT message. |
| 6    | ←         |    | LOCATION UPDATING ACCEPT        |                                                                                                                                                                                                                                                                        |
| 7    |           | SS |                                 |                                                                                                                                                                                                                                                                        |
| 8    |           | UE |                                 |                                                                                                                                                                                                                                                                        |
| 9    | ←         |    | SETUP                           |                                                                                                                                                                                                                                                                        |
| A10  | →         |    | CALL CONFIRMED                  | If the UE supports a basic service on TCH.                                                                                                                                                                                                                             |
| B10  | →         |    | RELEASE COMPLETE                | If the UE does not support any basic service on TCH.<br>cause #88.                                                                                                                                                                                                     |
| 11   | ←         |    | RRC CONNECTION RELEASE          | After the sending of this message, the SS waits for the disconnection of the main signalling link.                                                                                                                                                                     |
| 12   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                        |

~~Specific message contents~~

~~None.~~

~~9.5.8.3.5 Test requirement~~

~~At step 8 the UE shall not send any layer 3 message.~~

~~After step 9:~~

~~The UE shall send CALL CONFIRMED message if the UE supports a basic service on TCH.~~

~~The UE shall send RELEASE COMPLETE message if the UE does not support a basic service on TCH.~~

## ~~10 Circuit Switched Call Control (CC)~~

### ~~10.1 Circuit switched Call Control (CC) state machine verification~~

#### ~~10.1.1 General on CC state machine verification~~

The principle of checking the call control functions consists in the validation of each call control identified state.

State U0 as an initial state is not verified in the tests of 10.1.2 (establishment of an outgoing call).

State U0.1 is never verified.

The steps to be followed within each performed test are:

- bring the UE into the required state;
- trigger the tested event;
- check the UE response and new state.

In clauses 10.1.2 and 10.1.3 different tables are defined to bring the UE into the required initial state. The exact table to be chosen is specified individually in clause "Initial conditions" of "Method of test" for each test case.

For each test, unless otherwise specified, a circuit-switched basic service among those supported by the UE but excluding the emergency call teleservice shall be chosen arbitrarily, and the test shall be performed according to that basic service. If the only circuit-switched basic service supported by the mobile is emergency call, then the incoming call tests shall not be performed and the other call control tests shall be performed with the EMERGENCY SETUP message replacing the SETUP message.

The initial states are to be checked through STATUS ENQUIRY messages sent by the SS, when feasible. This is not explicitly stated in the tables of expected sequences of signalling messages. The checking of final states are explicitly included into the expected sequences of signalling messages.

The following postamble may be used by the SS to bring UE back to idle mode in those test cases, in which it is not already included into expected sequence of signalling messages:

**Table 10.1.1/1: A postamble to bring the UE back to idle mode.**

| Step            | Direction        |    | Message                                                   | Comments                                      |
|-----------------|------------------|----|-----------------------------------------------------------|-----------------------------------------------|
|                 | UE               | SS |                                                           |                                               |
| N<br>n+1<br>n+2 | <--<br>--><br>UE |    | RRC CONNECTION RELEASE<br>RRC CONNECTION RELEASE COMPLETE | the UE shall release the main signalling link |

The postamble has not been included into all of the tests in order to leave an option to concatenate the procedures in the future by using a final state of a test case as an initial state to another one.

For the special case of U0, the state is checked by sending STATUS ENQUIRY message with all possible values of transaction identifier (seven values) as U0 is the only state in which for every TI the UE will answer with release complete with cause #81. If U0 is to be verified when no RRC connection exists, first a mobile terminating radio connection must be established.

The UE responses are either call management messages received by the SS or lower layers functions activated within the UE or MMI actions (e.g. the buzzing of an alerting tone).

A time-out within the UE is triggered by the SS when it does not answer back an UE expected response.

The test sequences may be split in 3 main groups:

- establishment and release of an outgoing call;
- establishment and release of an incoming call;
- in-call functions.

Some test cases use Basic Generic Procedures, "Mobile terminated establishment of Radio Resource Connection" and "Radio Bearer Setup Procedure" defined in TS34.108 clause 7.

General tolerance value on protocol timers defined in TS34.108 is used in some test cases if no specific tolerance on timer is defined in a test case.

#### Remark on verification of transient states

Some call control states of the user equipment may be transient, depending on implementation, configuration of the UE and previous messages.

If a test starts in a transient state, then the test is executed without verification of the starting state.

### 10.1.2 Establishment of an outgoing call

#### Initial conditions

As a minimum requirement the UE is updated and has been given a TMSI, a ciphering key and cipher key sequence number, and the layer 2, RRC and MM functionalities have been verified.

There are as many CM initial conditions as states to be checked.

The tables below describe message exchanges which bring the UE in the requested initial states.

A state may be taken as initial only when all the states which lead to this initial states have been validated. The order followed in the test procedure will be U0, U0.1, U1, U3, U4, U10, U12, U19, U11 as seen in the table underneath.

The UE is brought again in the initial state starting with U0 at each new test performed.

**Table 10.1.2/1: Establishment of an outgoing call, procedure 1 (late assignment)**

| Step                                                                                                                                   | Direction |    | Message                       | Comments                   |
|----------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-------------------------------|----------------------------|
|                                                                                                                                        | UE        | SS |                               |                            |
| 1                                                                                                                                      | →         |    | RRC CONNECTION REQUEST        | Initiate outgoing call     |
| 2                                                                                                                                      | ←         |    | RRC CONNECTION SETUP          |                            |
| 3                                                                                                                                      | →         |    | RRC CONNECTION SETUP COMPLETE |                            |
| 4                                                                                                                                      | →         |    | CM SERVICE REQUEST            | U0.1                       |
| 5                                                                                                                                      | ←         |    | AUTHENTICATION REQUEST        |                            |
| 6                                                                                                                                      | →         |    | AUTHENTICATION RESPONSE       |                            |
| 7                                                                                                                                      | ←         |    | SECURITY MODE COMMAND         | U1                         |
| 8                                                                                                                                      | →         |    | SECURITY MODE COMPLETE        |                            |
| 9                                                                                                                                      | →         |    | SETUP                         |                            |
| 10                                                                                                                                     | ←         |    | CALL PROCEEDING               | U3                         |
| 11                                                                                                                                     | ←         |    | ALERTING                      | U4                         |
| 12                                                                                                                                     |           |    | Radio Bearer Setup Procedure  | DTCH, See TS 34.108        |
| 13                                                                                                                                     | ←         |    | CONNECT                       |                            |
| 14                                                                                                                                     | →         |    | CONNECT ACKNOWLEDGE           | U10                        |
| A15                                                                                                                                    | ←         |    | DISCONNECT                    | U12 (note 1)               |
| B15                                                                                                                                    | ←         |    | DISCONNECT                    | U12 (note 2)               |
| B16                                                                                                                                    | →         |    | RELEASE                       | U19                        |
| C15                                                                                                                                    |           |    | DISCONNECT                    | MMI action, terminate call |
| C16                                                                                                                                    | →         |    |                               |                            |
| NOTE 1:—The Progress Indicator IE with progress description #8 "in band information or appropriate pattern now available" is included. |           |    |                               |                            |
| NOTE 2:—The Progress Indication IE is not included.                                                                                    |           |    |                               |                            |

Table 10.1.2/2: Void

Table 10.1.2/3: Establishment of an outgoing call, procedure 3

| Step                                                                                                                                   | Direction |    | Message                       | Comments                   |
|----------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-------------------------------|----------------------------|
|                                                                                                                                        | UE        | SS |                               |                            |
| 1                                                                                                                                      | →         |    | RRC CONNECTION REQUEST        | Initiate outgoing call     |
| 2                                                                                                                                      | ←         |    | RRC CONNECTION SETUP          |                            |
| 3                                                                                                                                      | →         |    | RRC CONNECTION SETUP COMPLETE |                            |
| 4                                                                                                                                      | →         |    | CM SERVICE REQUEST            | U0.1                       |
| 5                                                                                                                                      | ←         |    | SECURITY MODE COMMAND         |                            |
| 6                                                                                                                                      | →         |    | SECURITY MODE COMPLETE        |                            |
| 7                                                                                                                                      | →         |    | SETUP                         | U1                         |
| 8                                                                                                                                      | ←         |    | AUTHENTICATION REQUEST        |                            |
| 9                                                                                                                                      | →         |    | AUTHENTICATION RESPONSE       |                            |
| 10                                                                                                                                     | ←         |    | CALL PROCEEDING               | U3                         |
| 11                                                                                                                                     |           |    | Radio Bearer Setup Procedure  | DTCH, See TS 34.108        |
| 12                                                                                                                                     | ←         |    | ALERTING                      | U4                         |
| 13                                                                                                                                     | →         |    | CONNECT                       |                            |
| 14                                                                                                                                     | ←         |    | CONNECT ACKNOWLEDGE           | U10                        |
| A15                                                                                                                                    | ←         |    | DISCONNECT                    | U12 (note 1)               |
| B15                                                                                                                                    | ←         |    | DISCONNECT                    | U12 (note 2)               |
| B16                                                                                                                                    | →         |    | RELEASE                       | U19                        |
| C15                                                                                                                                    |           |    |                               | MMI action, terminate call |
| C16                                                                                                                                    | →         |    | DISCONNECT                    | U11                        |
| NOTE 1: The Progress Indicator IE with progress description #8 "in band information or appropriate pattern now available" is included. |           |    |                               |                            |
| NOTE 2: The Progress indicator IE is not included.                                                                                     |           |    |                               |                            |

Table 10.1.2/4: Establishment of an outgoing call, procedure 4

| Step                                                                                                                                   | Direction |    | Message                       | Comments                    |
|----------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-------------------------------|-----------------------------|
|                                                                                                                                        | UE        | SS |                               |                             |
| 1                                                                                                                                      | →         |    | RRC CONNECTION REQUEST        | Initiate outgoing call      |
| 2                                                                                                                                      | ←         |    | RRC CONNECTION SETUP          |                             |
| 3                                                                                                                                      | →         |    | RRC CONNECTION SETUP COMPLETE |                             |
| 4                                                                                                                                      | →         |    | CM SERVICE REQUEST            | U0.1                        |
| 5                                                                                                                                      | ←         |    | IDENTITY REQUEST              |                             |
| 6                                                                                                                                      | →         |    | IDENTITY RESPONSE             |                             |
| 7                                                                                                                                      | ←         |    | SECURITY MODE COMMAND         |                             |
| 8                                                                                                                                      | →         |    | SECURITY MODE COMPLETE        |                             |
| 9                                                                                                                                      | →         |    | SETUP                         | U1                          |
| 10                                                                                                                                     | ←         |    | Radio Bearer Setup Procedure  | DTCH (note 1), See TS34.108 |
| 11                                                                                                                                     | ←         |    | CALL PROCEEDING               | U3                          |
| 12                                                                                                                                     | ←         |    | ALERTING                      | U4                          |
| 13                                                                                                                                     | ←         |    | CONNECT                       |                             |
| 14                                                                                                                                     | →         |    | CONNECT ACKNOWLEDGE           | U10                         |
| A15                                                                                                                                    | ←         |    | DISCONNECT                    | U12 (note 2)                |
| B15                                                                                                                                    | ←         |    | DISCONNECT                    | U12 (note 3)                |
| B16                                                                                                                                    | →         |    | RELEASE                       | U19                         |
| C15                                                                                                                                    |           |    |                               | MMI action, terminate call  |
| C16                                                                                                                                    | →         |    | DISCONNECT                    | U11                         |
| NOTE 1: Assigned channel is appropriate for the chosen bearer capability (see 10.1).                                                   |           |    |                               |                             |
| NOTE 2: The Progress Indicator IE with progress description #8 "in band information or appropriate pattern now available" is included. |           |    |                               |                             |
| NOTE 3: The Progress Indicator IE is not included.                                                                                     |           |    |                               |                             |

~~10.1.2.1 Outgoing call / U0 null state~~~~10.1.2.1.1 Outgoing call / U0 null state / MM connection requested~~~~10.1.2.1.1.1 Definition~~

The call control entity of the User Equipment requests the MM-sublayer to establish a mobile originating MM-connection.

~~10.1.2.1.1.2 Conformance requirement~~

- 1) Upon initiation of an outgoing basic call by user the UE shall initiate establishment of an MM connection, using as first MM message a CM SERVICE REQUEST message with CM service type "Mobile originating call establishment or packet mode connection establishment".

## References

— TS 24.008 clause 5.2.1.1 and clause 4.5.1.1, TS 25.331 clause 8.1.3.

~~10.1.2.1.1.3 Test purpose~~

To verify that upon initiation of an outgoing basic call by user the UE initiates establishment of an MM connection, using as first MM message a CM SERVICE REQUEST message with CM service type "Mobile originating call establishment or packet mode connection establishment".

~~10.1.2.1.1.4 Method of test~~

## Related ICS/IXIT statements

— supported MO circuit switched basic services.

## Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. When the SS receives CM SERVICE REQUEST, the contents of it shall be checked.

## Expected sequence

| Step | Direction |    | Message                         | Comments                                                                   |
|------|-----------|----|---------------------------------|----------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                            |
| 1    | →         |    | RRC CONNECTION REQUEST          | initiate outgoing call                                                     |
| 2    | ←         |    | RRC CONNECTION SETUP            |                                                                            |
| 3    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                            |
| 4    | →         |    | CM SERVICE REQUEST              |                                                                            |
| 5    | ←         |    | RRC CONNECTION RELEASE          | verify the type of call which is asked for "basic" or "emergency by the UE |
| 6    | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                            |
| 7    | UE        |    |                                 |                                                                            |
|      |           |    |                                 | the UE shall release the main signalling link                              |

Specific message contents:

None.

#### ~~10.1.2.1.1.5 Test requirements~~

~~After step 3 the UE shall initiate establishment of an MM connection, using as first MM message a CM SERVICE REQUEST message with CM service type "Mobile originating call establishment or packet mode connection establishment".~~

#### ~~10.1.2.2 Outgoing call / U0.1 MM connection pending~~

##### ~~10.1.2.2.1 Outgoing call / U0.1 MM connection pending / CM service rejected~~

###### ~~10.1.2.2.1.1 Definition~~

~~A request for MM connection is rejected by the SS.~~

###### ~~10.1.2.2.1.2 Conformance requirement~~

~~Upon receiving indication of an MM connection establishment being rejected, CC entity should inform upper layer of this rejection.~~

#### References

~~— TS 24.008, clause 4.5.1.1, TS 24.007, clause 6.2.2.~~

##### ~~10.1.2.2.1.3 Test purpose~~

~~To verify that a CC entity of the UE in CC state U0.1, "MM connection pending", upon the UE receiving a CM SERVICE REJECT message, returns to CC state U0, "Null".~~

##### ~~10.1.2.2.1.4 Method of test~~

#### Related ICS/IXIT statements

~~— supported MO circuit switched basic services.~~

#### Initial conditions

System Simulator:

~~— 1 cell, default parameters.~~

User Equipment:

~~— The UE is in MM state "idle, updated" with valid TMSI and CKSN.~~

~~— The UE is brought into the state U0.1 by using table 10.1.2/1.~~

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. When the SS receives CM SERVICE REQUEST, the contents of it shall be checked. The SS rejects it by CM SERVICE REJECT. Then the SS will check the state of the UE by using STATUS ENQUIRY with all the relevant transaction identifiers.

## Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                           |
|------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                    |
| 1    |           | <- | CM SERVICE REJECT               | cause shall be 81# (invalid TI value)<br>repeat steps 2-3 to cover all the transaction identifiers from 000 ...110 |
| 2    |           | <- | STATUS ENQUIRY                  |                                                                                                                    |
| 3    |           | -> | RELEASE COMPLETE                |                                                                                                                    |
| 4    |           | SS |                                 |                                                                                                                    |
| 5    |           | <- | RRC CONNECTION RELEASE          | the UE shall release the main signalling link                                                                      |
| 6    |           | -> | RRC CONNECTION RELEASE COMPLETE |                                                                                                                    |
| 7    |           | UE |                                 |                                                                                                                    |

## Specific message contents:

None.

## 10.1.2.2.1.5 Test requirements

After step 2 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

## 10.1.2.2.2 Outgoing call / U0.1 MM connection pending / CM service accepted

## 10.1.2.2.2.1 Definition

A CM request is accepted for the MM-connection by the SS.

## 10.1.2.2.2.2 Conformance requirement

A CC entity of the UE in CC-state U0.1, "MM-connection pending", upon the UE receiving a CM SERVICE ACCEPT message, shall send a SETUP message specifying the Called party BCD number that was entered into the UE and then enter CC state U1, "Call initiated".

## References

— TS 24.008, clause 4.5.1.1 and clause 5.2.1.1.

## 10.1.2.2.2.3 Test purpose

To verify that a CC entity of the UE in CC-state U0.1, "MM-connection pending", upon the UE receiving a CM SERVICE ACCEPT message, sends a SETUP message specifying the Called party BCD number that was entered into the UE and then enters CC state U1, "Call initiated".

## 10.1.2.2.2.4 Method of test

## Related ICS/IXIT statements

— supported MO circuit switched basic services.

## Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.



—The UE is brought into the state U0.1 by using table 10.1.2/1.

### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. When the UE is requesting a MM-connection, the SS will indicate acceptance by sending a CM SERVICE ACCEPT message. The UE shall respond with SETUP. Then the SS will check the state of the call control entity by STATUS ENQUIRY with the relevant transaction identifiers.

### Expected sequence

| Step | Direction |    | Message           | Comments                                                           |
|------|-----------|----|-------------------|--------------------------------------------------------------------|
|      | UE        | SS |                   |                                                                    |
| 1    |           | <- | CM SERVICE ACCEPT |                                                                    |
| 2    |           | -> | SETUP             | with called party BCD number.                                      |
| 3    |           | <- | STATUS ENQUIRY    |                                                                    |
| 4    |           | -> | STATUS            | cause shall be 30# (response to enq.) and state U1 call initiated. |

### Specific message contents:

None.

### 10.1.2.2.2.5 — Test requirements

After step 1 a CC entity of the UE in CC-state U0.1, "MM-connection pending", shall send a SETUP message specifying the Called party BCD number that was entered into the UE and then enter CC state U1, "Call initiated".

### 10.1.2.2.3 — Outgoing call / U0.1 MM connection pending / lower layer failure

#### 10.1.2.2.3.1 — Definition

The call control entity of the UE being in the state, U0.1, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated.

#### 10.1.2.2.3.2 — Conformance requirement

- 1) Upon a lower layer failure the UE releases the MM-connection in progress and returns to idle mode. In that state no call exists, and the CC entity is in state U0, "Null".

### References

—TS 24.008, clause 4.5.1.2, clause 5.2.1.1, clause 5.5.3.2 and clause 8.3, TS 25.331 clause 8.3.1 and clause 8.5.6.

#### 10.1.2.2.3.3 — Test purpose

To verify that after the UE with a CC entity in state U0.1, "MM-connection pending", has detected a lower layer failure and has returned to idle mode, the CC entity is in state U0, "Null".

#### 10.1.2.2.3.4 — Method of test

### Related ICS/IXIT statements

—supported MO circuit switched basic services.

### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

— The UE is brought into the state U0.1 by using table 10.1.2/1.

### Test procedure

An MO-circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. When the UE has sent a CM SERVICE REQUEST message, the SS modifies the scrambling code of downlink transmission (DL DPCH) to generate a lower layer failure at the UE. The SS waits long enough to enable the UE to perform cell update procedure. The SS sends RRC CONNECTION RELEASE message as a response to the CELL UPDATE message from the UE. The SS re-modifies the scrambling code of downlink transmission (DL DPCH) to the original one and waits 60 s. The SS will check that the UE will not send any message during 60 s.

### Expected sequence

| Step | Direction |    | Message                               | Comments                                                                   |
|------|-----------|----|---------------------------------------|----------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                            |
| 1    |           | SS | CELL UPDATE<br>RRC CONNECTION RELEASE | SS modifies the scrambling code of DPCH for generating lower layer failure |
| 2    | →         |    |                                       | CCCH                                                                       |
| 3    | ←         |    |                                       | CCCH                                                                       |
| 4    |           | SS |                                       | SS re-modifies the scrambling code of DPCH to the original one.            |
| 5    |           | SS |                                       | SS waits 60 s.<br>UE shall send no message on DCCH                         |

### Specific message contents:

None.

#### 10.1.2.2.3.5 — Test requirements

After step 4 the UE shall not send any message to the SS during 60 s.

#### 10.1.2.3 — Outgoing call / U1 call initiated

##### 10.1.2.3.1 — Outgoing call / U1 call initiated / receiving CALL PROCEEDING

###### 10.1.2.3.1.1 — Definition

The call control entity of the UE being in the state, U1, a CALL PROCEEDING message is sent by the SS.

###### 10.1.2.3.1.2 — Conformance requirement

- 1) A CC entity of the UE in CC-state U1, "Call initiated", upon receipt of a CALL PROCEEDING message, shall enter CC state U3, "Mobile originating call proceeding".

### References

— TS 24.008, clauses 5.2.1.1, 5.2.1.2 and 5.2.1.3.

~~10.1.2.3.1.3 ————— Test purpose~~

~~To verify that a CC entity of the UE in CC-state U1, "Call initiated", upon receipt of a CALL PROCEEDING message, enters CC state U3, "Mobile originating call proceeding".~~

~~10.1.2.3.1.4 ————— Method of test~~

~~Related ICS/IXIT statements~~

~~— supported MO circuit switched basic services.~~

~~Initial conditions~~

~~System Simulator:~~

~~— 1 cell, default parameters.~~

~~User Equipment:~~

~~— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~— The UE is brought into the state U1 by using table 10.1.2/1.~~

~~Test procedure~~

~~An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U1. The SS sends a CALL PROCEEDING message to the UE. The SS checks by using the status enquiry procedure that the CC entity has entered the state U3.~~

~~Expected sequence~~

| Step | Direction |    | Message         | Comments                      |
|------|-----------|----|-----------------|-------------------------------|
|      | UE        | SS |                 |                               |
| 1    |           | <- | CALL PROCEEDING | tone generation not mandatory |
| 2    |           | <- | STATUS ENQUIRY  |                               |
| 3    |           | -> | STATUS          | cause 30#, state U3           |

~~Specific message contents:~~

~~None.~~

~~10.1.2.3.1.5 ————— Test requirements~~

~~After step 1 a CC entity of the UE in CC-state U1, "Call initiated", shall enter CC state U3, "Mobile originating call proceeding".~~

~~10.1.2.3.2 ————— Outgoing call / U1 call initiated / rejecting with RELEASE COMPLETE~~

~~10.1.2.3.2.1 ————— Definition~~

~~The call control entity of the UE being in the state, U1, the call is rejected by a RELEASE COMPLETE message sent by the SS.~~

~~10.1.2.3.2.2 ————— Conformance requirement~~

- ~~1) A CC entity of the UE in CC-state U1, "Call initiated", upon receipt of a RELEASE COMPLETE message with valid cause value, shall enter CC state U0, "Null".~~

- 2) On returning to idle mode, the CC entities relating to the seven mobile originating transaction identifiers shall be in state U0, "Null".
- 3) On releasing the MM connection, the UE shall wait for MM layer release initiated by the network.

## References

Conformance requirement 1: — TS 24.008, clause 5.4.2 and clause 5.4.4.

Conformance requirement 2: — TS 24.008, clause 5.5.3.2.

Conformance requirement 3: — TS 24.008, clause 5.4.4.1.3, clause 4.5.3 and clause 8.1.4.

## 10.1.2.3.2.3 — Test purpose

- 1) To verify that a CC entity of the UE in CC state U1, "Call initiated", upon receipt of a RELEASE COMPLETE message with valid cause value, enters CC state U0, "Null".
- 2) To verify that in returning to idle mode, the CC entities relating to the seven mobile originating transaction identifiers are in state U0, "Null".
- 3) To verify that in releasing the MM connection, the UE shall wait for MM layer release initiated by SS.

## 10.1.2.3.2.4 — Method of test

## Related ICS/IXIT statements

— supported MO circuit switched basic services.

## Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in MM state "idle, updated" with valid TMSI and CKSN.

— The UE is brought into the state U1 by using table 10.1.2/1.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U1. The SS sends a RELEASE COMPLETE message to the UE. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

## Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                           |
|------|-----------|----|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                    |
| 1    |           | <  | RELEASE COMPLETE                | See specific message content below.<br><br>cause 81# (invalid TI value)<br>repeat steps 2-3 to cover all the transaction identifiers from 000...110<br>the main signalling link shall be released. |
| 2    |           | <  | STATUS ENQUIRY                  |                                                                                                                                                                                                    |
| 3    |           | >  | RELEASE COMPLETE                |                                                                                                                                                                                                    |
| 4    |           | SS |                                 |                                                                                                                                                                                                    |
| 5    |           | <  | RRC CONNECTION RELEASE          |                                                                                                                                                                                                    |
| 6    |           | >  | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                    |

~~Specific message contents:~~

~~RELEASE COMPLETE~~

~~— 1) With a valid cause value among:~~

~~related to numbering,~~

~~#1 unallocated number~~

~~#3 no route to destination~~

~~#22 number changed~~

~~#28 invalid number format~~

~~related to bearer capabilities,~~

~~#8 operator determined barring~~

~~#57 bearer capability not authorized~~

~~#58 bearer capability not presently available~~

~~#63 service or option not available~~

~~#65 bearer service not implemented~~

~~#34 no circuit/channel available (call queuing).~~

#### ~~10.1.2.3.2.5 — Test requirements~~

~~After step 2 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).~~

#### ~~10.1.2.3.3 — Outgoing call / U1 call initiated / T303 expiry~~

##### ~~10.1.2.3.3.1 — Definition~~

~~The call control entity of the UE being in the state, U1, if no response is then received from the SS, timer T303 expires at the UE side.~~

##### ~~10.1.2.3.3.2 — Conformance requirement~~

- ~~1) A CC entity of the UE in CC-state U1, "Call initiated", upon expiry of T303 shall send a DISCONNECT message to its peer entity and enter state U11, "Disconnect request".~~

#### ~~References~~

~~— TS 24.008, clause 5.2.1.1 and clause 5.4.~~

##### ~~10.1.2.3.3.3 — Test purpose~~

- ~~1) To verify that a CC entity of the UE in CC-state U1, "Call initiated", upon expiry of T303 sends a DISCONNECT message to its peer entity and enters state U11, "Disconnect request".~~

##### ~~10.1.2.3.3.4 — Method of test~~

#### ~~Related ICS/IXIT statements~~

~~— supported MO circuit switched basic services.~~

### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

— The UE is brought into the state U1 by using table 10.1.2/1.

### Test procedure

An MO-circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U1. When T303 expires at the UE, the UE shall send DISCONNECT. The SS checks by using the status enquiry procedure that the CC entity has entered the state U11, disconnect request.

### Expected sequence

| Step | Direction |    | Message        | Comments                                                                 |
|------|-----------|----|----------------|--------------------------------------------------------------------------|
|      | UE        | SS |                |                                                                          |
| 1    |           | SS |                | SS waits for T303-expiry.                                                |
| 2    |           | →  | DISCONNECT     | Shall be transmitted between 24 s and 36 s after the CM SERVICE REQUEST. |
| 3    |           | <  | STATUS ENQUIRY |                                                                          |
| 4    |           | →  | STATUS         | cause 30#, status U11                                                    |

### Specific message contents:

None.

#### 10.1.2.3.3.5 — Test requirements

Upon expiry of timer T303, a CC entity of the UE in CC-state U1, "Call initiated", shall send a DISCONNECT message and enter state U11, "Disconnect request".

#### 10.1.2.3.4 — Outgoing call / U1 call initiated / lower layer failure

##### 10.1.2.3.4.1 — Definition

The call control entity of the UE being in the state, U1, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated.

##### 10.1.2.3.4.2 — Conformance requirement

Upon a lower layer failure MM informs the relevant CM entities that the MM connection has been interrupted. As call re-establishment is not allowed, the CC entity must perform a local release. The UE returns to idle mode. In that state no call exists, and the CC entity is in state U0, "Null".

### References

— TS 24.008, clause 4.5.2.3, clause 5.2.1.1 and clause 5.5.3.2, TS 25.331 clause 8.3.1 and clause 8.5.6.

#### 10.1.2.3.4.3 — Test purpose

To verify that after the UE with a CC entity in state U1 "Call initiated", has detected a lower layer failure and has returned to idle mode, the CC entity is in state U0, "Null".

~~10.1.2.3.4.4 Method of test~~~~Related ICS/IXIT statements~~~~—supported MO circuit-switched basic services.~~~~Initial conditions~~~~System Simulator:~~~~—1 cell, default parameters.~~~~User Equipment:~~~~—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~~~—The UE is brought into the state U1 by using table 10.1.2/4.~~~~Test procedure~~

An MO circuit-switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The UE is brought to the state U1. The SS modifies the scrambling code of downlink transmission (DL DPCH) to generate a lower layer failure at the UE. The SS waits long enough to enable the UE to perform cell update procedure. The SS sends RRC CONNECTION RELEASE message as a response to the CELL UPDATE message from the UE. The SS re-modifies the scrambling code of downlink transmission (DL DPCH) to the original one and waits 60 s. The SS will check that the UE will not send any message during 60 s.

~~Expected sequence~~

| Step | Direction |    | Message                               | Comments                                                                   |
|------|-----------|----|---------------------------------------|----------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                            |
| 1    |           | SS | CELL UPDATE<br>RRC CONNECTION RELEASE | SS modifies the scrambling code of DPCH for generating lower-layer failure |
| 2    |           | -> |                                       | CCCH                                                                       |
| 3    |           | <- |                                       | CCCH                                                                       |
| 4    |           | SS |                                       | SS re-modifies the scrambling code of DPCH to the original one.            |
| 5    |           | SS |                                       | SS waits 60 s.<br>UE shall send no message on DCCH                         |

~~Specific message contents:~~~~None.~~~~10.1.2.3.4.5 Test requirements~~~~After step 4 the UE shall not send any message to the SS during 60 s.~~~~10.1.2.3.5 Outgoing call / U1 call initiated / receiving ALERTING~~~~10.1.2.3.5.1 Definition~~

The call control entity of the UE being in the state, U1, an ALERTING message is sent to the UE as a indication that a call is being alerted at a called end.

~~10.1.2.3.5.2 Conformance requirement~~

- ~~1) A CC entity of the UE in CC-state U1, "Call initiated", upon receipt of an ALERTING message, shall enter CC state U4, "Call delivered".~~

## References

—TS 24.008, clause 5.2.1.1.

### 10.1.2.3.5.3 — Test purpose

To verify that a CC entity of the UE in CC-state U1, "Call initiated", upon receipt of an ALERTING message, enters CC-state U4, "Call delivered".

### 10.1.2.3.5.4 — Method of test

## Related ICS/IXIT statements

—supported MO circuit switched basic services.

## Initial conditions

System Simulator:

—1 cell, default parameters.

User Equipment:

—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

—The UE is brought into the state U1 by using table 10.1.2/4.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U1. The SS sends an ALERTING message to the UE. The SS checks by using the status enquiry procedure that the CC entity has entered the state U4, call delivered.

## Expected sequence

| Step | Direction |    | Message        | Comments            |
|------|-----------|----|----------------|---------------------|
|      | UE        | SS |                |                     |
| 1    |           | <  | ALERTING       | cause 30#, state U4 |
| 2    |           | <  | STATUS ENQUIRY |                     |
| 3    |           | >  | STATUS         |                     |

## Specific message contents:

None.

### 10.1.2.3.5.5 — Test requirements

After step 1 a CC entity of the UE in CC-state U1, "Call initiated", shall enter CC-state U4, "Call delivered".

### 10.1.2.3.6 — Outgoing call / U1 call initiated / entering state U10

#### 10.1.2.3.6.1 — Definition

The call control entity of the UE being in the state, U1, a CONNECT message is received by the UE.

#### 10.1.2.3.6.2 — Conformance requirement

- 1) A CC entity of the UE in CC-state U1, "Call initiated", upon receipt of a CONNECT message, shall send a CONNECT ACKNOWLEDGE message to its peer entity and enter CC-state U10, "Active".



References

~~—TS 24.008, clause 5.2.1.1 and clause 5.2.1.6.~~

~~10.1.2.3.6.3~~ ~~Test purpose~~

~~To verify that a CC entity of the UE in CC-state U1, "Call initiated", upon receipt of a CONNECT message, sends a CONNECT ACKNOWLEDGE message to its peer entity and enters CC-state U10, "Active".~~

~~10.1.2.3.6.4~~ ~~Method of test~~

Related ICS/IXIT statements

~~—supported MO circuit switched basic services.~~

Initial conditions

System Simulator:

~~—1 cell, default parameters.~~

User Equipment:

~~—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~—The UE is brought into the state U1 by using table 10.1.2/4.~~

Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U1. The SS sends a CONNECT message to the UE. The UE shall respond by sending a CONNECT ACKNOWLEDGE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U10, active.

Expected sequence

| Step | Direction |    | Message             | Comments             |
|------|-----------|----|---------------------|----------------------|
|      | UE        | SS |                     |                      |
| 1    |           | <  | CONNECT             | cause 30#, state U10 |
| 2    |           | >  | CONNECT ACKNOWLEDGE |                      |
| 3    |           | <  | STATUS ENQUIRY      |                      |
| 4    |           | >  | STATUS              |                      |

Specific message contents:

None.

~~10.1.2.3.6.5~~ ~~Test requirements~~

~~After step 1 a CC entity of the UE in CC-state U1, "Call initiated", shall send a CONNECT ACKNOWLEDGE message and shall enter CC-state U10, "Active".~~

~~10.1.2.3.7~~ ~~Outgoing call / U1 call initiated / unknown message received~~

~~10.1.2.3.7.1~~ ~~Definition~~

~~The call control entity of the UE being in the state, U1, an unknown message is received by the UE.~~

~~10.1.2.3.7.2~~ ~~Conformance requirement~~

- ~~1) A CC entity of the UE in CC-state U1, "Call initiated", upon receipt of a message with message type not defined for the protocol discriminator from its peer entity shall return a STATUS message.~~

~~References~~

~~—TS 24.008 clause 8.4.~~

~~10.1.2.3.7.3~~ ~~Test purpose~~

~~To verify that a CC entity of the UE in CC-state U1, "Call initiated", upon receipt of a message with message type not defined for the protocol discriminator unknown message from its peer entity returns a STATUS message.~~

~~10.1.2.3.7.4~~ ~~Method of test~~

~~Related ICS/IXIT statements~~

~~—supported MO circuit switched basic services.~~

~~Initial conditions~~

~~System Simulator:~~

~~—1 cell, default parameters.~~

~~User Equipment:~~

~~—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~—The UE is brought into the state U1 by using table 10.1.2/1.~~

~~Test procedure~~

~~An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U1. The SS sends a message with message type not defined for the protocol discriminator to the UE. The UE shall respond with a STATUS message, and finally the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.~~

~~Expected sequence~~

| Step | Direction |    | Message         | Comments                                               |
|------|-----------|----|-----------------|--------------------------------------------------------|
|      | UE        | SS |                 |                                                        |
| 1    |           | <  | unknown message | message type not defined for PD<br>cause 97#, state U1 |
| 2    |           | >  | STATUS          |                                                        |
| 3    |           | <  | STATUS ENQUIRY  | cause 30#, state U1                                    |
| 4    |           | >  | STATUS          |                                                        |

~~Specific message contents:~~

~~None.~~

~~10.1.2.3.7.5~~ ~~Test requirements~~

~~After step 1 and step 3 a CC entity of the UE in CC-state U1, "Call initiated", shall return a STATUS message.~~

~~10.1.2.4 Outgoing call / U3 UE originating call proceeding~~~~10.1.2.4.1 Outgoing call / U3 UE originating call proceeding / ALERTING received~~~~10.1.2.4.1.1 Definition~~

The call control entity of the UE being in the state, U3, an ALERTING message is sent to the UE as a indication that a call is being alerted at a called end.

~~10.1.2.4.1.2 Conformance requirement~~

- 1) A CC entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a ALERTING message shall enter CC-state U4, "Call Delivered".

## References

— TS 24.008 clause 5.2.1.5.

~~10.1.2.4.1.3 Test purpose~~

To verify that a CC entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a ALERTING message enters CC-state U4, "Call Delivered".

~~10.1.2.4.1.4 Method of test~~

## Related ICS/IXIT statements

— supported MO circuit switched basic services.

## Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

— The UE is brought into the state U3 by using table 10.1.2/3.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends an ALERTING message to the UE. The SS checks by using the status enquiry procedure that the CC entity has entered the state U4, call delivered.

## Expected sequence

| Step | Direction |    | Message        | Comments            |
|------|-----------|----|----------------|---------------------|
|      | UE        | SS |                |                     |
| 1    |           | <- | ALERTING       | cause 30#, state U4 |
| 2    |           | <- | STATUS ENQUIRY |                     |
| 3    |           | -> | STATUS         |                     |

## Specific message contents:

None.

#### ~~10.1.2.4.1.5 — Test requirements~~

~~After step 1 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall enter CC-state U4, "Call Delivered".~~

#### ~~10.1.2.4.2 — Outgoing call / U3 UE originating call proceeding / CONNECT received~~

##### ~~10.1.2.4.2.1 — Definition~~

~~The call-control entity of the UE being in the state, U3, a CONNECT message is received by the UE.~~

##### ~~10.1.2.4.2.2 — Conformance requirement~~

- ~~1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a CONNECT message shall return a "CONNECT ACKNOWLEDGE" message to its peer entity and enter the CC state U10, "Active".~~
- ~~2) The UE shall then stop any locally generated indication.~~

#### References

~~Conformance requirement 1: — TS 24.008 clause 5.2.1.6.~~

~~Conformance requirement 2: — TS 24.008 clause 5.2.1.6.~~

##### ~~10.1.2.4.2.3 — Test purpose~~

- ~~1) To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a CONNECT message returns a "CONNECT ACKNOWLEDGE" message to its peer entity and enters the CC state U10, "Active".~~
- ~~2) To verify that the UE stops locally generated indication, if any.~~

##### ~~10.1.2.4.2.4 — Method of test~~

#### Related ICS/IXIT statements

~~— supported MO circuit-switched basic services.~~

#### Initial conditions

~~System Simulator:~~

~~— 1 cell, default parameters.~~

~~User Equipment:~~

~~— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~— The UE is brought into the state U3 by using table 10.1.2/3.~~

#### Test procedure

~~An MO circuit-switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC-entity of the UE is brought to the state U3. The SS sends a RADIO BEARER SETUP for traffic channel to the UE. The UE shall respond with a RADIO BEARER SETUP COMPLETE message. The SS sends a CONNECT message to the UE. The UE shall respond by sending a CONNECT ACKNOWLEDGE message. The SS checks by using the status enquiry procedure that the CC-entity has entered the state U10, active.~~

## Expected sequence

| Step | Direction |    | Message                      | Comments                                                                                      |
|------|-----------|----|------------------------------|-----------------------------------------------------------------------------------------------|
|      | UE        | SS |                              |                                                                                               |
| 1    |           |    | Radio Bearer Setup Procedure | (DTCH), See TS34.108<br>the UE shall stop tone generation, if any<br><br>cause 30#, state U10 |
| 2    |           | ←  | CONNECT                      |                                                                                               |
| 3    |           | →  | CONNECT ACKNOWLEDGE          |                                                                                               |
| 4    |           | ←  | STATUS ENQUIRY               |                                                                                               |
| 5    |           | →  | STATUS                       |                                                                                               |

## Specific message contents:

None.

## 10.1.2.4.2.5 — Test requirements

After step 1 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall return a "CONNECT ACKNOWLEDGE" message and enter the CC-state U10, "Active".

The UE shall stop locally generated indication.

## 10.1.2.4.3 — Outgoing call / U3 UE originating call proceeding / PROGRESS received without in-band information

## 10.1.2.4.3.1 — Definition

The call control entity of the UE being in the state, U3, a PROGRESS message is received by the UE. The PROGRESS message does not contain indication of in-band information availability.

## 10.1.2.4.3.2 — Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a PROGRESS message with valid cause values shall stay in CC-state U3.
- 2) After receipt of the PROGRESS message timer T310 shall be stopped.

## References

Conformance requirement 1: — TS 24.008 clause 5.2.1.4.

Conformance requirement 2: — TS 24.008 clause 11.3.

## 10.1.2.4.3.3 — Test purpose

- 1) To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a PROGRESS message with valid cause values stays in CC-state U3.
- 2) To verify that after receipt of the PROGRESS message timer T310 is stopped.

## 10.1.2.4.3.4 — Method of test

## Related ICS/IXIT statements

— supported MO circuit switched basic services.

## Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

- The UE is in MM-state "idle, updated" with valid TMSI and CKSN.
- The UE is brought into the state U3 by using table 10.1.2/3.

### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends a PROGRESS message not containing indication of in-band information availability to the UE. The SS checks that the UE has stopped T310, i.e. at T310 time-out no DISCONNECT message is sent by the UE. Then the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

### Expected sequence

| Step | Direction |    | Message        | Comments                                                          |
|------|-----------|----|----------------|-------------------------------------------------------------------|
|      | UE        | SS |                |                                                                   |
| 1    |           | <  | PROGRESS       | (note)                                                            |
| 2    |           | <  | STATUS ENQUIRY |                                                                   |
| 3    |           | >  | STATUS         | cause 30#, state U3                                               |
| 4    |           | SS |                | SS waits at least 45 s and checks no DISCONNECT is sent by the UE |
| 5    |           | <  | STATUS ENQUIRY |                                                                   |
| 6    |           | >  | STATUS         | cause 30#, state U3                                               |

NOTE: —Tested with a valid cause value among:

- #4 call has returned to PLMN/ISDN;
- #32 call is end-to-end PLMN/ISDN; or
- any value in the set #(21-127).

### Specific message contents:

None.

### 10.1.2.4.3.5 — Test requirements

After step 1 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall stay in CC-state U3.

After step 3 SS waits at least 45 s and checks no DISCONNECT is sent by the UE.

### 10.1.2.4.4 — Outgoing call / U3 UE originating call proceeding / PROGRESS with in-band information

#### 10.1.2.4.4.1 — Definition

The call control entity of the UE being in the state, U3, a PROGRESS message indicating availability of in-band information is received by the UE.

#### 10.1.2.4.4.2 — Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a PROGRESS message indicating in-band announcement shall through-connect the traffic channel for speech, if DTCH is in a speech mode. If DTCH is not in speech mode, the UE shall not through-connect the DTCH.
- 2) After receipt of the PROGRESS message, T310 shall be stopped.

## References

— TS 25.331 clause 8.2.1, TS 24.008 clause 5.2.1.4, clause 5.2.1.9, clause 5.5.1 and clause 11.3.

## 10.1.2.4.4.3 — Test purpose

- 1) To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a PROGRESS message indicating in-band announcement through-connects the traffic channel for speech, if DTCH is in speech mode. If DTCH is not in a speech mode, the UE does not through-connect the DTCH.
- 2) To verify that after receipt of the PROGRESS message, T310 is stopped.

## 10.1.2.4.4.4 — Method of test

## Related ICS/IXIT statements

— supported MO circuit switched basic services.

## Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

— The UE is brought into the state U3 by using table 10.1.2/3.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends a RADIO BEARER SETUP for traffic channel to the UE. The UE shall respond with a RADIO BEARER SETUP COMPLETE message. The SS sends a PROGRESS message containing indication of in-band information availability to the UE. The SS checks that if channel mode is speech, the DTCH shall be through-connected. If channel mode is not speech, the DTCH shall not be through connected. Also the SS checks that the UE has stopped T310, i.e. at T310 time-out no DISCONNECT message is sent by the UE. Then the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

## Expected sequence

| Step | Direction |    | Message                      | Comments                                                                                                                                                                               |
|------|-----------|----|------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                              |                                                                                                                                                                                        |
| 1    |           |    | Radio Bearer Setup Procedure | (DTCH), See TS34.108                                                                                                                                                                   |
| 2    |           | <- | PROGRESS                     | (note)<br>the UE shall stop all the CC-timers, if channel mode is speech, the DTCH shall be through-connected. If channel mode is not speech, the DTCH shall not be through-connected. |
| 3    |           | <- | STATUS ENQUIRY               | cause 30#, state U3                                                                                                                                                                    |
| 4    |           | -> | STATUS                       | SS waits at least 45 s and checks no DISCONNECT is sent by the UE.                                                                                                                     |
| 5    |           | SS |                              |                                                                                                                                                                                        |
| 6    |           | <- | STATUS ENQUIRY               | cause 30#, state U3                                                                                                                                                                    |
| 7    |           | -> | STATUS                       | If the channel mode is speech the SS will check that the user connection for speech is attached (both downlink and uplink).                                                            |
| 8    |           | SS |                              |                                                                                                                                                                                        |

### Specific message contents:

NOTE: ~~Tested with a valid cause value among:~~

- ~~— #1 call is not end to end PLMN/ISDN;~~
- ~~— #2 destination address is non PLMN/ISDN;~~
- ~~— #3 originating address is non PLMN/ISDN;~~
- ~~— #8 in band information or appropriate pattern now available or any value in the set #(6-20).~~

### ~~10.1.2.4.4.5~~ ~~Test requirements~~

~~After step 2 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall through-connect the traffic channel for speech, if DTCH is in a speech mode. If DTCH is not in speech mode, the UE shall not through-connect the DTCH.~~

~~After step 2 the SS waits at least 45 s and checks no DISCONNECT is sent by the UE.~~

~~After step 5 the SS checks that the user connection for speech is attached (both downlink and uplink), if the channel mode is speech.~~

### ~~10.1.2.4.5~~ ~~Outgoing call / U3 UE originating call proceeding / DISCONNECT with in band tones~~

#### ~~10.1.2.4.5.1~~ ~~Definition~~

~~The call control entity of the UE being in the state, U3, a DISCONNECT message indicating availability of in band information is received by the UE.~~

#### ~~10.1.2.4.5.2~~ ~~Conformance requirement~~

- ~~1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a DISCONNECT with progress indicator #8, shall through-connect the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE shall send a RELEASE message.~~

### References

- ~~— TS 24.008 clause 5.2.1.4 and clause 5.4.4.~~

### ~~10.1.2.4.5.3~~ ~~Test purpose~~

~~To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a DISCONNECT with progress indicator #8 through-connects the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE sends a RELEASE message.~~

### ~~10.1.2.4.5.4~~ ~~Method of test~~

### Related ICS/IXIT statements

- ~~— supported MO circuit switched basic services.~~

### Initial conditions

System Simulator:

- ~~— 1 cell, default parameters.~~

User Equipment:

- ~~— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~



—The UE is brought into the state U3 by using table 10.1.2/3.

### Test procedure

An MO-circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends a RADIO BEARER SETUP for traffic channel to the UE. The UE shall respond with a RADIO BEARER SETUP COMPLETE message. The SS sends a DISCONNECT message containing indication of in-band information availability to the UE. The SS checks that if channel mode is speech, the DTCH shall be through connected and the UE enters state U12, disconnect indication. If channel mode is not speech, the DTCH shall not be through connected and the UE shall enter state U19, release request.

### Expected sequence

| Step           | Direction |                | Message                                    | Comments                                                                                        |
|----------------|-----------|----------------|--------------------------------------------|-------------------------------------------------------------------------------------------------|
|                | UE        | SS             |                                            |                                                                                                 |
| 1<br>2         |           | <-             | Radio Bearer Setup Procedure<br>DISCONNECT | (DTCH), See TS34.108<br>(note)                                                                  |
| A3             |           | SS             |                                            | DTCH in speech mode:<br>the SS will check that the audio path for<br>in-band tones is attached. |
| A4<br>A5       |           | <-<br>->       | STATUS ENQUIRY<br>STATUS                   | cause 30#, state U12                                                                            |
| B3<br>B4<br>B5 |           | -><br><-<br>-> | RELEASE<br>STATUS ENQUIRY<br>STATUS        | DTCH is not in speech mode:<br>cause 30#, state U19                                             |

### Specific message contents:

NOTE:—the cause value:

—#8 in band information or appropriate pattern now available.

### 10.1.2.4.5.5 ——— Test requirements

After step 2 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall through-connect the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE shall send a RELEASE message.

### ~~10.1.2.4.6 ——— Outgoing call / U3 UE originating call proceeding / DISCONNECT without in band tones~~

#### 10.1.2.4.6.1 ——— Definition

The call control entity of the UE being in the state, U3, a DISCONNECT message is received by the UE. The DISCONNECT message does not contain indication of in-band information availability.

#### 10.1.2.4.6.2 ——— Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a DISCONNECT without progress indicator shall return a RELEASE message and enter the CC-state U19, "Release Request"

### References

—TS 24.008 clause 5.4.4.

~~10.1.2.4.6.3 Test purpose~~

~~To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a DISCONNECT without progress indicator returns a RELEASE message and enters the CC-state U19, "Release Request".~~

~~10.1.2.4.6.4 Method of test~~

~~Related ICS/IXIT statements~~

~~—supported MO circuit switched basic services.~~

~~Initial conditions~~

~~System Simulator:~~

~~—1 cell, default parameters.~~

~~User Equipment:~~

~~—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~—The UE is brought into the state U3 by using table 10.1.2/3.~~

~~Test procedure~~

~~An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends a DISCONNECT message not containing indication of in-band information availability to the UE. The UE shall respond with a RELEASE message. The SS checks by using the status enquiry procedure that the CC entity of the UE has entered the state U19, release request.~~

~~Expected sequence~~

| Step | Direction |    | Message        | Comments             |
|------|-----------|----|----------------|----------------------|
|      | UE        | SS |                |                      |
| 1    |           | ←  | DISCONNECT     | cause 30#, state U19 |
| 2    |           | →  | RELEASE        |                      |
| 3    |           | ←  | STATUS-ENQUIRY |                      |
| 4    |           | →  | STATUS         |                      |

~~Specific message contents:~~

~~None.~~

~~10.1.2.4.6.5 Test requirements~~

~~After step 1 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall send a RELEASE message and enter the CC-state U19, "Release Request".~~

~~10.1.2.4.7 Outgoing call / U3 UE originating call proceeding / RELEASE received~~

~~10.1.2.4.7.1 Definition~~

~~The call control entity of the UE being in the state, U3, a RELEASE message is received by the UE.~~

#### ~~10.1.2.4.7.2~~ Conformance requirement

- ~~1) A CC entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a RELEASE will return a RELEASE COMPLETE and enter the CC-state U0, "Null".~~
- ~~2) The UE on returning to the idle mode shall release the MM-connection and the CC-entities relating to the seven mobile originating transaction identifiers shall be in CC-state U0, "Null".~~
- ~~3) On releasing the MM-connection, the UE shall wait for MM layer release initiated by the network.~~

#### References

Conformance requirement 1: ~~—TS 24.008 clause 5.4.2 and clause 5.4.4.~~

Conformance requirement 2: ~~—TS 24.008 clause 4.5.3 and clause 5.5.3.2.~~

Conformance requirement 3: ~~—TS 24.008 clause 5.4.4.1.3 and clause 4.5.3, TS 25.331 clause 8.1.4.~~

#### ~~10.1.2.4.7.3~~ Test purpose

- ~~1) To verify that a CC entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon receipt of a RELEASE will return a RELEASE COMPLETE and enter the CC-state U0, "Null".~~
- ~~2) To verify that the UE on returning to the idle mode releases the MM-connection and that the CC-entities relating to the seven mobile originating transaction identifiers are in CC-state U0, "Null".~~
- ~~3) To verify that in releasing the MM-connection, the UE shall wait for MM layer release initiated by SS.~~

#### ~~10.1.2.4.7.4~~ Method of test

#### Related ICS/IXIT statements

~~—supported MO circuit switched basic services.~~

#### Initial conditions

System Simulator:

~~—1 cell, default parameters.~~

User Equipment:

~~—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~—The UE is brought into the state U3 by using table 10.1.2/3.~~

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends a RELEASE message to the UE. The UE shall respond with a RELEASE COMPLETE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

## Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                        |
|------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                 |
| 1    | <         |    | RELEASE                         | with cause "Normal, unspecified"<br><br>cause 81# (invalid TI value)<br>repeat steps 3-4 to cover all the transaction identifiers from 000...110<br>the main signalling link shall be released. |
| 2    | >         |    | RELEASE COMPLETE                |                                                                                                                                                                                                 |
| 3    | <         |    | STATUS ENQUIRY                  |                                                                                                                                                                                                 |
| 4    | >         |    | RELEASE COMPLETE                |                                                                                                                                                                                                 |
| 5    |           | SS |                                 |                                                                                                                                                                                                 |
| 6    | <         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                 |
| 7    | >         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                 |

## Specific message contents:

None.

## 10.1.2.4.7.5 Test requirements

After step 1 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall send a RELEASE COMPLETE message.

After step 3 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

## 10.1.2.4.8 Outgoing call / U3 UE originating call proceeding / termination requested by the user

## 10.1.2.4.8.1 Definition

The call control entity of the UE being in the state, U3, the user requests to terminate the call.

## 10.1.2.4.8.2 Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon request by the user to terminate will send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

## References

— TS 24.007 clause 6.2.2., TS 24.008 clause 5.4.3.

## 10.1.2.4.8.3 Test purpose

To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", upon request by the user to terminate will send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

## 10.1.2.4.8.4 Method of test

## Related ICS/IXIT statements

— supported MO circuit switched basic services.

## Initial conditions

System Simulator: — 1 cell, default parameters.

User Equipment: — The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

— The UE is brought into the state U3 by using table 10.1.2/3.

### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The user requests termination of the call. The UE shall send a DISCONNECT message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U11, disconnect request.

### Expected sequence

| Step | Direction |    | Message        | Comments                                               |
|------|-----------|----|----------------|--------------------------------------------------------|
|      | UE        | SS |                |                                                        |
| 1    |           |    |                | MMI action, terminate call<br><br>cause 30#, state U11 |
| 2    |           | →  | DISCONNECT     |                                                        |
| 3    |           | ←  | STATUS ENQUIRY |                                                        |
| 4    |           | →  | STATUS         |                                                        |

### Specific message contents:

None.

### 10.1.2.4.8.5 — Test requirements

After step 1 a CC entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

### 10.1.2.4.9 — Outgoing call / U3 UE originating call proceeding / traffic channel allocation

#### 10.1.2.4.9.1 — Definition

The call control entity of the UE being in the state, U3, a radio bearer establishment procedure is performed.

#### 10.1.2.4.9.2 — Conformance requirement

- 1) A CC entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, shall stay in CC-state U3.

### References

— TS 25.331 clause 8.2.1, TS 24.008 clause 5.2.1.9.

#### 10.1.2.4.9.3 — Test purpose

To verify that a CC entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, stays in CC-state U3.

#### 10.1.2.4.9.4 — Method of test

### Related ICS/IXIT statements

— supported MO circuit switched basic services.

### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

—The UE is brought into the state U3 by using table 10.1.2/3.

### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends a RADIO BEARER SETUP for traffic channel to the UE. The UE shall respond with a RADIO BEARER SETUP COMPLETE message. The SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

### Expected sequence

| Step | Direction |    | Message                      | Comments             |
|------|-----------|----|------------------------------|----------------------|
|      | UE        | SS |                              |                      |
| 1    |           |    | Radio Bearer Setup Procedure | (DTCH), See TS34.108 |
| 2    | <-        |    | STATUS ENQUIRY               |                      |
| 3    |           | -> | STATUS                       | cause 30#, state U3  |

### Specific message contents:

None.

### 10.1.2.4.9.5 — Test requirements

After step 1 the CC state U3, "Mobile Originating Call Proceeding", shall remain unchanged.

### 10.1.2.4.10 — Outgoing call / U3 UE originating call proceeding / timer T310 time-out

#### 10.1.2.4.10.1 — Definition

The call control entity of the UE being in the state, U3, if no response is then received from the SS, timer T310 expires at the UE side.

#### 10.1.2.4.10.2 — Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding" shall, upon expiry of timer T310, and not before, initiate call release by sending DISCONNECT and enter the CC-state U11, "Disconnect Request".

### References

—TS 24.008 clause 5.2.1.3./Abnormal case, clause 5.4.3 and clause 11.3.

#### 10.1.2.4.10.3 — Test purpose

To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding" will, upon expiry of timer T310, initiate call release by sending DISCONNECT and enter the CC-state U11, "Disconnect Request".

#### 10.1.2.4.10.4 — Method of test

### Related ICS/IXIT statements

—supported MO circuit switched basic services.

### Initial conditions

System Simulator:

—1 cell, default parameters.

User Equipment:

—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

—The UE is brought into the state U3 by using table 10.1.2/3.

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The T310 expires at the UE and the UE shall send DISCONNECT. The SS checks timer T310 accuracy and that the CC entity has entered the state U11, disconnect request.

#### Expected sequence

| Step | Direction |    | Message        | Comments                                                                                |
|------|-----------|----|----------------|-----------------------------------------------------------------------------------------|
|      | UE        | SS |                |                                                                                         |
| 1    |           | SS |                | the SS waits for T310 time-out<br>check the timer T310 accuracy<br>cause 30#, state U11 |
| 2    |           | →  | DISCONNECT     |                                                                                         |
| 3    |           | ←  | STATUS ENQUIRY |                                                                                         |
| 4    |           | →  | STATUS         |                                                                                         |

#### Specific message contents:

None.

#### 10.1.2.4.10.5 — Test requirements

Upon expiry of timer T310, a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding" shall initiate call release by sending a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

#### 10.1.2.4.11 — Outgoing call / U3 UE originating call proceeding / lower layer failure

##### 10.1.2.4.11.1 — Definition

The call control entity of the UE being in the state, U3, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated.

##### 10.1.2.4.11.2 — Conformance requirement

- 1) If a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding" has detected a lower layer failure and has returned to idle mode, the CC entity is in state U0, "Null".

#### References

—TS 24.008 clause 4.5.2.3, clause 4.5.3 and clause 5.5.3.2, TS 25.331 clause 8.3.1 and clause 8.5.6.

##### 10.1.2.4.11.3 — Test purpose

To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding" having detected a lower layer failure and having returned to idle mode, the CC entity is in state U0, "Null".

##### 10.1.2.4.11.4 — Method of test

#### Related ICS/IXIT statements

—supported MO circuit switched basic services.

### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

— The UE is brought into the state U3 by using table 10.1.2/4.

### Test procedure

An MO-circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The UE is brought to the state U3. The SS modifies the scrambling code of downlink transmission (DL DPCH) to generate a lower layer failure at the UE. The SS waits long enough to perform cell update procedure. The SS sends RRC CONNECTION RELEASE message as a response to the CELL UPDATE message from the UE. The SS re-modifies the scrambling code of downlink transmission (DL DPCH) to the original one and waits 60 s. The SS will check that the UE will not send any message during 60 s.

### Expected sequence

| Step | Direction |    | Message                               | Comments                                                                   |
|------|-----------|----|---------------------------------------|----------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                            |
| 1    |           | SS | CELL UPDATE<br>RRC CONNECTION RELEASE | SS modifies the scrambling code of DPCH for generating lower layer failure |
| 2    |           | →  |                                       | CCCH                                                                       |
| 3    |           | ←  |                                       | CCCH                                                                       |
| 4    |           | SS |                                       | SS re-modifies the scrambling code of DPCH to the original one.            |
| 5    |           | SS |                                       | SS waits 60 s.<br>UE shall send no message on DCCH                         |

### Specific message contents:

None.

#### 10.1.2.4.11.5 — Test requirements

After step 4 the UE shall not send any message to the SS during 60 s.

#### 10.1.2.4.12 — Outgoing call / U3 UE originating call proceeding / unknown message received

##### 10.1.2.4.12.1 — Definition

The call control entity of the UE being in the state, U3, an unknown message is received by the UE.

##### 10.1.2.4.12.2 — Conformance requirement

- 1) A CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding" having received an unknown message from its peer entity shall return a STATUS message.

### References

— TS 24.008 clause 8.5.



~~10.1.2.4.12.3~~ ~~Test purpose~~

~~To verify that a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding" having received an unknown message from its peer entity returns a STATUS message.~~

~~10.1.2.4.12.4~~ ~~Method of test~~

~~Related ICS/IXIT statements~~

~~—supported MO circuit switched basic services.~~

~~Initial conditions~~

~~System Simulator:~~

~~—1 cell, default parameters.~~

~~User Equipment:~~

~~—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~—The UE is brought into the state U3 by using table 10.1.2/1.~~

~~Test procedure~~

~~An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U3. The SS sends a message with message type not defined for the protocol discriminator to the UE. The UE shall respond with a STATUS message, and finally the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.~~

~~Expected sequence~~

| Step | Direction |    | Message         | Comments                        |
|------|-----------|----|-----------------|---------------------------------|
|      | UE        | SS |                 |                                 |
| 1    |           | <  | unknown message | message type not defined for PD |
| 2    |           | >  | STATUS          | cause 97#, state U3             |
| 3    |           | <  | STATUS ENQUIRY  |                                 |
| 4    |           | >  | STATUS          | cause 30#, state U3             |

~~Specific message contents:~~

~~None.~~

~~10.1.2.4.12.5~~ ~~Test requirements~~

~~After step 1 a CC-entity of the UE in CC-state U3, "Mobile Originating Call Proceeding", shall return a STATUS message.~~

~~10.1.2.4.13~~ ~~Outgoing call / U3 UE originating call proceeding / Internal alerting indication~~

~~10.1.2.4.13.1~~ ~~Definition~~

~~The call control entity of the UE being in the state, U3, an ALERTING message is sent to the UE when the user connection is not attached to the radio path.~~

**10.1.2.4.13.2** Conformance requirement

- 1) When the call control entity of the UE in the "mobile originating call proceeding" state receives an ALERTING message then it shall enter "call delivered" state and, for speech calls, if the user connection is not attached to the radio path, the UE shall internally generate an alerting indication.

**References**

- TS 24.008 clause 5.2.1.5.

**10.1.2.4.13.3** Test purpose

When the call control entity of the UE in the "mobile originating call proceeding" state receives an ALERTING message then it enters "call delivered" state and, for speech calls, if the user connection is not attached to the radio path, the UE generates internally an alerting indication.

**10.1.2.4.13.4** Method of test**Related ICS/IXIT statements**

- supported MO circuit-switched basic services.
- way to give internally generated alerting indication for outgoing calls.

**Initial conditions**

System Simulator:

- 1 cell, default parameters.

User Equipment:

- The UE is in MM-state "idle, updated" with valid TMSI and CKSN.
- The UE is brought into the state U3 by using table 10.1.2/1.

**Test procedure**

The SS sends an ALERTING message to the UE. The SS checks by using the status enquiry procedure that the CC entity has entered the state U4, call delivered. Also it is checked that the UE generates internally alerting indication to the user in the way described in the ICS/IXIT statements.

**Expected sequence**

| Step | Direction |    | Message        | Comments                                                                                                                        |
|------|-----------|----|----------------|---------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                |                                                                                                                                 |
| 1    |           | <- | ALERTING       | the UE shall generate an alerting indication to the user in the way described in the ICS/IXIT statements<br>cause 30#, state U4 |
| 2    |           | <- | STATUS ENQUIRY |                                                                                                                                 |
| 3    |           | -> | STATUS         |                                                                                                                                 |

Specific message contents:

None.

**10.1.2.4.13.5** Test requirements

After step 1 CC entity of the UE in CC state U3, the "Mobile Originating Call Proceeding" shall enter "Call Delivered" state and, for speech calls, if the user connection is not attached to the radio path, the UE shall internally generate an alerting indication.

~~10.1.2.5 Outgoing call / U4 call delivered~~

~~10.1.2.5.1 Outgoing call / U4 call delivered / CONNECT received~~

~~10.1.2.5.1.1 Definition~~

~~The call control entity of the UE being in the state, U4, a CONNECT message is received by the UE.~~

~~10.1.2.5.1.2 Conformance requirement~~

- ~~1) A CC-entity of the UE in CC-state U4, "Call Delivered", upon receipt of the CONNECT message shall return a CONNECT ACKNOWLEDGE to its peer entity and enter the CC-state U10, "Active".~~

~~References~~

~~—TS 24.008 clause 5.2.1.6.~~

~~10.1.2.5.1.3 Test purpose~~

~~To verify that a CC-entity of the UE in CC-state U4, "Call Delivered", upon receipt of the CONNECT message returns a CONNECT ACKNOWLEDGE to its peer entity and enters the CC-state U10, "Active".~~

~~10.1.2.5.1.4 Method of test~~

~~Related ICS/IXIT statements~~

~~—supported MO circuit switched basic services.~~

~~Initial conditions~~

~~System Simulator:~~

~~—1 cell, default parameters.~~

~~User Equipment:~~

~~—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~—The UE is brought into the state U4 by using table 10.1.2/3.~~

~~Test procedure~~

~~An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U4. The SS sends a CONNECT message to the UE. The UE shall respond by sending a CONNECT ACKNOWLEDGE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U10, active.~~

~~Expected sequence~~

| Step | Direction |    | Message             | Comments                                                 |
|------|-----------|----|---------------------|----------------------------------------------------------|
|      | UE        | SS |                     |                                                          |
| 1    |           | <  | CONNECT             | UE stops alerting, if applicable<br>cause 30#, state U10 |
| 2    |           | >  | CONNECT ACKNOWLEDGE |                                                          |
| 3    |           | <  | STATUS ENQUIRY      |                                                          |
| 4    |           | >  | STATUS              |                                                          |

~~Specific message contents:~~

~~None.~~

~~10.1.2.5.1.5 Test requirements~~

~~After step 1 a CC entity of the UE in CC state U4, "Call Delivered", shall return a CONNECT ACKNOWLEDGE message and enter the CC state U10, "Active".~~

~~10.1.2.5.2 Outgoing call / U4 call delivered / termination requested by the user~~~~10.1.2.5.2.1 Definition~~

~~The call control entity of the UE being in the state, U4, the user requests to terminate the call.~~

~~10.1.2.5.2.2 Conformance requirement~~

- ~~1) A CC entity of the UE in CC state U4, "Call Delivered", upon request by the user to terminate shall send a DISCONNECT message and enter the CC state U11, "Disconnect Request".~~

## References

~~— TS 24.007 clause 6.2.2, TS 24.008 clause 5.4.3.~~

~~10.1.2.5.2.3 Test purpose~~

~~To verify that a CC entity of the UE in CC state U4, "Call Delivered", upon request by the user to terminate will send a DISCONNECT message and enter the CC state U11, "Disconnect Request".~~

~~10.1.2.5.2.4 Method of test~~

## Related ICS/IXIT statements

~~— supported MO circuit switched basic services.~~

## Initial conditions

System Simulator:

~~— 1 cell, default parameters.~~

User Equipment:

~~— The UE is in MM state "idle, updated" with valid TMSI and CKSN.~~

~~— The UE is brought into the state U4 by using table 10.1.2/3.~~

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U4. The user requests termination of the call. The UE shall send a DISCONNECT message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U11, disconnect request.

## Expected sequence

| Step | Direction |    | Message        | Comments                                               |
|------|-----------|----|----------------|--------------------------------------------------------|
|      | UE        | SS |                |                                                        |
| 1    |           |    |                | MMI action, terminate call<br><br>cause 30#, state U11 |
| 2    |           | -> | DISCONNECT     |                                                        |
| 3    |           | <- | STATUS-ENQUIRY |                                                        |
| 4    |           | -> | STATUS         |                                                        |

Specific message contents:

None.

#### ~~10.1.2.5.2.5~~ ~~Test requirements~~

~~After step 1 a CC entity of the UE in CC state U4, "Call Delivered", shall send a DISCONNECT message and enter the CC state U11, "Disconnect Request".~~

#### ~~10.1.2.5.3~~ ~~Outgoing call / U4 call delivered / DISCONNECT with in band tones~~

##### ~~10.1.2.5.3.1~~ ~~Definition~~

~~The call control entity of the UE being in the state, U4, a DISCONNECT message indicating availability of in-band information is received by the UE.~~

##### ~~10.1.2.5.3.2~~ ~~Conformance requirement~~

- ~~1) A CC entity of the UE in CC state U4, "Call Delivered" shall, upon receipt of a DISCONNECT with a progress indicator indicating in-band information, shall through-connect the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE shall send a RELEASE message.~~

#### References

~~— TS 25.331 clause 8.2.1., TS 24.008 clause 5.4.4.1.1, clause 5.5.1 and clause 5.2.1.9.~~

#### ~~10.1.2.5.3.3~~ ~~Test purpose~~

~~To verify that a CC entity of the UE in CC state U4, "Call Delivered", upon receipt of a DISCONNECT with a progress indicator indicating in-band information, through-connects the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE shall send a RELEASE message.~~

#### ~~10.1.2.5.3.4~~ ~~Method of test~~

#### Related ICS/IXIT statements

~~— supported MO circuit switched basic services.~~

#### Initial conditions

System Simulator:

~~— 1 cell, default parameters.~~

User Equipment:

~~— The UE is in MM state "idle, updated" with valid TMSI and CKSN.~~

~~— The UE is brought into the state U4 by using table 10.1.2/3.~~

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U4. The SS sends a DISCONNECT message containing indication of in-band information availability to the UE. The SS checks that if channel mode is MO telephony, the DTCH shall be through connected and the UE enters state U12, disconnect indication. If channel mode is not speech, the DTCH shall not be through connected and the UE shall enter state U19, release request.

## Expected sequence

| Step | Direction |    | Message        | Comments                                                                                        |
|------|-----------|----|----------------|-------------------------------------------------------------------------------------------------|
|      | UE        | SS |                |                                                                                                 |
| 1    | <-        |    | DISCONNECT     | (note)                                                                                          |
| A2   | SS        |    |                | DTCH in speech mode:<br>the SS will check that the audio path for<br>in-band tones is attached. |
| A3   | <-        |    | STATUS ENQUIRY |                                                                                                 |
| A4   | ->        |    | STATUS         | cause 30#, state U12                                                                            |
| B2   | ->        |    | RELEASE        | DTCH is not in speech mode:                                                                     |
| B3   | <-        |    | STATUS ENQUIRY |                                                                                                 |
| B4   | ->        |    | STATUS         | cause 30#, state U19                                                                            |

## Specific message contents:

NOTE: — the Progress Indicator, Progress Description:

— #8 in-band information or appropriate pattern now available.

## 10.1.2.5.3.5 — Test requirements

After step 1 a CC-entity of the UE in CC-state U4, "Call-Delivered", shall through-connect the speech-channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE shall send a RELEASE message.

## 10.1.2.5.4 — Outgoing call / U4 call delivered / DISCONNECT without in-band tones

## 10.1.2.5.4.1 — Definition

The call-control entity of the UE being in the state, U4, a DISCONNECT message is received by the UE. The DISCONNECT message does not contain indication of in-band information availability.

## 10.1.2.5.4.2 — Conformance requirement

- 1) A CC-entity of the UE in CC-state U4, "Call-Delivered", upon receipt of a DISCONNECT without progress indicator, shall return a RELEASE message and enter the CC-state U19, "Release Request".

## References

— TS 24.008 clause 5.4.4.

## 10.1.2.5.4.3 — Test purpose

To verify that a CC-entity of the UE in CC-state U4, "Call-Delivered", upon receipt of a DISCONNECT without progress indicator, returns a RELEASE message and enters the CC-state U19, "Release Request".

## 10.1.2.5.4.4 — Method of test

## Related ICS/IXIT statements

— supported MO circuit-switched basic services.

## Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

—The UE is brought into the state U4 by using table 10.1.2/3.

### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U4. The SS sends a DISCONNECT message not containing indication of in-band information availability to the UE. The UE shall respond with a RELEASE message. The SS checks by using the status enquiry procedure that the CC entity of the UE has entered the state U19, release request.

### Expected sequence

| Step | Direction |    | Message        | Comments                                               |
|------|-----------|----|----------------|--------------------------------------------------------|
|      | UE        | SS |                |                                                        |
| 1    |           | <  | DISCONNECT     | without progress indicator<br><br>cause 30#, state U19 |
| 2    |           | >  | RELEASE        |                                                        |
| 3    |           | <  | STATUS ENQUIRY |                                                        |
| 4    |           | >  | STATUS         |                                                        |

### Specific message contents:

None.

### 10.1.2.5.4.5 — Test requirements

After step 1 a CC entity of the UE in CC-state U4, "Call Delivered", shall return a RELEASE message and enter the CC-state U19, "Release Request".

### 10.1.2.5.5 — Outgoing call / U4 call delivered / RELEASE received

#### 10.1.2.5.5.1 — Definition

The call control entity of the UE being in the state, U4, a RELEASE message is received by the UE.

#### 10.1.2.5.5.2 — Conformance requirement

- 1) A CC entity of the UE in CC-state U4, "Call Delivered", upon receipt of the RELEASE message shall respond with the RELEASE COMPLETE message and enter the CC-state U0, "Null".
- 2) The UE on returning to idle mode shall release the MM-connection and the CC-entities relating to the seven mobile originating transaction identifiers shall be in CC-state U0, "Null".

### References

Conformance requirement 1: —TS 24.008 clause 5.4.2 and clause 5.4.4.

Conformance requirement 2: —TS 24.008 clause 4.5.3 and clause 5.5.3.2.

### 10.1.2.5.5.3 — Test purpose

- 1) To verify that a CC entity of the UE in CC-state U4, "Call Delivered", upon receipt of the RELEASE message will respond with the RELEASE COMPLETE message and enter the CC-state U0, "Null".
- 2) To verify that the UE on returning the idle mode releases the MM-connection and that the CC-entities relating to the seven mobile originating transaction identifiers are in CC-state U0, "Null".

#### 10.1.2.5.5.4 Method of test

##### Related ICS/IXIT statements

—supported MO circuit-switched basic services.

##### Initial conditions

System Simulator:

—1 cell, default parameters.

User Equipment:

—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

—The UE is brought into the state U4 by using table 10.1.2/3.

##### Test procedure

An MO circuit-switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U4. The SS sends a RELEASE message to the UE. The UE shall respond with a RELEASE COMPLETE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

##### Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                      |
|------|-----------|----|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                               |
| 1    |           | <  | RELEASE                         | with cause "Normal, unspecified"                                                                                                                              |
| 2    |           | >  | RELEASE COMPLETE                |                                                                                                                                                               |
| 3    |           | <  | STATUS ENQUIRY                  |                                                                                                                                                               |
| 4    |           | >  | RELEASE COMPLETE                |                                                                                                                                                               |
| 5    |           | SS |                                 |                                                                                                                                                               |
| 6    |           | <  | RRC CONNECTION RELEASE          | cause 81# (invalid TI value)<br>repeat steps 3-4 to cover all the<br>transaction identifiers from 000...110<br>the main signalling link shall be<br>released. |
| 7    |           | >  | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                               |

##### Specific message contents:

None.

#### 10.1.2.5.5.5 Test requirements

After step 1 a CC entity of the UE in CC-state U4, "Call Delivered", shall respond with the RELEASE COMPLETE message.

After step 3 CC entities relating to all mobile-originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.2.5.6 Outgoing call / U4 call delivered / lower layer failure

##### 10.1.2.5.6.1 Definition

The call control entity of the UE being in the state, U4, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated.



~~10.1.2.5.6.2 Conformance requirement~~

- ~~1) When CC-entity of the UE in CC-state U4, "Call Delivered" has detected a lower layer failure and has returned to idle mode, the CC-entity is in CC-state U0, "Null".~~

~~References~~

~~— TS 24.008 clause 4.5.2.3, clause 4.5.3 and clause 5.5.3.2., TS 25.331 clause 8.3.1 and clause 8.5.6.~~

~~10.1.2.5.6.3 Test purpose~~

~~To verify that a CC-entity of the UE in CC-state U4, "Call Delivered" having detected a lower layer failure and has returned to idle mode, the CC-entity is in CC-state U0, "Null".~~

~~10.1.2.5.6.4 Method of test~~~~Related ICS/IXIT statements~~

~~— supported MO circuit switched basic services.~~

~~Initial conditions~~

~~System Simulator:~~

~~— 1 cell, default parameters.~~

~~User Equipment:~~

~~— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~— The UE is brought into the state U4 by using table 10.1.2/3.~~

~~Test procedure~~

~~An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The UE is brought to the state U4. The SS modifies the scrambling code of downlink transmission (DL DPCH) to generate a lower layer failure at the UE. The SS waits long enough to perform cell update procedure. The SS sends RRC CONNECTION RELEASE message as a response to the CELL UPDATE message from the UE. The SS re-modifies the scrambling code of downlink transmission (DL DPCH) to the original one and waits 60 s. The SS will check that the UE will not send any message during 60 s.~~

~~Expected sequence~~

| Step | Direction |    | Message                               | Comments                                                                   |
|------|-----------|----|---------------------------------------|----------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                            |
| 1    |           | SS | CELL UPDATE<br>RRC CONNECTION RELEASE | SS modifies the scrambling code of DPCH for generating lower layer failure |
| 2    | ->        |    |                                       | CCCH                                                                       |
| 3    | <         |    |                                       | CCCH                                                                       |
| 4    |           | SS |                                       | SS re-modifies the scrambling code of DPCH to the original one.            |
| 5    |           | SS |                                       | SS waits 60 s.<br>UE shall send no message on the DCCH                     |

~~Specific message contents:~~

~~None.~~

~~10.1.2.5.6.5 — Test requirements~~

~~After step 4 the UE shall not send any message to the SS during 60 s.~~

~~10.1.2.5.7 — Outgoing call / U4 call delivered / traffic channel allocation~~~~10.1.2.5.7.1 — Definition~~

~~The call control entity of the UE being in the state, U4, a radio bearer establishment procedure is performed.~~

~~10.1.2.5.7.2 — Conformance requirement~~

- ~~1) A CC-entity of the UE in CC-state U4, "Call Delivered", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, shall stay in CC-state U4.~~

## References

~~— TS 25.331 clause 8.2.1., TS 24.008 clause 5.2.1.9.~~

~~10.1.2.5.7.3 — Test purpose~~

~~To verify that a CC-entity of the UE in CC-state U4, "Call Delivered", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, stays in CC-state U4.~~

~~10.1.2.5.7.4 — Method of test~~

## Related ICS/IXIT statements

~~— supported MO circuit switched basic services.~~

## Initial conditions

System Simulator:

~~— 1 cell, default parameters.~~

User Equipment:

~~— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~— The UE is brought into the state U4 by using table 10.1.2/1.~~

## Test procedure

~~An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U4. The SS sends a RADIO BEARER SETUP for traffic channel to the UE. The UE shall respond with a RADIO BEARER SETUP COMPLETE message. The SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.~~

## Expected sequence

| Step | Direction |    | Message                      | Comments            |
|------|-----------|----|------------------------------|---------------------|
|      | UE        | SS |                              |                     |
| 1    |           |    | Radio Bearer Setup Procedure | DTCH, See TS34.108  |
| 2    | <-        |    | STATUS ENQUIRY               |                     |
| 3    |           | -> | STATUS                       | cause 30#, state U4 |

Specific message contents:

None.

#### ~~10.1.2.5.7.5~~ ~~Test requirements~~

~~After step 1 the CC state U4, "Call delivered", shall remain unchanged.~~

#### ~~10.1.2.5.8~~ ~~Outgoing call / U4 call delivered / unknown message received~~

##### ~~10.1.2.5.8.1~~ ~~Definition~~

~~The call control entity of the UE being in the state, U4, an unknown message is received by the UE.~~

##### ~~10.1.2.5.8.2~~ ~~Conformance requirement~~

- ~~1) A CC entity of the UE in CC state U4, "Call Delivered", having received an unknown message from its peer entity shall return a STATUS message.~~

#### References

~~—TS 24.008 clause 8.4.~~

##### ~~10.1.2.5.8.3~~ ~~Test purpose~~

~~To verify that a CC entity of the UE in CC state U4, "Call Delivered", having received an unknown message from its peer entity returns a STATUS message.~~

##### ~~10.1.2.5.8.4~~ ~~Method of test~~

#### Related ICS/IXIT statements

~~—supported MO circuit switched basic services.~~

#### Initial conditions

System Simulator:

~~—1 cell, default parameters.~~

User Equipment:

~~—The UE is in MM state "idle, updated" with valid TMSI and CKSN.~~

~~—The UE is brought into the state U4 by using table 10.1.2/4.~~

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U4. The SS sends a message with message type not defined for the protocol discriminator to the UE. The UE shall respond with a STATUS message, and finally the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

## Expected sequence

| Step | Direction |    | Message         | Comments                        |
|------|-----------|----|-----------------|---------------------------------|
|      | UE        | SS |                 |                                 |
| 1    | <         |    | unknown message | message type not defined for PD |
| 2    | >         |    | STATUS          | cause 97#, state U4             |
| 3    | <         |    | STATUS ENQUIRY  |                                 |
| 4    | >         |    | STATUS          | cause 30#, state U4             |

## Specific message contents:

None.

## 10.1.2.5.8.5 — Test requirements

After step 1 a CC entity of the UE in CC state U3, "Mobile Originating Call Proceeding", shall return a STATUS message.

## 10.1.2.6 — U10 call active

## 10.1.2.6.1 — U10 call active / termination requested by the user

## 10.1.2.6.1.1 — Definition

The call control entity of the UE being in the state, U10, the user requests to terminate the call.

## 10.1.2.6.1.2 — Conformance requirement

- 1) A CC entity of the UE in CC state U10, "Call Active", upon request by the user to terminate shall send a DISCONNECT message and enter the CC state U11, "Disconnect Request".

## References

— TS 24.007 clause 6.2.2, TS 24.008 clause 5.4.3.

## 10.1.2.6.1.3 — Test purpose

To verify that the a CC entity of the UE in CC state U10, "Call Active", upon request by the user to terminate will send a DISCONNECT message and enter the CC state U11, "Disconnect Request".

## 10.1.2.6.1.4 — Method of test

## Related ICS/IXIT statements

— supported MO circuit switched basic services.

## Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in MM state "idle, updated" with valid TMSI and CKSN.

— The UE is brought into the state U10 by using table 10.1.2/1.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U10. The user requests termination of the call. The UE shall send a DISCONNECT message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U11, disconnect request.

## Expected sequence

| Step | Direction |    | Message        | Comments                   |
|------|-----------|----|----------------|----------------------------|
|      | UE        | SS |                |                            |
| 1    |           |    |                |                            |
| 2    |           | →  | DISCONNECT     | MMI action, terminate call |
| 3    |           | ←  | STATUS ENQUIRY | U11                        |
| 4    |           | →  | STATUS         | cause 30#, state U11       |

## Specific message contents:

None.

## 10.1.2.6.1.5 — Test requirements

After step 1 a CC entity of the UE in CC state U10, "Call Active", shall send a DISCONNECT message and enter the CC state U11, "Disconnect Request".

## 10.1.2.6.2 — U10 call active / RELEASE received

### 10.1.2.6.2.1 — Definition

The call control entity of the UE being in the state, U10, a RELEASE message is received by the UE.

### 10.1.2.6.2.2 — Conformance requirement

- 1) A CC-entity of the UE in CC-state U10, "Call Active", upon receipt of the RELEASE shall respond with the RELEASE COMPLETE message and enter the CC-state U0, "Null"
- 2) When the UE returns to the idle mode it shall release the MM-connection and the CC-entities relating to the seven mobile originating transaction identifiers shall be in CC-state U0, "Null"

## References

Conformance requirement 1: — TS 24.008 clause 5.4.2 and clause 5.4.4.

Conformance requirement 2: — TS 24.008 clause 4.5.3 and clause 5.5.3.2.

### 10.1.2.6.2.3 — Test purpose

- 1) To verify that the a CC-entity of the UE in CC-state U10, "Call Active", upon receive of the RELEASE will respond with the RELEASE COMPLETE message and enter the CC-state U0, "Null"
- 2) To verify that the UE on returning to the idle mode releases the MM-connection and that the CC-entities relating to the seven mobile originating transaction identifiers are in CC-state U0, "Null"

### 10.1.2.6.2.4 — Method of test

## Related ICS/IXIT statements

— supported MO circuit switched basic services.

**Initial conditions**

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

— The UE is brought into the state U10 by using table 10.1.2/1.

**Test procedure**

An MO-circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U10. The SS sends a RELEASE message to the UE. The UE shall respond with a RELEASE COMPLETE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

**Expected sequence**

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                     |
|------|-----------|----|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                              |
| 1    |           | <  | RELEASE                         | with cause "Normal, unspecified"<br>the UE starts T3240<br><br>cause 81# (invalid TI value)<br>repeat steps 3-4 to cover all the<br>transaction identifiers from 000...110<br>the main signalling link shall be<br>released. |
| 2    |           | >  | RELEASE COMPLETE                |                                                                                                                                                                                                                              |
| 3    |           | <  | STATUS ENQUIRY                  |                                                                                                                                                                                                                              |
| 4    |           | >  | RELEASE COMPLETE                |                                                                                                                                                                                                                              |
| 5    |           | SS |                                 |                                                                                                                                                                                                                              |
| 6    |           | <  | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                              |
| 7    |           | >  | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                              |

Specific message contents:

None.

**10.1.2.6.2.5 — Test requirements**

After step 1 a CC entity of the UE in CC state U10, "Call Active", shall return a RELEASE COMPLETE message.

After step 3 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

**10.1.2.6.3 — U10 call active / DISCONNECT with in band tones****10.1.2.6.3.1 — Definition**

The call control entity of the UE being in the state, U10, a DISCONNECT message indicating availability of in band information is received by the UE.

### 10.1.2.6.3.2 ~~Conformance requirement~~

- 1) ~~A CC entity of the UE in CC state U10, "Call Active", upon receipt of a DISCONNECT message with a Progress Indicator indicating in-band information, shall through-connect the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE shall send a RELEASE message.~~

### References

~~— TS 24.008 clause 5.4.4.1.1 and clause 5.5.1.~~

### 10.1.2.6.3.3 ~~Test purpose~~

~~To verify that a CC entity of the UE in CC state U10, "Call Active", upon receipt of a DISCONNECT message with a Progress Indicator indicating in-band information, through-connects the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE sends a RELEASE message.~~

### 10.1.2.6.3.4 ~~Method of test~~

### Related ICS/IXIT statements

~~— supported MO circuit switched basic services.~~

### Initial conditions

System Simulator:

~~— 1 cell, default parameters.~~

User Equipment:

~~— The UE is in MM state "idle, updated" with valid TMSI and CKSN.~~

~~— The UE is brought into the state U10 by using table 10.1.2/1.~~

### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U10. The SS sends a DISCONNECT message containing indication of in-band information availability to the UE. The SS checks that if channel mode is speech, the DTCH shall be through connected and the UE enters state U12, disconnect indication. If channel mode is not speech, the DTCH shall not be through-connected and the UE enters state U19, release request.

### Expected sequence

| Step | Direction |    | Message                             | Comments                                                                                        |
|------|-----------|----|-------------------------------------|-------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                     |                                                                                                 |
| 1    | <         |    | DISCONNECT                          | (note)                                                                                          |
| A2   |           | SS | STATUS ENQUIRY<br>STATUS            | DTCH in speech mode:<br>the SS will check that the audio path for<br>in-band tones is attached. |
| A3   | <         |    |                                     | cause 30#, state U12                                                                            |
| A4   | >         |    |                                     |                                                                                                 |
| B2   |           |    | RELEASE<br>STATUS ENQUIRY<br>STATUS | DTCH is not in speech mode:                                                                     |
| B3   | <         |    |                                     | cause 30#, state U19                                                                            |
| B4   | >         |    |                                     |                                                                                                 |

### Specific message contents:

NOTE: ~~the Progress Indicator, Progress Description:~~

~~#8 in band information or appropriate pattern now available.~~

#### ~~10.1.2.6.3.5 Test requirements~~

~~After step 1 a CC-entity of the UE in CC-state U10, "Call Active", shall through-connect the speech channel to make in-band announcements available, if traffic channel is in speech mode. If DTCH is not in speech mode, the UE shall send a RELEASE message.~~

#### ~~10.1.2.6.4 U10 call active / DISCONNECT without in band tones~~

##### ~~10.1.2.6.4.1 Definition~~

~~The call control entity of the UE being in the state, U10, a DISCONNECT message is received by the UE. The DISCONNECT message does not contain indication of in-band information availability.~~

##### ~~10.1.2.6.4.2 Conformance requirement~~

- ~~1) A CC-entity of the UE in CC-state U10, "Call Active", upon receipt of a DISCONNECT message without progress indicator, shall return a RELEASE message and enter the CC-state U19, "Release Request".~~

### References

~~—TS 24.008 clause 5.4.4.~~

#### ~~10.1.2.6.4.3 Test purpose~~

~~To verify that the a CC-entity of the UE in CC-state U10, "Call Active", upon receipt of a DISCONNECT message without progress indicator, returns a RELEASE message and enters the CC-state U19, "Release Request".~~

#### ~~10.1.2.6.4.4 Method of test~~

### Related ICS/IXIT statements

~~—supported MO circuit switched basic services.~~

### Initial conditions

System Simulator:

~~—1 cell, default parameters.~~

User Equipment:

~~—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~—The UE is brought into the state U10 by using table 10.1.2/1.~~

### Test procedure

~~An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U10. The SS sends a DISCONNECT message not containing indication of in-band information availability to the UE. The UE shall respond with a RELEASE message. The SS checks by using the status enquiry procedure that the CC entity of the UE has entered the state U19, release request.~~



## Expected sequence

| Step | Direction |    | Message        | Comments                                               |
|------|-----------|----|----------------|--------------------------------------------------------|
|      | UE        | SS |                |                                                        |
| 1    | <         |    | DISCONNECT     | without progress indicator<br><br>cause 30#, state U19 |
| 2    | >         |    | RELEASE        |                                                        |
| 3    | <         |    | STATUS ENQUIRY |                                                        |
| 4    | >         |    | STATUS         |                                                        |

## Specific message contents:

None.

## 10.1.2.6.4.5 — Test requirements

A CC entity of the UE in CC-state U10, "Call Active", shall return a RELEASE message and enter the CC-state U19, "Release Request".

## 10.1.2.6.5 — U10 call active / RELEASE COMPLETE received

## 10.1.2.6.5.1 — Definition

The call control entity of the UE being in the state, U10, the call is cleared by a RELEASE COMPLETE message sent by the SS.

## 10.1.2.6.5.2 — Conformance requirement

- 1) A CC entity of the UE in CC-state U10, "active", upon receipt of a RELEASE COMPLETE message with valid cause value, shall enter CC state U0, "Null".
- 2) On returning to idle mode, the CC entities relating to the seven mobile originating transaction identifiers shall be in state U0, "Null".

## References

Conformance requirement 1: — TS 24.008 clause 5.4.2 and clause 5.4.4.

Conformance requirement 2: — TS 24.008 clause 5.4.4.1.3.

## 10.1.2.6.5.3 — Test purpose

- 1) To verify that a CC entity of the UE in CC-state U10, "Call active" upon receipt of a RELEASE COMPLETE message with valid cause value, enters CC state U0, "Null".
- 2) To verify that in returning to idle mode, the CC entities relating to the seven mobile originating transaction identifiers are in state U0, "Null".

## 10.1.2.6.5.4 — Method of test

## Related ICS/IXIT statements

— supported MO circuit-switched basic services.

## Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

—The UE is brought into the state U10 by using table 10.1.2/1.

### Test procedure

The SS sends a RELEASE COMPLETE message to the UE. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

### Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                     |
|------|-----------|----|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                              |
| 1    |           | <- | RELEASE COMPLETE                | note 1<br>note 2<br>cause 81# (invalid TI value);<br>repeat steps 2-3 to cover all the transaction identifiers from 000...110<br>the main signalling link shall be released. |
| 2    |           | <- | STATUS ENQUIRY                  |                                                                                                                                                                              |
| 3    |           | -> | RELEASE COMPLETE                |                                                                                                                                                                              |
| 4    |           | SS |                                 |                                                                                                                                                                              |
| 5    |           | <- | RRC CONNECTION RELEASE          |                                                                                                                                                                              |
| 6    |           | -> | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                              |

### Specific message contents:

NOTE 1: With the cause value chosen arbitrarily.

NOTE 2: TI flag has the value indicating the UE as a originator of the call.

### 10.1.2.6.5 — Test requirements

After step 2 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

### 10.1.2.6.6 — U10 call active / SETUP received

#### 10.1.2.6.6.1 — Definition

If the UE does not react correctly when receiving a SETUP message on a new Transaction Identifier during an active call, the active call may be lost.

#### 10.1.2.6.6.2 — Conformance requirement

- 1) A UE that has a call established when receiving a SETUP message shall respond either with a CALL CONFIRMED message or a RELEASE COMPLETE message, both with cause #17 "user busy".
- 2) The call control state of the existing transaction shall not be affected by the incoming SETUP message.

### Reference(s):

Conformance requirement 1: —TS 24.008 clause 5.2.2.3.1.

Conformance requirement 2: —TS 24.008 clause 5.1.1.

#### 10.1.2.6.6.3 — Test purpose

- 1) To verify that a User Equipment that has a call established and receives a SETUP message answers either with a CALL CONFIRMED message with cause "user busy" if it supports call waiting, or with a RELEASE COMPLETE message with cause "user busy" otherwise.
- 2) To verify that after having sent this message, the UE is still in state U10 for the established call.

#### 10.1.2.6.6.4 Method of test

##### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is idle updated with valid TMSI and CKSN.

— The UE is brought into the state U10 by using table 10.1.2/1.

##### Related ICS/IXIT statement(s)

— supported MO circuit switched basic services.

— support of call waiting Y/N.

##### Test Procedure

The UE has a mobile originated call in the U10 state. When UE sends a SETUP message and SS receives it in the first call establishment, SS sends a CALL PROCEEDING message without Network Call Control Capability IE.

The SS sends a SETUP message to the UE (with signal IE indicating "call waiting tone on" and without Network Call Control Capability IE).

If the UE does not support call waiting it shall answer by a RELEASE COMPLETE message.

If the UE supports call waiting it shall answer by a CALL CONFIRMED message followed by an ALERTING. The second transaction is then released by the SS with a RELEASE COMPLETE message.

In both cases the SS checks by using the status enquiry procedure that the CC entity of the UE is still in state U10, active call for the original call.

##### Expected sequence

| Step | Direction |    | Message          | Comments                                                                                                                                                                           |
|------|-----------|----|------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                  |                                                                                                                                                                                    |
| 1    |           | <- | SETUP            | this message establishes a second transaction The TI value shall be the same as the one that is in use for the MO call. The TI flag shall have the value specified for an MT call. |
| A2   |           | -> | RELEASE COMPLETE | if the UE does not support call waiting with cause user busy" with the TI of the second transaction                                                                                |
| B2   |           | -> | CALL CONFIRMED   | if the UE supports call waiting with cause user busy" with the TI of the second transaction                                                                                        |
| B3   |           | -> | ALERTING         | with the TI of the second transaction                                                                                                                                              |
| B4   |           | <- | RELEASE COMPLETE | with the TI of the second transaction                                                                                                                                              |
| 5    |           | <- | STATUS ENQUIRY   | with the TI of the original transaction                                                                                                                                            |
| 6    |           | -> | STATUS           | cause 30#, state U10 with the TI of the original transaction                                                                                                                       |

NOTE:—The Transaction Identifier of the second transaction shall be different from the one of the already established transaction.

##### Specific message contents

SETUP message contains a Signal IE with value "call waiting tone on" (H07).

#### ~~10.1.2.6.6.5 ——— Test requirements~~

~~After step 1 a UE that has a call established shall answer either with a CALL CONFIRMED message with cause "user busy" if it supports call waiting, or with a RELEASE COMPLETE message with cause "user busy" otherwise.~~

~~After step A2 or B2 the UE is still in state U10 for the established call.~~

#### ~~10.1.2.7 ——— U11 disconnect request~~

##### ~~10.1.2.7.1 ——— U11 disconnect request / clear collision~~

###### ~~10.1.2.7.1.1 ——— Definition~~

~~The call control entity of the UE being in the state, U11, a DISCONNECT message is received by the UE.~~

###### ~~10.1.2.7.1.2 ——— Conformance requirement~~

- ~~1) A CC entity of the UE in CC-state U11, "Disconnect Request", upon receipt of a DISCONNECT message, shall return to its peer entity the RELEASE message and enter the CC-state U19, "Release Request".~~

#### References

- ~~—— TS 24.008 clause 5.4.4.2.5.1.~~

##### ~~10.1.2.7.1.3 ——— Test purpose~~

~~To verify that the a CC entity of the UE in CC-state U11, "Disconnect Request", upon receipt of a DISCONNECT message, returns to its peer entity the RELEASE message and enters the CC-state U19, "Release Request".~~

##### ~~10.1.2.7.1.4 ——— Method of test~~

#### Related ICS/IXIT statements

- ~~—— supported MO circuit switched basic services.~~

#### Initial conditions

System Simulator:

- ~~—— 1 cell, default parameters.~~

User Equipment:

- ~~—— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~
- ~~—— The UE is brought into the state U11 by using table 10.1.2/3.~~

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U11. The SS sends a DISCONNECT message to the UE. The UE shall respond with a RELEASE message. The SS checks by using the status enquiry procedure that the CC entity of the UE has entered the state U19, release request.

## Expected sequence

| Step | Direction |    | Message        | Comments             |
|------|-----------|----|----------------|----------------------|
|      | UE        | SS |                |                      |
| 1    | <         |    | DISCONNECT     | cause 30#, state U19 |
| 2    | >         |    | RELEASE        |                      |
| 3    | <         |    | STATUS ENQUIRY |                      |
| 4    | >         |    | STATUS         |                      |

## Specific message contents:

None.

## 10.1.2.7.1.5 — Test requirements

After step 1 a CC-entity of the UE in CC-state U11, "Disconnect Request", shall return the RELEASE message and enter the CC-state U19, "Release Request".

## 10.1.2.7.2 — U11 disconnect request / RELEASE received

## 10.1.2.7.2.1 — Definition

The call control entity of the UE being in the state, U11, a RELEASE message is received by the UE.

## 10.1.2.7.2.2 — Conformance requirement

- 1) A CC-entity of the UE in CC-state U11, "Disconnect Request", upon receipt of the RELEASE message shall return RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) On returning to the idle mode the UE shall release the MM-connection and the CC-entities relating to the seven mobile-originating transaction identifiers shall be in CC-state U0, "Null".

## References

Conformance requirement 1: — TS 24.008 clause 5.4.3.

Conformance requirement 2: — TS 24.008 clause 4.5.3, clause 5.5.3.2 and clause 8.3.

## 10.1.2.7.2.3 — Test purpose

- 1) To verify that the a CC-entity of the UE in CC-state U11, "Disconnect Request", upon receipt of the RELEASE message shall return RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) To verify that the UE on returning to the idle mode releases the MM-connection and that the CC-entities relating to the seven mobile-originating transaction identifiers are in CC-state U0, "Null".

## 10.1.2.7.2.4 — Method of test

## Related ICS/IXIT statements

— supported MO circuit-switched basic services.

## Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

—The UE is brought into the state U11 by using table 10.1.2/3.

### Test procedure

An MO-circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U11. The SS sends a RELEASE message to the UE. The UE shall respond with a RELEASE COMPLETE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

### Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                |
|------|-----------|----|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                         |
| 1    |           | <  | RELEASE                         | cause 81# (invalid TI value)<br>repeat steps 3-4 to cover all the transaction identifiers from 000...110<br>the main signalling link shall be released. |
| 2    |           | >  | RELEASE COMPLETE                |                                                                                                                                                         |
| 3    |           | <  | STATUS ENQUIRY                  |                                                                                                                                                         |
| 4    |           | >  | RELEASE COMPLETE                |                                                                                                                                                         |
| 5    |           | SS |                                 |                                                                                                                                                         |
| 6    |           | <  | RRC CONNECTION RELEASE          |                                                                                                                                                         |
| 7    |           | >  | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                         |

### Specific message contents:

None.

### 10.1.2.7.2.5 — Test requirements

After step 1 a CC-entity of the UE in CC-state U11, "Disconnect Request", shall return the RELEASE COMPLETE.

After step 3 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

### 10.1.2.7.3 — U11 disconnect request / timer T305 time-out

#### 10.1.2.7.3.1 — Definition

The call control entity of the UE being in the state, U11, if no response is then received from the SS, timer T305 expires at the UE side.

#### 10.1.2.7.3.2 — Conformance requirement

- 1) A CC-entity of the UE in CC-state U11, "Disconnect Request" shall on expiry of T305, proceed with the connection release procedure by sending the RELEASE message to its peer entity and shall enter the CC-state U19, "Release Request".

### References

—TS 24.008 clause 5.4.3 and clause 11.3.

#### 10.1.2.7.3.3 — Test purpose

To verify that the CC-entity of the UE in CC-state U11, "Disconnect Request" shall on expiry of T305, proceed with the connection release procedure by sending the RELEASE message to its peer entity and enters the CC-state U19, "Release Request".

~~10.1.2.7.3.4 Method of test~~~~Related ICS/IXIT statements~~

~~—supported MO circuit-switched basic services.~~

~~Initial conditions~~

~~System Simulator:~~

~~—1 cell, default parameters.~~

~~User Equipment:~~

~~—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~—The UE is brought into the state U11 by using table 10.1.2/3.~~

~~Test procedure~~

~~An MO circuit-switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U11. Then T305 expires at the UE and the UE shall send a RELEASE message. The SS checks timer T305 accuracy and that the CC entity has entered the state U19, release request.~~

~~Expected sequence~~

| Step | Direction |    | Message        | Comments                                                                                                                                                        |
|------|-----------|----|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                |                                                                                                                                                                 |
| 1    |           | SS |                | SS waits until T305 expires at the UE<br>SS checks the time between DISCONNECT and RELEASE (note);<br>check the timer T305 accuracy<br><br>cause 30#, state U19 |
| 2    |           | -> | RELEASE        |                                                                                                                                                                 |
| 3    |           | <- | STATUS-ENQUIRY |                                                                                                                                                                 |
| 4    |           | -> | STATUS         |                                                                                                                                                                 |

~~Specific message contents:~~

~~NOTE:—With the same cause value as originally contained in the DISCONNECT message. An additional cause information element (#102 recovery on timer expiry) may be included.~~

~~10.1.2.7.3.5 Test requirements~~

~~Upon expiry of timer T305 a CC-entity of the UE in CC-state U11, "Disconnect Request", shall proceed with the connection release procedure by sending the RELEASE message and enter the CC-state U19, "Release Request".~~

~~10.1.2.7.4 U11 disconnect request / lower layer failure~~~~10.1.2.7.4.1 Definition~~

~~The call control entity of the UE being in the state, U11, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated.~~

~~10.1.2.7.4.2 Conformance requirement~~

- ~~1) A CC-entity of the UE in CC-state U11, "Disconnect Request" having detected a lower layer failure shall return to the idle mode. The CC entity is in state U0, "Null".~~

References

—TS 24.008 clause 4.5.2.3, clause 4.5.3, clause 5.5.3.2 and clause 8.3, TS 25.331 clause 8.3.1 and clause 8.5.6.

10.1.2.7.4.3 ——— Test purpose

To verify that the a CC-entity of the UE in CC-state U11, "Disconnect Request" having detected a lower layer failure returns to the idle mode. The CC entity is thus in state U0, "Null".

10.1.2.7.4.4 ——— Method of test

Related ICS/IXIT statements

—supported MO circuit switched basic services.

Initial conditions

System Simulator:

—1 cell, default parameters.

User Equipment:

—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

—The UE is brought into the state U11 by using table 10.1.2/4.

Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The UE is brought to the state U11. The SS modifies the scrambling code of downlink transmission (DL DPCH) to generate a lower layer failure at the UE. The SS waits long enough to enable the UE to perform cell update procedure. The SS sends RRC CONNECTION RELEASE message as a response to the CELL UPDATE message from the UE. The SS re-modifies the scrambling code of downlink transmission (DL DPCH) to the original one and waits 60 s. The SS will check that the UE will not send any message during 60 s.

Expected sequence

| Step | Direction |    | Message                | Comments                                                                   |
|------|-----------|----|------------------------|----------------------------------------------------------------------------|
|      | UE        | SS |                        |                                                                            |
| 1    |           | SS |                        | SS modifies the scrambling code of DPCH for generating lower layer failure |
| 2    | →         |    | CELL UPDATE            | CCCH                                                                       |
| 3    | ←         |    | RRC CONNECTION RELEASE | CCCH                                                                       |
| 4    |           | SS |                        | SS re-modifies the scrambling code of DPCH to the original one.            |
| 5    |           | SS |                        | SS waits 60 s.                                                             |

Specific message contents:

None.

10.1.2.7.4.5 ——— Test requirements

After step 4 the UE shall not send any message to the SS during 60 s.



~~10.1.2.7.5 U11 disconnect request / unknown message received~~~~10.1.2.7.5.1 Definition~~

~~The call control entity of the UE being in the state, U11, an unknown message is received by the UE.~~

~~10.1.2.7.5.2 Conformance requirement~~

- ~~1) A CC-entity of the UE in CC-state U11, "Disconnect Request", having received an unknown message from its peer entity shall return a STATUS message.~~

~~References~~

~~—TS 24.008 clause 8.4.~~

~~10.1.2.7.5.3 Test purpose~~

~~To verify that a CC-entity of the UE in CC-state U11, "Disconnect Request", having received an unknown message from its peer entity returns a STATUS message.~~

~~10.1.2.7.5.4 Method of test~~~~Related ICS/IXIT statements~~

~~—supported MO circuit switched basic services.~~

~~Initial conditions~~

~~System Simulator:~~

~~—1 cell, default parameters.~~

~~User Equipment:~~

~~—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~—The UE is brought into the state U11 by using table 10.1.2/4.~~

~~Test procedure~~

~~An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U11. The SS sends a message with message type not defined for the protocol discriminator to the UE. The UE shall respond with a STATUS message, and finally the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.~~

~~Expected sequence~~

| Step | Direction |    | Message         | Comments                                                |
|------|-----------|----|-----------------|---------------------------------------------------------|
|      | UE        | SS |                 |                                                         |
| 1    |           | ←  | unknown message | message type not defined for PD<br>cause 97#, state U11 |
| 2    |           | →  | STATUS          |                                                         |
| 3    |           | ←  | STATUS ENQUIRY  | cause 30#, state U11                                    |
| 4    |           | →  | STATUS          |                                                         |

~~Specific message contents:~~

~~None.~~

#### ~~10.1.2.7.5.5 — Test requirements~~

~~After step 1 a CC-entity of the UE in CC-state U11, "Disconnect Request", shall return a STATUS message.~~

#### ~~10.1.2.8 — U12 disconnect indication~~

##### ~~10.1.2.8.1 — U12 disconnect indication / call releasing requested by the user~~

###### ~~10.1.2.8.1.1 — Definition~~

~~The call control entity of the UE being in the state, U12, the user requests to terminate the call.~~

###### ~~10.1.2.8.1.2 — Conformance requirement~~

- ~~1) A CC-entity of the UE in CC-state U12, "Disconnect Indication" being in network initiated call release phase, shall, upon receiving a call release request from the user send a RELEASE to its peer entity and enter CC-state U19, "Release Request".~~

#### References

~~— TS 24.007 clause 6.2.2, TS 24.008 clause 5.4.4.~~

##### ~~10.1.2.8.1.3 — Test purpose~~

~~To verify that a CC-entity of the UE in CC-state U12, "Disconnect Indication" being in network initiated call release phase, shall, upon receiving a call release request from the user sends a RELEASE to its peer entity and enters CC-state U19, "Release Request"~~

##### ~~10.1.2.8.1.4 — Method of test~~

#### Related ICS/IXIT statements

~~— supported MO circuit switched basic services.~~

#### Initial conditions

System Simulator:

~~— 1 cell, default parameters.~~

User Equipment:

~~— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~— The UE is brought into the state U12 by using Option A of table 10.1.2/1.~~

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC-entity of the UE is brought to the state U12. The user requests termination of the call. The UE shall send a RELEASE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U19, release request.

## Expected sequence

| Step | Direction |    | Message        | Comments              |
|------|-----------|----|----------------|-----------------------|
|      | UE        | SS |                |                       |
| 1    |           |    |                | MMI action, "on hook" |
| 2    |           | -> | RELEASE        |                       |
| 3    |           | <- | STATUS ENQUIRY |                       |
| 4    |           | -> | STATUS         | cause 30#, state U19  |

## Specific message contents:

None.

## 10.1.2.8.1.5 — Test requirements

After step 1 a CC-entity of the UE in CC-state U12, "Disconnect Indication" being in network initiated call release phase, shall send a RELEASE message and enter CC-state U19, "Release Request".

## 10.1.2.8.2 — U12 disconnect indication / RELEASE received

## 10.1.2.8.2.1 — Definition

The call control entity of the UE being in the state, U12, a RELEASE message is received by the UE.

## 10.1.2.8.2.2 — Conformance requirement

- 1) A CC-entity of the UE in CC-state U12, "Disconnect Indication", upon receipt of a RELEASE message shall return to its peer entity the RELEASE COMPLETE message and enter the CC-state U0, "Null".
- 2) On returning to the idle mode the UE shall release the MM-connection and the CC-entities relating to the seven mobile originating transaction identifiers shall be in CC-state U0, "Null".

## References

Conformance requirement 1: — TS 24.008 clause 5.4.2

Conformance requirement 2: — TS 24.008 clause 4.5.3, clause 5.5.3.2 and clause 8.3.

## 10.1.2.8.2.3 — Test purpose

- 1) To verify that a CC-entity of the UE in CC-state U12, "Disconnect Indication", upon receipt of a RELEASE message returns to its peer entity the RELEASE COMPLETE message and enters the CC-state U0, "Null".
- 2) To verify that the UE on returning to the idle mode releases the MM-connection and that the CC-entities relating to the seven mobile originating transaction identifiers are in CC-state U0, "Null".

## 10.1.2.8.2.4 — Method of test

## Related ICS/IXIT statements

— supported MO circuit switched basic services.

## Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

—The UE is brought into the state U12 by using Option A of table 10.1.2/1.

### Test procedure

An MO-circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U12. The SS sends a RELEASE message to the UE. The UE shall respond with a RELEASE COMPLETE message. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

### Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                |
|------|-----------|----|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                         |
| 1    |           | <  | RELEASE                         | cause 81# (invalid TI value)<br>repeat steps 3-4 to cover all the transaction identifiers from 000...110<br>the main signalling link shall be released. |
| 2    |           | >  | RELEASE COMPLETE                |                                                                                                                                                         |
| 3    |           | <  | STATUS ENQUIRY                  |                                                                                                                                                         |
| 4    |           | >  | RELEASE COMPLETE                |                                                                                                                                                         |
| 5    |           | SS |                                 |                                                                                                                                                         |
| 6    |           | <  | RRC CONNECTION RELEASE          |                                                                                                                                                         |
| 7    |           | >  | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                         |

### Specific message contents:

None.

### 10.1.2.8.2.5 — Test requirements

After step 1 a CC-entity of the UE in CC-state U12, "Disconnect Indication", shall return the RELEASE COMPLETE message.

After step 3 CC-entities relating to all mobile-originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

### 10.1.2.8.3 — U12 disconnect indication / lower layer failure

#### 10.1.2.8.3.1 — Definition

The call control entity of the UE being in the state, U12, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated.

#### 10.1.2.8.3.2 — Conformance requirement

- 1) A CC-entity of the UE in CC-state U12, "Disconnect Indication" having detected a lower layer failure shall return to idle mode. The CC-entity is in state U0, "Null".

### References

—TS 24.008 clause 5.4.4.2.5.1, clause 4.5.3, clause 5.5.3.2 and clause 8.3, TS 25.331 clause 8.3.1 and clause 8.5.6.

### 10.1.2.8.3.3 — Test purpose

To verify that a CC-entity of the UE in CC-state U12, "Disconnect Indication" having detected a lower layer failure returns to idle mode. The CC-entity is thus in state U0, "Null".

#### 10.1.2.8.3.4 Method of test

##### Related ICS/IXIT statements

—supported MO circuit-switched basic services.

##### Initial conditions

System Simulator:

—1 cell, default parameters.

User Equipment:

—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

—The UE is brought into the state U12 by using Option A of table 10.1.2/3.

##### Test procedure

An MO circuit-switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The UE is brought to the state U12. The SS modifies the scrambling code of downlink transmission (DL DPCH) to generate a lower layer failure at the UE. The SS waits long enough to enable the UE to perform cell update procedure. The SS sends RRC CONNECTION RELEASE message as a response to the CELL UPDATE message from the UE. The SS re-modifies the scrambling code of downlink transmission (DL DPCH) to the original one and waits 60 s. The SS will check that the UE will not send any message during 60 s.

##### Expected sequence

| Step | Direction |    | Message                               | Comments                                                                   |
|------|-----------|----|---------------------------------------|----------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                            |
| 1    |           | SS | CELL UPDATE<br>RRC CONNECTION RELEASE | SS modifies the scrambling code of DPCH for generating lower layer failure |
| 2    | ->        |    |                                       | CCCH                                                                       |
| 3    | <-        |    |                                       | CCCH                                                                       |
| 4    |           | SS |                                       | SS re-modifies the scrambling code of DPCH to the original one.            |
| 5    |           | SS |                                       | SS waits 60 s.<br>UE shall send no message on the DCCH                     |

##### Specific message contents:

None.

#### 10.1.2.8.3.5 Test requirements

After step 4 the UE shall not send any message to the SS during 60 s.

#### 10.1.2.8.4 U12 disconnect indication / unknown message received

##### 10.1.2.8.4.1 Definition

The call control entity of the UE being in the state, U12, an unknown message is received by the UE.

##### 10.1.2.8.4.2 Conformance requirement

A CC-entity of the UE in CC-state U12, "Disconnect Indication" having received an unknown message from its peer entity shall return a STATUS message.

References

—TS 24.008 clause 8.4.

10.1.2.8.4.3 ——— Test purpose

To verify that a CC-entity of the UE in CC-state U12, "Disconnect Indication" having received an unknown message from its peer entity returns a STATUS message.

10.1.2.8.4.4 ——— Method of test

Related ICS/IXIT statements

—supported MO circuit switched basic services.

Initial conditions

System Simulator:

—1 cell, default parameters.

User Equipment:

—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

—The UE is brought into the state U12 by using Option A of table 10.1.2/3.

Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U12. The SS sends a message with message type not defined for the protocol discriminator to the UE. The UE shall respond with a STATUS message, and finally the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

Expected sequence

| Step | Direction |    | Message         | Comments                        |
|------|-----------|----|-----------------|---------------------------------|
|      | UE        | SS |                 |                                 |
| 1    |           | <  | unknown message | message type not defined for PD |
| 2    |           | >  | STATUS          | cause 97#, state U12            |
| 3    |           | <  | STATUS-ENQUIRY  |                                 |
| 4    |           | >  | STATUS          | cause 30#, state U12            |

Specific message contents:

None.

10.1.2.8.4.5 ——— Test requirements

After step 1 a CC-entity of the UE in CC-state U12, "Disconnect Indication", shall return a STATUS message.

10.1.2.9 ——— Outgoing call / U19 release request

10.1.2.9.1 ——— Outgoing call / U19 release request / timer T308 time-out

10.1.2.9.1.1 ——— Definition

The call control entity of the UE being in the state, U19, if no response is then received from the SS, timer T308 expires at the UE side.

~~10.1.2.9.1.2~~ ~~Conformance requirement~~

- ~~1) A CC entity of the UE in CC-state U19, "Release Request" will, upon the first expiry of timer T308 send the RELEASE message to its peer entity and remain in the CC-state U19.~~

~~References~~

~~— TS 24.008 clause 5.4.4.1.3.1 and clause 11.3.~~

~~10.1.2.9.1.3~~ ~~Test purpose~~

~~To verify that a CC entity of the UE in CC-state U19, "Release Request" will, upon the first expiry of timer T308 send the RELEASE message to its peer entity and remain in the CC-state U19.~~

~~10.1.2.9.1.4~~ ~~Method of test~~

~~Related ICS/IXIT statements~~

~~— supported MO circuit switched basic services.~~

~~Initial conditions~~

~~System Simulator:~~

~~— 1 cell, default parameters.~~

~~User Equipment:~~

~~— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~— The UE is brought into the state U19 by using table 10.1.2/4.~~

~~Test procedure~~

~~An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U19. When T308 expires at the UE, the UE shall send a RELEASE message. The SS checks timer T308 accuracy and that the state of the CC entity has remained unchanged.~~

~~Expected sequence~~

| Step                         | Direction |                                      | Message                   | Comments                                                                                                                                                        |
|------------------------------|-----------|--------------------------------------|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                              | UE        | SS                                   |                           |                                                                                                                                                                 |
| <del>1</del><br><del>2</del> |           | <del>SS</del><br><del>-&gt;</del>    | <del>RELEASE</del>        | <del>SS waits until T308 at the UE<br/>SS checks the time between the two<br/>RELEASE messages<br/>check the timer T308 accuracy<br/>cause 30#, state U19</del> |
| <del>3</del><br><del>4</del> |           | <del>&lt;-</del><br><del>-&gt;</del> |                           |                                                                                                                                                                 |
|                              |           |                                      | <del>STATUS ENQUIRY</del> |                                                                                                                                                                 |
|                              |           |                                      | <del>STATUS</del>         |                                                                                                                                                                 |

~~Specific message contents:~~

~~None.~~

~~10.1.2.9.1.5~~ ~~Test requirements~~

~~Upon the first expiry of timer T308 (after step 1) a CC entity of the UE in CC-state U19, "Release Request", shall send the RELEASE message and remain in the CC-state U19.~~

### ~~10.1.2.9.2 Outgoing call / U19 release request / 2nd timer T308 time-out~~

#### ~~10.1.2.9.2.1 Definition~~

~~The call control entity of the UE being in the state, U19, if no response is then received after timer T308 has expired two times in success at the UE.~~

#### ~~10.1.2.9.2.2 Conformance requirement~~

- ~~1) A CC-entity of the UE in CC-state U19, "Release Request", upon the 2nd expiry of the timer T308, shall enter the CC-state U0, "Null".~~
- ~~2) Subsequently the UE shall proceed with releasing the MM-connection and enter the idle mode with the CC entities relating to the seven mobile originating transaction identifiers in state U0, "Null".~~

#### References

Conformance requirement 1: ~~TS 24.008 clause 5.4.4.1.3.1 and clause 11.3.~~

Conformance requirement 2: ~~TS 24.008 clause 4.5.3 and clause 5.5.3.2.~~

#### ~~10.1.2.9.2.3 Test purpose~~

- ~~1) To verify that a CC-entity of the UE in CC-state U19, "Release Request", upon the 2nd expiry of the timer T308, enters the CC-state U0, "Null".~~
- ~~2) To verify that subsequently the UE proceeds with releasing the MM-connection and enters the idle mode with the CC entities relating to the seven mobile originating transaction identifiers in state U0, "Null".~~

#### ~~10.1.2.9.2.4 Method of test~~

#### Related ICS/IXIT statements

~~— supported MO circuit switched basic services.~~

#### Initial conditions

System Simulator:

~~— 1 cell, default parameters.~~

User Equipment:

~~— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~— The UE is brought into the state U19 by using table 10.1.2/4.~~

#### Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U19. The SS allows T308 expiry at the UE, and the UE shall repeat sending the RELEASE message and start timer T308 again. The SS allows again T308 expiry at the UE. The UE shall abort the RRC connection. The SS waits long enough to enable the UE to return to idle state listening to paging, and then pages UE to create RRC connection. Finally, the SS will check the state of the UE by using STATUS ENQUIRY with the relevant transaction identifiers.



## Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                   |
|------|-----------|----|--------------------------------------------------------------|----------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                            |
| 1    |           | SS |                                                              | SS waits until T308 expiry at the UE                                       |
| 2    |           | -> | RELEASE                                                      |                                                                            |
| 3    |           | <- | STATUS ENQUIRY                                               |                                                                            |
| 4    |           | -> | STATUS                                                       | cause 30#, state U19                                                       |
| 5    |           | SS |                                                              | SS waits until the second T308 expiry at the UE                            |
| 6    |           | SS |                                                              | SS waits T3240 expiry at the UE                                            |
| 7    |           | UE |                                                              | the main signalling link shall be released.                                |
| 8    |           | SS |                                                              | SS waits 10 s for the UE to return to listening to paging                  |
| 9    |           |    | Mobile terminated establishment of Radio Resource Connection | See TS34.108                                                               |
| 10   |           | <- | STATUS ENQUIRY                                               |                                                                            |
| 11   |           | -> | RELEASE COMPLETE                                             | cause 81# (invalid TI value)                                               |
| 12   |           | SS |                                                              | repeat steps 10-11 to cover all the transaction identifiers from 000...110 |
| 13   |           | <- | RRC CONNECTION RELEASE                                       | the main signalling link shall be released.                                |
| 14   |           | -> | RRC CONNECTION RELEASE COMPLETE                              |                                                                            |

## Specific message contents:

None.

## 10.1.2.9.2.5 — Test requirements

Upon the 2nd expiry of the timer T308 (after step 5) a CC entity of the UE in CC-state U19, "Release Request", shall enter the CC-state U0, "Null".

After step 10 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

## 10.1.2.9.3 — Outgoing call / U19 release request / RELEASE received

## 10.1.2.9.3.1 — Definition

The call control entity of the UE being in the state, U19, a RELEASE message is received by the UE.

## 10.1.2.9.3.2 — Conformance requirement

- 1) A CC entity of the UE in CC-state U19, "Release Request", upon receipt of a RELEASE, shall release the MM-connection and enter the CC-state U0, "Null" with the CC entities relating to the seven mobile originating transaction identifiers in state U0, "Null".

## References

— TS 24.008 clause 5.4.4.2.5.1, clause 11.3 and clause 5.5.3.2.

## 10.1.2.9.3.3 — Test purpose

To verify that a CC entity of the UE in CC-state U19, "Release Request", upon receipt of a RELEASE, shall release the MM-connection and enters the CC-state U0, "Null" with the CC entities relating to the seven mobile originating transaction identifiers in state U0, "Null".

#### 10.1.2.9.3.4 Method of test

##### Related ICS/IXIT statements

- supported MO circuit-switched basic services.

##### Initial conditions

System Simulator:

- 1 cell, default parameters.

User Equipment:

- The UE is in MM-state "idle, updated" with valid TMSI and CKSN.
- The UE is brought into the state U19 by using table 10.1.2/4.

##### Test procedure

An MO circuit-switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U19. The SS sends a RELEASE message to the UE. The UE shall release the MM-connection. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

##### Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                          |
|------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                   |
| 1    |           | <- | RELEASE                         | (note)<br>cause 81# (invalid-TI value)<br>repeat steps 2-3 to cover all the transaction identifiers from 000...110<br>the main signalling link shall be released. |
| 2    |           | <- | STATUS ENQUIRY                  |                                                                                                                                                                   |
| 3    |           | -> | RELEASE COMPLETE                |                                                                                                                                                                   |
| 4    |           | SS |                                 |                                                                                                                                                                   |
| 5    |           | <- | RRC CONNECTION RELEASE          |                                                                                                                                                                   |
| 6    |           | -> | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                   |

##### Specific message contents:

NOTE:—With the same cause number as originally contained in DISC and optional cause #102 recovery on timer expiry.

#### 10.1.2.9.3.5 Test requirements

After step 2 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid-TI value).

#### 10.1.2.9.4 Outgoing call / U19 release request / RELEASE COMPLETE received

##### 10.1.2.9.4.1 Definition

The call control entity of the UE being in the state, U19, a RELEASE COMPLETE message is received by the UE.

##### 10.1.2.9.4.2 Conformance requirement

- 1) A CC entity of the UE in CC-state U19, "Release Request", upon receipt of a RELEASE COMPLETE, shall release the MM-connection and enter the CC-state U0, "Null" with the CC entities relating to the seven mobile originating transaction identifiers in state U0, "Null".

## References

—TS 24.008 clause 5.4.4.1.3, clause 4.5.3 and clause 8.3.

### 10.1.2.9.4.3 — Test purpose

To verify that a CC-entity of the UE in CC-state U19, "Release Request", upon receipt of a RELEASE COMPLETE, shall release the MM-connection and enters the CC-state U0, "Null" with the CC entities relating to the seven mobile originating transaction identifiers in state U0, "Null".

### 10.1.2.9.4.4 — Method of test

## Related ICS/IXIT statements

—supported MO circuit-switched basic services.

## Initial conditions

System Simulator:

—1 cell, default parameters.

User Equipment:

—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

—The UE is brought into the state U19 by using table 10.1.2/1.

## Test procedure

An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The CC entity of the UE is brought to the state U19. The SS sends a RELEASE COMPLETE message to the UE. The UE shall release the MM-connection. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

## Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                |
|------|-----------|----|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                         |
| 1    |           | <- | RELEASE COMPLETE                | cause 81# (invalid TI value)<br>repeat steps 2-3 to cover all the transaction identifiers from 000...110<br>the main signalling link shall be released. |
| 2    |           | <- | STATUS ENQUIRY                  |                                                                                                                                                         |
| 3    |           | -> | RELEASE COMPLETE                |                                                                                                                                                         |
| 4    |           | SS |                                 |                                                                                                                                                         |
| 5    |           | <- | RRC CONNECTION RELEASE          |                                                                                                                                                         |
| 6    |           | -> | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                         |

Specific message contents:

None.

### 10.1.2.9.4.5 — Test requirements

After step 2 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

### ~~10.1.2.9.5 Outgoing call / U19 release request / lower layer failure~~

#### ~~10.1.2.9.5.1 Definition~~

~~The call control entity of the UE being in the state, U19, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated.~~

#### ~~10.1.2.9.5.2 Conformance requirement~~

~~A CC-entity of the UE in CC-state U19, "Release Request", having detected a lower layer failure, shall return to the idle mode, the CC-entity is in state U0, "Null".~~

#### ~~References~~

~~— TS 24.008 clause 4.5.2.3, clause 4.5.3, clause 5.5.3.2 and clause 8.3, TS 25.331 clause 8.3.1 and clause 8.5.6.~~

#### ~~10.1.2.9.5.3 Test purpose~~

~~To verify that a CC-entity of the UE in CC-state U19, "Release Request", having detected a lower layer failure, returns to the idle mode, the CC-entity is in state U0, "Null".~~

#### ~~10.1.2.9.5.4 Method of test~~

#### ~~Related ICS/IXIT statements~~

~~— supported MO circuit switched basic services.~~

#### ~~Initial conditions~~

~~System Simulator:~~

~~— 1 cell, default parameters.~~

~~User Equipment:~~

~~— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~— The UE is brought into the state U19 by using table 10.1.2/1.~~

#### ~~Test procedure~~

~~An MO circuit switched basic service is selected that is supported by the UE; if the UE supports MO telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then, the UE is made to initiate a call. The UE is brought to the state U19. The SS modifies the scrambling code of downlink transmission (DL DPCH) to generate a lower layer failure at the UE. The SS waits long enough to enable the UE to perform cell update procedure. The SS sends RRC CONNECTION RELEASE message as a response to the CELL UPDATE message from the UE. The SS re-modifies the scrambling code of downlink transmission (DL DPCH) to the original one and waits 60 s. The SS will check that the UE will not send any message during 60 s.~~

## Expected sequence

| Step | Direction |    | Message                               | Comments                                                                   |
|------|-----------|----|---------------------------------------|----------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                            |
| 1    |           | SS | CELL UPDATE<br>RRC-CONNECTION RELEASE | SS modifies the scrambling code of DPCH for generating lower layer failure |
| 2    |           | -> |                                       | CCCH                                                                       |
| 3    |           | <- |                                       | CCCH                                                                       |
| 4    |           | SS |                                       | SS re-modifies the scrambling code of DPCH to the original one.            |
| 5    |           | SS |                                       | SS waits 60 s.<br>UE shall send no message on the DCCH                     |

## Specific message contents:

None.

## 10.1.2.9.5.5 — Test requirements

After step 4 CC the UE shall not send any message to the SS during 60 s.

## 10.1.3 — Establishment of an incoming call / Initial conditions

The tables below describe message exchanges which bring the UE in the requested initial states in case of an incoming call.

A state may be taken as initial only when all the states which lead to this initial states have been validated. The order will be U0, U6, U9, U7, U8, U10, U26 etc. as in the following tables.

Table 10.1.3/1: Establishment of an incoming call, procedure 1

| Step | Direction |    | Message                                                      | Comments            |
|------|-----------|----|--------------------------------------------------------------|---------------------|
|      | UE        | SS |                                                              |                     |
| 1    |           |    | Mobile-terminated establishment of Radio Resource Connection | See TS 34.108       |
| 2    |           | -> | PAGING RESPONSE                                              |                     |
| 3    |           | <- | AUTHENTICATION REQUEST                                       |                     |
| 4    |           | -> | AUTHENTICATION RESPONSE                                      |                     |
| 5    |           | <- | SECURITY MODE COMMAND                                        |                     |
| 6    |           | -> | SECURITY MODE COMPLETE                                       |                     |
| 7    |           | <- | SETUP                                                        |                     |
| 8    |           | -> | CALL CONFIRMED                                               |                     |
| A9   |           | -> | CONNECT                                                      | U6, (note 1)<br>U9  |
| B9   |           | -> | ALERTING                                                     | U8, p = Y, (note 2) |
| B10  | UE        |    |                                                              | U7, p = N, (note 2) |
| B11  |           | -> | CONNECT                                                      | (note 3)<br>U8      |
| 12   |           |    | Radio Bearer Setup Procedure                                 | DTCH, See TS 34.108 |
| 13   |           | <- | CONNECT ACKNOWLEDGE                                          |                     |

NOTE 1: With signal information included in the SETUP message.

NOTE 2: The UE is supporting immediate connect (p = Y/N). See ICS/IXIT statement.

NOTE 3: If necessary (see ICS/IXIT statement), the UE is made to accept the call in the way described in a ICS/IXIT statement.

**Table 10.1.3/2: Establishment of an incoming call, procedure 2**

| Step                                                                                                                           | Direction |    | Message                                                      | Comments                    |
|--------------------------------------------------------------------------------------------------------------------------------|-----------|----|--------------------------------------------------------------|-----------------------------|
|                                                                                                                                | UE        | SS |                                                              |                             |
| 1                                                                                                                              |           |    | Mobile-terminated-establishment of Radio Resource Connection | See TS34.108                |
| 2                                                                                                                              | ->        |    | PAGING-RESPONSE                                              |                             |
| 3                                                                                                                              | <-        |    | SECURITY-MODE-COMMAND                                        |                             |
| 4                                                                                                                              | ->        |    | SECURITY-MODE-COMplete                                       |                             |
| 5                                                                                                                              | <-        |    | SETUP                                                        |                             |
| 6                                                                                                                              | ->        |    | CALL-CONFIRMED                                               |                             |
| A7                                                                                                                             | ->        |    | CONNECT                                                      | U6, (note 1)                |
| A8                                                                                                                             |           |    | Radio-Bearer-Setup-Procedure                                 | U9                          |
| B7                                                                                                                             | ->        |    | ALERTING                                                     | U8, p = Y, (note 2)         |
| B8                                                                                                                             |           |    | Radio-Bearer-Setup-Procedure                                 | DTCH, See TS34.108          |
| B9                                                                                                                             | UE        |    |                                                              | U7, p = N, (note 2)         |
| B10                                                                                                                            | ->        |    | CONNECT                                                      | DTCH, See TS34.108 (note 3) |
| 11                                                                                                                             | <-        |    | AUTHENTICATION-REQUEST                                       | U8                          |
| 12                                                                                                                             | ->        |    | AUTHENTICATION-RESPONSE                                      |                             |
| 13                                                                                                                             | <-        |    | CONNECT-ACKNOWLEDGE                                          |                             |
| NOTE 1: With signal information included in the SETUP message.                                                                 |           |    |                                                              |                             |
| NOTE 2: The UE is supporting immediate connect (p = Y/N). See ICS/IXIT statement.                                              |           |    |                                                              |                             |
| NOTE 3: If necessary (see ICS/IXIT statement), the UE is made to accept the call in the way described in a ICS/IXIT statement. |           |    |                                                              |                             |

**Table 10.1.3/3: Void****Table 10.1.3/4: Establishment of an incoming call, procedure 4**

| Step                                                                                                                           | Direction |    | Message                                                      | Comments            |
|--------------------------------------------------------------------------------------------------------------------------------|-----------|----|--------------------------------------------------------------|---------------------|
|                                                                                                                                | UE        | SS |                                                              |                     |
| 1                                                                                                                              |           |    | Mobile terminated establishment of Radio Resource Connection | See TS 34.108       |
| 2                                                                                                                              | ->        |    | PAGING-RESPONSE                                              |                     |
| 3                                                                                                                              | <-        |    | SECURITY-MODE-COMMAND                                        |                     |
| 4                                                                                                                              | ->        |    | SECURITY-MODE-COMplete                                       |                     |
| 5                                                                                                                              | <-        |    | SETUP                                                        |                     |
| 6                                                                                                                              | ->        |    | CALL-CONFIRMED                                               |                     |
| 7                                                                                                                              |           |    | Radio-Bearer-Setup-Procedure                                 |                     |
| A8                                                                                                                             | ->        |    | CONNECT                                                      | U6, (note 1)        |
| B8                                                                                                                             | ->        |    | ALERTING                                                     | U9                  |
| B9                                                                                                                             | UE        |    |                                                              | U8, p = Y, (note 2) |
| B10                                                                                                                            | ->        |    | CONNECT                                                      | U7, p = N, (note 2) |
| 11                                                                                                                             | <-        |    | AUTHENTICATION-REQUEST                                       | (note 3)            |
| 12                                                                                                                             | ->        |    | AUTHENTICATION-RESPONSE                                      | U8                  |
| 13                                                                                                                             | <-        |    | CONNECT-ACKNOWLEDGE                                          |                     |
| NOTE 1: The signal information element is not included in the SETUP message.                                                   |           |    |                                                              |                     |
| NOTE 2: The UE is supporting immediate connect (p = Y/N). See ICS/IXIT statement.                                              |           |    |                                                              |                     |
| NOTE 3: If necessary (see ICS/IXIT statement), the UE is made to accept the call in the way described in a ICS/IXIT statement. |           |    |                                                              |                     |

**10.1.3.1 Incoming call / U0 null state****10.1.3.1.1 Incoming call / U0 null state / SETUP received with a non-supported bearer capability****10.1.3.1.1.1 Definition**

The call control entity of the UE being in the state, U0, a SETUP message is received with only one bearer capability and this bearer capability is not supported by the UE.

**10.1.3.1.1.2** ——— **Conformance requirement**

- 1) A CC entity of the UE, upon receipt of SETUP containing one bearer capability and this bearer capability is not supported, shall return a RELEASE COMPLETE with correct cause value to its peer entity and return to the idle mode. The CC entities relating to the seven mobile terminating transaction identifiers shall be in the state U0, "Null".

**References**

—— TS 24.008 clause 5.2.2.2 and annex B.

**10.1.3.1.1.3** ——— **Test purpose**

To verify that a CC entity of the UE, upon receipt of SETUP containing one bearer capability and this bearer capability is not supported, returns a RELEASE COMPLETE with correct cause value to its peer entity, and returns to the idle mode. To verify that the CC entities relating to the seven mobile terminating transaction identifiers are then in the state U0, "Null".

**10.1.3.1.1.4** ——— **Method of test****Related ICS/IXIT statements**

—— supported MT circuit switched basic services.

**Initial conditions**

System Simulator:

—— 1 cell, default parameters.

User Equipment:

—— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

**Test procedure**

A mobile terminated call is initiated. The UE receives a SETUP message that contains a bearer capability not supported by the UE. The UE returns a RELEASE COMPLETE message. The SS checks by using the status enquiry procedure that the CC entity is still in the state U0 with all the relevant transaction identifiers.

**Expected sequence**

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                                      |
|------|-----------|----|--------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                               |
| 1    |           |    | Mobile terminated establishment of Radio Resource Connection | SS sends paging, See TS34.108<br><br>(note 1)<br>(note 2)<br><br>Cause #81 (invalid TI value).<br>Repeat steps 9-10 to cover all the transaction identifiers from 000... 110. |
| 2    |           | →  | PAGING RESPONSE                                              |                                                                                                                                                                               |
| 3    |           | ←  | AUTHENTICATION REQUEST                                       |                                                                                                                                                                               |
| 4    |           | →  | AUTHENTICATION RESPONSE                                      |                                                                                                                                                                               |
| 5    |           | ←  | SECURITY MODE COMMAND                                        |                                                                                                                                                                               |
| 6    |           | →  | SECURITY MODE COMPLETE                                       |                                                                                                                                                                               |
| 7    |           | ←  | SETUP                                                        |                                                                                                                                                                               |
| 8    |           | →  | RELEASE COMPLETE                                             |                                                                                                                                                                               |
| 9    |           | ←  | STATUS ENQUIRY                                               |                                                                                                                                                                               |
| 10   |           | →  | RELEASE COMPLETE                                             |                                                                                                                                                                               |
| 11   |           | SS |                                                              |                                                                                                                                                                               |

**Specific message contents:**

NOTE 1: With one bearer capability and that bearer capability is not supported by the UE.

NOTE 2: With cause #88 incompatible destination.

#### ~~10.1.3.1.1.5 Test requirements~~

~~After step 7 a CC entity of the UE shall return a RELEASE COMPLETE message with cause value #88 (incompatible destination) and return to the idle mode.~~

~~After step 9 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).~~

#### ~~10.1.3.2 Incoming call / U6 call present~~

##### ~~10.1.3.2.1 Incoming call / U6 call present / automatic call rejection~~

###### ~~10.1.3.2.1.1 Definition~~

~~Although the state U6 is transient, the ability to refuse a call (automatically) in this state is tested, if it is implemented at the UE.~~

###### ~~10.1.3.2.1.2 Conformance requirement~~

- ~~1) A CC entity of the UE in CC-state U6, "Call Present", upon receipt of a rejection indication of the incoming call from the user, send RELEASE COMPLETE with the appropriate cause value to its peer entity and enter the CC-state U0, "Null". The CC entities relating to the seven mobile terminating transaction identifiers shall be in state U0, "Null".~~

#### References

~~—TS 24.007 clause 6.2.2, TS 24.008 clause 5.2.2.3.1, clause 5.5.3.2 and clause 8.3.~~

##### ~~10.1.3.2.1.3 Test purpose~~

~~To verify that a CC entity of the UE in CC-state U6, "Call Present", shall upon receipt of a rejection indication of the incoming call from the user, shall send RELEASE COMPLETE with the appropriate cause value to its peer entity and enter the CC-state U0, "Null". The CC entities relating to the seven mobile terminating transaction identifiers are then in state U0, "Null".~~

##### ~~10.1.3.2.1.4 Method of test~~

#### Related ICS/IXIT statements

- ~~—supported teleservices;~~
- ~~—the UE supports an ability to refuse a call after receipt of a SETUP message.~~

#### Initial conditions

System Simulator:

- ~~—1 cell, default parameters.~~

User Equipment:

- ~~—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~
- ~~—The UE is brought into the state U6 by using table 10.1.3/2.~~

#### Test procedure

A teleservice is selected that is supported by the UE; if the UE supports speech, the selected teleservice is speech. If necessary, the UE is configured for that teleservice. Then a mobile terminated call is initiated. The call control entire of



the UE is brought to the state U6 (Note: The state U6 is not checked, since it is not stable). The UE is made to refuse the call (the refusal may require some preliminary preparations in order to achieve refusal at this point). The UE shall send a RELEASE COMPLETE message and enter a call control state U0. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

#### Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                |
|------|-----------|----|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                         |
| 1    |           |    |                                 | the UE is made to refuse the call (note)<br><br>cause 81# (invalid TI value)<br>repeat steps 3-4 to cover all the transaction identifiers from 000...110<br>the main signalling link shall be released. |
| 2    |           | -> | RELEASE COMPLETE                |                                                                                                                                                                                                         |
| 3    |           | <- | STATUS ENQUIRY                  |                                                                                                                                                                                                         |
| 4    |           | -> | RELEASE COMPLETE                |                                                                                                                                                                                                         |
| 5    |           | SS |                                 |                                                                                                                                                                                                         |
| 6    |           | <- | RRC CONNECTION RELEASE          |                                                                                                                                                                                                         |
| 7    |           | -> | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                         |

#### Specific message contents:

NOTE:—With cause value #21 call rejected.

#### 10.1.3.2.1.5—Test requirements

After step 1 a CC entity of the UE shall return a RELEASE COMPLETE message with cause value #21 (call rejected) and return to the idle mode.

After step 11 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.3.3—Incoming call / U9 mobile terminating call confirmed

##### 10.1.3.3.1—Incoming call / U9 mobile terminating call confirmed / alerting or immediate connecting

##### 10.1.3.3.1.1—Definition

The call control entity of the UE having entered the state, U9, with signal information received in the preceding SETUP message, the subsequent behaviour of the UE is tested.

##### 10.1.3.3.1.2—Conformance requirement

- 1) A CC entity in CC-state U9, "Mobile Terminating Call Confirmed", (if signalled by the network in previous SETUP message that it may alert) shall either send a ALERTING message to its peer entity and enter state U7, or send a CONNECT message to its peer entity and enter U8.

#### References

—TS 24.008 clause 5.2.2.3.2 and clause 5.2.2.5.

##### 10.1.3.3.1.3—Test purpose

To verify that a CC entity in CC-state U9, "Mobile Terminating Call Confirmed", (if signalled by the network in previous SETUP message that it may alert) will either send a ALERTING message to its peer entity and enter state U7, or send a CONNECT message to its peer entity and enter U8.

#### 10.1.3.3.1.4 Method of test

##### Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

##### Initial conditions

System Simulator:

- 1 cell, default parameters.

User Equipment:

- The UE is in MM-state "idle, updated" with valid TMSI and CKSN.
- The UE is brought into the state U9 by using table 10.1.3/2.

##### Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U9 by using a SETUP message containing signalling information element. (The state U9 is not a stable state in this case, and consequently it is not checked as an initial state.) If the UE supports immediate connect for the selected basic service ( $p = Y$ ), it sends a CONNECT message and enters the state U8, connect request. Otherwise ( $p = N$ ) the UE sends an ALERTING message and enters the state U7, call receiving. The SS checks by using the status enquiry procedure that the CC entity has entered its state as described.

##### Expected sequence

| Step | Direction |    | Message        | Comments                       |
|------|-----------|----|----------------|--------------------------------|
|      | UE        | SS |                |                                |
| A1   | ->        | <  | CONNECT        | $p = Y$<br>cause 30#, state U8 |
| A2   |           |    | STATUS-ENQUIRY |                                |
| A3   |           |    | STATUS         |                                |
| B1   | ->        | <  | ALERTING       | $p = N$<br>cause 30#, state U7 |
| B2   |           |    | STATUS-ENQUIRY |                                |
| B3   |           |    | STATUS         |                                |

##### Specific message contents:

None.

#### 10.1.3.3.1.5 Test requirements

A CC entity in CC-state U9, "Mobile Terminating Call Confirmed", (if signalled by the network in previous SETUP message that it may alert) shall either send an ALERTING message and enter state U7, or send a CONNECT message and enter U8.

#### 10.1.3.3.2 Incoming call / U9 mobile terminating call confirmed / DTCH assignment

##### 10.1.3.3.2.1 Definition

The call control entity of the UE being in the state, U9, a radio bearer establishment procedure is performed for traffic channel.

**10.1.3.3.2.2 Conformance requirement**

- 1) A CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", when a traffic channel is allocated by the network performing the radio-bearer establishment procedure, shall send a ALERTING message and enter state U7.

**References**

- TS 25.331 clause 8.2.1, TS 24.008 clause 5.2.2.7 and clause 5.2.2.3.2.

**10.1.3.3.2.3 Test purpose**

To verify that a CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", when a traffic channel is allocated by the network performing the radio-bearer establishment procedure, shall send a ALERTING message and enters state U7.

**10.1.3.3.2.4 Method of test****Related ICS/IXIT statements**

- supported MT circuit switched basic services;  
 — MT circuit switched basic services for which immediate connect is not used.

**Initial conditions**

System Simulator:

- 1 cell, default parameters.

User Equipment:

- The UE is in MM-state "idle, updated" with valid TMSI and CKSN.  
 — The UE is brought into the state U9 by using table 10.1.3/4.

**Test procedure**

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U9 (by using a SETUP message not containing the signal information element). The SS sends a RADIO BEARER SETUP for traffic channel to the UE. The UE shall respond with a RADIO BEARER SETUP COMPLETE message. The UE sends an ALERTING message and enters state U7, call received. The SS verifies by using the status enquiry procedure that the UE has entered the correct state.

**Expected sequence**

| Step | Direction |    | Message                      | Comments                                      |
|------|-----------|----|------------------------------|-----------------------------------------------|
|      | UE        | SS |                              |                                               |
| 1    |           |    | Radio Bearer Setup Procedure | DTCH, See TS34.108<br><br>cause 30#, state U7 |
| 2    |           | -> | ALERTING                     |                                               |
| 3    |           | <- | STATUS ENQUIRY               |                                               |
| 4    |           | -> | STATUS                       |                                               |

**Specific message contents:**

None.

#### ~~10.1.3.3.2.5 Test requirements~~

~~After step 1 a CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed" shall send a ALERTING message and enter state U7.~~

#### ~~10.1.3.3.3 Incoming call / U9 mobile terminating call confirmed / termination requested by the user~~

##### ~~10.1.3.3.3.1 Definition~~

~~The call control entity of the UE being in the state, U9, the user requests for releasing of the call.~~

##### ~~10.1.3.3.3.2 Conformance requirement~~

- ~~1) A CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", upon request by the user to terminate shall send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".~~

#### References

- ~~— TS 24.007 clause 6.2.2, TS 24.008 clause 5.4.3.~~

#### ~~10.1.3.3.3.3 Test purpose~~

~~To verify that a CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", upon request by the user to terminate will send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".~~

#### ~~10.1.3.3.3.4 Method of test~~

#### Related ICS/IXIT statements

- ~~— supported MT circuit switched basic services;~~
- ~~— MT circuit switched basic services for which immediate connect is not used;~~
- ~~— the UE supports user requested call clearing in the state U9.~~

#### Initial conditions

System Simulator:

- ~~— 1 cell, default parameters.~~

User Equipment:

- ~~— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~
- ~~— The UE is brought into the state U9 by using table 10.1.3/4.~~

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U9 (by using a SETUP message not containing the signal information element). Then the user requests termination of the call, if possible. The UE sends a DISCONNECT message and enters state U11, disconnect request. The SS verifies by using the status enquiry procedure that the UE has entered the correct state.

## Expected sequence

| Step | Direction |    | Message        | Comments                                                     |
|------|-----------|----|----------------|--------------------------------------------------------------|
|      | UE        | SS |                |                                                              |
| 1    |           |    |                | the UE is made to clear the call<br><br>cause 30#, state U11 |
| 2    |           | -> | DISCONNECT     |                                                              |
| 3    |           | <- | STATUS-ENQUIRY |                                                              |
| 4    |           | -> | STATUS         |                                                              |

## Specific message contents:

None.

~~10.1.3.3.3.5 Test requirements~~

After step 1 a CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", shall send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

~~10.1.3.3.4 Incoming call / U9 mobile terminating call confirmed / DISCONNECT received~~~~10.1.3.3.4.1 Definition~~

The call control-entity of the UE being in the state, U9, a DISCONNECT message is received by the UE.

~~10.1.3.3.4.2 Conformance requirement~~

- 1) A CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", upon receipt of a DISCONNECT shall return a RELEASE message and enter the CC-state U19, "Release Request".

## References

— TS 24.008 clause 5.4.4.

~~10.1.3.3.4.3 Test purpose~~

To verify that a CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", upon receipt of a DISCONNECT returns a RELEASE message and enters the CC-state U19, "Release Request".

~~10.1.3.3.4.4 Method of test~~

## Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

## Initial conditions

System Simulator:

- 1 cell, default parameters.

User Equipment:

- The UE is in MM-state "idle, updated" with valid TMSI and CKSN.
- The UE is brought into the state U9 by using table 10.1.3/4.

### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U9. The SS sends a DISCONNECT message to the UE. The UE responds by sending a RELEASE message and enters state U19, release request. The SS verifies by using the status enquiry procedure that the UE has entered the correct state.

### Expected sequence

| Step | Direction |    | Message        | Comments             |
|------|-----------|----|----------------|----------------------|
|      | UE        | SS |                |                      |
| 1    |           | <- | DISCONNECT     |                      |
| 2    |           | -> | RELEASE        |                      |
| 3    |           | <- | STATUS ENQUIRY |                      |
| 4    |           | -> | STATUS         | cause 30#, state U19 |

### Specific message contents:

None.

#### 10.1.3.3.4.5 — Test requirements

After step 1 a CC entity of the UE in CC-state U9, "UE Terminating Call Confirmed", shall return a RELEASE message and enter the CC-state U19, "Release Request".

#### 10.1.3.3.5 — Incoming call / U9 mobile terminating call confirmed / RELEASE received

##### 10.1.3.3.5.1 — Definition

The call control entity of the UE being in the state, U9, a RELEASE message is received by the UE.

##### 10.1.3.3.5.2 — Conformance requirement

- 1) A CC entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", upon receipt of a RELEASE shall return a RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) On returning to the idle mode the UE shall release the MM-connection and the CC-entities relating to the seven mobile terminating transaction identifiers shall be in CC-state U0, "Null".

### References

Conformance requirement 1: — TS 24.008 clause 5.4.4.

Conformance requirement 2: — TS 24.008 clause 4.5.3, clause 5.5.3.2 and clause 8.3.

#### 10.1.3.3.5.3 — Test purpose

- 1) To verify that a CC entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", upon receipt of a RELEASE will return a RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) To verify that the UE on returning to the idle mode releases the MM-connection and that the CC-entities relating to the seven mobile terminating transaction identifiers are in CC-state U0, "Null".

#### 10.1.3.3.5.4 — Method of test

### Related ICS/IXIT statements

— supported MT circuit switched basic services;

—MT circuit switched basic services for which immediate connect is not used.

#### Initial conditions

System Simulator:

—1 cell, default parameters.

User Equipment:

—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

—The UE is brought into the state U9 by using table 10.1.3/4.

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U9. The SS sends a RELEASE message to the UE. The UE responds by sending a RELEASE COMPLETE message and enters state U0, null. The SS verifies by using the status enquiry procedure that the UE has entered the correct state with the relevant transaction identifiers.

#### Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                      |
|------|-----------|----|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                               |
| 1    |           | <- | RELEASE                         | with cause "Normal, unspecified"                                                                                                                              |
| 2    |           | -> | RELEASE COMPLETE                |                                                                                                                                                               |
| 3    |           | <- | STATUS ENQUIRY                  |                                                                                                                                                               |
| 4    |           | -> | RELEASE COMPLETE                |                                                                                                                                                               |
| 5    |           | SS |                                 |                                                                                                                                                               |
| 6    |           | <- | RRC CONNECTION RELEASE          | cause 81# (invalid TI value)<br>repeat steps 3-4 to cover all the<br>transaction identifiers from 000...110<br>the main signalling link shall be<br>released. |
| 7    |           | -> | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                               |

#### Specific message contents:

None.

#### 10.1.3.3.5.5 — Test requirements

After step 1 a CC entity of the UE in CC-state U9, "UE Terminating Call Confirmed", shall return a RELEASE COMPLETE message.

After step 3 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

#### 10.1.3.3.6 — Incoming call / U9 mobile terminating call confirmed / lower layer failure

##### 10.1.3.3.6.1 — Definition

The call control entity of the UE being in the state, U9, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated.

##### 10.1.3.3.6.2 — Conformance requirement

- 1) A CC entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", having detected a lower layer failure shall return to idle mode, the CC entity is in state U0, "Null".

## References

—TS 24.008 clause 4.5.2.3, clause 4.5.3, clause 5.5.3.2 and clause 8.3, TS 25.331 clause 8.3.1 and clause 8.5.6.

### 10.1.3.3.6.3 — Test purpose

To verify that a CC entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed", having detected a lower layer failure returns to idle mode, the CC entity is in state U0, "Null".

### 10.1.3.3.6.4 — Method of test

## Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

## Initial conditions

System Simulator:

- 1 cell, default parameters.

User Equipment:

- The UE is in MM-state "idle, updated" with valid TMSI and CKSN.
- The UE is brought into the state U9 by using table 10.1.3/4.

## Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The UE is brought to the state U9. The SS modifies the scrambling code of downlink transmission (DL-DPCH) to generate a lower layer failure at the UE. The SS waits long enough to enable the UE to perform cell update procedure. The SS sends RRC-CONNECTION-RELEASE message as a response to the CELL-UPDATE message from the UE. The SS re-modifies the scrambling code of downlink transmission (DL-DPCH) to the original one and waits 60 s. The SS will check that the UE will not send any message during 60 s.

## Expected sequence

| Step | Direction |    | Message                | Comments                                                                   |
|------|-----------|----|------------------------|----------------------------------------------------------------------------|
|      | UE        | SS |                        |                                                                            |
| 1    |           | SS |                        | SS modifies the scrambling code of DPCH for generating lower layer failure |
| 2    | ->        |    | CELL-UPDATE            | CCCH                                                                       |
| 3    | <-        |    | RRC-CONNECTION-RELEASE | CCCH                                                                       |
| 4    |           | SS |                        | SS re-modifies the scrambling code of DPCH to the original one.            |
| 5    |           | SS |                        | SS waits 60 s.<br>UE shall send no message on the DCCH                     |

Specific message contents:

None.

### 10.1.3.3.6.5 — Test requirements

After step 4 the UE shall not send any message to the SS during 60 s.



~~10.1.3.3.7 Incoming call / U9 mobile terminating call confirmed / unknown message received~~~~10.1.3.3.7.1 Definition~~

The call control entity of the UE being in the state, U9, an unknown message is received by the UE.

~~10.1.3.3.7.2 Conformance requirement~~

- 1) A CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed" having received an unknown message from its peer entity shall return a STATUS message.

## References

—TS 24.008 clause 8.4.

~~10.1.3.3.7.3 Test purpose~~

To verify that a CC-entity of the UE in CC-state U9, "Mobile Terminating Call Confirmed" having received an unknown message from its peer entity returns a STATUS message.

~~10.1.3.3.7.4 Method of test~~

## Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

## Initial conditions

System Simulator:

- 1 cell, default parameters.

User Equipment:

- The UE is in MM-state "idle, updated" with valid TMSI and CKSN.
- The UE is brought into the state U9 by using table 10.1.3/4.

## Test procedure

A MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U9. The SS sends a message with message type not defined for the protocol discriminator to the UE. The UE shall respond with a STATUS message, and finally the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

## Expected sequence

| Step | Direction |    | Message         | Comments                                               |
|------|-----------|----|-----------------|--------------------------------------------------------|
|      | UE        | SS |                 |                                                        |
| 1    |           | <  | unknown message | message type not defined for PD<br>cause 97#, state U9 |
| 2    |           | >  | STATUS          |                                                        |
| 3    |           | <  | STATUS ENQUIRY  | cause 30#, state U9                                    |
| 4    |           | >  | STATUS          |                                                        |

Specific message contents:

None.

#### ~~10.1.3.3.7.5 Test requirements~~

~~After step 1 a CC entity of the UE in CC-state U9, "UE Terminating Call Confirmed", shall return a STATUS message.~~

#### ~~10.1.3.4 Incoming call / U7 call received~~

##### ~~10.1.3.4.1 Incoming call / U7 call received / call accepted~~

###### ~~10.1.3.4.1.1 Definition~~

~~The call control entity of the UE being in the state, U7, a user accepts the incoming call.~~

###### ~~10.1.3.4.1.2 Conformance requirement~~

- ~~1) A CC entity of a UE in CC-state U7, "Call Received", upon a user accepting the incoming call, shall send a CONNECT message to its peer entity and enter the CC-state U8, "Connect Request".~~

#### References

~~— TS 24.007 clause 6.2.2, TS 24.008 clause 5.2.2.5.~~

##### ~~10.1.3.4.1.3 Test purpose~~

~~To verify that a CC entity of a UE in CC-state U7, "Call Received", upon a user accepting the incoming call, shall send a CONNECT message to its peer entity and enter the CC-state U8, "Connect Request".~~

##### ~~10.1.3.4.1.4 Method of test~~

#### Related ICS/IXIT statements

- ~~— supported MT circuit switched basic services;~~
- ~~— MT circuit switched basic services for which immediate connect is not used.~~

#### Initial conditions

System Simulator:

- ~~— 1 cell, default parameters.~~

User Equipment:

- ~~— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~
- ~~— The UE is brought into the state U7 by using table 10.1.3/1.~~

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U7. The user accepts the incoming call. The UE sends a CONNECT message. The SS checks by using the status enquiry procedure that the CC entity has entered state U8, connect request.

## Expected sequence

| Step | Direction |    | Message        | Comments                                                                 |
|------|-----------|----|----------------|--------------------------------------------------------------------------|
|      | UE        | SS |                |                                                                          |
| 1    |           |    |                | the UE is made to accept the call by the user<br><br>cause 30#, state U8 |
| 2    |           | -> | CONNECT        |                                                                          |
| 3    |           | <- | STATUS-ENQUIRY |                                                                          |
| 4    |           | -> | STATUS         |                                                                          |

## Specific message contents:

None.

~~10.1.3.4.1.5 Test requirements~~

After step 1 a CC entity of a UE in CC-state U7, "Call Received", shall send a CONNECT message and enter the CC-state U8, "Connect Request".

~~10.1.3.4.2 Incoming call / U7 call received / termination requested by the user~~~~10.1.3.4.2.1 Definition~~

The call control entity of the UE being in the state, U7, a user requests to terminate incoming call.

~~10.1.3.4.2.2 Conformance requirement~~

- 1) A CC entity of a UE in CC-state U7, "Call Received", upon request by the user to terminate shall send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

## References

— TS 24.007 clause 6.2.2, TS 24.008 clause 5.4.3.

~~10.1.3.4.2.3 Test purpose~~

To verify that a CC entity of a UE in CC-state U7, "Call Received", upon request by the user to terminate will send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

~~10.1.3.4.2.4 Method of test~~

## Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

## Initial conditions

System Simulator:

- 1 cell, default parameters.

User Equipment:

- The UE is in MM-state "idle, updated" with valid TMSI and CKSN.
- The UE is brought into the state U7 by using table 10.1.3/1.

### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U7. The user initiates clearing the incoming call. The UE sends a DISCONNECT message. The SS checks by using the status enquiry procedure that the CC entity has entered state U11, disconnect request.

### Expected sequence

| Step | Direction |    | Message        | Comments                                                                |
|------|-----------|----|----------------|-------------------------------------------------------------------------|
|      | UE        | SS |                |                                                                         |
| 1    |           |    |                | the UE is made to terminate/reject the call<br><br>cause 30#, state U11 |
| 2    |           | -> | DISCONNECT     |                                                                         |
| 3    |           | <- | STATUS ENQUIRY |                                                                         |
| 4    |           | -> | STATUS         |                                                                         |

### Specific message contents:

None.

#### 10.1.3.4.2.5 — Test requirements

After step 1 a CC entity of a UE in CC-state U7, "Call Received", shall send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

#### 10.1.3.4.3 — Incoming call / U7 call received / DISCONNECT received

##### 10.1.3.4.3.1 — Definition

The call control entity of the UE being in the state, U7, a DISCONNECT message is received by the UE.

##### 10.1.3.4.3.2 — Conformance requirement

- 1) A CC entity of a UE in CC-state U7, "Call Received", upon receipt of a DISCONNECT with a progress indicator indicating in-band information from network, if a DTCH was not assigned, shall return a RELEASE message and enter the CC-state U19, "Release Request".

### References

— TS 24.008 clause 5.4.4.

#### 10.1.3.4.3.3 — Test purpose

To verify that a CC entity of a UE in CC-state U7, "Call Received", upon receipt of a DISCONNECT with a progress indicator indicating in-band information from network, if a DTCH was not assigned, returns a RELEASE message and enters the CC-state U19, "Release Request".

#### 10.1.3.4.3.4 — Method of test

### Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

— The UE is brought into the state U7 by using table 10.1.3/1.

### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U7. The SS sends a DISCONNECT message. The UE responds with a RELEASE message. The SS checks by using the status enquiry procedure that the CC entity has entered state U19, release request.

### Expected sequence

| Step | Direction |    | Message        | Comments                       |
|------|-----------|----|----------------|--------------------------------|
|      | UE        | SS |                |                                |
| 1    |           | <- | DISCONNECT     | (note)<br>cause 30#, state U19 |
| 2    |           | -> | RELEASE        |                                |
| 3    |           | <- | STATUS ENQUIRY |                                |
| 4    |           | -> | STATUS         |                                |

### Specific message contents:

NOTE: — With a progress indicator indicating in-band information; Progress Indicator, Progress Description #8.

#### 10.1.3.4.3.5 — Test requirements

After step 1 a CC entity of a UE in CC-state U7, "Call Received", if a DTCH was not assigned, shall return a RELEASE message and enter the CC-state U19, "Release Request".

#### 10.1.3.4.4 — Incoming call / U7 call received / RELEASE received

##### 10.1.3.4.4.1 — Definition

The call control entity of the UE being in the state, U7, a RELEASE message is received by the UE.

##### 10.1.3.4.4.2 — Conformance requirement

- 1) A CC entity of a UE in CC-state U7, "Call Received", upon receipt of a RELEASE shall return a RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) On returning to the idle mode the UE shall release the MM-connection and the CC-entities relating to the seven mobile terminating transaction identifiers shall be in CC-state U0, "Null".

### References

Conformance requirement 1: — TS 24.008 clause 5.4.4.

Conformance requirement 2: — TS 24.008 clause 4.5.3 and clause 5.5.3.2.

**10.1.3.4.4.3 — Test purpose**

- 1) To verify that a CC entity of a UE in CC-state U7, "Call Received", upon receipt of a RELEASE will return a RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) To verify that the UE on returning to the idle mode releases the MM-connection and that the CC-entities relating to the seven mobile terminating transaction identifiers are in CC-state U0, "Null".

**10.1.3.4.4.4 — Method of test****Related ICS/IXIT statements**

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

**Initial conditions**

System Simulator:

- 1 cell, default parameters.

User Equipment:

- The UE is in MM-state "idle, updated" with valid TMSI and CKSN.
- The UE is brought into the state U7 by using table 10.1.3/1.

**Test procedure**

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U7. The SS sends a RELEASE message. The UE responds with a RELEASE COMPLETE message. The SS checks by using the status enquiry procedure that the CC entity has entered state U0, null, with the relevant transaction identifiers.

**Expected sequence**

| Step | Direction |    | Message                         | Comments                                                                                                                                                      |
|------|-----------|----|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                               |
| 1    |           | <- | RELEASE                         | with cause "Normal, unspecified"                                                                                                                              |
| 2    |           | -> | RELEASE COMPLETE                |                                                                                                                                                               |
| 3    |           | <- | STATUS-ENQUIRY                  |                                                                                                                                                               |
| 4    |           | -> | RELEASE COMPLETE                |                                                                                                                                                               |
| 5    |           | SS |                                 |                                                                                                                                                               |
| 6    |           | <- | RRC-CONNECTION-RELEASE          | cause 81# (invalid-TI-value)<br>repeat steps 3-4 to cover all the<br>transaction identifiers from 000...110<br>the main signalling link shall be<br>released. |
| 7    |           | -> | RRC-CONNECTION-RELEASE COMPLETE |                                                                                                                                                               |

**Specific message contents:**

None.

**10.1.3.4.4.5 — Test requirements**

After step 1 a CC entity of a UE in CC-state U7, "Call Received", shall return a RELEASE COMPLETE message.

After step 3 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid-TI-value).

#### ~~10.1.3.4.5 Incoming call / U7 call received / lower layer failure~~

##### ~~10.1.3.4.5.1 Definition~~

~~The call control entity of the UE being in the state, U7, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated.~~

##### ~~10.1.3.4.5.2 Conformance requirement~~

- ~~1) A CC entity of a UE in CC-state U7, "Call Received", having detected a lower layer failure shall return to idle mode, the CC entity is in state U0, "Null".~~

#### References

~~— TS 24.008 clause 4.5.2.3, clause 4.5.3, clause 5.5.3.2 and clause 8.3, TS 25.331 clause 8.3.1, and clause 8.5.6.~~

##### ~~10.1.3.4.5.3 Test purpose~~

~~To verify that a CC entity of a UE in CC-state U7, "Call Received", having detected a lower layer failure returns to idle mode, the CC entity is in state U0, "Null".~~

##### ~~10.1.3.4.5.4 Method of test~~

#### Related ICS/IXIT statements

- ~~— supported MT circuit switched basic services;~~
- ~~— MT circuit switched basic services for which immediate connect is not used.~~

#### Initial conditions

System Simulator:

- ~~— 1 cell, default parameters.~~

User Equipment:

- ~~— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~
- ~~— The UE is brought into the state U7 by using table 10.1.3/2.~~

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The UE is brought to the state U7. The SS modifies the scrambling code of downlink transmission(DL DPCH) to generate a lower layer failure at the UE. The SS waits long enough to enable the UE to perform cell update procedure. The SS sends RRC CONNECTION RELEASE message as a response to the CELL UPDATE message from the UE. The SS re-modifies the scrambling code of downlink transmission(DL DPCH) to the original one and waits 60 s. The SS will check that the UE will not send any message during 60 s.

## Expected sequence

| Step | Direction |    | Message                | Comments                                                                   |
|------|-----------|----|------------------------|----------------------------------------------------------------------------|
|      | UE        | SS |                        |                                                                            |
| 1    |           | SS |                        | SS modifies the scrambling code of DPCH for generating lower layer failure |
| 2    | ->        |    | CELL UPDATE            | CCCH                                                                       |
| 3    | <-        |    | RRC CONNECTION RELEASE | CCCH                                                                       |
| 4    |           | SS |                        | SS re-modifies the scrambling code of DPCH to the original one.            |
| 5    |           | SS |                        | SS waits 60 s.<br>UE shall send no message on the DCCH                     |

## Specific message contents:

None.

~~10.1.3.4.5.5 — Test requirements~~

After step 4 the UE shall not send any message to the SS during 60 s.

~~10.1.3.4.6 — Incoming call / U7 call received / unknown message received~~~~10.1.3.4.6.1 — Definition~~

The call control entity of the UE being in the state, U7, an unknown message is received by the UE.

~~10.1.3.4.6.2 — Conformance requirement~~

- 1) A CC entity of a UE in CC-state U7, "Call Received", having received an unknown message from its peer entity shall return a STATUS message.

## References

— TS 24.008 clause 8.4.

~~10.1.3.4.6.3 — Test purpose~~

To verify that a CC entity of a UE in CC-state U7, "Call Received", having received an unknown message from its peer entity returns a STATUS message.

~~10.1.3.4.6.4 — Method of test~~

## Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

## Initial conditions

System Simulator:

- 1 cell, default parameters.

User Equipment:

- The UE is in MM-state "idle, updated" with valid TMSI and CKSN.
- The UE is brought into the state U7 by using table 10.1.3/1.



## Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U7. The SS sends a message with message type not defined for the protocol discriminator to the UE. The UE shall respond with a STATUS message, and finally the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

## Expected sequence

| Step | Direction |    | Message         | Comments                        |
|------|-----------|----|-----------------|---------------------------------|
|      | UE        | SS |                 |                                 |
| 1    |           | <- | unknown message | message type not defined for PD |
| 2    |           | -> | STATUS          | cause 97#, state U7             |
| 3    |           | <- | STATUS ENQUIRY  |                                 |
| 4    |           | -> | STATUS          | cause 30#, state U7             |

## Specific message contents:

None.

## 10.1.3.4.6.5 — Test requirements

After step 1 a CC entity of a UE in CC-state U7, "Call Received", shall return a STATUS message.

## 10.1.3.4.7 — Incoming call / U7 call received / DTCH assignment

### 10.1.3.4.7.1 — Definition

The call control entity of the UE being in the state, U7, a radio bearer establishment procedure is performed for traffic channel.

### 10.1.3.4.7.2 — Conformance requirement

- 1) A CC entity of a UE in CC-state U7, "Call Received", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, shall stay in CC-state U7.

## References

— TS 25.331 clause 8.2.1, TS 24.008 clause 5.2.2.7.

### 10.1.3.4.7.3 — Test purpose

To verify that a CC entity of a UE in CC-state U7, "Call Received", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, stays in CC-state U7.

### 10.1.3.4.7.4 — Method of test

## Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

## Initial conditions

System Simulator:

—1 cell, default parameters.

User Equipment:

—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

—The UE is brought into the state U7 by using table 10.1.3/1.

### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected basic service is telephony. If necessary, the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U7. The SS sends a RADIO BEARER SETUP for traffic channel to the UE. The UE shall respond with a RADIO BEARER SETUP COMPLETE message. The SS verifies by using the status enquiry procedure that the state of the CC entity has remained unchanged.

### Expected sequence

| Step | Direction |    | Message                      | Comments                                  |
|------|-----------|----|------------------------------|-------------------------------------------|
|      | UE        | SS |                              |                                           |
| 1    |           |    | Radio Bearer Setup Procedure | DTCH, See TS34.108<br>cause 30#, state U7 |
| 2    |           | <- | STATUS ENQUIRY               |                                           |
| 3    |           | -> | STATUS                       |                                           |

### Specific message contents:

None.

### 10.1.3.4.7.5 — Test requirements

After step 1 the CC state U7, "Call Received", shall remain unchanged.

### 10.1.3.4.8 — Incoming call / U7 call received / RELEASE COMPLETE received

#### 10.1.3.4.8.1 — Definition

The call control entity of the UE being in the state, U7, the call is cleared by a RELEASE COMPLETE message sent by the SS.

#### 10.1.3.4.8.2 — Conformance requirement

- 1) A CC entity of the UE in CC-state U7, "call received", upon receipt of a RELEASE COMPLETE message with valid cause value, shall enter CC state U0, "Null".
- 2) On returning to idle mode, the CC entities relating to the seven mobile terminating transaction identifiers shall be in state U0, "Null".

### References

Conformance requirement 1: —TS 24.008 clause 5.4.2 and clause 5.4.4.

Conformance requirement 2: —TS 24.008 clause 5.4.4.1.3.

#### 10.1.3.4.8.3 — Test purpose

- 1) To verify that a CC entity of the UE in CC-state U7, "Call received", upon receipt of a RELEASE COMPLETE message with valid cause value, enters CC state U0, "Null".

- 2) To verify that in returning to idle mode, the CC entities relating to the seven mobile terminating transaction identifiers are in state U0, "Null".

#### 10.1.3.4.8.4 Method of test

##### Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

##### Initial conditions

###### System Simulator:

- 1 cell, default parameters.

###### User Equipment:

- The UE is in MM-state "idle, updated" with valid TMSI and CKSN.
- The UE is brought into the state U7 by using table 10.1.3/1.

##### Test procedure

An MT circuit switched basic service is selected that is supported by the UE and for which the UE does not use immediate connection; if the UE supports MT telephony without immediate connection, the selected service is telephony. If necessary, the UE is configured for that basic service. The mobile terminated call is initiated. the CC entity of the UE is brought to U7. The SS sends a RELEASE COMPLETE message to the UE. The SS checks by using the status enquiry procedure that the CC entity has entered the state U0 with all the relevant transaction identifiers.

##### Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                            |
|------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                     |
| 1    |           | <- | RELEASE COMPLETE                | note 1<br><br>cause 81# (invalid TI value), note 2<br>repeat steps 2-3 to cover all the<br>transaction identifiers from 000...110<br>the main signalling link shall be<br>released. |
| 2    |           | <- | STATUS ENQUIRY                  |                                                                                                                                                                                     |
| 3    |           | -> | RELEASE COMPLETE                |                                                                                                                                                                                     |
| 4    |           | SS |                                 |                                                                                                                                                                                     |
| 5    |           | <- | RRC CONNECTION RELEASE          |                                                                                                                                                                                     |
| 6    |           | -> | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                     |

##### Specific message contents:

NOTE 1: With the cause value chosen arbitrarily.

NOTE 2: TI flag has the value indicating the SS as a originator of the call.

#### 10.1.3.4.8.5 Test requirements

After step 2 CC entities relating to all mobile originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).

### ~~10.1.3.5 Incoming call / U8 connect request~~

#### ~~10.1.3.5.1 Incoming call / U8 connect request / CONNECT acknowledged~~

##### ~~10.1.3.5.1.1 Definition~~

The call control entity of the UE being in the state, U8, a CONNECT ACKNOWLEDGE message is received by the UE.

##### ~~10.1.3.5.1.2 Conformance requirement~~

A CC entity of a UE in CC-state U8, "Connect Request", upon receipt of CONNECT ACKNOWLEDGE shall enter the CC-state U10, "Call Active".

#### References

~~— TS 24.008 clause 5.2.2.6.~~

##### ~~10.1.3.5.1.3 Test purpose~~

To verify that a CC entity of a UE in CC-state U8, "Connect Request", upon receipt of CONNECT ACKNOWLEDGE shall enter the CC-state U10, "Call Active".

##### ~~10.1.3.5.1.4 Method of test~~

#### Related ICS/IXIT statements

- ~~— supported MT circuit switched basic services;~~
- ~~— MT circuit switched basic services for which immediate connect is not used.~~

#### Initial conditions

System Simulator:

- ~~— 1 cell, default parameters.~~

User Equipment:

- ~~— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~
- ~~— The UE is brought into the state U8 by using table 10.1.3/2.~~

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U8 (if the UE uses immediate connection for the selected basic service then p = Y, otherwise p = N). The SS sends a CONNECT ACKNOWLEDGE message. The SS checks by using the status enquiry procedure that the CC entity of the UE has entered state U10, active.

#### Expected sequence

| Step | Direction |    | Message                      | Comments             |
|------|-----------|----|------------------------------|----------------------|
|      | UE        | SS |                              |                      |
| A1   |           |    | Radio Bearer Setup Procedure | p = Y, See TS34.108  |
| 2    | <         |    | CONNECT ACKNOWLEDGE          |                      |
| 3    | <         |    | STATUS ENQUIRY               |                      |
| 4    | >         |    | STATUS                       | cause 30#, state U10 |

Specific message contents:

None.

#### ~~10.1.3.5.1.5 Test requirements~~

~~After step 2 a CC entity of a UE in CC-state U8, "Connect Request", shall enter the CC-state U10, "Call Active".~~

#### ~~10.1.3.5.2 Incoming call / U8 connect request / timer T313 time-out~~

##### ~~10.1.3.5.2.1 Definition~~

~~The call control entity of the UE being in the state, U8, if no response is then received from the SS, timer T313 expires at the UE side.~~

##### ~~10.1.3.5.2.2 Conformance requirement~~

~~A CC entity of a UE in CC-state U8, "Connect Request", having waited for a reasonable length of time (e.g. expiry of timer T313) without receiving the appropriate protocol message to complete the incoming call, shall initiate the clearing of that incoming call by sending the CC message DISCONNECT and enter the CC-state U11, "Disconnect Request".~~

~~If an UE disconnects too early then, in the case of very late assignment of a traffic channel, systematic waste of radio resources may occur.~~

#### References

~~— TS 24.008 clause 5.2.2.6 and clause 5.4.3.~~

#### ~~10.1.3.5.2.3 Test purpose~~

~~To verify that a CC entity of a UE in CC-state U8, "Connect Request", having waited for a reasonable length of time (e.g. expiry of timer T313) without receiving the appropriate protocol message to complete the incoming call, shall initiate the clearing of that incoming call by sending the CC message DISCONNECT and enter the CC-state U11, "Disconnect Request".~~

#### ~~10.1.3.5.2.4 Method of test~~

#### Related ICS/IXIT statements

- ~~— supported MT circuit switched basic services;~~
- ~~— MT circuit switched basic services for which immediate connect is not used.~~

#### Initial conditions

System Simulator:

- ~~— 1 cell, default parameters.~~

User Equipment:

- ~~— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~
- ~~— The UE is brought into the state U8 by using table 10.1.3/2.~~

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U8 (if the UE uses immediate connection for the selected basic service then p = Y, otherwise p = N). The T313 expires at the UE and the UE sends a DISCONNECT

message and enters state U11, disconnect request. The SS checks by using the status enquiry procedure that the UE has entered the correct state.

#### Expected sequence

| Step | Direction |    | Message                      | Comments                                                                                                                 |
|------|-----------|----|------------------------------|--------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                              |                                                                                                                          |
| A1   |           |    | Radio Bearer Setup Procedure | p = Y, See TS34.108                                                                                                      |
| 2    |           | -> | DISCONNECT                   | Shall not be sent before 15 s after entry into state U8. But, shall be sent before 1,1 * T313 after entry into state U8. |
| 3    |           | <- | STATUS ENQUIRY               | cause 30#, state U11                                                                                                     |
| 4    |           | -> | STATUS                       |                                                                                                                          |

#### Specific message contents:

None.

#### 10.1.3.5.2.5 Test requirements

Upon expiry of timer T313 without receiving the appropriate protocol message to complete the incoming call a CC entity of a UE in CC-state U8, "Connect Request", shall initiate the clearing of that incoming call by sending a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

#### 10.1.3.5.3 Incoming call / U8 connect request / termination requested by the user

##### 10.1.3.5.3.1 Definition

The call control entity of the UE being in the state, U8, the user requests for releasing of the call.

##### 10.1.3.5.3.2 Conformance requirement

- 1) A CC entity of a UE in CC-state U8, "Connect Request", upon request by the user to terminate shall send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

#### References

— TS 24.007 clause 6.2.2, TS 24.008 clause 5.4.3.

##### 10.1.3.5.3.3 Test purpose

To verify that a CC entity of a UE in CC-state U8, "Connect Request", upon request by the user to terminate will send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

##### 10.1.3.5.3.4 Method of test

#### Related ICS/IXIT statements

- supported MT circuit switched basic services;
- MT circuit switched basic services for which immediate connect is not used.

#### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

- The UE is in MM-state "idle, updated" with valid TMSI and CKSN.
- The UE is brought into the state U8 by using table 10.1.3/2.

### Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U8 (if the UE uses immediate connection for the selected basic service then  $p = Y$ , otherwise  $p = N$ ). Then the user requests termination of the call. The UE sends a DISCONNECT message and enters state U11, disconnect request. The SS verifies by using the status enquiry procedure that the UE has entered the correct state.

### Expected sequence

| Step | Direction |    | Message                      | Comments                            |
|------|-----------|----|------------------------------|-------------------------------------|
|      | UE        | SS |                              |                                     |
| A1   |           |    | Radio Bearer Setup Procedure | $p = Y$ , See TS34.108              |
| 2    |           |    |                              | the user requests to clear the call |
| 3    |           | -> | DISCONNECT                   |                                     |
| 4    |           | <- | STATUS ENQUIRY               |                                     |
| 5    |           | -> | STATUS                       |                                     |
|      |           |    |                              | cause 30#, state U11                |

### Specific message contents:

None.

### 10.1.3.5.3.5 — Test requirements

After step 2 a CC entity of a UE in CC-state U8, "Connect Request", shall send a DISCONNECT message and enter the CC-state U11, "Disconnect Request".

### 10.1.3.5.4 — Incoming call / U8 connect request / DISCONNECT received with in-band information

#### 10.1.3.5.4.1 — Definition

The call control entity of the UE being in the state, U8, a DISCONNECT message indicating availability of in-band information is received by the UE.

#### 10.1.3.5.4.2 — Conformance requirement

A CC entity of a UE in CC-state U8, "Connect Request", upon receipt of a DISCONNECT with progress indicator #8 shall enter CC-state U12, if the traffic channel is in speech mode. If the DTCH is not in speech mode, the UE shall send a RELEASE message and enter CC-state U19.

### References

- TS 24.008 clause 5.4.4 and clause 5.5.1.

#### 10.1.3.5.4.3 — Test purpose

To verify that a CC entity of a UE in CC-state U8, "Connect Request", upon receipt of a DISCONNECT with progress indicator #8 enters CC-state U12, if the traffic channel is in speech mode, and that the UE sends a RELEASE message and enters CC-state U19 if the DTCH is not in speech mode.

#### 10.1.3.5.4.4 Method of test

##### Related ICS/IXIT statements

—supported MT circuit switched basic services.

##### Initial conditions

System Simulator:

—1 cell, default parameters.

User Equipment:

—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

The UE is brought into the state U8 by using table 10.1.3/4.

##### Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U8. The SS sends a DISCONNECT message containing indication of in-band information availability to the UE. If channel mode is speech, the UE enters state U12, disconnect indication. If channel mode is not speech, the UE sends a RELEASE message and enters state U19, release request.

##### Expected sequence

| Step | Direction |    | Message        | Comments                    |
|------|-----------|----|----------------|-----------------------------|
|      | UE        | SS |                |                             |
| 1    | <-        |    | DISCONNECT     | (note)                      |
| A2   | <-        |    | STATUS ENQUIRY | DTCH in speech mode:        |
| A3   | ->        |    | STATUS         | cause 30#, state U12        |
| B2   | ->        |    | RELEASE        | DTCH is not in speech mode: |
| B3   | <-        |    | STATUS ENQUIRY | cause 30#, state U19        |
| B4   | ->        |    | STATUS         |                             |

##### Specific message contents:

NOTE:—With a progress indicator indicating in-band information; Progress Indicator, Progress-description #8.

#### 10.1.3.5.4.5 Test requirements

After step 1 a CC entity of a UE in CC-state U8, "Connect Request", shall enter CC-state U12, if the traffic channel is in speech mode. If the DTCH is not in speech mode, the UE shall send a RELEASE message and enter CC-state U19.

#### 10.1.3.5.5 Incoming call / U8 connect request / DISCONNECT received without in-band information

##### 10.1.3.5.5.1 Definition

The call control entity of the UE being in the state, U8, a DISCONNECT message is received by the UE. The DISCONNECT message does not contain indication of in-band information availability.

##### 10.1.3.5.5.2 Conformance requirement

- 1) A CC entity of a UE in CC-state U8, "Connect Request", upon receipt of a DISCONNECT without progress indicator, shall return a RELEASE message and enter the CC-state U19, "Release Request".



## References

—TS 24.008 clause 5.4.4 and clause 5.4.4.1.2.

### 10.1.3.5.5.3 ——— Test purpose

To verify that a CC entity of a UE in CC-state U8, "Connect Request", upon receipt of a DISCONNECT without progress indicator, returns a RELEASE message and enters the CC-state U19, "Release Request".

### 10.1.3.5.5.4 ——— Method of test

## Related ICS/IXIT statements

—supported MT circuit switched basic services.

## Initial conditions

System Simulator:

—1 cell, default parameters.

User Equipment:

—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

—The UE is brought into the state U8 by using table 10.1.3/4.

## Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U8. The SS sends a DISCONNECT message not containing indication of in-band information availability to the UE. The UE shall respond with a RELEASE message. The SS checks by using the status enquiry procedure that the CC entity of the UE has entered the state U19, release request.

## Expected sequence

| Step | Direction |    | Message        | Comments                           |
|------|-----------|----|----------------|------------------------------------|
|      | UE        | SS |                |                                    |
| 1    |           | <  | DISCONNECT     | (note)<br><br>cause 30#, state U19 |
| 2    |           | >  | RELEASE        |                                    |
| 3    |           | <  | STATUS ENQUIRY |                                    |
| 4    |           | >  | STATUS         |                                    |

## Specific message contents:

NOTE: —Without a progress indicator indicating in-band information.

### 10.1.3.5.5.5 ——— Test requirements

After step 1 a CC entity of a UE in CC-state U8, "Connect Request", shall return a RELEASE message and enter the CC-state U19, "Release Request".

### 10.1.3.5.6 ——— Incoming call / U8 connect request / RELEASE received

#### 10.1.3.5.6.1 ——— Definition

The call control entity of the UE being in the state, U8, a RELEASE message is received by the UE.

**10.1.3.5.6.2** Conformance requirement

- 1) A CC entity of a UE in CC-state U8, "Connect Request", upon receipt of a RELEASE shall return a RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) On returning to the idle mode the UE shall release the MM-connection and the CC-entities relating to the seven mobile terminating transaction identifiers shall be in CC-state U0, "Null".

**References**

Conformance requirement 1: TS 24.008 clause 5.4.4.

Conformance requirement 2: TS 24.008 clause 4.5.3 and clause 5.5.3.2.

**10.1.3.5.6.3** Test purpose

- 1) To verify that a CC entity of a UE in CC-state U8, "Connect Request", upon receipt of a RELEASE will return a RELEASE COMPLETE and enter the CC-state U0, "Null".
- 2) To verify that the UE on returning to the idle mode releases the MM-connection and that the CC-entities relating to the seven mobile terminating transaction identifiers are in CC-state U0, "Null".

**10.1.3.5.6.4** Method of test**Related ICS/IXIT statements**

— supported MT circuit switched basic services.

**Initial conditions**

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

— The UE is brought into the state U8 by using table 10.1.3/1.

**Test procedure**

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U8. The SS sends a RELEASE message. The UE responds with a RELEASE COMPLETE message. The SS checks by using the status enquiry procedure that the CC entity has entered state U0, null, with the relevant transaction identifiers.

**Expected sequence**

| Step | Direction |    | Message                         | Comments                                                                                                                                                |
|------|-----------|----|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                         |
| 1    | <         |    | RELEASE                         | with cause "Normal, unspecified"                                                                                                                        |
| 2    |           | >  | RELEASE COMPLETE                |                                                                                                                                                         |
| 3    | <         |    | STATUS ENQUIRY                  |                                                                                                                                                         |
| 4    |           | >  | RELEASE COMPLETE                |                                                                                                                                                         |
| 5    |           | SS |                                 |                                                                                                                                                         |
| 6    | <         |    | RRC CONNECTION RELEASE          | cause 81# (invalid TI value)<br>repeat steps 3-4 to cover all the transaction identifiers from 000...110<br>the main signalling link shall be released. |
| 7    |           | >  | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                         |

Specific message contents:

None.

#### ~~10.1.3.5.6.5 Test requirements~~

~~After step 1 a CC entity of a UE in CC-state U8, "Connect Request", shall return a RELEASE COMPLETE message.~~

~~After step 3 CC entities relating to all mobile-originating transaction identifiers shall send RELEASE COMPLETE messages with cause value #81 (invalid TI value).~~

#### ~~10.1.3.5.7 Incoming call / U8 connect request / lower layer failure~~

##### ~~10.1.3.5.7.1 Definition~~

~~The call control entity of the UE being in the state, U8, a lower layer failure is accomplished at the UE and consequently, communication at layer 3 level with the peer entity is terminated.~~

##### ~~10.1.3.5.7.2 Conformance requirement~~

- ~~1) A CC entity of a UE in CC-state U8, "Connect Request", having detected a lower layer failure shall return to idle mode, the CC entity is in state U0, "Null".~~

#### References

~~— TS 24.008 clause 4.5.2.3, clause 4.5.3 and clause 5.5.3.2, TS 25.331 clause 8.3.1 and clause 8.5.6.~~

#### ~~10.1.3.5.7.3 Test purpose~~

~~To verify that a CC entity of a UE in CC-state U8, "Connect Request", having detected a lower layer failure returns to idle mode, the CC entity is in state U0, "Null".~~

#### ~~10.1.3.5.7.4 Method of test~~

#### Related ICS/IXIT statements

~~— supported MT circuit switched basic services.~~

#### Initial conditions

System Simulator:

~~— 1 cell, default parameters.~~

User Equipment:

~~— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~— The UE is brought into the state U8 by using table 10.1.3/1.~~

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The UE is brought to the state U8. The SS modifies the scrambling code of downlink transmission (DL DPCH) to generate a lower layer failure at the UE. The SS waits long enough to enable the UE to perform cell update procedure. The SS sends RRC CONNECTION RELEASE message as a response to the CELL UPDATE message from the UE. The SS re-modifies the scrambling code of downlink transmission (DL DPCH) to the original one and waits 60 s. The SS will check that the UE will not send any message during 60 s.

## Expected sequence

| Step | Direction |    | Message                | Comments                                                                    |
|------|-----------|----|------------------------|-----------------------------------------------------------------------------|
|      | UE        | SS |                        |                                                                             |
| 1    |           | SS |                        | SS modifies the scrambling code of DPCCH for generating lower layer failure |
| 2    | ->        |    | CELL UPDATE            | CCCH                                                                        |
| 3    | <-        |    | RRC CONNECTION RELEASE | CCCH                                                                        |
| 4    |           | SS |                        | SS re-modifies the scrambling code of DPCCH to the original one.            |
| 5    |           | SS |                        | SS waits 60 s.<br>UE shall send no message on the DCCH                      |

## Specific message contents:

None.

~~10.1.3.5.7.5 Test requirements~~

After step 4 the UE shall not send any message to the SS during 60 s.

~~10.1.3.5.8 Incoming call / U8 connect request / DTCH assignment~~~~10.1.3.5.8.1 Definition~~

The call control entity of the UE being in the state, U8, a radio bearer establishment procedure is performed for traffic channel.

~~10.1.3.5.8.2 Conformance requirement~~

- 1) A CC entity of a UE in CC-state U8, "Connect Request", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, shall stay in the CC-state U8.

## References

— TS 25.331 clause 8.2.1, TS 24.008 clause 5.2.2.7.

~~10.1.3.5.8.3 Test purpose~~

To verify that a CC entity of a UE in CC-state U8, "Connect Request", when a traffic channel is allocated by the network performing the radio bearer establishment procedure, stays in the CC-state U8.

~~10.1.3.5.8.4 Method of test~~

## Related ICS/IXIT statements

— supported MT circuit switched basic services.

## Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

— The UE is brought into the state U8 by using table 10.1.3/1.

### Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U8. The SS sends a RADIO BEARER SETUP for traffic channel to the UE. The UE shall respond with a RADIO BEARER SETUP COMPLETE message. The SS verifies by using the status enquiry procedure that the state of the CC entity has remained unchanged.

### Expected sequence

| Step | Direction |    | Message                      | Comments            |
|------|-----------|----|------------------------------|---------------------|
|      | UE        | SS |                              |                     |
| 1    |           |    | Radio Bearer Setup Procedure | DTCH, See TS34.108  |
| 2    |           | <- | STATUS ENQUIRY               |                     |
| 3    |           | -> | STATUS                       | cause 30#, state U8 |

### Specific message contents:

None.

### 10.1.3.5.8.5 — Test requirements

After step 1 the CC-state U8, "Connect Request", shall remain unchanged.

### 10.1.3.5.9 — Incoming call / U8 connect request / unknown message received

#### 10.1.3.5.9.1 — Definition

The call control entity of the UE being in the state, U8, an unknown message is received by the UE.

#### 10.1.3.5.9.2 — Conformance requirement

- 1) A CC entity of a UE in CC-state U8, "Connect Request", having received an unknown message from its peer entity shall return a STATUS message.

### References

— TS 24.008 clause 8.4.

### 10.1.3.5.9.3 — Test purpose

To verify that a CC entity of a UE in CC-state U8, "Connect Request", having received an unknown message from its peer entity returns a STATUS message.

### 10.1.3.5.9.4 — Method of test

### Related ICS/IXIT statements

— supported MT circuit switched basic services.

### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.

—The UE is brought into the state U8 by using table 10.1.3/1.

#### Test procedure

An MT circuit switched basic service is selected that is supported by the UE; if the UE supports MT telephony, the selected basic service is telephony. If necessary the UE is configured for that basic service. Then a mobile terminated call is initiated. The CC entity of the UE is brought to the state U8. The SS sends a message with message type not defined for the protocol discriminator to the UE. The UE shall respond with a STATUS message, and finally the SS checks by using the status enquiry procedure that the state of the CC entity has remained unchanged.

#### Expected sequence

| Step | Direction |    | Message         | Comments                        |
|------|-----------|----|-----------------|---------------------------------|
|      | UE        | SS |                 |                                 |
| 1    |           | <- | unknown message | message type not defined for PD |
| 2    |           | -> | STATUS          | cause 97#, state U8             |
| 3    |           | <- | STATUS ENQUIRY  |                                 |
| 4    |           | -> | STATUS          | cause 30#, state U8             |

#### Specific message contents:

None.

#### 10.1.3.5.9.5 — Test requirements

After step 1 a CC entity of a UE in CC-state U8, "Connect Request", shall return a STATUS message.

### 10.1.4 — In call functions

#### 10.1.4.1 — In-call functions / DTMF information transfer

##### 10.1.4.1.1 — In-call functions / DTMF information transfer / basic procedures

##### 10.1.4.1.1.1 — Definition

Dual Tone Multi Frequency (DTMF) is an inband one out of four plus one out of four signalling system primarily used from terminal instruments in telecommunication networks.

##### 10.1.4.1.1.2 — Conformance requirement

- 1) An UE supporting the Mobile originating DTMF protocol control procedure, having a CC entity for speech in state U10, "Active": when made to send a DTMF tone, shall send a START DTMF message on the correct DCCH.
- 2) An UE supporting the Mobile originating DTMF protocol control procedure, having a CC entity for speech in state U10, "Active": when made to send a DTMF tone (the corresponding IA5 character being selected from among the ones supported), shall send a START DTMF message specifying the correct IA5 character in the "keypad information" field of the keypad facility information element.

#### References

—TS 24.008 clause 5.5.7.

##### 10.1.4.1.1.3 — Test purpose

- 1) To verify that an UE supporting the Mobile originating DTMF protocol control procedure, having a CC entity for speech in state U10, "Active": when made to send a DTMF tone, sends a START DTMF message on the correct DCCH.

- 2) To verify that an UE supporting the Mobile originating DTMF protocol control procedure, having a CC entity for speech in state U10, "Active": when made to send a DTMF tone (the corresponding IA5 character being selected from among the ones supported), sends a START DTMF message specifying the correct IA5 character in the "keypad information" field of the keypad facility information element.

#### 10.1.4.1.1.4 Method of test

##### Related ICS/IXIT statements

- supported teleservices;
- supported character set (e.g. 0-9, #, \*, A, B, C, D);
- if and how DTMF tone is indicated to the user.

##### Initial conditions

###### System Simulator:

- 1 cell, default parameters.

###### User Equipment:

- The UE is in MM-state "idle, updated" with valid TMSI and CKSN.
- The UE is brought into the state U10 "Active" for speech by using Generic call setup procedure for mobile originating circuit switched call defined in TS 34.108.

##### Test procedure

The UE being in the call active state, a user causes a DTMF tone to be generated e.g. by depression of a key in the UE. A DTMF digit corresponding to the digit indicated by the user is sent in a START DTMF message by the UE. The SS will return a START DTMF ACKNOWLEDGE message to the UE. This acknowledgement may be used in the UE to generate an indication as a feedback for a successful transmission. Then the user indicates that the DTMF sending should cease e.g. by releasing the key. The UE will send a STOP DTMF message to the network which is acknowledged with STOP DTMF ACKNOWLEDGE by the SS.

The sequence described above is repeated for each of the applicable characters 0-9, #, \*, A, B, C, and D.

Then a case of rejecting a DTMF tone is tested and the state of the UE is verified.

## Expected sequence

| Step | Direction |    | Message                | Comments                                                                                     |
|------|-----------|----|------------------------|----------------------------------------------------------------------------------------------|
|      | UE        | SS |                        |                                                                                              |
| 1    |           | SS |                        | Request the user to cause a DTMF tone to be generated                                        |
|      | →         |    | START DTMF             | the SS will verify that the transmitted information corresponds to the digit pressed         |
| 2    |           | ←  | START DTMF ACKNOWLEDGE | possible indication of a DTMF tone depending the ICS/IXIT statements                         |
| 3    |           | ←  | STATUS ENQUIRY         |                                                                                              |
| 4    |           | →  | STATUS                 | cause 30#, state U10                                                                         |
| 5    |           | →  | STOP DTMF              |                                                                                              |
| 6    |           | ←  | STOP DTMF ACKNOWLEDGE  | the DTMF tone indication shall be stopped                                                    |
| 7    |           |    |                        | the steps 1-6 shall be repeated for each of the applicable characters 0-9, #, *, A, B, C, D. |
| 8    |           | ←  | STATUS ENQUIRY         |                                                                                              |
| 9    |           | →  | STATUS                 | cause 30#, state U10                                                                         |
| 10   |           | SS |                        | Request the user to cause a DTMF tone to be generated.                                       |
| 11   |           | →  | START DTMF             |                                                                                              |
| 12   |           | ←  | START DTMF REJECT      |                                                                                              |
| 13   |           | ←  | STATUS ENQUIRY         |                                                                                              |
| 14   |           | →  | STATUS                 | cause 30#, state U10                                                                         |

## Specific message contents:

None.

## 10.1.4.1.1.5 — Test requirements

Upon a user making to send a DTMF tone a CC entity for speech in the CC state U10, "Active", shall send a START DTMF message on the DCCH to SS.

The SS will verify that the transmitted information corresponds to the digit pressed in the UE.

After step 7 (successful DTMF transmission) the CC state U10, "Active", shall remain unchanged.

After step 11 (unsuccessful DTMF transmission) the CC state U10, "Active", shall remain unchanged.

## 10.1.4.2 — In-call functions / user notification

User notification procedure allows the network to notify a UE of any call-related event during the "active" state of a call. It also may allow a UE to notify the remote user of any appropriate call-related event during the "active" state of a call by sending a NOTIFY message containing a notification indicator to the network. No state change occurs at any of the interface sides during this procedure.

## 10.1.4.2.1 — In-call functions / User notification / UE terminated

## 10.1.4.2.1.1 — Definition

This is a case for testing user notification procedure terminated by the user equipment.

## 10.1.4.2.1.2 — Conformance requirement

- 1) A CC entity of a UE in CC state U10, "active", upon receiving of a NOTIFY message shall remain in the active state.



References

~~—TS 24.008 clause 5.3.1.~~

~~10.1.4.2.1.3 ——— Test purpose~~

~~To verify that a CC entity of a UE in CC-state U10, "active", upon receiving of a NOTIFY message remains in the active state.~~

~~10.1.4.2.1.4 ——— Method of test~~

Related ICS/IXIT statements

~~—supported circuit-switched basic services.~~

Initial conditions

System Simulator:

~~—1 cell, default parameters.~~

User Equipment:

~~—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~—The UE is brought into the state U10 "Active" by using Generic call setup procedure for mobile-originating circuit-switched calls defined in TS 34.108.~~

Test procedure

~~The UE being in the call active state, the SS will send a NOTIFY message to the UE. The state of the UE is checked after that.~~

Expected sequence

| Step | Direction |    | Message        | Comments             |
|------|-----------|----|----------------|----------------------|
|      | UE        | SS |                |                      |
| 1    |           | <- | NOTIFY         | cause 30#, state U10 |
| 2    |           | <- | STATUS ENQUIRY |                      |
| 3    |           | -> | STATUS         |                      |

Specific message contents:

None.

~~10.1.4.2.1.5 ——— Test requirements~~

~~After step 1 a CC entity of the UE in the CC-state U10, "active", shall remain in the active state.~~

~~10.1.4.3 ——— In-call functions / channel changes~~

~~The two following test cases are for testing some elementary radio resource level procedures during an active state of a call to ensure call maintenance also during Hard handover.~~

~~10.1.4.3.1 ——— In-call functions / channel changes / a successful channel change in active state/  
Hard handover~~

~~10.1.4.3.1.1 ——— Definition~~

~~This is a case to test a change of the frequency of a physical channel during active state of a call.~~

~~10.1.4.3.1.2~~ ~~Conformance requirement~~

- ~~1) The UE being in the call active state after having successful completed a physical channel reconfiguration, shall remain in the call active state.~~

~~References~~

~~— TS 24.008 clause 5.3.4.3.2, TS 25.331 clause 8.3.5.~~

~~10.1.4.3.1.3~~ ~~Test purpose~~

~~To verify that the UE being in the call active state after having successful completed a physical channel reconfiguration remains in the call active state.~~

~~10.1.4.3.1.4~~ ~~Method of test~~

~~Related ICS/IXIT statements~~

~~— supported circuit switched basic services;~~

~~Initial conditions~~

~~System Simulator:~~

~~— 1 cell, default parameters.~~

~~User Equipment:~~

~~— The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~— The UE is brought into the state U10 "Active" by using Generic call setup procedure for mobile originating circuit switched calls defined in TS 34.108.~~

~~Test procedure~~

~~The UE being in the call active state, the SS initiated physical channel reconfiguration procedure causing an intracell change of channel by sending a PHYSICAL CHANNEL RECONFIGURATION message to the UE. The UE performs physical channel reconfiguration procedure and after the main signalling link is successfully established, the UE returns a PHYSICAL CHANNEL RECONFIGURATION COMPLETE message on the uplink DCCH using AM RLC. The state of the UE is then checked.~~

~~Expected sequence~~

| Step | Direction |    | Message                                   | Comments |
|------|-----------|----|-------------------------------------------|----------|
|      | UE        | SS |                                           |          |
| 1    | <         | >  | PHYSICAL CHANNEL RECONFIGURATION          |          |
| 2    |           |    | PHYSICAL CHANNEL RECONFIGURATION COMPLETE |          |
| 3    | <         | >  | STATUS ENQUIRY                            |          |
| 4    |           |    | STATUS                                    |          |

~~cause 30#, state U10~~

~~Specific message contents:~~

~~None.~~

~~10.1.4.3.1.5~~ ~~Test requirements~~

~~The UE being in the call active state after having successful completed a physical channel reconfiguration, shall remain in the call active state.~~

### ~~10.1.4.3.2 In-call functions / channel changes / an unsuccessful channel change in active mode/Hard handover~~

#### ~~10.1.4.3.2.1 Definition~~

~~This is a case to test an unsuccessful change of the frequency of a physical channel during active state of a call.~~

#### ~~10.1.4.3.2.2 Conformance requirement~~

- ~~1) The UE, when returning to the old channel after physical channel reconfiguration failure, shall remain in the call active state.~~

#### References

~~—TS 24.008 clause 5.3.4.3.~~

#### ~~10.1.4.3.2.3 Test purpose~~

~~To verify that the UE, when returning to the old channel after physical channel reconfiguration failure, will remain in the call active state.~~

#### ~~10.1.4.3.2.4 Method of test~~

#### Related ICS/IXIT statements

~~—supported circuit switched basic services.~~

#### Initial conditions

System Simulator:

~~—1 cell, default parameters.~~

User Equipment:

~~—The UE is in MM-state "idle, updated" with valid TMSI and CKSN.~~

~~—The UE is brought into the state U10 "Active" by using Generic call setup procedure for mobile-originating circuit switched calls defined in TS 34.108.~~

#### Test procedure

The SS sends a PHYSICAL CHANNEL RECONFIGURATION message, but does not activate the assigned physical channel. The UE shall attempt try to activate the new channel (this is not verified) and shall then reactivate the "old" channel. The UE shall send a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC and shall set the cause value in IE "failure cause" to "physical channel failure". The state of the UE is then checked.

#### Expected sequence

| Step | Direction |    | Message                                  | Comments                                                                                                |
|------|-----------|----|------------------------------------------|---------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                          |                                                                                                         |
| 1    |           | <- | PHYSICAL CHANNEL RECONFIGURATION         | The UE attempts and fails to re-configure the physical channel.<br><br>NOTE<br><br>cause 30#, state U10 |
| 2    |           | -> | PHYSICAL CHANNEL RECONFIGURATION FAILURE |                                                                                                         |
| 3    |           | <- | STATUS ENQUIRY                           |                                                                                                         |
| 4    |           | -> | STATUS                                   |                                                                                                         |

Specific message contents:

NOTE: ~~With the cause value "physical channel failure".~~

#### ~~10.1.4.3.2.5 Test requirements~~

~~The UE being in the call active state after physical channel reconfiguration failure, shall remain in the call active state.~~

#### ~~10.1.4.4 In-call functions / UE terminated in-call modification~~

##### ~~10.1.4.4.1 In-call functions / UE terminated in-call modification / modify when new mode is not supported~~

~~This test is not applicable for R99.~~

#### ~~10.1.4.5 In-call functions / UE originated in-call modification~~

##### ~~10.1.4.5.1 In-call functions / UE originated in-call modification / a successful case of modifying~~

~~This test is not applicable for R99.~~

##### ~~10.1.4.5.2 In-call functions / UE originated in-call modification / modify rejected~~

~~This test is not applicable for R99.~~

##### ~~10.1.4.5.3 In-call functions / UE originated in-call modification / an abnormal case of acceptance~~

~~This test is not applicable for R99.~~

##### ~~10.1.4.5.4 In-call functions / UE originated in-call modification / an abnormal case of rejection~~

~~This test is not applicable for R99.~~

##### ~~10.1.4.5.5 In-call functions / UE originated in-call modification / time-out of timer T323~~

~~This test is not applicable for R99.~~

##### ~~10.1.4.5.6 In-call functions / UE originated in-call modification / a successful channel change in state mobile-originating modify~~

~~This test is not applicable for R99.~~

##### ~~10.1.4.5.7 In-call functions / UE originated in-call modification / an unsuccessful channel change in state mobile-originating modify~~

~~This test is not applicable for R99.~~

##### ~~10.1.4.5.8 In-call functions / UE originated in-call modification / unknown message received~~

~~This test is not applicable for R99.~~

##### ~~10.1.4.5.9 In-call functions / UE originated in-call modification / a release complete received~~

~~This test is not applicable for R99.~~

## ~~10.2 Call Re-establishment~~

### ~~10.2.1 Call Re-establishment/call present, re-establishment allowed~~

#### ~~10.2.1.1 Definition~~

~~This is to test a successful case of a call re-establishment procedure.~~

#### ~~10.2.1.2 Conformance requirement~~

- ~~1) If the call is in the "active" state or "mobile originating modify" state, the indication from MM that re-establishment is possible shall cause call control to request re-establishment from the MM-connection, suspend any further message to be sent and await the completion of the re-establishment procedure.~~
- ~~2) When the call control entity is notified that the MM-connection is re-established, it shall then resume the transmission of possibly suspended messages and resume user data exchange when an appropriate channel is available.~~

#### References

- ~~1) TS 24.008 clauses 4.5.1.6 and 5.5.4.2, TS 25.331 clause 8.3.1 and clause 8.5.6.~~
- ~~2) TS 24.008 clauses 4.5.1.6 and 5.5.4.3.~~

#### ~~10.2.1.3 Test purpose~~

~~The purpose of this test is to verify that the UE can correctly perform a call re-establishment procedure.~~

#### ~~10.2.1.4 Method of test~~

#### Related ICS/IXIT statements

~~—supported teleservices.~~

#### Initial conditions

System Simulator:

~~—1 cell, default parameters~~

User Equipment:

~~—The UE is in MM-state "idle, updated" with valid TMSI and CKSN on cell A.~~

#### Test procedure

The UE is brought into the state U10 "Active" by using Generic call setup procedure for mobile originating circuit switched calls defined in TS34.108. The SS modifies the scrambling code of downlink transmission (DL DPCH) to generate a lower layer failure at the UE. The SS waits long enough to enable the UE to perform cell update procedure. The SS sends RRC CONNECTION RELEASE as a response message to the CELL UPDATE message from the UE. The SS re-modifies the scrambling code of downlink transmission (DL DPCH) to the original one. The UE shall re-establish the call using CM RE-ESTABLISHMENT message. The SS performs security mode control and radio bearer establishment procedures. The UE shall through-connect the appropriate bearer channel. Then, the call is cleared by the SS.

## Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                               |
|------|-----------|----|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                        |
| 1    |           |    |                                 | The UE is brought into the state U10 "Active" by using Generic call setup procedure for mobile-originating circuit switched calls defined in TS34.108 (the appropriate bearer channel is through connected in both directions in DTCH) |
| 2    |           | SS |                                 | SS modifies the scrambling code of DPCCH for generating lower layer failure. CCCH                                                                                                                                                      |
| 3    | →         |    | CELL UPDATE                     | CCCH                                                                                                                                                                                                                                   |
| 4    | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                        |
| 5    |           | SS |                                 | SS re-modifies the scrambling code of DPCCH to the original one.                                                                                                                                                                       |
| 6    | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                        |
| 7    | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                        |
| 8    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                        |
| 9    | →         |    | CM REESTABLISHMENT REQUEST      | note specific message contents                                                                                                                                                                                                         |
| 10   | ←         |    | SECURITY MODE COMMAND           |                                                                                                                                                                                                                                        |
| 11   | →         |    | SECURITY MODE COMPLETE          |                                                                                                                                                                                                                                        |
| 12   |           |    | Radio Bearer Setup Procedure    |                                                                                                                                                                                                                                        |
| 13   | UE        |    |                                 | See TS34.108<br>The appropriate bearer channel is through connected in both directions. with cause value "Normal"                                                                                                                      |
| 14   | ←         |    | DISCONNECT                      |                                                                                                                                                                                                                                        |
| 15   | →         |    | RELEASE                         |                                                                                                                                                                                                                                        |
| 16   | ←         |    | RELEASE COMPLETE                |                                                                                                                                                                                                                                        |
| 17   | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                        |
| 18   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                        |

## Specific message contents:

CM RE-ESTABLISHMENT REQUEST message contains Ciphering key sequence number IE with the value which the UE was allocated in.

## 10.2.1.5 Test requirements

After step 2 a CC entity of the UE in the "active" state, shall suspend any further message to be sent and await the completion of the re-establishment procedure.

After step 12 the UE resume user data exchange when an appropriate channel is available.

## 10.3 User to user signalling

## 10.3.1 Definition

The "user to user" information element is used to convey information between the mobile user and a remote ISDN user.

NOTE: There is no test for an UE originating call including a "user-user" information element since it is not a mandatory UE feature.

## 10.3.2 Conformance requirement

The inclusion of the "user-user" information element in downlink call control messages shall cause no adverse effects on the operation of the UE.

## References

— TS 24.008 clauses 5.2.2, 9.3.7, 9.3.23.1 and 10.5.4.25.

### 10.3.3 Purpose of the test

The purpose of this test is to verify that inclusion of the "user-user" information element in either of the down link messages, SETUP or DISCONNECT causes no adverse effects on the operation of the UE.

### 10.3.4 Method of test

#### Related ICS/IXIT statement(s)

- Supported MT circuit-switched basic services.
- Support of user-user information element, and details of suitable codings.

#### Initial conditions:

##### System Simulator:

- The SS simulates 1 cell, with default parameters.

##### User Equipment:

- The UE is in MM-state "idle updated", with a valid TMSI and CKSN.

#### Test procedure

The SS attempts to set up a mobile terminated call, with one of the supported circuit-switched basic services which has been arbitrarily chosen, the generic call set up procedures for mobile terminating circuit-switched calls, (either speech or data) as specified in TS 34.108 clause 7. The default SETUP message contents are modified to include the user-user Information Element. The UE shall not respond adversely to the inclusion of the user-user information element.

After 30 s the SS sends a DISCONNECT message, again the UE shall not respond adversely to the inclusion of the user-user information element, but shall continue to clear down the call normally.

#### Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                               |
|------|-----------|----|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                        |
| 1    |           |    |                                 | Generic Call Setup procedure for mobile terminating circuit-switched calls defined in TS 34.108, depending on choice of Bearer Capability. The SETUP message contains the user-user IE, see Specific message contents. |
| 2    |           |    |                                 | The SS waits 30 s.                                                                                                                                                                                                     |
| 3    |           | <- | DISCONNECT                      | Message contains the user-user IE, see Specific message contents                                                                                                                                                       |
| 4    |           | -> | RELEASE                         |                                                                                                                                                                                                                        |
| 5    |           | <- | RELEASE COMPLETE                |                                                                                                                                                                                                                        |
| 6    |           | <- | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                        |
| 7    |           | -> | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                        |

#### Specific message contents:

SETUP message contains user-user IE with the string coded in IA5 characters: for example "Call Setup".

DISCONNECT message contains user-user IE with the string coded in IA5 characters: for example "Call Disconnect". (The codings above are for example only. For the case of an UE which supports "user-user" signalling it may be necessary to add meaning to the data fields, see ICS/IXIT statement(s).)

NOTE:—The codings above are for example only. For the case of an UE which supports "user-user" signalling it may be necessary to add meaning to the data fields, see ICS/IXIT statement(s).

### ~~10.3.5 Test requirements~~

~~The inclusion of the "user-user" information element in downlink call control messages shall cause no adverse effects on the operation of the UE.~~



## 11 Session Management Procedures

### 11.1 PDP context activation

#### 11.1.1 Initiated by the UE

##### 11.1.1.1 Attach initiated by context activation/QoS Offered by Network is the QoS Requested

###### 11.1.1.1.1 Definition

###### 11.1.1.1.2 Conformance requirement

PDP context activation shall initiate PS Attach by the UE to establish a GMM context, when the UE is PS Detached.

In order to request a PDP context activation, the UE sends an ACTIVATE PDP CONTEXT REQUEST message to the network, enters the state PDP ACTIVE-PENDING and starts timer T3380. The message contains the selected NSAPI, PDP type, requested QoS and, if the UE requests a static address, the PDP address.

If the QoS offered by the network is the same as the QoS requested by the UE, then upon receipt of the message ACTIVATE PDP CONTEXT ACCEPT the UE shall stop timer T3380.

In GSM, the MS shall initiate establishment of the logical link for the LLC SAPI indicated by the network with the offered QoS and selected radio priority level if no logical link has been already established for that SAPI.

In UMTS, both the network and the MS shall store the LLC SAPI and the radio priority in the PDP context.

A UE, which is capable of operating in both GSM and UMTS, shall use a valid LLC SAPI, while a UE which is capable of operating only in UMTS shall indicate the LLC SAPI value as "LLC SAPI not assigned" in order to avoid unnecessary value range checking and any other possible confusion in the network.

NOTE:—The radio priority level and the LLC SAPI parameters, though not used in UMTS, shall be included in the messages, in order to support handover between UMTS and GSM networks.

#### Reference

3GPP TS 24.008 clauses 6.1.3.1 and 6.1.3.1.1.

###### 11.1.1.1.3 Test purpose

To check that the UE initiates a PS attach, if one is not already active, when PDP context activation is requested.

To test the behaviour of the UE when SS responds to the PDP context activation request with the requested QoS.

###### 11.1.1.1.4 Method of test

#### Initial conditions

System Simulator:

—1 cell, default parameters.

User Equipment:

—The UE is in GMM state "GMM-DEREGISTERED, normal service" with valid P-TMSI and CKSN.

### Related ICS/IXIT statements

- PS Supported ————— yes/no
- Auto Attach supported ————— yes / no
- Method of context activation

### Test procedure

If the UE is attached, then the Detach Request is originated from the UE indicating "GPRS detach without switching off". The SS responds with a Detach Accept after completing the security mode procedures. A PDP context activation is then requested by the user. The PS attach (ATTACH REQUEST) is then indirectly caused by a requested PDP context activation. The SS returns the ATTACH ACCEPT message to the UE. Now session management can proceed with PDP context activation.

On receipt of the ACTIVATE PDP CONTEXT REQUEST message an ACTIVATE PDP CONTEXT ACCEPT is returned by the SS with the same requested QoS. The contents of the ACTIVATE PDP CONTEXT REQUEST message shall then be checked. The SS then waits for T3380 seconds to ensure T3380 has been stopped and no more ACTIVATE PDP CONTEXT REQUEST messages are sent by the UE. The SS then sends a MODIFY PDP CONTEXT REQUEST message to which the UE shall reply with a MODIFY PDP CONTEXT ACCEPT message to ensure the context has been set up.

### Expected sequence

| Step | Direction |    | Message                                              | Comments                                                                                                                 |
|------|-----------|----|------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                      |                                                                                                                          |
| 1    |           | →  | DETACH REQUEST                                       | Only sent if the UE attaches at power-up, if not go to step 3.<br>Detach is performed by the UE using MMI or AT Commands |
| 2    |           | ←  | DETACH ACCEPT                                        | SS sends Detach Accept message.                                                                                          |
| 3    | UE        |    |                                                      | Initiate a context activation                                                                                            |
| 4    |           | →  | ATTACH REQUEST                                       | Request attach                                                                                                           |
| 5    |           | ←  | ATTACH ACCEPT                                        | Accept attach                                                                                                            |
| 6    |           | →  | ACTIVATE PDP CONTEXT REQUEST                         | Request a PDP context activation (with static PDP address)                                                               |
| 7    |           | ←  | ACTIVATE PDP CONTEXT ACCEPT                          | Accept the PDP context activation                                                                                        |
| 8    |           | SS |                                                      | Wait for T3380 seconds to ensure no further activate request messages come from the UE                                   |
| 9    |           | ←  | MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION) | SS sends a modify request to UE for the activated context                                                                |
| 10   |           | →  | MODIFY PDP CONTEXT ACCEPT (UE TO NETWORK DIRECTION)  | UE accepts the modification request from the SS to show context is activated                                             |

### Specific message contents

None.

#### 11.1.1.1.5 ————— Test requirements

When requesting a PDP context activation, the UE shall:

- initiate a PS ATTACH if one is not already active;
- when the SS responds to a PDP context activation request, initiated by the UE, with the requested QoS, the UE shall complete the PDP context activation procedure. To check if the PDP context activation was successful, SS shall request PDP context modification and UE shall accept it.

### ~~11.1.1.2 QoS offered by the network is a lower QoS~~

#### ~~11.1.1.2.1 QoS accepted by UE~~

##### ~~11.1.1.2.1.1 Definition~~

##### ~~11.1.1.2.1.2 Conformance requirement~~

~~In order to request a PDP context activation, the UE sends an ACTIVATE PDP CONTEXT REQUEST message to the network, enters the state PDP-ACTIVE-PENDING and starts timer T3380. If the QoS offered by the network is acceptable to UE, then upon receipt of the message ACTIVATE PDP CONTEXT ACCEPT, the UE shall stop timer T3380.~~

~~In GSM, the MS shall initiate establishment of the logical link for the LLC SAPI indicated by the network with the offered QoS and selected radio priority level, if no logical link has been already established for that SAPI.~~

~~In UMTS, both the network and the MS shall store the LLC SAPI and the radio priority in the PDP context.~~

#### ~~Reference~~

~~3GPP TS 24.008 clause 6.1.3.1.1.~~

##### ~~11.1.1.2.1.3 Test purpose~~

~~To test the behaviour of the UE when the SS responds to a PDP context activation request with a lower QoS than that requested.~~

##### ~~11.1.1.2.1.4 Method of test~~

#### ~~Initial conditions~~

~~System Simulator:~~

~~— 1 cell, default parameters.~~

~~User Equipment:~~

~~— The UE is in GMM state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.~~

#### ~~Related ICS/IXIT statements~~

~~— PS Supported ————— yes/no~~

~~— User setting of Minimum QoS supported — yes/no~~

~~— Method of setting minimum QoS~~

~~— Method of context activation~~

### Test procedure

The requested QoS and Minimum QoS are set. A context activation is requested by the user. On receipt of the ACTIVATE PDP CONTEXT REQUEST message an ACTIVATE PDP CONTEXT ACCEPT is returned by the SS with QoS lower than the requested but higher than or equal to the minimum. The SS then sends a MODIFY PDP CONTEXT REQUEST message and the UE shall respond with a MODIFY PDP CONTEXT ACCEPT message to confirm the context is active.

### Expected sequence

| Step | Direction |    | Message                                              | Comments                                                                  |
|------|-----------|----|------------------------------------------------------|---------------------------------------------------------------------------|
|      | UE        | SS |                                                      |                                                                           |
| 1    | UE        |    |                                                      | Initiate a context activation                                             |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST                         | Request a PDP context activation                                          |
| 3    |           | ←  | ACTIVATE PDP CONTEXT ACCEPT                          | Accept a PDP context activation                                           |
| 4    |           | ←  | MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION) | Send a modify request to UE for the activated context                     |
| 5    | →         |    | MODIFY PDP CONTEXT ACCEPT (UE TO NETWORK DIRECTION)  | Accept the modification request from network to show context is activated |

### Specific message contents

None.

#### 11.1.1.2.1.5 Test requirements

To pass the test UE shall:

- when the SS responds to a PDP context activation request, initiated by the UE, with the QoS lower than the requested but higher than or equal to the minimum, the UE shall complete the PDP context activation procedure.
- to see if the PDP context activation was successful, SS shall request PDP context modification and UE shall accept it.

#### 11.1.1.2.2 QoS rejected by UE

##### 11.1.1.2.2.1 Definition

##### 11.1.1.2.2.2 Conformance requirement

In order to request a PDP context activation, the UE sends an ACTIVATE PDP CONTEXT REQUEST message to the network.

Upon receipt of the message ACTIVATE PDP CONTEXT ACCEPT offering a QoS which is not acceptable to the UE, the UE shall initiate the PDP context deactivation procedure.

### Reference

3GPP TS 24.008 clause 6.1.3.1.1.

#### 11.1.1.2.2.3 Test purpose

To test the behaviour of the UE when the QoS offered by SS in response to a PDP context activation request is not acceptable to the UE.

#### 11.1.1.2.2.4 Method of test

##### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

##### Related ICS/IXIT statements

— PS Supported ————— yes/no

— User setting of Minimum QoS supported — yes/no

— Method of setting minimum QoS

— Method of context activation

##### Test procedure

The requested QoS and Minimum QoS are set. A PDP context activation is requested by the user. On receipt of the ACTIVATE PDP CONTEXT REQUEST message an ACTIVATE PDP CONTEXT ACCEPT message is returned by the SS with a QoS lower than the minimum. The UE shall then send a DEACTIVATE PDP CONTEXT REQUEST message. A DEACTIVATE PDP CONTEXT ACCEPT message will be sent in return by the SS.

##### Expected sequence

| Step | Direction |    | Message                        | Comments                            |
|------|-----------|----|--------------------------------|-------------------------------------|
|      | UE        | SS |                                |                                     |
| 1    |           | UE |                                | Initiate a context activation       |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST   | Request a PDP context activation    |
| 3    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT    | Accept the PDP context activation   |
| 4    | →         |    | DEACTIVATE PDP CONTEXT REQUEST | Deactivate the PDP context          |
| 5    | ←         |    | DEACTIVATE PDP CONTEXT ACCEPT  | Accept the PDP context deactivation |

##### Specific message contents

None.

#### 11.1.1.2.2.5 Test requirements

The UE shall reject the QoS offered by the SS in response to a PDP context activation request, if the QoS is not acceptable to the UE.

### 11.1.2 PDP context activation requested by the network, successful and unsuccessful

#### 11.1.2.1 Definition

This test needs to take into account the number of active PDP contexts supported simultaneously by the UE, to be able to test the response when all contexts are activated and the network tries to initiate a new context.

### 11.1.2.2 ~~Conformance requirement~~

1) ~~Upon receipt of a REQUEST PDP CONTEXT ACTIVATION message:~~

- ~~• If the UE accepts the request the UE shall then initiate the PDP context activation procedure.~~
- ~~• If the UE rejects the request, the UE shall send a REQUEST PDP CONTEXT ACTIVATION REJECT message with one of the following causes:~~

~~#26: insufficient resources;~~

~~#31: activation rejected, unspecified;~~

~~#40: feature not supported; or~~

~~#95 — 111: protocol errors.~~

2) ~~The UE shall not ignore the request.~~

3) ~~If the UE accepts the request, the ACTIVATE PDP CONTEXT REQUEST message sent by the UE shall contain the parameters requested by the network in the REQUEST PDP CONTEXT ACTIVATION message, except for the offered QoS which may be changed by the UE.~~

4) ~~Whenever a REQUEST PDP CONTEXT ACTIVATION message is received by the UE specifying a transaction identifier relating to a PDP context not in state PDP-INACTIVE, the UE shall locally deactivate the old PDP context relating to the received transaction identifier. Furthermore, the UE shall continue with the activation procedure of a new PDP context as indicated in the received message.~~

### Reference

3GPP TS 24.008 clauses 6.1.3.1.2, 6.1.3.1.4 and 8.3.2.f).

3GPP TS 27.060 clause 7.3.3.

### 11.1.2.3 ~~Test purpose~~

~~To test the behaviour of the UE upon receipt of a context activation request from the SS.~~

### 11.1.2.4 ~~Method of test~~

#### Initial conditions

System Simulator:

~~— 1 cell, default parameters.~~

User Equipment:

~~— The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.~~

#### Related ICS/IXIT statements

~~— PS Supported ————— yes/no~~

~~— Network requested PDP context activation supported — yes/no~~

~~— Number of network initiated PDP contexts supported~~

### Case 1

~~For a UE that supports PDP context activation requested by the network.~~

### Test procedure

A REQUEST PDP CONTEXT ACTIVATION message is sent by the SS. On receipt of the ACTIVATE PDP CONTEXT REQUEST message an ACTIVATE PDP CONTEXT ACCEPT message is returned by the SS. This is repeated until the maximum number of contexts supported by the UE is activated.

If all 256 PDP contexts are supported by the UE (extended TI mechanism in SM allows 256 PDP contexts), skip to step 7, request PDP context activation for an existing PDP context.

If maximum number of PDP contexts supported by the UE is less than 256, one more context should be requested by the SS. In response to this activation request the UE shall return a REQUEST PDP CONTEXT ACTIVATION REJECT message with cause set to 'insufficient resources', 'activation rejected, unspecified' or 'protocol errors' using cause values #26, #31, #40 or #95-111.

REQUEST PDP CONTEXT ACTIVATION message is then sent by the SS using currently activated context transaction identifier. The UE shall activate this context in place of the previous context.

### Expected sequence

| Step | Direction |    | Message                               | Comments                                                                                                                                                                             |
|------|-----------|----|---------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                                                                                                      |
| 1    |           | ←  | REQUEST PDP CONTEXT ACTIVATION        | SS sends Request a PDP context activation to UE                                                                                                                                      |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST          | UE replies with a Request PDP context activation                                                                                                                                     |
| 3    |           | ←  | ACTIVATE PDP CONTEXT ACCEPT           | SS accepts the PDP context activation                                                                                                                                                |
| 4    |           | SS |                                       | Steps 1-3 are repeated for the number of Network Initiated contexts supported.<br>NOTE: If all 256 contexts are supported steps 5 and 6 should not be performed.                     |
| 5    | ←         |    | REQUEST PDP CONTEXT ACTIVATION        | SS requests a PDP context activation                                                                                                                                                 |
| 6    | →         |    | REQUEST PDP CONTEXT ACTIVATION REJECT | The context activation request is rejected with cause 'insufficient resources', 'activation rejected, unspecified' or 'protocol errors' using cause values #26, #31, #40 or #95-111. |
| 7    |           | ←  | REQUEST PDP CONTEXT ACTIVATION        | SS requests a PDP context activation for an existing context with TI the same as one of the active PDP contexts                                                                      |
| 8    |           | UE |                                       | UE locally deactivates the old PDP context with the same TI value                                                                                                                    |
| 9    | →         |    | ACTIVATE PDP CONTEXT REQUEST          | UE continues with the activation of a new PDP context to replace deactivated context                                                                                                 |
| 10   |           | ←  | ACTIVATE PDP CONTEXT ACCEPT           | SS accepts the PDP context activation                                                                                                                                                |

### Case 2

For an UE that does not support PDP context activation requested by the network.

### Test procedure

A REQUEST PDP CONTEXT ACTIVATION message is sent by the SS. The UE shall then send a REQUEST PDP CONTEXT ACTIVATION REJECT message.

## Expected sequence

| Step | Direction |    | Message                               | Comments                                                                                                                                                                                                       |
|------|-----------|----|---------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                                                                                                                                |
| 1    |           | ←  | REQUEST PDP CONTEXT ACTIVATION        | Request a PDP context activation                                                                                                                                                                               |
| 2    |           | →  | REQUEST PDP CONTEXT ACTIVATION REJECT | Reject the PDP context activation request with cause 'insufficient resources' or 'feature not supported', 'activation rejected, unspecified' or 'protocol errors' using cause values #26, #31, #40 or #95-111. |

## Specific message contents

In Case 1 step 7, TI IE value is equal to the TI value of one of the active PDP contexts, Offered PDP address IE value and/or Access point name IE value are (is) different from the corresponding IE value(s) in the existing PDP context.

## 11.1.2.5 Test requirements

The UE that is configured to support one or more PDP contexts simultaneously shall:

- accept PDP context activation initiated by the SS if number of active contexts is lower than the maximum.
- locally deactivate the old PDP context when a REQUEST PDP CONTEXT ACTIVATION message is received, specifying a transaction identifier relating to an active PDP context and continue with the activation procedure of a new PDP context as indicated in the received message.

The UE that does not support PDP Context Activation (a number of active contexts supported by the UE is equal to maximum or UE does not support PDP context) shall reject PDP context activation initiated by the SS.

## 11.1.3 Abnormal Cases

## 11.1.3.1 T3380 Expiry

## 11.1.3.1.1 Definition

## 11.1.3.1.2 Conformance requirement

- 1) On the first expiry of the timer T3380, the UE shall re-send the PDP CONTEXT ACTIVATION REQUEST.
- 2) On the second expiry of the timer T3380, the UE shall re-send the PDP CONTEXT ACTIVATION REQUEST.
- 3) On the third expiry of the timer T3380, the UE shall re-send the PDP CONTEXT ACTIVATION REQUEST.
- 4) On the fourth expiry of the timer T3380, the UE shall re-send the PDP CONTEXT ACTIVATION REQUEST.
- 5) On the fifth expiry of the timer T3380, the UE shall release all resources possibly allocated for this invocation and shall abort the procedure; no automatic PDP context activation re-attempt shall be performed.

## Reference

3GPP TS 24.008 clause 6.1.3.1.5 a).

## 11.1.3.1.3 Test purpose

To test the behaviour of the UE when the SS does not reply to PDP CONTEXT ACTIVATION REQUEST.



#### 11.1.3.1.4 Method of test

##### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

##### Related ICS/IXIT statements

— PS Supported — yes/no

— Method of activating a context

##### Test procedure

A PDP context activation is requested by the user. The UE shall send the ACTIVATE PDP CONTEXT REQUEST message five times with T3380 seconds between each message. After this, no further ACTIVATE PDP CONTEXT REQUEST messages shall be sent by the UE.

##### Expected sequence

| Step | Direction |    | Message                      | Comments                                                                                             |
|------|-----------|----|------------------------------|------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                              |                                                                                                      |
| 1    | UE        |    |                              | Initiate a context activation                                                                        |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST | Request a PDP context activation                                                                     |
| 3    |           | SS |                              | T3380 seconds                                                                                        |
| 4    | →         |    | ACTIVATE PDP CONTEXT REQUEST | Request a PDP context activation                                                                     |
| 5    |           | SS |                              | T3380 seconds                                                                                        |
| 6    | →         |    | ACTIVATE PDP CONTEXT REQUEST | Request a PDP context activation                                                                     |
| 7    |           | SS |                              | T3380 seconds                                                                                        |
| 8    | →         |    | ACTIVATE PDP CONTEXT REQUEST | Request a PDP context activation                                                                     |
| 9    |           | SS |                              | T3380 seconds                                                                                        |
| 10   | →         |    | ACTIVATE PDP CONTEXT REQUEST | Request a PDP context activation                                                                     |
| 11   |           | SS |                              | Wait for T3380 seconds to ensure no further ACTIVATE PDP CONTEXT REQUEST messages are sent by the UE |

##### Specific message contents

None.

#### 11.1.3.1.5 Test requirements

UE shall re-send the ACTIVATE PDP CONTEXT REQUEST to SS five times in order to initiate PDP context, with expiry of timer T3380 between messages. After fifth try, UE shall send no more ACTIVATE PDP CONTEXT REQUEST to SS.

### ~~11.1.3.2 Collision of UE initiated and network requested PDP context activation~~

#### ~~11.1.3.2.1 Definition~~

~~This test needs to take into account the number of PDP contexts supported by the UE, to be able to test the response when the network tries to initiate a new context.~~

#### ~~11.1.3.2.2 Conformance requirement~~

~~A collision of a UE initiated and a network requested PDP context activation procedure is identified by the UE if a REQUEST PDP CONTEXT ACTIVATION message is received from the network after the UE has sent an ACTIVATE PDP CONTEXT REQUEST message, and the UE has not yet received an ACTIVATE PDP CONTEXT ACCEPT or ACTIVATE PDP CONTEXT REJECT message.~~

~~NOTE: In general, the UE is unable to test if the PDP type, PDP address and APN in the REQUEST PDP CONTEXT ACTIVATION message are the same as those for the PDN to which it is attempting to activate a context. This is because the UE may have omitted one or more of the parameters in the ACTIVATE PDP CONTEXT REQUEST message, since it is relying on default values to be provided by the network.~~

~~In the case of such a collision, the UE initiated PDP context activation shall take precedence over the network requested PDP context activation. If the UE is able to compare the PDP type, PDP address and APN requested in the ACTIVATE PDP CONTEXT REQUEST message with those requested in the REQUEST PDP CONTEXT ACTIVATION message and these parameters are equal, then the UE shall discard the REQUEST PDP CONTEXT ACTIVATION message and shall wait for the network response to its ACTIVATE PDP CONTEXT REQUEST message. If the UE is not able to compare the PDP type, PDP address, and APN requested in the ACTIVATE PDP CONTEXT REQUEST message with those requested in the REQUEST PDP CONTEXT ACTIVATION message, then the UE shall send a REQUEST PDP CONTEXT ACTIVATION REJECT message with the cause 'insufficient resources' to the network, and wait for an ACTIVATE PDP CONTEXT ACCEPT message.~~

#### Reference

3GPP TS 24.008 clause 6.1.3.1.5 b), case: Static PDP address collision detected within the UE.

#### ~~11.1.3.2.3 Test purpose~~

~~To test the behaviour of the UE when there is a collision between an UE initiated and network requested PDP context activation detected by the UE.~~

#### ~~11.1.3.2.4 Method of test~~

##### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

##### Related ICS/IXIT statements

— PS Supported ————— yes/no

— Network requested PDP context activation supported — yes/no

— Method of PDP context activation

## Case 1

For an UE that supports PDP context activation requested by the network.

### Test procedure

A PDP context activation is requested by the user with a static PDP address. After receipt of the ACTIVATE PDP CONTEXT REQUEST message the SS sends a REQUEST PDP CONTEXT ACTIVATION message followed by an ACTIVATE PDP CONTEXT ACCEPT message in a time less than T3380 (Use T3380/2). The UE shall send no messages within this time.

### Expected sequence

| Step | Direction |    | Message                        | Comments                                                                            |
|------|-----------|----|--------------------------------|-------------------------------------------------------------------------------------|
|      | UE        | SS |                                |                                                                                     |
| 1    | UE        |    |                                | Initiate a context activation                                                       |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST   | Request a PDP context activation (with static PDP address)                          |
| 3    | ←         |    | REQUEST PDP CONTEXT ACTIVATION | Request a PDP context activation request                                            |
| 4    |           | SS |                                | Wait for T3380/2 seconds to ensure UE does not re-send ACTIVATE PDP CONTEXT REQUEST |
| 5    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT    | Accept the PDP context activation                                                   |

## Case 2

For a UE that does not support PDP context activation requested by the network.

### Test procedure

A PDP context activation is requested by the user. After receipt of the ACTIVATE PDP CONTEXT REQUEST message the SS sends a REQUEST PDP CONTEXT ACTIVATION message. The UE shall send a REQUEST PDP CONTEXT ACTIVATION REJECT message with cause set to 'insufficient resources'. The SS then sends an ACTIVATE PDP CONTEXT ACCEPT.

### Expected sequence

| Step | Direction |    | Message                               | Comments                               |
|------|-----------|----|---------------------------------------|----------------------------------------|
|      | UE        | SS |                                       |                                        |
| 1    | UE        |    |                                       | Initiate a context activation          |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST          | Request a PDP context activation       |
| 3    | ←         |    | REQUEST PDP CONTEXT ACTIVATION        | Request a PDP context activation       |
| 4    | →         |    | REQUEST PDP CONTEXT ACTIVATION REJECT | Cause set to 'insufficient resources'. |
| 5    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT           | Accept the PDP context activation      |

### Specific message contents

For Case 1 and Case 2:

Step 2: ACTIVATE PDP CONTEXT REQUEST message contains PDP address and APN IEs.

Step 3: REQUEST PDPD CONTEXT ACTIVATION message contains the same PDP address and APN values as in Step 2.

### ~~11.1.3.2.5 Test requirements~~

~~In the case of such collision,~~

- ~~— UE that supports PDP context activation requested by the network shall discard the REQUEST PDP CONTEXT ACTIVATION message from SS and wait for an ACTIVATE PDP CONTEXT ACCEPT message.~~
- ~~— UE that does not support PDP context activation requested by the network shall reject PDP context activation initiated by the SS.~~

### ~~11.1.3.3 Network initiated PDP context activation request for an already activated PDP context (on the UE side)~~

#### ~~11.1.3.3.1 Definition~~

#### ~~11.1.3.3.2 Conformance requirement~~

~~If the UE receives a REQUEST PDP CONTEXT ACTIVATION message with the same combination of APN, PDP type and PDP address as an already activated PDP context, the UE shall deactivate the existing PDP context and, if any, all the linked PDP contexts (matching the combination of APN, PDP type and PDP address) locally without notification to the network and proceed with the requested PDP context activation.~~

#### ~~Reference~~

~~3GPP TS 24.008 clause 6.1.3.1.5 d).~~

#### ~~11.1.3.3.3 Test purpose~~

~~To test the behaviour of the UE when it detects a network initiated PDP context activation for the PDP context already activated on the UE side.~~

#### ~~11.1.3.3.4 Method of test~~

#### ~~Initial conditions~~

~~System Simulator:~~

- ~~— 1 cell, default parameters.~~

~~User Equipment:~~

- ~~— The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.~~

#### ~~Related ICS/IXIT statements~~

~~PS Supported ————— yes/no~~

~~Method of PDP context activation~~

#### ~~Test procedure~~

~~A PDP context activation is requested by the user. SS accepts PDP context activation. Secondary PDP context activation is requested by the user. SS accepts secondary PDP context activation. SS sends a REQUEST PDP CONTEXT ACTIVATION message with the same combination of APN, PDP type and PDP address as an already activated PDP context. The UE deactivates the existing PDP context and linked secondary PDP context (matching the combination of APN, PDP type and PDP address) locally without notification to the SS and proceeds with the requested PDP context activation.~~

## Expected sequence

| Step | Direction |    | Message                                | Comments                                                                                                                     |
|------|-----------|----|----------------------------------------|------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                        |                                                                                                                              |
| 1    | UE        |    |                                        | Initiate a context activation                                                                                                |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST           | UE requests a PDP context activation                                                                                         |
| 3    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT            | SS accepts the PDP context activation                                                                                        |
| 4    | →         |    | ACTIVATE SECONDARY PDP CONTEXT REQUEST | UE requests a secondary PDP context activation                                                                               |
| 5    | ←         |    | ACTIVATE SECONDARY PDP CONTEXT ACCEPT  | SS accepts the secondary PDP context activation                                                                              |
| 6    | ←         |    | REQUEST PDP CONTEXT ACTIVATION         | SS requests a PDP context activation with the same combination of APN, PDP type and PDP address as the activated PDP context |
| 7    | UE        |    |                                        | UE locally deactivates the activated PDP context and the secondary PDP context                                               |
| 9    | →         |    | ACTIVATE PDP CONTEXT REQUEST           | UE replies with a Request PDP context activation                                                                             |
| 10   | ←         |    | ACTIVATE PDP CONTEXT ACCEPT            | SS accepts the PDP context activation                                                                                        |

## Specific message contents

None.

## 11.1.3.3.5—Test requirements

When inconsistency of PDP context between the UE and network is detected by the UE, then local synchronisation procedure shall be initiated in the UE. The PDP context and all (if any) linked contexts are implicitly deactivated and the new request shall be proceeded.

## 11.1.4—Secondary PDP context activation procedures

## 11.1.4.1—Successful Secondary PDP Context Activation Procedure Initiated by the UE

## 11.1.4.1.1—QoS Offered by Network is the QoS Requested

## 11.1.4.1.1.1—Definition

## 11.1.4.1.1.2—Conformance requirement

In order to request a secondary PDP context activation with the same PDP address and APN as an already active PDP context, the UE shall send an ACTIVATE SECONDARY PDP CONTEXT REQUEST message to the network, enter the state PDP ACTIVE-PENDING and start timer T3380. The message contains the selected NSAPI, a QoS profile, a requested LLC SAPI and the linked TI.

If the QoS offered by the network is the same as the QoS requested by the UE, then upon receipt of the message ACTIVATE SECONDARY PDP CONTEXT ACCEPT, the UE shall stop timer T3380.

In GSM the UE shall initiate establishment of the logical link for the LLC SAPI indicated by the network, with the offered QoS and selected radio priority level, if no logical link has been already established for that SAPI.

Although not used in UMTS, LLC SAPI shall be included in the messages, in order to support handover between UMTS and GSM networks.

## Reference

3GPP TS 24.008 clauses 6.1.3.2 and 6.1.3.2.1.

## 11.1.4.1.1.3 ——— Test purpose

To test the behaviour of the UE when SS responds to a Secondary PDP context activation request with the requested QoS.

## 11.1.4.1.1.4 ——— Method of test

## Initial conditions

System Simulator:

—— 1 cell, default parameters.

User Equipment:

—— The UE and is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

## Related ICS/IXIT statements

—— PS Supported ——— yes/no

—— Method of context activation

## Test procedure

A PDP context activation is requested by the user and accepted by the SS. Secondary PDP context activation is requested by the user. On receipt of the ACTIVATE SECONDARY PDP CONTEXT REQUEST message an ACTIVATE SECONDARY PDP CONTEXT ACCEPT is returned by the SS with the same requested QoS. The SS then waits for T3380 seconds to ensure T3380 has been stopped and no more ACTIVATE SECONDARY PDP CONTEXT REQUEST messages are sent by the UE. The SS then sends a MODIFY PDP CONTEXT REQUEST message to which the UE shall reply with a MODIFY PDP CONTEXT ACCEPT message to ensure the context has been set-up.

## Expected sequence

| Step | Direction |    | Message                                              | Comments                                                                               |
|------|-----------|----|------------------------------------------------------|----------------------------------------------------------------------------------------|
|      | UE        | SS |                                                      |                                                                                        |
| 1    |           | UE |                                                      | Initiate a PDP context activation                                                      |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST                         | Activate a PDP context                                                                 |
| 3    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT                          | Accept the PDP context                                                                 |
| 4    |           | UE |                                                      | Initiate a secondary PDP context activation                                            |
| 5    | →         |    | ACTIVATE SECONDARY PDP CONTEXT REQUEST               | Request a Secondary PDP context activation                                             |
| 6    | ←         |    | ACTIVATE SECONDARY PDP CONTEXT ACCEPT                | Accept the Secondary PDP context activation                                            |
| 7    |           | SS |                                                      | Wait for T3380 seconds to ensure no further activate request messages come from the UE |
| 8    | ←         |    | MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION) | SS sends a modify request to UE for the activated context                              |
| 9    | →         |    | MODIFY PDP CONTEXT ACCEPT (UE TO NETWORK DIRECTION)  | UE accepts the modification request from the network to show context is activated      |

### Specific message contents

The Linked TI information element in ~~ACTIVATE SECONDARY PDP CONTEXT REQUEST~~ message specifies the TI for the PDP context already activated. The SS can derive PDP address for the secondary PDP context from Linked TI.

#### ~~11.1.4.1.1.5~~ Test requirements

To pass the test the UE shall:

- when the SS responds to a Secondary PDP context activation request initiated by the UE, with the requested QoS, the UE shall complete the Secondary PDP context activation procedure. To check if the Secondary PDP context activation was successful, SS shall request PDP context modification and UE shall accept it.

#### ~~11.1.4.1.2~~ QoS Offered by Network is a lower QoS

##### ~~11.1.4.1.2.1~~ QoS accepted by UE

###### ~~11.1.4.1.2.1.1~~ Definition

This test can only be performed if minimum QoS can be set by the user.

###### ~~11.1.4.1.2.1.2~~ Conformance requirement

In order to request a Secondary PDP context activation with the same PDP address and APN as an already active PDP context, the UE shall send an ~~ACTIVATE SECONDARY PDP CONTEXT REQUEST~~ message to the network, enter the state ~~PDP ACTIVE-PENDING~~ and start timer T3380. If the QoS offered by the network is acceptable to UE, then upon receipt of the message ~~ACTIVATE SECONDARY PDP CONTEXT ACCEPT~~ the UE shall stop timer T3380.

In GSM the UE shall initiate establishment of the logical link for the LLC SAPI indicated by the network, with the offered QoS and selected radio priority level, if no logical link has been already established for that SAPI.

### Reference

3GPP TS 24.008 clauses 6.1.3.2 and 6.1.3.2.1.

###### ~~11.1.4.1.2.1.3~~ Test purpose

To test the behaviour of the UE when the SS responds to a Secondary PDP context activation request with a lower QoS than that requested.

###### ~~11.1.4.1.2.1.4~~ Method of test

### Initial conditions

System Simulator:

- 1 cell, default parameters.

User Equipment:

- The UE is in GMM state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

### Related ICS/IXIT statements

- PS Supported ————— yes/no
- User setting of Minimum QoS supported — yes/no
- Method of setting minimum QoS
- Method of context activation

## Test procedure

The requested QoS and Minimum QoS are set. A PDP context activation is requested by the user and accepted by the SS. Secondary context activation is requested by the user. On receipt of the ACTIVATE SECONDARY PDP CONTEXT REQUEST message an ACTIVATE SECONDARY PDP CONTEXT ACCEPT is returned by the SS with a QoS lower than the requested but higher than or equal to the minimum. The SS then sends a MODIFY PDP CONTEXT REQUEST message and the UE shall respond with a MODIFY PDP CONTEXT ACCEPT message to confirm the context is active.

## Expected sequence

| Step | Direction |    | Message                                              | Comments                                                                  |
|------|-----------|----|------------------------------------------------------|---------------------------------------------------------------------------|
|      | UE        | SS |                                                      |                                                                           |
| 1    |           | UE |                                                      | Initiate a PDP context activation                                         |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST                         | Activate a PDP context                                                    |
| 3    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT                          | Accept the PDP context                                                    |
| 4    |           | UE |                                                      | Initiate a secondary PDP context activation                               |
| 5    | →         |    | ACTIVATE SECONDARY PDP CONTEXT REQUEST               | Request a Secondary PDP context activation                                |
| 6    | ←         |    | ACTIVATE SECONDARY PDP CONTEXT ACCEPT                | Accept a Secondary PDP context activation                                 |
| 7    | ←         |    | MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION) | Send a modify request to UE for the activated context                     |
| 8    | →         |    | MODIFY PDP CONTEXT ACCEPT (UE TO NETWORK DIRECTION)  | Accept the modification request from network to show context is activated |

## Specific message contents

None.

### 11.1.4.1.2.1.5 — Test requirements

To pass the test when the SS responds to a Secondary PDP context activation request, initiated by the UE, with the QoS lower than the requested but higher than or equal to the minimum, the UE shall complete the Secondary PDP context activation procedure. To see if the PDP context activation was successful, SS shall request PDP context modification and UE shall accept it.

### 11.1.4.1.2.2 — QoS rejected by UE

#### 11.1.4.1.2.2.1 — Definition

This test can only be performed if minimum QoS can be set by the user.

#### 11.1.4.1.2.2.2 — Conformance requirement

In order to request a Secondary PDP context activation with the same PDP address and APN as an already active PDP context, the UE shall send an ACTIVATE SECONDARY PDP CONTEXT REQUEST message to the network.

Upon receipt of the message ACTIVATE SECONDARY PDP CONTEXT ACCEPT offering a QoS which is not acceptable to the UE, the UE shall initiate the PDP context deactivation procedure.

## Reference

3GPP TS 24.008 clauses 6.1.3.2 and 6.1.3.2.1.



~~11.1.4.1.2.2.3 Test purpose~~

~~To test the behaviour of the UE when the QoS, offered by SS in response to a Secondary PDP context activation request is not acceptable to the UE.~~

~~11.1.4.1.2.2.4 Method of test~~~~Initial conditions~~

~~System Simulator:~~

~~— 1 cell, default parameters.~~

~~User Equipment:~~

~~— The UE is in GMM state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.~~

~~Related ICS/IXIT statements~~

~~— PS Supported ————— yes/no~~

~~— User setting of Minimum QoS supported — yes/no~~

~~— Method of setting minimum QoS~~

~~— Method of context activation~~

~~Test procedure~~

~~The requested QoS and Minimum QoS are set. PDP context activation is requested by the user and accepted by the SS. Secondary PDP context activation is requested by the user. On receipt of the ACTIVATE SECONDARY PDP CONTEXT REQUEST message an ACTIVATE SECONDARY PDP CONTEXT ACCEPT message is returned by the SS with the QoS lower than the minimum. The UE shall then send a DEACTIVATE PDP CONTEXT REQUEST message for the secondary PDP context. A DEACTIVATE PDP CONTEXT ACCEPT message will be sent in return by the SS.~~

~~Expected sequence~~

| Step | Direction |    | Message                                | Comments                                                                    |
|------|-----------|----|----------------------------------------|-----------------------------------------------------------------------------|
|      | UE        | SS |                                        |                                                                             |
| 1    | UE        |    |                                        | Initiate a PDP context activation                                           |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST           | Activate a PDP context                                                      |
| 3    |           | ←  | ACTIVATE PDP CONTEXT ACCEPT            | Accept the PDP context                                                      |
| 4    | UE        |    |                                        | Initiate a secondary PDP context activation                                 |
| 5    | →         |    | ACTIVATE SECONDARY PDP CONTEXT REQUEST | Request a Secondary PDP context activation                                  |
| 6    |           | ←  | ACTIVATE SECONDARY PDP CONTEXT ACCEPT  | Accept the Secondary PDP context activation with QoS lower than Minimum QoS |
| 7    | →         |    | DEACTIVATE PDP CONTEXT REQUEST         | Request deactivation of the secondary PDP context                           |
| 8    |           | ←  | DEACTIVATE PDP CONTEXT ACCEPT          | Accept the PDP context deactivation                                         |

~~Specific message contents~~

~~In step 3 *Negotiated QoS* IE is equal to *Requested QoS* IE in step 2 and step 5.~~

~~In step 7 SM cause IE shall have value #37: QoS not accepted.~~

Tear down indicator IE shall not be included in the DEACTIVATE PDP CONTEXT REQUEST message because only the PDP context for this specific TI shall be deactivated.

#### ~~11.1.4.1.2.2.5~~ ——— Test requirements

The UE shall reject the QoS offered by the SS in response to a Secondary PDP context activation request, if the QoS is not acceptable to the UE.

#### ~~11.1.4.1.2.3~~ ——— LLC SAPI rejected by the UE

##### ~~11.1.4.1.2.3.1~~ Definition

This test can only be performed if LLC SAPI can be set by the user.

##### ~~11.1.4.1.2.3.2~~ ——— Conformance Requirement

In order to request a PDP context activation with the same PDP address and APN as an already active PDP context, the UE shall send an ACTIVATE SECONDARY PDP CONTEXT REQUEST message to the network.

Upon receipt of an ACTIVATE SECONDARY PDP CONTEXT REQUEST, the network shall select a radio priority level based on the QoS negotiated and shall reply with an ACTIVATE SECONDARY PDP CONTEXT ACCEPT message, if the request can be accepted.

Upon receipt of the message ACTIVATE SECONDARY PDP CONTEXT ACCEPT, the UE shall stop timer T3380 and enter the state PDP-ACTIVE.

In GSM the UE shall initiate establishment of the logical link for the LLC SAPI indicated by the network if no logical link has been already established for that SAPI. If the LLC SAPI indicated by the network can not be supported by the UE, the UE shall initiate the PDP context deactivation procedure.

##### ~~11.1.4.1.2.3.3~~ ——— Test Purpose

To verify the behaviour of the UE when the network responds to the ACTIVATE SECONDARY PDP CONTEXT REQUEST message with a negotiated LLC SAPI which is not supported by the UE.

#### Reference

3GPP TS 24.008, clause 6.1.3.2.1.

#### ~~11.1.4.1.2.3.4~~ ——— Method of test

#### Initial conditions

System Simulator:

—— 1 cell, default parameters.

User Equipment:

—— The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

#### Related ICS/IXIT statements

—— PS Supported ————— yes/no

—— User setting of LLC SAPI supported ——— yes/no

—— Method of setting LLC SAPI

—— Method of context activation

### Test procedure

The requested LLC SAPI is set. This is the only LLC SAPI supported by the UE. A PDP context activation is requested by the user and accepted by the SS. A secondary PDP context activation is requested by the user. On receipt of the ACTIVATE SECONDARY PDP CONTEXT REQUEST message an ACTIVATE SECONDARY PDP CONTEXT ACCEPT message is returned by the SS with the LLC SAPI not supported by the UE. The UE shall then send a DEACTIVATE PDP CONTEXT REQUEST message for the secondary PDP context. A DEACTIVATE PDP CONTEXT ACCEPT message will be sent in return by the SS.

### Expected sequence

| Step | Direction |    | Message                                | Comments                                                                          |
|------|-----------|----|----------------------------------------|-----------------------------------------------------------------------------------|
|      | UE        | SS |                                        |                                                                                   |
| 1    | UE        |    |                                        | Initiate a PDP context activation                                                 |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST           | Activate a PDP context                                                            |
| 3    |           | ←  | ACTIVATE PDP CONTEXT ACCEPT            | Accept the PDP context                                                            |
| 4    | UE        |    |                                        | Initiate a secondary PDP context activation                                       |
| 5    | →         |    | ACTIVATE SECONDARY PDP CONTEXT REQUEST | Request a Secondary PDP context activation                                        |
| 6    |           | ←  | ACTIVATE SECONDARY PDP CONTEXT ACCEPT  | Accept the Secondary PDP context activation with LLC SAPI not supported by the UE |
| 7    | →         |    | DEACTIVATE PDP CONTEXT REQUEST         | Request deactivation of all PDP contexts                                          |
| 8    |           | ←  | DEACTIVATE PDP CONTEXT ACCEPT          | Accept the PDP context deactivation                                               |

### Specific message contents

In step 3 *Negotiated LLC SAPI* IE is equal to *Requested LLC SAPI* IE in step 2 and step 5.

In step 7 SM cause IE shall have value #25: LLC or SNDCP failure. Also, *Tear down indicator* IE shall be included in the DEACTIVATE PDP CONTEXT REQUEST message to deactivate all PDP contexts for this PDP address.

## 11.1.4.2 Unsuccessful Secondary PDP Context Activation Procedure Initiated by the UE

### 11.1.4.2.1 Definition

### 11.1.4.2.2 Conformance requirement

Upon receipt of an ACTIVATE SECONDARY PDP CONTEXT REQUEST message, the network may reject the UE initiated PDP context activation by sending an ACTIVATE SECONDARY PDP CONTEXT REJECT message to the UE. Upon receipt of an ACTIVATE SECONDARY PDP CONTEXT REJECT message, the UE shall stop timer T3380 and enter the state PDP-INACTIVE.

### Reference

3GPP TS 24.008 clauses 6.1.3.2 and 6.1.3.2.2.

### 11.1.4.2.3 Test purpose

To test the behaviour of the UE when network rejects the UE initiated Secondary PDP context activation.

#### 11.1.4.2.4 Method of test

##### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE and is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

##### Related ICS/IXIT statements

— PS Supported ————— yes/no

— Method of context activation

##### Test procedure

A PDP context activation is requested by the user and accepted by the SS. Secondary context activation is requested by the user. On receipt of the ACTIVATE SECONDARY PDP CONTEXT REQUEST message from the UE, an ACTIVATE SECONDARY PDP CONTEXT REJECT with cause #43 'unknown PDP context' is returned by the SS. SS shall wait for T3380 seconds to ensure that the UE sends no more ACTIVATE SECONDARY PDP CONTEXT REQUEST messages.

##### Expected sequence

| Step | Direction |    | Message                                | Comments                                                                               |
|------|-----------|----|----------------------------------------|----------------------------------------------------------------------------------------|
|      | UE        | SS |                                        |                                                                                        |
| 1    |           | UE |                                        | Initiate a PDP context activation                                                      |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST           | Activate a PDP context                                                                 |
| 3    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT            | Accept the PDP context                                                                 |
| 4    |           | UE |                                        | Initiate a secondary PDP context activation                                            |
| 5    | →         |    | ACTIVATE SECONDARY PDP CONTEXT REQUEST | Request a Secondary PDP context activation                                             |
| 6    | ←         |    | ACTIVATE SECONDARY PDP CONTEXT REJECT  | SS rejects the Secondary PDP context activation with cause '#43: unknown PDP context'  |
| 7    |           | SS |                                        | Wait for T3380 seconds to ensure no further activate request messages come from the UE |

##### Specific message contents

Step 5. The *Linked TI* information element specifies the TI which is different from the TI in the PDP context activated in steps 1-3.

#### 11.1.4.2.5 Test requirements

After a secondary PDP context activation being rejected by the network, the UE shall not re-send the ACTIVATE SECONDARY PDP CONTEXT REQUEST message.

### ~~11.1.4.3 Abnormal cases~~

#### ~~11.1.4.3.1 T3380 Expiry~~

##### ~~11.1.4.3.1.1 Definition~~

##### ~~11.1.4.3.1.2 Conformance requirement~~

- ~~1) On the first expiry of the timer T3380, the UE shall re-send the ACTIVATE SECONDARY PDP CONTEXT REQUEST.~~
- ~~2) On the second expiry of the timer T3380, the UE shall re-send the ACTIVATE SECONDARY PDP CONTEXT REQUEST.~~
- ~~3) On the third expiry of the timer T3380, the UE shall re-send the ACTIVATE SECONDARY PDP CONTEXT REQUEST.~~
- ~~4) On the fourth expiry of the timer T3380, the UE shall re-send the ACTIVATE SECONDARY PDP CONTEXT REQUEST.~~
- ~~5) On the fifth expiry of the timer T3380, the UE shall release all resources possibly allocated for this invocation and shall abort the procedure; automatic secondary PDP context activation re-attempt shall be performed.~~

### Reference

3GPP TS 24.008 clause 6.1.3.2.3 a).

#### ~~11.1.4.3.1.3 Test purpose~~

To test the behaviour of the UE when the SS does not reply to ACTIVATE SECONDARY PDP CONTEXT REQUEST message.

#### ~~11.1.4.3.1.4 Method of test~~

### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

### Related ICS/IXIT statements

— PS Supported ————— yes/no

— Method of activating a context

### Test procedure

A PDP context is activated by the user and accepted by the SS. Secondary PDP context activation is requested by the user. The UE shall send ACTIVATE SECONDARY PDP CONTEXT REQUEST message five times with T3380 seconds between each message. After this, no further ACTIVATE SECONDARY PDP CONTEXT REQUEST messages shall be sent by the UE.

## Expected sequence

| Step | Direction |    | Message                                | Comments                                                                                                       |
|------|-----------|----|----------------------------------------|----------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                        |                                                                                                                |
| 1    | UE        |    |                                        | Initiate a PDP context activation                                                                              |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST           | Activate a PDP context                                                                                         |
| 3    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT            | Accept the PDP context                                                                                         |
| 4    | UE        |    |                                        | Initiate a secondary PDP context activation                                                                    |
| 5    | →         |    | ACTIVATE SECONDARY PDP CONTEXT REQUEST | Request a Secondary PDP context activation                                                                     |
| 6    | SS        |    |                                        | T3380 seconds                                                                                                  |
| 7    | →         |    | ACTIVATE SECONDARY PDP CONTEXT REQUEST | Request the Secondary PDP context activation                                                                   |
| 8    | SS        |    |                                        | T3380 seconds                                                                                                  |
| 9    | →         |    | ACTIVATE SECONDARY PDP CONTEXT REQUEST | Request the Secondary PDP context activation                                                                   |
| 10   | SS        |    |                                        | T3380 seconds                                                                                                  |
| 11   | →         |    | ACTIVATE SECONDARY PDP CONTEXT REQUEST | Request the Secondary PDP context activation                                                                   |
| 12   | SS        |    |                                        | T3380 seconds                                                                                                  |
| 13   | →         |    | ACTIVATE SECONDARY PDP CONTEXT REQUEST | Request the Secondary PDP context activation                                                                   |
| 14   | SS        |    |                                        | Wait for T3380 seconds to ensure no further ACTIVATE SECONDARY PDP CONTEXT REQUEST messages are sent by the UE |

## Specific message contents

None.

## 11.1.4.3.1.5 Test requirements

UE shall re-send the ACTIVATE SECONDARY PDP CONTEXT REQUEST to SS five times in order to initiate a Secondary PDP context, with expiry of timer T3380 between messages. After fifth try, UE shall send no more ACTIVATE SECONDARY PDP CONTEXT REQUEST messages to SS.

## 11.2 PDP context modification procedure

## 11.2.1 Network initiated PDP context modification

## 11.2.1.1 Definition

This test can only be performed if minimum QoS can be set by the user.

## 11.2.1.2 Conformance requirement

1) Upon receipt of a MODIFY PDP CONTEXT REQUEST message

- If the UE can accept the modification requested, the UE shall reply with the MODIFY PDP CONTEXT ACCEPT message.
- If the UE is unable to accept the modification requested, the UE shall initiate the PDP context deactivation procedure for the NSAPI that has been indicated in the message MODIFY PDP CONTEXT REQUEST—the reject cause IE value of the DEACTIVATE PDP CONTEXT REQUEST message shall indicate "QoS not accepted".

2) The UE shall either accept the modification request or deactivate the PDP context, it shall not ignore the modification request.

## Reference

3GPP TS 24.008 clauses 6.1.3.3 and 6.1.3.3.1.

### 11.2.1.3 Test purpose

To test the behaviour of the UE upon receipt of a MODIFY PDP CONTEXT REQUEST message from SS.

### 11.2.1.4 Method of test

#### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in GMM state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

#### Related ICS/IXIT statements

— PS Supported — yes/no

— User setting of Minimum QoS supported — yes/no

— Method of setting minimum QoS

— Method of activating a PDP context

#### Test procedure

A PDP context is activated by the user and accepted by the SS. A MODIFY PDP CONTEXT REQUEST message is then sent to the UE with a QoS that is acceptable to the UE (higher than or equal to the minimum QoS set in the UE). The UE shall send a MODIFY PDP CONTEXT ACCEPT message in return. A MODIFY PDP CONTEXT REQUEST message is then sent to the UE with a QoS that is not acceptable to the UE (lower than the minimum QoS set in the UE). The UE shall send a DEACTIVATE PDP CONTEXT REQUEST message in return.

#### Expected sequence

| Step | Direction |    | Message                                              | Comments                                                                                                  |
|------|-----------|----|------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                      |                                                                                                           |
| 1    |           | UE |                                                      | Initiate a PDP context activation                                                                         |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST                         | Activate the PDP context                                                                                  |
| 3    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT                          | Accept the PDP context                                                                                    |
| 4    | ←         |    | MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION) | Request the modification of a PDP context, with QoS higher than or equal to the minimum QoS set in the UE |
| 5    | →         |    | MODIFY PDP CONTEXT ACCEPT (UE TO NETWORK DIRECTION)  | Accept the PDP context modification                                                                       |
| 6    | ←         |    | MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION) | Request the modification of a PDP context, QoS lower than the minimum QoS set in the UE                   |
| 7    | →         |    | DEACTIVATE PDP CONTEXT REQUEST                       | Initiate the PDP context deactivation. Cause set to 'QoS not acceptable'                                  |
| 8    | ←         |    | DEACTIVATE PDP CONTEXT ACCEPT                        | Accept the PDP context deactivation                                                                       |

## Specific message contents

None.

### 11.2.1.5 Test requirements

The UE shall:

- Accept PDP context modification initiated by the SS if QoS is higher than or equal to the minimum QoS set in the UE;
- Reject PDP context modification initiated by the SS if QoS is lower than the minimum QoS set in the UE.

## 11.2.2 UE initiated PDP context modification

### 11.2.2.1 UE initiated PDP Context Modification accepted by network

#### 11.2.2.1.1 Definition

This test can only be performed if minimum QoS can be set by the user.

#### 11.2.2.1.2 Conformance requirement

In order to initiate the procedure, the UE sends the MODIFY PDP CONTEXT REQUEST message to the network, enters the state PDP-MODIFY-PENDING and starts timer T3381. The message may contain the requested new QoS and/or the TFT and the requested LLC SAPI (used in GSM).

Upon receipt of the MODIFY PDP CONTEXT REQUEST message, the network may reply with the MODIFY PDP CONTEXT ACCEPT message in order to accept the context modification. The reply message may contain the negotiated QoS and the radio priority level based on the new QoS profile and the negotiated LLC SAPI, that shall be used in GSM by the logical link.

Upon receipt of the MODIFY PDP CONTEXT ACCEPT message, the UE shall stop the timer T3381. If the offered QoS parameters received from the network differs from the QoS requested by the UE, the UE shall either accept the negotiated QoS or initiate the PDP context deactivation procedure.

## Reference

3GPP TS 24.008 clauses 6.1.3.3 and 6.1.3.3.2.

#### 11.2.2.1.3 Test purpose

To test the behaviour of the UE upon receipt of a MODIFY PDP CONTEXT ACCEPT message from the network with

- Requested QoS;
- QoS higher than or equal to the minimum QoS set in the UE;
- QoS lower than the minimum QoS set in the UE.

#### 11.2.2.1.4 Method of test

## Initial conditions

System Simulator:

- 1 cell, default parameters.

User Equipment:

- The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.



### Related ICS/IXIT statements

- PS Supported—yes/no
- User setting of Minimum QoS supported—yes/no
- Method of setting minimum QoS
- Method of activating a PDP context

### Test procedure

A PDP context is activated by the user and accepted by the SS. The UE initiates a PDP context modification by sending a MODIFY PDP CONTEXT REQUEST message with new QoS. The SS accepts the context modification and replies with the MODIFY PDP CONTEXT ACCEPT message with the QoS requested.

The UE initiates new PDP context modification with higher QoS. The SS is unable to provide requested QoS, so it replies by sending MODIFY PDP CONTEXT ACCEPT message with new QoS that is lower than requested but still acceptable to the UE (higher than or equal to the minimum QoS set in the UE).

The UE initiates new PDP context modification with new QoS. The SS is unable to provide requested QoS, so it replies by sending MODIFY PDP CONTEXT ACCEPT message with QoS that is not acceptable to the UE (lower than the minimum QoS set in the UE). The UE shall send a DEACTIVATE PDP CONTEXT REQUEST message in return and SS shall respond with a DEACTIVATE PDP CONTEXT ACCEPT message.

### Expected sequence

| Step | Direction |    | Message                                              | Comments                                                                           |
|------|-----------|----|------------------------------------------------------|------------------------------------------------------------------------------------|
|      | UE        | SS |                                                      |                                                                                    |
| 1    | UE        |    |                                                      | Initiate a PDP context activation                                                  |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST                         | Activate a PDP context                                                             |
| 3    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT                          | Accept the PDP context                                                             |
| 4    | →         |    | MODIFY PDP CONTEXT REQUEST (UE TO NETWORK DIRECTION) | Request the modification of a PDP context, with new QoS                            |
| 5    | ←         |    | MODIFY PDP CONTEXT ACCEPT (NETWORK TO UE DIRECTION)  | Accept the PDP context modification with QoS requested                             |
| 6    | →         |    | MODIFY PDP CONTEXT REQUEST (UE TO NETWORK DIRECTION) | Request the modification of a PDP context, with new QoS                            |
| 7    | ←         |    | MODIFY PDP CONTEXT ACCEPT (NETWORK TO UE DIRECTION)  | Accept the PDP context modification with QoS higher than the minimum QoS set in UE |
| 8    | →         |    | MODIFY PDP CONTEXT REQUEST (UE TO NETWORK DIRECTION) | Request the modification of a PDP context, with new QoS                            |
| 9    | ←         |    | MODIFY PDP CONTEXT ACCEPT (NETWORK TO UE DIRECTION)  | Accept the PDP context modification with QoS lower than the minimum QoS set in UE  |
| 10   | →         |    | DEACTIVATE PDP CONTEXT REQUEST                       | Initiate the PDP context deactivation. Cause set to 'QoS not acceptable'           |
| 11   | ←         |    | DEACTIVATE PDP CONTEXT ACCEPT                        | Accept the PDP context deactivation                                                |

### Specific message contents

None.

#### ~~11.2.2.1.5 Test requirements~~

~~When requesting the PDP context modification, the UE shall:~~

- ~~— Modify the PDP context if SS replied with the requested QoS;~~
- ~~— Modify the PDP context if SS replied with the acceptable QoS;~~
- ~~— Deactivate the PDP context if SS replied with the QoS not acceptable to UE.~~

#### ~~11.2.2.2 UE initiated PDP Context Modification not accepted by the network~~

##### ~~11.2.2.2.1 Definition~~

##### ~~11.2.2.2.2 Conformance requirement~~

~~In order to initiate the procedure, the MS sends the MODIFY PDP CONTEXT REQUEST message to the network, enters the state PDP-MODIFY-PENDING and starts timer T3381. The message may contain the requested new QoS and/or the TFT and the requested LLC SAPI (used in GSM).~~

~~Upon receipt of a MODIFY PDP CONTEXT REQUEST message, the network may reject the MS initiated PDP context modification request by sending a MODIFY PDP CONTEXT REJECT message to the MS. The message shall contain a cause code that typically indicates one of the following:~~

- ~~# 26: —insufficient resources;~~
- ~~# 32: —Service option not supported;~~
- ~~# 41: —semantic error in the TFT operation;~~
- ~~# 42: —syntactical error in the TFT operation;~~
- ~~# 44: —semantic errors in packet filter(s);~~
- ~~# 45: —syntactical errors in packet filter(s);~~
- ~~# 95 – 111: —protocol errors.~~

~~Upon receipt of a MODIFY PDP CONTEXT REJECT message, the MS shall stop timer T3381 and enter the state PDP-ACTIVE.~~

#### ~~Reference~~

~~3GPP TS 24.008 clauses 6.1.3.3, 6.1.3.3.2 and 6.1.3.3.3.~~

##### ~~11.2.2.2.3 Test purpose~~

~~To test the behaviour of the UE upon receipt of a MODIFY PDP CONTEXT REJECT message from the network.~~

##### ~~11.2.2.2.4 Method of test~~

#### ~~Initial conditions~~

~~System Simulator:~~

- ~~— 1 cell, default parameters.~~

~~User Equipment:~~

- ~~— The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.~~

#### ~~Related ICS/IXIT statements~~

- ~~— PS Supported ————— yes/no~~

—Method of activating a PDP context

### Test procedure

A PDP context is activated by the user and accepted by the SS. The UE initiates a PDP context modification by sending a MODIFY PDP CONTEXT REQUEST message. The SS rejects the context modification and replies with the MODIFY PDP CONTEXT REJECT with cause set to # 26: insufficient resources.

### Expected sequence

| Step | Direction |    | Message                                              | Comments                                                                                                                     |
|------|-----------|----|------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                      |                                                                                                                              |
| 1    |           | UE |                                                      | Initiate a PDP context activation                                                                                            |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST                         | Activate a PDP context                                                                                                       |
| 3    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT                          | Accept the PDP context                                                                                                       |
| 4    | →         |    | MODIFY PDP CONTEXT REQUEST (UE TO NETWORK DIRECTION) | Request the modification of a PDP context                                                                                    |
| 5    | ←         |    | MODIFY PDP CONTEXT REJECT                            | SS rejects PDP context modification                                                                                          |
| 6    |           | SS |                                                      | Wait for T3381 seconds to ensure no further MODIFY PDP CONTEXT REQUEST (UE TO NETWORK DIRECTION) messages are sent by the UE |

### Specific message contents

None.

### 11.2.2.2.5 — Test requirements

After receiving MODIFY PDP CONTEXT REJECT message from the network, UE shall not resend PDP context modification request.

## 11.2.3 — Abnormal cases

### 11.2.3.1 — T3381 Expiry

#### 11.2.3.1.1 — Definition

#### 11.2.3.1.2 — Conformance requirement

On the first expiry of timer T3381, the UE shall re-send the MODIFY PDP CONTEXT REQUEST message, reset and restart timer T3381. This retransmission is repeated four times, i.e. on the fifth expiry of timer T3381, the MS may UE continue to use the previously negotiated QoS or it may initiate the PDP context deactivation procedure.

### Reference

3GPP TS 24.008 clause 6.1.3.3.4 a) case: In the UE.

### Test purpose

To test the behaviour of the UE when network does not reply to MODIFY PDP CONTEXT REQUEST message.

#### 11.2.3.1.4 Method of test

##### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

##### Related ICS/IXIT statements

— PS Supported ————— yes/no

— Method of activating a PDP context

##### Test procedure

A PDP context activation is requested by the user and accepted by the SS. The UE shall send MODIFY PDP CONTEXT REQUEST (UE TO NETWORK DIRECTION) message five times with T3381 seconds between each message. After this no further MODIFY PDP CONTEXT REQUEST (UE TO NETWORK DIRECTION) messages shall be sent by the UE.

##### Expected sequence

| Step | Direction |    | Message                                              | Comments                                                                                                                     |
|------|-----------|----|------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                      |                                                                                                                              |
| 1    | UE        |    |                                                      | Initiate a PDP context activation                                                                                            |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST                         | Activate a PDP context                                                                                                       |
| 3    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT                          | Accept the PDP context activation                                                                                            |
| 4    | →         |    | MODIFY PDP CONTEXT REQUEST (UE TO NETWORK DIRECTION) | Request modification of the PDP context, with new QoS                                                                        |
| 5    |           | SS |                                                      | T3381 seconds                                                                                                                |
| 6    | →         |    | MODIFY PDP CONTEXT REQUEST (UE TO NETWORK DIRECTION) | Request modification of the PDP context, with new QoS                                                                        |
| 7    |           | SS |                                                      | T3381 seconds                                                                                                                |
| 8    | →         |    | MODIFY PDP CONTEXT REQUEST (UE TO NETWORK DIRECTION) | Request modification of the PDP context, with new QoS                                                                        |
| 9    |           | SS |                                                      | T3381 seconds                                                                                                                |
| 10   | →         |    | MODIFY PDP CONTEXT REQUEST (UE TO NETWORK DIRECTION) | Request modification of the PDP context, with new QoS                                                                        |
| 11   |           | SS |                                                      | T3381 seconds                                                                                                                |
| 12   | →         |    | MODIFY PDP CONTEXT REQUEST (UE TO NETWORK DIRECTION) | Request modification of the PDP context, with new QoS                                                                        |
| 13   |           | SS |                                                      | Wait for T3381 seconds to ensure no further MODIFY PDP CONTEXT REQUEST (UE TO NETWORK DIRECTION) messages are sent by the UE |

##### Specific message contents

None.

#### ~~11.1.4.3.1.5 Test requirements~~

~~UE shall re-send the MODIFY PDP CONTEXT REQUEST (UE TO NETWORK DIRECTION) to SS five times in order to initiate the PDP context modification, with expiry of timer T3381 between messages. After fifth try, UE shall send no more MODIFY PDP CONTEXT REQUEST (UE TO NETWORK DIRECTION) messages to SS.~~

#### ~~11.2.3.2 Collision of UE and network initiated PDP context modification procedures~~

##### ~~11.2.3.2.1 Definition~~

##### ~~11.2.3.2.2 Conformance requirement~~

~~A collision of a UE and network initiated PDP context modification procedures is identified by the UE if a MODIFY PDP CONTEXT REQUEST message is received from the network after the UE has sent a MODIFY PDP CONTEXT REQUEST message itself, and both messages contain the same TI and the UE has not yet received a MODIFY PDP CONTEXT ACCEPT message from the network.~~

~~In the case of such a collision, the network initiated PDP context modification shall take precedence over the UE initiated PDP context modification. The UE shall terminate internally the UE initiated PDP context modification procedure, enter the state PDP ACTIVE and proceed with the network initiated PDP context modification procedure by sending a MODIFY PDP CONTEXT ACCEPT message.~~

#### ~~Reference~~

~~3GPP TS 24.008 clause 6.1.3.3.4 b).~~

##### ~~11.2.3.2.3 Test purpose~~

~~To test behaviour of the UE when it identifies collision of the UE and network initiated PDP context modification with the same TI.~~

##### ~~11.2.3.2.4 Method of test~~

#### ~~Initial conditions~~

~~System Simulator:~~

~~— 1 cell, default parameters.~~

~~User Equipment:~~

~~— The UE is in GMM state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.~~

#### ~~Related ICS/IXIT statements~~

~~— PS Supported ————— yes/no~~

~~— Method of activating a PDP context~~

#### ~~Test procedure~~

~~A PDP context is activated by the user and accepted by the SS. The UE initiates a PDP context modification by sending a MODIFY PDP CONTEXT REQUEST message. Then the SS initiates the PDP context modification by sending MODIFY PDP CONTEXT REQUEST message with the same TI. The UE shall reply to the SS initiated PDP context modification procedure by sending MODIFY PDP CONTEXT ACCEPT message with the same TI.~~

## Expected sequence

| Step | Direction |    | Message                                              | Comments                                                                                           |
|------|-----------|----|------------------------------------------------------|----------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                      |                                                                                                    |
| 1    | UE        |    |                                                      | Initiate a PDP context activation                                                                  |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST                         | Activate a PDP context                                                                             |
| 3    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT                          | Accept the PDP context activation                                                                  |
| 4    | →         |    | MODIFY PDP CONTEXT REQUEST (UE TO NETWORK DIRECTION) | Request modification of the PDP context                                                            |
| 5    | ←         |    | MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION) | Request modification of the PDP context with the same TI                                           |
| 6    | UE        |    |                                                      | UE identifies collision, terminates internally the UE initiated PDP context modification procedure |
| 7    | →         |    | MODIFY PDP CONTEXT ACCEPT (UE TO NETWORK DIRECTION)  | Accept SS initiated PDP context modification                                                       |

## Specific message contents

Steps 4 and 5 – The TI IE value is the same, with TI flag set to "0" identifying both, the UE and the network, as transaction initiator. TI flag indicates to the UE that it is attempting to allocate the same TI value simultaneously with the SS.

Step 7 – The TI flag set to "1" indicating that the message belongs to the transaction initiated by the other side, in this case SS.

Steps 4, 5 and 7 – Bit7, Bit6 and Bit5 of the TI IE are the same.

## 11.2.3.2.5 Test requirements

In step 6, the UE shall terminate internally the UE initiated PDP context modification procedure and proceed with SS initiated PDP context modification.

## 11.3 PDP context deactivation procedures

## 11.3.1 PDP context deactivation initiated by the UE

## 11.3.1.1 Definition

## 11.3.1.2 Conformance requirement

The DEACTIVATE PDP CONTEXT REQUEST message sent by UE contains the transaction identifier in use for the PDP context to be deactivated and a cause code that typically indicates one of the following causes:

- #25: LLC or SMDCP failure (GSM only);
- #26: insufficient resources;
- #36: regular PDP context deactivation; or
- #37: QoS not accepted.

Upon receipt of the DEACTIVATE PDP CONTEXT ACCEPT message, the UE shall stop timer T3390.

Whenever any session management message except REQUEST PDP CONTEXT ACTIVATION or SM-STATUS is received by the UE specifying a transaction identifier which is not recognised as relating to an active context or to a context that is in the process of activation or deactivation, the UE shall send a SM-STATUS message with cause #81 "invalid transaction identifier value" using the received transaction identifier value including the extension octet and remain in the PDP-INACTIVE state.

## Reference

3GPP TS 24.008 clauses 6.1.3.4, 6.1.3.4.1 and 8.3.2 (b).

### 11.3.1.3 ————— Test purpose

To test the behaviour of the UE upon receipt of a DEACTIVATE PDP CONTEXT ACCEPT message from the SS in PDP context deactivation procedure initiated by the UE.

### 11.3.1.4 ————— Method of test

#### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in GMM state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

#### Related ICS/IXIT statements

— PS Supported ————— yes/no

— Method of activating a PDP context

— Method of deactivating the PDP context

#### Test procedure

A PDP context is activated by the user and accepted by the SS. PDP context deactivation is then requested by the user. The UE shall send a DEACTIVATE PDP CONTEXT REQUEST message to the SS. The SS shall then reply with a DEACTIVATE PDP CONTEXT ACCEPT message. The SS shall then wait for T3390 seconds to ensure T3390 has been stopped and that no further messages are sent from the UE. The SS shall then send a MODIFY PDP CONTEXT REQUEST for the deactivated context and the UE shall reply with an SM-STATUS message with cause #81 'transaction identifier not known'.

## Expected sequence

| Step | Direction |    | Message                                              | Comments                                                                         |
|------|-----------|----|------------------------------------------------------|----------------------------------------------------------------------------------|
|      | UE        | SS |                                                      |                                                                                  |
| 1    | UE        |    |                                                      | Initiate a context activation                                                    |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST                         | Activate a PDP context                                                           |
| 3    |           | ←  | ACTIVATE PDP CONTEXT ACCEPT                          | Accept the PDP context                                                           |
| 4    | UE        |    |                                                      | Initiate a context deactivation                                                  |
| 5    | →         |    | DEACTIVATE PDP CONTEXT REQUEST                       | Request a deactivation of a PDP context                                          |
| 6    |           | ←  | DEACTIVATE PDP CONTEXT ACCEPT                        | Accept the PDP context deactivation                                              |
| 7    |           | SS |                                                      | Wait for T3390 seconds to ensure no further deactivate request messages are sent |
| 8    |           | ←  | MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION) | Send a modify request to UE for the deactivated context.                         |
| 9    | →         |    | SM STATUS                                            | Cause set to #81                                                                 |

## Specific message contents

None.

## 11.3.1.5 Test requirements

In PDP context deactivation procedure initiated by the UE, upon receipt of a DEACTIVATE PDP CONTEXT ACCEPT message from the SS, the UE shall deactivate PDP context associated with given PDP address and TI.

Then, upon modification procedure initiated by the network, for deactivated PDP context, UE shall reply with SM STATUS message with cause #81.

~~11.3.2 PDP context deactivation initiated by the network~~~~11.3.2.1 Definition~~~~11.3.2.2 Conformance requirement~~

The DEACTIVATE PDP CONTEXT REQUEST message sent by SS contains the transaction identifier in use for the PDP context to be deactivated and a cause code that typically indicates one of the following causes:

# 25: LLC or SMDCP failure (GSM-only);

# 36: regular PDP context deactivation;

# 38: network failure; or

# 39: reactivation requested.

The UE shall, upon receipt of the DEACTIVATE PDP CONTEXT REQUEST message from network, reply with a DEACTIVATE PDP CONTEXT ACCEPT message.

## Reference

3GPP TS 24.008 clauses 6.1.3.4, 6.1.3.4.2.

## 11.3.2.3 Test purpose

To test the behaviour of the UE upon receipt of a DEACTIVATE PDP CONTEXT REQUEST message from the SS.



#### 11.3.2.4 Method of test

##### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.

##### Related ICS/IXIT statements

— PS Supported ————— yes/no

— Method of activating a PDP context

##### Test procedure

A PDP context is activated by the user and accepted by the SS. A DEACTIVATE PDP CONTEXT REQUEST message is then sent by the SS. The UE shall reply with a DEACTIVATE PDP CONTEXT ACCEPT message. The SS shall then send a MODIFY PDP CONTEXT REQUEST for the deactivated context and the UE shall reply with an SM STATUS message with cause #81 'invalid transaction identifier value'.

##### Expected sequence

| Step | Direction |    | Message                                              | Comments                                                 |
|------|-----------|----|------------------------------------------------------|----------------------------------------------------------|
|      | UE        | SS |                                                      |                                                          |
| 1    |           | UE |                                                      | Initiate a context activation                            |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST                         | Activate a PDP context                                   |
| 3    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT                          | Accept the PDP context                                   |
| 4    | ←         |    | DEACTIVATE PDP CONTEXT REQUEST                       | Request a deactivation of a PDP context                  |
| 5    | →         |    | DEACTIVATE PDP CONTEXT ACCEPT                        | Accept the PDP context deactivation.                     |
| 6    | ←         |    | MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION) | Send a modify request to UE for the deactivated context. |
| 7    | →         |    | SM STATUS                                            | Cause set to #81                                         |

##### Specific message contents

None.

#### 11.3.2.5 Test requirements

Upon receipt of a request for deactivation of a PDP context from the SS, the UE shall deactivate PDP context. Then, upon modification procedure initiated by the network, for deactivated PDP context, UE shall reply with SM STATUS message with cause #81, as confirmation that previously SS requested PDP context deactivation was performed by the UE.

### ~~11.3.3 Abnormal cases~~

#### ~~11.3.3.1 T3390 Expiry~~

##### ~~11.3.3.1.1 Definition~~

##### ~~11.3.3.1.2 Conformance requirement~~

- ~~— On the first expiry of timer T3390, the UE shall resend the message DEACTIVATE PDP CONTEXT REQUEST.~~
- ~~— On the second expiry of timer T3390, the UE shall resend the message DEACTIVATE PDP CONTEXT REQUEST.~~
- ~~— On the third expiry of timer T3390, the UE shall resend the message DEACTIVATE PDP CONTEXT REQUEST.~~
- ~~— On the fourth expiry of timer T3390, the UE shall resend the message DEACTIVATE PDP CONTEXT REQUEST.~~
- ~~— On the fifth expiry of timer T3390, the UE shall release all resources allocated and shall erase the PDP context related data.~~

#### Reference

3GPP TS 24.008 clause 6.1.3.4.3 a) case In the UE.

##### ~~11.3.3.1.3 Test purpose~~

To test the behaviour of the UE when the SS does not reply to a DEACTIVATE PDP CONTEXT REQUEST message from the UE.

##### ~~11.3.3.1.4 Method of test~~

#### ~~Initial conditions~~

System Simulator:

- ~~— 1 cell, default parameters.~~

User Equipment:

- ~~— The UE is in GMM state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.~~

#### ~~Related ICS/IXIT statements~~

- ~~— PS Supported ————— yes/no~~
- ~~— Method of activating a PDP context~~
- ~~— Method of deactivating a PDP context~~

#### Test procedure

A PDP context is activated by the user and accepted by the SS. PDP context deactivation is then requested by the user. The UE shall send a DEACTIVATE PDP CONTEXT REQUEST message five times with T3390 seconds between each message. T3390 seconds after the fifth message the SS shall send a MODIFY PDP CONTEXT REQUEST message for the deactivated context and the UE shall reply with SM STATUS with cause set to #81 'Transaction identifier not known'.

## Expected sequence

| Step | Direction |    | Message                                              | Comments                                |
|------|-----------|----|------------------------------------------------------|-----------------------------------------|
|      | UE        | SS |                                                      |                                         |
| 1    | UE        |    |                                                      | Initiate a context activation           |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST                         | Activate a PDP context                  |
| 3    |           | ←  | ACTIVATE PDP CONTEXT ACCEPT                          | Accept the PDP context                  |
| 4    | UE        |    |                                                      | Initiate a context deactivation         |
| 5    | →         |    | DEACTIVATE PDP CONTEXT REQUEST                       | Request a deactivation of a PDP context |
| 6    |           | SS |                                                      | T3390 seconds                           |
| 7    | →         |    | DEACTIVATE PDP CONTEXT REQUEST                       | Request a deactivation of a PDP context |
| 8    |           | SS |                                                      | T3390 seconds                           |
| 9    | →         |    | DEACTIVATE PDP CONTEXT REQUEST                       | Request a deactivation of a PDP context |
| 10   |           | SS |                                                      | T3390 seconds                           |
| 11   | →         |    | DEACTIVATE PDP CONTEXT REQUEST                       | Request a deactivation of a PDP context |
| 12   |           | SS |                                                      | T3390 seconds                           |
| 13   | →         |    | DEACTIVATE PDP CONTEXT REQUEST                       | Request a deactivation of a PDP context |
| 14   |           | SS |                                                      | Wait T3390 seconds                      |
| 15   | ←         |    | MODIFY PDP CONTEXT REQUEST (NETWORK TO UE DIRECTION) | Try to modify the deactivated context.  |
| 16   | →         |    | SM STATUS                                            | Cause set to #81                        |

## Specific message contents

None.

## 11.3.3.1.5 — Test requirements

If SS does not respond to UE initiated PDP context deactivation procedure, the UE shall retransmit a DEACTIVATE PDP CONTEXT REQUEST five times, with T3390 timer expiry between the successive messages, before releasing resources allocated to the PDP context and deleting PDP context related data.

## 11.3.3.2 — Collision of UE and network initiated PDP context deactivation requests

## 11.3.3.2.1 — Definition

## 11.3.3.2.2 — Conformance requirement

If the UE and the network initiated PDP context deactivation requests collide, the UE and the network shall each reply with the message DEACTIVATE PDP CONTEXT ACCEPT and shall stop timer T3390 and T3395, respectively.

## Reference

3GPP TS 24.008 clause 6.1.3.4.3 b).

## 11.3.3.2.3 — Test purpose

To test the behaviour of the UE when there is a collision between an UE initiated and network initiated context deactivation.

#### 11.3.3.2.4 Method of test

##### Initial conditions

System Simulator:

— 1 cell, default parameters.

User Equipment:

— The UE is in GMM-state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN

##### Related ICS/IXIT statements

— PS Supported ————— yes/no

— Method of activating a PDP context

— Method of deactivating a PDP context

##### Test procedure

A PDP context is activated by the user and accepted by the SS. Context deactivation is then requested by the user. Upon receipt of the DEACTIVATE PDP CONTEXT REQUEST message the SS sends a DEACTIVATE PDP CONTEXT REQUEST message. The UE shall reply with only one DEACTIVATE PDP CONTEXT ACCEPT message. Upon receipt of this message the SS sends a DEACTIVATE PDP CONTEXT ACCEPT message.

##### Expected sequence

| Step | Direction |    | Message                        | Comments                                |
|------|-----------|----|--------------------------------|-----------------------------------------|
|      | UE        | SS |                                |                                         |
| 1    | UE        |    |                                | Initiate a context activation           |
| 2    | →         |    | ACTIVATE PDP CONTEXT REQUEST   | Activate a PDP context                  |
| 3    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT    | Accept the PDP context                  |
| 4    | UE        |    |                                | Initiate a context deactivation         |
| 5    | →         |    | DEACTIVATE PDP CONTEXT REQUEST | Request a deactivation of a PDP context |
| 6    | ←         |    | DEACTIVATE PDP CONTEXT REQUEST | Request a deactivation of a PDP context |
| 7    | →         |    | DEACTIVATE PDP CONTEXT ACCEPT  | Accept the PDP context deactivation     |
| 8    | ←         |    | DEACTIVATE PDP CONTEXT ACCEPT  | Accept the PDP context deactivation     |

##### Specific message contents

None.

#### 11.3.3.2.5 Test requirements

When UE and SS initiated PDP context deactivation requests collide, the UE shall reply with DEACTIVATE PDP CONTEXT ACCEPT to the SS.

## ~~11.4 Unknown or Unforeseen Transaction Identifier/Non- semantical Mandatory Information Element Errors~~

### ~~11.4.1 Error cases~~

#### ~~11.4.1.1 Definition~~

#### ~~11.4.1.2 Conformance requirement~~

~~The mobile station shall ignore a session management message with TI-EXT bit = 0. Otherwise, the following procedures shall apply:~~

- ~~— Whenever any session management message, except REQUEST PDP CONTEXT ACTIVATION or SM-STATUS, is received by the UE specifying a transaction identifier which is not recognized as relating to an active context or to a context that is in the process of activation or, the UE shall send a SM-STATUS message with cause #81 "invalid transaction identifier value" using the received transaction identifier value including the extension octet and remain in the PDP-INACTIVE state.~~
- ~~— When a REQUEST PDP CONTEXT ACTIVATION message is received with a transaction identifier flag set to "1", this message shall be ignored.~~

~~When on receipt of a message,~~

- ~~— an "imperative message part" error; or~~
- ~~— a "missing mandatory IE " error.~~

~~is diagnosed or when a message containing:~~

- ~~— a syntactically incorrect mandatory IE; or~~
- ~~— an IE unknown in the message, but encoded as "comprehension required"; or~~
- ~~— an out of sequence IE encoded as "comprehension required".~~

~~is received, the UE shall proceed as follows:~~

- ~~— If the message was a SM message the SM-STATUS message with cause # 96 "invalid mandatory information" shall be returned.~~
- ~~— If a mobile station receives a SM message with message type not defined for the PD or not implemented by the receiver, it shall return a status message SM-STATUS with cause #97 'message type non-existent or not implemented'.~~
- ~~— If the mobile station receives a message not compatible with the protocol state, the mobile station shall ignore the message except for the fact that when the message was a SM message the SM-STATUS message with cause #98 'Message type not compatible with protocol state' shall be returned.~~

~~Other syntactic errors.~~

~~This clause applies to the analysis of the value part of an information element. It defines the following terminology:~~

- ~~— An IE is defined to be syntactically incorrect in a message if it contains at least one value defined as 'reserved', or if its value part violates syntactic rules given in the specification of the value part. However it is not a syntactical error that a type 4 standard IE specifies in its length indicator a greater length than possible according to the value part specification: extra bits are ignored.~~

### ~~Reference~~

~~3GPP TS 24.008 clauses 8.3.2 and 8.5 and 3GPP TS 24.007 clause 11.4.2.~~

#### ~~11.4.1.3 Test purpose~~

~~To test the behaviour of the UE when messages with unknown or unforeseen transaction identifiers or non-semantical mandatory information element errors occur.~~

#### ~~11.4.1.4 Method of test~~

##### ~~Initial conditions~~

~~System Simulator:~~

~~— 1 cell, default parameters.~~

~~User Equipment:~~

~~— The UE is in GMM state "GMM-REGISTERED, normal service" with valid P-TMSI and CKSN.~~

##### ~~Related ICS/IXIT statements~~

~~None.~~

##### ~~Test procedure~~

~~A PDP context activation is requested by the SS with the transaction identifier set to '1'. The UE shall not respond to this request.~~

~~A PDP context is then activated from the UE. Two invalid accept messages are then sent by the SS with T3380 seconds between them. After a further T3380 seconds a valid accept message is sent by the SS.~~

~~A deactivation message is then sent from the SS with the transaction identifier set to '111'. The UE shall reply with a SM-STATUS message with transaction identifier set to '111'.~~

~~A deactivate message is then sent from the SS with a different transaction identifier to the one used in the activate request message sent by the UE. The UE shall reply with a SM-STATUS message with cause #81 'invalid transaction identifier value'.~~

~~Three invalid modification messages are then sent to the UE in turn. The UE shall respond each time with a SM-STATUS message with cause # 96 "invalid mandatory information".~~

## Expected sequence

| Step | Direction |    | Message                                             | Comments                                                                                                   |
|------|-----------|----|-----------------------------------------------------|------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                     |                                                                                                            |
| 1    | ←         |    | REQUEST PDP CONTEXT ACTIVATION                      | Request the activation of a PDP context with the transaction identifier flag set to "1"                    |
| 2    |           | SS |                                                     | Wait 30 seconds to ensure UE does not request context activation                                           |
| 3    | UE        |    |                                                     | Initiate a context request                                                                                 |
| 4    | →         |    | ACTIVATE PDP CONTEXT REQUEST                        | Activate a PDP context from the UE                                                                         |
| 5    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT                         | Unknown IE encoded as 'comprehension required'                                                             |
| 6    | →         |    | SM STATUS                                           | Cause set to #96                                                                                           |
| 7    |           | SS |                                                     | Wait T3380 seconds                                                                                         |
| 8    | →         |    | ACTIVATE PDP CONTEXT REQUEST                        | Activate a PDP context from the UE (auto-generated)                                                        |
| 9    | ←         |    | ACTIVATE PDP CONTEXT ACCEPT                         | Out of sequence IE encoded as 'comprehension required'                                                     |
| 10   | →         |    | SM STATUS                                           | Cause set to #96                                                                                           |
| 11   |           | SS |                                                     | Wait T3380 seconds                                                                                         |
| 12   | →         |    | ACTIVATE PDP CONTEXT REQUEST                        | Activate a PDP context from the UE (auto-generated)                                                        |
| 13   | ←         |    | ACTIVATE PDP CONTEXT ACCEPT                         | Accept the PDP context                                                                                     |
| 16   | ←         |    | DEACTIVATE PDP CONTEXT REQUEST                      | Try to deactivate the context with a different transaction identifier to that used to activate the context |
| 17   | →         |    | SM STATUS                                           | Cause set to #81                                                                                           |
| 18   | ←         |    | MODIFY PDP CONTEXT REQUEST(NETWORK TO UE DIRECTION) | Request the modification of the PDP context                                                                |
| 19   | →         |    | SM STATUS                                           | Cause set to #96                                                                                           |
| 20   | ←         |    | MODIFY PDP CONTEXT REQUEST(NETWORK TO UE DIRECTION) | Request the modification of the PDP context                                                                |
| 21   | →         |    | SM STATUS                                           | Cause set to #96                                                                                           |
| 22   | ←         |    | MODIFY PDP CONTEXT REQUEST(NETWORK TO UE DIRECTION) | Request the modification of the PDP context                                                                |
| 23   | →         |    | SM STATUS                                           | Cause set to #96                                                                                           |

## 11.4.1.5 Test requirements

TBD.

## 12 Elementary procedure for Packet Switched Mobility Management

### 12.1 Applicability, default conditions and default messages

All test cases for PS mobility management apply for all PS mobiles unless otherwise stated in a specific test. Within each test case, the ICS statement indicates whether the test shall be performed for mobiles that can only operate in mode –class A, only in mode –class C, or in both mode –class A and C. For some procedures, the mobile class is of no importance.

Note that only the layer 3 messages are described in the document. The mapping of the layer 3 messages to lower layers and the use of logical channels is not described in the present document.

The terms 'PS/CS mode of operation' and 'PS mode of operation' are not used in the present document with some exceptions. Instead the terms 'UE operation mode A' and 'UE operation mode C' are used.

The default conditions and default message contents not specified in this clause must be set as in "PS default conditions"

Below is a list of the RAI values and the corresponding RAC, LAC and MCC used in the test cases:

RAI-1: MCC1/MNC1/LAC1/RAC1 (Used if only one cell)

RAI-2: MCC2/MNC1/LAC1/RAC1

RAI-3: MCC1/MNC1/LAC2/RAC1

RAI-4: MCC1/MNC1/LAC1/RAC2

RAI-5: MCC1/MNC1/LAC1/RAC3

RAI-6: MCC2/MNC1/LAC2/RAC1

RAI-7: MCC2/MNC1/LAC1/RAC2

RAI-8: MCC1/MNC2/LAC1/RAC1

RAI-9: MCC1/MNC2/LAC2/RAC1

RAI-10: MCC1/MNC2/LAC1/RAC2

If the User Equipment initial condition specifies that the mobile has a valid IMSI but the initial condition does not mention P-TMSI, then that shall be interpreted as that the mobile has no valid P-TMSI.

The tests are based on 3GPP TS 24.008.

## 12.2 PS attach procedure

This procedure is used to indicate for the network that the IMSI is available for traffic by establishment of a GMM context.

### 12.2.1 Normal PS attach

The normal PS attach procedure is a GMM procedure used by PS UEs of UE operation mode A or C to IMSI attach for PS services only.

#### 12.2.1.1 PS attach / accepted

##### 12.2.1.1.1 Definition

##### 12.2.1.1.2 Conformance requirement

- 1) If the network accepts the PS attach procedure (signalled by an IMSI) and allocates a P-TMSI, the UE shall acknowledge the P-TMSI and continue communication with the P-TMSI.
- 2) If the network accepts the PS attach procedure (signalled by P-TMSI) and reallocates a new P-TMSI, the UE shall acknowledge the new P-TMSI and continue communication with the new P-TMSI.
- 3) If the network accepts the PS attach procedure (signalled by a P-TMSI) from the UE without reallocation of the old P-TMSI, the UE shall continue communication with the old P-TMSI.

#### Reference

3GPP TS 24.008 clause 4.7.3.1



#### 12.2.1.1.3 ~~Test purpose~~

~~To test the behaviour of the UE if the network accepts the PS attach procedure.~~

~~The following cases are identified:~~

- ~~1) P-TMSI / P-TMSI signature is allocated;~~
- ~~2) P-TMSI / P-TMSI signature is reallocated;~~
- ~~3) Old P-TMSI / P-TMSI signature is not changed.~~

#### 12.2.1.1.4 ~~Method of test~~

##### ~~Initial condition~~

~~System Simulator:~~

- ~~— One cell operating in network operation mode II.~~

~~User Equipment:~~

- ~~— The UE has a valid IMSI.~~

##### ~~Related ICS/IXIT statements~~

- ~~— Support of PS service Yes/No~~
- ~~— UE operation mode A Yes/No~~
- ~~UE operation mode C Yes/No~~
- ~~Switch off on button Yes/No~~
- ~~Automatic PS attach procedure at switch on or power on Yes/No~~

##### ~~Test procedure~~

- ~~1) The UE sends an ATTACH REQUEST message with identity IMSI. The SS allocates a P-TMSI and returns ATTACH ACCEPT message with a P-TMSI. The UE acknowledge the P-TMSI by sending ATTACH COMPLETE message. Further communication UE – SS is performed by the new P-TMSI.~~
- ~~2) The UE sends an ATTACH REQUEST message with identity P-TMSI. The SS reallocates a new P-TMSI and returns ATTACH ACCEPT message with the new P-TMSI. The UE acknowledge the P-TMSI by sending ATTACH COMPLETE message. Further communication UE – SS is performed by the new P-TMSI. The UE will not answer signalling addressed to the old P-TMSI.~~
- ~~3) The UE sends an ATTACH REQUEST message with identity P-TMSI. The SS accepts the P-TMSI and returns ATTACH ACCEPT message without any P-TMSI. Further communication UE – SS is performed by the old P-TMSI.~~

## Expected Sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                           |
|------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                    |
| 1    | UE        |    |                                 | The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 26.                                                                |
| 2    | UE        |    |                                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                             |
| 3    | →         |    | ATTACH REQUEST                  | Attach type = 'PS attach'                                                                                                                                          |
| 4    | ←         |    | ATTACH ACCEPT                   | Mobile identity = IMSI<br>Attach result = 'PS only attached'                                                                                                       |
| 5    | →         |    | ATTACH COMPLETE                 | Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                  |
| 6    | ←         |    | PAGING TYPE1                    | Mobile identity = P-TMSI-2<br>Paging order is for PS services.                                                                                                     |
| 6a   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                    |
| 6b   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                    |
| 6c   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                    |
| 7    | →         |    | SERVICE REQUEST                 | Service type = "paging response"                                                                                                                                   |
| 7a   | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                    |
| 7b   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                    |
| 8    | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                                                                                              |
| 9    | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                             |
| 10   | UE        |    |                                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                             |
| 11   | →         |    | ATTACH REQUEST                  | Attach type = 'PS attach'                                                                                                                                          |
| 12   | ←         |    | ATTACH ACCEPT                   | Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>Attach result = 'PS only attached'                                            |
| 13   | →         |    | ATTACH COMPLETE                 | Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                                                                                  |
| 14   | ←         |    | GMM INFORMATION                 | Message sent with P-TMSI-1                                                                                                                                         |
| 14b  | →         |    | GMM STATUS                      | Message sent in case the UE does not support reception of GMM information message<br>Cause #97                                                                     |
| 15   | ←         |    | PAGING TYPE1                    | Mobile identity = P-TMSI-2<br>Paging order is for PS services.                                                                                                     |
| 16   | UE        |    |                                 | No response from the UE to the request. This is checked for 10 seconds.                                                                                            |
| 17   | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                                                                                              |
| 18   | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                             |
| 19   | UE        |    |                                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                             |
| 20   | →         |    | ATTACH REQUEST                  | Attach type = 'PS attach'                                                                                                                                          |
| 21   | ←         |    | ATTACH ACCEPT                   | Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1<br>No new mobile identity assigned.<br>P-TMSI and P-TMSI signature not included. |
| 22   | ←         |    | PAGING TYPE1                    | Routing area identity = RAI-1<br>Attach result = 'PS only attached'                                                                                                |
| 22a  | →         |    | RRC CONNECTION REQUEST          | Mobile identity = P-TMSI-1<br>Paging order is for PS services.<br>PAGING TYPE 1 (used for NW-mode II).                                                             |

| Step | Direction |    | Message                         | Comments                                                                                        |
|------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                 |
| 22b  | <-        |    | RRC CONNECTION SETUP            | Service type = "paging response"                                                                |
| 22c  | ->        |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                 |
| 23   | ->        |    | SERVICE REQUEST                 |                                                                                                 |
| 23a  | <-        |    | RRC CONNECTION RELEASE          |                                                                                                 |
| 23b  | ->        |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                 |
| 24   |           | UE |                                 | The UE is switched off or power is removed (see ICS).                                           |
| 25   | ->        |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'.         |
| 26   |           | UE |                                 | The UE is set in UE operation mode A (see ICS) and the test is repeated from step 2 to step 25. |

### Specific message contents

None.

#### 12.2.1.1.5 Test requirements

At step3, 11 and 20, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

UE shall perform the following actions depending on the Mobile identity in the ATTACH REQUEST message and on the Mobile identity in the ATTACH ACCEPT message.

- Case 1) The Mobile identity in the ATTACH REQUEST message is the IMSI and the Mobile identity in the ATTACH ACCEPT message is the P-TMSI.

— At step5, UE shall:

- acknowledge the P-TMSI by sending the ATTACH COMPLETE message.

- Case 2) The Mobile identity in the ATTACH REQUEST message is the P-TMSI and the Mobile identity in the ATTACH ACCEPT message is the new P-TMSI.

— At step13, UE shall:

- acknowledge the new P-TMSI by sending the ATTACH COMPLETE message.

At step23, UE shall:

- respond to the paging message for PS domain by sending the SERVICE REQUEST message.

#### 12.2.1.2 PS attach / rejected / IMSI invalid / illegal UE

##### 12.2.1.2.1 Definition

##### 12.2.1.2.2 Conformance requirement

- 1) If the network rejects a PS attach procedure from the User Equipment with the cause 'Illegal UE', the User Equipment shall consider USIM invalid for PS services until power is switched off or USIM is removed.
- 2) If the network rejects a PS attach procedure from the User Equipment with the cause 'Illegal UE' the User Equipment shall delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.
- 3) If the network rejects a PS attach procedure from the User Equipment with the cause 'Illegal UE', the User Equipment shall delete the LAI.

## Reference

3GPP TS 24.008 clause 4.7.3.1.

### ~~12.2.1.2.3~~ ~~Test purpose~~

~~To test the behaviour of the UE if the network rejects the PS attach procedure of the UE with the cause 'illegal UE'.~~

### ~~12.2.1.2.4~~ ~~Method of test~~

## Initial condition

### System Simulator:

- ~~— Three cells (not simultaneously activated), cell A with MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in~~
- ~~— MCC1/MNC1/LAC2/RAC1 (RAI-3), cell C in MCC2/MNC1/LAC1/RAC1 (RAI-2).~~
- ~~— All three cells are operating in network operation mode II (in case of UE operation mode A).~~

### User Equipment:

- ~~— The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.~~

## Related ICS/IXIT statements

- ~~— Support of PS service Yes/No~~
- ~~— UE operation mode C Yes/No~~
- ~~— UE operation mode A Yes/No (only if mode C not supported)~~
- ~~— Switch off on button Yes/No~~
- ~~— Automatic PS attach procedure at switch on or power on Yes/No~~

## Test procedure

~~The SS rejects a PS attach with the cause value 'Illegal UE'. The SS checks that the UE does not perform PS attach in the same or another PLMN.~~

## Expected Sequence

| Step                                                                                                                                                      | Direction |    | Message            | Comments                                                                                                                                                                                                            |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                           | UE        | SS |                    |                                                                                                                                                                                                                     |
| 1                                                                                                                                                         | UE        |    |                    | The following messages are sent and shall be received on cell A.<br>The UE is set in UE operation mode C (see ICS).                                                                                                 |
| 2                                                                                                                                                         |           | SS |                    | The SS is set in network operation mode II.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Off cell".<br>(see note) |
| 3                                                                                                                                                         | UE        |    |                    | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                                               |
| 4                                                                                                                                                         | →         |    | ATTACH REQUEST     | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                                                                                                      |
| 5                                                                                                                                                         |           | ←  | ATTACH REJECT      | GMM cause = 'Illegal UE'.                                                                                                                                                                                           |
| 6                                                                                                                                                         |           | SS |                    | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)                              |
| 7                                                                                                                                                         | UE        |    |                    | Cell B is preferred by the UE.                                                                                                                                                                                      |
| 8                                                                                                                                                         | UE        |    |                    | No ATTACH REQUEST sent to the SS<br>(SS waits 30 seconds).                                                                                                                                                          |
| 9                                                                                                                                                         | UE        |    |                    | The UE initiates an attach by MMI or by AT command.                                                                                                                                                                 |
| 10                                                                                                                                                        | UE        |    |                    | No ATTACH REQUEST sent to the SS<br>(SS waits 30 seconds).                                                                                                                                                          |
| 11                                                                                                                                                        |           | SS |                    | The following messages are sent and shall be received on cell C.<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Serving cell".<br>(see note)                              |
| 12                                                                                                                                                        | UE        |    |                    | Cell C is preferred by the UE.                                                                                                                                                                                      |
| 13                                                                                                                                                        | UE        |    |                    | No ATTACH REQUEST sent to the SS<br>(SS waits 30 seconds).                                                                                                                                                          |
| 14                                                                                                                                                        | UE        |    |                    | The UE initiates an attach by MMI or by AT command.                                                                                                                                                                 |
| 15                                                                                                                                                        | UE        |    |                    | No ATTACH REQUEST sent to the SS<br>(SS waits 30 seconds).                                                                                                                                                          |
| 16                                                                                                                                                        | UE        |    |                    | If possible (see ICS) switch off is performed.<br>Otherwise the power is removed.                                                                                                                                   |
| 17                                                                                                                                                        | UE        |    | Registration on CS | The UE is powered up or switched on.<br>See TS 34.108                                                                                                                                                               |
| 18                                                                                                                                                        | UE        |    |                    | This is applied only for UE in UE operation mode A.<br>Parameter mobile identity is IMSI.                                                                                                                           |
| 19                                                                                                                                                        | UE        |    |                    | The UE initiates an attach (see ICS).                                                                                                                                                                               |
| 20                                                                                                                                                        | →         |    | ATTACH REQUEST     | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                                                                                                                 |
| 21                                                                                                                                                        |           | ←  | ATTACH ACCEPT      | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-2                                                                                             |
| 22                                                                                                                                                        | →         |    | ATTACH COMPLETE    |                                                                                                                                                                                                                     |
| 23                                                                                                                                                        | UE        |    |                    | The UE is switched off or power is removed (see ICS).                                                                                                                                                               |
| 24                                                                                                                                                        | →         |    | DETACH REQUEST     | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                                              |
| NOTE:—The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                    |                                                                                                                                                                                                                     |

### Specific message contents

None.

#### 12.2.1.2.5 Test requirements

At step4, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step8, 10, 13 and 15, UE shall:

- not send the ATTACH REQUEST message to SS, even if there is an instruction of attach request from MMI or from AT command.

At step20, UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

#### 12.2.1.3 PS attach / rejected / IMSI invalid / PS services not allowed

##### 12.2.1.3.1 Definition

##### 12.2.1.3.2 Conformance requirement

- 1) If the network rejects a PS attach procedure from the User Equipment with the cause 'PS services not allowed', the User Equipment shall consider USIM invalid for PS services until power is switched off or USIM is removed.
- 2) If the network rejects a PS attach procedure from the User Equipment with the cause 'PS services not allowed' the User Equipment shall delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.

### Reference

3GPP TS 24.008 clause 4.7.3.1.

##### 12.2.1.3.3 Test purpose

To test the behaviour of the UE if the network rejects the PS attach procedure of the UE with the cause 'PS services not allowed' (no valid PS-subscription for the IMSI).

##### 12.2.1.3.4 Method of test

### Initial condition

System Simulator:

- Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (HPLMN, RAI-1) and cell B in MCC2/MNC1/LAC1/RAC1 (RAI-2). Both cells are operating in network operation mode II.

User Equipment:

- The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

### Related ICS/IXIT statements

- Support of PS service Yes/No
- UE operation mode C Yes/No
- UE operation mode A Yes/No

- USIM removal possible without powering down Yes/No
- Switch off on button Yes/No
- Automatic PS attach procedure at switch on or power on Yes/No

### Test procedure

The SS rejects a normal attach with the cause value 'PS services not allowed'. The SS checks that the UE does not perform PS attach in another PLMN.

### Expected Sequence

| Step                                                                                                                                                       | Direction |    | Message         | Comments                                                                                                                                                                               |
|------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                            | UE        | SS |                 |                                                                                                                                                                                        |
| 1                                                                                                                                                          |           | SS |                 | The following messages are sent and shall be received on cell A:<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note) |
| 2                                                                                                                                                          | UE        |    |                 | The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 17.                                                                                    |
| 3                                                                                                                                                          | UE        |    |                 | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                  |
| 4                                                                                                                                                          | →         |    | ATTACH REQUEST  | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                                                                         |
| 5                                                                                                                                                          |           | ←  | ATTACH REJECT   | GMM cause = 'PS services not allowed'                                                                                                                                                  |
| 6                                                                                                                                                          |           | SS |                 | The following messages are sent and shall be received on cell B:<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note) |
| 7                                                                                                                                                          | UE        |    |                 | Cell B is preferred by the UE.                                                                                                                                                         |
| 8                                                                                                                                                          | UE        |    |                 | No ATTACH REQUEST sent to the SS<br>(SS waits 30 seconds).                                                                                                                             |
| 9                                                                                                                                                          | UE        |    |                 | If possible (see ICS) USIM removal is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.                                              |
| 10                                                                                                                                                         | UE        |    |                 | The UE gets the USIM replaced, is powered up or switched on and initiates an attach (see ICS).                                                                                         |
| 11                                                                                                                                                         | →         |    | ATTACH REQUEST  | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                                                                                    |
| 12                                                                                                                                                         |           | ←  | ATTACH ACCEPT   | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-2                                                                |
| 13                                                                                                                                                         | →         |    | ATTACH COMPLETE |                                                                                                                                                                                        |
| 14                                                                                                                                                         | UE        |    |                 | The UE is switched off or power is removed (see ICS).                                                                                                                                  |
| 15                                                                                                                                                         | →         |    | DETACH REQUEST  | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                 |
| 16                                                                                                                                                         |           |    |                 | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note)                                                                     |
| 17                                                                                                                                                         | UE        |    |                 | The UE is set in UE operation mode A (see ICS) and the test is repeated from step 3 to step 15.                                                                                        |
| NOTE: —The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                 |                                                                                                                                                                                        |

### Specific message contents

None.

#### 12.2.1.3.5 Test requirements

At step4, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step8, UE shall:

- not perform a PS attach procedure.

At step11, after the UE is switched on or a USIM is replaced, UE shall:

- perform the PS attach procedure.

#### 12.2.1.4 PS attach / rejected / PLMN not allowed

##### 12.2.1.4.1 Definition

##### 12.2.1.4.2 Conformance requirement

- 1) If the network rejects a PS attach procedure from the User Equipment with the cause 'PLMN not allowed' the User Equipment shall:
  - 1.1 not perform PS attach when switched on in the same routing area or location area.
  - 1.2 not perform PS attach when in the same PLMN and when that PLMN is not selected manually.
  - 1.3 delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.
  - 1.4 store the PLMN in the 'forbidden PLMN' list.
- 2) If the network rejects a PS attach procedure from the User Equipment with the cause 'PLMN not allowed' the User Equipment shall perform PS attach when a new PLMN is entered.
- 3) If the network rejects a PS attach procedure from the User Equipment with the cause 'PLMN not allowed' and if after that the PLMN from which this rejection was received, is manually selected, the User Equipment shall perform a PS attach procedure.

### Reference

3GPP TS 24.008 clause 4.7.3.1.

##### 12.2.1.4.3 Test purpose

To test the behaviour of the UE if the network rejects the PS attach procedure of the UE with the cause 'PLMN not allowed'.

##### 12.2.1.4.4 Method of test

##### 12.2.1.4.4.1 Test procedure 1

### Initial condition

System Simulator:

- Four cells (not simultaneously activated), cell A in MCC1/MNC2/LAC1/RAC1 (RAI-8), cell B in MCC1/MNC2/LAC1/RAC1 (RAI-8), cell C in MCC1/MNC2/LAC2/RAC1 (RAI-9) and cell D in MCC2/MNC1/LAC1/RAC1 (RAI-2).



All four cells are operating in network operation mode II (in case of UE operation mode A). The PLMN of the four cells should NOT be that of the UE Home PLMN.

#### User Equipment:

—The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-8. UE is Idle Updated on cell A.

#### Related ICS/IXIT statements

—Support of PS service—Yes/No  
UE operation mode C—Yes/No  
UE operation mode A—Yes/No (only if mode C not supported)  
Switch off on button—Yes/No  
Automatic PS attach procedure at switch on or power on—Yes/No

#### Test procedure

The SS rejects a PS attach with the cause value 'PLMN not allowed'. The SS checks that the UE does not perform PS attach if activated in the same routing area or location area and performs PS attach only when a new PLMN is entered.

## Expected Sequence

| Step | Direction |    | Message         | Comments                                                                                                                                                                                                               |
|------|-----------|----|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                 |                                                                                                                                                                                                                        |
| 1    | SS        |    |                 | The following messages are sent and shall be received on cell A.                                                                                                                                                       |
| 2    | UE        |    |                 | The UE is set in UE operation mode C (see ICS).                                                                                                                                                                        |
| 3    | SS        |    |                 | The SS is set in network operation mode II.                                                                                                                                                                            |
| 4    | →         |    | ATTACH REQUEST  | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Off cell".<br>Set the cell type of cell D to the "Off cell".<br>(see note) |
| 5    | ←         |    | ATTACH REJECT   | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                                                  |
| 6    | UE        |    |                 | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-8<br>GMM cause = 'PLMN not allowed'<br>No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds).             |
| 7    | UE        |    |                 | The following messages are sent and shall be received on cell B.                                                                                                                                                       |
| 8    | SS        |    |                 | The UE is switched off.                                                                                                                                                                                                |
| 9    | UE        |    |                 | Set the cell type of cell A to the "Off cell".                                                                                                                                                                         |
| 10   | UE        |    |                 | Set the cell type of cell B to the "Serving cell".                                                                                                                                                                     |
| 11   | UE        |    |                 | (see note)                                                                                                                                                                                                             |
| 12   | SS        |    |                 | The UE is powered up or switched on.                                                                                                                                                                                   |
| 13   | UE        |    |                 | Cell B is preferred by the UE.                                                                                                                                                                                         |
| 14   | UE        |    |                 | No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds).                                                                                                                                                                 |
| 15   | SS        |    |                 | The following messages are sent and shall be received on cell C.                                                                                                                                                       |
| 16   | UE        |    |                 | Set the cell type of cell B to the "Off cell".                                                                                                                                                                         |
| 17   | UE        |    |                 | Set the cell type of cell C to the "Serving cell".                                                                                                                                                                     |
| 18   | UE        |    |                 | (see note)                                                                                                                                                                                                             |
| 19   | →         |    | ATTACH REQUEST  | Cell C is preferred by the UE.                                                                                                                                                                                         |
| 20   | ←         |    | ATTACH ACCEPT   | No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds).                                                                                                                                                                 |
| 21   | →         |    | ATTACH COMPLETE | The following messages are sent and shall be received on cell D.                                                                                                                                                       |
| 22   | UE        |    |                 | Set the cell type of cell C to the "Off cell".                                                                                                                                                                         |
| 23   | →         |    | DETACH REQUEST  | Set the cell type of cell D to the "Serving cell".<br>(see note)                                                                                                                                                       |
|      |           |    |                 | Cell D is preferred by the UE.                                                                                                                                                                                         |
|      |           |    |                 | See TS 34.108                                                                                                                                                                                                          |
|      |           |    |                 | This is applied only for UE in UE operation mode A.                                                                                                                                                                    |
|      |           |    |                 | The UE initiates an attach automatically, by MMI or by AT command.                                                                                                                                                     |
|      |           |    |                 | Attach type = 'PS attach'                                                                                                                                                                                              |
|      |           |    |                 | Mobile identity = IMSI                                                                                                                                                                                                 |
|      |           |    |                 | Attach result = 'PS only attached'                                                                                                                                                                                     |
|      |           |    |                 | Mobile identity = P-TMSI-1                                                                                                                                                                                             |
|      |           |    |                 | P-TMSI-1 signature                                                                                                                                                                                                     |
|      |           |    |                 | Routing area identity = RAI-2                                                                                                                                                                                          |
|      |           |    |                 | The UE is switched off or power is removed (see ICS).                                                                                                                                                                  |
|      |           |    |                 | Message not sent if power is removed.                                                                                                                                                                                  |
|      |           |    |                 | Detach type = 'power switched off, PS detach'                                                                                                                                                                          |

NOTE: — The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only".

#### 12.2.1.4.4.2 Test procedure 2

##### Initial condition

##### System Simulator:

- One cell operating in network operation mode II: MCC2/MNC1/LAC1/RAC1 (RAI-2). The PLMN of the cell should NOT be that of the Mobile Station Home PLMN.

##### User Equipment:

- The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-2. UE is Idle Updated on cell A.

##### Related ICS/IXIT statements

- Support of PS service Yes/No
- UE operation mode C Yes/No
- UE operation mode A Yes/No (only if mode C not supported)
- Switch off on button Yes/No
- Automatic PS attach procedure at switch on or power on Yes/No

##### Test procedure

The SS rejects a PS attach with the cause value 'PLMN not allowed'. The subscribers access rights is changed to allow PS attach. Then the PLMN from which this rejection was received is manually selected and the SS check that a PS attach is performed.

##### Expected Sequence

| Step | Direction |    | Message            | Comments                                                                               |
|------|-----------|----|--------------------|----------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                        |
| 1    | UE        |    |                    | The UE is set in UE operation mode C or A (see ICS).                                   |
| 2    | UE        |    |                    | The UE is powered up or switched on and initiates an attach (see ICS).                 |
| 3    | ->        |    | ATTACH REQUEST     | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature          |
| 4    | <-        |    | ATTACH REJECT      | Routing area identity = RAI-2<br>GMM cause = 'PLMN not allowed'                        |
| 5    | UE        |    |                    | No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds)                                  |
| 6    | UE        |    |                    | The current PLMN is selected manually.                                                 |
| 7    | UE        |    | Registration on CS | See TS 34.108<br>This is applied only for UE in UE operation mode A.                   |
| 8    | UE        |    |                    | The UE initiates an attach automatically, by MMI or by AT command.                     |
| 9    | ->        |    | ATTACH REQUEST     | Attach type = 'PS attach'<br>Mobile identity = IMSI                                    |
| 10   | <-        |    | ATTACH ACCEPT      | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature |
| 11   | ->        |    | ATTACH COMPLETE    | Routing area identity = RAI-2                                                          |
| 12   | UE        |    |                    | The UE is switched off or power is removed (see ICS).                                  |
| 13   | ->        |    | DETACH REQUEST     | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach' |

##### Specific message contents

None.

#### ~~12.2.1.4.5 Test requirements~~

##### ~~Test requirements for test procedure 1~~

~~At step4, when the UE is powered on or switched on, UE shall:~~

- ~~— initiate the PS attach procedure with information elements specified in the above Expected Sequence.~~

~~At step6, UE shall:~~

- ~~— not perform PS attach procedure.~~

~~UE shall perform the following actions depending on the PLMN or the routing area or the location area~~

- ~~— Case 1) UE is in the same routing area or location area when the power is switched on,~~

~~— At step11, UE shall:~~

- ~~— not perform PS attach procedure.~~

- ~~— Case2) UE is in the same PLMN, and this PLMN is not selected manually~~

~~— At step14, UE shall:~~

- ~~— not perform PS attach procedure.~~

- ~~— Case3) UE is in a new PLMN.~~

~~— At step19, UE shall:~~

- ~~— perform the PS attach procedure.~~

##### ~~Test requirements for test procedure 2~~

~~At step3, when the UE is powered on or switched on, UE shall:~~

- ~~— initiate the PS attach procedure with information elements specified in the above Expected Sequence.~~

~~At step5, UE shall:~~

- ~~— not perform PS attach procedure.~~

~~At step9, when the UE is in the new PLMN, and this PLMN is selected manually, UE shall~~

- ~~— perform the PS attach procedure.~~

#### ~~12.2.1.5a PS attach / rejected / roaming not allowed in this location area~~

##### ~~12.2.1.5a.1 Definition~~

##### ~~12.2.1.5a.2 Conformance requirement~~

- ~~1) If the network rejects a PS attach procedure from the User Equipment with the cause 'roaming not allowed in this location area' the User Equipment shall:~~

~~1.1 not perform PS attach when in the same location area.~~

~~1.2 delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.~~

~~1.3 store the LA in the 'forbidden location areas for roaming' list.~~

~~1.4 perform PS attach when a new location area is entered.~~

~~1.5 Periodically search for its HPLMN.~~

- 2) The User Equipment shall reset the list of 'Forbidden location areas for roaming' when switched off or when the USIM is removed.
- 3) The UE shall be capable of storing at least 6 entries in the list of 'Forbidden location areas for roaming'.

#### Reference

3GPP TS 24.008 clause 4.7.3.1.

#### ~~12.2.1.5a.3~~ Test purpose

##### Test purpose 1

To test that on receipt of a rejection using the 'roaming not allowed in this location area' cause code, the UE ceases trying to attach on that location area. Successful PS attach procedure is possible in other location areas.

##### Test purpose 2

To test that if the UE is switched off or the USIM is removed the list of 'forbidden location areas for roaming' is cleared.

##### Test purpose 3

To test that at least 6 entries can be held in the list of 'forbidden location areas for roaming' (the requirement in 3GPP TS 24.008 is to store at least 10 entries. This is not fully tested by the third procedure).

##### Test purpose 4

To test that if a cell of the Home PLMN is available then the UE returns to it in preference to any other available cell.

#### ~~12.2.1.5a.4~~ Method of test

#### ~~12.2.1.5a.4.1~~ Test procedure 1

#### Initial condition

#### System Simulator:

- Three cells (not simultaneously activated), cell A in MCC2/MNC1/LAC1/RAC1 (RAI-2, Not HPLMN), cell B in MCC2/MNC1/LAC2/RAC1 (RAI-6, Not HPLMN) and cell C in MCC2/MNC1/LAC1/RAC2 (RAI-7, Not HPLMN);
- All three cells are operating in network operation mode II.

#### User Equipment:

- The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-2.

#### Related ICS/IXIT statements

- Support of PS service — Yes/No
- UE operation mode C — Yes/No
- UE operation mode A — Yes/No
- Switch off on button — Yes/No
- Automatic PS attach procedure at switch on or power on — Yes/No

### Test procedure

The SS rejects a PS attach with the cause value 'Roaming not allowed in this area'. A new attempt for a PS attach is not possible. Successful PS attach / detach procedures are performed in another location area. A new attempt for a PS attach is performed in the 1<sup>st</sup> location area. This attempt shall not succeed, as the LA is on the forbidden list.

## Expected Sequence

| Step | Direction |    | Message                                                                                                                     | Comments                                                                                                                                                                               |
|------|-----------|----|-----------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                                                                             |                                                                                                                                                                                        |
| 1    | SS        | UE | ATTACH REQUEST<br><br>ATTACH REJECT                                                                                         | The following messages are sent and shall be received on cell A.<br>The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 19.                |
| 2    | SS        | UE |                                                                                                                             | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Off cell".<br>(see note)                   |
| 3    | UE        | SS |                                                                                                                             | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                  |
| 4    | →         | ←  |                                                                                                                             | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-2                                                                         |
| 5    | ←         | →  |                                                                                                                             | GMM cause = 'Roaming not allowed in this area'                                                                                                                                         |
| 6    | UE        | SS |                                                                                                                             | No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds).                                                                                                                                 |
| 7    | SS        | UE | Registration on CS<br><br>ATTACH REQUEST<br><br>ATTACH ACCEPT<br><br>ATTACH COMPLETE<br><br>DETACH REQUEST<br>DETACH ACCEPT | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note) |
| 8    | UE        | SS |                                                                                                                             | Cell B is preferred by the UE.                                                                                                                                                         |
| 9    | UE        | SS |                                                                                                                             | See TS 34.108<br>This is applied only for UE in UE operation mode A.<br>Parameter mobile identity is IMSI.                                                                             |
| 10   | UE        | SS |                                                                                                                             | The UE initiates an attach automatically, by MMI or by AT command.                                                                                                                     |
| 11   | →         | ←  |                                                                                                                             | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                                                                                    |
| 12   | ←         | →  |                                                                                                                             | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-6                                                                |
| 13   | →         | ←  |                                                                                                                             |                                                                                                                                                                                        |
| 14   | UE        | SS |                                                                                                                             | The UE initiates a PS detach (without power off) by MMI or by AT command.                                                                                                              |
| 15   | →         | ←  |                                                                                                                             | Detach type = 'normal detach, PS detach'                                                                                                                                               |
| 16   | ←         | →  |                                                                                                                             |                                                                                                                                                                                        |
| 17   | SS        | UE |                                                                                                                             | The following messages are sent and shall be received on cell C.<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Serving cell".<br>(see note) |
| 18   | UE        | SS |                                                                                                                             | Cell C is preferred by the UE.                                                                                                                                                         |
| 19   | UE        | SS |                                                                                                                             | No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds).<br>The UE is switched off or power is removed (see ICS)                                                                         |
| 20   | UE        | SS |                                                                                                                             | UE is switched off.                                                                                                                                                                    |
| 21   | SS        | UE |                                                                                                                             | Set the cell type of cell C to the "Off cell".<br>(see note)                                                                                                                           |
| 22   | UE        | SS |                                                                                                                             | The UE is set in UE operation mode A if supported (see ICS) and the test is repeated from step 2 to step 20.                                                                           |

NOTE: The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only".

#### ~~12.2.1.5a.4.2 Test procedure 2~~

##### ~~Initial condition~~

##### ~~System Simulator:~~

- ~~— One cell in MCC2/MNC1/LAC1/RAC1 (RAI-2, Not HPLMN) operating in network operation mode II.~~

##### ~~User Equipment:~~

- ~~— The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-2.~~

##### ~~Related ICS/IXIT statements~~

- ~~— Support of PS service — Yes/No~~
- ~~UE operation mode C — Yes/No~~
- ~~UE operation mode A — Yes/No (only if mode C not supported)~~
- ~~Switch off on button Yes/No~~
- ~~Automatic PS attach procedure at switch on or power on — Yes/No~~

##### ~~Test procedure~~

~~The SS rejects a PS attach updating with the cause value 'Roaming not allowed in this area'. The UE is switched off for 10 s and switched on again. The SS check that a PS attach is possible on the cell on which the PS attach had been rejected.~~

~~If USIM removal is possible without switching off: The SS rejects a PS attach with the cause value 'Roaming not allowed in this area'. The USIM is removed and inserted in the UE. The SS check that a PS attach is possible on the cell on which the PS attach had been rejected.~~



## Expected Sequence

| Step | Direction |    | Message            | Comments                                                                                                                                                            |
|------|-----------|----|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                                                     |
| 1    | UE        |    |                    | If UE operation mode C is supported, the UE is set in UE operation mode C (see ICS). If UE operation mode C is not supported, the UE is set in UE operation mode A. |
| 2    | UE        |    |                    | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                              |
| 3    | →         |    | ATTACH-REQUEST     | Attach type = 'PS-attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                       |
| 4    | ←         |    | ATTACH-REJECT      | Routing area identity = RAI-2<br>GMM-cause = 'Roaming not allowed in this area'                                                                                     |
| 5    | UE        |    |                    | No ATTACH-REQUEST sent to the SS (SS waits 30 seconds).                                                                                                             |
| 6    | UE        |    |                    | If possible (see ICS) switch off is performed. Otherwise the power is removed.                                                                                      |
| 7    | UE        |    |                    | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                              |
| 8    | UE        |    | Registration on CS | See TS 34.108<br>This is applied only for UE in UE operation mode A.                                                                                                |
| 9    | →         |    | ATTACH-REQUEST     | Parameter mobile identity is IMSI<br>Attach type = 'PS-attach'                                                                                                      |
| 10   | ←         |    | ATTACH-ACCEPT      | Mobile identity = IMSI<br>Attach result = 'PS-only attached'                                                                                                        |
| 11   | →         |    | ATTACH-COMPLETE    | Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                                                    |
| 12   | UE        |    |                    | Routing area identity = RAI-2<br>The UE is switched off or power is removed (see ICS).                                                                              |
| 13   | →         |    | DETACH-REQUEST     | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                              |

## 12.2.1.5a.4.3 — Test procedure 3

## Initial condition

## System Simulator:

- Six cells (not simultaneously activated), cell A in MCC2/MNC1/LAC1/RAC1 (RAI-2, Not HPLMN), cell B in MCC2/MNC1/LAC2/RAC1 (RAI-3, Not HPLMN), cell C in MCC2/MNC1/LAC3/RAC1 (Not HPLMN), cell D in MCC2/MNC1/LAC4/RAC1 (Not HPLMN), cell E in MCC2/MNC1/LAC5/RAC1 (Not HPLMN), cell F in MCC2/MNC1/LAC6/RAC1 (Not HPLMN).
- All six cells are operating in network operation mode II (in case of UE operation mode A).

## User Equipment:

- The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-2.

## Related ICS/IXIT statements

- Support of PS service — Yes/No
- UE operation mode C — Yes/No
- UE operation mode A — Yes/No (only if mode C not supported)
- Switch off on button — Yes/No
- Automatic PS attach procedure at switch on or power on — Yes/No

### Test procedure

The SS rejects a PS attach with the cause value 'Roaming not allowed in this area'. This is done for 6 different location areas. Then the SS checks that the UE does not attempt to perform an attach procedure on the non-allowed location areas.

Different types of UE may use different methods to periodically clear the list of forbidden areas (e.g. every day at 12am) for roaming. If the list is cleared while the test is being run, it may be necessary to re-run the test.

## Expected Sequence

| Step | Direction |    | Message            | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|------|-----------|----|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 1    |           | SS |                    | The following messages are sent and shall be received on cell A:<br>The SS is set in network operation mode II.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Off cell".<br>Set the cell type of cell D to the "Off cell".<br>Set the cell type of cell E to the "Off cell".<br>Set the cell type of cell F to the "Off cell".<br>(see note) |
| 2    | UE        |    |                    | The UE is set in UE operation mode C (see ICS).                                                                                                                                                                                                                                                                                                                                                                                               |
| 3    | UE        |    |                    | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                                                                                                                                                                                                                                                                         |
| 4    | →         |    | ATTACH REQUEST     | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-2                                                                                                                                                                                                                                                                                                                                |
| 5    |           | ←  | ATTACH REJECT      | GMM cause = 'Roaming not allowed in this area'                                                                                                                                                                                                                                                                                                                                                                                                |
| 6    | UE        |    |                    | No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds)                                                                                                                                                                                                                                                                                                                                                                                         |
| 7    |           | SS |                    | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)                                                                                                                                                                                                                                                        |
| 8    | UE        |    |                    | Cell B is preferred by the UE.                                                                                                                                                                                                                                                                                                                                                                                                                |
| 9    | UE        |    | Registration on CS | See TS 34.108<br>This is applied only in case of UE operation mode A.<br>Parameter mobile identity is IMSI.                                                                                                                                                                                                                                                                                                                                   |
| 10   | UE        |    |                    | The UE initiates an attach automatically, by MMI or by AT command.                                                                                                                                                                                                                                                                                                                                                                            |
| 11   | →         |    | ATTACH REQUEST     | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                                                                                                                                                                                                                                                                                                                                           |
| 12   |           | ←  | ATTACH REJECT      | GMM cause = 'Roaming not allowed in this area'                                                                                                                                                                                                                                                                                                                                                                                                |
| 13   | UE        |    |                    | No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds).                                                                                                                                                                                                                                                                                                                                                                                        |
| 14   |           | SS |                    | The following messages are sent and shall be received on cell C.<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Serving cell".<br>(see note)                                                                                                                                                                                                                                                        |
| 15   | UE        |    |                    | Cell C is preferred by the UE.                                                                                                                                                                                                                                                                                                                                                                                                                |
| 16   | UE        |    | Registration on CS | See TS 34.108<br>This is applied only for UE in UE operation mode A.<br>Parameter mobile identity is IMSI.                                                                                                                                                                                                                                                                                                                                    |
| 17   | UE        |    |                    | The UE initiates an attach automatically, by MMI or by AT command.                                                                                                                                                                                                                                                                                                                                                                            |
| 18   | →         |    | ATTACH REQUEST     | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                                                                                                                                                                                                                                                                                                                                           |
| 19   |           | ←  | ATTACH REJECT      | GMM cause = 'Roaming not allowed in this area'                                                                                                                                                                                                                                                                                                                                                                                                |
| 20   | UE        |    |                    | No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds).                                                                                                                                                                                                                                                                                                                                                                                        |
| 21   |           | SS |                    | The following messages are sent and shall be received on cell D.<br>Set the cell type of cell C to the "Off cell".<br>Set the cell type of cell D to the "Serving cell".<br>(see note)                                                                                                                                                                                                                                                        |

| Step     | Direction |    | Message            | Comments                                                                                                                                                                               |
|----------|-----------|----|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|          | UE        | SS |                    |                                                                                                                                                                                        |
| 22<br>23 | UE<br>UE  |    | Registration-on-CS | Cell D is preferred by the UE.<br>See TS 34.108<br>This is applied only for UE in UE operation mode A.<br>Parameter mobile identity is IMSI.                                           |
| 24       | UE        |    |                    | The UE initiates an attach automatically, by MMI or by AT command.                                                                                                                     |
| 25       | →         |    | ATTACH REQUEST     | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                                                                                    |
| 26       | ←         |    | ATTACH REJECT      | GMM cause = 'Roaming not allowed in this area'                                                                                                                                         |
| 27       | UE        |    |                    | No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds).                                                                                                                                 |
| 28       |           | SS |                    | The following messages are sent and shall be received on cell E.<br>Set the cell type of cell D to the "Off cell".<br>Set the cell type of cell E to the "Serving cell".<br>(see note) |
| 29<br>30 | UE<br>UE  |    | Registration-on-CS | Cell E is preferred by the UE.<br>See TS 34.108<br>This is applied only for UE in UE operation mode A.<br>Parameter mobile identity is IMSI.                                           |
| 31       | UE        |    |                    | The UE initiates an attach automatically, by MMI or by AT command.                                                                                                                     |
| 32       | →         |    | ATTACH REQUEST     | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                                                                                    |
| 33       | ←         |    | ATTACH REJECT      | GMM cause = 'Roaming not allowed in this area'                                                                                                                                         |
| 34       | UE        |    |                    | No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds).                                                                                                                                 |
| 35       |           | SS |                    | The following messages are sent and shall be received on cell F.<br>Set the cell type of cell E to the "Off cell".<br>Set the cell type of cell F to the "Serving cell".<br>(see note) |
| 36<br>37 | UE<br>UE  |    | Registration-on-CS | Cell F is preferred by the UE.<br>See TS 34.108<br>This is applied only for UE in UE operation mode A.                                                                                 |
| 38       | UE        |    |                    | The UE initiates an attach automatically, by MMI or by AT command.                                                                                                                     |
| 39       | →         |    | ATTACH REQUEST     | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                                                                                    |
| 40       | ←         |    | ATTACH REJECT      | GMM cause = 'Roaming not allowed in this area'                                                                                                                                         |
| 41       | UE        |    |                    | No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds)                                                                                                                                  |
| 42       |           | SS |                    | The following messages are sent and shall be received on cell E.<br>Set the cell type of cell E to the "Serving cell".<br>Set the cell type of cell F to the "Off cell".<br>(see note) |
| 43<br>44 | SS<br>UE  |    |                    | Cell E is preferred by the UE.<br>The UE initiates an attach automatically, by MMI or by AT command.                                                                                   |
| 45       | UE        |    |                    | No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds).                                                                                                                                 |
| 46       |           | SS |                    | The following messages are sent and shall be received on cell C.<br>Set the cell type of cell C to the "Serving cell".<br>Set the cell type of cell E to the "Off cell".<br>(see note) |
| 47<br>48 | SS<br>UE  |    |                    | Cell C is preferred by the UE.<br>The UE initiates an attach automatically, by MMI or by AT command.                                                                                   |

| Step                                                                                                                                                        | Direction |    | Message | Comments                                                                                                                                                                               |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                             | UE        | SS |         |                                                                                                                                                                                        |
| 49                                                                                                                                                          | UE        |    |         | No ATTACH REQUEST sent to SS (SS waits 30 seconds).                                                                                                                                    |
| 50                                                                                                                                                          | SS        |    |         | The following messages are sent and shall be received on cell A:<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell C to the "Off cell".<br>(see note) |
| 51                                                                                                                                                          | SS        |    |         | Cell A will be preferred by the UE.                                                                                                                                                    |
| 52                                                                                                                                                          | UE        |    |         | The UE initiates an attach automatically, by MMI or by AT command.                                                                                                                     |
| 53                                                                                                                                                          | UE        |    |         | No ATTACH REQUEST sent to SS (SS waits 30 seconds).                                                                                                                                    |
| NOTE: — The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |         |                                                                                                                                                                                        |

#### 12.2.1.5a.4.4 Test procedure4

##### Initial condition

##### System Simulator:

- Two cells, cell A in MCC2/MNC1/LAC1/RAC1 (not HPLMN, RAI-2) and cell B in MCC1/MNC1/LAC1/RAC1 (HPLMN, RAI-1).  
Both cells are operating in network operation mode II (in case of UE operation mode A).

##### User Equipment:

- The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-2.

##### Related ICS/IXIT statements

- Support of PS service — Yes/No
- UE operation mode C — Yes/No
- UE operation mode A — Yes/No (only if mode C not supported)
- Switch off on button Yes/No
- Automatic PS attach procedure at switch on or power on — Yes/No

##### Test procedure

The SS rejects a PS attach with the cause value "Roaming not allowed in this area". A second cell belonging to the HPLMN is activated. It is checked that the UE returns to its HPLMN.

## Expected Sequence

| Step                                                                                                                                                                     | Direction |    | Message            | Comments                                                                                              |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|--------------------|-------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                          | UE        | SS |                    |                                                                                                       |
| 1                                                                                                                                                                        | SS        |    |                    | The following messages are sent and shall be received on cell A.                                      |
| 2                                                                                                                                                                        | UE        |    |                    | The UE is set in UE operation mode C (see ICS).                                                       |
| 3                                                                                                                                                                        | SS        |    |                    | The SS is set in network operation mode II.                                                           |
| 4                                                                                                                                                                        | UE        |    |                    | Set the cell type of cell A to the "Serving cell".                                                    |
| 5                                                                                                                                                                        |           |    |                    | Set the cell type of cell B to the "Suitable neighbour cell".                                         |
| 6                                                                                                                                                                        |           |    |                    | (see note)                                                                                            |
| 7                                                                                                                                                                        | UE        |    |                    | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE. |
| 8                                                                                                                                                                        | →         |    | ATTACH REQUEST     | Attach type = 'PS attach'                                                                             |
| 9                                                                                                                                                                        |           |    |                    | Mobile identity = P-TMSI-1                                                                            |
| 10                                                                                                                                                                       |           |    |                    | P-TMSI-1 signature                                                                                    |
| 11                                                                                                                                                                       | ←         |    | ATTACH REJECT      | Routing area identity = RAI-2                                                                         |
| 12                                                                                                                                                                       |           |    |                    | GMM cause = 'Roaming not allowed in this area'                                                        |
| 13                                                                                                                                                                       | UE        |    |                    | No ATTACH REQUEST sent to SS (SS waits 30 seconds).                                                   |
| 14                                                                                                                                                                       | SS        |    |                    | The following messages are sent and shall be received on cell B.                                      |
| 15                                                                                                                                                                       |           |    |                    | Set the cell type of cell A to the "Suitable neighbour cell".                                         |
| 16                                                                                                                                                                       |           |    |                    | Set the cell type of cell B to the "Serving cell".                                                    |
| 17                                                                                                                                                                       |           |    |                    | (see note)                                                                                            |
| 18                                                                                                                                                                       | UE        |    | Registration on CS | See TS 34.108                                                                                         |
| 19                                                                                                                                                                       |           |    |                    | This is applied only for UE in UE operation mode A.                                                   |
| 20                                                                                                                                                                       |           |    |                    | Parameter mobile identity is IMSI.                                                                    |
| 21                                                                                                                                                                       | UE        |    |                    | The UE initiates an attach automatically, by MMI or by AT command.                                    |
| 22                                                                                                                                                                       | →         |    | ATTACH REQUEST     | Attach type = 'PS attach'                                                                             |
| 23                                                                                                                                                                       |           |    |                    | Mobile identity = IMSI                                                                                |
| 24                                                                                                                                                                       | ←         |    | ATTACH ACCEPT      | Attach result = 'PS only attached'                                                                    |
| 25                                                                                                                                                                       |           |    |                    | Mobile identity = P-TMSI-1                                                                            |
| 26                                                                                                                                                                       |           |    |                    | P-TMSI-1 signature                                                                                    |
| 27                                                                                                                                                                       |           |    |                    | Routing area identity = RAI-1                                                                         |
| 28                                                                                                                                                                       | →         |    | ATTACH COMPLETE    |                                                                                                       |
| 29                                                                                                                                                                       | UE        |    |                    | The UE is switched off or power is removed (see ICS).                                                 |
| 30                                                                                                                                                                       | →         |    | DETACH REQUEST     | Message not sent if power is removed.                                                                 |
| 31                                                                                                                                                                       |           |    |                    | Detach type = 'power switched off, PS detach'                                                         |
| NOTE: The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                    |                                                                                                       |

## Specific message contents

None.

## 12.2.1.5a.5 Test requirements

## Test requirements for Test procedure1

At step4, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step6, when the UE receives the ATTACH REJECT message with GMM cause = 'Roaming not allowed in this area', UE shall:

— not perform the PS attach procedure.

At step11, when the new location area is entered, UE shall:

— perform the PS attach procedure

At step19, when the rejected location area is entered, UE shall

— not perform PS attach procedure.

#### Test requirements for Test procedure2

At step3, when the UE is powered up or switched on, UE shall:

— initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step5, after the UE receives the ATTACH REJECT message with GMM cause = 'Roaming not allowed in this area', UE shall:

— not perform PS attach procedure.

At step9, when the UE is switched off or USIM is replaced, UE shall:

— perform the PS attach procedure.

#### Test requirements for Test procedure3

At step4, when the UE is powered up or switched on, UE shall:

— initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step6, 13, 20, 27, 34 and 41, after the UE receives the ATTACH REJECT message with GMM cause = 'Roaming not allowed in this area', UE shall:

— not perform PS attach procedure.

At step11, 18, 25, 32 and 39, UE shall:

— initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step45, 49 and 53, UE shall:

— not perform PS attach procedure.

#### Test requirements for Test procedure4

At step4, when the UE is powered up or switched on, UE shall:

— initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step6, when the UE receives the ATTACH REJECT message with GMM cause = 'Roaming not allowed in this area', UE shall:

— not perform PS attach procedure.

At step10, when a new location area is entered, UE shall:

— perform the PS attach procedure.

### ~~12.2.1.5b PS attach / rejected / No Suitable Cells In Location Area~~

#### ~~12.2.1.5b.1 Definition~~

#### ~~12.2.1.5b.2 Conformance requirement~~

~~(1) If the network rejects a PS attach procedure from the User Equipment with the cause 'No Suitable Cells In Location Area', the User Equipment shall:~~

- ~~1.1 not perform PS attach when in the same location area.~~
- ~~1.2 delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.~~
- ~~1.3 store the LA in the 'forbidden location areas for roaming' list.~~
- ~~1.4 perform PS attach when a new location area is entered.~~

#### Reference

3GPP TS 24.008 clauses 4.7.3.1.

#### ~~12.2.1.5b.3 Test purpose~~

~~To test the behaviour of the UE if the network rejects the PS attach procedure of the UE with the cause 'No Suitable Cells In Location Area'.~~

#### ~~12.2.1.5b.4 Method of test~~

#### Initial condition

System Simulator:

- ~~— Three cells, cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC2/RAC1 (RAI-3), cell C in MCC2/MNC1/LAC1/RAC1 (RAI-2)~~
- ~~— All three cells are operating in network operation mode II.~~

User Equipment:

- ~~— The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.~~

#### Related ICS/IXIT statements

- ~~— Support of PS service — Yes/No~~
- ~~UE operation mode A — Yes/No~~
- ~~Switch-off on button — Yes/No~~
- ~~Automatic PS attach procedure at switch-on or power-on — Yes/No~~

#### Test procedure

The SS rejects a PS attach with the cause value 'No Suitable Cells In Location Area'. The SS checks that the UE shall search for a suitable cell in a different location area on the same PLMN and shall perform PS attach procedure in that cell.



## Expected Sequence

| Step                                                                                                                                                                      | Direction |    | Message            | Comments                                                                                                                                                                                                                                                                                 |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                           | UE        | SS |                    |                                                                                                                                                                                                                                                                                          |
|                                                                                                                                                                           |           | SS |                    | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>Set the cell type of cell C to the "Suitable neighbour cell".<br>(see note)<br>The SS configures power level of each Cell as follows:<br>Cell A > Cell B = Cell C |
| 1                                                                                                                                                                         | UE        |    |                    | The UE is set in UE operation mode A (see ICS).                                                                                                                                                                                                                                          |
| 2                                                                                                                                                                         | UE        |    |                    | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                                                                                                                    |
| 3                                                                                                                                                                         | ->        |    | ATTACH REQUEST     | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                                                                                                                                                                           |
| 4                                                                                                                                                                         | <-        |    | ATTACH REJECT      | GMM cause = 'No Suitable Cells In Location Area'                                                                                                                                                                                                                                         |
| 5                                                                                                                                                                         |           | SS |                    | The SS initiates the RRC connection release. The following message are sent and shall be received on cell B.                                                                                                                                                                             |
| 6                                                                                                                                                                         | UE        |    | Registration on CS | See TS 34.108                                                                                                                                                                                                                                                                            |
| 7                                                                                                                                                                         | UE        |    |                    | The UE initiates an attach automatically, by MMI or by AT command.                                                                                                                                                                                                                       |
| 8                                                                                                                                                                         | ->        |    | ATTACH REQUEST     | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                                                                                                                                                                                      |
| 9                                                                                                                                                                         | <-        |    | ATTACH ACCEPT      | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-2                                                                                                                                                                  |
| 10                                                                                                                                                                        | ->        |    | ATTACH COMPLETE    |                                                                                                                                                                                                                                                                                          |
| 11                                                                                                                                                                        | UE        |    |                    | The UE is switched off or power is removed (see ICS).                                                                                                                                                                                                                                    |
| 12                                                                                                                                                                        | ->        |    | DETACH REQUEST     | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                                                                                                                   |
| NOTE: The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS 34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                    |                                                                                                                                                                                                                                                                                          |

## Specific message contents

None.

## 12.2.1.5b.5 — Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step8, when the UE enters a suitable cell in a different location area on the same PLMN, UE shall:

- perform the PS attach procedure.

### ~~12.2.1.6 PS attach / abnormal cases / access barred due to access class control~~

#### ~~12.2.1.6.1 Definition~~

#### ~~12.2.1.6.2 Conformance requirement~~

- ~~1) The UE shall not perform PS attach procedure, but stays in the current serving cell and applies normal cell reselection process.~~
- ~~2) The User Equipment shall perform the PS attach procedure when:~~
  - ~~2.1 Access is granted.~~
  - ~~2.2 Cell is changed.~~

#### Reference

3GPP TS 24.008 clause 4.7.3.1.

#### ~~12.2.1.6.3 Test purpose~~

##### ~~Test purpose1~~

~~To test the behaviour of the UE in case of access class control (access is granted).~~

##### ~~Test purpose2~~

~~To test the behaviour of the UE in case of access class control (Cell is changed).~~

#### ~~12.2.1.6.4 Method of test~~

##### ~~12.2.1.6.4.1 Test procedure1~~

##### Initial condition

An access class x (0-15) is arbitrarily chosen. The USIM is programmed with this access class x. Communication with User Equipments using access class x is initially indicated to be barred.

##### System Simulator:

- ~~— One cell operating in network operation mode II.~~
- ~~Access class x barred.~~

##### User Equipment:

- ~~— The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.~~

##### Related ICS/IXIT statements

- ~~— Support of PS service — Yes/No~~
- ~~— UE operation mode C — Yes/No~~
- ~~— UE operation mode A — Yes/No~~
- ~~— Switch off on button — Yes/No~~
- ~~— Automatic PS attach procedure at switch on or power on — Yes/No~~

### Test procedure

The SS indicates access class x barred. A PS attach procedure is not performed.

The SS indicates that access class x is not barred. A PS attach procedure is performed.

### Expected Sequence

| Step | Direction |    | Message         | Comments                                                                                                                |
|------|-----------|----|-----------------|-------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                 |                                                                                                                         |
| 1    | UE        |    |                 | The USIM is programmed with access class x.                                                                             |
| 2    | UE        |    |                 | The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 12.                     |
| 3    | UE        |    |                 | The UE is powered up or switched on and attempts to initiate an attach (see ICS).                                       |
| 4    | UE        |    |                 | No ATTACH REQUEST sent to SS, as access class x is barred (SS waits 30 seconds).                                        |
| 5    | SS        |    |                 | The access class x is not barred anymore.                                                                               |
| 6    | UE        |    |                 | The UE automatically initiates a PS attach.                                                                             |
| 7    | →         |    | ATTACH REQUEST  | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1          |
| 8    | ←         |    | ATTACH ACCEPT   | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1 |
| 9    | →         |    | ATTACH COMPLETE |                                                                                                                         |
| 10   | UE        |    |                 | The UE is switched off or power is removed (see ICS).                                                                   |
| 11   | →         |    | DETACH REQUEST  | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                  |
| 12   | SS        |    |                 | The SS is set in network operation mode II.                                                                             |
| 13   | UE        |    |                 | The UE is set in UE operation mode A (see ICS) and the test is repeated from step 3 to step 11.                         |

### 12.2.1.6.4.2 Test procedure2

#### Initial condition

An access class x (0-15) is arbitrarily chosen. The USIM is programmed with this access class x. Communication with User Equipments using access class x is indicated to be barred on cell A.

#### System Simulator:

- Two cells, cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1) has access class x barred, cell B in MCC1/MNC1/LAC1/RAC1 (RAI-1) has access class x not barred.
- Both cells are operating in network operation mode II (in case of UE operation mode A).

#### User Equipment:

- The UE has a valid P-TMSI-2, P-TMSI-2 signature and RAI-1.

#### Related ICS/IXIT statements

- Support of PS service — Yes/No
- UE operation mode C — Yes/No
- UE operation mode A Yes/No Switch off on button — Yes/No
- Automatic PS attach procedure at switch on or power on — Yes/No

### Test procedure

The SS indicates access class x barred. A PS attach procedure is not performed.

A cell change is performed into a cell where access class x is not barred. A PS attach procedure is performed.

### Expected Sequence

| Step                                                                                                                                                                     | Direction |    | Message         | Comments                                                                          |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-----------------|-----------------------------------------------------------------------------------|
|                                                                                                                                                                          | UE        | SS |                 |                                                                                   |
| 1                                                                                                                                                                        | UE        | SS |                 | The USIM is programmed with access class x.                                       |
| 2                                                                                                                                                                        |           | SS |                 | The following messages are sent and shall be received on cell A.                  |
| 3                                                                                                                                                                        | UE        |    |                 | The SS is set in network operation mode II.                                       |
| 4                                                                                                                                                                        | UE        |    |                 | Set the cell type of cell A to the "Serving cell".                                |
| 5                                                                                                                                                                        | UE        |    |                 | Set the cell type of cell B to the "Suitable neighbour cell".                     |
|                                                                                                                                                                          |           |    |                 | (see note)                                                                        |
|                                                                                                                                                                          |           |    |                 | The UE is set in UE operation mode C (see ICS).                                   |
|                                                                                                                                                                          |           |    |                 | The UE is powered up or switched on and attempts to initiate an attach (see ICS). |
|                                                                                                                                                                          |           |    |                 | No ATTACH REQUEST sent to SS, as access class x is barred (SS waits 30 seconds).  |
| 6                                                                                                                                                                        |           | SS |                 | The following messages are sent and shall be received on cell B.                  |
| 7                                                                                                                                                                        |           |    |                 | Set the cell type of cell A to the "Suitable neighbour cell".                     |
| 8                                                                                                                                                                        | UE        |    | ATTACH REQUEST  | Set the cell type of cell B to the "Serving cell".                                |
|                                                                                                                                                                          | →         |    |                 | (see note)                                                                        |
|                                                                                                                                                                          |           |    |                 | The UE automatically initiates an attach.                                         |
|                                                                                                                                                                          |           |    |                 | Attach type = 'PS attach'                                                         |
|                                                                                                                                                                          |           |    |                 | Mobile identity = P-TMSI-2                                                        |
|                                                                                                                                                                          |           |    |                 | P-TMSI-2 signature                                                                |
|                                                                                                                                                                          |           |    |                 | Routing area identity = RAI-1                                                     |
| 9                                                                                                                                                                        |           | ←  | ATTACH ACCEPT   | Attach result = 'PS only attached'                                                |
|                                                                                                                                                                          |           |    |                 | Mobile identity = P-TMSI-1                                                        |
|                                                                                                                                                                          |           |    |                 | P-TMSI-1 signature                                                                |
|                                                                                                                                                                          |           |    |                 | Routing area identity = RAI-1                                                     |
| 10                                                                                                                                                                       | →         |    | ATTACH COMPLETE |                                                                                   |
| 11                                                                                                                                                                       | UE        |    |                 | The UE is switched off or power is removed (see ICS).                             |
| 12                                                                                                                                                                       | →         |    | DETACH REQUEST  | Message not sent if power is removed.                                             |
|                                                                                                                                                                          |           |    |                 | Detach type = 'power switched off, PS detach'                                     |
| NOTE: The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                 |                                                                                   |

### Specific message contents

None.

### 12.2.1.6.5 Test requirements

#### Test requirements for Test procedure1

At step4, when the UE access class x is barred, UE shall:

- not perform a PS attach procedure.

At step7, when the UE access class x is granted, UE shall:

- initiate the PS attach procedure.

## ~~Test requirements for Test procedure2~~

~~At step5, when the UE access class x is barred, UE shall:~~

- ~~— not perform a PS attach procedure.~~

~~At step8, when the serving cell is changed, UE shall:~~

- ~~— initiate the PS attach procedure.~~

## ~~12.2.1.7 PS attach / abnormal cases / change of cell into new routing area~~

### ~~12.2.1.7.1 Definition~~

### ~~12.2.1.7.2 Conformance requirement~~

~~When a change of cell into a new routing area is performed before ATTACH ACCEPT message is received by the UE, the UE shall abort the PS attach procedure and re-initiate it immediately.~~

### ~~Reference~~

~~3GPP TS 24.008 clause 4.7.3.1.~~

### ~~12.2.1.7.3 Test purpose~~

~~To test the behaviour of the UE in case of procedure collision.~~

### ~~12.2.1.7.4 Method of test~~

### ~~Initial condition~~

~~System Simulator:~~

- ~~— Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1) and cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4).~~
- ~~Both cells are operating in network operation mode II (in case of UE operation mode A).~~

~~User Equipment:~~

- ~~— The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.~~

### ~~Related ICS/IXIT statements~~

- ~~— Support of PS service — Yes/No~~
- ~~— UE operation mode C — Yes/No~~
- ~~— UE operation mode A — Yes/No (only if mode C not supported)~~
- ~~— Switch off on button — Yes/No~~
- ~~— Automatic PS attach procedure at switch on or power on — Yes/No~~

### ~~Test procedure~~

~~The UE initiates a PS attach procedure. The ATTACH ACCEPT message is delayed from the SS. The UE performs a cell reselection to a cell in a new routing area. The UE shall re-initiate a PS attach procedure in the new routing area.~~

## Expected Sequence

| Step                                                                                                                                                      | Direction |    | Message        | Comments                                                                                              |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|----------------|-------------------------------------------------------------------------------------------------------|
|                                                                                                                                                           | UE        | SS |                |                                                                                                       |
| 1                                                                                                                                                         | SS        |    |                | The following messages are sent and shall be received on cell A.                                      |
| 2                                                                                                                                                         | UE        |    |                | The UE is set in UE operation mode C (see ICS).                                                       |
| 3                                                                                                                                                         | SS        |    |                | The SS is set in network operation mode II.                                                           |
| 4                                                                                                                                                         | UE        |    |                | Set the cell type of cell A to the "Serving cell".                                                    |
| 5                                                                                                                                                         | SS        |    |                | Set the cell type of cell B to the "Off cell". (see note)                                             |
| 6                                                                                                                                                         | UE        |    |                | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE. |
| 7                                                                                                                                                         | →         |    | ATTACH REQUEST | Attach type = 'PS attach'                                                                             |
| 8                                                                                                                                                         |           |    |                | Mobile identity = P-TMSI-1                                                                            |
| 9                                                                                                                                                         |           |    |                | P-TMSI-1 signature                                                                                    |
| 10                                                                                                                                                        |           |    |                | Routing area identity = RAI-1                                                                         |
| 11                                                                                                                                                        |           |    |                | No response to the ATTACH REQUEST message is given by the SS.                                         |
| 12                                                                                                                                                        | SS        |    |                | The following messages are sent and shall be received on cell B.                                      |
| 13                                                                                                                                                        | UE        |    |                | Set the cell type of cell A to the "Off cell".                                                        |
| 14                                                                                                                                                        | SS        |    |                | Set the cell type of cell B to the "Serving cell". (see note)                                         |
| 15                                                                                                                                                        | UE        |    |                | Cell B is preferred by the UE.                                                                        |
| 16                                                                                                                                                        | UE        |    |                | The UE automatically re-initiates the attach in the new cell.                                         |
| 17                                                                                                                                                        | →         |    | ATTACH REQUEST | Attach type = 'PS attach'                                                                             |
| 18                                                                                                                                                        |           |    |                | Mobile identity = P-TMSI-1                                                                            |
| 19                                                                                                                                                        |           |    |                | P-TMSI-1 signature                                                                                    |
| 20                                                                                                                                                        |           |    |                | Routing area identity = RAI-1                                                                         |
| 21                                                                                                                                                        | ←         |    | ATTACH ACCEPT  | No new mobile identity assigned.                                                                      |
| 22                                                                                                                                                        |           |    |                | P-TMSI and P-TMSI signature not included.                                                             |
| 23                                                                                                                                                        |           |    |                | Attach result = 'PS only attached'                                                                    |
| 24                                                                                                                                                        |           |    |                | Routing area identity = RAI-4                                                                         |
| 25                                                                                                                                                        | UE        |    |                | The UE is switched off or power is removed (see ICS).                                                 |
| 26                                                                                                                                                        | →         |    | DETACH REQUEST | Message not sent if power is removed.                                                                 |
| 27                                                                                                                                                        |           |    |                | Detach type = 'power switched off, PS detach'                                                         |
| NOTE: The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                |                                                                                                       |

## Specific message contents

None.

## 12.2.1.7.5 Test requirements

At step4, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected sequence.

At step8, when a change of cell into a new routing area is performed before ATTACH ACCEPT message or ATTACH REJECT message is received by the UE, UE shall:

- abort the PS attach procedure and re-initiate the PS attach procedure immediately with new information elements.

## ~~12.2.1.8 PS attach / abnormal cases / power off~~

### ~~12.2.1.8.1 Definition~~

### ~~12.2.1.8.2 Conformance requirement~~

~~When power is switched off before ATTACH ACCEPT message is received by the UE, the UE shall abort the PS attach procedure and perform a PS detach procedure.~~

### ~~Reference~~

~~3GPP TS 24.008 clause 4.7.3.~~

### ~~12.2.1.8.3 Test purpose~~

~~To test the behaviour of the UE in case of procedure collision.~~

### ~~12.2.1.8.4 Method of test~~

#### ~~Initial condition~~

#### ~~System Simulator:~~

- ~~— One cell operating in network operation mode II.~~

#### ~~User Equipment:~~

- ~~— The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.~~

#### ~~Related ICS/IXIT statements~~

- ~~— Support of PS service — Yes/No~~
- ~~UE operation mode C — Yes/No~~
- ~~UE operation mode A — Yes/No~~
- ~~Switch off on button — Yes/No~~
- ~~Automatic PS attach procedure at switch on or power on — Yes/No~~

#### ~~Test procedure~~

~~The UE is switched off after initiating an attach procedure. A PS detach is automatically performed by the UE before power is switched off.~~

## Expected Sequence

| Step | Direction |    | Message        | Comments                                                                                           |
|------|-----------|----|----------------|----------------------------------------------------------------------------------------------------|
|      | UE        | SS |                |                                                                                                    |
| 1    | UE        |    | ATTACH REQUEST | The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 7. |
| 2    | UE        |    |                | The UE is powered up or switched on and initiates an attach (see ICS).                             |
| 3    | →         |    |                | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                      |
| 4    |           | SS |                | Routing area identity = RAI-1<br>No response to the ATTACH REQUEST message is given by the SS.     |
| 5    | UE        |    | DETACH REQUEST | The UE is powered off and initiates a PS detach (with power off) by                                |
| 6    | →         |    |                | Detach type = 'power switched off, PS detach'                                                      |
| 7    | UE        |    |                | The UE is set in UE operation mode A (see ICS) and the test is repeated from step 2 to step 6.     |

## Specific message contents

None.

## 12.2.1.8.5 — Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step6, when power is switched off before ATTACH ACCEPT message is received, UE shall:

- abort the PS attach procedure and perform the PS detach procedure.

## 12.2.1.9 — PS attach / abnormal cases / PS detach procedure collision

## 12.2.1.9.1 — Definition

## 12.2.1.9.2 — Conformance requirement

- 1) When a DETACH REQUEST message is received by the UE (any cause except re-attach) while waiting for an ATTACH ACCEPT message, the UE shall terminate the PS attach procedure and continue with the PS detach procedure.
- 2) When a DETACH REQUEST message is received by the UE (cause re-attach) while waiting for an ATTACH ACCEPT message, the UE shall ignore the PS detach procedure and continue with the PS attach procedure.

## Reference

3GPP TS 24.008 clause 4.7.3.1.

## 12.2.1.9.3 — Test purpose

To test the behaviour of the UE in case of procedure collision.

## 12.2.1.9.4 — Method of test

## Initial condition

System Simulator:



—One cell operating in network operation mode H.

#### User Equipment:

—The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

#### Related ICS/IXIT statements

—Support of PS service—Yes/No

UE operation mode C—Yes/No

UE operation mode A—Yes/No (only if mode C not supported)

Switch off on button Yes/No

Automatic PS attach procedure at switch on or power on—Yes/No

#### Test procedure

The UE initiates a PS attach procedure. The SS does not answer the PS attach procedure, but initiates a PS detach procedure (any cause except re-attach). The UE shall terminate the PS attach procedure and continue with the PS detach procedure.

The UE initiates a PS attach procedure. The SS does not answer the PS attach procedure, but initiates a PS detach procedure (cause re-attach). The UE shall ignore the PS detach procedure and continue with the PS attach.

#### Expected Sequence

| Step | Direction |    | Message                                                                                                                                            | Comments                                                                               |
|------|-----------|----|----------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                                                                                                    |                                                                                        |
| 1    | UE        |    | ATTACH REQUEST                                                                                                                                     | The UE is set in UE operation mode C (see ICS).                                        |
| 2    | UE        |    |                                                                                                                                                    | The UE is powered up or switched on and initiates an attach (see ICS).                 |
| 3    | →         |    |                                                                                                                                                    | Attach type = 'PS attach'                                                              |
|      |           |    |                                                                                                                                                    | Mobile identity = P-TMSI-1                                                             |
|      |           |    |                                                                                                                                                    | P-TMSI-1 signature                                                                     |
|      |           |    |                                                                                                                                                    | Routing area identity = RAI-1                                                          |
| 4    | SS        |    | DETACH REQUEST<br>DETACH ACCEPT                                                                                                                    | The SS ignores the ATTACH REQUEST message and initiates a detach procedure.            |
| 5    | ←         |    |                                                                                                                                                    | Detach type = 're-attach not required'                                                 |
| 6    | →         |    |                                                                                                                                                    |                                                                                        |
| 7    | UE        |    | ATTACH REQUEST<br><br><br><br><br><br><br><br><br><br>DETACH REQUEST<br><br><br>ATTACH ACCEPT<br><br><br>ATTACH COMPLETE<br><br><br>DETACH REQUEST | The UE initiates the attach procedure by MMI or AT command.                            |
| 8    | →         |    |                                                                                                                                                    | Attach type = 'PS attach'                                                              |
|      |           |    |                                                                                                                                                    | Mobile identity = P-TMSI-1                                                             |
|      |           |    |                                                                                                                                                    | P-TMSI-1 signature                                                                     |
|      |           |    |                                                                                                                                                    | Routing area identity = RAI-1                                                          |
| 9    | SS        |    |                                                                                                                                                    | The SS ignores the ATTACH REQUEST message and initiates a detach procedure.            |
| 10   | ←         |    |                                                                                                                                                    | Detach type = 're-attach required'                                                     |
| 11   | UE        |    |                                                                                                                                                    | The UE ignores the DETACH REQUEST message and continue with the attach procedure.      |
| 12   | ←         |    |                                                                                                                                                    | Attach result = 'PS only attached'                                                     |
|      |           |    |                                                                                                                                                    | Mobile identity = P-TMSI-2                                                             |
|      |           |    |                                                                                                                                                    | P-TMSI-2 signature                                                                     |
|      |           |    |                                                                                                                                                    | Routing area identity = RAI-1                                                          |
| 13   | →         |    |                                                                                                                                                    |                                                                                        |
| 14   | UE        |    |                                                                                                                                                    | The UE is switched off or power is removed (see ICS).                                  |
| 15   | →         |    |                                                                                                                                                    | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach' |

#### Specific message contents

None.

#### ~~12.2.1.9.5 Test requirements~~

~~At step3, when the UE is powered up or switched on, UE shall:~~

- ~~—initiate the PS attach procedure with information elements specified in the above Expected Sequence.~~

~~UE shall perform the following actions depending on the Detach type in the DETACH REQUEST message:~~

~~Case1) Detach type = ‘re-attach not required’ GMM cause is not re-attach~~

~~At step6, when the DETACH REQUEST message is received by the UE while waiting for an ATTACH ACCEPT message, UE shall:~~

- ~~—terminate the PS attach procedure and continue with the PS detach procedure.~~

~~Case2) Detach type = ‘re-attach required’~~

~~At step11, when the DETACH REQUEST message is received by the UE while waiting for an ATTACH ACCEPT message, UE shall:~~

- ~~—ignore the PS detach procedure and continue with the PS attach procedure.~~

### ~~12.2.2 Combined PS attach~~

#### ~~12.2.2.1 Combined PS attach / PS and non-PS attach accepted~~

##### ~~12.2.2.1.1 Definition~~

##### ~~12.2.2.1.2 Conformance requirement~~

- ~~1) If the network accepts the combined PS attach procedure (signalled by an IMSI) and allocates a P-TMSI, the UE shall acknowledge the P-TMSI and continue communication with the P-TMSI.~~
- ~~2) If the network accepts the combined PS attach procedure (signalled by P-TMSI) and reallocates a new P-TMSI, the UE shall acknowledge the new P-TMSI and continue communication with the new P-TMSI.~~
- ~~3) If the network accepts the combined PS attach procedure (signalled by a P-TMSI) from the UE without reallocation of the previously used P-TMSI, the UE shall continue communication with the previously used P-TMSI.~~
- ~~4) If the network accepts the combined PS attach procedure and determines that IMSI shall be used in CS operations, the UE shall continue communication with the IMSI for CS operations.~~
- ~~5) If the network accepts the combined PS attach procedure and determines that a TMSI shall be used in CS operations, the UE shall continue communication with the TMSI for CS operations.~~

#### ~~Reference~~

~~3GPP TS 24.008 clause 4.7.3.2.~~

##### ~~12.2.2.1.3 Test purpose~~

~~To test the behaviour of the UE if the network accepts the PS attach procedure.~~

~~The following cases are identified:~~

- ~~1) P-TMSI / P-TMSI signature is allocated;~~
- ~~2) P-TMSI / P-TMSI signature is reallocated;~~
- ~~3) Old P-TMSI / P-TMSI signature is not changed;~~
- ~~4) Mobile terminating CS call is allowed with IMSI;~~

- 5) Mobile terminating CS call is not allowed with TMSI.

#### 12.2.2.1.4 Method of test

##### Initial condition

##### System Simulator:

- One cell operating in network operation mode I.

##### User Equipment:

- The UE has a valid IMSI.

##### Related ICS/IXIT statements

- Support of PS service — Yes/No  
UE operation mode A — Yes/No  
Switch off on button — Yes/No  
Automatic PS attach procedure at switch on or power on — Yes/No

##### Test procedure

- 1) The UE sends an ATTACH REQUEST message with identity IMSI. The SS allocates a P-TMSI and returns ATTACH ACCEPT message with a P-TMSI. The UE acknowledges the P-TMSI by sending ATTACH COMPLETE message. Further communication UE – SS is performed by the new P-TMSI. For CS calls, the IMSI is used.
- 2) The UE is CS paged in order to verify that the IMSI is used for CS calls.
- 3) The UE is PS paged in order to verify that the new P-TMSI is used for PS services.
- 4) The UE sends an ATTACH REQUEST message with identity P-TMSI. The SS allocates a new P-TMSI and returns ATTACH ACCEPT message with the new P-TMSI and a new TMSI. The UE acknowledges the P-TMSI and the TMSI by sending ATTACH COMPLETE message. Further communication UE – SS is performed by the new P-TMSI. For CS calls, the new TMSI is used. The UE is CS paged in order to verify that the new TMSI is used for CS services.
- 5) The UE is PS paged in order to verify that the new P-TMSI is used for PS services. The UE will not answer signalling addressed to the old P-TMSI.
- 6) The UE sends an ATTACH REQUEST message with identity P-TMSI. The SS accepts the P-TMSI and returns ATTACH ACCEPT message without any P-TMSI. Further communication UE – SS is performed by the previously used P-TMSI.
- 7) The UE is PS paged in order to verify that the previously used P-TMSI is used for PS services.

## Expected Sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                              |
|------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                       |
| 1    | UE        |    |                                 | The UE is set in UE operation mode A (see ICS).                                                                                                                                                       |
| 2    | UE        |    |                                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                |
| 3    | →         |    | ATTACH REQUEST                  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                   |
| 4    | ←         |    | ATTACH ACCEPT                   | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = IMSI<br>Routing area identity = RAI-1 |
| 5    | →         |    | ATTACH COMPLETE                 |                                                                                                                                                                                                       |
| 6    | ←         |    | PAGING TYPE1                    | Mobile identity = IMSI<br>Paging order is for CS services.                                                                                                                                            |
| 7    | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                       |
| 8    | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                       |
| 9    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                       |
| 10   | →         |    | PAGING RESPONSE                 | Mobile identity = IMSI                                                                                                                                                                                |
| 11   | ←         |    | RRC CONNECTION RELEASE          | After sending of this message, the SS waits for disconnection of the CS signalling link.                                                                                                              |
| 12   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                       |
| 13   | ←         |    | PAGING TYPE1                    | Mobile identity = P-TMSI-1<br>Paging for PS services                                                                                                                                                  |
| 13a  | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                       |
| 13b  | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                       |
| 13c  | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                       |
| 14   | →         |    | SERVICE REQUEST                 | service type = "paging response"                                                                                                                                                                      |
| 14a  | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                       |
| 14b  | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                       |
| 15   | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                                                                                                                                 |
| 16   | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach'                                                                                                |
| 17   | UE        |    |                                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                |
| 18   | →         |    | ATTACH REQUEST                  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>TMSI status = no valid TMSI available<br>Routing area identity = RAI-1                               |
| 19   | ←         |    | ATTACH ACCEPT                   | Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-1                                        |
| 20   | →         |    | ATTACH COMPLETE                 |                                                                                                                                                                                                       |
| 21   | ←         |    | GMM INFORMATION                 |                                                                                                                                                                                                       |
| 21b  | →         |    | GMM STATUS                      | Message sent in case the UE does not support reception of GMM information message<br>Cause #97                                                                                                        |
| 22   | ←         |    | PAGING TYPE 1                   | Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                                          |
| 23   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                       |
| 24   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                       |
| 25   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                       |
| 26   | →         |    | PAGING RESPONSE                 | Mobile identity = TMSI-1                                                                                                                                                                              |

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 27   | ←         |    | RRC CONNECTION RELEASE          | After sending of this message, the SS waits for disconnection of the CS signalling link.                                                                                                                                                                                                                                                                                                                                                                                            |
| 28   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 29   | ←         |    | PAGING TYPE1                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 29a  | →         |    | RRC CONNECTION REQUEST          | Mobile identity = P-TMSI-2<br>Paging for PS services                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 29b  | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 29c  | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 30   | →         |    | SERVICE REQUEST                 | service type = "paging response"                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 30a  | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 30b  | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 31   | ←         |    | PAGING TYPE1                    | Mobile identity = P-TMSI-1<br>Paging for PS services                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 32   | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 33   | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 34   | →         |    | DETACH REQUEST                  | The UE is switched off or power is removed (see ICS).<br>Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach'                                                                                                                                                                                                                                                                                                                     |
| 35   | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 36   | →         |    | ATTACH REQUEST                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 37   | ←         |    | ATTACH ACCEPT                   | The UE is powered up or switched on and initiates an attach (see ICS).<br>Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>TMSI status = valid TMSI available<br>No new mobile identity assigned.<br>TMSI and P-TMSI not included.<br>Attach result = 'Combined PS / IMSI attached'<br>P-TMSI-3 signature<br>Routing area identity = RAI-1<br>Mobile identity = P-TMSI-2<br>Paging for PS services |
| 38   | ←         |    | PAGING TYPE1                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 38a  | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 38b  | ←         |    | RRC CONNECTION SETUP            | service type = "paging response"                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 38c  | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 39   | →         |    | SERVICE REQUEST                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 39a  | ←         |    | RRC CONNECTION RELEASE          | The UE is switched off or power is removed (see ICS).<br>Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach'                                                                                                                                                                                                                                                                                                                     |
| 39b  | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 40   | UE        |    |                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 41   | →         |    | DETACH REQUEST                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |

#### Specific message contents

None.

#### 12.2.2.1.5 Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence.

Case 1) SS accept the combined PS attach procedure (signalled by an IMSI) and allocates a P-TMSI.

At step5, UE shall

— send the ATTACH COMPLETE message.

At step10, when the UE receives the paging message for CS domain with Mobile identity = IMSI, UE shall;

— respond to the paging message for CS domain by sending the PAGING RESPONSE message.

At step14, when the UE receives the paging message for PS domain with Mobile identity = P-TMSI-1, UE shall:

— respond to the paging message for PS domain by sending the SERVICE REQUEST message.

Case 2) SS accepts the combined PS attach procedure (signalled by P-TMSI) and reallocates a new P-TMSI and TMSI.

At step20, UE shall:

— send the ATTACH COMPLETE message.

At step26, when the UE receives the paging message for CS domain with Mobile identity = TMSI, UE shall;

— respond to the paging message for CS domain by sending the PAGING RESPONSE message.

At step30, when the UE receives the paging message for PS domain with Mobile identity = P-TMSI-2, UE shall:

— respond to the paging message for PS domain by sending the SERVICE REQUEST message.

Case 3) SS accepts the combined PS attach procedure (signalled by a P-TMSI) from the UE without reallocation of the previously used P-TMSI.

At step39, when the UE receives the paging message for PS domain with Mobile identity = P-TMSI-2, UE shall:

— respond to the paging message for PS domain by sending the SERVICE REQUEST message.

## 12.2.2.2 Combined PS attach / PS only attach accepted

### 12.2.2.2.1 Definition

### 12.2.2.2.2 Conformance requirement

- 1) If the network accepts the combined PS attach procedure, but GMM cause code 'TMSI unknown in HLR' is sent to the UE the User Equipment shall delete the stored TMSI, LAI and CKSN. The User Equipment shall consider USIM invalid for non-PS services until power is switched off or USIM is removed.
- 2) If the network accepts the combined PS attach procedure, but GMM cause code 'MSC temporarily not reachable', 'Network failure' or 'Congestion' is sent to the UE, an UE operation mode A UE may perform an MM IMSI attach procedure.

### Reference

3GPP TS 24.008 clause 4.7.3.2.

### 12.2.2.2.3 Test purpose

#### Test propose1

To test the behaviour of the UE if the network accepts the PS attach procedure with indication PS only, GMM cause 'TMSI unknown in HLR'.

#### Test porpose2

To test the behaviour of the UE if the network accepts the PS attach procedure with indication PS only, GMM cause 'MSC temporarily not reachable', 'Network failure' or 'Congestion'.

~~12.2.2.2.4 Method of test~~~~12.2.2.2.4.1 Test purpose1~~~~Initial condition~~~~System Simulator:~~~~— One cell operating in network operation mode 1.~~~~User Equipment:~~~~— The UE has a valid IMSI.~~~~Related ICS/IXIT statements~~~~— Support of PS service — Yes/No~~~~UE operation mode A — Yes/No~~~~Switch off on button Yes/No~~~~Automatic PS attach procedure at switch on or power on — Yes/No~~~~Test procedure~~

The UE sends an ATTACH REQUEST message with identity IMSI. The SS allocates a P-TMSI and returns ATTACH ACCEPT message with a P-TMSI. GMM cause 'IMSI unknown in HLR' is indicated from SS. Further communication UE-SS is performed by the P-TMSI. CS services are not possible.

~~Expected Sequence~~

| Step | Direction |    | Message         | Comments                                                                                                                                                                                              |
|------|-----------|----|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                 |                                                                                                                                                                                                       |
| 1    | UE        |    |                 | The UE is set in UE operation mode A.                                                                                                                                                                 |
| 2    | UE        |    |                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                |
| 3    | →         |    | ATTACH REQUEST  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                   |
| 4    | ←         |    | ATTACH ACCEPT   | TMSI status = no valid TMSI available<br>Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>GMM cause = 'IMSI unknown in HLR'<br>Routing area identity = RAI-1 |
| 5    | →         |    | ATTACH COMPLETE | Mobile identity = IMSI<br>Paging order is for CS services.<br>The UE shall not initiate an RRC connection.<br>This is checked during 3 seconds.                                                       |
| 6    | ←         |    | PAGING TYPE1    |                                                                                                                                                                                                       |
| 7    | UE        |    |                 | The UE is switched off or power is removed (see ICS).                                                                                                                                                 |
| 8    | UE        |    |                 | Message not sent if power is removed.                                                                                                                                                                 |
| 9    | →         |    | DETACH REQUEST  | Detach type = 'power switched off, PS detach'                                                                                                                                                         |

~~12.2.2.2.4.2 Test purpose2~~~~Initial condition~~~~System Simulator:~~~~— One cell operating in network operation mode 1.~~

**User Equipment:**

~~—The UE has a valid TMSI, P-TMSI, P-TMSI signature and RAI.~~

**Related ICS/IXIT statements**

~~—Support of PS service—Yes/No  
UE operation mode A—Yes/No  
Automatic MM IMSI attach procedure for UE operation mode A UE—Yes/No  
Switch off on button Yes/No  
Automatic PS attach procedure at switch on or power on—Yes/No~~

**Test procedure**

~~The UE sends an ATTACH REQUEST message. The SS allocates a P-TMSI and returns ATTACH ACCEPT message with a P-TMSI. GMM cause 'MSC temporarily not reachable', 'Network failure' or 'Congestion' is indicated from SS. The cause code is arbitrarily chosen. The UE sends a ROUTING AREA UPDATE REQUEST message. The SS returns a ROUTING AREA UPDATE ACCEPT message. GMM cause 'MSC temporarily not reachable', 'Network failure' or 'Congestion' is indicated from SS. The cause code is arbitrarily chosen. The ROUTING AREA UPDATE procedure is repeated four times. An UE operation mode A UE may then perform an MM IMSI attach procedure (according to the ICS statement). Further communication UE – SS is performed by the P-TMSI. The existence of a signalling channel is verified by a request for mobile identity.~~

**Expected Sequence**

~~Dependent whether the option 'Automatic MM IMSI attach procedure for UE operation mode A UE' is supported or not, the steps 1-22 or 23-53 apply depending on manufacturer (see ICS).~~



| Step | Direction |    | Message                     | Comments                                                                                                                                                                                                                                               |
|------|-----------|----|-----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                                                                                                                                        |
| 1    | UE        |    |                             | The UE is set in UE operation mode A and no automatic MM-IMSI attach procedure is indicated (see ICS).                                                                                                                                                 |
| 2    | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                                                                 |
| 3    | →         |    | ATTACH-REQUEST              | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1<br>TMSI status = valid TMSI available or IE is omitted                                                                  |
| 4    | ←         |    | ATTACH-ACCEPT               | Attach result = 'PS-only attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br><br>Routing area identity = RAI-1<br>GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen)                     |
| 5    | →         |    | ATTACH-COMPLETE             |                                                                                                                                                                                                                                                        |
| 7    | →         |    | ROUTING-AREA-UPDATE-REQUEST | Update type = 'Combined RA / LA updating with IMSI attach'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                                                                      |
| 8    | ←         |    | ROUTING-AREA-UPDATE-ACCEPT  | No new mobile identity assigned.<br>P-TMSI not included.<br>Update result = 'RA updated'<br>P-TMSI-3 signature<br>Routing area identity = RAI-1<br>GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen) |
| 10   | →         |    | ROUTING-AREA-UPDATE-REQUEST | Update type = 'Combined RA / LA updating with IMSI attach'<br>P-TMSI-3 signature<br>Routing area identity = RAI-1                                                                                                                                      |
| 11   | ←         |    | ROUTING-AREA-UPDATE-ACCEPT  | No new mobile identity assigned.<br>P-TMSI not included.<br>Update result = 'RA updated'<br>P-TMSI-4 signature<br>Routing area identity = RAI-1<br>GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen) |
| 12   | →         |    | ROUTING-AREA-UPDATE-REQUEST | Update type = 'Combined RA / LA updating with IMSI attach'<br>P-TMSI-4 signature<br>Routing area identity = RAI-1                                                                                                                                      |
| 13   | SS        |    |                             | The SS verifies that the time between the previous routing area update accept and routing area update request is T3311.                                                                                                                                |
| 14   | ←         |    | ROUTING-AREA-UPDATE-ACCEPT  | No new mobile identity assigned.<br>P-TMSI not included.<br>Update result = 'RA updated'<br>P-TMSI-5 signature<br>Routing area identity = RAI-1<br>GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen) |
| 16   | →         |    | ROUTING-AREA-UPDATE-REQUEST | Update type = 'Combined RA / LA updating with IMSI attach'<br>P-TMSI-5 signature<br>Routing area identity = RAI-1                                                                                                                                      |

| Step  | Direction |    | Message                     | Comments                                                                                                                                                                                                                                                        |
|-------|-----------|----|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       | UE        | SS |                             |                                                                                                                                                                                                                                                                 |
| 17    | ←         |    | ROUTING AREA UPDATE ACCEPT  | No new mobile identity assigned.<br>P-TMSI not included.<br>Update result = 'RA updated'<br>P-TMSI-6 signature<br>Routing area identity = RAI-1<br>GMM cause = 'MSC temporarily not reachable',<br>'Network failure' or 'Congestion' (arbitrarily chosen)       |
| 18-20 |           |    | (void)                      |                                                                                                                                                                                                                                                                 |
| 21    | UE        |    |                             | The UE is switched off or power is removed (see ICS).                                                                                                                                                                                                           |
| 22    | →         |    | DETACH REQUEST              | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'.<br>Stop the sequence.                                                                                                                                                   |
| 23    | UE        |    |                             | Automatic MM-IMSI attach procedure is indicated (see ICS).                                                                                                                                                                                                      |
| 24    | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                                                                          |
| 25    | →         |    | ATTACH REQUEST              | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1<br>TMSI status = valid TMSI available or IE is omitted                                                                           |
| 26    | ←         |    | ATTACH ACCEPT               | No new mobile identity assigned.<br>P-TMSI not included.<br>Attach result = 'PS only attached'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>GMM cause = 'MSC temporarily not reachable',<br>'Network failure' or 'Congestion' (arbitrarily chosen) |
| 28    | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'Combined RA / LA updating with IMSI attach'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                                                                               |
| 29    | ←         |    | ROUTING AREA UPDATE ACCEPT  | No new mobile identity assigned.<br>P-TMSI not included.<br>Update result = 'RA updated'<br>P-TMSI-3 signature<br>Routing area identity = RAI-1<br>GMM cause = 'MSC temporarily not reachable',<br>'Network failure' or 'Congestion' (arbitrarily chosen)       |
| 31    | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'Combined RA / LA updating with IMSI attach'<br>P-TMSI-3 signature<br>Routing area identity = RAI-1                                                                                                                                               |
| 32    | ←         |    | ROUTING AREA UPDATE ACCEPT  | No new mobile identity assigned.<br>P-TMSI not included.<br>Update result = 'RA updated'<br>P-TMSI-4 signature<br>Routing area identity = RAI-1<br>GMM cause = 'MSC temporarily not reachable',<br>'Network failure' or 'Congestion' (arbitrarily chosen)       |
| 33    | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'Combined RA / LA updating with IMSI attach'<br>P-TMSI-4 signature<br>Routing area identity = RAI-1                                                                                                                                               |
| 34    |           | SS |                             | The SS verifies that the time between the previous routing area update accept and routing area update request is T3311.                                                                                                                                         |

| Step  | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                                        |
|-------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       | UE        | SS |                                 |                                                                                                                                                                                                                                                                                                 |
| 35    | ←         |    | ROUTING AREA UPDATE ACCEPT      | No new mobile identity assigned.<br>P-TMSI not included.<br>Update result = 'RA updated'<br>P-TMSI-5 signature<br>Routing area identity = RAI-1<br>GMM cause = 'MSC temporarily not reachable',<br>'Network failure' or 'Congestion' (arbitrarily chosen)                                       |
| 37    | →         |    | ROUTING AREA UPDATE REQUEST     | Update type = 'Combined RA / LA updating with IMSI attach'<br>P-TMSI-5 signature<br>Routing area identity = RAI-1<br>TMSI status = no valid TMSI available                                                                                                                                      |
| 38    |           | SS |                                 | The SS verifies that the time between the previous routing area update accept and routing area update request is T3311.                                                                                                                                                                         |
| 39    | ←         |    | ROUTING AREA UPDATE ACCEPT      | No new mobile identity assigned.<br>P No new mobile identity assigned.<br>P-TMSI not included.<br>Update result = 'RA updated'<br>P-TMSI-6 signature<br>Routing area identity = RAI-1<br>GMM cause = 'MSC temporarily not reachable',<br>'Network failure' or 'Congestion' (arbitrarily chosen) |
| 40    | UE        |    |                                 | An automatic MM IMSI attach procedure is initiated.                                                                                                                                                                                                                                             |
| 41    | UE        |    | Registration on CS              | See TS 34.108<br>This is applied only for UE in UE operation mode A.<br>Parameter mobile identity is TMSI                                                                                                                                                                                       |
| 42-48 |           |    | (void)                          |                                                                                                                                                                                                                                                                                                 |
| 49    | ←         |    | PAGING TYPE1                    | Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                                                                                                                                    |
| 50    | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                                                 |
| 51    | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                                                 |
| 52    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                                                 |
| 53    | →         |    | PAGING RESPONSE                 | Mobile identity = TMSI-1                                                                                                                                                                                                                                                                        |
| 54    | ←         |    | RRC CONNECTION RELEASE          | After sending of this message, the SS waits for disconnection of the CS signalling link.                                                                                                                                                                                                        |
| 55    | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                                 |
| 56    | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                                                                                                                                                                                                                           |
| 57    | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                                                                                                                          |

#### Specific message contents

None.

#### 12.2.2.2.5 Test requirements

##### Test requirements for Test purpose1

At step3, when the UE is powered up or switched on, UE shall:

- initiate the Combined PS attach procedure with information elements specified in the above Expected Sequence.

At step7, when the UE receives the paging message for CS domain, UE shall:

- not respond to the paging message for CS domain.

## Test requirements for Test purpose2

Case 1) UE does not support Automatic MM-IMSI attach procedure.

At step3, when the UE is powered up or switched on, UE shall:

- initiate the Combined PS attach procedure with information elements specified in the above Expected Sequence.

At step7, 10, 12 and 16, when the routing area updating attempt counter is less than 5 and the stored RAI is equal to the RAI of the current serving cell, UE shall:

- perform the combined routing area update procedure indicating “combined RA/LA updating with IMSI attach”.

Case 2) UE supports Automatic MM-IMSI attach procedure.

At step25, when the UE is powered up or switched on, UE shall:

- initiate the Combined PS attach procedure with information elements specified in the above Expected Sequence.

At step28, 31, 33 and 37, when the routing area updating attempt counter is less than 5 and the stored RAI is equal to the RAI of the current serving cell, UE shall:

- perform the combined routing area update procedure indicating “combined RA/LA updating with IMSI attach”.

At step41, UE shall:

- perform MM location updating procedure.

At step53, UE shall:

- respond to the paging message for CS domain by sending the PAGING RESPONSE message.

## ~~12.2.2.3 Combined PS attach / PS attach while IMSI attach~~

### ~~12.2.2.3.1 Definition~~

### ~~12.2.2.3.2 Conformance requirement~~

If the PS UE is already attached for non-PS services by the MM specific attach procedure, but wants to perform an attach for PS services, the combined PS attach procedure is performed.

### Reference

3GPP TS 24.008 clause 4.7.3.2.

### ~~12.2.2.3.3 Test purpose~~

To test the behaviour of the UE if PS attach performed while IMSI attached.

### ~~12.2.2.3.4 Method of test~~

### Initial condition

System Simulator:

- One cell operating in network operation mode I. ATT flag is set.

User Equipment:

- The UE has a valid TMSI-1, P-TMSI-1, P-TMSI-1 signature and RAI-1.

### Related ICS/IXIT statements

- Support of PS service—Yes/No

- UE operation mode A — Yes/No  
 Switch off on button — Yes/No  
 Automatic PS attach procedure at switch on or power on — Yes/No

### Test procedure

The UE is forced to register for CS services but not to PS services. The SS verifies that the UE does not respond to paging messages for PS domain. Then the UE is triggered to perform the PS attach procedure and the SS verifies that it responds to PS paging messages.

### Expected Sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                              |
|------|-----------|----|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                       |
| 1    | UE        |    |                                 | The UE is set in UE operation mode A (see ICS) and configured not to perform an automatic PS attach at switch on.                                                     |
| 2    | UE        |    |                                 | The UE is powered up or switched on. No PS attach is performed (see ICS).                                                                                             |
| 3    |           |    | Registration on CS              | See TS 34.108<br>Location updating type = IMSI attach.                                                                                                                |
| 4    | ←         |    | PAGING TYPE1                    | The SS allocates TMSI-1<br>Mobile identity = P-TMSI-1<br>Paging order is for PS services.                                                                             |
| 5    | UE        |    |                                 | No response from the UE to the request. This is checked for 10 seconds.                                                                                               |
| 6    | UE        |    |                                 | The UE is triggered to perform a PS attach.                                                                                                                           |
| 7    | →         |    | ATTACH REQUEST                  | Attach type = 'PS attach while IMSI attached' or 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                    |
| 8    | ←         |    | ATTACH ACCEPT                   | Routing area identity = RAI-1<br>Attach result = 'Combined PS / IMSI attached'<br>No new mobile identity assigned. TMSI and P-TMSI not included<br>P-TMSI-2 signature |
| 9    | ←         |    | PAGING TYPE1                    | Routing area identity = RAI-1<br>Mobile identity = P-TMSI-1<br>Paging order is for PS services.                                                                       |
| 10   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                       |
| 11   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                       |
| 12   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                       |
| 13   | →         |    | SERVICE REQUEST                 | service type = "paging response"                                                                                                                                      |
| 14   | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                       |
| 15   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                       |
| 16   | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                                                                                                 |
| 17   | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach'                                                                |

### Specific message contents

None.

### 12.2.2.3.5 — Test requirements

UE is already attached for non-PS service with the MM specific attach procedure.

At step5, UE shall:

— not respond to the paging message for PS domain.

At step7, when the UE is requested to attach for PS services, UE shall:

— perform the combined PS attach procedure.

At step13, UE shall:

— respond to the paging message for PS domain by sending the SERVICE REQUEST message.

#### 12.2.2.4 Combined PS attach / rejected / IMSI invalid / illegal ME

##### 12.2.2.4.1 Definition

##### 12.2.2.4.2 Conformance requirement

- 1) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'Illegal ME', the User Equipment shall consider USIM invalid for PS and non-PS services until power is switched off or USIM is removed.
- 2) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'Illegal ME', the User Equipment shall delete the stored TMSI, LAI, CSKN, RAI, PS-CSKN, P-TMSI and P-TMSI signature.

#### Reference

— 3GPP TS 24.008 clause 4.7.3.2

##### 12.2.2.4.3 Test purpose

To test the behaviour of the UE if the network rejects the combined PS attach procedure of the UE with the cause 'Illegal ME'.

##### 12.2.2.4.4 Method of test

#### Initial condition

#### System Simulator:

— Three cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1) and cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4), cell C in MCC2/MNC1/LAC1/RAC1 (RAI-2).  
All three cells are operating in network operation mode I.

#### User Equipment:

— The UE has a valid TMSI-1, P-TMSI-1, P-TMSI-1 signature and RAI-1.

#### Related ICS/IXIT statements

— Support of PS service — Yes/No  
UE operation mode A — Yes/No  
USIM removal possible without powering down — Yes/No  
Switch off on button — Yes/No  
Automatic PS attach procedure at switch on or power on — Yes/No

#### Test procedure

The SS rejects a PS attach with the cause value 'Illegal ME'. The SS checks that the UE does not perform PS attach in the same or another PLMN. CS services are not possible as the USIM is blocked for CS services. PS services are not possible as the USIM is blocked for PS services.

## Expected Sequence

| Step | Direction |    | Message        | Comments                                                                                                                                                                                                                                 |
|------|-----------|----|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                |                                                                                                                                                                                                                                          |
| 1    |           | SS | ATTACH REQUEST | The following messages are sent and shall be received on cell A:<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Off cell".<br>(see note) |
| 2    | UE        |    |                | The UE is set in UE operation mode A (see ICS).                                                                                                                                                                                          |
| 3    | UE        |    |                | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                                                                    |
| 4    | →         |    |                | Attach type = 'Combined PS / IMSI attach' or 'PS attach while IMSI attached'                                                                                                                                                             |
|      |           |    |                | Mobile identity = P-TMSI-1                                                                                                                                                                                                               |
|      |           |    |                | P-TMSI-1 signature                                                                                                                                                                                                                       |
|      |           |    |                | Routing area identity = RAI-1                                                                                                                                                                                                            |
|      |           |    |                | TMSI status = valid TMSI available or IE is omitted                                                                                                                                                                                      |
| 5    | ←         |    |                | GMM cause 'Illegal ME'.                                                                                                                                                                                                                  |
| 6    | UE        |    |                | Mobile identity = TMSI-1 Paging order is for CS services.                                                                                                                                                                                |
| 7    | UE        |    |                | The UE shall not initiate an RRC connection. This is checked during 3 seconds.                                                                                                                                                           |
| 8    | ←         |    | PAGING TYPE1   | Mobile identity = IMSI Paging order is for CS services                                                                                                                                                                                   |
| 9    | UE        |    | PAGING TYPE1   | The UE shall not initiate an RRC connection. This is checked during 3 seconds.                                                                                                                                                           |
| 10   | ←         |    |                | Mobile identity = P-TMSI-1                                                                                                                                                                                                               |
| 11   | UE        |    |                | Paging order is for PS services.<br>No response from the UE to the request. This is checked for 10 seconds.                                                                                                                              |
| 12   |           | SS | PAGING TYPE1   | The following messages are sent and shall be received on cell B:<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)                                                   |
| 13   | UE        |    |                | Cell B is preferred by the UE.                                                                                                                                                                                                           |
| 14   | UE        |    |                | No ATTACH REQUEST sent to the SS (SS waits 30 seconds).                                                                                                                                                                                  |
| 15   | ←         |    |                | Mobile identity = IMSI Paging order is for CS services                                                                                                                                                                                   |
| 16   | UE        |    |                | The UE shall not initiate an RRC connection. This is checked during 3 seconds.                                                                                                                                                           |
| 17   |           | SS | PAGING TYPE1   | The following messages are sent and shall be received on cell C:<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Serving cell".<br>(see note)                                                   |
| 18   | UE        |    |                | Cell C is preferred by the UE.                                                                                                                                                                                                           |
| 19   | UE        |    |                | No ATTACH REQUEST sent to the SS (SS waits 30 seconds).                                                                                                                                                                                  |
| 20   | ←         |    |                | Mobile identity = IMSI Paging order is for PS services                                                                                                                                                                                   |
| 21   | UE        |    |                | No response from the UE to the request. This is checked for 10 seconds.                                                                                                                                                                  |
| 22   | UE        |    |                | If possible (see ICS) USIM removal is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.                                                                                                |
| 23   | UE        |    |                | The UE gets the USIM replaced, is powered up or switched on and initiates an attach (see ICS).                                                                                                                                           |
| 24   | UE        |    |                | Step 25 is only performed for non-auto attach UE.<br>A location updating procedure is initiated.                                                                                                                                         |

| Step                                                                                                                                                         | Direction |    | Message                            | Comments                                                                                                                                                                                                |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                              | UE        | SS |                                    |                                                                                                                                                                                                         |
| 25                                                                                                                                                           | UE        |    | Registration on CS                 | See TS34.108<br>Parameter Mobile identity is IMSI.                                                                                                                                                      |
| 26                                                                                                                                                           | UE        |    |                                    | UE initiates an attach automatically (see ICS),<br>by MMI or AT commands.                                                                                                                               |
| 27                                                                                                                                                           | →         |    | ATTACH REQUEST                     | Attach type = 'Combined PS / IMSI attach' or<br>'PS attach while IMSI attached'<br>Mobile identity = IMSI                                                                                               |
| 28                                                                                                                                                           | ←         |    | ATTACH ACCEPT                      | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-2 |
| 29                                                                                                                                                           | →         |    | ATTACH COMPLETE                    |                                                                                                                                                                                                         |
| 30                                                                                                                                                           | ←         |    | PAGING TYPE1                       | Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                                            |
| 31                                                                                                                                                           | →         |    | RRC CONNECTION REQUEST             |                                                                                                                                                                                                         |
| 32                                                                                                                                                           | ←         |    | RRC CONNECTION SETUP               |                                                                                                                                                                                                         |
| 33                                                                                                                                                           | →         |    | RRC CONNECTION SETUP<br>COMPLETE   |                                                                                                                                                                                                         |
| 34                                                                                                                                                           | →         |    | PAGING RESPONSE                    | Mobile identity = TMSI-2                                                                                                                                                                                |
| 35                                                                                                                                                           | ←         |    | RRC CONNECTION RELEASE             | After sending of this message, the SS waits for<br>disconnection of the CS signalling link.                                                                                                             |
| 36                                                                                                                                                           | →         |    | RRC CONNECTION RELEASE<br>COMPLETE |                                                                                                                                                                                                         |
| 37                                                                                                                                                           | UE        |    |                                    | The UE is switched off or power is removed<br>(see ICS).                                                                                                                                                |
| 38                                                                                                                                                           | →         |    | DETACH REQUEST                     | Message not sent if power is removed.<br>Detach type = 'power switched off, combined<br>PS / IMSI detach'                                                                                               |
| NOTE: The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference<br>Radio Conditions for signalling test cases only". |           |    |                                    |                                                                                                                                                                                                         |

### Specific message contents

None.

#### 12.2.2.4.5 Test requirements

At step4, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.

At step7, 9 and 16, when the UE receives the paging message for CS domain, UE shall,

- not respond to the paging message for CS domain.

At step11 and 21, when the UE receives the paging message for PS domain, UE shall,

- not respond to the paging message for PS domain.

At step27, when the USIM is replaced, UE shall:

- perform the combined PS attach procedure.

At step34, when the UE receives the paging message for CS domain, UE shall,

- respond to the paging message for CS domain by sending the RAGING RESPONSE message.



### ~~12.2.2.5 Combined PS attach / rejected / PS services and non-PS services not allowed~~

#### ~~12.2.2.5.1 Definition~~

#### ~~12.2.2.5.2 Conformance requirement~~

- ~~1) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'PS services and non-PS services not allowed', the User Equipment shall consider USIM invalid for PS and non-PS services until power is switched off or USIM is removed.~~
- ~~2) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'PS services and non-PS services not allowed', the User Equipment shall delete the stored TMSI, LAI, CSKN, RAI, PS-CKSN, P-TMSI and P-TMSI signature.~~

#### ~~Reference~~

~~3GPP TS 24.008 clause 4.7.3.2.~~

#### ~~12.2.2.5.3 Test purpose~~

~~To test the behaviour of the UE if the network rejects the combined PS attach procedure of the UE with the cause 'PS services and non-PS services not allowed'.~~

#### ~~12.2.2.5.4 Method of test~~

#### ~~Initial condition~~

~~System Simulator:~~

- ~~— Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1) and cell B in MCC2/MNC1/LAC1/RAC1 (RAI-2).~~
- ~~Both cells are operating in network operation mode I.~~

~~User Equipment:~~

- ~~— The UE has a valid TMSI-1, P-TMSI-1, P-TMSI-1 signature and RAI-1.~~

#### ~~Related ICS/IXIT statements~~

- ~~— Support of PS service — Yes/No~~
- ~~UE operation mode A — Yes/No~~
- ~~Switch off on button — Yes/No~~
- ~~Automatic PS attach procedure at switch on or power on — Yes/No~~

#### ~~Test procedure~~

~~The SS rejects a PS attach with the cause value 'PS services and non-PS services not allowed'. The SS checks that the UE does not perform PS attach in the same or another PLMN. CS services are not possible as the USIM is blocked for CS services. PS services are not possible as the USIM is blocked for PS services.~~

## Expected Sequence

| Step | Direction |    | Message            | Comments                                                                                                                                                                                       |
|------|-----------|----|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                                                                                |
| 1    |           | SS |                    | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note)         |
| 2    | UE        |    |                    | The UE is set in UE operation mode A (see ICS).                                                                                                                                                |
| 3    | UE        |    |                    | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                          |
| 4    | →         |    | ATTACH-REQUEST     | Attach type = 'Combined PS / IMSI attach' or 'PS attach while IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                              |
| 5    | ←         |    | ATTACH-REJECT      | GMM cause 'PS services and non-PS services not allowed'                                                                                                                                        |
| 6    | UE        |    |                    | The SS verifies that the UE does not attempt to access the network.<br>(SS waits 30 seconds).                                                                                                  |
| 7    | ←         |    | PAGING-TYPE1       | Mobile identity = IMSI<br>Paging order is for CS services.                                                                                                                                     |
| 8    | UE        |    |                    | The UE shall not initiate an RRC connection.<br>This is checked during 3 seconds.                                                                                                              |
| 9    | ←         |    | PAGING-TYPE1       | Mobile identity = P-TMSI-1<br>Paging order is for PS Paging.                                                                                                                                   |
| 10   | UE        |    |                    | No response from the UE to the request.<br>This is checked for 10 seconds                                                                                                                      |
| 11   |           | SS |                    | Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)                                                                             |
| 12   |           |    | (void)             |                                                                                                                                                                                                |
| 13   | UE        |    |                    | The SS verifies that the UE does not attempt to access the network.<br>(SS waits 30 seconds).                                                                                                  |
| 14   | ←         |    | PAGING-TYPE1       | Mobile identity = IMSI<br>Paging order is for CS services.                                                                                                                                     |
| 15   | UE        |    |                    | The UE shall not initiate an RRC connection.<br>This is checked during 3 seconds.                                                                                                              |
| 16   | ←         |    | PAGING-TYPE1       | Mobile identity = P-TMSI-1<br>Paging order is for PS services.                                                                                                                                 |
| 17   | UE        |    |                    | No response from the UE to the request. This is checked for 10 seconds.                                                                                                                        |
| 18   | UE        |    |                    | If possible (see ICS) switch off is performed.<br>Otherwise the power is removed.                                                                                                              |
| 19   | UE        |    | Registration-on-CS | The UE is powered up or switched.<br>See TS 34.108<br>This step is applied only for non-auto attach UE.<br>Location Update Procedure initiated from the UE. Parameter mobile identity is IMSI. |
| 20   | UE        |    |                    | UE initiates an attach automatically (see ICS), by MMI or AT commands.                                                                                                                         |
| 21   | UE        |    |                    |                                                                                                                                                                                                |
| 22   | →         |    | ATTACH-REQUEST     | Attach type = 'Combined PS / IMSI attach' or 'PS attach while IMSI attached'<br>Mobile identity = IMSI<br>TMSI status = no valid TMSI available                                                |
| 23   | ←         |    | ATTACH-ACCEPT      | Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-2                                 |
| 24   | →         |    | ATTACH-COMPLETE    |                                                                                                                                                                                                |

| Step                                                                                                                                                        | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                             | UE        | SS |                                 |                                                                                                                                                                                                                                                                         |
| 25                                                                                                                                                          | ←         |    | PAGING TYPE1                    | Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                                                                                                            |
| 26                                                                                                                                                          | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                         |
| 27                                                                                                                                                          | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                         |
| 28                                                                                                                                                          | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                         |
| 29                                                                                                                                                          | →         |    | PAGING RESPONSE                 |                                                                                                                                                                                                                                                                         |
| 30                                                                                                                                                          | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                         |
| 31                                                                                                                                                          | →         |    | RRC CONNECTION RELEASE COMPLETE | Mobile identity = P-TMSI-1<br>Paging is for PS services.<br><br>Service type = "paging response"<br><br>The UE is switched off or power is removed (see ICS).<br>Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach' |
| 32                                                                                                                                                          | ←         |    | PAGING TYPE1                    |                                                                                                                                                                                                                                                                         |
| 33                                                                                                                                                          | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                                         |
| 34                                                                                                                                                          | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                                         |
| 35                                                                                                                                                          | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                                         |
| 36                                                                                                                                                          | →         |    | SERVICE REQUEST                 |                                                                                                                                                                                                                                                                         |
| 37                                                                                                                                                          | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                         |
| 38                                                                                                                                                          | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                         |
| 39                                                                                                                                                          | UE        |    |                                 |                                                                                                                                                                                                                                                                         |
| 40                                                                                                                                                          | →         |    | DETACH REQUEST                  |                                                                                                                                                                                                                                                                         |
| NOTE: — The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                                                                                                                                         |

#### Specific message contents

None.

#### 12.2.2.5.5 Test requirements

At step4, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.

At step8 and 14, when the UE receives the paging message for CS domain, UE shall:

- not respond to the paging message for CS domain.

At step10 and 17, when the UE receives the paging message for PS domain, UE shall:

- not respond to the paging message for PS domain.

At step22, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure.

At step29, when the UE receives the paging message for CS domain, UE shall:

- respond to the paging message for CS domain by sending the PAGING RESPONSE message.

At step36, when the UE receives the paging message for PS domain, UE shall:

- respond to the paging message for PS domain by sending the SERVICE REQUEST message.

### ~~12.2.2.6 Combined PS attach / rejected / PS services not allowed~~

#### ~~12.2.2.6.1 Definition~~

#### ~~12.2.2.6.2 Conformance requirement~~

- ~~1) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'PS services not allowed', the User Equipment shall consider USIM invalid for PS services until power is switched off or USIM is removed.~~
- ~~2) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'PS services not allowed' the User Equipment shall delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.~~
- ~~3) A PS class AUE shall perform an MM-IMSI attach procedure.~~

#### Reference

~~— 3GPP TS 24.008 clause 4.7.3.2~~

#### ~~12.2.2.6.3 Test purpose~~

~~To test the behaviour of the UE if the network rejects the PS attach procedure of the UE with the cause 'PS services not allowed'.~~

#### ~~12.2.2.6.4 Method of test~~

#### Initial condition

##### System Simulator:

- ~~— Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1) and cell B in MCC2/MNC1/LAC1/RAC1 (RAI-2).~~
- ~~Both cells are operating in network operation mode I.~~
- ~~ATT flag set to 1~~

##### User Equipment:

- ~~— The UE has a valid TMSI, P-TMSI-1, P-TMSI-1 signature and RAI-1.~~

#### Related ICS/IXIT statements

- ~~— Support of PS service — Yes/No~~
- ~~UE operation mode A — Yes/No~~
- ~~Switch off on button — Yes/No~~
- ~~Automatic PS attach procedure at switch on or power on — Yes/No~~

#### Test procedure

~~The SS rejects a normal attach with the cause value 'PS services not allowed'. The SS checks that the UE does not perform PS attach. PS services are not possible. An UE operation mode A UE shall perform an MM-IMSI attach.~~

## Expected Sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                                     |
|------|-----------|----|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                              |
| 1    |           | SS |                                 | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note)                                                       |
| 2    | UE        |    | Registration on CS              | The UE is powered up or switched on.                                                                                                                                                                                                         |
| 2a   | UE        |    |                                 | See TS 34.108<br>This step is applied only for non-auto attach UE.                                                                                                                                                                           |
| 2b   | UE        |    |                                 | Location Update Procedure initiated from the UE. Parameter mobile identity is TMSI-1.                                                                                                                                                        |
| 3    | →         |    | ATTACH REQUEST                  | UE initiates an attach automatically (see ICS), via MMI or AT commands.<br>Attach type = 'Combined PS / IMSI attach' or 'PS attach while IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1 |
| 4    | ←         |    | ATTACH REJECT                   | GMM cause 'PS services not allowed'                                                                                                                                                                                                          |
| 5    | UE        |    |                                 | An automatic MM IMSI attach procedure is initiated.                                                                                                                                                                                          |
| 6    | UE        |    | Registration on CS              | See TS 34.108<br>Location updating type = IMSI attach.                                                                                                                                                                                       |
| 7    | ←         |    | PAGING TYPE1                    | The SS allocates TMSI-2.<br>Mobile identity = TMSI-2<br>Paging order is for CS services.                                                                                                                                                     |
| 8    | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                              |
| 9    | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                              |
| 10   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                              |
| 11   | →         |    | PAGING RESPONSE                 | Mobile identity = TMSI-2                                                                                                                                                                                                                     |
| 12   | ←         |    | RRC CONNECTION RELEASE          | After sending of this message, the SS waits for disconnection of the CS signaling link.                                                                                                                                                      |
| 13   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                              |
| 14   |           | SS |                                 | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)                                                       |
| 15   | UE        |    | Registration on CS              | Cell B is preferred by the UE.                                                                                                                                                                                                               |
| 16   | UE        |    |                                 | A location updating procedure is initiated.                                                                                                                                                                                                  |
| 17   | UE        |    |                                 | See TS 34.108<br>Location updating type = normal.                                                                                                                                                                                            |
| 18   | ←         |    | PAGING TYPE1                    | The SS allocates TMSI-1.<br>Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                                                     |
| 19   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                              |
| 20   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                              |
| 21   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                              |
| 22   | →         |    | PAGING RESPONSE                 | Mobile identity = TMSI-1                                                                                                                                                                                                                     |
| 23   | ←         |    | RRC CONNECTION RELEASE          | After sending of this message, the SS waits for disconnection of the CS signalling link.                                                                                                                                                     |
| 24   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                              |
| 25   | ←         |    | PAGING TYPE1                    | Mobile identity = P-TMSI-1<br>Paging is for PS services                                                                                                                                                                                      |
| 26   | UE        |    |                                 | No response from the UE to the request. This is checked for 10seconds.                                                                                                                                                                       |
| 27   | UE        |    |                                 | If possible (see ICS) switch off is performed. Otherwise the power is removed.                                                                                                                                                               |
| 27a  | UE        |    |                                 | If switch off is performed then UE performs IMSI detach procedure.                                                                                                                                                                           |

| Step                                                                                                                                                      | Direction |    | Message                         | Comments                                                                                                                                                                                         |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                           | UE        | SS |                                 |                                                                                                                                                                                                  |
| 28<br>28a                                                                                                                                                 | UE<br>UE  |    | Registration-on-CS              | The UE is powered up or switched.<br>See TS 34.108<br>This step is applied only for non-auto attach UE.<br>Location Update Procedure initiated from the UE. Parameter mobile identity is TMSI-1. |
| 28b                                                                                                                                                       | UE        |    |                                 | UE initiates an attach automatically (see ICS), via MMI or AT commands.                                                                                                                          |
| 29                                                                                                                                                        | →         |    | ATTACH REQUEST                  | Attach type = 'Combined PS / IMSI attach' or 'PS attach while IMSI attached'                                                                                                                     |
| 30                                                                                                                                                        | ←         |    | ATTACH ACCEPT                   | Mobile identity = IMSI<br>Attach result = 'Combined PS / IMSI attached'                                                                                                                          |
| 31                                                                                                                                                        | →         |    | ATTACH COMPLETE                 | Mobile identity = P-TMSI-1                                                                                                                                                                       |
| 32                                                                                                                                                        | ←         |    | PAGING TYPE1                    | P-TMSI-1 signature<br>Mobile identity = TMSI-2<br>Routing area identity = RAI-2                                                                                                                  |
| 33                                                                                                                                                        | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                  |
| 34                                                                                                                                                        | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                  |
| 35                                                                                                                                                        | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                  |
| 36                                                                                                                                                        | →         |    | PAGING RESPONSE                 | Mobile identity = TMSI-2                                                                                                                                                                         |
| 37                                                                                                                                                        | ←         |    | RRC CONNECTION RELEASE          | After sending of this message, the SS waits for disconnection of the CS signalling link.                                                                                                         |
| 38                                                                                                                                                        | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                  |
| 39                                                                                                                                                        | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                                                                                                                            |
| 40                                                                                                                                                        | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach'                                                                                           |
| NOTE: The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                                                                  |

#### Specific message contents

None.

#### 12.2.2.6.5 Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.

At step6, if the UE is PS class A, UE shall:

- perform the MM IMSI attach procedure.

At step11, 22 and 36, when the UE receives the paging message for CS domain, UE shall:

- respond to the paging message for CS domain by sending the PAGING RESPONSE message.

At step26, when the UE receives the paging message for PS domain, UE shall:

- not respond to the paging message for PS domain.

At step29, UE shall:

- perform the PS attach procedure.

### ~~12.2.2.7a Combined PS attach / rejected / location area not allowed~~

#### ~~12.2.2.7a.1 Definition~~

#### ~~12.2.2.7a.2 Conformance requirement~~

- ~~1) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'location area not allowed' the User Equipment shall:~~
  - ~~1.1 not perform combined PS attach when in the same location area.~~
  - ~~1.2 delete the stored LAI, CKSN, TMSI, RAI, PS-CKSN, P-TMSI and P-TMSI signature.~~
  - ~~1.3 store the LA in the 'forbidden location areas for regional provision of service'.~~
- ~~2) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'location area not allowed' the User Equipment shall:~~
  - ~~2.1 perform combined PS attach when a new location area is entered.~~
  - ~~2.2 delete the list of forbidden LAs when power is switched off.~~

#### ~~Reference~~

~~3GPP TS 24.008 clauses 4.7.3.2.~~

#### ~~12.2.2.7a.3 Test purpose~~

~~To test the behaviour of the UE if the network rejects the combined PS attach procedure with the cause 'Location Area not allowed'.~~

~~To test that the UE deletes the list of forbidden LAs when power is switched off.~~

#### ~~12.2.2.7a.4 Method of test~~

#### ~~Initial condition~~

##### ~~System Simulator:~~

- ~~— Three cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4), cell C in MCC1/MNC1/LAC2/RAC1 (RAI-3). All cells are operating in network operation mode I.~~

##### ~~User Equipment:~~

- ~~— The UE has a valid TMSI, P-TMSI, P-TMSI signature and RAI.~~

#### ~~Related ICS/IXIT statements~~

- ~~— Support of PS service — Yes/No~~
- ~~UE operation mode A — Yes/No~~
- ~~Switch off on button — Yes/No~~
- ~~Automatic PS attach procedure at switch on or power on — Yes/No~~

#### ~~Test procedure~~

~~The SS rejects a combined PS attach with the cause value 'Location Area not allowed'. The SS checks that the UE does not perform combined PS attach while in the location area, performs PS attach when a new location area is entered and deletes the list of forbidden LAs when switched off. CS services are not possible unless an IMSI attach procedure is performed.~~

~~Different types of UE may use different methods to periodically clear the list of forbidden location areas (e.g. every day at 12am). If the list is cleared while the test is being run, it may be necessary to re-run the test.~~

## Expected Sequence

| Step | Direction |    | Message            | Comments                                                                                                                                                                                                                                 |
|------|-----------|----|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                                                                                                                          |
| 1    |           | SS | ATTACH REQUEST     | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Off cell".<br>(see note) |
| 2    | UE        |    |                    | The UE is set in UE operation mode A (see ICS).                                                                                                                                                                                          |
| 3    | UE        |    |                    | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                                                                    |
| 4    | →         |    |                    | Attach type = 'Combined PS / IMSI attach' or "PS Attach while IMSI attached"                                                                                                                                                             |
|      |           |    |                    | Mobile identity = P-TMSI-1                                                                                                                                                                                                               |
|      |           |    |                    | P-TMSI-1 signature                                                                                                                                                                                                                       |
| 5    |           |    |                    | Routing area identity = RAI-1                                                                                                                                                                                                            |
| 6    | UE        |    |                    | GMM cause 'Location Area not allowed'                                                                                                                                                                                                    |
|      |           |    |                    | No LOCATION UPDATING REQ with type 'IMSI attach' is sent to the SS                                                                                                                                                                       |
|      |           |    |                    | (SS waits 30 seconds).                                                                                                                                                                                                                   |
| 7    |           |    | PAGING TYPE1       | Mobile identity = TMSI                                                                                                                                                                                                                   |
| 8    | UE        |    |                    | Paging order is for CS services.                                                                                                                                                                                                         |
| 9    |           |    |                    | The UE shall not initiate an RRC connection. This is checked during 3 seconds.                                                                                                                                                           |
|      |           |    |                    | Mobile identity = P-TMSI-1                                                                                                                                                                                                               |
| 10   | →         |    |                    | Paging order is for PS services.                                                                                                                                                                                                         |
|      |           |    |                    | No response from the UE to the request. This is checked for 10 seconds                                                                                                                                                                   |
| 11   |           | SS | PAGING TYPE1       | The following messages are sent and shall be received on cell B.                                                                                                                                                                         |
| 12   | UE        |    |                    | Set the cell type of cell A to the "Off cell".                                                                                                                                                                                           |
| 13   | UE        |    |                    | Set the cell type of cell B to the "Serving cell".<br>(see note)                                                                                                                                                                         |
|      |           |    |                    | Cell B is preferred by the UE.                                                                                                                                                                                                           |
| 15   |           |    |                    | No ATTACH REQUEST or LOCATION UPDATING REQ is sent to SS                                                                                                                                                                                 |
| 16   | UE        |    |                    | (SS waits 60 seconds)                                                                                                                                                                                                                    |
| 17   | UE        |    |                    | Mobile identity = P-TMSI-1                                                                                                                                                                                                               |
| 18   |           |    |                    | Paging order is for PS services.                                                                                                                                                                                                         |
|      |           |    |                    | No response from the UE to the request. This is checked for 10 seconds.                                                                                                                                                                  |
| 19   |           | SS | Registration on CS | The UE initiates an attach by MMI or AT command.                                                                                                                                                                                         |
| 20   | UE        |    |                    | No attach is performed by the UE. This is checked for 10 seconds.                                                                                                                                                                        |
| 20a  | UE        |    |                    | The following messages are sent and shall be received on cell C.                                                                                                                                                                         |
| 20b  | UE        |    |                    | Set the cell type of cell B to the "Off cell".                                                                                                                                                                                           |
| 21   | →         |    |                    | Set the cell type of cell C to the "Serving cell".<br>(see note)                                                                                                                                                                         |
|      |           |    |                    | Cell C is preferred by the UE.                                                                                                                                                                                                           |
|      |           |    |                    | Step 20a is only performed for non-auto attach UE and is optional.                                                                                                                                                                       |
|      |           |    |                    | Parameter Mobile identity is IMSI.                                                                                                                                                                                                       |
|      |           |    |                    | See TS 34.108                                                                                                                                                                                                                            |
|      |           |    |                    | UE initiates an attach automatically (see ICS) via MMI or AT commands.                                                                                                                                                                   |
|      |           |    |                    | Attach type = 'Combined PS / IMSI attach'                                                                                                                                                                                                |
|      |           |    |                    | Mobile identity = IMSI                                                                                                                                                                                                                   |
|      |           |    |                    | TMSI status = no valid TMSI available                                                                                                                                                                                                    |



| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                 |
|------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                          |
| 22   | ←         |    | ATTACH ACCEPT                   | Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-3                                                           |
| 23   | →         |    | ATTACH COMPLETE                 |                                                                                                                                                                                                                          |
| 24   | ←         |    | PAGING TYPE1                    | Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                                                             |
| 25   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                          |
| 26   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                          |
| 27   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                          |
| 28   | →         |    | PAGING RESPONSE                 | Mobile identity = TMSI-1                                                                                                                                                                                                 |
| 29   | ←         |    | RRC CONNECTION RELEASE          | After sending of this message, the SS waits for disconnection of the CS signalling link.                                                                                                                                 |
| 30   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                          |
| 31   | ←         |    | PAGING TYPE1                    | Mobile identity = P-TMSI-1<br>Paging order is for PS services.                                                                                                                                                           |
| 32   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                          |
| 33   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                          |
| 34   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                          |
| 35   | →         |    | SERVICE REQUEST                 | Service type = "paging response"                                                                                                                                                                                         |
| 36   | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                          |
| 37   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                          |
| 38   | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                                                                                                                                                    |
| 39   | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach'                                                                                                                   |
| 40   | UE        |    |                                 | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Serving cell".<br>(see note)<br>Cell B is preferred by the UE. |
| 41   | UE        |    |                                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                                   |
| 42   |           |    |                                 | Step 43 is only performed for non-auto attach UE.                                                                                                                                                                        |
| 43   | UE        |    | Registration on CS              | See TS 34.108                                                                                                                                                                                                            |
| 44   | UE        |    |                                 | UE initiates an attach automatically (see ICS), by MMI or AT commands.                                                                                                                                                   |
| 45   | →         |    | ATTACH REQUEST                  | Attach type = 'Combined PS / IMSI attach' or "PS Attach while IMSI attached"<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-3                                                        |
| 46   | ←         |    | ATTACH ACCEPT                   | Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Mobile identity = TMSI-2<br>Routing area identity = RAI-4                                                           |
| 47   | →         |    | ATTACH COMPLETE                 |                                                                                                                                                                                                                          |
| 48   | ←         |    | PAGING TYPE1                    | Mobile identity = TMSI-2<br>Paging order is for CS services.                                                                                                                                                             |
| 49   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                          |
| 50   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                          |
| 51   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                          |
| 52   | →         |    | PAGING RESPONSE                 | Mobile identity = TMSI-2                                                                                                                                                                                                 |
| 53   | ←         |    | RRC CONNECTION RELEASE          | After sending of this message, the SS waits for disconnection of the CS signalling link.                                                                                                                                 |

| Step                                                                                                                                                      | Direction |    | Message                         | Comments                                                                                                                                                        |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                           | UE        | SS |                                 |                                                                                                                                                                 |
| 54                                                                                                                                                        | →         |    | RRC CONNECTION RELEASE COMPLETE | Mobile identity = P-TMSI-2<br>Paging order is for PS services.                                                                                                  |
| 55                                                                                                                                                        | ←         |    | PAGING TYPE1                    |                                                                                                                                                                 |
| 56                                                                                                                                                        | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                 |
| 57                                                                                                                                                        | ←         |    | RRC CONNECTION SETUP            | service type = "paging response"                                                                                                                                |
| 58                                                                                                                                                        | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                 |
| 59                                                                                                                                                        | →         |    | SERVICE REQUEST                 |                                                                                                                                                                 |
| 60                                                                                                                                                        | ←         |    | RRC CONNECTION RELEASE          | The UE is switched off or power is removed (see ICS).<br>Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach' |
| 61                                                                                                                                                        | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                 |
| 62                                                                                                                                                        | UE        |    |                                 |                                                                                                                                                                 |
| 63                                                                                                                                                        | →         |    | DETACH REQUEST                  |                                                                                                                                                                 |
| NOTE: The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                                 |

### Specific message contents

None.

### 12.2.2.7a.5 Test requirements

At step4, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence

At step6, when the UE receives the ATTACH REJECT message with GMM cause = 'Location Area not allowed', UE shall:

- not initiate MM location updating procedure.

At step8, when the UE receives the paging message for CS domain, UE shall:

- not respond to the paging message for CS domain.

At step10 and 16, when the UE receives the paging message for PS domain, UE shall:

- not respond to the paging message for PS domain.

At step13 and 18, when the UE is in the same location area, UE shall:

- not perform PS attach procedure.

At step21, when the UE enters a new location area, UE shall

- perform the combined PS attach procedure.

At step28 and 52, when the UE receives the paging message for CS domain, UE shall:

- respond to the paging message for CS domain by sending the PAGING RESPONSE message.

At step35 and 59, when the UE receives the paging message for PS domain, UE shall:

- respond to the paging message for PS domain by sending the SERVICE REQUEST message.

At step45, when the UE is powered up or switched on, UE shall:

- perform the combined PS attach procedure.

### ~~12.2.2.7b Combined PS attach / rejected / No Suitable Cells In Location Area~~

#### ~~12.2.2.7b.1 Definition~~

#### ~~12.2.2.7b.2 Conformance requirement~~

~~1) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'No Suitable Cells In Location Area', the User Equipment shall:~~

~~1.1 not perform combined PS attach when in the same location area.~~

~~1.2 delete the stored LAI, CKSN, TMSI, RAI, PS-CKSN, P-TMSI and P-TMSI signature.~~

~~1.3 store the LA in the 'forbidden location areas for roaming'.~~

~~2) If the network rejects a combined PS attach procedure from the User Equipment with the cause 'No Suitable Cells In Location Area', the User Equipment shall:~~

~~2.1 search for a suitable cell in a different location area on the same PLMN.~~

#### Reference

3GPP TS 24.008 clauses 4.7.3.2.

#### ~~12.2.2.7b.3 Test purpose~~

~~To test the behaviour of the UE if the network rejects the combined PS attach procedure with the cause 'No Suitable Cells In Location Area'.~~

#### ~~12.2.2.7b.4 Method of test~~

#### Initial condition

##### System Simulator:

~~— Three cells, cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC2/RAC1 (RAI-3), cell C in MCC2/MNC1/LAC1/RAC1 (RAI-2)~~

##### User Equipment:

~~— The UE has valid TMSI, P-TMSI, P-TMSI signature and RAI~~

#### Related ICS/IXIT statements

~~— Support of PS service — Yes/No~~

~~UE operation mode A — Yes/No~~

~~Switch off on button — Yes/No~~

~~Automatic PS attach procedure at switch on or power on — Yes/No~~

#### Test procedure

~~The SS rejects a combined PS attach with the cause value 'No Suitable Cells In Location Area'. The SS checks that the UE shall search for a suitable cell in a different location area on the same PLMN and shall perform combined PS attach procedure in that cell~~

## Expected Sequence

| Step                                                                                                                                                                     | Direction |    | Message         | Comments                                                                                                                                                                                                                                                                                 |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                          | UE        | SS |                 |                                                                                                                                                                                                                                                                                          |
|                                                                                                                                                                          |           | SS |                 | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>Set the cell type of cell C to the "Suitable neighbour cell".<br>(see note)<br>The SS configures power level of each Cell as follows.<br>Cell A > Cell B = Cell C |
| 1                                                                                                                                                                        | UE        |    |                 | The UE is set in UE operation mode A (see ICS).                                                                                                                                                                                                                                          |
| 2                                                                                                                                                                        | UE        |    |                 | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                                                                                                                    |
| 3                                                                                                                                                                        | ->        |    | ATTACH REQUEST  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                                                                                                                            |
| 4                                                                                                                                                                        | <-        |    | ATTACH REJECT   | Routing area identity = RAI-1<br>GMM cause = 'No Suitable Cells In Location Area'                                                                                                                                                                                                        |
| 5                                                                                                                                                                        | SS        |    |                 | The SS initiates the RRC connection release.<br>The following message are sent and shall be received on cell B.                                                                                                                                                                          |
| 6                                                                                                                                                                        | UE        |    |                 | The UE initiates an attach automatically, by MMI or by AT command.                                                                                                                                                                                                                       |
| 7                                                                                                                                                                        | ->        |    | ATTACH REQUEST  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI<br>TMSI status = no valid TMSI available                                                                                                                                                                             |
| 8                                                                                                                                                                        | <-        |    | ATTACH ACCEPT   | Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Mobile identity = TMSI-2<br>Routing area identity = RAI-2                                                                                                                           |
| 9                                                                                                                                                                        | ->        |    | ATTACH COMPLETE |                                                                                                                                                                                                                                                                                          |
| 10                                                                                                                                                                       | UE        |    |                 | The UE is switched off or power is removed (see ICS).                                                                                                                                                                                                                                    |
| 11                                                                                                                                                                       | ->        |    | DETACH REQUEST  | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                                                                                                                   |
| NOTE: The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                 |                                                                                                                                                                                                                                                                                          |

## Specific message contents

None.

## 12.2.2.7b.5 Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected sequence.

At step7, when the UE enters a suitable cell in a different location area on the same PLMN, UE shall:

- initiate the combined PS attach procedure.

### ~~12.2.2.8 Combined PS attach / abnormal cases / attempt counter check / miscellaneous reject causes~~

#### ~~12.2.2.8.1 Definition~~

#### ~~12.2.2.8.2 Conformance requirement~~

- ~~1) When a combined PS attach procedure is rejected with the attempt counter less than five, the User Equipment shall repeat the combined PS attach procedure after T3311 timeout.~~
- ~~2) When a combined PS attach procedure is rejected with the attempt counter five, the User Equipment shall delete the stored TMSI, LAI, CKSN, P-TMSI, P-TMSI signature, PS CKSN and RAI and start T3302.~~
- ~~3) When the T3302 expire, a new combined PS attach procedure shall be initiated.~~

GMM cause codes that can be selected are:

'TMSI unknown in HLR'

'UE identity cannot be derived by the network'

'Network failure'

'Congestion'

'retry upon entry into a new cell'

'Semantically incorrect message'

'Invalid mandatory information'

'Message type non-existent or not implemented'

'Message type not compatible with the protocol state'

'Information element non-existent or not implemented'

'Conditional IE error'

'Message not compatible with the protocol state'

'Protocol error, unspecified'

### Reference

3GPP TS 24.008 clause 4.7.3.2.

#### ~~12.2.2.8.3 Test purpose~~

To test the behaviour of the UE with respect to the attempt counter.

#### ~~12.2.2.8.4 Method of test~~

#### Initial condition

System Simulator:

— One cell operating in network operation mode I.

User Equipment:

~~—The UE has a valid TMSI, P-TMSI, P-TMSI signature and RAI.~~

#### Related ICS/IXIT statements

~~—Support of PS service—Yes/No~~

~~UE operation mode A Yes/No Automatic PS attach procedure at switch on or power on Yes/No~~

~~—Switch off on button Yes/No~~

#### Test procedure

The UE initiates a combined PS attach procedure (attempt counter zero).

The SS rejects the attach with an arbitrarily chosen cause code.

The UE initiates a new combined PS attach procedure (attempt counter one) after T3311 expires.

The SS rejects the attach with an arbitrarily chosen cause code.

The UE initiates a new combined PS attach procedure (attempt counter two) after T3311 expires.

The SS rejects the attach with an arbitrarily chosen cause code.

The UE initiates a new combined PS attach procedure (attempt counter three) after T3311 expires.

The SS rejects the attach with an arbitrarily chosen cause code.

The UE initiates a new combined PS attach procedure (attempt counter four) after T3311 expires.

The SS rejects the attach with an arbitrarily chosen cause code.

The UE shall not perform a new successful attach procedure after 15 seconds.

The UE initiates a combined PS attach procedure with attempt counter zero after T3302 expires without P-TMSI, P-TMSI signature, PS CKSN and RAI.

T3302; set to 10 minutes.

T3311; 15 seconds.

## Expected Sequence

| Step | Direction |    | Message            | Comments                                                                                                                                        |
|------|-----------|----|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                    |                                                                                                                                                 |
| 1    | UE        |    |                    | The UE is set in UE operation mode A (see ICS).                                                                                                 |
| 2    | UE        |    |                    | The UE is powered up or switched on and initiates an attach (see ICS).                                                                          |
| 3    | →         |    | ATTACH REQUEST     | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                  |
| 4    | ←         |    | ATTACH REJECT      | Arbitrarily chosen GMM cause<br>T3302 with value 10 min.                                                                                        |
| 5    | →         |    | ATTACH REQUEST     | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                  |
| 6    |           | SS |                    | The SS verifies that the time between the attach reject and attach request is T3311                                                             |
| 7    | ←         |    | ATTACH REJECT      | Arbitrarily chosen GMM cause<br>T3302 with value 10 min.                                                                                        |
| 8    | →         |    | ATTACH REQUEST     | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                  |
| 9    |           | SS |                    | The SS verifies that the time between the attach reject and attach request is T3311                                                             |
| 10   | ←         |    | ATTACH REJECT      | Arbitrarily chosen GMM cause<br>T3302 with value 10 min.                                                                                        |
| 11   | →         |    | ATTACH REQUEST     | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                  |
| 12   |           | SS |                    | The SS verifies that the time between the attach reject and attach request is T3311                                                             |
| 13   | ←         |    | ATTACH REJECT      | Arbitrarily chosen GMM cause<br>T3302 with value 10 min.                                                                                        |
| 14   | →         |    | ATTACH REQUEST     | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                  |
| 15   |           | SS |                    | The SS verifies that the time between the attach reject and attach request is T3311                                                             |
| 16   | ←         |    | ATTACH REJECT      | Arbitrarily chosen GMM cause<br>T3302 with value 10 min.                                                                                        |
| 17   | UE        |    | Registration on CS | See TS 34.108<br>This is applied only for UE in UE operation mode A.                                                                            |
| 20   | ←         |    | PAGING TYPE1       | Parameter mobile identity is IMSI.<br>Paging order is for PS services.<br>Mobile identity = P-TMSI-1                                            |
| 21   | UE        |    |                    | No response from the UE to the request. This is checked for 10 seconds.                                                                         |
| 21a  | →         |    | ATTACH REQUEST     | Attach type = 'Combined PS/IMSI attach' or 'PS attach while IMSI attached'<br>Mobile identity = IMSI<br>TMSI status = no valid TMSI available   |
| 22   |           | SS |                    | The SS verifies that the UE does not attempt to attach for T3302.                                                                               |
| 23   | →         |    | ATTACH REQUEST     | Attach type = 'Combined PS / IMSI attach'<br>'PS attach while IMSI attached'<br>Mobile identity = IMSI<br>TMSI status = no valid TMSI available |

| Step | Direction |    | Message                         | Comments                                                                                                                                                     |
|------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                              |
| 24   | ←         |    | ATTACH ACCEPT                   | Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-1 |
| 25   | →         |    | ATTACH COMPLETE                 |                                                                                                                                                              |
| 26   | ←         |    | PAGING TYPE1                    | Mobile identity = TMSI-1<br>Paging order is for CS services..                                                                                                |
| 27   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                              |
| 28   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                              |
| 29   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                              |
| 30   | →         |    | PAGING RESPONSE                 | Mobile identity = TMSI-1                                                                                                                                     |
| 31   | ←         |    | RRC CONNECTION RELEASE          | After sending of this message, the SS waits for disconnection of the CS signalling link.                                                                     |
| 32   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                              |
| 33   | ←         |    | PAGING TYPE1                    | Mobile identity = P-TMSI-1                                                                                                                                   |
| 33a  | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                              |
| 33b  | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                              |
| 33c  | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                              |
| 34   | →         |    | SERVICE REQUEST                 | Service type = "paging response"                                                                                                                             |
| 34a  | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                              |
| 34b  | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                              |
| 35   | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                                                                                        |
| 36   | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach'                                                       |

### Specific message contents

None.

### 12.2.2.8.5 Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.

UE shall perform the following actions depending on the conditions described below.

- Case1) A combined PS attach procedure is rejected with the attempt counter less than five

- At step6, 9, 12 and 15, when the timer T3311 timeout has occurred, UE shall:

- repeat the combine PS attach procedure.

- Case2) A combined PS attach procedure is rejected with the attempt counter five

At step21, when the UE receives the paging message for PS domain, UE shall:

- not respond to the paging message for PS domain.

- Case3) The T3302 expires

- At step23, UE shall:

- re-initiate the new combined PS attach procedure.



At step30, when the UE receives the paging message for CS domain, UE shall:

- respond to the paging message for CS domain by sending the ~~PAGING RESPONSE~~ message.

At step34, when the UE receives the paging message for PS domain, UE shall:

- respond to the paging message for PS domain by sending the ~~SERVICE REQUEST~~ message.

### ~~12.2.2.9 Combined PS attach / abnormal cases / PS detach procedure collision~~

#### ~~12.2.2.9.1 Definition~~

#### ~~12.2.2.9.2 Conformance requirement~~

- ~~1) When a DETACH REQUEST message is received by the UE (any cause except re-attach) while waiting for an ATTACH ACCEPT message or ATTACH REJECT message, the UE shall terminate the combined PS attach procedure and continue with the combined PS detach procedure.~~
- ~~2) When a DETACH REQUEST message is received by the UE (cause re-attach) while waiting for an ATTACH ACCEPT message or ATTACH REJECT message, the UE shall ignore the combined PS detach procedure and continue with the combined PS attach procedure.~~

#### Reference

3GPP TS 24.008 clause 4.7.3.2.

#### ~~12.2.2.9.3 Test purpose~~

~~To test the behaviour of the UE in case of procedure collision.~~

#### ~~12.2.2.9.4 Method of test~~

#### Initial condition

System Simulator:

- One cell operating in network operation mode I.

User Equipment:

- The UE has valid TMSI, P-TMSI, P-TMSI signature and RAI. UE is Idle Updated.

#### Related ICS/IXIT statements

Support of PS service—Yes/No

UE operation mode A—Yes/No

Switch off on button—Yes/No

Automatic PS attach procedure at switch on or power on—Yes/No

Re-attach automatically when the network commands a detach with no cause value—Yes/No

#### Test procedure

The UE initiates a combined PS attach procedure. The SS does not answer the combined PS attach procedure, but initiates a combined PS detach procedure (any cause except re-attach). The UE shall terminate the combined PS attach procedure and continue with the combined PS detach procedure.

The UE initiates a combined PS attach procedure. The SS does not answer the combined PS attach procedure, but initiates a combined PS detach procedure (cause re-attach). The UE shall ignore the combined PS detach procedure and continue with the combined PS attach. CS services are also possible.

## Expected Sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                       |
|------|-----------|----|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                |
| 1    | UE        |    |                                 | The UE is set in UE operation mode A (see ICS).                                                                                                                |
| 2    | UE        |    |                                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                         |
| 3    | →         |    | ATTACH REQUEST                  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                                 |
| 4    |           | SS |                                 | The SS ignores the ATTACH REQUEST message and initiates a detach procedure.                                                                                    |
| 5    | ←         |    | DETACH REQUEST                  | Detach type = 're-attach not required'                                                                                                                         |
| 6    | →         |    | DETACH ACCEPT                   |                                                                                                                                                                |
| 7    |           |    | (void)                          |                                                                                                                                                                |
| 8    |           |    | (void)                          |                                                                                                                                                                |
| 9    | UE        |    |                                 | The UE is attached by MMI or AT command if the UE does not re-attach automatically upon receiving a network initiated detach with no cause value, (see Ixit).  |
| 10   | →         |    | ATTACH REQUEST                  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                                 |
| 11   |           | SS |                                 | The SS ignores the ATTACH REQUEST message and initiates a detach procedure.                                                                                    |
| 12   | ←         |    | DETACH REQUEST                  | Detach type = 're-attach required'                                                                                                                             |
| 13   | UE        |    |                                 | The UE ignores the DETACH REQUEST message and continue with the attach procedure                                                                               |
| 14   | ←         |    | ATTACH ACCEPT                   | Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Mobile identity = TMSI-2<br>Routing area identity = RAI-1 |
| 15   | →         |    | ATTACH COMPLETE                 | Mobile identity = TMSI-2<br>Paging order is for CS services.                                                                                                   |
| 16   | ←         |    | PAGING TYPE1                    |                                                                                                                                                                |
| 17   | →         |    | RRC CONNECTION REQUEST          | Mobile identity = TMSI-2                                                                                                                                       |
| 18   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                |
| 19   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                |
| 20   | →         |    | PAGING RESPONSE                 |                                                                                                                                                                |
| 21   | ←         |    | RRC CONNECTION RELEASE          | After sending of this message, the SS waits for disconnection of the CS signalling link.                                                                       |
| 22   | →         |    | RRC CONNECTION RELEASE COMPLETE | Paging order is for PS services.<br>Mobile identity = P-TMSI-2                                                                                                 |
| 23   | ←         |    | PAGING TYPE1                    |                                                                                                                                                                |
| 23a  | →         |    | RRC CONNECTION REQUEST          | Service type = "paging response"                                                                                                                               |
| 23b  | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                |
| 23c  | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                |
| 24   | →         |    | SERVICE REQUEST                 |                                                                                                                                                                |
| 24a  | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                |
| 24b  | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                |
| 25   | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                                                                                          |
| 26   | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach'                                                         |

### Specific message contents

None.

#### 12.2.2.9.5 Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.

UE shall perform the following actions depending on the Detach type described below.

Case1) Detach type is not re-attach

At step6, UE shall:

- respond to DETACH REQUEST message by sending DETACH ACCEPT message.

Case2) Detach type is re-attach

At step13, UE shall:

- ignore the PS detach procedure.

At step15, UE shall:

- send the ATTACH COMPLETE message.

At step20, when the UE receives the paging message for CS domain, UE shall:

- respond to the paging message for CS domain by sending the PAGING RESPONSE message.

At step24, when the UE receives the paging message for PS domain, UE shall:

- respond to the paging message for PS domain by sending the SERVICE REQUEST message.

## 12.3 PS detach procedure

### 12.3.1 UE initiated PS detach procedure

#### 12.3.1.1 PS detach / power off / accepted

##### 12.3.1.1.1 Definition

##### 12.3.1.1.2 Conformance requirement

The UE detaches the IMSI for PS services if the UE is switched off.

#### Reference

- 3GPP TS 24.008 clause 4.7.4.1

##### 12.3.1.1.3 Test purpose

To test the behaviour of the UE for the detach procedure.

#### 12.3.1.1.4 Method of test

##### Initial condition

##### System Simulator:

— One cell operating in network operation mode H.

##### User Equipment:

— The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

##### Related ICS/IXIT statements

— Support of PS service — Yes/No

UE operation mode C — Yes/No

UE operation mode A — Yes/No

Switch off on button — Yes/No

Automatic PS attach procedure at switch on or power on — Yes/No

##### Test procedure

The UE performs a PS attach procedure.

The UE sends a DETACH REQUEST message to the SS.

##### Expected Sequence

| Step | Direction |    | Message         | Comments                                                                                                                |
|------|-----------|----|-----------------|-------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                 |                                                                                                                         |
| 1    | UE        |    |                 | The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 8.                      |
| 2    | UE        |    |                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                  |
| 3    | →         |    | ATTACH REQUEST  | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                           |
| 4    |           | ←  | ATTACH ACCEPT   | Routing area identity = RAI-1<br>Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature |
| 5    | →         |    | ATTACH COMPLETE | Routing area identity = RAI-1                                                                                           |
| 6    | UE        |    |                 | The UE is switched off (see ICS).                                                                                       |
| 7    | →         |    | DETACH REQUEST  | Detach type = 'power switched off, PS detach'                                                                           |
| 8    | UE        |    |                 | The UE is set in UE operation mode A (see ICS) and the test is repeated from step 2 to step 7.                          |

##### Specific message contents

None.

#### 12.3.1.1.5 Test requirements

At step 3, when the UE is powered up or switched on, UE shall:

— initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step 7, when the UE is switched off, UE shall:

— send the DETACH REQUEST message to SS with the Detach type = 'power switched off, PS detach'.

### ~~12.3.1.2 PS detach / accepted~~

#### ~~12.3.1.2.1 Definition~~

#### ~~12.3.1.2.2 Conformance requirement~~

~~The UE detaches the IMSI for PS services if the UE is ordered to do so with MMI or AT commands.~~

#### ~~Reference~~

~~3GPP TS 24.008 clause 4.7.4.1.~~

#### ~~12.3.1.2.3 Test purpose~~

~~To test the behaviour of the UE for the detach procedure.~~

#### ~~12.3.1.2.4 Method of test~~

#### ~~Initial condition~~

##### ~~System Simulator:~~

~~— One cell operating in network operation mode II.~~

##### ~~User Equipment:~~

~~— The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.~~

#### ~~Related ICS/IXIT statements~~

~~— Support of PS service — Yes/No  
UE operation mode C — Yes/No  
UE operation mode A — Yes/No  
Switch off on button — Yes/No  
Automatic PS attach procedure at switch on or power on — Yes/No~~

#### ~~Test procedure~~

~~The UE performs a PS attach procedure.~~

~~The UE sends a DETACH REQUEST message to the SS.~~

~~The SS signal to the UE, but no response is received, as the signalling link is disconnected.~~

## Expected Sequence

| Step | Direction |    | Message        | Comments                                                                                                                                                                              |
|------|-----------|----|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                |                                                                                                                                                                                       |
| 1    | UE        |    |                | The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 12.                                                                                   |
| 2    | UE        |    |                | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                |
| 3    | →         |    | ATTACH REQUEST | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                                         |
| 4    | ←         |    | ATTACH ACCEPT  | Routing area identity = RAI-1<br>No new mobile identity assigned.<br>P-TMSI and P-TMSI signature not included.<br>Attach result = 'PS only attached'<br>Routing area identity = RAI-1 |
| 5    |           |    | (void)         |                                                                                                                                                                                       |
| 6    | UE        |    |                | The UE initiates a PS detach (without power off) by MMI or AT command.                                                                                                                |
| 7    | →         |    | DETACH REQUEST | Detach type = 'normal detach, PS detach'                                                                                                                                              |
| 8    | ←         |    | DETACH ACCEPT  |                                                                                                                                                                                       |
| 9    | ←         |    | PAGING TYPE1   | Mobile identity = P-TMSI-1<br>Paging order is for PS services.                                                                                                                        |
| 10   | UE        |    |                | No response from the UE to the request. This is checked for 10 seconds.                                                                                                               |
| 11   |           |    | (void)         |                                                                                                                                                                                       |
| 12   | UE        |    |                | The UE is set in UE operation mode A (see ICS) and the test is repeated from step 2 to step 10.                                                                                       |

## Specific message contents

None.

## 12.3.1.2.5 Test requirements

At step 3, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step 7, UE shall:

- sends the DETACH REQUEST message (without power off) to SS.

At step 10, when the UE receives the paging message for PS domain, UE shall:

- not respond to the paging message for PS domain.

## 12.3.1.3 PS detach / abnormal cases / attempt counter check / procedure timeout

## 12.3.1.3.1 Definition

## 12.3.1.3.2 Conformance requirement

- 1) When a T3321 timeout has occurred during a PS detach procedure with the attempt counter less than five, the User Equipment shall repeat the PS detach procedure.
- 2) When a T3321 timeout has occurred during a PS detach procedure with the attempt counter five, the User Equipment shall not repeat the procedure.

## Reference

3GPP TS 24.008 clause 4.7.4.1.

### 12.3.1.3.3 ~~Test purpose~~

~~To test the behaviour of the UE with respect to the attempt counter.~~

### 12.3.1.3.4 ~~Method of test~~

#### ~~Initial condition~~

~~System Simulator:~~

~~— One cell operating in network operation mode II.~~

~~User Equipment:~~

~~— The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.~~

#### ~~Related ICS/IXIT statements~~

~~— Support of PS service — Yes/No~~

~~UE operation mode C — Yes/No~~

~~UE operation mode A — Yes/No~~

~~Switch off on button — Yes/No~~

~~Automatic PS attach procedure at switch on or power on — Yes/No~~

#### ~~Test procedure~~

~~The UE performs a PS attach procedure.~~

~~The UE initiates a PS detach procedure (attempt counter zero). The SS does not answer with DETACH ACCEPT message before T3321 timeout.~~

~~The UE initiates a new PS detach procedure (attempt counter one) after T3321 expires. The SS does not answer with DETACH ACCEPT message before T3321 timeout.~~

~~The UE initiates a new PS detach procedure (attempt counter two) after T3321 expires. The SS does not answer with DETACH ACCEPT message before T3321 timeout.~~

~~The UE initiates a new PS detach procedure (attempt counter three) after T3321 expires. The SS does not answer with DETACH ACCEPT message before T3321 timeout.~~

~~The UE initiates a new PS detach procedure (attempt counter four) after T3321 expires. The SS does not answer with DETACH ACCEPT message before T3321 timeout.~~

~~The UE initiates a new PS detach procedure with attempt counter five (after T3321 expires). The SS does not answer with DETACH ACCEPT message before T3321 timeout.~~

~~At T3321 timeout in the UE, the UE then deletes the logical link since the retransmissions have been repeated four times.~~

~~The UE performs a new PS attach procedure.~~

~~T3321; 15 seconds.~~

## Expected Sequence

| Step | Direction |    | Message        | Comments                                                                                                                                                                              |
|------|-----------|----|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                |                                                                                                                                                                                       |
| 1    | UE        |    |                | The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 25.                                                                                   |
| 2    | UE        |    |                | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                |
| 3    | →         |    | ATTACH REQUEST | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                                         |
| 4    | ←         |    | ATTACH ACCEPT  | Routing area identity = RAI-1<br>No new mobile identity assigned.<br>P-TMSI and P-TMSI signature not included.<br>Attach result = 'PS only attached'<br>Routing area identity = RAI-1 |
| 5    | UE        |    |                | The UE initiates a PS detach (without power off) by MMI or AT command.                                                                                                                |
| 6    | →         |    | DETACH REQUEST | Detach type = 'normal detach, PS detach'                                                                                                                                              |
| 7    |           | SS |                | No response is given from the SS.                                                                                                                                                     |
| 8    |           | SS |                | The SS verifies that the time between the detach requests is 15 seconds                                                                                                               |
| 9    | →         |    | DETACH REQUEST | Detach type = 'normal detach, PS detach'                                                                                                                                              |
| 10   |           | SS |                | No response is given from the SS.                                                                                                                                                     |
| 11   |           | SS |                | The SS verifies that the time between the detach requests is 15 seconds                                                                                                               |
| 12   | →         |    | DETACH REQUEST | Detach type = 'normal detach, PS detach'                                                                                                                                              |
| 13   |           | SS |                | No response is given from the SS.                                                                                                                                                     |
| 14   |           | SS |                | The SS verifies that the time between the detach requests is 15 seconds                                                                                                               |
| 15   | →         |    | DETACH REQUEST | Detach type = 'normal detach, PS detach'                                                                                                                                              |
| 16   |           | SS |                | No response is given from the SS.                                                                                                                                                     |
| 17   |           | SS |                | The SS verifies that the time between the detach requests is 15 seconds                                                                                                               |
| 18   | →         |    | DETACH REQUEST | Detach type = 'normal detach, PS detach'                                                                                                                                              |
| 19   |           | SS |                | No response is given from the SS within 40 seconds and SS verifies that the UE will not send a DETACH REQUEST again.                                                                  |
| 20   | UE        |    |                | Initialte a PS attach                                                                                                                                                                 |
| 21   | →         |    | ATTACH REQUEST | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>Routing area identity = RAI-1                                                                                              |
| 22   | ←         |    | ATTACH ACCEPT  | No new mobile identity assigned.<br>P-TMSI and P-TMSI signature not included.<br>Attach result = 'PS only attached'<br>Routing area identity = RAI-1                                  |
| 23   |           |    |                | UE is switched off or power is removed (see ICS)                                                                                                                                      |
| 24   | →         |    | DETACH REQUEST | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                |
| 25   | UE        |    |                | The UE is set in UE operation mode A (see ICS) and the test is repeated from step 2 to step 24.                                                                                       |

## Specific message contents

None.

## 12.3.1.3.5 ——— Test requirements

At step3, when the UE is powered up or switched on, UE shall:

—— initiate the PS attaché procedure with the information elements specified in the above Expected Sequence.

At step9, 12, 15 and 18, when a T3321 expires with the attempt counter less than five, UE shall:



—initiate the new PS detach procedure.

At step19, when the attempt counter is greater than or equal to five, UE shall:

—not repeat the PS detach procedure.

At step20, UE shall:

—initiate the PS attaché procedure.

### ~~12.3.1.4 PS detach / abnormal cases / GMM common procedure collision~~

#### ~~12.3.1.4.1 Definition~~

#### ~~12.3.1.4.2 Conformance requirement~~

When any of the GMM common messages P-TMSI REALLOCATION COMMAND, GMM STATUS or GMM INFORMATION is received by the UE while waiting for a DETACH ACCEPT message with detach cause different from "power off", the UE shall ignore the GMM common message.

#### ~~Reference~~

3GPP TS 24.008 clause 4.7.4.1.

#### ~~12.3.1.4.3 Test purpose~~

To test the behaviour of the UE in case of procedure collision.

#### ~~12.3.1.4.4 Method of test~~

#### ~~Initial condition~~

System Simulator:

—One cell operating in network operation mode II.

User Equipment:

—The UE has a valid IMSI.

#### ~~Related ICS/IXIT statements~~

- Support of PS service—Yes/No
- UE operation mode C—Yes/No
- UE operation mode A—Yes/No (only if mode C not supported)
- Switch off on button—Yes/No
- Automatic PS attach procedure at switch on or power on—Yes/No

#### ~~Test procedure~~

The following test procedure is repeated for sequence counter k = 1,2,3:

The UE performs a PS attach.

The UE initiates a PS detach. The SS initiates a P-TMSI REALLOCATION COMMAND message (k=1), a GMM STATUS message (k=2) and a GMM INFORMATION message (k=3). The UE shall ignore the GMM common messages and continue with the PS detach procedure.

The SS signal to the UE, but no response is received, as the signalling link is disconnected.

## Expected Sequence

The test sequence is repeated for  $k = 1 \dots 3$

| Step | Direction |    | Message                     | Comments                                                                                                                                                                                     |
|------|-----------|----|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                                                                              |
| 1    | UE        |    |                             | The UE is set in UE operation mode C (see ICS).                                                                                                                                              |
| 2    | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                       |
| 3    | →         |    | ATTACH REQUEST              | Attach type = 'PS attach'                                                                                                                                                                    |
| 4    | ←         |    | ATTACH ACCEPT               | Mobile identity = IMSI<br>Attach result = 'PS only attached'                                                                                                                                 |
| 5    | →         |    | ATTACH COMPLETE             | Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                                                                                                            |
| 6    | UE        |    |                             | The UE initiates a detach (without power off) by MMI or AT command.                                                                                                                          |
| 7    | →         |    | DETACH REQUEST              | Detach type = 'normal detach, PS detach'                                                                                                                                                     |
| 8A   | SS        |    |                             | The SS sends a P-TMSI REALLOCATION COMMAND message                                                                                                                                           |
| 9A   | ←         |    | P-TMSI REALLOCATION COMMAND |                                                                                                                                                                                              |
| 10A  | UE        |    |                             | The UE ignores the message. This is verified for 12 seconds.                                                                                                                                 |
| 8B   | SS        |    |                             | The SS sends a GMM STATUS message                                                                                                                                                            |
| 9B   | ←         |    | GMM STATUS                  |                                                                                                                                                                                              |
| 10C  | UE        |    |                             | The UE ignores the message. This is verified for 12 seconds.                                                                                                                                 |
| 8C   | SS        |    |                             | The SS sends a GMM INFORMATION message                                                                                                                                                       |
| 9C   | ←         |    | GMM INFORMATION             |                                                                                                                                                                                              |
| 10C  | UE        |    |                             | The UE ignores the message which is verified for 12 seconds or if GMM INFORMATION message not implemented, sends a GMM STATUS with GMM Cause 'Message type non-existent or not implemented'. |
| 11   | ←         |    | DETACH ACCEPT               | The SS responds to the DETACH REQUEST                                                                                                                                                        |
| 12   | ←         |    | PAGING TYPE1                | Mobile identity = P-TMSI-1<br>Paging order is for PS services.                                                                                                                               |
| 13   | UE        |    |                             | No response from the UE to the request. This is checked for 10 seconds.                                                                                                                      |

## Specific message contents

None.

## 12.3.1.4.5 Test requirements

At step 3, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step 10A, 10B, 10C and 13, when any of the GMM common messages P-TMSI REALLOCATION COMMAND, GMM STATUS or GMM INFORMATION is received by the UE while waiting for a DETACH ACCEPT message with detach cause different from "power off, UE shall:

- ignore any of the GMM common message.

~~12.3.1.5 PS detach / power off / accepted~~~~12.3.1.5.1 Definition~~~~12.3.1.5.2 Conformance requirement~~

The UE detach the IMSI for PS and non-PS services.

## Reference

3GPP TS 24.008 clause 4.7.4.1.

~~12.3.1.5.3 Test purpose~~

To test the behaviour of the UE for the detach procedure.

~~12.3.1.5.4 Method of test~~

## Initial condition

## System Simulator:

— One cell operating in network operation mode 1.

## User Equipment:

— The UE has a valid IMSI.

## Related ICS/IXIT statements

— Support of PS service — Yes/No

UE operation mode A — Yes/No

Switch off on button — Yes/No

Automatic PS attach procedure at switch on or power on — Yes/No

## Test procedure

The UE performs a combined PS attach procedure (for PS and non-PS services).

The UE sends a DETACH REQUEST message to the SS. The UE then deletes the logical link.

## Expected Sequence

| Step | Direction |    | Message         | Comments                                                                                                                                                                    |
|------|-----------|----|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                 |                                                                                                                                                                             |
| 1    | UE        |    |                 | The UE is set in UE operation mode A (see ICS).                                                                                                                             |
| 2    | UE        |    |                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                      |
| 3    | —>        |    | ATTACH REQUEST  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                         |
| 4    | —<        |    | ATTACH ACCEPT   | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1 |
| 5    | —>        |    | ATTACH COMPLETE |                                                                                                                                                                             |
| 6    | UE        |    |                 | The UE is switched off (see ICS).                                                                                                                                           |
| 7    | —>        |    | DETACH REQUEST  | Detach type = 'power switched off, combined PS / IMSI detach'                                                                                                               |

### ~~Specific message contents~~

~~None.~~

### ~~12.3.1.5.5 Test requirements~~

~~At step3, when the UE is powered up or switched on, UE shall:~~

- ~~— initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.~~

~~At step7, when the UE is switched off, UE shall:~~

- ~~— send the DETACH REQUEST message to SS with the Detach type = 'power switched off, combined PS / IMSI detach'.~~

### ~~12.3.1.6 PS detach / accepted / PS/IMSI detach~~

#### ~~12.3.1.6.1 Definition~~

#### ~~12.3.1.6.2 Conformance requirement~~

~~The UE detach the IMSI for PS and non-PS services.~~

#### ~~Reference~~

~~3GPP TS 24.008 clause 4.7.4.1.~~

#### ~~12.3.1.6.3 Test purpose~~

~~To test the behaviour of the UE for the detach procedure.~~

#### ~~12.3.1.6.4 Method of test~~

#### ~~Initial condition~~

~~System Simulator:~~

- ~~— One cell operating in network operation mode I.~~

~~User Equipment:~~

- ~~— The UE has a valid IMSI.~~

#### ~~Related ICS/IXIT statements~~

- ~~— Support of PS service — Yes/No~~
- ~~UE operation mode A — Yes/No~~
- ~~Switch off on button — Yes/No~~
- ~~Automatic PS attach procedure at switch on or power on — Yes/No~~
- ~~User requested combined PS and non-PS detached without powering off — Yes/No~~

#### ~~Test procedure~~

~~The UE performs a combined PS attach procedure (for PS and non-PS services).~~

~~The UE sends a DETACH REQUEST message to the SS. When the UE receives the DETACH ACCEPT, the UE then deletes the logical link.~~

~~The SS signal to the UE, but no response is received, as the signalling link is disconnected.~~

## Expected Sequence

| Step | Direction |    | Message         | Comments                                                                                                                                                                                                |
|------|-----------|----|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                 |                                                                                                                                                                                                         |
| 1    | UE        |    |                 | The UE is set in UE operation mode A (see ICS).                                                                                                                                                         |
| 2    | UE        |    |                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                  |
| 3    | →         |    | ATTACH REQUEST  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                     |
| 4    | ←         |    | ATTACH ACCEPT   | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-1 |
| 5    | →         |    | ATTACH COMPLETE |                                                                                                                                                                                                         |
| 6    | UE        |    |                 | The UE initiates a detach (without power off) by MMI or AT command.                                                                                                                                     |
| 7    | →         |    | DETACH REQUEST  | Detach type = 'normal detach, combined PS / IMSI detach'                                                                                                                                                |
| 8    | ←         |    | DETACH ACCEPT   |                                                                                                                                                                                                         |
| 9    | ←         |    | PAGING TYPE1    | Mobile identity = P-TMSI-1                                                                                                                                                                              |
| 10   | UE        |    |                 | Paging order is for PS services.<br>No response from the UE to the request. This is checked for 10 seconds.                                                                                             |
| 11   | ←         |    | PAGING TYPE1    | Mobile identity = IMSI                                                                                                                                                                                  |
| 12   | UE        |    |                 | Paging order is for CS services.<br>The UE shall not initiate an RRC connection. This is checked during 3 seconds.                                                                                      |

## Specific message contents

None.

## 12.3.1.6.5 — Test requirements

At step 3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.

At step 10, when the UE receives the paging message for PS domain, UE shall:

- not respond to the paging message for PS domain.

At step 12, when the UE receives the paging message for CS domain, UE shall:

- not respond to the paging message for CS domain.

## 12.3.1.7 — PS detach / accepted / IMSI detach

## 12.3.1.7.1 — Definition

## 12.3.1.7.2 — Conformance requirement

The UE shall detach for CS services.

## Reference

3GPP TS 24.008 clause 4.7.4.1.

### ~~12.3.1.7.3 Test purpose~~

~~To test the behaviour of the UE for the detach procedure.~~

### ~~12.3.1.7.4 Method of test~~

#### ~~Initial condition~~

##### ~~System Simulator:~~

- ~~— One cell operating in network operation mode I.~~

##### ~~User Equipment:~~

- ~~— The UE has a valid IMSI.~~

#### ~~Related ICS/IXIT statements~~

- ~~— Support of PS service — Yes/No~~
- ~~UE operation mode A — Yes/No~~
- ~~Switch off on button — Yes/No~~
- ~~Automatic PS attach procedure at switch on or power on — Yes/No~~
- ~~User requested non-PS detached — Yes/No~~

#### ~~Test procedure~~

~~The UE performs a combined PS attach procedure (for PS and non-PS services).~~

~~The UE performs an PS detach (for non-PS services).~~

~~CS services are not possible.~~

~~The UE attach for non-PS services by a routing area update procedure and CS services are again possible.~~

## Expected Sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                |
|------|-----------|----|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                         |
| 1    | UE        |    |                                 | The UE is set in UE operation mode A (see ICS).                                                                                                                                                         |
| 2    | UE        |    |                                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                  |
| 3    | →         |    | ATTACH REQUEST                  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                     |
| 4    | ←         |    | ATTACH ACCEPT                   | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-1 |
| 5    | →         |    | ATTACH COMPLETE                 |                                                                                                                                                                                                         |
| 6    | UE        |    |                                 | The UE initiates a detach for non-PS services (without power off) (see ICS).                                                                                                                            |
| 7    | →         |    | DETACH REQUEST                  | Detach type = 'normal detach, IMSI detach'                                                                                                                                                              |
| 8    | ←         |    | DETACH ACCEPT                   |                                                                                                                                                                                                         |
| 9    | ←         |    | PAGING TYPE1                    | Mobile identity = P-TMSI-1<br>Paging order is for PS services.                                                                                                                                          |
| 9a   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                         |
| 9b   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                         |
| 9c   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                         |
| 10   | →         |    | SERVICE REQUEST                 | service type = "paging response"                                                                                                                                                                        |
| 10a  | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                         |
| 10b  | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                         |
| 11   | ←         |    | PAGING TYPE1                    | Mobile identity = TMSI-1<br>Paging order is for CS services.<br>Paging order is for RRC connection.                                                                                                     |
| 12   | UE        |    |                                 | The UE shall not initiate an RRC connection. This is checked during 3 seconds.                                                                                                                          |
| 13   | UE        |    |                                 | The UE initiates an attach for non-PS services by a RA update procedure (see ICS).                                                                                                                      |
| 14   | →         |    | ROUTING AREA UPDATE REQUEST     | Update type = "Combined RA/LA updating with IMSI attach"<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                                                                                         |
| 15   | ←         |    | ROUTING AREA UPDATE ACCEPT      | Update result = 'Combined RA/LA updated'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-1                                               |
| 16   | →         |    | ROUTING AREA UPDATE COMPLETE    |                                                                                                                                                                                                         |
| 17   | ←         |    | PAGING TYPE1                    | Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                                            |
| 18   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                         |
| 19   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                         |
| 20   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                         |
| 21   | →         |    | PAGING RESPONSE                 | Mobile identity = TMSI-1                                                                                                                                                                                |
| 22   | ←         |    | RRC CONNECTION RELEASE          | After sending of this message, the SS waits for disconnection of the CS signalling link.                                                                                                                |
| 23   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                         |
| 24   | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                                                                                                                                   |
| 25   | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach'                                                                                                  |

### Specific message contents

None.

#### 12.3.1.7.5 Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.

At step10, after the detach procedure (Detach type = 'normal detach, IMSI detach') is completed, UE shall:

- respond to the paging message for PS domain by sending the SERVICE REQUEST message.

At step12, after the detach procedure (Detach type = 'normal detach, IMSI detach') is completed, UE shall:

- not respond to the paging message for CS.

At step21, after the routing area updating procedure (Update type = 'Combined RA/LA updating') is completed, UE shall:

- respond to the paging message for CS domain by sending the PAGING RESPONSE message.

#### 12.3.1.8 PS detach / abnormal cases / change of cell into new routing area

##### 12.3.1.8.1 Definition

##### 12.3.1.8.2 Conformance requirement

When a change of cell into a new routing area is performed before DETACH ACCEPT message is received by the UE, the UE shall abort the PS detach procedure and re-initiate it after the routing area update procedure.

### Reference

3GPP TS 24.008 clause 4.7.4.1.

##### 12.3.1.8.3 Test purpose

To test the behaviour of the UE in case of procedure collision.

##### 12.3.1.8.4 Method of test

### Initial condition

System Simulator:

- Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1) and cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4).  
Both cells are operating in network operation mode I.

User Equipment:

- The UE has a valid IMSI.

### Related ICS/IXIT statements

- Support of PS service — Yes/No
- UE operation mode A — Yes/No
- Switch off on button — Yes/No
- Automatic PS attach procedure at switch on or power on — Yes/No
- User requested combined PS and non-PS detached without powering off — Yes/No



**Test procedure**

The UE performs a combined PS attach procedure (for PS and non-PS services).

The UE initiates a PS detach procedure. The DETACH ACCEPT message is delayed from the SS.

The UE performs a cell update into a new routing area.

The UE shall re-initiate a PS detach procedure when the routing area update procedure is finished.

The UE deletes the logical link.

**Expected Sequence**

| Step | Direction |    | Message                      | Comments                                                                                                                                                                                                |
|------|-----------|----|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                              |                                                                                                                                                                                                         |
| 1    |           | SS |                              | The following messages are sent and shall be received on cell A:<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note)                  |
| 2    | UE        |    |                              | The UE is set in UE operation mode A (see ICS).                                                                                                                                                         |
| 3    | UE        |    |                              | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                                   |
| 4    | →         |    | ATTACH REQUEST               | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                     |
| 5    | ←         |    | ATTACH ACCEPT                | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-1 |
| 6    | →         |    | ATTACH COMPLETE              |                                                                                                                                                                                                         |
| 7    | UE        |    |                              | The UE initiates a PS detach (without power off) by MMI or AT command.                                                                                                                                  |
| 8    | →         |    | DETACH REQUEST               | Detach type = 'normal detach, combined PS / IMSI detach'                                                                                                                                                |
| 9    |           | SS |                              | No response to the DETACH REQUEST message is given by the SS                                                                                                                                            |
| 10   |           | SS |                              | The following messages are sent and shall be received on cell B:<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)                  |
| 11   | UE        |    |                              | Cell B is preferred by the UE.                                                                                                                                                                          |
| 12   | →         |    | ROUTING AREA UPDATE REQUEST  | The UE performs a RA update in the new cell.<br>Update type = 'Combined RA/LA updating'<br>P-TMSI-1 signature<br>Routing area identity = RAI-1<br>TMSI status = valid TMSI available or IE omitted      |
| 13   | ←         |    | ROUTING AREA UPDATE ACCEPT   | Update result = 'Combined RA/LA updated'<br><br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-4                                                                       |
| 14   | →         |    | ROUTING AREA UPDATE COMPLETE |                                                                                                                                                                                                         |
| 15   | →         |    | DETACH REQUEST               | The detach is automatically re-attempted.<br>Detach type = 'normal detach, combined PS / IMSI detach'                                                                                                   |
| 16   | ←         |    | DETACH ACCEPT                |                                                                                                                                                                                                         |

NOTE: — The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only".

### Specific message contents

None.

#### 12.3.1.8.5 Test requirements

At step4, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.

At step12, when a change of cell into a new routing area is performed before DETACH ACCEPT message is received by the UE, UE shall:

- abort a PS detach procedure.
- perform routing area updating procedure.

At step15, when the UE completes a routing area updating procedure, UE shall:

- re-initiate the PS detach procedure.

#### 12.3.1.9 PS detach / abnormal cases / PS detach procedure collision

##### 12.3.1.9.1 Definition

##### 12.3.1.9.2 Conformance requirement

When a DETACH REQUEST is received by the UE while waiting for a DETACH ACCEPT message, the UE shall answer the network initiated PS detach procedure.

### Reference

3GPP TS 24.008 clause 4.7.4.1.

##### 12.3.1.9.3 Test purpose

To test the behaviour of the UE in case of procedure collision.

##### 12.3.1.9.4 Method of test

### Initial condition

System Simulator:

- One cell operating in network operation mode I.

User Equipment:

- The UE has a valid IMSI.

### Related ICS/IXIT statements

- Support of PS service—Yes/No
- UE operation mode A—Yes/No
- Switch off-on button—Yes/No
- Automatic PS attach procedure at switch on or power on—Yes/No
- User requested combined PS and non-PS detached without powering off—Yes/No

### Test procedure

The UE performs a combined PS attach procedure (for PS and non-PS services).

The UE initiates a PS detach. The SS does not answer the detach procedure, but initiates a detach procedure (cause re-attach not required). The UE shall continue with the network initiated detach procedure.

The UE deletes the logical link.

PS and CS services are not possible.

#### Expected Sequence

| Step | Direction |    | Message         | Comments                                                                                                                                                                                                |
|------|-----------|----|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                 |                                                                                                                                                                                                         |
| 1    | UE        |    |                 | The UE is set in UE operation mode A (see ICS).                                                                                                                                                         |
| 2    | UE        |    |                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                  |
| 3    | →         |    | ATTACH REQUEST  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                     |
| 4    | ←         |    | ATTACH ACCEPT   | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-1 |
| 5    | →         |    | ATTACH COMPLETE |                                                                                                                                                                                                         |
| 6    | UE        |    |                 | The UE initiates a PS detach (without power off) by MMI or AT command.                                                                                                                                  |
| 7    | →         |    | DETACH REQUEST  | Detach type = 'normal detach, combined PS / IMSI detach'                                                                                                                                                |
| 8    | ←         |    | DETACH REQUEST  | Detach type = 're-attach not required'                                                                                                                                                                  |
| 9    | →         |    | DETACH ACCEPT   | The UE answers the network initiated detach.                                                                                                                                                            |
| 10   | ←         |    | DETACH ACCEPT   | The SS answers the UE initiated detach.                                                                                                                                                                 |
| 11   | ←         |    | PAGING TYPE1    | Mobile identity = P-TMSI-1<br>Paging order is for PS services.                                                                                                                                          |
| 12   | UE        |    |                 | No response from the UE to the request. This is checked for 10 seconds.                                                                                                                                 |
| 13   | ←         |    | PAGING TYPE 1   | Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                                            |
| 14   | UE        |    |                 | The UE shall not initiate an RRC connection. This is checked during 3 seconds.                                                                                                                          |

#### Specific message contents

None.

#### 12.3.1.9.5 ——— Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.

At step9, when the UE receives DETACH REQUEST message from SS before UE initiated PS detach procedure has been completed, UE shall:

- send the DETACH ACCEPT message to SS.

At step12, when the UE receives the paging message for PS domain, UE shall:

- not respond to the paging message for PS domain.

At step14, when the UE receives the paging message for CS domain, UE shall:

- not respond to the paging message for CS domain.

## ~~12.3.2 Network initiated PS detach procedure~~

### ~~12.3.2.1 PS detach / re-attach not required / accepted~~

#### ~~12.3.2.1.1 Definition~~

#### ~~12.3.2.1.2 Conformance requirement~~

~~The UE detach the IMSI for PS services.~~

#### ~~Reference~~

~~3GPP TS 24.008 clause 4.7.4.2.~~

#### ~~12.3.2.1.3 Test purpose~~

~~To test the behaviour of the UE for the detach procedure.~~

#### ~~12.3.2.1.4 Method of test~~

#### ~~Initial condition~~

~~System Simulator:~~

- ~~— One cell operating in network operation mode II (in case of UE operation mode A).~~

~~User Equipment:~~

- ~~— The UE has a valid IMSI.~~

#### ~~Related ICS/IXIT statements~~

- ~~— Support of PS service — Yes/No~~
- ~~UE operation mode C — Yes/No~~
- ~~UE operation mode A — Yes/No (only if mode C not supported)~~
- ~~Switch off on button — Yes/No~~
- ~~Automatic PS attach procedure at switch on or power on — Yes/No~~

#### ~~Test procedure~~

~~The UE performs a PS attach procedure.~~

~~The SS sends a DETACH REQUEST message to the UE. The UE then deletes the logical link.~~

~~The SS signal to the UE, but no response is received, as the signalling link is disconnected.~~

## Expected Sequence

| Step | Direction |    | Message         | Comments                                                                |
|------|-----------|----|-----------------|-------------------------------------------------------------------------|
|      | UE        | SS |                 |                                                                         |
| 1    |           | SS |                 | The SS is set in network operation mode II.                             |
| 2    |           | UE |                 | The UE is set in UE operation mode A or C (see ICS).                    |
| 3    |           | UE |                 | The UE is powered up or switched on and initiates an attach (see ICS).  |
| 4    | →         |    | ATTACH REQUEST  | Attach type = 'PS attach'                                               |
| 5    | ←         |    | ATTACH ACCEPT   | Mobile identity = IMSI                                                  |
|      |           |    |                 | Attach result = 'PS only attached'                                      |
|      |           |    |                 | Mobile identity = P-TMSI-1                                              |
|      |           |    |                 | P-TMSI-1 signature                                                      |
|      |           |    |                 | Routing area identity = RAI-1                                           |
| 6    | →         |    | ATTACH COMPLETE |                                                                         |
| 7    |           | SS |                 | The SS initiates a PS detach.                                           |
| 8    | ←         |    | DETACH REQUEST  | Detach type = 're-attach not required'                                  |
| 9    | →         |    | DETACH ACCEPT   |                                                                         |
| 10   | ←         |    | PAGING TYPE1    | Mobile identity = P-TMSI-1                                              |
|      |           |    |                 | Paging order is for PS services.                                        |
|      |           |    |                 | PAGING TYPE1 (used for NW mode II).                                     |
| 11   |           | UE |                 | No response from the UE to the request. This is checked for 10 seconds. |

## Specific message contents

None.

## 12.3.2.1.5 Test requirements

At step4, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step9, when the UE receives the DETACH REQUEST message from SS and the detach type IE indicates 're-attach not required', the UE shall:

- send DETACH ACCEPT message to SS.

At step11, when the UE receives the paging message for PS domain, UE shall:

- not respond to the paging message for PS domain.

## 12.3.2.2 PS detach / rejected / IMSI invalid / PS services not allowed

## 12.3.2.2.1 Definition

## 12.3.2.2.2 Conformance requirement

- 1) If the network performs a PS detach procedure with the cause 'PS services not allowed', the User Equipment shall consider USIM invalid for PS services until power is switched off or USIM is removed.
- 2) If the network performs a PS detach procedure with the cause 'PS services not allowed' the User Equipment shall delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.

## Reference

3GPP TS 24.008 clause 4.7.4.2.

### ~~12.3.2.2.3 Test purpose~~

~~To test the behaviour of the UE if the network orders a PS detach procedure with the cause 'PS services not allowed' (no valid PS-subscription for the IMSI).~~

### ~~12.3.2.2.4 Method of test~~

#### ~~Initial condition~~

#### ~~System Simulator:~~

- ~~— Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (HPLMN, RAI-1) and cell B in MCC2/MNC1/LAC1/RAC1 (RAI-2).~~
- ~~Both cells are operating in network operation mode II.~~

#### ~~User Equipment:~~

- ~~— The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.~~

#### ~~Related ICS/IXIT statements~~

- ~~— Support of PS service — Yes/No~~
- ~~UE operation mode C — Yes/No~~
- ~~UE operation mode A — Yes/No~~
- ~~USIM removal possible without powering down — Yes/No~~
- ~~Switch off on button — Yes/No~~
- ~~Automatic PS attach procedure at switch on or power on — Yes/No~~

#### ~~Test procedure~~

~~The SS performs a detach with the cause value 'PS services not allowed'. The SS checks that the UE does not perform PS attach in another PLMN.~~

## Expected Sequence

| Step                                                                                                                                                      | Direction |    | Message            | Comments                                                                                                                                                                                                              |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                           | UE        | SS |                    |                                                                                                                                                                                                                       |
| 1                                                                                                                                                         |           | SS |                    | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note)                                |
| 2                                                                                                                                                         | UE        |    |                    | The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 22.                                                                                                                   |
| 3                                                                                                                                                         | UE        |    |                    | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                                                 |
| 4                                                                                                                                                         | →         |    | ATTACH REQUEST     | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                                                                         |
| 5                                                                                                                                                         | ←         |    | ATTACH ACCEPT      | Routing area identity = RAI-1<br>Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature                                                                                               |
| 6                                                                                                                                                         | →         |    | ATTACH COMPLETE    | Routing area identity = RAI-1                                                                                                                                                                                         |
| 7                                                                                                                                                         | ←         |    | DETACH REQUEST     | Detach type = 're-attach not required'                                                                                                                                                                                |
| 8                                                                                                                                                         | →         |    | DETACH ACCEPT      | Cause = 'PS services not allowed'                                                                                                                                                                                     |
| 9                                                                                                                                                         |           | SS |                    | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)                                |
| 10                                                                                                                                                        | UE        |    |                    | Cell B is preferred by the UE.                                                                                                                                                                                        |
| 11                                                                                                                                                        | UE        |    | Registration on CS | Step 11 is only performed for UE Operation Mode A.<br>See TS 34.108<br>This is applied only for UE in UE operation mode A.                                                                                            |
| 12                                                                                                                                                        |           |    |                    | Parameter mobile identity is IMSI.                                                                                                                                                                                    |
| 13                                                                                                                                                        | UE        |    |                    | The UE initiates an attach automatically (see ICS), by MMI or AT commands.                                                                                                                                            |
| 14                                                                                                                                                        | UE        |    |                    | No ATTACH REQUEST sent to the SS (SS waits 30 seconds).                                                                                                                                                               |
| 15                                                                                                                                                        | UE        |    |                    | If possible (see ICS) USIM removal is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.                                                                             |
| 16                                                                                                                                                        | →         |    | ATTACH REQUEST     | The UE gets the USIM replaced, is powered up or switched on and initiates an attach (see ICS).<br>Attach type = 'PS attach'                                                                                           |
| 17                                                                                                                                                        | ←         |    | ATTACH ACCEPT      | Mobile identity = IMSI<br>Attach result = 'PS only attached'                                                                                                                                                          |
| 18                                                                                                                                                        | →         |    | ATTACH COMPLETE    | Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                                                                                                      |
| 19                                                                                                                                                        | UE        |    |                    | Routing area identity = RAI-2                                                                                                                                                                                         |
| 20                                                                                                                                                        | →         |    | DETACH REQUEST     | The UE is switched off or power is removed (see ICS).<br>Message not sent if power is removed.                                                                                                                        |
| 21                                                                                                                                                        |           |    |                    | Detach type = 'power switched off, PS detach'                                                                                                                                                                         |
| 22                                                                                                                                                        | UE        |    |                    | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note)<br>The UE is set in UE operation mode A (see ICS) and the test is repeated from step 3 to step 18. |
| NOTE: The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                    |                                                                                                                                                                                                                       |

### Specific message contents

None.

### ~~12.3.2.2.5 Test requirements~~

~~At step4 and 15, when the UE is powered up or switched on, UE shall:~~

- ~~— initiate the PS attach procedure with the information elements specified in the above Expected Sequence.~~

~~At step8, when the UE receives the DETACH REQUEST message (Detach type = 're-attach not required', Cause = 'PS services not allowed') from SS, UE shall:~~

- ~~— send DETACH ACCEPT message.~~

~~At step13, UE shall:~~

- ~~— not perform PS attach procedure.~~

### ~~12.3.2.3 PS detach / IMSI detach / accepted~~

#### ~~12.3.2.3.1 Definition~~

#### ~~12.3.2.3.2 Conformance requirement~~

~~The UE detach the IMSI for PS services.~~

#### Reference

3GPP TS 24.008 clause 4.7.4.2.

#### ~~12.3.2.3.3 Test purpose~~

~~To test the behaviour of the UE for the detach procedure.~~

#### ~~12.3.2.3.4 Method of test~~

#### Initial condition

System Simulator:

- One cell operating in network operation mode I.

User Equipment:

- The UE has a valid IMSI.

#### Related ICS/IXIT statements

- Support of PS service — Yes/No
- UE operation mode A — Yes/No
- Switch off on button — Yes/No
- Automatic PS attach procedure at switch on or power on — Yes/No

#### Test procedure

The UE performs a combined PS attach procedure (for PS and non-PS services).

The SS sends a DETACH REQUEST message to the UE. The UE then performs an IMSI detach (detach for non-PS services).



The SS signal to the UE, but no response is received, as the signalling link is disconnected.

The UE attach for non-PS services by a routing area update procedure. Both PS and CS services are possible.

#### Expected Sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                              |
|------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                       |
| 1    | UE        |    |                                 | The UE is set in UE operation mode A (see ICS).                                                                                                                                                       |
| 2    | UE        |    |                                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                |
| 3    | →         |    | ATTACH REQUEST                  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                   |
| 4    | ←         |    | ATTACH ACCEPT                   | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = IMSI<br>Routing area identity = RAI-1 |
| 5    | →         |    | ATTACH COMPLETE                 |                                                                                                                                                                                                       |
| 6    | SS        |    |                                 | The SS initiates a detach for non-PS services.                                                                                                                                                        |
| 7    | ←         |    | DETACH REQUEST                  | Detach type = 'IMSI detach'                                                                                                                                                                           |
| 8    | →         |    | DETACH ACCEPT                   |                                                                                                                                                                                                       |
| 9    | UE        |    |                                 | The UE initiates an attach for non-PS services (see ICS).                                                                                                                                             |
| 10   | →         |    | ROUTING AREA UPDATE REQUEST     | Update type = 'Combined RA/LA updating with IMSI attach'<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                                                                                       |
| 11   | ←         |    | ROUTING AREA UPDATE ACCEPT      | TMSI status = no valid TMSI available<br>Update result = 'Combined RA/LA updating'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-1   |
| 12   | →         |    | ROUTING AREA UPDATE COMPLETE    |                                                                                                                                                                                                       |
| 13   | ←         |    | PAGING TYPE1                    | Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                                          |
| 14   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                       |
| 15   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                       |
| 16   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                       |
| 17   | →         |    | PAGING RESPONSE                 | Mobile identity = TMSI-1                                                                                                                                                                              |
| 18   | ←         |    | RRC CONNECTION RELEASE          | After sending of this message, the SS waits for disconnection of the CS signalling link.                                                                                                              |
| 19   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                       |
| 20   | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                                                                                                                                 |
| 21   | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach'                                                                                                |

#### Specific message contents

None.

#### 12.3.2.3.5 Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.

At step8, when the UE receives the DETACH REQUEST message with Detach-type = 'IMSI-detach', UE shall;

- send the DETACH ACCEPT message to SS.

At step10, after the completion of the detach procedure, UE shall;

- perform combined routing area updating procedure.

At step17, when the UE receives the paging message for CS domain, UE shall:

- respond to the paging message for CS domain by sending the PAGING RESPONSE message.

### ~~12.3.2.4 PS detach / re-attach requested / accepted~~

#### ~~12.3.2.4.1 Definition~~

#### ~~12.3.2.4.2 Conformance requirement~~

~~The UE shall deactivate the logical link and re-activate it.~~

#### ~~Reference~~

~~3GPP TS 24.008 clause 4.7.4.2.~~

#### ~~12.3.2.4.3 Test purpose~~

~~To test the behaviour of the UE for the detach procedure in case automatic re-attach.~~

#### ~~12.3.2.4.4 Method of test~~

#### ~~Initial condition~~

~~System Simulator:~~

- One cell in operating in network operation mode I.

~~User Equipment:~~

- The UE has a valid TMSI, P-TMSI, P-TMSI signature and RAI.

#### ~~Related ICS/IXIT statements~~

- Support of PS service—Yes/No
- UE operation mode A—Yes/No
- Switch-off on button—Yes/No
- Automatic PS attach procedure at switch-on or power-on—Yes/No

#### ~~Test procedure~~

~~The UE performs a combined PS attach procedure (for PS and non-PS services).~~

~~The SS sends a DETACH REQUEST message to the UE with cause re-attach. The UE then detaches for PS services. The UE automatically performs a new combined PS attach procedure (for PS and non-PS services) and PS and CS services are possible.~~

## Expected Sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                   |
|------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                            |
| 1    | →         | UE |                                 | The UE is set in UE operation mode A (see ICS).                                                                                                                                            |
| 2    | →         | UE |                                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                     |
| 3    | →         |    | ATTACH REQUEST                  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                              |
| 4    | ←         |    | ATTACH ACCEPT                   | Routing area identity = RAI-1<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-1<br>No new P-TMSI and P-TMSI signature assigned |
| 5    | →         |    | ATTACH COMPLETE                 |                                                                                                                                                                                            |
| 6    | →         | SS |                                 | The SS initiates a detach with re-attach.                                                                                                                                                  |
| 7    | ←         |    | DETACH REQUEST                  | Detach type = 're-attach required'                                                                                                                                                         |
| 8    | →         |    | DETACH ACCEPT                   |                                                                                                                                                                                            |
| 9    | →         |    | ATTACH REQUEST                  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = P-TMSI-1<br>Routing area identity = RAI-1                                                                                   |
| 10   | ←         |    | ATTACH ACCEPT                   | Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = TMSI-1<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                             |
| 11   | →         |    | ATTACH COMPLETE                 |                                                                                                                                                                                            |
| 12   | ←         |    | PAGING TYPE1                    | Mobile identity = P-TMSI-2<br>Paging order is for PS services.                                                                                                                             |
| 12a  | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                            |
| 12b  | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                            |
| 12c  | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                            |
| 13   | →         |    | SERVICE REQUEST                 | service type = "paging response"                                                                                                                                                           |
| 13a  | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                            |
| 13b  | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                            |
| 14   | ←         |    | PAGING TYPE1                    | Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                               |
| 15   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                            |
| 16   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                            |
| 17   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                            |
| 18   | →         |    | PAGING RESPONSE                 | Mobile identity = TMSI-1                                                                                                                                                                   |
| 19   | ←         |    | RRC CONNECTION RELEASE          | After sending of this message, the SS waits for disconnection of the CS signalling link.                                                                                                   |
| 20   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                            |
| 21   | →         | UE |                                 | The UE is switched off or power is removed (see ICS).                                                                                                                                      |
| 22   | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach'                                                                                     |

## Specific message contents

None.

## 12.3.2.4.5 ——— Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.

At step8, when the UE receives DETACH REQUEST message with Detach type = 're-attach required', UE shall:

- send DETACH ACCEPT message to SS.

At step9, after UE completed PS detach procedure with Detach type = 're-attach required', UE shall:

- initiate the combined PS attach procedure.

At step13, when the UE receives the paging message for PS domain, UE shall:

- respond to the paging message for PS domain by sending the SERVICE REQUEST message.

At step18, when the UE receives the paging message for CS domain, UE shall:

- respond to the paging message for CS domain by sending the PAGING RESPONSE message.

### 12.3.2.5 ~~PS detach / rejected / location area not allowed~~

#### 12.3.2.5.1 ~~Definition~~

#### 12.3.2.5.2 ~~Conformance requirement~~

- 1) ~~If the network performs a PS detach procedure with the cause 'location area not allowed' the User Equipment shall:~~
  - 1.1 ~~not perform combined PS attach when in the same location area.~~
  - 1.2 ~~delete the stored LAI, CKSN, TMSI, RAI, PS-CKSN, P-TMSI and P-TMSI signature.~~
  - 1.3 ~~store the LA in the 'forbidden location areas for regional provision of service'.~~
- 2) ~~If the network performs a PS detach procedure with the cause 'location area not allowed' the User Equipment shall:~~
  - 2.1 ~~perform combined PS attach when a new location area is entered.~~
  - 2.2 ~~delete the list of forbidden LAs when power is switched off.~~

#### Reference

3GPP TS 24.008 clauses 4.7.4.2.

#### 12.3.2.5.3 ~~Test purpose~~

~~To test the behaviour of the UE if the network orders the PS detach procedure with the cause 'Location Area not allowed'.~~

~~To test that the UE deletes the list of forbidden LAs when power is switched off.~~

#### 12.3.2.5.4 ~~Method of test~~

#### Initial condition

System Simulator:

- Three cells (not simultaneously activated), cell A in MCC2/MNC1/LAC1/RAC2 (RAI-2, Not HPLMN), cell B in MCC2/MNC1/LAC1/RAC2 (RAI-7, Not HPLMN), cell C in MCC2/MNC1/LAC2/RAC1 (RAI-6, Not HPLMN).  
All cells are operating in network operation mode I.

User Equipment:

~~—The UE has a valid IMSI.~~

#### ~~Related ICS/IXIT statements~~

~~—Support of PS service—Yes/No~~

~~UE operation mode A—Yes/No~~

~~Switch off on button Yes/No~~

~~Automatic PS attach procedure at switch on or power on—Yes/No~~

#### ~~Test procedure~~

~~The SS orders a PS detach with the cause value 'Location Area not allowed'. The SS checks that the UE does not perform combined PS attach while in the location area, performs PS attach when a new location area is entered and deletes the list of forbidden LAs when switched off. CS services are not possible unless an IMSI attach procedure is performed.~~

~~Different types of UE may use different methods to periodically clear the list of forbidden location areas (e.g. every day at 12am). If the list is cleared while the test is being run, it may be necessary to re-run the test.~~

## Expected Sequence

| Step | Direction |    | Message         | Comments                                                                                                                                                                                                                                 |
|------|-----------|----|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                 |                                                                                                                                                                                                                                          |
| 1    |           | SS |                 | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Off cell".<br>(see note) |
| 2    | UE        |    |                 | The UE is set in UE operation mode A (see ICS).                                                                                                                                                                                          |
| 3    | UE        |    |                 | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                                                                    |
| 4    | →         |    | ATTACH REQUEST  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                                                      |
| 5    | ←         |    | ATTACH ACCEPT   | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-2                                  |
| 6    | →         |    | ATTACH COMPLETE |                                                                                                                                                                                                                                          |
| 7    | ←         |    | DETACH REQUEST  | Detach type = 're-attach not required'<br>Cause 'Location Area not allowed'                                                                                                                                                              |
| 8    | →         |    | DETACH ACCEPT   |                                                                                                                                                                                                                                          |
| 9    | UE        |    |                 | No LOCATION UPDATING REQ with type 'IMSI attach' is sent to the SS<br>(SS waits 30 seconds).                                                                                                                                             |
| 10   | ←         |    | PAGING TYPE1    | Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                                                                             |
| 11   | UE        |    |                 | The UE shall not initiate an RRC connection.<br>This is checked during 3 seconds.                                                                                                                                                        |
| 12   | ←         |    | PAGING TYPE1    | Mobile identity = P-TMSI-1<br>Paging order is for PS services.                                                                                                                                                                           |
| 13   | UE        |    |                 | No response from the UE to the request.<br>This is checked for 10 seconds                                                                                                                                                                |
| 14   |           | SS |                 | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)                                                   |
| 15   | UE        |    |                 | Cell B is preferred by the UE.                                                                                                                                                                                                           |
| 16   | UE        |    |                 | The UE initiates an attach automatically, by MMI or by AT command.                                                                                                                                                                       |
| 17   | UE        |    |                 | No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds)                                                                                                                                                                                    |
| 18   | UE        |    |                 | No LOCATION UPDATING REQ with type 'IMSI attach' is sent to the SS<br>(SS waits 30 seconds).                                                                                                                                             |
| 19   | ←         |    | PAGING TYPE1    | Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                                                                             |
| 20   | UE        |    |                 | The UE shall not initiate an RRC connection.<br>This is checked during 3 seconds.                                                                                                                                                        |
| 21   | ←         |    | PAGING TYPE1    | Mobile identity = P-TMSI-1<br>Paging order is for PS services.                                                                                                                                                                           |
| 22   |           |    |                 | No response from the UE to the request.<br>This is checked for 10 seconds                                                                                                                                                                |
| 23   |           | SS |                 | The following messages are sent and shall be received on cell C.<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Serving cell".<br>(see note)                                                   |
| 24   | UE        |    |                 | Cell C is preferred by the UE.<br>Step 25 is only performed for non-auto-attach UE.                                                                                                                                                      |

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                                       |
|------|-----------|----|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                                |
| 25   | UE        |    | Registration on CS              | See TS34.108                                                                                                                                                                                                                                   |
| 26   | UE        |    |                                 | Parameter mobile identity is IMSI.                                                                                                                                                                                                             |
| 27   | →         |    | ATTACH REQUEST                  | The UE initiates an attach automatically (See ICS), by MMI or AT command.<br>Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI<br>TMSI status = no valid TMSI available                                                      |
| 28   | ←         |    | ATTACH ACCEPT                   | Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-6                                                                                 |
| 29   | →         |    | ATTACH COMPLETE                 |                                                                                                                                                                                                                                                |
| 30   | ←         |    | PAGING TYPE1                    | Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                                                                                   |
| 31   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                |
| 32   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                |
| 33   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                |
| 34   | →         |    | PAGING RESPONSE                 | Mobile identity = TMSI-1                                                                                                                                                                                                                       |
| 35   | ←         |    | RRC CONNECTION RELEASE          | After sending of this message, the SS waits for disconnection of the CS signalling link.                                                                                                                                                       |
| 36   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                |
| 37   | ←         |    | PAGING TYPE1                    | Mobile identity = P-TMSI-1<br>Paging order is for PS services.                                                                                                                                                                                 |
| 38   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                |
| 39   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                |
| 40   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                |
| 41   | →         |    | SERVICE REQUEST                 | service type = "paging response"                                                                                                                                                                                                               |
| 42   | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                |
| 43   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                |
| 44   | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                                                                                                                                                                          |
| 45   | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach'                                                                                                                                         |
| 46   | UE        |    |                                 | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell B to the "Serving cell".<br>Set the cell type of cell C to the "Off cell".<br>(see note)                                                         |
| 47   | UE        |    |                                 | Cell B is preferred by the UE.<br>The UE is powered up or switched on and initiates an attach (see ICS).<br>Step 48 is only performed for non-auto attach UE.                                                                                  |
| 48   | UE        |    | Registration on CS              | See TS34.108                                                                                                                                                                                                                                   |
| 49   | UE        |    |                                 | Parameter mobile identity is TMSI-1                                                                                                                                                                                                            |
| 50   | →         |    | ATTACH REQUEST                  | UE initiates an attach automatically (see ICS), by MMI or AT commands.<br>Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-6<br>TMSI status = valid TMSI available |
| 51   | ←         |    | ATTACH ACCEPT                   | Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Mobile identity = TMSI-2<br>Routing area identity = RAI-7                                                                                 |
| 52   | →         |    | ATTACH COMPLETE                 |                                                                                                                                                                                                                                                |
| 53   | ←         |    | PAGING TYPE1                    | Mobile identity = TMSI-2<br>Paging order is for CS services.                                                                                                                                                                                   |

| Step                                                                                                                                                        | Direction |    | Message                         | Comments                                                                                                                                                        |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                             | UE        | SS |                                 |                                                                                                                                                                 |
| 54                                                                                                                                                          | →         |    | RRC CONNECTION REQUEST          | Mobile identity = TMSI-2<br>After sending of this message, the SS waits for disconnection of the CS signalling link.                                            |
| 55                                                                                                                                                          | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                 |
| 56                                                                                                                                                          | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                 |
| 57                                                                                                                                                          | →         |    | PAGING RESPONSE                 |                                                                                                                                                                 |
| 58                                                                                                                                                          | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                 |
| 59                                                                                                                                                          | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                 |
| 60                                                                                                                                                          | ←         |    | PAGING TYPE1                    | Mobile identity = P-TMSI-2<br>Paging order is for PS services.                                                                                                  |
| 61                                                                                                                                                          | →         |    | RRC CONNECTION REQUEST          | service type = "paging response"                                                                                                                                |
| 62                                                                                                                                                          | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                 |
| 63                                                                                                                                                          | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                 |
| 64                                                                                                                                                          | →         |    | SERVICE REQUEST                 |                                                                                                                                                                 |
| 65                                                                                                                                                          | ←         |    | RRC CONNECTION RELEASE          | The UE is switched off or power is removed (see ICS).<br>Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach' |
| 66                                                                                                                                                          | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                 |
| 67                                                                                                                                                          | UE        |    |                                 |                                                                                                                                                                 |
| 68                                                                                                                                                          | →         |    | DETACH REQUEST                  |                                                                                                                                                                 |
| NOTE: — The definitions for “Off cell” and “Serving cell” are specified in TS34.108 clause 6.1 “Reference Radio Conditions for signalling test cases only”. |           |    |                                 |                                                                                                                                                                 |

#### Specific message contents

None.

#### 12.3.2.5.5 — Test requirements

At step4, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step8, when the UE receive the DETACH REQUEST message (Detach type = 're-attach not required', Cause = 'Location Area not allowed') from SS, UE shall:

- send the DETACH ACCEPT message.

UE shall perform the following action depending on UE location.

- 1) UE is in the same location area.

At step9 and 18, UE shall:

- not perform location updating procedure.

At step11 and 20, when the UE receives the paging message for CS domain, UE shall:

- not respond to the paging message for PS domain.

At step13 and 22, when the UE receives the paging message for PS domain, UE shall:

- not respond to the paging message for PS domain.

At step17, UE shall;

- not perform PS attach procedure.

- 2) UE is in the new location area.



At step27, UE shall;

— perform the combined PS attach procedure.

At step34, when the UE receives the paging message for CS domain with Mobile identity = IMSI, UE shall;

— respond to the paging message for CS domain by sending the PAGING RESPONSE message.

At step41, when the UE receives the paging message for PS domain with Mobile identity = P-TMSI-1, UE shall:

— respond to the paging message for PS domain by sending the SERVICE REQUEST message.

At step50, when the UE is powered up or switched on, UE shall:

— initiate the PS attach procedure with the information elements specified in the above Expected Sequence

At step57, when the UE receives the paging message for CS domain with Mobile identity = IMSI, UE shall;

— respond to the paging message for CS domain by sending the PAGING RESPONSE message.

At step64, when the UE receives the paging message for PS domain with Mobile identity = P-TMSI-1, UE shall:

— respond to the paging message for PS domain by sending the SERVICE REQUEST message.

### ~~12.3.2.6 PS detach / rejected / No Suitable Cells In Location Area~~

#### ~~12.3.2.6.1 Definition~~

#### ~~12.3.2.6.2 Conformance requirement~~

1. If the network performs a PS detach procedure with the cause 'No Suitable Cells In Location Area', the User Equipment shall:

1.1 delete the stored LAI, CKSN, TMSI, RAI, PS-CKSN, P-TMSI and P-TMSI signature.

1.2 store the LA in the 'forbidden location areas for roaming'.

#### Reference

3GPP TS 24.008 clauses 4.7.4.2.

#### ~~12.3.2.6.3 Test purpose~~

To test the behaviour of the UE if the network sends the DETACH REQUEST message with the cause 'No Suitable Cells In Location Area'.

#### ~~12.3.2.6.4 Method of test~~

#### Initial condition

##### System Simulator:

— Three cells, cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC2/RAC1 (RAI-3), cell C in MCC2/MNC1/LAC1/RAC1 (RAI-2)

— All three cells are operating in network operation mode II.

##### User Equipment:

— The UE has valid IMSI.

## Related ICS/IXIT statements

- Support of PS service—Yes/No
- UE operation mode A—Yes/No
- Switch off on button—Yes/No
- Automatic PS attach procedure at switch on or power on—Yes/No

## Test procedure

The SS sends a DETACH REQUEST message with the cause value 'No Suitable Cells In Location Area'. The SS checks that the UE shall not perform combined PS attach while in the same location area on the same PLMN. The SS checks that the UE shall perform PS attach when the UE enters a suitable cell in a different location area on the same PLMN.

## Expected Sequence

| Step                                                                                                                                                                     | Direction |    | Message         | Comments                                                                                                                                                                                                                                                                                 |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                          | UE        | SS |                 |                                                                                                                                                                                                                                                                                          |
| 1                                                                                                                                                                        | UE        | SS |                 | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>Set the cell type of cell C to the "Suitable neighbour cell".<br>(see note)<br>The SS configures power level of each Cell as follows:<br>Cell A > Cell B = Cell C |
| 2                                                                                                                                                                        | UE        |    |                 | The UE is set in UE operation mode A (see ICS).                                                                                                                                                                                                                                          |
| 3                                                                                                                                                                        | ->        |    | ATTACH REQUEST  | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.<br>Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                             |
| 4                                                                                                                                                                        | <-        |    | ATTACH ACCEPT   | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-1                                                                                  |
| 5                                                                                                                                                                        | ->        |    | ATTACH COMPLETE |                                                                                                                                                                                                                                                                                          |
| 6                                                                                                                                                                        | <-        |    | DETACH REQUEST  | Detach type = 're-attach not required'<br>Cause 'No Suitable Cells In Location Area'                                                                                                                                                                                                     |
| 7                                                                                                                                                                        | ->        |    | DETACH COMPLETE |                                                                                                                                                                                                                                                                                          |
| 8                                                                                                                                                                        | UE        |    |                 | The following message are sent and shall be received on cell B.                                                                                                                                                                                                                          |
| 9                                                                                                                                                                        | ->        |    | ATTACH REQUEST  | The UE initiates an attach automatically, by MMI or by AT command.<br>Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                                |
| 10                                                                                                                                                                       | <-        |    | ATTACH ACCEPT   | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Mobile identity = TMSI-2<br>Routing area identity = RAI-□                                                                                  |
| 11                                                                                                                                                                       | ->        |    | ATTACH COMPLETE |                                                                                                                                                                                                                                                                                          |
| 12                                                                                                                                                                       | UE        |    |                 | The UE is switched off or power is removed (see ICS).                                                                                                                                                                                                                                    |
| 13                                                                                                                                                                       | ->        |    | DETACH REQUEST  | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                                                                                                                   |
| NOTE:—The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                 |                                                                                                                                                                                                                                                                                          |

### Specific message contents

None.

#### 12.3.2.6.5 Test requirements

At step3, when the UE is powered up or switched on, UE shall:

—initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step9, when the UE enters a suitable cell in a different location area on the same PLMN, UE shall:

—perform the PS attach procedure.

## 12.4 Routing area updating procedure

This procedure is used to update the actual routing area of an UE in the network.

### 12.4.1 Normal routing area updating

The routing area updating procedure is a GMM procedure used by PS UEs of UE operation mode A or C that are IMSI attached for PS services only.

#### 12.4.1.1 Routing area updating / accepted

##### 12.4.1.1.1 Definition

##### 12.4.1.1.2 Conformance requirement

- 1) If the network accepts the routing area updating procedure and reallocates a P-TMSI, the UE shall acknowledge the new P-TMSI and continue communication with the new P-TMSI.
- 2) If the network accepts the routing area updating procedure from the UE without reallocation of the old P-TMSI, the UE shall continue communication with the old P-TMSI.

### Reference

3GPP TS 24.008 clause 4.7.5.1.

##### 12.4.1.1.3 Test purpose

To test the behaviour of the UE if the network accepts the routing area updating procedure.

The following cases are identified:

- 1) P-TMSI / P-TMSI signature is reallocated.
- 2) Old P-TMSI / P-TMSI signature is not changed.

##### 12.4.1.1.4 Method of test

### Initial condition

System Simulator:

- Two cells, cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4). Both cells are operating in network operation mode II.

User Equipment:

- The UE has a valid IMSI.

## Related ICS/IXIT statements

- Support of PS service—Yes/No  
 UE operation mode A—Yes/No  
 UE operation mode C—Yes/No  
 Switch off on button—Yes/No  
 Automatic PS attach procedure at switch on or power on—Yes/No

## Test procedure

- 1) The UE sends a ROUTING AREA UPDATE REQUEST message. The SS reallocates the P-TMSI and returns ROUTING AREA UPDATE ACCEPT message with a new P-TMSI. The UE acknowledge the new P-TMSI by sending ROUTING AREA UPDATE COMPLETE message. Further communication UE – SS is performed by the new P-TMSI. The UE will not answer signalling addressed to the old P-TMSI.
- 2) The UE sends a ROUTING AREA UPDATE REQUEST message. The SS accepts the P-TMSI and returns ROUTING AREA UPDATE ACCEPT message without any P-TMSI. Further communication UE – SS is performed by the P-TMSI.

## Expected Sequence

| Step | Direction |    | Message                      | Comments                                                                                                                                                                                              |
|------|-----------|----|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                              |                                                                                                                                                                                                       |
| 1    |           | SS |                              | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>(see note) |
| 2    | UE        |    |                              | The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 22.                                                                                                   |
| 3    | UE        |    |                              | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                |
| 4    | →         |    | ATTACH REQUEST               | Attach type = 'PS attach'                                                                                                                                                                             |
| 5    |           | ←  | ATTACH ACCEPT                | Mobile identity = IMSI<br>Attach result = 'PS only attached'                                                                                                                                          |
| 6    | →         |    | ATTACH COMPLETE              | Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                                                     |
| 7    |           | SS |                              | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Suitable neighbour cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note) |
| 8    | →         |    | ROUTING AREA UPDATE REQUEST  | Update type = 'RA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                                                    |
| 9    |           | ←  | ROUTING AREA UPDATE ACCEPT   | Update result = 'RA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-4                                                                                     |
| 10   | →         |    | ROUTING AREA UPDATE COMPLETE |                                                                                                                                                                                                       |
| 11   | ←         |    | GMM INFORMATION              | Message sent with P-TMSI-1                                                                                                                                                                            |
| 11b  | →         |    | GMM STATUS                   | Message sent in case the UE does not support reception of GMM information message<br>Cause #97                                                                                                        |
| 12   | ←         |    | PAGING TYPE1                 | Mobile identity = P-TMSI-2<br>PAGING TYPE1 (used for NW-mode II).<br>Paging order is for PS services.                                                                                                 |
| 13   | UE        |    |                              | No response from the UE to the request. This is checked for 10 seconds.                                                                                                                               |

| Step                                                                                                                                                                     | Direction |    | Message                         | Comments                                                                                                                                                                                              |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                          | UE        | SS |                                 |                                                                                                                                                                                                       |
| 14                                                                                                                                                                       |           | SS |                                 | The following messages are sent and shall be received on cell A:<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>(see note) |
| 15                                                                                                                                                                       | UE        |    |                                 | Cell A is preferred by the UE.                                                                                                                                                                        |
| 16                                                                                                                                                                       | →         |    | ROUTING AREA UPDATE REQUEST     | Update type = 'RA updating'<br>P-TMSI-1 signature<br>Routing area identity = RAI-4                                                                                                                    |
| 17                                                                                                                                                                       |           | ←  | ROUTING AREA UPDATE ACCEPT      | No new mobile identity assigned.<br>P-TMSI not included.<br>Update result = 'RA updated'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                       |
| 18                                                                                                                                                                       |           | ←  | PAGING TYPE1                    | Mobile identity = P-TMSI-1<br>Paging order is for PS services.<br>PAGING TYPE 1 (used for NW-mode II).                                                                                                |
| 18a                                                                                                                                                                      | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                       |
| 18b                                                                                                                                                                      | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                       |
| 18c                                                                                                                                                                      | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                       |
| 19                                                                                                                                                                       | →         |    | SERVICE REQUEST                 | service type = "paging response"                                                                                                                                                                      |
| 19a                                                                                                                                                                      | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                       |
| 19b                                                                                                                                                                      | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                       |
| 20                                                                                                                                                                       | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                                                                                                                                 |
| 21                                                                                                                                                                       | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                                |
| 22                                                                                                                                                                       | UE        |    |                                 | The UE is set in UE operation mode A (see ICS) and the test is repeated from step 3 to step 21.                                                                                                       |
| NOTE:—The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                                                                       |

### Specific message contents

None.

### 12.4.1.1.5 Test requirements

At step4, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step8, UE shall;

- initiate the routing area updating procedure with the information elements specified in the above Expected Sequence.

At step13, when the UE receives the paging message for PS domain with Mobile identity = P-TMSI-2, UE shall:

- not respond to the paging message for PS domain.

At step16, UE shall;

- initiate the routing area updating procedure with the information elements specified in the above Expected Sequence.

At step19, when the UE receives the paging message for PS domain with Mobile identity = P-TMSI-1, UE shall:

- respond to the paging message for PS domain by sending the SERVICE REQUEST message.

### ~~12.4.1.2 Routing area updating / rejected / IMSI invalid / illegal ME~~

#### ~~12.4.1.2.1 Definition~~

#### ~~12.4.1.2.2 Conformance requirement~~

- ~~1) If the network rejects a routing area updating procedure from the User Equipment with the cause 'Illegal ME', the User Equipment shall consider USIM invalid for PS services until power is switched off or USIM is removed.~~
- ~~2) If the network rejects a routing area updating procedure from the User Equipment with the cause 'Illegal ME', the User Equipment shall delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.~~

#### Reference

3GPP TS 24.008 clause 4.7.5.1.

#### ~~12.4.1.2.3 Test purpose~~

~~To test the behaviour of the UE if the network rejects the routing area updating procedure of the UE with the cause 'Illegal ME'.~~

#### ~~12.4.1.2.4 Method of test~~

#### Initial condition

System Simulator:

- ~~— Three cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4), cell C in MCC2/MNC1/LAC1/RAC1 (RAI-2).~~
- ~~All three cells are operating in network operation mode II (in case of UE operation mode A)~~

User Equipment:

- ~~— The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.~~

#### Related ICS/IXIT statements

- ~~— Support of PS service — Yes/No~~
- ~~UE operation mode C — Yes/No~~
- ~~UE operation mode A — Yes/No (only if mode C not supported)~~
- ~~USIM removal possible without powering down — Yes/No~~
- ~~Switch off on button — Yes/No~~
- ~~Automatic PS attach procedure at switch on or power on — Yes/No~~

#### Test procedure

~~The SS rejects a routing area updating with the cause value 'Illegal ME'. The SS checks that the UE does not perform PS attach in the same or another PLMN.~~

## Expected Sequence

| Step | Direction |    | Message                     | Comments                                                                                                                                                                                                            |
|------|-----------|----|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                                                                                                     |
| 1    | UE        |    |                             | The following messages are sent and shall be received on cell A.<br>The UE is set in UE operation mode C (see ICS).                                                                                                 |
| 2    |           | SS |                             | The SS is set in network operation mode II.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Off cell".<br>(see note) |
| 3    | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                                               |
| 4    | →         |    | ATTACH REQUEST              | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                                                                       |
| 5    |           | ←  | ATTACH ACCEPT               | Routing area identity = RAI-1<br>No new mobile identity assigned. P-TMSI and P-TMSI signature not included.<br>Attach result = 'PS only attached'<br>Routing area identity = RAI-1                                  |
| 6    |           | SS |                             | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)                              |
| 7    | UE        |    |                             | Cell B is preferred by the UE.                                                                                                                                                                                      |
| 8    | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'RA updating'                                                                                                                                                                                         |
| 9    |           | ←  | ROUTING AREA UPDATE REJECT  | Routing area identity = RAI-1<br>GMM cause = 'Illegal ME'                                                                                                                                                           |
| 10   |           | ←  | PAGING TYPE1                | Mobile identity = P-TMSI-1<br>PAGING TYPE1 (used for NW mode II).<br>Paging order is for PS services.                                                                                                               |
| 11   | UE        |    |                             | No response from the UE to the request. This is checked for 10 seconds.                                                                                                                                             |
| 12   |           | SS |                             | The following messages are sent and shall be received on cell C.<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Serving cell".<br>(see note)                              |
| 13   | UE        |    |                             | Cell C is preferred by the UE.                                                                                                                                                                                      |
| 14   | UE        |    |                             | No ATTACH REQUEST sent to the SS<br>(SS waits 30 seconds).                                                                                                                                                          |
| 15   | UE        |    |                             | If possible (see ICS) USIM removal is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.                                                                           |
| 16   | UE        |    |                             | The UE gets the USIM replaced, is powered up or switched on and initiates an attach (see ICS).                                                                                                                      |
| 16a  |           |    |                             | Step 16b is only performed by UE in operation mode A                                                                                                                                                                |
| 16b  | UE        |    | Registration on CS          | See TS 34.108<br>Parameter mobile identity is IMSI.                                                                                                                                                                 |
| 17   | →         |    | ATTACH REQUEST              | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                                                                                                                 |
| 18   |           | ←  | ATTACH ACCEPT               | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-2                                                                                             |
| 19   | →         |    | ATTACH COMPLETE             |                                                                                                                                                                                                                     |
| 20   | UE        |    |                             | The UE is switched off or power is removed (see ICS).                                                                                                                                                               |

|                                                                                                                                                           |   |                |                                                                                     |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|---|----------------|-------------------------------------------------------------------------------------|
| 21                                                                                                                                                        | → | DETACH REQUEST | Message not sent if power is removed. Detach type = 'power switched off, PS detach' |
| NOTE: The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |   |                |                                                                                     |

### Specific message contents

None.

#### 12.4.1.2.5 Test requirements

At step4, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step8, UE shall;

- initiate the routing area updating procedure with the information elements specified in the above Expected Sequence.

At step11, after the routing area updating procedure is rejected with GMM cause = 'Illegal ME', UE shall;

- not respond to the paging message for PS domain.

At step14, UE shall,

- not initiate PS attach procedure.

At step17, after the UE is powered up or USIM is replaced, UE shall;

- initiate the PS attach procedure.

#### 12.4.1.3 Routing area updating / rejected / UE identity cannot be derived by the network

##### 12.4.1.3.1 Definition

##### 12.4.1.3.2 Conformance requirement

If the network rejects a routing area updating procedure from the User Equipment with the cause 'UE identity cannot be derived by the network', the User Equipment shall delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.

Depending on the manufacturer the UE may or may not perform a PS attach procedure.

### Reference

3GPP TS 24.008 clause 4.7.5.1.

##### 12.4.1.3.3 Test purpose

To test the behaviour of the UE if the network rejects the routing area updating procedure of the UE with the cause 'UE identity cannot be derived by the network'.

##### 12.4.1.3.4 Method of test

### Initial condition

System Simulator:



- Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4).  
Both cells are operating in network operation mode II (in case of UE operation mode A).

#### User Equipment:

- The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

#### Related ICS/IXIT statements

- Support of PS service—Yes/No
- UE operation mode C—Yes/No
- UE operation mode A—Yes/No (only if mode C not supported)
- Automatic attach procedure when UE identity cannot be derived by the network—Yes/No
- Switch off on button—Yes/No
- Automatic PS attach procedure at switch on or power on—Yes/No

#### Test procedure

The SS rejects a normal routing area updating with the cause value 'UE identity cannot be derived by the network'. The UE detach locally. A new PS attach may be performed.

## Expected Sequence

| Step                                                                                                                                                        | Direction |    | Message                     | Comments                                                                                                                                                                                                                              |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                             | UE        | SS |                             |                                                                                                                                                                                                                                       |
| 1                                                                                                                                                           |           | SS |                             | The following messages are sent and shall be received on cell A:<br>The SS is set in network operation mode II.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note) |
| 2                                                                                                                                                           | UE        |    |                             | The UE is set in UE operation mode C (see ICS).                                                                                                                                                                                       |
| 3                                                                                                                                                           | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                                                                 |
| 4                                                                                                                                                           | →         |    | ATTACH REQUEST              | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                                                                                         |
| 5                                                                                                                                                           | ←         |    | ATTACH ACCEPT               | Routing area identity = RAI-1<br>Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature                                                                                                               |
| 6                                                                                                                                                           | →         |    | ATTACH COMPLETE             | Routing area identity = RAI-1                                                                                                                                                                                                         |
| 7                                                                                                                                                           |           | SS |                             | The following messages are sent and shall be received on cell B:<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)                                                |
| 8                                                                                                                                                           | UE        |    |                             | Cell B is preferred by the UE.                                                                                                                                                                                                        |
| 9                                                                                                                                                           | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'RA updating'<br>P-TMSI-2 signature                                                                                                                                                                                     |
| 10                                                                                                                                                          | ←         |    | ROUTING AREA UPDATE REJECT  | Routing area identity = RAI-1<br>GMM cause = 'UE identity cannot be derived by the network'                                                                                                                                           |
| 11                                                                                                                                                          | UE        |    |                             | If an automatic attach procedure by the UE is not possible when the UE identity cannot be derived by the network (see ICS) goto step 19.                                                                                              |
| 12                                                                                                                                                          | UE        |    |                             | An Automatic PS attach procedure is initiated (see ICS).                                                                                                                                                                              |
| 13                                                                                                                                                          | →         |    | ATTACH REQUEST              | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                                                                                                                                   |
| 14                                                                                                                                                          | ←         |    | ATTACH ACCEPT               | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                                                                                |
| 15                                                                                                                                                          | →         |    | ATTACH COMPLETE             | Routing area identity = RAI-4                                                                                                                                                                                                         |
| 16                                                                                                                                                          | UE        |    |                             | The UE is switched off or power is removed (see ICS).                                                                                                                                                                                 |
| 17                                                                                                                                                          | →         |    | DETACH REQUEST              | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                                                                |
| 18                                                                                                                                                          |           |    |                             | Stop the sequence                                                                                                                                                                                                                     |
| 19                                                                                                                                                          | ←         |    | PAGING TYPE1                | Mobile identity = P-TMSI-2<br>PAGING TYPE1 (used for NW-mode II).<br>Paging order is for PS services.                                                                                                                                 |
| 20                                                                                                                                                          | UE        |    |                             | No response from the UE to the request, as the UE has detached locally. This is checked for 10 seconds.                                                                                                                               |
| NOTE: — The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                             |                                                                                                                                                                                                                                       |

## Specific message contents

None.

#### ~~12.4.1.3.5 Test requirements~~

~~At step4, when the UE is powered up or switched on, UE shall:~~

- ~~— initiate the PS attach procedure with the information elements specified in the above Expected Sequence.~~

~~At step9, UE shall;~~

- ~~— initiate the routing area updating procedure with the information elements specified in the above Expected Sequence.~~

~~UE shall perform the following actions depending on the implementation of the UE.~~

~~Case 1) UE supports an Automatic PS attach procedure.~~

~~At step13, UE shall;~~

- ~~— initiate the PS attach procedure.~~

~~Case 2) UE does not support an Automatic PS attach procedure.~~

~~At step20, when the UE receives the paging message for PS domain, UE shall:~~

- ~~— not respond to the paging message for PS domain.~~

#### ~~12.4.1.4a Routing area updating / rejected / location area not allowed~~

##### ~~12.4.1.4a.1 Definition~~

##### ~~12.4.1.4a.2 Conformance requirement~~

- ~~1) If the network rejects a routing area updating procedure from the User Equipment with the cause 'location area not allowed' the User Equipment shall:~~

~~1.1 not perform PS attach when in the same location area.~~

~~1.2 delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.~~

~~1.3 store the LA in the 'forbidden location areas for regional provision of service'.~~

- ~~2) If the network rejects a routing area updating procedure from the User Equipment with the cause 'location area not allowed' the User Equipment shall:~~

~~2.1 perform PS attach when a new location area is entered.~~

~~2.2 delete the list of forbidden LAs after switch off (power off).~~

#### ~~Reference~~

~~3GPP TS 24.008 clauses 4.7.5.1.~~

##### ~~12.4.1.4a.3 Test purpose~~

~~To test the behaviour of the UE if the network rejects the routing area updating procedure of the UE with the cause 'Location Area not allowed'.~~

~~To test that the UE deletes the list of forbidden LAs when power is switched off.~~

##### ~~12.4.1.4a.4 Method of test~~

#### ~~Initial condition~~

~~System Simulator:~~

- Three cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1) , cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4), cell C in MCC1/MNC1/LAC2/RAC1 (RAI-3).
- All cells are operating in network operation mode II.

#### User Equipment:

- The UE has a valid IMSI.

#### Related ICS/IXIT statements

- Support of PS service—Yes/No
- UE operation mode A—Yes/No
- UE operation mode C—Yes/No
- USIM removal possible without powering down—Yes/No
- Switch off on button—Yes/No
- Automatic PS attach procedure at switch on or power on—Yes/No

#### Test procedure

The SS rejects a routing area updating with the cause value 'Location Area not allowed'. The SS checks that the UE does not perform PS attach while in the location area, performs PS attach when a new location area is entered and deletes the list of forbidden LAs when switched off.

Different types of UE may use different methods to periodically clear the list of forbidden location areas (e.g. every day at 12am). If the list is cleared while the test is being run, it may be necessary to re-run the test.

## Expected Sequence

| Step | Direction |    | Message                     | Comments                                                                                                                                                                                                                                 |
|------|-----------|----|-----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                                                                                                                          |
| 1    |           | SS |                             | The following messages are sent and shall be received on cell C.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Serving cell".<br>(see note) |
| 2    | UE        |    |                             | The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 33.                                                                                                                                      |
| 3    | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS). Cell C is preferred by the UE.                                                                                                                                    |
| 4    | →         |    | ATTACH REQUEST              | Attach type = 'PS attach'                                                                                                                                                                                                                |
| 5    | ←         |    | ATTACH ACCEPT               | Mobile identity = IMSI<br>Attach result = 'PS only attached'                                                                                                                                                                             |
| 6    | →         |    | ATTACH COMPLETE             | Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-3                                                                                                                                                        |
| 7    |           | SS |                             | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell B to the "Serving cell".<br>Set the cell type of cell C to the "Off cell".<br>(see note)                                                   |
| 8    |           | SS |                             | Cell B is preferred by the UE.                                                                                                                                                                                                           |
| 8a   |           |    |                             | The following step is only performed for UE Operation Mode A.                                                                                                                                                                            |
| 8b   | UE        |    | Registration on CS          | See TS34.108                                                                                                                                                                                                                             |
| 9    | →         |    | ROUTING AREA UPDATE REQUEST | Parameter mobile identity is IMSI<br>Update type = 'RA updating'                                                                                                                                                                         |
| 10   | ←         |    | ROUTING AREA UPDATE REJECT  | P-TMSI-1 signature<br>Routing area identity = RAI-3<br>GMM cause = 'Location Area not allowed'                                                                                                                                           |
| 11   | ←         |    | PAGING TYPE1                | Mobile identity = P-TMSI-1<br>PAGING TYPE1 (used for NW mode II).<br>Paging order is for PS services.                                                                                                                                    |
| 12   | UE        |    |                             | No response from the UE to the request. This is checked for 10 seconds.                                                                                                                                                                  |
| 13   |           | SS |                             | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note)                                                   |
| 14   | UE        |    |                             | Cell A is preferred by the UE.                                                                                                                                                                                                           |
| 15   | UE        |    |                             | No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds)                                                                                                                                                                                    |
| 16   |           | SS |                             | The following messages are sent and shall be received on cell C.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell C to the "Serving cell".<br>(see note)                                                   |
| 17   | UE        |    |                             | Cell C is preferred by the UE.                                                                                                                                                                                                           |
| 17a  |           |    |                             | The following step is only performed for UE Operation Mode A.                                                                                                                                                                            |
| 17b  | UE        |    | Registration on CS          | See TS34.108                                                                                                                                                                                                                             |
| 18   | →         |    | ATTACH REQUEST              | Parameter mobile identity is IMSI<br>Attach type = 'PS attach'                                                                                                                                                                           |
| 19   | ←         |    | ATTACH ACCEPT               | Mobile identity = IMSI<br>Attach result = 'PS only attached'                                                                                                                                                                             |
| 20   | →         |    | ATTACH COMPLETE             | Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-3                                                                                                                                                        |

| Step                                                                                                                                                        | Direction |    | Message                     | Comments                                                                                                                                                                               |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                             | UE        | SS |                             |                                                                                                                                                                                        |
| 21                                                                                                                                                          | UE        |    | DETACH REQUEST              | If possible (see ICS) USIM removal is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.                                              |
| 22                                                                                                                                                          | →         |    |                             | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                 |
| 23                                                                                                                                                          | UE        |    | ATTACH REQUEST              | The UE gets the USIM replaced, is powered up or switched on and initiates an attach (see ICS).<br>Attach type = 'PS attach'                                                            |
| 24                                                                                                                                                          | →         |    |                             | Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-3                                                                                                      |
| 25                                                                                                                                                          | ←         |    | ATTACH ACCEPT               | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-3                                                                |
| 26                                                                                                                                                          | →         |    | ATTACH COMPLETE             |                                                                                                                                                                                        |
| 27                                                                                                                                                          | SS        |    | Registration on CS          | The following messages are sent and shall be received on cell A:<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell C to the "Off cell".<br>(see note) |
| 28<br>28a                                                                                                                                                   |           |    |                             | Cell A is preferred by the UE.<br>The following step is only performed for UE Operation Mode A.                                                                                        |
| 28b                                                                                                                                                         | UE        |    | ROUTING AREA UPDATE REQUEST | See TS34.108<br>Parameter mobile identity is IMSI                                                                                                                                      |
| 29                                                                                                                                                          | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'RA updating'<br>P-TMSI-1 signature<br>Routing area identity = RAI-3                                                                                                     |
| 30                                                                                                                                                          | ←         |    | ROUTING AREA UPDATE ACCEPT  | No new mobile identity assigned. P-TMSI and P-TMSI signature not included. Update result = 'RA updated'                                                                                |
| 31                                                                                                                                                          | UE        |    | DETACH REQUEST              | Routing area identity = RAI-1<br>The UE is switched off or power is removed (see ICS).                                                                                                 |
| 32                                                                                                                                                          | →         |    |                             | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                 |
| 33<br>34                                                                                                                                                    | SS<br>UE  |    |                             | The SS is set in network operation mode II.<br>The UE is set in UE operation mode A (see ICS), cell A is switched off and the test is repeated from step 2 to step 32.                 |
| NOTE: — The definitions for “Off cell” and “Serving cell” are specified in TS34.108 clause 6.1 “Reference Radio Conditions for signalling test cases only”. |           |    |                             |                                                                                                                                                                                        |

### Specific message contents

None.

### 12.4.1.4a.5 Test requirements

At step4, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step9, UE shall:

- initiate the routing area updating procedure with the information elements specified in the above Expected Sequence.

At step12, when the UE receives the paging message for PS domain, UE shall:

- not respond to the paging message for PS domain.

At step12 and 15, when in the same location area, UE shall

- not perform PS attach procedure.

At step18, when a new location area is entered, UE shall

- perform the PS attach procedure.

At step24, when the USIM is replaced, UE shall;

- perform the PS attach procedure.

At step29, UE shall;

- initiate the routing area updating procedure with the information elements specified in the above Expected Sequence.

#### ~~12.4.1.4b Routing area updating / rejected / No Suitable Cells In Location Area~~

##### ~~12.4.1.4b.1 Definition~~

##### ~~12.4.1.4b.2 Conformance requirement~~

1) If the network rejects a routing area updating procedure from the User Equipment with the cause 'No Suitable Cells In Location Area', the User Equipment shall:

- 1.1 delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.
- 1.2 store the LA or the PLMN identity in the 'forbidden location areas for roaming'.
- 1.3 search for a suitable cell in a different location area on the same PLMN.

#### Reference

3GPP TS 24.008 clauses 4.7.5.1.

##### ~~12.4.1.4b.3 Test purpose~~

To test the behaviour of the UE if the network rejects the routing area updating procedure with the cause 'No Suitable Cells In Location Area'.

To test that the UE deletes the list of forbidden LAs when power is switched off.

##### ~~12.4.1.4b.4 Method of test~~

#### Initial condition

##### System Simulator:

- Four cells, cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC2/RAC1 (RAI-3), cell C in MCC2/MNC1/LAC1/RAC1 (RAI-2), cell D in MCC1/MNC1/LAC1/RAC2 (RAI-4);
- All three cells are operating in network operation mode II.

##### User Equipment:

- The UE has valid IMSI.

#### Related ICS/IXIT statements

- Support of PS service — Yes/No
- UE operation mode A — Yes/No
- USIM removal possible without powering down — Yes/No

Switch off on button — Yes/No

Automatic PS attach procedure at switch on or power on — Yes/No

### Test procedure

The SS rejects a routing area updating with the cause value 'No Suitable Cells In Location Area'. The SS checks that the UE shall perform PS attach procedure when the UE enters a suitable cell in a different location area on the same PLMN.

### Expected Sequence

| Step                                                                                                                                                                       | Direction |    | Message                     | Comments                                                                                                                                                                                                                                                                                                                                                                                    |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                            | UE        | SS |                             |                                                                                                                                                                                                                                                                                                                                                                                             |
| 1                                                                                                                                                                          |           | SS |                             | The following message are sent and shall be received on cell D:<br>Set the cell type of cell A to the "Suitable neighbour cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>Set the cell type of cell C to the "Suitable neighbour cell".<br>Set the cell type of cell D to the "Serving cell".                                                                    |
| 2                                                                                                                                                                          | UE        |    |                             | (see note)<br>The UE is powered up or switched on and initiates an attach (see ICS). Cell D is preferred by the UE.                                                                                                                                                                                                                                                                         |
| 3                                                                                                                                                                          | →         |    | ATTACH REQUEST              | Attach type = 'PS attach'                                                                                                                                                                                                                                                                                                                                                                   |
| 4                                                                                                                                                                          | ←         |    | ATTACH ACCEPT               | Mobile identity = IMSI<br>Attach result = 'PS only attached'                                                                                                                                                                                                                                                                                                                                |
| 5                                                                                                                                                                          | →         |    | ATTACH COMPLETE             | Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-4                                                                                                                                                                                                                                                                                                           |
| 6                                                                                                                                                                          |           | SS |                             | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>Set the cell type of cell C to the "Suitable neighbour cell".<br>Set the cell type of cell D to the "Suitable neighbour cell".<br>(see note)<br>The SS configures power level of each Cell as follows:<br>Cell A > Cell B = Cell C<br>Cell A is preferred by the UE. |
| 7                                                                                                                                                                          | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'RA updating'                                                                                                                                                                                                                                                                                                                                                                 |
| 8                                                                                                                                                                          | ←         |    | ROUTING AREA UPDATE REJECT  | P-TMSI-1 signature<br>Routing area identity = RAI-4<br>GMM cause = 'No Suitable Cells In Location Area'                                                                                                                                                                                                                                                                                     |
| 9                                                                                                                                                                          | →         |    | ATTACH REQUEST              | The following message are sent and shall be received on cell D.<br>Attach type = 'PS attach'                                                                                                                                                                                                                                                                                                |
| 10                                                                                                                                                                         | ←         |    | ATTACH ACCEPT               | Mobile identity = IMSI<br>Attach result = 'PS only attached'                                                                                                                                                                                                                                                                                                                                |
| 11                                                                                                                                                                         | →         |    | ATTACH COMPLETE             | Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-3                                                                                                                                                                                                                                                                                                           |
| 12                                                                                                                                                                         | →         |    | DETACH REQUEST              | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                                                                                                                                                                                                                      |
| NOTE: — The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                             |                                                                                                                                                                                                                                                                                                                                                                                             |



### Specific message contents

None.

#### 12.4.1.4b.5 ——— Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step7, UE shall;

- initiate the routing area updating procedure.

At step9, when the UE enters a suitable cell in a different location area on the same PLMN, UE shall:

- perform the PS attach procedure.

#### 12.4.1.5 ——— Routing area updating / abnormal cases / attempt counter check / miscellaneous reject causes

##### 12.4.1.5.1 ——— Definition

##### 12.4.1.5.2 ——— Conformance requirement

When a routing area updating procedure is rejected with the attempt counter less than five, the UE shall repeat the routing area updating procedure after T3330 timeout.

When a T3330 timeout has occurred during a routing area updating procedure with the attempt counter five, the UE shall start timer T3302.

When the T3302 expire, a new routing area updating procedure shall be initiated.

### Reference

3GPP TS 24.008 clause 4.7.5.1.

##### 12.4.1.5.3 ——— Test purpose

To test the behaviour of the UE with respect to the attempt counter.

##### 12.4.1.5.4 ——— Method of test

### Initial condition

System Simulator:

- Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4). The ATT-flag shall indicate that the MS should use IMSI attach/detach procedures.  
Both cells are operating in network operation mode II (in case of UE operation mode A).

User Equipment:

- The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

### Related ICS/IXIT statements

- Support of PS service — Yes/No
- UE operation mode C — Yes/No
- UE operation mode A — Yes/No (only if mode C not supported)

Switch off on button — Yes/No

Automatic PS attach procedure at switch on or power on — Yes/No

### Test procedure

The UE initiates a routing area updating procedure (attempt counter zero).

The SS rejects the routing area updating procedure with a GMM cause 'congestion' code.

The UE initiates a new routing area updating procedure (attempt counter one) after T3311 expires.

The SS rejects the routing area updating procedure with a GMM cause 'congestion' code.

The UE initiates a new routing area updating procedure (attempt counter two) after T3311 expires.

The SS rejects the routing area updating procedure with a GMM cause 'congestion' code.

The UE initiates a new routing area updating procedure (attempt counter three) after T3311 expires.

The SS rejects the routing area updating procedure with a GMM cause 'congestion' code.

The UE initiates a new routing area updating procedure (attempt counter four) after T3311 expires.

The SS rejects the routing area updating procedure with a GMM cause 'congestion' code.

The UE initiates a new routing area updating procedure with attempt counter five (after T3311 expires).

The SS rejects the routing area updating procedure with a GMM cause 'congestion' code.

The UE shall not perform a new successful routing area updating procedure after T3311 seconds.

The UE initiates a routing area updating procedure with attempt counter zero after T3302 expires with the stored P-TMSI, P-TMSI signature, PS-CKSN and RAI.

T3302; set to 12 minutes.

T3330; set to 15 seconds.

T3311; set to 15 seconds.

## Expected Sequence

| Step | Direction |    | Message                     | Comments                                                                                              |
|------|-----------|----|-----------------------------|-------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                       |
| 1    | SS        |    |                             | The following messages are sent and shall be received on cell A.                                      |
| 2    | UE        |    |                             | The UE is set in UE operation mode C (see ICS).                                                       |
| 2a   | SS        |    |                             | The SS is set in network operation mode II.                                                           |
| 3    | UE        |    |                             | Set the cell type of cell A to the "Serving cell".                                                    |
| 4    | UE        |    |                             | Set the cell type of cell B to the "Off cell".                                                        |
| 5    | UE        |    |                             | (see note)                                                                                            |
| 6    | UE        |    | Registration on CS          | See TS 34.108                                                                                         |
| 7    | UE        |    |                             | This step is applied only for UE in UE operation mode A.                                              |
| 8    | UE        |    |                             | Parameter mobile identity is TMSI.                                                                    |
| 9    | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE. |
| 10   | →         |    | ATTACH REQUEST              | Attach type = 'PS attach'                                                                             |
| 11   |           |    |                             | Mobile identity = P-TMSI-1                                                                            |
| 12   |           |    |                             | P-TMSI-1 signature                                                                                    |
| 13   |           |    |                             | Routing area identity = RAI-1                                                                         |
| 14   | ←         |    | ATTACH ACCEPT               | No new mobile identity assigned.                                                                      |
| 15   |           |    |                             | P-TMSI not included.                                                                                  |
| 16   |           |    |                             | Attach result = 'PS only attached'                                                                    |
| 17   |           |    |                             | P-TMSI-2 signature                                                                                    |
| 18   |           |    |                             | Routing area identity = RAI-1                                                                         |
| 19   | SS        |    |                             | The following messages are sent and shall be received on cell B.                                      |
| 20   | SS        |    |                             | Set the cell type of cell A to the "Off cell".                                                        |
| 21   | SS        |    |                             | Set the cell type of cell B to the "Serving cell".                                                    |
| 22   | SS        |    |                             | (see note)                                                                                            |
| 23   | SS        |    |                             | Cell B is preferred by the UE.                                                                        |
| 24   | →         |    | ROUTING-AREA UPDATE REQUEST | Update type = 'RA updating'                                                                           |
| 25   |           |    |                             | P-TMSI-2 signature                                                                                    |
| 26   |           |    |                             | Routing area identity = RAI-1                                                                         |
| 27   | ←         |    | ROUTING-AREA UPDATE REJECT  | GMM cause = 'Congestion'                                                                              |
| 28   | SS        |    |                             | The SS verifies that the time between the routing area updating requests is 15 seconds                |
| 29   | →         |    | ROUTING-AREA UPDATE REQUEST | Update type = 'RA updating'                                                                           |
| 30   |           |    |                             | P-TMSI-2 signature                                                                                    |
| 31   |           |    |                             | Routing area identity = RAI-1                                                                         |
| 32   | ←         |    | ROUTING-AREA UPDATE REJECT  | GMM cause = 'Congestion'                                                                              |
| 33   | SS        |    |                             | The SS verifies that the time between the routing area updating requests is 15 seconds                |
| 34   | →         |    | ROUTING-AREA UPDATE REQUEST | Update type = 'RA updating'                                                                           |
| 35   |           |    |                             | P-TMSI-2 signature                                                                                    |
| 36   |           |    |                             | Routing area identity = RAI-1                                                                         |
| 37   | ←         |    | ROUTING-AREA UPDATE REJECT  | GMM cause = 'Congestion'                                                                              |
| 38   | SS        |    |                             | The SS verifies that the time between the routing area updating requests is 15 seconds                |
| 39   | →         |    | ROUTING-AREA UPDATE REQUEST | Update type = 'RA updating'                                                                           |
| 40   |           |    |                             | P-TMSI-2 signature                                                                                    |
| 41   |           |    |                             | Routing area identity = RAI-1                                                                         |
| 42   | ←         |    | ROUTING-AREA UPDATE REJECT  | GMM cause = 'Congestion'                                                                              |
| 43   | SS        |    |                             | The SS verifies that the time between the routing area updating requests is 15 seconds                |
| 44   | →         |    | ROUTING-AREA UPDATE REQUEST | Update type = 'RA updating'                                                                           |
| 45   |           |    |                             | P-TMSI-2 signature                                                                                    |
| 46   |           |    |                             | Routing area identity = RAI-1                                                                         |

| Step                                                                                                                                                      | Direction |    | Message                      | Comments                                                                                                                                                                  |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                           | UE        | SS |                              |                                                                                                                                                                           |
| 21                                                                                                                                                        | ←         |    | ROUTING AREA UPDATE REJECT   | GMM-cause = 'Congestion'                                                                                                                                                  |
| 22                                                                                                                                                        |           | SS |                              | The SS verifies that the UE does not attempt to attach for 10 minutes.                                                                                                    |
| 23                                                                                                                                                        |           | SS |                              | The SS shall release the PS signalling connection.                                                                                                                        |
| 23a                                                                                                                                                       | UE        |    | Registration on CS           | See TS 34.108<br>This step is applied only for UE in UE operation mode A.<br>Parameter mobile identity is TMSI.                                                           |
| 24                                                                                                                                                        | →         |    | ROUTING AREA UPDATE REQUEST  | Update type = 'RA updating'                                                                                                                                               |
| 25                                                                                                                                                        | ←         |    | ROUTING AREA UPDATE ACCEPT   | P-TMSI-2 signature<br>Routing area identity = RAI-1<br>Update result = 'RA updated'<br>Mobile identity = P-TMSI-2<br>P-TMSI-3 signature<br>Routing area identity = RAI-4  |
| 26                                                                                                                                                        | →         |    | ROUTING AREA UPDATE COMPLETE |                                                                                                                                                                           |
| 27                                                                                                                                                        | UE        |    |                              | The UE is switched off or power is removed (see ICS).                                                                                                                     |
| 28                                                                                                                                                        | →         |    | DETACH REQUEST               | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                    |
| 29                                                                                                                                                        | →         |    | IMSI-DETACH INDICATION       | This step is only performed for UE Operation Mode A.<br>MS establish a RRC connection on lower layers to perform an IMSI detach.<br>Message not sent if power is removed. |
| NOTE: The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                              |                                                                                                                                                                           |

#### Specific message contents

None.

#### 12.4.1.5.5 Test requirements

At step4, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step8, UE shall:

- perform the routing area updating procedure.

UE shall perform the following actions depending on the conditions described below.

- Case 1) At step11, 14, 17 and 20, a routing area updating procedure is rejected from SS with the attempt counter less than five,
  - UE shall:
    - repeat the routing area updating procedure after T3330 timeout
- Case2) At step22 a routing area updating procedure is rejected from SS with the attempt counter five
  - At step22, UE shall:
    - not initiate a routing area updating procedure.
- Case3) At step24, the T3302 expires
  - UE shall:

— initiate the new routing area updating procedure

#### ~~12.4.1.6 Routing area updating / abnormal cases / change of cell into new routing area~~

##### ~~12.4.1.6.1 Definition~~

##### ~~12.4.1.6.2 Conformance requirement~~

~~When a change of cell into a new routing area is performed before the routing area updating procedure is finished, the UE shall abort the routing area updating procedure and re-initiate it in the new routing area.~~

#### ~~Reference~~

~~3GPP TS 24.008 clause 4.7.5.1.~~

##### ~~12.4.1.6.3 Test purpose~~

~~To test the behaviour of the UE in case of procedure collision.~~

##### ~~12.4.1.6.4 Method of test~~

#### ~~Initial condition~~

##### ~~System Simulator:~~

- ~~— Three cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4) and cell C in MCC1/MNC1/LAC1/RAC3 (RAI-5).~~
- ~~All cells are operating in network operation mode II (in case of UE operation mode A).~~

##### ~~User Equipment:~~

- ~~— The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.~~

#### ~~Related ICS/IXIT statements~~

- ~~— Support of PS service — Yes/No~~
- ~~UE operation mode C — Yes/No~~
- ~~UE operation mode A — Yes/No~~
- ~~Switch off on button — Yes/No~~
- ~~Automatic PS attach procedure at switch on or power on — Yes/No~~

#### ~~Test procedure~~

~~The UE initiates a routing area updating procedure. The ROUTING AREA UPDATE ACCEPT message is delayed from the SS. The UE performs a cell update into a new routing area. The UE shall re-initiate a routing area updating procedure in the new routing area.~~

## Expected Sequence

| Step                                                                                                                                                        | Direction |    | Message                     | Comments                                                                                                                                                                               |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                             | UE        | SS |                             |                                                                                                                                                                                        |
| 1                                                                                                                                                           | SS        |    | ATTACH REQUEST              | The following messages are sent and shall be received on cell A.<br>The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 18.                |
| 2                                                                                                                                                           | UE        |    |                             | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Off cell".<br>(see note)                   |
| 3                                                                                                                                                           | SS        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                  |
| 4                                                                                                                                                           | UE        |    |                             | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                                          |
| 5                                                                                                                                                           | SS        |    |                             | Routing area identity = RAI-1<br>Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature                                                                |
| 6                                                                                                                                                           | UE        |    |                             | Routing area identity = RAI-1                                                                                                                                                          |
| 7                                                                                                                                                           | SS        |    | ROUTING AREA UPDATE REQUEST | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note) |
| 8                                                                                                                                                           | UE        |    |                             | Cell B is preferred by the UE.                                                                                                                                                         |
| 9                                                                                                                                                           | SS        |    |                             | Update type = 'RA updating'<br>P-TMSI-2 signature                                                                                                                                      |
| 10                                                                                                                                                          | UE        |    |                             | Routing area identity = RAI-1<br>No response to the ROUTING AREA UPDATE REQUEST message is given by the SS                                                                             |
| 11                                                                                                                                                          | SS        |    | ROUTING AREA UPDATE REQUEST | The following messages are sent and shall be received on cell C.<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Serving cell".<br>(see note) |
| 12                                                                                                                                                          | UE        |    |                             | Cell C is preferred by the UE.                                                                                                                                                         |
| 13                                                                                                                                                          | SS        |    |                             | Update type = 'RA updating'<br>P-TMSI-2 signature                                                                                                                                      |
| 14                                                                                                                                                          | UE        |    |                             | Routing area identity = RAI-1<br>Update result = 'RA updated'<br>Mobile identity = P-TMSI-2<br>P-TMSI-3 signature                                                                      |
| 15                                                                                                                                                          | SS        |    |                             | Routing area identity = RAI-5                                                                                                                                                          |
| 16                                                                                                                                                          | UE        |    |                             |                                                                                                                                                                                        |
| 17                                                                                                                                                          | SS        |    |                             |                                                                                                                                                                                        |
| 18                                                                                                                                                          | SS        |    | DETACH REQUEST              | The UE is switched off or power is removed (see ICS).<br>Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                        |
| 19                                                                                                                                                          | UE        |    |                             |                                                                                                                                                                                        |
| NOTE: — The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                             |                                                                                                                                                                                        |

## Specific message contents

None.

#### 12.4.1.6.5 ~~Test requirements~~

~~At step4, when the UE is powered up or switched on, UE shall:~~

- ~~—initiate the PS attach procedure with the information elements specified in the above Expected Sequence.~~

~~At step9, UE shall:~~

- ~~—initiate the routing area update procedure.~~

~~At step13, when change of cell into a new routing area is performed before the routing area updating procedure is finished, UE shall:~~

- ~~—abort the routing area updating procedure.~~
- ~~—re-initiate new routing area updating procedure in the new routing area.~~

#### ~~12.4.1.7 Routing area updating / abnormal cases / change of cell during routing area updating procedure~~

##### ~~12.4.1.7.1 Definition~~

##### ~~12.4.1.7.2 Conformance requirement~~

~~When a change of cell within a new routing area is performed before the routing area updating procedure is finished, the UE shall perform the cell update before the routing area updating procedure is finished.~~

#### ~~Reference~~

~~3GPP TS 24.008 clause 4.7.5.1.~~

##### ~~12.4.1.7.3 Test purpose~~

~~To test the behaviour of the UE in case of procedure collision.~~

##### ~~12.4.1.7.4 Method of test~~

#### ~~Initial condition~~

~~System Simulator:~~

- ~~—Three cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4) and cell C in MCC1/MNC1/LAC1/RAC2 (RAI-4). All three cells are operating in network operation mode II.~~

~~User Equipment:~~

- ~~—The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.~~

#### ~~Related ICS/IXIT statements~~

- ~~—Support of PS service—Yes/No~~
- ~~UE operation mode C—Yes/No~~
- ~~UE operation mode A—Yes/No~~
- ~~Switch off on button—Yes/No~~
- ~~Automatic PS attach procedure at switch on or power on—Yes/No~~

#### ~~Test procedure~~

~~The UE initiates a routing area updating procedure. The ROUTING AREA UPDATE ACCEPT message is delayed from the SS. The UE performs a cell update within the routing area. The UE then waits for the ROUTING AREA UPDATE ACCEPT message.~~

## Expected Sequence

| Step                                                                                                                                                      | Direction |    | Message                      | Comments                                                                                                                                                                                                                                                                      |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                           | UE        | SS |                              |                                                                                                                                                                                                                                                                               |
| 1                                                                                                                                                         | SS        |    |                              | The following messages are sent and shall be received on cell A.                                                                                                                                                                                                              |
| 2                                                                                                                                                         | UE        |    |                              | The UE is set in UE operation mode C (see ICS).                                                                                                                                                                                                                               |
| 3                                                                                                                                                         | SS        |    |                              | The SS is set in network operation mode II.                                                                                                                                                                                                                                   |
| 4                                                                                                                                                         | →         |    | ATTACH REQUEST               | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Off cell".<br>(see note)<br>The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE. |
| 5                                                                                                                                                         | ←         |    | ATTACH ACCEPT                | Attach result = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1<br>No new mobile identity assigned.<br>P-TMSI not included.<br>Attach result = 'PS only attached'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1     |
| 6                                                                                                                                                         | SS        |    |                              | The following messages are sent and shall be received on cell B.                                                                                                                                                                                                              |
| 7                                                                                                                                                         | SS        |    |                              | Set the cell type of cell A to the "Off cell".                                                                                                                                                                                                                                |
| 8                                                                                                                                                         | →         |    | ROUTING AREA UPDATE REQUEST  | Set the cell type of cell B to the "Serving cell".<br>(see note)<br>Cell B is preferred by the UE.                                                                                                                                                                            |
| 9                                                                                                                                                         | SS        |    |                              | Update type = 'RA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>No response to the ROUTING AREA UPDATE REQUEST message is given by the SS                                                                                                               |
| 10                                                                                                                                                        | SS        |    |                              | The following messages are sent and shall be received on cell C.                                                                                                                                                                                                              |
| 11                                                                                                                                                        | SS        |    |                              | Set the cell type of cell B to the "Off cell".                                                                                                                                                                                                                                |
| 12a                                                                                                                                                       | →         |    | CELL UPDATE                  | Set the cell type of cell C to the "Serving cell".<br>(see note)<br>Cell C is preferred by the UE.                                                                                                                                                                            |
| 12b                                                                                                                                                       | ←         |    | CELL UPDATE CONFIRM          | Cell update cause = 'cell reselection'                                                                                                                                                                                                                                        |
| 13                                                                                                                                                        | ←         |    | ROUTING AREA UPDATE ACCEPT   | Update result = 'RA updated'<br>Mobile identity = P-TMSI-2<br>P-TMSI-3 signature<br>Routing area identity = RAI-4                                                                                                                                                             |
| 14                                                                                                                                                        | →         |    | ROUTING AREA UPDATE COMPLETE |                                                                                                                                                                                                                                                                               |
| 15                                                                                                                                                        | UE        |    |                              | The UE is switched off or power is removed (see ICS).                                                                                                                                                                                                                         |
| 16                                                                                                                                                        | →         |    | DETACH REQUEST               | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                                                                                                        |
| NOTE: The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                              |                                                                                                                                                                                                                                                                               |

## Specific message contents

None.

## 12.4.1.7.5 Test requirements

At step4, when the UE is powered up or switched on, UE shall:



- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step8, UE shall:

- initiate routing area update procedure.

At step12a, when a change of cell within a new routing area is performed, UE shall:

- perform the cell update before the routing area updating procedure is finished.

#### ~~12.4.1.8 Routing area updating / abnormal cases / P-TMSI reallocation procedure collision~~

##### ~~12.4.1.8.1 Definition~~

##### ~~12.4.1.8.2 Conformance requirement~~

When a P-TMSI REALLOCATION COMMAND message is received by the UE while waiting for a ROUTING AREA UPDATE ACCEPT message, the UE shall ignore the P-TMSI reallocation procedure and continue with the routing area updating procedure.

#### Reference

3GPP TS 24.008 clause 4.7.5.1.

##### ~~12.4.1.8.3 Test purpose~~

To test the behaviour of the UE in case of procedure collision.

##### ~~12.4.1.8.4 Method of test~~

#### ~~Initial condition~~

System Simulator:

- Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1) and cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4).  
Both cells are operating in network operation mode II (in case of UE operation mode A).

User Equipment:

- The UE has a valid IMSI.

#### Related ICS/IXIT statements

- Support of PS service—Yes/No
- UE operation mode C—Yes/No
- UE operation mode A—Yes/No (only if mode C not supported)
- Switch off on button—Yes/No
- Automatic PS attach procedure at switch on or power on—Yes/No

#### Test procedure

The UE initiates a routing area updating procedure. The SS does not answer the routing area updating procedure, but initiates a P-TMSI reallocation procedure. The UE shall ignore the P-TMSI reallocation procedure and continue with the routing area updating procedure.

## Expected Sequence

| Step                                                                                                                                                      | Direction |    | Message                      | Comments                                                                                                                |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|------------------------------|-------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                           | UE        | SS |                              |                                                                                                                         |
| 1                                                                                                                                                         | SS        |    |                              | The following messages are sent and shall be received on cell A.                                                        |
| 2                                                                                                                                                         | UE        |    |                              | The UE is set in UE operation mode C (see ICS).                                                                         |
| 3                                                                                                                                                         | SS        |    |                              | The SS is set in network operation mode II.                                                                             |
| 4                                                                                                                                                         | SS        |    |                              | Set the cell type of cell A to the "Serving cell".                                                                      |
| 5                                                                                                                                                         | SS        |    |                              | Set the cell type of cell B to the "Off cell". (see note)                                                               |
| 6                                                                                                                                                         | UE        |    |                              | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                   |
| 7                                                                                                                                                         | →         |    | ATTACH REQUEST               | Attach result = 'PS attach'<br>Mobile identity = IMSI                                                                   |
| 8                                                                                                                                                         | ←         |    | ATTACH ACCEPT                | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1 |
| 9                                                                                                                                                         | →         |    | ATTACH COMPLETE              |                                                                                                                         |
| 10                                                                                                                                                        | SS        |    |                              | The following messages are sent and shall be received on cell B.                                                        |
| 11                                                                                                                                                        | SS        |    |                              | Set the cell type of cell A to the "Off cell".                                                                          |
| 12                                                                                                                                                        | SS        |    |                              | Set the cell type of cell B to the "Serving cell". (see note)                                                           |
| 13                                                                                                                                                        | SS        |    |                              | Cell B is preferred by the UE.                                                                                          |
| 14                                                                                                                                                        | →         |    | ROUTING AREA UPDATE REQUEST  | Update type = 'RA updating'<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                                      |
| 15                                                                                                                                                        | ←         |    | P-TMSI REALLOCATION COMMAND  | Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                                       |
| 16                                                                                                                                                        | UE        |    |                              | The UE ignores the P-TMSI reallocation command.                                                                         |
| 17                                                                                                                                                        | ←         |    | ROUTING AREA UPDATE ACCEPT   | Update result = 'RA updated'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-4       |
| 18                                                                                                                                                        | →         |    | ROUTING AREA UPDATE COMPLETE |                                                                                                                         |
| 19                                                                                                                                                        | UE        |    |                              | The UE is switched off or power is removed (see ICS).                                                                   |
| 20                                                                                                                                                        | →         |    | DETACH REQUEST               | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                  |
| NOTE: The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                              |                                                                                                                         |

## Specific message contents

None.

## 12.4.1.8.5 Test requirements

At step4, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step9, UE shall:

- initiate the routing area updating procedure.

At step11, when a P-TMSI REALLOCATION COMMAND message is received from SS while waiting for a ROUTING AREA UPDATE ACCEPT message, UE shall:

- ~~— ignore the P-TMSI reallocation procedure.~~
- ~~— continue with the routing area updating procedure.~~

## ~~12.4.2 Combined routing area updating~~

The combined routing area updating procedure is a GMM procedure used by PS UEs of UE operation mode A that are IMSI attached for PS and non-PS services. In order to use the combined routing area updating procedure, the network must operate in network operation mode I.

### ~~12.4.2.1 Combined routing area updating / combined RA/LA accepted~~

#### ~~12.4.2.1.1 Definition~~

#### ~~12.4.2.1.2 Conformance requirement~~

- ~~1) If the network accepts the combined routing area updating procedure and reallocates a P-TMSI, the UE shall acknowledge the new P-TMSI and continue communication with the new P-TMSI.~~
- ~~2) If the network accepts the combined routing area updating procedure from the UE without reallocation of the old P-TMSI, the UE shall continue communication with the old P-TMSI.~~

#### Reference

3GPP TS 24.008 clause 4.7.5.2.

#### ~~12.4.2.1.3 Test purpose~~

To test the behaviour of the UE if the network accepts the combined routing area updating procedure.

The following cases are identified:

- ~~1) P-TMSI / P-TMSI signature is reallocated.~~
- ~~2) Old P-TMSI / P-TMSI signature is not changed.~~
- ~~3) Mobile terminating CS call is allowed with IMSI.~~
- ~~4) Mobile terminating CS call is allowed with TMSI.~~

#### ~~12.4.2.1.4 Method of test~~

#### Initial condition

##### System Simulator:

- ~~— Two cells, cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4).~~
- ~~Both cells operating in network operation mode I.~~

##### User Equipment:

- ~~— The UE has a valid IMSI.~~

#### Related ICS/IXIT statements

- ~~— Support of PS service — Yes/No~~
- ~~UE operation mode A — Yes/No~~
- ~~Switch off on button — Yes/No~~
- ~~Automatic PS attach procedure at switch on or power on — Yes/No~~

## Test procedure

- 1) A combined PS attach procedure is performed. The UE sends a ROUTING AREA UPDATE REQUEST message. The SS reallocates the P-TMSI, unassigns the TMSI and returns ROUTING AREA UPDATE ACCEPT message with a new P-TMSI and IMSI. The UE acknowledge the new P-TMSI by sending ROUTING AREA UPDATE COMPLETE message. Further communication UE – SS is performed by the new P-TMSI. For CS calls, the IMSI is used
- 2) The UE is CS paged in order to verify that the IMSI is used for CS calls.
- 3) A combined PS attach procedure is performed. The UE sends an ROUTING AREA UPDATE REQUEST message. The SS accepts the P-TMSI signature and returns ROUTING AREA UPDATE ACCEPT message without any P-TMSI and with a new TMSI. The UE acknowledge the new TMSI by sending ROUTING AREA UPDATE COMPLETE message. Further communication UE-SS is performed by the old P-TMSI. For CS calls, the new TMSI is used.
- 4) The UE is CS paged in order to verify that the TMSI is used for CS calls.

## Expected Sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                              |
|------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                       |
| 1    |           | SS |                                 | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>(see note)                                                                     |
| 1a   | UE        |    |                                 | The UE is set in UE-operation mode A (see ICS).                                                                                                                                                       |
| 2    | UE        |    |                                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                |
| 3    | →         |    | ATTACH REQUEST                  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                   |
| 4    | ←         |    | ATTACH ACCEPT                   | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature                                                            |
| 5    | →         |    | ATTACH COMPLETE                 | Routing area identity = RAI-1                                                                                                                                                                         |
| 6    |           | SS |                                 | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Suitable neighbour cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note) |
| 7    | →         |    | ROUTING AREA UPDATE REQUEST     | Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature                                                                                                                                         |
| 8    | ←         |    | ROUTING AREA UPDATE ACCEPT      | Routing area identity = RAI-1<br>TMSI status = no valid TMSI available<br>Update result = 'Combined RA/LA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                |
| 9    | →         |    | ROUTING AREA UPDATE COMPLETE    | Mobile identity = IMSI<br>Routing area identity = RAI-4                                                                                                                                               |
| 10   | ←         |    | PAGING TYPE1                    | Mobile identity = P-TMSI-1<br>Paging order is for PS services.                                                                                                                                        |
| 10a  | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                       |
| 10b  | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                       |
| 10c  | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                       |
| 11   | →         |    | SERVICE REQUEST                 | service type = "paging response"                                                                                                                                                                      |
| 11a  | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                       |
| 11b  | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                       |

| Step                                                                                                                                                                     | Direction |    | Message                            | Comments                                                                                                                                                                                                    |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                          | UE        | SS |                                    |                                                                                                                                                                                                             |
| 12                                                                                                                                                                       | ←         |    | PAGING-TYPE1                       | Mobile identity = IMSI<br>Paging order is for CS services.                                                                                                                                                  |
| 13                                                                                                                                                                       | →         |    | RRC-CONNECTION-REQUEST             |                                                                                                                                                                                                             |
| 14                                                                                                                                                                       | ←         |    | RRC-CONNECTION-SETUP               |                                                                                                                                                                                                             |
| 15                                                                                                                                                                       | →         |    | RRC-CONNECTION-SETUP<br>COMPLETE   |                                                                                                                                                                                                             |
| 16                                                                                                                                                                       | →         |    | PAGING-RESPONSE                    | Mobile identity = IMSI<br>After sending of this message, the SS waits for<br>disconnection of the CS signalling link.                                                                                       |
| 17                                                                                                                                                                       | ←         |    | RRC-CONNECTION-RELEASE             |                                                                                                                                                                                                             |
| 18                                                                                                                                                                       | →         |    | RRC-CONNECTION-RELEASE<br>COMPLETE |                                                                                                                                                                                                             |
| 19                                                                                                                                                                       |           | SS |                                    | The following messages are sent and shall be<br>received on cell A:<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable<br>neighbour cell".<br>(see note) |
| 20                                                                                                                                                                       | →         |    | ROUTING-AREA-UPDATE<br>REQUEST     | Update type = 'Combined RA/LA updating'<br>P-TMSI-1 signature<br>Routing area identity = RAI-4<br>TMSI status = no valid TMSI available                                                                     |
| 21                                                                                                                                                                       | ←         |    | ROUTING-AREA-UPDATE<br>ACCEPT      | Update result = 'Combined RA/LA updated'<br>No P-TMSI<br>P-TMSI-2 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-1                                                                    |
| 22                                                                                                                                                                       | →         |    | ROUTING-AREA-UPDATE<br>COMPLETE    |                                                                                                                                                                                                             |
| 23                                                                                                                                                                       | ←         |    | PAGING-TYPE1                       | Mobile identity = P-TMSI-1<br>Paging order is for PS services.                                                                                                                                              |
| 23a                                                                                                                                                                      | →         |    | RRC-CONNECTION-REQUEST             |                                                                                                                                                                                                             |
| 23b                                                                                                                                                                      | ←         |    | RRC-CONNECTION-SETUP               |                                                                                                                                                                                                             |
| 23c                                                                                                                                                                      | →         |    | RRC-CONNECTION-SETUP<br>COMPLETE   |                                                                                                                                                                                                             |
| 24                                                                                                                                                                       | →         |    | SERVICE-REQUEST                    | service type = "paging response"                                                                                                                                                                            |
| 24a                                                                                                                                                                      | ←         |    | RRC-CONNECTION-RELEASE             |                                                                                                                                                                                                             |
| 24b                                                                                                                                                                      | →         |    | RRC-CONNECTION-RELEASE<br>COMPLETE |                                                                                                                                                                                                             |
| 25                                                                                                                                                                       | ←         |    | PAGING-TYPE1                       | Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                                                |
| 26                                                                                                                                                                       | →         |    | RRC-CONNECTION-REQUEST             |                                                                                                                                                                                                             |
| 27                                                                                                                                                                       | ←         |    | RRC-CONNECTION-SETUP               |                                                                                                                                                                                                             |
| 28                                                                                                                                                                       | →         |    | RRC-CONNECTION-SETUP<br>COMPLETE   |                                                                                                                                                                                                             |
| 29                                                                                                                                                                       | →         |    | PAGING-RESPONSE                    | Mobile identity = TMSI-1                                                                                                                                                                                    |
| 30                                                                                                                                                                       | ←         |    | RRC-CONNECTION-RELEASE             | After sending of this message, the SS waits for<br>disconnection of the CS signalling link.                                                                                                                 |
| 31                                                                                                                                                                       | →         |    | RRC-CONNECTION-RELEASE<br>COMPLETE |                                                                                                                                                                                                             |
| 32                                                                                                                                                                       | UE        |    |                                    | The UE is switched off or power is removed<br>(see ICS).                                                                                                                                                    |
| 33                                                                                                                                                                       | →         |    | DETACH-REQUEST                     | Message not sent if power is removed.<br>Detach type = 'power switched off, combined<br>PS / IMSI detach'                                                                                                   |
| NOTE:—The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                    |                                                                                                                                                                                                             |

## Specific message contents

None.

#### 12.4.2.1.5 ~~Test requirements~~

At step3, when the UE is powered up or switched on, UE shall:

- ~~— initiate the combined PS attach procedure with information elements specified in the above Expected Sequence.~~

At step7, when the RF level of the attached cell is lower than the RF level of the new cell, UE shall:

- ~~— initiate the combined routing area update procedure (Update type = 'Combined RA/LA updating') with the information elements specified above Expected Sequence.~~

At step9, UE shall:

- ~~— acknowledge the new P-TMSI by sending the ROUTING AREA UPDATE COMPLETE message.~~

At step11, when the UE receives the paging message for PS domain, UE shall:

- ~~— respond to the paging message for PS domain by sending the SERVICE REQUEST message.~~

At step16, when the UE receives the paging message for CS domain, UE shall;

- ~~— respond to the paging message for CS domain by sending the PAGING RESPONSE message.~~

At step20, when the RF level of the attached cell is lower than the RF level of the new cell, UE shall:

- ~~— initiate the combined routing area update procedure (Update type = 'Combined RA/LA updating') with the information elements specified above Expected Sequence.~~

At step22, UE shall:

- ~~— acknowledge the new TMSI by sending the ROUTING AREA UPDATE COMPLETE message.~~

At step24, when the UE receives the paging message for PS domain, UE shall:

- ~~— respond to the paging message for PS domain by sending the SERVICE REQUEST message.~~

At step29, when the UE receives the paging message for CS domain, UE shall;

- ~~— respond to the paging message for CS domain by sending the PAGING RESPONSE message.~~

#### 12.4.2.2 ~~Combined routing area updating / UE in CS operation at change of RA~~

##### 12.4.2.2.1 ~~Definition~~

##### 12.4.2.2.2 ~~Conformance requirement~~

PS UE in UE operation mode A that is in an ongoing CS transaction at change of routing area shall initiate the normal routing area updating procedure.

##### Reference

3GPP TS 24.008 clause 4.7.5.2.

##### 12.4.2.2.3 ~~Test purpose~~

To test the behaviour of the UE if the routing area is changed during an ongoing circuit switched transmission.

##### 12.4.2.2.4 ~~Method of test~~

##### Initial condition

System Simulator:

- Two cells, cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4). Both cells operating in network operation mode I.

#### User Equipment:

- The UE has a valid IMSI.

#### Related ICS/IXIT statements

- Support of PS service — Yes/No
- UE operation mode A — Yes/No
- Switch off on button — Yes/No
- Automatic PS attach procedure at switch on or power on — Yes/No

#### Test procedure

A combined PS attach procedure is performed. The UE in UE operation mode A initiates a CS call. The routing area change. The UE will perform the normal routing area updating procedure during the ongoing circuit-switched transaction.

## Expected Sequence

| Step                                                                                                                                                                       | Direction |    | Message                      | Comments                                                                                                                                                                    |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                            | UE        | SS |                              |                                                                                                                                                                             |
| 1                                                                                                                                                                          |           |    |                              | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>(see note)                                           |
| 1a                                                                                                                                                                         | UE        |    |                              | The UE is set in UE operation mode A (see ICS).                                                                                                                             |
| 2                                                                                                                                                                          | UE        |    |                              | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                      |
| 3                                                                                                                                                                          | →         |    | ATTACH REQUEST               | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                         |
| 4                                                                                                                                                                          | ←         |    | ATTACH ACCEPT                | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1 |
| 5                                                                                                                                                                          | →         |    | ATTACH COMPLETE              |                                                                                                                                                                             |
| 6                                                                                                                                                                          | UE        |    |                              | A CS call is initiated.                                                                                                                                                     |
| 7                                                                                                                                                                          |           | SS |                              | Activate cell B with the same signal strength as cell A.                                                                                                                    |
| 8                                                                                                                                                                          |           | ←  |                              | Handover commanded by SS on to DCH of cell B<br>The following messages are sent and shall be received on cell B.                                                            |
| 9                                                                                                                                                                          | →         |    | ROUTING AREA UPDATE REQUEST  | Update type = 'RA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>TMSI status = no valid TMSI available                                                 |
| 10                                                                                                                                                                         | ←         |    | ROUTING AREA UPDATE ACCEPT   | Update result = 'RA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = IMSI<br>Routing area identity = RAI-4                                 |
| 11                                                                                                                                                                         | →         |    | ROUTING AREA UPDATE COMPLETE |                                                                                                                                                                             |
| 12                                                                                                                                                                         | ←         |    | PAGING TYPE2                 | Mobile identity = P-TMSI-1<br>Paging order is for PS services.                                                                                                              |
| 13                                                                                                                                                                         | →         |    | SERVICE REQUEST              | service type = "paging response"                                                                                                                                            |
| 14                                                                                                                                                                         | SS        |    |                              | The SS initiates the RRC connection release.                                                                                                                                |
| 15                                                                                                                                                                         | UE        |    |                              | The UE is switched off or power is removed (see ICS).                                                                                                                       |
| 16                                                                                                                                                                         | →         |    | DETACH REQUEST               | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach'                                                                      |
| NOTE: — The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                              |                                                                                                                                                                             |

## Specific message contents

None.

## 12.4.2.2.5 — Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with information elements specified in the above Expected Sequence.

At step9, when the RF level of the attached cell is lower than the RF level of the new cell during the CS connection, UE shall:

- initiate the normal routing area updating procedure.



### ~~12.4.2.3 Combined routing area updating / RA only accepted~~

#### ~~12.4.2.3.1 Definition~~

#### ~~12.4.2.3.2 Conformance requirement~~

- ~~1) If the network accepts the combined PS attach procedure, but GMM cause code 'TMSI unknown in HLR' is sent to the UE the User Equipment shall delete the stored TMSI, LAI and CKSN. The User Equipment shall consider USIM invalid for non-PS services until power is switched off or USIM is removed.~~
- ~~2) If the network accepts the combined PS attach procedure, but GMM cause code 'MSC temporarily not reachable', 'Network failure' or 'Congestion' is sent to the UE, an UE operation mode A UE may perform an MM IMSI attach procedure.~~

#### Reference

3GPP TS 24.008 clause 4.7.5.2.

#### ~~12.4.2.3.3 Test purpose~~

##### ~~Test porpose1~~

~~To test the behaviour of the UE if the network accepts the routing area updating procedure with indication RA only, GMM cause 'TMSI unknown in HLR'.~~

##### ~~Test porpose2~~

~~To test the behaviour of the UE if the network accepts the routing area updating procedure with indication RA only, GMM cause 'MSC temporarily not reachable', 'Network failure' or 'Congestion'.~~

#### ~~12.4.2.3.4 Method of test~~

##### ~~Test Procedure1~~

##### ~~Initial condition~~

~~System Simulator:~~

- ~~— Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4).~~
- ~~Both cells operating in network operation mode I.~~

~~User Equipment:~~

- ~~— The UE has a valid IMSI.~~

##### ~~Related ICS/IXIT statements~~

- ~~— Support of PS service — Yes/No~~
- ~~UE operation mode A — Yes/No~~
- ~~Switch off on button — Yes/No~~
- ~~Automatic PS attach procedure at switch on or power on — Yes/No~~

##### ~~Test procedure~~

~~After attach, the UE sends an ROUTING AREA UPDATE REQUEST message. The SS allocates a P-TMSI and returns ROUTING AREA UPDATE ACCEPT message with a P-TMSI. GMM cause 'TMSI unknown in HLR' is indicated from SS. Further communication UE – SS is performed by the P-TMSI. CS services are not possible.~~

## Expected Sequence

| Step                                                                                                                                                      | Direction |    | Message                         | Comments                                                                                                                                                                                        |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                           | UE        | SS |                                 |                                                                                                                                                                                                 |
| 1                                                                                                                                                         |           | SS |                                 | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note)                                                                              |
| 1a                                                                                                                                                        | UE        |    |                                 | The UE is set in UE operation mode A (see ICS).                                                                                                                                                 |
| 2                                                                                                                                                         | UE        |    |                                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                          |
| 3                                                                                                                                                         | →         |    | ATTACH REQUEST                  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                             |
| 4                                                                                                                                                         | ←         |    | ATTACH ACCEPT                   | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature                                                      |
| 5                                                                                                                                                         | →         |    | ATTACH COMPLETE                 | Routing area identity = RAI-1                                                                                                                                                                   |
| 6                                                                                                                                                         |           | SS |                                 | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)          |
| 7                                                                                                                                                         | →         |    | ROUTING AREA UPDATE REQUEST     | Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                                  |
| 8                                                                                                                                                         | ←         |    | ROUTING AREA UPDATE ACCEPT      | TMSI status = no valid TMSI available<br>Update result = 'RA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-4<br>GMM cause = 'IMSI unknown in HLR' |
| 9                                                                                                                                                         | →         |    | ROUTING AREA UPDATE COMPLETE    |                                                                                                                                                                                                 |
| 10                                                                                                                                                        | ←         |    | PAGING TYPE1                    | Mobile identity = P-TMSI-1<br>Paging order is for PS services.                                                                                                                                  |
| 10a                                                                                                                                                       | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                 |
| 10b                                                                                                                                                       | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                 |
| 10c                                                                                                                                                       | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                 |
| 11                                                                                                                                                        | →         |    | SERVICE REQUEST                 | service type = "paging response"                                                                                                                                                                |
| 11a                                                                                                                                                       | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                 |
| 11b                                                                                                                                                       | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                 |
| 12                                                                                                                                                        | ←         |    | PAGING TYPE1                    | Mobile identity = IMSI<br>Paging order is for CS services.                                                                                                                                      |
| 13                                                                                                                                                        | UE        |    |                                 | The UE shall not initiate an RRC connection.<br>This is checked during 3 seconds.                                                                                                               |
| 14                                                                                                                                                        | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                                                                                                                           |
| 15                                                                                                                                                        | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                          |
| NOTE:—The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                                                                 |

## Test Procedure2

## Initial condition

## System Simulator:

- Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4).
- Both cells operating in network operation mode I.

## User Equipment:

—The UE has a valid IMSI.

## Related ICS/IXIT statements

—Support of PS service—Yes/No

UE operation mode A—Yes/No

Automatic MM IMSI attach procedure for UE operation mode A UE—Yes/No

Switch off on button—Yes/No

Automatic PS attach procedure at switch on or power on—Yes/No

## Test procedure

After attach, the UE sends an ROUTING AREA UPDATE REQUEST message. The SS allocates a new P-TMSI signature and returns ROUTING AREA UPDATE ACCEPT message. GMM cause 'MSC temporarily not reachable', 'Network failure' or 'Congestion' is indicated from SS. The cause code is arbitrarily chosen. This procedure is repeated until the routing area updating attempt counter is equal to five. An UE operation mode A UE may perform an MM IMSI attach procedure (according to the ICS statement). Further communication UE-SS is performed by the P-TMSI. The existence of a signalling channel is verified by a request for mobile identity. It is further verified that the UE after a successful IMSI attach procedure can perform CS services.

## Expected Sequence

Dependent whether the option 'Automatic MM IMSI attach procedure for UE operation mode A UE' is not supported or not, the steps 1-13 or 14-35 apply depending on manufacturer (see ICS).

| Step | Direction |    | Message                     | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|------|-----------|----|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 1    |           | SS |                             | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note)<br>The UE is set in UE operation mode A and no automatic MM IMSI attach procedure is indicated (see ICS).<br>The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                                                                |
| 1a   | UE        |    |                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 2    | UE        |    |                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 3    |           | →  | ATTACH REQUEST              | Attach type = 'Combined PS / IMSI attach' or 'PS attach while IMSI attached'<br>Mobile identity = IMSI<br>TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                                                                                                                                                                                                     |
| 4    |           | ←  | ATTACH ACCEPT               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 5    |           | →  | ATTACH COMPLETE             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 6    |           | SS |                             | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)<br>Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>TMSI status = no valid TMSI available<br>Update result = 'RA updated'<br>Mobile identity = P-TMSI-1P-TMSI-1 signature<br>Routing area identity = RAI-4<br>GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen) |
| 7    |           | →  | ROUTING AREA UPDATE REQUEST |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 8    |           | ←  | ROUTING AREA UPDATE ACCEPT  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |

| Step | Direction |    | Message                      | Comments                                                                                                                                                                                                                 |
|------|-----------|----|------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                              |                                                                                                                                                                                                                          |
| 9    | →         |    | ROUTING AREA UPDATE COMPLETE |                                                                                                                                                                                                                          |
| 10   |           |    |                              | The routing area updating attempt counter =1.<br>The combined routing area updating procedure is reinitialised at the expiry of T3311                                                                                    |
| 11   | →         |    | ROUTING AREA UPDATE REQUEST  | Update type = 'Combined RA/LA updating with IMSI attach'<br>P-TMSI-1 signature<br>Routing area identity = RAI-4<br>TMSI status = no valid TMSI available                                                                 |
| 12   | ←         |    | ROUTING AREA UPDATE ACCEPT   | Update result = 'RA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-4<br>GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen) |
| 13   | →         |    | ROUTING AREA UPDATE COMPLETE |                                                                                                                                                                                                                          |
| 14   | →         |    |                              | The routing area updating attempt counter =2.<br>The combined routing area updating procedure is reinitialised at the expiry of T3311                                                                                    |
| 15   |           |    | ROUTING AREA UPDATE REQUEST  | Update type = 'Combined RA/LA updating with IMSI attach'<br>P-TMSI-1 signature<br>Routing area identity = RAI-4<br>TMSI status = no valid TMSI available                                                                 |
| 16   | ←         |    | ROUTING AREA UPDATE ACCEPT   | Update result = 'RA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-4<br>GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen) |
| 17   | →         |    | ROUTING AREA UPDATE COMPLETE |                                                                                                                                                                                                                          |
| 18   | →         |    |                              | The routing area updating attempt counter =3.<br>The combined routing area updating procedure is reinitialised at the expiry of T3311                                                                                    |
| 19   |           |    | ROUTING AREA UPDATE REQUEST  | Update type = 'Combined RA/LA updating with IMSI attach'<br>P-TMSI-1 signature<br>Routing area identity = RAI-4<br>TMSI status = no valid TMSI available                                                                 |
| 20   | ←         |    | ROUTING AREA UPDATE ACCEPT   | Update result = 'RA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-4<br>GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen) |
| 21   | →         |    | ROUTING AREA UPDATE COMPLETE |                                                                                                                                                                                                                          |
| 22   | →         |    |                              | The routing area updating attempt counter =4.<br>The combined routing area updating procedure is reinitialised at the expiry of T3311                                                                                    |
| 23   |           |    | ROUTING AREA UPDATE REQUEST  | Update type = 'Combined RA/LA updating with IMSI attach'<br>P-TMSI-1 signature<br>Routing area identity = RAI-4<br>TMSI status = no valid TMSI available                                                                 |

| Step | Direction |    | Message                      | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|------|-----------|----|------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 24   | <-        |    | ROUTING AREA UPDATE ACCEPT   | Update result = 'RA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-4<br>GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen)<br><br>The routing area updating attempt counter = 5.<br>The combined routing area updating procedure is reinitialised at the expiry of T3311.<br>The UE is switched off or power is removed (see ICS).<br>Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'<br>Stop the sequence.                                                                                                                                                                                                                                                                                                                         |
| 25   |           |    | ROUTING AREA UPDATE COMPLETE |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 26   |           |    |                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 27   |           |    |                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 28   | —>        |    | DETACH REQUEST               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|      |           |    |                              | The following messages are sent and shall be received on cell B                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 29   | UE        |    | ATTACH REQUEST               | The UE is set in UE operation mode A and automatic MM-IMSI attach procedure is indicated (see ICS).<br>The UE is powered up or switched on and initiates an attach (see ICS).<br>Attach type = 'Combined PS / IMSI attach' or 'PS attach while IMSI attached'<br>Mobile identity = IMSI<br>TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-4                                                                                                                                                                                                                                                                                                                                                                                                   |
| 30   |           |    |                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 31   |           |    |                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 32   |           |    | ATTACH ACCEPT                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 33   |           |    | ATTACH COMPLETE              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 34   | SS        |    | ROUTING AREA UPDATE REQUEST  | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note)<br>Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-4<br>TMSI status = no valid TMSI available<br>Update result = 'RA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1<br>GMM cause = 'MSC temporarily not reachable', 'Network failure' or 'Congestion' (arbitrarily chosen)<br><br>The routing area updating attempt counter = 1.<br>The combined routing area updating procedure is reinitialised at the expiry of T3311.<br>Update type = 'Combined RA/LA updating with IMSI attach'<br>P-TMSI-1 signature<br>Routing area identity = RAI-1<br>TMSI status = no valid TMSI available |
| 35   |           |    |                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 36   |           |    | ROUTING AREA UPDATE ACCEPT   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 37   |           |    | ROUTING AREA UPDATE COMPLETE |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 38   |           |    |                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 39   |           |    | ROUTING AREA UPDATE REQUEST  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                       |
|------|-----------|----|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                |
| 40   |           | <- | ROUTING-AREA-UPDATE<br>ACCEPT   | Update result = 'RA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1<br>GMM cause = 'MSC temporarily not reachable',<br>'Network failure' or 'Congestion' (arbitrarily<br>chosen) |
| 41   |           | -> | ROUTING-AREA-UPDATE<br>COMPLETE |                                                                                                                                                                                                                                |
| 42   |           |    |                                 | The routing area updating attempt counter =2.<br>The combined routing area updating procedure<br>is reinitialised at the expiry of T3311                                                                                       |
| 43   |           | -> | ROUTING-AREA-UPDATE<br>REQUEST  | Update type = 'Combined RA/LA updating<br>with IMSI attach'<br>P-TMSI-1 signature<br>Routing area identity = RAI-1<br>TMSI status = no valid TMSI available                                                                    |
| 44   |           | <- | ROUTING-AREA-UPDATE<br>ACCEPT   | Update result = 'RA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1<br>GMM cause = 'MSC temporarily not reachable',<br>'Network failure' or 'Congestion' (arbitrarily<br>chosen) |
| 45   |           | -> | ROUTING-AREA-UPDATE<br>COMPLETE |                                                                                                                                                                                                                                |
| 46   |           |    |                                 | The routing area updating attempt counter =3.<br>The combined routing area updating procedure<br>is reinitialised at the expiry of T3311                                                                                       |
| 47   |           | -> | ROUTING-AREA-UPDATE<br>REQUEST  | Update type = 'Combined RA/LA updating<br>with IMSI attach'<br>P-TMSI-1 signature<br>Routing area identity = RAI-1<br>TMSI status = no valid TMSI available                                                                    |
| 48   |           | <- | ROUTING-AREA-UPDATE<br>ACCEPT   | Update result = 'RA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1<br>GMM cause = 'MSC temporarily not reachable',<br>'Network failure' or 'Congestion' (arbitrarily<br>chosen) |
| 49   |           | -> | ROUTING-AREA-UPDATE<br>COMPLETE |                                                                                                                                                                                                                                |
| 50   |           |    |                                 | The routing area updating attempt counter =4.<br>The combined routing area updating procedure<br>is reinitialised at the expiry of T3311                                                                                       |
| 51   |           | -> | ROUTING-AREA-UPDATE<br>REQUEST  | Update type = 'Combined RA/LA updating – with<br>IMSI attach'<br>P-TMSI-1 signature<br>Routing area identity = RAI-1<br>TMSI status = no valid TMSI available                                                                  |
| 52   |           | <- | ROUTING-AREA-UPDATE<br>ACCEPT   | Update result = 'RA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1<br>GMM cause = 'MSC temporarily not reachable',<br>'Network failure' or 'Congestion' (arbitrarily<br>chosen) |
| 53   |           | -> | ROUTING-AREA-UPDATE<br>COMPLETE |                                                                                                                                                                                                                                |
| 54   |           |    |                                 | The routing area updating attempt counter =5.                                                                                                                                                                                  |
| 55   | UE        |    | Registration on CS              | See TS 34.108<br>This is applied only for UE in UE operation<br>mode A.<br>Parameter mobile identity is TMSI-1.                                                                                                                |

| Step                                                                                                                                                        | Direction |    | Message                         | Comments                                                                                 |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|------------------------------------------------------------------------------------------|
|                                                                                                                                                             | UE        | SS |                                 |                                                                                          |
| 56                                                                                                                                                          | —<        |    | PAGING TYPE1                    | Mobile identity = TMSI-1<br>Paging order is for CS services.                             |
| 57                                                                                                                                                          | —>        |    | RRC CONNECTION REQUEST          |                                                                                          |
| 58                                                                                                                                                          | —<        |    | RRC CONNECTION SETUP            |                                                                                          |
| 59                                                                                                                                                          | —>        |    | RRC CONNECTION SETUP COMPLETE   |                                                                                          |
| 60                                                                                                                                                          | —>        |    | PAGING RESPONSE                 | Mobile identity = TMSI-1                                                                 |
| 61                                                                                                                                                          | —<        |    | RRC CONNECTION RELEASE          | After sending of this message, the SS waits for disconnection of the CS signalling link. |
| 62                                                                                                                                                          | —>        |    | RRC CONNECTION RELEASE COMPLETE |                                                                                          |
| 63                                                                                                                                                          | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                    |
| 64                                                                                                                                                          | —>        |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'   |
| NOTE: — The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                          |

### Specific message contents

None.

### 12.4.2.3.5 — Test requirements

#### Test requirements for Test Procedure1

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with information elements specified in the above Expected Sequence.

At step7, when the RF level of the attached cell is lower than the RF level of the new cell, UE shall:

- initiate the combined routing area updating procedure.

At step9, UE shall:

- acknowledge the new P-TMSI by sending the ROUTING AREA UPDATE COMPLETE message.

At step11, when the UE receives the paging message for PS domain, UE shall:

- respond to the paging message for PS domain by sending the SERVICE REQUEST message.

At step13, when the UE receives the paging message for CS domain, UE shall:

- not respond to the paging message for CS domain.

#### Test requirements for Test Procedure2

At step3 and 31, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with information elements specified in the above Expected Sequence.

At step6 and 35, when the RF level of the attached cell is lower than the RF level of the new cell, UE shall:

- initiate the combined routing area updating procedure.

At step11, 15, 19 and 23, UE shall:

- re-initiate the combined routing area updating procedure.

At step39, 43, 47 and 51, UE shall:

- re-initiate the combined routing area updating procedure.

At step55, UE shall:

- perform MM location updating procedure.

At step60, when the UE receives the paging message for CS domain, UE shall:

- not respond to the paging message for CS domain.

## ~~12.4.2.4 Combined routing area updating / rejected / PLMN not allowed~~

### ~~12.4.2.4.1 Definition~~

### ~~12.4.2.4.2 Conformance requirement~~

- 1) If the network rejects a combined routing area updating procedure from the User Equipment with the cause 'PLMN not allowed' the User Equipment shall:

- 1.1 not perform combined GPRA attach when switched on in the same location area or PLMN.
- 1.2 delete the stored RAI, PS-CKSN, P-TMSI, P-TMSI signature, TMSI-CKSN and LAI.
- 1.3 store the PLMN in the 'forbidden PLMN list'.

- 2) An MS that receives a ROUTING AREA UPDATE REJECT message stops timer T3330, enters state MM IDLE and for all causes except #12, #14 and #15 deletes the list of "equivalent PLMNs".

## Reference

3GPP TS 24.008 clause 4.7.5.2.

### ~~12.4.2.4.3 Test purpose~~

To test the behaviour of the UE if the network rejects the combined routing area updating procedure of the UE with the cause 'PLMN not allowed'.

### ~~12.4.2.4.4 Method of test~~

## Initial condition

### System Simulator:

- Five cells (not simultaneously activated), cell A in MCC1/MNC2/LAC1/RAC1 (RAI-8), cell B in MCC1/MNC2/LAC1/RAC2 (RAI-10), cell C in MCC1/MNC2/LAC2/RAC1 (RAI-9) and cell D in MCC2/MNC1/LAC1/RAC1 (RAI-2), cell E in MCC1/MNC3/LAC1/RAC1 (RAI-11).
- The PLMN containing Cells A, B and C is equivalent to the PLMN that contains Cell E.  
All five cells are operating in network operation mode I

### User Equipment:

- The UE has a valid IMSI.

## Related ICS/IXIT statements

- Support of PS service—Yes/No
- UE operation mode A—Yes/No
- Switch off on button—Yes/No
- Automatic PS attach procedure at switch on or power on—Yes/No



### Test procedure

The SS rejects a combined routing area updating with the cause value 'PLMN not allowed'. The SS checks that the UE does not perform PS attach if activated in the same PLMN. The SS checks that the UE does not perform IMSI attach if activated in the same PLMN.

## Expected Sequence

| Step | Direction |    | Message                     | Comments                                                                                                                                                                                                                                                                                                                                     |
|------|-----------|----|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                                                                                                                                                                                                                              |
| 1    |           | SS | ATTACH-REQUEST              | The following messages are sent and shall be received on cell A:<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Off cell".<br>Set the cell type of cell D to the "Off cell".<br>Set the cell type of cell E to the "Off cell".<br>(see note) |
| 2    | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                                                                                                                                                       |
| 3    | →         |    |                             | Attach type = 'Combined PS / IMSI attach'                                                                                                                                                                                                                                                                                                    |
| 4    |           | ←  |                             | Mobile identity = IMSI<br>TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'                                                                                                                                                                                                                             |
| 5    | →         |    |                             | Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-8<br>Mobile identity = TMSI-1<br>Equivalent PLMN: MCC = 1, MNC=3                                                                                                                                                                                             |
| 7    |           | SS | ROUTING-AREA-UPDATE-REQUEST | The following messages are sent and shall be received on cell B and cell E:<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>Set the cell type of cell E to the "Suitable neighbour cell".<br>(see note)                                                                           |
| 8    | UE        |    |                             | Cell B is preferred by the UE.                                                                                                                                                                                                                                                                                                               |
| 9    | →         |    |                             | Update type = 'Combined RA/LA updating'                                                                                                                                                                                                                                                                                                      |
| 10   |           | ←  |                             | P-TMSI-2 signature<br>Routing area identity = RAI-8<br>TMSI status = valid TMSI available<br>GMM cause = 'PLMN not allowed'                                                                                                                                                                                                                  |
| 11   | UE        |    |                             | The UE initiates an attach by MMI or AT command.                                                                                                                                                                                                                                                                                             |
| 12   | UE        |    | PAGING-TYPE1                | No ATTACH-REQUEST sent to SS<br>(SS waits 30 seconds).                                                                                                                                                                                                                                                                                       |
| 12a  | SS        |    |                             | The SS deactivates cell E.                                                                                                                                                                                                                                                                                                                   |
| 13   |           | ←  |                             | Set the cell type of cell E to the "Off cell".<br>Mobile identity = P-TMSI-2                                                                                                                                                                                                                                                                 |
| 14   | UE        |    |                             | Paging order is for PS services.<br>No response from the UE to the request. This is checked for 10 seconds.                                                                                                                                                                                                                                  |
| 15   |           | SS | PAGING-TYPE1                | The following messages are sent and shall be received on cell C:<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Serving cell".<br>(see note)                                                                                                                                                       |
| 16   | UE        |    |                             | Cell C is preferred by the UE.                                                                                                                                                                                                                                                                                                               |
| 17   | UE        |    |                             | The UE initiates an attach by MMI or by AT command.                                                                                                                                                                                                                                                                                          |
| 18   | UE        |    |                             | No ATTACH-REQUEST sent to SS<br>(SS waits 30 seconds).                                                                                                                                                                                                                                                                                       |
| 19   |           | ←  |                             | Mobile identity = TMSI-1                                                                                                                                                                                                                                                                                                                     |
| 20   | UE        |    |                             | Paging order is for CS services.<br>The UE shall not initiate an RRC connection.<br>This is checked during 3 seconds.                                                                                                                                                                                                                        |
| 21   |           | SS |                             | The following messages are sent and shall be received on cell A:<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell C to the "Off cell".<br>(see note)                                                                                                                                                       |
| 22   | UE        |    |                             | Cell A is preferred by the UE.                                                                                                                                                                                                                                                                                                               |

| Step                                                                                                                                                                                 | Direction |    | Message            | Comments                                                                                                                                                                                                                                                                     |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                                      | UE        | SS |                    |                                                                                                                                                                                                                                                                              |
| 23                                                                                                                                                                                   | UE        |    | PAGING TYPE1       | The UE initiates an attach by MMI or by AT command.                                                                                                                                                                                                                          |
| 24                                                                                                                                                                                   | UE        |    |                    | No ATTACH REQUEST sent to SS                                                                                                                                                                                                                                                 |
| 25                                                                                                                                                                                   | ←         |    |                    | (SS waits 30 seconds).                                                                                                                                                                                                                                                       |
| 26                                                                                                                                                                                   | UE        |    |                    | Mobile identity = P-TMSI-2<br>Paging order is for PS services.<br>No response from the UE to the request. This is checked for 10 seconds.                                                                                                                                    |
| 27                                                                                                                                                                                   |           | SS | Registration on CS | The following messages are sent and shall be received on cell D.                                                                                                                                                                                                             |
| 28                                                                                                                                                                                   | UE        |    |                    | Set the cell type of cell A to the "Off cell".                                                                                                                                                                                                                               |
| 28a                                                                                                                                                                                  | UE        |    |                    | Set the cell type of cell D to the "Serving cell". (see note)                                                                                                                                                                                                                |
| 29                                                                                                                                                                                   | UE        |    |                    | Cell D is preferred by the UE.<br>See TS 34.108<br>This step is applied only for non-auto-attach UE.<br>Location Update Procedure initiated from the UE.                                                                                                                     |
| 30                                                                                                                                                                                   | →         |    | ATTACH REQUEST     | The UE initiates an attach automatically (see ICS), by MMI or by AT command.                                                                                                                                                                                                 |
| 31                                                                                                                                                                                   | ←         |    | ATTACH ACCEPT      | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI<br>TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-2<br>Mobile identity = IMSI |
| 32                                                                                                                                                                                   | →         |    | ATTACH COMPLETE    |                                                                                                                                                                                                                                                                              |
| 33                                                                                                                                                                                   | UE        |    |                    | The UE is switched off or power is removed (see ICS).                                                                                                                                                                                                                        |
| 34                                                                                                                                                                                   | →         |    | DETACH REQUEST     | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach'                                                                                                                                                                       |
| NOTE: The definitions for "Off cell", "Serving cell" and "Suitable neighbour cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                    |                                                                                                                                                                                                                                                                              |

### Specific message contents

None.

### 12.4.2.4.5 Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with information elements specified in the above Expected Sequence.

At step9, when the RF level of the attached cell is lower than the RF level of the new cell, UE shall:

- initiate the combined routing area update procedure (Update type = 'Combined RA/LA updating') with the information elements specified above Expected Sequence.

At step 10, the UE shall delete the equivalent PLMN list (MCC=1, MNC=3).

At step 12, the UE shall not initiate a PS attach procedure to cell E.

At step 18 and 24, UE shall:

- not initiate a PS attach procedure.

At step14, 20 and 26, when the UE receives the paging message for PS domain, UE shall:

- not respond to the paging message for PS domain.

At step20, when the UE receives the paging message for CS domain, UE shall:

- not respond to the paging message for CS domain.

At step30, UE shall:

- perform the PS attach procedure.

#### ~~12.4.2.5a~~ Combined routing area updating / rejected / roaming not allowed in this location area

##### ~~12.4.2.5a.1~~ Definition

##### ~~12.4.2.5a.2~~ Conformance requirement

- 1) If the network rejects a combined routing area updating procedure from the User Equipment with the cause 'roaming not allowed in this location area' the User Equipment:
  - 1.1 shall not perform combined PS attach when in the same location area.
  - 1.2 shall delete the stored RAI, PS-CKSN, P-TMSI P-TMSI signature, TMSI, CKSN and LAI.
  - 1.3 shall store the LA in the 'forbidden location areas for roaming'.
  - 1.4 may perform combined PS attach when a new location area is entered.
- 2) The User Equipment shall reset the list of 'Forbidden location areas for roaming' when switched off or when the USIM is removed.

#### Reference

3GPP TS 24.008 clause 4.7.5.2.

##### ~~12.4.2.5a.3~~ Test purpose

###### ~~Test purpose1~~

To test that on receipt of a rejection using the 'Roaming not allowed in this area' cause code, the UE ceases trying a routing area updating procedure on that location area. Successful combined routing area updating procedure is possible in other location areas.

###### ~~Test purpose2~~

To test that if the UE is switched off or the USIM is removed the list of 'forbidden location areas for roaming' is cleared.

##### ~~12.4.2.5a.4~~ Method of test

###### ~~12.4.2.5a.4.1~~ Test procedure1

#### ~~Initial condition~~

System Simulator:

- Two cells, cell A in MCC2/MNC1/LAC1/RAC1 (RAI-2), cell B in MCC2/MNC1/LAC2/RAC1 (RAI-6). Both cells are operating in network operation mode I.

User Equipment:

- The UE has a valid IMSI.

#### Related ICS/IXIT statements

- Support of PS service — Yes/No
- UE operation mode A — Yes/No
- Switch off on button — Yes/No
- Automatic PS attach procedure at switch on or power on — Yes/No

#### Test procedure

The SS rejects a combined routing area updating with the cause value 'Roaming not allowed in this area'. A new attempt for a combined PS attach is not possible. Successful combined PS attach procedure is performed in another location area. The UE is moved back to the 1<sup>st</sup> location area. A combined routing area updating shall not be performed, as the LA is on the forbidden list.

## Expected Sequence

| Step | Direction |    | Message                     | Comments                                                                                                                                                                                                |
|------|-----------|----|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                                                                                         |
| 1    |           | SS |                             | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>(see note)   |
| 2    | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                  |
| 3    | →         |    | ATTACH REQUEST              | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                     |
| 4    | ←         |    | ATTACH ACCEPT               | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-2<br>Mobile identity = TMSI-1 |
| 5    | →         |    | ATTACH COMPLETE             |                                                                                                                                                                                                         |
| 7    |           | SS |                             | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Suitable neighbour cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)   |
| 8    | UE        |    |                             | Cell B is preferred by the UE.                                                                                                                                                                          |
| 9    | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-2                                                                                                          |
| 10   | ←         |    | ROUTING AREA UPDATE REJECT  | GMM cause = 'Roaming not allowed in this area'                                                                                                                                                          |
| 11   | UE        |    |                             | The UE initiates an attach by MMI or by AT command.                                                                                                                                                     |
| 12   | UE        |    |                             | No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds).                                                                                                                                                  |
| 13   | ←         |    | PAGING TYPE1                | Mobile identity = P-TMSI-2<br>Paging order is for PS services.                                                                                                                                          |
| 14   | UE        |    |                             | No response from the UE to the request. This is checked for 10 seconds.                                                                                                                                 |
| 15   | ←         |    | PAGING TYPE1                | Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                                            |
| 16   | UE        |    |                             | The UE shall not initiate an RRC connection.<br>This is checked during 3 seconds.                                                                                                                       |
| 17   |           | SS |                             | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>(see note)   |
| 18   | UE        |    |                             | Cell A is preferred by the UE.                                                                                                                                                                          |
| 18a  | UE        |    | Registration on CS          | See TS 34.108<br>This step is applied only for non-auto attach UE.<br>Location Update Procedure initiated from the UE.                                                                                  |
| 19   | UE        |    |                             | The UE initiates an attach automatically (see ICS), by MMI or by AT command.                                                                                                                            |
| 20   | →         |    | ATTACH REQUEST              | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                     |
| 21   | ←         |    | ATTACH ACCEPT               | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-2<br>Mobile identity = TMSI-1 |
| 22   | →         |    | ATTACH COMPLETE             |                                                                                                                                                                                                         |

| Step                                                                                                                                                                     | Direction |    | Message                         | Comments                                                                                                                                                                                              |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                          | UE        | SS |                                 |                                                                                                                                                                                                       |
| 23                                                                                                                                                                       | ←         |    | PAGING TYPE1                    | Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                                          |
| 24                                                                                                                                                                       | →         |    | RRG CONNECTION REQUEST          |                                                                                                                                                                                                       |
| 25                                                                                                                                                                       | ←         |    | RRG CONNECTION SETUP            |                                                                                                                                                                                                       |
| 26                                                                                                                                                                       | →         |    | RRG CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                       |
| 27                                                                                                                                                                       | →         |    | PAGING RESPONSE                 | Mobile identity = TMSI-1                                                                                                                                                                              |
| 28                                                                                                                                                                       | ←         |    | RRG CONNECTION RELEASE          | After sending of this message, the SS waits for disconnection of the CS signalling link.                                                                                                              |
| 29                                                                                                                                                                       | →         |    | RRG CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                       |
| 30                                                                                                                                                                       | ←         |    | PAGING TYPE1                    | Mobile identity = P-TMSI-1<br>Paging order is for PS services.                                                                                                                                        |
| 30a                                                                                                                                                                      | →         |    | RRG CONNECTION REQUEST          |                                                                                                                                                                                                       |
| 30b                                                                                                                                                                      | ←         |    | RRG CONNECTION SETUP            |                                                                                                                                                                                                       |
| 30c                                                                                                                                                                      | →         |    | RRG CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                       |
| 31                                                                                                                                                                       | →         |    | SERVICE REQUEST                 | service type = "paging response"                                                                                                                                                                      |
| 31a                                                                                                                                                                      | ←         |    | RRG CONNECTION RELEASE          |                                                                                                                                                                                                       |
| 31b                                                                                                                                                                      | →         |    | RRG CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                       |
| 32                                                                                                                                                                       |           | SS |                                 | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Suitable neighbour cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note) |
| 33                                                                                                                                                                       |           | UE |                                 | No ROUTING AREA UPDATE REQUEST sent to SS<br>(SS waits 30 seconds).                                                                                                                                   |
| 34                                                                                                                                                                       | ←         |    | PAGING TYPE1                    | Mobile identity = P-TMSI-2<br>Paging order is for PS services.                                                                                                                                        |
| 35                                                                                                                                                                       |           | UE |                                 | No response from the UE to the request. This is checked for 10 seconds.                                                                                                                               |
| NOTE: The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                                                                       |

#### 12.4.2.5a.4.2 Test procedure2

##### Initial condition

##### System Simulator:

- Two cells, cell A in MCC2/MNC1/LAC1/RAC1 (RAI-2), cell B in MCC2/MNC1/LAC2/RAC1 (RAI-6). Both cells are operating in network operation mode I.

##### User Equipment:

- The UE has a valid IMSI. UE is Idle Updated on cell A.

##### Related ICS/IXIT statements

- Support of PS service — Yes/No
- UE operation mode A — Yes/No
- USIM removal possible without powering down — Yes/No
- Switch off on button — Yes/No
- Automatic PS attach procedure at switch on or power on — Yes/No

### Test procedure

The SS rejects a combined routing area updating with the cause value 'Roaming not allowed in this area'. The UE is switched off for 10 seconds and switched on again. The SS checks that a combined PS attach is possible on the cell on which the previous combined routing area updating had been rejected.

If USIM removal is possible without switching off:

The SS rejects a routing area updating with the cause value 'Roaming not allowed in this area'. The USIM is removed and inserted in the UE. The SS checks that a PS attach procedure and routing area updating procedure is possible on the cell on which the routing area updating had previously been rejected.



## Expected Sequence

| Step | Direction |    | Message                     | Comments                                                                                                                                                                                                |
|------|-----------|----|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                                                                                         |
| 1    |           | SS |                             | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>(see note)   |
| 2    | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                  |
| 3    | →         |    | ATTACH REQUEST              | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                     |
| 4    | ←         |    | ATTACH ACCEPT               | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-2<br>Mobile identity = TMSI-1 |
| 5    | →         |    | ATTACH COMPLETE             |                                                                                                                                                                                                         |
| 7    |           | SS |                             | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Suitable neighbour cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)   |
| 8    | UE        |    |                             | Cell B is preferred by the UE.                                                                                                                                                                          |
| 9    | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-2                                                                                                          |
| 10   | ←         |    | ROUTING AREA UPDATE REJECT  | GMM cause = 'Roaming not allowed in this area'                                                                                                                                                          |
| 11   | UE        |    |                             | The UE initiates an attach by MMI or by AT command.                                                                                                                                                     |
| 12   | UE        |    |                             | No ATTACH REQUEST sent to SS<br>(SS waits 30 seconds).                                                                                                                                                  |
| 13   | ←         |    | PAGING TYPE1                | Mobile identity = P-TMSI-2<br>Paging order is for PS services.                                                                                                                                          |
| 14   | UE        |    |                             | No response from the UE to the request. This is checked for 10 seconds.                                                                                                                                 |
| 15   | ←         |    | PAGING TYPE1                | Mobile identity = TMSI-1<br>Paging order is for CS services.                                                                                                                                            |
| 16   | UE        |    |                             | The UE shall not initiate an RRC connection. This is checked during 3 seconds.                                                                                                                          |
| 17   | UE        |    |                             | If possible (see ICS) USIM removal is performed. Otherwise if possible (see ICS) switch off is performed. Otherwise the power is removed.                                                               |
| 18   | UE        |    |                             | The UE gets the USIM replaced, is powered up or switched on.                                                                                                                                            |
| 18a  | UE        |    | Registration on CS          | See TS 34.108<br>This step is applied only for non-auto attach UE.<br>Location Update Procedure initiated from the UE.                                                                                  |
| 19   | UE        |    |                             | The UE initiates an attach automatically (see ICS) by MMI or AT command.                                                                                                                                |
| 20   | →         |    | ATTACH REQUEST              | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                     |
| 21   | ←         |    | ATTACH ACCEPT               | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-6<br>Mobile identity = TMSI-1 |
| 22   | →         |    | ATTACH COMPLETE             |                                                                                                                                                                                                         |

| Step                                                                                                                                                                       | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                    |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                            | UE        | SS |                                 |                                                                                                                                                                                                                                                             |
| 23                                                                                                                                                                         | ←         |    | PAGING TYPE1                    | Mobile identity = TMSI-1<br>Paging order is for CS services.<br><br>Mobile identity = TMSI-1<br>After sending of this message, the SS waits for disconnection of the CS signalling link.                                                                    |
| 24                                                                                                                                                                         | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                             |
| 25                                                                                                                                                                         | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                             |
| 26                                                                                                                                                                         | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                             |
| 27                                                                                                                                                                         | →         |    | PAGING RESPONSE                 |                                                                                                                                                                                                                                                             |
| 28                                                                                                                                                                         | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                             |
| 29                                                                                                                                                                         | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                             |
| 30                                                                                                                                                                         | ←         |    | PAGING TYPE1                    | Mobile identity = P-TMSI-1<br><br><br><br>service type = "paging response"<br><br><br><br><br>The UE is switched off or power is removed (see ICS).<br>Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS/IMSI detach' |
| 30a                                                                                                                                                                        | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                                                                                             |
| 30b                                                                                                                                                                        | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                                                                                             |
| 30c                                                                                                                                                                        | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                                                                                             |
| 31                                                                                                                                                                         | →         |    | SERVICE REQUEST                 |                                                                                                                                                                                                                                                             |
| 31a                                                                                                                                                                        | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                             |
| 31b                                                                                                                                                                        | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                             |
| 32                                                                                                                                                                         | UE        |    |                                 |                                                                                                                                                                                                                                                             |
| 33                                                                                                                                                                         | →         |    | DETACH REQUEST                  |                                                                                                                                                                                                                                                             |
| NOTE: — The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                 |                                                                                                                                                                                                                                                             |

### Specific message contents

None.

### 12.4.2.5a.5 Test requirements

#### Test requirements for Test procedure1

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with information elements specified in the above Expected Sequence.

At step9, when the RF level of the attached cell is lower than the RF level of the new cell, UE shall:

- initiate the combined routing area update procedure (Update type = 'Combined RA/LA updating') with the information elements specified above Expected Sequence

At step12, when the SS rejects the combined routing area update procedure with GMM cause = 'Roaming not allowed in this area', UE shall:

- not initiate a PS attach procedure.

At step14, when the UE receives the paging message for PS domain, UE shall;

- not respond to the paging message for PS domain.

At step16, when the UE receives the paging message for CS domain, UE shall:

- not respond to the paging message for CS domain.

At step20, UE shall:

- initiate the combined PS attach procedure.

At step27, when the UE receives the paging message for CS domain, UE shall:

- respond to the paging message for CS domain by sending the PAGING RESPONSE message.

At step31, when the UE receives the paging message for PS domain, UE shall:

- respond to the paging message for PS domain by sending the SERVICE REQUEST message.

At step35, when the UE receives the paging message for PS domain, UE shall:

- not respond to the paging message for PS domain.

## Test requirements for Test procedure2

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with information elements specified in the above Expected Sequence.

At step9, UE shall:

- initiate the combined routing area update procedure (Update type = 'Combined RA/LA updating') with the information elements specified above Expected Sequence.

At step14, when the UE receives the paging message for PS domain, UE shall:

- not respond to the paging message for PS domain.

At step16, when the UE receives the paging message for CS domain, UE shall:

- not respond to the paging message for CS domain.

At step20, UE shall:

- initiate the combined PS attach procedure.

At step27, when the UE receives the paging message for CS domain, UE shall:

- respond to the paging message for CS domain by sending the PAGING RESPONSE message.

At step31, when the UE receives the paging message for PS domain, UE shall:

- respond to the paging message for PS domain by sending the SERVICE REQUEST message.

## 12.4.2.5b ~~Combined routing area updating / rejected / No Suitable Cells In Location Area.~~

### 12.4.2.5b.1 ~~Definition~~

### 12.4.2.5b.2 ~~Conformance requirement~~

- 1) If the network rejects a combined routing area updating procedure from the User Equipment with the cause 'No Suitable Cells In Location Area', the User Equipment shall:
  - 1.1 delete the stored RAI, PS-CKSN, P-TMSI and P-TMSI signature.
  - 1.2 store the LA or the PLMN identity in the 'forbidden location areas for roaming'.
  - 1.3 search for a suitable cell in a different location area on the same PLMN.
- 2) An MS that receives a ROUTING AREA UPDATE REJECT message stops timer T3330, enters state MM IDLE and for all causes except #12, #14 and #15 deletes the list of "equivalent PLMNs".

## Reference

3GPP TS 24.008 clauses 4.7.5.2.4

### ~~12.4.2.5b.3~~ ———— Test purpose

~~To test the behaviour of the UE if the network rejects a combined routing area updating procedure of the UE with the cause 'No Suitable Cells In Location Area'.~~

~~To test that the UE deletes the list of forbidden LAs when power is switched off.~~

### ~~12.4.2.5b.4~~ ———— Method of test

## ~~Initial condition~~

### ~~System Simulator:~~

~~—— Five cells, cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC2/RAC1 (RAI-3), cell C in MCC2/MNC1/LAC1/RAC1 (RAI-2), cell D in MCC1/MNC1/LAC1/RAC2 (RAI-4), cell E in MCC1/MNC2/LAC1/RAC1 (RAI-5).~~

~~—— All five cells are operating in network operation mode II.~~

~~The PLMN contains Cell A, B and D is equivalent to the PLMN that contains Cell E.~~

### ~~User Equipment:~~

~~—— The UE has valid IMSI.~~

## Related ICS/IXIT statements

~~—— Support of PS service——Yes/No~~

~~UE operation mode A——Yes/No~~

~~USIM removal possible without powering down——Yes/No~~

~~Switch off on button——Yes/No~~

~~Automatic PS attach procedure at switch on or power on——Yes/No~~

## Test procedure

~~The SS rejects a combined routing area updating with the cause value 'No Suitable Cells In Location Area'. The SS checks that the UE shall perform PS attach procedure when the UE enters a suitable cell in a different location area on the same PLMN.~~

## Expected Sequence

| Step | Direction |    | Message                     | Comments                                                                                                                                                                                                                                                                                                                                                                                 |
|------|-----------|----|-----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                                                                                                                                                                                                                                                                          |
| 1    |           | SS |                             | The following message are sent and shall be received on cell D.<br>Set the cell type of cell A to the "Suitable neighbour cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>Set the cell type of cell C to the "Suitable neighbour cell".<br>Set the cell type of cell D to the "Serving cell".<br>Set the cell type of cell E to the "Off cell".<br>(see note) |
| 2    | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS). Cell D is preferred by the UE.                                                                                                                                                                                                                                                                                    |
| 3    | ->        |    | ATTACH-REQUEST              | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                                                                                                                                                                                                      |
| 4    | <-        |    | ATTACH-ACCEPT               | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-4<br>Mobile identity = IMSI                                                                                                                                                                                    |
| 5    | ->        |    | ATTACH-COMPLETE             | Equivalent PLMN: MCC = 1, MNC=2                                                                                                                                                                                                                                                                                                                                                          |
| 6    |           | SS |                             | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>Set the cell type of cell C to the "Suitable neighbour cell".<br>Set the cell type of cell D to the "Off cell".<br>(see note)<br>The SS configures power level of each Cell as follows:<br>Cell A > Cell B = Cell C<br>Cell A is preferred by the UE.             |
| 7    | ->        |    | ROUTING-AREA-UPDATE REQUEST | Update type = 'Combined RA/LA updating'<br>P-TMSI-1 signature<br>Routing area identity = RAI-4                                                                                                                                                                                                                                                                                           |
| 8    | <-        |    | ROUTING-AREA-UPDATE REJECT  | GMM-cause = 'No Suitable Cells In Location Area'                                                                                                                                                                                                                                                                                                                                         |
| 9    | ->        |    | ATTACH-REQUEST              | The following message are sent and shall be received on cell B.<br>Attach type = 'Combined PS / IMSI attached'<br>Mobile identity = IMSI                                                                                                                                                                                                                                                 |
| 10   | <-        |    | ATTACH-ACCEPT               | Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-3<br>Equivalent PLMN: MCC = 1, MNC=2                                                                                                                                                                                                                    |
| 11   | ->        |    | ATTACH-COMPLETE             |                                                                                                                                                                                                                                                                                                                                                                                          |
| 12   |           | SS |                             | Set the cell type of cell D to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>Set the cell type of cell E to the "Suitable neighbour cell".<br>(note)<br>The SS deactivates Cell B and activates Cell D and Cell E<br>The SS configures power level of each Cell as follows:<br>Cell D > Cell E<br>Cell D is preferred by the UE.               |
| 13   |           |    |                             |                                                                                                                                                                                                                                                                                                                                                                                          |

|                                                                                                                                                                                      |    |                             |                                                                                                                                    |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----|-----------------------------|------------------------------------------------------------------------------------------------------------------------------------|
| 14                                                                                                                                                                                   | -> | ROUTING-AREA UPDATE REQUEST | Update type = 'Combined RA/LA updating'<br>P-TMSI-1 signature<br>Routing-area identity = RAI-4                                     |
| 15                                                                                                                                                                                   | <- | ROUTING-AREA UPDATE REJECT  | GMM cause = 'No Suitable Cells In Location Area'                                                                                   |
| 16                                                                                                                                                                                   |    |                             | The following message are sent and shall be received on cell E.                                                                    |
| 17                                                                                                                                                                                   | -> | ATTACH REQUEST              | Attach type = 'Combined PS / IMSI attached'<br>Mobile identity = IMSI                                                              |
| 18                                                                                                                                                                                   | <- | ATTACH ACCEPT               | Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-3<br>P-TMSI-3 signature<br>Routing-area identity = RAI-5 |
| 19                                                                                                                                                                                   | -> | DETACH REQUEST              | Equivalent PLMN: MCC=1, MNC=1<br>Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'            |
| NOTE: The definitions for "Suitable neighbour cell", "Serving cell" and "Off cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |    |                             |                                                                                                                                    |

### Specific message contents

None.

#### 12.4.2.5b.5 Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the Combined PS attach procedure with the information elements specified in the above Expected Sequence.

At step7, when the RF level of the attached cell is lower than the RF level of the new cell, UE shall:

- initiate the combined routing area update procedure.

At step 8, the UE shall maintain the equivalent PLMN list (MCC=1, MNC=2).

At step9, when the UE enters a suitable cell in a different location area on the same PLMN, UE shall:

- perform the PS attach procedure.

At step 15, the UE shall maintain the equivalent PLMN list (MCC=1, MNC=2).

At step 17, when the UE enters a suitable cell in a different but equivalent PLMN (MCC=1, MNC=2), UE shall:

- perform the PS attach procedure.

#### 12.4.2.6 Combined routing area updating / abnormal cases / access barred due to access class control

##### 12.4.2.6.1 Definition

##### 12.4.2.6.2 Conformance requirement

- 1) The UE shall not perform combined routing area updating procedure, but stays in the current serving cell and applies normal cell reselection process.
- 2) The User Equipment shall perform the combined routing area updating procedure when:
  - 2.1 Access is granted.
  - 2.2 Cell is changed.

## Reference

3GPP TS 24.008 clause 4.7.5.2.

### 12.4.2.6.3 ——— Test purpose

#### Test purpose1

To test the behaviour of the UE in case of access class control (access is granted).

#### Test purpose2

To test the behaviour of the UE in case of access class control (cell is changed).

### 12.4.2.6.4 ——— Method of test

#### 12.4.2.6.4.1 ——— Test procedure1

#### Initial condition

An access class x (0-15) is arbitrarily chosen. The USIM is programmed with this access class x. Communication with User Equipments using access class x is initially indicated to be barred on Cell B.

#### System Simulator:

- Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1) has Access Class x not barred, cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4) has Access Class x barred.
- Both cells are operating in network operation mode I.

#### User Equipment:

- The UE has valid IMSI. UE is Idle Updated on cell A.

#### Related ICS/IXIT statements

- Support of PS service — Yes/No
- UE operation mode A — Yes/No
- Switch off on button — Yes/No
- Automatic PS attach procedure at switch on or power on — Yes/No

#### Test procedure

A PS attach procedure is performed. The routing area is changed. The SS indicates access class x barred. A routing area updating procedure is not performed.

The SS indicates that access class x is not barred. A routing area updating procedure is performed.

## Expected Sequence

| Step                                                                                                                                                        | Direction |    | Message                      | Comments                                                                                                                                                                                           |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                             | UE        | SS |                              |                                                                                                                                                                                                    |
| 1                                                                                                                                                           |           | SS |                              | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note)             |
| 2                                                                                                                                                           | UE        |    |                              | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                             |
| 3                                                                                                                                                           | →         |    | ATTACH REQUEST               | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                |
| 4                                                                                                                                                           | ←         |    | ATTACH ACCEPT                | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                        |
| 5                                                                                                                                                           | →         |    | ATTACH COMPLETE              | Mobile identity = IMSI                                                                                                                                                                             |
| 6                                                                                                                                                           |           | SS |                              | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)             |
| 7                                                                                                                                                           | UE        |    |                              | Cell B is preferred by the UE.                                                                                                                                                                     |
| 8                                                                                                                                                           | UE        |    |                              | No ROUTING AREA UPDATE REQUEST sent to SS, as access class x is barred<br>(SS waits 30 seconds).                                                                                                   |
| 9                                                                                                                                                           |           | SS |                              | The access class x is not barred anymore.                                                                                                                                                          |
| 10                                                                                                                                                          | →         |    | ROUTING AREA UPDATE REQUEST  | Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                                     |
| 11                                                                                                                                                          | ←         |    | ROUTING AREA UPDATE ACCEPT   | TMSI status = no valid TMSI available<br>Update result = 'Combined RA/LA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-4 |
| 12                                                                                                                                                          | →         |    | ROUTING AREA UPDATE COMPLETE |                                                                                                                                                                                                    |
| 13                                                                                                                                                          | UE        |    |                              | The UE is switched off or power is removed<br>(see ICS).                                                                                                                                           |
| 14                                                                                                                                                          | →         |    | DETACH REQUEST               | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS/IMSI detach'                                                                                               |
| NOTE: — The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                              |                                                                                                                                                                                                    |

## Specific message contents

None.

## 12.4.2.6.4.2 — Test procedure2

## Initial condition

An access class x (0-15) is arbitrarily chosen. The USIM is programmed with this access class x. Communication with User Equipments using access class x is indicated to be barred on cell B.

## System Simulator:

- Three cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1) has access class x not barred, cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4) has access class x barred, cell C in



~~MCC1/MNC1/LAC1/RAC2 (RAI-4) has access class x not barred.  
All three cells are operating in network operation mode I.~~

~~User Equipment:~~

~~—The UE has a valid IMSI.~~

~~Related ICS/IXIT statements~~

~~—Support of PS service—Yes/No~~

~~UE operation mode A—Yes/No~~

~~Switch off on button—Yes/No~~

~~Automatic PS attach procedure at switch on or power on—Yes/No~~

~~Test procedure~~

~~A PS attach procedure is performed. The routing area is changed. The SS indicates access class x barred. A routing area updating procedure is not performed.~~

~~A cell change is performed into a cell where access class x is not barred. A routing area updating procedure is performed.~~

## Expected Sequence

| Step                                                                                                                                                      | Direction |    | Message                      | Comments                                                                                                                                                                                                                                 |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                           | UE        | SS |                              |                                                                                                                                                                                                                                          |
| 1                                                                                                                                                         |           | SS |                              | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Off cell".<br>(see note) |
| 2                                                                                                                                                         | UE        |    |                              | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                                                   |
| 3                                                                                                                                                         | →         |    | ATTACH REQUEST               | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                                                      |
| 4                                                                                                                                                         | ←         |    | ATTACH ACCEPT                | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                              |
| 5                                                                                                                                                         | →         |    | ATTACH COMPLETE              | Mobile identity = IMSI                                                                                                                                                                                                                   |
| 6                                                                                                                                                         |           | SS |                              | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)                                                   |
| 7                                                                                                                                                         | UE        |    |                              | Cell B is preferred by the UE.                                                                                                                                                                                                           |
| 8                                                                                                                                                         | UE        |    |                              | No ROUTING AREA UPDATE REQUEST sent to SS, as access class x is barred (SS waits 30 seconds).                                                                                                                                            |
| 9                                                                                                                                                         |           | SS |                              | The following messages are sent and shall be received on cell C.<br>Set the cell type of cell B to the "Off cell".<br>Set the cell type of cell C to the "Serving cell".<br>(see note)                                                   |
| 10                                                                                                                                                        | UE        |    |                              | Cell C is preferred by the UE.                                                                                                                                                                                                           |
| 11                                                                                                                                                        | →         |    | ROUTING AREA UPDATE REQUEST  | Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                                                                           |
| 12                                                                                                                                                        | ←         |    | ROUTING AREA UPDATE ACCEPT   | TMSI status = no valid TMSI available<br>Update result = 'Combined RA/LA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-4                                       |
| 13                                                                                                                                                        | →         |    | ROUTING AREA UPDATE COMPLETE |                                                                                                                                                                                                                                          |
| 14                                                                                                                                                        | UE        |    |                              | The UE is switched off or power is removed (see ICS).                                                                                                                                                                                    |
| 15                                                                                                                                                        | →         |    | DETACH REQUEST               | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS/IMSI detach'                                                                                                                                     |
| NOTE: The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                              |                                                                                                                                                                                                                                          |

## Specific message contents

None.

## 12.4.2.6.5 Test requirements

## Test requirements for Test procedure1

At step3, when the UE is powered up or switched on, UE shall:

—initiate the combined PS attach procedure with information elements specified in the above Expected Sequence.

At step8, when the access class x is barred, UE shall:

—not perform the combined routing area updating procedure.

At step10, when the access class x is not barred, UE shall:

—perform the combined routing area updating procedure.

#### Test requirements for Test procedure2

At step3, when the UE is powered up or switched on, UE shall:

—initiate the combined PS attach procedure with information elements specified in the above Expected Sequence.

At step8, when the access class x is barred UE shall:

—not perform the combined routing area updating procedure.

At step11, when the serving cell is changed, UE shall:

—perform the combined routing area updating procedure.

### ~~12.4.2.7 Combined routing area updating / abnormal cases / attempt counter check / procedure timeout~~

#### ~~12.4.2.7.1 Definition~~

#### ~~12.4.2.7.2 Conformance requirement~~

- ~~1) When a T3330 timeout has occurred during a routing area updating procedure, the UE shall repeat the routing area updating procedure after T3330 timeout until the procedure is repeated five times.~~
- ~~2) When a routing area updating procedure is repeated five times, the routing area updating attempt counter is incremented and five more routing area updating procedures are performed. This procedure is repeated until the routing area updating attempt counter is five, the UE shall then start timer T3302.~~
- ~~3) When the T3302 expire, a new routing area updating procedure shall be initiated.~~

#### Reference

3GPP TS 24.008 clause 4.7.5.2.

#### ~~12.4.2.7.3 Test purpose~~

To test the behaviour of the UE with respect to the attempt counter.

#### ~~12.4.2.7.4 Method of test~~

#### Initial condition

##### System Simulator:

- Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4).
- Both cells are operating in network operation mode L.

##### User Equipment:

- The UE has a valid IMSI. UE is Idle Updated on cell A.

### Related ICS/IXIT statements

- Support of PS service—Yes/No
- UE operation mode A—Yes/No
- Switch off on button—Yes/No
- Automatic PS attach procedure at switch on or power on—Yes/No

### Test procedure

The UE initiates a routing area updating procedure (routing area updating attempt counter zero). The SS does not answer with ROUTING AREA UPDATE ACCEPT message before T3330 timeout. The UE restarts the routing area updating procedure four times. The SS never answers with ROUTING AREA UPDATE ACCEPT message before T3330 timeout. After five consecutive routing area update procedures, the routing area updating attempt counter is incremented and T3311 is started.

The UE initiates a new routing area updating procedure (routing area updating attempt counter one) after T3311 expires. The SS does not answer with ROUTING AREA UPDATE ACCEPT message before T3330 timeout. The UE restarts the routing area updating procedure four times. The SS never answers with ROUTING AREA UPDATE ACCEPT message before T3330 timeout. After five consecutive routing area update procedures, the routing area updating attempt counter is incremented and T3311 is started.

The UE initiates a new routing area updating procedure (routing area updating attempt counter two) after T3311 expires. The SS does not answer with ROUTING AREA UPDATE ACCEPT message before T3330 timeout. The UE restarts the routing area updating procedure four times. The SS never answers with ROUTING AREA UPDATE ACCEPT message before T3330 timeout. After five consecutive routing area update procedures, the routing area updating attempt counter is incremented and T3311 is started.

The UE initiates a new routing area updating procedure (routing area updating attempt counter three) after T3311 expires. The SS does not answer with ROUTING AREA UPDATE ACCEPT message before T3330 timeout. The UE restarts the routing area updating procedure four times. The SS never answers with ROUTING AREA UPDATE ACCEPT message before T3330 timeout. After five consecutive routing area update procedures, the routing area updating attempt counter is incremented and T3311 is started.

The UE initiates a new routing area updating procedure (routing area updating attempt counter four) after T3311 expires. The SS does not answer with ROUTING AREA UPDATE ACCEPT message before T3330 timeout. The UE restarts the routing area updating procedure four times. The SS never answers with ROUTING AREA UPDATE ACCEPT message before T3330 timeout. After five consecutive routing area update procedures, the routing area updating attempt counter is incremented and as the routing area updating attempt counter is five, T3302 is started.

The UE performs a Location Update procedure.

The UE initiates a routing area updating procedure with routing area updating attempt counter zero after T3302 expires with the stored P-TMSI, P-TMSI signature, PS-CKSN and RAU.

T3302; set to 12 minutes.

T3311; 15 seconds.

T3330; 15 seconds.

## Expected Sequence

| Step | Direction |    | Message                     | Comments                                                                                                                                                                                                                                                                            |
|------|-----------|----|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                                                                                                                                                                     |
| 1    |           | SS |                             | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note)                                                                                              |
| 2    | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                                                                                              |
| 3    | →         |    | ATTACH REQUEST              | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                                                                                                 |
| 4    | ←         |    | ATTACH ACCEPT               | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                                         |
| 5    | →         |    | ATTACH COMPLETE             | Mobile identity = IMSI                                                                                                                                                                                                                                                              |
| 6    |           | SS |                             | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)                                                                                              |
| 7    | UE        |    |                             | Cell B is preferred by the UE.<br>K = 1.                                                                                                                                                                                                                                            |
| 8    | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>TMSI status = no valid TMSI available<br>Routing area updating attempt counter = k (k is not visible. It is only used for clarifying the sequence.)<br>Retransmission counter = 0 |
| 9    |           | SS |                             | No response is given from the SS.                                                                                                                                                                                                                                                   |
| 10   |           | SS |                             | The SS verifies that the time between the RA update requests is T3330seconds                                                                                                                                                                                                        |
| 11   | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>TMSI status = no valid TMSI available<br>Routing area updating attempt counter = k<br>Retransmission counter = 1                                                                  |
| 12   |           | SS |                             | No response is given from the SS.                                                                                                                                                                                                                                                   |
| 13   |           | SS |                             | The SS verifies that the time between the RA update requests is T3330seconds                                                                                                                                                                                                        |
| 14   | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>TMSI status = no valid TMSI available<br>Routing area updating attempt counter = k<br>Retransmission counter = 2                                                                  |
| 15   |           | SS |                             | No response is given from the SS.                                                                                                                                                                                                                                                   |
| 16   |           | SS |                             | The SS verifies that the time between the RA update requests is T3330seconds                                                                                                                                                                                                        |
| 17   | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>TMSI status = no valid TMSI available<br>Routing area updating attempt counter = k<br>Retransmission counter = 3                                                                  |
| 18   |           | SS |                             | No response is given from the SS.                                                                                                                                                                                                                                                   |
| 19   |           | SS |                             | The SS verifies that the time between the RA update requests is T3330seconds                                                                                                                                                                                                        |

| Step                                                                                                                                                      | Direction |    | Message                       | Comments                                                                                                                                                                                                           |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                           | UE        | SS |                               |                                                                                                                                                                                                                    |
| 20                                                                                                                                                        | →         |    | ROUTING AREA UPDATING REQUEST | Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>TMSI status = no valid TMSI available<br>Routing area updating attempt counter = k<br>Retransmission counter = 4 |
| 21                                                                                                                                                        |           | SS |                               | No response is given from the SS.                                                                                                                                                                                  |
| 22                                                                                                                                                        |           | SS |                               | The SS verifies that the time between the RA update requests is T3311 + T3330 seconds.                                                                                                                             |
| 23                                                                                                                                                        |           | SS |                               | Step 8—22 is repeated four times with k = 2, k = 3, k = 4 and k = 5                                                                                                                                                |
| 23a                                                                                                                                                       | UE        |    | Registration on CS            | The UE performs a normal location updating procedure.<br>See TS 34.108                                                                                                                                             |
| 24                                                                                                                                                        |           | SS |                               | The SS verifies that the time between the RA update requests is T3302 + T3330 seconds                                                                                                                              |
| 25                                                                                                                                                        | →         |    | ROUTING AREA UPDATE REQUEST   | Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>TMSI status = no valid TMSI available                                                                            |
| 26                                                                                                                                                        | ←         |    | ROUTING AREA UPDATE ACCEPT    | Update result = 'Combined RA/LA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = IMSI<br>Routing area identity = RAI-4                                                            |
| 27                                                                                                                                                        | →         |    | ROUTING AREA UPDATE COMPLETE  |                                                                                                                                                                                                                    |
| 28                                                                                                                                                        | UE        |    |                               | The UE is switched off or power is removed (see ICS).                                                                                                                                                              |
| 29                                                                                                                                                        | →         |    | DETACH REQUEST                | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS/IMSI detach'                                                                                                               |
| NOTE: The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                               |                                                                                                                                                                                                                    |

### Specific message contents

None.

### 12.4.2.7.5 Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with information elements specified in the above Expected Sequence.

At step8, when the RF level of the attached cell is lower than the RF level of the new cell, UE shall:

- initiate the combined routing area updating procedure with information elements specified in the above Expected Sequence.

UE shall perform the following actions depending on the conditions described below.

- Case 1) A timer T3330 timeout has occurred during a combined routing area updating procedure with the Routing area attempt counter less than five and the Retransmission counter less than five

At step11, 14, 17 and 20, UE shall:

- repeat the combined routing area updating procedure after the timer T3330 timeout

- Case 2) A timer T3330 timeout has occurred during a combined routing area updating procedure with the Routing area attempt counter less than five and the Retransmission counter five

At step 22, UE shall:

— not repeat the combined routing area updating procedure.

Case 3) A timer T3311 timeout has occurred and the Routing area attempt counter is less than five,

At step23, UE shall:

— repeat the combined routing area updating procedure

— Case 4) A timer T3330 timeout has occurred during a combined routing area updating procedure with the Routing area attempt counter five and the Retransmission-counter five.

At step24, UE shall:

— not initiate a routing area updating procedure.

Case5) The timer T3302 expires

At step25, UE shall:

— initiate the new routing area updating procedure

## ~~12.4.2.8 Combined routing area updating / abnormal cases / change of cell into new routing area~~

### ~~12.4.2.8.1 Definition~~

### ~~12.4.2.8.2 Conformance requirement~~

When a change of cell into a new routing area is performed before the routing area updating procedure is finished, the UE shall abort the routing area updating procedure and re-initiate it in the new routing area.

### Reference

3GPP TS 24.008 clause 4.7.5.2.

### ~~12.4.2.8.3 Test purpose~~

To test the behaviour of the UE in case of procedure collision.

### ~~12.4.2.8.4 Method of test~~

### Initial condition

#### System Simulator:

- Three cells, cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4), cell C in MCC1/MNC1/LAC1/RAC3 (RAI-5).
- All three cells are operating in network operation mode I.

#### User Equipment:

- The UE has a valid IMSI.

### Related ICS/IXIT statements

- Support of PS service — Yes/No
- UE operation mode A — Yes/No
- Switch off on button — Yes/No
- Automatic PS attach procedure at switch on or power on — Yes/No

### Test procedure

The UE initiates a routing area updating procedure. The ROUTING AREA UPDATE ACCEPT message is delayed from the SS. The UE performs a cell update into a new routing area. The UE shall re-initiate a routing area updating procedure in the new routing area. The UE shall not increment the attempt counter.



## Expected Sequence

| Step | Direction |    | Message                     | Comments                                                                                                                                                                                                                                                               |
|------|-----------|----|-----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                                                                                                                                                        |
| 1    |           | SS | ATTACH-REQUEST              | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>Set the cell type of cell C to the "Suitable neighbour cell".<br>(see note) |
| 2    | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                                                                                 |
| 3    | →         |    |                             | Attach type = 'Combined PS / IMSI attach'                                                                                                                                                                                                                              |
| 4    | ←         |    |                             | Mobile identity = IMSI<br>TMSI status = no valid TMSI available                                                                                                                                                                                                        |
| 5    | →         |    |                             | Attach result = 'Combined PS / IMSI attached'                                                                                                                                                                                                                          |
| 6    |           | SS | ROUTING-AREA-UPDATE-REQUEST | Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>Mobile identity = IMSI                                                                                                                                                            |
| 7    | UE        |    |                             | The following messages are sent and shall be received on cell B.                                                                                                                                                                                                       |
| 8    | →         |    |                             | Set the cell type of cell A to the "Suitable neighbour cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)                                                                                                                                      |
| 9    | SS        |    |                             | Cell B is preferred by the UE.                                                                                                                                                                                                                                         |
| 10   |           | SS | ROUTING-AREA-UPDATE-REQUEST | Update type = 'Combined RA/LA updating'                                                                                                                                                                                                                                |
| 11   | UE        |    |                             | P-TMSI-2 signature                                                                                                                                                                                                                                                     |
| 12   | →         |    |                             | Routing area identity = RAI-1                                                                                                                                                                                                                                          |
| 13   | ←         |    |                             | TMSI status = no valid TMSI available                                                                                                                                                                                                                                  |
| 14   | →         |    | ROUTING-AREA-UPDATE-ACCEPT  | No response id given from the SS.                                                                                                                                                                                                                                      |
| 15   | UE        |    |                             | The following messages are sent and shall be received on cell C.                                                                                                                                                                                                       |
| 16   | →         |    |                             | Set the cell type of cell B to the "Suitable neighbour cell".<br>Set the cell type of cell C to the "Serving cell".<br>(see note)                                                                                                                                      |
| 17   | SS        |    |                             | The RF level of cell B is lowered, and the RF level of cell C is increased, until cell C is preferred by the UE.                                                                                                                                                       |
| 18   |           | SS | ROUTING-AREA-UPDATE-REQUEST | Update type = 'Combined RA/LA updating'                                                                                                                                                                                                                                |
| 19   | UE        |    |                             | P-TMSI-2 signature                                                                                                                                                                                                                                                     |
| 20   | →         |    |                             | Routing area identity = RAI-1                                                                                                                                                                                                                                          |
| 21   | ←         |    |                             | TMSI status = no valid TMSI available                                                                                                                                                                                                                                  |
| 22   | →         |    | ROUTING-AREA-UPDATE-ACCEPT  | Update result = 'Combined RA/LA updated'                                                                                                                                                                                                                               |
| 23   | UE        |    |                             | Mobile identity = P-TMSI-1                                                                                                                                                                                                                                             |
| 24   | →         |    |                             | P-TMSI-1 signature                                                                                                                                                                                                                                                     |
| 25   | SS        |    |                             | Mobile identity = IMSI                                                                                                                                                                                                                                                 |
| 26   |           | SS | ROUTING-AREA-UPDATE-REQUEST | Routing area identity = RAI-5                                                                                                                                                                                                                                          |
| 27   | UE        |    |                             | The UE is switched off or power is removed (see ICS).                                                                                                                                                                                                                  |
| 28   | →         |    |                             | Message not sent if power is removed.                                                                                                                                                                                                                                  |
| 29   | SS        |    |                             | Detach type = 'power switched off, combined PS/IMSI detach'                                                                                                                                                                                                            |

NOTE: The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only".

## Specific message contents

None.

#### 12.4.2.8.5 Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.

At step8, when the RF level of the attached cell is lower than the RF level of the new cell, UE shall:

- initiate the routing area update procedure.

At step12, when change of cell into new routing area is performed before the routing area updating procedure is finished, UE shall:

- abort the routing area updating procedure.
- re-initiate new routing area updating procedure in the new routing area.

#### 12.4.2.9 Combined routing area updating / abnormal cases / change of cell during routing area updating procedure

##### 12.4.2.9.1 Definition

##### 12.4.2.9.2 Conformance requirement

When a change of cell within new routing area is performed before the routing area updating procedure is finished, the UE shall perform the cell update before the routing area updating procedure is finished.

##### Reference

3GPP TS 24.008 clause 4.7.5.2.

##### 12.4.2.9.3 Test purpose

To test the behaviour of the UE in case of procedure collision.

##### 12.4.2.9.4 Method of test

##### Initial condition

System Simulator:

- Three cells, cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4), cell C in MCC1/MNC1/LAC1/RAC2 (RAI-4).
- All three cells are operating in network operation mode I.

User Equipment:

- The UE has a valid IMSI. UE is Idle Updated on cell A.

##### Related ICS/IXIT statements

- Support of PS service—Yes/No
- UE operation mode A—Yes/No
- Switch off on button—Yes/No
- Automatic PS attach procedure at switch on or power on—Yes/No

##### Test procedure

The UE initiates a routing area updating procedure. The ROUTING AREA UPDATE ACCEPT message is delayed from the SS. The UE performs a cell update within the routing area. The UE then waits for the ROUTING AREA UPDATE ACCEPT message.

## Expected Sequence

| Step                                                                                                                                                                       | Direction |    | Message                      | Comments                                                                                                                                                                                                                                                               |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                            | UE        | SS |                              |                                                                                                                                                                                                                                                                        |
| 1                                                                                                                                                                          |           | SS |                              | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>Set the cell type of cell C to the "Suitable neighbour cell".<br>(see note) |
| 2                                                                                                                                                                          | UE        |    |                              | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                                                                                 |
| 3                                                                                                                                                                          | →         |    | ATTACH REQUEST               | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                                                                                    |
| 4                                                                                                                                                                          | ←         |    | ATTACH ACCEPT                | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                            |
| 5                                                                                                                                                                          | →         |    | ATTACH COMPLETE              | Mobile identity = IMSI                                                                                                                                                                                                                                                 |
| 6                                                                                                                                                                          |           | SS |                              | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Suitable neighbour cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)                                                                  |
| 7                                                                                                                                                                          | UE        |    |                              | Cell B is preferred by the UE.                                                                                                                                                                                                                                         |
| 8                                                                                                                                                                          | →         |    | ROUTING AREA UPDATE REQUEST  | Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                                                                                                         |
| 9                                                                                                                                                                          |           | SS |                              | TMSI status = no valid TMSI available<br>No response id given from the SS.                                                                                                                                                                                             |
| 10                                                                                                                                                                         |           | SS |                              | The following messages are sent and shall be received on cell C.<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>Set the cell type of cell C to the "Serving cell".<br>(see note)                                                                  |
| 11                                                                                                                                                                         | UE        |    |                              | The RF level of cell B is lowered until cell C is preferred by the UE.                                                                                                                                                                                                 |
| 12a                                                                                                                                                                        | →         |    | CELL UPDATE                  | Cell update cause = 'cell reselection'                                                                                                                                                                                                                                 |
| 12b                                                                                                                                                                        | ←         |    | CELL UPDATE CONFIRM          |                                                                                                                                                                                                                                                                        |
| 13                                                                                                                                                                         | ←         |    | ROUTING AREA UPDATE ACCEPT   | Update result = 'Combined RA/LA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = IMSI<br>Routing area identity = RAI-4                                                                                                                |
| 14                                                                                                                                                                         | →         |    | ROUTING AREA UPDATE COMPLETE |                                                                                                                                                                                                                                                                        |
| 15                                                                                                                                                                         | UE        |    |                              | The UE is switched off or power is removed (see ICS).                                                                                                                                                                                                                  |
| 16                                                                                                                                                                         | →         |    | DETACH REQUEST               | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS/IMSI detach'                                                                                                                                                                   |
| NOTE: — The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                              |                                                                                                                                                                                                                                                                        |

## Specific message contents

None.

#### 12.4.2.9.5 ——— Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.

At step8, when the RF level of the attached cell is lower than the RF level of the new cell, UE shall:

- initiate routing area update procedure.

At step12a, when a change of cell within a new routing area is performed before the routing area updating procedure is finished, UE shall:

- perform the cell update.

#### 12.4.2.10 ——— Combined routing area updating / abnormal cases / PS detach procedure collision

##### 12.4.2.10.1 ——— Definition

##### 12.4.2.10.2 ——— Conformance requirement

- 1) When a detach request is received with cause 'PS detach' or 'combined PS/IMSI detach' by the UE while waiting for a ROUTING AREA UPDATE ACCEPT message, the UE shall terminate the routing area updating procedure and continue with the PS detach procedure.
- 2) When a detach request is received with cause 'IMSI detach' by the UE while waiting for a ROUTING AREA UPDATE ACCEPT message, the UE shall ignore the detach request and continue with the routing area updating procedure.

#### Reference

3GPP TS 24.008 clause 4.7.5.2.

##### 12.4.2.10.3 ——— Test purpose

To test the behaviour of the UE in case of procedure collision.

##### 12.4.2.10.4 ——— Method of test

##### 12.4.2.10.4.1 ——— Test procedure1

#### Initial condition

System Simulator:

- Two cells, cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4). Both cells are operating in network operation mode I.

User Equipment:

- The UE has a valid IMSI.

#### Related ICS/IXIT statements

- Support of PS service — Yes/No
- UE operation mode A — Yes/No
- Switch off on button — Yes/No
- Automatic PS attach procedure at switch on or power on — Yes/No

## Test procedure

The UE initiates a routing area updating procedure. The SS does not answer the routing area updating procedure, but initiates a PS detach procedure with cause 'PS detach' or 'combined PS/IMSI detach'. The UE shall terminate the routing area updating procedure and continue with the PS detach procedure.

## Expected Sequence

| Step                                                                                                                                                                     | Direction |    | Message                     | Comments                                                                                                                                                                                              |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                          | UE        | SS |                             |                                                                                                                                                                                                       |
| 1                                                                                                                                                                        |           | SS |                             | The following messages are sent and shall be received on cell A:<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>(see note) |
| 2                                                                                                                                                                        | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                |
| 3                                                                                                                                                                        | →         |    | ATTACH REQUEST              | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                   |
| 4                                                                                                                                                                        | ←         |    | ATTACH ACCEPT               | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                           |
| 5                                                                                                                                                                        | →         |    | ATTACH COMPLETE             | Mobile identity = IMSI                                                                                                                                                                                |
| 6                                                                                                                                                                        |           | SS |                             | The following messages are sent and shall be received on cell B:<br>Set the cell type of cell A to the "Suitable neighbour cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note) |
| 7                                                                                                                                                                        | UE        |    |                             | Cell B is preferred by the UE.                                                                                                                                                                        |
| 8                                                                                                                                                                        | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                                        |
| 9                                                                                                                                                                        |           | SS |                             | TMSI status = no valid TMSI available<br>The SS ignores the ROUTING AREA UPDATE REQUEST message and initiates a detach procedure.                                                                     |
| 10                                                                                                                                                                       | ←         |    | DETACH REQUEST              | Detach type = 're-attach not required'                                                                                                                                                                |
| 11                                                                                                                                                                       | →         |    | DETACH ACCEPT               |                                                                                                                                                                                                       |
| NOTE: The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                             |                                                                                                                                                                                                       |

## Specific message contents

None.

## 12.4.2.10.4.2 Test procedure2

### Initial condition

### System Simulator:

Two cells, cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4).  
Both cells are operating in network operation mode 1.

### User Equipment:

The UE has a valid P-TMSI, P-TMSI signature and RAI.

#### Related ICS/IXIT statements

Support of PS service—Yes/No

UE operation mode A—Yes/No

Switch off on button—Yes/No

Automatic PS attach procedure at switch on or power on—Yes/No

#### Test procedure

The UE initiates a routing area updating procedure. The SS does not answer the routing area updating procedure, but initiates a PS detach procedure with cause 'IMSI detach'. The UE shall ignore the detach procedure and continue with the routing area updating procedure.

## Expected Sequence

| Step                                                                                                                                                                     | Direction |    | Message                      | Comments                                                                                                                                                                                              |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                          | UE        | SS |                              |                                                                                                                                                                                                       |
| 1                                                                                                                                                                        |           | SS |                              | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>(see note) |
| 2                                                                                                                                                                        | UE        |    |                              | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                |
| 3                                                                                                                                                                        | →         |    | ATTACH REQUEST               | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                   |
| 4                                                                                                                                                                        | ←         |    | ATTACH ACCEPT                | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>Mobile identity = IMSI |
| 5                                                                                                                                                                        | →         |    | ATTACH COMPLETE              |                                                                                                                                                                                                       |
| 6                                                                                                                                                                        |           | SS |                              | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Suitable neighbour cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note) |
| 7                                                                                                                                                                        | UE        |    |                              | Cell B is preferred by the UE.                                                                                                                                                                        |
| 8                                                                                                                                                                        | →         |    | ROUTING AREA UPDATE REQUEST  | Update type = 'Combined RA/LA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>TMSI status = no valid TMSI available                                                               |
| 9                                                                                                                                                                        |           | SS |                              | The SS ignores the ROUTING AREA UPDATE REQUEST message and initiates a detach procedure.                                                                                                              |
| 10                                                                                                                                                                       | ←         |    | DETACH REQUEST               | Detach type = 'IMSI detach'                                                                                                                                                                           |
| 11                                                                                                                                                                       | UE        |    |                              | The UE ignores the DETACH REQUEST message and continue the routing area updating procedure.                                                                                                           |
| 12                                                                                                                                                                       | ←         |    | ROUTING AREA UPDATE ACCEPT   | Update result = 'Combined RA/LA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = IMSI<br>Routing area identity = RAI-4                                               |
| 13                                                                                                                                                                       | →         |    | ROUTING AREA UPDATE COMPLETE |                                                                                                                                                                                                       |
| 14                                                                                                                                                                       | UE        |    |                              | The UE is switched off or power is removed (see ICS).                                                                                                                                                 |
| 15                                                                                                                                                                       | →         |    | DETACH REQUEST               | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS/IMSI detach'                                                                                                  |
| NOTE: The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                              |                                                                                                                                                                                                       |

## Specific message contents

None.

## 12.4.2.10.5 Test requirements

## Test requirements for Test procedure1

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.

At step8, when the RF level of the attached cell is lower than the RF level of the new cell, UE shall:

- initiate routing area update procedure.

At step11, when the UE receives a DETACH REQUEST message with cause 'PS detach' or 'combined PS/IMSI detach' from SS while waiting for a ROUTING AREA UPDATE ACCEPT message, UE shall:

- terminate the routing area updating procedure
- continue with the PS detach procedure.

#### Test requirements for Test procedure2

At step3, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.

At step8, when the RF level of the attached cell is lower than the RF level of the new cell, UE shall:

- initiate routing area update procedure.

At step11, the UE receives a DETACH REQUEST message with cause 'IMSI detach' from SS while waiting for a ROUTING AREA UPDATE ACCEPT message, UE shall:

- ignore the detach request procedure.
- continue with the routing area updating procedure.

### 12.4.3 Periodic routing area updating

#### 12.4.3.1 Periodic routing area updating / accepted

##### 12.4.3.1.1 Definition

##### 12.4.3.1.2 Conformance requirement

The User Equipment shall perform a periodic routing area update procedure after a T3312 timeout.

#### Reference

3GPP TS 24.008 clauses 4.7.2.2 and 4.7.5.1.

##### 12.4.3.1.3 Test purpose

To test the behaviour of the UE with respect to the periodic routing area updating procedure.

##### 12.4.3.1.4 Method of test

#### Initial condition

System Simulator:

One cell operating in network operation mode II (in case of UE operation mode A).

User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.



### Related ICS/IXIT statements

Support of PS service—Yes/No  
 UE operation mode C—Yes/No  
 UE operation mode A—Yes/No  
 USIM removal possible without powering down—Yes/No  
 Switch off on button—Yes/No  
 Automatic PS attach procedure at switch on or power on—Yes/No

### Test procedure

The UE initiates a PS attach procedure with identity P-TMSI. The SS reallocates the P-TMSI and returns ATTACH ACCEPT message with a new P-TMSI and timer T3312. The UE acknowledge the new P-TMSI by sending ATTACH COMPLETE message. A routing area updating procedure is performed at T3312 timeout.

T3312; set to 6 minutes.

### Expected Sequence

| Step | Direction |    | Message                     | Comments                                                                                                                                                                      |
|------|-----------|----|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                                                               |
| 1    |           | SS |                             | The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 11.                                                                           |
| 2    | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                        |
| 3    | →         |    | ATTACH REQUEST              | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                                 |
| 4    |           | ←  | ATTACH ACCEPT               | Routing area identity = RAI-1<br>Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>T3312 = 6 minutes |
| 5    | →         |    | ATTACH COMPLETE             |                                                                                                                                                                               |
| 6    | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'Periodic updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                      |
| 7    |           | SS |                             | The SS verifies that the time between the attach and the periodic RA updating is T3312                                                                                        |
| 8    |           | ←  | ROUTING AREA UPDATE ACCEPT  | No new mobile identity assigned.<br>P-TMSI not included.<br>Update result = 'RA updated'<br>P-TMSI-3 signature<br>Routing area identity = RAI-1                               |
| 9    | UE        |    |                             | The UE is switched off or power is removed (see ICS).                                                                                                                         |
| 10   | →         |    | DETACH REQUEST              | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                        |
| 11   |           |    |                             | The SS is set in network operation mode II.                                                                                                                                   |
| 12   | UE        |    |                             | The UE is set in UE operation mode A (see ICS) and the test is repeated from step 3 to step 10.                                                                               |

### Specific message contents

None.

#### 12.4.3.1.5 Test requirements

At step 3, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step6, when the timer T3312 is expired, UE shall:

- initiate the routing area updating procedure with Update type = 'Periodic updating'.

### ~~12.4.3.2~~ ~~Periodic routing area updating / accepted / T3312 default value~~

#### ~~12.4.3.2.1~~ ~~Definition~~

#### ~~12.4.3.2.2~~ ~~Conformance requirement~~

~~The User Equipment shall perform a periodic routing area update procedure after a T3312 timeout.~~

#### ~~Reference~~

~~3GPP TS 24.008 clauses 4.7.2.2 and 4.7.5.2.~~

#### ~~12.4.3.2.3~~ ~~Test purpose~~

~~To test the behaviour of the UE with respect to the periodic routing area updating procedure.~~

#### ~~12.4.3.2.4~~ ~~Method of test~~

#### ~~Initial condition~~

##### ~~System Simulator:~~

~~One cell operating in network operation mode I.~~

##### ~~User Equipment:~~

~~The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.~~

#### ~~Related ICS/IXIT statements~~

~~Support of PS service—Yes/No~~

~~UE operation mode A—Yes/No~~

~~Switch off on button—Yes/No~~

~~Automatic PS attach procedure at switch on or power on—Yes/No~~

#### ~~Test procedure~~

~~The UE initiates a combined PS attach procedure. The SS reallocates the P-TMSI and returns ATTACH ACCEPT message with a new P-TMSI and timer T3312 is omitted. The UE acknowledge the new P-TMSI by sending ATTACH COMPLETE message. After 54 minutes, a periodic routing area updating procedure is initiated by the UE.~~

~~T3312; default value 54 minutes.~~

## Expected Sequence

| Step | Direction |    | Message                     | Comments                                                                                                                                                                        |
|------|-----------|----|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                                                                 |
| 1    | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                          |
| 2    | →         |    | ATTACH REQUEST              | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                                                  |
| 3    |           | ←  | ATTACH ACCEPT               | Attach result = 'Combined PS /IMSI attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-1<br>T3312 = 54 min |
| 4    | →         |    | ATTACH COMPLETE             |                                                                                                                                                                                 |
| 5    | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'Periodic updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>TMSI status = valid TMSI available or IE not present.                               |
| 6    |           | SS |                             | The SS verifies that the time between the attach request and the periodic RA updating is T3312                                                                                  |
| 7    |           | ←  | ROUTING AREA UPDATE ACCEPT  | No new mobile identity assigned.<br>P-TMSI and TMSI not included.<br>Update result = 'RAupdated'<br>P-TMSI-3 signature<br>Routing area identity = RAI-1                         |
| 8    | UE        |    |                             | The UE is switched off or power is removed (see ICS).                                                                                                                           |
| 9    | →         |    | DETACH REQUEST              | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS/IMSI detach'                                                                            |

## Specific message contents

None.

## 12.4.3.2.5 — Test requirements

At step3, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step5, when the timer T3312 is expired, UE shall:

- initiate the routing area updating procedure with Update type = 'Periodic updating'.

## 12.4.3.3 — Periodic routing area updating / no cell available / network mode I

## 12.4.3.3.1 — Definition

## 12.4.3.3.2 — Conformance requirement

If the UE is both IMSI attached for PS and non-PS services, and if the UE lost coverage of the registered PLMN and timer T3312 expires; if the UE returns to coverage in a cell that supports PS and the network is in network operation mode I, then the UE shall perform a combined routing area update procedure indicating 'combined RA/LA updating with IMSI attach'.

## Reference

3GPP TS 24.008 clauses 4.7.2.2 and 4.7.5.1.

### 12.4.3.3.3 ——— Test purpose

To test the behaviour of the UE with respect to the periodic routing area updating procedure.

### 12.4.3.3.4 ——— Method of test

## Initial condition

### System Simulator:

Two cells, cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4).  
Cell A is operating in network operation mode II and cell B is in network operation mode I.

### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

Idle updated on Cell A

## Related ICS/IXIT statements

Support of PS service—Yes/No

UE operation mode A—Yes/No

Switch off on button—Yes/No

Automatic PS attach procedure at switch on or power on—Yes/No

## Test procedure

The UE initiates a PS attach procedure. The SS reallocates the P-TMSI and returns ATTACH ACCEPT message with a new P-TMSI and timer T3312. The UE acknowledge the new P-TMSI by sending ATTACH COMPLETE message. PS radio contact is distorted before T3312 timeout. PS radio contact is established again (after T3312 timeout), and a routing area updating procedure is performed immediately.

T3312; set to 6 minutes.

## Expected Sequence

| Step                                                                                                                                                                     | Direction |    | Message                     | Comments                                                                                                                                                                                              |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                          | UE        | SS |                             |                                                                                                                                                                                                       |
| 1                                                                                                                                                                        |           | SS | ATTACH REQUEST              | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>(see note) |
| 2                                                                                                                                                                        |           | SS |                             | The UE is set in UE operation mode A (see ICS).                                                                                                                                                       |
| 3                                                                                                                                                                        | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                                |
| 4                                                                                                                                                                        | →         |    |                             | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                                                         |
| 5                                                                                                                                                                        | ←         |    |                             | Routing area identity = RAI-1<br>Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature                                                                               |
| 6                                                                                                                                                                        | →         |    |                             | Routing area identity = RAI-1<br>T3312 = 6 minutes                                                                                                                                                    |
| 7                                                                                                                                                                        |           | SS |                             | After 5 minutes, the signal strength is lowered until the UE has lost contact with the SS.                                                                                                            |
| 8                                                                                                                                                                        |           | SS |                             | Wait 2 minutes.                                                                                                                                                                                       |
| 9                                                                                                                                                                        |           | SS | ROUTING AREA UPDATE REQUEST | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Suitable neighbour cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note) |
| 10                                                                                                                                                                       | UE        |    |                             | Cell B is preferred by the UE.                                                                                                                                                                        |
| 11                                                                                                                                                                       | UE        |    |                             | The UE immediately starts a combined RA updating procedure                                                                                                                                            |
| 12                                                                                                                                                                       | →         |    |                             | Update type = 'Combined RA/LA updating with IMSI attach'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>TMSI status = valid TMSI available or IE is omitted.                               |
| 13                                                                                                                                                                       | ←         |    |                             | Update result = 'Combined RA/LA updated'<br>Mobile identity = P-TMSI-3<br>P-TMSI-3 signature<br>Mobile identity = TMSI-2<br>Routing area identity = RAI-4                                             |
| 14                                                                                                                                                                       | →         |    |                             |                                                                                                                                                                                                       |
| 15                                                                                                                                                                       | UE        |    |                             | The UE is switched off or power is removed (see ICS).                                                                                                                                                 |
| 16                                                                                                                                                                       | →         |    |                             | Message not sent if power is removed.<br>Detach type = 'power switched off, combined PS / IMSI detach'                                                                                                |
| NOTE: The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                             |                                                                                                                                                                                                       |

## Specific message contents

None.

## 12.4.3.3.5 Test requirements

At step4, when the UE is powered up or switched on, UE shall:

- initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step12, when the UE is both IMSI attached for PS and non-PS service, and if the UE lost coverage of the reiterated PLMN and the timer T3312 expires, if the UE returns to coverage in a cell that supports PS and the network is in network operation mode I, UE shall:

- perform the combined routing area update procedure indicating "combined RA/LA updating with IMSI attach".

#### ~~12.4.3.4~~ Periodic routing area updating / no cell available

##### ~~12.4.3.4.1~~ Definition

##### ~~12.4.3.4.2~~ Conformance requirement

If the UE is both IMSI attached for PS and non-PS services, and if the UE lost coverage of the registered PLMN and timer T3312 expires; if the UE returns to coverage in a cell that supports PS and the network is in network operation mode II, then the UE shall perform a periodic routing area update procedure and a periodic location update procedure.

#### Reference

3GPP TS 24.008 clauses 4.7.2.2 and 4.7.5.2.

##### ~~12.4.3.4.3~~ Test purpose

To test the behaviour of the UE with respect to the periodic routing area updating procedure.

##### ~~12.4.3.4.4~~ Method of test

#### Initial condition

System Simulator:

- One cell operating in network operation mode II.

User Equipment:

- The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

Idle updated on Cell A

#### Related ICS/IXIT statements

- Support of PS service—Yes/No
- UE operation mode A—Yes/No
- Switch off on button—Yes/No
- Automatic PS attach procedure at switch on or power on—Yes/No

#### Test procedure

The UE initiates a PS attach procedure. The SS reallocates the P-TMSI and returns ATTACH ACCEPT message with a new P-TMSI and timer T3312. The UE acknowledge the new P-TMSI by sending ATTACH COMPLETE message. PS radio contact is distorted before T3312 timeout. PS radio contact is established again (after T3312 timeout), and a periodic routing area updating procedure and a periodic location update procedure is performed immediately.

T3312; set to 6 minutes.

## Expected Sequence

| Step | Direction |    | Message                     | Comments                                                                                                                                                                      |
|------|-----------|----|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                             |                                                                                                                                                                               |
| 1    | UE        |    |                             | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                        |
| 2    | →         |    | ATTACH REQUEST              | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                                 |
| 3    | ←         |    | ATTACH ACCEPT               | Routing area identity = RAI-1<br>Attach result = 'PS-only attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>T3312 = 6 minutes |
| 4    | →         |    | ATTACH COMPLETE             |                                                                                                                                                                               |
| 5-12 |           |    | (void)                      |                                                                                                                                                                               |
| 13   |           | SS |                             | After 5 minutes, the signal strength is lowered until the UE have lost contact with the SS.                                                                                   |
| 14   |           | SS |                             | After 2 minutes, the signal strength is increased until the UE have got contact with the SS.                                                                                  |
| 15   | UE        |    |                             | The UE immediately start the periodic RA updating procedure                                                                                                                   |
| 16   | →         |    | ROUTING AREA UPDATE REQUEST | Update type = 'Periodic updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                      |
| 17   | ←         |    | ROUTING AREA UPDATE ACCEPT  | No new mobile identity assigned.<br>P-TMSI not included.<br>Update result = 'RA updated'<br>P-TMSI-3 signature<br>Routing area identity = RAI-1                               |
| 18   | UE        |    |                             | The UE is switched off or power is removed (see ICS).                                                                                                                         |
| 19   | →         |    | DETACH REQUEST              | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                        |

## Specific message contents

## RRC System information block type 1

| Information element                  | CommentValue |
|--------------------------------------|--------------|
| T3212 (Periodical Location updating) | Infinity     |

## 12.4.3.4.5 Test requirements

At step2, when the UE is powered up or switched on, UE shall:

- initiate the combined PS attach procedure with the information elements specified in the above Expected Sequence.

At step16, when the UE is both IMSI attached for PS and non-PS service, and if the UE lost coverage of the reiterated PLMN and the timer T3312 expires, if the UE returns to coverage in a cell in the same RA that supports PS and that indicates that the network is in network operation mode II, UE shall:

- perform the periodic routing area updating procedure indicating "Periodic updating".

## ~~12.5 P-TMSI reallocation~~

### ~~12.5.1 Definition~~

### ~~12.5.2 Conformance requirement~~

- ~~1) A User Equipment shall acknowledge a new P-TMSI when explicitly allocated.~~
- ~~2) The P-TMSI shall be updated on the USIM when the User Equipment is correctly deactivated in accordance with the manufacturer's instructions.~~
- ~~3) A User Equipment shall use the given P-TMSI in further communication with the network.~~

### ~~Reference~~

~~3GPP TS 24.008 clause 4.7.6.~~

### ~~12.5.3 Test purpose~~

~~To verify that the UE is able to receive and acknowledge a new P-TMSI by means of an explicit P-TMSI reallocation procedure.~~

~~To verify that the UE has stored the P-TMSI in a non-volatile memory.~~

~~The implicit reallocation procedure is tested in the attach procedure.~~

### ~~12.5.4 Method of test~~

#### ~~Initial condition~~

~~System Simulator:~~

~~One cell operating in network operation mode II.~~

~~User Equipment:~~

~~The UE has a valid IMSI.~~

#### ~~Related ICS/IXIT statements~~

~~Support of PS service—Yes/No~~

~~UE operation mode A—Yes/No~~

~~UE operation mode C—Yes/No (only if mode A not supported)~~

~~Switch off on button—Yes/No~~

~~Automatic PS attach procedure at switch on or power on—Yes/No~~

#### ~~Test procedure~~

~~An explicit P-TMSI reallocation procedure is performed (P-TMSI reallocation command sent from the SS and acknowledged from the UE by P-TMSI reallocation complete). The UE is PS detached and switched off. Its power supply is interrupted for 10 seconds. The power supply is resumed and then the UE is switched on. A PS attach procedure is performed with the given P-TMSI as identity.~~



## Expected Sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                            |
|------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                     |
| 1    | UE        |    |                                 | The UE is set in UE operation mode A (see ICS). If UE operation mode A not supported set the UE in operation mode C.                                                                |
| 2    | UE        |    |                                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                              |
| 3    | →         |    | ATTACH REQUEST                  | Attach type = 'PS attach'                                                                                                                                                           |
| 4    | ←         |    | ATTACH ACCEPT                   | Mobile identity = IMSI<br>Attach result = 'PS only attached'                                                                                                                        |
| 5    | →         |    | ATTACH COMPLETE                 | Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                                                                                                   |
| 6    | ←         |    | P-TMSI REALLOCATION COMMAND     | Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                                   |
| 7    | →         |    | P-TMSI REALLOCATION COMPLETE    |                                                                                                                                                                                     |
| 8    | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                                                                                                               |
| 9    | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                              |
| 10   | UE        |    |                                 | Ensure the power is removed from the UE for at least 10 seconds                                                                                                                     |
| 11   | UE        |    |                                 | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                              |
| 12   | →         |    | ATTACH REQUEST                  | Attach type = 'PS attach'                                                                                                                                                           |
| 13   | ←         |    | ATTACH ACCEPT                   | Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>No new mobile identity assigned.<br>P-TMSI not included.<br>Attach result = 'PS only attached' |
| 14   | ←         |    | PAGING TYPE1                    | P-TMSI-3 signature<br>Routing area identity = RAI-1<br>Mobile identity = P-TMSI-2<br>Paging order is for PS services.                                                               |
| 15   | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                     |
| 16   | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                     |
| 17   | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                                                     |
| 18   | →         |    | SERVICE REQUEST                 | service type = "paging response"                                                                                                                                                    |
| 19   | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                     |
| 20   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                     |
| 21   | UE        |    |                                 | The UE is switched off or power is removed (see ICS).                                                                                                                               |
| 22   | →         |    | DETACH REQUEST                  | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                              |

## Specific message contents

None.

## 12.5.5 Test requirements

At step3, when the UE is powered up or switched on, UE shall:

—initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step7, when the UE receives P-TMSI REALLOCATION COMMAND message from SS, UE shall:

—acknowledge the new P-TMSI by sending P-TMSI REALLOCATION COMPLETE message.

At step12, when the UE is powered up or switched on, UE shall:

—initiate the PS attach procedure with the information elements specified in the above Expected Sequence.

At step18, when the UE receives the paging message for PS domain with Mobile identity = P-TMSI-2, UE shall:

—respond to the paging message for PS domain by sending the SERVICE REQUEST message.

## 12.6 PS authentication and ciphering

### 12.6.1 Test of authentication

The purpose of this procedure is to verify the user identity. A correct response is essential to guarantee the establishment of the connection. If not, the connection will drop.

#### 12.6.1.1 Authentication accepted

##### 12.6.1.1.1 Definition

##### 12.6.1.1.2 Conformance requirement

A User Equipment shall correctly respond in an authentication and ciphering procedure by sending a response with the RES information field set to the same value as the one produced by the authentication and ciphering algorithm in the network.

#### Reference

3GPP TS 24.008 clause 4.7.7.

##### 12.6.1.1.3 Test purpose

To test the behaviour of the UE if the network accepts the authentication and ciphering procedure.

##### 12.6.1.1.4 Method of test

#### Initial condition

##### System Simulator:

Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4).

Both cells are operating in network operation mode II.

##### User Equipment:

The UE has a valid IMSI.

#### Related ICS/IXIT statements

Support of PS service—Yes/No

UE operation mode A—Yes/No

UE operation mode C—Yes/No

Switch off on button—Yes/No

Automatic PS attach procedure at switch on or power on—Yes/No

#### Test procedure

A PS attach is performed, and the SS initiates an authentication and ciphering procedure.

The SS checks the value RES sent by the UE in the AUTHENTICATION AND CIPHERING RESPONSE message.

The UE initiates a routing area updating procedure and the SS checks the value of the PS Ciphering Key Sequence Number sent by the UE in the ROUTING AREA REQUEST message.

#### Expected Sequence

| Step                                                                                                                                                        | Direction |    | Message                               | Comments                                                                                                                                                                               |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                             | UE        | SS |                                       |                                                                                                                                                                                        |
| 1                                                                                                                                                           |           | SS |                                       | The following messages are sent and shall be received on cell A:<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note) |
| 2                                                                                                                                                           | UE        |    |                                       | The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 17.                                                                                    |
| 3                                                                                                                                                           | UE        |    |                                       | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                 |
| 4                                                                                                                                                           | →         |    | ATTACH REQUEST                        | Attach type = 'PS attach'                                                                                                                                                              |
| 5                                                                                                                                                           | ←         |    | AUTHENTICATION AND CIPHERING REQUEST  | Mobile identity = IMSI                                                                                                                                                                 |
| 6                                                                                                                                                           | →         |    | AUTHENTICATION AND CIPHERING RESPONSE | Request authentication.<br>Set PS-CKSN-1<br>RES                                                                                                                                        |
| 7                                                                                                                                                           |           | SS |                                       | The SS checks the RES value.                                                                                                                                                           |
| 8                                                                                                                                                           | ←         |    | ATTACH ACCEPT                         | Attach result = 'PS only attached'                                                                                                                                                     |
|                                                                                                                                                             |           |    |                                       | Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                                      |
| 9                                                                                                                                                           | →         |    | ATTACH COMPLETE                       |                                                                                                                                                                                        |
| 10                                                                                                                                                          |           | SS |                                       | The following messages are sent and shall be received on cell B:<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note) |
| 11                                                                                                                                                          | →         |    | ROUTING AREA UPDATE REQUEST           | Update type = 'RA updating'                                                                                                                                                            |
|                                                                                                                                                             |           |    |                                       | P-TMSI-2 signature<br>Routing area identity = RAI-1<br>PS-CKSN-1                                                                                                                       |
| 12                                                                                                                                                          |           | SS |                                       | The value of PS-CKSN is checked                                                                                                                                                        |
| 13                                                                                                                                                          | ←         |    | ROUTING AREA UPDATE ACCEPT            | Update result = 'RA updated'                                                                                                                                                           |
|                                                                                                                                                             |           |    |                                       | Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-4                                                                                                      |
| 14                                                                                                                                                          | →         |    | ROUTING AREA UPDATE COMPLETE          |                                                                                                                                                                                        |
| 15                                                                                                                                                          | UE        |    |                                       | The UE is switched off or power is removed (see ICS).                                                                                                                                  |
| 16                                                                                                                                                          | →         |    | DETACH REQUEST                        | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                 |
| 17                                                                                                                                                          |           | SS |                                       | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note)                                                                     |
| 18                                                                                                                                                          | UE        |    |                                       | The UE is set in UE operation mode A (see ICS) and the test is repeated from step 3 to step 16.                                                                                        |
| NOTE: — The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                       |                                                                                                                                                                                        |

#### Specific message contents

None.

#### ~~12.6.1.1.5 Test requirements~~

~~At step4, when the UE is powered on or switched on, UE shall:~~

- ~~—initiate the PS attach procedure with information elements specified in the above Expected Sequence.~~

~~At step6, when the UE receives the AUTHENTICATION AND CIPHERING REQUEST message from SS, UE shall:~~

- ~~—send the AUTHENTICATION AND CIPHERING RESPONSE message with the RES information field set to the same value as the one produced by the authentication and ciphering algorithm in the network.~~

~~At step11, when the RF level of the attached cell is lower than the RF level of the new cell, UE shall:~~

- ~~—perform routing area updating procedure.~~

#### ~~12.6.1.2 Authentication rejected by the network~~

##### ~~12.6.1.2.1 Definition~~

##### ~~12.6.1.2.2 Conformance requirement~~

~~Upon receipt of an AUTHENTICATION AND CIPHERING REJECT message, the UE shall set the PS update status to GU3 ROAMING NOT ALLOWED and shall delete the P-TMSI, P-TMSI signature, RAI and PS ciphering key sequence number stored.~~

~~The USIM shall be considered as invalid until switching off or the USIM is removed.~~

~~If the AUTHENTICATION AND CIPHERING REJECT message is received, the UE shall abort any GMM procedure, shall stop the timers T3310 and T3330 (if running) and shall enter state GMM-DEREGISTERED.~~

##### ~~Reference~~

~~3GPP TS 24.008 clauses 4.7.7.5.~~

##### ~~12.6.1.2.3 Test purpose~~

~~To test the behaviour of the UE if the network rejects the authentication and ciphering procedure.~~

##### ~~12.6.1.2.4 Method of test~~

##### ~~Initial condition~~

##### ~~System Simulator:~~

~~Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4).  
Both cells are operating in network operation mode II.~~

##### ~~User Equipment:~~

~~The UE has a valid IMSI.~~

##### ~~Related ICS/IXIT statements~~

~~Support of PS service—Yes/No  
UE operation mode A—Yes/No  
UE operation mode C—Yes/No  
Switch off on button—Yes/No  
Automatic PS attach procedure at switch on or power on—Yes/No~~

### Test procedure

The test sequence is repeated for  $K = 1, 2$ .

A complete PS attach procedure is performed. The SS rejects the following authentication and ciphering procedure. The UE is paged with its former P-TMSI and shall not respond.

The Cell is changed into a new Routing Area.

The SS checks that the UE does not perform normal routing area updating.

The SS then checks that the UE does not perform a PS detach.

The SS checks that the UE does not perform a PS Attach procedure.

### Expected Sequence

The test sequence is repeated for  $k = 1, 2$

For  $k = 1$ , the UE is set in UE operation mode C. If MS operation mode C not supported then  $k = 2$ .

For  $k = 2$  the UE is set in UE operation mode A.

| Step                                                                                                                                                        | Direction |    | Message                               | Comments                                                                                                                                                                               |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                             | UE        | SS |                                       |                                                                                                                                                                                        |
| 1                                                                                                                                                           |           | SS |                                       | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note) |
| 2                                                                                                                                                           | UE        |    |                                       | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                 |
| 3                                                                                                                                                           | →         |    | ATTACH REQUEST                        | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                                                                                    |
| 4                                                                                                                                                           | ←         |    | ATTACH ACCEPT                         | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                                                                |
| 5                                                                                                                                                           | →         |    | ATTACH COMPLETE                       |                                                                                                                                                                                        |
| 6                                                                                                                                                           | ←         |    | AUTHENTICATION AND CIPHERING REQUEST  | Request authentication.<br>Set PS-CKSN-1                                                                                                                                               |
| 7                                                                                                                                                           | →         |    | AUTHENTICATION AND CIPHERING RESPONSE | RES                                                                                                                                                                                    |
| 8                                                                                                                                                           | ←         |    | AUTHENTICATION AND CIPHERING REJECT   |                                                                                                                                                                                        |
| 9                                                                                                                                                           | ←         |    | PAGING TYPE1                          | Mobile identity = IMSI                                                                                                                                                                 |
| 10                                                                                                                                                          | UE        |    |                                       | Paging order is for PS services.<br>No response from the UE to the request. This is checked for 10 seconds.                                                                            |
| 11                                                                                                                                                          |           | SS |                                       | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note) |
| 12                                                                                                                                                          | UE        |    |                                       | Cell B is preferred by the MS.                                                                                                                                                         |
| 13                                                                                                                                                          | UE        |    |                                       | No ROUTING AREA UPDATE REQUEST sent to the SS<br>(SS waits 30 seconds).                                                                                                                |
| 14                                                                                                                                                          | UE        |    |                                       | If possible (see ICS) the UE initiates an attach by MMI or by AT command.                                                                                                              |
| 15                                                                                                                                                          | UE        |    |                                       | No ATTACH REQUEST sent to the SS<br>(SS waits 30 seconds).                                                                                                                             |
| 16                                                                                                                                                          | UE        |    |                                       | The UE is switched off (see ICS).                                                                                                                                                      |
| 17                                                                                                                                                          | SS        |    |                                       | No DETACH REQUEST sent to the SS<br>(SS waits 30 seconds).                                                                                                                             |
| 18                                                                                                                                                          |           |    |                                       | The UE is powered up or switched on and initiates an attach (see ICS).<br>Step 19 is only performed for k=2                                                                            |
| 19                                                                                                                                                          | UE        |    | Registration on CS                    | Parameter mobile identity is IMSI.<br>See TS 34.108                                                                                                                                    |
| 20                                                                                                                                                          | →         |    | ATTACH REQUEST                        | Attach type = 'PS only attached'<br>Mobile identity = IMSI                                                                                                                             |
| 21                                                                                                                                                          | ←         |    | ATTACH ACCEPT                         | Attach result = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-2                                                                       |
| 22                                                                                                                                                          | →         |    | ATTACH COMPLETE                       |                                                                                                                                                                                        |
| NOTE: — The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                       |                                                                                                                                                                                        |

## Specific message contents

None.

## 12.6.1.2.5 — Test requirements

At step3, when the UE is powered on or switched on, UE shall:

—initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step9, when the UE receives the AUTHENTICATION AND CIPHERING REJECT message, UE shall:

—not respond paging message for PS domain.

At step13, when the RF level of the attached cell is lower than the RF level of the new cell, UE shall:

—not perform normal routing area updating.

At step17, when the UE is switched off, UE shall:

—not perform PS detach procedure.

### 12.6.1.3 Authentication rejected by the UE

#### 12.6.1.3.1 GMM cause 'MAC failure'

##### 12.6.1.3.1.1 Definition

##### 12.6.1.3.1.2 Conformance requirement

If the UE considers the MAC code (supplied by the core network in the AUTN parameter) to be invalid, the UE shall send AUTHENTICATION AND CIPHERING FAILURE message with the reject cause 'MAC failure' to the System Simulator.

#### Reference

3GPP TS 24.008 clause 4.7.7.

##### 12.6.1.3.1.3 Test purpose

To test the behaviors of the UE, when the UE considers the MAC code (supplied by the core network in the AUTN parameter) to be invalid.

##### 12.6.1.3.1.4 Method of test

#### Initial condition

System Simulator:

—Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4).  
Both cells are operating in network operation mode II.

—The MAC (Message Authentication Code) code, which is included in AUTHENTICATION AND CIPHERING REQUEST, is invalid value.

User Equipment:

—The UE has a valid IMSI.

#### Related ICS/IXIT statements

—Support of PS service—Yes/No  
UE operation mode A—Yes/No  
UE operation mode C—Yes/No  
Switch off on button—Yes/No  
Automatic PS attach procedure at switch on or power on—Yes/No

### ~~Test procedure~~

~~A PS attach is performed, and the SS initiates an authentication and ciphering procedure.~~

~~The UE sends AUTHENTICATION AND CIPHERING FAILURE message with reject cause 'MAC failure' to the SS and starts timer T3214.~~

~~The SS initiates an identification procedure, upon receipt of a failure message with reject cause 'MAC failure'.~~

~~After the identification procedure is complete, the SS re-initiates an authentication and ciphering procedure.~~

~~T3360; set to 6 seconds.~~

~~T3318; set to 5 seconds.~~



## Expected Sequence

| Step                                                                                                                                                        | Direction |    | Message                               | Comments                                                                                                                                                                               |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                             | UE        | SS |                                       |                                                                                                                                                                                        |
| 1                                                                                                                                                           |           | SS |                                       | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note) |
| 2                                                                                                                                                           | UE        |    |                                       | The UE is set in UE operation mode C (see ICS). If UE operation mode C is not supported, goto step 25.                                                                                 |
| 3                                                                                                                                                           | UE        |    |                                       |                                                                                                                                                                                        |
| 4                                                                                                                                                           |           |    |                                       | The following messages are sent and shall be received on cell A.                                                                                                                       |
| 5                                                                                                                                                           | UE        |    |                                       | The UE is powered up or switched on and initiates an attach (see ICS).                                                                                                                 |
| 6                                                                                                                                                           | ->        |    | ATTACH REQUEST                        | Attach type = 'PS attach'<br>Mobility identity = IMSI                                                                                                                                  |
| 7                                                                                                                                                           | <-        |    | AUTHENTICATION AND CIPHERING REQUEST  | Request authentication.<br>Invalid Message Authentication Code (MAC).                                                                                                                  |
| 9                                                                                                                                                           | ->        |    | AUTHENTICATION AND CIPHERING FAILURE  | GMM cause='MAC failure'                                                                                                                                                                |
| 10                                                                                                                                                          | <-        |    | IDENTITY REQUEST                      | Identity type = IMSI                                                                                                                                                                   |
| 11                                                                                                                                                          | ->        |    | IDENTITY RESPONSE                     | Mobile identity = IMSI                                                                                                                                                                 |
| 13                                                                                                                                                          | <-        |    | AUTHENTICATION AND CIPHERING REQUEST  | Request authentication.                                                                                                                                                                |
| 14                                                                                                                                                          | ->        |    | AUTHENTICATION AND CIPHERING RESPONSE | Including PS-CSKN-1<br>RES                                                                                                                                                             |
| 15                                                                                                                                                          | SS        |    |                                       | The SS checks the RES value.                                                                                                                                                           |
| 16                                                                                                                                                          | <-        |    | ATTACH ACCEPT                         | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                |
| 17                                                                                                                                                          | ->        |    | ATTACH COMPLETE                       |                                                                                                                                                                                        |
| 18                                                                                                                                                          |           | SS |                                       | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note) |
| 19                                                                                                                                                          | ->        |    | ROUTING AREA UPDATE REQUEST           | Update type = 'RA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>PS-CSKN-1                                                                                        |
| 20                                                                                                                                                          | SS        |    |                                       | The value of PS-CSKN is checked                                                                                                                                                        |
| 21                                                                                                                                                          | <-        |    | ROUTING AREA UPDATE ACCEPT            | Update result = 'RA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-2                                                                      |
| 22                                                                                                                                                          | ->        |    | ROUTING AREA UPDATE COMPLETE          |                                                                                                                                                                                        |
| 23                                                                                                                                                          | UE        |    |                                       | The UE is switched off or power is removed (see ICS).                                                                                                                                  |
| 24                                                                                                                                                          | ->        |    | DETACH REQUEST                        | Message is not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                              |
| 25                                                                                                                                                          | UE        |    |                                       | The UE is set in UE operation mode A (see ICS) and the test is repeated from step 1 to step 24.                                                                                        |
| NOTE: — The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                       |                                                                                                                                                                                        |

## Specific message contents

None.

#### ~~12.6.1.3.1.5~~ ~~Test requirements~~

~~At step6, when the UE is powered on or switched on, UE shall:~~

- ~~— initiate the PS attach procedure with information element specified in the above Expected Sequence.~~

~~At step9, when the UE receives the AUTHENTICATION AND CIPHERING REQUEST with Invalid Message Authentication Code, UE shall:~~

- ~~— send the AUTHENTICATION AND CIPHERING FAILURE message with GMM cause 'MAC failure' to the SS~~

~~At step11, when the UE receives the IDENTITY REQUEST message with Identity type = IMSI from SS, UE shall:~~

- ~~— send the IDENTITY RESPONSE message with Mobile identity = IMSI to SS.~~

~~At step14, when the UE receives the second AUTHENTICATION AND CIPHERING REQUEST message (containing a valid MAC) from SS, UE shall:~~

- ~~— send the AUTHENTICATION AND CIPHERING RESPONSE message to SS~~

#### ~~12.6.1.3.2~~ ~~GMM cause 'Synch failure'~~

##### ~~12.6.1.3.2.1~~ ~~Definition~~

##### ~~12.6.1.3.2.2~~ ~~Conformance requirement~~

~~If the UE considers the SQN (supplied by the core network in the AUTN parameter) to be out of range, the UE shall send AUTHENTICATION AND CIPHERING FAILURE message with the reject cause 'Synch failure' to the System Simulator.~~

#### ~~Reference~~

~~3GPP TS 24.008 clause 4.7.7.~~

##### ~~12.6.1.3.2.3~~ ~~Test purpose~~

~~To test the behaviors of the UE, when the UE considers the SQN (supplied by the core network in the AUTN parameter) to be out of range.~~

##### ~~12.6.1.3.2.4~~ ~~Method of test~~

#### ~~Initial condition~~

#### ~~System Simulator:~~

- ~~— Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4).~~
- ~~Both cells are operating in network operation mode II.~~

#### ~~User Equipment:~~

- ~~— The UE has a valid IMSI.~~

#### ~~Related ICS/IXIT statements~~

- ~~— Support of PS service — Yes/No~~
- ~~UE operation mode A — Yes/No~~
- ~~UE operation mode C — Yes/No~~
- ~~Switch off-on button — Yes/No~~
- ~~Automatic PS attach procedure at switch on or power on — Yes/No~~

**Test procedure**

A PS attach is performed, and the SS initiates an authentication and ciphering procedure.

UE sends AUTHENTICATION AND CIPHERING FAILURE message with reject cause 'synch failure' to the SS and starts timer T3214.

SS re-initiates an authentication and ciphering procedure.

T3360; set to 6 seconds.

T3320; set to 15 seconds.

**Expected Sequence**

| Step | Direction |    | Message                               | Comments                                                                                                                                                                               |
|------|-----------|----|---------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                                                                                                        |
| 1    |           | SS |                                       | The following messages are sent and shall be received on cell A.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note) |
| 2    | UE        |    |                                       | The UE is set in UE operation mode C (see ICS). If UE operation mode C is not supported, goto step 21.                                                                                 |
| 3    | UE        |    |                                       | The following messages are sent and shall be received on cell A.<br>The UE is powered up or switched on and initiates an attach (see ICS).                                             |
| 4    | ->        |    | ATTACH REQUEST                        | Attach type = 'PS attach'                                                                                                                                                              |
| 5    | <-        |    | AUTHENTICATION AND CIPHERING REQUEST  | Mobility identity = IMSI<br>Request authentication.                                                                                                                                    |
| 6    |           | SS |                                       | SN is out of range.                                                                                                                                                                    |
| 7    | ->        |    | AUTHENTICATION AND CIPHERING FAILURE  | The SS starts the timer T3360<br>GMM cause = 'Synch failure'                                                                                                                           |
| 8    |           | SS |                                       | AUTS parameter<br>set new authentication vectors. (re-synchronisation)                                                                                                                 |
| 9    | <-        |    | AUTHENTICATION AND CIPHERING REQUEST  | Request authentication.                                                                                                                                                                |
| 10   | ->        |    | AUTHENTICATION AND CIPHERING RESPONSE | Including PS-CKSN-1<br>RES                                                                                                                                                             |
| 11   |           | SS |                                       | The SS checks the RES value.                                                                                                                                                           |
| 12   | <-        |    | ATTACH ACCEPT                         | Attach result = 'PS-only attached'                                                                                                                                                     |
| 13   | ->        |    | ATTACH COMPLETE                       | Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1                                                                                                      |
| 14   |           | SS |                                       | The following messages are sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note) |
| 15   | ->        |    | ROUTING AREA UPDATE REQUEST           | Update type = 'RA updating'<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>PS-CKSN-1                                                                                        |
| 16   |           | SS |                                       | The value of PS-CKSN is checked                                                                                                                                                        |
| 17   | <-        |    | ROUTING AREA UPDATE ACCEPT            | Update result = 'RA updated'                                                                                                                                                           |
| 18   | ->        |    | ROUTING AREA UPDATE COMPLETE          | Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-2                                                                                                      |
| 19   | UE        |    |                                       | The UE is switched off or power is removed (see ICS).                                                                                                                                  |
| 20   | ->        |    | DETACH REQUEST                        | Message is not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                              |

| Step                                                                                                                                                      | Direction |    | Message | Comments                                                                                        |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------|-------------------------------------------------------------------------------------------------|
|                                                                                                                                                           | UE        | SS |         |                                                                                                 |
|                                                                                                                                                           |           |    |         |                                                                                                 |
| 21                                                                                                                                                        | UE        |    |         | The UE is set in UE operation mode A (see ICS) and the test is repeated from step 1 to step 20. |
| NOTE: The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |         |                                                                                                 |

#### Specific message contents

None.

#### 12.6.1.3.2.5 Test requirements

At step4, when the UE is powered on or switched on, UE shall:

- initiate the PS attach procedure with information element specified in the above Expected Sequence.

At step7, when the UE receives the AUTHENTICATION AND CIPHERING REQUEST message (SQN is out of range.), UE shall:

- send the AUTHENTICATION AND CIPHERING FAILURE message with GMM cause 'synch failure' to the SS

At step10, when the UE receives the second AUTHENTICATION AND CIPHERING REQUEST message from SS, UE shall:

- send the AUTHENTICATION AND CIPHERING RESPONSE message to SS.

At step15, when the RF level of the attached cell is lower than the RF level of the new cell, UE shall:

- perform routing area updating procedure.

#### 12.6.1.3.3 Authentication rejected by the UE / fraudulent network

##### 12.6.1.3.3.1 Definition

##### 12.6.1.3.3.2 Conformance requirement

It can be assumed that the source of the authentication challenge is not genuine (authentication not accepted by the UE) if any of the following occur:

- After sending the AUTHENTICATION & CIPHERING FAILURE message with GMM cause 'MAC failure' the timer T3318 expires;
- Upon receipt of the second AUTHENTICATION & CIPHERING REQUEST message from the network while the T3318 is running and the MAC value cannot be resolved.

If the UE deems that the network has failed in the authentication check, then the UE shall treat the cell where the AUTHENTICATION & CIPHERING REQUEST message was received as barred, until System Information is refreshed.

#### Reference

3GPP TS 24.008 clause 4.7.7.6.1.

##### 12.6.1.3.3.3 Test purpose

To test UE treating a cell as barred:

1. when the network sends the second AUTHENTICATION & CIPHERING REQUEST message with invalid MAC code during the timer T3318 is running.
2. when the timer T3318 has expired.

#### 12.6.1.3.3.4 Method of test

##### Initial condition

##### System Simulator:

- Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1(RAI-1), cell B in MCC1/MNC1/LAC1/RAC2(RAI-2).
- Both cells are operating in network operation mode II.

##### User Equipment:

- The UE has a valid IMSI.

##### Related ICS/IXIT statements

- Support of PS service — Yes/No
- UE operation mode A — Yes/No
- UE operation mode C — Yes/No
- Automatic PS attach procedure at switch on or power on — Yes/No

##### Test procedure

Two cells are configured. Cell A transmits with higher power so that the UE attempts an attach procedure to cell A.

During the attach procedure, the SS initiates an authentication and ciphering procedure but it sends an incorrect Message Authentication Code (MAC) value in its AUTHENTICATION AND CIPHERING REQUEST message.

The UE sends AUTHENTICATION AND CIPHERING FAILURE message to the SS indicating authentication failure.

The SS repeats a second time the authentication procedure, which fails again. Next, the UE shall attempt to attach to cell B, which again fails. In this case T3318 expires after the second attempt.

The UE shall treat now both cells as barred and shall not attempt to access the network, even if the user triggers the UE to perform an attach procedure.

## Expected Sequence

| Step                                                                                                                                                      | Direction |    | Message                              | Comments                                                                                                                                                      |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|--------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                           | UE        | SS |                                      |                                                                                                                                                               |
| 1                                                                                                                                                         |           | SS |                                      | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note)                                            |
| 2                                                                                                                                                         | UE        |    |                                      | The following messages are sent and shall be received on cell A.<br>The UE is powered up or switched on and initiates an attach procedure.                    |
| 3                                                                                                                                                         | ->        |    | ATTACH REQUEST                       | Attach type = 'PS attach'<br>Mobility identity = IMSI                                                                                                         |
| 4                                                                                                                                                         | <-        |    | AUTHENTICATION AND CIPHERING REQUEST | Request for authentication.                                                                                                                                   |
| 5                                                                                                                                                         | ->        |    | AUTHENTICATION AND CIPHERING FAILURE | Invalid Message Authentication Code (MAC).<br>GMM cause='MAC failure'                                                                                         |
| 6                                                                                                                                                         | <-        |    | AUTHENTICATION AND CIPHERING REQUEST | Request for authentication.                                                                                                                                   |
| 7                                                                                                                                                         | ->        |    | AUTHENTICATION AND CIPHERING FAILURE | Invalid Message Authentication Code (MAC).<br>GMM cause='MAC failure'                                                                                         |
| 8                                                                                                                                                         |           | SS |                                      | SS verifies that the UE does not attempt to access the network for 30s.                                                                                       |
| 9                                                                                                                                                         |           | SS |                                      | Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)                                            |
| 10                                                                                                                                                        | UE        |    |                                      | UE shall attempt an attach on cell B.<br>The following messages are sent and shall be received on cell B.<br>The UE initiates an attach by MMI or AT command. |
| 11                                                                                                                                                        | ->        |    | ATTACH REQUEST                       | Attach type = 'PS attach'<br>Mobility identity = IMSI                                                                                                         |
| 12                                                                                                                                                        | <-        |    | AUTHENTICATION AND CIPHERING REQUEST | Request for authentication.                                                                                                                                   |
| 13                                                                                                                                                        | ->        |    | AUTHENTICATION AND CIPHERING FAILURE | Invalid Message Authentication Code (MAC).<br>GMM cause='MAC failure'                                                                                         |
| 14                                                                                                                                                        | SS        |    |                                      | SS waits T3318 (20s)                                                                                                                                          |
| 15                                                                                                                                                        | SS        |    |                                      | SS verifies that the UE does not attempt to access the network for 30s.                                                                                       |
| 16                                                                                                                                                        | UE        |    |                                      | The UE initiates an attach by MMI or AT command.                                                                                                              |
| 17                                                                                                                                                        | SS        |    |                                      | SS verifies that the UE does not attempt to access the network for 30s.                                                                                       |
| NOTE: The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                      |                                                                                                                                                               |

## Specific message contents

None.

## 12.6.1.3.3.5 Test requirements

At step3, when the UE is powered on or switched on, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step5, when the UE receives the AUTHENTICATION AND CIPHERING REQUEST message with invalid Message Authentication Code (MAC), UE shall:

- send the AUTHENTICATION AND CIPHERING FAILURE message with GMM cause 'MAC failure' to the SS.

At step7, when the UE receives the second AUTHENTICATION AND CIPHERING REQUEST message with invalid Message Authentication Code (MAC) from the network during a timer T3318 is running, UE shall:

~~—send an AUTHENTICATION AND CIPHERING FAILURE message with GMM cause 'MAC failure' to the SS.~~

~~At step11, when the activated cell is changed from cell A to cell B, UE shall:~~

~~—initiate the PS attach procedure with information elements specified in the above Expected Sequence.~~

~~At step13, when the UE receives the AUTHENTICATION AND CIPHERING REQUEST message with invalid Message Authentication Code (MAC), UE shall:~~

~~—send an AUTHENTICATION AND CIPHERING FAILURE message with GMM cause 'MAC failure' to the SS.~~

~~At step17, when the timer T3318 is expired, UE shall:~~

~~—not attempt to access the network.~~

## ~~12.6.2 Void~~

## ~~12.7 Identification procedure~~

~~The purpose of this procedure is to check that the UE gives its identity as requested by the network. If this procedure does not work, it will not be possible for the network to rely on the identity claimed by the UE.~~

### ~~12.7.1 General Identification~~

#### ~~12.7.1.1 Definition~~

#### ~~12.7.1.2 Conformance requirement~~

- ~~1) When requested by the network the User Equipment shall send its IMSI.~~
- ~~2) When requested by the network the User Equipment shall send its IMEI as stored in the Mobile Equipment.~~
- ~~3) When requested by the network the User Equipment shall send its IMEISV as stored in the Mobile Equipment.~~

#### ~~Reference~~

~~3GPP TS 24.008 clauses 4.7.8~~

#### ~~12.7.1.3 Test purpose~~

~~To verify that the UE sends identity information as requested by the system. The following identities can be requested: IMSI, IMEI and IMEISV.~~

#### ~~12.7.1.4 Method of test~~

#### ~~Initial condition~~

~~System Simulator:~~

~~One cell operating in network mode II.~~

~~User Equipment:~~

~~The UE has a valid IMSI.~~

#### ~~Related ICS/IXIT statements~~

~~Support of PS service Yes/No~~

~~UE operation mode A Yes/No~~

~~UE operation mode C Yes/No~~

Switch off on button—Yes/No

Automatic PS attach procedure at switch on or power on—Yes/No

### Test procedure

The SS requests identity information from the UE:

—IMSI

—IMEI

—IMEISV

### Expected Sequence

| Step | Direction |    | Message           | Comments                                                                                            |
|------|-----------|----|-------------------|-----------------------------------------------------------------------------------------------------|
|      | UE        | SS |                   |                                                                                                     |
| 1    |           | SS |                   | The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 14. |
| 2    | UE        |    |                   | The UE is powered up or switched on and initiates an attach (see ICS).                              |
| 3    | →         |    | ATTACH REQUEST    | Attach type = 'PS attach'                                                                           |
| 4    |           | ←  | ATTACH ACCEPT     | Mobile identity = IMSI                                                                              |
|      |           |    |                   | Attach result = 'PS only attached'                                                                  |
|      |           |    |                   | Mobile identity = P-TMSI-1                                                                          |
|      |           |    |                   | P-TMSI-1 signature                                                                                  |
|      |           |    |                   | Routing area identity = RAI-1                                                                       |
| 5    | →         |    | ATTACH COMPLETE   |                                                                                                     |
| 6    |           | ←  | IDENTITY REQUEST  | Identity type = IMSI                                                                                |
| 7    | →         |    | IDENTITY RESPONSE | Mobile identity = IMSI                                                                              |
| 8    |           | ←  | IDENTITY REQUEST  | Identity type = IMEI                                                                                |
| 9    | →         |    | IDENTITY RESPONSE | Mobile identity = IMEI                                                                              |
| 10   |           | ←  | IDENTITY REQUEST  | Identity type = IMEISV                                                                              |
| 11   | →         |    | IDENTITY RESPONSE | Mobile identity = IMEISV                                                                            |
| 12   | UE        |    |                   | The UE is switched off or power is removed (see ICS).                                               |
| 13   | →         |    | DETACH REQUEST    | Message not sent if power is removed.                                                               |
|      |           |    |                   | Detach type = 'power switched off, PS detach'                                                       |
| 14   | UE        |    |                   | The UE is set in UE operation mode A (see ICS) and the test is repeated from step 2 to step 13.     |

### Specific message contents

None.

#### 12.7.1.5 Test requirements

At step3, when the UE is powered on or switched on, UE shall:

—initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step7, when the SS requests an IMSI with the IDENTITY REQUEST message, UE shall:

—send the IDENTITY RESPONSE message with the Mobile identity = IMSI.

At step9, when the SS requests an IMEI with the IDENTITY REQUEST message, UE shall:

—send the IDENTITY RESPONSE message with the Mobile identity = IMEI.

At step11, when the SS requests an IMEISV with the IDENTITY REQUEST message, UE shall:

—send the IDENTITY RESPONSE message with the Mobile identity = IMEISV.



## ~~12.8 GMM READY timer handling~~

~~The READY timer is not applicable for UMTS.~~

### ~~12.8.1 Definition~~

### ~~12.8.2 Conformance requirement~~

~~If a READY timer value is received by an UE capable of both UMTS and GSM in the ATTACH ACCEPT or the ROUTING AREA UPDATE ACCEPT messages, then the received value shall be stored by the UE in order to be used at an intersystem change from UMTS to GSM.~~

### ~~Reference~~

~~3GPP TS 24.008 clause 4.7.2.1~~

### ~~12.8.3 Test purpose~~

~~To verify the functionality of the READY timer.~~

### ~~12.8.4 Method of test~~

#### ~~12.8.4.1 Test procedure1~~

### ~~Initial condition~~

~~System Simulator:~~

~~Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC1 (RAI-1).  
Both cells are operating in network operation mode II.~~

~~User Equipment:~~

~~The UE has a valid IMSI.~~

### ~~Related ICS/IXIT statements~~

~~Support of PS service—Yes/No~~

~~UE operation mode A—Yes/No~~

~~Switch off on button—Yes/No~~

~~Automatic PS attach procedure at switch on or power on—Yes/No~~

### ~~Test procedure~~

~~An attach is performed.~~

~~T3314; set to 60 seconds~~

## Expected Sequence

| Step                                                                                                                                                      | Direction |    | Message         | Comments                                                                                                                                                                               |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                           | UE        | SS |                 |                                                                                                                                                                                        |
| 1                                                                                                                                                         |           | SS |                 | The following messages are sent and shall be received on cell A:<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note) |
| 2                                                                                                                                                         | UE        |    |                 | The UE is set in UE operation mode A (see ICS). If UE operation mode A not supported set the UE in operation mode C.                                                                   |
| 3                                                                                                                                                         | →         |    | ATTACH REQUEST  | The UE is powered up or switched on and initiates an attach (see ICS).<br>Attach type = 'PS attach'                                                                                    |
| 4                                                                                                                                                         | ←         |    | ATTACH ACCEPT   | Mobile identity = IMSI<br>Attach result = 'PS only attached'                                                                                                                           |
| 5                                                                                                                                                         | →         |    | ATTACH COMPLETE | Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-1<br>T3314 = 60 seconds                                                                                |
| 6                                                                                                                                                         | UE        |    |                 | The UE is switched off or power is removed (see ICS).                                                                                                                                  |
| 7                                                                                                                                                         | →         |    | DETACH REQUEST  | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                 |
| NOTE: The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                 |                                                                                                                                                                                        |

## Specific message contents

None.

## 12.8.5 Test requirements

At step4, when the UE receives the ATTACH ACCEPT or the ROUTING AREA UPDATE ACCEPT messages, UE shall:

- store the received READY timer value.

## 12.9 Service Request procedure (UMTS Only)

## 12.9.1 Service Request Initiated by UE Procedure

## 12.9.1.1 Definition

## 12.9.1.2 Conformance requirement

UE shall send the Service Request message to the network in order to establish the PS signalling connection for the upper layer signalling or for the resource reservation for active PDP context(s).

## Reference

TS 24.008 clauses 4.7.13

TS 23.060 clauses 6.12.1

## 12.9.1.3 Test purpose

To test the behaviour of the UE if the UE initiates the CM layer service (e.g. SM or SMS) procedure.

~~12.9.1.4 Method of test~~~~Initial condition~~~~System Simulator:~~~~One cell operating in network operation mode II.~~~~User Equipment:~~~~The UE has a valid IMSI~~~~Related ICS/EXIT statements~~~~Support of PS service Yes/No~~~~UE operation mode A Yes/No~~~~UE operation mode C Yes/No~~~~Switch off on button Yes/No~~~~Test procedure~~

- ~~a) The UE in PMM-IDLE state sends a SERVICE REQUEST message to the SS in order to establish the PS signalling connection for the upper layer signalling.~~
- ~~b) After the SS receives the SERVICE REQUEST message, the SS performs authentication procedure.~~

~~Expected Sequence~~

| Step | Direction |    | Message                               | Comments                                                                                               |
|------|-----------|----|---------------------------------------|--------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                        |
| 1    | UE        |    |                                       | The UE is set in UE operation mode C (see ICS). If UE operation mode C not supported, goto step 12.    |
| 2    | UE        |    |                                       | The UE is powered up or switched on and initiates an attach (see ICS).                                 |
| 3    | ->        |    | ATTACH REQUEST                        | Attach type = 'PS attach'                                                                              |
| 4    | <-        |    | ATTACH ACCEPT                         | Mobile identity = IMSI                                                                                 |
|      |           |    |                                       | Attach result = 'PS only attached'                                                                     |
|      |           |    |                                       | Mobile identity = P-TMSI-1                                                                             |
|      |           |    |                                       | P-TMSI-1 signature                                                                                     |
|      |           |    |                                       | Routing area identity = RAI-1                                                                          |
| 5    | ->        |    | ATTACH COMPLETE                       |                                                                                                        |
| 6    | UE        |    |                                       | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command. |
| 7    | ->        |    | SERVICE REQUEST                       | Service type = "signalling",                                                                           |
| 8    | <-        |    | AUTHENTICATION AND CIPHERING REQUEST  |                                                                                                        |
| 9    | ->        |    | AUTHENTICATION AND CIPHERING RESPONSE |                                                                                                        |
| 10   | UE        |    |                                       | The UE is switched off or power is removed (see ICS).                                                  |
| 11   | ->        |    | DETACH REQUEST                        | Detach type = 'power switched off, PS detach'                                                          |
| 12   | UE        |    |                                       | The UE is set in UE operation mode A (see ICS) and the test is repeated from step 2 to step 11.        |

~~Specific message contents~~~~None.~~

### ~~12.9.1.5 Test requirements~~

~~At step3, when the UE is powered on or switched on, UE shall:~~

- ~~—initiate the PS attach procedure with information elements specified in the above Expected Sequence.~~

~~At step7, when the UE has any signalling message (e.g. for SM or SMS) that requires security protection, the UE shall:~~

- ~~—send the SERVICE REQUEST message with service type indicated "signalling".~~

## ~~12.9.2 Service Request Initiated by Network Procedure~~

### ~~12.9.2.1 Definition~~

### ~~12.9.2.2 Conformance requirement~~

~~When the UE receives a paging request for PS domain from the network in PMM-IDLE mode, the UE shall send the SERVICE REQUEST message to the network.~~

### ~~Reference~~

~~TS 24.008 clauses 4.7.13~~

~~TS 23.060 clauses 6.12.2~~

### ~~12.9.2.3 Test purpose~~

~~To test the behavior of the UE if the UE receives the paging request for PS domain service from the network.~~

### ~~12.9.2.4 Method of test~~

### ~~Initial condition~~

~~System Simulator:~~

~~One cell operating in network operation mode II.~~

~~User Equipment:~~

~~The UE has a valid IMSI~~

### ~~Related ICS/IXIT statements~~

~~Support of PS service Yes/No~~

~~UE operation mode A Yes/No~~

~~UE operation mode C Yes/No~~

~~Switch off on button Yes/No~~

### ~~Test procedure~~

- ~~a) The UE is in PMM-IDLE state. The SS pages the UE by sending a Paging message to the UE.~~
- ~~b) The UE sends a SERVICE REQUEST message to the SS. Service Type specifies Paging Response. The Service Request is carried over the radio in an RRC Direct Transfer message.~~
- ~~c) After the SS receives the SERVICE REQUEST message from the UE, SS initiates an authentication procedure.~~

## Expected Sequence

| Step | Direction |    | Message                               | Comments                                                                                            |
|------|-----------|----|---------------------------------------|-----------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                     |
| 1    | UE        |    |                                       | The UE is set in UE-operation mode C (see ICS). If UE-operation mode C not supported, goto step 12. |
| 2    | UE        |    |                                       | The UE is powered up or switched in and initiates an attach (see ICS).                              |
| 3    | →         |    | ATTACH REQUEST                        | Attach type = 'PS attach'                                                                           |
| 4    | ←         |    | ATTACH ACCEPT                         | Mobile identity = IMSI                                                                              |
|      |           |    |                                       | Attach result = 'PS-only attached'                                                                  |
|      |           |    |                                       | Mobile identity = P-TMSI-1                                                                          |
|      |           |    |                                       | P-TMSI-1 signature                                                                                  |
|      |           |    |                                       | Routing-area identity = RAI-1                                                                       |
| 5    | →         |    | ATTACH COMPLETE                       |                                                                                                     |
| 6    | ←         |    | PAGING TYPE1                          |                                                                                                     |
| 7    | →         |    | SERVICE REQUEST                       | Service type = "Paging response"                                                                    |
| 8    | ←         |    | AUTHENTICATION AND CIPHERING REQUEST  |                                                                                                     |
| 9    | →         |    | AUTHENTICATION AND CIPHERING RESPONSE |                                                                                                     |
| 10   | UE        |    |                                       | The UE is switched off or power is removed (see ICS).                                               |
| 11   | →         |    | DETACH REQUEST                        | Message not sent if power is removed.                                                               |
|      |           |    |                                       | Detach type = 'power switched off, PS detach'                                                       |
| 12   | UE        |    |                                       | The UE is set in UE-operation mode A (see ICS) and the test is repeated from step 2 to step 11.     |

## Specific message contents

None.

## 12.9.2.5 Test requirements

At step3, when the UE is powered on or switched on, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step6, when the UE receives a paging request for PS domain from the network in PMM-IDLE mode, the UE shall:

- send the SERVICE REQUEST message with service type indicated "paging response".

## 12.9.3 Service Request / rejected / Illegal MS

## 12.9.3.1 Definition

## 12.9.3.2 Conformance requirement

If the network rejects a service request procedure from the UE with the cause "Illegal MS", the UE shall:

- 1) set the GPRS update status to GU3 ROAMING NOT ALLOWED and enter state GMM DEREGISTERED.
- 2) delete any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number.
- 3) consider the USIM as invalid for PS service until switched off or the USIM is removed.

## Reference

TS 24.008 clauses 4.7.13.4

### ~~12.9.3.3 Test purpose~~

~~To test the behaviour of the UE if the network rejects the service request procedure with the cause "Illegal MS".~~

### ~~12.9.3.4 Method of test~~

#### ~~Initial condition~~

#### ~~System Simulator:~~

~~One cell operating in network operation mode II.~~

#### ~~User Equipment:~~

~~The UE has a valid P-TMSI-1, P-TMSI-1 signature, RAI-1 and IMSI.~~

#### ~~Related ICS/IXIT statements~~

~~Support of PS service Yes/No~~

~~UE operation mode A Yes/No~~

~~UE operation mode C Yes/No~~

~~Switch off on button Yes/No~~

#### ~~Test procedure~~

- ~~a) The UE sends a SERVICE REQUEST message to the SS in order to establish the PS signalling connection for the upper layer signalling.~~
- ~~b) After the SS receiving the SERVICE REQUEST message, the SS sends a SERVICE REJECT message with the cause value #3(Illegal MS).~~
- ~~c) After the UE receives the SERVICE REJECT message with the cause value #3(Illegal MS), the UE deletes any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number.~~
- ~~d) The SS checks that the UE does not initiate an upper-layer signalling until the power of the UE is switched off.~~
- ~~e) The SS checks that the UE does not initiate an upper-layer signalling until the USIM is removed from the UE.~~

## Expected Sequence

| Step | Direction |    | Message         | Comments                                                                                                           |
|------|-----------|----|-----------------|--------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                 |                                                                                                                    |
| 1    | UE        |    |                 | The following message are sent and shall be received on cell A.<br>The UE is set in UE operation mode C (see ICS). |
| 2    | SS        |    |                 | The SS is set in network operation mode II and activates cell A.                                                   |
| 3    | UE        |    |                 | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.              |
| 4    | ->        |    | ATTACH-REQUEST  | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                      |
| 5    | <-        |    | ATTACH-ACCEPT   | Routing area identity = RAI-1<br>No new mobile identity assigned.<br>P-TMSI and P-TMSI signature not included.     |
| 6    |           |    | Void            | Routing area identity = RAI-1<br>Attach result = 'PS only attached'                                                |
| 7    | UE        |    |                 | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.             |
| 8    | ->        |    | SERVICE-REQUEST | Service type = "signalling"                                                                                        |
| 9    | <-        |    | SERVICE-REJECT  | Reject cause = "Illegal MS"                                                                                        |
| 10   | UE        |    |                 | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.             |
| 11   | SS        |    |                 | The SS verifies that the UE does not attempt to access the network.<br>(SS waits 30 seconds)                       |
| 12   | UE        |    |                 | The UE is switched off.                                                                                            |
| 13   |           |    | Void            |                                                                                                                    |
| 14   | UE        |    |                 | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.              |
| 15   | ->        |    | ATTACH-REQUEST  | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                |
| 16   | <-        |    | ATTACH-ACCEPT   | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                             |
| 17   | ->        |    | ATTACH-COMPLETE | Routing area identity = RAI-1                                                                                      |
| 18   | UE        |    |                 | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.             |
| 19   | ->        |    | SERVICE-REQUEST | Service type = "signalling"                                                                                        |
| 20   | <-        |    | SERVICE-REJECT  | Reject cause = "Illegal MS"                                                                                        |
| 21   | UE        |    |                 | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.             |
| 22   | SS        |    |                 | The SS verifies that the UE does not attempt to access the network.<br>(SS waits 30 seconds)                       |
| 23   | UE        |    |                 | USIM is removed.                                                                                                   |
| 24   | UE        |    |                 | USIM is inserted.                                                                                                  |
| 25   | UE        |    |                 | The UE initiates a PS attach, by MMI or by AT command.                                                             |
| 26   | ->        |    | ATTACH-REQUEST  | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                |
| 27   | <-        |    | ATTACH-ACCEPT   | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                             |
| 28   | ->        |    | ATTACH-COMPLETE | Routing area identity = RAI-1                                                                                      |

| Step | Direction |    | Message                                                                       | Comments                                                                                                                                      |
|------|-----------|----|-------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                               |                                                                                                                                               |
| 29   | UE        |    | SERVICE REQUEST                                                               | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.                                        |
| 30   | ->        |    |                                                                               | Service type = "signalling"                                                                                                                   |
| 31   | <-        |    | AUTHENTICATION AND CIPHERING REQUEST<br>AUTHENTICATION AND CIPHERING RESPONSE | The SS initiate a security mode control procedure.<br>After the security mode control procedure is completed, the SS releases RRC connection. |
| 32   | ->        |    |                                                                               |                                                                                                                                               |
| 33   | SS        |    |                                                                               |                                                                                                                                               |
| 34   | SS        |    |                                                                               |                                                                                                                                               |
| 35   | UE        |    | DETACH REQUEST                                                                | The UE is switched off or power is removed (see ICS).                                                                                         |
| 36   | ->        |    |                                                                               | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                        |

### Specific message contents

None.

### 12.9.3.5 Test requirements

At step4, when the UE is powered on or switched on, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step11, when the UE receives the SERVICE REJECT message with cause "Illegal MS" UE shall:

- not attempt to access the network.

At step15, when the UE is powered on or switched on, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step22, when the UE receives the SERVICE REJECT message with cause "Illegal MS" UE shall:

- not attempt to access the network.

At step26, when the USIM is replaced, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step30, UE shall:

- initiate the service request procedure.

## 12.9.4 Service Request / rejected / PS services not allowed

### 12.9.4.1 Definition

### 12.9.4.2 Conformance requirement

If the network rejects a service request procedure from the UE with the cause "PS services not allowed", the UE shall:

- 1) set the GPRS update state to GU3 ROAMING NOT ALLOWED.
- 2) delete any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number.
- 3) consider the USIM as invalid for PS service until the UE is switched off or until the USIM is removed.



## Reference

TS 24.008 clauses 4.7.13.4

### ~~12.9.4.3~~ ~~Test purpose~~

~~To test the behaviour of the UE if the network rejects the service request procedure with the cause "PS service not allowed".~~

### ~~12.9.4.4~~ ~~Method of test~~

#### Initial condition

##### System Simulator:

One cell operating in network operation mode II.

##### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

#### Related ICS/IXIT statements

Support of PS service Yes/No

UE operation mode A Yes/No

UE operation mode C Yes/No

Switch off on button Yes/No

#### Test procedure

- a) ~~The UE sends a SERVICE REQUEST message to the SS in order to establish the PS signalling connection for the upper layer signalling.~~
- b) ~~After the SS receiving the SERVICE REQUEST message, the SS sends a SERVICE REJECT message with the cause value #7(PS services not allowed).~~
- c) ~~After the UE receives the SERVICE REJECT message with the cause value #7(PS services not allowed), the UE deletes any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number.~~
- d) ~~The SS checks that the UE does not initiate an upper layer signalling until the UE is switched off.~~
- e) ~~The SS checks that the UE does not initiate an upper layer signalling until the USIM is removed from the UE.~~

## Expected Sequence

| Step | Direction |    | Message         | Comments                                                                                                           |
|------|-----------|----|-----------------|--------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                 |                                                                                                                    |
| 1    | UE        |    |                 | The following message are sent and shall be received on cell A.<br>The UE is set in UE operation mode C (see ICS). |
| 2    | SS        |    |                 | The SS is set in network operation mode II and activates cell A.                                                   |
| 3    | UE        |    |                 | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.              |
| 4    | ->        |    | ATTACH REQUEST  | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                      |
| 5    | <-        |    | ATTACH ACCEPT   | Routing area identity = RAI-1<br>No new mobile identity assigned.<br>P-TMSI and P-TMSI signature not included.     |
| 6    |           |    | Void            | Routing area identity = RAI-1<br>Attach result = 'PS only attached'                                                |
| 7    | UE        |    |                 | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.             |
| 8    | ->        |    | SERVICE REQUEST | Service type = "signalling"                                                                                        |
| 9    | <-        |    | SERVICE REJECT  | Reject cause = "PS services not allowed"                                                                           |
| 10   | UE        |    |                 | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.             |
| 11   | SS        |    |                 | The SS verifies that the UE does not attempt to access the network.<br>(SS wait 30seconds)                         |
| 12   | UE        |    |                 | The UE is switched off.                                                                                            |
| 13   |           |    | Void            |                                                                                                                    |
| 14   | UE        |    |                 | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.              |
| 15   | ->        |    | ATTACH REQUEST  | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                |
| 16   | <-        |    | ATTACH ACCEPT   | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                             |
| 17   | ->        |    | ATTACH COMPLETE | Routing area identity = RAI-2                                                                                      |
| 18   | UE        |    |                 | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.             |
| 19   | ->        |    | SERVICE REQUEST | Service type = "signalling"                                                                                        |
| 20   | <-        |    | SERVICE REJECT  | Reject cause = "PS services not allowed"                                                                           |
| 21   | UE        |    |                 | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.             |
| 22   | SS        |    |                 | The SS verifies that the UE does not attempt to access the network.<br>(SS wait 30seconds)                         |
| 23   | UE        |    |                 | USIM is removed.                                                                                                   |
| 24   | UE        |    |                 | USIM is inserted.                                                                                                  |
| 25   | UE        |    |                 | The UE initiates a PS attach, by MMI or by AT command.                                                             |
| 26   | ->        |    | ATTACH REQUEST  | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                |
| 27   | <-        |    | ATTACH ACCEPT   | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                             |
| 28   | ->        |    | ATTACH COMPLETE | Routing area identity = RAI-3                                                                                      |

| Step | Direction |    | Message                                                                       | Comments                                                                                                                                      |
|------|-----------|----|-------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                               |                                                                                                                                               |
| 29   | UE        |    | SERVICE REQUEST                                                               | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.                                        |
| 30   | ->        |    |                                                                               | Service type = "signalling"                                                                                                                   |
| 31   | <-        |    | AUTHENTICATION AND CIPHERING REQUEST<br>AUTHENTICATION AND CIPHERING RESPONSE | The SS initiate a security mode control procedure.<br>After the security mode control procedure is completed, the SS releases RRC connection. |
| 32   | ->        |    |                                                                               |                                                                                                                                               |
| 33   | SS        |    |                                                                               |                                                                                                                                               |
| 34   | SS        |    |                                                                               |                                                                                                                                               |
| 35   | UE        |    | DETACH REQUEST                                                                | The UE is switched off or power is removed (see ICS).                                                                                         |
| 36   | ->        |    |                                                                               | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                        |

### Specific message contents

#### 12.9.4.5 Test requirements

At step4, when the UE is powered on or switched on, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step11, when the UE receives the SERVICE REJECT message with cause "PS services not allowed" UE shall:

- not attempt to access the network.

At step15, when the UE is powered on or switched on, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step22, when the UE receives the SERVICE REJECT message with cause "PS services not allowed" UE shall:

- not attempt to access the network.

At step26, when the USIM is replaced, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step30, UE shall:

- initiate the service request procedure.

### 12.9.5 Service Request / rejected / MS identity cannot be derived by the network

#### 12.9.5.1 Definition

#### 12.9.5.2 Conformance requirement

If the network rejects a service request procedure from the UE with the cause "MS identity cannot be derived by the network", the UE shall:

- 1) set the GPRS update states to GU2 NOT UPDATED.
- 2) delete any P-TMSI, P-TMSI signature, RAI and GPRS ciphering key sequence number.
- 3) initiate the PS attach procedure automatically.

## Reference

TS 24.008 clauses 4.7.13.4

### ~~12.9.5.3~~ ~~Test purpose~~

~~To test the behaviour of the UE if the network rejects the service request procedure with the cause "MS identity cannot be derived by the network".~~

### ~~12.9.5.4~~ ~~Method of test~~

#### Initial condition

##### System Simulator:

One cell operating in network operation mode II.

##### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

#### Related ICS/IXIT statements

Support of PS service Yes/No

UE operation mode A Yes/No

UE operation mode C Yes/No

Switch off on button Yes/No

Automatic PS attach procedure at switch on or power on Yes/No

#### Test procedure

- ~~a) The UE sends a SERVICE REQUEST message to the SS in order to establish the PS signalling connection for the upper layer signalling.~~
- ~~b) After the SS receiving the SERVICE REQUEST message, the SS sends a SERVICE REJECT message with the cause value #9 (MS identity cannot be derived by the network).~~

## Expected Sequence

| Step | Direction |    | Message                               | Comments                                                                                                                                             |
|------|-----------|----|---------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                                                                      |
| 1    | UE        |    |                                       | The following message are sent and shall be received on cell A.<br>The UE is set in UE operation mode C (see ICS).                                   |
| 2    | SS        |    |                                       | The SS is set in network operation mode II and activates cell A.                                                                                     |
| 3    | UE        |    |                                       | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                |
| 4    | ->        |    | ATTACH REQUEST                        | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                                       |
| 5    | <-        |    | ATTACH ACCEPT                         | No new mobile identity assigned.<br>P-TMSI and P-TMSI signature not included.<br>Routing area identity = RAI-1<br>Attach result = 'PS only attached' |
| 6    |           |    | Void                                  |                                                                                                                                                      |
| 7    | UE        |    |                                       | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.                                               |
| 8    | ->        |    | SERVICE REQUEST                       | Service type = "signalling"                                                                                                                          |
| 9    | <-        |    | SERVICE REJECT                        | Reject cause = "MS identity cannot be derived by the network"                                                                                        |
| 10   | UE        |    |                                       | The UE automatically initiates the PS attach procedure.                                                                                              |
| 11   | ->        |    | ATTACH REQUEST                        | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                                                  |
| 12   | <-        |    | ATTACH ACCEPT                         | Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature                                                               |
| 13   | ->        |    | ATTACH COMPLETE                       |                                                                                                                                                      |
| 14   | UE        |    |                                       | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.                                               |
| 15   | ->        |    | SERVICE REQUEST                       | Service type = "signalling"                                                                                                                          |
| 16   | <-        |    | AUTHENTICATION AND CIPHERING REQUEST  |                                                                                                                                                      |
| 17   | ->        |    | AUTHENTICATION AND CIPHERING RESPONSE |                                                                                                                                                      |
| 18   | SS        |    |                                       | The SS initiate a security mode control procedure.                                                                                                   |
| 19   | SS        |    |                                       | After the security mode control procedure is completed, the SS releases RRC connection.                                                              |
| 20   | UE        |    |                                       | The UE is switched off or power is removed (see ICS).                                                                                                |
| 21   | ->        |    | DETACH REQUEST                        | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                               |

## Specific message contents

None.

## 12.9.5.5 Test requirements

At step4, when the UE is powered on or switched on, UE shall:

—initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step11, when the UE receives the SERVICE REJECT message with cause "MS identity cannot be derived by the network" UE shall:

- initiate PS attach procedure automatically.

## ~~12.9.6 Service Request / rejected / PLMN not allowed~~

### ~~12.9.6.1 Definition~~

### ~~12.9.6.2 Conformance requirement~~

~~If the network rejects a service request procedure from the UE with the cause "PLMN not allowed", the UE shall:~~

- ~~1) delete any RAI, P-TMSI, P-TMSI signature and GPRS ciphering key sequence number.~~
- ~~2) set the GPRS update status to GU3 ROAMING NOT ALLOWED.~~
- ~~3) store the LAI or the PLMN identity in the appropriate forbidden list.~~

### Reference

TS 24.008 clauses 4.7.13.4

### ~~12.9.6.3 Test purpose~~

~~To test the behaviour of the UE if the network rejects the service request procedure with the cause "PLMN not allowed".~~

### ~~12.9.6.4 Method of test~~

#### Initial condition

#### System Simulator:

- Two cells (not simultaneously activated), cell A in MCC1/MNC1/LAC1/RAC1 cell B in MCC2/MNC1/LAC1/RAC1.
- All two cells are operating in network operation mode II.

#### User Equipment:

- The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

### Related ICS/IXIT statements

- Support of PS service Yes/No
- UE operation mode A Yes/No
- UE operation mode C Yes/No
- Switch off on button Yes/No

### Test procedure

- ~~The UE sends a SERVICE REQUEST message to the SS in order to establish the PS signalling connection for the upper layer signalling.~~
- ~~After the SS receiving the SERVICE REQUEST message, the SS sends a SERVICE REJECT message with the cause value #11 (PLMN not allowed).~~
- ~~The SS checks that the UE does not initiate an upper layer signalling until the UE is switched off.~~
- ~~The SS checks that the UE does not answer a Page from the SS until the power of the UE is switched off.~~

## Expected Sequence

| Step                                                                                                                                                      | Direction |    | Message         | Comments                                                                                                                                                                                    |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                           | UE        | SS |                 |                                                                                                                                                                                             |
| 1                                                                                                                                                         | UE        |    |                 | The following message are sent and shall be received on cell A.<br>The UE is set in UE operation mode C (see ICS).                                                                          |
| 2                                                                                                                                                         | SS        |    |                 | The SS is set in network operation mode II.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Off cell".<br>(see note)                           |
| 3                                                                                                                                                         | UE        |    |                 | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                       |
| 4                                                                                                                                                         | ->        |    | ATTACH REQUEST  | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                                                                              |
| 5                                                                                                                                                         | <-        |    | ATTACH ACCEPT   | No new mobile identity assigned.<br>P-TMSI and P-TMSI signature not included.<br>Routing area identity = RAI-1<br>Attach result = 'PS only attached'                                        |
| 6                                                                                                                                                         |           |    | Void            |                                                                                                                                                                                             |
| 7                                                                                                                                                         | UE        |    |                 | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.                                                                                      |
| 8                                                                                                                                                         | ->        |    | SERVICE REQUEST | Service type = "signalling"                                                                                                                                                                 |
| 9                                                                                                                                                         | <-        |    | SERVICE REJECT  | Reject cause = "PLMN not allowed"                                                                                                                                                           |
| 10                                                                                                                                                        | UE        |    |                 | The UE stores the LAI or the PLMN identity in the "forbidden PLMN list".                                                                                                                    |
| 11                                                                                                                                                        | UE        |    |                 | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.                                                                                      |
| 12                                                                                                                                                        | SS        |    |                 | The SS verifies that the UE does not attempt to access the network.<br>(SS wait 30second)                                                                                                   |
| 13                                                                                                                                                        | <-        |    | PAGING TYPE1    | Paging order is for PS service                                                                                                                                                              |
| 14                                                                                                                                                        | UE        |    |                 | No response from the UE to the request. This is checked for 10 seconds.                                                                                                                     |
| 15                                                                                                                                                        | SS        |    |                 | The following messages shall be sent and shall be received on cell B.<br>Set the cell type of cell A to the "Off cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note) |
| 16                                                                                                                                                        | UE        |    |                 | Cell B is preferred by the UE.                                                                                                                                                              |
| 17                                                                                                                                                        | UE        |    |                 | The UE initiates an attach automatically, by MMI or by AT command.                                                                                                                          |
| 18                                                                                                                                                        | ->        |    | ATTACH REQUEST  | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                                                                                         |
| 19                                                                                                                                                        | <-        |    | ATTACH ACCEPT   | Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-2<br>Attach result = 'PS only attached'                                                                     |
| 20                                                                                                                                                        | ->        |    | ATTACH COMPLETE |                                                                                                                                                                                             |
| 21                                                                                                                                                        | UE        |    |                 | The UE is switched off or power is removed (see ICS).                                                                                                                                       |
| 22                                                                                                                                                        | ->        |    | DETACH REQUEST  |                                                                                                                                                                                             |
| NOTE: The definitions for "Off cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                 |                                                                                                                                                                                             |

## Specific message contents

None.

#### ~~12.9.6.5 Test requirements~~

~~At step4, when the UE is powered on or switched on, UE shall:~~

- ~~—initiate the PS attach procedure with information elements specified in the above Expected Sequence.~~

~~At step12, when the UE receives the SERVICE REJECT message with cause "PLMN not allowed", UE shall:~~

- ~~—not perform a PS attach procedure in the same PLMN.~~

~~At step13, when the UE receives the paging message for PS domain UE shall:~~

- ~~—not respond to the paging message for PS domain.~~

~~At step18, UE shall:~~

- ~~—perform PS attach procedure.~~

### ~~12.9.7a Service Request / rejected / No PDP context activated~~

#### ~~12.9.7a.1 Definition~~

#### ~~12.9.7a.2 Conformance requirement~~

~~If the network rejects a service request procedure with the cause "No PDP context activated", the UE shall:~~

- ~~—deactivate all active PDP contexts.~~

~~After the UE deactivates all active PDP contexts, UE shall:~~

- ~~—perform PDP context(s) activation.~~

#### ~~Reference~~

~~TS 24.008 clauses 4.7.13.4~~

#### ~~12.9.7a.3 Test purpose~~

~~To test the behaviour of the UE if the network rejects the service request procedure with the cause "No PDP context activated".~~

#### ~~12.9.7a.4 Method of test~~

##### ~~Initial condition~~

~~System Simulator:~~

~~One cell operating in network operation mode II.~~

~~User Equipment:~~

~~The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.~~

#### ~~Related ICS/IXIT statements~~

~~Support of PS service Yes/No~~

~~UE operation mode A Yes/No~~

~~UE operation mode C Yes/No~~

~~Switch off on button Yes/No~~



### Test procedure

- a) The UE sends a SERVICE REQUEST message to the SS in order to establish the PS signalling connection for the upper layer signalling.
- b) After the SS receiving the SERVICE REQUEST message, the SS sends a SERVICE REJECT message with the cause value #40 (No PDP context activated).
- c) After the UE receives the SERVICE REJECT message, the UE shall send the ACTIVATE PDP CONTEXT REQUEST message.

### Expected Sequence

| Step | Direction |    | Message                      | Comments                                                                                              |
|------|-----------|----|------------------------------|-------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                              |                                                                                                       |
| 1    |           |    |                              | The following message are sent and shall be received on cell A.                                       |
| 2    |           |    |                              | The UE is set in UE operation mode C (see ICS).                                                       |
| 3    |           |    |                              | The SS is set in network operation mode II and activates cell A.                                      |
| 4    | ->        |    | ATTACH REQUEST               | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE. |
| 5    | <-        |    | ATTACH ACCEPT                |                                                                                                       |
| 6    | ->        |    | ATTACH COMPLETE              |                                                                                                       |
| 7    | UE        |    |                              |                                                                                                       |
| 8    | ->        |    | SERVICE REQUEST              | The UE initiates a PS call, by MMI or by AT command.                                                  |
| 9    | <-        |    | SERVICE REJECT               | Service type = "signalling"                                                                           |
| 10   | UE        |    |                              | Reject cause = "No PDP context activated"                                                             |
| 11   | UE        |    |                              | The UE shall deactivate locally all active PDP contexts.                                              |
| 11a  | ->        |    | SERVICE REQUEST              | The UE initiates a PS call, by MMI or by AT command.                                                  |
| 11b  | SS        |    |                              | Service type = "signalling"                                                                           |
| 12   | ->        |    | ACTIVATE PDP CONTEXT REQUEST | SS initiates a security procedure by sending SECURITY MODE COMMAND message.                           |
| 13   | <-        |    | ACTIVATE PDP CONTEXT ACCEPT  | Request a PDP context activation                                                                      |
| 14   | UE        |    |                              | Accept the PDP context activation                                                                     |
| 15   | ->        |    | DEACTIVE PDP CONTEXT REQUEST | The UE initiates Deactivate PDP Context request, by MMI or by AT command.                             |
| 16   | <-        |    | DEACTIVE PDP CONTEXT ACCEPT  | Deactivate PDP context deactivation                                                                   |
| 17   | UE        |    |                              | Accept PDP context deactivation                                                                       |
| 18   | UE        |    |                              | The UE is switched off or power is removed (see ICS).                                                 |
| 19   | ->        |    | DETACH REQUEST               | The UE initiates Detach request, by MMI or by AT command.                                             |
|      |           |    |                              | Message not sent if power is removed.                                                                 |
|      |           |    |                              | Detach type = 'power switched off, PS detach'                                                         |

### Specific message contents

None.

### 12.9.7a.5 Test requirements

At step4, when the UE is powered on or switched on, UE shall:

- initiate the PS attach procedure.

When the UE receives a SERVICE REJECT message with the cause "No PDP context activated", UE shall:

- deactivate all active PDP context.

At step11a, UE shall:

- initiates a Service request procedure.

At step12, UE shall:

- perform PDP context(s) activation.

### ~~12.9.7b — Service Request / rejected / No Suitable Cells In Location Area~~

#### ~~12.9.7b.1 — Definition~~

#### ~~12.9.7b.2 — Conformance requirement~~

If the network rejects a service request procedure from the UE with the cause "No Suitable Cells In Location Area", the UE shall:

- 1) delete any RAI, P-TMSI, P-TMSI signature and GPRS ciphering key sequence number.
- 2) set the GPRS update status to GU3 ROAMING NOT ALLOWED.
- 3) store the LAI or the PLMN identity in the list of 'forbidden location areas for roaming'.
- 4) search for a suitable cell in a different location area on the same PLMN.

#### Reference

TS 24.008 clauses 4.7.13.4

#### ~~12.9.7b.3 — Test purpose~~

To test the behaviour of the UE if the network rejects the service request procedure with the cause "No Suitable Cells In Location Area".

#### ~~12.9.7b.4 — Method of test~~

#### Initial condition

System Simulator:

Three cells, cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC2/RAC1 (RAI-3), cell C in MCC2/MNC1/LAC1/RAC1 (RAI-2)

All three cells are operating in network operation mode II.

User Equipment:

The UE has valid IMSI.

#### Related ICS/IXIT statements

Support of PS service — Yes/No

UE operation mode A — Yes/No

Switch off on button — Yes/No

Automatic PS attach procedure at switch on or power on — Yes/No

## Test procedure

The SS rejects a Service request with the cause value 'No Suitable Cells In Location Area'. The SS checks that the UE shall perform PS attach procedure when the UE enters a suitable cell in a different location area on the same PLMN.

## Expected Sequence

| Step                                                                                                                                                                     | Direction |    | Message         | Comments                                                                                                                                                                                                                                                                                 |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                          | UE        | SS |                 |                                                                                                                                                                                                                                                                                          |
|                                                                                                                                                                          |           | SS |                 | Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>Set the cell type of cell C to the "Suitable neighbour cell".<br>(see note)<br>The SS configures power level of each Cell as follows:<br>Cell A > Cell B = Cell C |
| 1                                                                                                                                                                        | UE        |    |                 | The UE is set in UE operation mode A (see ICS).                                                                                                                                                                                                                                          |
| 2                                                                                                                                                                        | UE        |    |                 | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                                                                                                                    |
| 3                                                                                                                                                                        | ->        |    | ATTACH REQUEST  | Attach type = 'Combined PS / IMSI attach'<br>Mobile identity = IMSI                                                                                                                                                                                                                      |
| 4                                                                                                                                                                        | <-        |    | ATTACH ACCEPT   | TMSI status = no valid TMSI available<br>Attach result = 'Combined PS / IMSI attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Mobile identity = TMSI-1<br>Routing area identity = RAI-1                                                                                  |
| 5                                                                                                                                                                        | ->        |    | ATTACH COMPLETE |                                                                                                                                                                                                                                                                                          |
| 6                                                                                                                                                                        | SS        |    |                 | The SS initiates the RRC connection release.                                                                                                                                                                                                                                             |
| 7                                                                                                                                                                        | UE        |    |                 | The UE initiates a PS call, by MMI or by AT command.                                                                                                                                                                                                                                     |
| 8                                                                                                                                                                        | ->        |    | SERVICE REQUEST | Service type = "signalling"                                                                                                                                                                                                                                                              |
| 9                                                                                                                                                                        | <-        |    | SERVICE REJECT  | Reject cause = "No Suitable Cells In Location Area"                                                                                                                                                                                                                                      |
|                                                                                                                                                                          |           |    |                 | The following message are sent and shall be received on cell B.                                                                                                                                                                                                                          |
| 10                                                                                                                                                                       | ->        |    | ATTACH REQUEST  | Attach type = 'PS attach'<br>Mobile identity = IMSI                                                                                                                                                                                                                                      |
| 11                                                                                                                                                                       | <-        |    | ATTACH ACCEPT   | Mobile identity = P-TMSI-2<br>P-TMSI-2 signature<br>Routing area identity = RAI-2<br>Attach result = 'PS only attached'                                                                                                                                                                  |
| 12                                                                                                                                                                       | ->        |    | ATTACH COMPLETE |                                                                                                                                                                                                                                                                                          |
| 13                                                                                                                                                                       | UE        |    |                 | The UE is switched off or power is removed (see ICS).                                                                                                                                                                                                                                    |
| 14                                                                                                                                                                       | ->        |    | DETACH REQUEST  |                                                                                                                                                                                                                                                                                          |
| NOTE: The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                 |                                                                                                                                                                                                                                                                                          |

## Specific message contents

None.

## 12.9.7b.5 Test requirements

At step3, when the UE is powered on or switched on, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step10, when the UE enters a suitable cell in a different location area on the same PLMN, UE shall:

~~—perform the PS attach procedure.~~

## ~~12.9.8 Service Request / Abnormal cases / Access barred due to access class control~~

### ~~12.9.8.1 Definition~~

### ~~12.9.8.2 Conformance requirement~~

~~If the UE access class X is barred, the UE shall:~~

- ~~1) not start Service Request procedure.~~
- ~~2) stay in the current serving cell.~~
- ~~3) apply normal cell reselection process.~~

~~If the UE access class X is granted or serving cell is changed, the UE shall:~~

- ~~1) start Service Request procedure.~~

### ~~Reference~~

~~TS 24.008 clauses 4.7.13.5.~~

### ~~12.9.8.3 Test purpose~~

~~To test the behavior of the UE in case of access class control (access is granted).~~

### ~~12.9.8.4 Method of test~~

#### ~~Initial condition~~

~~A random access class X (0-15) is selected. The USIM is programmed with this access class X.~~

~~Initially, an access class X is barred.~~

#### ~~System Simulator:~~

~~One cell operating in network operation mode II.~~

~~Access class x barred.~~

#### ~~User Equipment:~~

~~The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.~~

### ~~Related ICS/IXIT statements~~

~~Support of PS service—Yes/No~~

~~UE operation mode C—Yes/No~~

~~UE operation mode A—Yes/No~~

~~Switch off on button—Yes/No~~

~~Automatic PS attach procedure at switch on or power on—Yes/No~~

### ~~Test procedure~~

~~The SS initiates access class X barred. A service request procedure is not performed.~~

The SS initiates that access class X is not barred. A service request procedure is performed.

#### Expected Sequence

| Step | Direction |    | Message                               | Comments                                                                                                                                                |
|------|-----------|----|---------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                                                                         |
| 1    | UE        |    |                                       | The USIM is set up Access class x.<br>The access class x is barred in cell A.<br>The UE is powered up or switched on and attempt to initiate an ATTACH. |
| 2    | UE        |    |                                       | No SERVICE REQUEST sent to SS, as access class X is barred.<br>(SS waits 30 seconds)                                                                    |
| 3    | SS        |    |                                       | The access class x is not barred anymore.                                                                                                               |
| 4    | UE        |    |                                       | The UE automatically initiates an attach.                                                                                                               |
| 5    | ->        |    | ATTACH REQUEST                        | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-2<br>P-TMSI-2 signature                                                                           |
| 6    | <-        |    | ATTACH ACCEPT                         | Routing area identity = RAI-1<br>Attach result = 'PS only attached'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                 |
| 7    | ->        |    | ATTACH COMPLETE                       | Routing area identity = RAI-1                                                                                                                           |
| 8    | UE        |    |                                       | The UE initiates an upper layer signalling, e.g., Active PDP Context request, by MMI or by AT command.                                                  |
| 9    | ->        |    | SERVICE REQUEST                       | Service Type = "signalling".                                                                                                                            |
| 10   | <-        |    | AUTHENTICATION AND CIPHERING REQUEST  |                                                                                                                                                         |
| 11   | ->        |    | AUTHENTICATION AND CIPHERING RESPONSE |                                                                                                                                                         |
| 12   | UE        |    |                                       | The UE is switched off or power is removed (see ICS).                                                                                                   |
| 13   | ->        |    | DETACH REQUEST                        | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                  |

#### Specific message contents

None.

#### 12.9.8.5 Test requirements

At step2, when the UE access class x is barred, UE shall:

— not perform Service Request procedure.

At step5, when the UE access class x is barred, UE shall:

— initiate the PS attach procedure.

At step9, UE shall:

— perform Service Request procedure.

## ~~12.9.9 Service Request / Abnormal cases / Routing area update procedure is triggered~~

### ~~12.9.9.1 Definition~~

### ~~12.9.9.2 Conformance requirement~~

If a cell change into a new routing area occurs and the necessity of routing area update procedure is determined before the security mode control procedure is completed, the UE shall:

- ~~— abort Service request procedure.~~
- ~~— start routing area update procedure immediately.~~

### Reference

~~TS 24.008 clause 4.7.13.5~~

### ~~12.9.9.3 Test purpose~~

To test the behavior of the UE in case of collision between Routing area update procedure and Service request procedure.

### ~~12.9.9.4 Method of test~~

#### Initial condition

#### System Simulator:

Two cells, cell A in MCC1/MNC1/LAC1/RAC1 (RAI-1), cell B in MCC1/MNC1/LAC1/RAC2 (RAI-4). Both cells are operating in network operation mode II.

#### User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

#### Related ICS/IXIT statements

Support of PS service Yes/No

UE operation mode A Yes/No

UE operation mode C Yes/No

Switch off on button Yes/No

#### Test procedure

- ~~a) The UE sends a SERVICE REQUEST message to the SS in order to establish the PS signalling connection for the upper layer signalling.~~
- ~~b) The UE initiates the routing area update procedure.~~
- ~~c) The UE aborts Service request procedure and performs Routing area updating procedure.~~

## Expected Sequence

| Step                                                                                                                                                                       | Direction |    | Message                               | Comments                                                                                                                                                                                                                                                  |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                            | UE        | SS |                                       |                                                                                                                                                                                                                                                           |
| 1                                                                                                                                                                          | UE        |    |                                       | The following message are sent and shall be received on cell A.<br>The UE is set in UE operation mode C (see ICS).                                                                                                                                        |
| 2                                                                                                                                                                          |           | SS |                                       | The SS is set in network operation mode II.<br>Set the cell type of cell A to the "Serving cell".<br>Set the cell type of cell B to the "Suitable neighbour cell".<br>(see note)                                                                          |
| 3                                                                                                                                                                          | UE        |    |                                       | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                                                                                                                                     |
| 4                                                                                                                                                                          | ->        |    | ATTACH REQUEST                        | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                                                                                                             |
| 5                                                                                                                                                                          | <-        |    | ATTACH ACCEPT                         | Routing area identity = RAI-1<br>No new mobile identity assigned.<br>P-TMSI and P-TMSI signature not included.<br>Routing area identity = RAI-1<br>Attach result = 'PS-only attached'                                                                     |
| 6                                                                                                                                                                          | UE        |    | Void                                  | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.                                                                                                                                                    |
| 7                                                                                                                                                                          | ->        |    | SERVICE REQUEST                       | Service type = "signalling"                                                                                                                                                                                                                               |
| 8                                                                                                                                                                          | SS        |    |                                       | Activate cell B with a lower signal strength than cell A. The RF level of cell A is lowered until cell B is preferred by the UE.                                                                                                                          |
| 9                                                                                                                                                                          | UE        |    |                                       | The UE aborts Service request procedure.                                                                                                                                                                                                                  |
| 10                                                                                                                                                                         | ->        |    | ROUTING-AREA UPDATE REQUEST           | Set the cell type of cell A to the "Suitable neighbour cell".<br>Set the cell type of cell B to the "Serving cell".<br>(see note)<br>The following message are sent and shall be received on cell B.<br>Update type = 'RA updating'<br>P-TMSI-2 signature |
| 11                                                                                                                                                                         | <-        |    | ROUTING-AREA UPDATE ACCEPT            | Update result = 'RA updated'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature                                                                                                                                                                          |
| 12                                                                                                                                                                         | ->        |    | ROUTING-AREA UPDATE COMPLETE          | Routing area identity = RAI-4                                                                                                                                                                                                                             |
| 13                                                                                                                                                                         | UE        |    |                                       | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.                                                                                                                                                    |
| 14                                                                                                                                                                         | ->        |    | SERVICE REQUEST                       | Service type = "signalling"                                                                                                                                                                                                                               |
| 15                                                                                                                                                                         | <-        |    | AUTHENTICATION AND CIPHERING REQUEST  |                                                                                                                                                                                                                                                           |
| 16                                                                                                                                                                         | ->        |    | AUTHENTICATION AND CIPHERING RESPONSE |                                                                                                                                                                                                                                                           |
| 17                                                                                                                                                                         | SS        |    |                                       | The SS initiate a security mode control procedure.                                                                                                                                                                                                        |
| 18                                                                                                                                                                         | SS        |    |                                       | After the security mode control procedure is completed, the SS releases RRC connection.                                                                                                                                                                   |
| 19                                                                                                                                                                         | UE        |    |                                       | The UE is switched off or power is removed (see ICS).                                                                                                                                                                                                     |
| 20                                                                                                                                                                         | ->        |    | DETACH REQUEST                        | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                                                                                                                                                                    |
| NOTE: — The definitions for "Suitable neighbour cell" and "Serving cell" are specified in TS34.108 clause 6.1 "Reference Radio Conditions for signalling test cases only". |           |    |                                       |                                                                                                                                                                                                                                                           |

### Specific message contents

None.

#### 12.9.9.5 Test requirements

At step3, when the UE is powered on or switched on, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence—.

At step7, UE shall:

- perform the service request procedure.

At step10, when the routing area update procedure is initiated before the security mode control procedure is completed, UE shall;

- abort a Service request procedure
- perform the routing area updating procedure.

At step14, after the UE completes the routing area updating procedure, UE shall;

- restart the Service Request procedure.

### 12.9.10 Service Request / Abnormal cases / Power off

#### 12.9.10.1 Definition

#### 12.9.10.2 Conformance requirement

When the UE in GMM-SERVICE-REQUEST-INITIATED state is switched off, UE shall:

- perform PS detach procedure.

#### Reference

TS 24.008 clauses 4.7.13.5

#### 12.9.10.3 Test purpose

To test the behavior of the UE in case of collision between Service request procedure and "powered off".

#### 12.9.10.4 Method of test

#### Initial condition

System Simulator:

One cell operating in network operation mode II.

User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

#### Related ICS/IXIT statements

Support of PS service Yes/No

UE operation mode A Yes/No

UE operation mode C Yes/No

Switch off on button Yes/No



### Test procedure

The UE is switched off after initiating a Service request procedure. A PS detach is automatically performed by the UE before power is switched off.

### Expected Sequence

| Step | Direction |    | Message         | Comments                                                                                                                                     |
|------|-----------|----|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                 |                                                                                                                                              |
| 1    | UE        |    |                 | The following message are sent and shall be received on cell A.<br>The UE is set in UE operation mode C (see ICS).                           |
| 2    |           | SS |                 | The SS is set in network operation mode II and activates cell A.                                                                             |
| 3    | UE        |    |                 | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.                                        |
| 4    | ->        |    | ATTACH REQUEST  | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1                               |
| 5    | <-        |    | ATTACH ACCEPT   | No new mobile identity assigned.<br>P-TMSI and P-TMSI signature not included.<br>Routing area identity = RAI-1                               |
| 6    | UE        |    |                 | Attach result = 'PS only attached'<br>The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command. |
| 7    | ->        |    | SERVICE REQUEST | Service type = "signalling"                                                                                                                  |
| 8    | UE        |    |                 | The UE is powered off and initiates a PS detach (with power off) by MMI or by AT command.                                                    |
| 9    | ->        |    | DETACH REQUEST  | Detach type = 'power switched off, PS detach'                                                                                                |

### Specific message contents

None.

### 12.9.10.5 Test requirements

At step4, when the UE is powered on or switched on, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step7, UE shall:

- perform the service request procedure

At step9, when the UE is switched off during the Service Request procedure, UE shall;

- abort the Service request procedure.
- perform the PS detach procedure.

## ~~12.9.11 Service Request / Abnormal cases / Service request procedure collision~~

### ~~12.9.11.1 Definition~~

### ~~12.9.11.2 Conformance requirement~~

~~When the UE in GMM-SERVICE-REQUEST-INITIATED state receives a DETACH REQUEST message from the network, UE shall:~~

- ~~— perform the PS detach procedure.~~
- ~~— abort Service request procedure.~~

### Reference

TS 24.008 clauses 4.7.13.5

### ~~12.9.11.3 Test purpose~~

~~To test the behaviour of the UE in case of collision between Service request procedure and PS detach procedure.~~

### ~~12.9.11.4 Method of test~~

#### Initial condition

System Simulator:

One cell operating in network operation mode II.

User Equipment:

The UE has a valid P-TMSI-1, P-TMSI-1 signature and RAI-1.

#### Related ICS/IXIT statements

Support of PS service Yes/No

UE operation mode A Yes/No

UE operation mode C Yes/No

Switch off on button Yes/No

#### Test procedure

- ~~a) The UE sends a SERVICE REQUEST message to the SS in order to establish the PS signalling connection for the upper layer signalling.~~
- ~~b) The SS sends a DETACH REQUEST message to the UE, before the security procedure is not started.~~
- ~~c) After the UE receives the DETACH REQUEST message, the UE aborts the Service request procedure.~~

## Expected Sequence

| Step | Direction |    | Message         | Comments                                                                                                           |
|------|-----------|----|-----------------|--------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                 |                                                                                                                    |
| 1    | UE        |    |                 | The following message are sent and shall be received on cell A.<br>The UE is set in UE operation mode C (see ICS). |
| 2    | SS        |    |                 | The SS is set in network operation mode II and activates cell A.                                                   |
| 3    | UE        |    |                 | The UE is powered up or switched on and initiates an attach (see ICS). Cell A is preferred by the UE.              |
| 4    | ->        |    | ATTACH REQUEST  | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1     |
| 5    | <-        |    | ATTACH ACCEPT   | No new mobile identity assigned.<br>P-TMSI and P-TMSI signature not included.<br>Routing area identity = RAI-1     |
| 6    |           |    | Void            | Attach result = 'PS only attached'                                                                                 |
| 7    | UE        |    |                 | The UE initiates an upper-layer signalling, e.g., Active PDP Context request, by MMI or by AT command.             |
| 8    | ->        |    | SERVICE REQUEST | Service type = "signalling"                                                                                        |
| 9    | SS        |    |                 | The SS does not respond to SERVICE REQUEST message.                                                                |
| 10   | <-        |    | DETACH REQUEST  | GMM cause = "reattach request"                                                                                     |
| 11   | ->        |    | ATTACH REQUEST  | Attach type = 'PS attach'<br>Mobile identity = P-TMSI-1<br>P-TMSI-1 signature<br>Routing area identity = RAI-1     |
| 12   | <-        |    | ATTACH ACCEPT   | No new mobile identity assigned.<br>P-TMSI and P-TMSI signature not included.<br>Routing area identity = RAI-1     |
| 13   | ->        |    | ATTACH COMPLETE | Attach result = 'PS only attached'                                                                                 |
| 14   | UE        |    |                 | The UE is switched off or power is removed (see ICS).                                                              |
| 15   | ->        |    | DETACH REQUEST  | Message not sent if power is removed.<br>Detach type = 'power switched off, PS detach'                             |

## Specific message contents

None.

## 12.9.11.5 Test requirements

At step4, when the UE is powered on or switched on, UE shall:

- initiate the PS attach procedure with information elements specified in the above Expected Sequence.

At step11, when the UE receives a DETACH REQUEST message from the network before the Service request procedure completes, UE shall;

- abort the Service request procedure.
- perform the PS detach procedure.

## ~~13 General Tests~~

### ~~13.1 Emergency call / general~~

In this clause, the emergency call service is tested for user equipment that support Emergency speech call in the following cases:

- ~~— emergency call initiated in the MM idle state with authentication and security;~~
- ~~— emergency call initiated in the MM idle, no IMSI state (hence without authentication and without security), the network accepting the call;~~
- ~~— emergency call initiated in the MM idle, no IMSI state (hence without authentication and without security), the network rejecting the call.~~

These tests on emergency calls are only applicable to an UE supporting Emergency speech call.

### ~~13.2 Emergency call~~

Emergency call establishment can be initiated by an UE whether location updating has been successful or not and whether a USIM is inserted into the UE or not; but only if the UE is equipped for speech.

If the procedures tested in this clause are not correctly implemented in the UE, establishment, maintenance and clearing of connections might fail in the essential case of emergency calls.

The tests of this clause are only applicable to an UE supporting Emergency speech call.

#### ~~13.2.1 Emergency call / with USIM~~

##### ~~13.2.1.1 Emergency call / with USIM / accept case~~

###### ~~13.2.1.1.1 Definition~~

When a USIM is present, subscriber specific emergency call set-up MMI shall be provided. The operator shall specify preferred emergency call MMI(s) (e.g. 911 for US citizens or 110, 118 and 119 for Japanese citizens) for use in any (i.e. home or visited) PLMN. This shall be stored in the USIM and the UE shall read this and use any entry of these digits to set up an emergency call. It shall be possible to store more than one instance of this field.

When a USIM containing stored emergency numbers is present, only those numbers are identified as emergency numbers, i.e. default emergency numbers stored in the UE are ignored.

###### ~~13.2.1.1.2 Conformance requirement~~

- ~~1) The UE in the "MM idle" state, as after a successful location update, after the emergency call number has been entered by user, shall send a RRC CONNECTION REQUEST message with correct establishment cause ("emergency call").~~
- ~~2) After assignment of a dedicated channel the first layer message sent by the UE on the assigned dedicated channel shall be a CM SERVICE REQUEST message specifying the correct CKSN and TMSI, with CM Service Type "emergency call establishment".~~
- ~~3) Authentication and security mode setting shall be performed successfully.~~
- ~~4) After security mode setting acceptance by the network, the UE shall send an EMERGENCY SETUP message.~~
- ~~5), 6) The emergency call shall be correctly established. The assignment procedure shall be correctly performed.~~
- ~~7) After receipt of a CONNECT ACKNOWLEDGE message during correct establishment of the emergency call the DTCH shall be through connected in both directions if an appropriate DTCH is available.~~

- 8) The call shall be cleared correctly.

#### Reference(s):

- For conformance requirement 1 and 2: TS 25.331 clause 8.1.3, TS 24.008 clause 5.2.1, TS 24.008 clause 4.5.1.5, TS 22.010 clause 8.
- For conformance requirement 3: TS 25.331, clause 8.1.12, TS 24.008 clause 4.3.2.
- For conformance requirement 4: TS 24.008, clause 5.2.1.
- For conformance requirement 5 and 6: TS 25.331, clause 8.2.2.
- For conformance requirement 7: TS 24.008, clause 5.2.1.6.
- For conformance requirement 8: TS 24.008, clause 5.4.

#### 13.2.1.1.3 ————— Test purpose

- 1) To verify that an UE supporting speech in the state "MM idle", when made to call the emergency call number, sends a RRC CONNECTION REQUEST message with establishment cause "emergency call".
- 2) To verify that after assignment of a dedicated channel the first layer message sent by the UE on the assigned dedicated channel is a CM SERVICE REQUEST message specifying the correct CKSN and TMSI, with CM Service Type "emergency call establishment".
- 3) To verify that authentication and security mode setting are performed successfully.
- 4) To verify that after security mode setting acceptance by the SS, the UE sends an EMERGENCY SETUP message.
- 5) To verify that subsequently, the SS having sent a CALL PROCEEDING message and then an ALERT message and having initiated the assignment procedure of an appropriate speech traffic channel, the UE performs correctly that assignment procedure.
- 6) To verify subsequent correct performance of a connect procedure.
- 7) To verify that subsequently the UE has through connected the DTCH in both directions.
- 8) To verify that the call is cleared correctly.

#### 13.2.1.1.4 ————— Method of test

#### Related ICS Statements

- Emergency speech call.

#### Initial Conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE is in state "MM idle" with valid TMSI and CKSN.

#### Test procedure

The UE is made to initiate an emergency call. The call is established with late assignment. Having reached the active state, the call is cleared by the SS.

## Expected Sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                      |
|------|-----------|----|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                               |
| 1    | UE        |    |                                 | The "called emergency call number" is entered.                                                                                                                |
| 2    | →         |    | RRC CONNECTION REQUEST          | Establishment cause is emergency call establishment.                                                                                                          |
| 3    |           | ←  | RRC CONNECTION SETUP            | SS accepts the establishment of a RRC connection                                                                                                              |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE   |                                                                                                                                                               |
| 5    | →         |    | CM SERVICE REQUEST              | The CM service type IE indicates "emergency call establishment".                                                                                              |
| 6    |           | ←  | AUTHENTICATION REQUEST          | IE Authentication Parameter AUTN shall be present in the message.                                                                                             |
| 7    | →         |    | AUTHENTICATION RESPONSE         | SRES specifies correct value.                                                                                                                                 |
| 8    |           | ←  | SECURITY MODE COMMAND           | SS starts deciphering after sending the message.                                                                                                              |
| 9    | →         |    | SECURITY MODE COMPLETE          | Shall be sent enciphered. All following messages shall be sent enciphered.                                                                                    |
| 10   |           | SS |                                 | SS starts ciphering.                                                                                                                                          |
| 11   | →         |    | EMERGENCY SETUP                 |                                                                                                                                                               |
| 12   |           | ←  | CALL PROCEEDING                 |                                                                                                                                                               |
| 13   |           | ←  | ALERTING                        |                                                                                                                                                               |
| 14   |           | ←  | RADIO BEARER SETUP              | The rate of the channel is that one indicated by the EMERGENCY SETUP message, if that message did not offer a choice, and the rate is the preferred one else. |
| 15   | →         |    | RADIO BEARER SETUP COMPLETE     |                                                                                                                                                               |
| 16   |           | ←  | CONNECT                         |                                                                                                                                                               |
| 17   | →         |    | CONNECT ACKNOWLEDGE             |                                                                                                                                                               |
| 18   | UE        |    |                                 | The DTCH is through connected in both directions.                                                                                                             |
| 19   |           | ←  | DISCONNECT                      |                                                                                                                                                               |
| 20   | →         |    | RELEASE                         |                                                                                                                                                               |
| 21   |           | ←  | RELEASE COMPLETE                |                                                                                                                                                               |
| 22   |           | ←  | RRC CONNECTION RELEASE          |                                                                                                                                                               |
| 23   | →         |    | RRC CONNECTION RELEASE COMPLETE | The main signalling link is released.                                                                                                                         |

## Specific Message Contents

None.

~~13.2.2 Emergency call / without USIM~~~~13.2.2.1 Emergency call / without USIM / accept case~~~~13.2.2.1.1 Definition~~

The following emergency numbers shall be stored in the UE for use without USIM: 000, 08, 112, 110, 118, 119, 911 and 999.

~~13.2.2.1.2 Conformance requirement~~

- ~~1) The UE in the "MM idle, no IMSI" state, as after a successful location update, after the emergency call number has been entered by user, shall send a RRC CONNECTION REQUEST message with correct establishment cause ("emergency call").~~
- ~~2) After assignment of a dedicated channel the first layer message sent by the UE on the assigned dedicated channel shall be a CM SERVICE REQUEST message specifying the correct IMEI and a non-available CKSN, with CM Service Type "emergency call establishment".~~
- ~~3) After security mode setting acceptance by the network, the UE shall send an EMERGENCY SETUP message.~~
- ~~4), 5) The emergency call shall be correctly established. The assignment procedure shall be correctly performed.~~

- 6) After receipt of a CONNECT ACKNOWLEDGE message during correct establishment of the emergency call the DTCH shall be through connected in both directions if an appropriate DTCH is available.
- 7) The call shall be cleared correctly.

#### Reference(s):

- For conformance requirement 1 and 2: TS 25.331 clause 8.1.3, TS 24.008 clause 5.2.1, TS 24.008 clause 4.5.1.5, TS 22.010 clause 8.
- For conformance requirement 3: TS 24.008, clause 5.2.1.
- For conformance requirements 4 and 5: TS 25.331, clause 8.2.2.
- For conformance requirement 6: TS 24.008, clause 5.2.1.6.
- For conformance requirement 7: TS 24.008, clause 5.4.

#### 13.2.2.1.3 ————— Test purpose

- 1) To verify that the UE in the "MM idle, no IMSI" state (no USIM inserted) when made to call the emergency call number, sends a RRC CONNECTION REQUEST message with establishment cause "emergency call".
- 2) To verify that after assignment of a dedicated channel the first layer message sent by the UE on the assigned dedicated channel is a CM SERVICE REQUEST message in which the security key sequence number IE indicates "no key is available", the CM service type IE indicates "emergency number establishment", and the mobile identity IE specifies the IMEI of the UE.
- 3) To verify that after receipt of a CM SERVICE ACCEPT message from the SS, the UE sends an EMERGENCY SETUP message.
- 4) To verify that subsequently, the SS having sent a CALL PROCEEDING message and then an ALERT message and having initiated the assignment procedure of an appropriate speech traffic channel, the UE performs correctly that assignment procedure.
- 5) To verify subsequent correct performance of a connect procedure.
- 6) To verify that subsequently the UE has through connected the DTCH in both directions.
- 7) To verify that the call is cleared correctly.

#### 13.2.2.1.4 ————— Method of test

#### Related ICS Statements

- Emergency speech call

#### Initial Conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE is in MM-state "MM idle, no IMSI", no USIM inserted.

#### Test procedure

The UE is made to initiate an emergency call. The call is established without authentication, without security, with late assignment. Having reached the active state, the call is cleared by the SS.

## Expected Sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                 |
|------|-----------|----|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                          |
| 1    | UE        |    |                                 | The "called emergency call number" is entered. Establishment cause is "emergency call". SS accepts the establishment of a RRC connection                                                 |
| 2    | →         |    | RRC CONNECTION REQUEST          |                                                                                                                                                                                          |
| 3    | ←         |    | RRC CONNECTION SETUP            |                                                                                                                                                                                          |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE   | The CM service type IE indicates "emergency call establishment". The mobile identity IE specifies the IMEI of the UE. The cipher key sequence number IE indicates "no key is available". |
| 5    | →         |    | CM SERVICE REQUEST              |                                                                                                                                                                                          |
| 6    | ←         |    | CM SERVICE ACCEPT               |                                                                                                                                                                                          |
| 7    | →         |    | EMERGENCY SETUP                 | The rate of the channel is one indicated by the EMERGENCY SETUP message.                                                                                                                 |
| 8    | ←         |    | CALL PROCEEDING                 |                                                                                                                                                                                          |
| 9    | ←         |    | ALERTING                        |                                                                                                                                                                                          |
| 10   | ←         |    | RADIO BEARER SETUP              | The DTCH is through connected in both directions.                                                                                                                                        |
| 11   | →         |    | RADIO BEARER SETUP COMPLETE     |                                                                                                                                                                                          |
| 12   | ←         |    | CONNECT                         |                                                                                                                                                                                          |
| 13   | →         |    | CONNECT ACKNOWLEDGE             | The main signalling link is released                                                                                                                                                     |
| 14   | UE        |    |                                 |                                                                                                                                                                                          |
| 15   | ←         |    | DISCONNECT                      |                                                                                                                                                                                          |
| 16   | →         |    | RELEASE                         |                                                                                                                                                                                          |
| 17   | ←         |    | RELEASE COMPLETE                |                                                                                                                                                                                          |
| 18   | ←         |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                          |
| 19   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                          |

## Specific Message Contents

None.

## 13.2.2.2 Emergency call / without USIM / reject case

## 13.2.2.2.1 Definition

The following emergency numbers shall be stored in the UE for use without USIM: 000, 08, 112, 110, 118, 119, 911 and 999.

## 13.2.2.2.2 Conformance requirement

- 1) The UE in the "MM idle, no IMSI" state (no USIM inserted), after the emergency call number has been entered, shall send a RRC CONNECTION REQUEST message with correct establishment cause ("emergency call").
- 2) After assignment of a dedicated channel the first layer message sent by the UE on the assigned dedicated channel shall be a CM SERVICE REQUEST message specifying the correct IMEI and a non-available CKSN, with CM Service Type "emergency call establishment".
- 3) In the situation at the end of test purpose 2, when the UE receives a CM SERVICE REJECT message, it shall abandon the emergency call.

## Reference(s):

- For conformance requirement 1 and 2: TS 25.331 clause 8.1.3, TS 24.008 clause 5.2.1, TS 24.008 clause 4.5.1.5, TS 22.010 clause 8.
- For conformance requirement 3: TS 24.008 clause 4.5.1.5.



**13.2.2.2.3 Test purpose**

- 1) To verify that the UE in the "MM idle, no IMSI" state (no USIM inserted) when made to call the emergency call number, sends a RRC CONNECTION REQUEST message with establishment cause "emergency call".
- 2) To verify that after assignment of a dedicated channel the first layer message sent by the UE on the assigned dedicated channel is a CM SERVICE REQUEST message in which the security key sequence number IE indicates "no key is available", the CM service type IE indicates "emergency call establishment", and the mobile identity IE specifies the IMEI of the UE.
- 3) To verify that after receipt of a CM SERVICE REJECT message from the SS, the UE abandons the emergency call establishment.

**13.2.2.2.4 Method of test****Related ICS statements**

- Emergency speech call.

**Initial Conditions**

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE is in state "MM idle, no IMSI", no USIM inserted.

**Test procedure**

The UE is made to initiate an emergency call. The call is established without authentication, without security, with early assignment. The SS responds to the CM SERVICE REQUEST from the UE with a CM SERVICE REJECT message specifying in the reject cause IE the reject cause value "IMEI not accepted". The SS then verifies for during 5 seconds that the UE does not send a layer 3 message. Then the call is cleared by the SS. The SS verifies during 20 seconds after disconnection of the main signalling link that the UE does not initiate a RRC connection establishment.

**Expected Sequence**

| Step | Direction |    | Message                                             | Comments                                                                                                                                                                                                                                                                                                                                    |
|------|-----------|----|-----------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                     |                                                                                                                                                                                                                                                                                                                                             |
| 1    | UE        |    |                                                     | The "called emergency call number" is entered. Establishment cause is "emergency call". SS accepts the establishment of a RRC connection                                                                                                                                                                                                    |
| 2    | -->       |    | RRC CONNECTION REQUEST                              |                                                                                                                                                                                                                                                                                                                                             |
| 3    | <--       |    | RRC CONNECTION SETUP                                |                                                                                                                                                                                                                                                                                                                                             |
| 4    | -->       |    | RRC CONNECTION SETUP COMPLETE<br>CM SERVICE REQUEST | The CM service type IE indicates "emergency call establishment". The mobile identity IE specifies the IMEI of the UE. The cipher key sequence number IE indicates "no key is available". the reject cause IE specifies reject cause value #5, "IMEI not accepted". During 5 seconds, the SS verifies that the UE does not send L3 messages. |
| 6    | <--       |    | CM SERVICE REJECT                                   |                                                                                                                                                                                                                                                                                                                                             |
| 7    |           | SS |                                                     |                                                                                                                                                                                                                                                                                                                                             |
| 8    | <--       |    | RRC CONNECTION RELEASE                              | The main signalling link is released. During 20 seconds, the SS verifies that the UE does not initiate a RRC connection establishment                                                                                                                                                                                                       |
| 9    | -->       |    | RRC CONNECTION RELEASE COMPLETE                     |                                                                                                                                                                                                                                                                                                                                             |
| 10   |           | SS |                                                     |                                                                                                                                                                                                                                                                                                                                             |

**Specific Message Contents:**

None.

## ~~14 Interoperability Radio Bearer Tests~~

### ~~14.1 General information for interoperability radio bearer tests~~

The purpose of the interoperability radio bearer test cases are to ensure interoperability of UE's in different regions and networks. For this purpose representative radio bearer configurations that will be used in real network implementations have been defined in TS 34.108 [9], clause 6.10.

The applicability of radio bearer tests is dependent on the UE uplink and downlink radio access capabilities and UE support tele- and bearer-services. See TS 34.123-2, annex B for applicability of the specific test cases.

#### ~~14.1.1 Generic radio bearer test procedure~~

##### ~~Initial conditions~~

~~UE in idle mode~~

##### ~~Test procedure~~

- ~~a) The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.10 for the actual radio bearer test.~~
- ~~b) The SS limits the UE allowed uplink transport format combinations according to the "Restricted UL TFCIs", as specified for the sub-test of the actual radio bearer test, using the RRC transport format combination control procedure. See note 1.~~
- ~~c) The SS closes the test loop using UE test loop mode 1 and setting the UL RLC SDU size parameter, for all radio bearers under test, according to the "UL RLC SDU size" value as specified for the sub-test of the actual radio bearer test.~~
- ~~d) The SS transmits, for all radio bearers under test, one or more RLC SDUs having the size equal to the "Test data size" as specified for the sub-test of the actual radio bearer test. See note 2.~~
- ~~e) The SS checks that, for all radio bearers under test, the content of the received RLC SDU has the correct content and is received having the correct transport format. See TS 34.109 [10] clause 5.3.2.6.2 for details regarding the UE loopback of RLC SDUs.~~
- ~~f) The SS opens the UE test loop.~~
- ~~g) Steps b) to f) are repeated for all sub-tests~~
- ~~h) The SS may optionally release the radio bearer.~~
- ~~i) The SS may optionally deactivate the radio bearer test mode.~~

~~NOTE 1: The restricted set of TFCIs shall contain all possible TFCI that could happen in a sub-test. The actual TTI of the different radio bearers and signaling radio bearers as well as the possible UE processing delays shall be taken into consideration.~~

~~NOTE 2: For the case when the reference radio bearer configuration under test uses RLC transparent mode in downlink and is not configured for segmented operation then the radio bearer test case shall use a DL RLC SDU size (defined by the "Test data size" parameter) equal to the DL RLC PDU size. See [7] TS 25.322 for details regarding UE operation in RLC transparent mode.~~

## Expected sequence

## CS paging procedure

| Step | Direction |    | Message                              | Comments                 |
|------|-----------|----|--------------------------------------|--------------------------|
|      | UE        | SS |                                      |                          |
| 1    | <--       |    | SYSTEM INFORMATION (BCCH)            | Broadcast                |
| 2    | <--       |    | PAGING TYPE 1 (PCCH)                 | Paging (CS domain, TMSI) |
| 3    | -->       |    | RRC CONNECTION REQUEST (CCCH)        | RRC                      |
| 4    | <--       |    | RRC CONNECTION SETUP (CCCH)          | RRC                      |
| 5    | -->       |    | RRC CONNECTION SETUP COMPLETE (DCCH) | RRC                      |
| 6    | -->       |    | PAGING RESPONSE (DCCH)               | RR                       |

## PS paging procedure

| Step | Direction |    | Message                              | Comments                   |
|------|-----------|----|--------------------------------------|----------------------------|
|      | UE        | SS |                                      |                            |
| 1    | <--       |    | SYSTEM INFORMATION (BCCH)            | Broadcast                  |
| 2    | <--       |    | PAGING TYPE 1 (PCCH)                 | Paging (PS domain, P-TMSI) |
| 3    | -->       |    | RRC CONNECTION REQUEST (CCCH)        | RRC                        |
| 4    | <--       |    | RRC CONNECTION SETUP (CCCH)          | RRC                        |
| 5    | -->       |    | RRC CONNECTION SETUP COMPLETE (DCCH) | RRC                        |
| 6a   | -->       |    | SERVICE REQUEST (DCCH)               | GMM                        |
| 6b   | <--       |    | SECURITY MODE COMMAND                | RRC see note 1             |
| 6c   | -->       |    | SECURITY MODE COMPLETE               | RRC see note 1             |

Note 1 — Step 6b and Step 6c are inserted in order to stop T3317 timer in the UE, which starts after transmitting SERVICE REQUEST message.

| Step | Direction  |    | Message                                   | Comments                                                                                                                                                                                            |
|------|------------|----|-------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE         | SS |                                           |                                                                                                                                                                                                     |
| 1..6 | <--<br>--> |    | Paging                                    | Use the CS paging procedure for testing of CS and combined CS/PS reference radio bearer configurations.<br><br>Use the PS paging procedure for testing of PS reference radio bearer configurations. |
| 7    | <--        |    | ACTIVATE RB TEST MODE (DCCH)              | TC                                                                                                                                                                                                  |
| 8    | -->        |    | ACTIVATE RB TEST MODE COMPLETE (DCCH)     | TC                                                                                                                                                                                                  |
| 9    | <--        |    | RADIO BEARER SETUP (DCCH)                 | RRC                                                                                                                                                                                                 |
| 10   | -->        |    | RADIO BEARER SETUP COMPLETE (DCCH)        | RRC                                                                                                                                                                                                 |
| 11   | <--        |    | TRANSPORT FORMAT COMBINATION CONTROL      | RRC<br>Transport format combinations is limited to "Restricted UL TFCIs", as specified for the sub-test                                                                                             |
| 12   | <--        |    | CLOSE UE TEST LOOP                        | TC<br>UE test mode 1<br>RLC SDU size is for every active radio bearer set to "UL RLC SDU size", as specified for the sub-test.                                                                      |
| 13   | -->        |    | CLOSE UE TEST LOOP COMPLETE (DCCH)        | TC                                                                                                                                                                                                  |
| 14   | <--        |    | DOWNLINK RLC SDU                          | Send test data using the downlink transport format combination under test                                                                                                                           |
| 15   | -->        |    | UPLINK RLC SDU                            |                                                                                                                                                                                                     |
| 16   | <--        |    | OPEN UE TEST LOOP                         | TC                                                                                                                                                                                                  |
| 17   | -->        |    | OPEN UE TEST LOOP COMPLETE                | TC                                                                                                                                                                                                  |
| 18   |            |    | Repeat steps 11 to 17 for every sub-test. |                                                                                                                                                                                                     |
| 19   |            |    | RB RELEASE                                | RRC<br>Optional step                                                                                                                                                                                |
| 20   | <--        |    | DEACTIVATE RB TEST MODE                   | TC<br>Optional step                                                                                                                                                                                 |
| 21   | -->        |    | DEACTIVATE RB TEST MODE COMPLETE          | TC<br>Optional step                                                                                                                                                                                 |

## 14.2 Combinations on DPCH

### 14.2.1 Stand-alone UL:1.7 DL:1.7 kbps SRBs for DCCH

Test to verify establishment and signalling of stand-alone signalling reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.1.

The test case is performed by running test case 9.4.1 (Location updating / accepted) using the stand-alone signalling reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.3.1.

### 14.2.2 Stand-alone UL:3.4 DL:3.4 kbps SRBs for DCCH

Test to verify establishment and signalling of stand-alone signalling reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.2.

The test case is performed by running test case 9.4.1 (Location updating / accepted) using the stand-alone signalling reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.3.2.

### 14.2.3 Stand-alone UL:13.6 DL:13.6 kbps SRBs for DCCH

Test to verify establishment and signalling of stand-alone signalling reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.3.

The test case is performed by running test case 9.4.1 (Location updating / accepted) using the stand-alone signalling reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.3.3.

## ~~14.2.4 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

### ~~14.2.4.1 Conformance requirement~~

The UE shall be able to establish the UTRAN requested radio bearers within the UE's signaled radio access capabilities.

The UE shall correctly transfer user data from peer to peer RLC entities according to the requested radio bearer configuration.

#### Reference(s)

3GPP TS 25.331, clause 8.2.1

3GPP TS 25.2xx series (Physical Layer)

3GPP TS 25.321 (MAC)

3GPP TS 25.322 (RLC)

### ~~14.2.4.2 Test purpose~~

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.4.

### ~~14.2.4.3 Method of test~~

#### Uplink TFS:

|     | TFI       | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | RB7<br>(RAB subflow #3) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | N/A   |

#### Uplink TFCS:

| TFCI    | (RB5, RB6, RB7, DCCH) |
|---------|-----------------------|
| UL_TFC0 | (TF0, TF0, TF0, TF0)  |
| UL_TFC1 | (TF1, TF0, TF0, TF0)  |
| UL_TFC2 | (TF2, TF1, TF1, TF0)  |
| UL_TFC3 | (TF0, TF0, TF0, TF1)  |
| UL_TFC4 | (TF1, TF0, TF0, TF1)  |
| UL_TFC5 | (TF2, TF1, TF1, TF1)  |

#### Downlink TFS:

|     |           | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | RB7<br>(RAB subflow #3) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x103                   | 0x60                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | N/A   |

#### Downlink TFCS:

| TFCI    | (RB5, RB6, RB7, DCCH) |
|---------|-----------------------|
| DL_TFC0 | (TF0, TF0, TF0, TF0)  |
| DL_TFC1 | (TF1, TF0, TF0, TF0)  |
| DL_TFC2 | (TF2, TF1, TF1, TF0)  |
| DL_TFC3 | (TF0, TF0, TF0, TF1)  |
| DL_TFC4 | (TF1, TF0, TF0, TF1)  |
| DL_TFC5 | (TF2, TF1, TF1, TF1)  |

Sub-tests:

| Sub-test                                                                              | Downlink TFCs under test | Uplink TFCs Under test | Implicitely tested                 | Restricted UL-TFCIs                | UL-RLC SDU size<br>(note)                     | Test data size<br>(note)                      |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|------------------------------------|------------------------------------|-----------------------------------------------|-----------------------------------------------|
| 1                                                                                     | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4 | RB5: 39-bits<br>RB6: 103-bits<br>RB7: 60-bits | RB5: 39-bits<br>RB6: No-data<br>RB7: No-data  |
| 2                                                                                     | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5 | RB5: 81-bits<br>RB6: 103-bits<br>RB7: 60-bits | RB5: 81-bits<br>RB6: 103-bits<br>RB7: 60-bits |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                    |                                    |                                               |                                               |

See 14.1.1 for test procedure.

#### 14.2.4.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

— for sub-test 1: RB5/TF1 (1x39);

— for sub-test 2: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).

3. At step 15 the UE shall return

— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6 or RB7.

— for sub-test 2: an RLC SDU on each of RB5, RB6 and RB7 having the same content as sent by SS

#### ~~14.2.4a Conversational / speech / UL:(12.2 7.95 5.9 4.75) DL:(12.2 7.95 5.9 4.75) kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.4a.

#### ~~14.2.5 Conversational / speech / UL:10.2 DL:10.2 kbps / CS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH~~

##### ~~14.2.5.1 Conformance requirement~~

See clause 14.2.4.1.

### 14.2.5.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.5.

### 14.2.5.3 Method of test

Uplink TFS:

|     | TFI       | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 0x65(alt. 1x0)          | 0x99                    | 0x40                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x99                    | 1x40                    | 1x148 |
|     | TF2, bits | 1x65                    | N/A                     | N/A                     | N/A   |

Uplink TFCS:

| TFCI    | (RB5, RB6, RB7, DCCH) |
|---------|-----------------------|
| UL_TFC0 | (TF0, TF0, TF0, TF0)  |
| UL_TFC1 | (TF1, TF0, TF0, TF0)  |
| UL_TFC2 | (TF2, TF1, TF1, TF0)  |
| UL_TFC3 | (TF0, TF0, TF0, TF1)  |
| UL_TFC4 | (TF1, TF0, TF0, TF1)  |
| UL_TFC5 | (TF2, TF1, TF1, TF1)  |

Downlink TFS:

|     |           | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x99                    | 0x40                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x99                    | 1x40                    | 1x148 |
|     | TF2, bits | 1x65                    | N/A                     | N/A                     | N/A   |

Downlink TFCS:

| TFCI    | (RB5, RB6, RB7, DCCH) |
|---------|-----------------------|
| DL_TFC0 | (TF0, TF0, TF0, TF0)  |
| DL_TFC1 | (TF1, TF0, TF0, TF0)  |
| DL_TFC2 | (TF2, TF1, TF1, TF0)  |
| DL_TFC3 | (TF0, TF0, TF0, TF1)  |
| DL_TFC4 | (TF1, TF0, TF0, TF1)  |
| DL_TFC5 | (TF2, TF1, TF1, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCS under test | Uplink TFCS Under test | Implicitely tested                 | Restricted UL-TFCIs                | UL RLC-SDU size<br>(note)                    | Test data size<br>(note)                     |
|----------|--------------------------|------------------------|------------------------------------|------------------------------------|----------------------------------------------|----------------------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4 | RB5: 39-bits<br>RB6: 99-bits<br>RB7: 40-bits | RB5: 39-bits<br>RB6: No data<br>RB7: No data |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5 | RB5: 65-bits<br>RB6: 99-bits<br>RB7: 40-bits | RB5: 65-bits<br>RB6: 99-bits<br>RB7: 40-bits |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC-SDUs.

See clause 14.1.1 for test procedure.

~~14.2.5.4 Test requirements~~

See 14.1.1 for definition of step 10 and step 15.

~~1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.~~

~~2. At step 15 the UE transmitted transport format shall be~~

~~— for sub-test 1: RB5/TF1 (1x39);~~

~~— for sub-test 2: RB5/TF2 (1x65); RB6/TF1 (1x99); and RB7/TF1 (1x40);~~

~~3. At step 15 the UE shall return~~

~~— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6 or RB7;~~

~~— for sub-test 2: an RLC SDU on each of RB5, RB6 and RB7 having the same content as sent by SS.~~

~~14.2.5a Conversational / speech / UL:(10.2, 6.7, 5.9, 4.75) DL:(10.2, 6.7, 5.9, 4.75) kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.5a.

~~14.2.6 Conversational / speech / UL:7.95 DL:7.95 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

~~14.2.6.1 Conformance requirement~~

See clause 14.2.4.1.

~~14.2.6.2 Test purpose~~

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.6.

~~14.2.6.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 0x75 (alt. 1x0)         | 0x84                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x84                    | 1x148 |
|     | TF2, bits | 1x75                    | N/A                     | N/A   |

Uplink TFCS:

| TFCI    | (RB5, RB6, DCCH) |
|---------|------------------|
| UL_TFC0 | (TF0, TF0, TF0)  |
| UL_TFC1 | (TF1, TF0, TF0)  |
| UL_TFC2 | (TF2, TF1, TF0)  |
| UL_TFC3 | (TF0, TF0, TF1)  |
| UL_TFC4 | (TF1, TF0, TF1)  |
| UL_TFC5 | (TF2, TF1, TF1)  |

Downlink TFS:



|     |           | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x84                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x84                    | 1x148 |
|     | TF2, bits | 1x75                    | N/A                     | N/A   |

Downlink-TFCS:

| TFCI    | (RB5, RB6, DCCH) |
|---------|------------------|
| DL_TFC0 | (TF0, TF0, TF0)  |
| DL_TFC1 | (TF1, TF0, TF0)  |
| DL_TFC2 | (TF2, TF1, TF0)  |
| DL_TFC3 | (TF0, TF0, TF1)  |
| DL_TFC4 | (TF1, TF0, TF1)  |
| DL_TFC5 | (TF2, TF1, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCS under test | Uplink TFCS Under test | Implicitely tested                 | Restricted UL-TFCIs                 | UL RLC SDU size<br>(note)    | Test data size<br>(note)     |
|----------|--------------------------|------------------------|------------------------------------|-------------------------------------|------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4  | RB5: 39-bits<br>RB6: 84-bits | RB5: 39-bits<br>RB6: No-data |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5, | RB5: 75-bits<br>RB6: 84-bits | RB5: 75-bits<br>RB6: 84-bits |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See clause 14.1.1 for test procedure.

#### 14.2.6.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO-BEARER-SETUP-COMPLETE.

2. At step 15 the UE transmitted transport format shall be

— for sub-test 1: RB5/TF1 (1x39);

— for sub-test 2: RB5/TF2 (1x75) and RB6/TF1 (1x84);

3. At step 15 the UE shall return

— for sub-test 1: an RLC-SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6;

— for sub-test 2: an RLC-SDU on each of RB5 and RB6 having the same content as sent by SS.

#### 14.2.7 Conversational / speech / UL:7.4 DL:7.4 kbps / CS-RAB+ UL:3.4 DL:3.4 kbps-SRBs for DCCH

##### 14.2.7.1 Conformance requirement

See clause 14.2.4.1.

### 14.2.7.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.7.

### 14.2.7.3 Method of test

Uplink TFS:

|     | TFI       | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 0x61 (alt. 1x0)         | 0x87                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x87                    | 1x148 |
|     | TF2, bits | 1x61                    | N/A                     | N/A   |

Uplink TFCS:

| TFCI    | (RB5, RB6, DCCH) |
|---------|------------------|
| UL_TFC0 | (TF0, TF0, TF0)  |
| UL_TFC1 | (TF1, TF0, TF0)  |
| UL_TFC2 | (TF2, TF1, TF0)  |
| UL_TFC3 | (TF0, TF0, TF1)  |
| UL_TFC4 | (TF1, TF0, TF1)  |
| UL_TFC5 | (TF2, TF1, TF1)  |

Downlink TFS:

|     |           | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x87                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x87                    | 1x148 |
|     | TF2, bits | 1x61                    | N/A                     | N/A   |

Downlink TFCS:

| TFCI    | (RB5, RB6, DCCH) |
|---------|------------------|
| DL_TFC0 | (TF0, TF0, TF0)  |
| DL_TFC1 | (TF1, TF0, TF0)  |
| DL_TFC2 | (TF2, TF1, TF0)  |
| DL_TFC3 | (TF0, TF0, TF1)  |
| DL_TFC4 | (TF1, TF0, TF1)  |
| DL_TFC5 | (TF2, TF1, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCS under test | Uplink TFCS Under test | Implicitely tested                 | Restricted UL-TFCIs                 | UL RLC-SDU size<br>(note)    | Test data size<br>(note)     |
|----------|--------------------------|------------------------|------------------------------------|-------------------------------------|------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4  | RB5: 39 bits<br>RB6: 87 bits | RB5: 39 bits<br>RB6: No data |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5, | RB5: 61 bits<br>RB6: 87 bits | RB5: 61 bits<br>RB6: 87 bits |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC-SDUs.

See clause 14.1.1 for test procedure.

~~14.2.7.4 Test requirements~~

See 14.1.1 for definition of step 10 and step 15.

~~1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.~~

~~2. At step 15 the UE transmitted transport format shall be~~

~~— for sub-test 1: RB5/TF1 (1x39).~~

~~— for sub-test 2: RB5/TF2 (1x61) and RB6/TF1 (1x87).~~

~~3. At step 15 the UE shall return~~

~~— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6.~~

~~— for sub-test 2: an RLC SDU on each of RB5 and RB6 having the same content as sent by SS~~

~~14.2.7a Conversational / speech / UL:(7.4, 6.7, 5.9, 4.75) DL:(7.4, 6.7, 5.9, 4.75) kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.7a.

~~14.2.8 Conversational / speech / UL:6.7 DL:6.7 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

~~14.2.8.1 Conformance requirement~~

See clause 14.2.4.1.

~~14.2.8.2 Test purpose~~

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.8.

~~14.2.8.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 0x58 (alt. 1x0)         | 0x76                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x76                    | 1x148 |
|     | TF2, bits | 1x58                    | N/A                     | N/A   |

Uplink TFCS:

| TFCI    | (RB5, RB6, DCCH) |
|---------|------------------|
| UL_TFC0 | (TF0, TF0, TF0)  |
| UL_TFC1 | (TF1, TF0, TF0)  |
| UL_TFC2 | (TF2, TF1, TF0)  |
| UL_TFC3 | (TF0, TF0, TF1)  |
| UL_TFC4 | (TF1, TF0, TF1)  |
| UL_TFC5 | (TF2, TF1, TF1)  |

Downlink TFS:

|     |           | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x76                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x76                    | 1x148 |
|     | TF2, bits | 1x58                    | N/A                     | N/A   |

Downlink-TFCS:

| TFCI    | (RB5, RB6, DCCH) |
|---------|------------------|
| DL_TFC0 | (TF0, TF0, TF0)  |
| DL_TFC1 | (TF1, TF0, TF0)  |
| DL_TFC2 | (TF2, TF1, TF0)  |
| DL_TFC3 | (TF0, TF0, TF1)  |
| DL_TFC4 | (TF1, TF0, TF1)  |
| DL_TFC5 | (TF2, TF1, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCS under test | Uplink TFCS Under test | Implicitely tested                 | Restricted UL-TFCIs                 | UL RLC SDU size<br>(note)    | Test data size<br>(note)     |
|----------|--------------------------|------------------------|------------------------------------|-------------------------------------|------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4  | RB5: 39-bits<br>RB6: 76-bits | RB5: 39-bits<br>RB6: No-data |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5, | RB5: 58-bits<br>RB6: 76-bits | RB5: 58-bits<br>RB6: 76-bits |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See clause 14.1.1 for test procedure.

#### 14.2.8.4 Test requirements

See clause 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO-BEARER-SETUP-COMPLETE.

2. At step 15 the UE transmitted transport format shall be

— for sub-test 1: RB5/TF1 (1x39);

— for sub-test 2: RB5/TF2 (1x58) and RB6/TF1 (1x76);

3. At step 15 the UE shall return

— for sub-test 1: an RLC-SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6;

— for sub-test 2: an RLC-SDU on each of RB5 and RB6 having the same content as sent by SS

#### 14.2.9 Conversational / speech / UL:5.9 DL:5.9 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

##### 14.2.9.1 Conformance requirement

See clause 14.2.4.1.

### 14.2.9.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.9.

### 14.2.9.3 Method of test

Uplink TFS:

|     | TFI       | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 0x55 (alt. 1x0)         | 0x63                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x63                    | 1x148 |
|     | TF2, bits | 1x55                    | N/A                     | N/A   |

Uplink TFCS:

| TFCI    | (RB5, RB6, DCCH) |
|---------|------------------|
| UL_TFC0 | (TF0, TF0, TF0)  |
| UL_TFC1 | (TF1, TF0, TF0)  |
| UL_TFC2 | (TF2, TF1, TF0)  |
| UL_TFC3 | (TF0, TF0, TF1)  |
| UL_TFC4 | (TF1, TF0, TF1)  |
| UL_TFC5 | (TF2, TF1, TF1)  |

Downlink TFS:

|     |           | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x63                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x63                    | 1x148 |
|     | TF2, bits | 1x55                    | N/A                     | N/A   |

Downlink TFCS:

| TFCI    | (RB5, RB6, DCCH) |
|---------|------------------|
| DL_TFC0 | (TF0, TF0, TF0)  |
| DL_TFC1 | (TF1, TF0, TF0)  |
| DL_TFC2 | (TF2, TF1, TF0)  |
| DL_TFC3 | (TF0, TF0, TF1)  |
| DL_TFC4 | (TF1, TF0, TF1)  |
| DL_TFC5 | (TF2, TF1, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCS under test | Uplink TFCS Under test | Implicitely tested                 | Restricted UL-TFCIs                | UL RLC-SDU size<br>(note)    | Test data size<br>(note)     |
|----------|--------------------------|------------------------|------------------------------------|------------------------------------|------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4 | RB5: 39 bits<br>RB6: 63 bits | RB5: 39 bits<br>RB6: No data |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5 | RB5: 55 bits<br>RB6: 63 bits | RB5: 55 bits<br>RB6: 63 bits |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC-SDUs.

See clause 14.1.1 for test procedure.

**14.2.9.4 Test requirements**

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x39).
  - for sub-test 2: RB5/TF2 (1x55) and RB6/TF1 (1x63).
3. At step 15 the UE shall return
  - for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6.
  - for sub-test 2: an RLC SDU on each of RB5 and RB6 having the same content as sent by SS

**14.2.10 Conversational / speech / UL:5.15 DL:5.15 kbps / CS RAB + UL:1.7 DL:1.7 kbps SRBs for DCCH****14.2.10.1 Conformance requirement**

See clause 14.2.4.1.

**14.2.10.2 Test purpose**

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.10.

**14.2.10.3 Method of test**

Uplink-TFS:

|     | <b>TFI</b> | <b>RB5<br/>(RAB subflow #1)</b> | <b>RB6<br/>(RAB subflow #2)</b> | <b>DCCH</b> |
|-----|------------|---------------------------------|---------------------------------|-------------|
| TFS | TF0, bits  | 0x49 (alt. 1x0)                 | 0x54                            | 0x148       |
|     | TF1, bits  | 1x39                            | 1x54                            | 1x148       |
|     | TF2, bits  | 1x49                            | N/A                             | N/A         |

Uplink-TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| UL_TFC0     | (TF0, TF0, TF0)         |
| UL_TFC1     | (TF1, TF0, TF0)         |
| UL_TFC2     | (TF2, TF1, TF0)         |
| UL_TFC3     | (TF0, TF0, TF1)         |
| UL_TFC4     | (TF1, TF0, TF1)         |
| UL_TFC5     | (TF2, TF1, TF1)         |

Downlink-TFS:

|     |           | <b>RB5<br/>(RAB subflow #1)</b> | <b>RB6<br/>(RAB subflow #2)</b> | <b>DCCH</b> |
|-----|-----------|---------------------------------|---------------------------------|-------------|
| TFS | TF0, bits | 1x0                             | 0x54                            | 0x148       |
|     | TF1, bits | 1x39                            | 1x54                            | 1x148       |
|     | TF2, bits | 1x49                            | N/A                             | N/A         |

Downlink-TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| DL_TFC0     | (TF0, TF0, TF0)         |
| DL_TFC1     | (TF1, TF0, TF0)         |
| DL_TFC2     | (TF2, TF1, TF0)         |
| DL_TFC3     | (TF0, TF0, TF1)         |
| DL_TFC4     | (TF1, TF0, TF1)         |
| DL_TFC5     | (TF2, TF1, TF1)         |

Sub-tests:

| <b>Sub-test</b>                                                                       | <b>Downlink TFCs under test</b> | <b>Uplink TFCs Under test</b> | <b>Implicitely tested</b>          | <b>Restricted UL-TFCIs</b>          | <b>UL-RLC SDU size</b><br>(note) | <b>Test data size</b><br>(note) |
|---------------------------------------------------------------------------------------|---------------------------------|-------------------------------|------------------------------------|-------------------------------------|----------------------------------|---------------------------------|
| 1                                                                                     | DL_TFC1                         | UL_TFC1                       | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4  | RB5: 39-bits<br>RB6: 54-bits     | RB5: 39-bits<br>RB6: No-data    |
| 2                                                                                     | DL_TFC2                         | UL_TFC2                       | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5, | RB5: 49-bits<br>RB6: 54-bits     | RB5: 49-bits<br>RB6: 54-bits    |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                                 |                               |                                    |                                     |                                  |                                 |

See clause 14.1.1 for test procedure.

#### 14.2.10.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x39).
  - for sub-test 2: RB5/TF2 (1x49) and RB6/TF1 (1x54).
3. At step 15 the UE shall return
  - for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6.
  - for sub-test 2: an RLC SDU on each of RB5 and RB6 having the same content as sent by SS

#### 14.2.11 Conversational / speech / UL:4.75 DL:4.75 kbps / CS RAB + UL:1.7 DL:1.7 kbps SRBs for DCCH

##### 14.2.11.1 Conformance requirement

See clause 14.2.4.1.

##### 14.2.11.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.11.

##### 14.2.11.3 Method of test

Uplink TFS:

|     | TFI       | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 0x49 (alt. 1x0)         | 0x53                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x53                    | 1x148 |
|     | TF2, bits | 1x42                    | N/A                     | N/A   |

Uplink-TFCS:

| TFCI    | (RB5, RB6, DCCH) |
|---------|------------------|
| UL_TFC0 | (TF0, TF0, TF0)  |
| UL_TFC1 | (TF1, TF0, TF0)  |
| UL_TFC2 | (TF2, TF1, TF0)  |
| UL_TFC3 | (TF0, TF0, TF1)  |
| UL_TFC4 | (TF1, TF0, TF1)  |
| UL_TFC5 | (TF2, TF1, TF1)  |

Downlink-TFS:

|     |           | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x53                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x53                    | 1x148 |
|     | TF2, bits | 1x42                    | N/A                     | N/A   |

Downlink-TFCS:

| TFCI    | (RB5, RB6, DCCH) |
|---------|------------------|
| DL_TFC0 | (TF0, TF0, TF0)  |
| DL_TFC1 | (TF1, TF0, TF0)  |
| DL_TFC2 | (TF2, TF1, TF0)  |
| DL_TFC3 | (TF0, TF0, TF1)  |
| DL_TFC4 | (TF1, TF0, TF1)  |
| DL_TFC5 | (TF2, TF1, TF1)  |

Sub-tests:

| Sub-test                                                                              | Downlink TFCS under test | Uplink TFCS Under test | Implicitely tested                 | Restricted UL-TFCIs                 | UL-RLC SDU size<br>(note)    | Test data size<br>(note)     |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|------------------------------------|-------------------------------------|------------------------------|------------------------------|
| 1                                                                                     | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4  | RB5: 39-bits<br>RB6: 53-bits | RB5: 39-bits<br>RB6: No-data |
| 2                                                                                     | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5, | RB5: 42-bits<br>RB6: 53-bits | RB5: 42-bits<br>RB6: 53-bits |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                    |                                     |                              |                              |

See clause 14.1.1 for test procedure.

#### 14.2.11.4 Test requirements

See clause 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

— for sub-test 1: RB5/TF1 (1x39).



— for sub-test 2: RB5/TF2 (1x42) and RB6/TF1 (1x53).

3. At step 15 the UE shall return

— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6;

— for sub-test 2: an RLC SDU on each of RB5 and RB6 having the same content as sent by SS

## 14.2.12 Conversational / unknown / UL:28.8 DL:28.8 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

### 14.2.12.1 Conformance requirement

See 14.2.4.1.

### 14.2.12.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.12.

### 14.2.12.3 Method of test

#### Initial Conditions

The following RLC Info parameter values shall be set by the SS:

|                           |      |
|---------------------------|------|
| Uplink RLC                |      |
| — TM-RLC                  |      |
| — Segmentation indication | TRUE |
| Downlink RLC              |      |
| — TM-RLC                  |      |
| — Segmentation indication | TRUE |

#### Uplink TFS:

|     | TFI       | RB5<br>(28.8 kbps) | DCCH  |
|-----|-----------|--------------------|-------|
| TFS | TF0, bits | 0x576              | 0x148 |
|     | TF1, bits | 1x576              | 1x148 |
|     | TF2, bits | 2x576              | N/A   |

#### Uplink TFCs:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF0, TF1)  |
| UL_TFC4 | (TF1, TF1)  |
| UL_TFC5 | (TF2, TF1)  |

#### Downlink TFS:

|     |           | RB5<br>(28.8 kbps) | DCCH  |
|-----|-----------|--------------------|-------|
| TFS | TF0, bits | 0x576              | 0x148 |
|     | TF1, bits | 1x576              | 1x148 |
|     | TF2, bits | 2x576              | N/A   |

Downlink TFCS:

| TFCS    | (RB5, DCCH) |
|---------|-------------|
| DL_TFC0 | (TF0, TF0)  |
| DL_TFC1 | (TF1, TF0)  |
| DL_TFC2 | (TF2, TF0)  |
| DL_TFC3 | (TF0, TF1)  |
| DL_TFC4 | (TF1, TF1)  |
| DL_TFC5 | (TF2, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCS under test | Uplink TFCS Under test | Implicitely-tested                 | Restricted UL TFCS                 | UL RLC SDU size (bits) (note) | Test data size (bits) (note) |
|----------|--------------------------|------------------------|------------------------------------|------------------------------------|-------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4 | RB5: 576                      | RB5: 576                     |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5 | RB5: 1152                     | RB5: 1152                    |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See clause 14.1.1 for test procedure.

#### 14.2.12.4 Test requirements

See clause 14.1.1 for definition of step 10 and step 15.

- At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x576).
  - for sub-test 2: RB5/TF2 (2x576).
- At step 15 the UE shall return
  - for sub-test 1 and 2: an RLC SDU on RB5 having the same content as sent by SS.

### ~~14.2.13 Conversational / unknown / UL:64 kbps / CS RAB + UL:3.4 kbps SRBs for DCCH~~

#### ~~14.2.13.1 Conversational / unknown / UL:64 kbps / CS RAB / 20 ms TTI~~

##### ~~14.2.13.1.1 Conformance requirement~~

See clause 14.2.4.1.

##### ~~14.2.13.1.2 Test purpose~~

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.13 for the 20 ms TTI case.

## 14.2.13.1.3 Method of test

## Initial Conditions

The following RLC Info parameter values shall be set by the SS:

|                                                       |      |
|-------------------------------------------------------|------|
| Uplink RLC<br>— TM-RLC<br>— Segmentation indication   | TRUE |
| Downlink RLC<br>— TM-RLC<br>— Segmentation indication | TRUE |

## Uplink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x640            | 0x148 |
|     | TF1, bits | 2x640            | 1x148 |

## Uplink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF0, TF1)  |
| UL_TFC3 | (TF1, TF1)  |

## Downlink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x640            | 0x148 |
|     | TF1, bits | 2x640            | 1x148 |

## Downlink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| DL_TFC0 | (TF0, TF0)  |
| DL_TFC1 | (TF1, TF0)  |
| DL_TFC2 | (TF0, TF1)  |
| DL_TFC3 | (TF1, TF1)  |

## Sub-tests:

| Sub-test | Downlink TFCS Under test | Uplink TFCS Under test | Implicitely-tested                 | Restricted UL-TFCIs                | UL-RLC-SDU size (bits) (note) | Test data size (bits) (note) |
|----------|--------------------------|------------------------|------------------------------------|------------------------------------|-------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 1280                     | RB5: 1280                    |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See clause 14.1.1 for test procedure.

## 14.2.13.1.4 Test requirements

See clause 14.1.1 for definition of step 10 and step 15.

1. ~~At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.~~
2. ~~At step 15 the UE transmitted transport format shall be~~
  - ~~— for sub-test 1: RB5/TF1 (2x640).~~
3. ~~At step 15 the UE shall return~~
  - ~~— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS.~~

#### ~~14.2.13.2 Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 40 ms TTI~~

##### ~~14.2.13.2.1 Conformance requirement~~

See clause 14.2.4.1.

##### ~~14.2.13.2.2 Test purpose~~

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.13 for the 40 ms TTI case.

##### ~~14.2.13.2.3 Method of test~~

#### Initial Conditions

The following RLC Info parameter values shall be set by the SS:

|                                                       |      |
|-------------------------------------------------------|------|
| Uplink RLC<br>— TM RLC<br>— Segmentation indication   | TRUE |
| Downlink RLC<br>— TM RLC<br>— Segmentation indication | TRUE |

#### Uplink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x640            | 0x148 |
|     | TF1, bits | 4x640            | 1x148 |

#### Uplink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF0, TF1)  |
| UL_TFC3 | (TF1, TF1)  |

#### Downlink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x640            | 0x148 |
|     | TF1, bits | 4x640            | 1x148 |

#### Downlink TFCS:

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| DL_TFC0     | (TF0, TF0)         |
| DL_TFC1     | (TF1, TF0)         |
| DL_TFC2     | (TF0, TF1)         |
| DL_TFC3     | (TF1, TF1)         |

Sub-tests:

| <b>Sub-test</b> | <b>Downlink TFCS Under test</b> | <b>Uplink TFCS Under test</b> | <b>Implicitely tested</b>          | <b>Restricted UL-TFCIs</b>         | <b>UL-RLC-SDU size (bits) (note)</b> | <b>Test data size (bits) (note)</b> |
|-----------------|---------------------------------|-------------------------------|------------------------------------|------------------------------------|--------------------------------------|-------------------------------------|
| 1               | DL_TFC1                         | UL_TFC1                       | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 2560                            | RB5: 2560                           |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 14.2.13.2.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

- At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (4x640).
- At step 15 the UE shall return
  - for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS.

#### 14.2.14 Conversational / unknown / UL:32 DL:32 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

##### 14.2.14.1 Conversational / unknown / UL:32 DL:32 kbps / CS RAB / 20 ms TTI

###### 14.2.14.1.1 Conformance requirement

See 14.2.4.1.

###### 14.2.14.1.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.14 for the 20 ms TTI case.

###### 14.2.14.1.3 Method of test

Uplink-TFS:

|     | <b>TFI</b> | <b>RB5 (32 kbps)</b> | <b>DCCH</b> |
|-----|------------|----------------------|-------------|
| TFS | TF0, bits  | 0x640                | 0x148       |
|     | TF1, bits  | 1x640                | 1x148       |

Uplink-TFCS:

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| UL_TFC0     | (TF0, TF0)         |
| UL_TFC1     | (TF1, TF0)         |
| UL_TFC2     | (TF0, TF1)         |
| UL_TFC3     | (TF1, TF1)         |

Downlink TFS:

|            | <b>TFI</b> | <b>RB5<br/>(32 kbps)</b> | <b>DCCH</b> |
|------------|------------|--------------------------|-------------|
| <b>TFS</b> | TF0, bits  | 0x640                    | 0x148       |
|            | TF1, bits  | 1x640                    | 1x148       |

Downlink TFCS:

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| DL_TFC0     | (TF0, TF0)         |
| DL_TFC1     | (TF1, TF0)         |
| DL_TFC2     | (TF0, TF1)         |
| DL_TFC3     | (TF1, TF1)         |

Sub-tests:

| <b>Sub-test</b> | <b>Downlink TFCS Under test</b> | <b>Uplink TFCS Under test</b> | <b>Implicitely tested</b>          | <b>Restricted UL-TFCIs</b>         | <b>UL RLC SDU size (bits) (note)</b> | <b>Test data size (bits) (note)</b> |
|-----------------|---------------------------------|-------------------------------|------------------------------------|------------------------------------|--------------------------------------|-------------------------------------|
| 1               | DL_TFC1                         | UL_TFC1                       | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 640                             | RB5: 640                            |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 14.2.14.1.4 Test requirements

- At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x640).
- At step 15 the UE shall return
  - for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS.

#### 14.2.14.2 Conversational / unknown / UL:32 DL:32 kbps / CS RAB / 40 ms TTI

##### 14.2.14.2.1 Conformance requirement

See 14.2.4.1.

##### 14.2.14.2.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.14 for the 40 ms TTI case.

## 14.2.14.2.3 Method of test

## Initial Conditions

The following RLC Info parameter values shall be set by the SS:

|                                                       |      |
|-------------------------------------------------------|------|
| Uplink RLC<br>— TM-RLC<br>— Segmentation indication   | TRUE |
| Downlink RLC<br>— TM-RLC<br>— Segmentation indication | TRUE |

## Uplink-TFS:

|     | TFI       | RB5<br>(32 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x640            | 0x148 |
|     | TF1, bits | 2x640            | 1x148 |

## Uplink-TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF0, TF1)  |
| UL_TFC3 | (TF1, TF1)  |

## Downlink-TFS:

|     | TFI       | RB5<br>(32 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x640            | 0x148 |
|     | TF1, bits | 2x640            | 1x148 |

## Downlink-TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| DL_TFC0 | (TF0, TF0)  |
| DL_TFC1 | (TF1, TF0)  |
| DL_TFC2 | (TF0, TF1)  |
| DL_TFC3 | (TF1, TF1)  |

## Sub-tests:

| Sub-test | Downlink TFCS Under test | Uplink TFCS Under test | Implicitely-tested                 | Restricted UL-TFCIs                | UL-RLC-SDU size (bits) (note) | Test data size (bits) (note) |
|----------|--------------------------|------------------------|------------------------------------|------------------------------------|-------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 1280                     | RB5: 1280                    |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

## 14.2.14.2.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. ~~At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.~~
2. ~~At step 15 the UE transmitted transport format shall be~~
  - ~~— for sub-test 1: RB5/TF1 (2x640).~~
3. ~~At step 15 the UE shall return~~
  - ~~— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS.~~

### ~~14.2.15 Streaming / unknown / UL:14.4/DL:14.4 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

#### ~~14.2.15.1 Conformance requirement~~

~~See 14.2.4.1.~~

#### ~~14.2.15.2 Test purpose~~

~~To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.15.~~

#### ~~14.2.15.3 Method of test~~

~~Uplink TFS:~~

|            | <b>TFI</b> | <b>RB5<br/>(14.4 kbps)</b> | <b>DCCH</b> |
|------------|------------|----------------------------|-------------|
| <b>TFS</b> | TF0, bits  | 0x576                      | 0x148       |
|            | TF1, bits  | 1x576                      | 1x148       |

~~Uplink TFCS:~~

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| UL_TFC0     | (TF0, TF0)         |
| UL_TFC1     | (TF1, TF0)         |
| UL_TFC2     | (TF0, TF1)         |
| UL_TFC3     | (TF1, TF1)         |

~~Downlink TFS:~~

|            | <b>TFI</b> | <b>RB5<br/>(14.4 kbps)</b> | <b>DCCH</b> |
|------------|------------|----------------------------|-------------|
| <b>TFS</b> | TF0, bits  | 0x576                      | 0x148       |
|            | TF1, bits  | 1x576                      | 1x148       |

~~Downlink TFCS:~~

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| DL_TFC0     | (TF0, TF0)         |
| DL_TFC1     | (TF1, TF0)         |
| DL_TFC2     | (TF0, TF1)         |
| DL_TFC3     | (TF1, TF1)         |

~~Sub-tests:~~



| Sub-test                                                                                | Downlink TFCs Under test | Uplink TFCs Under test | Implicitely tested                 | Restricted UL-TFCIs                | UL-RLC SDU size (bits) (note) | Test data size (bits) (note) |
|-----------------------------------------------------------------------------------------|--------------------------|------------------------|------------------------------------|------------------------------------|-------------------------------|------------------------------|
| 1                                                                                       | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                      | RB5: 576                     |
| NOTE: — See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                    |                                    |                               |                              |

See 14.1.1 for test procedure.

#### 14.2.15.4 ————— Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. — At step 10 the UE shall send RADIO-BEARER-SETUP-COMPLETE.
2. — At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x576).
3. — At step 15 the UE shall return
  - for sub-test 1: an RLC-SDU on RB5 having the same content as sent by SS.

#### 14.2.16 — Streaming / unknown / UL:28.8/DL:28.8 kbps / CS-RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

##### 14.2.16.1 ————— Conformance requirement

See 14.2.4.1.

##### 14.2.16.2 ————— Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.16.

##### 14.2.16.3 ————— Method of test

Uplink-TFS:

|     | TFI       | RB5 (28.8 kbps) | DCCH  |
|-----|-----------|-----------------|-------|
| TFS | TF0, bits | 0x576           | 0x148 |
|     | TF1, bits | 1x576           | 1x148 |
|     | TF2, bits | 2x576           | N/A   |

Uplink-TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF0, TF1)  |
| UL_TFC4 | (TF1, TF1)  |
| UL_TFC5 | (TF2, TF1)  |

Downlink-TFS:

|     |           | RB5<br>(28.8 kbps) | DCCH  |
|-----|-----------|--------------------|-------|
| TFS | TF0, bits | 0x576              | 0x148 |
|     | TF1, bits | 1x576              | 1x148 |
|     | TF2, bits | 2x576              | N/A   |

Downlink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| DL_TFC0 | (TF0, TF0)  |
| DL_TFC1 | (TF1, TF0)  |
| DL_TFC2 | (TF2, TF0)  |
| DL_TFC3 | (TF0, TF1)  |
| DL_TFC4 | (TF1, TF1)  |
| DL_TFC5 | (TF2, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCS<br>Under test | Uplink TFCS<br>Under test | Implicitely tested                 | Restricted UL TFCIs                 | UL RLC SDU size<br>(bits)<br>(note) | Test data size<br>(bits)<br>(note) |
|----------|-----------------------------|---------------------------|------------------------------------|-------------------------------------|-------------------------------------|------------------------------------|
| 1        | DL_TFC1                     | UL_TFC1                   | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4  | RB5: 576                            | RB5: 576                           |
| 2        | DL_TFC2                     | UL_TFC2                   | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5, | RB5: 1152                           | RB5: 1152                          |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 14.2.16.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

- At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x576).
  - for sub-test 2: RB5/TF2 (2x576).
- At step 15 the UE shall return
  - for sub-test 1 and 2: an RLC SDU on RB5 having the same content as sent by SS.

#### 14.2.17 Streaming / unknown / UL:57.6/DL:57.6 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

##### 14.2.17.1 Conformance requirement

See 14.2.4.1.

##### 14.2.17.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.17.

## 14.2.17.3 Method of test

Uplink-TFS:

|     | TFI       | RB5<br>(57.6 kbps) | DCCH  |
|-----|-----------|--------------------|-------|
| TFS | TF0, bits | 0x576              | 0x148 |
|     | TF1, bits | 1x576              | 1x148 |
|     | TF2, bits | 2x576              | N/A   |
|     | TF3, bits | 3x576              | N/A   |
|     | TF4, bits | 4x576              | N/A   |

Uplink-TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |

Downlink-TFS:

|     | TFI       | RB5<br>(57.6 kbps) | DCCH  |
|-----|-----------|--------------------|-------|
| TFS | TF0, bits | 0x576              | 0x148 |
|     | TF1, bits | 1x576              | 1x148 |
|     | TF2, bits | 2x576              | N/A   |
|     | TF3, bits | 3x576              | N/A   |
|     | TF4, bits | 4x576              | N/A   |

Downlink-TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| DL_TFC0 | (TF0, TF0)  |
| DL_TFC1 | (TF1, TF0)  |
| DL_TFC2 | (TF2, TF0)  |
| DL_TFC3 | (TF3, TF0)  |
| DL_TFC4 | (TF4, TF0)  |
| DL_TFC5 | (TF0, TF1)  |
| DL_TFC6 | (TF1, TF1)  |
| DL_TFC7 | (TF2, TF1)  |
| DL_TFC8 | (TF3, TF1)  |
| DL_TFC9 | (TF4, TF1)  |

Sub-tests:

| Sub-test                                                                              | Downlink TFCs Under test | Uplink TFCs Under test | Implicitely tested                  | Restricted UL-TFCIs                | UL RLC SDU size (bits) (note) | Test data size (bits) (note) |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|-------------------------------------|------------------------------------|-------------------------------|------------------------------|
| 1                                                                                     | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5; | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 576                      | RB5: 576                     |
| 2                                                                                     | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5  | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 1152                     | RB5: 1152                    |
| 3                                                                                     | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5  | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 1728                     | RB5: 1728                    |
| 4                                                                                     | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5  | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 2304                     | RB5: 2304                    |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                     |                                    |                               |                              |

See 14.1.1 for test procedure.

#### 14.2.17.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x576).
  - for sub-test 2: RB5/TF2 (2x576).
  - for sub-test 3: RB5/TF3 (3x576).
  - for sub-test 4: RB5/TF4 (4x576).
3. At step 15 the UE shall return
  - for sub-test 1 to 4: an RLC SDU on RB5 having the same content as sent by SS.

#### 14.2.18 Streaming / unknown / UL:0 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

##### 14.2.18.1 Conformance requirement

See 14.2.4.1.

##### 14.2.18.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.18.

To be able to test the downlink radio bearer using the UE loopback function for the reference radio bearer UL:0 DL: 64 kbps, the reference radio bearer configuration according to TS 34.108, clause 6.10.2.4.1.15.1 (Streaming/unknown/UL:14.4 kbps) is used in uplink.

##### 14.2.18.3 Method of test

Uplink-TFS:

|     | TFI       | RB5<br>(14.4 kbps) | DCCH  |
|-----|-----------|--------------------|-------|
| TFS | TF0, bits | 0x576              | 0x148 |
|     | TF1, bits | 1x576              | 1x148 |

Uplink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF0, TF1)  |
| UL_TFC3 | (TF1, TF1)  |

Downlink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x320            | 0x148 |
|     | TF1, bits | 1x320            | 1x148 |
|     | TF2, bits | 2x320            | N/A   |
|     | TF3, bits | 4x320            | N/A   |
|     | TF4, bits | 8x320            | N/A   |

Downlink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| DL_TFC0 | (TF0, TF0)  |
| DL_TFC1 | (TF1, TF0)  |
| DL_TFC2 | (TF2, TF0)  |
| DL_TFC3 | (TF3, TF0)  |
| DL_TFC4 | (TF4, TF0)  |
| DL_TFC5 | (TF0, TF1)  |
| DL_TFC6 | (TF1, TF1)  |
| DL_TFC7 | (TF2, TF1)  |
| DL_TFC8 | (TF3, TF1)  |
| DL_TFC9 | (TF4, TF1)  |

Sub-tests:

| Sub-test                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Downlink TFCs Under test | Uplink TFCs Under test | Implicitly tested                  | Restricted UL TFCs                 | UL RLC SDU size (bits) (note 1) | Test data size (bits) (note 1) |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|------------------------|------------------------------------|------------------------------------|---------------------------------|--------------------------------|
| 1                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                        | RB5: 320 (note 2)              |
| 2                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | DL_TFC2                  | UL_TFC1                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                        | RB5: 640 (note 3)              |
| 3                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | DL_TFC3                  | UL_TFC1                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                        | RB5: 1280 (note 4)             |
| 4                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | DL_TFC4                  | UL_TFC1                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                        | RB5: 2560 (note 5)             |
| NOTE 1: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.<br>NOTE 2: SS is using a DL RLC SDU with 320 bits as test data (=DL RLC PDU size for DL/TF1). UE will return one RLC PDU. SS creates an UL RLC SDU from the first 320 bits of the received RLC PDU.<br>NOTE 3: SS is using a DL RLC SDU size of 640 bits as test data (=DL RLC PDU size for DL/TF2). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.<br>NOTE 4: SS is using a DL RLC SDU size of 1280 bits as test data (=DL RLC PDU size for DL/TF3). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.<br>NOTE 5: SS is using a DL RLC SDU size of 2560 bits as test data (=DL RLC PDU size for DL/TF4). UE will return one RLC PDU. SS creates an UL RLC SDU. |                          |                        |                                    |                                    |                                 |                                |

See 14.1.1 for test procedure.

#### 14.2.18.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE shall return
  - for sub-test 1: an RLC SDU on RB5 having the same content as sent by the SS.
  - for sub-test 2 to 4: an RLC SDU on RB5 having the same content as the first 576 bits of the RLC SDU sent by the SS.

### 14.2.19 Streaming / unknown / UL:64 DL:0 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

#### 14.2.19.1 Conformance requirement

See 14.2.4.1.

#### 14.2.19.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.19.

To be able to test the uplink radio bearer using the UE loopback function for the reference radio bearer UL:64 DL:0 kbps, the reference radio bearer configuration according to TS 34.108, clause 6.10.2.4.1.15.2 (Streaming/unknown/DL:14.4 kbps) is used in downlink.

## 14.2.19.3 Method of test

## Uplink-TFS:

|     | <b>TFI</b> | <b>RB5<br/>(64 kbps)</b> | <b>DCCH</b> |
|-----|------------|--------------------------|-------------|
| TFS | TF0, bits  | 0x320                    | 0x148       |
|     | TF1, bits  | 1x320                    | 1x148       |
|     | TF2, bits  | 2x320                    | N/A         |
|     | TF3, bits  | 4x320                    | N/A         |
|     | TF4, bits  | 8x320                    | N/A         |

## Uplink-TFCS:

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| UL_TFC0     | (TF0, TF0)         |
| UL_TFC1     | (TF1, TF0)         |
| UL_TFC2     | (TF2, TF0)         |
| UL_TFC3     | (TF3, TF0)         |
| UL_TFC4     | (TF4, TF0)         |
| UL_TFC5     | (TF0, TF1)         |
| UL_TFC6     | (TF1, TF1)         |
| UL_TFC7     | (TF2, TF1)         |
| UL_TFC8     | (TF3, TF1)         |
| UL_TFC9     | (TF4, TF1)         |

## Downlink-TFS:

|     | <b>TFI</b> | <b>RB5<br/>(14.4 kbps)</b> | <b>DCCH</b> |
|-----|------------|----------------------------|-------------|
| TFS | TF0, bits  | 0x576                      | 0x148       |
|     | TF1, bits  | 1x576                      | 1x148       |

## Downlink-TFCS:

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| DL_TFC0     | (TF0, TF0)         |
| DL_TFC1     | (TF1, TF0)         |
| DL_TFC2     | (TF0, TF1)         |
| DL_TFC3     | (TF1, TF1)         |

Sub-tests:

| Sub-test | Downlink TFCs Under test | Uplink TFCs Under test | Implicitly tested                  | Restricted UL TFCs                 | UL RLC SDU size (bits) (note 1) | Test data size (bits) (note 1) |
|----------|--------------------------|------------------------|------------------------------------|------------------------------------|---------------------------------|--------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 320                        | RB5: 576 (note 2)              |
| 2        | DL_TFC1                  | UL_TFC2                | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 640                        | RB5: 576 (note 3)              |
| 3        | DL_TFC1                  | UL_TFC3                | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 1280                       | RB5: 576 (note 4)              |
| 4        | DL_TFC1                  | UL_TFC4                | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 2560                       | RB5: 576 (note 5)              |

NOTE 1: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

NOTE 2: SS is using a DL RLC SDU with 576 bits as test data (=DL RLC PDU size for DL/TF1). UE will return the first 320 bits of the test data.

NOTE 3: SS is using a DL RLC SDU size of 576 bits as test data (=DL RLC PDU size for DL/TF1). UE will return an RLC SDU repeating the received DL RLC SDU two times (truncating the last one to fit the UL RLC SDU size of 640 bits).

NOTE 4: SS is using a DL RLC SDU size of 576 bits as test data (=DL RLC PDU size for DL/TF1). UE will return an RLC SDU repeating the received DL RLC SDU three times (truncating the last one to fit the UL RLC SDU size of 1280 bits).

NOTE 5: SS is using a DL RLC SDU size of 576 bits as test data (=DL RLC PDU size for DL/TF1). UE will return an RLC SDU repeating the received DL RLC SDU five times (truncating the last one to fit the UL RLC SDU size of 2560 bits).

See 14.1.1 for test procedure.

#### 14.2.19.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

— for sub-test 1: RB5/TF1 (1x320).

— for sub-test 2: RB5/TF2 (2x320).

— for sub-test 3: RB5/TF3 (4x320).

— for sub-test 4: RB5/TF4 (8x320).

3. At step 15 the UE shall return

— for sub-test 1: an RLC SDU on RB5 having the same content as the first 320 bits of the DL RLC SDU sent by the SS.

— for sub-test 2: an RLC SDU on RB5 for which the first 576 bits are equal to the sent DL RLC SDU bit pattern and the remaining 64 bits are equal to the first 64 bits of the sent DL RLC SDU.

— for sub-test 3: an RLC SDU on RB5 for which the first 1152 bits are equal to the sent DL RLC SDU bit pattern repeated twice and the remaining 128 bits are equal to the first 128 bits of the sent DL RLC SDU.

— for sub-test 4: an RLC SDU on RB5 for which the first 2304 bits are equal to the sent DL RLC SDU bit pattern repeated four times and the remaining 256 bits are equal to the first 256 of the sent DL RLC SDU.



## 14.2.20 Streaming / unknown / UL:0 DL:128 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

### 14.2.20.1 Conformance requirement

See 14.2.4.1.

### 14.2.20.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.20.

To be able to test the downlink radio bearer using the UE loopback function for the reference radio bearer UL:0 DL:128 kbps, the reference radio bearer configuration according to TS 34.108, clause 6.10.2.4.1.15.1 (Streaming/unknown/UL:14.4 kbps) is used in uplink. For all sub-tests UL\_TFC1 is used.

### 14.2.20.3 Method of test

Uplink TFS:

|     | TFI       | RB5<br>(28.8 kbps) | DCCH  |
|-----|-----------|--------------------|-------|
| TFS | TF0, bits | 0x576              | 0x148 |
|     | TF1, bits | 1x576              | 1x148 |

Uplink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF0, TF1)  |
| UL_TFC3 | (TF1, TF1)  |

Downlink TFS:

|     | TFI       | RB5<br>(128 kbps) | DCCH  |
|-----|-----------|-------------------|-------|
| TFS | TF0, bits | 0x320             | 0x148 |
|     | TF1, bits | 1x320             | 1x148 |
|     | TF2, bits | 2x320             | N/A   |
|     | TF3, bits | 4x320             | N/A   |
|     | TF4, bits | 8x320             | N/A   |
|     | TF5, bits | 16x320            | N/A   |

Downlink TFCS:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC0  | (TF0, TF0)  |
| DL_TFC1  | (TF1, TF0)  |
| DL_TFC2  | (TF2, TF0)  |
| DL_TFC3  | (TF3, TF0)  |
| DL_TFC4  | (TF4, TF0)  |
| DL_TFC5  | (TF5, TF0)  |
| DL_TFC6  | (TF0, TF1)  |
| DL_TFC7  | (TF1, TF1)  |
| DL_TFC8  | (TF2, TF1)  |
| DL_TFC9  | (TF3, TF1)  |
| DL_TFC10 | (TF4, TF1)  |
| DL_TFC11 | (TF5, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCs Under test | Uplink TFCs Under test | Implicitly tested                  | Restricted UL TFCs                 | UL RLC SDU-size (bits) (note 1) | Test data size (bits) (note 1) |
|----------|--------------------------|------------------------|------------------------------------|------------------------------------|---------------------------------|--------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                        | RB5: 320 (note 2)              |
| 2        | DL_TFC2                  | UL_TFC1                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                        | RB5: 640 (note 3)              |
| 3        | DL_TFC3                  | UL_TFC1                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                        | RB5: 1280 (note 4)             |
| 4        | DL_TFC4                  | UL_TFC1                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                        | RB5: 2560 (note 5)             |
| 5        | DL_TFC5                  | UL_TFC1                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                        | RB5: 5120 (note 6)             |

NOTE 1: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

NOTE 2: SS is using a DL RLC SDU with 320 bits as test data (=DL RLC PDU size for DL/TF1). UE will return one RLC PDU. SS creates an UL RLC SDU from the first 320 bits of the received RLC PDU.

NOTE 3: SS is using a DL RLC SDU size of 640 bits as test data (=DL RLC PDU size for DL/TF2). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.

NOTE 4: SS is using a DL RLC SDU size of 1280 bits as test data (=DL RLC PDU size for DL/TF3). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.

NOTE 5: SS is using a DL RLC SDU size of 2560 bits as test data (=DL RLC PDU size for DL/TF4). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.

NOTE 6: SS is using a DL RLC SDU size of 5120 bits as test data (=DL RLC PDU size for DL/TF5). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.

See 14.1.1 for test procedure.

#### 14.2.20.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE shall return

— for sub-test 1: an RLC SDU on RB5 having the same content as sent by the SS.

— for sub-test 2 to 5: an RLC SDU on RB5 having the same content as the first 576 bits of the RLC SDU sent by the SS.

#### 14.2.21 Streaming / unknown / UL:128 DL:0 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

##### 14.2.21.1 Conformance requirement

See 14.2.4.1.

### 14.2.21.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.21.

To be able to test the uplink radio bearer using the UE loopback function for the reference radio bearer UL:64 DL: 0 kbps, the reference radio bearer configuration according to TS 34.108, clause 6.10.2.4.1.15.2 (Streaming/unknown/DL:14.4 kbps) is used in downlink.

### 14.2.21.3 Method of test

Uplink TFS:

|     | <b>TFI</b> | <b>RB5<br/>(128 kbps)</b> | <b>DCCH</b> |
|-----|------------|---------------------------|-------------|
| TFS | TF0, bits  | 0x320                     | 0x148       |
|     | TF1, bits  | 1x320                     | 1x148       |
|     | TF2, bits  | 2x320                     | N/A         |
|     | TF3, bits  | 4x320                     | N/A         |
|     | TF4, bits  | 8x320                     | N/A         |
|     | TF5, bits  | 16x320                    | N/A         |

Uplink TFCS:

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| UL_TFC0     | (TF0, TF0)         |
| UL_TFC1     | (TF1, TF0)         |
| UL_TFC2     | (TF2, TF0)         |
| UL_TFC3     | (TF3, TF0)         |
| UL_TFC4     | (TF4, TF0)         |
| UL_TFC5     | (TF4, TF0)         |
| UL_TFC6     | (TF0, TF1)         |
| UL_TFC7     | (TF1, TF1)         |
| UL_TFC8     | (TF2, TF1)         |
| UL_TFC9     | (TF3, TF1)         |
| UL_TFC10    | (TF4, TF1)         |
| UL_TFC11    | (TF5, TF1)         |

Downlink TFS:

|     | <b>TFI</b> | <b>RB5<br/>(28.8 kbps)</b> | <b>DCCH</b> |
|-----|------------|----------------------------|-------------|
| TFS | TF0, bits  | 0x576                      | 0x148       |
|     | TF1, bits  | 1x576                      | 1x148       |

Downlink TFCS:

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| DL_TFC0     | (TF0, TF0)         |
| DL_TFC1     | (TF1, TF0)         |
| DL_TFC2     | (TF0, TF1)         |
| DL_TFC3     | (TF1, TF1)         |

Sub-tests:

| Sub-test | Downlink TFCs Under test | Uplink TFCs Under test | Implicitly tested                  | Restricted UL TFCs                  | UL RLC SDU-size (bits) (note 1) | Test data size (bits) (note 1) |
|----------|--------------------------|------------------------|------------------------------------|-------------------------------------|---------------------------------|--------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC1, UL_TFC6, UL_TFC7  | RB5: 320                        | RB5: 576 (note 2)              |
| 2        | DL_TFC1                  | UL_TFC2                | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC2, UL_TFC6, UL_TFC8  | RB5: 640                        | RB5: 576 (note 3)              |
| 3        | DL_TFC1                  | UL_TFC3                | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC3, UL_TFC6, UL_TFC9  | RB5: 1280                       | RB5: 576 (note 4)              |
| 4        | DL_TFC1                  | UL_TFC4                | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC4, UL_TFC6, UL_TFC10 | RB5: 2560                       | RB5: 576 (note 5)              |
| 5        | DL_TFC1                  | UL_TFC5                | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC5, UL_TFC6, UL_TFC11 | RB5: 5120                       | RB5: 576 (note 6)              |

NOTE 1: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

NOTE 2: SS is using a DL RLC SDU with 576 bits as test data (=DL RLC PDU size for DL/TF1). UE will return the first 320 bits of the test data.

NOTE 3: SS is using a DL RLC SDU size of 576 bits as test data (=DL RLC PDU size for DL/TF1). UE will return an RLC SDU repeating the received DL RLC SDU two times (truncating the last one to fit the UL RLC SDU size of 640 bits).

NOTE 4: SS is using a DL RLC SDU size of 576 bits as test data (=DL RLC PDU size for DL/TF1). UE will return an RLC SDU repeating the received DL RLC SDU three times (truncating the last one to fit the UL RLC SDU size of 1280 bits).

NOTE 5: SS is using a DL RLC SDU size of 576 bits as test data (=DL RLC PDU size for DL/TF1). UE will return an RLC SDU repeating the received DL RLC SDU five times (truncating the last one to fit the UL RLC SDU size of 2560 bits).

NOTE 6: SS is using a DL RLC SDU size of 576 bits as test data (=DL RLC PDU size for DL/TF1). UE will return an RLC SDU repeating the received DL RLC SDU nine times (truncating the last one to fit the UL RLC SDU size of 5120 bits).

See 14.1.1 for test procedure.

## 14.2.21.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

— for sub-test 1: RB5/TF1 (1x320).

— for sub-test 2: RB5/TF2 (2x320).

— for sub-test 3: RB5/TF3 (4x320).

— for sub-test 4: RB5/TF4 (8x320).

— for sub-test 5: RB5/TF5 (16x320).

3. At step 15 the UE shall return

— for sub-test 1: an RLC SDU on RB5 having the same content as the first 320 bits of the DL RLC SDU sent by the SS.

- for sub-test 2: an RLC SDU on RB5 for which the first 576 bits are equal to the sent DL RLC SDU bit pattern and the remaining 64 bits are equal to the first 64 bits of the DL RLC SDU sent by the SS.
- for sub-test 3: an RLC SDU on RB5 for which the first 1152 bits are equal to the sent DL RLC SDU bit pattern repeated twice and the remaining 128 bits are equal to the first 128 of the sent DL RLC SDU.
- for sub-test 4: an RLC SDU on RB5 for which the first 2304 bits are equal to the sent DL RLC SDU bit pattern repeated four times and the remaining 256 bits are equal to the first 256 of the sent DL RLC SDU.
- for sub-test 5: an RLC SDU on RB5 for which the first 4608 bits are equal to the sent DL RLC SDU bit pattern repeated eight times and the remaining 512 bits are equal to the first 512 of the sent DL RLC SDU.

## ~~14.2.22 Streaming / unknown / UL:0 DL:384 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

### ~~14.2.22.1 Conformance requirement~~

~~See 14.2.4.1.~~

### ~~14.2.22.2 Test purpose~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.22.~~

~~To be able to test the downlink radio bearer using the UE loopback function for the reference radio bearer UL:0 DL:384 kbps, the reference radio bearer configuration according to TS 34.108, clause 6.10.2.4.1.15.1 (Streaming/unknown/UL:14.4 kbps) is used in uplink.~~

### ~~14.2.22.3 Method of test~~

~~Uplink TFS:~~

|     | <b>TFI</b> | <b>RB5<br/>(28.8 kbps)</b> | <b>DCCH</b> |
|-----|------------|----------------------------|-------------|
| TFS | TF0, bits  | 0x576                      | 0x148       |
|     | TF1, bits  | 1x576                      | 1x148       |

~~Uplink TFCS:~~

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| UL_TFC0     | (TF0, TF0)         |
| UL_TFC1     | (TF1, TF0)         |
| UL_TFC2     | (TF0, TF1)         |
| UL_TFC3     | (TF1, TF1)         |

~~Downlink TFS:~~

|     | <b>TFI</b> | <b>RB5<br/>(384 kbps)</b> | <b>DCCH</b> |
|-----|------------|---------------------------|-------------|
| TFS | TF0, bits  | 0x320                     | 0x148       |
|     | TF1, bits  | 1x320                     | 1x148       |
|     | TF2, bits  | 2x320                     | N/A         |
|     | TF3, bits  | 4x320                     | N/A         |
|     | TF4, bits  | 8x320                     | N/A         |
|     | TF5, bits  | 16x320                    | N/A         |
|     | TF6, bits  | 32x320                    | N/A         |
|     | TF7, bits  | 48x320                    | N/A         |

## Downlink TFCS:

| TFCS     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC0  | (TF0, TF0)  |
| DL_TFC1  | (TF1, TF0)  |
| DL_TFC2  | (TF2, TF0)  |
| DL_TFC3  | (TF3, TF0)  |
| DL_TFC4  | (TF4, TF0)  |
| DL_TFC5  | (TF5, TF0)  |
| DL_TFC6  | (TF6, TF0)  |
| DL_TFC7  | (TF7, TF0)  |
| DL_TFC8  | (TF0, TF1)  |
| DL_TFC9  | (TF1, TF1)  |
| DL_TFC10 | (TF2, TF1)  |
| DL_TFC11 | (TF3, TF1)  |
| DL_TFC12 | (TF4, TF1)  |
| DL_TFC13 | (TF5, TF1)  |
| DL_TFC14 | (TF6, TF1)  |
| DL_TFC15 | (TF7, TF1)  |

## Sub-tests:

| Sub-test | Downlink TFCS Under test | Uplink TFCS Under test | Implicitely tested                  | Restricted UL TFCS                 | UL RLC SDU-size (bits) (note 1) | Test data size (bits) (note 1) |
|----------|--------------------------|------------------------|-------------------------------------|------------------------------------|---------------------------------|--------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC8, UL_TFC0, UL_TFC2  | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                        | RB5: 320 (note 2)              |
| 2        | DL_TFC2                  | UL_TFC1                | DL_TFC0, DL_TFC8, UL_TFC0, UL_TFC2  | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                        | RB5: 640 (note 3)              |
| 3        | DL_TFC3                  | UL_TFC1                | DL_TFC0, DL_TFC8, UL_TFC0, UL_TFC2, | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                        | RB5: 1280 (note 4)             |
| 4        | DL_TFC4                  | UL_TFC1                | DL_TFC0, DL_TFC8, UL_TFC0, UL_TFC2  | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                        | RB5: 2560 (note 5)             |
| 5        | DL_TFC5                  | UL_TFC1                | DL_TFC0, DL_TFC8, UL_TFC0, UL_TFC2  | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                        | RB5: 5120 (note 6)             |
| 6        | DL_TFC6                  | UL_TFC1                | DL_TFC0, DL_TFC8, UL_TFC0, UL_TFC2  | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                        | RB5: 10240 (note 7)            |

| Sub-test                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | Downlink TFCs Under test | Uplink TFCs Under test | Implicitely tested                 | Restricted UL TFCIs                | UL RLC SDU-size (bits) (note 1) | Test data size (bits) (note 1) |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|------------------------|------------------------------------|------------------------------------|---------------------------------|--------------------------------|
| 7                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | DL_TFC7                  | UL_TFC1                | DL_TFC0, DL_TFC8, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 576                        | RB5: 15360 (note 8)            |
| <p>NOTE 1: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.</p> <p>NOTE 2: SS is using a DL RLC SDU with 320 bits as test data (=DL RLC PDU size for DL/TF1). UE will return one RLC PDU. SS creates an UL RLC SDU from the first 320 bits of the received RLC PDU.</p> <p>NOTE 3: SS is using a DL RLC SDU size of 640 bits as test data (=DL RLC PDU size for DL/TF2). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 4: SS is using a DL RLC SDU size of 1280 bits as test data (=DL RLC PDU size for DL/TF3). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 5: SS is using a DL RLC SDU size of 2560 bits as test data (=DL RLC PDU size for DL/TF4). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 6: SS is using a DL RLC SDU size of 5120 bits as test data (=DL RLC PDU size for DL/TF5). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 7: SS is using a DL RLC SDU size of 10240 bits as test data (=DL RLC PDU size for DL/TF6). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 8: SS is using a DL RLC SDU size of 15360 bits as test data (=DL RLC PDU size for DL/TF7). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> |                          |                        |                                    |                                    |                                 |                                |

See 14.1.1 for test procedure.

#### 14.2.22.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE shall return
  - for sub-test 1: an RLC SDU on RB5 having the same content as sent by the SS.
  - for sub-test 2 to 7: an RLC SDU on RB5 having the same content as the first 576 bits of the RLC SDU sent by the SS.

### 14.2.23 Interactive or background / UL:32 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

#### 14.2.23.1 Interactive or background / UL:32 DL:8 kbps / PS RAB / (TC,10 ms TTI)

##### 14.2.23.1.1 Conformance requirement

See 14.2.4.1.

##### 14.2.23.1.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.23 for the turbo channel coding and uplink 10 ms TTI case.

### 14.2.23.1.3 ~~Method of test~~

~~Uplink TFS:~~

|            | <b>TFI</b> | <b>RB5<br/>(32 kbps)</b> | <b>DCCH</b> |
|------------|------------|--------------------------|-------------|
| <b>TFS</b> | TF0, bits  | 0x336                    | 0x148       |
|            | TF1, bits  | 1x336                    | 1x148       |

~~Uplink TFCS:~~

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| UL_TFC0     | (TF0, TF0)         |
| UL_TFC1     | (TF1, TF0)         |
| UL_TFC2     | (TF0, TF1)         |
| UL_TFC3     | (TF1, TF1)         |

~~Downlink TFS:~~

|            | <b>TFI</b> | <b>RB5<br/>(8 kbps)</b> | <b>DCCH</b> |
|------------|------------|-------------------------|-------------|
| <b>TFS</b> | TF0, bits  | 0x336                   | 0x148       |
|            | TF1, bits  | 1x336                   | 1x148       |

~~Downlink TFCS:~~

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| DL_TFC0     | (TF0, TF0)         |
| DL_TFC1     | (TF1, TF0)         |
| DL_TFC2     | (TF0, TF1)         |
| DL_TFC3     | (TF1, TF1)         |

~~Sub-tests:~~

| <b>Sub-test</b> | <b>Downlink<br/>TFCS<br/>Under test</b> | <b>Uplink<br/>TFCS<br/>Under test</b> | <b>Implicitely tested</b>             | <b>Restricted<br/>UL-TFCIs</b>              | <b>UL RLC SDU<br/>size<br/>(bits)<br/>(note)</b> | <b>Test data size<br/>(bits)<br/>(note)</b> |
|-----------------|-----------------------------------------|---------------------------------------|---------------------------------------|---------------------------------------------|--------------------------------------------------|---------------------------------------------|
| 1               | DL_TFC1                                 | UL_TFC1                               | DL_TFC0, DL_TFC2, UL_TFC0,<br>UL_TFC2 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC2,<br>UL_TFC3 | RB5: 312                                         | RB5: 312                                    |

~~NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.~~

See 14.1.1 for test procedure.

### 14.2.23.1.4 ~~Test requirements~~

See 14.1.1 for definition of step 10 and step 15.

1. ~~At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.~~
2. ~~At step 15 the UE transmitted transport format shall be~~
  - ~~— for sub-test 1: RB5/TF1 (1x336).~~
3. ~~At step 15 the UE shall return~~
  - ~~— for sub-test 1: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.~~



~~14.2.23.2 Interactive or background / UL:32 DL:8 kbps / PS RAB / (TC, 20 ms TTI)~~~~14.2.23.2.1 Conformance requirement~~~~See 14.2.4.1.~~~~14.2.23.2.2 Test purpose~~~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.23 for the turbo channel coding and uplink 20 ms TTI case.~~~~14.2.23.2.3 Method of test~~~~Uplink TFS:~~

|            | <b>TFI</b> | <b>RB5<br/>(32 kbps)</b> | <b>DCCH</b> |
|------------|------------|--------------------------|-------------|
| <b>TFS</b> | TF0, bits  | 0x336                    | 0x148       |
|            | TF1, bits  | 1x336                    | 1x148       |
|            | TF2, bits  | 2x336                    | N/A         |

~~Uplink TFCS:~~

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| UL_TFC0     | (TF0, TF0)         |
| UL_TFC1     | (TF1, TF0)         |
| UL_TFC2     | (TF2, TF0)         |
| UL_TFC3     | (TF0, TF1)         |
| UL_TFC4     | (TF1, TF1)         |
| UL_TFC5     | (TF2, TF1)         |

~~Downlink TFS:~~

|            | <b>TFI</b> | <b>RB5<br/>(8 kbps)</b> | <b>DCCH</b> |
|------------|------------|-------------------------|-------------|
| <b>TFS</b> | TF0, bits  | 0x336                   | 0x148       |
|            | TF1, bits  | 1x336                   | 1x148       |

~~Downlink TFCS:~~

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| DL_TFC0     | (TF0, TF0)         |
| DL_TFC1     | (TF1, TF0)         |
| DL_TFC2     | (TF0, TF1)         |
| DL_TFC3     | (TF1, TF1)         |

Sub-tests:

| Sub-test | Downlink TFCs Under test | Uplink TFCs Under test | Implicitely-tested                 | Restricted UL TFCIs                | UL RLC SDU size (bits) (note) | Test data size (bits) (note) |
|----------|--------------------------|------------------------|------------------------------------|------------------------------------|-------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4 | RB5: 312                      | RB5: 312                     |
| 2        | DL_TFC1                  | UL_TFC2                | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5 | RB5: 632                      | RB5: 632                     |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 14.2.23.2.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
3. At step 15 the UE shall return
  - for sub-test 1 and 2: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

#### 14.2.23.3 Interactive or background / UL:32 DL:8 kbps / PS RAB / (CC, 10 ms TTI)

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.23 for the convolutional channel coding and uplink 10 ms TTI case.

See test case 14.2.23.1 for test procedure and test requirement.

#### 14.2.23.4 Interactive or background / UL:32 DL:8 kbps / PS RAB / (CC, 20 ms TTI)

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.23 for the convolutional channel coding and uplink 20 ms TTI case.

See test case 14.2.23.2 for test procedure and test requirement.

#### 14.2.23a Interactive or background / UL:8 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.23a.

#### 14.2.23b Interactive or background / UL:16 DL:16 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.23b.

### ~~14.2.23c Interactive or background / UL:32 DL:32 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.23c.

### ~~14.2.23d Interactive or background / UL:32 DL:32 kbps / PS RAB (20 ms TTI) + UL:3.4 DL:3.4 kbps SRBs for DCCH.~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.23d.

### ~~14.2.24 Interactive or background / UL:64 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

#### ~~14.2.24.1 Interactive or background / UL:64 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / TC~~

##### ~~14.2.24.1.1 Conformance requirement~~

See 14.2.4.1.1.

##### ~~14.2.24.1.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.24 for the downlink turbo coding case.

##### ~~14.2.24.1.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x336            | 0x148 |
|     | TF1, bits | 1x336            | 1x148 |
|     | TF2, bits | 2x336            | N/A   |
|     | TF3, bits | 3x336            | N/A   |
|     | TF4, bits | 4x336            | N/A   |

Uplink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |

Downlink TFS:

|            | <b>TFI</b> | <b>RB5<br/>(8 kbps)</b> | <b>DCCH</b> |
|------------|------------|-------------------------|-------------|
| <b>TFS</b> | TF0, bits  | 0x336                   | 0x148       |
|            | TF1, bits  | 1x336                   | 1x148       |

Downlink TFCS:

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| DL_TFC0     | (TF0, TF0)         |
| DL_TFC1     | (TF1, TF0)         |
| DL_TFC2     | (TF0, TF1)         |
| DL_TFC3     | (TF1, TF1)         |

Sub-tests:

| <b>Sub-test</b> | <b>Downlink TFCS Under test</b> | <b>Uplink TFCS Under test</b> | <b>Implicitely tested</b>          | <b>Restricted UL TFCIs</b>         | <b>UL RLC SDU size (bits) (note)</b> | <b>Test data size (bits) (note)</b> |
|-----------------|---------------------------------|-------------------------------|------------------------------------|------------------------------------|--------------------------------------|-------------------------------------|
| 1               | DL_TFC1                         | UL_TFC1                       | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 312                             | RB5: 312                            |
| 2               | DL_TFC1                         | UL_TFC2                       | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 632                             | RB5: 632                            |
| 3               | DL_TFC1                         | UL_TFC3                       | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 952                             | RB5: 952                            |
| 4               | DL_TFC1                         | UL_TFC4                       | DL_TFC0, DL_TFC2, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 1272                            | RB5: 1272                           |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 14.2.24.1.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (3x336).
  - for sub-test 4: RB5/TF4 (4x336).
3. At step 15 the UE shall return
  - for sub-test 1 to 4: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

### ~~14.2.24.2 — Interactive or background / UL:64 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / CC~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.24 for the downlink convolutional channel coding case.

See test case 14.2.24.1 for test procedure and test requirement.

### ~~14.2.25 — Interactive or background / UL:32 DL: 64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

#### ~~14.2.25.1 — Interactive or background / UL:32 DL: 64 kbps / PS RAB / (TC, 10 ms TTI)~~

##### ~~14.2.25.1.1 — Conformance requirement~~

See 14.2.4.1.

##### ~~14.2.25.1.2 — Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.25 for the uplink turbo channel coding and 10 ms TTI case.

##### ~~14.2.25.1.3 — Method of test~~

Uplink-TFS:

|     | TFI       | RB5<br>(32 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x336            | 0x148 |
|     | TF1, bits | 1x336            | 1x148 |

Uplink-TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF0, TF1)  |
| UL_TFC3 | (TF1, TF1)  |

Downlink-TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x336            | 0x148 |
|     | TF1, bits | 1x336            | 1x148 |
|     | TF2, bits | 2x336            | N/A   |
|     | TF3, bits | 3x336            | N/A   |
|     | TF4, bits | 4x336            | N/A   |

Downlink-TFCS:

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| DL_TFC0     | (TF0, TF0)         |
| DL_TFC1     | (TF1, TF0)         |
| DL_TFC2     | (TF2, TF0)         |
| DL_TFC3     | (TF3, TF0)         |
| DL_TFC4     | (TF4, TF0)         |
| DL_TFC5     | (TF0, TF1)         |
| DL_TFC6     | (TF1, TF1)         |
| DL_TFC7     | (TF2, TF1)         |
| DL_TFC8     | (TF3, TF1)         |
| DL_TFC9     | (TF4, TF1)         |

Sub-tests:

| <b>Sub-test</b> | <b>Downlink TFCs Under test</b> | <b>Uplink TFCs Under test</b> | <b>Implicitely-tested</b>          | <b>Restricted UL TFCs</b>          | <b>UL RLC SDU size (bits) (note)</b> | <b>Test data size (bits) (note)</b> |
|-----------------|---------------------------------|-------------------------------|------------------------------------|------------------------------------|--------------------------------------|-------------------------------------|
| 1               | DL_TFC1                         | UL_TFC1                       | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 312                             | RB5: 312                            |
| 2               | DL_TFC2                         | UL_TFC1                       | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 632                             | RB5: 632                            |
| 3               | DL_TFC3                         | UL_TFC1                       | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 952                             | RB5: 952                            |
| 4               | DL_TFC4                         | UL_TFC1                       | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC2 | UL_TFC0, UL_TFC1, UL_TFC2, UL_TFC3 | RB5: 1272                            | RB5: 1272                           |

NOTE:— See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 14.2.25.1.4 ——— Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1 to 4: RB5/TF1 (1x336).
3. At step 15 the UE shall return
  - for sub-test 1 to 4: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

#### 14.2.25.2 ——— Interactive or background / UL:32 DL: 64 kbps / PS RAB / (TC, 20 ms TTI)

##### 14.2.25.2.1 ——— Conformance requirement

See 14.2.4.1.

##### 14.2.25.2.2 ——— Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.25 for the uplink turbo channel coding and 20 ms TTI case.

## 14.2.25.2.3 Method of test

## Uplink TFS:

|     | TFI       | RB5<br>(32 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x336            | 0x148 |
|     | TF1, bits | 1x336            | 1x148 |
|     | TF2, bits | 2x336            | N/A   |

## Uplink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF0, TF1)  |
| UL_TFC4 | (TF1, TF1)  |
| UL_TFC5 | (TF2, TF1)  |

## Downlink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x336            | 0x148 |
|     | TF1, bits | 1x336            | 1x148 |
|     | TF2, bits | 2x336            | N/A   |
|     | TF3, bits | 3x336            | N/A   |
|     | TF4, bits | 4x336            | N/A   |

## Downlink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| DL_TFC0 | (TF0, TF0)  |
| DL_TFC1 | (TF1, TF0)  |
| DL_TFC2 | (TF2, TF0)  |
| DL_TFC3 | (TF3, TF0)  |
| DL_TFC4 | (TF4, TF0)  |
| DL_TFC5 | (TF0, TF1)  |
| DL_TFC6 | (TF1, TF1)  |
| DL_TFC7 | (TF2, TF1)  |
| DL_TFC8 | (TF3, TF1)  |
| DL_TFC9 | (TF4, TF1)  |

## Sub-tests:

| Sub-test                                                                              | Downlink TFCs Under test | Uplink TFCs Under test | Implicitely tested                 | Restricted UL TFCIs                | UL RLC SDU size (bits) (note) | Test data size (bits) (note) |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|------------------------------------|------------------------------------|-------------------------------|------------------------------|
| 1                                                                                     | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4 | RB5: 312                      | RB5: 312                     |
| 2                                                                                     | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5 | RB5: 632                      | RB5: 632                     |
| 3                                                                                     | DL_TFC3                  | UL_TFC1                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4 | RB5: 952                      | RB5: 952                     |
| 4                                                                                     | DL_TFC4                  | UL_TFC2                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5 | RB5: 1272                     | RB5: 1272                    |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                    |                                    |                               |                              |

See 14.1.1 for test procedure.

#### 14.2.25.2.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF1 (1x336).
  - for sub-test 4: RB5/TF2 (2x336).
3. At step 15 the UE shall return
  - for sub-test 1 to 4: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

#### 14.2.25.3 Interactive or background / UL:32 DL:64 kbps / PS RAB / (CG, 10 ms TTI)

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.25 for the uplink convolutional channel coding and 10 ms TTI case.

See test case 14.2.25.1 for test procedure and test requirement.

#### 14.2.25.4 Interactive or background / UL:32 DL:64 kbps / PS RAB / (CG, 20 ms TTI)

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.25 for the uplink convolutional channel coding and 20 ms TTI case.

See test case 14.2.25.2 for test procedure and test requirement.



## 14.2.26 ~~Interactive or background / UL:64 DL: 64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

### 14.2.26.1 ~~Conformance requirement~~

See 14.2.4.1.

### 14.2.26.2 ~~Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.26.

### 14.2.26.3 ~~Method of test~~

Uplink TFS:

|     | <b>TFI</b> | <b>RB5<br/>(64 kbps)</b> | <b>DCCH</b> |
|-----|------------|--------------------------|-------------|
| TFS | TF0, bits  | 0x336                    | 0x148       |
|     | TF1, bits  | 1x336                    | 1x148       |
|     | TF2, bits  | 2x336                    | N/A         |
|     | TF3, bits  | 3x336                    | N/A         |
|     | TF4, bits  | 4x336                    | N/A         |

Uplink TFCS:

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| UL_TFC0     | (TF0, TF0)         |
| UL_TFC1     | (TF1, TF0)         |
| UL_TFC2     | (TF2, TF0)         |
| UL_TFC3     | (TF3, TF0)         |
| UL_TFC4     | (TF4, TF0)         |
| UL_TFC5     | (TF0, TF1)         |
| UL_TFC6     | (TF1, TF1)         |
| UL_TFC7     | (TF2, TF1)         |
| UL_TFC8     | (TF3, TF1)         |
| UL_TFC9     | (TF4, TF1)         |

Downlink TFS:

|     | <b>TFI</b> | <b>RB5<br/>(64 kbps)</b> | <b>DCCH</b> |
|-----|------------|--------------------------|-------------|
| TFS | TF0, bits  | 0x336                    | 0x148       |
|     | TF1, bits  | 1x336                    | 1x148       |
|     | TF2, bits  | 2x336                    | N/A         |
|     | TF3, bits  | 3x336                    | N/A         |
|     | TF4, bits  | 4x336                    | N/A         |

Downlink TFCS:

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| DL_TFC0     | (TF0, TF0)         |
| DL_TFC1     | (TF1, TF0)         |
| DL_TFC2     | (TF2, TF0)         |
| DL_TFC3     | (TF3, TF0)         |
| DL_TFC4     | (TF4, TF0)         |
| DL_TFC5     | (TF0, TF1)         |
| DL_TFC6     | (TF1, TF1)         |
| DL_TFC7     | (TF2, TF1)         |
| DL_TFC8     | (TF3, TF1)         |
| DL_TFC9     | (TF4, TF1)         |

Sub-tests:

| <b>Sub-test</b> | <b>Downlink TFCs Under test</b> | <b>Uplink TFCs Under test</b> | <b>Implicitely tested</b>          | <b>Restricted UL TFCIs</b>         | <b>UL RLC SDU size (bits) (note)</b> | <b>Test data size (bits) (note)</b> |
|-----------------|---------------------------------|-------------------------------|------------------------------------|------------------------------------|--------------------------------------|-------------------------------------|
| 1               | DL_TFC1                         | UL_TFC1                       | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 312                             | RB5: 312                            |
| 2               | DL_TFC2                         | UL_TFC2                       | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 632                             | RB5: 632                            |
| 3               | DL_TFC3                         | UL_TFC3                       | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 952                             | RB5: 952                            |
| 4               | DL_TFC4                         | UL_TFC4                       | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 1272                            | RB5: 1272                           |

NOTE:— See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 14.2.26.4 ————— Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (3x336).
  - for sub-test 4: RB5/TF4 (4x336).
3. At step 15 the UE shall return
  - for sub-test 1 to 4: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

## 14.2.27 ~~Interactive or background / UL:64 DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

### 14.2.27.1 ~~Conformance requirement~~

See 14.2.4.1.

### 14.2.27.2 ~~Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.27.

### 14.2.27.3 ~~Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x336            | 0x148 |
|     | TF1, bits | 1x336            | 1x148 |
|     | TF2, bits | 2x336            | N/A   |
|     | TF3, bits | 3x336            | N/A   |
|     | TF4, bits | 4x336            | N/A   |

Uplink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |

Downlink TFS:

|     | TFI       | RB5<br>(128 kbps) | DCCH  |
|-----|-----------|-------------------|-------|
| TFS | TF0, bits | 0x336             | 0x148 |
|     | TF1, bits | 1x336             | 1x148 |
|     | TF2, bits | 2x336             | N/A   |
|     | TF3, bits | 4x336             | N/A   |
|     | TF4, bits | 8x336             | N/A   |

Downlink TFCS:

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| DL_TFC0     | (TF0, TF0)         |
| DL_TFC1     | (TF1, TF0)         |
| DL_TFC2     | (TF2, TF0)         |
| DL_TFC3     | (TF3, TF0)         |
| DL_TFC4     | (TF4, TF0)         |
| DL_TFC5     | (TF0, TF1)         |
| DL_TFC6     | (TF1, TF1)         |
| DL_TFC7     | (TF2, TF1)         |
| DL_TFC8     | (TF3, TF1)         |
| DL_TFC9     | (TF4, TF1)         |

Sub-tests:

| <b>Sub-test</b> | <b>Downlink TFCs Under test</b> | <b>Uplink TFCs Under test</b> | <b>Implicitely tested</b>          | <b>Restricted UL TFCIs</b>         | <b>UL RLC SDU size (bits) (note)</b> | <b>Test data size (bits) (note)</b> |
|-----------------|---------------------------------|-------------------------------|------------------------------------|------------------------------------|--------------------------------------|-------------------------------------|
| 1               | DL_TFC1                         | UL_TFC1                       | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 312                             | RB5: 312                            |
| 2               | DL_TFC2                         | UL_TFC2                       | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 632                             | RB5: 632                            |
| 3               | DL_TFC3                         | UL_TFC3                       | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 1272                            | RB5: 1272                           |
| 4               | DL_TFC4                         | UL_TFC4                       | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 2552                            | RB5: 2552                           |

NOTE:— See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 14.2.27.4 ————— Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (3x336).
  - for sub-test 4: RB5/TF4 (4x336).
3. At step 15 the UE shall return
  - for sub-test 1 to 4: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

## 14.2.28 ~~Interactive or background / UL:128 DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

### 14.2.28.1 ~~Conformance requirement~~

See 14.2.4.1.

### 14.2.28.2 ~~Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.28.

### 14.2.28.3 ~~Method of test~~

Uplink TFS:

|     | <b>TFI</b> | <b>RB5<br/>(128 kbps)</b> | <b>DCCH</b> |
|-----|------------|---------------------------|-------------|
| TFS | TF0, bits  | 0x336                     | 0x148       |
|     | TF1, bits  | 1x336                     | 1x148       |
|     | TF2, bits  | 2x336                     | N/A         |
|     | TF3, bits  | 4x336                     | N/A         |
|     | TF4, bits  | 8x336                     | N/A         |

Uplink TFCS:

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| UL_TFC0     | (TF0, TF0)         |
| UL_TFC1     | (TF1, TF0)         |
| UL_TFC2     | (TF2, TF0)         |
| UL_TFC3     | (TF3, TF0)         |
| UL_TFC4     | (TF4, TF0)         |
| UL_TFC5     | (TF0, TF1)         |
| UL_TFC6     | (TF1, TF1)         |
| UL_TFC7     | (TF2, TF1)         |
| UL_TFC8     | (TF3, TF1)         |
| UL_TFC9     | (TF4, TF1)         |

Downlink TFS:

|     | <b>TFI</b> | <b>RB5<br/>(128 kbps)</b> | <b>DCCH</b> |
|-----|------------|---------------------------|-------------|
| TFS | TF0, bits  | 0x336                     | 0x148       |
|     | TF1, bits  | 1x336                     | 1x148       |
|     | TF2, bits  | 2x336                     | N/A         |
|     | TF3, bits  | 4x336                     | N/A         |
|     | TF4, bits  | 8x336                     | N/A         |

Downlink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| DL_TFC0 | (TF0, TF0)  |
| DL_TFC1 | (TF1, TF0)  |
| DL_TFC2 | (TF2, TF0)  |
| DL_TFC3 | (TF3, TF0)  |
| DL_TFC4 | (TF4, TF0)  |
| DL_TFC5 | (TF0, TF1)  |
| DL_TFC6 | (TF1, TF1)  |
| DL_TFC7 | (TF2, TF1)  |
| DL_TFC8 | (TF3, TF1)  |
| DL_TFC9 | (TF4, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCS Under test | Uplink TFCS Under test | Implicitely tested                 | Restricted UL-TFCIs                | UL RLC SDU size (bits) (note) | Test data size (bits) (note) |
|----------|--------------------------|------------------------|------------------------------------|------------------------------------|-------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 312                      | RB5: 312                     |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 632                      | RB5: 632                     |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 1272                     | RB5: 1272                    |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 2552                     | RB5: 2552                    |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 14.2.28.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (4x336).
  - for sub-test 4: RB5/TF4 (8x336).
3. At step 15 the UE shall return
  - for sub-test 1 to 4: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

## 14.2.29 ~~Interactive or background / UL:64 DL:144 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH~~

### 14.2.29.1 ~~Conformance requirement~~

See 14.2.4.1.

### 14.2.29.2 ~~Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.29.

### 14.2.29.3 ~~Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x336            | 0x148 |
|     | TF1, bits | 1x336            | 1x148 |
|     | TF2, bits | 2x336            | N/A   |
|     | TF3, bits | 3x336            | N/A   |
|     | TF4, bits | 4x336            | N/A   |

Uplink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |

Downlink TFS:

|     | TFI       | RB5<br>(144 kbps) | DCCH  |
|-----|-----------|-------------------|-------|
| TFS | TF0, bits | 0x336             | 0x148 |
|     | TF1, bits | 1x336             | 1x148 |
|     | TF2, bits | 2x336             | N/A   |
|     | TF3, bits | 4x336             | N/A   |
|     | TF4, bits | 8x336             | N/A   |
|     | TF5, bits | 9x336             | N/A   |

Downlink TFCS:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC0  | (TF0, TF0)  |
| DL_TFC1  | (TF1, TF0)  |
| DL_TFC2  | (TF2, TF0)  |
| DL_TFC3  | (TF3, TF0)  |
| DL_TFC4  | (TF4, TF0)  |
| DL_TFC5  | (TF5, TF1)  |
| DL_TFC6  | (TF0, TF1)  |
| DL_TFC7  | (TF1, TF1)  |
| DL_TFC8  | (TF2, TF1)  |
| DL_TFC9  | (TF3, TF1)  |
| DL_TFC10 | (TF4, TF1)  |
| DL_TFC11 | (TF5, TF1)  |

Sub-tests:

| Sub-test                                                                              | Downlink TFCS Under test | Uplink TFCS Under test | Implicitely tested                 | Restricted UL TFCIs                | UL RLC SDU-size (bits) (note) | Test data size (bits) (note) |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|------------------------------------|------------------------------------|-------------------------------|------------------------------|
| 1                                                                                     | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 312                      | RB5: 312                     |
| 2                                                                                     | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 632                      | RB5: 632                     |
| 3                                                                                     | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 1272                     | RB5: 1272                    |
| 4                                                                                     | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 2552                     | RB5: 2552                    |
| 5                                                                                     | DL_TFC5                  | UL_TFC3                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 2872                     | RB5: 2872                    |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                    |                                    |                               |                              |

See 14.1.1 for test procedure.

#### 14.2.29.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (4x336).
  - for sub-test 4: RB5/TF4 (8x336).
  - for sub-test 5: RB5/TF3 (4x336).



3. At step 15 the UE shall return

— for sub-test 1 to 5: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

### ~~14.2.30 Interactive or background / UL:144 DL:144 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH~~

#### ~~14.2.30.1 Conformance requirement~~

See 14.2.4.1.

#### ~~14.2.30.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.30.

#### ~~14.2.30.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(144 kbps) | DCCH  |
|-----|-----------|-------------------|-------|
| TFS | TF0, bits | 0x336             | 0x148 |
|     | TF1, bits | 1x336             | 1x148 |
|     | TF2, bits | 2x336             | N/A   |
|     | TF3, bits | 4x336             | N/A   |
|     | TF4, bits | 8x336             | N/A   |
|     | TF5, bits | 9x336             | N/A   |

Uplink TFCs:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| UL_TFC0  | (TF0, TF0)  |
| UL_TFC1  | (TF1, TF0)  |
| UL_TFC2  | (TF2, TF0)  |
| UL_TFC3  | (TF3, TF0)  |
| UL_TFC4  | (TF4, TF0)  |
| UL_TFC5  | (TF5, TF1)  |
| UL_TFC6  | (TF0, TF1)  |
| UL_TFC7  | (TF1, TF1)  |
| UL_TFC8  | (TF2, TF1)  |
| UL_TFC9  | (TF3, TF1)  |
| UL_TFC10 | (TF4, TF1)  |
| UL_TFC11 | (TF5, TF1)  |

Downlink TFS:

|     | TFI       | RB5<br>(144 kbps) | DCCH  |
|-----|-----------|-------------------|-------|
| TFS | TF0, bits | 0x336             | 0x148 |
|     | TF1, bits | 1x336             | 1x148 |
|     | TF2, bits | 2x336             | N/A   |
|     | TF3, bits | 4x336             | N/A   |
|     | TF4, bits | 8x336             | N/A   |
|     | TF5, bits | 9x336             | N/A   |

Downlink TFCS:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC0  | (TF0, TF0)  |
| DL_TFC1  | (TF1, TF0)  |
| DL_TFC2  | (TF2, TF0)  |
| DL_TFC3  | (TF3, TF0)  |
| DL_TFC4  | (TF4, TF0)  |
| DL_TFC5  | (TF5, TF1)  |
| DL_TFC6  | (TF0, TF1)  |
| DL_TFC7  | (TF1, TF1)  |
| DL_TFC8  | (TF2, TF1)  |
| DL_TFC9  | (TF3, TF1)  |
| DL_TFC10 | (TF4, TF1)  |
| DL_TFC11 | (TF5, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCS Under test | Uplink TFCS Under test | Implicitely tested                 | Restricted UL TFCIs                 | UL RLC SDU-size (bits) (note) | Test data size (bits) (note) |
|----------|--------------------------|------------------------|------------------------------------|-------------------------------------|-------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC1, UL_TFC6, UL_TFC7  | RB5: 312                      | RB5: 312                     |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC2, UL_TFC6, UL_TFC8  | RB5: 632                      | RB5: 632                     |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC3, UL_TFC6, UL_TFC9  | RB5: 1272                     | RB5: 1272                    |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC4, UL_TFC6, UL_TFC10 | RB5: 2552                     | RB5: 2552                    |
| 5        | DL_TFC5                  | UL_TFC5                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC5, UL_TFC6, UL_TFC11 | RB5: 2872                     | RB5: 2872                    |

NOTE:— See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 14.2.30.4 ——— Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

- for sub-test 1: RB5/TF1 (1x336).
- for sub-test 2: RB5/TF2 (2x336).
- for sub-test 3: RB5/TF3 (4x336).
- for sub-test 4: RB5/TF4 (8x336).
- for sub-test 5: RB5/TF5 (9x336).

3. At step 15 the UE shall return

— for sub-test 1 to 5: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

### ~~14.2.31 Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH~~

#### ~~14.2.31.1 Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH/ 10 ms TTI~~

##### ~~14.2.31.1.1 Conformance requirement~~

See 14.2.4.1.

##### ~~14.2.31.1.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.31 for the downlink 10 ms TTI case.

##### ~~14.2.31.1.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x336            | 0x148 |
|     | TF1, bits | 1x336            | 1x148 |
|     | TF2, bits | 2x336            | N/A   |
|     | TF3, bits | 3x336            | N/A   |
|     | TF4, bits | 4x336            | N/A   |

Uplink TFCs:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |

Downlink TFS:

|     | TFI       | RB5<br>(256 kbps, 10ms) | DCCH  |
|-----|-----------|-------------------------|-------|
| TFS | TF0, bits | 0x336                   | 0x148 |
|     | TF1, bits | 1x336                   | 1x148 |
|     | TF2, bits | 2x336                   | N/A   |
|     | TF3, bits | 4x336                   | N/A   |
|     | TF4, bits | 8x336                   | N/A   |

Downlink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| DL_TFC0 | (TF0, TF0)  |
| DL_TFC1 | (TF1, TF0)  |
| DL_TFC2 | (TF2, TF0)  |
| DL_TFC3 | (TF3, TF0)  |
| DL_TFC4 | (TF4, TF0)  |
| DL_TFC5 | (TF0, TF1)  |
| DL_TFC6 | (TF1, TF1)  |
| DL_TFC7 | (TF2, TF1)  |
| DL_TFC8 | (TF3, TF1)  |
| DL_TFC9 | (TF4, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCS Under test | Uplink TFCS Under test | Implicitely tested                 | Restricted UL TFCIs                | UL RLC SDU-size (bits) (note) | Test data size (bits) (note) |
|----------|--------------------------|------------------------|------------------------------------|------------------------------------|-------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 312                      | RB5: 312                     |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 632                      | RB5: 632                     |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 1272                     | RB5: 1272                    |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC5, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 2552                     | RB5: 2552                    |

NOTE: — See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 14.2.31.1.4 ——— Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (3x336).
  - for sub-test 4: RB5/TF4 (4x336).
3. At step 15 the UE shall return
  - for sub-test 1 to 4: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

~~14.2.31.2 — Interactive or background / UL:64 DL:256 kbps / PS RAB / 20 ms TTI~~~~14.2.31.2.1 — Conformance requirement~~~~See 14.2.4.1.~~~~14.2.31.2.2 — Test purpose~~~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.31 for the downlink 20 ms TTI case.~~~~14.2.31.2.3 — Method of test~~~~Uplink TFS:~~

|            | <b>TFI</b> | <b>RB5<br/>(64 kbps)</b> | <b>DCCH</b> |
|------------|------------|--------------------------|-------------|
| <b>TFS</b> | TF0, bits  | 0x336                    | 0x148       |
|            | TF1, bits  | 1x336                    | 1x148       |
|            | TF2, bits  | 2x336                    | N/A         |
|            | TF3, bits  | 3x336                    | N/A         |
|            | TF4, bits  | 4x336                    | N/A         |

~~Uplink TFCS:~~

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| UL_TFC0     | (TF0, TF0)         |
| UL_TFC1     | (TF1, TF0)         |
| UL_TFC2     | (TF2, TF0)         |
| UL_TFC3     | (TF3, TF0)         |
| UL_TFC4     | (TF4, TF0)         |
| UL_TFC5     | (TF0, TF1)         |
| UL_TFC6     | (TF1, TF1)         |
| UL_TFC7     | (TF2, TF1)         |
| UL_TFC8     | (TF3, TF1)         |
| UL_TFC9     | (TF4, TF1)         |

~~Downlink TFS:~~

|            | <b>TFI</b> | <b>RB5<br/>(256 kbps, 20ms)</b> | <b>DCCH</b> |
|------------|------------|---------------------------------|-------------|
| <b>TFS</b> | TF0, bits  | 0x336                           | 0x148       |
|            | TF1, bits  | 1x336                           | 1x148       |
|            | TF2, bits  | 2x336                           | N/A         |
|            | TF3, bits  | 4x336                           | N/A         |
|            | TF4, bits  | 8x336                           | N/A         |
|            | TF5, bits  | 12x336                          | N/A         |
|            | TF6, bits  | 16x336                          | N/A         |

Downlink TFCS:

| TFCS     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC0  | (TF0, TF0)  |
| DL_TFC1  | (TF1, TF0)  |
| DL_TFC2  | (TF2, TF0)  |
| DL_TFC3  | (TF3, TF0)  |
| DL_TFC4  | (TF4, TF0)  |
| DL_TFC5  | (TF5, TF0)  |
| DL_TFC6  | (TF6, TF0)  |
| DL_TFC7  | (TF0, TF1)  |
| DL_TFC8  | (TF1, TF1)  |
| DL_TFC9  | (TF2, TF1)  |
| DL_TFC10 | (TF3, TF1)  |
| DL_TFC11 | (TF4, TF1)  |
| DL_TFC12 | (TF5, TF1)  |
| DL_TFC13 | (TF6, TF1)  |

Sub-tests:

| Sub-test                                                                              | Downlink TFCS Under test | Uplink TFCS Under test | Implicitely tested                 | Restricted UL TFCSs                | UL RLC SDU-size (bits) (note) | Test data size (bits) (note) |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|------------------------------------|------------------------------------|-------------------------------|------------------------------|
| 1                                                                                     | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC7, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 312                      | RB5: 312                     |
| 2                                                                                     | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC7, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 632                      | RB5: 632                     |
| 3                                                                                     | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC7, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 1272                     | RB5: 1272                    |
| 4                                                                                     | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC7, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 2552                     | RB5: 2552                    |
| 5                                                                                     | DL_TFC5                  | UL_TFC4                | DL_TFC0, DL_TFC7, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 3832                     | RB5: 3832                    |
| 6                                                                                     | DL_TFC6                  | UL_TFC4                | DL_TFC0, DL_TFC7, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 5112                     | RB5: 5112                    |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                    |                                    |                               |                              |

See 14.1.1 for test procedure.

#### 14.2.31.2.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

— for sub-test 1: RB5/TF1 (1x336).

— for sub-test 2: RB5/TF2 (2x336).

— for sub-test 3: RB5/TF3 (3x336).

— for sub-test 4 to 6: RB5/TF4 (4x336).

3. At step 15 the UE shall return

— for sub-test 1 to 6: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

## ~~14.2.32 Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH~~

### ~~14.2.32.1 Interactive or background / UL:64 DL:384 kbps / PS RAB / 10 ms TTI~~

#### ~~14.2.32.1.1 Conformance requirement~~

See 14.2.4.1.

#### ~~14.2.32.1.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.32 for the 10 ms TTI case.

#### ~~14.2.32.1.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x336            | 0x148 |
|     | TF1, bits | 1x336            | 1x148 |
|     | TF2, bits | 2x336            | N/A   |
|     | TF3, bits | 3x336            | N/A   |
|     | TF4, bits | 4x336            | N/A   |

Uplink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |

Downlink TFS:

|     | TFI       | RB5<br>(384 kbps, 10ms) | DCCH  |
|-----|-----------|-------------------------|-------|
| TFS | TF0, bits | 0x336                   | 0x148 |
|     | TF1, bits | 1x336                   | 1x148 |
|     | TF2, bits | 2x336                   | N/A   |
|     | TF3, bits | 4x336                   | N/A   |
|     | TF4, bits | 8x336                   | N/A   |
|     | TF5, bits | 12x336                  | N/A   |

Downlink TFCS:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC0  | (TF0, TF0)  |
| DL_TFC1  | (TF1, TF0)  |
| DL_TFC2  | (TF2, TF0)  |
| DL_TFC3  | (TF3, TF0)  |
| DL_TFC4  | (TF4, TF0)  |
| DL_TFC5  | (TF5, TF0)  |
| DL_TFC6  | (TF0, TF1)  |
| DL_TFC7  | (TF1, TF1)  |
| DL_TFC8  | (TF2, TF1)  |
| DL_TFC9  | (TF3, TF1)  |
| DL_TFC10 | (TF4, TF1)  |
| DL_TFC11 | (TF5, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCS Under test | Uplink TFCS Under test | Implicitely tested                 | Restricted UL TFCIs                | UL RLC SDU-size (bits) (note) | Test data size (bits) (note) |
|----------|--------------------------|------------------------|------------------------------------|------------------------------------|-------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 312                      | RB5: 312                     |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 632                      | RB5: 632                     |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 1272                     | RB5: 1272                    |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 2552                     | RB5: 2552                    |
| 5        | DL_TFC5                  | UL_TFC4                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 3832                     | RB5: 3832                    |

NOTE:— See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 14.2.32.1.4 ——— Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (3x336).
  - for sub-test 4 and 5: RB5/TF4 (4x336).
3. At step 15 the UE shall return
  - for sub-test 1 to 5: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.



~~14.2.32.2 — Interactive or background / UL:64 DL:384 kbps / PS RAB / 20 ms TTI~~~~14.2.32.2.1 — Conformance requirement~~~~See 14.2.4.1.~~~~14.2.32.2.2 — Test purpose~~~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.32 for the 20 ms TTI case.~~~~14.2.32.2.3 — Method of test~~~~Uplink TFS:~~

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x336            | 0x148 |
|     | TF1, bits | 1x336            | 1x148 |
|     | TF2, bits | 2x336            | N/A   |
|     | TF3, bits | 3x336            | N/A   |
|     | TF4, bits | 4x336            | N/A   |

~~Uplink TFCS:~~

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |

~~Downlink TFS:~~

|     | TFI       | RB5<br>(384 kbps, 20ms) | DCCH  |
|-----|-----------|-------------------------|-------|
| TFS | TF0, bits | 0x336                   | 0x148 |
|     | TF1, bits | 1x336                   | 1x148 |
|     | TF2, bits | 2x336                   | N/A   |
|     | TF3, bits | 4x336                   | N/A   |
|     | TF4, bits | 8x336                   | N/A   |
|     | TF5, bits | 12x336                  | N/A   |
|     | TF6, bits | 16x336                  | N/A   |
|     | TF7, bits | 20x336                  | N/A   |
|     | TF8, bits | 24x336                  | N/A   |

## Downlink TFCS:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC0  | (TF0, TF0)  |
| DL_TFC1  | (TF1, TF0)  |
| DL_TFC2  | (TF2, TF0)  |
| DL_TFC3  | (TF3, TF0)  |
| DL_TFC4  | (TF4, TF0)  |
| DL_TFC5  | (TF5, TF0)  |
| DL_TFC6  | (TF6, TF0)  |
| DL_TFC7  | (TF7, TF0)  |
| DL_TFC8  | (TF8, TF0)  |
| DL_TFC9  | (TF0, TF1)  |
| DL_TFC10 | (TF1, TF1)  |
| DL_TFC11 | (TF2, TF1)  |
| DL_TFC12 | (TF3, TF1)  |
| DL_TFC13 | (TF4, TF1)  |
| DL_TFC14 | (TF5, TF1)  |
| DL_TFC15 | (TF6, TF1)  |
| DL_TFC16 | (TF7, TF1)  |
| DL_TFC17 | (TF8, TF1)  |

## Sub-tests:

| Sub-test | Downlink TFCS Under test | Uplink TFCS Under test | Implicitly-tested                    | Restricted UL-TFCIs                | UL-RLC SDU-size (bits) (note) | Test data size (bits) (note) |
|----------|--------------------------|------------------------|--------------------------------------|------------------------------------|-------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC9, UL_TFC0, UL_TFC5   | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 312                      | RB5: 312                     |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC9, UL_TFC0, UL_TFC5   | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 632                      | RB5: 632                     |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC9, UL_TFC0, UL_TFC5   | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 1272                     | RB5: 1272                    |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC9, UL_TFC0, UL_TFC5   | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 2552                     | RB5: 2552                    |
| 5        | DL_TFC5                  | UL_TFC4                | DL_TFC0, DL_TFC9, UL_TFC0, UL_TFC5   | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 3832                     | RB5: 3832                    |
| 6        | DL_TFC6                  | UL_TFC4                | DL_TFC0, DL_TFC9, UL_TFC0, UL_TFC5   | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 5112                     | RB5: 5112                    |
| 7        | DL_TFC7                  | UL_TFC4                | DL_TFC0, DL_TFC9, , UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 6392                     | RB5: 6392                    |
| 8        | DL_TFC8                  | UL_TFC4                | DL_TFC0, DL_TFC9, UL_TFC0, UL_TFC5   | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 7672                     | RB5: 7672                    |

NOTE: — See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

~~14.2.32.2.4 Test requirements~~

See 14.1.1 for definition of step 10 and step 15.

- ~~1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.~~
- ~~2. At step 15 the UE transmitted transport format shall be~~
  - ~~— for sub-test 1: RB5/TF1 (1x336).~~
  - ~~— for sub-test 2: RB5/TF2 (2x336).~~
  - ~~— for sub-test 3: RB5/TF3 (3x336).~~
  - ~~— for sub-test 4 to 8: RB5/TF4 (4x336).~~
- ~~3. At step 15 the UE shall return~~
  - ~~— for sub-test 1 to 8: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.~~

~~14.2.33 Interactive or background / UL:128 DL:384 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH~~~~14.2.33.1 Interactive or background / UL:128 DL:384 kbps / PS RAB / 10 ms TTI~~~~14.2.33.1.1 Conformance requirement~~

See 14.2.4.1.

~~14.2.33.1.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.33 for the 10 ms TTI case.

~~14.2.33.1.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(128 kbps) | DCCH  |
|-----|-----------|-------------------|-------|
| TFS | TF0, bits | 0x336             | 0x148 |
|     | TF1, bits | 1x336             | 1x148 |
|     | TF2, bits | 2x336             | N/A   |
|     | TF3, bits | 4x336             | N/A   |
|     | TF4, bits | 8x336             | N/A   |

Uplink TFCs:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |

## Downlink TFS:

|            | <b>TFI</b> | <b>RB5<br/>(384 kbps, 10ms)</b> | <b>DCCH</b> |
|------------|------------|---------------------------------|-------------|
| <b>TFS</b> | TF0, bits  | 0x336                           | 0x148       |
|            | TF1, bits  | 1x336                           | 1x148       |
|            | TF2, bits  | 2x336                           | N/A         |
|            | TF3, bits  | 4x336                           | N/A         |
|            | TF4, bits  | 8x336                           | N/A         |
|            | TF5, bits  | 12x336                          | N/A         |

## Downlink TFCs:

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| DL_TFC0     | (TF0, TF0)         |
| DL_TFC1     | (TF1, TF0)         |
| DL_TFC2     | (TF2, TF0)         |
| DL_TFC3     | (TF3, TF0)         |
| DL_TFC4     | (TF4, TF0)         |
| DL_TFC5     | (TF5, TF0)         |
| DL_TFC6     | (TF0, TF1)         |
| DL_TFC7     | (TF1, TF1)         |
| DL_TFC8     | (TF2, TF1)         |
| DL_TFC9     | (TF3, TF1)         |
| DL_TFC10    | (TF4, TF1)         |
| DL_TFC11    | (TF5, TF1)         |

## Sub-tests:

| <b>Sub-test</b> | <b>Downlink TFCs Under test</b> | <b>Uplink TFCs Under test</b> | <b>Implicitely tested</b>          | <b>Restricted UL TFCIs</b>         | <b>UL RLC SDU-size (bits) (note)</b> | <b>Test data size (bits) (note)</b> |
|-----------------|---------------------------------|-------------------------------|------------------------------------|------------------------------------|--------------------------------------|-------------------------------------|
| 1               | DL_TFC1                         | UL_TFC1                       | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 312                             | RB5: 312                            |
| 2               | DL_TFC2                         | UL_TFC2                       | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 632                             | RB5: 632                            |
| 3               | DL_TFC3                         | UL_TFC3                       | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 1272                            | RB5: 1272                           |
| 4               | DL_TFC4                         | UL_TFC4                       | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 2552                            | RB5: 2552                           |
| 5               | DL_TFC5                         | UL_TFC4                       | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 3832                            | RB5: 3832                           |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

## 14.2.33.1.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be
- for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (4x336).
  - for sub-test 4 and 5: RB5/TF4 (8x336).
3. At step 15 the UE shall return
- for sub-test 1 to 5: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

~~14.2.33.2 Interactive or background / UL:128 DL:384 kbps / PS RAB / 20 ms TTI~~

~~14.2.33.2.1 Conformance requirement~~

See 14.2.4.1.

~~14.2.33.2.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.33 for the 20 ms TTI case.

~~14.2.33.2.3 Method of test~~

Uplink-TFS:

|     | TFI       | RB5<br>(128 kbps) | DCCH  |
|-----|-----------|-------------------|-------|
| TFS | TF0, bits | 0x336             | 0x148 |
|     | TF1, bits | 1x336             | 1x148 |
|     | TF2, bits | 2x336             | N/A   |
|     | TF3, bits | 4x336             | N/A   |
|     | TF4, bits | 8x336             | N/A   |

Uplink-TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |

Downlink TFS:

|     | TFI       | RB5<br>(384 kbps, 20ms) | DCCH  |
|-----|-----------|-------------------------|-------|
| TFS | TF0, bits | 0x336                   | 0x148 |
|     | TF1, bits | 1x336                   | 1x148 |
|     | TF2, bits | 2x336                   | N/A   |
|     | TF3, bits | 4x336                   | N/A   |
|     | TF4, bits | 8x336                   | N/A   |
|     | TF5, bits | 12x336                  | N/A   |
|     | TF6, bits | 16x336                  | N/A   |
|     | TF7, bits | 20x336                  | N/A   |
|     | TF8, bits | 24x336                  | N/A   |

Downlink TFCS:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC0  | (TF0, TF0)  |
| DL_TFC1  | (TF1, TF0)  |
| DL_TFC2  | (TF2, TF0)  |
| DL_TFC3  | (TF3, TF0)  |
| DL_TFC4  | (TF4, TF0)  |
| DL_TFC5  | (TF5, TF0)  |
| DL_TFC6  | (TF6, TF0)  |
| DL_TFC7  | (TF7, TF0)  |
| DL_TFC8  | (TF8, TF0)  |
| DL_TFC9  | (TF0, TF1)  |
| DL_TFC10 | (TF1, TF1)  |
| DL_TFC11 | (TF2, TF1)  |
| DL_TFC12 | (TF3, TF1)  |
| DL_TFC13 | (TF4, TF1)  |
| DL_TFC14 | (TF5, TF1)  |
| DL_TFC15 | (TF6, TF1)  |
| DL_TFC16 | (TF7, TF1)  |
| DL_TFC17 | (TF8, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCs Under test | Uplink TFCs Under test | Implicitely tested                  | Restricted UL TFCIs                | UL RLC SDU size (bits) (note) | Test data size (bits) (note) |
|----------|--------------------------|------------------------|-------------------------------------|------------------------------------|-------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC9, UL_TFC0, UL_TFC5  | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 312                      | RB5: 312                     |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC9, UL_TFC0, UL_TFC5  | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 632                      | RB5: 632                     |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC9, UL_TFC0, UL_TFC5  | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 1272                     | RB5: 1272                    |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC9, UL_TFC0, UL_TFC5  | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 2552                     | RB5: 2552                    |
| 5        | DL_TFC5                  | UL_TFC4                | DL_TFC0, DL_TFC9, UL_TFC0, UL_TFC5, | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 3832                     | RB5: 3832                    |
| 6        | DL_TFC6                  | UL_TFC4                | DL_TFC0, DL_TFC9, UL_TFC0, UL_TFC5  | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 5112                     | RB5: 5112                    |
| 7        | DL_TFC7                  | UL_TFC4                | DL_TFC0, DL_TFC9, UL_TFC0, UL_TFC5  | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 6392                     | RB5: 6392                    |
| 8        | DL_TFC8                  | UL_TFC4                | DL_TFC0, DL_TFC9, UL_TFC0, UL_TFC5  | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 7672                     | RB5: 7672                    |

NOTE: — See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 14.2.33.2.4 — Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (4x336).
  - for sub-test 4 to 8: RB5/TF4 (8x336).
3. At step 15 the UE shall return
  - for sub-test 1 to 8: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

## ~~14.2.34 Interactive or background / UL:384 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

### ~~14.2.34.1 Interactive or background / UL:384 DL:384 kbps / PS RAB / 10 ms TTI~~

#### ~~14.2.34.1.1 Conformance requirement~~

See 14.2.4.1.

#### ~~14.2.34.1.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.34 for the 10 ms TTI case.

#### ~~14.2.34.1.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(384 kbps, 10ms) | DCCH  |
|-----|-----------|-------------------------|-------|
| TFS | TF0, bits | 0x336                   | 0x148 |
|     | TF1, bits | 1x336                   | 1x148 |
|     | TF2, bits | 2x336                   | N/A   |
|     | TF3, bits | 4x336                   | N/A   |
|     | TF4, bits | 8x336                   | N/A   |
|     | TF5, bits | 12x336                  | N/A   |

Uplink TFCs:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| UL_TFC0  | (TF0, TF0)  |
| UL_TFC1  | (TF1, TF0)  |
| UL_TFC2  | (TF2, TF0)  |
| UL_TFC3  | (TF3, TF0)  |
| UL_TFC4  | (TF4, TF0)  |
| UL_TFC5  | (TF5, TF0)  |
| UL_TFC6  | (TF0, TF1)  |
| UL_TFC7  | (TF1, TF1)  |
| UL_TFC8  | (TF2, TF1)  |
| UL_TFC9  | (TF3, TF1)  |
| UL_TFC10 | (TF4, TF1)  |
| UL_TFC11 | (TF5, TF1)  |

Downlink TFS:

|     | TFI       | RB5<br>(384 kbps, 10ms) | DCCH  |
|-----|-----------|-------------------------|-------|
| TFS | TF0, bits | 0x336                   | 0x148 |
|     | TF1, bits | 1x336                   | 1x148 |
|     | TF2, bits | 2x336                   | N/A   |
|     | TF3, bits | 4x336                   | N/A   |
|     | TF4, bits | 8x336                   | N/A   |
|     | TF5, bits | 12x336                  | N/A   |



Downlink TFCS:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC0  | (TF0, TF0)  |
| DL_TFC1  | (TF1, TF0)  |
| DL_TFC2  | (TF2, TF0)  |
| DL_TFC3  | (TF3, TF0)  |
| DL_TFC4  | (TF4, TF0)  |
| DL_TFC5  | (TF5, TF0)  |
| DL_TFC6  | (TF0, TF1)  |
| DL_TFC7  | (TF1, TF1)  |
| DL_TFC8  | (TF2, TF1)  |
| DL_TFC9  | (TF3, TF1)  |
| DL_TFC10 | (TF4, TF1)  |
| DL_TFC11 | (TF5, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCS Under test | Uplink TFCS Under test | Implicitely tested                 | Restricted UL TFCIs                 | UL RLC SDU-size (bits) (note) | Test data size (bits) (note) |
|----------|--------------------------|------------------------|------------------------------------|-------------------------------------|-------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC7, UL_TFC0, UL_TFC7 | UL_TFC0, UL_TFC1, UL_TFC7, UL_TFC8  | RB5: 312                      | RB5: 312                     |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC7, UL_TFC0, UL_TFC7 | UL_TFC0, UL_TFC2, UL_TFC7, UL_TFC9  | RB5: 632                      | RB5: 632                     |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC7, UL_TFC0, UL_TFC7 | UL_TFC0, UL_TFC3, UL_TFC7, UL_TFC10 | RB5: 1272                     | RB5: 1272                    |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC7, UL_TFC0, UL_TFC7 | UL_TFC0, UL_TFC4, UL_TFC7, UL_TFC11 | RB5: 2552                     | RB5: 2552                    |
| 5        | DL_TFC5                  | UL_TFC5                | DL_TFC0, DL_TFC7, UL_TFC0, UL_TFC7 | UL_TFC0, UL_TFC5, UL_TFC7, UL_TFC12 | RB5: 3832                     | RB5: 3832                    |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 14.2.34.1.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

- for sub-test 1: RB5/TF1 (1x336).
- for sub-test 2: RB5/TF2 (2x336).
- for sub-test 3: RB5/TF3 (4x336).
- for sub-test 4: RB5/TF4 (8x336).
- for sub-test 5: RB5/TF4 (12x336).

3. At step 15 the UE shall return

— for sub-test 1 to 5: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

#### ~~14.2.34.2 Interactive or background / UL:384 DL:384 kbps / PS RAB / 20 ms TTI~~

##### ~~14.2.34.2.1 Conformance requirement~~

See 14.2.4.1.

##### ~~14.2.34.2.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.34. for the 20 ms TTI case

##### ~~14.2.34.2.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(384 kbps, 20ms) | DCCH  |
|-----|-----------|-------------------------|-------|
| TFS | TF0, bits | 0x336                   | 0x148 |
|     | TF1, bits | 1x336                   | 1x148 |
|     | TF2, bits | 2x336                   | N/A   |
|     | TF3, bits | 4x336                   | N/A   |
|     | TF4, bits | 8x336                   | N/A   |
|     | TF5, bits | 12x336                  | N/A   |
|     | TF6, bits | 16x336                  | N/A   |
|     | TF7, bits | 20x336                  | N/A   |
|     | TF8, bits | 24x336                  | N/A   |

Uplink TFCS:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| UL_TFC0  | (TF0, TF0)  |
| UL_TFC1  | (TF1, TF0)  |
| UL_TFC2  | (TF2, TF0)  |
| UL_TFC3  | (TF3, TF0)  |
| UL_TFC4  | (TF4, TF0)  |
| UL_TFC5  | (TF5, TF0)  |
| UL_TFC6  | (TF6, TF0)  |
| UL_TFC7  | (TF7, TF0)  |
| UL_TFC8  | (TF8, TF0)  |
| UL_TFC9  | (TF0, TF1)  |
| UL_TFC10 | (TF1, TF1)  |
| UL_TFC11 | (TF2, TF1)  |
| UL_TFC12 | (TF3, TF1)  |
| UL_TFC13 | (TF4, TF1)  |
| UL_TFC14 | (TF5, TF1)  |
| UL_TFC15 | (TF6, TF1)  |
| UL_TFC16 | (TF7, TF1)  |
| UL_TFC17 | (TF8, TF1)  |

## Downlink TFS:

|     | TFI       | RB5<br>(384 kbps, 20ms) | DCCH  |
|-----|-----------|-------------------------|-------|
| TFS | TF0, bits | 0x336                   | 0x148 |
|     | TF1, bits | 1x336                   | 1x148 |
|     | TF2, bits | 2x336                   | N/A   |
|     | TF3, bits | 4x336                   | N/A   |
|     | TF4, bits | 8x336                   | N/A   |
|     | TF5, bits | 12x336                  | N/A   |
|     | TF6, bits | 16x336                  | N/A   |
|     | TF7, bits | 20x336                  | N/A   |
|     | TF8, bits | 24x336                  | N/A   |

## Downlink TFCs:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC0  | (TF0, TF0)  |
| DL_TFC1  | (TF1, TF0)  |
| DL_TFC2  | (TF2, TF0)  |
| DL_TFC3  | (TF3, TF0)  |
| DL_TFC4  | (TF4, TF0)  |
| DL_TFC5  | (TF5, TF0)  |
| DL_TFC6  | (TF6, TF0)  |
| DL_TFC7  | (TF7, TF0)  |
| DL_TFC8  | (TF8, TF0)  |
| DL_TFC9  | (TF0, TF1)  |
| DL_TFC10 | (TF1, TF1)  |
| DL_TFC11 | (TF2, TF1)  |
| DL_TFC12 | (TF3, TF1)  |
| DL_TFC13 | (TF4, TF1)  |
| DL_TFC14 | (TF5, TF1)  |
| DL_TFC15 | (TF6, TF1)  |
| DL_TFC16 | (TF7, TF1)  |
| DL_TFC17 | (TF8, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCs Under test | Uplink TFCs Under test | Implicitely tested                    | Restricted UL TFCIs                          | UL RLC SDU size (bits) (note) | Test data size (bits) (note) |
|----------|--------------------------|------------------------|---------------------------------------|----------------------------------------------|-------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC9,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC9,<br>UL_TFC10 | RB5: 312                      | RB5: 312                     |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC9,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC9,<br>UL_TFC11 | RB5: 632                      | RB5: 632                     |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC9,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC9,<br>UL_TFC12 | RB5: 1272                     | RB5: 1272                    |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC9,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC9,<br>UL_TFC13 | RB5: 2552                     | RB5: 2552                    |
| 5        | DL_TFC5                  | UL_TFC5                | DL_TFC0, DL_TFC9,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC9,<br>UL_TFC14 | RB5: 3832                     | RB5: 3832                    |
| 6        | DL_TFC6                  | UL_TFC6                | DL_TFC0, DL_TFC9,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC9,<br>UL_TFC15 | RB5: 5112                     | RB5: 5112                    |
| 7        | DL_TFC7                  | UL_TFC7                | DL_TFC0, DL_TFC9,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC9,<br>UL_TFC16 | RB5: 6392                     | RB5: 6392                    |
| 8        | DL_TFC8                  | UL_TFC8                | DL_TFC0, DL_TFC9,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC9,<br>UL_TFC17 | RB5: 7672                     | RB5: 7672                    |

NOTE: — See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 14.2.34.2.4 ——— Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

- for sub-test 1: RB5/TF1 (1x336).
- for sub-test 2: RB5/TF2 (2x336).
- for sub-test 3: RB5/TF3 (4x336).
- for sub-test 4: RB5/TF4 (8x336).
- for sub-test 5: RB5/TF5 (12x336).
- for sub-test 6: RB5/TF6 (16x336).
- for sub-test 7: RB5/TF7 (20x336).
- for sub-test 8: RB5/TF8 (24x336).

3. At step 15 the UE shall return

— for sub-test 1 to 8: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

### ~~14.2.35 Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

#### ~~14.2.35.1 Interactive or background / UL:64 DL:2048 kbps / PS RAB / 10 ms TTI~~

##### ~~14.2.35.1.1 Conformance requirement~~

See 14.2.4.1.

##### ~~14.2.35.1.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.35 for the 10 ms TTI case.

##### ~~14.2.35.1.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x336            | 0x148 |
|     | TF1, bits | 1x336            | 1x148 |
|     | TF2, bits | 2x336            | N/A   |
|     | TF3, bits | 3x336            | N/A   |
|     | TF4, bits | 4x336            | N/A   |

Uplink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |

## Downlink TFS:

|     | TFI        | RB5<br>(2048-kbps,<br>10ms) | DCCH  |
|-----|------------|-----------------------------|-------|
| TFS | TF0, bits  | 0x656                       | 0x148 |
|     | TF1, bits  | 1x656                       | 1x148 |
|     | TF2, bits  | 2x656                       | N/A   |
|     | TF3, bits  | 4x656                       | N/A   |
|     | TF4, bits  | 8x656                       | N/A   |
|     | TF5, bits  | 12x656                      | N/A   |
|     | TF6, bits  | 16x656                      | N/A   |
|     | TF7, bits  | 20x656                      | N/A   |
|     | TF8, bits  | 24x656                      | N/A   |
|     | TF9, bits  | 28x656                      | N/A   |
|     | TF10, bits | 32x656                      | N/A   |

## Downlink TFCs:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC0  | (TF0, TF0)  |
| DL_TFC1  | (TF1, TF0)  |
| DL_TFC2  | (TF2, TF0)  |
| DL_TFC3  | (TF3, TF0)  |
| DL_TFC4  | (TF4, TF0)  |
| DL_TFC5  | (TF5, TF0)  |
| DL_TFC6  | (TF6, TF0)  |
| DL_TFC7  | (TF7, TF0)  |
| DL_TFC8  | (TF8, TF0)  |
| DL_TFC9  | (TF9, TF0)  |
| DL_TFC10 | (TF10, TF0) |
| DL_TFC11 | (TF0, TF1)  |
| DL_TFC12 | (TF1, TF1)  |
| DL_TFC13 | (TF2, TF1)  |
| DL_TFC14 | (TF3, TF1)  |
| DL_TFC15 | (TF4, TF1)  |
| DL_TFC16 | (TF5, TF1)  |
| DL_TFC17 | (TF6, TF1)  |
| DL_TFC18 | (TF7, TF1)  |
| DL_TFC19 | (TF8, TF1)  |
| DL_TFC20 | (TF9, TF1)  |
| DL_TFC21 | (TF10, TF1) |

Sub-tests:

| Sub-test | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                  | Restricted UL TFCIs                | UL RLC SDU-size (bits) | Test data size (bits) |
|----------|--------------------------|------------------------|-------------------------------------|------------------------------------|------------------------|-----------------------|
|          |                          |                        |                                     |                                    | (note)                 | (note)                |
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 632               | RB5: 632              |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 1272              | RB5: 1272             |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 2552              | RB5: 2552             |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 5112              | RB5: 5112             |
| 5        | DL_TFC5                  | UL_TFC4                | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 7672              | RB5: 7672             |
| 6        | DL_TFC6                  | UL_TFC4                | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 10232             | RB5: 10232            |
| 7        | DL_TFC7                  | UL_TFC4                | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 12792             | RB5: 12792            |
| 8        | DL_TFC8                  | UL_TFC4                | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 15352             | RB5: 15352            |
| 9        | DL_TFC9                  | UL_TFC4                | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 17912             | RB5: 17912            |
| 10       | DL_TFC10                 | UL_TFC4                | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 20472             | RB5: 20472            |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

**14.2.35.1.4 Test requirements**

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (3x336).
  - for sub-test 4 to 10: RB5/TF4 (4x336).

3. At step 15 the UE shall return

— for sub-test 1 to 10: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

### ~~14.2.35.2 Interactive or background / UL:64 DL:2048 kbps / PS RAB / 20 ms TTI~~

#### ~~14.2.35.2.1 Conformance requirement~~

See 14.2.4.1.

#### ~~14.2.35.2.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.35 for the 20 ms TTI case.

#### ~~14.2.35.2.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x336            | 0x148 |
|     | TF1, bits | 1x336            | 1x148 |
|     | TF2, bits | 2x336            | N/A   |
|     | TF3, bits | 3x336            | N/A   |
|     | TF4, bits | 4x336            | N/A   |

Uplink TFCs:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |



## Downlink TFS:

|     | TFI        | RB5<br>(2048 kbps,<br>10ms) | DCCH  |
|-----|------------|-----------------------------|-------|
| TFS | TF0, bits  | 0x656                       | 0x148 |
|     | TF1, bits  | 1x656                       | 1x148 |
|     | TF2, bits  | 2x656                       | N/A   |
|     | TF3, bits  | 4x656                       | N/A   |
|     | TF4, bits  | 8x656                       | N/A   |
|     | TF5, bits  | 12x656                      | N/A   |
|     | TF6, bits  | 16x656                      | N/A   |
|     | TF7, bits  | 20x656                      | N/A   |
|     | TF8, bits  | 24x656                      | N/A   |
|     | TF9, bits  | 28x656                      | N/A   |
|     | TF10, bits | 32x656                      | N/A   |
|     | TF11, bits | 36x656                      | N/A   |
|     | TF12, bits | 40x656                      | N/A   |
|     | TF13, bits | 44x656                      | N/A   |
|     | TF14, bits | 48x656                      | N/A   |
|     | TF15, bits | 52x656                      | N/A   |
|     | TF16, bits | 56x656                      | N/A   |
|     | TF17, bits | 60x656                      | N/A   |
|     | TF18, bits | 64x656                      | N/A   |

## Downlink TFCs:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC0  | (TF0, TF0)  |
| DL_TFC1  | (TF1, TF0)  |
| DL_TFC2  | (TF2, TF0)  |
| DL_TFC3  | (TF3, TF0)  |
| DL_TFC4  | (TF4, TF0)  |
| DL_TFC5  | (TF5, TF0)  |
| DL_TFC6  | (TF6, TF0)  |
| DL_TFC7  | (TF7, TF0)  |
| DL_TFC8  | (TF8, TF0)  |
| DL_TFC9  | (TF9, TF0)  |
| DL_TFC10 | (TF10, TF0) |
| DL_TFC11 | (TF11, TF0) |
| DL_TFC12 | (TF12, TF0) |
| DL_TFC13 | (TF13, TF0) |
| DL_TFC14 | (TF14, TF0) |
| DL_TFC15 | (TF15, TF0) |
| DL_TFC16 | (TF16, TF0) |
| DL_TFC17 | (TF17, TF0) |
| DL_TFC18 | (TF18, TF0) |
| DL_TFC19 | (TF0, TF1)  |
| DL_TFC20 | (TF1, TF1)  |
| DL_TFC21 | (TF2, TF1)  |
| DL_TFC22 | (TF3, TF1)  |
| DL_TFC23 | (TF4, TF1)  |
| DL_TFC24 | (TF5, TF1)  |
| DL_TFC25 | (TF6, TF1)  |
| DL_TFC26 | (TF7, TF1)  |
| DL_TFC27 | (TF8, TF1)  |
| DL_TFC28 | (TF9, TF1)  |
| DL_TFC29 | (TF10, TF1) |
| DL_TFC30 | (TF11, TF1) |
| DL_TFC31 | (TF12, TF1) |
| DL_TFC32 | (TF13, TF1) |
| DL_TFC33 | (TF14, TF1) |
| DL_TFC34 | (TF15, TF1) |

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC35 | (TF16, TF1) |
| DL_TFC36 | (TF17, TF1) |
| DL_TFC37 | (TF18, TF1) |

Sub-tests:

| Sub-test | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                  | Restricted UL TFCIs                | UL RLC SDU-size (bits)<br>(note) | Test data size (bits)<br>(note) |
|----------|--------------------------|------------------------|-------------------------------------|------------------------------------|----------------------------------|---------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 632                         | RB5: 632                        |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 1272                        | RB5: 1272                       |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 2552                        | RB5: 2552                       |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 5112                        | RB5: 5112                       |
| 5        | DL_TFC5                  | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 7672                        | RB5: 7672                       |
| 6        | DL_TFC6                  | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 10232                       | RB5: 10232                      |
| 7        | DL_TFC7                  | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 12792                       | RB5: 12792                      |
| 8        | DL_TFC8                  | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 15352                       | RB5: 15352                      |
| 9        | DL_TFC9                  | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 17912                       | RB5: 17912                      |
| 10       | DL_TFC10                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 20472                       | RB5: 20472                      |
| 11       | DL_TFC11                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 23032                       | RB5: 23032                      |
| 12       | DL_TFC12                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 25592                       | RB5: 25592                      |
| 13       | DL_TFC13                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 28152                       | RB5: 28152                      |

| Sub-test                                                                              | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                  | Restricted UL TFCIs                | UL RLC SDU-size (bits)<br>(note) | Test data size (bits)<br>(note) |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|-------------------------------------|------------------------------------|----------------------------------|---------------------------------|
| 14                                                                                    | DL_TFC14                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 30712                       | RB5: 30712                      |
| 15                                                                                    | DL_TFC15                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 33272                       | RB5: 33272                      |
| 16                                                                                    | DL_TFC16                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 35832                       | RB5: 35832                      |
| 17                                                                                    | DL_TFC17                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 38392                       | RB5: 38392                      |
| 18                                                                                    | DL_TFC18                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 40952                       | RB5: 40952                      |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                     |                                    |                                  |                                 |

See 14.1.1 for test procedure.

#### 14.2.35.2.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (3x336).
  - for sub-test 4 to 18: RB5/TF4 (4x336).
3. At step 15 the UE shall return
  - for sub-test 1 to 18: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

#### 14.2.36 Interactive or background / UL:128 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

##### 14.2.36.1 Interactive or background / UL:128 DL:2048 kbps / PS RAB / 10 ms TTI

###### 14.2.36.1.1 Conformance requirement

See 14.2.4.1.

###### 14.2.36.1.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.36 for the 10 ms TTI case.

## 14.2.36.1.3 Method of test

Uplink TFS:

|     | TFI       | RB5<br>(128 kbps) | DCCH  |
|-----|-----------|-------------------|-------|
| TFS | TF0, bits | 0x336             | 0x148 |
|     | TF1, bits | 1x336             | 1x148 |
|     | TF2, bits | 2x336             | N/A   |
|     | TF3, bits | 4x336             | N/A   |
|     | TF4, bits | 8x336             | N/A   |

Uplink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |

Downlink TFS:

|     | TFI        | RB5<br>(2048 kbps,<br>10ms) | DCCH  |
|-----|------------|-----------------------------|-------|
| TFS | TF0, bits  | 0x656                       | 0x148 |
|     | TF1, bits  | 1x656                       | 1x148 |
|     | TF2, bits  | 2x656                       | N/A   |
|     | TF3, bits  | 4x656                       | N/A   |
|     | TF4, bits  | 8x656                       | N/A   |
|     | TF5, bits  | 12x656                      | N/A   |
|     | TF6, bits  | 16x656                      | N/A   |
|     | TF7, bits  | 20x656                      | N/A   |
|     | TF8, bits  | 24x656                      | N/A   |
|     | TF9, bits  | 28x656                      | N/A   |
|     | TF10, bits | 32x656                      | N/A   |

Downlink TFCS:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC0  | (TF0, TF0)  |
| DL_TFC1  | (TF1, TF0)  |
| DL_TFC2  | (TF2, TF0)  |
| DL_TFC3  | (TF3, TF0)  |
| DL_TFC4  | (TF4, TF0)  |
| DL_TFC5  | (TF5, TF0)  |
| DL_TFC6  | (TF6, TF0)  |
| DL_TFC7  | (TF7, TF0)  |
| DL_TFC8  | (TF8, TF0)  |
| DL_TFC9  | (TF9, TF0)  |
| DL_TFC10 | (TF10, TF0) |
| DL_TFC11 | (TF0, TF1)  |
| DL_TFC12 | (TF1, TF1)  |
| DL_TFC13 | (TF2, TF1)  |
| DL_TFC14 | (TF3, TF1)  |
| DL_TFC15 | (TF4, TF1)  |

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| DL_TFC16    | (TF5, TF1)         |
| DL_TFC17    | (TF6, TF1)         |
| DL_TFC18    | (TF7, TF1)         |
| DL_TFC19    | (TF8, TF1)         |
| DL_TFC20    | (TF9, TF1)         |
| DL_TFC21    | (TF10, TF1)        |

Sub-tests:

| <b>Sub-test</b>                                                                       | <b>Downlink TFCs Under Test</b> | <b>Uplink TFCs Under test</b> | <b>Implicitely tested</b>           | <b>Restricted UL TFCIs</b>         | <b>UL RLC SDU-size (bits)</b><br>(note) | <b>Test data size (bits)</b><br>(note) |
|---------------------------------------------------------------------------------------|---------------------------------|-------------------------------|-------------------------------------|------------------------------------|-----------------------------------------|----------------------------------------|
| 1                                                                                     | DL_TFC1                         | UL_TFC1                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 632                                | RB5: 632                               |
| 2                                                                                     | DL_TFC2                         | UL_TFC2                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 1272                               | RB5: 1272                              |
| 3                                                                                     | DL_TFC3                         | UL_TFC3                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 2552                               | RB5: 2552                              |
| 4                                                                                     | DL_TFC4                         | UL_TFC4                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 5112                               | RB5: 5112                              |
| 5                                                                                     | DL_TFC5                         | UL_TFC4                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 7672                               | RB5: 7672                              |
| 6                                                                                     | DL_TFC6                         | UL_TFC4                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 10232                              | RB5: 10232                             |
| 7                                                                                     | DL_TFC7                         | UL_TFC4                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 12792                              | RB5: 12792                             |
| 8                                                                                     | DL_TFC8                         | UL_TFC4                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 15352                              | RB5: 15352                             |
| 9                                                                                     | DL_TFC9                         | UL_TFC4                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 17912                              | RB5: 17912                             |
| 10                                                                                    | DL_TFC10                        | UL_TFC4                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 20472                              | RB5: 20472                             |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                                 |                               |                                     |                                    |                                         |                                        |

See 14.1.1 for test procedure.

#### 14.2.36.1.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

- At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

- 2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (4x336).
  - for sub-test 4 to 10: RB5/TF4 (8x336).
- 3. At step 15 the UE shall return
  - for sub-test 1 to 10: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

~~14.2.36.2~~ ~~Interactive or background / UL:128 kbps / PS-RAB / 20 ms TTI~~

~~14.2.36.2.1~~ ~~Conformance requirement~~

See 14.2.4.1.

~~14.2.36.2.2~~ ~~Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.36 for the 20 ms TTI case.

~~14.2.36.2.3~~ ~~Method of test~~

Uplink-TFS:

|     | TFI       | RB5<br>(128 kbps) | DCCH  |
|-----|-----------|-------------------|-------|
| TFS | TF0, bits | 0x336             | 0x148 |
|     | TF1, bits | 1x336             | 1x148 |
|     | TF2, bits | 2x336             | N/A   |
|     | TF3, bits | 4x336             | N/A   |
|     | TF4, bits | 8x336             | N/A   |

Uplink-TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |

## Downlink TFS:

|     | TFI        | RB5<br>(2048 kbps,<br>10ms) | DCCH  |
|-----|------------|-----------------------------|-------|
| TFS | TF0, bits  | 0x656                       | 0x148 |
|     | TF1, bits  | 1x656                       | 1x148 |
|     | TF2, bits  | 2x656                       | N/A   |
|     | TF3, bits  | 4x656                       | N/A   |
|     | TF4, bits  | 8x656                       | N/A   |
|     | TF5, bits  | 12x656                      | N/A   |
|     | TF6, bits  | 16x656                      | N/A   |
|     | TF7, bits  | 20x656                      | N/A   |
|     | TF8, bits  | 24x656                      | N/A   |
|     | TF9, bits  | 28x656                      | N/A   |
|     | TF10, bits | 32x656                      | N/A   |
|     | TF11, bits | 36x656                      | N/A   |
|     | TF12, bits | 40x656                      | N/A   |
|     | TF13, bits | 44x656                      | N/A   |
|     | TF14, bits | 48x656                      | N/A   |
|     | TF15, bits | 52x656                      | N/A   |
|     | TF16, bits | 56x656                      | N/A   |
|     | TF17, bits | 60x656                      | N/A   |
|     | TF18, bits | 64x656                      | N/A   |

## Downlink TFCs:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC0  | (TF0, TF0)  |
| DL_TFC1  | (TF1, TF0)  |
| DL_TFC2  | (TF2, TF0)  |
| DL_TFC3  | (TF3, TF0)  |
| DL_TFC4  | (TF4, TF0)  |
| DL_TFC5  | (TF5, TF0)  |
| DL_TFC6  | (TF6, TF0)  |
| DL_TFC7  | (TF7, TF0)  |
| DL_TFC8  | (TF8, TF0)  |
| DL_TFC9  | (TF9, TF0)  |
| DL_TFC10 | (TF10, TF0) |
| DL_TFC11 | (TF11, TF0) |
| DL_TFC12 | (TF12, TF0) |
| DL_TFC13 | (TF13, TF0) |
| DL_TFC14 | (TF14, TF0) |
| DL_TFC15 | (TF15, TF0) |
| DL_TFC16 | (TF16, TF0) |
| DL_TFC17 | (TF17, TF0) |
| DL_TFC18 | (TF18, TF0) |
| DL_TFC19 | (TF0, TF1)  |
| DL_TFC20 | (TF1, TF1)  |
| DL_TFC21 | (TF2, TF1)  |
| DL_TFC22 | (TF3, TF1)  |
| DL_TFC23 | (TF4, TF1)  |
| DL_TFC24 | (TF5, TF1)  |
| DL_TFC25 | (TF6, TF1)  |
| DL_TFC26 | (TF7, TF1)  |
| DL_TFC27 | (TF8, TF1)  |
| DL_TFC28 | (TF9, TF1)  |
| DL_TFC29 | (TF10, TF1) |
| DL_TFC30 | (TF11, TF1) |
| DL_TFC31 | (TF12, TF1) |
| DL_TFC32 | (TF13, TF1) |
| DL_TFC33 | (TF14, TF1) |
| DL_TFC34 | (TF15, TF1) |

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC35 | (TF16, TF1) |
| DL_TFC36 | (TF17, TF1) |
| DL_TFC37 | (TF18, TF1) |

Sub-tests:

| Sub-test | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                  | Restricted UL TFCIs                | UL RLC SDU-size (bits)<br>(note) | Test data size (bits)<br>(note) |
|----------|--------------------------|------------------------|-------------------------------------|------------------------------------|----------------------------------|---------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC1, UL_TFC5, UL_TFC6 | RB5: 632                         | RB5: 632                        |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC2, UL_TFC5, UL_TFC7 | RB5: 1272                        | RB5: 1272                       |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC3, UL_TFC5, UL_TFC8 | RB5: 2552                        | RB5: 2552                       |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 5112                        | RB5: 5112                       |
| 5        | DL_TFC5                  | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 7672                        | RB5: 7672                       |
| 6        | DL_TFC6                  | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 10232                       | RB5: 10232                      |
| 7        | DL_TFC7                  | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 12792                       | RB5: 12792                      |
| 8        | DL_TFC8                  | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 15352                       | RB5: 15352                      |
| 9        | DL_TFC9                  | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 17912                       | RB5: 17912                      |
| 10       | DL_TFC10                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 20472                       | RB5: 20472                      |
| 11       | DL_TFC11                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 23032                       | RB5: 23032                      |
| 12       | DL_TFC12                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 25592                       | RB5: 25592                      |
| 13       | DL_TFC13                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 28152                       | RB5: 28152                      |



| Sub-test                                                                              | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                  | Restricted UL TFCIs                | UL RLC SDU-size (bits)<br>(note) | Test data size (bits)<br>(note) |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|-------------------------------------|------------------------------------|----------------------------------|---------------------------------|
| 14                                                                                    | DL_TFC14                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 30712                       | RB5: 30712                      |
| 15                                                                                    | DL_TFC15                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 33272                       | RB5: 33272                      |
| 16                                                                                    | DL_TFC16                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 35832                       | RB5: 35832                      |
| 17                                                                                    | DL_TFC17                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 38392                       | RB5: 38392                      |
| 18                                                                                    | DL_TFC18                 | UL_TFC4                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5 | UL_TFC0, UL_TFC4, UL_TFC5, UL_TFC9 | RB5: 40952                       | RB5: 40952                      |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                     |                                    |                                  |                                 |

See 14.1.1 for test procedure.

#### 14.2.36.2.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

- At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (4x336).
  - for sub-test 4 to 18: RB5/TF4 (8x336).
- At step 15 the UE shall return
  - for sub-test 1 to 18: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

#### 14.2.37 Interactive or background / UL:384 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

##### 14.2.37.1 Interactive or background / UL:384 DL:2048 kbps / PS RAB / 10 ms TTI

###### 14.2.37.1.1 Conformance requirement

See 14.2.4.1.

###### 14.2.37.1.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.37 for the 10 ms TTI case.

## 14.2.37.1.3 Method of test

Uplink TFS:

|     | TFI       | RB5<br>(384 kbps, 10ms) | DCCH  |
|-----|-----------|-------------------------|-------|
| TFS | TF0, bits | 0x336                   | 0x148 |
|     | TF1, bits | 1x336                   | 1x148 |
|     | TF2, bits | 2x336                   | N/A   |
|     | TF3, bits | 4x336                   | N/A   |
|     | TF4, bits | 8x336                   | N/A   |
|     | TF5, bits | 12x336                  | N/A   |

Uplink TFCS:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| UL_TFC0  | (TF0, TF0)  |
| UL_TFC1  | (TF1, TF0)  |
| UL_TFC2  | (TF2, TF0)  |
| UL_TFC3  | (TF3, TF0)  |
| UL_TFC4  | (TF4, TF0)  |
| UL_TFC5  | (TF5, TF0)  |
| UL_TFC6  | (TF0, TF1)  |
| UL_TFC7  | (TF1, TF1)  |
| UL_TFC8  | (TF2, TF1)  |
| UL_TFC9  | (TF3, TF1)  |
| UL_TFC10 | (TF4, TF1)  |
| UL_TFC11 | (TF5, TF1)  |

Downlink TFS:

|     | TFI        | RB5<br>(2048 kbps,<br>10ms) | DCCH  |
|-----|------------|-----------------------------|-------|
| TFS | TF0, bits  | 0x656                       | 0x148 |
|     | TF1, bits  | 1x656                       | 1x148 |
|     | TF2, bits  | 2x656                       | N/A   |
|     | TF3, bits  | 4x656                       | N/A   |
|     | TF4, bits  | 8x656                       | N/A   |
|     | TF5, bits  | 12x656                      | N/A   |
|     | TF6, bits  | 16x656                      | N/A   |
|     | TF7, bits  | 20x656                      | N/A   |
|     | TF8, bits  | 24x656                      | N/A   |
|     | TF9, bits  | 28x656                      | N/A   |
|     | TF10, bits | 32x656                      | N/A   |

Downlink TFCS:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| DL_TFC0  | (TF0, TF0)  |
| DL_TFC1  | (TF1, TF0)  |
| DL_TFC2  | (TF2, TF0)  |
| DL_TFC3  | (TF3, TF0)  |
| DL_TFC4  | (TF4, TF0)  |
| DL_TFC5  | (TF5, TF0)  |
| DL_TFC6  | (TF6, TF0)  |
| DL_TFC7  | (TF7, TF0)  |
| DL_TFC8  | (TF8, TF0)  |
| DL_TFC9  | (TF9, TF0)  |
| DL_TFC10 | (TF10, TF0) |
| DL_TFC11 | (TF0, TF1)  |
| DL_TFC12 | (TF1, TF1)  |

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| DL_TFC13    | (TF2, TF1)         |
| DL_TFC14    | (TF3, TF1)         |
| DL_TFC15    | (TF4, TF1)         |
| DL_TFC16    | (TF5, TF1)         |
| DL_TFC17    | (TF6, TF1)         |
| DL_TFC18    | (TF7, TF1)         |
| DL_TFC19    | (TF8, TF1)         |
| DL_TFC20    | (TF9, TF1)         |
| DL_TFC21    | (TF10, TF1)        |

Sub-tests:

| <b>Sub-test</b>                                                                       | <b>Downlink TFCs Under Test</b> | <b>Uplink TFCs Under test</b> | <b>Implicitely-tested</b>           | <b>Restricted UL TFCIs</b>          | <b>UL RLC SDU-size (bits)</b> | <b>Test data size (bits)</b> |
|---------------------------------------------------------------------------------------|---------------------------------|-------------------------------|-------------------------------------|-------------------------------------|-------------------------------|------------------------------|
|                                                                                       |                                 |                               |                                     |                                     | (note)                        | (note)                       |
| 1                                                                                     | DL_TFC1                         | UL_TFC1                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC1, UL_TFC6, UL_TFC7  | RB5: 632                      | RB5: 632                     |
| 2                                                                                     | DL_TFC2                         | UL_TFC2                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC2, UL_TFC6, UL_TFC8  | RB5: 1272                     | RB5: 1272                    |
| 3                                                                                     | DL_TFC3                         | UL_TFC3                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC3, UL_TFC6, UL_TFC9  | RB5: 2552                     | RB5: 2552                    |
| 4                                                                                     | DL_TFC4                         | UL_TFC4                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC4, UL_TFC6, UL_TFC10 | RB5: 5112                     | RB5: 5112                    |
| 5                                                                                     | DL_TFC5                         | UL_TFC5                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC5, UL_TFC6, UL_TFC11 | RB5: 7672                     | RB5: 7672                    |
| 6                                                                                     | DL_TFC6                         | UL_TFC5                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC5, UL_TFC6, UL_TFC11 | RB5: 10232                    | RB5: 10232                   |
| 7                                                                                     | DL_TFC7                         | UL_TFC5                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC5, UL_TFC6, UL_TFC11 | RB5: 12792                    | RB5: 12792                   |
| 8                                                                                     | DL_TFC8                         | UL_TFC5                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC5, UL_TFC6, UL_TFC11 | RB5: 15352                    | RB5: 15352                   |
| 9                                                                                     | DL_TFC9                         | UL_TFC5                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC5, UL_TFC6, UL_TFC11 | RB5: 17912                    | RB5: 17912                   |
| 10                                                                                    | DL_TFC10                        | UL_TFC5                       | DL_TFC0, DL_TFC11, UL_TFC0, UL_TFC6 | UL_TFC0, UL_TFC5, UL_TFC6, UL_TFC11 | RB5: 20472                    | RB5: 20472                   |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                                 |                               |                                     |                                     |                               |                              |

See 14.1.1 for test procedure.

~~14.2.37.1.4 Test requirements~~

See 14.1.1 for definition of step 10 and step 15.

- ~~1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.~~
- ~~2. At step 15 the UE transmitted transport format shall be~~
  - ~~— for sub-test 1: RB5/TF1 (1x336).~~
  - ~~— for sub-test 2: RB5/TF2 (2x336).~~
  - ~~— for sub-test 3: RB5/TF3 (4x336).~~
  - ~~— for sub-test 4: RB5/TF3 (8x336).~~
  - ~~— for sub-test 5 to 10: RB5/TF4 (12x336).~~
- ~~3. At step 15 the UE shall return~~
  - ~~— for sub-test 1 to 10: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.~~

~~14.2.37.2 Interactive or background / UL:384 DL:2048 kbps / PS RAB / 20 ms TTI~~~~14.2.37.2.1 Conformance requirement~~

See 14.2.4.1.

~~14.2.37.2.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.37 for the 20 ms TTI case.

~~14.2.37.2.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(384 kbps, 20ms) | DCCH  |
|-----|-----------|-------------------------|-------|
| TFS | TF0, bits | 0x336                   | 0x148 |
|     | TF1, bits | 1x336                   | 1x148 |
|     | TF2, bits | 2x336                   | N/A   |
|     | TF3, bits | 4x336                   | N/A   |
|     | TF4, bits | 8x336                   | N/A   |
|     | TF5, bits | 12x336                  | N/A   |
|     | TF6, bits | 16x336                  | N/A   |
|     | TF7, bits | 20x336                  | N/A   |
|     | TF8, bits | 24x336                  | N/A   |

Uplink TFCS:

| TFCI     | (RB5, DCCH) |
|----------|-------------|
| UL_TFC0  | (TF0, TF0)  |
| UL_TFC1  | (TF1, TF0)  |
| UL_TFC2  | (TF2, TF0)  |
| UL_TFC3  | (TF3, TF0)  |
| UL_TFC4  | (TF4, TF0)  |
| UL_TFC5  | (TF5, TF0)  |
| UL_TFC6  | (TF6, TF0)  |
| UL_TFC7  | (TF7, TF0)  |
| UL_TFC8  | (TF8, TF0)  |
| UL_TFC9  | (TF0, TF1)  |
| UL_TFC10 | (TF1, TF1)  |

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| UL_TFC11    | (TF2, TF1)         |
| UL_TFC12    | (TF3, TF1)         |
| UL_TFC13    | (TF4, TF1)         |
| UL_TFC14    | (TF5, TF1)         |
| UL_TFC15    | (TF6, TF1)         |
| UL_TFC16    | (TF7, TF1)         |
| UL_TFC17    | (TF8, TF1)         |

Downlink-TFS:

|            | <b>TFI</b> | <b>RB5<br/>(2048-kbps,<br/>10ms)</b> | <b>DCCH</b> |
|------------|------------|--------------------------------------|-------------|
| <b>TFS</b> | TF0, bits  | 0x656                                | 0x148       |
|            | TF1, bits  | 1x656                                | 1x148       |
|            | TF2, bits  | 2x656                                | N/A         |
|            | TF3, bits  | 4x656                                | N/A         |
|            | TF4, bits  | 8x656                                | N/A         |
|            | TF5, bits  | 12x656                               | N/A         |
|            | TF6, bits  | 16x656                               | N/A         |
|            | TF7, bits  | 20x656                               | N/A         |
|            | TF8, bits  | 24x656                               | N/A         |
|            | TF9, bits  | 28x656                               | N/A         |
|            | TF10, bits | 32x656                               | N/A         |
|            | TF11, bits | 36x656                               | N/A         |
|            | TF12, bits | 40x656                               | N/A         |
|            | TF13, bits | 44x656                               | N/A         |
|            | TF14, bits | 48x656                               | N/A         |
|            | TF15, bits | 52x656                               | N/A         |
|            | TF16, bits | 56x656                               | N/A         |
|            | TF17, bits | 60x656                               | N/A         |
|            | TF18, bits | 64x656                               | N/A         |

Downlink-TFCS:

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| DL_TFC0     | (TF0, TF0)         |
| DL_TFC1     | (TF1, TF0)         |
| DL_TFC2     | (TF2, TF0)         |
| DL_TFC3     | (TF3, TF0)         |
| DL_TFC4     | (TF4, TF0)         |
| DL_TFC5     | (TF5, TF0)         |
| DL_TFC6     | (TF6, TF0)         |
| DL_TFC7     | (TF7, TF0)         |
| DL_TFC8     | (TF8, TF0)         |
| DL_TFC9     | (TF9, TF0)         |
| DL_TFC10    | (TF10, TF0)        |
| DL_TFC11    | (TF11, TF0)        |
| DL_TFC12    | (TF12, TF0)        |
| DL_TFC13    | (TF13, TF0)        |
| DL_TFC14    | (TF14, TF0)        |
| DL_TFC15    | (TF15, TF0)        |
| DL_TFC16    | (TF16, TF0)        |
| DL_TFC17    | (TF17, TF0)        |
| DL_TFC18    | (TF18, TF0)        |
| DL_TFC19    | (TF0, TF1)         |
| DL_TFC20    | (TF1, TF1)         |
| DL_TFC21    | (TF2, TF1)         |
| DL_TFC22    | (TF3, TF1)         |
| DL_TFC23    | (TF4, TF1)         |
| DL_TFC24    | (TF5, TF1)         |

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| DL_TFC25    | (TF6, TF1)         |
| DL_TFC26    | (TF7, TF1)         |
| DL_TFC27    | (TF8, TF1)         |
| DL_TFC28    | (TF9, TF1)         |
| DL_TFC29    | (TF10, TF1)        |
| DL_TFC30    | (TF11, TF1)        |
| DL_TFC31    | (TF12, TF1)        |
| DL_TFC32    | (TF13, TF1)        |
| DL_TFC33    | (TF14, TF1)        |
| DL_TFC34    | (TF15, TF1)        |
| DL_TFC35    | (TF16, TF1)        |
| DL_TFC36    | (TF17, TF1)        |
| DL_TFC37    | (TF18, TF1)        |

## Sub-tests:

| <b>Sub-test</b> | <b>Downlink TFCS Under Test</b> | <b>Uplink TFCS Under test</b> | <b>Implicitely tested</b>             | <b>Restricted UL TFCIs</b>          | <b>UL RLC SDU-size (bits)</b><br>(note) | <b>Test data size (bits)</b><br>(note) |
|-----------------|---------------------------------|-------------------------------|---------------------------------------|-------------------------------------|-----------------------------------------|----------------------------------------|
| 1               | DL_TFC1                         | UL_TFC1                       | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC9   | UL_TFC0, UL_TFC1, UL_TFC9, UL_TFC10 | RB5: 632                                | RB5: 632                               |
| 2               | DL_TFC2                         | UL_TFC2                       | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC9   | UL_TFC0, UL_TFC2, UL_TFC9, UL_TFC11 | RB5: 1272                               | RB5: 1272                              |
| 3               | DL_TFC3                         | UL_TFC3                       | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC9   | UL_TFC0, UL_TFC3, UL_TFC9, UL_TFC12 | RB5: 2552                               | RB5: 2552                              |
| 4               | DL_TFC4                         | UL_TFC4                       | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC9   | UL_TFC0, UL_TFC4, UL_TFC9, UL_TFC13 | RB5: 5112                               | RB5: 5112                              |
| 5               | DL_TFC5                         | UL_TFC5                       | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC9   | UL_TFC0, UL_TFC5, UL_TFC9, UL_TFC14 | RB5: 7672                               | RB5: 7672                              |
| 6               | DL_TFC6                         | UL_TFC6                       | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC9   | UL_TFC0, UL_TFC6, UL_TFC9, UL_TFC15 | RB5: 10232                              | RB5: 10232                             |
| 7               | DL_TFC7                         | UL_TFC7                       | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC9   | UL_TFC0, UL_TFC7, UL_TFC9, UL_TFC16 | RB5: 12792                              | RB5: 12792                             |
| 8               | DL_TFC8                         | UL_TFC8                       | DL_TFC0, DL_TFC19, , UL_TFC0, UL_TFC9 | UL_TFC0, UL_TFC8, UL_TFC9, UL_TFC17 | RB5: 15352                              | RB5: 15352                             |
| 9               | DL_TFC9                         | UL_TFC8                       | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC9   | UL_TFC0, UL_TFC8, UL_TFC9, UL_TFC17 | RB5: 17912                              | RB5: 17912                             |
| 10              | DL_TFC10                        | UL_TFC8                       | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC9   | UL_TFC0, UL_TFC8, UL_TFC9, UL_TFC17 | RB5: 20472                              | RB5: 20472                             |
| 11              | DL_TFC11                        | UL_TFC8                       | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC9   | UL_TFC0, UL_TFC8, UL_TFC9, UL_TFC17 | RB5: 23032                              | RB5: 23032                             |

| Sub-test                                                                              | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                    | Restricted UL TFCIs                 | UL RLC SDU-size (bits)<br>(note) | Test data size (bits)<br>(note) |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|---------------------------------------|-------------------------------------|----------------------------------|---------------------------------|
| 12                                                                                    | DL_TFC12                 | UL_TFC8                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC5   | UL_TFC0, UL_TFC8, UL_TFC9, UL_TFC17 | RB5: 25592                       | RB5: 25592                      |
| 13                                                                                    | DL_TFC13                 | UL_TFC8                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC9   | UL_TFC0, UL_TFC8, UL_TFC9, UL_TFC17 | RB5: 28152                       | RB5: 28152                      |
| 14                                                                                    | DL_TFC14                 | UL_TFC8                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC9   | UL_TFC0, UL_TFC8, UL_TFC9, UL_TFC17 | RB5: 30712                       | RB5: 30712                      |
| 15                                                                                    | DL_TFC15                 | UL_TFC8                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC9   | UL_TFC0, UL_TFC8, UL_TFC9, UL_TFC17 | RB5: 33272                       | RB5: 33272                      |
| 16                                                                                    | DL_TFC16                 | UL_TFC8                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC9   | UL_TFC0, UL_TFC8, UL_TFC9, UL_TFC17 | RB5: 35832                       | RB5: 35832                      |
| 17                                                                                    | DL_TFC17                 | UL_TFC8                | DL_TFC0, DL_TFC19, UL_TFC0, UL_TFC9   | UL_TFC0, UL_TFC8, UL_TFC9, UL_TFC17 | RB5: 38392                       | RB5: 38392                      |
| 18                                                                                    | DL_TFC18                 | UL_TFC8                | DL_TFC0, DL_TFC19, , UL_TFC0, UL_TFC9 | UL_TFC0, UL_TFC8, UL_TFC9, UL_TFC17 | RB5: 40952                       | RB5: 40952                      |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                       |                                     |                                  |                                 |

See 14.1.1 for test procedure.

#### 14.2.37.2.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (4x336).
  - for sub-test 4: RB5/TF4 (8x336).
  - for sub-test 5: RB5/TF5 (12x336).
  - for sub-test 6: RB5/TF6 (16x336).
  - for sub-test 7: RB5/TF7 (20x336).
  - for sub-test 8 to 18: RB5/TF4 (24x336).
3. At step 15 the UE shall return
  - for sub-test 1 to 18: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

### ~~14.2.38 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

#### ~~14.2.38.1 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32 DL:8 kbps / PS RAB / (TC, 20 ms TTI)~~

##### ~~14.2.38.1.1 Conformance requirement~~

See 14.2.4.1.

##### ~~14.2.38.1.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.38 for the turbo channel coding and 20 ms TTI case.

##### ~~14.2.38.1.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | RB8<br>(32 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x336            | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336            | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x336            | N/A   |

Uplink TFCs:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| UL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| UL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| UL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| UL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| UL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| UL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| UL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| UL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| UL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| UL_TFC9  | (TF0, TF0, TF0, TF0, TF1)  |
| UL_TFC10 | (TF1, TF0, TF0, TF0, TF1)  |
| UL_TFC11 | (TF2, TF1, TF1, TF0, TF1)  |
| UL_TFC12 | (TF0, TF0, TF0, TF1, TF1)  |
| UL_TFC13 | (TF1, TF0, TF0, TF1, TF1)  |
| UL_TFC14 | (TF2, TF1, TF1, TF1, TF1)  |
| UL_TFC15 | (TF0, TF0, TF0, TF2, TF1)  |
| UL_TFC16 | (TF1, TF0, TF0, TF2, TF1)  |
| UL_TFC17 | (TF2, TF1, TF1, TF2, TF1)  |

Downlink TFS:

|     |           | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | RB8<br>(8 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-----------------|-------|
| TFS | TF0, bits | 1x0                     | 0x103                   | 0x60                    | 0x336           | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336           | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | N/A             | N/A   |



Downlink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| DL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| DL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| DL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| DL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| DL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| DL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| DL_TFC6  | (TF0, TF0, TF0, TF0, TF1)  |
| DL_TFC7  | (TF1, TF0, TF0, TF0, TF1)  |
| DL_TFC8  | (TF2, TF1, TF1, TF0, TF1)  |
| DL_TFC9  | (TF0, TF0, TF0, TF1, TF1)  |
| DL_TFC10 | (TF1, TF0, TF0, TF1, TF1)  |
| DL_TFC11 | (TF2, TF1, TF1, TF1, TF1)  |

Sub-tests:

| Sub-test                                                                                | Downlink TFCS under test | Uplink TFCS Under test | Implicitely tested                 | Restricted UL TFCIs                 | UL RLC SDU size (bits) (note)              | Test data size (bits) (note)                             |
|-----------------------------------------------------------------------------------------|--------------------------|------------------------|------------------------------------|-------------------------------------|--------------------------------------------|----------------------------------------------------------|
| 1                                                                                       | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC9 | UL_TFC0, UL_TFC1, UL_TFC9, UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data  |
| 2                                                                                       | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC9 | UL_TFC0, UL_TFC2, UL_TFC9, UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data           |
| 3                                                                                       | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC9 | UL_TFC0, UL_TFC3, UL_TFC9, UL_TFC12 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 312 |
| 4                                                                                       | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC9 | UL_TFC0, UL_TFC4, UL_TFC9, UL_TFC13 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 312      |
| 5                                                                                       | DL_TFC5                  | UL_TFC5                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC9 | UL_TFC0, UL_TFC5, UL_TFC9, UL_TFC14 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312               |
| 6                                                                                       | DL_TFC5                  | UL_TFC6                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC9 | UL_TFC0, UL_TFC6, UL_TFC9, UL_TFC15 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 632 |
| 7                                                                                       | DL_TFC5                  | UL_TFC7                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC9 | UL_TFC0, UL_TFC7, UL_TFC9, UL_TFC16 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 632      |
| 8                                                                                       | DL_TFC5                  | UL_TFC8                | DL_TFC0, DL_TFC6, UL_TFC0, UL_TFC9 | UL_TFC0, UL_TFC8, UL_TFC9, UL_TFC17 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632               |
| NOTE: — See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                    |                                     |                                            |                                                          |

See 14.1.1 for test procedure.

#### 14.2.38.1.4 ——— Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

- for sub-test 1: RB5/TF1 (1x39);
- for sub-test 2: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60);
- for sub-test 3: RB8/TF1 (1x336)
- for sub-test 4: RB5/TF1 (1x39) and RB8/TF1 (1x336);
- for sub-test 5: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF1 (1x336);
- for sub-test 6: RB8/TF2 (2x336)
- for sub-test 7: RB5/TF1 (1x39) and RB8/TF2 (2x336);
- for sub-test 8: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF2 (2x336);

3. At step 15 the UE shall return

- for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6, RB7 and RB8;
- for sub-test 2: an RLC SDU on RB5, RB6 and RB7 having the same content as sent by SS; and no data shall be received on RB8;
- for sub-test 3 and 6: an RLC SDU on RB8 having the same content as sent by SS; and no data shall be received on RB5, RB6 and RB7;
- for sub-test 4 and 7: an RLC SDU on RB5 and RB8 having the same content as sent by SS; and no data shall be received on RB6 and RB7;
- for sub-test 5 and 8: an RLC SDU on RB5, RB6, RB7 and RB8 having the same content as sent by SS;

#### ~~14.2.38.2 — Conversational / speech / UL:12.2 kbps / DL:12.2 kbps / CS RAB + Interactive or background / UL:32 kbps / DL:8 kbps / PS RAB / (TC, 10 ms TTI)~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.38 for the turbo channel coding and 10 ms TTI case.

See 14.2.38.1 for test procedure and test requirements. Only sub-tests 1 to 5 are applicable for the 10 ms TTI case.

#### ~~14.2.38.3 — Conversational / speech / UL:12.2 kbps / DL:12.2 kbps / CS RAB + Interactive or background / UL:32 kbps / DL:8 kbps / PS RAB / (CC, 20 ms TTI)~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.38 for the convolutional channel coding and 20 ms TTI case.

See test case 14.2.38.1 for test procedure and test requirement.

#### ~~14.2.38.4 — Conversational / speech / UL:12.2 kbps / DL:12.2 kbps / CS RAB + Interactive or background / UL:32 kbps / DL:8 kbps / PS RAB / (CC, 10 ms TTI)~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.38 for the convolutional channel coding and 10 ms TTI case.

See test case 14.2.38.2 for test procedure and test requirement.

~~14.2.38a Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB +  
Interactive or background / UL:0 DL:0 kbps / PS RAB + UL:3.4  
DL:3.4 kbps SRBs for DCCH.~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.38a.~~

~~14.2.38b Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB +  
Interactive or background / UL:8 DL:8 kbps / PS RAB + UL:3.4  
DL:3.4 kbps SRBs for DCCH.~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.38b.~~

~~14.2.38c Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB +  
Interactive or background / UL:32 DL:32 kbps / PS RAB + UL:3.4  
DL:3.4 kbps SRBs for DCCH.~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.38c.~~

~~14.2.38d Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB +  
Interactive or background / UL:64 DL:64 kbps / PS RAB +  
Interactive or background / UL:64 DL:64 kbps / PS RAB + UL:3.4  
DL:3.4 kbps SRBs for DCCH.~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.38d.~~

~~14.2.38e Conversational / speech / UL:(12.2 7.95 5.9 4.75) DL:(12.2 7.95 5.9  
4.75) kbps / CS RAB + Interactive or background / UL:0 DL:0 kbps /  
PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.38e.~~

~~14.2.38f Conversational / speech / UL:(12.2 7.95 5.9 4.75) DL:(12.2 7.95 5.9  
4.75) kbps / CS RAB + Interactive or background / UL:8 DL:8 kbps /  
PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.38f.~~

~~14.2.38g Conversational / speech / UL:(12.2 7.95 5.9 4.75) DL:(12.2 7.95 5.9  
4.75) kbps / CS RAB + Interactive or background / UL:16 DL:16  
kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.38g.~~

~~14.2.38h Conversational / speech / UL:(12.2 7.95 5.9 4.75) DL:(12.2 7.95 5.9 4.75) kbps / CS RAB + Interactive or background / UL:32 DL:32 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.38h.~~

~~14.2.38i Conversational / speech / UL:(12.2 7.95 5.9 4.75) DL:(12.2 7.95 5.9 4.75) kbps / CS RAB + Interactive or background / UL:64 DL:64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.38i.~~

~~14.2.38j Conversational / speech / UL:(12.2 7.95 5.9 4.75) DL:(12.2 7.95 5.9 4.75) kbps / CS RAB + Interactive or background / UL:64 DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.38j.~~

~~14.2.39 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32 DL:64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

~~14.2.39.1 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32 DL:64 kbps / PS RAB / (TC, 10 ms TTI)~~

~~14.2.39.1.1 Conformance requirement~~

~~See 14.2.4.1.~~

~~14.2.39.1.2 Test purpose~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.39 for the uplink turbo channel coding and 10 ms TTI case.~~

~~14.2.39.1.3 Method of test~~

~~Uplink TFS:~~

|     | TFI       | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | RB7<br>(RAB subflow #3) | RB8<br>(32 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x336            | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336            | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | N/A              | N/A   |

~~Uplink TFCS:~~

| <b>TFCI</b> | <b>(RB5, RB6, RB7, RB8, DCCH)</b> |
|-------------|-----------------------------------|
| UL_TFC0     | (TF0, TF0, TF0, TF0, TF0)         |
| UL_TFC1     | (TF1, TF0, TF0, TF0, TF0)         |
| UL_TFC2     | (TF2, TF1, TF1, TF0, TF0)         |
| UL_TFC3     | (TF0, TF0, TF0, TF1, TF0)         |
| UL_TFC4     | (TF1, TF0, TF0, TF1, TF0)         |
| UL_TFC5     | (TF2, TF1, TF1, TF1, TF0)         |
| UL_TFC6     | (TF0, TF0, TF0, TF0, TF1)         |
| UL_TFC7     | (TF1, TF0, TF0, TF0, TF1)         |
| UL_TFC8     | (TF2, TF1, TF1, TF0, TF1)         |
| UL_TFC9     | (TF0, TF0, TF0, TF1, TF1)         |
| UL_TFC10    | (TF1, TF0, TF0, TF1, TF1)         |
| UL_TFC11    | (TF2, TF1, TF1, TF1, TF1)         |

## Downlink TFS:

|     |           | <b>RB5<br/>(RAB-subflow #1)</b> | <b>RB6<br/>(RAB-subflow #2)</b> | <b>RB7<br/>(RAB-subflow #3)</b> | <b>RB8<br/>(64 kbps)</b> | <b>DCCH</b> |
|-----|-----------|---------------------------------|---------------------------------|---------------------------------|--------------------------|-------------|
| TFS | TF0, bits | 1x0                             | 0x103                           | 0x60                            | 0x336                    | 0x148       |
|     | TF1, bits | 1x39                            | 1x103                           | 1x60                            | 1x336                    | 1x148       |
|     | TF2, bits | 1x81                            | N/A                             | N/A                             | 2x336                    | N/A         |
|     | TF3, bits | N/A                             | N/A                             | N/A                             | 3x336                    | N/A         |
|     | TF4, bits | N/A                             | N/A                             | N/A                             | 4x336                    | N/A         |

## Downlink TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, RB7, RB8, DCCH)</b> |
|-------------|-----------------------------------|
| DL_TFC0     | (TF0, TF0, TF0, TF0, TF0)         |
| DL_TFC1     | (TF1, TF0, TF0, TF0, TF0)         |
| DL_TFC2     | (TF2, TF1, TF1, TF0, TF0)         |
| DL_TFC3     | (TF0, TF0, TF0, TF1, TF0)         |
| DL_TFC4     | (TF1, TF0, TF0, TF1, TF0)         |
| DL_TFC5     | (TF2, TF1, TF1, TF1, TF0)         |
| DL_TFC6     | (TF0, TF0, TF0, TF2, TF0)         |
| DL_TFC7     | (TF1, TF0, TF0, TF2, TF0)         |
| DL_TFC8     | (TF2, TF1, TF1, TF2, TF0)         |
| DL_TFC9     | (TF0, TF0, TF0, TF3, TF0)         |
| DL_TFC10    | (TF1, TF0, TF0, TF3, TF0)         |
| DL_TFC11    | (TF2, TF1, TF1, TF3, TF0)         |
| DL_TFC12    | (TF0, TF0, TF0, TF4, TF0)         |
| DL_TFC13    | (TF1, TF0, TF0, TF4, TF0)         |
| DL_TFC14    | (TF2, TF1, TF1, TF4, TF0)         |
| DL_TFC15    | (TF0, TF0, TF0, TF0, TF1)         |
| DL_TFC16    | (TF1, TF0, TF0, TF0, TF1)         |
| DL_TFC17    | (TF2, TF1, TF1, TF0, TF1)         |
| DL_TFC18    | (TF0, TF0, TF0, TF1, TF1)         |
| DL_TFC19    | (TF1, TF0, TF0, TF1, TF1)         |
| DL_TFC20    | (TF2, TF1, TF1, TF1, TF1)         |
| DL_TFC21    | (TF0, TF0, TF0, TF2, TF1)         |
| DL_TFC22    | (TF1, TF0, TF0, TF2, TF1)         |
| DL_TFC23    | (TF2, TF1, TF1, TF2, TF1)         |
| DL_TFC24    | (TF0, TF0, TF0, TF3, TF1)         |
| DL_TFC25    | (TF1, TF0, TF0, TF3, TF1)         |
| DL_TFC26    | (TF2, TF1, TF1, TF3, TF1)         |
| DL_TFC27    | (TF0, TF0, TF0, TF4, TF1)         |
| DL_TFC28    | (TF1, TF0, TF0, TF4, TF1)         |
| DL_TFC29    | (TF2, TF1, TF1, TF4, TF1)         |

Sub-tests:

| Sub-test                                                                               | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                     | Restricted UL TFCs                           | UL RLC SDU size (bits) (note)               | Test data size (bits) (note)                              |
|----------------------------------------------------------------------------------------|--------------------------|------------------------|----------------------------------------|----------------------------------------------|---------------------------------------------|-----------------------------------------------------------|
| 1                                                                                      | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC9,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data   |
| 2                                                                                      | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC9,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data            |
| 3                                                                                      | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC9,<br>UL_TFC12 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 312  |
| 4                                                                                      | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC9,<br>UL_TFC13 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 312       |
| 5                                                                                      | DL_TFC5                  | UL_TFC5                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC9,<br>UL_TFC14 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312                |
| 6                                                                                      | DL_TFC6                  | UL_TFC3                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC9,<br>UL_TFC12 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 632  |
| 7                                                                                      | DL_TFC7                  | UL_TFC4                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC9,<br>UL_TFC13 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 632       |
| 8                                                                                      | DL_TFC8                  | UL_TFC5                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC9,<br>UL_TFC14 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632                |
| 9                                                                                      | DL_TFC9                  | UL_TFC3                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC9,<br>UL_TFC12 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 952  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 952  |
| 10                                                                                     | DL_TFC10                 | UL_TFC4                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC9,<br>UL_TFC13 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 952  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 952       |
| 11                                                                                     | DL_TFC11                 | UL_TFC5                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC9,<br>UL_TFC14 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 952  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 952                |
| 12                                                                                     | DL_TFC12                 | UL_TFC3                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC9,<br>UL_TFC12 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 1272 |
| 13                                                                                     | DL_TFC13                 | UL_TFC4                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC9,<br>UL_TFC13 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 1272      |
| 14                                                                                     | DL_TFC14                 | UL_TFC5                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC9,<br>UL_TFC14 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272               |
| NOTE:— See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                        |                                              |                                             |                                                           |

See 14.1.1 for test procedure.

**14.2.39.1.4** ~~Test requirements~~

See 14.1.1 for definition of step 10 and step 15.

1. ~~At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.~~
2. ~~At step 15 the UE transmitted transport format shall be~~
  - ~~— for sub-test 1: RB5/TF1 (1x39).~~
  - ~~— for sub-test 2: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).~~
  - ~~— for sub-test 3, 6, 9 and 12: RB8/TF1 (1x336)~~
  - ~~— for sub-test 4, 7, 10 and 13: RB5/TF1 (1x39) and RB8/TF1 (1x336).~~
  - ~~— for sub-test 5, 8, 11 and 14: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF1 (1x336).~~
3. ~~At step 15 the UE shall return~~
  - ~~— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6, RB7 and RB8.~~
  - ~~— for sub-test 2: an RLC SDU on RB5, RB6 and RB7 having the same content as sent by SS; and no data shall be received on RB8.~~
  - ~~— for sub-test 3, 6, 9 and 12: an RLC SDU on RB8 having the same content as sent by SS; and no data shall be received on RB5, RB6 and RB7.~~
  - ~~— for sub-test 4, 7, 10 and 13: an RLC SDU on RB5 and RB8 having the same content as sent by SS; and no data shall be received on RB6 and RB7.~~
  - ~~— for sub-test 5, 8, 11 and 14: an RLC SDU on RB5, RB6, RB7 and RB8 having the same content as sent by SS.~~

**14.2.39.2** ~~Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32 DL:64 kbps / PS RAB / (TC, 20 ms TTI)~~**14.2.39.2.1** ~~Conformance requirement~~

See 14.2.4.1.

**14.2.39.2.2** ~~Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.39 for the uplink turbo channel coding and 20 ms TTI case.

**14.2.39.2.3** ~~Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | RB7<br>(RAB subflow #3) | RB8<br>(32 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x336            | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336            | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x336            | N/A   |

## Uplink TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, RB7, RB8, DCCH)</b> |
|-------------|-----------------------------------|
| UL_TFC0     | (TF0, TF0, TF0, TF0, TF0)         |
| UL_TFC1     | (TF1, TF0, TF0, TF0, TF0)         |
| UL_TFC2     | (TF2, TF1, TF1, TF0, TF0)         |
| UL_TFC3     | (TF0, TF0, TF0, TF1, TF0)         |
| UL_TFC4     | (TF1, TF0, TF0, TF1, TF0)         |
| UL_TFC5     | (TF2, TF1, TF1, TF1, TF0)         |
| UL_TFC6     | (TF0, TF0, TF0, TF2, TF0)         |
| UL_TFC7     | (TF1, TF0, TF0, TF2, TF0)         |
| UL_TFC8     | (TF2, TF1, TF1, TF2, TF0)         |
| UL_TFC9     | (TF0, TF0, TF0, TF0, TF1)         |
| UL_TFC10    | (TF1, TF0, TF0, TF0, TF1)         |
| UL_TFC11    | (TF2, TF1, TF1, TF0, TF1)         |
| UL_TFC12    | (TF0, TF0, TF0, TF1, TF1)         |
| UL_TFC13    | (TF1, TF0, TF0, TF1, TF1)         |
| UL_TFC14    | (TF2, TF1, TF1, TF1, TF1)         |
| UL_TFC15    | (TF0, TF0, TF0, TF2, TF1)         |
| UL_TFC16    | (TF1, TF0, TF0, TF2, TF1)         |
| UL_TFC17    | (TF2, TF1, TF1, TF2, TF1)         |

## Downlink TFS:

|            |           | <b>RB5<br/>(RAB subflow #1)</b> | <b>RB6<br/>(RAB subflow #2)</b> | <b>RB7<br/>(RAB subflow #3)</b> | <b>RB8<br/>(64 kbps)</b> | <b>DCCH</b> |
|------------|-----------|---------------------------------|---------------------------------|---------------------------------|--------------------------|-------------|
| <b>TFS</b> | TF0, bits | 1x0                             | 0x103                           | 0x60                            | 0x336                    | 0x148       |
|            | TF1, bits | 1x39                            | 1x103                           | 1x60                            | 1x336                    | 1x148       |
|            | TF2, bits | 1x81                            | N/A                             | N/A                             | 2x336                    | N/A         |
|            | TF3, bits | N/A                             | N/A                             | N/A                             | 3x336                    | N/A         |
|            | TF4, bits | N/A                             | N/A                             | N/A                             | 4x336                    | N/A         |



Downlink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| DL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| DL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| DL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| DL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| DL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| DL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| DL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| DL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| DL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| DL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| DL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| DL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| DL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| DL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| DL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| DL_TFC15 | (TF0, TF0, TF0, TF0, TF1)  |
| DL_TFC16 | (TF1, TF0, TF0, TF0, TF1)  |
| DL_TFC17 | (TF2, TF1, TF1, TF0, TF1)  |
| DL_TFC18 | (TF0, TF0, TF0, TF1, TF1)  |
| DL_TFC19 | (TF1, TF0, TF0, TF1, TF1)  |
| DL_TFC20 | (TF2, TF1, TF1, TF1, TF1)  |
| DL_TFC21 | (TF0, TF0, TF0, TF2, TF1)  |
| DL_TFC22 | (TF1, TF0, TF0, TF2, TF1)  |
| DL_TFC23 | (TF2, TF1, TF1, TF2, TF1)  |
| DL_TFC24 | (TF0, TF0, TF0, TF3, TF1)  |
| DL_TFC25 | (TF1, TF0, TF0, TF3, TF1)  |
| DL_TFC26 | (TF2, TF1, TF1, TF3, TF1)  |
| DL_TFC27 | (TF0, TF0, TF0, TF4, TF1)  |
| DL_TFC28 | (TF1, TF0, TF0, TF4, TF1)  |
| DL_TFC29 | (TF2, TF1, TF1, TF4, TF1)  |

Sub-tests:

| Sub-test                                                                                | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                     | Restricted UL TFCIs                          | UL RLC SDU size (bits) (note)               | Test data size (bits) (note)                              |
|-----------------------------------------------------------------------------------------|--------------------------|------------------------|----------------------------------------|----------------------------------------------|---------------------------------------------|-----------------------------------------------------------|
| 1                                                                                       | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC9,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data   |
| 2                                                                                       | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC9,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data            |
| 3                                                                                       | DL_TFC3                  | UL_TFC3                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC9,<br>UL_TFC12 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 312  |
| 4                                                                                       | DL_TFC4                  | UL_TFC4                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC9,<br>UL_TFC13 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 312       |
| 5                                                                                       | DL_TFC5                  | UL_TFC5                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC9,<br>UL_TFC14 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312                |
| 6                                                                                       | DL_TFC6                  | UL_TFC6                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC9,<br>UL_TFC15 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 632  |
| 7                                                                                       | DL_TFC7                  | UL_TFC7                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC9,<br>UL_TFC16 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 632       |
| 8                                                                                       | DL_TFC8                  | UL_TFC8                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC9,<br>UL_TFC17 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632                |
| 9                                                                                       | DL_TFC9                  | UL_TFC6                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC9,<br>UL_TFC15 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 952  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 952  |
| 10                                                                                      | DL_TFC10                 | UL_TFC7                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC9,<br>UL_TFC15 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 952  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 952       |
| 11                                                                                      | DL_TFC11                 | UL_TFC8                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC9,<br>UL_TFC17 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 952  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 952                |
| 12                                                                                      | DL_TFC12                 | UL_TFC6                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC9,<br>UL_TFC15 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 1272 |
| 13                                                                                      | DL_TFC13                 | UL_TFC7                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC9,<br>UL_TFC16 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 1272      |
| 14                                                                                      | DL_TFC14                 | UL_TFC8                | DL_TFC0, DL_TFC15,<br>UL_TFC0, UL_TFC9 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC9,<br>UL_TFC17 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272               |
| NOTE: — See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                        |                                              |                                             |                                                           |

See 14.1.1 for test procedure.

#### ~~14.2.39.2.4 Test requirements~~

See 14.1.1 for definition of step 10 and step 15.

- ~~1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.~~
- ~~2. At step 15 the UE transmitted transport format shall be~~
  - ~~— for sub-test 1: RB5/TF1 (1x39).~~
  - ~~— for sub-test 2: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).~~
  - ~~— for sub-test 3: RB8/TF1 (1x336)~~
  - ~~— for sub-test 4: RB5/TF1 (1x39) and RB8/TF1 (1x336).~~
  - ~~— for sub-test 5: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF1 (1x336).~~
  - ~~— for sub-test 6, 9 and 12: RB8/TF2 (2x336)~~
  - ~~— for sub-test 7, 10 and 13: RB5/TF1 (1x39) and RB8/TF2 (2x336).~~
  - ~~— for sub-test 8, 11 and 14: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF2 (2x336).~~
- ~~3. At step 15 the UE shall return~~
  - ~~— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6, RB7 and RB8.~~
  - ~~— for sub-test 2: an RLC SDU on RB5, RB6 and RB7 having the same content as sent by SS; and no data shall be received on RB8.~~
  - ~~— for sub-test 3, 6, 9 and 12: an RLC SDU on RB8 having the same content as sent by SS; and no data shall be received on RB5, RB6 and RB7.~~
  - ~~— for sub-test 4, 7, 10 and 13: an RLC SDU on RB5 and RB8 having the same content as sent by SS; and no data shall be received on RB6 and RB7.~~
  - ~~— for sub-test 5, 8, 11 and 14: an RLC SDU on RB5, RB6, RB7 and RB8 having the same content as sent by SS.~~

#### ~~14.2.39.3 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32 DL:64 kbps / PS RAB / (CC, 10 ms TTI)~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.39 for the uplink convolutional channel coding and 10 ms TTI case.

See test case 14.2.39.1 for test procedure and test requirement.

#### ~~14.2.39.4 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32 DL:64 kbps / PS RAB / (CC, 20 ms TTI)~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.39 for the uplink convolutional channel coding and 20 ms TTI case.

See test case 14.2.39.2 for test procedure and test requirement.

## ~~14.2.40 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB+ Interactive or background / UL:64 DL:64 kbps / PS RAB+ UL:3.4 DL: 3.4 kbps SRBs for DCCH~~

### ~~14.2.40.1 Conformance requirement~~

~~See 14.2.4.1.~~

### ~~14.2.40.2 Test purpose~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.40.~~

### ~~14.2.40.3 Method of test~~

~~Uplink TFS:~~

|     | TFI       | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | RB8<br>(64-kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x336            | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336            | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x336            | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 3x336            | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 4x336            | N/A   |

~~Uplink TFCS:~~

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| UL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| UL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| UL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| UL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| UL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| UL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| UL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| UL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| UL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| UL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| UL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| UL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| UL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| UL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| UL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| UL_TFC15 | (TF0, TF0, TF0, TF0, TF1)  |
| UL_TFC16 | (TF1, TF0, TF0, TF0, TF1)  |
| UL_TFC17 | (TF2, TF1, TF1, TF0, TF1)  |
| UL_TFC18 | (TF0, TF0, TF0, TF1, TF1)  |
| UL_TFC19 | (TF1, TF0, TF0, TF1, TF1)  |
| UL_TFC20 | (TF2, TF1, TF1, TF1, TF1)  |
| UL_TFC21 | (TF0, TF0, TF0, TF2, TF1)  |
| UL_TFC22 | (TF1, TF0, TF0, TF2, TF1)  |
| UL_TFC23 | (TF2, TF1, TF1, TF2, TF1)  |
| UL_TFC24 | (TF0, TF0, TF0, TF3, TF1)  |
| UL_TFC25 | (TF1, TF0, TF0, TF3, TF1)  |
| UL_TFC26 | (TF2, TF1, TF1, TF3, TF1)  |
| UL_TFC27 | (TF0, TF0, TF0, TF4, TF1)  |
| UL_TFC28 | (TF1, TF0, TF0, TF4, TF1)  |
| UL_TFC29 | (TF2, TF1, TF1, TF4, TF1)  |

## Downlink TFS:

|            |           | <b>RB5<br/>(RAB subflow #1)</b> | <b>RB6<br/>(RAB subflow #2)</b> | <b>RB7<br/>(RAB subflow #3)</b> | <b>RB8<br/>(64 kbps)</b> | <b>DCCH</b> |
|------------|-----------|---------------------------------|---------------------------------|---------------------------------|--------------------------|-------------|
| <b>TFS</b> | TF0, bits | 1x0                             | 0x103                           | 0x60                            | 0x336                    | 0x148       |
|            | TF1, bits | 1x39                            | 1x103                           | 1x60                            | 1x336                    | 1x148       |
|            | TF2, bits | 1x81                            | N/A                             | N/A                             | 2x336                    | N/A         |
|            | TF3, bits | N/A                             | N/A                             | N/A                             | 3x336                    | N/A         |
|            | TF4, bits | N/A                             | N/A                             | N/A                             | 4x336                    | N/A         |

## Downlink TFCs:

| <b>TFCI</b> | <b>(RB5, RB6, RB7, RB8, DCCH)</b> |
|-------------|-----------------------------------|
| DL_TFC0     | (TF0, TF0, TF0, TF0, TF0)         |
| DL_TFC1     | (TF1, TF0, TF0, TF0, TF0)         |
| DL_TFC2     | (TF2, TF1, TF1, TF0, TF0)         |
| DL_TFC3     | (TF0, TF0, TF0, TF1, TF0)         |
| DL_TFC4     | (TF1, TF0, TF0, TF1, TF0)         |
| DL_TFC5     | (TF2, TF1, TF1, TF1, TF0)         |
| DL_TFC6     | (TF0, TF0, TF0, TF2, TF0)         |
| DL_TFC7     | (TF1, TF0, TF0, TF2, TF0)         |
| DL_TFC8     | (TF2, TF1, TF1, TF2, TF0)         |
| DL_TFC9     | (TF0, TF0, TF0, TF3, TF0)         |
| DL_TFC10    | (TF1, TF0, TF0, TF3, TF0)         |
| DL_TFC11    | (TF2, TF1, TF1, TF3, TF0)         |
| DL_TFC12    | (TF0, TF0, TF0, TF4, TF0)         |
| DL_TFC13    | (TF1, TF0, TF0, TF4, TF0)         |
| DL_TFC14    | (TF2, TF1, TF1, TF4, TF0)         |
| DL_TFC15    | (TF0, TF0, TF0, TF0, TF1)         |
| DL_TFC16    | (TF1, TF0, TF0, TF0, TF1)         |
| DL_TFC17    | (TF2, TF1, TF1, TF0, TF1)         |
| DL_TFC18    | (TF0, TF0, TF0, TF1, TF1)         |
| DL_TFC19    | (TF1, TF0, TF0, TF1, TF1)         |
| DL_TFC20    | (TF2, TF1, TF1, TF1, TF1)         |
| DL_TFC21    | (TF0, TF0, TF0, TF2, TF1)         |
| DL_TFC22    | (TF1, TF0, TF0, TF2, TF1)         |
| DL_TFC23    | (TF2, TF1, TF1, TF2, TF1)         |
| DL_TFC24    | (TF0, TF0, TF0, TF3, TF1)         |
| DL_TFC25    | (TF1, TF0, TF0, TF3, TF1)         |
| DL_TFC26    | (TF2, TF1, TF1, TF3, TF1)         |
| DL_TFC27    | (TF0, TF0, TF0, TF4, TF1)         |
| DL_TFC28    | (TF1, TF0, TF0, TF4, TF1)         |
| DL_TFC29    | (TF2, TF1, TF1, TF4, TF1)         |

Sub-tests:

| Sub-test                                                                                | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely-tested                             | Restricted-UL TFCIs                            | UL-RLC SDU-size (bits) (note)               | Test data-size (bits) (note)                              |
|-----------------------------------------------------------------------------------------|--------------------------|------------------------|------------------------------------------------|------------------------------------------------|---------------------------------------------|-----------------------------------------------------------|
| 1                                                                                       | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC1,<br>UL_TFC15,<br>UL_TFC16  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data   |
| 2                                                                                       | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC2,<br>UL_TFC15,<br>UL_TFC17  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data            |
| 3                                                                                       | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC3,<br>UL_TFC15,<br>UL_TFC18  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 312  |
| 4                                                                                       | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC15,<br>DUL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC15,<br>UL_TFC19  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 312       |
| 5                                                                                       | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC5,<br>UL_TFC15,<br>UL_TFC20  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312                |
| 6                                                                                       | DL_TFC6                  | UL_TFC6                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC6,<br>UL_TFC15,<br>UL_TFC21  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 632  |
| 7                                                                                       | DL_TFC7                  | UL_TFC7                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC7,<br>UL_TFC15,<br>UL_TFC22  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 632       |
| 8                                                                                       | DL_TFC8                  | UL_TFC8                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC8,<br>UL_TFC15,<br>UL_TFC23  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632                |
| 9                                                                                       | DL_TFC9                  | UL_TFC9                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC9,<br>UL_TFC15,<br>UL_TFC24  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 952  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 952  |
| 10                                                                                      | DL_TFC10                 | UL_TFC10               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC10,<br>UL_TFC15,<br>UL_TFC25 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 952  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 952       |
| 11                                                                                      | DL_TFC11                 | UL_TFC11               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC11,<br>UL_TFC15,<br>UL_TFC26 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 952  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 952                |
| 12                                                                                      | DL_TFC12                 | UL_TFC12               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 1272 |
| 13                                                                                      | DL_TFC13                 | UL_TFC13               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 1272      |
| 14                                                                                      | DL_TFC14                 | UL_TFC14               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272               |
| NOTE: — See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                                |                                                |                                             |                                                           |

See 14.1.1 for test procedure.

#### 14.2.40.4 ~~Test requirements~~

See 14.1.1 for definition of step 10 and step 15.

- ~~1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.~~
- ~~2. At step 15 the UE transmitted transport format shall be~~
  - ~~— for sub-test 1: RB5/TF1 (1x39).~~
  - ~~— for sub-test 2: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).~~
  - ~~— for sub-test 3: RB8/TF1 (1x336)~~
  - ~~— for sub-test 4: RB5/TF1 (1x39) and RB8/TF1 (1x336).~~
  - ~~— for sub-test 5: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF1 (1x336).~~
  - ~~— for sub-test 6: RB8/TF2 (2x336)~~
  - ~~— for sub-test 7: RB5/TF1 (1x39) and RB8/TF2 (2x336).~~
  - ~~— for sub-test 8: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF2 (2x336).~~
  - ~~— for sub-test 9: RB8/TF3 (3x336)~~
  - ~~— for sub-test 10: RB5/TF1 (1x39) and RB8/TF3 (3x336).~~
  - ~~— for sub-test 11: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF3 (3x336).~~
  - ~~— for sub-test 12: RB8/TF4 (4x336)~~
  - ~~— for sub-test 13: RB5/TF1 (1x39) and RB8/TF4 (4x336).~~
  - ~~— for sub-test 14: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF4 (4x336).~~
- ~~3. At step 15 the UE shall return~~
  - ~~— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6, RB7 and RB8.~~
  - ~~— for sub-test 2: an RLC SDU on RB5, RB6 and RB7 having the same content as sent by SS; and no data shall be received on RB8.~~
  - ~~— for sub-test 3, 6, 9 and 12: an RLC SDU on RB8 having the same content as sent by SS; and no data shall be received on RB5, RB6 and RB7.~~
  - ~~— for sub-test 4, 7, 10 and 13: an RLC SDU on RB5 and RB8 having the same content as sent by SS; and no data shall be received on RB6 and RB7.~~
  - ~~— for sub-test 5, 8, 11 and 14: an RLC SDU on RB5, RB6, RB7 and RB8 having the same content as sent by SS.~~

#### ~~14.2.41 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

##### ~~14.2.41.1 Conformance requirement~~

~~See 14.2.4.1.~~

##### ~~14.2.41.2 Test purpose~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.41.~~

## 14.2.41.3 Method of test

Uplink-TFS:

|     | TFI       | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | RB8<br>(64-kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x336            | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336            | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x336            | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 3x336            | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 4x336            | N/A   |

Uplink-TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| UL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| UL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| UL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| UL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| UL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| UL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| UL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| UL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| UL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| UL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| UL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| UL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| UL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| UL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| UL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| UL_TFC15 | (TF0, TF0, TF0, TF0, TF1)  |
| UL_TFC16 | (TF1, TF0, TF0, TF0, TF1)  |
| UL_TFC17 | (TF2, TF1, TF1, TF0, TF1)  |
| UL_TFC18 | (TF0, TF0, TF0, TF1, TF1)  |
| UL_TFC19 | (TF1, TF0, TF0, TF1, TF1)  |
| UL_TFC20 | (TF2, TF1, TF1, TF1, TF1)  |
| UL_TFC21 | (TF0, TF0, TF0, TF2, TF1)  |
| UL_TFC22 | (TF1, TF0, TF0, TF2, TF1)  |
| UL_TFC23 | (TF2, TF1, TF1, TF2, TF1)  |
| UL_TFC24 | (TF0, TF0, TF0, TF3, TF1)  |
| UL_TFC25 | (TF1, TF0, TF0, TF3, TF1)  |
| UL_TFC26 | (TF2, TF1, TF1, TF3, TF1)  |
| UL_TFC27 | (TF0, TF0, TF0, TF4, TF1)  |
| UL_TFC28 | (TF1, TF0, TF0, TF4, TF1)  |
| UL_TFC29 | (TF2, TF1, TF1, TF4, TF1)  |

Downlink-TFS:

|     |           | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | RB8<br>(128-kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x103                   | 0x60                    | 0x336             | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336             | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x336             | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 4x336             | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 8x336             | N/A   |



## Downlink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| DL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| DL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| DL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| DL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| DL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| DL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| DL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| DL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| DL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| DL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| DL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| DL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| DL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| DL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| DL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| DL_TFC15 | (TF0, TF0, TF0, TF0, TF1)  |
| DL_TFC16 | (TF1, TF0, TF0, TF0, TF1)  |
| DL_TFC17 | (TF2, TF1, TF1, TF0, TF1)  |
| DL_TFC18 | (TF0, TF0, TF0, TF1, TF1)  |
| DL_TFC19 | (TF1, TF0, TF0, TF1, TF1)  |
| DL_TFC20 | (TF2, TF1, TF1, TF1, TF1)  |
| DL_TFC21 | (TF0, TF0, TF0, TF2, TF1)  |
| DL_TFC22 | (TF1, TF0, TF0, TF2, TF1)  |
| DL_TFC23 | (TF2, TF1, TF1, TF2, TF1)  |
| DL_TFC24 | (TF0, TF0, TF0, TF3, TF1)  |
| DL_TFC25 | (TF1, TF0, TF0, TF3, TF1)  |
| DL_TFC26 | (TF2, TF1, TF1, TF3, TF1)  |
| DL_TFC27 | (TF0, TF0, TF0, TF4, TF1)  |
| DL_TFC28 | (TF1, TF0, TF0, TF4, TF1)  |
| DL_TFC29 | (TF2, TF1, TF1, TF4, TF1)  |

Sub-tests:

| Sub-test                                                                               | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely-tested                            | Restricted-UL TFCIs                            | UL-RLC-SDU size (bits) (note)               | Test data-size (bits) (note)                              |
|----------------------------------------------------------------------------------------|--------------------------|------------------------|-----------------------------------------------|------------------------------------------------|---------------------------------------------|-----------------------------------------------------------|
| 1                                                                                      | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC15,<br>UL_TFC16  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data   |
| 2                                                                                      | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC15,<br>UL_TFC17  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data            |
| 3                                                                                      | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC15,<br>UL_TFC18  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 312  |
| 4                                                                                      | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC15,<br>UL_TFC19  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 312       |
| 5                                                                                      | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC15,<br>UL_TFC20  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312                |
| 6                                                                                      | DL_TFC6                  | UL_TFC6                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC15,<br>UL_TFC21  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 632  |
| 7                                                                                      | DL_TFC7                  | UL_TFC7                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC15,<br>UL_TFC22  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 632       |
| 8                                                                                      | DL_TFC8                  | UL_TFC8                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC15,<br>UL_TFC23  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632                |
| 9                                                                                      | DL_TFC9                  | UL_TFC9                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC15,<br>UL_TFC24  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 1272 |
| 10                                                                                     | DL_TFC10                 | UL_TFC10               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC10,<br>UL_TFC15,<br>UL_TFC25 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 1272      |
| 11                                                                                     | DL_TFC11                 | UL_TFC11               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC11,<br>UL_TFC15,<br>UL_TFC26 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272               |
| 12                                                                                     | DL_TFC12                 | UL_TFC12               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 2552 |
| 13                                                                                     | DL_TFC13                 | UL_TFC13               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 2552      |
| 14                                                                                     | DL_TFC14                 | UL_TFC14               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2552               |
| NOTE:— See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                               |                                                |                                             |                                                           |

See 14.1.1 for test procedure.

#### ~~14.2.41.4 Test requirements~~

~~See 14.1.1 for definition of step 10 and step 15.~~

~~1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.~~

~~2. At step 15 the UE transmitted transport format shall be~~

~~— for sub-test 1: RB5/TF1 (1x39).~~

~~— for sub-test 2: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).~~

~~— for sub-test 3: RB8/TF1 (1x336)~~

~~— for sub-test 4: RB5/TF1 (1x39) and RB8/TF1 (1x336).~~

~~— for sub-test 5: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF1 (1x336).~~

~~— for sub-test 6: RB8/TF2 (2x336)~~

~~— for sub-test 7: RB5/TF1 (1x39) and RB8/TF2 (2x336).~~

~~— for sub-test 8: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF2 (2x336).~~

~~— for sub-test 9: RB8/TF3 (3x336)~~

~~— for sub-test 10: RB5/TF1 (1x39) and RB8/TF3 (3x336).~~

~~— for sub-test 11: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF3 (3x336).~~

~~— for sub-test 12: RB8/TF4 (4x336)~~

~~— for sub-test 13: RB5/TF1 (1x39) and RB8/TF4 (4x336).~~

~~— for sub-test 14: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF4 (4x336).~~

~~3. At step 15 the UE shall return~~

~~— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6, RB7 and RB8.~~

~~— for sub-test 2: an RLC SDU on RB5, RB6 and RB7 having the same content as sent by SS; and no data shall be received on RB8.~~

~~— for sub-test 3, 6, 9 and 12: an RLC SDU on RB8 having the same content as sent by SS; and no data shall be received on RB5, RB6 and RB7.~~

~~— for sub-test 4, 7, 10 and 13: an RLC SDU on RB5 and RB8 having the same content as sent by SS; and no data shall be received on RB6 and RB7.~~

~~— for sub-test 5, 8, 11 and 14: an RLC SDU on RB5, RB6, RB7 and RB8 having the same content as sent by SS.~~

#### ~~14.2.42 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

##### ~~14.2.42.1 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:256 kbps / PS RAB / 10 ms TTI~~

###### ~~14.2.42.1.1 Conformance requirement~~

~~See 14.2.4.1.~~

### 14.2.42.1.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.42 for the downlink 10 ms TTI case.

### 14.2.42.1.3 Method of test

Uplink TFS:

|     | TFI       | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | RB7<br>(RAB subflow #3) | RB8<br>(64 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x336            | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336            | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x336            | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 3x336            | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 4x336            | N/A   |

Uplink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| UL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| UL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| UL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| UL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| UL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| UL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| UL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| UL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| UL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| UL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| UL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| UL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| UL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| UL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| UL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| UL_TFC15 | (TF0, TF0, TF0, TF0, TF1)  |
| UL_TFC16 | (TF1, TF0, TF0, TF0, TF1)  |
| UL_TFC17 | (TF2, TF1, TF1, TF0, TF1)  |
| UL_TFC18 | (TF0, TF0, TF0, TF1, TF1)  |
| UL_TFC19 | (TF1, TF0, TF0, TF1, TF1)  |
| UL_TFC20 | (TF2, TF1, TF1, TF1, TF1)  |
| UL_TFC21 | (TF0, TF0, TF0, TF2, TF1)  |
| UL_TFC22 | (TF1, TF0, TF0, TF2, TF1)  |
| UL_TFC23 | (TF2, TF1, TF1, TF2, TF1)  |
| UL_TFC24 | (TF0, TF0, TF0, TF3, TF1)  |
| UL_TFC25 | (TF1, TF0, TF0, TF3, TF1)  |
| UL_TFC26 | (TF2, TF1, TF1, TF3, TF1)  |
| UL_TFC27 | (TF0, TF0, TF0, TF4, TF1)  |
| UL_TFC28 | (TF1, TF0, TF0, TF4, TF1)  |
| UL_TFC29 | (TF2, TF1, TF1, TF4, TF1)  |

Downlink TFS:

|     |           | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | RB7<br>(RAB subflow #3) | RB8<br>(256 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x103                   | 0x60                    | 0x336             | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336             | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x336             | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 4x336             | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 8x336             | N/A   |

Downlink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| DL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| DL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| DL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| DL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| DL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| DL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| DL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| DL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| DL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| DL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| DL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| DL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| DL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| DL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| DL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| DL_TFC15 | (TF0, TF0, TF0, TF0, TF1)  |
| DL_TFC16 | (TF1, TF0, TF0, TF0, TF1)  |
| DL_TFC17 | (TF2, TF1, TF1, TF0, TF1)  |
| DL_TFC18 | (TF0, TF0, TF0, TF1, TF1)  |
| DL_TFC19 | (TF1, TF0, TF0, TF1, TF1)  |
| DL_TFC20 | (TF2, TF1, TF1, TF1, TF1)  |
| DL_TFC21 | (TF0, TF0, TF0, TF2, TF1)  |
| DL_TFC22 | (TF1, TF0, TF0, TF2, TF1)  |
| DL_TFC23 | (TF2, TF1, TF1, TF2, TF1)  |
| DL_TFC24 | (TF0, TF0, TF0, TF3, TF1)  |
| DL_TFC25 | (TF1, TF0, TF0, TF3, TF1)  |
| DL_TFC26 | (TF2, TF1, TF1, TF3, TF1)  |
| DL_TFC27 | (TF0, TF0, TF0, TF4, TF1)  |
| DL_TFC28 | (TF1, TF0, TF0, TF4, TF1)  |
| DL_TFC29 | (TF2, TF1, TF1, TF4, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely-tested                            | Restricted-UL TFCIs                            | UL RLC SDU size (bits) (note)               | Test data-size (bits) (note)                              |
|----------|--------------------------|------------------------|-----------------------------------------------|------------------------------------------------|---------------------------------------------|-----------------------------------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC15,<br>UL_TFC16  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data   |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC15,<br>UL_TFC17  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data            |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC15,<br>UL_TFC18  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 312  |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC15,<br>UL_TFC19  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 312       |
| 5        | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC15,<br>UL_TFC20  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312                |
| 6        | DL_TFC6                  | UL_TFC6                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC15,<br>UL_TFC21  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 632  |
| 7        | DL_TFC7                  | UL_TFC7                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC15,<br>UL_TFC22  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 632       |
| 8        | DL_TFC8                  | UL_TFC8                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC15,<br>UL_TFC23  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632                |
| 9        | DL_TFC9                  | UL_TFC9                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC15,<br>UL_TFC24  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 1272 |
| 10       | DL_TFC10                 | UL_TFC10               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC10,<br>UL_TFC15,<br>UL_TFC25 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 1272      |
| 11       | DL_TFC11                 | UL_TFC11               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC11,<br>UL_TFC15,<br>UL_TFC26 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272               |
| 12       | DL_TFC12                 | UL_TFC12               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 2552 |
| 13       | DL_TFC13                 | UL_TFC13               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 2552      |
| 14       | DL_TFC14                 | UL_TFC14               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2552               |

NOTE: — See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### ~~14.2.42.1.4 Test requirements~~

See 14.1.1 for definition of step 10 and step 15.

- ~~1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.~~
- ~~2. At step 15 the UE transmitted transport format shall be~~
  - ~~— for sub-test 1: RB5/TF1 (1x39).~~
  - ~~— for sub-test 2: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).~~
  - ~~— for sub-test 3: RB8/TF1 (1x336)~~
  - ~~— for sub-test 4: RB5/TF1 (1x39) and RB8/TF1 (1x336).~~
  - ~~— for sub-test 5: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF1 (1x336).~~
  - ~~— for sub-test 6: RB8/TF2 (2x336)~~
  - ~~— for sub-test 7: RB5/TF1 (1x39) and RB8/TF2 (2x336).~~
  - ~~— for sub-test 8: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF2 (2x336).~~
  - ~~— for sub-test 9: RB8/TF3 (3x336)~~
  - ~~— for sub-test 10: RB5/TF1 (1x39) and RB8/TF3 (3x336).~~
  - ~~— for sub-test 11: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF3 (3x336).~~
  - ~~— for sub-test 12: RB8/TF4 (4x336)~~
  - ~~— for sub-test 13: RB5/TF1 (1x39) and RB8/TF4 (4x336).~~
  - ~~— for sub-test 14: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF4 (4x336).~~
- ~~3. At step 15 the UE shall return~~
  - ~~— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6, RB7 and RB8.~~
  - ~~— for sub-test 2: an RLC SDU on RB5, RB6 and RB7 having the same content as sent by SS; and no data shall be received on RB8.~~
  - ~~— for sub-test 3, 6, 9 and 12: an RLC SDU on RB8 having the same content as sent by SS; and no data shall be received on RB5, RB6 and RB7.~~
  - ~~— for sub-test 4, 7, 10 and 13: an RLC SDU on RB5 and RB8 having the same content as sent by SS; and no data shall be received on RB6 and RB7.~~
  - ~~— for sub-test 5, 8, 11 and 14: an RLC SDU on RB5, RB6, RB7 and RB8 having the same content as sent by SS.~~

#### ~~14.2.42.2 Conversational / speech / UL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:256 kbps / PS RAB / 20 ms TTI~~

##### ~~14.2.42.2.1 Conformance requirement~~

See 14.2.4.1.

##### ~~14.2.42.2.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.42 for the downlink 20 ms TTI case.

## 14.2.42.2.3 Method of test

Uplink-TFS:

|     | TFI       | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | RB8<br>(64-kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x336            | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336            | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x336            | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 3x336            | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 4x336            | N/A   |

Uplink-TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| UL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| UL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| UL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| UL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| UL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| UL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| UL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| UL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| UL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| UL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| UL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| UL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| UL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| UL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| UL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| UL_TFC15 | (TF0, TF0, TF0, TF0, TF1)  |
| UL_TFC16 | (TF1, TF0, TF0, TF0, TF1)  |
| UL_TFC17 | (TF2, TF1, TF1, TF0, TF1)  |
| UL_TFC18 | (TF0, TF0, TF0, TF1, TF1)  |
| UL_TFC19 | (TF1, TF0, TF0, TF1, TF1)  |
| UL_TFC20 | (TF2, TF1, TF1, TF1, TF1)  |
| UL_TFC21 | (TF0, TF0, TF0, TF2, TF1)  |
| UL_TFC22 | (TF1, TF0, TF0, TF2, TF1)  |
| UL_TFC23 | (TF2, TF1, TF1, TF2, TF1)  |
| UL_TFC24 | (TF0, TF0, TF0, TF3, TF1)  |
| UL_TFC25 | (TF1, TF0, TF0, TF3, TF1)  |
| UL_TFC26 | (TF2, TF1, TF1, TF3, TF1)  |
| UL_TFC27 | (TF0, TF0, TF0, TF4, TF1)  |
| UL_TFC28 | (TF1, TF0, TF0, TF4, TF1)  |
| UL_TFC29 | (TF2, TF1, TF1, TF4, TF1)  |

Downlink-TFS:

|     |           | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | RB8<br>(256-kbps,<br>20-ms) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-----------------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x103                   | 0x60                    | 0x336                       | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336                       | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x336                       | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 4x336                       | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 8x336                       | N/A   |
|     | TF5, bits | N/A                     | N/A                     | N/A                     | 12x336                      | N/A   |
|     | TF6, bits | N/A                     | N/A                     | N/A                     | 16x336                      | N/A   |



## Downlink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| DL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| DL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| DL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| DL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| DL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| DL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| DL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| DL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| DL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| DL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| DL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| DL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| DL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| DL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| DL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| DL_TFC15 | (TF0, TF0, TF0, TF5, TF0)  |
| DL_TFC16 | (TF1, TF0, TF0, TF5, TF0)  |
| DL_TFC17 | (TF2, TF1, TF1, TF5, TF0)  |
| DL_TFC18 | (TF0, TF0, TF0, TF6, TF0)  |
| DL_TFC19 | (TF1, TF0, TF0, TF6, TF0)  |
| DL_TFC20 | (TF2, TF1, TF1, TF6, TF0)  |
| DL_TFC21 | (TF0, TF0, TF0, TF0, TF1)  |
| DL_TFC22 | (TF1, TF0, TF0, TF0, TF1)  |
| DL_TFC23 | (TF2, TF1, TF1, TF0, TF1)  |
| DL_TFC24 | (TF0, TF0, TF0, TF1, TF1)  |
| DL_TFC25 | (TF1, TF0, TF0, TF1, TF1)  |
| DL_TFC26 | (TF2, TF1, TF1, TF1, TF1)  |
| DL_TFC27 | (TF0, TF0, TF0, TF2, TF1)  |
| DL_TFC28 | (TF1, TF0, TF0, TF2, TF1)  |
| DL_TFC29 | (TF2, TF1, TF1, TF2, TF1)  |
| DL_TFC30 | (TF0, TF0, TF0, TF3, TF1)  |
| DL_TFC31 | (TF1, TF0, TF0, TF3, TF1)  |
| DL_TFC32 | (TF2, TF1, TF1, TF3, TF1)  |
| DL_TFC33 | (TF0, TF0, TF0, TF4, TF1)  |
| DL_TFC34 | (TF1, TF0, TF0, TF4, TF1)  |
| DL_TFC35 | (TF2, TF1, TF1, TF4, TF1)  |
| DL_TFC36 | (TF0, TF0, TF0, TF5, TF1)  |
| DL_TFC37 | (TF1, TF0, TF0, TF5, TF1)  |
| DL_TFC38 | (TF2, TF1, TF1, TF5, TF1)  |
| DL_TFC39 | (TF0, TF0, TF0, TF6, TF1)  |
| DL_TFC40 | (TF1, TF0, TF0, TF6, TF1)  |
| DL_TFC41 | (TF2, TF1, TF1, TF6, TF1)  |

## Sub-tests:

| Sub-test | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely-tested                            | Restricted-UL TFCIs                            | UL-RLC-SDU size (bits) (note)               | Test data size (bits) (note)                              |
|----------|--------------------------|------------------------|-----------------------------------------------|------------------------------------------------|---------------------------------------------|-----------------------------------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC15,<br>UL_TFC16  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data   |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC15,<br>UL_TFC17  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data            |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC15,<br>UL_TFC18  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 312  |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC15,<br>UL_TFC19  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 312       |
| 5        | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC15,<br>UL_TFC20  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312                |
| 6        | DL_TFC6                  | UL_TFC6                | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC15,<br>UL_TFC21  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 632  |
| 7        | DL_TFC7                  | UL_TFC7                | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC15,<br>UL_TFC22  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 632       |
| 8        | DL_TFC8                  | UL_TFC8                | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC15,<br>UL_TFC23  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632                |
| 9        | DL_TFC9                  | UL_TFC9                | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC15,<br>UL_TFC24  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 1272 |
| 10       | DL_TFC10                 | UL_TFC10               | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC10,<br>UL_TFC15,<br>UL_TFC25 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 1272      |
| 11       | DL_TFC11                 | UL_TFC11               | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC11,<br>UL_TFC15,<br>UL_TFC26 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272               |
| 12       | DL_TFC12                 | UL_TFC12               | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 2552 |
| 13       | DL_TFC13                 | UL_TFC13               | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 2552      |
| 14       | DL_TFC14                 | UL_TFC14               | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2552               |
| 15       | DL_TFC15                 | UL_TFC12               | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 3832 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 3832 |

| Sub-test                                                                              | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                            | Restricted-UL TFCIs                            | UL RLC SDU size (bits) (note)               | Test data size (bits) (note)                              |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|-----------------------------------------------|------------------------------------------------|---------------------------------------------|-----------------------------------------------------------|
| 16                                                                                    | DL_TFC16                 | UL_TFC13               | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 3832 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 3832      |
| 17                                                                                    | DL_TFC17                 | UL_TFC14               | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 3832 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 3832               |
| 18                                                                                    | DL_TFC18                 | UL_TFC12               | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 5112 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 5112 |
| 19                                                                                    | DL_TFC19                 | UL_TFC13               | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 5112 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 5112      |
| 20                                                                                    | DL_TFC20                 | UL_TFC14               | DL_TFC0,<br>DL_TFC21,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 5112 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 5112               |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                               |                                                |                                             |                                                           |

See 14.1.1 for test procedure.

#### 14.2.42.2.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

- for sub-test 1: RB5/TF1 (1x39).
- for sub-test 2: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).
- for sub-test 3: RB8/TF1 (1x336)
- for sub-test 4: RB5/TF1 (1x39) and RB8/TF1 (1x336).
- for sub-test 5: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF1 (1x336).
- for sub-test 6: RB8/TF2 (2x336)
- for sub-test 7: RB5/TF1 (1x39) and RB8/TF2 (2x336).
- for sub-test 8: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF2 (2x336).
- for sub-test 9: RB8/TF3 (3x336)
- for sub-test 10: RB5/TF1 (1x39) and RB8/TF3 (3x336).
- for sub-test 11: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF3 (3x336).
- for sub-test 12, 15 and 18: RB8/TF4 (4x336)
- for sub-test 13, 16 and 19: RB5/TF1 (1x39) and RB8/TF4 (4x336).
- for sub-test 14, 17 and 20: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF4 (4x336).

3. At step 15 the UE shall return

- for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6, RB7 and RB8.
- for sub-test 2: an RLC SDU on RB5, RB6 and RB7 having the same content as sent by SS; and no data shall be received on RB8.
- for sub-test 3, 6, 9, 12, 15 and 18: an RLC SDU on RB8 having the same content as sent by SS; and no data shall be received on RB5, RB6 and RB7.
- for sub-test 4, 7, 10, 13, 16 and 19: an RLC SDU on RB5 and RB8 having the same content as sent by SS; and no data shall be received on RB6 and RB7.
- for sub-test 5, 8, 11, 14, 17 and 20: an RLC SDU on RB5, RB6, RB7 and RB8 having the same content as sent by SS.

#### ~~14.2.43 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

##### ~~14.2.43.1 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:384 kbps / PS RAB / 10 ms TTI~~

###### ~~14.2.43.1.1 Conformance requirement~~

See 14.2.4.1.

###### ~~14.2.43.1.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.43 for the downlink 10 ms TTI case.

###### ~~14.2.43.1.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | RB7<br>(RAB subflow #3) | RB8<br>(64 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x336            | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336            | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x336            | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 3x336            | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 4x336            | N/A   |

## Uplink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| UL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| UL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| UL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| UL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| UL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| UL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| UL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| UL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| UL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| UL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| UL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| UL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| UL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| UL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| UL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| UL_TFC15 | (TF0, TF0, TF0, TF0, TF1)  |
| UL_TFC16 | (TF1, TF0, TF0, TF0, TF1)  |
| UL_TFC17 | (TF2, TF1, TF1, TF0, TF1)  |
| UL_TFC18 | (TF0, TF0, TF0, TF1, TF1)  |
| UL_TFC19 | (TF1, TF0, TF0, TF1, TF1)  |
| UL_TFC20 | (TF2, TF1, TF1, TF1, TF1)  |
| UL_TFC21 | (TF0, TF0, TF0, TF2, TF1)  |
| UL_TFC22 | (TF1, TF0, TF0, TF2, TF1)  |
| UL_TFC23 | (TF2, TF1, TF1, TF2, TF1)  |
| UL_TFC24 | (TF0, TF0, TF0, TF3, TF1)  |
| UL_TFC25 | (TF1, TF0, TF0, TF3, TF1)  |
| UL_TFC26 | (TF2, TF1, TF1, TF3, TF1)  |
| UL_TFC27 | (TF0, TF0, TF0, TF4, TF1)  |
| UL_TFC28 | (TF1, TF0, TF0, TF4, TF1)  |
| UL_TFC29 | (TF2, TF1, TF1, TF4, TF1)  |

## Downlink TFS:

|     |           | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | RB7<br>(RAB subflow #3) | RB8<br>(384 kbps,<br>10 ms) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-----------------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x103                   | 0x60                    | 0x336                       | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336                       | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x336                       | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 4x336                       | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 8x336                       | N/A   |
|     | TF5, bits | N/A                     | N/A                     | N/A                     | 12x336                      | N/A   |

## Downlink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| DL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| DL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| DL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| DL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| DL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| DL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| DL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| DL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| DL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| DL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| DL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| DL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| DL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| DL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| DL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| DL_TFC15 | (TF0, TF0, TF0, TF5, TF0)  |
| DL_TFC16 | (TF1, TF0, TF0, TF5, TF0)  |
| DL_TFC17 | (TF2, TF1, TF1, TF5, TF0)  |
| DL_TFC18 | (TF0, TF0, TF0, TF0, TF1)  |
| DL_TFC19 | (TF1, TF0, TF0, TF0, TF1)  |
| DL_TFC20 | (TF2, TF1, TF1, TF0, TF1)  |
| DL_TFC21 | (TF0, TF0, TF0, TF1, TF1)  |
| DL_TFC22 | (TF1, TF0, TF0, TF1, TF1)  |
| DL_TFC23 | (TF2, TF1, TF1, TF1, TF1)  |
| DL_TFC24 | (TF0, TF0, TF0, TF2, TF1)  |
| DL_TFC25 | (TF1, TF0, TF0, TF2, TF1)  |
| DL_TFC26 | (TF2, TF1, TF1, TF2, TF1)  |
| DL_TFC27 | (TF0, TF0, TF0, TF3, TF1)  |
| DL_TFC28 | (TF1, TF0, TF0, TF3, TF1)  |
| DL_TFC29 | (TF2, TF1, TF1, TF3, TF1)  |
| DL_TFC30 | (TF0, TF0, TF0, TF4, TF1)  |
| DL_TFC31 | (TF1, TF0, TF0, TF4, TF1)  |
| DL_TFC32 | (TF2, TF1, TF1, TF4, TF1)  |
| DL_TFC33 | (TF0, TF0, TF0, TF5, TF1)  |
| DL_TFC34 | (TF1, TF0, TF0, TF5, TF1)  |
| DL_TFC35 | (TF2, TF1, TF1, TF5, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely-tested                            | Restricted-UL TFCIs                            | UL-RLC-SDU size (bits) (note)               | Test data size (bits) (note)                              |
|----------|--------------------------|------------------------|-----------------------------------------------|------------------------------------------------|---------------------------------------------|-----------------------------------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC15,<br>UL_TFC16  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data   |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC15,<br>UL_TFC17  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data            |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC15,<br>UL_TFC18  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 312  |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC15,<br>UL_TFC19  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 312       |
| 5        | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC15,<br>UL_TFC20  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312                |
| 6        | DL_TFC6                  | UL_TFC6                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC15,<br>UL_TFC21  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 632  |
| 7        | DL_TFC7                  | UL_TFC7                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC15,<br>UL_TFC22  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 632       |
| 8        | DL_TFC8                  | UL_TFC8                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC15,<br>UL_TFC23  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632                |
| 9        | DL_TFC9                  | UL_TFC9                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC15,<br>UL_TFC24  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 1272 |
| 10       | DL_TFC10                 | UL_TFC10               | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC10,<br>UL_TFC15,<br>UL_TFC25 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 1272      |
| 11       | DL_TFC11                 | UL_TFC11               | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC11,<br>UL_TFC15,<br>UL_TFC26 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272               |
| 12       | DL_TFC12                 | UL_TFC12               | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 2552 |
| 13       | DL_TFC13                 | UL_TFC13               | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 2552      |
| 14       | DL_TFC14                 | UL_TFC14               | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2552               |
| 15       | DL_TFC15                 | UL_TFC12               | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 3832 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 3832 |

| Sub-test                                                                              | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitly tested                             | Restricted UL TFCs                             | UL RLC SDU size (bits) (note)               | Test data size (bits) (note)                         |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|-----------------------------------------------|------------------------------------------------|---------------------------------------------|------------------------------------------------------|
| 16                                                                                    | DL_TFC16                 | UL_TFC13               | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 3832 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 3832 |
| 17                                                                                    | DL_TFC17                 | UL_TFC14               | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 3832 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 3832          |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                               |                                                |                                             |                                                      |

See 14.1.1 for test procedure.

#### 14.2.43.1.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

- for sub-test 1: RB5/TF1 (1x39).
- for sub-test 2: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).
- for sub-test 3: RB8/TF1 (1x336)
- for sub-test 4: RB5/TF1 (1x39) and RB8/TF1 (1x336).
- for sub-test 5: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF1 (1x336).
- for sub-test 6: RB8/TF2 (2x336)
- for sub-test 7: RB5/TF1 (1x39) and RB8/TF2 (2x336).
- for sub-test 8: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF2 (2x336).
- for sub-test 9: RB8/TF3 (3x336)
- for sub-test 10: RB5/TF1 (1x39) and RB8/TF3 (3x336).
- for sub-test 11: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF3 (3x336).
- for sub-test 12 and 15: RB8/TF4 (4x336)
- for sub-test 13 and 16: RB5/TF1 (1x39) and RB8/TF4 (4x336).
- for sub-test 14 and 17: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF4 (4x336).

3. At step 15 the UE shall return

- for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6, RB7 and RB8.
- for sub-test 2: an RLC SDU on RB5, RB6 and RB7 having the same content as sent by SS; and no data shall be received on RB8.
- for sub-test 3, 6, 9, 12 and 15: an RLC SDU on RB8 having the same content as sent by SS; and no data shall be received on RB5, RB6 and RB7.
- for sub-test 4, 7, 10, 13 and 16: an RLC SDU on RB5 and RB8 having the same content as sent by SS; and no data shall be received on RB6 and RB7.



- for sub-test 5, 8, 11, 14, and 17: an RLC SDU on RB5, RB6, RB7 and RB8 having the same content as sent by SS.

### ~~14.2.43.2 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:384 kbps / PS RAB / 20 ms TTI~~

#### ~~14.2.43.2.1 Conformance requirement~~

See 14.2.4.1.

#### ~~14.2.43.2.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.43 for the downlink 20 ms TTI case.

#### ~~14.2.43.2.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | RB7<br>(RAB subflow #3) | RB8<br>(64 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x336            | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336            | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x336            | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 3x336            | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 4x336            | N/A   |

Uplink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| UL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| UL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| UL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| UL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| UL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| UL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| UL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| UL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| UL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| UL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| UL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| UL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| UL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| UL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| UL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| UL_TFC15 | (TF0, TF0, TF0, TF0, TF1)  |
| UL_TFC16 | (TF1, TF0, TF0, TF0, TF1)  |
| UL_TFC17 | (TF2, TF1, TF1, TF0, TF1)  |
| UL_TFC18 | (TF0, TF0, TF0, TF1, TF1)  |
| UL_TFC19 | (TF1, TF0, TF0, TF1, TF1)  |
| UL_TFC20 | (TF2, TF1, TF1, TF1, TF1)  |
| UL_TFC21 | (TF0, TF0, TF0, TF2, TF1)  |
| UL_TFC22 | (TF1, TF0, TF0, TF2, TF1)  |
| UL_TFC23 | (TF2, TF1, TF1, TF2, TF1)  |
| UL_TFC24 | (TF0, TF0, TF0, TF3, TF1)  |
| UL_TFC25 | (TF1, TF0, TF0, TF3, TF1)  |
| UL_TFC26 | (TF2, TF1, TF1, TF3, TF1)  |
| UL_TFC27 | (TF0, TF0, TF0, TF4, TF1)  |
| UL_TFC28 | (TF1, TF0, TF0, TF4, TF1)  |
| UL_TFC29 | (TF2, TF1, TF1, TF4, TF1)  |

## Downlink TFS:

|     |           | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | RB7<br>(RAB subflow #3) | RB8<br>(384 kbps,<br>10 ms) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-----------------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x103                   | 0x60                    | 0x336                       | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336                       | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x336                       | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 4x336                       | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 8x336                       | N/A   |
|     | TF5, bits | N/A                     | N/A                     | N/A                     | 12x336                      | N/A   |
|     | TF6, bits | N/A                     | N/A                     | N/A                     | 16x336                      | N/A   |
|     | TF7, bits | N/A                     | N/A                     | N/A                     | 20x336                      | N/A   |
|     | TF8, bits | N/A                     | N/A                     | N/A                     | 24x336                      | N/A   |

## Downlink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| DL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| DL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| DL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| DL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| DL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| DL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| DL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| DL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| DL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| DL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| DL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| DL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| DL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| DL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| DL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| DL_TFC15 | (TF0, TF0, TF0, TF5, TF0)  |
| DL_TFC16 | (TF1, TF0, TF0, TF5, TF0)  |
| DL_TFC17 | (TF2, TF1, TF1, TF5, TF0)  |
| DL_TFC18 | (TF0, TF0, TF0, TF6, TF0)  |
| DL_TFC19 | (TF1, TF0, TF0, TF6, TF0)  |
| DL_TFC20 | (TF2, TF1, TF1, TF6, TF0)  |
| DL_TFC21 | (TF0, TF0, TF0, TF7, TF0)  |
| DL_TFC22 | (TF1, TF0, TF0, TF7, TF0)  |
| DL_TFC23 | (TF2, TF1, TF1, TF7, TF0)  |
| DL_TFC24 | (TF0, TF0, TF0, TF8, TF0)  |
| DL_TFC25 | (TF1, TF0, TF0, TF8, TF0)  |
| DL_TFC26 | (TF2, TF1, TF1, TF8, TF0)  |
| DL_TFC27 | (TF0, TF0, TF0, TF0, TF1)  |
| DL_TFC28 | (TF1, TF0, TF0, TF0, TF1)  |
| DL_TFC29 | (TF2, TF1, TF1, TF0, TF1)  |
| DL_TFC30 | (TF0, TF0, TF0, TF1, TF1)  |
| DL_TFC31 | (TF1, TF0, TF0, TF1, TF1)  |
| DL_TFC32 | (TF2, TF1, TF1, TF1, TF1)  |
| DL_TFC33 | (TF0, TF0, TF0, TF2, TF1)  |
| DL_TFC34 | (TF1, TF0, TF0, TF2, TF1)  |
| DL_TFC35 | (TF2, TF1, TF1, TF2, TF1)  |
| DL_TFC36 | (TF0, TF0, TF0, TF3, TF1)  |
| DL_TFC37 | (TF1, TF0, TF0, TF3, TF1)  |
| DL_TFC38 | (TF2, TF1, TF1, TF3, TF1)  |
| DL_TFC39 | (TF0, TF0, TF0, TF4, TF1)  |
| DL_TFC40 | (TF1, TF0, TF0, TF4, TF1)  |
| DL_TFC41 | (TF2, TF1, TF1, TF4, TF1)  |
| DL_TFC42 | (TF0, TF0, TF0, TF5, TF1)  |
| DL_TFC43 | (TF1, TF0, TF0, TF5, TF1)  |
| DL_TFC44 | (TF2, TF1, TF1, TF5, TF1)  |

| <b>TFCI</b> | <b>(RB5, RB6, RB7, RB8, DCCH)</b> |
|-------------|-----------------------------------|
| DL_TFC45    | (TF0, TF0, TF0, TF6, TF1)         |
| DL_TFC46    | (TF1, TF0, TF0, TF6, TF1)         |
| DL_TFC47    | (TF2, TF1, TF1, TF6, TF1)         |
| DL_TFC48    | (TF0, TF0, TF0, TF7, TF1)         |
| DL_TFC49    | (TF1, TF0, TF0, TF7, TF1)         |
| DL_TFC50    | (TF2, TF1, TF1, TF7, TF1)         |
| DL_TFC51    | (TF0, TF0, TF0, TF8, TF1)         |
| DL_TFC52    | (TF1, TF0, TF0, TF8, TF1)         |
| DL_TFC53    | (TF2, TF1, TF1, TF8, TF1)         |

Sub-tests:

| <b>Sub-test</b> | <b>Downlink TFCs Under Test</b> | <b>Uplink TFCs Under test</b> | <b>Implicitely-tested</b>                      | <b>Restricted-UL TFCIs</b>                     | <b>UL-RLC SDU size (bits) (note)</b>        | <b>Test-data-size (bits) (note)</b>                       |
|-----------------|---------------------------------|-------------------------------|------------------------------------------------|------------------------------------------------|---------------------------------------------|-----------------------------------------------------------|
| 1               | DL_TFC1                         | UL_TFC1                       | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC1,<br>UL_TFC15,<br>UL_TFC16  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data   |
| 2               | DL_TFC2                         | UL_TFC2                       | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC2,<br>UL_TFC15,<br>UL_TFC17  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data            |
| 3               | DL_TFC3                         | UL_TFC3                       | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC3,<br>UL_TFC15,<br>UL_TFC18  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 312  |
| 4               | DL_TFC4                         | UL_TFC4                       | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15, | UL_TFC0,<br>UL_TFC4,<br>UL_TFC15,<br>UL_TFC19  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 312       |
| 5               | DL_TFC5                         | UL_TFC5                       | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC5,<br>UL_TFC15,<br>UL_TFC20  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 312                |
| 6               | DL_TFC6                         | UL_TFC6                       | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC6,<br>UL_TFC15,<br>UL_TFC21  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 632  |
| 7               | DL_TFC7                         | UL_TFC7                       | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC7,<br>UL_TFC15,<br>UL_TFC22  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 632       |
| 8               | DL_TFC8                         | UL_TFC8                       | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC8,<br>UL_TFC15,<br>UL_TFC23  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632                |
| 9               | DL_TFC9                         | UL_TFC9                       | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC9,<br>UL_TFC15,<br>UL_TFC24  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 1272 |
| 10              | DL_TFC10                        | UL_TFC10                      | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC10,<br>UL_TFC15,<br>UL_TFC25 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 1272      |
| 11              | DL_TFC11                        | UL_TFC11                      | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC11,<br>UL_TFC15,<br>UL_TFC26 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272               |
| 12              | DL_TFC12                        | UL_TFC12                      | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15  | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 2552 |

| Sub-test | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                            | Restricted UL TFCIs                            | UL RLC SDU size (bits) (note)               | Test data size (bits) (note)                              |
|----------|--------------------------|------------------------|-----------------------------------------------|------------------------------------------------|---------------------------------------------|-----------------------------------------------------------|
| 13       | DL_TFC13                 | UL_TFC13               | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 2552      |
| 14       | DL_TFC14                 | UL_TFC14               | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2552               |
| 15       | DL_TFC15                 | UL_TFC12               | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 3832 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 3832 |
| 16       | DL_TFC16                 | UL_TFC13               | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 3832 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 3832      |
| 17       | DL_TFC17                 | UL_TFC14               | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 3832 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 3832               |
| 18       | DL_TFC18                 | UL_TFC12               | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 5112 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 5112 |
| 19       | DL_TFC19                 | UL_TFC13               | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 5112 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 5112      |
| 20       | DL_TFC20                 | UL_TFC14               | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 5112 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 5112               |
| 21       | DL_TFC21                 | UL_TFC12               | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 6392 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 6392 |
| 22       | DL_TFC22                 | UL_TFC13               | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 6392 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 6392      |
| 23       | DL_TFC23                 | UL_TFC14               | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 6392 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 6392               |
| 24       | DL_TFC24                 | UL_TFC12               | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 7672 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 7672 |
| 25       | DL_TFC25                 | UL_TFC13               | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 7672 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 7672      |
| 26       | DL_TFC26                 | UL_TFC14               | DL_TFC0,<br>DL_TFC27,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 7672 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 7672               |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### ~~14.2.43.2.4 Test requirements~~

~~See 14.1.1 for definition of step 10 and step 15.~~

- ~~1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.~~
- ~~2. At step 15 the UE transmitted transport format shall be~~
  - ~~— for sub-test 1: RB5/TF1 (1x39).~~
  - ~~— for sub-test 2: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).~~
  - ~~— for sub-test 3: RB8/TF1 (1x336)~~
  - ~~— for sub-test 4: RB5/TF1 (1x39) and RB8/TF1 (1x336).~~
  - ~~— for sub-test 5: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF1 (1x336).~~
  - ~~— for sub-test 6: RB8/TF2 (2x336)~~
  - ~~— for sub-test 7: RB5/TF1 (1x39) and RB8/TF2 (2x336).~~
  - ~~— for sub-test 8: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF2 (2x336).~~
  - ~~— for sub-test 9: RB8/TF3 (3x336)~~
  - ~~— for sub-test 10: RB5/TF1 (1x39) and RB8/TF3 (3x336).~~
  - ~~— for sub-test 11: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF3 (3x336).~~
  - ~~— for sub-test 12, 15, 18, 21 and 24: RB8/TF4 (4x336)~~
  - ~~— for sub-test 13, 16, 19, 22 and 25: RB5/TF1 (1x39) and RB8/TF4 (4x336).~~
  - ~~— for sub-test 14, 17, 20, 23 and 26: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF4 (4x336).~~
- ~~3. At step 15 the UE shall return~~
  - ~~— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6, RB7 and RB8.~~
  - ~~— for sub-test 2: an RLC SDU on RB5, RB6 and RB7 having the same content as sent by SS; and no data shall be received on RB8.~~
  - ~~— for sub-test 3, 6, 9, 12, 15, 18, 21 and 24: an RLC SDU on RB8 having the same content as sent by SS; and no data shall be received on RB5, RB6 and RB7.~~
  - ~~— for sub-test 4, 7, 10, 13, 16, 19, 22 and 25: an RLC SDU on RB5 and RB8 having the same content as sent by SS; and no data shall be received on RB6 and RB7.~~
  - ~~— for sub-test 5, 8, 11, 14, 17, 20, 23 and 26: an RLC SDU on RB5, RB6, RB7 and RB8 having the same content as sent by SS.~~

#### ~~14.2.44 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:128 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

##### ~~14.2.44.1 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:128 DL:2048 kbps / PS RAB / 10 ms TTI~~

###### ~~14.2.44.1.1 Conformance requirement~~

~~See 14.2.4.1.~~

## 14.2.44.1.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.44 for the downlink 10-ms TTI case.

## 14.2.44.1.3 Method of test

Uplink TFS:

|     | TFI       | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | RB7<br>(RAB subflow #3) | RB8<br>(128 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x336             | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336             | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x336             | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 4x336             | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 8x336             | N/A   |

Uplink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| UL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| UL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| UL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| UL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| UL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| UL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| UL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| UL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| UL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| UL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| UL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| UL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| UL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| UL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| UL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| UL_TFC15 | (TF0, TF0, TF0, TF0, TF1)  |
| UL_TFC16 | (TF1, TF0, TF0, TF0, TF1)  |
| UL_TFC17 | (TF2, TF1, TF1, TF0, TF1)  |
| UL_TFC18 | (TF0, TF0, TF0, TF1, TF1)  |
| UL_TFC19 | (TF1, TF0, TF0, TF1, TF1)  |
| UL_TFC20 | (TF2, TF1, TF1, TF1, TF1)  |
| UL_TFC21 | (TF0, TF0, TF0, TF2, TF1)  |
| UL_TFC22 | (TF1, TF0, TF0, TF2, TF1)  |
| UL_TFC23 | (TF2, TF1, TF1, TF2, TF1)  |
| UL_TFC24 | (TF0, TF0, TF0, TF3, TF1)  |
| UL_TFC25 | (TF1, TF0, TF0, TF3, TF1)  |
| UL_TFC26 | (TF2, TF1, TF1, TF3, TF1)  |
| UL_TFC27 | (TF0, TF0, TF0, TF4, TF1)  |
| UL_TFC28 | (TF1, TF0, TF0, TF4, TF1)  |
| UL_TFC29 | (TF2, TF1, TF1, TF4, TF1)  |

Downlink TFS:

|     |            | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | RB8<br>(2048 kbps) | DCCH  |
|-----|------------|-------------------------|-------------------------|-------------------------|--------------------|-------|
| TFS | TF0, bits  | 1x0                     | 0x103                   | 0x60                    | 0x656              | 0x148 |
|     | TF1, bits  | 1x39                    | 1x103                   | 1x60                    | 1x656              | 1x148 |
|     | TF2, bits  | 1x81                    | N/A                     | N/A                     | 2x656              | N/A   |
|     | TF3, bits  | N/A                     | N/A                     | N/A                     | 4x656              | N/A   |
|     | TF4, bits  | N/A                     | N/A                     | N/A                     | 8x656              | N/A   |
|     | TF5, bits  | N/A                     | N/A                     | N/A                     | 12x656             | N/A   |
|     | TF6, bits  | N/A                     | N/A                     | N/A                     | 16x656             | N/A   |
|     | TF7, bits  | N/A                     | N/A                     | N/A                     | 20x656             | N/A   |
|     | TF8, bits  | N/A                     | N/A                     | N/A                     | 24x656             | N/A   |
|     | TF9, bits  | N/A                     | N/A                     | N/A                     | 28x656             | N/A   |
|     | TF10, bits | N/A                     | N/A                     | N/A                     | 32x656             | N/A   |

## Downlink TFCs:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| DL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| DL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| DL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| DL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| DL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| DL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| DL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| DL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| DL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| DL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| DL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| DL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| DL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| DL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| DL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| DL_TFC15 | (TF0, TF0, TF0, TF5, TF0)  |
| DL_TFC16 | (TF1, TF0, TF0, TF5, TF0)  |
| DL_TFC17 | (TF2, TF1, TF1, TF5, TF0)  |
| DL_TFC18 | (TF0, TF0, TF0, TF6, TF0)  |
| DL_TFC19 | (TF1, TF0, TF0, TF6, TF0)  |
| DL_TFC20 | (TF2, TF1, TF1, TF6, TF0)  |
| DL_TFC21 | (TF0, TF0, TF0, TF7, TF0)  |
| DL_TFC22 | (TF1, TF0, TF0, TF7, TF0)  |
| DL_TFC23 | (TF2, TF1, TF1, TF7, TF0)  |
| DL_TFC24 | (TF0, TF0, TF0, TF8, TF0)  |
| DL_TFC25 | (TF1, TF0, TF0, TF8, TF0)  |
| DL_TFC26 | (TF2, TF1, TF1, TF8, TF0)  |
| DL_TFC27 | (TF0, TF0, TF0, TF9, TF0)  |
| DL_TFC28 | (TF1, TF0, TF0, TF9, TF0)  |
| DL_TFC29 | (TF2, TF1, TF1, TF9, TF0)  |
| DL_TFC30 | (TF0, TF0, TF0, TF10, TF0) |
| DL_TFC31 | (TF1, TF0, TF0, TF10, TF0) |
| DL_TFC32 | (TF2, TF1, TF1, TF10, TF0) |
| DL_TFC33 | (TF0, TF0, TF0, TF0, TF1)  |
| DL_TFC34 | (TF1, TF0, TF0, TF0, TF1)  |
| DL_TFC35 | (TF2, TF1, TF1, TF0, TF1)  |
| DL_TFC36 | (TF0, TF0, TF0, TF1, TF1)  |
| DL_TFC37 | (TF1, TF0, TF0, TF1, TF1)  |
| DL_TFC38 | (TF2, TF1, TF1, TF1, TF1)  |
| DL_TFC39 | (TF0, TF0, TF0, TF2, TF1)  |
| DL_TFC40 | (TF1, TF0, TF0, TF2, TF1)  |
| DL_TFC41 | (TF2, TF1, TF1, TF2, TF1)  |
| DL_TFC42 | (TF0, TF0, TF0, TF3, TF1)  |
| DL_TFC43 | (TF1, TF0, TF0, TF3, TF1)  |
| DL_TFC44 | (TF2, TF1, TF1, TF3, TF1)  |
| DL_TFC45 | (TF0, TF0, TF0, TF4, TF1)  |

| <b>TFCI</b> | <b>(RB5, RB6, RB7, RB8, DCCH)</b> |
|-------------|-----------------------------------|
| DL_TFC46    | (TF1, TF0, TF0, TF4, TF1)         |
| DL_TFC47    | (TF2, TF1, TF1, TF4, TF1)         |
| DL_TFC48    | (TF0, TF0, TF0, TF5, TF1)         |
| DL_TFC49    | (TF1, TF0, TF0, TF5, TF1)         |
| DL_TFC50    | (TF2, TF1, TF1, TF5, TF1)         |
| DL_TFC51    | (TF0, TF0, TF0, TF6, TF1)         |
| DL_TFC52    | (TF1, TF0, TF0, TF6, TF1)         |
| DL_TFC53    | (TF2, TF1, TF1, TF6, TF1)         |
| DL_TFC54    | (TF0, TF0, TF0, TF7, TF1)         |
| DL_TFC55    | (TF1, TF0, TF0, TF7, TF1)         |
| DL_TFC56    | (TF2, TF1, TF1, TF7, TF1)         |
| DL_TFC57    | (TF0, TF0, TF0, TF8, TF1)         |
| DL_TFC58    | (TF1, TF0, TF0, TF8, TF1)         |
| DL_TFC59    | (TF2, TF1, TF1, TF8, TF1)         |
| DL_TFC60    | (TF0, TF0, TF0, TF9, TF1)         |
| DL_TFC61    | (TF1, TF0, TF0, TF9, TF1)         |
| DL_TFC62    | (TF2, TF1, TF1, TF9, TF1)         |
| DL_TFC63    | (TF0, TF0, TF0, TF10, TF1)        |
| DL_TFC64    | (TF1, TF0, TF0, TF10, TF1)        |
| DL_TFC65    | (TF2, TF1, TF1, TF10, TF1)        |

## Sub-tests:

| <b>Sub-test</b> | <b>Downlink TFCs under test</b> | <b>Uplink TFCs Under test</b> | <b>Implicitely tested</b>                     | <b>Restricted UL TFCIs</b>                    | <b>UL RLC SDU-size (bits) (note)</b>        | <b>Test data-size (bits) (note)</b>                       |
|-----------------|---------------------------------|-------------------------------|-----------------------------------------------|-----------------------------------------------|---------------------------------------------|-----------------------------------------------------------|
| 1               | DL_TFC1                         | UL_TFC1                       | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC15,<br>UL_TFC16 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data   |
| 2               | DL_TFC2                         | UL_TFC2                       | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC15,<br>UL_TFC17 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data            |
| 3               | DL_TFC3                         | UL_TFC3                       | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC15,<br>UL_TFC18 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 632  |
| 4               | DL_TFC4                         | UL_TFC4                       | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC15,<br>UL_TFC19 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 632       |
| 5               | DL_TFC5                         | UL_TFC5                       | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC15,<br>UL_TFC20 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632                |
| 6               | DL_TFC6                         | UL_TFC6                       | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC15,<br>UL_TFC21 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 1272 |
| 7               | DL_TFC7                         | UL_TFC7                       | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC15,<br>UL_TFC22 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 1272      |
| 8               | DL_TFC8                         | UL_TFC8                       | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC15,<br>UL_TFC23 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272               |
| 9               | DL_TFC9                         | UL_TFC9                       | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC15,<br>UL_TFC24 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 2552 |



| Sub-test | Downlink TFCs under test | Uplink TFCs Under test | Implicitely tested                            | Restricted UL TFCIs                            | UL RLC SDU-size (bits) (note)                | Test data-size (bits) (note)                               |
|----------|--------------------------|------------------------|-----------------------------------------------|------------------------------------------------|----------------------------------------------|------------------------------------------------------------|
| 10       | DL_TFC10                 | UL_TFC10               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC10,<br>UL_TFC15,<br>UL_TFC25 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2552  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 2552       |
| 11       | DL_TFC11                 | UL_TFC11               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC11,<br>UL_TFC15,<br>UL_TFC26 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2552  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2552                |
| 12       | DL_TFC12                 | UL_TFC12               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 5112  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 5112  |
| 13       | DL_TFC13                 | UL_TFC13               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 5112  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 5112       |
| 14       | DL_TFC14                 | UL_TFC14               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 5112  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 5112                |
| 15       | DL_TFC15                 | UL_TFC12               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 7672  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 7672  |
| 16       | DL_TFC16                 | UL_TFC13               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 7672  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 7672       |
| 17       | DL_TFC17                 | UL_TFC14               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 7672  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 7672                |
| 18       | DL_TFC18                 | UL_TFC12               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 10232 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 10232 |
| 19       | DL_TFC19                 | UL_TFC13               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 10232 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 10232      |
| 20       | DL_TFC20                 | UL_TFC14               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 10232 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 10232               |
| 21       | DL_TFC21                 | UL_TFC12               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 12792 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 12792 |
| 22       | DL_TFC22                 | UL_TFC13               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 12792 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 12792      |
| 23       | DL_TFC23                 | UL_TFC14               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 12792 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 12792               |
| 24       | DL_TFC24                 | UL_TFC12               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 15352 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 15352 |
| 25       | DL_TFC25                 | UL_TFC13               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 15352 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 15352      |

| Sub-test                                                                              | Downlink TFCs under test | Uplink TFCs Under test | Implicitely tested                            | Restricted UL TFCIs                            | UL RLC SDU-size (bits) (note)                | Test data-size (bits) (note)                               |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|-----------------------------------------------|------------------------------------------------|----------------------------------------------|------------------------------------------------------------|
| 26                                                                                    | DL_TFC26                 | UL_TFC14               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 15352 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 15352               |
| 27                                                                                    | DL_TFC27                 | UL_TFC12               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 17912 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 17912 |
| 28                                                                                    | DL_TFC28                 | UL_TFC13               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 17912 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 17912      |
| 29                                                                                    | DL_TFC29                 | UL_TFC14               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 17912 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 17912               |
| 30                                                                                    | DL_TFC30                 | UL_TFC12               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 20472 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 20472 |
| 31                                                                                    | DL_TFC31                 | UL_TFC13               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 20472 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 20472      |
| 32                                                                                    | DL_TFC32                 | UL_TFC14               | DL_TFC0,<br>DL_TFC33,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 20472 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 20472               |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                               |                                                |                                              |                                                            |

See 14.1.1 for test procedure.

#### 14.2.44.1.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

- for sub-test 1: RB5/TF1 (1x39).
- for sub-test 2: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).
- for sub-test 3: RB8/TF1 (1x336)
- for sub-test 4: RB5/TF1 (1x39) and RB8/TF1 (1x336).
- for sub-test 5: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF1 (1x336).
- for sub-test 6: RB8/TF2 (2x336)
- for sub-test 7: RB5/TF1 (1x39) and RB8/TF2 (2x336).
- for sub-test 8: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF2 (2x336).
- for sub-test 9: RB8/TF3 (4x336)
- for sub-test 10: RB5/TF1 (1x39) and RB8/TF3 (4x336).
- for sub-test 11: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF3 (4x336).
- for sub-test 12,15,18,21,24,27,30: RB8/TF4 (8x336)

— for sub-test 13,16,19,22,25,28,31: RB5/TF1 (1x39) and RB8/TF4 (8x336).

— for sub-test 14,17,20,23,26,29,32: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF4 (8x336).

3. At step 15 the UE shall return

— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6, RB7 and RB8.

— for sub-test 2: an RLC SDU on RB5, RB6 and RB7 having the same content as sent by SS; and no data shall be received on RB8.

— for sub-test 3, 6, 9, 12, 15, 18, 21, 24, 27, 30: an RLC SDU on RB8 having the same content as sent by SS; and no data shall be received on RB5, RB6 and RB7.

— for sub-test 4, 7, 10, 13, 16, 19, 22, 25, 28, 31: an RLC SDU on RB5 and RB8 having the same content as sent by SS; and no data shall be received on RB6 and RB7.

— for sub-test 5, 8, 11, 14, 17, 20, 23, 26, 29, 32: an RLC SDU on RB5, RB6, RB7 and RB8 having the same content as sent by SS.

#### 14.2.44.2 ~~Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:128 DL:2048 kbps / PS RAB / 20 ms TTI~~

##### 14.2.44.2.1 ~~Conformance requirement~~

See 14.2.4.1.

##### 14.2.44.2.2 ~~Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.44 for the downlink 20 ms TTI case.

##### 14.2.44.2.3 ~~Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | RB7<br>(RAB subflow #3) | RB8<br>(128 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x336             | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x336             | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x336             | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 4x336             | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 8x336             | N/A   |

## Uplink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| UL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| UL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| UL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| UL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| UL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| UL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| UL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| UL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| UL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| UL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| UL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| UL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| UL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| UL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| UL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| UL_TFC15 | (TF0, TF0, TF0, TF0, TF1)  |
| UL_TFC16 | (TF1, TF0, TF0, TF0, TF1)  |
| UL_TFC17 | (TF2, TF1, TF1, TF0, TF1)  |
| UL_TFC18 | (TF0, TF0, TF0, TF1, TF1)  |
| UL_TFC19 | (TF1, TF0, TF0, TF1, TF1)  |
| UL_TFC20 | (TF2, TF1, TF1, TF1, TF1)  |
| UL_TFC21 | (TF0, TF0, TF0, TF2, TF1)  |
| UL_TFC22 | (TF1, TF0, TF0, TF2, TF1)  |
| UL_TFC23 | (TF2, TF1, TF1, TF2, TF1)  |
| UL_TFC24 | (TF0, TF0, TF0, TF3, TF1)  |
| UL_TFC25 | (TF1, TF0, TF0, TF3, TF1)  |
| UL_TFC26 | (TF2, TF1, TF1, TF3, TF1)  |
| UL_TFC27 | (TF0, TF0, TF0, TF4, TF1)  |
| UL_TFC28 | (TF1, TF0, TF0, TF4, TF1)  |
| UL_TFC29 | (TF2, TF1, TF1, TF4, TF1)  |

## Downlink TFS:

|     |            | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | RB8<br>(2048 kbps) | DCCH  |
|-----|------------|-------------------------|-------------------------|-------------------------|--------------------|-------|
| TFS | TF0, bits  | 1x0                     | 0x103                   | 0x60                    | 0x656              | 0x148 |
|     | TF1, bits  | 1x39                    | 1x103                   | 1x60                    | 1x656              | 1x148 |
|     | TF2, bits  | 1x81                    | N/A                     | N/A                     | 2x656              | N/A   |
|     | TF3, bits  | N/A                     | N/A                     | N/A                     | 4x656              | N/A   |
|     | TF4, bits  | N/A                     | N/A                     | N/A                     | 8x656              | N/A   |
|     | TF5, bits  | N/A                     | N/A                     | N/A                     | 12x656             | N/A   |
|     | TF6, bits  | N/A                     | N/A                     | N/A                     | 16x656             | N/A   |
|     | TF7, bits  | N/A                     | N/A                     | N/A                     | 20x656             | N/A   |
|     | TF8, bits  | N/A                     | N/A                     | N/A                     | 24x656             | N/A   |
|     | TF9, bits  | N/A                     | N/A                     | N/A                     | 28x656             | N/A   |
|     | TF10, bits | N/A                     | N/A                     | N/A                     | 32x656             | N/A   |
|     | TF11, bits | N/A                     | N/A                     | N/A                     | 36x656             | N/A   |
|     | TF12, bits | N/A                     | N/A                     | N/A                     | 40x656             | N/A   |
|     | TF13, bits | N/A                     | N/A                     | N/A                     | 44x656             | N/A   |
|     | TF14, bits | N/A                     | N/A                     | N/A                     | 48x656             | N/A   |
|     | TF15, bits | N/A                     | N/A                     | N/A                     | 52x656             | N/A   |
|     | TF16, bits | N/A                     | N/A                     | N/A                     | 56x656             | N/A   |
|     | TF17, bits | N/A                     | N/A                     | N/A                     | 60x656             | N/A   |
|     | TF18, bits | N/A                     | N/A                     | N/A                     | 64x656             | N/A   |

## Downlink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| DL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| DL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| DL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| DL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| DL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| DL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| DL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| DL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| DL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| DL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| DL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| DL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| DL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| DL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| DL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| DL_TFC15 | (TF0, TF0, TF0, TF5, TF0)  |
| DL_TFC16 | (TF1, TF0, TF0, TF5, TF0)  |
| DL_TFC17 | (TF2, TF1, TF1, TF5, TF0)  |
| DL_TFC18 | (TF0, TF0, TF0, TF6, TF0)  |
| DL_TFC19 | (TF1, TF0, TF0, TF6, TF0)  |
| DL_TFC20 | (TF2, TF1, TF1, TF6, TF0)  |
| DL_TFC21 | (TF0, TF0, TF0, TF7, TF0)  |
| DL_TFC22 | (TF1, TF0, TF0, TF7, TF0)  |
| DL_TFC23 | (TF2, TF1, TF1, TF7, TF0)  |
| DL_TFC24 | (TF0, TF0, TF0, TF8, TF0)  |
| DL_TFC25 | (TF1, TF0, TF0, TF8, TF0)  |
| DL_TFC26 | (TF2, TF1, TF1, TF8, TF0)  |
| DL_TFC27 | (TF0, TF0, TF0, TF9, TF0)  |
| DL_TFC28 | (TF1, TF0, TF0, TF9, TF0)  |
| DL_TFC29 | (TF2, TF1, TF1, TF9, TF0)  |
| DL_TFC30 | (TF0, TF0, TF0, TF10, TF0) |
| DL_TFC31 | (TF1, TF0, TF0, TF10, TF0) |
| DL_TFC32 | (TF2, TF1, TF1, TF10, TF0) |
| DL_TFC33 | (TF0, TF0, TF0, TF11, TF0) |
| DL_TFC34 | (TF1, TF0, TF0, TF11, TF0) |
| DL_TFC35 | (TF2, TF1, TF1, TF11, TF0) |
| DL_TFC36 | (TF0, TF0, TF0, TF12, TF0) |
| DL_TFC37 | (TF1, TF0, TF0, TF12, TF0) |
| DL_TFC38 | (TF2, TF1, TF1, TF12, TF0) |
| DL_TFC39 | (TF0, TF0, TF0, TF13, TF0) |
| DL_TFC40 | (TF1, TF0, TF0, TF13, TF0) |
| DL_TFC41 | (TF2, TF1, TF1, TF13, TF0) |
| DL_TFC42 | (TF0, TF0, TF0, TF14, TF0) |
| DL_TFC43 | (TF1, TF0, TF0, TF14, TF0) |
| DL_TFC44 | (TF2, TF1, TF1, TF14, TF0) |
| DL_TFC45 | (TF0, TF0, TF0, TF15, TF0) |
| DL_TFC46 | (TF1, TF0, TF0, TF15, TF0) |
| DL_TFC47 | (TF2, TF1, TF1, TF15, TF0) |
| DL_TFC48 | (TF0, TF0, TF0, TF16, TF0) |
| DL_TFC49 | (TF1, TF0, TF0, TF16, TF0) |
| DL_TFC50 | (TF2, TF1, TF1, TF16, TF0) |
| DL_TFC51 | (TF0, TF0, TF0, TF17, TF0) |
| DL_TFC52 | (TF1, TF0, TF0, TF17, TF0) |
| DL_TFC53 | (TF2, TF1, TF1, TF17, TF0) |
| DL_TFC54 | (TF0, TF0, TF0, TF18, TF0) |
| DL_TFC55 | (TF1, TF0, TF0, TF18, TF0) |
| DL_TFC56 | (TF2, TF1, TF1, TF18, TF0) |
| DL_TFC57 | (TF0, TF0, TF0, TF0, TF1)  |
| DL_TFC58 | (TF1, TF0, TF0, TF0, TF1)  |
| DL_TFC59 | (TF2, TF1, TF1, TF0, TF1)  |
| DL_TFC60 | (TF0, TF0, TF0, TF1, TF1)  |

| <b>TFCI</b> | <b>(RB5, RB6, RB7, RB8, DCCH)</b> |
|-------------|-----------------------------------|
| DL_TFC61    | (TF1, TF0, TF0, TF1, TF1)         |
| DL_TFC61    | (TF2, TF1, TF1, TF1, TF1)         |
| DL_TFC63    | (TF0, TF0, TF0, TF2, TF1)         |
| DL_TFC64    | (TF1, TF0, TF0, TF2, TF1)         |
| DL_TFC65    | (TF2, TF1, TF1, TF2, TF1)         |
| DL_TFC66    | (TF0, TF0, TF0, TF3, TF1)         |
| DL_TFC67    | (TF1, TF0, TF0, TF3, TF1)         |
| DL_TFC68    | (TF2, TF1, TF1, TF3, TF1)         |
| DL_TFC69    | (TF0, TF0, TF0, TF4, TF1)         |
| DL_TFC70    | (TF1, TF0, TF0, TF4, TF1)         |
| DL_TFC71    | (TF2, TF1, TF1, TF4, TF1)         |
| DL_TFC72    | (TF0, TF0, TF0, TF5, TF1)         |
| DL_TFC73    | (TF1, TF0, TF0, TF5, TF1)         |
| DL_TFC74    | (TF2, TF1, TF1, TF5, TF1)         |
| DL_TFC75    | (TF0, TF0, TF0, TF6, TF1)         |
| DL_TFC76    | (TF1, TF0, TF0, TF6, TF1)         |
| DL_TFC77    | (TF2, TF1, TF1, TF6, TF1)         |
| DL_TFC78    | (TF0, TF0, TF0, TF7, TF1)         |
| DL_TFC79    | (TF1, TF0, TF0, TF7, TF1)         |
| DL_TFC80    | (TF2, TF1, TF1, TF7, TF1)         |
| DL_TFC81    | (TF0, TF0, TF0, TF8, TF1)         |
| DL_TFC82    | (TF1, TF0, TF0, TF8, TF1)         |
| DL_TFC83    | (TF2, TF1, TF1, TF8, TF1)         |
| DL_TFC84    | (TF0, TF0, TF0, TF9, TF1)         |
| DL_TFC85    | (TF1, TF0, TF0, TF9, TF1)         |
| DL_TFC86    | (TF2, TF1, TF1, TF9, TF1)         |
| DL_TFC87    | (TF0, TF0, TF0, TF10, TF1)        |
| DL_TFC88    | (TF1, TF0, TF0, TF10, TF1)        |
| DL_TFC89    | (TF2, TF1, TF1, TF10, TF1)        |
| DL_TFC90    | (TF0, TF0, TF0, TF11, TF1)        |
| DL_TFC91    | (TF1, TF0, TF0, TF11, TF1)        |
| DL_TFC92    | (TF2, TF1, TF1, TF11, TF1)        |
| DL_TFC93    | (TF0, TF0, TF0, TF12, TF1)        |
| DL_TFC94    | (TF1, TF0, TF0, TF12, TF1)        |
| DL_TFC95    | (TF2, TF1, TF1, TF12, TF1)        |
| DL_TFC96    | (TF0, TF0, TF0, TF13, TF1)        |
| DL_TFC97    | (TF1, TF0, TF0, TF13, TF1)        |
| DL_TFC98    | (TF2, TF1, TF1, TF13, TF1)        |
| DL_TFC99    | (TF0, TF0, TF0, TF14, TF1)        |
| DL_TFC100   | (TF1, TF0, TF0, TF14, TF1)        |
| DL_TFC101   | (TF2, TF1, TF1, TF14, TF1)        |
| DL_TFC102   | (TF0, TF0, TF0, TF15, TF1)        |
| DL_TFC103   | (TF1, TF0, TF0, TF15, TF1)        |
| DL_TFC104   | (TF2, TF1, TF1, TF15, TF1)        |
| DL_TFC105   | (TF0, TF0, TF0, TF16, TF1)        |
| DL_TFC106   | (TF1, TF0, TF0, TF16, TF1)        |
| DL_TFC107   | (TF2, TF1, TF1, TF16, TF1)        |
| DL_TFC108   | (TF0, TF0, TF0, TF17, TF1)        |
| DL_TFC109   | (TF1, TF0, TF0, TF17, TF1)        |
| DL_TFC110   | (TF2, TF1, TF1, TF17, TF1)        |
| DL_TFC111   | (TF0, TF0, TF0, TF18, TF1)        |
| DL_TFC112   | (TF1, TF0, TF0, TF18, TF1)        |
| DL_TFC113   | (TF2, TF1, TF1, TF18, TF1)        |

## Sub-tests:

| Sub-test | Downlink TFCs under test | Uplink TFCs Under test | Implicitely tested                            | Restricted-UL TFCIs                            | UL-RLC SDU-size (bits) (note)               | Test data-size (bits) (note)                              |
|----------|--------------------------|------------------------|-----------------------------------------------|------------------------------------------------|---------------------------------------------|-----------------------------------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC15,<br>UL_TFC16  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data   |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC15,<br>UL_TFC17  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data            |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC15,<br>UL_TFC18  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 632  |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC15,<br>UL_TFC19  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 632       |
| 5        | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC15,<br>UL_TFC20  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 632                |
| 6        | DL_TFC6                  | UL_TFC6                | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC15,<br>UL_TFC21  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 1272 |
| 7        | DL_TFC7                  | UL_TFC7                | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC15,<br>UL_TFC22  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 1272      |
| 8        | DL_TFC8                  | UL_TFC8                | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC15,<br>UL_TFC23  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1272               |
| 9        | DL_TFC9                  | UL_TFC9                | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC15,<br>UL_TFC24  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 2552 |
| 10       | DL_TFC10                 | UL_TFC10               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC10,<br>UL_TFC15,<br>UL_TFC25 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 2552      |
| 11       | DL_TFC11                 | UL_TFC11               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC11,<br>UL_TFC15,<br>UL_TFC26 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2552 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2552               |
| 12       | DL_TFC12                 | UL_TFC12               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 5112 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 5112 |
| 13       | DL_TFC13                 | UL_TFC13               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 5112 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 5112      |
| 14       | DL_TFC14                 | UL_TFC14               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 5112 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 5112               |
| 15       | DL_TFC15                 | UL_TFC12               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 7672 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 7672 |

| Sub-test | Downlink TFCs under test | Uplink TFCs Under test | Implicitely tested                            | Restricted-UL TFCIs                            | UL RLC SDU-size (bits) (note)                | Test data-size (bits) (note)                               |
|----------|--------------------------|------------------------|-----------------------------------------------|------------------------------------------------|----------------------------------------------|------------------------------------------------------------|
| 16       | DL_TFC16                 | UL_TFC13               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 7672  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 7672       |
| 17       | DL_TFC17                 | UL_TFC14               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 7672  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 7672                |
| 18       | DL_TFC18                 | UL_TFC12               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 10232 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 10232 |
| 19       | DL_TFC19                 | UL_TFC13               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 10232 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 10232      |
| 20       | DL_TFC20                 | UL_TFC14               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 10232 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 10232               |
| 21       | DL_TFC21                 | UL_TFC12               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 12792 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 12792 |
| 22       | DL_TFC22                 | UL_TFC13               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 12792 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 12792      |
| 23       | DL_TFC23                 | UL_TFC14               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 12792 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 12792               |
| 24       | DL_TFC24                 | UL_TFC12               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 15352 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 15352 |
| 25       | DL_TFC25                 | UL_TFC13               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 15352 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 15352      |
| 26       | DL_TFC26                 | UL_TFC14               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 15352 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 15352               |
| 27       | DL_TFC27                 | UL_TFC12               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 17912 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 17912 |
| 28       | DL_TFC28                 | UL_TFC13               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 17912 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 17912      |
| 29       | DL_TFC29                 | UL_TFC14               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 17912 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 17912               |
| 30       | DL_TFC30                 | UL_TFC12               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 20472 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 20472 |
| 31       | DL_TFC31                 | UL_TFC13               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 20472 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 20472      |



| Sub-test | Downlink TFCs under test | Uplink TFCs Under test | Implicitely tested                            | Restricted-UL TFCIs                            | UL RLC SDU-size (bits) (note)                | Test data-size (bits) (note)                               |
|----------|--------------------------|------------------------|-----------------------------------------------|------------------------------------------------|----------------------------------------------|------------------------------------------------------------|
| 32       | DL_TFC32                 | UL_TFC14               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 20472 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 20472               |
| 33       | DL_TFC33                 | UL_TFC12               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 23032 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 23032 |
| 34       | DL_TFC34                 | UL_TFC13               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 23032 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 23032      |
| 35       | DL_TFC35                 | UL_TFC14               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 23032 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 23032               |
| 36       | DL_TFC36                 | UL_TFC12               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 25592 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 25592 |
| 37       | DL_TFC37                 | UL_TFC13               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 25592 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 25592      |
| 38       | DL_TFC38                 | UL_TFC14               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 25592 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 25592               |
| 39       | DL_TFC39                 | UL_TFC12               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 28152 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 28152 |
| 40       | DL_TFC40                 | UL_TFC13               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 28152 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 28152      |
| 41       | DL_TFC41                 | UL_TFC14               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 28152 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 28152               |
| 42       | DL_TFC42                 | UL_TFC12               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 30712 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 30712 |
| 43       | DL_TFC43                 | UL_TFC13               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 30712 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 30712      |
| 44       | DL_TFC44                 | UL_TFC14               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 30712 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 30712               |
| 45       | DL_TFC45                 | UL_TFC12               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 33272 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 33272 |
| 46       | DL_TFC46                 | UL_TFC13               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 33272 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 33272      |
| 47       | DL_TFC47                 | UL_TFC14               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 33272 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 33272               |

| Sub-test                                                                              | Downlink TFCs under test | Uplink TFCs Under test | Implicitely tested                            | Restricted-UL TFCIs                            | UL RLC SDU-size (bits) (note)                | Test data-size (bits) (note)                               |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|-----------------------------------------------|------------------------------------------------|----------------------------------------------|------------------------------------------------------------|
| 48                                                                                    | DL_TFC48                 | UL_TFC12               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 35832 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 35832 |
| 49                                                                                    | DL_TFC49                 | UL_TFC13               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 35832 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 35832      |
| 50                                                                                    | DL_TFC50                 | UL_TFC14               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 35832 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 35832               |
| 51                                                                                    | DL_TFC51                 | UL_TFC12               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 38392 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 38392 |
| 52                                                                                    | DL_TFC52                 | UL_TFC13               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 38392 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 38392      |
| 53                                                                                    | DL_TFC53                 | UL_TFC14               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 38392 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 38392               |
| 54                                                                                    | DL_TFC54                 | UL_TFC12               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 40952 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 40952 |
| 55                                                                                    | DL_TFC55                 | UL_TFC13               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC28 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 40952 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 40952      |
| 56                                                                                    | DL_TFC56                 | UL_TFC14               | DL_TFC0,<br>DL_TFC57,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 40952 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 40952               |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                               |                                                |                                              |                                                            |

See 14.1.1 for test procedure.

#### 14.2.44.2.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x39).
  - for sub-test 2: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).
  - for sub-test 3: RB8/TF1 (1x336)
  - for sub-test 4: RB5/TF1 (1x39) and RB8/TF1 (1x336).
  - for sub-test 5: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF1 (1x336).
  - for sub-test 6: RB8/TF2 (2x336)
  - for sub-test 7: RB5/TF1 (1x39) and RB8/TF2 (2x336).
  - for sub-test 8: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF2 (2x336).

- for sub-test 9: RB8/TF3 (4x336)
- for sub-test 10: RB5/TF1 (1x39) and RB8/TF3 (4x336).
- for sub-test 11: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF3 (4x336).
- for sub-test 12,15,18,21,24,27,30,33,36,39,42: RB8/TF4 (8x336)
- for sub-test 13,16,19,22,25,28,31,34,37,40,43: RB5/TF1 (1x39) and RB8/TF4 (8x336).
- for sub-test 14,17,20,23,26,29,32,35,38,41,44: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF4 (8x336).

3. At step 15 the UE shall return

- for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6, RB7 and RB8.
- for sub-test 2: an RLC SDU on RB5, RB6 and RB7 having the same content as sent by SS; and no data shall be received on RB8.
- for sub-test 3, 6, 9, 12, 15, 18, 21, 24, 27, 30, 33, 36, 39, 42: an RLC SDU on RB8 having the same content as sent by SS; and no data shall be received on RB5, RB6 and RB7.
- for sub-test 4, 7, 10, 13, 16, 19, 22, 25, 28, 31, 34, 37, 40, 43: an RLC SDU on RB5 and RB8 having the same content as sent by SS; and no data shall be received on RB6 and RB7.
- for sub-test 5, 8, 11, 14, 17, 20, 23, 26, 29, 32, 35, 38, 41, 44: an RLC SDU on RB5, RB6, RB7 and RB8 having the same content as sent by SS.

#### ~~14.2.45 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Streaming / unknown / UL:57.6 DL:57.6 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

~~14.2.45.1 Conformance requirement~~

~~See 14.2.4.1.~~

~~14.2.45.2 Test purpose~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.45.~~

~~14.2.45.3 Method of test~~

~~Uplink TFS:~~

|     | TFI       | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | RB7<br>(RAB subflow #3) | RB8<br>(57.6<br>kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-----------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x576                 | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x576                 | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x576                 | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 3x576                 | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 4x576                 | N/A   |

## Uplink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| UL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| UL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| UL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| UL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| UL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| UL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| UL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| UL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| UL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| UL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| UL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| UL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| UL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| UL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| UL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| UL_TFC15 | (TF0, TF0, TF0, TF0, TF1)  |
| UL_TFC16 | (TF1, TF0, TF0, TF0, TF1)  |
| UL_TFC17 | (TF2, TF1, TF1, TF0, TF1)  |
| UL_TFC18 | (TF0, TF0, TF0, TF1, TF1)  |
| UL_TFC19 | (TF1, TF0, TF0, TF1, TF1)  |
| UL_TFC20 | (TF2, TF1, TF1, TF1, TF1)  |
| UL_TFC21 | (TF0, TF0, TF0, TF2, TF1)  |
| UL_TFC22 | (TF1, TF0, TF0, TF2, TF1)  |
| UL_TFC23 | (TF2, TF1, TF1, TF2, TF1)  |
| UL_TFC24 | (TF0, TF0, TF0, TF3, TF1)  |
| UL_TFC25 | (TF1, TF0, TF0, TF3, TF1)  |
| UL_TFC26 | (TF2, TF1, TF1, TF3, TF1)  |
| UL_TFC27 | (TF0, TF0, TF0, TF4, TF1)  |
| UL_TFC28 | (TF1, TF0, TF0, TF4, TF1)  |
| UL_TFC29 | (TF2, TF1, TF1, TF4, TF1)  |

## Downlink TFS:

|     |           | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | RB8<br>(57.6 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|--------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x103                   | 0x60                    | 0x576              | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x576              | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x576              | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 3x576              | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 4x576              | N/A   |

## Downlink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| DL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| DL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| DL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| DL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| DL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| DL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| DL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| DL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| DL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| DL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| DL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| DL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| DL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| DL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| DL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| DL_TFC15 | (TF0, TF0, TF0, TF0, TF1)  |
| DL_TFC16 | (TF1, TF0, TF0, TF0, TF1)  |
| DL_TFC17 | (TF2, TF1, TF1, TF0, TF1)  |
| DL_TFC18 | (TF0, TF0, TF0, TF1, TF1)  |
| DL_TFC19 | (TF1, TF0, TF0, TF1, TF1)  |
| DL_TFC20 | (TF2, TF1, TF1, TF1, TF1)  |
| DL_TFC21 | (TF0, TF0, TF0, TF2, TF1)  |
| DL_TFC22 | (TF1, TF0, TF0, TF2, TF1)  |
| DL_TFC23 | (TF2, TF1, TF1, TF2, TF1)  |
| DL_TFC24 | (TF0, TF0, TF0, TF3, TF1)  |
| DL_TFC25 | (TF1, TF0, TF0, TF3, TF1)  |
| DL_TFC26 | (TF2, TF1, TF1, TF3, TF1)  |
| DL_TFC27 | (TF0, TF0, TF0, TF4, TF1)  |
| DL_TFC28 | (TF1, TF0, TF0, TF4, TF1)  |
| DL_TFC29 | (TF2, TF1, TF1, TF4, TF1)  |

Sub-tests:

| Sub-test                                                                                | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                            | Restricted-UL TFCIs                            | UL RLC-SDU size (bits) (note)               | Test-data-size (bits) (note)                              |
|-----------------------------------------------------------------------------------------|--------------------------|------------------------|-----------------------------------------------|------------------------------------------------|---------------------------------------------|-----------------------------------------------------------|
| 1                                                                                       | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC15,<br>UL_TFC16  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data   |
| 2                                                                                       | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC15,<br>UL_TFC17  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data            |
| 3                                                                                       | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC15,<br>UL_TFC18  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576  | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 336  |
| 4                                                                                       | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC15,<br>UL_TFC19  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576  | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 576       |
| 5                                                                                       | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC15,<br>UL_TFC20  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576                |
| 6                                                                                       | DL_TFC6                  | UL_TFC6                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC15,<br>UL_TFC21  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1152 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 1152 |
| 7                                                                                       | DL_TFC7                  | UL_TFC7                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC15,<br>UL_TFC22  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1152 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 1152      |
| 8                                                                                       | DL_TFC8                  | UL_TFC8                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC15,<br>UL_TFC23  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1152 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1152               |
| 9                                                                                       | DL_TFC9                  | UL_TFC9                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC15,<br>UL_TFC24  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1728 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 1728 |
| 10                                                                                      | DL_TFC10                 | UL_TFC10               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC10,<br>UL_TFC15,<br>UL_TFC25 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1728 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 1728      |
| 11                                                                                      | DL_TFC11                 | UL_TFC11               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC11,<br>UL_TFC15,<br>UL_TFC26 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1728 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1728               |
| 12                                                                                      | DL_TFC12                 | UL_TFC12               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC12,<br>UL_TFC15,<br>UL_TFC26 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2304 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 2304 |
| 13                                                                                      | DL_TFC13                 | UL_TFC13               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC13,<br>UL_TFC15,<br>UL_TFC27 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2304 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 2304      |
| 14                                                                                      | DL_TFC14                 | UL_TFC14               | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC15 | UL_TFC0,<br>UL_TFC14,<br>UL_TFC15,<br>UL_TFC29 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2304 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2304               |
| NOTE: — See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                               |                                                |                                             |                                                           |

See 14.1.1 for test procedure.

#### ~~14.2.45.4 Test requirements~~

~~See 14.1.1 for definition of step 10 and step 15.~~

~~1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.~~

~~2. At step 15 the UE transmitted transport format shall be~~

~~— for sub-test 1: RB5/TF1 (1x39).~~

~~— for sub-test 2: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).~~

~~— for sub-test 3: RB8/TF1 (1x576)~~

~~— for sub-test 4: RB5/TF1 (1x39) and RB8/TF1 (1x576).~~

~~— for sub-test 5: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF1 (1x576).~~

~~— for sub-test 6: RB8/TF2 (2x576)~~

~~— for sub-test 7: RB5/TF1 (1x39) and RB8/TF2 (2x576).~~

~~— for sub-test 8: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF2 (2x576).~~

~~— for sub-test 9: RB8/TF2 (3x576)~~

~~— for sub-test 10: RB5/TF1 (1x39) and RB8/TF3 (3x576).~~

~~— for sub-test 11: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF3 (3x576).~~

~~— for sub-test 12: RB8/TF2 (4x576)~~

~~— for sub-test 13: RB5/TF1 (1x39) and RB8/TF4 (4x576).~~

~~— for sub-test 14: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF4 (4x576).~~

~~3. At step 15 the UE shall return~~

~~— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6, RB7 and RB8.~~

~~— for sub-test 2: an RLC SDU on RB5, RB6 and RB7 having the same content as sent by SS; and no data shall be received on RB8.~~

~~— for sub-test 3, 6, 9 and 12: an RLC SDU on RB8 having the same content as sent by SS; and no data shall be received on RB5, RB6 and RB7.~~

~~— for sub-test 4, 7, 10 and 13: an RLC SDU on RB5 and RB8 having the same content as sent by SS; and no data shall be received on RB6 and RB7.~~

~~— for sub-test 5, 8, 11 and 14: an RLC SDU on RB5, RB6, RB7 and RB8 having the same content as sent by SS.~~

#### ~~14.2.46 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Streaming / unknown / UL:0 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

##### ~~14.2.46.1 Conformance requirement~~

~~See 14.2.4.1.~~

##### ~~14.2.46.2 Test purpose~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.46.~~

To be able to test the downlink radio bearer using the UE loopback function for the reference radio bearer UL:0 DL: 64 kbps,, the reference radio bearer configuration according to TS 34.108, clause 6.10.2.4.1.15.1 (Streaming/unknown/UL:14.4 kbps) is used in uplink.

#### 14.2.46.3 Method of test

Uplink TFS:

|     | TFI       | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | RB8<br>(14.4 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|--------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x576              | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x576              | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | N/A                | N/A   |

Uplink TFCs:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| UL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| UL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| UL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| UL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| UL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| UL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| UL_TFC6  | (TF0, TF0, TF0, TF0, TF1)  |
| UL_TFC7  | (TF1, TF0, TF0, TF0, TF1)  |
| UL_TFC8  | (TF2, TF1, TF1, TF0, TF1)  |
| UL_TFC9  | (TF0, TF0, TF0, TF1, TF1)  |
| UL_TFC10 | (TF1, TF0, TF0, TF1, TF1)  |
| UL_TFC11 | (TF2, TF1, TF1, TF1, TF1)  |

Downlink TFS:

|     |           | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | RB8<br>(64 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x103                   | 0x60                    | 0x320            | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x320            | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x320            | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 4x320            | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 8x320            | N/A   |



## Downlink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| DL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| DL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| DL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| DL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| DL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| DL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| DL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| DL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| DL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| DL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| DL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| DL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| DL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| DL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| DL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| DL_TFC15 | (TF0, TF0, TF0, TF0, TF1)  |
| DL_TFC16 | (TF1, TF0, TF0, TF0, TF1)  |
| DL_TFC17 | (TF2, TF1, TF1, TF0, TF1)  |
| DL_TFC18 | (TF0, TF0, TF0, TF1, TF1)  |
| DL_TFC19 | (TF1, TF0, TF0, TF1, TF1)  |
| DL_TFC20 | (TF2, TF1, TF1, TF1, TF1)  |
| DL_TFC21 | (TF0, TF0, TF0, TF2, TF1)  |
| DL_TFC22 | (TF1, TF0, TF0, TF2, TF1)  |
| DL_TFC23 | (TF2, TF1, TF1, TF2, TF1)  |
| DL_TFC24 | (TF0, TF0, TF0, TF3, TF1)  |
| DL_TFC25 | (TF1, TF0, TF0, TF3, TF1)  |
| DL_TFC26 | (TF2, TF1, TF1, TF3, TF1)  |
| DL_TFC27 | (TF0, TF0, TF0, TF4, TF1)  |
| DL_TFC28 | (TF1, TF0, TF0, TF4, TF1)  |
| DL_TFC29 | (TF2, TF1, TF1, TF4, TF1)  |

## Sub-tests:

| Sub-test | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                           | Restricted-UL TFCIs                          | UL-RLC SDU size (bits)<br>(note 1)         | Test data size (bits)<br>(note 1)                                     |
|----------|--------------------------|------------------------|----------------------------------------------|----------------------------------------------|--------------------------------------------|-----------------------------------------------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC6,<br>UL_TFC7  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data               |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC6,<br>UL_TFC8  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data                        |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 320<br>(note 2)  |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 320<br>(note 2)       |
| 5        | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 320<br>(note 2)                |
| 6        | DL_TFC6                  | UL_TFC3                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 640<br>(note 3)  |
| 7        | DL_TFC7                  | UL_TFC4                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 640<br>(note 3)       |
| 8        | DL_TFC8                  | UL_TFC5                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 640<br>(note 3)                |
| 9        | DL_TFC9                  | UL_TFC3                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 1280<br>(note 4) |
| 10       | DL_TFC10                 | UL_TFC4                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 1280<br>(note 4)      |
| 11       | DL_TFC11                 | UL_TFC5                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1280<br>(note 4)               |
| 12       | DL_TFC12                 | UL_TFC3                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 2560<br>(note 5) |

| Sub-test | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                           | Restricted UL TFCIs                          | UL RLC SDU-size (bits) (note 1)            | Test data size (bits) (note 1)                                   |
|----------|--------------------------|------------------------|----------------------------------------------|----------------------------------------------|--------------------------------------------|------------------------------------------------------------------|
| 13       | DL_TFC13                 | UL_TFC4                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 2560<br>(note 5) |
| 14       | DL_TFC14                 | UL_TFC5                | DL_TFC0,<br>DL_TFC15,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2560<br>(note 5)          |

NOTE 1: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

NOTE 2: RB8: SS is using a DL RLC SDU with 320 bits as test data (=DL RLC PDU size for DL/TF1). UE will return one RLC PDU. SS creates an UL RLC SDU from the first 320 bits of the received RLC PDU.

NOTE 3: RB8: SS is using a DL RLC SDU size of 640 bits as test data (=DL RLC PDU size for DL/TF2). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.

NOTE 4: RB8: SS is using a DL RLC SDU size of 1280 bits as test data (=DL RLC PDU size for DL/TF3). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.

NOTE 5: RB8: SS is using a DL RLC SDU size of 2560 bits as test data (=DL RLC PDU size for DL/TF4). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.

See 14.1.1 for test procedure.

#### 14.2.46.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

— for sub-test 1, 4, 7, 10 and 13: RB5/TF1 (1x39).

— for sub-test 2, 5, 8, 11 and 14: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).

3. At step 15 the UE shall return

— for sub-test 3, 6, 9 and 12: no data on RB5, RB6 and RB7.

— for sub-test 1, 4, 7, 10 and 13: an RLC SDU on RB5 having the same content as sent by the SS; and no data shall be received on RB6 or RB7.

— for sub-test 2, 5, 8, 11 and 14: an RLC SDU on each of RB5, RB6 and RB7 having the same content as sent by the SS.

— for sub-test 1 to 2: no data on RB8.

— for sub-test 3 to 5: an RLC SDU on RB8 having the same content as sent by the SS.

— for sub-test 6 to 14: an RLC SDU on RB5 having the same content as the first 576 bits of the RLC SDU sent by the SS.

#### 14.2.47 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Streaming / unknown / UL:0 DL:128 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH

##### 14.2.47.1 Conformance requirement

See 14.2.4.1.

## 14.2.47.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.47.

To be able to test the downlink radio bearer using the UE loopback function for the reference radio bearer UL:0 DL: 128 kbps, the reference radio bearer configuration according to TS 34.108, clause 6.10.2.4.1.15.1 (Streaming/unknown/UL:14.4 kbps) is used in uplink.

## 14.2.47.3 Method of test

Uplink-TFS:

|     | TFI       | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | RB8<br>(14.4 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|--------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x576              | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x576              | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | N/A                | N/A   |

Uplink-TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| UL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| UL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| UL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| UL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| UL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| UL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| UL_TFC6  | (TF0, TF0, TF0, TF0, TF1)  |
| UL_TFC7  | (TF1, TF0, TF0, TF0, TF1)  |
| UL_TFC8  | (TF2, TF1, TF1, TF0, TF1)  |
| UL_TFC9  | (TF0, TF0, TF0, TF1, TF1)  |
| UL_TFC10 | (TF1, TF0, TF0, TF1, TF1)  |
| UL_TFC11 | (TF2, TF1, TF1, TF1, TF1)  |

Downlink-TFS:

|     |           | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | RB8<br>(128 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x103                   | 0x60                    | 0x320             | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x320             | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | 2x320             | N/A   |
|     | TF3, bits | N/A                     | N/A                     | N/A                     | 4x320             | N/A   |
|     | TF4, bits | N/A                     | N/A                     | N/A                     | 8x320             | N/A   |
|     | TF5, bits | N/A                     | N/A                     | N/A                     | 16x320            | N/A   |

## Downlink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| DL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| DL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| DL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| DL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| DL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| DL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| DL_TFC6  | (TF0, TF0, TF0, TF2, TF0)  |
| DL_TFC7  | (TF1, TF0, TF0, TF2, TF0)  |
| DL_TFC8  | (TF2, TF1, TF1, TF2, TF0)  |
| DL_TFC9  | (TF0, TF0, TF0, TF3, TF0)  |
| DL_TFC10 | (TF1, TF0, TF0, TF3, TF0)  |
| DL_TFC11 | (TF2, TF1, TF1, TF3, TF0)  |
| DL_TFC12 | (TF0, TF0, TF0, TF4, TF0)  |
| DL_TFC13 | (TF1, TF0, TF0, TF4, TF0)  |
| DL_TFC14 | (TF2, TF1, TF1, TF4, TF0)  |
| DL_TFC15 | (TF0, TF0, TF0, TF5, TF0)  |
| DL_TFC16 | (TF1, TF0, TF0, TF5, TF0)  |
| DL_TFC17 | (TF2, TF1, TF1, TF5, TF0)  |
| DL_TFC18 | (TF0, TF0, TF0, TF0, TF1)  |
| DL_TFC19 | (TF1, TF0, TF0, TF0, TF1)  |
| DL_TFC20 | (TF2, TF1, TF1, TF0, TF1)  |
| DL_TFC21 | (TF0, TF0, TF0, TF1, TF1)  |
| DL_TFC22 | (TF1, TF0, TF0, TF1, TF1)  |
| DL_TFC23 | (TF2, TF1, TF1, TF1, TF1)  |
| DL_TFC24 | (TF0, TF0, TF0, TF2, TF1)  |
| DL_TFC25 | (TF1, TF0, TF0, TF2, TF1)  |
| DL_TFC26 | (TF2, TF1, TF1, TF2, TF1)  |
| DL_TFC27 | (TF0, TF0, TF0, TF3, TF1)  |
| DL_TFC28 | (TF1, TF0, TF0, TF3, TF1)  |
| DL_TFC29 | (TF2, TF1, TF1, TF3, TF1)  |
| DL_TFC30 | (TF0, TF0, TF0, TF4, TF1)  |
| DL_TFC31 | (TF1, TF0, TF0, TF4, TF1)  |
| DL_TFC32 | (TF2, TF1, TF1, TF4, TF1)  |
| DL_TFC33 | (TF0, TF0, TF0, TF5, TF1)  |
| DL_TFC34 | (TF1, TF0, TF0, TF5, TF1)  |
| DL_TFC35 | (TF2, TF1, TF1, TF5, TF1)  |

## Sub-tests:

| Sub-test | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely-tested                           | Restricted-UL TFCIs                          | UL RLC SDU size (bits)<br>(note 1)         | Test data size (bits)<br>(note 1)                                     |
|----------|--------------------------|------------------------|----------------------------------------------|----------------------------------------------|--------------------------------------------|-----------------------------------------------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC6,<br>UL_TFC7  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data               |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC6,<br>UL_TFC8  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data                        |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 320<br>(note 2)  |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 320<br>(note 2)       |
| 5        | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 320<br>(note 2)                |
| 6        | DL_TFC6                  | UL_TFC3                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 640<br>(note 3)  |
| 7        | DL_TFC7                  | UL_TFC4                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 640<br>(note 3)       |
| 8        | DL_TFC8                  | UL_TFC5                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 640<br>(note 3)                |
| 9        | DL_TFC9                  | UL_TFC3                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 1280<br>(note 4) |
| 10       | DL_TFC10                 | UL_TFC4                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 1280<br>(note 4)      |
| 11       | DL_TFC11                 | UL_TFC5                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1280<br>(note 4)               |
| 12       | DL_TFC12                 | UL_TFC3                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 2560<br>(note 5) |

| Sub-test                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                           | Restricted UL TFCIs                          | UL RLC SDU size (bits) (note 1)            | Test data size (bits) (note 1)                                        |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|------------------------|----------------------------------------------|----------------------------------------------|--------------------------------------------|-----------------------------------------------------------------------|
| 13                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | DL_TFC13                 | UL_TFC4                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 2560<br>(note 5)      |
| 14                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | DL_TFC14                 | UL_TFC5                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2560<br>(note 5)               |
| 15                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | DL_TFC15                 | UL_TFC3                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 5120<br>(note 6) |
| 16                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | DL_TFC16                 | UL_TFC4                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 5120<br>(note 6)      |
| 17                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | DL_TFC17                 | UL_TFC5                | DL_TFC0,<br>DL_TFC18,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 5120<br>(note 6)               |
| <p>NOTE 1: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.</p> <p>NOTE 2: RB8: SS is using a DL RLC SDU with 320 bits as test data (=DL RLC PDU size for DL/TF1). UE will return 1 RLC PDU. SS creates an UL RLC SDU from the first 320 bits of the received RLC PDU.</p> <p>NOTE 3: RB8: SS is using a DL RLC SDU size of 640 bits as test data (=DL RLC PDU size for DL/TF2). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 4: RB8: SS is using a DL RLC SDU size of 1280 bits as test data (=DL RLC PDU size for DL/TF3). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 5: RB8: SS is using a DL RLC SDU size of 2560 bits as test data (=DL RLC PDU size for DL/TF4). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 6: RB8: SS is using a DL RLC SDU size of 5120 bits as test data (=DL RLC PDU size for DL/TF5). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> |                          |                        |                                              |                                              |                                            |                                                                       |

See 14.1.1 for test procedure.

#### 14.2.47.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1, 4, 7, 10, 13 and 16: RB5/TF1 (1x39);
  - for sub-test 2, 5, 8, 11, 14 and 17: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).
3. At step 15 the UE shall return
  - for sub-test 3, 6, 9, 12 and 15: no data on RB5, RB6 and RB7.
  - for sub-test 1, 4, 7, 10, 13 and 16: an RLC SDU on RB5 having the same content as sent by the SS; and no data shall be received on RB6 or RB7.
  - for sub-test 2, 5, 8, 11, 14 and 17: an RLC SDU on each of RB5, RB6 and RB7 having the same content as sent by the SS.
  - for sub-test 1 to 2: no data on RB8.

- for sub-test 3 to 5: an RLC SDU on RB8 having the same content as sent by the SS.
- for sub-test 6 to 17: an RLC SDU on RB5 having the same content as the first 576 bits of the RLC SDU sent by the SS.

#### ~~14.2.48 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Streaming / unknown / UL:0 DL:384 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

##### ~~14.2.48.1 Conformance requirement~~

~~See 14.2.4.1.~~

##### ~~14.2.48.2 Test purpose~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.48.~~

~~To be able to test the downlink radio bearer using the UE loopback function for the reference radio bearer UL:0 DL:384 kbps,, the reference radio bearer configuration according to TS 34.108, clause 6.10.2.4.1.15.1 (Streaming/unknown/UL:14.4 kbps) is used in uplink.~~

##### ~~14.2.48.3 Method of test~~

~~Uplink TFS:~~

|            | <b>TFI</b> | <b>RB5<br/>(RAB subflow #1)</b> | <b>RB6<br/>(RAB subflow #2)</b> | <b>RB7<br/>(RAB subflow #3)</b> | <b>RB8<br/>(14.4 kbps)</b> | <b>DCCH</b> |
|------------|------------|---------------------------------|---------------------------------|---------------------------------|----------------------------|-------------|
| <b>TFS</b> | TF0, bits  | 0x81(alt. 1x0)                  | 0x103                           | 0x60                            | 0x576                      | 0x148       |
|            | TF1, bits  | 1x39                            | 1x103                           | 1x60                            | 1x576                      | 1x148       |
|            | TF2, bits  | 1x81                            | N/A                             | N/A                             | N/A                        | N/A         |

~~Uplink TFCS:~~

| <b>TFCI</b> | <b>(RB5, RB6, RB7, RB8, DCCH)</b> |
|-------------|-----------------------------------|
| UL_TFC0     | (TF0, TF0, TF0, TF0, TF0)         |
| UL_TFC1     | (TF1, TF0, TF0, TF0, TF0)         |
| UL_TFC2     | (TF2, TF1, TF1, TF0, TF0)         |
| UL_TFC3     | (TF0, TF0, TF0, TF1, TF0)         |
| UL_TFC4     | (TF1, TF0, TF0, TF1, TF0)         |
| UL_TFC5     | (TF2, TF1, TF1, TF1, TF0)         |
| UL_TFC6     | (TF0, TF0, TF0, TF0, TF1)         |
| UL_TFC7     | (TF1, TF0, TF0, TF0, TF1)         |
| UL_TFC8     | (TF2, TF1, TF1, TF0, TF1)         |
| UL_TFC9     | (TF0, TF0, TF0, TF1, TF1)         |
| UL_TFC10    | (TF1, TF0, TF0, TF1, TF1)         |
| UL_TFC11    | (TF2, TF1, TF1, TF1, TF1)         |



## Downlink TFS:

|            |           | <b>RB5</b><br><b>(RAB subflow #1)</b> | <b>RB6</b><br><b>(RAB subflow #2)</b> | <b>RB7</b><br><b>(RAB subflow #3)</b> | <b>RB8</b><br><b>(128 kbps)</b> | <b>DCCH</b> |
|------------|-----------|---------------------------------------|---------------------------------------|---------------------------------------|---------------------------------|-------------|
| <b>TFS</b> | TF0, bits | 1x0                                   | 0x103                                 | 0x60                                  | 0x320                           | 0x148       |
|            | TF1, bits | 1x39                                  | 1x103                                 | 1x60                                  | 1x320                           | 1x148       |
|            | TF2, bits | 1x81                                  | N/A                                   | N/A                                   | 2x320                           | N/A         |
|            | TF3, bits | N/A                                   | N/A                                   | N/A                                   | 4x320                           | N/A         |
|            | TF4, bits | N/A                                   | N/A                                   | N/A                                   | 8x320                           | N/A         |
|            | TF5, bits | N/A                                   | N/A                                   | N/A                                   | 16x320                          | N/A         |
|            | TF6, bits | N/A                                   | N/A                                   | N/A                                   | 32x320                          | N/A         |
|            | TF7, bits | N/A                                   | N/A                                   | N/A                                   | 48x320                          | N/A         |

## Downlink TFCs:

| <b>TFCI</b> | <b>(RB5, RB6, RB7, RB8, DCCH)</b> |
|-------------|-----------------------------------|
| DL_TFC0     | (TF0, TF0, TF0, TF0, TF0)         |
| DL_TFC1     | (TF1, TF0, TF0, TF0, TF0)         |
| DL_TFC2     | (TF2, TF1, TF1, TF0, TF0)         |
| DL_TFC3     | (TF0, TF0, TF0, TF1, TF0)         |
| DL_TFC4     | (TF1, TF0, TF0, TF1, TF0)         |
| DL_TFC5     | (TF2, TF1, TF1, TF1, TF0)         |
| DL_TFC6     | (TF0, TF0, TF0, TF2, TF0)         |
| DL_TFC7     | (TF1, TF0, TF0, TF2, TF0)         |
| DL_TFC8     | (TF2, TF1, TF1, TF2, TF0)         |
| DL_TFC9     | (TF0, TF0, TF0, TF3, TF0)         |
| DL_TFC10    | (TF1, TF0, TF0, TF3, TF0)         |
| DL_TFC11    | (TF2, TF1, TF1, TF3, TF0)         |
| DL_TFC12    | (TF0, TF0, TF0, TF4, TF0)         |
| DL_TFC13    | (TF1, TF0, TF0, TF4, TF0)         |
| DL_TFC14    | (TF2, TF1, TF1, TF4, TF0)         |
| DL_TFC15    | (TF0, TF0, TF0, TF5, TF0)         |
| DL_TFC16    | (TF1, TF0, TF0, TF5, TF0)         |
| DL_TFC17    | (TF2, TF1, TF1, TF5, TF0)         |
| DL_TFC18    | (TF0, TF0, TF0, TF6, TF0)         |
| DL_TFC19    | (TF1, TF0, TF0, TF6, TF0)         |
| DL_TFC20    | (TF2, TF1, TF1, TF6, TF0)         |
| DL_TFC21    | (TF0, TF0, TF0, TF7, TF0)         |
| DL_TFC22    | (TF1, TF0, TF0, TF7, TF0)         |
| DL_TFC23    | (TF2, TF1, TF1, TF7, TF0)         |
| DL_TFC24    | (TF0, TF0, TF0, TF0, TF1)         |
| DL_TFC25    | (TF1, TF0, TF0, TF0, TF1)         |
| DL_TFC26    | (TF2, TF1, TF1, TF0, TF1)         |
| DL_TFC27    | (TF0, TF0, TF0, TF1, TF1)         |
| DL_TFC28    | (TF1, TF0, TF0, TF1, TF1)         |
| DL_TFC29    | (TF2, TF1, TF1, TF1, TF1)         |
| DL_TFC30    | (TF0, TF0, TF0, TF2, TF1)         |
| DL_TFC31    | (TF1, TF0, TF0, TF2, TF1)         |
| DL_TFC32    | (TF2, TF1, TF1, TF2, TF1)         |
| DL_TFC33    | (TF0, TF0, TF0, TF3, TF1)         |
| DL_TFC34    | (TF1, TF0, TF0, TF3, TF1)         |
| DL_TFC35    | (TF2, TF1, TF1, TF3, TF1)         |
| DL_TFC36    | (TF0, TF0, TF0, TF4, TF1)         |
| DL_TFC37    | (TF1, TF0, TF0, TF4, TF1)         |
| DL_TFC38    | (TF2, TF1, TF1, TF4, TF1)         |
| DL_TFC39    | (TF0, TF0, TF0, TF5, TF1)         |
| DL_TFC40    | (TF1, TF0, TF0, TF5, TF1)         |
| DL_TFC41    | (TF2, TF1, TF1, TF5, TF1)         |
| DL_TFC42    | (TF0, TF0, TF0, TF6, TF1)         |
| DL_TFC43    | (TF1, TF0, TF0, TF6, TF1)         |
| DL_TFC44    | (TF2, TF1, TF1, TF6, TF1)         |
| DL_TFC45    | (TF0, TF0, TF0, TF7, TF1)         |
| DL_TFC46    | (TF1, TF0, TF0, TF7, TF1)         |

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| DL_TFC47 | (TF2, TF1, TF1, TF7, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                           | Restricted UL TFCIs                          | UL RLC SDU size (bits) (note 1)            | Test data size (bits) (note 1)                                        |
|----------|--------------------------|------------------------|----------------------------------------------|----------------------------------------------|--------------------------------------------|-----------------------------------------------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC6,<br>UL_TFC7  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data               |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC6,<br>UL_TFC8  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data                        |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 320<br>(note 2)  |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 320<br>(note 2)       |
| 5        | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 320<br>(note 2)                |
| 6        | DL_TFC6                  | UL_TFC3                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 640<br>(note 3)  |
| 7        | DL_TFC7                  | UL_TFC4                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 640<br>(note 3)       |
| 8        | DL_TFC8                  | UL_TFC5                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 640<br>(note 3)                |
| 9        | DL_TFC9                  | UL_TFC3                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 1280<br>(note 4) |
| 10       | DL_TFC10                 | UL_TFC4                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 1280<br>(note 4)      |
| 11       | DL_TFC11                 | UL_TFC5                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1280<br>(note 4)               |
| 12       | DL_TFC12                 | UL_TFC3                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 2560<br>(note 5) |

| Sub-test | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                           | Restricted-UL TFCIs                          | UL RLC SDU size (bits) (note 1)            | Test data-size (bits) (note 1)                                         |
|----------|--------------------------|------------------------|----------------------------------------------|----------------------------------------------|--------------------------------------------|------------------------------------------------------------------------|
| 13       | DL_TFC13                 | UL_TFC4                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 2560<br>(note 5)       |
| 14       | DL_TFC14                 | UL_TFC5                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2560<br>(note 5)                |
| 15       | DL_TFC15                 | UL_TFC3                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 5120<br>(note 6)  |
| 16       | DL_TFC16                 | UL_TFC4                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 5120<br>(note 6)       |
| 17       | DL_TFC17                 | UL_TFC5                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 5120<br>(note 6)                |
| 18       | DL_TFC18                 | UL_TFC3                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 10240<br>(note 7) |
| 19       | DL_TFC19                 | UL_TFC4                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 10240<br>(note 7)      |
| 20       | DL_TFC20                 | UL_TFC5                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 10240<br>(note 7)               |
| 21       | DL_TFC21                 | UL_TFC3                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 15360<br>(note 8) |

| Sub-test                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                           | Restricted-UL TFCIs                          | UL RLC SDU size (bits) (note 1)            | Test data size (bits) (note 1)                                    |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|------------------------|----------------------------------------------|----------------------------------------------|--------------------------------------------|-------------------------------------------------------------------|
| 22                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | DL_TFC22                 | UL_TFC4                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 15360<br>(note 8) |
| 23                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | DL_TFC23                 | UL_TFC5                | DL_TFC0,<br>DL_TFC24,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 576 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 15360<br>(note 8)          |
| <p>NOTE 1: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.</p> <p>NOTE 2: RB8: SS is using a DL RLC SDU with 320 bits as test data (=DL RLC PDU size for DL/TF1). UE will return 1 RLC PDU. SS creates an UL RLC SDU from the first 320 bits of the received RLC PDU.</p> <p>NOTE 3: RB8: SS is using a DL RLC SDU size of 640 bits as test data (=DL RLC PDU size for DL/TF2). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 4: RB8: SS is using a DL RLC SDU size of 1280 bits as test data (=DL RLC PDU size for DL/TF3). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 5: RB8: SS is using a DL RLC SDU size of 2560 bits as test data (=DL RLC PDU size for DL/TF4). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 6: RB8: SS is using a DL RLC SDU size of 5120 bits as test data (=DL RLC PDU size for DL/TF5). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 7: RB8: SS is using a DL RLC SDU size of 10240 bits as test data (=DL RLC PDU size for DL/TF6). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 8: RB8: SS is using a DL RLC SDU size of 15360 bits as test data (=DL RLC PDU size for DL/TF7). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> |                          |                        |                                              |                                              |                                            |                                                                   |

See 14.1.1 for test procedure.

#### 14.2.48.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1, 4, 7, 10, 13, 16, 19 and 22: RB5/TF1 (1x39).
  - for sub-test 2, 5, 8, 11, 14, 17, 20 and 23: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).
3. At step 15 the UE shall return
  - for sub-test 3, 6, 9, 12, 15, 18 and 21: no data on RB5, RB6 and RB7.
  - for sub-test 1, 4, 7, 10, 13, 16, 19 and 22: an RLC SDU on RB5 having the same content as sent by the SS; and no data shall be received on RB6 or RB7.
  - for sub-test 2, 5, 8, 11, 14, 17, 20 and 23: an RLC SDU on each of RB5, RB6 and RB7 having the same content as sent by the SS.
  - for sub-test 1 to 2: no data on RB8.
  - for sub-test 3 to 5: an RLC SDU on RB8 having the same content as sent by the SS.
  - for sub-test 6 to 23: an RLC SDU on RB5 having the same content as the first 576 bits of the RLC SDU sent by the SS.

## ~~14.2.49 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Conversational / unknown / UL:64 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

### ~~14.2.49.1 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 20 ms TTI~~

#### ~~14.2.49.1.1 Conformance requirement~~

See 14.2.4.1.

#### ~~14.2.49.1.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.49 for the 20 ms TTI case.

#### ~~14.2.49.1.3 Method of test~~

#### Initial Conditions

The following RLC Info parameter values shall be set by the SS for the Conversational / unknown / UL:64 DL:64 kbps / CS RAB (RB8):

|                                                       |      |
|-------------------------------------------------------|------|
| Uplink RLC<br>— TM RLC<br>— Segmentation indication   | TRUE |
| Downlink RLC<br>— TM RLC<br>— Segmentation indication | TRUE |

#### Uplink TFS:

|     | TFI       | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | RB7<br>(RAB subflow #3) | RB8<br>(64 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x640            | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 2x640            | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | N/A              | N/A   |

#### Uplink TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| UL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| UL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| UL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| UL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| UL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| UL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| UL_TFC6  | (TF0, TF0, TF0, TF0, TF1)  |
| UL_TFC7  | (TF1, TF0, TF0, TF0, TF1)  |
| UL_TFC8  | (TF2, TF1, TF1, TF0, TF1)  |
| UL_TFC9  | (TF0, TF0, TF0, TF1, TF1)  |
| UL_TFC10 | (TF1, TF0, TF0, TF1, TF1)  |
| UL_TFC11 | (TF2, TF1, TF1, TF1, TF1)  |

#### Downlink TFS:

|     |           | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | RB8<br>(64 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x103                   | 0x60                    | 0x640            | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 2x640            | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | N/A              | N/A   |

Downlink-TFCS:

| TFCI     | (RB5, RB6, RB7, RB8, DCCH) |
|----------|----------------------------|
| DL_TFC0  | (TF0, TF0, TF0, TF0, TF0)  |
| DL_TFC1  | (TF1, TF0, TF0, TF0, TF0)  |
| DL_TFC2  | (TF2, TF1, TF1, TF0, TF0)  |
| DL_TFC3  | (TF0, TF0, TF0, TF1, TF0)  |
| DL_TFC4  | (TF1, TF0, TF0, TF1, TF0)  |
| DL_TFC5  | (TF2, TF1, TF1, TF1, TF0)  |
| DL_TFC6  | (TF0, TF0, TF0, TF0, TF1)  |
| DL_TFC7  | (TF1, TF0, TF0, TF0, TF1)  |
| DL_TFC8  | (TF2, TF1, TF1, TF0, TF1)  |
| DL_TFC9  | (TF0, TF0, TF0, TF1, TF1)  |
| DL_TFC10 | (TF1, TF0, TF0, TF1, TF1)  |
| DL_TFC11 | (TF2, TF1, TF1, TF1, TF1)  |

Sub-tests:

| Sub-test                                                                              | Downlink TFCS Under Test | Uplink TFCS Under test | Implicitely tested                          | Restricted-UL TFCIs                          | UL RLC SDU size (bits) (note)               | Test data size (bits) (note)                              |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|---------------------------------------------|----------------------------------------------|---------------------------------------------|-----------------------------------------------------------|
| 1                                                                                     | DL_TFC1                  | UL_TFC1                | DL_TFC0;<br>DL_TFC6;<br>UL_TFC0;<br>UL_TFC6 | UL_TFC0;<br>UL_TFC1;<br>UL_TFC6;<br>UL_TFC7  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1280 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data   |
| 2                                                                                     | DL_TFC2                  | UL_TFC2                | DL_TFC0;<br>DL_TFC6;<br>UL_TFC0;<br>UL_TFC6 | UL_TFC0;<br>UL_TFC2;<br>UL_TFC6;<br>UL_TFC8  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1280 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data            |
| 3                                                                                     | DL_TFC3                  | UL_TFC3                | DL_TFC0;<br>DL_TFC6;<br>UL_TFC0;<br>UL_TFC6 | UL_TFC0;<br>UL_TFC3;<br>UL_TFC6;<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1280 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 1280 |
| 4                                                                                     | DL_TFC4                  | UL_TFC4                | DL_TFC0;<br>DL_TFC6;<br>UL_TFC0;<br>UL_TFC6 | UL_TFC0;<br>UL_TFC4;<br>UL_TFC6;<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 1280 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 1280      |
| 5                                                                                     | DL_TFC5                  | UL_TFC5                | DL_TFC0;<br>DL_TFC6;<br>UL_TFC0;<br>UL_TFC6 | UL_TFC0;<br>UL_TFC5;<br>UL_TFC6;<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1280 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 1280               |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                             |                                              |                                             |                                                           |

See 14.1.1 for test procedure.

#### 14.2.49.1.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

— for sub-test 1: RB5/TF1 (1x39).

— for sub-test 2: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).

- for sub-test 3: RB8/TF1 (2x640)
- for sub-test 4: RB5/TF1 (1x39) and RB8/TF1 (2x640).
- for sub-test 5: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF1 (2x640).

3. At step 15 the UE shall return

- for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6, RB7 and RB8.
- for sub-test 2: an RLC SDU on RB5, RB6 and RB7 having the same content as sent by SS; and no data shall be received on RB8.
- for sub-test 3: an RLC SDU on RB8 having the same content as sent by SS; and no data shall be received on RB5, RB6 and RB7.
- for sub-test 4: an RLC SDU on RB5 and RB8 having the same content as sent by SS; and no data shall be received on RB6 and RB7.
- for sub-test 5: an RLC SDU on RB5, RB6, RB7 and RB8 having the same content as sent by SS.

~~14.2.49.2 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 40 ms TTI~~

~~14.2.49.2.1 Conformance requirement~~

See 14.2.4.1.

~~14.2.49.2.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.49 for the 40 ms TTI case.

~~14.2.49.2.3 Method of test~~

~~Initial Conditions~~

The following RLC Info parameter values shall be set by the SS for the Conversational / unknown / UL:64 DL:64 kbps / CS RAB (RB8):

|                           |      |
|---------------------------|------|
| Uplink RLC                |      |
| — TM RLC                  |      |
| — Segmentation indication | TRUE |
| Downlink RLC              |      |
| — TM RLC                  |      |
| — Segmentation indication | TRUE |

~~Uplink TFS:~~

|     | TFI       | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | RB7<br>(RAB subflow #3) | RB8<br>(64 kbps) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x640            | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 4x640            | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | N/A              | N/A   |

~~Uplink TFCS:~~

| <b>TFCI</b> | <b>(RB5, RB6, RB7, RB8, DCCH)</b> |
|-------------|-----------------------------------|
| UL_TFC0     | (TF0, TF0, TF0, TF0, TF0)         |
| UL_TFC1     | (TF1, TF0, TF0, TF0, TF0)         |
| UL_TFC2     | (TF2, TF1, TF1, TF0, TF0)         |
| UL_TFC3     | (TF0, TF0, TF0, TF1, TF0)         |
| UL_TFC4     | (TF1, TF0, TF0, TF1, TF0)         |
| UL_TFC5     | (TF2, TF1, TF1, TF1, TF0)         |
| UL_TFC6     | (TF0, TF0, TF0, TF0, TF1)         |
| UL_TFC7     | (TF1, TF0, TF0, TF0, TF1)         |
| UL_TFC8     | (TF2, TF1, TF1, TF0, TF1)         |
| UL_TFC9     | (TF0, TF0, TF0, TF1, TF1)         |
| UL_TFC10    | (TF1, TF0, TF0, TF1, TF1)         |
| UL_TFC11    | (TF2, TF1, TF1, TF1, TF1)         |

## Downlink-TFS:

|     |           | <b>RB5<br/>(RAB-subflow #1)</b> | <b>RB6<br/>(RAB-subflow #2)</b> | <b>RB7<br/>(RAB-subflow #3)</b> | <b>RB8<br/>(64 kbps)</b> | <b>DCCH</b> |
|-----|-----------|---------------------------------|---------------------------------|---------------------------------|--------------------------|-------------|
| TFS | TF0, bits | 1x0                             | 0x103                           | 0x60                            | 0x640                    | 0x148       |
|     | TF1, bits | 1x39                            | 1x103                           | 1x60                            | 4x640                    | 1x148       |
|     | TF2, bits | 1x81                            | N/A                             | N/A                             | N/A                      | N/A         |

## Downlink-TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, RB7, RB8, DCCH)</b> |
|-------------|-----------------------------------|
| DL_TFC0     | (TF0, TF0, TF0, TF0, TF0)         |
| DL_TFC1     | (TF1, TF0, TF0, TF0, TF0)         |
| DL_TFC2     | (TF2, TF1, TF1, TF0, TF0)         |
| DL_TFC3     | (TF0, TF0, TF0, TF1, TF0)         |
| DL_TFC4     | (TF1, TF0, TF0, TF1, TF0)         |
| DL_TFC5     | (TF2, TF1, TF1, TF1, TF0)         |
| DL_TFC6     | (TF0, TF0, TF0, TF0, TF1)         |
| DL_TFC7     | (TF1, TF0, TF0, TF0, TF1)         |
| DL_TFC8     | (TF2, TF1, TF1, TF0, TF1)         |
| DL_TFC9     | (TF0, TF0, TF0, TF1, TF1)         |
| DL_TFC10    | (TF1, TF0, TF0, TF1, TF1)         |
| DL_TFC11    | (TF2, TF1, TF1, TF1, TF1)         |

## Sub-tests:



| Sub-test                                                                              | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                          | Restricted-UL TFCIs                          | UL RLC SDU size (bits) (note)               | Test data size (bits) (note)                              |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|---------------------------------------------|----------------------------------------------|---------------------------------------------|-----------------------------------------------------------|
| 1                                                                                     | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC6,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC6,<br>UL_TFC7  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2560 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: No data   |
| 2                                                                                     | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC6,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC6,<br>UL_TFC8  | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2560 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: No data            |
| 3                                                                                     | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC6,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC6,<br>UL_TFC9  | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2560 | RB5: No data<br>RB6: No data<br>RB7: No data<br>RB8: 2560 |
| 4                                                                                     | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC6,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC6,<br>UL_TFC10 | RB5: 39<br>RB6: 103<br>RB7: 60<br>RB8: 2560 | RB5: 39<br>RB6: No data<br>RB7: No data<br>RB8: 2560      |
| 5                                                                                     | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC6,<br>UL_TFC0,<br>UL_TFC6 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC6,<br>UL_TFC11 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2560 | RB5: 81<br>RB6: 103<br>RB7: 60<br>RB8: 2560               |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                             |                                              |                                             |                                                           |

See 14.1.1 for test procedure.

#### 14.2.49.2.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

- for sub-test 1: RB5/TF1 (1x39).
- for sub-test 2: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).
- for sub-test 3: RB8/TF1 (4x640)
- for sub-test 4: RB5/TF1 (1x39) and RB8/TF1 (2x640).
- for sub-test 5: RB5/TF2 (1x81); RB6/TF1 (1x103); RB7/TF1 (1x60); and RB8/TF1 (4x640).

3. At step 15 the UE shall return

- for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6, RB7 and RB8.
- for sub-test 2: an RLC SDU on RB5, RB6 and RB7 having the same content as sent by SS; and no data shall be received on RB8.
- for sub-test 3: an RLC SDU on RB8 having the same content as sent by SS; and no data shall be received on RB5, RB6 and RB7.
- for sub-test 4: an RLC SDU on RB5 and RB8 having the same content as sent by SS; and no data shall be received on RB6 and RB7.
- for sub-test 5: an RLC SDU on RB5, RB6, RB7 and RB8 having the same content as sent by SS.

## ~~14.2.50 Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Conversational / unknown / UL:64 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

### ~~14.2.50.1 Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Conversational / unknown / UL:64 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI~~

#### ~~14.2.50.1.1 Conformance requirement~~

See 14.2.4.1.

#### ~~14.2.50.1.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.50 for the 20 ms TTI case.

#### ~~14.2.50.1.3 Method of test~~

#### Initial Conditions

The following RLC Info parameter values shall be set by the SS for the Conversational / unknown / UL:64 DL:64 kbps / CS RAB (RB5 and RB6):

|                                                         | <b>RB5<br/>(64 kbps)</b> | <b>RB6<br/>(64 kbps)</b> |
|---------------------------------------------------------|--------------------------|--------------------------|
| Uplink RLC<br>—— TM RLC<br>—— Segmentation indication   | TRUE                     | TRUE                     |
| Downlink RLC<br>—— TM RLC<br>—— Segmentation indication | TRUE                     | TRUE                     |

#### Uplink TFS:

|     | <b>TFI</b> | <b>RB5<br/>(64 kbps)</b> | <b>RB6<br/>(64 kbps)</b> | <b>DCCH</b> |
|-----|------------|--------------------------|--------------------------|-------------|
| TFS | TF0, bits  | 0x640                    | 0x640                    | 0x148       |
|     | TF1, bits  | 2x640                    | 2x640                    | 1x148       |
|     | TF2, bits  | N/A                      | N/A                      | N/A         |

#### Uplink TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| UL_TFC0     | (TF0, TF0, TF0)         |
| UL_TFC1     | (TF1, TF0, TF0)         |
| UL_TFC2     | (TF0, TF1, TF0)         |
| UL_TFC3     | (TF1, TF1, TF0)         |
| UL_TFC4     | (TF0, TF0, TF1)         |
| UL_TFC5     | (TF1, TF0, TF1)         |
| UL_TFC6     | (TF0, TF1, TF1)         |
| UL_TFC7     | (TF1, TF1, TF1)         |

Downlink TFS:

|     | TFI       | RB5<br>(64 kbps) | RB6<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|------------------|-------|
| TFS | TF0, bits | 0x640            | 0x640            | 0x148 |
|     | TF1, bits | 2x640            | 2x640            | 1x148 |
|     | TF2, bits | N/A              | N/A              | N/A   |

Downlink TFCs:

| TFCI    | (RB5, RB6, DCCH) |
|---------|------------------|
| DL_TFC0 | (TF0, TF0, TF0)  |
| DL_TFC1 | (TF1, TF0, TF0)  |
| DL_TFC2 | (TF0, TF1, TF0)  |
| DL_TFC3 | (TF1, TF1, TF0)  |
| DL_TFC4 | (TF0, TF0, TF1)  |
| DL_TFC5 | (TF1, TF0, TF1)  |
| DL_TFC6 | (TF0, TF1, TF1)  |
| DL_TFC7 | (TF1, TF1, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                          | Restricted UL TFCIs                         | UL RLC SDU-size (bits) (note) | Test data size (bits) (note) |
|----------|--------------------------|------------------------|---------------------------------------------|---------------------------------------------|-------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC4,<br>UL_TFC0,<br>UL_TFC4 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC4,<br>UL_TFC5 | RB5: 1280<br>RB6: 1280        | RB5: 1280<br>RB6: No data    |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC4,<br>UL_TFC0,<br>UL_TFC4 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC4,<br>UL_TFC6 | RB5: 1280<br>RB6: 1280        | RB5: No data<br>RB6: 1280    |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC4,<br>UL_TFC0,<br>UL_TFC4 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC4,<br>UL_TFC7 | RB5: 1280<br>RB6: 1280        | RB5: 1280<br>RB6: 1280       |

NOTE: — See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 14.2.50.1.4 — Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

— for sub-test 1: RB5/TF1 (2x640).

— for sub-test 2: RB6/TF1 (2x640).

— for sub-test 3: RB5/TF1 (2x640); RB6/TF1 (2x640)

3. At step 15 the UE shall return

— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6.

— for sub-test 2: an RLC SDU on RB6 having the same content as sent by SS; and no data shall be received on RB5.

— for sub-test 3: an RLC SDU on RB5 and RB6 having the same content as sent by SS.

### ~~14.2.50.2 Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Conversational / unknown / UL:64 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 40 ms TTI~~

#### ~~14.2.50.2.1 Conformance requirement~~

See 14.2.4.1.

#### ~~14.2.50.2.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.50 for the 40 ms TTI case.

#### ~~14.2.50.2.3 Method of test~~

#### Initial Conditions

The following RLC Info parameter values shall be set by the SS for the Conversational / unknown / UL:64 DL:64 kbps / CS RAB (RB5 and RB6):

|                                                       | <b>RB5<br/>(64 kbps)</b> | <b>RB6<br/>(64 kbps)</b> |
|-------------------------------------------------------|--------------------------|--------------------------|
| Uplink RLC<br>— TM RLC<br>— Segmentation indication   | TRUE                     | TRUE                     |
| Downlink RLC<br>— TM RLC<br>— Segmentation indication | TRUE                     | TRUE                     |

#### Uplink TFS:

|     | <b>TFI</b> | <b>RB5<br/>(64 kbps)</b> | <b>RB6<br/>(64 kbps)</b> | <b>DCCH</b> |
|-----|------------|--------------------------|--------------------------|-------------|
| TFS | TF0, bits  | 0x640                    | 0x640                    | 0x148       |
|     | TF1, bits  | 4x640                    | 4x640                    | 1x148       |
|     | TF2, bits  | N/A                      | N/A                      | N/A         |

#### Uplink TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| UL_TFC0     | (TF0, TF0, TF0)         |
| UL_TFC1     | (TF1, TF0, TF0)         |
| UL_TFC2     | (TF0, TF1, TF0)         |
| UL_TFC3     | (TF1, TF1, TF0)         |
| UL_TFC4     | (TF0, TF0, TF1)         |
| UL_TFC5     | (TF1, TF0, TF1)         |
| UL_TFC6     | (TF0, TF1, TF1)         |
| UL_TFC7     | (TF1, TF1, TF1)         |

#### Downlink TFS:

|     | <b>TFI</b> | <b>RB5<br/>(64 kbps)</b> | <b>RB6<br/>(64 kbps)</b> | <b>DCCH</b> |
|-----|------------|--------------------------|--------------------------|-------------|
| TFS | TF0, bits  | 0x640                    | 0x640                    | 0x148       |
|     | TF1, bits  | 4x640                    | 4x640                    | 1x148       |
|     | TF2, bits  | N/A                      | N/A                      | N/A         |

Downlink TFCS:

| TFCI    | (RB5, RB6, DCCH) |
|---------|------------------|
| DL_TFC0 | (TF0, TF0, TF0)  |
| DL_TFC1 | (TF1, TF0, TF0)  |
| DL_TFC2 | (TF0, TF1, TF0)  |
| DL_TFC3 | (TF1, TF1, TF0)  |
| DL_TFC4 | (TF0, TF0, TF1)  |
| DL_TFC5 | (TF1, TF0, TF1)  |
| DL_TFC6 | (TF0, TF1, TF1)  |
| DL_TFC7 | (TF1, TF1, TF1)  |

Sub-tests:

| Sub-test                                                                              | Downlink TFCS Under Test | Uplink TFCS Under test | Implicitely tested                          | Restricted UL TFCIs                         | UL RLC SDU size (bits) (note) | Test data size (bits) (note) |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|---------------------------------------------|---------------------------------------------|-------------------------------|------------------------------|
| 1                                                                                     | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC4,<br>UL_TFC0,<br>UL_TFC4 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC4,<br>UL_TFC5 | RB5: 2560<br>RB6: 2560        | RB5: 2560<br>RB6: No data    |
| 2                                                                                     | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC4,<br>UL_TFC0,<br>UL_TFC4 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC4,<br>UL_TFC6 | RB5: 2560<br>RB6: 2560        | RB5: No data<br>RB6: 2560    |
| 3                                                                                     | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC4,<br>UL_TFC0,<br>UL_TFC4 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC4,<br>UL_TFC7 | RB5: 2560<br>RB6: 2560        | RB5: 2560<br>RB6: 2560       |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                             |                                             |                               |                              |

See 14.1.1 for test procedure.

#### 14.2.50.2.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

— for sub-test 1: RB5/TF1 (4x640).

— for sub-test 2: RB6/TF1 (4x640).

— for sub-test 3: RB5/TF1 (4x640); RB6/TF1 (4x640)

3. At step 15 the UE shall return

— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6.

— for sub-test 2: an RLC SDU on RB6 having the same content as sent by SS; and no data shall be received on RB5.

— for sub-test 3: an RLC SDU on RB5 and RB6 having the same content as sent by SS.

~~14.2.51 Conversational / unknown / UL:64 DL:64 kbps / CS RAB +  
Interactive or background / UL:64 DL:64 kbps / PS RAB + UL:3.4  
DL:3.4 kbps SRBs for DCCH~~

~~14.2.51.1 Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 20 ms TTI +  
Interactive or background / UL:64 DL:64 kbps / PS RAB~~

~~14.2.51.1.1 Conformance requirement~~

~~See 14.2.4.1.~~

~~14.2.51.1.2 Test purpose~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.51 for the 20 ms TTI case.~~

~~14.2.51.1.3 Method of test~~

~~Initial Conditions~~

~~The following RLC Info parameter values shall be set by the SS for the Conversational / unknown / UL:64 DL:64 kbps / CS RAB (RB5):~~

|                           |  | <b>RB5<br/>(Conv.<br/>64 kbps)</b> |
|---------------------------|--|------------------------------------|
| Uplink RLC                |  |                                    |
| — TM RLC                  |  |                                    |
| — Segmentation indication |  | TRUE                               |
| Downlink RLC              |  |                                    |
| — TM RLC                  |  |                                    |
| — Segmentation indication |  | TRUE                               |

~~Uplink TFS:~~

|     | <b>TFI</b> | <b>RB5<br/>(Conv.<br/>64 kbps)</b> | <b>RB6<br/>(I/B<br/>64 kbps)</b> | <b>DCCH</b> |
|-----|------------|------------------------------------|----------------------------------|-------------|
| TFS | TF0, bits  | 0x640                              | 0x336                            | 0x148       |
|     | TF1, bits  | 2x640                              | 1x336                            | 1x148       |
|     | TF2, bits  | N/A                                | 2x336                            | N/A         |
|     | TF3, bits  | N/A                                | 3x336                            | N/A         |
|     | TF4, bits  | N/A                                | 4x336                            | N/A         |

~~Uplink TFCS:~~

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| UL_TFC0     | (TF0, TF0, TF0)         |
| UL_TFC1     | (TF0, TF1, TF0)         |
| UL_TFC2     | (TF0, TF2, TF0)         |
| UL_TFC3     | (TF0, TF3, TF0)         |
| UL_TFC4     | (TF0, TF4, TF0)         |
| UL_TFC5     | (TF1, TF0, TF0)         |
| UL_TFC6     | (TF1, TF1, TF0)         |
| UL_TFC7     | (TF1, TF2, TF0)         |
| UL_TFC8     | (TF1, TF3, TF0)         |
| UL_TFC9     | (TF1, TF4, TF0)         |
| UL_TFC10    | (TF0, TF0, TF1)         |
| UL_TFC11    | (TF0, TF1, TF1)         |
| UL_TFC12    | (TF0, TF2, TF1)         |
| UL_TFC13    | (TF0, TF3, TF1)         |
| UL_TFC14    | (TF0, TF4, TF1)         |
| UL_TFC15    | (TF1, TF0, TF1)         |
| UL_TFC16    | (TF1, TF1, TF1)         |
| UL_TFC17    | (TF1, TF2, TF1)         |
| UL_TFC18    | (TF1, TF3, TF1)         |
| UL_TFC19    | (TF1, TF4, TF1)         |

Downlink-TFS:

|     | <b>TFI</b> | <b>RB5<br/>(Conv.<br/>64 kbps)</b> | <b>RB6<br/>(I/B<br/>64 kbps)</b> | <b>DCCH</b> |
|-----|------------|------------------------------------|----------------------------------|-------------|
| TFS | TF0, bits  | 0x640                              | 0x336                            | 0x148       |
|     | TF1, bits  | 2x640                              | 1x336                            | 1x148       |
|     | TF2, bits  | N/A                                | 2x336                            | N/A         |
|     | TF3, bits  | N/A                                | 3x336                            | N/A         |
|     | TF4, bits  | N/A                                | 4x336                            | N/A         |

Downlink-TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| DL_TFC0     | (TF0, TF0, TF0)         |
| DL_TFC1     | (TF0, TF1, TF0)         |
| DL_TFC2     | (TF0, TF2, TF0)         |
| DL_TFC3     | (TF0, TF3, TF0)         |
| DL_TFC4     | (TF0, TF4, TF0)         |
| DL_TFC5     | (TF1, TF0, TF0)         |
| DL_TFC6     | (TF1, TF1, TF0)         |
| DL_TFC7     | (TF1, TF2, TF0)         |
| DL_TFC8     | (TF1, TF3, TF0)         |
| DL_TFC9     | (TF1, TF4, TF0)         |
| DL_TFC10    | (TF0, TF0, TF1)         |
| DL_TFC11    | (TF0, TF1, TF1)         |
| DL_TFC12    | (TF0, TF2, TF1)         |
| DL_TFC13    | (TF0, TF3, TF1)         |
| DL_TFC14    | (TF0, TF4, TF1)         |
| DL_TFC15    | (TF1, TF0, TF1)         |
| DL_TFC16    | (TF1, TF1, TF1)         |
| DL_TFC17    | (TF1, TF2, TF1)         |
| DL_TFC18    | (TF1, TF3, TF1)         |
| DL_TFC19    | (TF1, TF4, TF1)         |

Sub-tests:

| Sub-test                                                                              | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                            | Restricted UL TFCs                            | UL RLC SDU-size (bits) (note) | Test data-size (bits) (note) |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|-----------------------------------------------|-----------------------------------------------|-------------------------------|------------------------------|
| 1                                                                                     | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC10,<br>UL_TFC11 | RB5: 1280<br>RB6: 312         | RB5: No data<br>RB6: 312     |
| 2                                                                                     | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC10,<br>UL_TFC12 | RB5: 1280<br>RB6: 632         | RB5: No data<br>RB6: 632     |
| 3                                                                                     | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC10,<br>UL_TFC13 | RB5: 1280<br>RB6: 952         | RB5: No data<br>RB6: 952     |
| 4                                                                                     | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC10,<br>UL_TFC14 | RB5: 1280<br>RB6: 1272        | RB5: No data<br>RB6: 1272    |
| 5                                                                                     | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC10,<br>UL_TFC15 | RB5: 1280<br>RB6: 312         | RB5: 1280<br>RB6: No data    |
| 6                                                                                     | DL_TFC6                  | UL_TFC6                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC10,<br>UL_TFC16 | RB5: 1280<br>RB6: 312         | RB5: 1280<br>RB6: 312        |
| 7                                                                                     | DL_TFC7                  | UL_TFC7                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC10,<br>UL_TFC17 | RB5: 1280<br>RB6: 632         | RB5: 1280<br>RB6: 632        |
| 8                                                                                     | DL_TFC8                  | UL_TFC8                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC10,<br>UL_TFC18 | RB5: 1280<br>RB6: 952         | RB5: 1280<br>RB6: 952        |
| 9                                                                                     | DL_TFC9                  | UL_TFC9                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC10,<br>UL_TFC19 | RB5: 1280<br>RB6: 1272        | RB5: 1280<br>RB6: 1272       |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                               |                                               |                               |                              |

See 14.1.1 for test procedure.

#### 14.2.51.1.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1 and 6: RB6/TF1 (1x336).
  - for sub-test 2 and 7: RB6/TF1 (2x336).
  - for sub-test 3 and 8: RB6/TF1 (3x336).
  - for sub-test 4 and 9: RB6/TF1 (4x336).
  - for sub-test 5, 6, 7, 8 and 9: RB5/TF1 (2x640)
3. At step 15 the UE shall return
  - for sub-test 1, 2, 3, 4: an RLC SDU on RB6 having the same content as sent by SS; and no data shall be received on RB5.



- for sub-test 5: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6;
- for sub-test 6, 7, 8 and 9: an RLC SDU on RB5 and RB6 having the same content as sent by SS.

#### ~~14.2.51.2 Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 40 ms TTI + Interactive or background / UL:64 DL:64 kbps / PS RAB~~

##### ~~14.2.51.2.1 Conformance requirement~~

~~See 14.2.4.1.~~

##### ~~14.2.51.2.2 Test purpose~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.51 for the 40 ms TTI case.~~

##### ~~14.2.51.2.3 Method of test~~

#### ~~Initial Conditions~~

~~The following RLC Info parameter values shall be set by the SS for the Conversational / unknown / UL:64 DL:64 kbps / CS RAB (RB5):~~

|                                                       | <b>RB5<br/>(Conv.<br/>64 kbps)</b> |
|-------------------------------------------------------|------------------------------------|
| Uplink RLC<br>— TM RLC<br>— Segmentation indication   | TRUE                               |
| Downlink RLC<br>— TM RLC<br>— Segmentation indication | TRUE                               |

#### ~~Uplink TFS:~~

|            | <b>TFI</b> | <b>RB5<br/>(Conv.<br/>64 kbps)</b> | <b>RB6<br/>(I/B<br/>64 kbps)</b> | <b>DCCH</b> |
|------------|------------|------------------------------------|----------------------------------|-------------|
| <b>TFS</b> | TF0, bits  | 0x640                              | 0x336                            | 0x148       |
|            | TF1, bits  | 4x640                              | 1x336                            | 1x148       |
|            | TF2, bits  | N/A                                | 2x336                            | N/A         |
|            | TF3, bits  | N/A                                | 3x336                            | N/A         |
|            | TF4, bits  | N/A                                | 4x336                            | N/A         |

#### ~~Uplink TFCS:~~

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| UL_TFC0     | (TF0, TF0, TF0)         |
| UL_TFC1     | (TF0, TF1, TF0)         |
| UL_TFC2     | (TF0, TF2, TF0)         |
| UL_TFC3     | (TF0, TF3, TF0)         |
| UL_TFC4     | (TF0, TF4, TF0)         |
| UL_TFC5     | (TF1, TF0, TF0)         |
| UL_TFC6     | (TF1, TF1, TF0)         |
| UL_TFC7     | (TF1, TF2, TF0)         |
| UL_TFC8     | (TF1, TF3, TF0)         |
| UL_TFC9     | (TF1, TF4, TF0)         |
| UL_TFC10    | (TF0, TF0, TF1)         |
| UL_TFC11    | (TF0, TF1, TF1)         |
| UL_TFC12    | (TF0, TF2, TF1)         |
| UL_TFC13    | (TF0, TF3, TF1)         |
| UL_TFC14    | (TF0, TF4, TF1)         |
| UL_TFC15    | (TF1, TF0, TF1)         |
| UL_TFC16    | (TF1, TF1, TF1)         |
| UL_TFC17    | (TF1, TF2, TF1)         |
| UL_TFC18    | (TF1, TF3, TF1)         |
| UL_TFC19    | (TF1, TF4, TF1)         |

Downlink-TFS:

|     | <b>TFI</b> | <b>RB5<br/>(Conv.<br/>64 kbps)</b> | <b>RB6<br/>(I/B<br/>64 kbps)</b> | <b>DCCH</b> |
|-----|------------|------------------------------------|----------------------------------|-------------|
| TFS | TF0, bits  | 0x640                              | 0x336                            | 0x148       |
|     | TF1, bits  | 4x640                              | 1x336                            | 1x148       |
|     | TF2, bits  | N/A                                | 2x336                            | N/A         |
|     | TF3, bits  | N/A                                | 3x336                            | N/A         |
|     | TF4, bits  | N/A                                | 4x336                            | N/A         |

Downlink-TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| DL_TFC0     | (TF0, TF0, TF0)         |
| DL_TFC1     | (TF0, TF1, TF0)         |
| DL_TFC2     | (TF0, TF2, TF0)         |
| DL_TFC3     | (TF0, TF3, TF0)         |
| DL_TFC4     | (TF0, TF4, TF0)         |
| DL_TFC5     | (TF1, TF0, TF0)         |
| DL_TFC6     | (TF1, TF1, TF0)         |
| DL_TFC7     | (TF1, TF2, TF0)         |
| DL_TFC8     | (TF1, TF3, TF0)         |
| DL_TFC9     | (TF1, TF4, TF0)         |
| DL_TFC10    | (TF0, TF0, TF1)         |
| DL_TFC11    | (TF0, TF1, TF1)         |
| DL_TFC12    | (TF0, TF2, TF1)         |
| DL_TFC13    | (TF0, TF3, TF1)         |
| DL_TFC14    | (TF0, TF4, TF1)         |
| DL_TFC15    | (TF1, TF0, TF1)         |
| DL_TFC16    | (TF1, TF1, TF1)         |
| DL_TFC17    | (TF1, TF2, TF1)         |
| DL_TFC18    | (TF1, TF3, TF1)         |
| DL_TFC19    | (TF1, TF4, TF1)         |

Sub-tests:

| Sub-test                                                                                | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                            | Restricted-UL TFCIs                           | UL-RLC-SDU size (bits) (note) | Test data size (bits) (note) |
|-----------------------------------------------------------------------------------------|--------------------------|------------------------|-----------------------------------------------|-----------------------------------------------|-------------------------------|------------------------------|
| 1                                                                                       | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC10,<br>UL_TFC11 | RB5: 2560<br>RB6: 312         | RB5: No data<br>RB6: 312     |
| 2                                                                                       | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC10,<br>UL_TFC12 | RB5: 2560<br>RB6: 632         | RB5: No data<br>RB6: 632     |
| 3                                                                                       | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC10,<br>UL_TFC13 | RB5: 2560<br>RB6: 952         | RB5: No data<br>RB6: 952     |
| 4                                                                                       | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC10,<br>UL_TFC14 | RB5: 2560<br>RB6: 1344        | RB5: No data<br>RB6: 1344    |
| 5                                                                                       | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC10,<br>UL_TFC15 | RB5: 2560<br>RB6: 312         | RB5: 2560<br>RB6: No data    |
| 6                                                                                       | DL_TFC6                  | UL_TFC6                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC10,<br>UL_TFC16 | RB5: 2560<br>RB6: 312         | RB5: 2560<br>RB6: 312        |
| 7                                                                                       | DL_TFC7                  | UL_TFC7                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC10,<br>UL_TFC17 | RB5: 2560<br>RB6: 632         | RB5: 2560<br>RB6: 632        |
| 8                                                                                       | DL_TFC8                  | UL_TFC8                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC10,<br>UL_TFC18 | RB5: 2560<br>RB6: 952         | RB5: 2560<br>RB6: 952        |
| 9                                                                                       | DL_TFC9                  | UL_TFC9                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC10,<br>UL_TFC19 | RB5: 2560<br>RB6: 1272        | RB5: 2560<br>RB6: 1272       |
| NOTE: — See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                               |                                               |                               |                              |

See 14.1.1 for test procedure.

#### 14.2.51.2.4 — Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

— for sub-test 1 and 6: RB6/TF1 (1x336).

— for sub-test 2 and 7: RB6/TF1 (2x336).

— for sub-test 3 and 8: RB6/TF1 (3x336).

— for sub-test 4 and 9: RB6/TF1 (4x336).

— for sub-test 5, 6, 7, 8 and 9: RB5/TF1 (4x640)

3. At step 15 the UE shall return

- for sub-test 1, 2, 3, 4: an RLC SDU on RB6 having the same content as sent by SS; and no data shall be received on RB5;
- for sub-test 5: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6;
- for sub-test 6, 7, 8 and 9: an RLC SDU on RB5 and RB6 having the same content as sent by SS.

#### ~~14.2.51a Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Interactive or Background / UL:8 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.51a.

#### ~~14.2.51b Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Interactive or Background / UL:16 DL:64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.51b.

#### ~~14.2.52 Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Interactive or background / UL:64 DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

##### ~~14.2.52.1 Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 20 ms TTI + Interactive or background / UL:64 DL:128 kbps / PS RAB~~

###### ~~14.2.52.1.1 Conformance requirement~~

See 14.2.4.1.

###### ~~14.2.52.1.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.52 for the 20 ms TTI case.

###### ~~14.2.52.1.3 Method of test~~

#### Initial Conditions

The following RLC Info parameter values shall be set by the SS for the Conversational / unknown / UL:64 DL:64 kbps / CS RAB (RB5):

|                                                       | <b>RB5<br/>(Conv.<br/>64 kbps)</b> |
|-------------------------------------------------------|------------------------------------|
| Uplink RLC<br>— TM RLC<br>— Segmentation indication   | TRUE                               |
| Downlink RLC<br>— TM RLC<br>— Segmentation indication | TRUE                               |

## Uplink TFS:

|     | TFI       | RB5<br>(Conv.<br>64 kbps) | RB6<br>(I/B<br>64 kbps) | DCCH  |
|-----|-----------|---------------------------|-------------------------|-------|
| TFS | TF0, bits | 0x640                     | 0x336                   | 0x148 |
|     | TF1, bits | 2x640                     | 1x336                   | 1x148 |
|     | TF2, bits | N/A                       | 2x336                   | N/A   |
|     | TF3, bits | N/A                       | 3x336                   | N/A   |
|     | TF4, bits | N/A                       | 4x336                   | N/A   |

## Uplink TFCS:

| TFCI     | (RB5, RB6, DCCH) |
|----------|------------------|
| UL_TFC0  | (TF0, TF0, TF0)  |
| UL_TFC1  | (TF0, TF1, TF0)  |
| UL_TFC2  | (TF0, TF2, TF0)  |
| UL_TFC3  | (TF0, TF3, TF0)  |
| UL_TFC4  | (TF0, TF4, TF0)  |
| UL_TFC5  | (TF1, TF0, TF0)  |
| UL_TFC6  | (TF1, TF1, TF0)  |
| UL_TFC7  | (TF1, TF2, TF0)  |
| UL_TFC8  | (TF1, TF3, TF0)  |
| UL_TFC9  | (TF1, TF4, TF0)  |
| UL_TFC10 | (TF0, TF0, TF1)  |
| UL_TFC11 | (TF0, TF1, TF1)  |
| UL_TFC12 | (TF0, TF2, TF1)  |
| UL_TFC13 | (TF0, TF3, TF1)  |
| UL_TFC14 | (TF0, TF4, TF1)  |
| UL_TFC15 | (TF1, TF0, TF1)  |
| UL_TFC16 | (TF1, TF1, TF1)  |
| UL_TFC17 | (TF1, TF2, TF1)  |
| UL_TFC18 | (TF1, TF3, TF1)  |
| UL_TFC19 | (TF1, TF4, TF1)  |

## Downlink TFS:

|     | TFI       | RB5<br>(Conv.<br>64 kbps) | RB6<br>(I/B<br>128 kbps) | DCCH  |
|-----|-----------|---------------------------|--------------------------|-------|
| TFS | TF0, bits | 0x640                     | 0x336                    | 0x148 |
|     | TF1, bits | 2x640                     | 1x336                    | 1x148 |
|     | TF2, bits | N/A                       | 2x336                    | N/A   |
|     | TF3, bits | N/A                       | 4x336                    | N/A   |
|     | TF4, bits | N/A                       | 8x336                    | N/A   |

## Downlink TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| DL_TFC0     | (TF0, TF0, TF0)         |
| DL_TFC1     | (TF0, TF1, TF0)         |
| DL_TFC2     | (TF0, TF2, TF0)         |
| DL_TFC3     | (TF0, TF3, TF0)         |
| DL_TFC4     | (TF0, TF4, TF0)         |
| DL_TFC5     | (TF1, TF0, TF0)         |
| DL_TFC6     | (TF1, TF1, TF0)         |
| DL_TFC7     | (TF1, TF2, TF0)         |
| DL_TFC8     | (TF1, TF3, TF0)         |
| DL_TFC9     | (TF1, TF4, TF0)         |
| DL_TFC10    | (TF0, TF0, TF1)         |
| DL_TFC11    | (TF0, TF1, TF1)         |
| DL_TFC12    | (TF0, TF2, TF1)         |
| DL_TFC13    | (TF0, TF3, TF1)         |
| DL_TFC14    | (TF0, TF4, TF1)         |
| DL_TFC15    | (TF1, TF0, TF1)         |
| DL_TFC16    | (TF1, TF1, TF1)         |
| DL_TFC17    | (TF1, TF2, TF1)         |
| DL_TFC18    | (TF1, TF3, TF1)         |
| DL_TFC19    | (TF1, TF4, TF1)         |

Sub-tests:

| Sub-test                                                                              | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                            | Restricted-UL TFCIs                           | UL RLC-SDU size (bits) (note) | Test data size (bits) (note) |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|-----------------------------------------------|-----------------------------------------------|-------------------------------|------------------------------|
| 1                                                                                     | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC10,<br>UL_TFC11 | RB5: 1280<br>RB6: 312         | RB5: No data<br>RB6: 312     |
| 2                                                                                     | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC10,<br>UL_TFC12 | RB5: 1280<br>RB6: 632         | RB5: No data<br>RB6: 632     |
| 3                                                                                     | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC10,<br>UL_TFC13 | RB5: 1280<br>RB6: 1272        | RB5: No data<br>RB6: 1272    |
| 4                                                                                     | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC10,<br>UL_TFC14 | RB5: 1280<br>RB6: 2552        | RB5: No data<br>RB6: 2552    |
| 5                                                                                     | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC10,<br>UL_TFC15 | RB5: 1280<br>RB6: 312         | RB5: 1280<br>RB6: No data    |
| 6                                                                                     | DL_TFC6                  | UL_TFC6                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC10,<br>UL_TFC16 | RB5: 1280<br>RB6: 312         | RB5: 1280<br>RB6: 312        |
| 7                                                                                     | DL_TFC7                  | UL_TFC7                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC10,<br>UL_TFC17 | RB5: 1280<br>RB6: 632         | RB5: 1280<br>RB6: 632        |
| 8                                                                                     | DL_TFC8                  | UL_TFC8                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC10,<br>UL_TFC18 | RB5: 1280<br>RB6: 1272        | RB5: 1280<br>RB6: 1272       |
| 9                                                                                     | DL_TFC9                  | UL_TFC9                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC10,<br>UL_TFC19 | RB5: 1280<br>RB6: 2552        | RB5: 1280<br>RB6: 2552       |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                               |                                               |                               |                              |

See 14.1.1 for test procedure.

#### 14.2.52.1.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

— for sub-test 1 and 6: RB6/TF1 (1x336).

— for sub-test 2 and 7: RB6/TF1 (2x336).

— for sub-test 3 and 8: RB6/TF1 (3x336).

— for sub-test 4 and 9: RB6/TF1 (4x336).

— for sub-test 5, 6, 7, 8 and 9: RB5/TF1 (2x640)

3. At step 15 the UE shall return
- for sub-test 1, 2, 3, 4: an RLC SDU on RB6 having the same content as sent by SS; and no data shall be received on RB5.
  - for sub-test 5: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6.
  - for sub-test 6, 7, 8 and 9: an RLC SDU on RB5 and RB6 having the same content as sent by SS.

~~14.2.52.2 Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 40 ms TTI +  
Interactive or background / UL:64 DL:128 kbps / PS RAB~~

~~14.2.52.2.1 Conformance requirement~~

~~See 14.2.4.1.~~

~~14.2.52.2.2 Test purpose~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.51 for the 40 ms TTI case.~~

~~14.2.52.2.3 Method of test~~

~~Initial Conditions~~

~~The following RLC Info-parameter values shall be set by the SS for the Conversational / unknown / UL:64 DL:64 kbps / CS RAB (RB5):~~

|                                                       | <b>RB5<br/>(Conv.<br/>64 kbps)</b> |
|-------------------------------------------------------|------------------------------------|
| Uplink RLC<br>— TM-RLC<br>— Segmentation indication   | TRUE                               |
| Downlink RLC<br>— TM-RLC<br>— Segmentation indication | TRUE                               |

~~Uplink-TFS:~~

|     | <b>TFI</b> | <b>RB5<br/>(Conv.<br/>64 kbps)</b> | <b>RB6<br/>(I/B<br/>64 kbps)</b> | <b>DCCH</b> |
|-----|------------|------------------------------------|----------------------------------|-------------|
| TFS | TF0, bits  | 0x640                              | 0x336                            | 0x148       |
|     | TF1, bits  | 4x640                              | 1x336                            | 1x148       |
|     | TF2, bits  | N/A                                | 2x336                            | N/A         |
|     | TF3, bits  | N/A                                | 3x336                            | N/A         |
|     | TF4, bits  | N/A                                | 4x336                            | N/A         |

~~Uplink-TFCS:~~



| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| UL_TFC0     | (TF0, TF0, TF0)         |
| UL_TFC1     | (TF0, TF1, TF0)         |
| UL_TFC2     | (TF0, TF2, TF0)         |
| UL_TFC3     | (TF0, TF3, TF0)         |
| UL_TFC4     | (TF0, TF4, TF0)         |
| UL_TFC5     | (TF1, TF0, TF0)         |
| UL_TFC6     | (TF1, TF1, TF0)         |
| UL_TFC7     | (TF1, TF2, TF0)         |
| UL_TFC8     | (TF1, TF3, TF0)         |
| UL_TFC9     | (TF1, TF4, TF0)         |
| UL_TFC10    | (TF0, TF0, TF1)         |
| UL_TFC11    | (TF0, TF1, TF1)         |
| UL_TFC12    | (TF0, TF2, TF1)         |
| UL_TFC13    | (TF0, TF3, TF1)         |
| UL_TFC14    | (TF0, TF4, TF1)         |
| UL_TFC15    | (TF1, TF0, TF1)         |
| UL_TFC16    | (TF1, TF1, TF1)         |
| UL_TFC17    | (TF1, TF2, TF1)         |
| UL_TFC18    | (TF1, TF3, TF1)         |
| UL_TFC19    | (TF1, TF4, TF1)         |

Downlink-TFS:

|     | <b>TFI</b> | <b>RB5<br/>(Conv.<br/>64 kbps)</b> | <b>RB6<br/>(I/B<br/>128 kbps)</b> | <b>DCCH</b> |
|-----|------------|------------------------------------|-----------------------------------|-------------|
| TFS | TF0, bits  | 0x640                              | 0x336                             | 0x148       |
|     | TF1, bits  | 4x640                              | 1x336                             | 1x148       |
|     | TF2, bits  | N/A                                | 2x336                             | N/A         |
|     | TF3, bits  | N/A                                | 4x336                             | N/A         |
|     | TF4, bits  | N/A                                | 8x336                             | N/A         |

Downlink-TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| DL_TFC0     | (TF0, TF0, TF0)         |
| DL_TFC1     | (TF0, TF1, TF0)         |
| DL_TFC2     | (TF0, TF2, TF0)         |
| DL_TFC3     | (TF0, TF3, TF0)         |
| DL_TFC4     | (TF0, TF4, TF0)         |
| DL_TFC5     | (TF1, TF0, TF0)         |
| DL_TFC6     | (TF1, TF1, TF0)         |
| DL_TFC7     | (TF1, TF2, TF0)         |
| DL_TFC8     | (TF1, TF3, TF0)         |
| DL_TFC9     | (TF1, TF4, TF0)         |
| DL_TFC10    | (TF0, TF0, TF1)         |
| DL_TFC11    | (TF0, TF1, TF1)         |
| DL_TFC12    | (TF0, TF2, TF1)         |
| DL_TFC13    | (TF0, TF3, TF1)         |
| DL_TFC14    | (TF0, TF4, TF1)         |
| DL_TFC15    | (TF1, TF0, TF1)         |
| DL_TFC16    | (TF1, TF1, TF1)         |
| DL_TFC17    | (TF1, TF2, TF1)         |
| DL_TFC18    | (TF1, TF3, TF1)         |
| DL_TFC19    | (TF1, TF4, TF1)         |

Sub-tests:

| Sub-test                                                                              | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                            | Restricted-UL TFCIs                           | UL RLC SDU size (bits) (note) | Test data size (bits) (note) |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|-----------------------------------------------|-----------------------------------------------|-------------------------------|------------------------------|
| 1                                                                                     | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC10,<br>UL_TFC11 | RB5: 2560<br>RB6: 312         | RB5: No data<br>RB6: 312     |
| 2                                                                                     | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC10,<br>UL_TFC12 | RB5: 2560<br>RB6: 632         | RB5: No data<br>RB6: 632     |
| 3                                                                                     | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC10,<br>UL_TFC13 | RB5: 2560<br>RB6: 1272        | RB5: No data<br>RB6: 1272    |
| 4                                                                                     | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC10,<br>UL_TFC14 | RB5: 2560<br>RB6: 2552        | RB5: No data<br>RB6: 2552    |
| 5                                                                                     | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC10,<br>UL_TFC15 | RB5: 2560<br>RB6: 312         | RB5: 2560<br>RB6: No data    |
| 6                                                                                     | DL_TFC6                  | UL_TFC6                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC10,<br>UL_TFC16 | RB5: 2560<br>RB6: 312         | RB5: 2560<br>RB6: 312        |
| 7                                                                                     | DL_TFC7                  | UL_TFC7                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC10,<br>UL_TFC17 | RB5: 2560<br>RB6: 632         | RB5: 2560<br>RB6: 632        |
| 8                                                                                     | DL_TFC8                  | UL_TFC8                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC10,<br>UL_TFC18 | RB5: 2560<br>RB6: 1272        | RB5: 2560<br>RB6: 1272       |
| 9                                                                                     | DL_TFC9                  | UL_TFC9                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC10,<br>UL_TFC19 | RB5: 2560<br>RB6: 2552        | RB5: 2560<br>RB6: 2552       |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                               |                                               |                               |                              |

See 14.1.1 for test procedure.

#### 14.2.52.2.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1 and 6: RB6/TF1 (1x336).
  - for sub-test 2 and 7: RB6/TF1 (2x336).
  - for sub-test 3 and 8: RB6/TF1 (3x336).
  - for sub-test 4 and 9: RB6/TF1 (4x336).
  - for sub-test 5, 6, 7, 8 and 9: RB5/TF1 (4x640)
3. At step 15 the UE shall return
  - for sub-test 1, 2, 3, 4: an RLC SDU on RB6 having the same content as sent by SS; and no data shall be received on RB5.

- for sub-test 5: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6;
- for sub-test 6, 7, 8 and 9: an RLC SDU on RB5 and RB6 having the same content as sent by SS.

### ~~14.2.53 Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Interactive or background / UL:128 DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

#### ~~14.2.53.1 Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 20 ms TTI + Interactive or background / UL:128 DL:128 kbps / PS RAB~~

##### ~~14.2.53.1.1 Conformance requirement~~

~~See 14.2.4.1.~~

##### ~~14.2.53.1.2 Test purpose~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.53 for the 20 ms TTI case.~~

##### ~~14.2.53.1.3 Method of test~~

#### ~~Initial Conditions~~

~~The following RLC Info-parameter values shall be set by the SS for the Conversational / unknown / UL:64 DL:64 kbps / CS RAB (RB5):~~

|                           | <b>RB5<br/>(Conv.<br/>64 kbps)</b> |
|---------------------------|------------------------------------|
| Uplink RLC                |                                    |
| — TM RLC                  |                                    |
| — Segmentation indication | TRUE                               |
| Downlink RLC              |                                    |
| — TM RLC                  |                                    |
| — Segmentation indication | TRUE                               |

#### ~~Uplink TFS:~~

|     | <b>TFI</b> | <b>RB5<br/>(Conv.<br/>64 kbps)</b> | <b>RB6<br/>(I/B<br/>128 kbps)</b> | <b>DCCH</b> |
|-----|------------|------------------------------------|-----------------------------------|-------------|
| TFS | TF0, bits  | 0x640                              | 0x336                             | 0x148       |
|     | TF1, bits  | 2x640                              | 1x336                             | 1x148       |
|     | TF2, bits  | N/A                                | 2x336                             | N/A         |
|     | TF3, bits  | N/A                                | 4x336                             | N/A         |
|     | TF4, bits  | N/A                                | 8x336                             | N/A         |

#### ~~Uplink TFCS:~~

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| UL_TFC0     | (TF0, TF0, TF0)         |
| UL_TFC1     | (TF0, TF1, TF0)         |
| UL_TFC2     | (TF0, TF2, TF0)         |
| UL_TFC3     | (TF0, TF3, TF0)         |
| UL_TFC4     | (TF0, TF4, TF0)         |
| UL_TFC5     | (TF1, TF0, TF0)         |
| UL_TFC6     | (TF1, TF1, TF0)         |
| UL_TFC7     | (TF1, TF2, TF0)         |
| UL_TFC8     | (TF1, TF3, TF0)         |
| UL_TFC9     | (TF1, TF4, TF0)         |
| UL_TFC10    | (TF0, TF0, TF1)         |
| UL_TFC11    | (TF0, TF1, TF1)         |
| UL_TFC12    | (TF0, TF2, TF1)         |
| UL_TFC13    | (TF0, TF3, TF1)         |
| UL_TFC14    | (TF0, TF4, TF1)         |
| UL_TFC15    | (TF1, TF0, TF1)         |
| UL_TFC16    | (TF1, TF1, TF1)         |
| UL_TFC17    | (TF1, TF2, TF1)         |
| UL_TFC18    | (TF1, TF3, TF1)         |
| UL_TFC19    | (TF1, TF4, TF1)         |

Downlink-TFS:

|     | <b>TFI</b> | <b>RB5<br/>(Conv.<br/>64 kbps)</b> | <b>RB6<br/>(I/B<br/>128 kbps)</b> | <b>DCCH</b> |
|-----|------------|------------------------------------|-----------------------------------|-------------|
| TFS | TF0, bits  | 0x640                              | 0x336                             | 0x148       |
|     | TF1, bits  | 2x640                              | 1x336                             | 1x148       |
|     | TF2, bits  | N/A                                | 2x336                             | N/A         |
|     | TF3, bits  | N/A                                | 4x336                             | N/A         |
|     | TF4, bits  | N/A                                | 8x336                             | N/A         |

Downlink-TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| DL_TFC0     | (TF0, TF0, TF0)         |
| DL_TFC1     | (TF0, TF1, TF0)         |
| DL_TFC2     | (TF0, TF2, TF0)         |
| DL_TFC3     | (TF0, TF3, TF0)         |
| DL_TFC4     | (TF0, TF4, TF0)         |
| DL_TFC5     | (TF1, TF0, TF0)         |
| DL_TFC6     | (TF1, TF1, TF0)         |
| DL_TFC7     | (TF1, TF2, TF0)         |
| DL_TFC8     | (TF1, TF3, TF0)         |
| DL_TFC9     | (TF1, TF4, TF0)         |
| DL_TFC10    | (TF0, TF0, TF1)         |
| DL_TFC11    | (TF0, TF1, TF1)         |
| DL_TFC12    | (TF0, TF2, TF1)         |
| DL_TFC13    | (TF0, TF3, TF1)         |
| DL_TFC14    | (TF0, TF4, TF1)         |
| DL_TFC15    | (TF1, TF0, TF1)         |
| DL_TFC16    | (TF1, TF1, TF1)         |
| DL_TFC17    | (TF1, TF2, TF1)         |
| DL_TFC18    | (TF1, TF3, TF1)         |
| DL_TFC19    | (TF1, TF4, TF1)         |

Sub-tests:

| Sub-test                                                                              | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                            | Restricted UL TFCIs                           | UL RLC SDU-size (bits) (note) | Test data size (bits) (note) |
|---------------------------------------------------------------------------------------|--------------------------|------------------------|-----------------------------------------------|-----------------------------------------------|-------------------------------|------------------------------|
| 1                                                                                     | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC10,<br>UL_TFC11 | RB5: 640<br>RB6: 312          | RB5: No data<br>RB6: 312     |
| 2                                                                                     | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC10,<br>UL_TFC12 | RB5: 1280<br>RB6: 632         | RB5: No data<br>RB6: 632     |
| 3                                                                                     | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC10,<br>UL_TFC13 | RB5: 1280<br>RB6: 1272        | RB5: No data<br>RB6: 1272    |
| 4                                                                                     | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC10,<br>UL_TFC14 | RB5: 1280<br>RB6: 2552        | RB5: No data<br>RB6: 2552    |
| 5                                                                                     | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC10,<br>UL_TFC15 | RB5: 1280<br>RB6: 312         | RB5: 1280<br>RB6: No data    |
| 6                                                                                     | DL_TFC6                  | UL_TFC6                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC10,<br>UL_TFC16 | RB5: 1280<br>RB6: 312         | RB5: 1280<br>RB6: 312        |
| 7                                                                                     | DL_TFC7                  | UL_TFC7                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC10,<br>UL_TFC17 | RB5: 1280<br>RB6: 632         | RB5: 1280<br>RB6: 632        |
| 8                                                                                     | DL_TFC8                  | UL_TFC8                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC10,<br>UL_TFC18 | RB5: 1280<br>RB6: 1272        | RB5: 1280<br>RB6: 1272       |
| 9                                                                                     | DL_TFC9                  | UL_TFC9                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC10,<br>UL_TFC19 | RB5: 1280<br>RB6: 2552        | RB5: 1280<br>RB6: 2552       |
| NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                               |                                               |                               |                              |

See 14.1.1 for test procedure.

#### 14.2.53.1.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1 and 6: RB6/TF1 (1x336).
  - for sub-test 2 and 7: RB6/TF1 (2x336).
  - for sub-test 3 and 8: RB6/TF1 (4x336).
  - for sub-test 4 and 9: RB6/TF1 (8x336).
  - for sub-test 5, 6, 7, 8 and 9: RB5/TF1 (2x640)
3. At step 15 the UE shall return
  - for sub-test 1, 2, 3, 4: an RLC SDU on RB6 having the same content as sent by SS; and no data shall be received on RB5.

- for sub-test 5: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6;
- for sub-test 6, 7, 8 and 9: an RLC SDU on RB5 and RB6 having the same content as sent by SS.

**14.2.53.2** ~~Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 40 ms TTI +  
Interactive or background / UL:128 DL:128 kbps / PS RAB~~

**14.2.53.2.1** ~~Conformance requirement~~

See 14.2.4.1.

**14.2.53.2.2** ~~Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.53 for the 40 ms TTI case.

**14.2.53.2.3** ~~Method of test~~

**Initial Conditions**

The following RLC Info parameter values shall be set by the SS for the Conversational / unknown / UL:64 DL:64 kbps / CS RAB (RB5):

|                                                       | <b>RB5<br/>(Conv.<br/>64 kbps)</b> |
|-------------------------------------------------------|------------------------------------|
| Uplink RLC<br>— TM RLC<br>— Segmentation indication   | TRUE                               |
| Downlink RLC<br>— TM RLC<br>— Segmentation indication | TRUE                               |

**Uplink TFS:**

|            | <b>TFI</b> | <b>RB5<br/>(Conv.<br/>64 kbps)</b> | <b>RB6<br/>(I/B<br/>128 kbps)</b> | <b>DCCH</b> |
|------------|------------|------------------------------------|-----------------------------------|-------------|
| <b>TFS</b> | TF0, bits  | 0x640                              | 0x336                             | 0x148       |
|            | TF1, bits  | 4x640                              | 1x336                             | 1x148       |
|            | TF2, bits  | N/A                                | 2x336                             | N/A         |
|            | TF3, bits  | N/A                                | 4x336                             | N/A         |
|            | TF4, bits  | N/A                                | 8x336                             | N/A         |

**Uplink TFCS:**

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| UL_TFC0     | (TF0, TF0, TF0)         |
| UL_TFC1     | (TF0, TF1, TF0)         |
| UL_TFC2     | (TF0, TF2, TF0)         |
| UL_TFC3     | (TF0, TF3, TF0)         |
| UL_TFC4     | (TF0, TF4, TF0)         |
| UL_TFC5     | (TF1, TF0, TF0)         |
| UL_TFC6     | (TF1, TF1, TF0)         |
| UL_TFC7     | (TF1, TF2, TF0)         |
| UL_TFC8     | (TF1, TF3, TF0)         |
| UL_TFC9     | (TF1, TF4, TF0)         |
| UL_TFC10    | (TF0, TF0, TF1)         |
| UL_TFC11    | (TF0, TF1, TF1)         |
| UL_TFC12    | (TF0, TF2, TF1)         |
| UL_TFC13    | (TF0, TF3, TF1)         |
| UL_TFC14    | (TF0, TF4, TF1)         |
| UL_TFC15    | (TF1, TF0, TF1)         |
| UL_TFC16    | (TF1, TF1, TF1)         |
| UL_TFC17    | (TF1, TF2, TF1)         |
| UL_TFC18    | (TF1, TF3, TF1)         |
| UL_TFC19    | (TF1, TF4, TF1)         |

Downlink-TFS:

|     | <b>TFI</b> | <b>RB5<br/>(Conv.<br/>64 kbps)</b> | <b>RB6<br/>(I/B<br/>128 kbps)</b> | <b>DCCH</b> |
|-----|------------|------------------------------------|-----------------------------------|-------------|
| TFS | TF0, bits  | 0x640                              | 0x336                             | 0x148       |
|     | TF1, bits  | 4x640                              | 1x336                             | 1x148       |
|     | TF2, bits  | N/A                                | 2x336                             | N/A         |
|     | TF3, bits  | N/A                                | 4x336                             | N/A         |
|     | TF4, bits  | N/A                                | 8x336                             | N/A         |

Downlink-TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| DL_TFC0     | (TF0, TF0, TF0)         |
| DL_TFC1     | (TF0, TF1, TF0)         |
| DL_TFC2     | (TF0, TF2, TF0)         |
| DL_TFC3     | (TF0, TF3, TF0)         |
| DL_TFC4     | (TF0, TF4, TF0)         |
| DL_TFC5     | (TF1, TF0, TF0)         |
| DL_TFC6     | (TF1, TF1, TF0)         |
| DL_TFC7     | (TF1, TF2, TF0)         |
| DL_TFC8     | (TF1, TF3, TF0)         |
| DL_TFC9     | (TF1, TF4, TF0)         |
| DL_TFC10    | (TF0, TF0, TF1)         |
| DL_TFC11    | (TF0, TF1, TF1)         |
| DL_TFC12    | (TF0, TF2, TF1)         |
| DL_TFC13    | (TF0, TF3, TF1)         |
| DL_TFC14    | (TF0, TF4, TF1)         |
| DL_TFC15    | (TF1, TF0, TF1)         |
| DL_TFC16    | (TF1, TF1, TF1)         |
| DL_TFC17    | (TF1, TF2, TF1)         |
| DL_TFC18    | (TF1, TF3, TF1)         |
| DL_TFC19    | (TF1, TF4, TF1)         |

Sub-tests:

| Sub-test                                                                                | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                            | Restricted-UL TFCIs                           | UL RLC SDU size (bits) (note) | Test data size (bits) (note) |
|-----------------------------------------------------------------------------------------|--------------------------|------------------------|-----------------------------------------------|-----------------------------------------------|-------------------------------|------------------------------|
| 1                                                                                       | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC10,<br>UL_TFC11 | RB5: 2560<br>RB6: 312         | RB5: No data<br>RB6: 312     |
| 2                                                                                       | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC10,<br>UL_TFC12 | RB5: 2560<br>RB6: 632         | RB5: No data<br>RB6: 632     |
| 3                                                                                       | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC10,<br>UL_TFC13 | RB5: 2560<br>RB6: 1272        | RB5: No data<br>RB6: 1272    |
| 4                                                                                       | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC10,<br>UL_TFC14 | RB5: 2560<br>RB6: 2552        | RB5: No data<br>RB6: 2552    |
| 5                                                                                       | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC10,<br>UL_TFC15 | RB5: 2560<br>RB6: 312         | RB5: 2560<br>RB6: No data    |
| 6                                                                                       | DL_TFC6                  | UL_TFC6                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC10,<br>UL_TFC16 | RB5: 2560<br>RB6: 312         | RB5: 2560<br>RB6: 312        |
| 7                                                                                       | DL_TFC7                  | UL_TFC7                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC10,<br>UL_TFC17 | RB5: 2560<br>RB6: 632         | RB5: 2560<br>RB6: 632        |
| 8                                                                                       | DL_TFC8                  | UL_TFC8                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC10,<br>UL_TFC18 | RB5: 2560<br>RB6: 1272        | RB5: 2560<br>RB6: 1272       |
| 9                                                                                       | DL_TFC9                  | UL_TFC9                | DL_TFC0,<br>DL_TFC10,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC10,<br>UL_TFC19 | RB5: 2560<br>RB6: 2552        | RB5: 2560<br>RB6: 2552       |
| NOTE: — See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs. |                          |                        |                                               |                                               |                               |                              |

See 14.1.1 for test procedure.

#### 14.2.53.2.4 — Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1 and 6: RB6/TF1 (1x336).
  - for sub-test 2 and 7: RB6/TF1 (2x336).
  - for sub-test 3 and 8: RB6/TF1 (4x336).
  - for sub-test 4 and 9: RB6/TF1 (8x336).
  - for sub-test 5, 6, 7, 8 and 9: RB5/TF1 (4x640)



3. At step 15 the UE shall return

- for sub-test 1, 2, 3, 4: an RLC SDU on RB6 having the same content as sent by SS; and no data shall be received on RB5.
- for sub-test 5: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6.
- for sub-test 6, 7, 8 and 9: an RLC SDU on RB5 and RB6 having the same content as sent by SS.

#### ~~14.2.54 Interactive or background / UL:64 DL:128 kbps / PS RAB + Streaming / unknown / UL:0 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

~~14.2.54.1 Conformance requirement~~

~~See 14.2.4.1.~~

~~14.2.54.2 Test purpose~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.54.~~

~~To be able to test the downlink radio bearer using the UE loopback function for the reference radio bearer UL:0 DL: 64 kbps, the reference radio bearer configuration according to TS 34.108, clause 6.10.2.4.1.15.1 (Streaming/unknown/UL:14.4 kbps) is used in uplink.~~

~~14.2.54.3 Method of test~~

~~Uplink TFS:~~

|     | TFI       | RB5<br>(I/B<br>64 kbps) | RB6<br>(Str.<br>14.4 kbps) | DCCH  |
|-----|-----------|-------------------------|----------------------------|-------|
| TFS | TF0, bits | 0x336                   | 0x576                      | 0x148 |
|     | TF1, bits | 1x336                   | 1x576                      | 1x148 |
|     | TF2, bits | 2x336                   | N/A                        | N/A   |
|     | TF3, bits | 3x336                   | N/A                        | N/A   |
|     | TF4, bits | 4x336                   | N/A                        | N/A   |

## Uplink TFCS:

| TFCI     | (RB5, RB6, DCCH) |
|----------|------------------|
| UL_TFC0  | (TF0, TF0, TF0)  |
| UL_TFC1  | (TF1, TF0, TF0)  |
| UL_TFC2  | (TF2, TF0, TF0)  |
| UL_TFC3  | (TF3, TF0, TF0)  |
| UL_TFC4  | (TF4, TF0, TF0)  |
| UL_TFC5  | (TF0, TF1, TF0)  |
| UL_TFC6  | (TF1, TF1, TF0)  |
| UL_TFC7  | (TF2, TF1, TF0)  |
| UL_TFC8  | (TF3, TF1, TF0)  |
| UL_TFC9  | (TF4, TF1, TF0)  |
| UL_TFC10 | (TF0, TF0, TF1)  |
| UL_TFC11 | (TF1, TF0, TF1)  |
| UL_TFC12 | (TF2, TF0, TF1)  |
| UL_TFC13 | (TF3, TF0, TF1)  |
| UL_TFC14 | (TF4, TF0, TF1)  |
| UL_TFC15 | (TF0, TF1, TF1)  |
| UL_TFC16 | (TF1, TF1, TF1)  |
| UL_TFC17 | (TF2, TF1, TF1)  |
| UL_TFC18 | (TF3, TF1, TF1)  |
| UL_TFC19 | (TF4, TF1, TF1)  |

## Downlink TFS:

|     | TFI       | RB5<br>(I/B<br>128 kbps) | RB6<br>(Str.<br>64 kbps) | DCCH  |
|-----|-----------|--------------------------|--------------------------|-------|
| TFS | TF0, bits | 0x336                    | 0x320                    | 0x148 |
|     | TF1, bits | 1x336                    | 1x320                    | 1x148 |
|     | TF2, bits | 2x336                    | 2x320                    | N/A   |
|     | TF3, bits | 4x336                    | 4x320                    | N/A   |
|     | TF4, bits | 8x336                    | 8x320                    | N/A   |

## Downlink TFCS:

| TFCI     | (RB5, RB6, DCCH) |
|----------|------------------|
| DL_TFC0  | (TF0, TF0, TF0)  |
| DL_TFC1  | (TF1, TF0, TF0)  |
| DL_TFC2  | (TF2, TF0, TF0)  |
| DL_TFC3  | (TF3, TF0, TF0)  |
| DL_TFC4  | (TF4, TF0, TF0)  |
| DL_TFC5  | (TF0, TF1, TF0)  |
| DL_TFC6  | (TF1, TF1, TF0)  |
| DL_TFC7  | (TF2, TF1, TF0)  |
| DL_TFC8  | (TF3, TF1, TF0)  |
| DL_TFC9  | (TF4, TF1, TF0)  |
| DL_TFC10 | (TF0, TF2, TF0)  |
| DL_TFC11 | (TF1, TF2, TF0)  |
| DL_TFC12 | (TF2, TF2, TF0)  |
| DL_TFC13 | (TF3, TF2, TF0)  |
| DL_TFC14 | (TF4, TF2, TF0)  |
| DL_TFC15 | (TF0, TF3, TF0)  |
| DL_TFC16 | (TF1, TF3, TF0)  |
| DL_TFC17 | (TF2, TF3, TF0)  |
| DL_TFC18 | (TF3, TF3, TF0)  |
| DL_TFC19 | (TF4, TF3, TF0)  |
| DL_TFC20 | (TF0, TF4, TF0)  |
| DL_TFC21 | (TF1, TF4, TF0)  |
| DL_TFC22 | (TF2, TF4, TF0)  |
| DL_TFC23 | (TF3, TF4, TF0)  |
| DL_TFC24 | (TF4, TF4, TF0)  |

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| DL_TFC25    | (TF0, TF0, TF1)         |
| DL_TFC26    | (TF1, TF0, TF1)         |
| DL_TFC27    | (TF2, TF0, TF1)         |
| DL_TFC28    | (TF3, TF0, TF1)         |
| DL_TFC29    | (TF4, TF0, TF1)         |
| DL_TFC30    | (TF0, TF1, TF1)         |
| DL_TFC31    | (TF1, TF1, TF1)         |
| DL_TFC32    | (TF2, TF1, TF1)         |
| DL_TFC33    | (TF3, TF1, TF1)         |
| DL_TFC34    | (TF4, TF1, TF1)         |
| DL_TFC35    | (TF0, TF2, TF1)         |
| DL_TFC36    | (TF1, TF2, TF1)         |
| DL_TFC37    | (TF2, TF2, TF1)         |
| DL_TFC38    | (TF3, TF2, TF1)         |
| DL_TFC39    | (TF4, TF2, TF1)         |
| DL_TFC40    | (TF0, TF3, TF1)         |
| DL_TFC41    | (TF1, TF3, TF1)         |
| DL_TFC42    | (TF2, TF3, TF1)         |
| DL_TFC43    | (TF3, TF3, TF1)         |
| DL_TFC44    | (TF4, TF3, TF1)         |
| DL_TFC45    | (TF0, TF4, TF1)         |
| DL_TFC46    | (TF1, TF4, TF1)         |
| DL_TFC47    | (TF2, TF4, TF1)         |
| DL_TFC48    | (TF3, TF4, TF1)         |
| DL_TFC49    | (TF4, TF4, TF1)         |

## Sub-tests:

| <b>Sub-test</b> | <b>Downlink TFCs Under Test</b> | <b>Uplink TFCs Under test</b> | <b>Implicitely tested</b>                     | <b>Restricted UL TFCIs</b>                    | <b>UL RLC SDU-size (bits) (note 1)</b> | <b>Test data-size (bits) (note 1)</b> |
|-----------------|---------------------------------|-------------------------------|-----------------------------------------------|-----------------------------------------------|----------------------------------------|---------------------------------------|
| 1               | DL_TFC1                         | UL_TFC1                       | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC10,<br>UL_TFC11 | RB5: 312<br>RB6: 576                   | RB5: 312<br>RB6: No data              |
| 2               | DL_TFC2                         | UL_TFC2                       | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC10,<br>UL_TFC12 | RB5: 632<br>RB6: 576                   | RB5: 632<br>RB6: No data              |
| 3               | DL_TFC3                         | UL_TFC3                       | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC10,<br>UL_TFC13 | RB5: 1272<br>RB6: 576                  | RB5: 1272<br>RB6: No data             |
| 4               | DL_TFC4                         | UL_TFC4                       | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC10,<br>UL_TFC14 | RB5: 2552<br>RB6: 576                  | RB5: 2552<br>RB6: No data             |
| 5               | DL_TFC5                         | UL_TFC5                       | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC10,<br>UL_TFC15 | RB5: 312<br>RB6: 576                   | RB5: No data<br>RB6: 320<br>(note 2)  |
| 6               | DL_TFC6                         | UL_TFC6                       | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC10,<br>UL_TFC16 | RB5: 312<br>RB6: 576                   | RB5: 312<br>RB6: 320<br>(note 2)      |
| 7               | DL_TFC7                         | UL_TFC7                       | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC10,<br>UL_TFC17 | RB5: 632<br>RB6: 576                   | RB5: 632<br>RB6: 320<br>(note 2)      |
| 8               | DL_TFC8                         | UL_TFC8                       | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC10,<br>UL_TFC18 | RB5: 1272<br>RB6: 576                  | RB5: 1272<br>RB6: 320<br>(note 2)     |

| Sub-test | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                            | Restricted UL TFCs                            | UL RLC SDU-size (bits) (note 1) | Test data size (bits) (note 1)        |
|----------|--------------------------|------------------------|-----------------------------------------------|-----------------------------------------------|---------------------------------|---------------------------------------|
| 9        | DL_TFC9                  | UL_TFC9                | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC10,<br>UL_TFC19 | RB5: 2552<br>RB6: 576           | RB5: 2552<br>RB6: 320<br>(note 2)     |
| 10       | DL_TFC10                 | UL_TFC5                | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC10,<br>UL_TFC15 | RB5: 312<br>RB6: 576            | RB5: No data<br>RB6: 640<br>(note 3)  |
| 11       | DL_TFC11                 | UL_TFC6                | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC10,<br>UL_TFC16 | RB5: 312<br>RB6: 576            | RB5: 312<br>RB6: 640<br>(note 3)      |
| 12       | DL_TFC12                 | UL_TFC7                | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC10,<br>UL_TFC17 | RB5: 632<br>RB6: 576            | RB5: 632<br>RB6: 640<br>(note 3)      |
| 13       | DL_TFC13                 | UL_TFC8                | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC10,<br>UL_TFC18 | RB5: 1272<br>RB6: 576           | RB5: 1272<br>RB6: 640<br>(note 3)     |
| 14       | DL_TFC14                 | UL_TFC9                | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC10,<br>UL_TFC19 | RB5: 2552<br>RB6: 576           | RB5: 2552<br>RB6: 640<br>(note 3)     |
| 15       | DL_TFC15                 | UL_TFC5                | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC10,<br>UL_TFC15 | RB5: 312<br>RB6: 576            | RB5: No data<br>RB6: 1280<br>(note 4) |
| 16       | DL_TFC16                 | UL_TFC6                | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC10,<br>UL_TFC16 | RB5: 312<br>RB6: 576            | RB5: 312<br>RB6: 1280<br>(note 4)     |
| 17       | DL_TFC17                 | UL_TFC7                | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC10,<br>UL_TFC17 | RB5: 632<br>RB6: 576            | RB5: 632<br>RB6: 1280<br>(note 4)     |
| 18       | DL_TFC18                 | UL_TFC8                | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC10,<br>UL_TFC18 | RB5: 1272<br>RB6: 576           | RB5: 1272<br>RB6: 1280<br>(note 4)    |
| 19       | DL_TFC19                 | UL_TFC9                | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC10,<br>UL_TFC19 | RB5: 2552<br>RB6: 576           | RB5: 2552<br>RB6: 1280<br>(note 4)    |
| 20       | DL_TFC20                 | UL_TFC5                | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC10,<br>UL_TFC15 | RB5: 312<br>RB6: 576            | RB5: No data<br>RB6: 2560<br>(note 5) |
| 21       | DL_TFC21                 | UL_TFC6                | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC10,<br>UL_TFC16 | RB5: 312<br>RB6: 576            | RB5: 312<br>RB6: 2560<br>(note 5)     |
| 22       | DL_TFC22                 | UL_TFC7                | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC10,<br>UL_TFC17 | RB5: 632<br>RB6: 576            | RB5: 632<br>RB6: 2560<br>(note 5)     |

| Sub-test                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                            | Restricted UL TFCIs                           | UL RLC SDU-size (bits) (note 1) | Test data size (bits) (note 1)     |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|------------------------|-----------------------------------------------|-----------------------------------------------|---------------------------------|------------------------------------|
| 23                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | DL_TFC23                 | UL_TFC8                | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC10,<br>UL_TFC18 | RB5: 1272<br>RB6: 576           | RB5: 1272<br>RB6: 2560<br>(note 5) |
| 24                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | DL_TFC24                 | UL_TFC9                | DL_TFC0,<br>DL_TFC25,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC10,<br>UL_TFC19 | RB5: 2552<br>RB6: 576           | RB5: 2552<br>RB6: 2560<br>(note 5) |
| <p>NOTE 1: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.</p> <p>NOTE 2: RB6: SS is using a DL RLC SDU with 320 bits as test data (=DL RLC PDU size for DL/TF1). UE will return one RLC PDU. SS creates an UL RLC SDU from the first 320 bits of the received RLC PDU.</p> <p>NOTE 3: RB6: SS is using a DL RLC SDU size of 640 bits as test data (=DL RLC PDU size for DL/TF2). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 4: RB6: SS is using a DL RLC SDU size of 1280 bits as test data (=DL RLC PDU size for DL/TF3). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 5: RB6: SS is using a DL RLC SDU size of 2560 bits as test data (=DL RLC PDU size for DL/TF4). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> |                          |                        |                                               |                                               |                                 |                                    |

See 14.1.1 for test procedure.

#### 14.2.54.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1, 6, 11, 16 and 21: RB5/TF1 (1x336).
  - for sub-test 2, 7, 12, 17 and 22: RB5/TF1 (2x336).
  - for sub-test 3, 8, 13, 18 and 23: RB5/TF1 (3x336).
  - for sub-test 4, 9, 14, 19 and 24: RB5/TF1 (4x336).
3. At step 15 the UE shall return
  - for sub-test 1, 2, 3, 4, 6, 7, 8, 9, 11, 12, 13, 14, 16, 17, 18, 19, 21, 22, 23 and 24: an RLC SDU on RB5 having the same content as sent by the SS.
  - for sub-test 5, 10, 15 and 20: no data shall be received on RB5.
  - for sub-test 1 to 4: no data shall be received on RB6.
  - for sub-test 5 to 9: an RLC SDU on RB6 having the same content as sent by the SS.
  - for sub-test 10 to 24: an RLC SDU on RB5 having the same content as the first 576 bits of the RLC SDU sent by the SS.

## ~~14.2.55 Interactive or background / UL:64 DL:128 kbps / PS RAB + Streaming / unknown / UL:0 DL:128 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

### ~~14.2.55.1 Conformance requirement~~

See 14.2.4.1.

### ~~14.2.55.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.55.

To be able to test the downlink radio bearer using the UE loopback function for the reference radio bearer UL:0 DL: 64 kbps, the reference radio bearer configuration according to TS 34.108, clause 6.10.2.4.1.15.1 (Streaming/unknown/UL:14.4 kbps) is used in uplink.

### ~~14.2.55.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(I/B<br>64 kbps) | RB6<br>(Str.<br>14.4 kbps) | DCCH  |
|-----|-----------|-------------------------|----------------------------|-------|
| TFS | TF0, bits | 0x336                   | 0x576                      | 0x148 |
|     | TF1, bits | 1x336                   | 1x576                      | 1x148 |
|     | TF2, bits | 2x336                   | N/A                        | N/A   |
|     | TF3, bits | 3x336                   | N/A                        | N/A   |
|     | TF4, bits | 4x336                   | N/A                        | N/A   |

Uplink TFCs:

| TFCI     | (RB5, RB6, DCCH) |
|----------|------------------|
| UL_TFC0  | (TF0, TF0, TF0)  |
| UL_TFC1  | (TF1, TF0, TF0)  |
| UL_TFC2  | (TF2, TF0, TF0)  |
| UL_TFC3  | (TF3, TF0, TF0)  |
| UL_TFC4  | (TF4, TF0, TF0)  |
| UL_TFC5  | (TF0, TF1, TF0)  |
| UL_TFC6  | (TF1, TF1, TF0)  |
| UL_TFC7  | (TF2, TF1, TF0)  |
| UL_TFC8  | (TF3, TF1, TF0)  |
| UL_TFC9  | (TF4, TF1, TF0)  |
| UL_TFC10 | (TF0, TF0, TF1)  |
| UL_TFC11 | (TF1, TF0, TF1)  |
| UL_TFC12 | (TF2, TF0, TF1)  |
| UL_TFC13 | (TF3, TF0, TF1)  |
| UL_TFC14 | (TF4, TF0, TF1)  |
| UL_TFC15 | (TF0, TF1, TF1)  |
| UL_TFC16 | (TF1, TF1, TF1)  |
| UL_TFC17 | (TF2, TF1, TF1)  |
| UL_TFC18 | (TF3, TF1, TF1)  |
| UL_TFC19 | (TF4, TF1, TF1)  |

Downlink TFS:

|     | TFI       | RB5<br>(I/B<br>128 kbps) | RB6<br>(Str.<br>128 kbps) | DCCH  |
|-----|-----------|--------------------------|---------------------------|-------|
| TFS | TF0, bits | 0x336                    | 0x320                     | 0x148 |
|     | TF1, bits | 1x336                    | 1x320                     | 1x148 |
|     | TF2, bits | 2x336                    | 2x320                     | N/A   |
|     | TF3, bits | 4x336                    | 4x320                     | N/A   |
|     | TF4, bits | 8x336                    | 8x320                     | N/A   |
|     | TF5, bits | N/A                      | 16x320                    | N/A   |

## Downlink TFCS:

| TFCI     | (RB5, RB6, DCCH) |
|----------|------------------|
| DL_TFC0  | (TF0, TF0, TF0)  |
| DL_TFC1  | (TF1, TF0, TF0)  |
| DL_TFC2  | (TF2, TF0, TF0)  |
| DL_TFC3  | (TF3, TF0, TF0)  |
| DL_TFC4  | (TF4, TF0, TF0)  |
| DL_TFC5  | (TF0, TF1, TF0)  |
| DL_TFC6  | (TF1, TF1, TF0)  |
| DL_TFC7  | (TF2, TF1, TF0)  |
| DL_TFC8  | (TF3, TF1, TF0)  |
| DL_TFC9  | (TF4, TF1, TF0)  |
| DL_TFC10 | (TF0, TF2, TF0)  |
| DL_TFC11 | (TF1, TF2, TF0)  |
| DL_TFC12 | (TF2, TF2, TF0)  |
| DL_TFC13 | (TF3, TF2, TF0)  |
| DL_TFC14 | (TF4, TF2, TF0)  |
| DL_TFC15 | (TF0, TF3, TF0)  |
| DL_TFC16 | (TF1, TF3, TF0)  |
| DL_TFC17 | (TF2, TF3, TF0)  |
| DL_TFC18 | (TF3, TF3, TF0)  |
| DL_TFC19 | (TF4, TF3, TF0)  |
| DL_TFC20 | (TF0, TF4, TF0)  |
| DL_TFC21 | (TF1, TF4, TF0)  |
| DL_TFC22 | (TF2, TF4, TF0)  |
| DL_TFC23 | (TF3, TF4, TF0)  |
| DL_TFC24 | (TF4, TF4, TF0)  |
| DL_TFC25 | (TF0, TF5, TF0)  |
| DL_TFC26 | (TF1, TF5, TF0)  |
| DL_TFC27 | (TF2, TF5, TF0)  |
| DL_TFC28 | (TF3, TF5, TF0)  |
| DL_TFC29 | (TF4, TF5, TF0)  |
| DL_TFC30 | (TF0, TF0, TF1)  |
| DL_TFC31 | (TF1, TF0, TF1)  |
| DL_TFC32 | (TF2, TF0, TF1)  |
| DL_TFC33 | (TF3, TF0, TF1)  |
| DL_TFC34 | (TF4, TF0, TF1)  |
| DL_TFC35 | (TF0, TF1, TF1)  |
| DL_TFC36 | (TF1, TF1, TF1)  |
| DL_TFC37 | (TF2, TF1, TF1)  |
| DL_TFC38 | (TF3, TF1, TF1)  |
| DL_TFC39 | (TF4, TF1, TF1)  |
| DL_TFC40 | (TF0, TF2, TF1)  |
| DL_TFC41 | (TF1, TF2, TF1)  |
| DL_TFC42 | (TF2, TF2, TF1)  |
| DL_TFC43 | (TF3, TF2, TF1)  |
| DL_TFC44 | (TF4, TF2, TF1)  |
| DL_TFC45 | (TF0, TF3, TF1)  |
| DL_TFC46 | (TF1, TF3, TF1)  |
| DL_TFC47 | (TF2, TF3, TF1)  |
| DL_TFC48 | (TF3, TF3, TF1)  |
| DL_TFC49 | (TF4, TF3, TF1)  |
| DL_TFC50 | (TF0, TF4, TF1)  |
| DL_TFC51 | (TF1, TF4, TF1)  |
| DL_TFC52 | (TF2, TF4, TF1)  |
| DL_TFC53 | (TF3, TF4, TF1)  |
| DL_TFC54 | (TF4, TF4, TF1)  |
| DL_TFC55 | (TF0, TF5, TF1)  |
| DL_TFC56 | (TF1, TF5, TF1)  |
| DL_TFC57 | (TF2, TF5, TF1)  |
| DL_TFC58 | (TF3, TF5, TF1)  |
| DL_TFC59 | (TF4, TF5, TF1)  |



## Sub-tests:

| Sub-test | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                            | Restricted-UL TFCIs                           | UL RLC SDU size (bits) (note 1) | Test data size (bits) (note 1)        |
|----------|--------------------------|------------------------|-----------------------------------------------|-----------------------------------------------|---------------------------------|---------------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC10,<br>UL_TFC11 | RB5: 312<br>RB6: 576            | RB5: 312<br>RB6: No data              |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC10,<br>UL_TFC12 | RB5: 632<br>RB6: 576            | RB5: 632<br>RB6: No data              |
| 3        | DL_TFC3                  | UL_TFC3                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC10,<br>UL_TFC13 | RB5: 1272<br>RB6: 576           | RB5: 1272<br>RB6: No data             |
| 4        | DL_TFC4                  | UL_TFC4                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC10,<br>UL_TFC14 | RB5: 2552<br>RB6: 576           | RB5: 2552<br>RB6: No data             |
| 5        | DL_TFC5                  | UL_TFC5                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC10,<br>UL_TFC15 | RB5: 312<br>RB6: 576            | RB5: No data<br>RB6: 320<br>(note 2)  |
| 6        | DL_TFC6                  | UL_TFC6                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC10,<br>UL_TFC16 | RB5: 312<br>RB6: 576            | RB5: 312<br>RB6: 320<br>(note 2)      |
| 7        | DL_TFC7                  | UL_TFC7                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC10,<br>UL_TFC17 | RB5: 632<br>RB6: 576            | RB5: 632<br>RB6: 320<br>(note 2)      |
| 8        | DL_TFC8                  | UL_TFC8                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC10,<br>UL_TFC18 | RB5: 1272<br>RB6: 576           | RB5: 1272<br>RB6: 320<br>(note 2)     |
| 9        | DL_TFC9                  | UL_TFC9                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC10,<br>UL_TFC19 | RB5: 2552<br>RB6: 576           | RB5: 2552<br>RB6: 320<br>(note 2)     |
| 10       | DL_TFC10                 | UL_TFC5                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC10,<br>UL_TFC15 | RB5: 312<br>RB6: 576            | RB5: No data<br>RB6: 640<br>(note 3)  |
| 11       | DL_TFC11                 | UL_TFC6                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC10,<br>UL_TFC16 | RB5: 312<br>RB6: 576            | RB5: 312<br>RB6: 640<br>(note 3)      |
| 12       | DL_TFC12                 | UL_TFC7                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC10,<br>UL_TFC17 | RB5: 632<br>RB6: 576            | RB5: 632<br>RB6: 640<br>(note 3)      |
| 13       | DL_TFC13                 | UL_TFC8                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC10,<br>UL_TFC18 | RB5: 1272<br>RB6: 576           | RB5: 1272<br>RB6: 640<br>(note 3)     |
| 14       | DL_TFC14                 | UL_TFC9                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC10,<br>UL_TFC19 | RB5: 2552<br>RB6: 576           | RB5: 2552<br>RB6: 640<br>(note 3)     |
| 15       | DL_TFC15                 | UL_TFC5                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC10,<br>UL_TFC15 | RB5: 312<br>RB6: 576            | RB5: No data<br>RB6: 1280<br>(note 4) |

| Sub-test | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                            | Restricted-UL TFCIs                           | UL RLC SDU size (bits) (note 1) | Test data size (bits) (note 1)        |
|----------|--------------------------|------------------------|-----------------------------------------------|-----------------------------------------------|---------------------------------|---------------------------------------|
| 16       | DL_TFC16                 | UL_TFC6                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC10,<br>UL_TFC16 | RB5: 312<br>RB6: 576            | RB5: 312<br>RB6: 1280<br>(note 4)     |
| 17       | DL_TFC17                 | UL_TFC7                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC10,<br>UL_TFC17 | RB5: 632<br>RB6: 576            | RB5: 632<br>RB6: 1280<br>(note 4)     |
| 18       | DL_TFC18                 | UL_TFC8                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC10,<br>UL_TFC18 | RB5: 1272<br>RB6: 576           | RB5: 1272<br>RB6: 1280<br>(note 4)    |
| 19       | DL_TFC19                 | UL_TFC9                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC10,<br>UL_TFC19 | RB5: 2552<br>RB6: 576           | RB5: 2552<br>RB6: 1280<br>(note 4)    |
| 20       | DL_TFC20                 | UL_TFC5                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC10,<br>UL_TFC15 | RB5: 312<br>RB6: 576            | RB5: No data<br>RB6: 2560<br>(note 5) |
| 21       | DL_TFC21                 | UL_TFC6                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC10,<br>UL_TFC16 | RB5: 312<br>RB6: 576            | RB5: 312<br>RB6: 2560<br>(note 5)     |
| 22       | DL_TFC22                 | UL_TFC7                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC10,<br>UL_TFC17 | RB5: 632<br>RB6: 576            | RB5: 632<br>RB6: 2560<br>(note 5)     |
| 23       | DL_TFC23                 | UL_TFC8                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC10,<br>UL_TFC18 | RB5: 1272<br>RB6: 576           | RB5: 1272<br>RB6: 2560<br>(note 5)    |
| 24       | DL_TFC24                 | UL_TFC9                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC10,<br>UL_TFC19 | RB5: 2552<br>RB6: 576           | RB5: 2552<br>RB6: 2560<br>(note 5)    |
| 25       | DL_TFC20                 | UL_TFC5                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC5,<br>UL_TFC10,<br>UL_TFC15 | RB5: 312<br>RB6: 576            | RB5: No data<br>RB6: 5120<br>(note 6) |
| 26       | DL_TFC21                 | UL_TFC6                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC6,<br>UL_TFC10,<br>UL_TFC16 | RB5: 312<br>RB6: 576            | RB5: 312<br>RB6: 5120<br>(note 6)     |
| 27       | DL_TFC22                 | UL_TFC7                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC7,<br>UL_TFC10,<br>UL_TFC17 | RB5: 632<br>RB6: 576            | RB5: 632<br>RB6: 5120<br>(note 6)     |

| Sub-test                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Downlink TFCs Under Test | Uplink TFCs Under test | Implicitely tested                            | Restricted-UL TFCIs                           | UL RLC SDU size (bits) (note 1) | Test data size (bits) (note 1)     |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|------------------------|-----------------------------------------------|-----------------------------------------------|---------------------------------|------------------------------------|
| 28                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | DL_TFC23                 | UL_TFC8                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC8,<br>UL_TFC10,<br>UL_TFC18 | RB5: 1272<br>RB6: 576           | RB5: 1272<br>RB6: 5120<br>(note 6) |
| 29                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | DL_TFC24                 | UL_TFC9                | DL_TFC0,<br>DL_TFC30,<br>UL_TFC0,<br>UL_TFC10 | UL_TFC0,<br>UL_TFC9,<br>UL_TFC10,<br>UL_TFC19 | RB5: 2552<br>RB6: 576           | RB5: 2552<br>RB6: 5120<br>(note 6) |
| <p>NOTE 1: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.</p> <p>NOTE 2: RB6: SS is using a DL RLC SDU with 320 bits as test data (=DL RLC PDU size for DL/TF1). UE will return one RLC PDU. SS creates an UL RLC SDU from the first 320 bits of the received RLC PDU.</p> <p>NOTE 3: RB6: SS is using a DL RLC SDU size of 640 bits as test data (=DL RLC PDU size for DL/TF2). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 4: RB6: SS is using a DL RLC SDU size of 1280 bits as test data (=DL RLC PDU size for DL/TF3). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 5: RB6: SS is using a DL RLC SDU size of 2560 bits as test data (=DL RLC PDU size for DL/TF4). UE will return one RLC PDU. SS creates an UL RLC SDU from the received RLC PDU.</p> <p>NOTE 6: RB6: SS is using a DL RLC SDU size of 5120 bits as test data (=DL RLC PDU size for DL/TF5). UE will return one RLC PDU. SS creates an UL RLC SDU. from the received RLC PDU.</p> |                          |                        |                                               |                                               |                                 |                                    |

See 14.1.1 for test procedure.

#### 14.2.55.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

- for sub-test 1, 6, 11, 16, 21 and 26: RB5/TF1 (1x336).
- for sub-test 2, 7, 12, 17, 22 and 27: RB5/TF1 (2x336).
- for sub-test 3, 8, 13, 18, 23 and 28: RB5/TF1 (3x336).
- for sub-test 4, 9, 14, 19, 24 and 29: RB5/TF1 (4x336).

3. At step 15 the UE shall return

- for sub-test 1, 2, 3, 4, 6, 7, 8, 9, 11, 12, 13, 14, 16, 17, 18, 19, 21, 22, 23, 24, 26, 27, 28 and 29: an RLC SDU on RB5 having the same content as sent by the SS.
- for sub-test 5, 10, 15, 20 and 25: no data shall be received on RB5.
- for sub-test 1, 2, 3 and 4: no data shall be received on RB6.
- for sub-test 5 to 9: an RLC SDU on RB6 having the same content as sent by the SS.
- for sub-test 10 to 29: an RLC SDU on RB5 having the same content as the first 576 bits of the RLC SDU sent by the SS.

#### 14.2.56 Interactive or background / UL:8 DL:8 kbps / PS RAB + Interactive or background / UL:8 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.56.

### ~~14.2.57 Interactive or background / UL:64 DL:64 kbps / PS RAB + Interactive or background / UL:64 DL:64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.57.~~

### ~~14.2.58 Streaming / unknown / UL:16 DL:64 kbps / PS RAB + Interactive or background / UL:8 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.1.58.~~

## ~~14.3 Combinations on PDSCH and DPCH~~

### ~~14.3.1 Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH~~

#### ~~14.3.1.1 Interactive or background / UL:64 DL:256 kbps / PS RAB / 10 ms TTI~~

##### ~~14.3.1.1.1 Conformance requirement~~

~~See 14.2.4.1.~~

##### ~~14.3.1.1.2 Test purpose~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.1 for the downlink 10 ms TTI case.~~

##### ~~14.3.1.1.3 Method of test~~

~~Uplink TFS:~~

|     | <b>TFI</b> | <b>RB5<br/>(64 kbps)</b> | <b>DCCH</b> |
|-----|------------|--------------------------|-------------|
| TFS | TF0, bits  | 0x336                    | 0x148       |
|     | TF1, bits  | 1x336                    | 1x148       |
|     | TF2, bits  | 2x336                    | N/A         |
|     | TF3, bits  | 3x336                    | N/A         |
|     | TF4, bits  | 4x336                    | N/A         |

~~Uplink TFCS:~~

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| UL_TFC0     | (TF0, TF0)         |
| UL_TFC1     | (TF1, TF0)         |
| UL_TFC2     | (TF2, TF0)         |
| UL_TFC3     | (TF3, TF0)         |
| UL_TFC4     | (TF4, TF0)         |
| UL_TFC5     | (TF0, TF1)         |
| UL_TFC6     | (TF1, TF1)         |
| UL_TFC7     | (TF2, TF1)         |
| UL_TFC8     | (TF3, TF1)         |
| UL_TFC9     | (TF4, TF1)         |

## DSCH downlink TFS:

|     | <b>TFI</b>     | <b>RB5<br/>(256 kbps)</b> |
|-----|----------------|---------------------------|
| TFS | DSCH_TF0, bits | 0x354                     |
|     | DSCH_TF1, bits | 1x354                     |
|     | DSCH_TF2, bits | 2x354                     |
|     | DSCH_TF3, bits | 4x354                     |
|     | DSCH_TF4, bits | 8x354                     |

## DSCH downlink TFCs:

| <b>TFCI</b>  | <b>RB5</b> |
|--------------|------------|
| DL_DSCH_TFC0 | DSCH_TF0   |
| DL_DSCH_TFC1 | DSCH_TF1   |
| DL_DSCH_TFC2 | DSCH_TF2   |
| DL_DSCH_TFC3 | DSCH_TF3   |
| DL_DSCH_TFC4 | DSCH_TF4   |

## DCH downlink TFS:

|     | <b>TFI</b>    | <b>DCCH</b> |
|-----|---------------|-------------|
| TFS | DCH_TF0, bits | 0x148       |
|     | DCH_TF1, bits | 1x148       |

## DCH downlink TFCs:

| <b>TFCI</b> | <b>DCCH</b> |
|-------------|-------------|
| DL_DCH_TFC0 | DCH_TF0     |
| DL_DCH_TFC1 | DCH_TF1     |

## Sub-tests:

| Sub-test                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Downlink TFCs Under test | Uplink TFCs Under test | Implicitely tested                                                   | Restricted UL TFCs                          | UL RLC SDU size (bits) (note 1) | Test data size (bits) (note 1) |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|------------------------|----------------------------------------------------------------------|---------------------------------------------|---------------------------------|--------------------------------|
| 1                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | DL_DSCH_TFC1             | UL_TFC1                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC5,<br>UL_TFC6 | RB5: 354                        | RB5: 354<br>(note 2)           |
| 2                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | DL_DSCH_TFC2             | UL_TFC2                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC5,<br>UL_TFC7 | RB5: 708                        | RB5: 708<br>(note 3)           |
| 3                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | DL_DSCH_TFC3             | UL_TFC3                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC5,<br>UL_TFC8 | RB5: 1416                       | RB5: 1416<br>(note 4)          |
| 4                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | DL_DSCH_TFC4             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 2832                       | RB5: 2832<br>(note 5)          |
| <p>NOTE 1: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.</p> <p>NOTE 2: SS is using a DL RLC SDU with 354 bits as test data (=DL RLC PDU size for DL/DSCH_TF1). UE will return two RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 and the first 18 bits of RLC PDU#2.</p> <p>NOTE 3: SS is using a DL RLC SDU size of 708 bits as test data (=DL RLC PDU size for DL/DSCH_TF2). UE will return two RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 and the first 36 bits of RLC PDU#2.</p> <p>NOTE 4: SS is using a DL RLC SDU size of 1416 bits as test data (=DL RLC PDU size for DL/DSCH_TF3). UE will return two RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 and the first 408 bits of RLC PDU#2.</p> <p>NOTE 5: SS is using a DL RLC SDU size of 2832 bits as test data (=DL RLC PDU size for DL/DSCH_TF4). UE will return three RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1, RLC PDU#2 and the first 144 bits of RLC PDU#3.</p> |                          |                        |                                                                      |                                             |                                 |                                |

See 14.1.1 for test procedure.

#### 14.3.1.1.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (3x336).
  - for sub-test 4: RB5/TF4 (4x336).
3. At step 15 the UE shall return
  - for sub-test 1 to 4: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

#### 14.3.1.2 Interactive or background / UL:64 DL:256 kbps / PS-RAB / 20 ms TTI

##### 14.3.1.2.1 Conformance requirement

See 14.2.4.1.

#### 14.3.1.2.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.1 for the downlink 20 ms TTI case.

#### 14.3.1.2.3 Method of test

Uplink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x336            | 0x148 |
|     | TF1, bits | 1x336            | 1x148 |
|     | TF2, bits | 2x336            | N/A   |
|     | TF3, bits | 3x336            | N/A   |
|     | TF4, bits | 4x336            | N/A   |

Uplink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |

DSCH downlink TFS:

|     | TFI            | RB5<br>(256 kbps) |
|-----|----------------|-------------------|
| TFS | DSCH_TF0, bits | 0x354             |
|     | DSCH_TF1, bits | 1x354             |
|     | DSCH_TF2, bits | 2x354             |
|     | DSCH_TF3, bits | 4x354             |
|     | DSCH_TF4, bits | 8x354             |
|     | DSCH_TF5, bits | 12x354            |
|     | DSCH_TF6, bits | 16x354            |

DSCH downlink TFCS:

| TFCI         | RB5      |
|--------------|----------|
| DL_DSCH_TFC0 | DSCH_TF0 |
| DL_DSCH_TFC1 | DSCH_TF1 |
| DL_DSCH_TFC2 | DSCH_TF2 |
| DL_DSCH_TFC3 | DSCH_TF3 |
| DL_DSCH_TFC4 | DSCH_TF4 |
| DL_DSCH_TFC5 | DSCH_TF5 |
| DL_DSCH_TFC6 | DSCH_TF6 |

DCH downlink TFS:

|     | TFI           | DCCH  |
|-----|---------------|-------|
| TFS | DCH_TF0, bits | 0x148 |
|     | DCH_TF1, bits | 1x148 |

DCH downlink TFCS:

| TFCS        | DCCH    |
|-------------|---------|
| DL_DCH_TFC0 | DCH_TF0 |
| DL_DCH_TFC1 | DCH_TF1 |

Sub-tests:

| Sub-test                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | Downlink TFCS Under test | Uplink TFCS Under test | Implicitely tested                                                   | Restricted UL TFCSs                         | UL RLC SDU-size (bits) (note 1) | Test data size (bits) (note 1) |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|------------------------|----------------------------------------------------------------------|---------------------------------------------|---------------------------------|--------------------------------|
| 1                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | DL_DSCH_TFC1             | UL_TFC1                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC5,<br>UL_TFC6 | RB5: 354                        | RB5: 354<br>(note 2)           |
| 2                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | DL_DSCH_TFC2             | UL_TFC2                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC5,<br>UL_TFC7 | RB5: 708                        | RB5: 708<br>(note 3)           |
| 3                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | DL_DSCH_TFC3             | UL_TFC3                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC5,<br>UL_TFC8 | RB5: 1416                       | RB5: 1416<br>(note 4)          |
| 4                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | DL_DSCH_TFC4             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 2832                       | RB5: 2832<br>(note 5)          |
| 5                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | DL_DSCH_TFC5             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 4248                       | RB5: 4248<br>(note 6)          |
| 6                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | DL_DSCH_TFC6             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 5664                       | RB5: 5664<br>(note 7)          |
| <p>NOTE 1: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.</p> <p>NOTE 2: SS is using a DL RLC SDU with 354 bits as test data (=DL RLC PDU size for DL/DSCH_TF1). UE will return two RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 and the first 18 bits of RLC PDU#2.</p> <p>NOTE 3: SS is using a DL RLC SDU size of 708 bits as test data (=DL RLC PDU size for DL/DSCH_TF2). UE will return two RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 and the first 36 bits of RLC PDU#2.</p> <p>NOTE 4: SS is using a DL RLC SDU size of 1416 bits as test data (=DL RLC PDU size for DL/DSCH_TF3). UE will return two RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 and the first 408 bits of RLC PDU#2.</p> <p>NOTE 5: SS is using a DL RLC SDU size of 2832 bits as test data (=DL RLC PDU size for DL/DSCH_TF4). UE will return three RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1, RLC PDU#2 and the first 144 bits of RLC PDU#3.</p> <p>NOTE 6: SS is using a DL RLC SDU size of 4248 bits as test data (=DL RLC PDU size for DL/DSCH_TF5). UE will return four RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1, RLC PDU#2, RLC PDU#3 and the first 216 bits of RLC PDU#4.</p> <p>NOTE 7: SS is using a DL RLC SDU size of 5664 bits as test data (=DL RLC PDU size for DL/DSCH_TF6). UE will return five RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1, RLC PDU#2, RLC PDU#3, RLC PDU#4 and the first 288 bits of RLC PDU#5.</p> |                          |                        |                                                                      |                                             |                                 |                                |

See 14.1.1 for test procedure.



~~14.3.1.2.4 Test requirements~~

See 14.1.1 for definition of step 10 and step 15.

- ~~1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.~~
- ~~2. At step 15 the UE transmitted transport format shall be~~
  - ~~— for sub-test 1: RB5/TF1 (1x336).~~
  - ~~— for sub-test 2: RB5/TF2 (2x336).~~
  - ~~— for sub-test 3: RB5/TF3 (3x336).~~
  - ~~— for sub-test 4, 5 and 6: RB5/TF4 (4x336).~~
- ~~3. At step 15 the UE shall return~~
  - ~~— for sub-test 1 to 6: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.~~

~~14.3.2 Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH~~~~14.3.2.1 Interactive or background / UL:64 DL:384 kbps / PS RAB / 10 ms TTI~~~~14.3.2.1.1 Conformance requirement~~

See 14.2.4.1.

~~14.3.2.1.2 Test purpose~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.2 for the downlink 10 ms TTI case.

~~14.3.2.1.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x336            | 0x148 |
|     | TF1, bits | 1x336            | 1x148 |
|     | TF2, bits | 2x336            | N/A   |
|     | TF3, bits | 3x336            | N/A   |
|     | TF4, bits | 4x336            | N/A   |

Uplink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |

DSCH downlink TFS:

|            | <b>TFI</b>     | <b>RB5<br/>(384 kbps)</b> |
|------------|----------------|---------------------------|
| <b>TFS</b> | DSCH_TF0, bits | 0x354                     |
|            | DSCH_TF1, bits | 1x354                     |
|            | DSCH_TF2, bits | 2x354                     |
|            | DSCH_TF3, bits | 4x354                     |
|            | DSCH_TF4, bits | 8x354                     |
|            | DSCH_TF5, bits | 12x354                    |

DSCH downlink TFCs:

| <b>TFCI</b>  | <b>RB5</b> |
|--------------|------------|
| DL_DSCH_TFC0 | DSCH_TF0   |
| DL_DSCH_TFC1 | DSCH_TF1   |
| DL_DSCH_TFC2 | DSCH_TF2   |
| DL_DSCH_TFC3 | DSCH_TF3   |
| DL_DSCH_TFC4 | DSCH_TF4   |
| DL_DSCH_TFC5 | DSCH_TF5   |

DCH downlink TFS:

|            | <b>TFI</b>    | <b>DCCH</b> |
|------------|---------------|-------------|
| <b>TFS</b> | DCH_TF0, bits | 0x148       |
|            | DCH_TF1, bits | 1x148       |

DCH downlink TFCs:

| <b>TFCI</b> | <b>DCCH</b> |
|-------------|-------------|
| DL_DCH_TFC0 | DCH_TF0     |
| DL_DCH_TFC1 | DCH_TF1     |

Sub-tests:

| <b>Sub-test</b> | <b>Downlink TFCs Under test</b> | <b>Uplink TFCs Under test</b> | <b>Implicitely tested</b>                                            | <b>Restricted-UL TFCIs</b>                  | <b>UL RLC SDU size (bits) (note 1)</b> | <b>Test data size (bits) (note 1)</b> |
|-----------------|---------------------------------|-------------------------------|----------------------------------------------------------------------|---------------------------------------------|----------------------------------------|---------------------------------------|
| 1               | DL_DSCH_TFC1                    | UL_TFC1                       | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC5,<br>UL_TFC6 | RB5: 354                               | RB5: 354<br>(note 2)                  |
| 2               | DL_DSCH_TFC2                    | UL_TFC2                       | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC5,<br>UL_TFC7 | RB5: 708                               | RB5: 708<br>(note 3)                  |
| 3               | DL_DSCH_TFC3                    | UL_TFC3                       | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC5,<br>UL_TFC8 | RB5: 1416                              | RB5: 1416<br>(note 4)                 |
| 4               | DL_DSCH_TFC4                    | UL_TFC4                       | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 2832                              | RB5: 2832<br>(note 5)                 |

| Sub-test                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Downlink TFCs Under test | Uplink TFCs Under test | Implicitly tested                                                      | Restricted UL TFCs                          | UL RLC SDU-size (bits) (note 1) | Test data size (bits) (note 1) |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|------------------------|------------------------------------------------------------------------|---------------------------------------------|---------------------------------|--------------------------------|
| 5                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | DL_DSCH_TFC5             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DSCH_TFC0,<br>DL_DSCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 4248                       | RB5: 4248 (note 6)             |
| <p>NOTE 1: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.</p> <p>NOTE 2: SS is using a DL RLC SDU with 354 bits as test data (=DL RLC PDU size for DL/DSCH_TF1). UE will return two RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 and the first 18 bits of RLC PDU#2.</p> <p>NOTE 3: SS is using a DL RLC SDU size of 708 bits as test data (=DL RLC PDU size for DL/DSCH_TF2). UE will return two RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 and the first 36 bits of RLC PDU#2.</p> <p>NOTE 4: SS is using a DL RLC SDU size of 1416 bits as test data (=DL RLC PDU size for DL/DSCH_TF3). UE will return two RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 and the first 408 bits of RLC PDU#2.</p> <p>NOTE 5: SS is using a DL RLC SDU size of 2832 bits as test data (=DL RLC PDU size for DL/DSCH_TF4). UE will return three RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1, RLC PDU#2 and the first 144 bits of RLC PDU#3.</p> <p>NOTE 6: SS is using a DL RLC SDU size of 4248 bits as test data (=DL RLC PDU size for DL/DSCH_TF5). UE will return four RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1, RLC PDU#2, RLC PDU#3 and the first 216 bits of RLC PDU#4.</p> |                          |                        |                                                                        |                                             |                                 |                                |

See 14.1.1 for test procedure.

#### 14.3.2.1.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (3x336).
  - for sub-test 4, 5 and 6: RB5/TF4 (4x336).
3. At step 15 the UE shall return
  - for sub-test 1 to 6: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

#### 14.3.2.2 Interactive or background / UL:64 DL:384 kbps / PS RAB / 20 ms TTI

##### 14.3.2.2.1 Conformance requirement

See 14.2.4.1.

##### 14.3.2.2.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.2 for the downlink 20 ms TTI case.

## 14.3.2.2.3 Method of test

Uplink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x336            | 0x148 |
|     | TF1, bits | 1x336            | 1x148 |
|     | TF2, bits | 2x336            | N/A   |
|     | TF3, bits | 3x336            | N/A   |
|     | TF4, bits | 4x336            | N/A   |

Uplink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |

DSCH downlink TFS:

|     | TFI            | RB5<br>(384 kbps) |
|-----|----------------|-------------------|
| TFS | DSCH_TF0, bits | 0x354             |
|     | DSCH_TF1, bits | 1x354             |
|     | DSCH_TF2, bits | 2x354             |
|     | DSCH_TF3, bits | 4x354             |
|     | DSCH_TF4, bits | 8x354             |
|     | DSCH_TF5, bits | 12x354            |
|     | DSCH_TF6, bits | 16x354            |
|     | DSCH_TF7, bits | 20x354            |
|     | DSCH_TF8, bits | 24x354            |

DSCH downlink TFCS:

| TFCI         | RB5      |
|--------------|----------|
| DL_DSCH_TFC0 | DSCH_TF0 |
| DL_DSCH_TFC1 | DSCH_TF1 |
| DL_DSCH_TFC2 | DSCH_TF2 |
| DL_DSCH_TFC3 | DSCH_TF3 |
| DL_DSCH_TFC4 | DSCH_TF4 |
| DL_DSCH_TFC5 | DSCH_TF5 |
| DL_DSCH_TFC6 | DSCH_TF6 |
| DL_DSCH_TFC7 | DSCH_TF7 |
| DL_DSCH_TFC8 | DSCH_TF8 |

DCH downlink TFS:

|     | TFI           | DCCH  |
|-----|---------------|-------|
| TFS | DCH_TF0, bits | 0x148 |
|     | DCH_TF1, bits | 1x148 |

DCH downlink TFCS:

| TFCS        | DCCH    |
|-------------|---------|
| DL_DCH_TFC0 | DCH_TF0 |
| DL_DCH_TFC1 | DCH_TF1 |

Sub-tests:

| Sub-test | Downlink TFCS Under test | Uplink TFCS Under test | Implicitely tested                                                | Restricted UL-TFCIs                         | UL-RLC SDU-size (bits) (note-1) | Test-data size (bits) (note-1) |
|----------|--------------------------|------------------------|-------------------------------------------------------------------|---------------------------------------------|---------------------------------|--------------------------------|
| 1        | DL_DSCH_TFC1             | UL_TFC1                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0, UL_TFC5 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC5,<br>UL_TFC6 | RB5: 354                        | RB5: 354<br>(note-2)           |
| 2        | DL_DSCH_TFC2             | UL_TFC2                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0, UL_TFC5 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC5,<br>UL_TFC7 | RB5: 708                        | RB5: 708<br>(note-3)           |
| 3        | DL_DSCH_TFC3             | UL_TFC3                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0, UL_TFC5 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC5,<br>UL_TFC8 | RB5: 1416                       | RB5: 1416<br>(note-4)          |
| 4        | DL_DSCH_TFC4             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0, UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 2832                       | RB5: 2832<br>(note-5)          |
| 5        | DL_DSCH_TFC5             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0, UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 4248                       | RB5: 4248<br>(note-6)          |
| 6        | DL_DSCH_TFC6             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0, UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 5664                       | RB5: 5664<br>(note-7)          |
| 7        | DL_DSCH_TFC7             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0, UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 7080                       | RB5: 7080<br>(note-8)          |

| Sub-test                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | Downlink TFCS Under test | Uplink TFCS Under test | Implicitly tested                                                 | Restricted UL TFCSs                         | UL RLC SDU size (bits) (note 1) | Test data size (bits) (note 1) |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|------------------------|-------------------------------------------------------------------|---------------------------------------------|---------------------------------|--------------------------------|
| 8                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | DL_DSCH_TFC8             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0, UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 8496                       | RB5: 8496 (note 9)             |
| <p>NOTE 1: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.</p> <p>NOTE 2: SS is using a DL RLC SDU with 354 bits as test data (=DL RLC PDU size for DL/DSCH_TF1). UE will return two RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 and the first 18 bits of RLC PDU#2.</p> <p>NOTE 3: SS is using a DL RLC SDU size of 708 bits as test data (=DL RLC PDU size for DL/DSCH_TF2). UE will return two RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 and the first 36 bits of RLC PDU#2.</p> <p>NOTE 4: SS is using a DL RLC SDU size of 1416 bits as test data (=DL RLC PDU size for DL/DSCH_TF3). UE will return two RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 and the first 408 bits of RLC PDU#2.</p> <p>NOTE 5: SS is using a DL RLC SDU size of 2832 bits as test data (=DL RLC PDU size for DL/DSCH_TF4). UE will return three RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1, RLC PDU#2 and the first 144 bits of RLC PDU#3.</p> <p>NOTE 6: SS is using a DL RLC SDU size of 4248 bits as test data (=DL RLC PDU size for DL/DSCH_TF5). UE will return four RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1, RLC PDU#2, RLC PDU#3 and the first 216 bits of RLC PDU#4.</p> <p>NOTE 7: SS is using a DL RLC SDU size of 4248 bits as test data (=DL RLC PDU size for DL/DSCH_TF6). UE will return five RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#4 and the first 288 bits of RLC PDU#5.</p> <p>NOTE 8: SS is using a DL RLC SDU size of 4248 bits as test data (=DL RLC PDU size for DL/DSCH_TF7). UE will return six RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#5 and the first 360 bits of RLC PDU#6.</p> <p>NOTE 9: SS is using a DL RLC SDU size of 4248 bits as test data (=DL RLC PDU size for DL/DSCH_TF8). UE will return seven RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#6 and the first 432 bits of RLC PDU#7.</p> |                          |                        |                                                                   |                                             |                                 |                                |

See 14.1.1 for test procedure.

#### 14.3.2.2.4 ————— Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x336).
  - for sub-test 2: RB5/TF2 (2x336).
  - for sub-test 3: RB5/TF3 (3x336).
  - for sub-test 4, 5, 6, 7 and 8: RB5/TF4 (4x336).
3. At step 15 the UE shall return
  - for sub-test 1 to 8: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

### 14.3.3 ————— Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH

#### 14.3.3.1 ————— Interactive or background / UL:64 DL:2048 kbps / PS RAB / 10 ms TTI

##### 14.3.3.1.1 ————— Conformance requirement

See 14.2.4.1.

### 14.3.3.1.2 Test purpose

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.3 for the downlink 10 ms TTI case.

### 14.3.3.1.3 Method of test

Uplink TFS:

|     | TFI       | RB5<br>(64 kbps) | DCCH  |
|-----|-----------|------------------|-------|
| TFS | TF0, bits | 0x336            | 0x148 |
|     | TF1, bits | 1x336            | 1x148 |
|     | TF2, bits | 2x336            | N/A   |
|     | TF3, bits | 3x336            | N/A   |
|     | TF4, bits | 4x336            | N/A   |

Uplink TFCS:

| TFCI    | (RB5, DCCH) |
|---------|-------------|
| UL_TFC0 | (TF0, TF0)  |
| UL_TFC1 | (TF1, TF0)  |
| UL_TFC2 | (TF2, TF0)  |
| UL_TFC3 | (TF3, TF0)  |
| UL_TFC4 | (TF4, TF0)  |
| UL_TFC5 | (TF0, TF1)  |
| UL_TFC6 | (TF1, TF1)  |
| UL_TFC7 | (TF2, TF1)  |
| UL_TFC8 | (TF3, TF1)  |
| UL_TFC9 | (TF4, TF1)  |

DSCH downlink TFS:

|     | TFI             | RB5<br>(384 kbps) |
|-----|-----------------|-------------------|
| TFS | DSCH_TF0, bits  | 0x674             |
|     | DSCH_TF1, bits  | 1x674             |
|     | DSCH_TF2, bits  | 2x674             |
|     | DSCH_TF3, bits  | 4x674             |
|     | DSCH_TF4, bits  | 8x674             |
|     | DSCH_TF5, bits  | 12x674            |
|     | DSCH_TF6, bits  | 16x674            |
|     | DSCH_TF7, bits  | 20x674            |
|     | DSCH_TF8, bits  | 24x674            |
|     | DSCH_TF9, bits  | 28x674            |
|     | DSCH_TF10, bits | 32x674            |

DSCH downlink TFCS:

| TFCI          | RB5       |
|---------------|-----------|
| DL_DSCH_TFC0  | DSCH_TF0  |
| DL_DSCH_TFC1  | DSCH_TF1  |
| DL_DSCH_TFC2  | DSCH_TF2  |
| DL_DSCH_TFC3  | DSCH_TF3  |
| DL_DSCH_TFC4  | DSCH_TF4  |
| DL_DSCH_TFC5  | DSCH_TF5  |
| DL_DSCH_TFC6  | DSCH_TF6  |
| DL_DSCH_TFC7  | DSCH_TF7  |
| DL_DSCH_TFC8  | DSCH_TF8  |
| DL_DSCH_TFC9  | DSCH_TF9  |
| DL_DSCH_TFC10 | DSCH_TF10 |

DCH downlink TFS:

|     | <b>TFI</b>    | <b>DCCH</b> |
|-----|---------------|-------------|
| TFS | DCH_TF0, bits | 0x148       |
|     | DCH_TF1, bits | 1x148       |

DCH downlink TFCS:

| <b>TFCI</b> | <b>DCCH</b> |
|-------------|-------------|
| DL_DCH_TFC0 | DCH_TF0     |
| DL_DCH_TFC1 | DCH_TF1     |

Sub-tests:

| Sub-test | Downlink TFCS Under test | Uplink TFCS Under test | Implicitely tested                                                   | Restricted UL TFCIs                         | UL RLC SDU-size (bits) (note 1) | Test data-size (bits) (note 1) |
|----------|--------------------------|------------------------|----------------------------------------------------------------------|---------------------------------------------|---------------------------------|--------------------------------|
| 1        | DL_DSCH_TFC1             | UL_TFC1                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC5,<br>UL_TFC6 | RB5: 674                        | RB5: 674<br>(note 2)           |
| 2        | DL_DSCH_TFC2             | UL_TFC2                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC5,<br>UL_TFC7 | RB5: 1348                       | RB5: 1348<br>(note 3)          |
| 3        | DL_DSCH_TFC3             | UL_TFC3                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC5,<br>UL_TFC8 | RB5: 2696                       | RB5: 2696<br>(note 4)          |
| 4        | DL_DSCH_TFC4             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 5392                       | RB5: 5392<br>(note 5)          |
| 5        | DL_DSCH_TFC5             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 8088                       | RB5: 8088<br>(note 6)          |
| 6        | DL_DSCH_TFC6             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 10784                      | RB5: 10784<br>(note 7)         |
| 7        | DL_DSCH_TFC7             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 13480                      | RB5: 13480<br>(note 8)         |
| 8        | DL_DSCH_TFC8             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 16176                      | RB5: 16176<br>(note 9)         |



| Sub-test | Downlink TFCs Under test | Uplink TFCs Under test | Implicitely tested                                                   | Restricted UL TFCs                          | UL RLC SDU size (bits) (note 1) | Test data size (bits) (note 1) |
|----------|--------------------------|------------------------|----------------------------------------------------------------------|---------------------------------------------|---------------------------------|--------------------------------|
| 9        | DL_DSCH_TFC9             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 18872                      | RB5: 18872<br>(note 10)        |
| 10       | DL_DSCH_TFC10            | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 21568                      | RB5: 21568<br>(note 11)        |

NOTE 1: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

NOTE 2: SS is using a DL RLC SDU with 674 bits as test data (=DL RLC PDU size for DL/DSCH\_TF1). UE will return three RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1, RLC SDU#2 and the first 2 bits of RLC PDU#3.

NOTE 3: SS is using a DL RLC SDU size of 1348 bits as test data (=DL RLC PDU size for DL/DSCH\_TF2). UE will return three RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1, RLC SDU#2 and the first 4 bits of RLC PDU#3.

NOTE 4: SS is using a DL RLC SDU size of 2696 bits as test data (=DL RLC PDU size for DL/DSCH\_TF3). UE will return three RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1, RLC SDU#2 and the first 680 bits of RLC PDU#3.

NOTE 5: SS is using a DL RLC SDU size of 5392 bits as test data (=DL RLC PDU size for DL/DSCH\_TF4). UE will return five RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#4 and the first 16 bits of RLC PDU#5.

NOTE 6: SS is using a DL RLC SDU size of 8088 bits as test data (=DL RLC PDU size for DL/DSCH\_TF5). UE will return seven RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#6 and the first 24 bits of RLC PDU#7.

NOTE 7: SS is using a DL RLC SDU size of 10784 bits as test data (=DL RLC PDU size for DL/DSCH\_TF6). UE will return nine RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#8 and the first 32 bits of RLC PDU#9.

NOTE 8: SS is using a DL RLC SDU size of 13480 bits as test data (=DL RLC PDU size for DL/DSCH\_TF7). UE will return eleven RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#10 and the first 40 bits of RLC PDU#11.

NOTE 9: SS is using a DL RLC SDU size of 16176 bits as test data (=DL RLC PDU size for DL/DSCH\_TF8). UE will return thirteen RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#12 and the first 48 bits of RLC PDU#13.

NOTE 10: SS is using a DL RLC SDU size of 18872 bits as test data (=DL RLC PDU size for DL/DSCH\_TF9). UE will return fifteen RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#14 and the first 56 bits of RLC PDU#15.

NOTE 11: SS is using a DL RLC SDU size of 21568 bits as test data (=DL RLC PDU size for DL/DSCH\_TF10). UE will return seventeen RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#16 and the first 64 bits of RLC PDU#17.

See 14.1.1 for test procedure.

#### 14.3.3.1.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

— for sub-test 1: RB5/TF1 (1x336).

— for sub-test 2: RB5/TF2 (2x336).

— for sub-test 3: RB5/TF3 (3x336).

— for sub-test 4, 5, 6, 7, 8, 9 and 10: RB5/TF4 (4x336).

3. At step 15 the UE shall return

— for sub-test 1 to 10: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

~~14.3.3.2 Interactive or background / UL:64 DL:2048 kbps / PS RAB / 20 ms TTI~~~~14.3.3.2.1 Conformance requirement~~~~See 14.2.4.1.~~~~14.3.3.2.2 Test purpose~~~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.3 for the downlink 20 ms TTI case.~~~~14.3.3.2.3 Method of test~~~~Uplink TFS:~~

|            | <b>TFI</b> | <b>RB5<br/>(64 kbps)</b> | <b>DCCH</b> |
|------------|------------|--------------------------|-------------|
| <b>TFS</b> | TF0, bits  | 0x336                    | 0x148       |
|            | TF1, bits  | 1x336                    | 1x148       |
|            | TF2, bits  | 2x336                    | N/A         |
|            | TF3, bits  | 3x336                    | N/A         |
|            | TF4, bits  | 4x336                    | N/A         |

~~Uplink TFCS:~~

| <b>TFCI</b> | <b>(RB5, DCCH)</b> |
|-------------|--------------------|
| UL_TFC0     | (TF0, TF0)         |
| UL_TFC1     | (TF1, TF0)         |
| UL_TFC2     | (TF2, TF0)         |
| UL_TFC3     | (TF3, TF0)         |
| UL_TFC4     | (TF4, TF0)         |
| UL_TFC5     | (TF0, TF1)         |
| UL_TFC6     | (TF1, TF1)         |
| UL_TFC7     | (TF2, TF1)         |
| UL_TFC8     | (TF3, TF1)         |
| UL_TFC9     | (TF4, TF1)         |

~~DSCH downlink TFS:~~

|            | <b>TFI</b>      | <b>RB5<br/>(384 kbps)</b> |
|------------|-----------------|---------------------------|
| <b>TFS</b> | DSCH_TF0, bits  | 0x674                     |
|            | DSCH_TF1, bits  | 1x674                     |
|            | DSCH_TF2, bits  | 2x674                     |
|            | DSCH_TF3, bits  | 4x674                     |
|            | DSCH_TF4, bits  | 8x674                     |
|            | DSCH_TF5, bits  | 12x674                    |
|            | DSCH_TF6, bits  | 16x674                    |
|            | DSCH_TF7, bits  | 20x674                    |
|            | DSCH_TF8, bits  | 24x674                    |
|            | DSCH_TF9, bits  | 28x674                    |
|            | DSCH_TF10, bits | 32x674                    |
|            | DSCH_TF11, bits | 36x674                    |
|            | DSCH_TF12, bits | 40x674                    |
|            | DSCH_TF13, bits | 44x674                    |
|            | DSCH_TF14, bits | 48x674                    |
|            | DSCH_TF15, bits | 52x674                    |
|            | DSCH_TF16, bits | 56x674                    |
|            | DSCH_TF17, bits | 60x674                    |
|            | DSCH_TF18, bits | 64x674                    |

## DSCH downlink TFCS:

| <b>TFCI</b>   | <b>RB5</b> |
|---------------|------------|
| DL_DSCH_TFC0  | DSCH_TF0   |
| DL_DSCH_TFC1  | DSCH_TF1   |
| DL_DSCH_TFC2  | DSCH_TF2   |
| DL_DSCH_TFC3  | DSCH_TF3   |
| DL_DSCH_TFC4  | DSCH_TF4   |
| DL_DSCH_TFC5  | DSCH_TF5   |
| DL_DSCH_TFC6  | DSCH_TF6   |
| DL_DSCH_TFC7  | DSCH_TF7   |
| DL_DSCH_TFC8  | DSCH_TF8   |
| DL_DSCH_TFC9  | DSCH_TF9   |
| DL_DSCH_TFC10 | DSCH_TF10  |
| DL_DSCH_TFC11 | DSCH_TF11  |
| DL_DSCH_TFC12 | DSCH_TF12  |
| DL_DSCH_TFC13 | DSCH_TF13  |
| DL_DSCH_TFC14 | DSCH_TF14  |
| DL_DSCH_TFC15 | DSCH_TF15  |
| DL_DSCH_TFC16 | DSCH_TF16  |
| DL_DSCH_TFC17 | DSCH_TF17  |
| DL_DSCH_TFC18 | DSCH_TF18  |

## DCH downlink TFS:

|     | <b>TFI</b>    | <b>DCCH</b> |
|-----|---------------|-------------|
| TFS | DCH_TF0, bits | 0x148       |
|     | DCH_TF1, bits | 1x148       |

## DCH downlink TFCS:

| <b>TFCI</b> | <b>DCCH</b> |
|-------------|-------------|
| DL_DCH_TFC0 | DCH_TF0     |
| DL_DCH_TFC1 | DCH_TF1     |

Sub-tests:

| Sub-test | Downlink TFCs Under test | Uplink TFCs Under test | Implicitely tested                                                   | Restricted UL TFCs                          | UL RLC SDU size (bits) (note 1) | Test data size (bits) (note 1) |
|----------|--------------------------|------------------------|----------------------------------------------------------------------|---------------------------------------------|---------------------------------|--------------------------------|
| 1        | DL_DSCH_TFC1             | UL_TFC1                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC1,<br>UL_TFC5,<br>UL_TFC6 | RB5: 674                        | RB5: 674<br>(note 2)           |
| 2        | DL_DSCH_TFC2             | UL_TFC2                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC2,<br>UL_TFC5,<br>UL_TFC7 | RB5: 1348                       | RB5: 1348<br>(note 3)          |
| 3        | DL_DSCH_TFC3             | UL_TFC3                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC3,<br>UL_TFC5,<br>UL_TFC8 | RB5: 2696                       | RB5: 2696<br>(note 4)          |
| 4        | DL_DSCH_TFC4             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 5392                       | RB5: 5392<br>(note 5)          |
| 5        | DL_DSCH_TFC5             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 8088                       | RB5: 8088<br>(note 6)          |
| 6        | DL_DSCH_TFC6             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 10784                      | RB5: 10784<br>(note 7)         |
| 7        | DL_DSCH_TFC7             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 13480                      | RB5: 13480<br>(note 8)         |
| 8        | DL_DSCH_TFC8             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 16176                      | RB5: 16176<br>(note 9)         |
| 9        | DL_DSCH_TFC9             | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 18872                      | RB5: 18872<br>(note 10)        |
| 10       | DL_DSCH_TFC10            | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 21568                      | RB5: 21568<br>(note 11)        |
| 11       | DL_DSCH_TFC11            | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 24264                      | RB5: 24264<br>(note 12)        |
| 12       | DL_DSCH_TFC12            | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 26960                      | RB5: 26960<br>(note 13)        |

| Sub-test | Downlink TFCs Under test | Uplink TFCs Under test | Implicitely tested                                                   | Restricted UL-TFCIs                         | UL-RLC SDU-size (bits) (note 1) | Test data size (bits) (note 1) |
|----------|--------------------------|------------------------|----------------------------------------------------------------------|---------------------------------------------|---------------------------------|--------------------------------|
| 13       | DL_DSCH_TFC13            | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 29656                      | RB5: 29656<br>(note 14)        |
| 14       | DL_DSCH_TFC14            | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 32352                      | RB5: 32352<br>(note 15)        |
| 15       | DL_DSCH_TFC15            | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 35048                      | RB5: 35048<br>(note 16)        |
| 16       | DL_DSCH_TFC16            | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 37744                      | RB5: 37744<br>(note 17)        |
| 17       | DL_DSCH_TFC17            | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 40440                      | RB5: 40440<br>(note 18)        |
| 18       | DL_DSCH_TFC18            | UL_TFC4                | DL_DSCH_TFC0,<br>DL_DCH_TFC0,<br>DL_DCH_TFC1,<br>UL_TFC0,<br>UL_TFC5 | UL_TFC0,<br>UL_TFC4,<br>UL_TFC5,<br>UL_TFC9 | RB5: 43136                      | RB5: 43136<br>(note 19)        |

| Sub-test                                                                                                                                                                                                                                                 | Downlink TFCs Under test | Uplink TFCs Under test | Implicitely tested | Restricted UL TFCs | UL RLC SDU size (bits) (note 1) | Test data size (bits) (note 1) |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|------------------------|--------------------|--------------------|---------------------------------|--------------------------------|
| NOTE 1: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.                                                                                                                                                                  |                          |                        |                    |                    |                                 |                                |
| NOTE 2: SS is using a DL RLC SDU with 674 bits as test data (=DL RLC PDU size for DL/DSCH_TF1). UE will return three RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1, RLC SDU#2 and the first 2 bits of RLC PDU#3.                     |                          |                        |                    |                    |                                 |                                |
| NOTE 3: SS is using a DL RLC SDU size of 1348 bits as test data (=DL RLC PDU size for DL/DSCH_TF2). UE will return three RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1, RLC SDU#2 and the first 4 bits of RLC PDU#3.                 |                          |                        |                    |                    |                                 |                                |
| NOTE 4: SS is using a DL RLC SDU size of 2696 bits as test data (=DL RLC PDU size for DL/DSCH_TF3). UE will return three RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1, RLC SDU#2 and the first 680 bits of RLC PDU#3.               |                          |                        |                    |                    |                                 |                                |
| NOTE 5: SS is using a DL RLC SDU size of 5392 bits as test data (=DL RLC PDU size for DL/DSCH_TF4). UE will return five RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#4 and the first 16 bits of RLC PDU#5.               |                          |                        |                    |                    |                                 |                                |
| NOTE 6: SS is using a DL RLC SDU size of 8088 bits as test data (=DL RLC PDU size for DL/DSCH_TF5). UE will return seven RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#6 and the first 24 bits of RLC PDU#7.              |                          |                        |                    |                    |                                 |                                |
| NOTE 7: SS is using a DL RLC SDU size of 10784 bits as test data (=DL RLC PDU size for DL/DSCH_TF6). UE will return nine RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#8 and the first 32 bits of RLC PDU#9.              |                          |                        |                    |                    |                                 |                                |
| NOTE 8: SS is using a DL RLC SDU size of 13480 bits as test data (=DL RLC PDU size for DL/DSCH_TF7). UE will return eleven RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#10 and the first 40 bits of RLC PDU#11.          |                          |                        |                    |                    |                                 |                                |
| NOTE 9: SS is using a DL RLC SDU size of 16176 bits as test data (=DL RLC PDU size for DL/DSCH_TF8). UE will return thirteen RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#12 and the first 48 bits of RLC PDU#13.        |                          |                        |                    |                    |                                 |                                |
| NOTE 10: SS is using a DL RLC SDU size of 18872 bits as test data (=DL RLC PDU size for DL/DSCH_TF9). UE will return fifteen RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#14 and the first 56 bits of RLC PDU#15.        |                          |                        |                    |                    |                                 |                                |
| NOTE 11: SS is using a DL RLC SDU size of 21568 bits as test data (=DL RLC PDU size for DL/DSCH_TF10). UE will return seventeen RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#16 and the first 64 bits of RLC PDU#17.     |                          |                        |                    |                    |                                 |                                |
| NOTE 12: SS is using a DL RLC SDU size of 24264 bits as test data (=DL RLC PDU size for DL/DSCH_TF11). UE will return nineteen RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#18 and the first 72 bits of RLC PDU#19.      |                          |                        |                    |                    |                                 |                                |
| NOTE 13: SS is using a DL RLC SDU size of 26960 bits as test data (=DL RLC PDU size for DL/DSCH_TF12). UE will return twenty-one RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#20 and the first 80 bits of RLC PDU#21.    |                          |                        |                    |                    |                                 |                                |
| NOTE 14: SS is using a DL RLC SDU size of 29656 bits as test data (=DL RLC PDU size for DL/DSCH_TF13). UE will return twenty-three RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#22 and the first 88 bits of RLC PDU#23.  |                          |                        |                    |                    |                                 |                                |
| NOTE 15: SS is using a DL RLC SDU size of 32352 bits as test data (=DL RLC PDU size for DL/DSCH_TF14). UE will return twenty-five RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#24 and the first 96 bits of RLC PDU#25.   |                          |                        |                    |                    |                                 |                                |
| NOTE 16: SS is using a DL RLC SDU size of 35048 bits as test data (=DL RLC PDU size for DL/DSCH_TF15). UE will return twenty-seven RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#26 and the first 104 bits of RLC PDU#27. |                          |                        |                    |                    |                                 |                                |
| NOTE 17: SS is using a DL RLC SDU size of 37744 bits as test data (=DL RLC PDU size for DL/DSCH_TF16). UE will return twenty-nine RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#28 and the first 112 bits of RLC PDU#29.  |                          |                        |                    |                    |                                 |                                |
| NOTE 18: SS is using a DL RLC SDU size of 40440 bits as test data (=DL RLC PDU size for DL/DSCH_TF17). UE will return thirty-one RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#30 and the first 120 bits of RLC PDU#31.   |                          |                        |                    |                    |                                 |                                |
| NOTE 19: SS is using a DL RLC SDU size of 43136 bits as test data (=DL RLC PDU size for DL/DSCH_TF18). UE will return thirty-three RLC PDUs. The SS creates an UL RLC SDU by concatenating RLC PDU#1 to RLC PDU#32 and the first 128 bits of RLC PDU#33. |                          |                        |                    |                    |                                 |                                |

See 14.1.1 for test procedure.

#### 14.3.3.2.4 Test requirements

See 14.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

- for sub-test 1: RB5/TF1 (1x336).
- for sub-test 2: RB5/TF2 (2x336).
- for sub-test 3: RB5/TF3 (3x336).
- for sub-test 4 to 18: RB5/TF4 (4x336).

3. At step 15 the UE shall return

- for sub-test 1 to 18: an RLC SDU on RB5 having the same content as the DL RLC SDU sent by the SS.

#### ~~14.3.4 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

##### ~~14.3.4.1 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.4 for the downlink 10 ms TTI case.

##### ~~14.3.4.2 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.4 for the downlink 20 ms TTI case.

#### ~~14.3.5 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

##### ~~14.3.5.1 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.5 for the downlink 10 ms TTI case.

##### ~~14.3.5.2 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI~~

Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.5 for the downlink 20 ms TTI case.

### ~~14.3.6 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

#### ~~14.3.6.1 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.6 for the downlink 10 ms TTI case.~~

#### ~~14.3.6.2 Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.2.6 for the downlink 20 ms TTI case.~~

## ~~14.4 Combinations on SCCPCH~~

### ~~14.4.1 Stand-alone signalling RB for PCCH~~

~~Test to verify establishment and signalling of stand-alone signalling reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.3.1.~~

~~The test case is performed by running test case 8.1.1.2 (Paging for Connection in connected mode (CELL\_PCH)) using the stand-alone signalling reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.3.1.~~

### ~~14.4.2 Interactive/Background 32 kbps PS RAB + SRBs for CCCH + SRB for DCCH + SRB for BCCH~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.3.2.~~

### ~~14.4.3 Interactive/Background 32 kbps RAB + SRBs for PCCH + SRB for CCCH + SRB for DCCH + SRB for BCCH~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.3.3.~~

### ~~14.4.4 RB for CTCH + SRB for CCCH + SRB for BCCH.~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.3.4.~~

## ~~14.5 Combinations on PRACH~~

### ~~14.5.1 Interactive/Background 32 kbps PS RAB + SRB for CCCH + SRB for DCCH~~

~~Test to verify establishment and data transfer of reference radio bearer configuration as specified in TS 34.108, clause 6.10.2.4.4.1.~~



---

## ~~15~~ ~~Supplementary Services~~

~~This clause is FFS.~~

## 16 Short message service (SMS)

Ref.: 3GPP TS 23.040, 3GPP TS 24.011 (point to point)  
3GPP TS 23.041, (cell broadcast)

### General

The purpose of these tests is to verify that the UE can handle Iu mode system functions when submitting or receiving Short Messages (SM) between UE and a short message service centre as described in 3GPP TS 23.040.

The procedures are based upon services provided by the Mobility Management (MM) sublayer and GPRS Mobility Management (GMM) sublayer which are not tested in this case.

The SMS comprises three basic services; SMS point to point services on CS mode, on PS mode and SMS cell broadcast service. The SMS point to point services on CS mode shall work in an active UE at any time independent of whether or not there is a speech or data call in progress. The SMS point to point services on PS mode shall work in an active UE at any time independent of whether or not there is a PDP context in progress. The SMS cell broadcast service only works when the UE is in idle mode.

Since the timer TC1M currently is not standardized, the value of TC1M shall be declared by the manufacturer (to be used in clauses 16.1.1 and 16.1.2).

The manufacturer shall declare whether SMS messages are stored in the USIM and/or the ME. This shall be referred to as the SMS message store in the following tests.

Unless otherwise stated default message contents from 3GPP TS 34.108 applies for following tests.

## 16.1 Short message service point to point on CS mode

All of test cases in this clause are applied to UE supporting CS mode.

### 16.1.1 SMS mobile terminated

#### 16.1.1.1 Definition

#### 16.1.1.2 Conformance requirements

An active UE shall be able to receive short message TPDU (SMS-DELIVER) at any time, independently of whether or not there is a speech or data call in progress. A report will always be returned to the SC, confirming that the UE has received the short message.

#### Reference

3GPP TS 23.040, clause 3.1.

#### 16.1.1.3 Test purpose

To verify the ability of a UE to receive and decode the SMS where provided for the point to point service.

#### 16.1.1.4 Method of test

#### Initial Conditions

- System simulator;
- 1 cell, default parameters.

- User Equipment:
  - the UE shall be in MM-state "Idle, updated";
  - the SMS message storage shall be empty.

#### Related ICS/IXIT Statements

Support for Short message MT/PP.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

Support for call control state U10.

#### Test procedure

- a) Mobile terminates establishment of Radio Resource Connection. After the completion of RRC Connection SS authenticates UE.
  - After the SS receives SECURITY MODE COMPLETE, the SS sends a CP-DATA message. The information element of the CP-DATA message will be RP-DATA RPDU (SMS DELIVER TPDU).
- b) The SS waits a maximum of 25 s for the CP-ACK message and then a maximum of 60 s for the CP-DATA message containing the RP-ACK RPDU.
- c) The SS sends a CP-ACK to the UE within TC1M with no further CP-DATA messages and the SS initiates RRC Connection release.
- d) Steps a), b) and c) are repeated but the first CP-DATA message from the UE is not acknowledged. The second CP-DATA message from the UE is acknowledged by a CP-ACK within a time TC1M.
- e) Steps a) and b) are repeated. The SS is configured not to send CP-ACK. Then maximum 3 CP-DATA retransmissions may occur. After a duration of TC1M + 5 s after the last CP-DATA retransmission the SS then initiates the channel release. The 5 s is the appropriate time to wait to verify that the UE does not send more than the maximum allowed (3) CP-DATA retransmissions.
- f) The SMS message store shall be cleared manually by the operator.
- g) A data or speech call is established on a DTCH with the SS and the state U10 of call control is entered.
  - The SS sends a CP-DATA message. The information element of the CP-DATA message will be RP-DATA RPDU (SMS DELIVER TPDU). The SS waits a maximum of 25 s for the CP-ACK message and then a maximum of 60 s for the CP-DATA message containing the RP-ACK RPDU.
- h) The SS sends a CP-ACK to the UE within TC1M with no further CP-DATA messages and the SS initiates RRC Connection release. The SMS message store shall be cleared manually by the operator.
- i) Steps g) and h) are repeated but the first CP-DATA message from the UE is not acknowledged. The second CP-DATA message from the UE is acknowledged by a CP-ACK within a time TC1M.
- j) Step g) is repeated. The SS is configured not to send CP-ACK. Then maximum 3 CP-DATA retransmissions may occur. After a duration of TC1M + 15 s after the last CP-DATA retransmission the SS initiates the channel release. The 15 s is the appropriate time to wait to verify that the UE does not send more than the maximum allowed (3) CP-DATA retransmissions (during a call in progress).

- k) A data or speech call is established on a DTCH with the SS and the state U10 of call control shall be entered. The speech call is cleared by the SS with a disconnect message. (The call clearing is continued on the DCCH in parallel to the following exchange of messages related to SMS):
- The SS sends a CP-DATA RPDU (SMS DELIVER TPDU) message. The information element of the CP-DATA message is RP-DATA.
  - The SS waits a maximum of 25 s for the CP-ACK message and then a maximum of 60 s for the CP-DATA message containing the RP-ACK RPDU.
  - The SS sends a CP-ACK to the UE within TC1M with no further CP-DATA messages and the SS initiates channel release.
  - The SMS message store shall be cleared manually by the operator.
- l) A data or speech call is established with the SS and the state U10 of call control is entered. The speech call shall be cleared from the UE. (The call clearing is continued in parallel to the following exchange of messages related to SMS):
- The SS sends a CP-DATA message. The information element of the CP-DATA message is RP-DATA RPDU (SMS DELIVER TPDU).
  - The SS waits a maximum of 25 s for the CP-ACK message and then a maximum of 60 s for the CP-DATA message containing the RP-ACK RPDU.
  - The SS sends a CP-ACK to the UE within TC1M with no further CP-DATA messages and the SS initiates RRC Connection release.
  - The SMS message store shall be cleared manually by the operator.

#### Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                             |
|------|-----------|----|--------------------------------------------------------------|--------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                      |
| 1    |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS 34.108                                                                   |
| 2    | →         |    | PAGING RESPONSE                                              |                                                                                      |
| 3    | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                      |
| 4    | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                      |
| 5    | ←         |    | SECURITY MODE COMMAND                                        |                                                                                      |
| 6    | →         |    | SECURITY MODE COMPLETE                                       |                                                                                      |
| 7    | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS DELIVER TPDU)                                             |
| 8    |           | SS |                                                              | Waits max 25 s for CP-ACK                                                            |
| 9    | →         |    | CP-ACK                                                       |                                                                                      |
| 10   |           | SS |                                                              | Waits max 60 s for RP-ACK RPDU                                                       |
| 11   | →         |    | CP-DATA                                                      | Contains RP-ACK RPDU                                                                 |
| 12   | ←         |    | CP-ACK                                                       |                                                                                      |
| 13   | UE        |    |                                                              | There should be no further CP-DATA messages until the UE aborts the RRC connection.  |
| 14   | UE        |    |                                                              | The UE shall indicate that an SM has arrived.                                        |
| 15   |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS 34.108                                                                   |
| 16   | →         |    | PAGING RESPONSE                                              |                                                                                      |
| 17   | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                      |
| 18   | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                      |
| 19   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                      |
| 20   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                      |
| 21   | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS DELIVER TPDU)                                             |
| 22   |           | SS |                                                              | Waits max 25 s for CP-ACK                                                            |
| 23   | →         |    | CP-ACK                                                       |                                                                                      |
| 24   |           | SS |                                                              | Waits max 60 s for RP-ACK RPDU                                                       |
| 25   | →         |    | CP-DATA                                                      | First CP-DATA from UE, contains RP-ACK RPDU                                          |
| 26   |           | SS |                                                              | First CP-DATA message not acknowledged by SS                                         |
| 27   | →         |    | CP-DATA                                                      | Retransmitted CP-DATA from UE within twice TC1M, after step 25, contains RP-ACK RPDU |
| 28   | ←         |    | CP-ACK                                                       | Second CP-DATA message is acknowledged                                               |

| Step | Direction |    | Message                                                      | Comments                                                                                                  |
|------|-----------|----|--------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                           |
| 29   | UE        |    |                                                              | There should be no further CP-DATA messages until the UE aborts the RRC connection.                       |
| 30   | UE        |    |                                                              | The UE shall indicate that an SM has arrived.                                                             |
| 31   |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS 34.108                                                                                        |
| 32   | →         |    | PAGING RESPONSE                                              |                                                                                                           |
| 33   | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                                           |
| 34   | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                                           |
| 35   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                           |
| 36   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                           |
| 37   | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS DELIVER TPDU)                                                                  |
| 38   | SS        |    |                                                              | Waits max 25 s for CP-ACK                                                                                 |
| 39   | →         |    | CP-ACK                                                       |                                                                                                           |
| 40   | SS        |    |                                                              | Waits max 60 s for RP-ACK RPDU                                                                            |
| 41   | →         |    | CP-DATA                                                      | Contains RP-ACK RPDU                                                                                      |
| 42   | SS        |    |                                                              | First CP-DATA message not acknowledged by SS                                                              |
| 43   |           |    | CP-DATA                                                      | Retransmitted CP-DATA from UE within twice TC1M after step 41, contains RP-ACK RPDU                       |
| 44   | SS        |    |                                                              | Retransmitted CP-DATA message not acknowledged by SS                                                      |
| 45   | UE        |    |                                                              | Depending upon the maximum number of CP-DATA retransmissions implemented, step 43 and 44 may be repeated. |
| 46   | ←         |    | RRC CONNECTION RELEASE                                       | RRC connection is released after a duration of TC1M + 5 s after the last CP-DATA retransmission.          |
| 47   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                           |
| 48   | UE        |    |                                                              | The UE shall indicate that an SM has arrived.                                                             |
| 49   | SS        |    |                                                              | A data or speech call is established on a DTCH and the state U10 of call control is entered.              |
| 50   |           |    | (void)                                                       |                                                                                                           |
| 51   | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS DELIVER TPDU)                                                                  |
| 52   | SS        |    |                                                              | Waits max 25 s for CP-ACK                                                                                 |
| 53   | →         |    | CP-ACK                                                       |                                                                                                           |
| 54   | SS        |    |                                                              | Waits max 60 s for RP-ACK RPDU                                                                            |
| 55   | →         |    | CP-DATA                                                      | Contains RP-ACK RPDU                                                                                      |
| 56   | ←         |    | CP-ACK                                                       |                                                                                                           |
| 57   | ←         |    | DISCONNECT                                                   | Disconnect the active call                                                                                |
| 58   | →         |    | RELEASE                                                      |                                                                                                           |
| 59   | UE        |    |                                                              | The UE shall indicate that an SM has arrived.                                                             |
| 60   | UE        |    |                                                              | Clear the SMS message store                                                                               |
| 61   | SS        |    |                                                              | A data or speech call is established on a DTCH and the state U10 of call control is entered.              |
| 62   | ←         |    | (void)                                                       |                                                                                                           |
| 63   | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS DELIVER TPDU)                                                                  |
| 64   | SS        |    |                                                              | Waits max 25 s for CP-ACK                                                                                 |
| 65   | →         |    | CP-ACK                                                       |                                                                                                           |
| 66   | SS        |    |                                                              | Waits max 60 s for RP-ACK RPDU                                                                            |
| 67   | →         |    | CP-DATA                                                      | First CP-DATA from UE, contains RP-ACK RPDU                                                               |
| 68   | SS        |    |                                                              | First CP-DATA message not acknowledged by SS                                                              |
| 69   | →         |    | CP-DATA                                                      | Retransmitted CP-DATA message within twice TC1M after step 67, contains RP-ACK RPDU                       |
| 70   | ←         |    | CP-ACK                                                       | Second CP-DATA message is acknowledged                                                                    |
| 71   | ←         |    | DISCONNECT                                                   | Disconnect the active call                                                                                |
| 72   | →         |    | RELEASE                                                      |                                                                                                           |
| 74   | UE        |    |                                                              | There should be no further CP-DATA messages until the UE aborts the RRC connection                        |
| 75   | UE        |    |                                                              | The UE shall indicate that an SM has arrived.                                                             |
| 76   | UE        |    |                                                              | Clear the SMS message store                                                                               |
| 77   | SS        |    |                                                              | A data or speech call is established on a DTCH and the state U10 of call control is entered.              |
| 78   |           |    | (void)                                                       |                                                                                                           |
| 79   | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS DELIVER TPDU)                                                                  |
| 80   | SS        |    |                                                              | Waits max 25 s for CP-ACK                                                                                 |
| 81   | →         |    | CP-ACK                                                       |                                                                                                           |

| Step                                                                                                                                           | Direction |    | Message                         | Comments                                                                                                                                                                |
|------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                | UE        | SS |                                 |                                                                                                                                                                         |
| 82                                                                                                                                             |           | SS |                                 | Waits max 60 s for RP-ACK RPDU                                                                                                                                          |
| 83                                                                                                                                             | →         |    | CP-DATA                         | First CP-DATA from UE, contains RP-ACK RPDU                                                                                                                             |
| 84                                                                                                                                             |           | SS |                                 | First CP-DATA message not acknowledged by SS                                                                                                                            |
| 85                                                                                                                                             | →         |    | CP-DATA                         | Transmitted CP-DATA message within twice TC1M after step 83, contains RP-ACK RPDU                                                                                       |
| 86                                                                                                                                             |           | SS |                                 | Retransmitted CP-DATA message not acknowledged by SS                                                                                                                    |
| 87                                                                                                                                             | UE        |    |                                 | Depending on the maximum number of CP-DATA retransmissions implemented, step 85-86 may be repeated. The maximum number of retransmissions may however not exceed three. |
| 88                                                                                                                                             | ←         |    | RRC CONNECTION RELEASE          | RRC CONNECTION is released after a duration of TC1M + 15 s after the last CP-DATA retransmission.                                                                       |
| 89                                                                                                                                             | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                         |
| 90                                                                                                                                             | UE        |    |                                 | The UE shall indicate that an SM has arrived.                                                                                                                           |
| 91                                                                                                                                             | UE        |    |                                 | Clear the SMS message store                                                                                                                                             |
| 92                                                                                                                                             |           | SS |                                 | A data or speech call is established on a DTCH and the state U10 of call control is entered.                                                                            |
| 93                                                                                                                                             |           |    | (void)                          |                                                                                                                                                                         |
| 94                                                                                                                                             | ←         |    | DISCONNECT                      | The speech call is cleared by the SS. The call clearing is continued in parallel to the following exchange of messages related to SMS.                                  |
| 95                                                                                                                                             | ←         |    | CP-DATA                         | Contains RP-DATA RPDU (SMS DELIVER TPDU)                                                                                                                                |
| 96                                                                                                                                             |           | SS |                                 | Waits max 25 s for CP-ACK                                                                                                                                               |
| 97                                                                                                                                             | →         |    | CP-ACK                          |                                                                                                                                                                         |
| 98                                                                                                                                             |           | SS |                                 | Waits max 60 s for RP-ACK RPDU                                                                                                                                          |
| 99                                                                                                                                             | →         |    | CP-DATA                         | Contains RP-ACK RPDU                                                                                                                                                    |
| 100                                                                                                                                            | ←         |    | CP-ACK                          |                                                                                                                                                                         |
| 101                                                                                                                                            | UE        |    |                                 | There should be no further CP-DATA messages until the UE aborts the RRC connection.                                                                                     |
| 102                                                                                                                                            | UE        |    |                                 | The UE shall indicate that an SM has arrived.                                                                                                                           |
| 103                                                                                                                                            | UE        |    |                                 | Clear the SMS message store                                                                                                                                             |
| 104                                                                                                                                            |           | SS |                                 | A data or speech call is established on a DTCH and the state U10 of call control is entered.                                                                            |
| 105                                                                                                                                            |           |    | (void)                          |                                                                                                                                                                         |
| 106                                                                                                                                            | →         |    | DISCONNECT                      | The speech call is cleared from the UE. The call clearing is continued in parallel to the following exchange of messages related to SMS.                                |
| 107                                                                                                                                            | ←         |    | CP-DATA                         | Contains RP-DATA RPDU (SMS DELIVER TPDU)                                                                                                                                |
| 108                                                                                                                                            | ←         |    | RELEASE                         | This message is likely to be sent before all of the CP-DATA message has been sent on the DCCH.                                                                          |
| 109                                                                                                                                            | →         |    | RELEASE COMPLETE                |                                                                                                                                                                         |
| 110                                                                                                                                            | →         |    | CP-ACK                          | shall be sent before 25 s after the start of step 107                                                                                                                   |
| 111                                                                                                                                            |           | SS |                                 | Waits max 60 s for RP-ACK RPDU                                                                                                                                          |
| 112                                                                                                                                            | →         |    | CP-DATA                         | Contains RP-ACK RPDU                                                                                                                                                    |
| 113                                                                                                                                            | ←         |    | CP-ACK                          |                                                                                                                                                                         |
| 114                                                                                                                                            | UE        |    |                                 | There should be no further CP-DATA messages until the UE aborts the RRC connection.                                                                                     |
| 115                                                                                                                                            | UE        |    |                                 | The UE shall indicate that an SM has arrived.                                                                                                                           |
| 116                                                                                                                                            | UE        |    |                                 | Clear the SMS message store                                                                                                                                             |
| NOTE: — Time values for SS wait time are chosen sufficiently high to be sure that the UE has enough time to respond to the different messages. |           |    |                                 |                                                                                                                                                                         |

## Specific Message Contents

## SMS DELIVER TPDU

| Information element                                                                                                                                     | CommentValue                     |
|---------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|
| TP-UDL                                                                                                                                                  | 160                              |
| TP-UD (140 octets)                                                                                                                                      | text of message (160 characters) |
| NOTE: — The 160 characters in TP-UD shall include at least one occurrence of each character in the default alphabet (see 3GPP TS 23.038, clause 6.2.1). |                                  |

### ~~16.1.1.5 Test requirements~~

~~After step 7 UE shall receive SMS-DELIVER TPDU and send CP-ACK within 25 s and CP-DATA containing RP-ACK within 60 s.~~

~~After step 25 UE shall retransmit CP-DATA containing RP-ACK within twice TC1M.~~

~~After step 30 UE shall indicate that an SM has arrived.~~

~~After step 43 UE shall repeat CP-DATA retransmissions as many times as the decided maximum number.~~

~~After step 48 UE shall indicate that an SM has arrived.~~

~~After step 51 UE shall receive SMS-DELIVER TPDU and send CP-ACK within 25 s and CP-DATA containing RP-ACK within 60 s.~~

~~After step 67 UE shall retransmit CP-DATA containing RP-ACK within twice TC1M.~~

~~After step 74 UE shall indicate that an SM has arrived.~~

~~After step 79 UE shall repeat CP-DATA retransmissions as many times as the decided maximum number.~~

~~After step 90 UE shall indicate that an SM has arrived.~~

~~After step 95 UE shall receive SMS-DELIVER TPDU and send CP-ACK within 25 s and CP-DATA containing RP-ACK within 60 s.~~

~~After step 107 UE shall receive SMS-DELIVER TPDU and send CP-ACK within 25 s and CP-DATA containing RP-ACK within 60 s.~~

## ~~16.1.2 SMS mobile originated~~

### ~~16.1.2.1 Definition~~

### ~~16.1.2.2 Conformance requirements~~

~~An active UE shall be able to submit short message TPDU (SMS-SUBMIT) at any time, independently of whether or not there is a speech or data call in progress.~~

### ~~Reference~~

~~3GPP TS 23.040 clause 3.1.~~

### ~~16.1.2.3 Test purpose~~

~~To verify that the UE is able to correctly send a short message where the SMS is provided for the point to point service.~~

### ~~16.1.2.4 Method of test~~

### ~~Initial Conditions~~

- ~~— System simulator:~~
  - ~~— 1 cell, default parameters.~~
- ~~— User Equipment:~~
  - ~~— the UE shall be in MM-state "Idle, updated";~~
  - ~~— the SMS message storage shall be empty.~~

### Related ICS/IXIT Statements

Support for Short message MO/PP.

Support for state U10 of call control.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

Maximum length (characters) of a mobile originated short message.

### Test procedure

- a) The UE shall be set up to send a SM to the SS. The SS responds to RRC CONNECTION REQUEST by allocating a CCCH. The SS receives RRC CONNECTION SETUP COMPLETE on DCGH and then performs the authentication.
- b) After receiving SECURITY MODE COMMAND UE shall send SECURITY COMMAND COMPLETE.
- c) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message within TC1M followed by a CP-DATA message containing the correct RP-ACK RPDU. The SS waits a maximum of 25 s for the CP-ACK message.
- d) The SS sends a channel release message to the UE.
- e) Steps a) and b) are repeated. The SS is configured not to send the CP-ACK message. Then maximum 3 CP-DATA retransmissions may occur. After a duration of TC1M + 5 s after the last CP-DATA retransmission the SS initiates channel release. The 5 s is the appropriate time to wait to verify that the UE does not send more than the maximum CP-DATA retransmissions.
- f) Steps a) and b) are repeated. On receipt of the CP-DATA from the UE the SS sends a CP-ERROR message within TC1M containing a "Network Failure" cause. Then the SS initiates channel release.
- g) A data or speech call is established with the SS and the state U10 of call control is entered. The UE is set up to send an SM to the SS. After the reception of the CM SERVICE REQUEST, the SS sends a CM SERVICE ACCEPT message.
- h) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message within TC1M followed by a CP-DATA message containing the correct RP-ACK RPDU. The SS waits a maximum of 25 s for the CP-ACK message. Then the SS sends a channel release message to the UE.
- i) Step g) is repeated. The SS is configured not to send the CP-ACK message. Then maximum 3 CP-DATA retransmissions may occur. After a duration of TC1M + 15 s after the last CP-DATA retransmission the SS initiates channel release. The 15 s is the appropriate time to wait to verify that the UE does not send more than the maximum CP-DATA retransmissions (during a call in progress).
- j) (void)
- k) The UE is set up to send an SM to the SS. On receipt of the CM SERVICE REQUEST the SS sends a CM SERVICE REJECT message with the reject cause set to "Service Option not supported" or "Service Option temporarily out of order". After 5 s the SS initiates channel release.



## Expected sequence

| Step | Direction |    | Message                          | Comments                                                                                                                                                             |
|------|-----------|----|----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                  |                                                                                                                                                                      |
| 1    | ←         |    | SYSTEM INFORMATION               | BCCH                                                                                                                                                                 |
| 2    | →         |    | RRC CONNECTION REQUEST           | CCCH                                                                                                                                                                 |
| 3    | ←         |    | RRC CONNECTION SETUP             | CCCH                                                                                                                                                                 |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE    | DCCH                                                                                                                                                                 |
| 5    | →         |    | CM SERVICE REQUEST               |                                                                                                                                                                      |
| 6    | ←         |    | AUTHENTICATION REQUEST           |                                                                                                                                                                      |
| 7    | →         |    | AUTHENTICATION RESPONSE          |                                                                                                                                                                      |
| 8    | ←         |    | SECURITY MODE COMMAND            |                                                                                                                                                                      |
| 9    | →         |    | SECURITY MODE COMPLETE           |                                                                                                                                                                      |
| 10   | →         |    | CP DATA                          | Contains RP-DATA RPDU (SMS SUBMIT TPDU)                                                                                                                              |
| 11   | ←         |    | CP ACK                           | Sent within TC1M after step 10                                                                                                                                       |
| 12   | ←         |    | CP DATA                          | Contains RP-ACK RPDU                                                                                                                                                 |
| 13   | SS        |    |                                  | Waits max 25 s for CP-ACK                                                                                                                                            |
| 14   | →         |    | CP ACK                           |                                                                                                                                                                      |
| 15   | ←         |    | RRC CONNECTION RELEASE           | RRC connection is released.                                                                                                                                          |
| 16   | →         |    | -RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                      |
| 17   | ←         |    | SYSTEM INFORMATION               | BCCH                                                                                                                                                                 |
| 18   | →         |    | RRC CONNECTION REQUEST           | CCCH                                                                                                                                                                 |
| 19   | ←         |    | RRC CONNECTION SETUP             | CCCH                                                                                                                                                                 |
| 20   | →         |    | RRC CONNECTION SETUP COMPLETE    | DCCH                                                                                                                                                                 |
| 21   |           |    |                                  |                                                                                                                                                                      |
| 22   | →         |    | CM SERVICE REQUEST               |                                                                                                                                                                      |
| 23   | ←         |    | AUTHENTICATION REQUEST           |                                                                                                                                                                      |
| 24   | →         |    | AUTHENTICATION RESPONSE          |                                                                                                                                                                      |
| 25   | ←         |    | SECURITY MODE COMMAND            |                                                                                                                                                                      |
| 26   | →         |    | SECURITY MODE COMPLETE           |                                                                                                                                                                      |
| 27   | →         |    | CP DATA                          | Contains RP-DATA RPDU (SMS SUBMIT TPDU)                                                                                                                              |
| 28   | SS        |    |                                  | SS configured not to send CP-ACK                                                                                                                                     |
| 29   | →         |    | CP DATA                          | Retransmitted CP-DATA message within twice TC1M after step 27                                                                                                        |
| 30   | UE        |    |                                  | Depending on the maximum number of CP-DATA retransmissions implemented, step 29 may be repeated. The maximum number of retransmissions may however not exceed three. |
| 31   | ←         |    | RRC CONNECTION RELEASE           | RRC CONNECTION is released after a duration of TC1M + 5 s after the last CP-DATA retransmission.                                                                     |
| 32   | →         |    | -RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                      |
| 33   | ←         |    | SYSTEM INFORMATION               | BCCH                                                                                                                                                                 |
| 34   | →         |    | RRC CONNECTION REQUEST           | CCCH                                                                                                                                                                 |
| 35   | ←         |    | RRC CONNECTION SETUP             | CCCH                                                                                                                                                                 |
| 36   | →         |    | RRC CONNECTION SETUP COMPLETE    | DCCH                                                                                                                                                                 |
| 37   | →         |    | CM SERVICE REQUEST               |                                                                                                                                                                      |
| 38   | ←         |    | AUTHENTICATION REQUEST           |                                                                                                                                                                      |
| 39   | →         |    | AUTHENTICATION RESPONSE          |                                                                                                                                                                      |
| 40   | ←         |    | SECURITY MODE COMMAND            |                                                                                                                                                                      |
| 41   | →         |    | SECURITY MODE COMPLETE           |                                                                                                                                                                      |
| 42   | →         |    | CP DATA                          | Contains RP-DATA RPDU (SMS SUBMIT TPDU)                                                                                                                              |
| 43   | ←         |    | CP ERROR                         | Sent within TC1M containing "Network Failure" cause.                                                                                                                 |
| 44   | ←         |    | -RRC CONNECTION RELEASE          | RRC CONNECTION is released.                                                                                                                                          |
| 45   | →         |    | -RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                      |
| 46   | SS        |    |                                  | A data or speech call is established on a DTCH and the state U10 of call control is entered.                                                                         |
| 47   | UE        |    |                                  | The UE is set up to send an SM                                                                                                                                       |
| 48   | →         |    | CM SERVICE REQUEST               | CM service type set to "short message"                                                                                                                               |
| 49   | ←         |    | CM SERVICE ACCEPT                |                                                                                                                                                                      |
| 50   | →         |    | CP DATA                          | Contains RP-DATA RPDU (SMS SUBMIT TPDU)                                                                                                                              |

| Step                                                                                                                                            | Direction |    | Message                                    | Comments                                                                                                                                                             |
|-------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|--------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                 | UE        | SS |                                            |                                                                                                                                                                      |
| 51                                                                                                                                              | ←         |    | CP-ACK                                     | Sent within TC1M after step 50                                                                                                                                       |
| 52                                                                                                                                              | ←         |    | CP-DATA                                    | Contains RP-ACK RPDU                                                                                                                                                 |
| 53                                                                                                                                              |           | SS |                                            | Waits max 25 s for CP-ACK                                                                                                                                            |
| 54                                                                                                                                              | →         |    | CP-ACK                                     |                                                                                                                                                                      |
| 55                                                                                                                                              | ←         |    | <del>RRC CONNECTION RELEASE</del>          | RRC CONNECTION is released.                                                                                                                                          |
| 56                                                                                                                                              | →         |    | <del>RRC CONNECTION RELEASE COMPLETE</del> |                                                                                                                                                                      |
| 57                                                                                                                                              |           | SS |                                            |                                                                                                                                                                      |
| 58                                                                                                                                              | →         |    | CM SERVICE REQUEST                         | -CM service type set to "short message "                                                                                                                             |
| 59                                                                                                                                              | ←         |    | CM SERVICE ACCEPT                          |                                                                                                                                                                      |
| 60                                                                                                                                              | →         |    | CP-DATA                                    | Contains RP-DATA RPDU (SMS SUBMIT TPDU)                                                                                                                              |
| 61                                                                                                                                              |           | SS |                                            | SS configured not to send CP-ACK                                                                                                                                     |
| 62                                                                                                                                              | →         |    | CP-DATA                                    | Transmitted CP-DATA message within twice TC1M after step 60                                                                                                          |
| 63                                                                                                                                              |           | UE |                                            | Depending on the maximum number of CP-DATA retransmissions implemented, step 62 may be repeated. The maximum number of retransmissions may however not exceed three. |
| 64                                                                                                                                              | ←         |    | <del>RRC CONNECTION RELEASE</del>          | RRC CONNECTION is released after a duration of TC1m + 15 s after the last CP-DATA retransmission.                                                                    |
| 65                                                                                                                                              | →         |    | <del>RRC CONNECTION RELEASE COMPLETE</del> |                                                                                                                                                                      |
| 66-78                                                                                                                                           |           |    | (void)                                     |                                                                                                                                                                      |
| 79                                                                                                                                              | →         |    | RRC CONNECTION REQUEST                     |                                                                                                                                                                      |
| 80                                                                                                                                              | ←         |    | RRC CONNECTION SETUP                       |                                                                                                                                                                      |
| 81                                                                                                                                              | →         |    | RRC CONNECTION SETUP COMPLETE              |                                                                                                                                                                      |
| 82                                                                                                                                              | →         |    | CM SERVICE REQUEST                         | -CM service type set to "short message transfer"                                                                                                                     |
| 83                                                                                                                                              | ←         |    | CM SERVICE REJ                             | Reject cause set to "Service Option not supported" or "Service Option temporarily out of order"                                                                      |
| 84                                                                                                                                              |           |    | (void)                                     |                                                                                                                                                                      |
| 85                                                                                                                                              | ←         |    | RRC CONNECTION RELEASE                     | Sent 5 s after CM SERVICE REJ                                                                                                                                        |
| 86                                                                                                                                              | →         |    | RRC CONNECTION RELEASE COMPLETE            |                                                                                                                                                                      |
| NOTE: — Time values for SS wait times are chosen sufficiently high to be sure that the UE has enough time to respond to the different messages. |           |    |                                            |                                                                                                                                                                      |

### Specific Message Contents

#### SMS SUBMIT TPDU

| Information element              | Comment/Value                                                                                                 |
|----------------------------------|---------------------------------------------------------------------------------------------------------------|
| TP-UDL<br>TP-UD (140 octets max) | as applicable<br>maximum number of characters (text of message) as defined by the manufacturer (see ICS/IXIT) |

#### 16.1.2.5 — Test requirements

After step 9 UE shall send a CP-DATA containing RP-data. The RP-DATA shall contain SMS SUBMIT TPDU.

After step 27 UE shall retransmit a CP-DATA containing RP-data. The RP-DATA shall contain SMS SUBMIT TPDU.

After step 44 UE shall send the RRC CONNECTION RELEASE COMPLETE.

After step 49 UE shall send a CP-DATA containing RP-data. The RP-DATA shall contain SMS SUBMIT TPDU.

After step 60 UE shall repeat CP-DATA retransmissions as many times as the decided maximum number.

After step 83 UE shall not send CP-DATA.

### ~~16.1.3—Test of memory full condition and memory available notification:~~

The Memory Available Notification provides a means for the UE to notify the network that it has memory available to receive one or more short messages. The SMS status field in the USIM contains status information on the "memory available" notification flag.

#### ~~16.1.3.1—Definition~~

#### ~~16.1.3.2—Conformance requirement~~

- ~~1. When a mobile terminated message is Class 2, the UE shall ensure that the message has been transferred to the SMS data field in the USIM before sending an acknowledgement to the SC. The UE shall return a protocol error message if the short message cannot be stored in the USIM and there is other short message storage available in the UE. If all the short message storage in the UE is already in use, the UE shall return "memory capability exceeded".~~
- ~~2. When the UE rejects a short message due to lack of available memory capability the need to transfer notification shall be stored in the USIM.~~
- ~~3. If the memory capability becomes available because memory is cleared, the value of the memory capability exceeded notification flag in the USIM is read. If the flag is set, the UE notifies the network that memory capability is now available. After a positive acknowledgement from the network, the ME unsets the memory capability exceeded notification flag in the USIM.~~

#### References

- ~~—3GPP TS 23.040 clause 9.2.3.10, 3GPP TS 23.038 clause 4.~~
- ~~—3GPP TS 23.040 clause 10.3 (operation 14).~~
- ~~—3GPP TS 23.040 clause 10.3 (operation 14).~~

#### ~~16.1.3.3—Test purpose~~

- ~~1. To verify that the UE sends the correct acknowledgement when its memory in the USIM becomes full.~~
- ~~2. To verify that the UE sends the correct acknowledgement when its memory in the ME and the USIM becomes full, and sets the "memory exceeded" notification flag in the USIM.~~
- ~~3. To verify that the UE performs the "memory available" procedure when its message store becomes available for receiving short messages, and only at this moment.~~

#### ~~16.1.3.4—Method of test~~

#### Initial conditions

- ~~—System Simulator:~~
  - ~~—1 cell, default parameters.~~
- ~~—User Equipment:~~
  - ~~—the UE shall be in MM-state "Idle, updated";~~
  - ~~—the SMS message storage shall be empty;~~
  - ~~—the UE shall be connected to the USIM simulator. The following shall be present in the USIM simulator:~~
    - ~~—EF<sub>SMS</sub> with at least one record;~~
    - ~~—EF<sub>SMSstatus7</sub> with SMS "Memory Cap. Exceed" notification flag set to "memory available";~~
    - ~~—Service no. 4 (SMS) in EF<sub>SST</sub> set to allocated and activated.~~

- for storing of Class 1 Short Messages the UE shall be set up to store Short Messages in the ME memory (by way of MMI, as described in ICS/IXIT statement).

#### Related ICS/IXIT Statements

Support for Short message MT/PP.

Whether SMS messages are stored in the USIM and/or the ME.

The value of timer TC1M.

#### Test procedure

- a) step a) of clause 16.1.5.3 (test of Class 2 Short Messages) is repeated until the UE sends a negative acknowledgement (RP-ERROR). The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.
- b) a Class 1 Short Message is sent to the UE.
- c) step b) is repeated until the UE sends a negative acknowledgement (RP-ERROR). The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.
- d) a Short Message is sent to the UE with the DCS field of the SMS-DELIVER TPDU set to 0.
- e) the SS prompts the operator to read a short message and to remove it from the message store of the UE.
- f) the SS waits for a RRC CONNECTION REQUEST from the UE, and sends a RRC CONNECTION SETUP.
- g) after the SS receives a RRC CONNECTION SETUP COMPLETE, the SS authenticates the UE and activates ciphering.
- h) the SS answers to the RP-SMMA from the UE with a CP-DATA containing a RP-ACK RPDU.
- i) after the UE has acknowledged the CP-DATA with a CP-ACK, the SS releases the RRC connection. The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been unset on the USIM.
- j) step e) is repeated.

#### Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|------|-----------|----|--------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 1    |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108<br><br>Contains RP-DATA RPDU (SMS-DELIVER TPDU), Class 2 Short Message<br>Waits max 25 s for CP-ACK<br><br>Waits max 60 s for RP-ACK RPDU<br>Contains RP-ACK RPDU<br>Within TC1M after step 11<br>RRC connection is released. Step 1-13 is repeated until UE sends a negative acknowledgement (RP-ERROR) in step 16. The RP-ERROR RPDU-cause field shall be "Protocol error, unspecified" if there is message capability in the ME, or "Memory capability exceeded" if there is no message capability in the ME. If the total memory store of the UE is full, the ME shall set the "memory capability exceeded" notification flag on the USIM. |
| 2    | -->       |    | PAGING RESPONSE                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 3    | <--       |    | AUTHENTICATION REQUEST                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 4    | -->       |    | AUTHENTICATION RESPONSE                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 5    | <--       |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 6    | -->       |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 7    | <--       |    | CP-DATA                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 8    |           | SS |                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 9    | -->       |    | CP-ACK                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 10   |           | SS |                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 11   | -->       |    | CP-DATA                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 12   | <--       |    | CP-ACK                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 13   | <--       |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 14   | -->       |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                                                                                                                                                                      |
|------|-----------|----|--------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                                                                                                                                                               |
| 15   |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108                                                                                                                                                                                                                                                                                             |
| 16   | →         |    | PAGING RESPONSE                                              |                                                                                                                                                                                                                                                                                                               |
| 17   | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                                                                                                                                                                                                                                               |
| 18   | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                                                                                                                                                                                                                                               |
| 19   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                                                                                                                               |
| 20   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                                                                                                                                               |
| 21   | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-DELIVER TPDU), Class 1-Short Message                                                                                                                                                                                                                                               |
| 22   |           | SS |                                                              | Waits max 25 s for CP-ACK                                                                                                                                                                                                                                                                                     |
| 23   | →         |    | CP-ACK                                                       |                                                                                                                                                                                                                                                                                                               |
| 24   |           | SS |                                                              | Waits max 60 s for RP-ACK RPDU                                                                                                                                                                                                                                                                                |
| 25   | →         |    | CP-DATA                                                      | Shall contain RP-ACK RPDU if there is memory capability in the ME. If not it shall contain RP-ERROR RPDU which cause field shall be "memory capability exceeded". If the total memory store of the UE now becomes full at this step, the ME shall set the "memory cap. exceed" notification flag on the USIM. |
| 26   | ←         |    | CP-ACK                                                       | Within TC1M after step 25                                                                                                                                                                                                                                                                                     |
| 27   | ←         |    | RRC CONNECTION RELEASE                                       | RRC connection is released. Step 15-27 is repeated until the UE sends an RP-ERROR. The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.                                                                                                          |
| 28   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                                                                                                               |
| 29   |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108                                                                                                                                                                                                                                                                                             |
| 30   | →         |    | PAGING RESPONSE                                              |                                                                                                                                                                                                                                                                                                               |
| 31   | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                                                                                                                                                                                                                                               |
| 32   | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                                                                                                                                                                                                                                               |
| 33   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                                                                                                                               |
| 34   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                                                                                                                                               |
| 35   | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-DELIVER TPDU) with TP-DCS set to 0                                                                                                                                                                                                                                                 |
| 36   |           | SS |                                                              | Waits max 25 s for CP-ACK                                                                                                                                                                                                                                                                                     |
| 37   | →         |    | CP-ACK                                                       |                                                                                                                                                                                                                                                                                                               |
| 38   |           | SS |                                                              | Waits max 60 s for RP-ACK RPDU                                                                                                                                                                                                                                                                                |
| 39   | →         |    | CP-DATA                                                      | Shall contain RP-ERROR RPDU with error cause "memory capability exceeded".                                                                                                                                                                                                                                    |
| 40   | ←         |    | CP-ACK                                                       | Within TC1M after step 39                                                                                                                                                                                                                                                                                     |
| 41   | ←         |    | RRC CONNECTION RELEASE                                       | RRC connection is released.                                                                                                                                                                                                                                                                                   |
| 42   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                                                                                                               |
| 43   |           | SS |                                                              | Prompts the operator to remove one of the short messages from the message store of the UE.                                                                                                                                                                                                                    |
| 44   | ←         |    | SYSTEM INFORMATION                                           | BCCH                                                                                                                                                                                                                                                                                                          |
| 45   | →         |    | RRC CONNECTION REQUEST                                       | CCCH                                                                                                                                                                                                                                                                                                          |
| 46   | ←         |    | RRC CONNECTION SETUP                                         | CCCH                                                                                                                                                                                                                                                                                                          |
| 47   | →         |    | RRC CONNECTION SETUP COMPLETE                                | DCCH                                                                                                                                                                                                                                                                                                          |
| 48   | →         |    | CM SERVICE REQUEST                                           | CM service type information element is set to "Short message transfer".                                                                                                                                                                                                                                       |
| 49   | ←         |    | CM SERVICE ACCEPT                                            |                                                                                                                                                                                                                                                                                                               |
| 50   | →         |    | CP-DATA                                                      | Contains RP-SMMA RPDU                                                                                                                                                                                                                                                                                         |
| 51   | ←         |    | CP-ACK                                                       |                                                                                                                                                                                                                                                                                                               |
| 52   | ←         |    | CP-DATA                                                      | Contains RP-ACK RPDU                                                                                                                                                                                                                                                                                          |
| 53   | →         |    | CP-ACK                                                       | Acknowledge of CP-DATA containing the RP-ACK RPDU. The ME shall unset the "memory capability exceeded" notification flag on the USIM.                                                                                                                                                                         |
| 54   | ←         |    | RRC CONNECTION RELEASE                                       | RRC connection is released. The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been unset on the USIM.                                                                                                                                                               |
| 55   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                                                                                                               |

| Step                                                                                                                                           | Direction |    | Message | Comments                                                                                                                                                                                                                                                                                                 |
|------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                | UE        | SS |         |                                                                                                                                                                                                                                                                                                          |
| 56                                                                                                                                             | SS        |    |         | Prompts the operator to remove one of the short messages from the message store of the UE. Shall not attempt to send a RP-SMMA RPDU. This is verified by checking that the UE does not send a CHANNEL REQUEST message with the establishment cause "Other services which can be completed with an SDCCH" |
| 57                                                                                                                                             | UE        |    |         |                                                                                                                                                                                                                                                                                                          |
| NOTE: — Time values for SS wait time are chosen sufficiently high to be sure that the UE has enough time to respond to the different messages. |           |    |         |                                                                                                                                                                                                                                                                                                          |

### Specific Message Contents

#### SMS-DELIVER TPDU in step 7

| Information element | CommentValue                          |
|---------------------|---------------------------------------|
| TP-DCS              | default alphabet, class 2 "11110010"B |

#### SMS-DELIVER TPDU in step 21

|        |                                       |
|--------|---------------------------------------|
| TP-DCS | default alphabet, class 1 "11110001"B |
|--------|---------------------------------------|

#### SMS-DELIVER TPDU in step 35

|        |                              |
|--------|------------------------------|
| TP-DCS | default alphabet—"00000000"B |
|--------|------------------------------|

### 16.1.3.5 — Test requirements

After UE sends a negative acknowledgement (RP-ERROR) in step 11, the USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.

After UE sends a negative acknowledgement (RP-ERROR) in step 23, the USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.

After step 53 the ME shall unset the "memory capability exceeded" notification flag on the USIM.

After step 56 UE shall not attempt to send a RP-SMMA RPDU.

### 16.1.4 — Test of the status report capabilities and of SMS-COMMAND:

This test applies to UEs which support the status report capabilities.

#### 16.1.4.1 — Definition

#### 16.1.4.2 — Conformance requirement

The SMS offers the SC the capabilities of informing the UE of the status of a previously sent mobile originated short message. This is achieved by the SC returning a status report TPDU (SMS-STATUS-REPORT) to the originating UE.

SMS-COMMAND enables an UE to invoke an operation at the SC.

The UE shall increment TP-MR by 1 for each SMS-SUBMIT or SMS-COMMAND being submitted.

### References

— 3GPP TS 23.040 clause 3.2.9.

— 3GPP TS 23.040 clause 9.2.3.6.

#### ~~16.1.4.3 Test purpose~~

- ~~1) To verify that the UE is able to accept a SMS-STATUS-REPORT TPDU.~~
- ~~2) To verify that the UE is able to use the SMS-COMMAND functionality correctly and sends an SMS-COMMAND TPDU with the correct TP-Message-Reference.~~

#### ~~16.1.4.4 Method of test~~

##### ~~Initial conditions~~

- ~~— System Simulator:~~
  - ~~— 1 cell, default parameters.~~
- ~~— User Equipment:~~
  - ~~— the UE shall be in MM-state "Idle, updated".~~

##### ~~Related ICS/IXIT Statements~~

~~Support of SMS MO/PP and MT/PP.~~

##### ~~Test procedure~~

- ~~a) The UE is made to send a Mobile Originated short message setting TP-SRR as in steps a) to d) of test 16.1.2 (SMS Mobile originated).~~
- ~~b) The SS sends a CP-DATA message containing a RP-DATA RPDU itself containing an SMS-STATUS-REPORT TPDU.~~
- ~~c) The SS sends a RRC CONNECTION RELEASE message.~~
- ~~d) The UE is made to send an SMS-COMMAND message enquiring about the previously submitted short message.~~
- ~~e) void.~~
- ~~f) The SS acknowledges the CP-DATA message from the UE with a CP-ACK followed by a CP-DATA message containing an RP-ACK RPDU~~
- ~~g) After receiving the CP-ACK from the UE, the SS releases the RRC connection by using a RRC CONNECTION RELEASE message.~~
- ~~h) The UE is made to send an SMS-COMMAND message requiring to delete the previously submitted short message.~~
- ~~i) steps e) to g) are repeated.~~

## Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                  |
|------|-----------|----|--------------------------------------------------------------|-------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                           |
| 1    | ←         |    | SYSTEM INFORMATION                                           | BCCH                                                                                      |
| 2    | →         |    | RRC CONNECTION REQUEST                                       | CCCH                                                                                      |
| 3    | ←         |    | RRC CONNECTION SETUP                                         | CCCH                                                                                      |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE                                | DCCH                                                                                      |
| 5    | →         |    | CM SERVICE REQUEST                                           |                                                                                           |
| 6    | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                           |
| 7    | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                           |
| 8    | ←         |    | SECURITY MODE COMMAND                                        |                                                                                           |
| 9    | →         |    | SECURITY MODE COMPLETE                                       |                                                                                           |
| 10   | →         |    | CP DATA                                                      | Contains RP-DATA RPDU (SMS SUBMIT TPDU)                                                   |
| 11   | ←         |    | CP ACK                                                       | Sent within TC1M after step 10                                                            |
| 12   | ←         |    | CP DATA                                                      | Contains RP-ACK RPDU                                                                      |
| 13   | SS        |    |                                                              | Waits max 25 s for CP-ACK                                                                 |
| 14   | →         |    | CP ACK                                                       |                                                                                           |
| 15   | ←         |    | RRC CONNECTION RELEASE                                       | RRC connection is released.                                                               |
| 16   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                           |
| 17   |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108                                                                         |
| 18   | →         |    | PAGING RESPONSE                                              |                                                                                           |
| 19   | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                           |
| 20   | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                           |
| 21   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                           |
| 22   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                           |
| 23   | ←         |    | CP DATA                                                      | Contains RP-DATA RPDU (SMS STATUS-REPORT TPDU)                                            |
| 24   | →         |    | CP ACK                                                       |                                                                                           |
| 25   | →         |    | CP DATA                                                      | Contains RP-ACK RPDU                                                                      |
| 26   | ←         |    | CP ACK                                                       |                                                                                           |
| 27   | ←         |    | RRC CONNECTION RELEASE                                       | RRC connection is released.                                                               |
| 28   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                           |
| 29   | UE        |    |                                                              | The UE is made to send an SMS-COMMAND message enquiring about the previously submitted SM |
| 30   | ←         |    | SYSTEM INFORMATION                                           | BCCH                                                                                      |
| 31   | →         |    | RRC CONNECTION REQUEST                                       | CCCH                                                                                      |
| 32   | ←         |    | RRC CONNECTION SETUP                                         | CCCH                                                                                      |
| 33   | →         |    | RRC CONNECTION SETUP COMPLETE                                | DCCH                                                                                      |
| 34   | →         |    | CM SERVICE REQUEST                                           |                                                                                           |
| 35   | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                           |
| 36   | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                           |
| 37   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                           |
| 38   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                           |
| 39   | →         |    | CP DATA                                                      | Contains RP-DATA RPDU (SMS-COMMAND TPDU) which shall contain the correct TP-MR            |
| 40   | ←         |    | CP ACK                                                       |                                                                                           |
| 41   | ←         |    | CP DATA                                                      | Contains RP-ACK RPDU                                                                      |
| 42   | →         |    | CP ACK                                                       |                                                                                           |
| 43   | ←         |    | RRC CONNECTION RELEASE                                       | RRC connection is released.                                                               |
| 44   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                           |
| 45   | UE        |    | The UE is made to send an SMS-COMMAND                        | -message requiring to delete the previously submitted SM.                                 |
| 46   | →         |    | RRC CONNECTION REQUEST                                       | CCCH                                                                                      |
| 47   | ←         |    | RRC CONNECTION SETUP                                         | CCCH                                                                                      |
| 48   | →         |    | RRC CONNECTION SETUP COMPLETE                                | DCCH                                                                                      |
| 49   | →         |    | CM SERVICE REQUEST                                           |                                                                                           |
| 50   | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                           |



| Step | Direction |    | Message                         | Comments                                                                       |
|------|-----------|----|---------------------------------|--------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                |
| 51   | →         |    | AUTHENTICATION-RESPONSE         | Contains RP-DATA-RPDU (SMS-COMMAND-TPDU) which shall contain the correct TP-MR |
| 52   | ←         |    | SECURITY-MODE-COMMAND           |                                                                                |
| 53   | →         |    | SECURITY-MODE-COMplete          |                                                                                |
| 54   | →         |    | CP-DATA                         |                                                                                |
| 55   | ←         |    | CP-ACK                          |                                                                                |
| 56   | ←         |    | CP-DATA                         |                                                                                |
| 57   | →         |    | CP-ACK                          |                                                                                |
| 58   | ←         |    | RRC-CONNECTION-RELEASE          |                                                                                |
| 59   | →         |    | RRC-CONNECTION-RELEASE-COMplete |                                                                                |

### Specific Message Contents

#### SMS-SUBMIT-TPDU

| Information element | Comment Value                   |
|---------------------|---------------------------------|
| TP-SRR              | status report is requested—"1"B |

#### SMS-STATUS-REPORT-TPDU (SS to UE in step 23):

| Information element | Comment Value                                     |
|---------------------|---------------------------------------------------|
| TP-MR               | same as previous SMS-SUBMIT                       |
| TP-MMS              | no more messages—"1"B                             |
| TP-SRQ              | result of SMS-SUBMIT—"0"B                         |
| TP-RA               | same as the Destination address of the SMS-SUBMIT |
| TP-ST               | SM received—"00000000"B                           |

#### first SMS-COMMAND-TPDU (UE to SS in step 39)

| Information element | Comment Value                                                      |
|---------------------|--------------------------------------------------------------------|
| TP-MR               | TP-MR in previous SMS-SUBMIT plus "1"                              |
| TP-SRR              | status report requested—"1"B                                       |
| TP-CT               | Enquiry relating to previously submitted short message—"00000000"B |
| TP-MN               | not checked (TP-MR in previous SMS-SUBMIT)                         |

#### second SMS-COMMAND-TPDU (UE to SS in step 54)

| Information element | Comment Value                                         |
|---------------------|-------------------------------------------------------|
| TP-MR               | TP-MR in previous SMS-COMMAND plus "1"                |
| TP-CT               | Delete previously submitted short message—"00000010"B |
| TP-MN               | not checked (TP-MR in previous SMS-SUBMIT)            |

### 16.1.4.5 Test requirements

After step 23 UE accept a SMS-STATUS-REPORT-TPDU.

After step 38 UE shall send a SMS-COMMAND-TPDU with the correct TP-Message-Reference.

After step 53 UE shall send a SMS-COMMAND-TPDU with the correct TP-Message-Reference.

## ~~16.1.5 Test of message class 0 to 3~~

### ~~16.1.5.1 Short message class 0~~

#### ~~16.1.5.1.1 Definition~~

#### ~~16.1.5.1.2 Conformance requirement~~

~~When a mobile terminated message is class 0 and the UE has the capability of indicating short messages, the UE shall indicate the message immediately and send an acknowledgement to the SC when the message has successfully reached the UE irrespective of whether there is memory available in the USIM or ME. The message shall not be automatically stored in the USIM or ME.~~

#### ~~References~~

~~3GPP TS 23.038 clause 4.~~

#### ~~16.1.5.1.3 Test purpose~~

~~To verify that the UE will accept and indicate but not store a class 0 message, and that it will accept and indicate a class 0 message if its message store is full.~~

~~NOTE:—failure of this test in a UE could cause it to reject a class 0 message when its SMS memory becomes full. This could lead to unwanted repetitions between the UE and the service centre.~~

#### ~~16.1.5.1.4 Method of test~~

#### ~~Initial conditions~~

- ~~—System Simulator:~~
  - ~~— 1 cell, default parameters.~~
- ~~—User Equipment:~~
  - ~~— the UE shall be in MM-state "Idle, updated";~~
  - ~~— the UE message store shall be empty.~~

#### ~~Related ICS/IXIT Statements~~

~~Support for Short message MT/PP.~~

~~The value of timer TC1M.~~

~~Whether SMS messages are stored in the USIM and/or the ME.~~

#### ~~Test procedure~~

- ~~a) The SS sends a class 0 message by using the method described in step a) of clause 16.1.1 but with the TPDU described in this clause.~~
- ~~b) The UE message store shall be filled (for example by using the method of clause 16.1.3 test of the memory available notification) with the same SMS-DELIVER TPDU except that TP-DCS is set to class 1.~~
- ~~c) The SS sends a class 0 message as in step a).~~

## Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                                                                            |
|------|-----------|----|--------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                                                                     |
| 1    |           |    | Mobile terminated establishment of Radio-Resource-Connection | See 3GPP TS34.108                                                                                                                                                                                                   |
| 2    | →         |    | PAGING RESPONSE                                              |                                                                                                                                                                                                                     |
| 3    | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                                                                                                                                                     |
| 4    | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                                                                                                                                                     |
| 5    | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                                     |
| 6    | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                                                     |
| 7    | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-DELIVER TPDU), Class 0 Short Message                                                                                                                                                     |
| 8    | →         |    | CP-ACK                                                       |                                                                                                                                                                                                                     |
| 9    | →         |    | CP-DATA                                                      | Contains RP-ACK RPDU.                                                                                                                                                                                               |
| 10   | ←         |    | CP-ACK                                                       |                                                                                                                                                                                                                     |
| 11   | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                     |
| 12   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                     |
| 13   | UE        |    |                                                              | The content of the short message shall be indicated by the ME. The UE shall not store the message. This can be checked by verifying that it is impossible to retrieve any short messages from the UE message store. |
| 14   |           | SS |                                                              | The UE message-store shall be filled (for example by using the method of 16.1.3) with Class 1 SMS-DELIVER TPDU.                                                                                                     |
| 15   |           |    | Mobile terminated establishment of Radio-Resource-Connection | See 3GPP TS34.108                                                                                                                                                                                                   |
| 16   | →         |    | PAGING RESPONSE                                              |                                                                                                                                                                                                                     |
| 17   | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                                                                                                                                                     |
| 18   | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                                                                                                                                                     |
| 19   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                                     |
| 20   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                                                     |
| 21   | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-DELIVER TPDU), Class 0 Short Message                                                                                                                                                     |
| 22   | →         |    | CP-ACK                                                       |                                                                                                                                                                                                                     |
| 23   | →         |    | CP-DATA                                                      | Contains RP-ACK RPDU.                                                                                                                                                                                               |
| 24   | ←         |    | CP-ACK                                                       |                                                                                                                                                                                                                     |
| 25   | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                     |
| 26   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                     |
| 27   | UE        |    |                                                              | The content of the short message shall be indicated by the ME.                                                                                                                                                      |

## Specific Message Contents

## SMS-DELIVER TPDU (containing a class 0 message) (SS to UE)

| Information element | CommentValue                            |
|---------------------|-----------------------------------------|
| TP-DCS              | default alphabet, class 0 "1111 0000" B |

## SMS-DELIVER TPDU (containing a class 1 message to fill the UE message store) (SS to UE)

| Information element | CommentValue                            |
|---------------------|-----------------------------------------|
| TP-DCS              | default alphabet, class 1 "1111 0001" B |

## 16.1.5.1.5 Test requirements

After step 7 UE shall accept and indicate but not store a class 0 message.

After step 21 UE shall accept and indicate a class 0 message.

### ~~16.1.5.2 Test of class 1 short messages~~

~~This test shall apply to UEs which support:~~

- ~~— storing of received Class 1 Short Messages; and~~
- ~~— indicating of stored Short Messages.~~

#### ~~16.1.5.2.1 Definition~~

#### ~~16.1.5.2.2 Conformance requirement~~

~~When a mobile terminated message is class 1, the UE shall send an acknowledgement to the SC when the message has successfully reached the UE and can be stored, either in the ME or in the USIM.~~

#### ~~References~~

~~3GPP TS 23.038 clause 4.~~

#### ~~16.1.5.2.3 Test purpose~~

~~This procedure verifies that the UE acts correctly on receiving a class 1 message, i.e. that it stores the message in the ME or USIM and sends an acknowledgement (at RP and CP Layer).~~

#### ~~16.1.5.2.4 Method of test~~

##### ~~Initial conditions~~

- ~~— System Simulator:~~
  - ~~— 1 cell, default parameters.~~
- ~~— User Equipment:~~
  - ~~— the UE shall be in MM-state "Idle, updated";~~
  - ~~— the UE message store shall be empty;~~
  - ~~— for storing of class 1 Short Messages, the UE shall be set up to store Short Messages in the ME memory (by way of MMI, as described in ICS/IXIT statement).~~

##### ~~Related ICS/IXIT Statements~~

~~Support for Short message MT/PP.~~

~~The value of timer TC1M.~~

~~Whether SMS messages are stored in the USIM and/or the ME.~~

##### ~~Test procedure~~

- ~~a) The SS delivers a Short Message of class 1 to the UE as specified in clause 16.1.1, step a).~~
- ~~b) The Short Message is recalled (e.g. by means of the MMI).~~

## Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                        |
|------|-----------|----|--------------------------------------------------------------|-----------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                 |
| 1    |           |    | Mobile terminated establishment of Radio-Resource-Connection | See 3GPP TS34.108                                               |
| 2    | →         |    | PAGING RESPONSE                                              |                                                                 |
| 3    | ←         |    | AUTHENTICATION REQUEST                                       |                                                                 |
| 4    | →         |    | AUTHENTICATION RESPONSE                                      |                                                                 |
| 5    | ←         |    | SECURITY MODE COMMAND                                        |                                                                 |
| 6    | →         |    | SECURITY MODE COMPLETE                                       |                                                                 |
| 7    | ←         |    | CP-DATA                                                      | Contains RP-DATA-RPDU (SMS-DELIVER-TPDU), Class 1-Short Message |
| 8    | →         |    | CP-ACK                                                       |                                                                 |
| 9    | →         |    | CP-DATA                                                      | Contains RP-ACK-RPDU.                                           |
| 10   | ←         |    | CP-ACK                                                       |                                                                 |
| 11   | ←         |    | RRC-CONNECTION RELEASE                                       |                                                                 |
| 12   | →         |    | RRC-CONNECTION RELEASE COMPLETE                              |                                                                 |
| 13   | UE        |    |                                                              | The short message shall be recalled and indicated at the UE.    |

## Specific Message Contents

## SMS-DELIVER-TPDU (containing a class 1 message) (SS to UE)

| Information element | CommentValue                           |
|---------------------|----------------------------------------|
| TP-DCS              | default alphabet, class 1 "1111 0001"B |

## 16.1.5.2.5 Test requirements

After step 7 UE shall store the message in the ME or USIM and send an acknowledgement.

## 16.1.5.3 Test of class 2 short messages

## 16.1.5.3.1 Definition

Class 2 Short Messages are defined as USIM-specific, and the UE shall ensure that a message of this class is stored on the USIM.

## 16.1.5.3.2 Conformance requirement

When a mobile terminated message is Class 2, the UE shall ensure that the message has been correctly transferred to the SMS data field in the USIM before sending an acknowledgement to the SC. The UE shall return a "protocol error, unspecified" error message if the short message cannot be stored in the USIM and there is other short message storage available at the UE. If all the short message storage at the UE is already in use, the UE shall return "memory capacity exceeded".

## Reference(s)

3GPP TS 23.040 clause 9.2.3.10.

3GPP TS 23.038 clause 4.

3GPP TS 34.108 clause 8.3.2.28.

## 16.1.5.3.3 Test purpose

This procedure verifies that the UE acts correctly on receiving a class 2 message, i.e. that it stores the message correctly in the USIM, and if this is not possible, returns a protocol error message, with the correct error cause, to the network.

There are 2 cases:

- 1) if the UE supports storing of short messages in the USIM and in the ME, and storage in the ME is not full, and the short message cannot be stored in the USIM, the error cause shall be "protocol error, unspecified";
- 2) if the UE supports storing of short messages in the USIM and not in the ME, and storage in the ME is not full, and the short message cannot be stored in the USIM, the error cause shall be "memory capacity exceeded".

NOTE: If the UE supports storing of short messages in the USIM and the ME, and storage in the ME is full, and the short message cannot be stored in the USIM, the error cause shall be "memory capacity exceeded". This case is not tested in this test.

#### 16.1.5.3.4 Method of test

##### Initial conditions

— System Simulator:

— 1 cell, default parameters.

— User Equipment:

— the UE shall be in MM-state "Idle, updated";

— the ME message store shall be empty;

— the ME shall be connected to the USIM simulator. The following shall be present in the USIM simulator:

— EF<sub>SMS</sub> with at least two free records and one full record;

— EF<sub>SMSstatus</sub> with SMS "Memory Cap. Exceed" notification flag set to "memory available";

— Service no. 4 (SMS) in EF<sub>SS-T</sub> set to allocated and activated;

— for storing of Class 1 Short Messages the UE shall be set up to store Short Messages in the ME memory (by way of MMI, as described in ICS/IXIT statement).

##### Related ICS/IXIT Statements

Support for Short message MT/PP.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

##### Test procedure

- a) The SS delivers a Short Message of class 2 to the UE as specified in clause 16.1.1, step b).
- b) Following an attempt by the ME to store the short message in a free record of EF<sub>SMS</sub> in the USIM, the USIM simulator returns the status response "OK" ("90 00").
- c) Step a) is repeated.
- d) Following an attempt by the ME to store the short message in a free record of EF<sub>SMS</sub> in the USIM, the USIM simulator returns the status response "memory problem" ("92 40").
- e) The USIM simulator indicates if an attempt was made in steps a) and c) to store the messages and if the messages are stored according to the requirement.

## Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|------|-----------|----|--------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 1    |           | <  | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108<br><br>Contains RP-DATA RPDU (SMS-DELIVER TPDU), Class 2 Short Message                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 2    |           | →  | PAGING RESPONSE                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 3    |           | <  | AUTHENTICATION REQUEST                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 4    |           | →  | AUTHENTICATION RESPONSE                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 5    |           | <  | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 6    |           | →  | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 7    |           | <  | CP-DATA                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 8    |           | →  | CP-ACK                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 9    | ME        |    |                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 10   | USIM      |    |                                                              | The ME shall correctly store the short message in a free record of EFSMS in the USIM, i.e. —the ME shall use a free record — the first byte of the record shall indicate "message received by UE from network"<br>— the TS Service Centre Address shall be correctly stored<br><br>— the TPDU shall be identical to that sent by the SS<br><br>— bytes following the TPDU shall be set to "FF"                                                                                                                                            |
| 11   |           | →  | CP-DATA                                                      | The USIM simulator returns the status response "OK" ("90 00"). The USIM simulator shall indicate if an attempt was made by the ME to store the short message in the USIM.<br>Contains RP-ACK RPDU.                                                                                                                                                                                                                                                                                                                                        |
| 12   |           | <  | CP-ACK                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 13   |           | <  | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 14   |           | →  | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 15   |           |    | Mobile terminated establishment of Radio Resource Connection |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 16   |           | →  | PAGING RESPONSE                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 17   |           | <  | AUTHENTICATION REQUEST                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 18   |           | →  | AUTHENTICATION RESPONSE                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 19   |           | <  | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 20   |           | →  | SECURITY MODE COMPLETE                                       | Contains RP-DATA RPDU (SMS-DELIVER TPDU), Class 2 Short Message<br><br>The ME shall attempt to store the short message in a free record of EFSMS in the USIM.<br>The USIM simulator returns the status response "memory problem" ("92 40"). The USIM simulator shall indicate if an attempt was made by the ME to store the short message in the USIM.<br>Contains RP-ERROR RPDU with error cause "protocol error, unspecified" if the UE supports storing of short messages in the ME, or error cause "memory capacity exceeded" if not. |
| 21   |           | <  | CP-DATA                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 22   |           | →  | CP-ACK                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 23   | ME        |    |                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 24   | USIM      |    |                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 25   |           | →  | CP-DATA                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 26   |           | <  | CP-ACK                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 27   |           | <  | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 28   |           | →  | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |

## Specific Message Contents

## SMS-DELIVER TPDU (containing a class 2 message) (SS to UE)

| Information element | CommentValue                                  |
|---------------------|-----------------------------------------------|
| TP-DCS              | default alphabet, class 2 ————— "1111 0010" B |

#### ~~16.1.5.3.5 Test requirements~~

~~After step 10 UE shall confirm that the short message is stored in the USIM and send CP-DATA containing RP-ACK RPDU.~~

~~After step 24 UE shall confirm that the short message cannot be stored in the USIM and send CP-DATA containing RP-ERROR RPDU. If UE supports storing of short message in the ME, the error cause of RP-ERROR RPDU shall be "protocol error, unspecified", and if not the error cause of RP-ERROR RPDU shall be "memory capacity exceeded"~~

#### ~~16.1.5.4 Test of class 3 short messages~~

~~For further study.~~

#### ~~16.1.6 Test of short message type 0~~

~~For further study.~~

#### ~~16.1.7 Test of the replace mechanism for SM type 1-7~~

##### ~~16.1.7.1 Definition~~

##### ~~16.1.7.2 Conformance requirement~~

~~On receipt of a short message, the UE shall check to see if the associated Protocol Identifier contains a Replace Short Message Type code. If such a code is present, then the UE will check the associated originating address (TP-OA) and replace any existing stored message having the same Protocol Identifier code and originating address with the new short message.~~

##### ~~Reference(s)~~

~~3GPP TS 23.040 clause 9.2.3.9.~~

##### ~~16.1.7.3 Test purpose~~

~~This procedure verifies the correct implementation of the replace mechanism for Replace Short Messages.~~

##### ~~16.1.7.4 Method of test~~

##### ~~Initial conditions~~

- ~~— System Simulator:~~
  - ~~— 1 cell, default parameters.~~
- ~~— User Equipment:~~
  - ~~— the UE shall be in MM-state "Idle, updated";~~
  - ~~— the UE message store shall be empty.~~

##### ~~Related ICS/IXIT Statements~~

~~Support for Short message MT/PP.~~

~~The value of timer TC1M.~~



## Test procedure

- a) Two different numbers n and m are drawn randomly between 1 and 7. Two different addresses for TP-Originating-Address (TPOA1 and TPOA2) are drawn.
- b) The SS delivers a short message to the UE as specified in clause 16.1.1 step a). In the SMS-DELIVER TPDU, the TP-Protocol-Identifier parameter is "Replace Short Message Type n", the TP-Originating-Address is TPOA1, and the RP-Originating-Address is RPOA.
- c) Step b) is repeated but with a different TP-Originating-Address (TPOA2), and different contents of TP-User-Data in the SMS-DELIVER TPDU. The other parameters are the same as in step b).
- d) Void
- e) Step c) is repeated but with the TP-Protocol-Identifier equal to "Replace Short Message Type m", and contents of TP-User-Data different from the former two messages. The other parameters are the same as in step c).
- f) Step e) is repeated but the contents of TP-User-Data are different from that used in step e).
- g) The SS prompts the operator to indicate the Short Messages stored in the UE.

## Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                                                                         |
|------|-----------|----|--------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                  |
| 1    |           |    | Mobile terminated establishment of Radio-Resource-Connection | See 3GPP TS34.108                                                                                                                                |
| 2    |           | →  | PAGING-RESPONSE                                              |                                                                                                                                                  |
| 3    |           | ←  | AUTHENTICATION-REQUEST                                       |                                                                                                                                                  |
| 4    |           | →  | AUTHENTICATION-RESPONSE                                      |                                                                                                                                                  |
| 5    |           | ←  | SECURITY-MODE-COMMAND                                        |                                                                                                                                                  |
| 6    |           | →  | SECURITY-MODE-COMplete                                       |                                                                                                                                                  |
| 7    |           | ←  | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-DELIVER TPDU) TP-PID is "Replace Short Message Type n", TP-OA is TPOA1 and RP-OA is RPOA                              |
| 8    |           | →  | CP-ACK                                                       |                                                                                                                                                  |
| 9    |           | →  | CP-DATA                                                      | Contains RP-ACK RPDU.                                                                                                                            |
| 10   |           | ←  | CP-ACK                                                       |                                                                                                                                                  |
| 11   |           | ←  | RRC-CONNECTION-RELEASE                                       |                                                                                                                                                  |
| 12   |           | →  | RRC-CONNECTION-RELEASE COMPLETE                              |                                                                                                                                                  |
| 13   |           |    | Mobile terminated establishment of Radio-Resource-Connection | See 3GPP TS34.108                                                                                                                                |
| 14   |           | →  | PAGING-RESPONSE                                              |                                                                                                                                                  |
| 15   |           | ←  | AUTHENTICATION-REQUEST                                       |                                                                                                                                                  |
| 16   |           | →  | AUTHENTICATION-RESPONSE                                      |                                                                                                                                                  |
| 17   |           | ←  | SECURITY-MODE-COMMAND                                        |                                                                                                                                                  |
| 18   |           | →  | SECURITY-MODE-COMplete                                       |                                                                                                                                                  |
| 19   |           | ←  | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-DELIVER TPDU) TP-PID is "Replace Short Message Type n", TP-OA is TPOA2 and RP-OA is RPOA, TP-UD different from step 7 |
| 20   |           | →  | CP-ACK                                                       |                                                                                                                                                  |
| 21   |           | →  | CP-DATA                                                      | Contains RP-ACK RPDU.                                                                                                                            |
| 22   |           | ←  | CP-ACK                                                       |                                                                                                                                                  |
| 23   |           | ←  | RRC-CONNECTION-RELEASE                                       |                                                                                                                                                  |
| 24   |           | →  | RRC-CONNECTION-RELEASE COMPLETE                              |                                                                                                                                                  |
| 25   |           |    | (void)                                                       |                                                                                                                                                  |
| 26   |           |    | (void)                                                       |                                                                                                                                                  |
| 27   |           |    | (void)                                                       |                                                                                                                                                  |
| 28   |           |    | (void)                                                       |                                                                                                                                                  |
| 29   |           |    | (void)                                                       |                                                                                                                                                  |
| 30   |           |    | (void)                                                       |                                                                                                                                                  |
| 31   |           |    | (void)                                                       |                                                                                                                                                  |
| 32   |           |    | (void)                                                       |                                                                                                                                                  |
| 33   |           |    | (void)                                                       |                                                                                                                                                  |
| 34   |           |    | (void)                                                       |                                                                                                                                                  |

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                        |
|------|-----------|----|--------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                 |
| 35   |           |    | (void)                                                       |                                                                                                                                                                 |
| 36   |           |    | (void)                                                       |                                                                                                                                                                 |
| 37   |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108                                                                                                                                               |
| 38   | →         |    | PAGING RESPONSE                                              |                                                                                                                                                                 |
| 39   | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                                                                                                 |
| 40   | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                                                                                                 |
| 41   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                 |
| 42   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                 |
| 43   | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-DELIVER TPDU) TP-PID is "Replace Short Message Type m", TP-OA is TPOA2 and RP-OA is RPOA, TP-UD different from step 7 and 19         |
| 44   | →         |    | CP-ACK                                                       |                                                                                                                                                                 |
| 45   | →         |    | CP-DATA                                                      | Contains RP-ACK RPDU.                                                                                                                                           |
| 46   | ←         |    | CP-ACK                                                       |                                                                                                                                                                 |
| 47   | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                 |
| 48   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                 |
| 49   |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108                                                                                                                                               |
| 50   | →         |    | PAGING RESPONSE                                              |                                                                                                                                                                 |
| 51   | ←         |    | AUTHENTICATION REQUEST                                       |                                                                                                                                                                 |
| 52   | →         |    | AUTHENTICATION RESPONSE                                      |                                                                                                                                                                 |
| 53   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                 |
| 54   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                 |
| 55   | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-DELIVER TPDU) TP-PID is "Replace Short Message Type m", TP-OA is TPOA2 and RP-OA is RPOA, TP-UD different from step 43               |
| 56   | →         |    | CP-ACK                                                       |                                                                                                                                                                 |
| 57   | →         |    | CP-DATA                                                      | Contains RP-ACK RPDU.                                                                                                                                           |
| 58   | ←         |    | CP-ACK                                                       |                                                                                                                                                                 |
| 59   | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                 |
| 60   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                 |
| 61   |           | SS |                                                              | Prompts the operator to indicate the Short Messages stored in the UE. Only the Short Messages delivered in step 7, 19 and 55 shall be retrievable and indicated |

### Specific Message Contents

#### SMS-DELIVER TPDU

| Information element | CommentValue                                                            |
|---------------------|-------------------------------------------------------------------------|
| TP-MMS              | no more messages are waiting in SC "1" B                                |
| TP-PID              | binary 01000xxx, xxx represents n resp. m (see test method description) |

#### 16.1.7.5 Test requirements

After step 60 only the Short Messages delivered in step 7, 19 and 55 shall be retrieved and indicated.

### 16.1.8 Test of the reply path scheme

#### 16.1.8.1 Definition

#### 16.1.8.2 Conformance requirement

When a replying UE receives an original mobile terminated short message it has:

- originating SME = TP-Originating Address in the SMS-DELIVER TPDU;
- original SC = RP-Originating Address in the RP-MT-DATA.

When submitting the reply mobile originated short message, the replying UE should use parameters as follows:

- TP-Destination Address in SMS-SUBMIT TPDU = originating SME;
- RP-Destination Address in RP-MO-DATA = original SC.

#### Reference(s)

3GPP TS 23.040 Annex D.5, D.6

#### 16.1.8.3 ————— Test purpose

This procedure verifies that the UE is able to send a Reply Short Message back to the correct originating SME even if in the meantime it receives another Short Message.

#### 16.1.8.4 ————— Method of test

#### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in MM-state "Idle, updated";
  - the UE message store shall be empty.

#### Related ICS/IXIT Statements

Support for Short message MT/PP.

Support for Short message MO/PP.

The value of timer TC1M.

#### Test procedure

- a) The SS delivers a Short Message as specified in clause 16.1.1, step b) with TP-Reply-Path set to 1.
- b) Step a) is repeated but with:
  - different TP-Originating-Address for the originating SME;
  - different RP-Originating-Address for the original SC; and
  - different message contents TP-User-Data.
- c) UE sends the Reply Short Message corresponding to one of two received Short Messages (e.g. by means of the MMI).
- d) step c) is repeated for the other Short Message.

#### Expected sequence

| Step | Direction |     | Message                                                      | Comments          |
|------|-----------|-----|--------------------------------------------------------------|-------------------|
|      | UE        | SS  |                                                              |                   |
| 1    |           |     | Mobile-terminated establishment of Radio-Resource Connection | See 3GPP TS34.108 |
| 2    |           | --> | PAGING-RESPONSE                                              |                   |

| Step | Direction |    | Message                                                      | Comments                                                                                                                      |
|------|-----------|----|--------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                               |
| 3    | ←         |    | AUTHENTICATION-REQUEST                                       |                                                                                                                               |
| 4    | →         |    | AUTHENTICATION-RESPONSE                                      |                                                                                                                               |
| 5    | ←         |    | SECURITY-MODE-COMMAND                                        |                                                                                                                               |
| 6    | →         |    | SECURITY-MODE-COMplete                                       |                                                                                                                               |
| 7    | ←         |    | CP-DATA                                                      | Contains RP-DATA-RPDU (SMS-DELIVER-TPDU) TP-RP set to 1                                                                       |
| 8    | →         |    | CP-ACK                                                       | Sent within TC1M after step 7                                                                                                 |
| 9    | →         |    | CP-DATA                                                      | Contains RP-ACK-RPDU.                                                                                                         |
| 10   | ←         |    | CP-ACK                                                       |                                                                                                                               |
| 11   | ←         |    | RRC-CONNECTION-RELEASE                                       |                                                                                                                               |
| 12   | →         |    | RRC-CONNECTION-RELEASE COMPLETE                              |                                                                                                                               |
| 13   |           |    | Mobile-terminated-establishment of Radio-Resource-Connection | See 3GPP-TS34.108                                                                                                             |
| 14   | →         |    | PAGING-RESPONSE                                              |                                                                                                                               |
| 15   | ←         |    | AUTHENTICATION-REQUEST                                       |                                                                                                                               |
| 16   | →         |    | AUTHENTICATION-RESPONSE                                      |                                                                                                                               |
| 17   | ←         |    | SECURITY-MODE-COMMAND                                        |                                                                                                                               |
| 18   | →         |    | SECURITY-MODE-COMplete                                       |                                                                                                                               |
| 19   | ←         |    | CP-DATA                                                      | Contains RP-DATA-RPDU (SMS-DELIVER-TPDU) TP-OA, RP-OA and TP-UD different from step 7                                         |
| 20   | →         |    | CP-ACK                                                       | Sent within TC1M after step 7                                                                                                 |
| 21   | →         |    | CP-DATA                                                      | Contains RP-ACK-RPDU.                                                                                                         |
| 22   | ←         |    | CP-ACK                                                       |                                                                                                                               |
| 23   | ←         |    | RRC-CONNECTION-RELEASE                                       |                                                                                                                               |
| 24   | →         |    | RRC-CONNECTION-RELEASE COMPLETE                              |                                                                                                                               |
| 25   | UE        |    |                                                              | UE sends the Reply Short Message corresponding to one of two received Short Messages.                                         |
| 26   | ←         |    | SYSTEM-INFORMATION                                           | BCCH                                                                                                                          |
| 27   | →         |    | RRC-CONNECTION-REQUEST                                       | CCCH                                                                                                                          |
| 28   | ←         |    | RRC-CONNECTION-SETUP                                         | CCCH                                                                                                                          |
| 29   | →         |    | RRC-CONNECTION-SETUP COMPLETE                                | DCCH                                                                                                                          |
| 30   | →         |    | CM-SERVICE-REQUEST                                           |                                                                                                                               |
| 31   | ←         |    | AUTHENTICATION-REQUEST                                       |                                                                                                                               |
| 32   | →         |    | AUTHENTICATION-RESPONSE                                      |                                                                                                                               |
| 33   | ←         |    | SECURITY-MODE-COMMAND                                        |                                                                                                                               |
| 34   | →         |    | SECURITY-MODE-COMplete                                       |                                                                                                                               |
| 35   | →         |    | CP-DATA                                                      | Contains RP-DATA-RPDU (SMS-SUBMIT-TPDU) RP-DA = RP-OA corresponding to the message TP-DA = TP-OA corresponding to the message |
| 36   | ←         |    | CP-ACK                                                       | Sent within TC1M after step 35                                                                                                |
| 37   | ←         |    | CP-DATA                                                      | Contains RP-ACK-RPDU                                                                                                          |
| 38   | SS        |    |                                                              | Waits max 25 s for CP-ACK                                                                                                     |
| 39   | →         |    | CP-ACK                                                       |                                                                                                                               |
| 40   | ←         |    | RRC-CONNECTION-RELEASE                                       | RRC-connection is released.                                                                                                   |
| 40A  | →         |    | RRC-CONNECTION-RELEASE COMPLETE                              |                                                                                                                               |
| 41   | UE        |    |                                                              | UE sends the Reply Short Message corresponding to other Short Message.                                                        |
| 42   | ←         |    | SYSTEM-INFORMATION                                           | BCCH                                                                                                                          |
| 43   | →         |    | RRC-CONNECTION-REQUEST                                       | CCCH                                                                                                                          |
| 44   | ←         |    | RRC-CONNECTION-SETUP                                         | CCCH                                                                                                                          |
| 45   | →         |    | RRC-CONNECTION-SETUP COMPLETE                                | DCCH                                                                                                                          |
| 46   | →         |    | CM-SERVICE-REQUEST                                           |                                                                                                                               |
| 47   | ←         |    | AUTHENTICATION-REQUEST                                       |                                                                                                                               |
| 48   | →         |    | AUTHENTICATION-RESPONSE                                      |                                                                                                                               |
| 49   | ←         |    | SECURITY-MODE-COMMAND                                        |                                                                                                                               |
| 50   | →         |    | SECURITY-MODE-COMplete                                       |                                                                                                                               |
| 51   | →         |    | CP-DATA                                                      | Contains RP-DATA-RPDU (SMS-SUBMIT-TPDU) RP-DA = RP-OA corresponding to the Message TP-DA = TP-OA corresponding to the message |

| Step | Direction |    | Message                         | Comments                                                                            |
|------|-----------|----|---------------------------------|-------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                     |
| 52   | <--       |    | CP-ACK                          | Sent within TC1M after step 51<br>Contains RP-ACK RPDU<br>Waits max 25 s for CP-ACK |
| 53   | <--       |    | CP-DATA                         |                                                                                     |
| 54   | SS        |    |                                 |                                                                                     |
| 55   | -->       |    | CP-ACK                          |                                                                                     |
| 56   | <--       |    | RRC CONNECTION RELEASE          | RRC connection is released.                                                         |
| 57   | -->       |    | RRC CONNECTION RELEASE COMPLETE |                                                                                     |

## Specific Message Contents

### SMS-DELIVER TPDU

| Information element | CommentValue                            |
|---------------------|-----------------------------------------|
| TP-MMS              | no more messages are waiting in SC "1"B |
| TP-RP               | Reply Path exists "1"B                  |

#### 16.1.8.5 Test requirements

After step 34 UE shall send the Reply Short Message corresponding to one of two previously received short messages.

After step 50 UE shall send the Reply Short Message corresponding to the other of two previously received short messages.

## 16.1.9 Multiple SMS mobile originated

### 16.1.9.1 UE in idle mode

This test applies to UE supporting the ability of sending multiple short messages on the same RRC connection when there is no call in progress.

#### 16.1.9.1.1 Definition

#### 16.1.9.1.2 Conformance requirements

When the UE chooses to use the same RRC connection to send another short message or a memory available notification, then:

- the UE shall transmit a CM SERVICE REQUEST for the new CM connection before the final CP-ACK (e.g. the one that acknowledges the CP-DATA that carried the RP-ACK) for the old MM connection is transmitted;
- before transmission of the first CP-DATA on the new MM connection, the UE shall transmit the CP-ACK for the old MM connection;
- the Transaction Identifier used on the new MM connection shall be different to that used on the old MM connection; and
- the UE shall not initiate establishment of the new MM connection before the final CP-DATA (e.g. the one carrying the RP-ACK) has been received.

## Reference

- 3GPP TS 23.040 clause 3.1.
- 3GPP TS 24.011 clause 5.4.

### ~~16.1.9.1.3 Test purpose~~

~~To verify that the UE is able to correctly send multiple short messages on the same RRC connection when using a DCCH.~~

### ~~16.1.9.1.4 Method of test~~

#### ~~Initial conditions~~

- ~~— System simulator:~~
  - ~~— 1 cell, default parameters.~~
- ~~— User Equipment:~~
  - ~~— the UE shall be in MM-state "Idle, updated";~~
  - ~~— the SMS message storage shall be empty.~~

#### ~~Related ICS/IXIT statements~~

~~Support for multiple short message MO/PP on the same RRC connection.~~

~~Description of how to enter multiple SMS.~~

~~Whether SMS messages are stored in the USIM and/or the ME.~~

#### ~~Foreseen final state of UE~~

~~Idle, updated.~~

#### ~~Test procedure~~

- ~~a) The UE shall be set up to send 3 short messages as multiple SM to the SS. The SS answers correctly to RRC CONNECTION REQUEST on CCCH and then performs the authentication.~~
- ~~b) After receiving SECURITY MODE COMMAND UE shall send SECURITY COMMAND COMPLETE.~~
- ~~c) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message followed by a CP-DATA message containing the correct RP-ACK RPDU. The Transaction Identifier used on this MM connection is 'x'.~~
- ~~d) The UE shall transmit a CM SERVICE REQUEST for the new CM connection (for the second short message) before the final CP-ACK (the one that acknowledges the CP-DATA that carried the RP-ACK before) for the old MM connection is transmitted. The UE shall not initiate establishment of the new MM connection before the final CP-DATA (i.e. the one carrying the RP-ACK for the first short message) has been received. Before transmission of the first CP-DATA on the new MM connection, the UE shall transmit the CP-ACK for the old MM connection. The Transaction Identifier used on the new MM connection shall be y, where y <-> x (see procedure c)).~~
- ~~e) The SS waits a maximum of 5 s after receiving the CM SERVICE REQUEST for the CP-ACK message from the UE.~~
- ~~f) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message followed by a CP-DATA message containing the correct RP-ACK RPDU.~~

- g) The UE shall transmit a CM SERVICE REQUEST for the new CM connection (for the third short message) before the final CP-ACK (the one that acknowledges the CP-DATA that carried the RP-ACK before) for the old MM connection is transmitted. Before transmission of the first CP-DATA on the new MM connection, the UE shall transmit the CP-ACK for the old MM connection. The Transaction Identifier used on the new MM connection shall be z, where  $z < y$  (see procedure d)). The UE shall not initiate establishment of the new MM connection before the final CP-DATA (i.e. the one carrying the RP-ACK for the second short message) has been received.
- h) The SS waits a maximum of 5 s after receiving the CM SERVICE REQUEST for the CP-ACK message from the UE.
- i) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message followed by a CP-DATA message containing the correct RP-ACK RPDU.
- j) The SS waits a maximum of 5 s after sending CP-DATA for the CP-ACK message from the UE.
- k) The SS sends a RRC CONNECTION RELEASE to the UE.

#### Expected sequence

| Step | Direction |    | Message                         | Comments                                                                                                                                     |
|------|-----------|----|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                              |
| 1    | ←         |    | SYSTEM INFORMATION              | BCCH                                                                                                                                         |
| 2    | →         |    | RRC CONNECTION REQUEST          | CCCH                                                                                                                                         |
| 3    | ←         |    | RRC CONNECTION SETUP            | CCCH                                                                                                                                         |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE   | DCCH                                                                                                                                         |
| 5    | →         |    | CM SERVICE REQUEST              |                                                                                                                                              |
| 6    | ←         |    | AUTHENTICATION REQUEST          |                                                                                                                                              |
| 7    | →         |    | AUTHENTICATION RESPONSE         |                                                                                                                                              |
| 8    | ←         |    | SECURITY MODE COMMAND           |                                                                                                                                              |
| 9    | →         |    | SECURITY MODE COMPLETE          |                                                                                                                                              |
| 10   | →         |    | CP-DATA                         | Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 10, 11, 12 and 14 shall be x.                              |
| 11   | ←         |    | CP-ACK                          |                                                                                                                                              |
| 12   | ←         |    | CP-DATA                         | Contains RP-ACK RPDU                                                                                                                         |
| 13   | →         |    | CM SERVICE REQUEST              | CM service type set to "Short message transfer".                                                                                             |
| 14   | →         |    | CP-ACK                          | Shall be sent within 5 s of step 13                                                                                                          |
| 15   | ←         |    | CM SERVICE ACCEPT               |                                                                                                                                              |
| 16   | →         |    | CP-DATA                         | Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 16, 17, 18 and 20 shall be y where $y < x$ (see step 10).  |
| 17   | ←         |    | CP-ACK                          |                                                                                                                                              |
| 18   | ←         |    | CP-DATA                         | Contains RP-ACK RPDU                                                                                                                         |
| 19   | →         |    | CM SERVICE REQUEST              | CM service type set to "Short message transfer".                                                                                             |
| 20   | →         |    | CP-ACK                          | Shall be sent within 5 s of step 19                                                                                                          |
| 21   | ←         |    | CM SERVICE ACCEPT               |                                                                                                                                              |
| 22   | →         |    | CP-DATA                         | Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 22, 23, 24 and 25 shall be z, where $z < y$ (see step 16). |
| 23   | ←         |    | CP-ACK                          |                                                                                                                                              |
| 24   | ←         |    | CP-DATA                         | Contains RP-ACK RPDU                                                                                                                         |
| 25   | →         |    | CP-ACK                          | Shall be sent within 5 s of step 24                                                                                                          |
| 26   | ←         |    | RRC CONNECTION RELEASE          | RRC connection is released.                                                                                                                  |
| 27   | →         |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                              |

#### 16.1.9.1.5 Test requirements

In step 13 the UE shall transmit a CM SERVICE REQUEST for the new CM connection (for the second short message) before the final CP-ACK for the old MM connection is transmitted.

In step 19 the UE shall transmit a CM SERVICE REQUEST for the new CM connection (for the third short message) before the final CP-ACK for the old MM connection is transmitted.

#### ~~16.1.9.2 UE in active mode~~

This test applies to UE supporting the ability of sending concatenated multiple short messages when there is a call in progress.

##### ~~16.1.9.2.1 Definition~~

##### ~~16.1.9.2.2 Conformance requirements~~

When the UE chooses to use the same RRC connection to send another short message or a memory available notification, then:

- the UE shall transmit a CM SERVICE REQUEST for the new CM connection before the final CP-ACK (e.g. the one that acknowledges the CP-DATA that carried the RP-ACK) for the old MM connection is transmitted;
- before transmission of the first CP-DATA on the new MM connection, the UE shall transmit the CP-ACK for the old MM connection;
- the Transaction Identifier used on the new MM connection shall be different to that used on the old MM connection; and
- the UE shall not initiate establishment of the new MM connection before the final CP-DATA (e.g. the one carrying the RP-ACK) has been received.

#### Reference

- 3GPP TS 23.040 clause 3.1.
- 3GPP TS 24.011 clause 5.4.

##### ~~16.1.9.2.3 Test purpose~~

To verify that the UE is able to correctly concatenate multiple short messages on the same RRC connection when sent parallel to a call.

##### ~~16.1.9.2.4 Method of test~~

#### ~~Initial conditions~~

- System simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in MM-state "Idle, updated";
  - the SMS message storage shall be empty.

#### Related ICS/IXIT statements

Support for multiple short message MO/PP on the same RRC connection.

Description of how to enter multiple SMS.

Support for state U10 of call control.

Whether SMS messages are stored in the USIM and/or the ME.



## Foreseen final state of UE

Idle, updated.

## Test procedure

- a) A data or speech call is established on a DTCH with the SS and the state U10 of call control is entered. The UE is set up to send 3 short messages as multiple SM to the SS. After the reception of the CM SERVICE REQUEST, the SS sends a CM SERVICE ACCEPT message.
- b) Steps c) to k) of the test procedure in clause 16.1.9.1.4 are repeated.

## Expected sequence

| Step | Direction |    | Message                                   | Comments                                                                                                                                        |
|------|-----------|----|-------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                                 |
| 1    |           | SS |                                           | A data or speech call is established on a DTCH and the state U10 of call control is entered.                                                    |
| 2    | UE        |    |                                           | The UE is set up to send 3 short messages as multiple SM                                                                                        |
| 3    | →         |    | CM SERVICE REQUEST                        | Sent in a layer 2 frame on the DCCH. CM service type set to "short message transfer"                                                            |
| 4    | ←         |    | CM SERVICE ACCEPT                         |                                                                                                                                                 |
| 7    | →         |    | CP-DATA                                   | Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 7, 8, 9 and 11 shall be x.                                    |
| 8    | ←         |    | CP-ACK                                    |                                                                                                                                                 |
| 9    | ←         |    | CP-DATA                                   | Contains RP-ACK RPDU                                                                                                                            |
| 10   | →         |    | CM SERVICE REQUEST                        | Sent in a layer 2 frame on the DCCH. CM service type set to "short message transfer"                                                            |
| 11   | →         |    | CP-ACK                                    | Shall be sent within 5 s of step 10                                                                                                             |
| 12   | ←         |    | CM SERVICE ACCEPT                         |                                                                                                                                                 |
| 13   | →         |    | CP-DATA                                   | Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 13, 14, 15 and 17 shall be y where $y \neq x$ (see step 7).   |
| 14   | ←         |    | CP-ACK                                    |                                                                                                                                                 |
| 15   | ←         |    | CP-DATA                                   | Contains RP-ACK RPDU                                                                                                                            |
| 16   | →         |    | CM SERVICE REQUEST                        | Sent in a layer 2 frame on the DCCH. CM service type set to "short message transfer"                                                            |
| 17   | →         |    | CP-ACK                                    | Shall be sent within 5 s of step 16                                                                                                             |
| 18   | ←         |    | CM SERVICE ACCEPT                         |                                                                                                                                                 |
| 19   | →         |    | CP-DATA                                   | Contains RP-DATA RPDU (SMS SUBMIT TPDU). The Transaction Identifier used in steps 19, 20, 21 and 22 shall be z, where $z \neq y$ (see step 13). |
| 20   | ←         |    | CP-ACK                                    |                                                                                                                                                 |
| 21   | ←         |    | CP-DATA                                   | Contains RP-ACK RPDU                                                                                                                            |
| 22   | →         |    | CP-ACK                                    | Shall be sent within 5 s of step 21                                                                                                             |
| 23   | ←         |    | <del>RR</del> CONNECTION RELEASE          | <del>RR</del> connection is released.                                                                                                           |
| 24   | →         |    | <del>RR</del> CONNECTION RELEASE COMPLETE |                                                                                                                                                 |

## 16.1.9.2.5 Test requirements

In step 10 the UE shall transmit a CM SERVICE REQUEST for the new CM connection (for the second short message) before the final CP-ACK for the old MM connection is transmitted.

In step 16 the UE shall transmit a CM SERVICE REQUEST for the new CM connection (for the third short message) before the final CP-ACK for the old MM connection is transmitted.

## ~~16.1.10 Test of capabilities of simultaneously receiving a short message whilst sending a mobile originated short message~~

### ~~16.1.10.1 Definition~~

### ~~16.1.10.2 Conformance requirements~~

~~An active UE shall be able to receive short message TPDU (SMS-SUBMIT) at any time, independently of whether or not there is in SMS mobile originated.~~

### ~~Reference~~

~~3GPP TS 23.040 clause 3.1.~~

### ~~16.1.10.3 Test purpose~~

~~The test verifies that the UE is capable of simultaneously receiving a network originated SM whilst sending a mobile originated SM.~~

### ~~16.1.10.4 Method of test~~

#### ~~Initial Conditions~~

- ~~— System simulator:~~
  - ~~— 1 cell, default parameters.~~
- ~~— User Equipment:~~
  - ~~— the UE shall be in MM-state "Idle, updated";~~
  - ~~— the SMS message storage shall be empty.~~

#### ~~Related ICS/EXIT Statements~~

~~Support for Short message MO/PP and MT/PP.~~

~~Support for state U10 of call control.~~

~~The value of timer TC1M.~~

~~Whether SMS messages are stored in the USIM and/or the ME.~~

~~Maximum length (characters) of a mobile originated short message.~~

#### ~~Test procedure~~

- ~~a) The SS is configured to receive a mobile originated SM. In clause 16.1.2 steps a) and b) are repeated and, using the end of the CP-DATA message from the UE as a trigger, the SS sends a SM to the UE. In this case a new transaction identifier shall be used in the CP messages of SMS mobile terminated.~~

Expected sequence

| Step                                                                                                                                            | Direction |     | Message                       | Comments                                                                                                                                                                                                                                                                                                                                                                            |
|-------------------------------------------------------------------------------------------------------------------------------------------------|-----------|-----|-------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                 | UE        | SS  |                               |                                                                                                                                                                                                                                                                                                                                                                                     |
| 1                                                                                                                                               |           | <-- | SYSTEM INFORMATION            | BCCH                                                                                                                                                                                                                                                                                                                                                                                |
| 2                                                                                                                                               |           | --> | RRC CONNECTION REQUEST        | CCCH                                                                                                                                                                                                                                                                                                                                                                                |
| 3                                                                                                                                               |           | <-- | RRC CONNECTION SETUP          | CCCH                                                                                                                                                                                                                                                                                                                                                                                |
| 4                                                                                                                                               |           | --> | RRC CONNECTION SETUP COMPLETE | DCCH                                                                                                                                                                                                                                                                                                                                                                                |
| 5                                                                                                                                               |           | --> | CM SERVICE REQUEST            |                                                                                                                                                                                                                                                                                                                                                                                     |
| 6                                                                                                                                               |           | <-- | AUTHENTICATION REQUEST        |                                                                                                                                                                                                                                                                                                                                                                                     |
| 7                                                                                                                                               |           | --> | AUTHENTICATION RESPONSE       |                                                                                                                                                                                                                                                                                                                                                                                     |
| 8                                                                                                                                               |           | <-- | SECURITY MODE COMMAND         |                                                                                                                                                                                                                                                                                                                                                                                     |
| 9                                                                                                                                               |           | --> | SECURITY MODE COMPLETE        |                                                                                                                                                                                                                                                                                                                                                                                     |
| 10                                                                                                                                              |           | --> | CP-DATA                       | Contains RP-DATA RPDU (SMS SUBMIT TPDU)                                                                                                                                                                                                                                                                                                                                             |
| 11                                                                                                                                              |           | SS  |                               | The SS sends an SM to the UE triggered by the end of the CP-DATA message from the UE                                                                                                                                                                                                                                                                                                |
| 12                                                                                                                                              |           | <-- | CP-DATA                       | Contains RP-DATA RPDU (SMS DELIVER TPDU)                                                                                                                                                                                                                                                                                                                                            |
| 13                                                                                                                                              |           | UE  |                               | The UE shall correctly receive the SM and indicate that a message has arrived. In the MO case the UE shall send the CP-ACK message with transaction identifier assigned to this transfer. In the MT case the UE shall send a CP-ACK message and a CP-DATA message containing the RP-ACK RPDU. The transaction identifier shall be the same as chosen by the SS for the MT transfer. |
| NOTE: — Time values for SS wait times are chosen sufficiently high to be sure that the UE has enough time to respond to the different messages. |           |     |                               |                                                                                                                                                                                                                                                                                                                                                                                     |

Specific Message Contents

SMS SUBMIT TPDU

| Information element              | CommentValue                                                                                                  |
|----------------------------------|---------------------------------------------------------------------------------------------------------------|
| TP-UDL<br>TP-UD (140 octets max) | as applicable<br>maximum number of characters (text of message) as defined by the manufacturer (see ICS/IXIT) |

16.1.10.5 — Test requirements

After step 12 UE shall correctly receive the SM and indicate that a message has arrived.

16.2 — Short message service point to point on PS mode

All of test cases in this clause are applied to the UE supported PS mode.

16.2.1 — SMS mobile terminated

16.2.1.1 — Definition

16.2.1.2 — Conformance requirements

An active UE shall be able to receive short message TPDU (SMS-DELIVER) at any time, independently of whether or not there is a PDP context in progress. A report will always be returned to the SC, confirming that the UE has received the short message.

Reference

3GPP TS 23.040 clause 3.1.

### ~~16.2.1.3 Test purpose~~

~~To verify the ability of a UE to receive and decode the SMS where provided for the point to point service.~~

### ~~16.2.1.4 Method of test~~

#### ~~Initial Conditions~~

- ~~— System simulator:~~
  - ~~— 1 cell, default parameters.~~
- ~~— User Equipment:~~
  - ~~— the UE shall be in GMM-state "GMM-REGISTERED";~~
  - ~~— the SMS message storage shall be empty.~~

#### ~~Related ICS/IXIT Statements~~

~~Support for Short message MT/PP.~~

~~The value of timer TC1M.~~

~~Whether SMS messages are stored in the USIM and/or the ME.~~

~~Support for session management state "PDP-ACTIVE".~~

#### ~~Test procedure~~

- ~~a) Mobile terminates establishment of Radio Resource Connection. After the completion of RRC Connection the SS authenticates the UE and activates ciphering.~~
  - ~~— After the SS receives SECURITY MODE COMPLETE, the SS sends a CP-DATA message. The information element of the CP-DATA message will be RP-DATA RPDU (SMS DELIVER TPDU).~~
- ~~b) The SS waits a maximum of 25 s for the CP-ACK message and then a maximum of 60 s for the CP-DATA message containing the RP-ACK RPDU.~~
- ~~c) The SS sends a CP-ACK to the UE within TC1M with no further CP-DATA messages and the SS initiates channel release.~~
- ~~d) Steps a), b) and c) are repeated but the first CP-DATA message from the UE is not acknowledged. The second CP-DATA message from the UE is acknowledged by a CP-ACK within a time TC1M.~~
- ~~e) Steps a) and b) are repeated. The SS is configured not to send CP-ACK. Then maximum 3 CP-DATA retransmissions may occur. After a duration of TC1M + 5 s after the last CP-DATA retransmission the SS then initiates the channel release. The 5 s is the appropriate time to wait to verify that the UE does not send more than the maximum allowed (3) CP-DATA retransmissions.~~
- ~~f) The SMS message store shall be cleared manually by the operator.~~
- ~~g) A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered.~~
  - ~~— The SS sends a CP-DATA message. The information element of the CP-DATA message will be RP-DATA RPDU (SMS DELIVER TPDU). The SS waits a maximum of 25 s for the CP-ACK message and then a maximum of 60 s for the CP-DATA message containing the RP-ACK RPDU.~~
- ~~h) The SS sends a CP-ACK to the UE within TC1M with no further CP-DATA messages and the SS initiates channel release. The SMS message store shall be cleared manually by the operator.~~
- ~~i) Steps g) and h) are repeated but the first CP-DATA message from the UE is not acknowledged. The second CP-DATA message from the UE is acknowledged by a CP-ACK within a time TC1M.~~

- j) ~~Step g) is repeated. The SS is configured not to send CP-ACK. Then maximum 3 CP-DATA retransmissions may occur. After a duration of TC1M + 15 s after the last CP-DATA retransmission the SS initiates the channel release. The 15 s is the appropriate time to wait to verify that the UE does not send more than the maximum allowed (3) CP-DATA retransmissions (during PDP context in progress).~~
- k) ~~A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered. The PDP context is cleared by the SS with a disconnect message. (The PDP context deactivating is continued in parallel to the following exchange of messages related to SMS).~~
- ~~— The SS sends a CP-DATA RPDU (SMS DELIVER TPDU) message. The information element of the CP-DATA message is RP-DATA.~~
- ~~— The SS waits a maximum of 25 s for the CP-ACK message and then a maximum of 60 s for the CP-DATA message containing the RP-ACK RPDU.~~
- ~~— The SS sends a CP-ACK to the UE within TC1M with no further CP-DATA messages and the SS initiates channel release.~~
- ~~— The SMS message store shall be cleared manually by the operator.~~
- l) ~~A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered. The PDP context shall be cleared from the UE. (The PDP context deactivating is continued in parallel to the following exchange of messages related to SMS).~~
- ~~— The SS sends a CP-DATA message. The information element of the CP-DATA message is RP-DATA RPDU (SMS DELIVER TPDU).~~
- ~~— The SS waits a maximum of 25 s for the CP-ACK message and then a maximum of 60 s for the CP-DATA message containing the RP-ACK RPDU.~~
- ~~— The SS sends a CP-ACK to the UE within TC1M with no further CP-DATA messages and the SS initiates channel release.~~
- ~~— The SMS message store shall be cleared manually by the operator.~~

## Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                     |
|------|-----------|----|--------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                              |
| 1    |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108                                                                                                                                            |
| 2    | →         |    | SERVICE REQUEST                                              |                                                                                                                                                              |
| 3    | ←         |    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                                                                                                              |
| 4    | →         |    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                                                                                                                              |
| 5    | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                              |
| 6    | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                              |
| 7    | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-DELIVER TPDU)                                                                                                                     |
| 8    | SS        |    |                                                              | Waits max 25 s for CP-ACK                                                                                                                                    |
| 9    | →         |    | CP-ACK                                                       |                                                                                                                                                              |
| 10   | SS        |    |                                                              | Waits max 60 s for RP-ACK RPDU                                                                                                                               |
| 11   | →         |    | CP-DATA                                                      | Contains RP-ACK RPDU                                                                                                                                         |
| 12   | ←         |    | CP-ACK                                                       |                                                                                                                                                              |
| 13   | UE        |    |                                                              | There should be no further CP-DATA messages until the UE aborts the RRC connection (disconnection of layer 2). The UE shall indicate that an SM has arrived. |
| 14   | UE        |    |                                                              |                                                                                                                                                              |
| 15   |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108                                                                                                                                            |
| 16   | →         |    | SERVICE REQUEST                                              |                                                                                                                                                              |
| 17   | ←         |    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                                                                                                              |
| 18   | →         |    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                                                                                                                              |
| 19   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                              |
| 20   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                              |
| 21   | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-DELIVER TPDU)                                                                                                                     |
| 22   | SS        |    |                                                              | Waits max 25 s for CP-ACK                                                                                                                                    |
| 23   | →         |    | CP-ACK                                                       |                                                                                                                                                              |
| 24   | SS        |    |                                                              | Waits max 60 s for RP-ACK RPDU                                                                                                                               |
| 25   | →         |    | CP-DATA                                                      | First CP-DATA from UE, contains RP-ACK RPDU                                                                                                                  |
| 26   | SS        |    |                                                              | First CP-DATA message not acknowledged by SS                                                                                                                 |
| 27   | →         |    | CP-DATA                                                      | Retransmitted CP-DATA from UE within twice TC1M, after step 25, contains RP-ACK RPDU                                                                         |
| 28   | ←         |    | CP-ACK                                                       | Second CP-DATA message is acknowledged                                                                                                                       |
| 29   | UE        |    |                                                              | There should be no further CP-DATA messages until the UE aborts the RRC connection                                                                           |
| 30   | UE        |    |                                                              | The UE shall indicate that an SM has arrived.                                                                                                                |
| 31   |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108                                                                                                                                            |
| 32   | →         |    | SERVICE REQUEST                                              |                                                                                                                                                              |
| 33   | ←         |    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                                                                                                              |
| 34   | →         |    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                                                                                                                              |
| 35   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                              |
| 36   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                              |
| 37   | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-DELIVER TPDU)                                                                                                                     |
| 38   | SS        |    |                                                              | Waits max 25 s for CP-ACK                                                                                                                                    |
| 39   | →         |    | CP-ACK                                                       |                                                                                                                                                              |
| 40   | SS        |    |                                                              | Waits max 60 s for RP-ACK RPDU                                                                                                                               |
| 41   | →         |    | CP-DATA                                                      | Contains RP-ACK RPDU                                                                                                                                         |
| 42   | SS        |    |                                                              | First CP-DATA message not acknowledged by SS                                                                                                                 |
| 43   |           |    | CP-DATA                                                      | Retransmitted CP-DATA from UE within twice TC1M after step 41, contains RP-ACK RPDU                                                                          |
| 44   | SS        |    |                                                              | Retransmitted CP-DATA message not acknowledged by SS                                                                                                         |
| 45   | UE        |    |                                                              | Depending upon the maximum number of CP-DATA retransmissions implemented, step 43 and 44 may be repeated.                                                    |
| 46   | ←         |    | RRC CONNECTION RELEASE                                       | RRC connection is released after a duration of TC1M + 5 s after the last CP-DATA retransmission.                                                             |

| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                     |
|------|-----------|----|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                                                              |
| 47   | -->       |    | RRC CONNECTION RELEASE COMPLETE | The UE shall indicate that an SM has arrived.<br>A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered.                                                                                                                         |
| 48   | UE        |    |                                 |                                                                                                                                                                                                                                                                              |
| 49   | SS        |    |                                 |                                                                                                                                                                                                                                                                              |
| 50   | (void)    |    |                                 | Contains RP-DATA RPDU (SMS DELIVER TPDU)<br>Waits max 25 s for CP-ACK                                                                                                                                                                                                        |
| 51   | <--       |    | CP-DATA                         |                                                                                                                                                                                                                                                                              |
| 52   | SS        |    |                                 |                                                                                                                                                                                                                                                                              |
| 53   | -->       |    | CP-ACK                          | Waits max 60 s for RP-ACK RPDU<br>Contains RP-ACK RPDU                                                                                                                                                                                                                       |
| 54   | SS        |    |                                 |                                                                                                                                                                                                                                                                              |
| 55   | -->       |    | CP-DATA                         |                                                                                                                                                                                                                                                                              |
| 56   | <--       |    | CP-ACK                          | Deactivates an existing PDP context.                                                                                                                                                                                                                                         |
| 57   | <--       |    | DEACTIVATE PDP CONTEXT REQUEST  |                                                                                                                                                                                                                                                                              |
| 58   | -->       |    | DEACTIVATE PDP CONTEXT ACCEPT   |                                                                                                                                                                                                                                                                              |
| 59   | UE        |    |                                 | The UE shall indicate that an SM has arrived.<br>Clear the SMS message store<br>A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered.                                                                                          |
| 60   | UE        |    |                                 |                                                                                                                                                                                                                                                                              |
| 61   | SS        |    |                                 |                                                                                                                                                                                                                                                                              |
| 62   | (void)    |    |                                 | Contains RP-DATA RPDU (SMS DELIVER TPDU)<br>Waits max 25 s for CP-ACK                                                                                                                                                                                                        |
| 63   | <--       |    | CP-DATA                         |                                                                                                                                                                                                                                                                              |
| 64   | SS        |    |                                 |                                                                                                                                                                                                                                                                              |
| 65   | -->       |    | CP-ACK                          | Waits max 60 s for RP-ACK RPDU<br>First CP-DATA from UE, contains RP-ACK RPDU<br>First CP-DATA message not acknowledged by SS                                                                                                                                                |
| 66   | SS        |    |                                 |                                                                                                                                                                                                                                                                              |
| 67   | -->       |    | CP-DATA                         |                                                                                                                                                                                                                                                                              |
| 68   | SS        |    |                                 | Retransmitted CP-DATA message within twice TC1M after step 67, contains RP-ACK RPDU<br>Second CP-DATA message is acknowledged<br>Deactivates an existing PDP context.                                                                                                        |
| 69   | -->       |    | CP-DATA                         |                                                                                                                                                                                                                                                                              |
| 70   | <--       |    | CP-ACK                          |                                                                                                                                                                                                                                                                              |
| 71   | <--       |    | DEACTIVATE PDP CONTEXT REQUEST  | Deactivates an existing PDP context.                                                                                                                                                                                                                                         |
| 72   | -->       |    | DEACTIVATE PDP CONTEXT ACCEPT   |                                                                                                                                                                                                                                                                              |
| 73   | UE        |    |                                 |                                                                                                                                                                                                                                                                              |
| 74   | UE        |    |                                 | There should be no further CP-DATA messages until the UE aborts the RRC connection<br>The UE shall indicate that an SM has arrived.<br>Clear the SMS message store<br>A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered.    |
| 75   | UE        |    |                                 |                                                                                                                                                                                                                                                                              |
| 76   | SS        |    |                                 |                                                                                                                                                                                                                                                                              |
| 77   | (void)    |    |                                 | Contains RP-DATA RPDU (SMS DELIVER TPDU)<br>Waits max 25 s for CP-ACK                                                                                                                                                                                                        |
| 78   | <--       |    | CP-DATA                         |                                                                                                                                                                                                                                                                              |
| 79   | SS        |    |                                 |                                                                                                                                                                                                                                                                              |
| 80   | -->       |    | CP-ACK                          | Waits max 60 s for RP-ACK RPDU<br>First CP-DATA from UE, contains RP-ACK RPDU<br>First CP-DATA message not acknowledged by SS                                                                                                                                                |
| 81   | SS        |    |                                 |                                                                                                                                                                                                                                                                              |
| 82   | -->       |    | CP-DATA                         |                                                                                                                                                                                                                                                                              |
| 83   | SS        |    |                                 | Transmitted CP-DATA message within twice TC1M after step 82, contains RP-ACK RPDU<br>Retransmitted CP-DATA message not acknowledged by SS                                                                                                                                    |
| 84   | -->       |    | CP-DATA                         |                                                                                                                                                                                                                                                                              |
| 85   | SS        |    |                                 |                                                                                                                                                                                                                                                                              |
| 86   | UE        |    |                                 | Depending on the maximum number of CP-DATA retransmissions implemented, step 83-84 may be repeated. The maximum number of retransmissions may however not exceed three.<br>RRC CONNECTION is released after a duration of TC1M + 15 s after the last CP-DATA retransmission. |
| 87   | <--       |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                              |
| 88   | -->       |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                              |
| 89   | UE        |    |                                 | The UE shall indicate that an SM has arrived.<br>Clear the SMS message store<br>A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered.                                                                                          |
| 90   | UE        |    |                                 |                                                                                                                                                                                                                                                                              |
| 91   | SS        |    |                                 |                                                                                                                                                                                                                                                                              |
| 92   | (void)    |    |                                 | Contains RP-DATA RPDU (SMS DELIVER TPDU)                                                                                                                                                                                                                                     |
| 93   | (void)    |    |                                 |                                                                                                                                                                                                                                                                              |
| 94   | <--       |    | CP-DATA                         |                                                                                                                                                                                                                                                                              |

| Step                                                                                                                                         | Direction |    | Message                        | Comments                                                                                                                                                                                                         |
|----------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                              | UE        | SS |                                |                                                                                                                                                                                                                  |
| 94A                                                                                                                                          | <--       |    | DEACTIVATE PDP-CONTEXT REQUEST | The PDP context is deactivated by the SS. The PDP context deactivating is continued in parallel to the following exchange of messages related to SMS.<br>This message may be transmitted after this step timing. |
| 94B                                                                                                                                          | -->       |    | DEACTIVATE PDP-CONTEXT ACCEPT  |                                                                                                                                                                                                                  |
| 95                                                                                                                                           |           | SS |                                | Waits max 25 s for CP-ACK                                                                                                                                                                                        |
| 96                                                                                                                                           | -->       |    | CP-ACK                         |                                                                                                                                                                                                                  |
| 97                                                                                                                                           |           | SS |                                | Waits max 60 s for RP-ACK RPDU                                                                                                                                                                                   |
| 98                                                                                                                                           | -->       |    | CP-DATA                        | Contains RP-ACK RPDU                                                                                                                                                                                             |
| 99                                                                                                                                           | <--       |    | CP-ACK                         |                                                                                                                                                                                                                  |
| 100                                                                                                                                          | UE        |    |                                | There should be no further CP-DATA messages until the UE aborts the RRC connection.                                                                                                                              |
| 101                                                                                                                                          | UE        |    |                                | The UE shall indicate that an SM has arrived.                                                                                                                                                                    |
| 102                                                                                                                                          | UE        |    |                                | Clear the SMS message store                                                                                                                                                                                      |
| 103                                                                                                                                          | SS        |    |                                | A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered.                                                                                                              |
| 104                                                                                                                                          |           |    | (void)                         |                                                                                                                                                                                                                  |
| 105                                                                                                                                          | -->       |    | DEACTIVATE PDP-CONTEXT REQUEST | The PDP context is deactivated by the UE. The PDP context deactivation is continued in parallel to the following                                                                                                 |
| 106                                                                                                                                          | <--       |    | CP-DATA                        | Contains RP-DATA RPDU (SMS-DELIVER TPDU)                                                                                                                                                                         |
| 107                                                                                                                                          | <--       |    | DEACTIVATE PDP-CONTEXT ACCEPT  |                                                                                                                                                                                                                  |
| 108                                                                                                                                          | -->       |    | CP-ACK                         | shall be sent before 25 s after the start of step 106                                                                                                                                                            |
| 109                                                                                                                                          |           | SS |                                | Waits max 60 s for RP-ACK RPDU                                                                                                                                                                                   |
| 110                                                                                                                                          | -->       |    | CP-DATA                        | Contains RP-ACK RPDU                                                                                                                                                                                             |
| 111                                                                                                                                          | <--       |    | CP-ACK                         |                                                                                                                                                                                                                  |
| 112                                                                                                                                          | UE        |    |                                | There should be no further CP-DATA messages until the UE aborts the RRC connection.                                                                                                                              |
| 113                                                                                                                                          | UE        |    |                                | The UE shall indicate that an SM has arrived.                                                                                                                                                                    |
| 114                                                                                                                                          | UE        |    |                                | Clear the SMS message store                                                                                                                                                                                      |
| NOTE: Time values for SS wait time are chosen sufficiently high to be sure that the UE has enough time to respond to the different messages. |           |    |                                |                                                                                                                                                                                                                  |

### Specific Message Contents

#### SMS-DELIVER TPDU

| Information element                                                                                                                                   | Comment/Value                    |
|-------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|
| TP-UDL                                                                                                                                                | 160                              |
| TP-UD (140 octets)                                                                                                                                    | text of message (160 characters) |
| NOTE: The 160 characters in TP-UD shall include at least one occurrence of each character in the default alphabet (see 3GPP TS 23.038, clause 6.2.1). |                                  |

#### 16.2.1.5 Test requirements

After step 7 UE shall receive SMS-DELIVER TPDU and send CP-ACK within 25 s and CP-DATA containing RP-ACK within 60 s.

After step 25 UE shall retransmit CP-DATA containing RP-ACK within twice TC1M.

After step 30 UE shall indicate that an SM has arrived.

After step 43 UE shall repeat CP-DATA retransmissions as many times as the decided maximum number.

After step 48 UE shall indicate that an SM has arrived.

After step 51 UE shall receive SMS-DELIVER TPDU and send CP-ACK within 25 s and CP-DATA containing RP-ACK within 60 s.

After step 67 UE shall retransmit CP-DATA containing RP-ACK within twice TC1M.



~~After step 73 UE shall indicate that an SM has arrived.~~

~~After step 78 UE shall repeat CP-DATA retransmissions as many times as the decided maximum number.~~

~~After step 89 UE shall indicate that an SM has arrived.~~

~~After step 94 UE shall receive SMS-DELIVER TPDU and send CP-ACK within 25 s and CP-DATA containing RP-ACK within 60 s.~~

~~After step 106 UE shall receive SMS-DELIVER TPDU and send CP-ACK within 25 s and CP-DATA containing RP-ACK within 60 s.~~

## ~~16.2.2 SMS mobile originated~~

### ~~16.2.2.1 Definition~~

### ~~16.2.2.2 Conformance requirements~~

~~An active UE shall be able to submit short message TPDU (SMS-SUBMIT) at any time, independently of whether or not there is a PDP context in progress.~~

### ~~Reference~~

~~3GPP TS 23.040 clause 3.1.~~

### ~~16.2.2.3 Test purpose~~

~~To verify that the UE is able to correctly send a short message where the SMS is provided for the point to point service.~~

### ~~16.2.2.4 Method of test~~

### ~~Initial Conditions~~

- ~~— System simulator:~~
  - ~~— 1 cell, default parameters.~~
- ~~— User Equipment:~~
  - ~~— the UE shall be in GMM-state "GMM-REGISTERED";~~
  - ~~— the SMS message storage shall be empty.~~

### ~~Related ICS/IXIT Statements~~

~~Support for Short message MO/PP.~~

~~Support for state PDP-ACTIVE of session management.~~

~~The value of timer TC1M.~~

~~Whether SMS messages are stored in the USIM and/or the ME.~~

~~Maximum length (characters) of a mobile originated short message.~~

### ~~Test procedure~~

- ~~a) The UE shall be set up to send a SM to the SS. The SS responds to RRC CONNECTION REQUEST by allocating a CCCH. The SS receives RRC CONNECTION SETUP COMPLETE on DCCH and then performs the authentication.~~
- ~~b) After receiving SECURITY MODE COMMAND UE shall send SECURITY COMMAND COMPLETE.~~

- c) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message within TC1M followed by a CP-DATA message containing the correct RP-ACK RPDU. The SS waits a maximum of 25 s for the CP-ACK message.
- d) The SS sends a channel release message to the UE.
- e) Steps a) and b) are repeated. The SS is configured not to send the CP-ACK message. Then maximum 3 CP-DATA retransmissions may occur. After a duration of TC1M + 5 s after the last CP-DATA retransmission the SS initiates channel release. The 5 s is the appropriate time to wait to verify that the UE does not send more than the maximum CP-DATA retransmissions.
- f) Steps a) and b) are repeated. On receipt of the CP-DATA from the UE the SS sends a CP-ERROR message within TC1M containing a "Network Failure" cause. Then the SS initiates channel release.
- g) A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered. The UE is set up to send an SM to the SS. After the reception of the SERVICE REQUEST, the SS sends a SERVICE ACCEPT message.
- h) The SS responds to the CP-DATA containing RP-DATA RPDU (SMS SUBMIT TPDU) from the UE with a CP-ACK message within TC1M followed by a CP-DATA message containing the correct RP-ACK RPDU. The SS waits a maximum of 25 s for the CP-ACK message. Then the SS sends a channel release message to the UE.
- i) Step g) is repeated. The SS is configured not to send the CP-ACK message. Then maximum 3 CP-DATA retransmissions may occur. After a duration of TC1M + 15 s after the last CP-DATA retransmission the SS initiates channel release. The 15 s is the appropriate time to wait to verify that the UE does not send more than the maximum CP-DATA retransmissions (during a PDP context in progress).
- j) (void)
- k) The UE is set up to send an SM to the SS. On receipt of the SERVICE REQUEST the SS sends a SERVICE REJECT message with the reject cause set to "GPRS services not allowed". After 5 s the SS initiates channel release.

## Expected sequence

| Step | Direction |    | Message                               | Comments                                |
|------|-----------|----|---------------------------------------|-----------------------------------------|
|      | UE        | SS |                                       |                                         |
| 1    |           | ←  | SYSTEM INFORMATION                    | BCCH                                    |
| 2    | →         |    | RRC CONNECTION REQUEST                | CCCH                                    |
| 3    | ←         |    | RRC CONNECTION SETUP                  | CCCH                                    |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE         | DCCH                                    |
| 5    | →         |    | SERVICE REQUEST                       |                                         |
| 6    | ←         |    | AUTHENTICATION AND CIPHERING REQUEST  |                                         |
| 7    | →         |    | AUTHENTICATION AND CIPHERING RESPONSE |                                         |
| 8    | ←         |    | SECURITY MODE COMMAND                 |                                         |
| 9    | →         |    | SECURITY MODE COMPLETE                |                                         |
| 10   | →         |    | CP-DATA                               | Contains RP-DATA RPDU (SMS SUBMIT TPDU) |
| 11   | ←         |    | CP-ACK                                | Sent within TC1M after step 10          |
| 12   | ←         |    | CP-DATA                               | Contains RP-ACK RPDU                    |
| 13   |           | SS |                                       | Waits max 25 s for CP-ACK               |
| 14   | →         |    | CP-ACK                                |                                         |
| 15   | ←         |    | RRC CONNECTION RELEASE                | RRC connection is released.             |
| 16   | →         |    | RRC CONNECTION RELEASE COMPLETE       |                                         |
| 17   | ←         |    | SYSTEM INFORMATION                    | BCCH                                    |
| 18   | →         |    | RRC CONNECTION REQUEST                | CCCH                                    |
| 19   | ←         |    | RRC CONNECTION SETUP                  | CCCH                                    |
| 20   | →         |    | RRC CONNECTION SETUP COMPLETE         | DCCH                                    |
| 21   | →         |    | SERVICE REQUEST                       |                                         |
| 22   | ←         |    | AUTHENTICATION AND CIPHERING REQUEST  |                                         |

| Step  | Direction |    | Message                               | Comments                                                                                                                                                             |
|-------|-----------|----|---------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       | UE        | SS |                                       |                                                                                                                                                                      |
| 23    | →         |    | AUTHENTICATION AND CIPHERING RESPONSE |                                                                                                                                                                      |
| 24    | ←         |    | SECURITY MODE COMMAND                 |                                                                                                                                                                      |
| 25    | →         |    | SECURITY MODE COMPLETE                |                                                                                                                                                                      |
| 26    | →         |    | CP-DATA                               | Contains RP-DATA RPDU (SMS SUBMIT TPDU)                                                                                                                              |
| 27    | SS        |    |                                       | SS configured not to send CP-ACK                                                                                                                                     |
| 28    | →         |    | CP-DATA                               | Retransmitted CP-DATA message within twice TC1M after step 26                                                                                                        |
| 29    | UE        |    |                                       | Depending on the maximum number of CP-DATA retransmissions implemented, step 28 may be repeated. The maximum number of retransmissions may however not exceed three. |
| 30    | ←         |    | RRC CONNECTION RELEASE                | RRC CONNECTION is released after a duration of TC1M + 5 s after the last CP-DATA retransmission.                                                                     |
| 31    | →         |    | RRC CONNECTION RELEASE COMPLETE       |                                                                                                                                                                      |
| 32    | ←         |    | SYSTEM INFORMATION                    | BCCH                                                                                                                                                                 |
| 33    | →         |    | RRC CONNECTION REQUEST                | CCCH                                                                                                                                                                 |
| 34    | ←         |    | RRC CONNECTION SETUP                  | CCCH                                                                                                                                                                 |
| 35    | →         |    | RRC CONNECTION SETUP COMPLETE         | DCCH                                                                                                                                                                 |
| 36    | →         |    | SERVICE REQUEST                       |                                                                                                                                                                      |
| 37    | ←         |    | AUTHENTICATION AND CIPHERING REQUEST  |                                                                                                                                                                      |
| 38    | →         |    | AUTHENTICATION AND CIPHERING RESPONSE |                                                                                                                                                                      |
| 39    | ←         |    | SECURITY MODE COMMAND                 |                                                                                                                                                                      |
| 40    | →         |    | SECURITY MODE COMPLETE                |                                                                                                                                                                      |
| 41    | →         |    | CP-DATA                               | Contains RP-DATA RPDU (SMS SUBMIT TPDU)                                                                                                                              |
| 42    | ←         |    | CP-ERROR                              | Sent within TC1M containing "Network Failure" cause.                                                                                                                 |
| 43    | ←         |    | RRC CONNECTION RELEASE                | RRC CONNECTION is released.                                                                                                                                          |
| 44    | →         |    | RRC CONNECTION RELEASE COMPLETE       |                                                                                                                                                                      |
| 45    | SS        |    |                                       | A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered.                                                                  |
| 46    | UE        |    |                                       | The UE is set up to send an SM                                                                                                                                       |
| 47    | →         |    | SERVICE REQUEST                       |                                                                                                                                                                      |
| 48    | ←         |    | SERVICE ACCEPT                        |                                                                                                                                                                      |
| 49    | →         |    | CP-DATA                               | Contains RP-DATA RPDU (SMS SUBMIT TPDU)                                                                                                                              |
| 50    | ←         |    | CP-ACK                                | Sent within TC1M after step 49                                                                                                                                       |
| 51    | ←         |    | CP-DATA                               | Contains RP-ACK RPDU                                                                                                                                                 |
| 52    | SS        |    |                                       | Waits max 25 s for CP-ACK                                                                                                                                            |
| 53    | →         |    | CP-ACK                                |                                                                                                                                                                      |
| 54    | ←         |    | RRC CONNECTION RELEASE                | RRC CONNECTION is released.                                                                                                                                          |
| 55    | →         |    | RRC CONNECTION RELEASE COMPLETE       |                                                                                                                                                                      |
| 56    | SS        |    |                                       | A PDP context is established with the SS and the state PDP-ACTIVE of session management is entered.                                                                  |
| 57    | →         |    | SERVICE REQUEST                       |                                                                                                                                                                      |
| 58    | ←         |    | SERVICE ACCEPT                        |                                                                                                                                                                      |
| 59    | →         |    | CP-DATA                               | Contains RP-DATA RPDU (SMS SUBMIT TPDU)                                                                                                                              |
| 60    | SS        |    |                                       | SS configured not to send CP-ACK                                                                                                                                     |
| 61    | →         |    | CP-DATA                               | Transmitted CP-DATA message within twice TC1M after step 59                                                                                                          |
| 62    | UE        |    |                                       | Depending on the maximum number of CP-DATA retransmissions implemented, step 61 may be repeated. The maximum number of retransmissions may however not exceed three. |
| 63    | ←         |    | RRC CONNECTION RELEASE                | RRC CONNECTION is released after a duration of TC1M + 15 s after the last CP-DATA retransmission.                                                                    |
| 64    | →         |    | RRC CONNECTION RELEASE COMPLETE       |                                                                                                                                                                      |
| 65-77 |           |    | (void)                                |                                                                                                                                                                      |
| 78    | →         |    | RRC CONNECTION REQUEST                | initiate outgoing call                                                                                                                                               |
| 79    | ←         |    | RRC CONNECTION SETUP                  |                                                                                                                                                                      |

| Step                                                                                                                                          | Direction |    | Message                         | Comments                                                                      |
|-----------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------|-------------------------------------------------------------------------------|
|                                                                                                                                               | UE        | SS |                                 |                                                                               |
| 80                                                                                                                                            | -->       |    | RRC CONNECTION SETUP COMPLETE   | Reject cause set to "GPRS services not allowed"<br>Sent 5 s after SERVICE REJ |
| 81                                                                                                                                            | -->       |    | SERVICE REQUEST                 |                                                                               |
| 82                                                                                                                                            | <--       |    | SERVICE REJECT                  |                                                                               |
| 83                                                                                                                                            | <--       |    | RRC CONNECTION RELEASE          |                                                                               |
| 84                                                                                                                                            | -->       |    | RRC CONNECTION RELEASE COMPLETE |                                                                               |
| NOTE: Time values for SS wait times are chosen sufficiently high to be sure that the UE has enough time to respond to the different messages. |           |    |                                 |                                                                               |

## Specific Message Contents

### SMS SUBMIT TPDU

| Information element              | CommentValue                                                                                                  |
|----------------------------------|---------------------------------------------------------------------------------------------------------------|
| TP-UDL<br>TP-UD (140 octets max) | as applicable<br>maximum number of characters (text of message) as defined by the manufacturer (see ICS/IXIT) |

### 16.2.2.5 Test requirements

After step 9 UE shall send a CP-DATA containing RP-data. The RP-DATA shall contain SMS SUBMIT TPDU.

After step 26 UE shall retransmit a CP-DATA containing RP-data. The RP-DATA shall contain SMS SUBMIT TPDU.

After step 43 UE shall send the RRC CONNECTION RELEASE COMPLETE.

After step 48 UE shall send a CP-DATA containing RP-data. The RP-DATA shall contain SMS SUBMIT TPDU.

After step 61 UE shall repeat CP-DATA retransmissions as many times as the decided maximum number.

After step 82 UE shall not send CP-DATA.

### 16.2.3 Test of memory full condition and memory available notification:

The Memory Available Notification provides a means for the UE to notify the network that it has memory available to receive one or more short messages. The SMS status field in the USIM contains status information on the "memory available" notification flag.

#### 16.2.3.1 Definition

#### 16.2.3.2 Conformance requirement

- When a mobile terminated message is Class 2, the UE shall ensure that the message has been transferred to the SMS data field in the USIM before sending an acknowledgement to the SC. The UE shall return a protocol error message if the short message cannot be stored in the USIM and there is other short message storage available in the UE. If all the short message storage in the UE is already in use, the UE shall return "memory capability exceeded".
- When the UE rejects a short message due to lack of available memory capability the need to transfer notification shall be stored in the USIM.
- If the memory capability becomes available because memory is cleared, the value of the memory capability exceeded notification flag in the USIM is read. If the flag is set, the UE notifies the network that memory capability is now available. After a positive acknowledgement from the network, the ME unsets the memory capability exceeded notification flag in the USIM.

## References

- 3GPP TS 23.040 clause 9.2.3.10, 3GPP TS 23.038 clause 4.
- 3GPP TS 23.040 clause 10.3 (operation 14).
- 3GPP TS 23.040 clause 10.3 (operation 14).

### 16.2.3.3 Test purpose

1. To verify that the UE sends the correct acknowledgement when its memory in the USIM becomes full.
2. To verify that the UE sends the correct acknowledgement when its memory in the ME and the USIM becomes full, and sets the "memory exceeded" notification flag in the USIM.
3. To verify that the UE performs the "memory available" procedure when its message store becomes available for receiving short messages, and only at this moment.

### 16.2.3.4 Method of test

#### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in GMM-state "GMM-REGISTERED";
  - the SMS message storage shall be empty;
  - the UE shall be connected to the USIM simulator. The following shall be present in the USIM simulator:
    - EF<sub>SMS</sub> with at least one record;
    - EF<sub>SMSstatus</sub> with SMS "Memory Cap. Exceed" notification flag set to "memory available";
    - Service no. 4 (SMS) in EF<sub>SS-T</sub> set to allocated and activated.
  - for storing of Class 1 Short Messages the UE shall be set up to store Short Messages in the ME memory (by way of MMI, as described in ICS/IXIT statement).

#### Related ICS/IXIT Statements

Support for Short message MT/PP.

Whether SMS messages are stored in the USIM and/or the ME.

The value of timer TC1M.

#### Test procedure

- a) step a) of clause 16.2.5.3 (test of Class 2 Short Messages) is repeated until the UE sends a negative acknowledgement (RP-ERROR). The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.
- b) a Class 1 Short Message is sent to the UE.
- c) step b) is repeated until the UE sends a negative acknowledgement (RP-ERROR). The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.
- d) a Short Message is sent to the UE with the DCS field of the SMS-DELIVER TPDU set to 0.
- e) the SS prompts the operator to read a short message and to remove it from the message store of the UE.

- f) the SS waits for a RRC CONNECTION REQUEST from the UE, and sends a RRC CONNECTION SETUP.
- g) after the SS receives a RRC CONNECTION SETUP COMPLETE, the SS authenticates the UE and activates ciphering.
- h) the SS answers to the RP-SMMA from the UE with a CP-DATA containing a RP-ACK RPDU.
- i) after the UE has acknowledged the CP-DATA with a CP-ACK, the SS releases the RRC connection. The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been unset on the USIM.
- j) step e) is repeated.

## Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|------|-----------|----|--------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 1    |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 2    | →         |    | SERVICE REQUEST                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 3    | ←         |    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 4    | →         |    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 5    | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 6    | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 7    | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-DELIVER TPDU), Class 2 Short Message                                                                                                                                                                                                                                                                                                                                                                              |
| 8    |           | SS |                                                              | Waits max 25 s for CP-ACK                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 9    | →         |    | CP-ACK                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 10   |           | SS |                                                              | Waits max 60 s for RP-ACK RPDU                                                                                                                                                                                                                                                                                                                                                                                                               |
| 11   | →         |    | CP-DATA                                                      | Contains RP-ACK RPDU                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 12   | ←         |    | CP-ACK                                                       | Within TC1M after step 11                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 13   | ←         |    | RRC CONNECTION RELEASE                                       | RRC connection is released. Step 1-18 is repeated until UE sends a negative acknowledgement (RP-ERROR) in step 11. The RP-ERROR RPDU cause field shall be "Protocol error, unspecified" if there is message capability in the ME, or "Memory capability exceeded" if there is no message capability in the ME. If the total memory store of the UE is full, the ME shall set the "memory capability exceeded" notification flag on the USIM. |
| 14   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 15   |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 16   | →         |    | SERVICE REQUEST                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 17   | ←         |    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 18   | →         |    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 19   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 20   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 21   | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-DELIVER TPDU), Class 1 Short Message                                                                                                                                                                                                                                                                                                                                                                              |
| 22   |           | SS |                                                              | Waits max 25 s for CP-ACK                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 23   | →         |    | CP-ACK                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 24   |           | SS |                                                              | Waits max 60 s for RP-ACK RPDU                                                                                                                                                                                                                                                                                                                                                                                                               |
| 25   | →         |    | CP-DATA                                                      | Shall contain RP-ACK RPDU if there is memory capability in the ME. If not it shall contain RP-ERROR RPDU which cause field shall be "memory capability exceeded". If the total memory store of the UE now becomes full at this step, the ME shall set the "memory cap. exceed" notification flag on the USIM.                                                                                                                                |
| 26   | ←         |    | CP-ACK                                                       | Within TC1M after step 25                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 27   | ←         |    | RRC CONNECTION RELEASE                                       | RRC connection is released. Step 19-36 is repeated until the UE sends an RP-ERROR. The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.                                                                                                                                                                                                                                         |

| Step                                                                                                                                           | Direction |    | Message                                                      | Comments                                                                                                                                                                                                       |
|------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|--------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                | UE        | SS |                                                              |                                                                                                                                                                                                                |
| 28                                                                                                                                             | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                |
| 29                                                                                                                                             |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108                                                                                                                                                                                              |
| 30                                                                                                                                             | →         |    | SERVICE REQUEST                                              |                                                                                                                                                                                                                |
| 31                                                                                                                                             | ←         |    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                                                                                                                                                                |
| 32                                                                                                                                             | →         |    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                                                                                                                                                                                |
| 33                                                                                                                                             | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                                |
| 34                                                                                                                                             | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                                                |
| 35                                                                                                                                             | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-DELIVER TPDU) with TP-DCS set to 0                                                                                                                                                  |
| 36                                                                                                                                             |           | SS |                                                              | Waits max 25 s for CP-ACK                                                                                                                                                                                      |
| 37                                                                                                                                             | →         |    | CP-ACK                                                       |                                                                                                                                                                                                                |
| 38                                                                                                                                             |           | SS |                                                              | Waits max 60 s for RP-ACK RPDU                                                                                                                                                                                 |
| 39                                                                                                                                             | →         |    | CP-DATA                                                      | Shall contain RP-ERROR RPDU with error cause "memory capability exceeded".                                                                                                                                     |
| 40                                                                                                                                             | ←         |    | CP-ACK                                                       | Within TC1M after step 39                                                                                                                                                                                      |
| 41                                                                                                                                             | ←         |    | RRC CONNECTION RELEASE                                       | RRC connection is released.                                                                                                                                                                                    |
| 42                                                                                                                                             | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                |
| 43                                                                                                                                             |           | SS |                                                              | Prompts the operator to remove one of the short messages from the message store of the UE.                                                                                                                     |
| 44                                                                                                                                             | ←         |    | SYSTEM INFORMATION                                           | BCCH                                                                                                                                                                                                           |
| 45                                                                                                                                             | →         |    | RRC CONNECTION REQUEST                                       | CCCH                                                                                                                                                                                                           |
| 46                                                                                                                                             | ←         |    | RRC CONNECTION SETUP                                         | CCCH                                                                                                                                                                                                           |
| 47                                                                                                                                             | →         |    | RRC CONNECTION SETUP COMPLETE                                | DCCH                                                                                                                                                                                                           |
| 48                                                                                                                                             | →         |    | SERVICE REQUEST                                              |                                                                                                                                                                                                                |
| 49                                                                                                                                             | ←         |    | SERVICE ACCEPT                                               |                                                                                                                                                                                                                |
| 50                                                                                                                                             | →         |    | CP-DATA                                                      | Contains RP-SMMA RPDU                                                                                                                                                                                          |
| 51                                                                                                                                             | ←         |    | CP-ACK                                                       |                                                                                                                                                                                                                |
| 52                                                                                                                                             | ←         |    | CP-DATA                                                      | Contains RP-ACK RPDU                                                                                                                                                                                           |
| 53                                                                                                                                             | →         |    | CP-ACK                                                       | Acknowledge of CP-DATA containing the RP-ACK RPDU. The ME shall unset the "memory capability exceeded" notification flag on the USIM.                                                                          |
| 54                                                                                                                                             | ←         |    | RRC CONNECTION RELEASE                                       | RRC connection is released. The USIM simulator shall indicate if the "memory capability exceeded" notification flag has been unset on the USIM.                                                                |
| 55                                                                                                                                             | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                |
| 56                                                                                                                                             |           | SS |                                                              | Prompts the operator to remove one of the short messages from the message store of the UE.                                                                                                                     |
| 57                                                                                                                                             | UE        |    |                                                              | Shall not attempt to send a RP-SMMA RPDU. This is verified by checking that the UE does not send a CHANNEL REQUEST message with the establishment cause "Other services which can be completed with an SDCCCH" |
| NOTE: — Time values for SS wait time are chosen sufficiently high to be sure that the UE has enough time to respond to the different messages. |           |    |                                                              |                                                                                                                                                                                                                |

### Specific Message Contents

#### SMS-DELIVER TPDU in step 7

| Information element | Comment/Value                         |
|---------------------|---------------------------------------|
| TP-DCS              | default alphabet, class 2 "11110010"B |

#### SMS-DELIVER TPDU in step 21

|        |                                       |
|--------|---------------------------------------|
| TP-DCS | default alphabet, class 1 "11110001"B |
|--------|---------------------------------------|

SMS-DELIVER TPDU in step 35

|        |                              |
|--------|------------------------------|
| TP-DCS | default alphabet "00000000"B |
|--------|------------------------------|

### 16.2.3.5 ~~Test requirements~~

After UE sends a negative acknowledgement (RP-ERROR) in step 11, the USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.

After UE sends a negative acknowledgement (RP-ERROR) in step 23, the USIM simulator shall indicate if the "memory capability exceeded" notification flag has been set on the USIM.

After step 53 the ME shall unset the "memory capability exceeded" notification flag on the USIM.

After step 56 UE shall not attempt to send a RP-SMMA RPDU.

## 16.2.4 ~~Test of the status report capabilities and of SMS-COMMAND:~~

This test applies to UEs which support the status report capabilities.

### 16.2.4.1 ~~Definition~~

### 16.2.4.2 ~~Conformance requirement~~

The SMS offers the SC the capabilities of informing the UE of the status of a previously sent mobile-originated short message. This is achieved by the SC returning a status report TPDU (SMS-STATUS-REPORT) to the originating UE.

SMS-COMMAND enables an UE to invoke an operation at the SC.

The UE shall increment TP-MR by 1 for each SMS-SUBMIT or SMS-COMMAND being submitted.

### References

- 3GPP TS 23.040 clause 3.2.9.
- 3GPP TS 23.040 clause 9.2.3.6.

### 16.2.4.3 ~~Test purpose~~

- 1) To verify that the UE is able to accept a SMS-STATUS-REPORT TPDU.
- 2) To verify that the UE is able to use the SMS-COMMAND functionality correctly and sends an SMS-COMMAND TPDU with the correct TP-Message-Reference.

### 16.2.4.4 ~~Method of test~~

#### Initial conditions

- System Simulator:
  - 1 cell, default parameters.
- User Equipment:
  - the UE shall be in GMM-state "GMM-REGISTERED".

#### Related ICS/IXIT Statements

Support of SMS MO/PP and MT/PP.



## Test procedure

- a) The UE is made to send a Mobile Originated short message setting TP-SRR as in steps a) to d) of test 16.2.2 (SMS Mobile-originated).
- b) The SS sends a CP-DATA message containing a RP-DATA RPDU itself containing an SMS-STATUS-REPORT TPDU.
- c) The SS sends a RRC CONNECTION RELEASE message.
- d) The UE is made to send an SMS-COMMAND message enquiring about the previously submitted short message.
- e) Void.
- f) The SS acknowledges the CP-DATA message from the UE with a CP-ACK followed by a CP-DATA message containing an RP-ACK RPDU.
- g) After receiving the CP-ACK from the UE, the SS releases the RRC connection by using a RRC CONNECTION RELEASE message.
- h) The UE is made to send an SMS-COMMAND message requiring to delete the previously submitted short message.
- i) steps e) to g) are repeated.

## Expected sequence

| Step | Direction |    | Message                                                      | Comments                                       |
|------|-----------|----|--------------------------------------------------------------|------------------------------------------------|
|      | UE        | SS |                                                              |                                                |
| 1    | ←         |    | SYSTEM INFORMATION                                           | BCCH                                           |
| 2    | →         |    | RRC CONNECTION REQUEST                                       | CCCH                                           |
| 3    | ←         |    | RRC CONNECTION SETUP                                         | CCCH                                           |
| 4    | →         |    | RRC CONNECTION SETUP COMPLETE                                | DCCH                                           |
| 5    | →         |    | SERVICE REQUEST                                              |                                                |
| 6    | ←         |    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                |
| 7    | →         |    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                |
| 8    | ←         |    | SECURITY MODE COMMAND                                        |                                                |
| 9    | →         |    | SECURITY MODE COMPLETE                                       |                                                |
| 10   | →         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-SUBMIT TPDU)        |
| 11   | ←         |    | CP-ACK                                                       | Sent within TC1M after step 10                 |
| 12   | ←         |    | CP-DATA                                                      | Contains RP-ACK RPDU                           |
| 13   |           | SS |                                                              | Waits max 25 s for CP-ACK                      |
| 14   | →         |    | CP-ACK                                                       |                                                |
| 15   | ←         |    | RRC CONNECTION RELEASE                                       | RRC connection is released.                    |
| 16   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                |
| 17   |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108                              |
| 18   | →         |    | SERVICE REQUEST                                              |                                                |
| 19   | ←         |    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                |
| 20   | →         |    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                |
| 21   | ←         |    | SECURITY MODE COMMAND                                        |                                                |
| 22   | →         |    | SECURITY MODE COMPLETE                                       |                                                |
| 23   | ←         |    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-STATUS-REPORT TPDU) |
| 24   | →         |    | CP-ACK                                                       |                                                |
| 25   | →         |    | CP-DATA                                                      | Contains RP-ACK RPDU                           |
| 26   | ←         |    | CP-ACK                                                       |                                                |
| 27   | ←         |    | RRC CONNECTION RELEASE                                       |                                                |
| 28   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                |

| Step | Direction |    | Message                               | Comments                                                                                  |
|------|-----------|----|---------------------------------------|-------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                           |
| 29   | UE        |    |                                       | The UE is made to send an SMS-COMMAND message enquiring about the previously submitted SM |
| 30   | ←         |    | SYSTEM INFORMATION                    | BCCH                                                                                      |
| 31   | →         |    | RRC CONNECTION REQUEST                | CCCH                                                                                      |
| 32   | ←         |    | RRC CONNECTION SETUP                  | CCCH                                                                                      |
| 33   | →         |    | RRC CONNECTION SETUP COMPLETE         | DCCH                                                                                      |
| 34   | →         |    | SERVICE REQUEST                       |                                                                                           |
| 35   | ←         |    | AUTHENTICATION AND CIPHERING REQUEST  |                                                                                           |
| 36   | →         |    | AUTHENTICATION AND CIPHERING RESPONSE |                                                                                           |
| 37   | ←         |    | SECURITY MODE COMMAND                 |                                                                                           |
| 38   | →         |    | SECURITY MODE COMPLETE                |                                                                                           |
| 39   | →         |    | CP-DATA                               | Contains RP-DATA RPDU (SMS-COMMAND TPDU) which shall contain the correct TP-MR            |
| 40   | ←         |    | CP-ACK                                |                                                                                           |
| 41   | ←         |    | CP-DATA                               | Contains RP-ACK RPDU                                                                      |
| 42   | →         |    | CP-ACK                                |                                                                                           |
| 43   | ←         |    | RRC CONNECTION RELEASE                |                                                                                           |
| 44   | →         |    | RRC CONNECTION RELEASE COMPLETE       |                                                                                           |
| 45   | UE        |    | The UE is made to send an SMS-COMMAND | -message requiring to delete the previously submitted SM.                                 |
| 46   | →         |    | RRC CONNECTION REQUEST                | CCCH                                                                                      |
| 47   | ←         |    | RRC CONNECTION SETUP                  | CCCH                                                                                      |
| 48   | →         |    | RRC CONNECTION SETUP COMPLETE         | DCCH                                                                                      |
| 49   | →         |    | SERVICE REQUEST                       |                                                                                           |
| 50   | ←         |    | AUTHENTICATION AND CIPHERING REQUEST  |                                                                                           |
| 51   | →         |    | AUTHENTICATION AND CIPHERING RESPONSE |                                                                                           |
| 52   | ←         |    | SECURITY MODE COMMAND                 |                                                                                           |
| 53   | →         |    | SECURITY MODE COMPLETE                |                                                                                           |
| 54   | →         |    | CP-DATA                               | Contains RP-DATA RPDU (SMS-COMMAND TPDU) which shall contain the correct TP-MR            |
| 55   | ←         |    | CP-ACK                                |                                                                                           |
| 56   | ←         |    | CP-DATA                               | Contains RP-ACK RPDU                                                                      |
| 57   | →         |    | CP-ACK                                |                                                                                           |
| 58   | ←         |    | RRC CONNECTION RELEASE                |                                                                                           |
| 59   | →         |    | RRC CONNECTION RELEASE COMPLETE       |                                                                                           |

### Specific Message Contents

#### SMS-SUBMIT TPDU

| Information element | Comment Value                   |
|---------------------|---------------------------------|
| TP-SRR              | status report is requested—"1"B |

#### SMS-STATUS-REPORT TPDU (SS to UE in step 23):

| Information element | Comment Value                                     |
|---------------------|---------------------------------------------------|
| TP-MR               | same as previous SMS-SUBMIT                       |
| TP-MMS              | no more messages—"1"B                             |
| TP-SRQ              | result of SMS-SUBMIT—"0"B                         |
| TP-RA               | same as the Destination address of the SMS-SUBMIT |
| TP-ST               | SM received—"00000000"B                           |

first SMS-COMMAND-TPDU (UE to SS in step 39)

| Information element | Comment Value                                                      |
|---------------------|--------------------------------------------------------------------|
| TP-MR               | TP-MR in previous SMS-SUBMIT plus "1"                              |
| TP-SRR              | status-report requested "1"B                                       |
| TP-CT               | Enquiry relating to previously submitted short message "00000000"B |
| TP-MN               | not checked (TP-MR in previous SMS-SUBMIT)                         |

second SMS-COMMAND-TPDU (UE to SS in step 54)

| Information element | Comment Value                                         |
|---------------------|-------------------------------------------------------|
| TP-MR               | TP-MR in previous SMS-COMMAND plus "1"                |
| TP-CT               | Delete previously submitted short message "00000010"B |
| TP-MN               | not checked (TP-MR in previous SMS-SUBMIT)            |

#### 16.2.4.5 Test requirements

After step 23 UE accept a SMS-STATUS-REPORT-TPDU.

After step 39 UE shall send a SMS-COMMAND-TPDU with the correct TP-Message-Reference.

After step 54 UE shall send a SMS-COMMAND-TPDU with the correct TP-Message-Reference.

### 16.2.5 Test of message class 0 to 3

#### 16.2.5.1 Short message class 0

##### 16.2.5.1.1 Definition

##### 16.2.5.1.2 Conformance requirement

When a mobile terminated message is class 0 and the UE has the capability of indicating short messages, the UE shall indicate the message immediately and send an acknowledgement to the SC when the message has successfully reached the UE irrespective of whether there is memory available in the USIM or ME. The message shall not be automatically stored in the USIM or ME.

#### References

3GPP TS 23.038, clause 4.

##### 16.2.5.1.3 Test purpose

To verify that the UE will accept and indicate but not store a class 0 message, and that it will accept and indicate a class 0 message if its message store is full.

NOTE: failure of this test in a UE could cause it to reject a class 0 message when its SMS memory becomes full. This could lead to unwanted repetitions between the UE and the service centre.

##### 16.2.5.1.4 Method of test

#### Initial conditions

— System Simulator:

— 1 cell, default parameters.

— User Equipment:

— the UE shall be in GMM-state "GMM-REGISTERED";

— the UE message store shall be empty.

#### Related ICS/IXIT Statements

Support for Short message MT/PP.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

#### Test procedure

- a) The SS sends a class 0 message by using the method described in step a) of clause 16.2.1 but with the TPDU described in this clause.
- b) The UE message store shall be filled (for example by using the method of clause 16.2.3 test of the memory available notification) with the same SMS-DELIVER TPDU except that TP-DCS is set to class 1.
- c) The SS sends a class 0 message as in step a).

#### Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                        |
|------|-----------|----|--------------------------------------------------------------|-----------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                 |
| 1    |           |    | Mobile-terminated-establishment of Radio-Resource-Connection | See 3GPP TS34.108                                               |
| 2    | →         |    | SERVICE REQUEST                                              |                                                                 |
| 3    | ←         |    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                 |
| 4    | →         |    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                                 |
| 5    | ←         |    | SECURITY MODE COMMAND                                        |                                                                 |
| 6    | →         |    | SECURITY MODE COMPLETE                                       |                                                                 |
| 7    | ←         |    | CP-DATA                                                      |                                                                 |
| 8    | →         |    | CP-ACK                                                       |                                                                 |
| 9    | →         |    | CP-DATA                                                      |                                                                 |
| 10   | ←         |    | CP-ACK                                                       |                                                                 |
| 11   | ←         |    | RRC CONNECTION RELEASE                                       |                                                                 |
| 12   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                 |
| 13   | UE        |    |                                                              | Contains RP-DATA RPDU (SMS-DELIVER TPDU), Class 0 Short Message |
| 14   |           | SS |                                                              |                                                                 |
| 15   |           |    | Mobile-terminated-establishment of Radio-Resource-Connection |                                                                 |
| 16   | →         |    | SERVICE REQUEST                                              | See 3GPP TS34.108                                               |
| 17   | ←         |    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                 |
| 18   | →         |    | AUTHENTICATION AND CIPHERING RESPONSE                        | Contains RP-DATA RPDU (SMS-DELIVER TPDU), Class 0 Short Message |
| 19   | ←         |    | SECURITY MODE COMMAND                                        |                                                                 |
| 20   | →         |    | SECURITY MODE COMPLETE                                       |                                                                 |
| 21   | ←         |    | CP-DATA                                                      |                                                                 |
| 22   | →         |    | CP-ACK                                                       |                                                                 |
| 23   | →         |    | CP-DATA                                                      |                                                                 |
| 24   | ←         |    | CP-ACK                                                       |                                                                 |
| 25   | ←         |    | RRC CONNECTION RELEASE                                       |                                                                 |

| Step | Direction |    | Message                            | Comments                                                       |
|------|-----------|----|------------------------------------|----------------------------------------------------------------|
|      | UE        | SS |                                    |                                                                |
| 26   | -->       | SS | RRG-CONNECTION-RELEASE<br>COMPLETE | The content of the short message shall be indicated by the ME. |
| 27   |           |    |                                    |                                                                |

### Specific Message Contents

#### SMS-DELIVER TPDU (containing a class 0 message) (SS to UE)

| Information element | CommentValue                           |
|---------------------|----------------------------------------|
| TP-DCS              | default alphabet, class 0 "1111 0000"B |

#### SMS-DELIVER TPDU (containing a class 1 message to fill the UE message store) (SS to UE)

| Information element | CommentValue                           |
|---------------------|----------------------------------------|
| TP-DCS              | default alphabet, class 1 "1111 0001"B |

#### 16.2.5.1.5 Test requirements

After step 7 UE shall accept and indicate but not store a class 0 message.

After step 21 UE shall accept and indicate a class 0 message.

#### 16.2.5.2 Test of class 1 short messages

This test shall apply to UEs which support:

- storing of received Class 1 Short Messages; and
- indicating of stored Short Messages.

#### 16.2.5.2.1 Definition

#### 16.2.5.2.2 Conformance requirement

When a mobile terminated message is class 1, the UE shall send an acknowledgement to the SC when the message has successfully reached the UE and can be stored, either in the ME or in the USIM.

### References

3GPP TS 23.038 clause 4.

#### 16.2.5.2.3 Test purpose

This procedure verifies that the UE acts correctly on receiving a class 1 message, i.e. that it stores the message in the ME or USIM and sends an acknowledgement (at RP and CP Layer).

#### 16.2.5.2.4 Method of test

### Initial conditions

- System Simulator:
- 1 cell, default parameters.
- User Equipment:

- the UE shall be in GMM-state "GMM-REGISTERED";
- the UE message store shall be empty;
- for storing of class 1 Short Messages, the UE shall be set up to store Short Messages in the ME memory (by way of MMI, as described in ICS/IXIT statement).

#### Related ICS/IXIT Statements

Support for Short message MT/PP.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

#### Test procedure

- a) The SS delivers a Short Message of class 1 to the UE as specified in clause 16.2.1, step a).
- b) The Short Message is recalled (e.g. by means of the MMI).

#### Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                                                  |
|------|-----------|----|--------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                                           |
| 1    |           |    | Mobile terminated establishment of Radio-Resource-Connection | See 3GPP TS34.108<br><br>Contains RP-DATA RPDU (SMS-DELIVER TPDU), Class 1 Short Message<br><br>Contains RP-ACK RPDU.<br><br>The short message shall be recalled and indicated at the UE. |
| 2    | →         |    | SERVICE REQUEST                                              |                                                                                                                                                                                           |
| 3    |           | ←  | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                                                                                                                                           |
| 4    | →         |    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                                                                                                                                                           |
| 5    |           | ←  | SECURITY MODE COMMAND                                        |                                                                                                                                                                                           |
| 6    | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                           |
| 7    |           | ←  | CP-DATA                                                      |                                                                                                                                                                                           |
| 8    | →         |    | CP-ACK                                                       |                                                                                                                                                                                           |
| 9    | →         |    | CP-DATA                                                      |                                                                                                                                                                                           |
| 10   |           | ←  | CP-ACK                                                       |                                                                                                                                                                                           |
| 11   |           | ←  | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                           |
| 12   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                           |
| 13   | UE        |    |                                                              |                                                                                                                                                                                           |

#### Specific Message Contents

SMS-DELIVER TPDU (containing a class 1 message) (SS to UE)

| Information element | CommentValue                            |
|---------------------|-----------------------------------------|
| TP-DCS              | default alphabet, class 1 "1111 0001" B |

#### 16.2.5.2.5 Test requirements

After step 7 UE shall store the message in the ME or USIM and send an acknowledgement.

### 16.2.5.3 — Test of class 2 short messages

#### 16.2.5.3.1 — Definition

Class 2 Short Messages are defined as USIM-specific, and the UE shall ensure that a message of this class is stored on the USIM.

#### 16.2.5.3.2 — Conformance requirement

When a mobile terminated message is Class 2, the UE shall ensure that the message has been correctly transferred to the SMS data field in the USIM before sending an acknowledgement to the SC. The UE shall return a "protocol error, unspecified" error message if the short message cannot be stored in the USIM and there is other short message storage available at the UE. If all the short message storage at the UE is already in use, the UE shall return "memory capacity exceeded".

#### Reference(s)

3GPP TS 23.040 clause 9.2.3.10; 3GPP TS 23.038 clause 4. 3GPP TS 34.108 clause 8.3.2.28.

#### 16.2.5.3.3 — Test purpose

This procedure verifies that the UE acts correctly on receiving a class 2 message, i.e. that it stores the message correctly in the USIM, and if this is not possible, returns a protocol error message, with the correct error cause, to the network.

There are 2 cases:

- 1) if the UE supports storing of short messages in the USIM and in the ME, and storage in the ME is not full, and the short message cannot be stored in the USIM, the error cause shall be "protocol error, unspecified";
- 2) if the UE supports storing of short messages in the USIM and not in the ME, and storage in the ME is not full, and the short message cannot be stored in the USIM, the error cause shall be "memory capacity exceeded".

NOTE: If the UE supports storing of short messages in the USIM and the ME, and storage in the ME is full, and the short message cannot be stored in the USIM, the error cause shall be "memory capacity exceeded". This case is not tested in this test.

#### 16.2.5.3.4 — Method of test

##### Initial conditions

— System Simulator:

- 1 cell, default parameters.

— User Equipment:

- the UE shall be in GMM-state "GMM-REGISTERED";
- the ME message store shall be empty;
- the ME shall be connected to the USIM simulator. The following shall be present in the USIM simulator:
  - EF<sub>SMS</sub> with at least two free records and one full record;
  - EF<sub>SMSstatus</sub> with SMS "Memory Cap. Exceed" notification flag set to "memory available";
  - Service no. 4 (SMS) in EF<sub>ST</sub> set to allocated and activated;
  - for storing of Class 1 Short Messages the UE shall be set up to store Short Messages in the ME memory (by way of MMI, as described in ICS/IXIT statement).

**Related ICS/IXIT Statements**

Support for Short message MT/PP.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

**Test procedure**

- a) The SS delivers a Short Message of class 2 to the UE as specified in clause 16.2.1, step b).
- b) Following an attempt by the ME to store the short message in a free record of EF<sub>SMS</sub> in the USIM, the USIM simulator returns the status response "OK" ("90 00").
- c) Step a) is repeated.
- d) Following an attempt by the ME to store the short message in a free record of EF<sub>SMS</sub> in the USIM, the USIM simulator returns the status response "memory problem" ("92 40").
- e) The USIM simulator indicates if an attempt was made in steps a) and c) to store the messages and if the messages are stored according to the requirement.

**Expected sequence**

| Step | Direction |      | Message                                                      | Comments                                                                                                                                                                                                                                                                                                                                                                                          |
|------|-----------|------|--------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS   |                                                              |                                                                                                                                                                                                                                                                                                                                                                                                   |
| 1    |           |      | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108                                                                                                                                                                                                                                                                                                                                                                                 |
| 2    |           | →    | SERVICE REQUEST                                              |                                                                                                                                                                                                                                                                                                                                                                                                   |
| 3    |           | ←    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                                                                                                                                                                                                                                                                                                                                                   |
| 4    |           | →    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                                                                                                                                                                                                                                                                                                                                                                   |
| 5    |           | ←    | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                                                                                                                                                                                                                   |
| 6    |           | →    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                                                                                                                                                                                                                                   |
| 7    |           | ←    | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-DELIVER TPDU), Class 2 Short-Message                                                                                                                                                                                                                                                                                                                                   |
| 8    |           | →    | CP-ACK                                                       |                                                                                                                                                                                                                                                                                                                                                                                                   |
| 9    |           | ME   |                                                              | The ME shall correctly store the short message in a free record of EF <sub>SMS</sub> in the USIM, i.e. the ME shall use a free record — the first byte of the record shall indicate "message received by UE from network"<br>— the TS-Service-Centre-Address shall be correctly stored<br>— the TPDU shall be identical to that sent by the SS<br>— bytes following the TPDU shall be set to "FF" |
| 10   |           | USIM |                                                              | The USIM simulator returns the status response "OK" ("90 00"). The USIM simulator shall indicate if an attempt was made by the ME to store the short message in the USIM.                                                                                                                                                                                                                         |
| 11   |           | →    | CP-DATA                                                      | Contains RP-ACK RPDU.                                                                                                                                                                                                                                                                                                                                                                             |
| 12   |           | ←    | CP-ACK                                                       |                                                                                                                                                                                                                                                                                                                                                                                                   |
| 13   |           | ←    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                                                                                                                                                                                                                   |
| 14   |           | →    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                                                                                                                                                                                                                   |
| 15   |           |      | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108                                                                                                                                                                                                                                                                                                                                                                                 |
| 16   |           | →    | SERVICE REQUEST                                              |                                                                                                                                                                                                                                                                                                                                                                                                   |
| 17   |           | ←    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                                                                                                                                                                                                                                                                                                                                                   |
| 18   |           | →    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                                                                                                                                                                                                                                                                                                                                                                   |
| 19   |           | ←    | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                                                                                                                                                                                                                   |



| Step | Direction |    | Message                         | Comments                                                                                                                                                                                                                                                                        |
|------|-----------|----|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                                                                                                                                 |
| 20   | -->       |    | SECURITY MODE COMPLETE          | Contains RP-DATA RPDU (SMS-DELIVER TPDU), Class 2 Short Message                                                                                                                                                                                                                 |
| 21   | <--       |    | CP-DATA                         |                                                                                                                                                                                                                                                                                 |
| 22   | -->       |    | CP-ACK                          |                                                                                                                                                                                                                                                                                 |
| 23   | ME        |    |                                 | The ME shall attempt to store the short message in a free record of EFSMS in the USIM.<br>The USIM simulator returns the status response "memory problem" ("92-40"). The USIM simulator shall indicate if an attempt was made by the ME to store the short message in the USIM. |
| 24   | USIM      |    |                                 |                                                                                                                                                                                                                                                                                 |
| 25   | -->       |    | CP-DATA                         | Contains RP-ERROR RPDU with error cause "protocol error, unspecified" if the UE supports storing of short messages in the ME, or error cause "memory capacity exceeded" if not.                                                                                                 |
| 26   | <--       |    | CP-ACK                          |                                                                                                                                                                                                                                                                                 |
| 27   | <--       |    | RRC CONNECTION RELEASE          |                                                                                                                                                                                                                                                                                 |
| 28   | -->       |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                                                                                                                                 |

### Specific Message Contents

#### SMS-DELIVER TPDU (containing a class 2 message) (SS to UE)

| Information element | CommentValue                           |
|---------------------|----------------------------------------|
| TP-DCS              | default alphabet, class 2 "1111 0010"B |

#### 16.2.5.3.5 Test requirements

After step 10 UE shall confirm that the short message is stored in the USIM and send CP-DATA containing RP-ACK RPDU.

After step 24 UE shall confirm that the short message cannot be stored in the USIM and send CP-DATA containing RP-ERROR RPDU. If UE supports storing of short message in the ME, the error cause of RP-ERROR RPDU shall be "protocol error, unspecified", and if not the error cause of RP-ERROR RPDU shall be "memory capacity exceeded"

#### 16.2.5.4 Test of class 3 short messages

For further study.

#### 16.2.6 Test of short message type 0

For further study.

#### 16.2.7 Test of the replace mechanism for SM type 1-7

##### 16.2.7.1 Definition

##### 16.2.7.2 Conformance requirement

On receipt of a short message, the UE shall check to see if the associated Protocol Identifier contains a Replace Short Message Type code. If such a code is present, then the UE will check the associated originating address (TP-OA) and replace any existing stored message having the same Protocol Identifier code and originating address with the new short message.

#### Reference(s)

3GPP TS 23.040; clause 9.2.3.9.

~~16.2.7.3 Test purpose~~

~~This procedure verifies the correct implementation of the replace mechanism for Replace Short Messages.~~

~~16.2.7.4 Method of test~~~~Initial conditions~~

- ~~— System Simulator:~~
  - ~~— 1 cell, default parameters.~~
- ~~— User Equipment:~~
  - ~~— the UE shall be in GMM-state "GMM-REGISTERED";~~
  - ~~— the UE message store shall be empty.~~

~~Related ICS/IXIT Statements~~

~~Support for Short message MT/PP.~~

~~The value of timer TC1M.~~

~~Test procedure~~

- ~~a) Two different numbers n and m are drawn randomly between 1 and 7. Two different addresses for TP-Originating-Address (TPOA1 and TPOA2) are drawn.~~
- ~~b) The SS delivers a short message to the UE as specified in clause 16.2.1 step a). In the SMS-DELIVER TPDU, the TP-Protocol-Identifier parameter is "Replace Short Message Type n", the TP-Originating-Address is TPOA1, and the RP-Originating-Address is RPOA.~~
- ~~c) Step b) is repeated but with a different TP-Originating-Address (TPOA2), and different contents of TP-User-Data in the SMS-DELIVER TPDU. The other parameters are the same as in step b).~~
- ~~d) –~~
- ~~e) Step c) is repeated but with the TP-Protocol-Identifier equal to "Replace Short Message Type m", and contents of TP-User-Data different from the former two messages. The other parameters are the same as in step c).~~
- ~~f) Step e) is repeated but the contents of TP-User-Data are different from that used in step e).~~
- ~~g) The SS prompts the operator to indicate the Short Messages stored in the UE.~~

~~Expected sequence~~

| Step | Direction |     | Message                                                      | Comments                                                                                                            |
|------|-----------|-----|--------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS  |                                                              |                                                                                                                     |
| 1    |           |     | Mobile terminated establishment of Radio-Resource-Connection | See 3GPP TS34.108                                                                                                   |
| 2    | -->       |     | SERVICE REQUEST                                              |                                                                                                                     |
| 3    | <--       |     | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                                                                     |
| 4    | -->       |     | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                                                                                     |
| 5    | <--       |     | SECURITY MODE COMMAND                                        |                                                                                                                     |
| 6    | -->       |     | SECURITY MODE COMPLETE                                       |                                                                                                                     |
| 7    |           | <-- | CP-DATA                                                      | Contains RP-DATA RPDU (SMS-DELIVER TPDU) TP-PID is "Replace Short Message Type n", TP-OA is TPOA1 and RP-OA is RPOA |
| 8    | -->       |     | CP-ACK                                                       | Contains RP-ACK RPDU.                                                                                               |
| 9    | -->       |     | CP-DATA                                                      |                                                                                                                     |
| 10   | <--       |     | CP-ACK                                                       |                                                                                                                     |
| 11   | <--       |     | RRG-CONNECTION RELEASE                                       |                                                                                                                     |

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                                                                |
|------|-----------|----|--------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                                                         |
| 12   | →         |    | RRC CONNECTION RELEASE COMPLETE                              | See 3GPP TS34.108<br><br>Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-PID is "Replace Short Message Type n", TP-OA is TPOA2 and RP-OA is RPOA1, TP-UD different from step 7<br><br>Contains RP-ACK RPDU. |
| 13   |           |    | Mobile terminated establishment of Radio Resource Connection |                                                                                                                                                                                                         |
| 14   | →         |    | SERVICE REQUEST                                              |                                                                                                                                                                                                         |
| 15   | ←         |    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                                                                                                                                                         |
| 16   | →         |    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                                                                                                                                                                         |
| 17   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                         |
| 18   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                                         |
| 19   | ←         |    | CP-DATA                                                      |                                                                                                                                                                                                         |
| 20   | →         |    | CP-ACK                                                       |                                                                                                                                                                                                         |
| 21   | →         |    | CP-DATA                                                      |                                                                                                                                                                                                         |
| 22   | ←         |    | CP-ACK                                                       |                                                                                                                                                                                                         |
| 23   | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                         |
| 24   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                         |
| 25   |           |    | (void)                                                       |                                                                                                                                                                                                         |
| 26   |           |    | (void)                                                       |                                                                                                                                                                                                         |
| 27   |           |    | (void)                                                       |                                                                                                                                                                                                         |
| 28   |           |    | (void)                                                       |                                                                                                                                                                                                         |
| 29   |           |    | (void)                                                       |                                                                                                                                                                                                         |
| 30   |           |    | (void)                                                       |                                                                                                                                                                                                         |
| 31   |           |    | (void)                                                       |                                                                                                                                                                                                         |
| 32   |           |    | (void)                                                       |                                                                                                                                                                                                         |
| 33   |           |    | (void)                                                       |                                                                                                                                                                                                         |
| 34   |           |    | (void)                                                       |                                                                                                                                                                                                         |
| 35   |           |    | (void)                                                       |                                                                                                                                                                                                         |
| 36   |           |    | (void)                                                       |                                                                                                                                                                                                         |
| 37   |           |    | (void)                                                       | See 3GPP TS34.108                                                                                                                                                                                       |
| 38   | →         |    | SERVICE REQUEST                                              | Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-PID is "Replace Short Message Type m", TP-OA is TPOA2 and RP-OA is RPOA, TP-UD different from step 7 and 19<br><br>Contains RP-ACK RPDU.                    |
| 39   | ←         |    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                                                                                                                                                         |
| 40   | →         |    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                                                                                                                                                                         |
| 41   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                         |
| 42   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                                         |
| 43   | ←         |    | CP-DATA                                                      |                                                                                                                                                                                                         |
| 44   | →         |    | CP-ACK                                                       |                                                                                                                                                                                                         |
| 45   | →         |    | CP-DATA                                                      |                                                                                                                                                                                                         |
| 46   | ←         |    | CP-ACK                                                       |                                                                                                                                                                                                         |
| 47   | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                                                         |
| 48   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                                                         |
| 49   |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108<br><br>Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-PID is "Replace Short Message Type m", TP-OA is TPOA2 and RP-OA is RPOA, TP-UD different from step 43                              |
| 50   | →         |    | SERVICE REQUEST                                              |                                                                                                                                                                                                         |
| 51   | ←         |    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                                                                                                                                                         |
| 52   | →         |    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                                                                                                                                                                         |
| 53   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                                                         |
| 54   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                                                         |
| 55   | ←         |    | CP-DATA                                                      |                                                                                                                                                                                                         |
| 56   | →         |    | CP-ACK                                                       |                                                                                                                                                                                                         |
| 57   | →         |    | CP-DATA                                                      |                                                                                                                                                                                                         |

| Step | Direction |    | Message                         | Comments                                                                                                                                                        |
|------|-----------|----|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                 |                                                                                                                                                                 |
| 58   | <--       |    | GP-ACK                          | Prompts the operator to indicate the Short Messages stored in the UE. Only the Short Messages delivered in step 7, 19 and 55 shall be retrievable and indicated |
| 59   | <--       |    | RRC CONNECTION RELEASE          |                                                                                                                                                                 |
| 60   | -->       |    | RRC CONNECTION RELEASE COMPLETE |                                                                                                                                                                 |
| 61   |           | SS |                                 |                                                                                                                                                                 |

## Specific Message Contents

### SMS-DELIVER TPDU

| Information element | CommentValue                                                                                                          |
|---------------------|-----------------------------------------------------------------------------------------------------------------------|
| TP-MMS<br>TP-PID    | no more messages are waiting in SC—"1"B<br>binary 01000xxx, xxx represents n resp. m (see test<br>method description) |

#### 16.2.7.5 Test requirements

After step 60 only the Short Messages delivered in step 7, 19 and 55 shall be retrieved and indicated.

## 16.2.8 Test of the reply path scheme

### 16.2.8.1 Definition

### 16.2.8.2 Conformance requirement

When a replying UE receives an original mobile terminated short message it has:

- originating SME = TP-Originating Address in the SMS-DELIVER TPDU;
- original SC = RP-Originating Address in the RP-MT-DATA.

When submitting the reply mobile originated short message, the replying UE should use parameters as follows:

- TP-Destination Address in SMS-SUBMIT TPDU = originating SME;
- RP-Destination Address in RP-MO-DATA = original SC.

### Reference(s)

3GPP TS 23.040 Annex D clauses D.5 and D.6.

### 16.2.8.3 Test purpose

This procedure verifies that the UE is able to send a Reply Short Message back to the correct originating SME even if in the meantime it receives another Short Message.

### 16.2.8.4 Method of test

#### Initial conditions

- System Simulator:
- 1 cell, default parameters.
- User Equipment:

- the UE shall be in GMM-state "GMM-REGISTERED";
- the UE message store shall be empty.

#### Related ICS/IXIT Statements

Support for Short message MT/PP.

Support for Short message MO/PP.

The value of timer TC1M.

#### Test procedure

- a) The SS delivers a Short Message as specified in clause 16.2.1, step b) with TP-Reply-Path set to 1.
- b) Step a) is repeated but with:
  - different TP-Originating-Address for the originating SME;
  - different RP-Originating-Address for the original SC; and
  - different message contents TP-User-Data.
- c) UE sends the Reply Short Message corresponding to one of two received Short Messages (e.g. by means of the MMI).
- d) step c) is repeated for the other Short Message.

#### Expected sequence

| Step | Direction |    | Message                                                      | Comments                                                                                                                                                                 |
|------|-----------|----|--------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                              |                                                                                                                                                                          |
| 1    |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108<br><br>Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-RP set to 1<br>Sent within TC1M after step 7<br>Contains RP-ACK RPDU.                               |
| 2    | →         |    | SERVICE REQUEST                                              |                                                                                                                                                                          |
| 3    | ←         |    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                                                                                                                          |
| 4    | →         |    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                                                                                                                                          |
| 5    | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                          |
| 6    | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                          |
| 7    | ←         |    | CP-DATA                                                      |                                                                                                                                                                          |
| 8    | →         |    | CP-ACK                                                       |                                                                                                                                                                          |
| 9    | →         |    | CP-DATA                                                      |                                                                                                                                                                          |
| 10   | ←         |    | CP-ACK                                                       |                                                                                                                                                                          |
| 11   | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                          |
| 12   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                          |
| 13   |           |    | Mobile terminated establishment of Radio Resource Connection | See 3GPP TS34.108<br><br>Contains RP-DATA RPDU (SMS DELIVER TPDU) TP-OA, RP-OA and TP-UD different from step 7<br>Sent within TC1M after step 7<br>Contains RP-ACK RPDU. |
| 14   | →         |    | SERVICE REQUEST                                              |                                                                                                                                                                          |
| 15   | ←         |    | AUTHENTICATION AND CIPHERING REQUEST                         |                                                                                                                                                                          |
| 16   | →         |    | AUTHENTICATION AND CIPHERING RESPONSE                        |                                                                                                                                                                          |
| 17   | ←         |    | SECURITY MODE COMMAND                                        |                                                                                                                                                                          |
| 18   | →         |    | SECURITY MODE COMPLETE                                       |                                                                                                                                                                          |
| 19   | ←         |    | CP-DATA                                                      |                                                                                                                                                                          |
| 20   | →         |    | CP-ACK                                                       |                                                                                                                                                                          |
| 21   | →         |    | CP-DATA                                                      |                                                                                                                                                                          |
| 22   | ←         |    | CP-ACK                                                       |                                                                                                                                                                          |
| 23   | ←         |    | RRC CONNECTION RELEASE                                       |                                                                                                                                                                          |
| 24   | →         |    | RRC CONNECTION RELEASE COMPLETE                              |                                                                                                                                                                          |

| Step | Direction |    | Message                               | Comments                                                                                                                                                        |
|------|-----------|----|---------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                       |                                                                                                                                                                 |
| 25   | UE        |    |                                       | UE sends the Reply Short Message corresponding to one of two received Short Messages.                                                                           |
| 26   | ←         |    | SYSTEM INFORMATION                    | BCCH                                                                                                                                                            |
| 27   | →         |    | RRC CONNECTION REQUEST                | CCCH                                                                                                                                                            |
| 28   | ←         |    | RRC CONNECTION SETUP                  | CCCH                                                                                                                                                            |
| 29   | →         |    | RRC CONNECTION SETUP COMPLETE         | DCCH                                                                                                                                                            |
| 30   | →         |    | SERVICE REQUEST                       |                                                                                                                                                                 |
| 31   | ←         |    | AUTHENTICATION AND CIPHERING REQUEST  |                                                                                                                                                                 |
| 32   | →         |    | AUTHENTICATION AND CIPHERING RESPONSE |                                                                                                                                                                 |
| 33   | ←         |    | SECURITY MODE COMMAND                 |                                                                                                                                                                 |
| 34   | →         |    | SECURITY MODE COMPLETE                |                                                                                                                                                                 |
| 35   | →         |    | CP-DATA                               | Contains RP-DATA RPDU (SMS-SUBMIT TPDU) RP-DA = RP-OA corresponding to the message TP-DA = TP-OA corresponding to the message<br>Sent within TC1M after step 35 |
| 36   | ←         |    | CP-ACK                                | Contains RP-ACK RPDU                                                                                                                                            |
| 37   | ←         |    | CP-DATA                               | Waits max 25 s for CP-ACK                                                                                                                                       |
| 38   | SS        |    |                                       |                                                                                                                                                                 |
| 39   | →         |    | CP-ACK                                |                                                                                                                                                                 |
| 40   | ←         |    | RRC CONNECTION RELEASE                | RRC connection is released.                                                                                                                                     |
| 41   | →         |    | RRC CONNECTION RELEASE COMPLETE       |                                                                                                                                                                 |
| 42   | UE        |    |                                       | UE sends the Reply Short Message corresponding to other Short Message.                                                                                          |
| 43   | ←         |    | SYSTEM INFORMATION                    | BCCH                                                                                                                                                            |
| 44   | →         |    | RRC CONNECTION REQUEST                | CCCH                                                                                                                                                            |
| 45   | ←         |    | RRC CONNECTION SETUP                  | CCCH                                                                                                                                                            |
| 46   | →         |    | RRC CONNECTION SETUP COMPLETE         | DCCH                                                                                                                                                            |
| 47   | →         |    | SERVICE REQUEST                       |                                                                                                                                                                 |
| 48   | ←         |    | AUTHENTICATION AND CIPHERING REQUEST  |                                                                                                                                                                 |
| 49   | →         |    | AUTHENTICATION AND CIPHERING RESPONSE |                                                                                                                                                                 |
| 50   | ←         |    | SECURITY MODE COMMAND                 |                                                                                                                                                                 |
| 51   | →         |    | SECURITY MODE COMPLETE                |                                                                                                                                                                 |
| 52   | →         |    | CP-DATA                               | Contains RP-DATA RPDU (SMS-SUBMIT TPDU) RP-DA = RP-OA corresponding to the Message TP-DA = TP-OA corresponding to the message<br>Sent within TC1M after step 52 |
| 53   | ←         |    | CP-ACK                                | Contains RP-ACK RPDU                                                                                                                                            |
| 54   | ←         |    | CP-DATA                               | Waits max 25 s for CP-ACK                                                                                                                                       |
| 55   | SS        |    |                                       |                                                                                                                                                                 |
| 56   | →         |    | CP-ACK                                |                                                                                                                                                                 |
| 57   | ←         |    | RRC CONNECTION RELEASE                | RRC connection is released.                                                                                                                                     |
| 58   | →         |    | RRC CONNECTION RELEASE COMPLETE       |                                                                                                                                                                 |

### Specific Message Contents

#### SMS-DELIVER TPDU

| Information element | Comment/Value                            |
|---------------------|------------------------------------------|
| TP-MMS              | no more messages are waiting in SC "1" B |
| TP-RP               | Reply Path exists "1" B                  |

### 16.2.8.5 Test requirements

After step 34 UE shall send the Reply Short Message corresponding to one of two previously received short messages.

After step 51 UE shall send the Reply Short Message corresponding to the other of two previously received short messages.

## ~~16.2.9 Multiple SMS mobile originated~~

### ~~16.2.9.1 UE in idle mode~~

This test is not applicable for R99.

### ~~16.2.9.2 UE in active mode~~

This test is not applicable for R99.

## ~~16.2.10 Test of capabilities of simultaneously receiving a short message whilst sending a mobile originated short message~~

### ~~16.2.10.1 Definition~~

### ~~16.2.10.2 Conformance requirements~~

An active UE shall be able to receive short message TPDU (SMS-SUBMIT) at any time, independently of whether or not there is in SMS mobile originated.

### ~~Reference~~

3GPP TS 23.040 clause 3.1.

### ~~16.2.10.3 Test purpose~~

The test verifies that the UE is capable of simultaneously receiving a network originated SM whilst sending a mobile originated SM.

### ~~16.2.10.4 Method of test~~

### ~~Initial Conditions~~

- ~~— System simulator:~~
  - ~~— 1 cell, default parameters.~~
- ~~— User Equipment:~~
  - ~~— the UE shall be in GMM-state "GMM-REGISTERED";~~
  - ~~— the SMS message storage shall be empty.~~

### ~~Related ICS/IXIT Statements~~

Support for Short message MO/PP and MT/PP.

Support for state PDP-ACTIVE of session management.

The value of timer TC1M.

Whether SMS messages are stored in the USIM and/or the ME.

Maximum length (characters) of a mobile originated short message.

Test procedure

- a) The SS is configured to receive a mobile originated SM. In clause 16.2.2 steps a) and b) are repeated and, using the end of the CP-DATA message from the UE as a trigger, the SS sends a SM to the UE. In this case a new transaction identifier shall be used in the CP messages of SMS mobile terminated.

Expected sequence

| Step                                                                                                                                          | Direction |    | Message                               | Comments                                                                                                                                                                                                                                                                                                                                                                            |
|-----------------------------------------------------------------------------------------------------------------------------------------------|-----------|----|---------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                               | UE        | SS |                                       |                                                                                                                                                                                                                                                                                                                                                                                     |
| 1                                                                                                                                             |           | ←  | SYSTEM INFORMATION                    | BCCH                                                                                                                                                                                                                                                                                                                                                                                |
| 2                                                                                                                                             |           | →  | RRC CONNECTION REQUEST                | CCCH                                                                                                                                                                                                                                                                                                                                                                                |
| 3                                                                                                                                             |           | ←  | RRC CONNECTION SETUP                  | CCCH                                                                                                                                                                                                                                                                                                                                                                                |
| 4                                                                                                                                             |           | →  | RRC CONNECTION SETUP COMPLETE         | DCCH                                                                                                                                                                                                                                                                                                                                                                                |
| 5                                                                                                                                             |           | →  | SERVICE REQUEST                       |                                                                                                                                                                                                                                                                                                                                                                                     |
| 6                                                                                                                                             |           | ←  | AUTHENTICATION AND CIPHERING REQUEST  |                                                                                                                                                                                                                                                                                                                                                                                     |
| 7                                                                                                                                             |           | →  | AUTHENTICATION AND CIPHERING RESPONSE |                                                                                                                                                                                                                                                                                                                                                                                     |
| 8                                                                                                                                             |           | ←  | SECURITY MODE COMMAND                 |                                                                                                                                                                                                                                                                                                                                                                                     |
| 9                                                                                                                                             |           | →  | SECURITY MODE COMPLETE                |                                                                                                                                                                                                                                                                                                                                                                                     |
| 10                                                                                                                                            |           | →  | CP-DATA                               | Contains RP-DATA RPDU (SMS SUBMIT TPDU)                                                                                                                                                                                                                                                                                                                                             |
| 11                                                                                                                                            |           | SS |                                       | The SS sends an SM to the UE triggered by the end of the CP-DATA message from the UE                                                                                                                                                                                                                                                                                                |
| 12                                                                                                                                            |           | ←  | CP-DATA                               | Contains RP-DATA RPDU (SMS DELIVER TPDU)                                                                                                                                                                                                                                                                                                                                            |
| 13                                                                                                                                            |           | UE |                                       | The UE shall correctly receive the SM and indicate that a message has arrived. In the MO case the UE shall send the CP-ACK message with transaction identifier assigned to this transfer. In the MT case the UE shall send a CP-ACK message and a CP-DATA message containing the RP-ACK RPDU. The transaction identifier shall be the same as chosen by the SS for the MT transfer. |
| NOTE: Time values for SS wait times are chosen sufficiently high to be sure that the UE has enough time to respond to the different messages. |           |    |                                       |                                                                                                                                                                                                                                                                                                                                                                                     |

Specific Message Contents

SMS SUBMIT TPDU

| Information element              | CommentValue                                                                                                  |
|----------------------------------|---------------------------------------------------------------------------------------------------------------|
| TP-UDL<br>TP-UD (140 octets max) | as applicable<br>maximum number of characters (text of message) as defined by the manufacturer (see ICS/IXIT) |

16.2.10.5 Test requirements

After step 12 UE shall correctly receive the SM and indicate that a message has arrived.

16.3 Short message service cell broadcast

16.3.1 Definition

16.3.2 Conformance requirements

In idle mode, the UE listens to the BCCH and to the paging sub-channel for the paging group it belongs to. The UE is required to receive and analyse the paging messages and immediate assignment messages sent on the paging subchannel corresponding to its paging subgroup.



## Reference

- 3GPP TS 23.041 clause 8.
- 3GPP TS 25.324 clause 11.

### 16.3.3 Test purpose

This test verifies that an UE supporting SMS-CB is able to receive SMS-CB messages.

### 16.3.4 Method of test

#### Initial conditions

- System Simulator:
  - 1 cell, default parameters;
  - the SS provides a BCCH/CCCH to support the UE in idle mode;
  - periodic location updating is disabled.
- User Equipment:
  - the UE shall be in the idle updated state.

#### Related ICS/IXIT Statements

Support for short message transmission-cell broadcast.

#### Test procedure

Three Cell Broadcast (CB) messages are sent by the SS on the CBCH with message codes 0,1,1 in serial number fields respectively.

The UE shall respond to the page.

#### Expected sequence

Since the SMS-CB messages are sent continuously, a table is not applicable in this test.

#### Specific Message Contents:

#### Cell broadcast test message content

| Information element  | CommentValue                                       |
|----------------------|----------------------------------------------------|
| Message Type         | CBS Message "1"B (see 3GPP TS 25.324, clause 11.1) |
| Message ID           |                                                    |
| Serial Number        |                                                    |
| — Geographical scope | "00"B                                              |
| — Message code       | see test procedure "0000000000"B or "0000000001"B  |
| — Update number      | as applicable                                      |
| Data Coding Scheme   | Default alphabet, English "00000001"B              |
| CB Data              | max 1246 octets                                    |

### 16.3.5 Test requirements

In consequence of test the UE shall ignore third message and store two messages.

## 16.4 Default message contents:

### 16.4.1 Default message contents for SM-CP protocol

#### CP-DATA

|                        |                                    |
|------------------------|------------------------------------|
| Protocol Discriminator | SMS messages ("1001"B)             |
| Transaction Identifier |                                    |
| — TIO                  | any value from the set {0, ..., 6} |
| — TI flag              | 0                                  |
| Message type           | 00000001                           |
| CP-User data           |                                    |
| — length indicator     |                                    |
| — RPDU                 | max 248 octets                     |

#### CP-ACK

|                        |                        |
|------------------------|------------------------|
| Protocol Discriminator | SMS messages ("1001"B) |
| Transaction Identifier |                        |
| — TIO                  |                        |
| — TI flag              |                        |
| Message type           | 00000100               |

#### CP-ERROR

|                        |                                    |
|------------------------|------------------------------------|
| Protocol Discriminator | SMS messages ("1001"B)             |
| Transaction Identifier |                                    |
| — TIO                  |                                    |
| — TI flag              |                                    |
| Message type           | 00010000                           |
| CP-Cause               |                                    |
| — Cause value          | see 3GPP TS 24.011, clause 8.1.4.2 |

### 16.4.2 Default message contents for SM-RP protocol

#### RP-DATA

| Information element    | Comment Value                      |
|------------------------|------------------------------------|
| RP-Message Type        | "001"B (SS->UE) or "000"B (UE->SS) |
| RP-Message Reference   | see 3GPP TS 24.011, clause 8.2.3   |
| RP-Originator Address  | see 3GPP TS 24.011, clause 8.2.5.1 |
| RP-Destination Address | see 3GPP TS 24.011, clause 8.2.5.2 |
| RP-User Data           | see 3GPP TS 24.011, clause 8.2.5.3 |
| — Length indicator     |                                    |
| — TP-DATA              | max 233 octets                     |

#### RP-ACK

| Information element  | Comment Value                                                        |
|----------------------|----------------------------------------------------------------------|
| RP-Message Type      | "010"B (UE->SS) or "011"B (SS->UE)                                   |
| RP-Message Reference | see 3GPP TS 24.011, clause 8.2.3                                     |
| RP-User Data         | see 3GPP TS 24.011, clause 8.2.5.3 : optional, may be present or not |
| — RP-User Data IEI   | "1000001"B                                                           |
| — Length indicator   |                                                                      |
| — TP-Data            | max 232 octets                                                       |

## RP-ERROR

| Information element  | Comment Value                                                       |
|----------------------|---------------------------------------------------------------------|
| RP-Message Type      | "100"B (UE->SS) or "101"B(SS->UE)                                   |
| RP-Message Reference | see 3GPP TS 24.011, clause 8.2.3                                    |
| RP-Cause             | see 3GPP TS 24.011, clause 8.2.5.4                                  |
| RP-User Data         | see 3GPP TS 24.011, clause 8.2.5.3: optional, may be present or not |
| — RP-User Data IEI   | "1000001"B                                                          |
| — Length indicator   |                                                                     |
| — TP-Data            | max 232 octets                                                      |

## RP-SMMA-UE-&gt;SS)

| Information element  | Comment Value                    |
|----------------------|----------------------------------|
| RP-Message Type      | "110"B (UE->SS)                  |
| RP-Message Reference | see 3GPP TS 24.011, clause 8.2.3 |

~~16.4.3 Default message contents for SM-TP protocol~~

## SMS-DELIVER-TPDU

| Information element | Comment Value                        |
|---------------------|--------------------------------------|
| TP-MTI              | SMS-DELIVER—"00"B                    |
| TP-MMS              | more messages are waiting in SC—"0"B |
| TP-RP               | no reply path—"0"B                   |
| TP-UDHI             | TP-UD contains only the SM—"0"B      |
| TP-SRI              | no status report returned—"0"B       |
| TP-OA               | an international number coded E.164  |
| TP-PID              | default—"00000000"B                  |
| TP-DCS              | default alphabet—"00000000"B         |
| TP-SCTS             | any legal value (cf. 3GPP TS 23.040) |
| TP-UDL              |                                      |
| TP-UD               | max 140 octets                       |

## SMS-SUBMIT-TPDU

| Information element | Comment Value                        |
|---------------------|--------------------------------------|
| TP-MTI              | SMS-SUBMIT—"01"B                     |
| TP-RD               | SC shall accept same SMS-SUBMIT—"0"B |
| TP-VPF              | TP-VP field not present—"00"B        |
| TP-RP               | no reply path—"0"B                   |
| TP-UDHI             | TP-UD contains only the SM—"00"B     |
| TP-SRR              | no request of status report—"00"B    |
| TP-MR               |                                      |
| TP-DA               | an international number coded E.164  |
| TP-PID              | default—"00000000"B                  |
| TP-DCS              | default alphabet—"00000000"B         |
| TP-VP               |                                      |
| TP-UDL              |                                      |
| TP-UD               | max 140 octets                       |

## SMS-COMMAND-TPDU

| Information element | Comment-Value                      |
|---------------------|------------------------------------|
| TP-MTI              | SMS-COMMAND"10"B                   |
| TP-UDHI             | TP-UD-contains-only-the-SM-"00"B   |
| TP-SRR              | status-report-not-requested—"0"B   |
| TP-MR               |                                    |
| TP-PID              | default"00000000"B                 |
| TP-CT               |                                    |
| TP-MN               |                                    |
| TP-DA               | an-international-number-coded-E164 |
| TP-CDL              |                                    |
| TP-CD               |                                    |

## SMS-STATUS-REPORT-TPDU

| Information element | Comment-Value                                         |
|---------------------|-------------------------------------------------------|
| TP-MTI              | SMS-STATUS-REPORT"10"B                                |
| TP-MMS              | no-more-messages—"1"B                                 |
| TP-SRQ              | result-of-SMS-SUBMIT—"0"B                             |
| TP-MR               |                                                       |
| TP-RA               | the-destination-address-of-the-previous-SM-MO         |
| TP-SCTS             | any-legal-value-(cf. 3GPP TS 23.040, clause 9.2.3.11) |
| TP-DT               | any-legal-value-(cf. 3GPP TS 23.040, clause 9.2.3.13) |
| TP-ST               | see 3GPP TS 23.040, clause 9.2.3.15                   |

## 17 User Equipment features (MMI, VHE, MexE, SAT)

### 17.1 Test of autocalling restrictions

#### 17.1.1 General

It is essential that all autocalling apparatus is prevented from continuously dialling a given number, to avoid machines repeatedly disturbing PSTN-subscribers in error, or numerous repeat attempts to unobtainable numbers which cause waste of valuable network resources. Therefore autocalling restrictions are defined by TS 22.001.

The tests shall be performed using all of the call methods specified by the supplier in the IXIT statement TS 34.123-2. The supplier shall state any autocalling procedures implemented and how many times they can be repeated to a single number and the minimum re-attempt interval(s), i.e. the complete re-try schedule or algorithm with parameter values. The supplier shall further describe any automatic methods for making repeated calls to a single number. The supplier shall also state in the IXIT statement the number of B-party numbers that can be stored on the list of blacklisted numbers as described in TS 22.001, annex E.

For an external R-interface the supplier shall state in the IXIT statement the procedure for autocalling restrictions for that interface and the possible parameter settings for the number of times the LTE can make a re-attempt and the minimum accepted time between re-attempts accepted by the UE. The conditions for clearing the autocalling constraints shall be stated in the IXIT statement.

For external interfaces the LTE must be programmed so that it clearly attempts to violate the autocalling constraints.

For all the tests in this clause the call setup procedure uses the Generic Setup Procedure for Circuit Switched connection as specified in TS 34.108 clause 7. A Radio Access Bearer to set up shall be selected from one of the speech or CS data bearers within the capability of the UE as specified in the ICS statement. Unless otherwise indicated, this procedure shall only run to the transmission by the SS or UE of the SETUP message (CC).

## ~~17.1.2 Constraining the access to a single number (TS 22.001 category 3)~~

### ~~17.1.2.1 Definition~~

This test checks that when an auto-dialled call to a B-party number fails due to a category 3 cause, only one retry to that number is permitted.

During this test the SETUP messages shall contain the same B-party number.

No manual intervention shall be performed except to initiate and end the test.

### ~~17.1.2.2 Conformance requirement~~

A repeat call attempt may be made when a call attempt is unsuccessful for the reasons listed below (as defined in TS 24.008).

These reasons are classified in three major categories:

1. "Busy destination";
2. "Unobtainable destination – temporary";
3. "Unobtainable destination – permanent/long term".

NOTE: Cause values for each category are defined in TS 22.001, annex E.

The table below describes a repeat call restriction pattern to any B-number. This pattern defines a maximum number (n) of call repeat attempts; when this number n is reached, the associated B-number shall be blacklisted by the UE until a manual re-set at the UE is performed in respect of that B-number. When a repeat attempt to any one B-number fails, or is blacklisted, this does not prevent calls being made to other B-numbers.

For the categories 1 and 2 above, n shall be 10; for category 3, n shall be 1.

| Call attempt         | Minimum duration between call attempts |
|----------------------|----------------------------------------|
| Initial call attempt | -                                      |
| 1st repeat attempt   | 5 s                                    |
| 2nd repeat attempt   | 1 min                                  |
| 3rd repeat attempt   | 1 min                                  |
| 4th repeat attempt   | 1 min                                  |
| 5th repeat attempt   | 3 min                                  |
| —                    |                                        |
| —                    |                                        |
| nth repeat attempt   | 3 min                                  |

Reference:

3GPP TS 22.001 annex E.

### ~~17.1.2.3 Test purpose~~

To ensure the correct behaviour of the UE to TS 22.001 Category 3.

### ~~17.1.2.4 Method of test~~

Initial condition.

There shall be no numbers in the list of blacklisted numbers in the UE. The time set between the first re-attempt and the next re-attempt is set to the minimum value possible. The number of re-attempts is set to the lowest possible number, greater than 1, that is supported by the UE. The autocalling function is invoked for the B-party number to be used during the test.

**Related ICS/IXIT Statement(s)**ICS: ~~—— TBD.~~IXIT: ~~—— Description of auto-calling management:~~

- ~~—— selection of the auto-calling;~~
- ~~—— indication that the call failed and a re-try is attempted;~~
- ~~—— indication that a call finally failed.~~

**Test Procedure**

| Step | Direction |    | Message                                                     | Comments                                                                                           |
|------|-----------|----|-------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                             |                                                                                                    |
| 1    | UE        |    |                                                             | "called number" entered                                                                            |
| 2    |           | →  | GENERIC SETUP PROCEDURE MOBILE ORIGINATED, CS (Up to SETUP) | Establishment cause indicates "originating call".                                                  |
| 3    |           | ←  | RELEASE COMPLETE                                            | Cause value from category 3 of TS 22.001, Annex E.                                                 |
| 4    |           | ←  | RRC CONNECTION RELEASE                                      |                                                                                                    |
| 5    |           | →  | RRC CONNECTION RELEASE COMPLETE                             | The signalling link is released                                                                    |
| 6    |           |    |                                                             | The UE is invoking the auto-calling function. The time between step 4 and 7 must be minimum 5 sec. |
| 7    |           | →  | GENERIC SETUP PROCEDURE MOBILE ORIGINATED, CS (Up to SETUP) | Establishment cause indicates "originating call".                                                  |
| 8    |           | ←  | RELEASE COMPLETE                                            | Cause value from category 3 of TS 22.001, Annex E.                                                 |
| 9    |           | ←  | RRC CONNECTION RELEASE                                      |                                                                                                    |
| 10   |           | →  | RRC CONNECTION RELEASE COMPLETE                             | The main signalling link is released                                                               |
| 11   | UE        |    |                                                             | Clear the auto-calling constraint after a minimum of 2 minutes from step 9.                        |

**17.1.2.5 ~~—— Test requirements~~**

The time between step 4 and 7 must be minimum 5 s.

No further call attempt shall be made after step 9.

**17.1.3 ~~Constraining the access to a single number (TS 22.001 categories 1 and 2)~~****17.1.3.1 ~~—— Definition~~**

This test checks that when an auto-dialled call to a B-party number fails due to a category 2 cause, the time between of retries complies with the requirements, and the number of retries does not exceed that declared by the UE manufacturer, and is never more than 10.

During this test the SETUP messages shall contain the same B-party number.

No manual intervention shall be performed except to initiate and end the test.

**17.1.3.2 ~~Conformance requirement~~**

The UE must fulfil the requirements for category 1 and 2, see clause 17.1.2.2.

**Reference:**

3GPP TS 22.001 annex E.

### ~~17.1.3.3 Test purpose~~

~~To ensure the correct behaviour of the UE to TS 22.001 Categories 1 and 2.~~

### ~~17.1.3.4 Method of test~~

#### ~~Initial condition~~

~~There shall be no numbers in the list of blacklisted numbers in the UE. The re-try scheme is set to give the shortest possible intervals between re-tries. The number of re-attempts is set to the maximum possible number (N), that is supported by the UE. The autocalling function is invoked for the B-party number to be used during the test.~~

#### ~~Related ICS/EXIT Statement(s)~~

~~ICS: TBD~~

~~EXIT: Description of auto-calling management:~~

- ~~— selection of the auto-calling;~~
- ~~— indication that the call failed and a re-try is attempted;~~
- ~~— indication that a call finally failed.~~

#### ~~Test Procedure~~

~~A, UE originated, generic call setup is performed up to the SETUP message. The SS then releases the establishment with a cause value from category 1 or 2 (TS 22.001, annex E).~~

~~The UE is continuously making new generic call setup attempts invoked by the auto-calling function after each RRC CONNECTION RELEASE from the SS.~~

| Step | Direction |    | Message                                                           | Comments                                                                                                                                                                                                                                                                                                                                                                    |
|------|-----------|----|-------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                                                   |                                                                                                                                                                                                                                                                                                                                                                             |
| 1    | UE        |    |                                                                   | "called number" entered                                                                                                                                                                                                                                                                                                                                                     |
| 2    | →         |    | GENERIC SETUP PROCEDURE<br>MOBILE-ORIGINATED, CS (Up to<br>SETUP) | Establishment cause indicates "originating call".                                                                                                                                                                                                                                                                                                                           |
| 3    | ←         |    | RELEASE COMPLETE                                                  | Cause value from category 1 or 2 of TS 22.001, Annex E. This shall be chosen randomly, from both categories. Cause no. 27 shall be excluded if the UE has implemented in category 3 of TS 22.001, as declared in I_XIT statement                                                                                                                                            |
| 4    | ←         |    | RRC CONNECTION RELEASE                                            | The UE is invoking the auto calling function. 1: At the first re-attempt the time between step 4 and 7 must be minimum 5 sec. 2: At the 2 <sup>nd</sup> , 3 <sup>rd</sup> and 4 <sup>th</sup> re-attempt the time between step 4 and 7 must be minimum 1 min. 3: At the 5 <sup>th</sup> to 10 <sup>th</sup> re-attempt the time between step 4 and 7 must be minimum 3 min. |
| 5    |           |    |                                                                   |                                                                                                                                                                                                                                                                                                                                                                             |
| 6    | →         |    | RRC CONNECTION RELEASE<br>COMPLETE                                | The signalling link is released                                                                                                                                                                                                                                                                                                                                             |
| 7    | →         |    | GENERIC SETUP PROCEDURE<br>MOBILE-ORIGINATED, CS (Up to<br>SETUP) | Establishment cause indicates "originating call".                                                                                                                                                                                                                                                                                                                           |
| 8    | ←         |    | RELEASE COMPLETE                                                  | Cause value from category 1 or 2 of TS 22.001, Annex E. This shall be chosen randomly, from both categories. Cause no. 27 shall be excluded if the UE has implemented in category 3 of TS 22.001, as declared in I_XIT statement                                                                                                                                            |
| 9    | ←         |    | RRC CONNECTION RELEASE                                            | The signalling link is released.                                                                                                                                                                                                                                                                                                                                            |
| 10   | →         |    | RRC CONNECTION RELEASE<br>COMPLETE                                |                                                                                                                                                                                                                                                                                                                                                                             |
| 11   |           |    |                                                                   | The auto calling function shall repeat step 5 to 9 (N-1) times. The UE shall not make more than maximum 10 re-attempts.                                                                                                                                                                                                                                                     |
| 12   | UE        |    |                                                                   | Clear the auto calling constraint by manual intervention after a minimum of 4 minutes from step 11. Following the final completion of step 11 the UE initiate a call prior to manual intervention.                                                                                                                                                                          |

### 17.1.3.5 Test requirements

1: At the first re-attempt the time between step 4 and 7 must be minimum 5 sec. 2: At the 2<sup>nd</sup>, 3<sup>rd</sup> and 4<sup>th</sup> re-attempt the time between step 4 and 7 must be minimum 1 min. 3: At the 5<sup>th</sup> to 10<sup>th</sup> re-attempt the time between step 4 and 7 must be minimum 3 min.

The UE shall not make more than maximum 10 re-attempts.

## 17.1.4 Behaviour of the UE when its list of blacklisted numbers is full

### 17.1.4.1 Definition and applicability

This tests that the UE does not allow autocalling when its list of blacklisted numbers is full.

The number of B-party numbers that can be stored in the list of blacklisted numbers, as stated in the I\_XIT statement, is M.

This test shall only apply to UE that are capable of autocalling more than M B-party numbers.

### 17.1.4.2 Conformance requirement

The number of B numbers that can be held in the blacklist is at the manufacturers discretion but there shall be at least 8. However, when the blacklist is full the UE shall prohibit further automatic call attempts to any one number until the blacklist is manually cleared at the UE in respect of one or more B numbers.



## Reference

TS 22.001, Annex E.

### 17.1.4.3 Test purpose

To ensure the correct behaviour of the UE when its list of blacklisted numbers is full.

### 17.1.4.4 Method of test

#### Initial condition

The list of blacklisted numbers, in the UE, shall be full. This may be achieved as described in the procedure in clause 17.1.2, applied to M-B-party numbers.

#### Related ICS/IXIT Statement(s)

PICS: TBD.

PIXIT: Description of auto-calling management:

- selection of the auto-calling;
- indication that the call failed and a re-try is attempted;
- indication that a call finally failed.

#### Test Procedure

The autocalling function is invoked for a B-party number that is not in the list of blacklisted numbers.

Clear the autocalling constraint by manual intervention after a minimum of 10 s.

### 17.1.4.5 Test requirements

The UE must not initiate a call.

---

## 18 Multi-Layer Functional Tests

The present clause specifies the multi-layer functional test cases that are not covered by the interoperability radio bearer test cases in clause 14 or by any other test cases in the present document.

### 18.1 Radio Bearer Tests for 1.28 Mcps TDD option

#### 18.1.1 General information for radio bearer tests (1.28 Mcps TDD)

The purpose of these radio bearer test cases is to test properly the Reference Radio Bearer configurations included in TS34.108 [9], clause 6.11 for 1.28 Mcps TDD option.

The applicability of radio bearer tests is dependent on the UE uplink and downlink radio access capabilities and UE support tele- and bearer-services. See TS 34.123-2, annex B for applicability of the specific test cases.

##### 18.1.1.1 Generic radio bearer test procedure

#### Initial conditions

UE in idle mode

### Test procedure

- a) ~~The SS setup the reference radio bearer configuration as specified in TS 34.108, clause 6.11 for the actual radio bearer test.~~
- b) ~~The SS limits the UE allowed uplink transport format combinations according to the "Restricted UL TFCIs", as specified for the sub-test of the actual radio bearer test, using the RRC transport format combination control procedure.~~
- c) ~~The SS closes the test loop using UE test loop mode 1 and setting the UL RLC SDU size parameter, for all radio bearers under test, according to the "UL RLC SDU size" value as specified for the sub-test of the actual radio bearer test.~~
- d) ~~The SS transmits, for all radio bearers under test, an RLC SDU having the size equal to the "Test data size" as specified for the sub-test of the actual radio bearer test. See note 1.~~
- e) ~~The SS checks that, for all radio bearers under test, the content of the received RLC SDU has the correct content and is received having the correct transport format. See TS 34.109 [10] clause 5.3.2.6.2 for details regarding the UE loopback of RLC SDUs.~~
- f) ~~The SS opens the UE test loop.~~
- g) ~~Steps b) to f) are repeated for all sub-tests~~
- h) ~~The SS may optionally release the radio bearer.~~
- i) ~~The SS may optionally deactivate the radio bearer test mode.~~

~~NOTE: For the case when the reference radio bearer configuration under test uses RLC transparent mode in downlink then the radio bearer test case shall use a DL RLC SDU size (defined by the "Test data size" parameter) equal to the DL RLC PDU size. This is due to that the UE test loop function has no ability to perform reassembly of segmented DL RLC SDUs while the RLC is operated in transparent mode. See [7] TS 25.322 for details regarding UE operation in RLC transparent mode.~~

## Expected sequence

| Step | Direction |    | Message                                   | Comments                                                                                                                       |
|------|-----------|----|-------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
|      | UE        | SS |                                           |                                                                                                                                |
| 1    | <--       |    | SYSTEM INFORMATION (BCCH)                 | Broadcast                                                                                                                      |
| 2    | <--       |    | PAGING (PCCH)                             | Paging                                                                                                                         |
| 3    | -->       |    | RRC CONNECTION REQUEST (CCCH)             | RRC                                                                                                                            |
| 4    | <--       |    | RRC CONNECTION SETUP (CCCH)               | RRC                                                                                                                            |
| 5    | -->       |    | RRC CONNECTION SETUP COMPLETE (DCCH)      | RRC                                                                                                                            |
| 6    | -->       |    | PAGING RESPONSE (DCCH)                    | RR                                                                                                                             |
| 7    | <--       |    | ACTIVATE RB TEST MODE (DCCH)              | TC                                                                                                                             |
| 8    | -->       |    | ACTIVATE RB TEST MODE COMPLETE (DCCH)     | TC                                                                                                                             |
| 9    | <--       |    | RADIO BEARER SETUP (DCCH)                 | RRC                                                                                                                            |
| 10   | -->       |    | RADIO BEARER SETUP COMPLETE (DCCH)        | RRC                                                                                                                            |
| 11   | <--       |    | TRANSPORT FORMAT COMBINATION CONTROL      | RRC<br>Transport format combinations is limited to "Restricted UL TFCIs", as specified for the sub-test                        |
| 12   | <--       |    | CLOSE UE TEST LOOP                        | TC<br>UE test mode 1<br>RLC SDU size is for every active radio bearer set to "UL RLC SDU size", as specified for the sub-test. |
| 13   | -->       |    | CLOSE UE TEST LOOP COMPLETE (DCCH)        | TC                                                                                                                             |
| 14   | <--       |    | DOWNLINK RLC SDU                          | Send test data using the downlink transport format combination under test                                                      |
| 15   | -->       |    | UPLINK RLC SDU                            |                                                                                                                                |
| 16   | <--       |    | OPEN UE TEST LOOP                         | TC                                                                                                                             |
| 17   | -->       |    | OPEN UE TEST LOOP COMPLETE                | TC                                                                                                                             |
| 18   |           |    | Repeat steps 11 to 17 for every sub-test. |                                                                                                                                |
| 19   |           |    | RB RELEASE                                | RRC<br>Optional step                                                                                                           |
| 20   | <--       |    | DEACTIVATE RB TEST MODE                   | TC<br>Optional step                                                                                                            |
| 21   | -->       |    | DEACTIVATE RB TEST MODE COMPLETE          | TC<br>Optional step                                                                                                            |

~~18.1.2 Combinations on DPCH~~~~18.1.2.1 Stand-alone UL:1.7 DL:1.7 kbps SRBs for DCCH~~~~Implicitly tested.~~~~18.1.2.2 Stand-alone UL:3.4 DL:3.4 kbps SRBs for DCCH~~~~Implicitly tested.~~~~18.1.2.3 Stand-alone UL:13.6 DL:13.6 kbps SRBs for DCCH~~~~Implicitly tested.~~~~18.1.2.4 Conversational / speech / UL:12.2 DL:12.2 kbps / CS-RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~~~18.1.2.4.1 Conformance requirement~~~~The UE shall be able to establish the UTRAN requested radio bearers within the UE's signaled radio access capabilities.~~

The UE shall correctly transfer user data from peer to peer RLC entities according to the requested radio bearer configuration.

#### Reference(s)

3GPP TS 25.331, clause 8.2.1

3GPP TS 25.2xx series (Physical Layer)

3GPP TS 25.321 (MAC)

3GPP TS 25.322 (RLC)

#### 18.1.2.4.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.11.5.4.1.4.

#### 18.1.2.4.3 Method of test

Uplink TFS:

|     | TFI       | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 0x81(alt. 1x0)          | 0x103                   | 0x60                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | N/A   |

Uplink TFCS:

| TFCI    | (RB5, RB6, RB7, DCCH) |
|---------|-----------------------|
| UL_TFC0 | (TF0, TF0, TF0, TF0)  |
| UL_TFC1 | (TF1, TF0, TF0, TF0)  |
| UL_TFC2 | (TF2, TF1, TF1, TF0)  |
| UL_TFC3 | (TF0, TF0, TF0, TF1)  |
| UL_TFC4 | (TF1, TF0, TF0, TF1)  |
| UL_TFC5 | (TF2, TF1, TF1, TF1)  |

Downlink TFS:

|     |           | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | RB7<br>(RAB-subflow #3) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x103                   | 0x60                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x103                   | 1x60                    | 1x148 |
|     | TF2, bits | 1x81                    | N/A                     | N/A                     | N/A   |

Downlink TFCS:

| TFCI    | (RB5, RB6, RB7, DCCH) |
|---------|-----------------------|
| DL_TFC0 | (TF0, TF0, TF0, TF0)  |
| DL_TFC1 | (TF1, TF0, TF0, TF0)  |
| DL_TFC2 | (TF2, TF1, TF1, TF0)  |
| DL_TFC3 | (TF0, TF0, TF0, TF1)  |
| DL_TFC4 | (TF1, TF0, TF0, TF1)  |
| DL_TFC5 | (TF2, TF1, TF1, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCs under test | Uplink TFCs Under test | Implicitely-tested                 | Restricted UL-TFCIs                | UL-RLC-SDU size<br>(note)                     | Test data size<br>(note)                      |
|----------|--------------------------|------------------------|------------------------------------|------------------------------------|-----------------------------------------------|-----------------------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4 | RB5: 39-bits<br>RB6: 103-bits<br>RB7: 60-bits | RB5: 39-bits<br>RB6: No data<br>RB7: No data  |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5 | RB5: 81-bits<br>RB6: 103-bits<br>RB7: 60-bits | RB5: 81-bits<br>RB6: 103-bits<br>RB7: 60-bits |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See 14.1.1 for test procedure.

#### 18.1.2.4.4 Test requirements

See 18.1.1.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
2. At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x39);
  - for sub-test 2: RB5/TF2 (1x81); RB6/TF1 (1x103); and RB7/TF1 (1x60).
3. At step 15 the UE shall return
  - for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6 or RB7.
  - for sub-test 2: an RLC SDU on each of RB5, RB6 and RB7 having the same content as sent by SS

#### 18.1.2.5 Conversational / speech / UL:10.2 DL:10.2 kbps / CS-RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH

##### 18.1.2.5.1 Conformance requirement

See clause 18.1.2.4.1.

##### 18.1.2.5.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.11.5.4.1.5.

##### 18.1.2.5.3 Method of test

Uplink-TFS:

|     | TFI       | RB5<br>(RAB subflow #1) | RB6<br>(RAB subflow #2) | RB7<br>(RAB subflow #3) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 0x65(alt. 1x0)          | 0x99                    | 0x40                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x99                    | 1x40                    | 1x148 |
|     | TF2, bits | 1x65                    | N/A                     | N/A                     | N/A   |

Uplink TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, RB7, DCCH)</b> |
|-------------|------------------------------|
| UL_TFC0     | (TF0, TF0, TF0, TF0)         |
| UL_TFC1     | (TF1, TF0, TF0, TF0)         |
| UL_TFC2     | (TF2, TF1, TF1, TF0)         |
| UL_TFC3     | (TF0, TF0, TF0, TF1)         |
| UL_TFC4     | (TF1, TF0, TF0, TF1)         |
| UL_TFC5     | (TF2, TF1, TF1, TF1)         |

Downlink TFS:

|            |           | <b>RB5<br/>(RAB subflow #1)</b> | <b>RB6<br/>(RAB subflow #2)</b> | <b>RB7<br/>(RAB subflow #3)</b> | <b>DCCH</b> |
|------------|-----------|---------------------------------|---------------------------------|---------------------------------|-------------|
| <b>TFS</b> | TF0, bits | 1x0                             | 0x99                            | 0x40                            | 0x148       |
|            | TF1, bits | 1x39                            | 1x99                            | 1x40                            | 1x148       |
|            | TF2, bits | 1x65                            | N/A                             | N/A                             | N/A         |

Downlink TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, RB7, DCCH)</b> |
|-------------|------------------------------|
| DL_TFC0     | (TF0, TF0, TF0, TF0)         |
| DL_TFC1     | (TF1, TF0, TF0, TF0)         |
| DL_TFC2     | (TF2, TF1, TF1, TF0)         |
| DL_TFC3     | (TF0, TF0, TF0, TF1)         |
| DL_TFC4     | (TF1, TF0, TF0, TF1)         |
| DL_TFC5     | (TF2, TF1, TF1, TF1)         |

Sub-tests:

| <b>Sub-test</b> | <b>Downlink TFCS under test</b> | <b>Uplink TFCS Under test</b> | <b>Implicitely tested</b>          | <b>Restricted UL TFCIs</b>         | <b>UL RLC SDU size</b>                       | <b>Test data size</b>                        |
|-----------------|---------------------------------|-------------------------------|------------------------------------|------------------------------------|----------------------------------------------|----------------------------------------------|
|                 |                                 |                               |                                    |                                    | (note)                                       | (note)                                       |
| 1               | DL_TFC1                         | UL_TFC1                       | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4 | RB5: 39 bits<br>RB6: 99 bits<br>RB7: 40 bits | RB5: 39 bits<br>RB6: No data<br>RB7: No data |
| 2               | DL_TFC2                         | UL_TFC2                       | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5 | RB5: 65 bits<br>RB6: 99 bits<br>RB7: 40 bits | RB5: 65 bits<br>RB6: 99 bits<br>RB7: 40 bits |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See clause 18.1.1.1 for test procedure.

#### 18.1.2.5.4 Test requirements

See 18.1.1.1 for definition of step 10 and step 15.

- At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x39);
  - for sub-test 2: RB5/TF2 (1x65); RB6/TF1 (1x99); and RB7/TF1 (1x40).

3. At step 15 the UE shall return

- for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6 or RB7.
- for sub-test 2: an RLC SDU on each of RB5, RB6 and RB7 having the same content as sent by SS.

### ~~18.1.2.6 Conversational / speech / UL:7.95 DL:7.95 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

#### ~~18.1.2.6.1 Conformance requirement~~

See clause 18.1.2.4.1.

#### ~~18.1.2.6.2 Test purpose~~

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.11.5.4.1.6.

#### ~~18.1.2.6.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 0x75 (alt. 1x0)         | 0x84                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x84                    | 1x148 |
|     | TF2, bits | 1x75                    | N/A                     | N/A   |

Uplink TFCS:

| TFCI    | (RB5, RB6, DCCH) |
|---------|------------------|
| UL_TFC0 | (TF0, TF0, TF0)  |
| UL_TFC1 | (TF1, TF0, TF0)  |
| UL_TFC2 | (TF2, TF1, TF0)  |
| UL_TFC3 | (TF0, TF0, TF1)  |
| UL_TFC4 | (TF1, TF0, TF1)  |
| UL_TFC5 | (TF2, TF1, TF1)  |

Downlink TFS:

|     |           | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x84                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x84                    | 1x148 |
|     | TF2, bits | 1x75                    | N/A                     | N/A   |

Downlink TFCS:

| TFCI    | (RB5, RB6, DCCH) |
|---------|------------------|
| DL_TFC0 | (TF0, TF0, TF0)  |
| DL_TFC1 | (TF1, TF0, TF0)  |
| DL_TFC2 | (TF2, TF1, TF0)  |
| DL_TFC3 | (TF0, TF0, TF1)  |
| DL_TFC4 | (TF1, TF0, TF1)  |
| DL_TFC5 | (TF2, TF1, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCs under test | Uplink TFCs Under test | Implicitely-tested                 | Restricted UL-TFCIs                 | UL-RLC-SDU size<br>(note)    | Test data size<br>(note)     |
|----------|--------------------------|------------------------|------------------------------------|-------------------------------------|------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4  | RB5: 39 bits<br>RB6: 84 bits | RB5: 39 bits<br>RB6: No data |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5, | RB5: 75 bits<br>RB6: 84 bits | RB5: 75 bits<br>RB6: 84 bits |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See clause 18.1.1.1 for test procedure.

#### 18.1.2.6.4 Test requirements

See 18.1.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

— for sub-test 1: RB5/TF1 (1x39);

— for sub-test 2: RB5/TF2 (1x75) and RB6/TF1 (1x84);

3. At step 15 the UE shall return

— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6;

— for sub-test 2: an RLC SDU on each of RB5 and RB6 having the same content as sent by SS.

#### 18.1.2.7 Conversational / speech / UL:7.4 DL:7.4 kbps / CS-RAB+ UL:3.4 DL:3.4 kbps SRBs for DCCH

##### 18.1.2.7.1 Conformance requirement

See clause 18.1.2.4.1.

##### 18.1.2.7.2 Test purpose

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.11.5.4.1.7.

##### 18.1.2.7.3 Method of test

Uplink-TFS:

|     | TFI       | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 0x61 (alt. 1x0)         | 0x87                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x87                    | 1x148 |
|     | TF2, bits | 1x61                    | N/A                     | N/A   |



Uplink TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| UL_TFC0     | (TF0, TF0, TF0)         |
| UL_TFC1     | (TF1, TF0, TF0)         |
| UL_TFC2     | (TF2, TF1, TF0)         |
| UL_TFC3     | (TF0, TF0, TF1)         |
| UL_TFC4     | (TF1, TF0, TF1)         |
| UL_TFC5     | (TF2, TF1, TF1)         |

Downlink TFS:

|            |           | <b>RB5<br/>(RAB subflow #1)</b> | <b>RB6<br/>(RAB subflow #2)</b> | <b>DCCH</b> |
|------------|-----------|---------------------------------|---------------------------------|-------------|
| <b>TFS</b> | TF0, bits | 1x0                             | 0x87                            | 0x148       |
|            | TF1, bits | 1x39                            | 1x87                            | 1x148       |
|            | TF2, bits | 1x61                            | N/A                             | N/A         |

Downlink TFCS:

| <b>TFCI</b> | <b>(RB5, RB6, DCCH)</b> |
|-------------|-------------------------|
| DL_TFC0     | (TF0, TF0, TF0)         |
| DL_TFC1     | (TF1, TF0, TF0)         |
| DL_TFC2     | (TF2, TF1, TF0)         |
| DL_TFC3     | (TF0, TF0, TF1)         |
| DL_TFC4     | (TF1, TF0, TF1)         |
| DL_TFC5     | (TF2, TF1, TF1)         |

Sub-tests:

| <b>Sub-test</b> | <b>Downlink TFCS under test</b> | <b>Uplink TFCS Under test</b> | <b>Implicitely tested</b>          | <b>Restricted UL TFCIs</b>         | <b>UL RLC SDU size</b>       | <b>Test data size</b>        |
|-----------------|---------------------------------|-------------------------------|------------------------------------|------------------------------------|------------------------------|------------------------------|
|                 |                                 |                               |                                    |                                    | (note)                       | (note)                       |
| 1               | DL_TFC1                         | UL_TFC1                       | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4 | RB5: 39 bits<br>RB6: 87 bits | RB5: 39 bits<br>RB6: No data |
| 2               | DL_TFC2                         | UL_TFC2                       | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5 | RB5: 61 bits<br>RB6: 87 bits | RB5: 61 bits<br>RB6: 87 bits |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See clause 18.1.1.1 for test procedure.

#### 18.1.2.7.4 Test requirements

See 18.1.1.1 for definition of step 10 and step 15.

- At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.
- At step 15 the UE transmitted transport format shall be
  - for sub-test 1: RB5/TF1 (1x39).
  - for sub-test 2: RB5/TF2 (1x61) and RB6/TF1 (1x87).

3. At step 15 the UE shall return

- for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6;
- for sub-test 2: an RLC SDU on each of RB5 and RB6 having the same content as sent by SS

### ~~18.1.2.8 Conversational / speech / UL:6.7 DL:6.7 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH~~

#### ~~18.1.2.8.1 Conformance requirement~~

See clause 18.1.2.4.1.

#### ~~18.1.2.8.2 Test purpose~~

To verify radio bearer establishment and correct data transfer for reference radio bearer configuration as specified in TS 34.108, clause 6.11.5.4.1.8.

#### ~~18.1.2.8.3 Method of test~~

Uplink TFS:

|     | TFI       | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 0x58 (alt. 1x0)         | 0x76                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x76                    | 1x148 |
|     | TF2, bits | 1x58                    | N/A                     | N/A   |

Uplink TFCS:

| TFCI    | (RB5, RB6, DCCH) |
|---------|------------------|
| UL_TFC0 | (TF0, TF0, TF0)  |
| UL_TFC1 | (TF1, TF0, TF0)  |
| UL_TFC2 | (TF2, TF1, TF0)  |
| UL_TFC3 | (TF0, TF0, TF1)  |
| UL_TFC4 | (TF1, TF0, TF1)  |
| UL_TFC5 | (TF2, TF1, TF1)  |

Downlink TFS:

|     |           | RB5<br>(RAB-subflow #1) | RB6<br>(RAB-subflow #2) | DCCH  |
|-----|-----------|-------------------------|-------------------------|-------|
| TFS | TF0, bits | 1x0                     | 0x76                    | 0x148 |
|     | TF1, bits | 1x39                    | 1x76                    | 1x148 |
|     | TF2, bits | 1x58                    | N/A                     | N/A   |

Downlink TFCS:

| TFCI    | (RB5, RB6, DCCH) |
|---------|------------------|
| DL_TFC0 | (TF0, TF0, TF0)  |
| DL_TFC1 | (TF1, TF0, TF0)  |
| DL_TFC2 | (TF2, TF1, TF0)  |
| DL_TFC3 | (TF0, TF0, TF1)  |
| DL_TFC4 | (TF1, TF0, TF1)  |
| DL_TFC5 | (TF2, TF1, TF1)  |

Sub-tests:

| Sub-test | Downlink TFCs under test | Uplink TFCs Under test | Implicitely tested                 | Restricted UL-TFCIs                 | UL-RLC-SDU size<br>(note)    | Test data size<br>(note)     |
|----------|--------------------------|------------------------|------------------------------------|-------------------------------------|------------------------------|------------------------------|
| 1        | DL_TFC1                  | UL_TFC1                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC1, UL_TFC3, UL_TFC4  | RB5: 39 bits<br>RB6: 76 bits | RB5: 39 bits<br>RB6: No data |
| 2        | DL_TFC2                  | UL_TFC2                | DL_TFC0, DL_TFC3, UL_TFC0, UL_TFC3 | UL_TFC0, UL_TFC2, UL_TFC3, UL_TFC5, | RB5: 58 bits<br>RB6: 76 bits | RB5: 58 bits<br>RB6: 76 bits |

NOTE: See TS 34.109 [10] clause 5.3.2.6.2 for details regarding loopback of RLC SDUs.

See clause 18.1.1.1 for test procedure.

#### 18.1.2.8.4 Test requirements

See clause 18.1.1.1 for definition of step 10 and step 15.

1. At step 10 the UE shall send RADIO BEARER SETUP COMPLETE.

2. At step 15 the UE transmitted transport format shall be

— for sub-test 1: RB5/TF1 (1x39);

— for sub-test 2: RB5/TF2 (1x58) and RB6/TF1 (1x76);

3. At step 15 the UE shall return

— for sub-test 1: an RLC SDU on RB5 having the same content as sent by SS; and no data shall be received on RB6;

— for sub-test 2: an RLC SDU on each of RB5 and RB6 having the same content as sent by SS

## Annex A (normative): (void)Default RRC Message Contents

### A.1 Default RRC Message Contents (FDD)

This clause contains the default values of RRC messages, other than those specified in TS 34.108 clauses 6 and 9. Unless indicated otherwise in specific test cases, they shall be transmitted by the system simulator in RRC messages, and which are required to be received from the UE under test.

The necessary L3 messages are listed in alphabetic order, with the exception of the SYSTEM INFORMATION messages, where it is the information elements which are listed in alphabetic order (this is because some information elements occur in several SYSTEM INFORMATION types).

In this clause, decimal values are normally used. However, sometimes a hexadecimal value, indicated by an "H", or a binary value, indicated by a "B" is used.

Default SYSTEM INFORMATION:

NOTE:—SYSTEM INFORMATION BLOCK TYPE 1 (except for PLMN type "GSM-MAP"), SYSTEM INFORMATION BLOCK TYPE 8, SYSTEM INFORMATION BLOCK TYPE 9, SYSTEM INFORMATION BLOCK TYPE 10, SYSTEM INFORMATION BLOCK TYPE 14, SYSTEM INFORMATION BLOCK TYPE 15 and SYSTEM INFORMATION BLOCK TYPE 16 messages are not used.

Contents of ACTIVE SET UPDATE message: AM

| Information Element                   | Value/remark                                                                                                                                                                                                                             |
|---------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                          | Arbitrarily selects one integer between 0 to 3                                                                                                                                                                                           |
| RRC transaction identifier            | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| Integrity check info                  | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                 |
| ——— message authentication code       | SS provides the value of this IE, from its internal counter.                                                                                                                                                                             |
| ——— RRC message sequence number       | Not Present                                                                                                                                                                                                                              |
| Integrity protection mode info        | Not Present                                                                                                                                                                                                                              |
| Ciphering mode info                   | Not Present                                                                                                                                                                                                                              |
| Activation time                       | now                                                                                                                                                                                                                                      |
| New U-RNTI                            | Not Present                                                                                                                                                                                                                              |
| CN information info                   | Not Present                                                                                                                                                                                                                              |
| Downlink counter synchronisation info | Not Present                                                                                                                                                                                                                              |
| Maximum allowed UL TX power           | 33dBm                                                                                                                                                                                                                                    |
| Radio link addition information       | Not Present                                                                                                                                                                                                                              |
| Radio link removal information        | Not Present                                                                                                                                                                                                                              |
| TX Diversity Mode                     | None                                                                                                                                                                                                                                     |
| SSDT information                      | Not Present                                                                                                                                                                                                                              |

## Contents of ACTIVE SET UPDATE COMPLETE message: AM

| Information Element                                | Value/remark                                                                                                                                                                                                                                       |
|----------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                       |                                                                                                                                                                                                                                                    |
| RRC transaction identifier                         | Checked to see if it matches the same value used in the corresponding downlink ACTIVE SET UPDATE message                                                                                                                                           |
| Integrity check info                               | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| — Message authentication code                      | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| — RRC Message sequence number                      | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Uplink integrity protection activation info        | Not checked                                                                                                                                                                                                                                        |
| Radio bearer uplink ciphering activation time info | Not checked                                                                                                                                                                                                                                        |
| Uplink counter synchronisation info                | Not checked                                                                                                                                                                                                                                        |

## Contents of ACTIVE SET UPDATE FAILURE message: AM

| Information Element           | Value/remark                                                                                                                                                                                                                                       |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                  |                                                                                                                                                                                                                                                    |
| RRC transaction identifier    | Checked to see if it matches the same value used in the corresponding downlink ACTIVE SET UPDATE message                                                                                                                                           |
| Integrity check info          | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| — Message authentication code | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| — RRC Message sequence number | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Failure cause                 | Refer to test requirement                                                                                                                                                                                                                          |

## Contents of CELL UPDATE message: TM

| Information Element                  | Value/remark                                                                                                                                                                                                                                       |
|--------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                         |                                                                                                                                                                                                                                                    |
| U-RNTI                               | Checked to see if it is set to the following values<br>0000-0000-0001B                                                                                                                                                                             |
| —— SRNC identity                     | 0000-0000-0000-0000-0001B                                                                                                                                                                                                                          |
| —— S-RNTI                            |                                                                                                                                                                                                                                                    |
| RRC transaction identifier           | Checked to see if it is absent                                                                                                                                                                                                                     |
| Integrity check info                 | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub IEs shall be absent. |
| —— Message authentication code       | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| —— RRC Message sequence number       | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| START List                           | Checked to see if the 'CN domain identity' and 'START' IEs are present for all CN domains supported by the UE                                                                                                                                      |
| —— CN domain identity                | Checked to see if it is one of the supported CN domains                                                                                                                                                                                            |
| —— START                             | Checked to see if it is present                                                                                                                                                                                                                    |
| AM_RLC error indication (RB2 or RB3) | Checked to see if it is set to 'FALSE'                                                                                                                                                                                                             |
| AM_RLC error indication (RB>3)       | Checked to see if it is set to 'FALSE'                                                                                                                                                                                                             |
| Cell update cause                    | See the test content                                                                                                                                                                                                                               |
| Failure cause                        | Checked to see if it is absent                                                                                                                                                                                                                     |
| RB timer indicator                   |                                                                                                                                                                                                                                                    |
| —— T314 expired                      | Checked to see if it is set to 'FALSE'                                                                                                                                                                                                             |
| —— T315 expired                      | Checked to see if it is set to 'FALSE'                                                                                                                                                                                                             |
| Measured results on RACH             | Not checked                                                                                                                                                                                                                                        |

## Contents of CELL UPDATE CONFIRM message: UM

| Information Element                                                | Value/remark                                                                                                                                                                                                                             |
|--------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                                       |                                                                                                                                                                                                                                          |
| U-RNTI                                                             | If this message is sent on CCCH, use the following values. Else, this IE is absent.                                                                                                                                                      |
| —— SRNC identity                                                   | 0000-0000-0001B                                                                                                                                                                                                                          |
| —— S-RNTI                                                          | 0000-0000-0000-0000-0001B                                                                                                                                                                                                                |
| RRC transaction identifier                                         | Selects an arbitrary integer between 0 to 3                                                                                                                                                                                              |
| Integrity check info                                               | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| —— message authentication code                                     | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                 |
| —— RRC message sequence number                                     | SS provides the value of this IE, from its internal counter.                                                                                                                                                                             |
| Integrity protection mode info                                     | Not Present                                                                                                                                                                                                                              |
| Ciphering mode info                                                | Not Present                                                                                                                                                                                                                              |
| Activation time                                                    | Not Present — use default value                                                                                                                                                                                                          |
| New U-RNTI                                                         | Not Present                                                                                                                                                                                                                              |
| New C-RNTI                                                         | Not Present                                                                                                                                                                                                                              |
| RRC State indicator                                                | CELL_FACH                                                                                                                                                                                                                                |
| UTRAN-DRX cycle length coefficient                                 | Not Present                                                                                                                                                                                                                              |
| RLC re-establish indicator (RB2 or RB3)                            | FALSE                                                                                                                                                                                                                                    |
| RLC re-establish indicator (RB>3)                                  | FALSE                                                                                                                                                                                                                                    |
| CN information info                                                | Not Present                                                                                                                                                                                                                              |
| URA identity                                                       | 0000-0000-0001B                                                                                                                                                                                                                          |
| RB information to release list                                     | Not Present                                                                                                                                                                                                                              |
| RB information to reconfigure list                                 | Not Present                                                                                                                                                                                                                              |
| RB information to be affected list                                 | Not Present                                                                                                                                                                                                                              |
| Downlink counter synchronisation info                              | Not Present                                                                                                                                                                                                                              |
| UL Transport channel information common for all transport channels | Not Present                                                                                                                                                                                                                              |
| Deleted TrCH information list                                      | Not Present                                                                                                                                                                                                                              |
| Added or Reconfigured TrCH information list                        | Not Present                                                                                                                                                                                                                              |
| CHOICE Mode                                                        | FDD                                                                                                                                                                                                                                      |
| — CPGH set ID                                                      | Not Present                                                                                                                                                                                                                              |
| — Added or Reconfigured TrCH information for DRAC list             | Not Present                                                                                                                                                                                                                              |
| DL Transport channel information common for all transport channels | Not Present                                                                                                                                                                                                                              |
| Deleted TrCH information list                                      | Not Present                                                                                                                                                                                                                              |
| Added or Reconfigured TrCH information list                        | Not Present                                                                                                                                                                                                                              |
| Frequency info                                                     | Not Present                                                                                                                                                                                                                              |
| Maximum allowed UL TX power                                        | Not Present                                                                                                                                                                                                                              |
| CHOICE channel requirement                                         | Not Present                                                                                                                                                                                                                              |
| CHOICE mode                                                        | FDD                                                                                                                                                                                                                                      |
| —— Downlink PDSCH information                                      | Not Present                                                                                                                                                                                                                              |
| Downlink information common for all radio links                    | Not Present                                                                                                                                                                                                                              |
| Downlink information per radio link list                           | Not Present                                                                                                                                                                                                                              |

## Contents of MEASUREMENT CONTROL message: AM

| Information Element                                             | Value/remark                                                                                                                                                                                                                              |
|-----------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                                    | Arbitrarily selects an unused integer between 0 to 3                                                                                                                                                                                      |
| RRC transaction identifier                                      | The presence of this IE is dependent on I-XIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| Integrity check info                                            | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                  |
| <del>Message authentication code</del>                          | SS provides the value of this IE, from its internal counter.                                                                                                                                                                              |
| <del>RRC message sequence number</del>                          | 1                                                                                                                                                                                                                                         |
| Measurement Identity                                            | Setup                                                                                                                                                                                                                                     |
| Measurement Command                                             |                                                                                                                                                                                                                                           |
| Measurement Reporting Mode                                      |                                                                                                                                                                                                                                           |
| <del>Measurement Report Transfer Mode</del>                     | Acknowledged mode RLC                                                                                                                                                                                                                     |
| <del>Measurement Reporting/Event Trigger Reporting Mode</del>   | Event Trigger                                                                                                                                                                                                                             |
| Additional measurement list                                     | Not Present                                                                                                                                                                                                                               |
| CHOICE Measurement type                                         | Intra-frequency measurement                                                                                                                                                                                                               |
| <del>Intra-frequency measurement</del>                          |                                                                                                                                                                                                                                           |
| <del>Intra-frequency cell info</del>                            |                                                                                                                                                                                                                                           |
| <del>New intra-frequency cell</del>                             |                                                                                                                                                                                                                                           |
| <del>Intra-frequency cell-id</del>                              | 1                                                                                                                                                                                                                                         |
| <del>Cell info</del>                                            |                                                                                                                                                                                                                                           |
| <del>Cell individual offset</del>                               | 0dB                                                                                                                                                                                                                                       |
| <del>Reference time difference to cell</del>                    | Not Present                                                                                                                                                                                                                               |
| <del>Read SFN number</del>                                      | FALSE                                                                                                                                                                                                                                     |
| <del>CHOICE mode</del>                                          | FDD                                                                                                                                                                                                                                       |
| <del>Primary CPICH info</del>                                   |                                                                                                                                                                                                                                           |
| <del>Primary scrambling code</del>                              | Different from the Default setting in TS34.108 clause 6.1 (FDD)                                                                                                                                                                           |
| <del>Primary CPICH Tx power</del>                               | Not Present                                                                                                                                                                                                                               |
| <del>TX Diversity indicator</del>                               | FALSE                                                                                                                                                                                                                                     |
| <del>Intra-frequency measurement quantity</del>                 |                                                                                                                                                                                                                                           |
| <del>Filter coefficient</del>                                   | 0                                                                                                                                                                                                                                         |
| <del>Measurement quantity</del>                                 | CPICH RSCP                                                                                                                                                                                                                                |
| <del>Intra-frequency reporting quantity</del>                   |                                                                                                                                                                                                                                           |
| <del>Reporting quantities for active set cells</del>            |                                                                                                                                                                                                                                           |
| <del>SFN-SFN observed time difference reporting indicator</del> | No report                                                                                                                                                                                                                                 |
| <del>Cell synchronisation information reporting indicator</del> | FALSE                                                                                                                                                                                                                                     |
| <del>Cell Identity reporting indicator</del>                    | TRUE                                                                                                                                                                                                                                      |
| <del>CPICH Ec/N0 reporting indicator</del>                      | FALSE                                                                                                                                                                                                                                     |
| <del>CPICH RSCP reporting indicator</del>                       | TRUE                                                                                                                                                                                                                                      |
| <del>Pathloss reporting indicator</del>                         | FALSE                                                                                                                                                                                                                                     |
| <del>Reporting quantities for monitored cells</del>             |                                                                                                                                                                                                                                           |
| <del>SFN-SFN observed time difference reporting indicator</del> | No report                                                                                                                                                                                                                                 |
| <del>Cell synchronisation information reporting indicator</del> | FALSE                                                                                                                                                                                                                                     |
| <del>Cell Identity reporting indicator</del>                    | TRUE                                                                                                                                                                                                                                      |
| <del>CPICH Ec/N0 reporting indicator</del>                      | FALSE                                                                                                                                                                                                                                     |
| <del>CPICH RSCP reporting indicator</del>                       | TRUE                                                                                                                                                                                                                                      |
| <del>Pathloss reporting indicator</del>                         | FALSE                                                                                                                                                                                                                                     |
| <del>Reporting quantities for detected set cells</del>          | Not Present                                                                                                                                                                                                                               |
| <del>Reporting cell status</del>                                |                                                                                                                                                                                                                                           |
| <del>CHOICE reported cell</del>                                 | Report cell within active set and/or monitored cells on used frequency                                                                                                                                                                    |
| <del>Maximum number of reported cells</del>                     | 2                                                                                                                                                                                                                                         |
| <del>Measurement validity</del>                                 | Not Present                                                                                                                                                                                                                               |
| <del>CHOICE report criteria</del>                               | Periodic reporting criteria                                                                                                                                                                                                               |
| <del>Amount of reporting</del>                                  | Infinity                                                                                                                                                                                                                                  |
| <del>Reporting interval</del>                                   | 64 sec                                                                                                                                                                                                                                    |
| DPCH Compressed mode status info                                | Not Present                                                                                                                                                                                                                               |



## Contents of MEASUREMENT CONTROL FAILURE message: AM

| Information Element           | Value/remark                                                                                                                                                                                                                                       |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                  |                                                                                                                                                                                                                                                    |
| RRC transaction identifier    | Checked to see if it's set to the identical value for the same IE in the downlink MEASUREMENT CONTROL message                                                                                                                                      |
| Integrity check info          | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| — Message authentication code | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| — RRC Message sequence number | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Failure cause                 | See the test content                                                                                                                                                                                                                               |

## Contents of MEASUREMENT REPORT message: AM

| Information Element                | Value/remark                                                                                                                                                                                                                                       |
|------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                       |                                                                                                                                                                                                                                                    |
| Integrity check info               | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| — Message authentication code      | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| — RRC Message sequence number      | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Measurement identity               | 1                                                                                                                                                                                                                                                  |
| Measured Results                   |                                                                                                                                                                                                                                                    |
| — Intra-frequency measured results |                                                                                                                                                                                                                                                    |
| — Cell measured results            |                                                                                                                                                                                                                                                    |
| — Cell Identity                    | Not present                                                                                                                                                                                                                                        |
| — SFN-SFN observed time difference | Checked that this IE is absent                                                                                                                                                                                                                     |
| — Cell synchronisation information | Checked that this IE is absent                                                                                                                                                                                                                     |
| — Primary CPICH info               |                                                                                                                                                                                                                                                    |
| — Primary scrambling code          | Different from the Default setting in TS34.108 clause 6.1 (FDD)                                                                                                                                                                                    |
| — CPICH Ec/NO                      | Checked that this IE is absent                                                                                                                                                                                                                     |
| — CPICH RSCP                       | Checked that this IE is present                                                                                                                                                                                                                    |
| — Pathloss                         | Checked that this IE is absent                                                                                                                                                                                                                     |
| Measured results on RACH           | Checked that this IE is absent                                                                                                                                                                                                                     |
| Additional measured results        | Checked that this IE is absent                                                                                                                                                                                                                     |
| Event results                      | Checked that this IE is absent                                                                                                                                                                                                                     |

## Contents of PAGING TYPE 1 message: TM (SMS in CS)

| Information Element           | Value/remark                                                             |
|-------------------------------|--------------------------------------------------------------------------|
| Message Type                  |                                                                          |
| Paging record list            |                                                                          |
| — Paging record               |                                                                          |
| — CHOICE Used paging identity | CN identity                                                              |
| — Paging cause                | Terminating Low Priority Signalling                                      |
| — CN domain identity          | CS domain                                                                |
| — CHOICE UE identity          |                                                                          |
| — IMSI (GSM-MAP)              | Set to the same octet string as in the IMSI stored in the TEST USIM card |
| BCCH modification info        | Not Present                                                              |

## Contents of PAGING TYPE 1 message: TM (SMS in PS)

| Information Element            | Value/remark                                                             |
|--------------------------------|--------------------------------------------------------------------------|
| Message Type                   |                                                                          |
| Paging record list             |                                                                          |
| — Paging record                |                                                                          |
| —— CHOICE Used paging identity | CN identity                                                              |
| —— Paging cause                | Terminating Low Priority Signalling                                      |
| —— CN domain identity          | PS domain                                                                |
| —— CHOICE UE identity          |                                                                          |
| —— IMSI (GSM-MAP)              | Set to the same octet string as in the IMSI stored in the TEST USIM card |
| BCCH modification info         | Not Present                                                              |

## Contents of PAGING TYPE 2 message: AM (Speech in CS)

| Information Element            | Value/remark                                                                                                                                                                                                                             |
|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                   |                                                                                                                                                                                                                                          |
| RRC transaction identifier     | Arbitrarily selects an integer between 0 and 3                                                                                                                                                                                           |
| Integrity check info           | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| —— message authentication code | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                 |
| —— RRC message sequence number | SS provides the value of this IE, from its internal counter.                                                                                                                                                                             |
| Paging cause                   | Terminating Conversational Call                                                                                                                                                                                                          |
| CN domain identity             | CS domain                                                                                                                                                                                                                                |
| Paging record type identifier  | Select the same type as in the IE "Initial UE Identity" in RRC CONNECTION REQUEST message.                                                                                                                                               |

## Contents of PHYSICAL CHANNEL RECONFIGURATION message: AM or UM

| Information Element                                                                                                                                                                                                                                                                                                                                                                         | Condition              | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Message Type</b><br><br>RRC transaction identifier<br>Integrity check info<br><br>——→ message authentication code<br>——→ RRC message sequence number<br><br>Integrity protection mode info<br>Ciphering mode info<br>Activation time<br>New U-RNTI<br>New C-RNTI                                                                                                                         | A1, A2, A3, A4, A5, A6 | Arbitrarily selects an integer between 0 and 3<br>The presence of this IE is dependent on IXT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted.<br>SS calculates the value of MAC-I for this message and writes to this IE.<br>SS provides the value of this IE, from its internal counter.<br>Not Present<br>Not Present<br>(256+CFN-(CFN MOD 8 + 8))MOD 256<br>Not Present<br>Not Present |
| RRC State indicator                                                                                                                                                                                                                                                                                                                                                                         | A1, A2, A3, A4         | CELL_DCH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| RRC State indicator                                                                                                                                                                                                                                                                                                                                                                         | A5, A6                 | CELL_FACH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| UTRAN-DRX cycle length coefficient<br><br>CN information info<br>URA identity<br>Downlink counter synchronisation info<br>Frequency info<br>——→ UARFCN uplink (Nu)<br>——→ UARFCN downlink (Nd)<br>Maximum allowed UL TX power                                                                                                                                                               | A1, A2, A3, A4, A5, A6 | Not Present<br><br>Not Present<br>Not Present<br>Not Present<br>Reference to clause 5.1 Test frequencies<br>Reference to clause 5.1 Test frequencies<br>33dBm                                                                                                                                                                                                                                                                                                                                                                 |
| CHOICE channel requirement                                                                                                                                                                                                                                                                                                                                                                  | A5, A6                 | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| CHOICE channel requirement<br><br>——→ Uplink DPCH power control info<br>——→ DPCCH power offset<br>——→ PC Preamble<br>——→ SRB delay<br>——→ Power Control Algorithm<br>——→ TPC step size<br>——→ Scrambling code type<br>——→ Scrambling code number<br>——→ Number of DPDCH<br>——→ spreading factor<br><br>——→ TFCI existence<br><br>——→ Number of FBI bit<br><br>——→ Puncturing Limit          | A1, A2, A3, A4         | Uplink DPCH info<br><br>-6dB<br>1 frame<br>7 frames<br>Algorithm1<br>1dB<br>Long<br>0 (0 to 16777215)<br>Not Present(1)<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Reference to TS34.108 clause 6.10<br>Parameter Set                                                                                                                         |
| CHOICE Mode                                                                                                                                                                                                                                                                                                                                                                                 | A1, A2, A3, A4, A5, A6 | FDD                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| ——→ Downlink PDSCH information                                                                                                                                                                                                                                                                                                                                                              |                        | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Downlink information common for all radio links<br>——→ Downlink DPCH info common for all RL<br>——→ Timing indicator<br>——→ CFN-targetSFN frame offset<br>——→ Downlink DPCH power control information<br>——→ DPC mode<br>——→ CHOICE mode<br>——→ Power offset $P_{Pilot-DPDCH}$<br>——→ DL rate matching restriction information<br>——→ Spreading factor<br><br>——→ Fixed or Flexible Position | A1, A2, A3             | Maintain<br>Not Present<br><br>0 (single)<br>FDD<br>0<br>Not Present<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Reference to TS34.108 clause 6.10                                                                                                                                                                                                                                                                                                                                                               |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Condition      | Value/remark                                                                                                                                                                                                                                                                                                                                    |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>→ TFCI existence</li> <li>→ CHOICE SF</li> <li>→ DPCH compressed mode info</li> <li>→ TX Diversity mode</li> <li>→ SSDT information</li> <li>→ Default DPCH Offset Value</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                | Parameter Set<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Not Present<br>None<br>Not Present<br>Not Present                                                                                                                                                                  |
| Downlink information common for all radio links <ul style="list-style-type: none"> <li>→ Downlink DPCH info common for all RL</li> <li>→ Timing indicator</li> <li>→ CFN-targetSFN frame offset</li> <li>→ Downlink DPCH power control information</li> <li>→ DPC mode</li> <li>→ CHOICE mode</li> <li>→ Power offset <math>P_{\text{Pilot-DPCH}}</math></li> <li>→ DL rate matching restriction information</li> <li>→ Spreading factor</li> <li>→ Fixed or Flexible Position</li> <li>→ TFCI existence</li> <li>→ CHOICE SF</li> <li>→ DPCH compressed mode info</li> <li>→ TX Diversity mode</li> <li>→ SSDT information</li> <li>→ Default DPCH Offset Value</li> </ul>                                                                                  | A4             | Initialise<br>Not Present<br>0 (single)<br>FDD<br>0<br>Not Present<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Not Present<br>None<br>Not Present<br>Not Present |
| Downlink information common for all radio links                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | A5, A6         | Not Present                                                                                                                                                                                                                                                                                                                                     |
| Downlink information for each radio links <ul style="list-style-type: none"> <li>→ Primary CPICH info</li> <li>→ Primary scrambling code</li> <li>→ PDSCH with SHO-DCH info</li> <li>→ PDSCH code mapping</li> <li>→ Downlink DPCH info for each RL</li> <li>→ Primary CPICH usage for channel estimation</li> <li>→ DPCH frame offset</li> <li>→ Power offset <math>P_{\text{Pilot-DPCH}}</math></li> <li>→ Secondary CPICH info</li> <li>→ DL channelisation code</li> <li>→ Secondary scrambling code</li> <li>→ Spreading factor</li> <li>→ Code number</li> <li>→ Scrambling code change</li> <li>→ TPC combination index</li> <li>→ SSDT Cell Identity</li> <li>→ Closed loop timing adjustment mode</li> <li>→ SCCPCH information for FACH</li> </ul> | A1, A2, A3, A4 | Ref. to the Default setting in TS34.108 clause 6.1 (FDD)<br>Not Present<br>Not Present<br>Primary CPICH may be used<br>0 chips<br>0<br>Not Present<br>5<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>0<br>No change<br>0<br>Not Present<br>Not Present<br>Not Present                                                               |
| <ul style="list-style-type: none"> <li>→ Downlink information for each radio link</li> <li>→ Choice mode</li> <li>→ Primary CPICH info</li> <li>→ Primary scrambling code</li> <li>→ PDSCH with SHO-DCH info</li> <li>→ PDSCH code mapping</li> <li>→ Downlink DPCH info for each RL</li> <li>→ SCCPCH Information for FACH</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                       | A5             | FDD<br>Ref. to the Default setting in TS34.108 clause 6.1 (FDD)<br>Not Present<br>Not Present<br>Not Present<br>Not Present                                                                                                                                                                                                                     |
| → Downlink information for each radio link                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | A6             | Not Present                                                                                                                                                                                                                                                                                                                                     |

| Condition | Explanation                                                 |
|-----------|-------------------------------------------------------------|
| A1        | This IE need for "Non-speech in CS"                         |
| A2        | This IE need for "Speech in CS"                             |
| A3        | This IE need for "Packet to CELL_DCH from CELL_DCH in PS"   |
| A4        | This IE need for "Packet to CELL_DCH from CELL_FACH in PS"  |
| A5        | This IE need for "Packet to CELL_FACH from CELL_DCH in PS"  |
| A6        | This IE need for "Packet to CELL_FACH from CELL_FACH in PS" |

#### Contents of PHYSICAL CHANNEL RECONFIGURATION COMPLETE message: AM

| Information Element                                | Value/remark                                                                                                                                                                                                                                       |
|----------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                       |                                                                                                                                                                                                                                                    |
| RRC-transaction-identifier                         | Checked to see if it's set to identical value of the same IE in the downlink PHYSICAL CHANNEL RECONFIGURATION message                                                                                                                              |
| Integrity-check-info                               | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| —— Message authentication code                     | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| —— RRC Message sequence number                     | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Uplink integrity protection activation info        | Not checked                                                                                                                                                                                                                                        |
| CHOICE-mode                                        | FDD                                                                                                                                                                                                                                                |
| COUNT-C activation time                            | The presence of this IE depends on the following 2 factors: (a) There exists RB(s) mapped to RLC-TM, (b) UE is transiting to CELL_DCH state after the reconfiguration procedure. Else, this IE is absent.                                          |
| Radio-bearer uplink ciphering activation time info | Not checked                                                                                                                                                                                                                                        |
| Uplink-counter-synchronisation info                | Not checked                                                                                                                                                                                                                                        |

#### Contents of PHYSICAL CHANNEL RECONFIGURATION FAILURE message: AM

| Information Element            | Value/remark                                                                                                                                                                                                                                       |
|--------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                   |                                                                                                                                                                                                                                                    |
| RRC-transaction-identifier     | Checked to see if it is set to identical value of the same IE in the downlink PHYSICAL CHANNEL RECONFIGURATION message.                                                                                                                            |
| Integrity-check-info           | The presence if this IE is dependent on IXIT statements in TS 34.123-2. if integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| —— Message authentication code | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| —— RRC Message sequence number | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Failure-cause                  | Checked to see if it meets test requirement                                                                                                                                                                                                        |

## Contents of RADIO BEARER SETUP message: AM or UM

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Condition                           | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Message Type</p> <p>RRC transaction identifier</p> <p>Integrity check info</p> <p>———— message authentication code</p> <p>———— RRC message sequence number</p> <p>Integrity protection mode info</p> <p>Ciphering mode info</p> <p>———— Ciphering mode command</p> <p>———— Ciphering algorithm</p> <p>———— Ciphering activation time for DPCH</p> <p>———— Radio bearer downlink ciphering activation time info</p> <p>Activation time</p> <p>New U-RNTI</p> <p>New C-RNTI</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | <p>A1, A4,<br/>A5,<br/>A6,A7,A8</p> | <p>Arbitrarily selects an integer between 0 and 3</p> <p>The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted.</p> <p>SS calculates the value of MAC-I for this message and writes to this IE.</p> <p>SS provides the value of this IE, from its internal counter.</p> <p>Not Present</p> <p>The presence of this IE is dependent on IXIT statements in TS 34.123-2. If ciphering is indicated to be active, this IE present with the values of the sub-IEs as stated below. Else, this IE is omitted.</p> <p>Start/restart</p> <p>Use one of the supported ciphering algorithms (256+CFN-(CFN MOD 8 + 8))MOD 256</p> <p>Not Present</p> <p>(256+CFN-(CFN MOD 8 + 8))MOD 256</p> <p>Not Present</p> <p>Not Present</p> |
| RRC State indicator                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | A1,<br>A4,A7,A8                     | CELL_DCH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| RRC State indicator                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | A5, A6                              | CELL_FACH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| UTRAN DRX cycle length coefficient                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | A1, A4,<br>A5,<br>A6,A7,A8          | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| CN information info                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |                                     | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| URA identity                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |                                     | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Signalling RB information to setup                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                                     | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <p>RAB information for setup</p> <p>———— RAB info</p> <p>———— RAB identity</p> <p>———— CN domain identity</p> <p>———— NAS Synchronization Indicator</p> <p>———— Re-establishment timer</p> <p>———— RB information to setup</p> <p>———— RB identity</p> <p>———— PDCP info</p> <p>———— CHOICE RLC info type</p> <p>———— CHOICE Uplink RLC mode</p> <p>———— Transmission RLC discard</p> <p>———— Segmentation indication</p> <p>———— CHOICE Downlink RLC mode</p> <p>———— Segmentation indication</p> <p>———— RB mapping info</p> <p>———— Information for each multiplexing option</p> <p>———— RLC logical channel mapping indicator</p> <p>———— Number of uplink RLC logical channels</p> <p>———— Uplink transport channel type</p> <p>———— UL Transport channel identity</p> <p>———— Logical channel identity</p> <p>———— CHOICE RLC size list</p> <p>———— MAC logical channel priority</p> <p>———— Downlink RLC logical channel info</p> <p>———— Number of downlink RLC logical channels</p> | A1,A7                               | <p>0000 0001B</p> <p>CS domain</p> <p>Not Present</p> <p>useT314</p> <p>10</p> <p>Not Present</p> <p>RLC info</p> <p>TM RLC</p> <p>Not Present</p> <p>FALSE</p> <p>TM RLC</p> <p>FALSE</p> <p>Not Present</p> <p>1</p> <p>DCH</p> <p>1</p> <p>Not Present</p> <p>Configured</p> <p>1</p> <p>1</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Condition | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>Downlink transport channel type</li> <li>DL DCH Transport channel identity</li> <li>DL DSCH Transport channel identity</li> <li>Logical channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |           | DCH<br>6<br>Not Present<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| RAB information for setup <ul style="list-style-type: none"> <li>RAB info</li> <li>RAB identity</li> <li>CN domain identity</li> <li>NAS Synchronization Indicator</li> <li>Re-establishment timer</li> <li>RB information to setup</li> <li>RB identity</li> <li>PDCP info</li> <li>CHOICE RLC info type</li> <li>CHOICE Uplink RLC mode</li> <li>Transmission RLC discard</li> <li>Segmentation indication</li> <li>CHOICE Downlink RLC mode</li> <li>Segmentation indication</li> <li>RB mapping info</li> <li>Information for each multiplexing option</li> <li>RLC logical channel mapping indicator</li> <li>Number of uplink RLC logical channels</li> <li>Uplink transport channel type</li> <li>UL Transport channel identity</li> <li>Logical channel identity</li> <li>CHOICE RLC size list</li> <li>MAC logical channel priority</li> <li>Downlink RLC logical channel info</li> <li>Number of downlink RLC logical channels</li> <li>Downlink transport channel type</li> <li>DL DCH Transport channel identity</li> <li>DL DSCH Transport channel identity</li> <li>Logical channel identity</li> <li>RB identity</li> <li>PDCP info</li> <li>CHOICE RLC info type</li> <li>CHOICE Uplink RLC mode</li> <li>Transmission RLC discard</li> <li>Segmentation indication</li> <li>CHOICE Downlink RLC mode</li> <li>Segmentation indication</li> <li>RB mapping info</li> <li>Information for each multiplexing option</li> <li>RLC logical channel mapping indicator</li> <li>Number of uplink RLC logical channels</li> <li>Uplink transport channel type</li> <li>UL Transport channel identity</li> <li>Logical channel identity</li> <li>CHOICE RLC size list</li> <li>MAC logical channel priority</li> <li>Downlink RLC logical channel info</li> <li>Number of downlink RLC logical channels</li> <li>Downlink transport channel type</li> <li>DL DCH Transport channel identity</li> <li>DL DSCH Transport channel identity</li> <li>Logical channel identity</li> <li>RB identity</li> <li>PDCP info</li> <li>CHOICE RLC info type</li> <li>CHOICE Uplink RLC mode</li> <li>Transmission RLC discard</li> <li>Segmentation indication</li> <li>CHOICE Downlink RLC mode</li> <li>Segmentation indication</li> <li>RB mapping info</li> <li>Information for each multiplexing option</li> </ul> | A8        | 0000 0001B<br>CS domain<br>Not Present<br>useT314<br><br>10<br>Not Present<br>RLC info<br>TM RLC<br>Not Present<br>FALSE<br>TM RLC<br>FALSE<br><br>Not Present<br>1<br>DCH<br>1<br>Not Present<br>Configured<br>1<br><br>1<br>DCH<br>6<br>Not Present<br>Not Present<br>11<br>Not Present<br>RLC info<br>TM RLC<br>Not Present<br>FALSE<br>TM RLC<br>FALSE<br><br>Not Present<br>1<br>DCH<br>2<br>Not Present<br>Configured<br>1<br><br>1<br>DCH<br>7<br>Not Present<br>Not Present<br>12<br>Not Present<br>RLC info<br>TM RLC<br>Not Present<br>FALSE<br>TM RLC<br>FALSE |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Condition  | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— DL DSCH Transport channel identity</li> <li>— Logical channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |            | Not Present<br>1<br>DCH<br>3<br>Not Present<br>Configured<br>1<br>1<br>DCH<br>8<br>Not Present<br>Not Present                                                                                                                                                                                                                                                                                                                                                                         |
| RAB information for setup <ul style="list-style-type: none"> <li>— RAB info</li> <li>— RAB identity</li> <li>— CN domain identity</li> <li>— NAS Synchronization Indicator</li> <li>— Re-establishment timer</li> </ul><br>RB information to setup <ul style="list-style-type: none"> <li>— RB identity</li> <li>— PDCP info</li> <li>— CHOICE RLC info type</li> <li>— CHOICE Uplink RLC mode</li> <li>— Transmission RLC discard</li> <li>— CHOICE SDU discard mode</li> <li>— MAX_DAT</li> <li>— Timer_MRW</li> <li>— MaxMRW</li> <li>— Transmission window size</li> <li>— Timer_RST</li> <li>— Max_RST</li> <li>— Polling info</li> <li>— Timer_poll_prohibit</li> <li>— Timer_poll</li> <li>— Poll_SDU</li> <li>— Last transmission PDU poll</li> <li>— Last retransmission PDU poll</li> <li>— Poll_Windows</li> <li>— CHOICE Downlink RLC mode</li> <li>— In-sequence delivery</li> <li>— Receiving window size</li> <li>— Downlink RLC status info</li> <li>— Timer_status_prohibit</li> <li>— Timer_EPC</li> <li>— Missing PDU indicator</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— DL DSCH Transport channel identity</li> <li>— Logical channel identity</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> </ul> | A4, A5, A6 | (AM-DTCH for PS domain)<br>0000-0101B<br>PS domain<br>Not Present<br>useT314<br><br>20<br>Not Present<br>RLC info<br>AM-RLC<br><br>Max-DAT retransmissions<br>4<br>100<br>4<br>8<br>500<br>4<br><br>200<br>200<br>1<br>TRUE<br>TRUE<br>99<br>AM-RLC<br>TRUE<br>8<br><br>200<br>200<br>TRUE<br><br>2-RBMuxOptions<br>Not Present<br>1<br>DCH<br>1<br>Not Present<br>Configured<br>1<br><br>1<br>DCH<br>6<br>Not Present<br>Not Present<br>Not Present<br>1<br>RACH<br>Not Present<br>7 |



| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Condition                                                | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <del>CHOICE RLC size list</del><br><del>RLC size index</del><br><br><del>MAC logical channel priority</del><br><del>Downlink RLC logical channel info</del><br><del>Number of downlink RLC logical channels</del><br><del>Downlink transport channel type</del><br><del>DL DCH Transport channel identity</del><br><del>DL DSCH Transport channel identity</del><br><del>Logical channel identity</del>                                                                                                                                                                                                                                                                                                              |                                                          | Explicit list<br>Reference to TS34.108 clause 6 Parameter Set 6<br><br>1<br>FACH<br>Not Present<br>Not Present<br>7                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| RB information to be affected<br><br>Downlink counter synchronisation info                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | A1, A4,<br>A5,<br>A6,A7,A8<br>A1, A4,<br>A5,<br>A6,A7,A8 | Not Present<br><br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| UL Transport channel information for all transport channels<br><del>PRACH TFCS</del><br><del>CHOICE mode</del><br><del>TFC subset</del><br><del>UL DCH TFCS</del><br><del>CHOICE TFCI signalling</del><br><del>TFCI Field 1 information</del><br><del>CHOICE TFCS representation</del><br><del>TFCS complete reconfigure information</del><br><del>CHOICE CTFC Size</del><br><br><del>CTFC information</del><br><br><del>CTFC</del><br><br><del>Power offset information</del><br><del>CHOICE Gain Factors</del><br><br><del>Gain factor <math>\beta_c</math></del><br><br><del>Gain factor <math>\beta_d</math></del><br><br><del>Reference TFC ID</del><br><del>CHOICE mode</del><br><del>Power offset P-p-m</del> | A1,A4,A7,<br>A8                                          | Not Present<br>FDD<br>Not Present<br><br>Normal<br><br>Complete reconfiguration<br><br>Number of bits used must be enough to cover all combinations of CTFC from TS34.108 clause 6.10 Parameter Set.<br>This IE is repeated for TFC numbers and reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br><br>Computed Gain Factors(The last TFC is set to Signalled Gain Factors)<br>11 (below 64 kbps)<br>9 (higher than 64 kbps) (Not Present if the CHOICE Gain Factors is set to Computed Gain Factors)<br>15<br>(Not Present if the CHOICE Gain Factors is set to Computed Gain Factors)<br>0<br>FDD<br>Not Present |
| UL Transport channel information for all transport channels<br><del>PRACH TFCS</del><br><del>CHOICE mode</del><br><del>TFC subset</del><br><del>UL DCH TFCS</del>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | A5, A6                                                   | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Deleted UL TrCH information<br><br>Added or Reconfigured UL TrCH information<br><del>Uplink transport channel type</del><br><del>UL Transport channel identity</del><br><del>TFS</del><br><del>CHOICE Transport channel type</del><br><del>Dynamic Transport format information</del><br><del>RLC Size</del><br><br><del>Number of TBs and TTI List</del><br><del>Transmission Time Interval</del><br><del>Number of Transport blocks</del>                                                                                                                                                                                                                                                                          | A1, A4,<br>A5,<br>A6,A7,A8<br>A1                         | Not Present<br><br>DCH<br>1<br><br>Dedicated transport channels<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter                                                                                                                                                                                                                                                                                                                                                                                                                                         |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Condition | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>——&gt; CHOICE Logical Channel list</li> <li>——&gt; Semi-static Transport Format information</li> <li>——&gt; Transmission time interval</li> <li>——&gt; Type of channel coding</li> <li>——&gt; Coding Rate</li> <li>——&gt; Rate matching attribute</li> <li>——&gt; CRC size</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |           | Set<br>All<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Added or Reconfigured UL TrCH information <ul style="list-style-type: none"> <li>——&gt; Uplink transport channel type</li> <li>——&gt; UL Transport channel identity</li> <li>——&gt; TFS</li> <li>——&gt; CHOICE Transport channel type</li> <li>——&gt; Dynamic Transport format information</li> <li>——&gt; RLC Size</li> <li>——&gt; Number of TBs and TTI List</li> <li>——&gt; Transmission Time Interval</li> <li>——&gt; Number of Transport blocks</li> <li>——&gt; CHOICE Logical Channel list</li> <li>——&gt; Semi-static Transport Format information</li> <li>——&gt; Transmission time interval</li> <li>——&gt; Type of channel coding</li> <li>——&gt; Coding Rate</li> <li>——&gt; Rate matching attribute</li> <li>——&gt; CRC size</li> <li>——&gt; Uplink transport channel type</li> <li>——&gt; UL Transport channel identity</li> <li>——&gt; TFS</li> <li>——&gt; CHOICE Transport channel type</li> <li>——&gt; Dynamic Transport format information</li> <li>——&gt; RLC Size</li> <li>——&gt; Number of TBs and TTI List</li> <li>——&gt; Transmission Time Interval</li> <li>——&gt; Number of Transport blocks</li> <li>——&gt; CHOICE Logical Channel list</li> <li>——&gt; Semi-static Transport Format information</li> <li>——&gt; Transmission time interval</li> <li>——&gt; Type of channel coding</li> <li>——&gt; Coding Rate</li> <li>——&gt; Rate matching attribute</li> <li>——&gt; CRC size</li> </ul> | A4,A7     | 2 TrCHs(DCH for DCCH and DCH for DTCH)<br>DCH<br>5<br><br>Dedicated transport channels<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br>All<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>DCH<br>1<br><br>Dedicated transport channels<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br>All<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set |
| Added or Reconfigured UL TrCH information <ul style="list-style-type: none"> <li>——&gt; Uplink transport channel type</li> <li>——&gt; UL Transport channel identity</li> <li>——&gt; TFS</li> <li>——&gt; CHOICE Transport channel type</li> <li>——&gt; Dynamic Transport format information</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | A8        | 4 TrCHs(DCH for DCCH and 3DCHs for DTCH)<br>DCH<br>5<br><br>Dedicated transport channels                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Condition | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>——→ RLC Size</li> <li>——→ Number of TBs and TTI List</li> <li>——→ Transmission Time Interval</li> <li>——→ Number of Transport blocks</li> <li>——→ CHOICE Logical Channel list</li> <li>——→ Semi-static Transport Format information</li> <li>——→ Transmission time interval</li> <li>——→ Type of channel coding</li> <li>——→ Coding Rate</li> <li>——→ Rate matching attribute</li> <li>——→ CRC size</li> <li>——→ Uplink transport channel type</li> <li>——→ UL Transport channel identity</li> <li>——→ TFS</li> <li>——→ CHOICE Transport channel type</li> <li>——→ Dynamic Transport format information</li> <li>——→ RLC Size</li> <li>——→ Number of TBs and TTI List</li> <li>——→ Transmission Time Interval</li> <li>——→ Number of Transport blocks</li> <li>——→ CHOICE Logical Channel list</li> <li>——→ Semi-static Transport Format information</li> <li>——→ Transmission time interval</li> <li>——→ Type of channel coding</li> <li>——→ Coding Rate</li> <li>——→ Rate matching attribute</li> <li>——→ CRC size</li> <li>——→ Uplink transport channel type</li> <li>——→ UL Transport channel identity</li> <li>——→ TFS</li> <li>——→ CHOICE Transport channel type</li> <li>——→ Dynamic Transport format information</li> <li>——→ RLC Size</li> <li>——→ Number of TBs and TTI List</li> <li>——→ Transmission Time Interval</li> <li>——→ Number of Transport blocks</li> <li>——→ CHOICE Logical Channel list</li> <li>——→ Semi-static Transport Format information</li> <li>——→ Transmission time interval</li> <li>——→ Type of channel coding</li> <li>——→ Coding Rate</li> <li>——→ Rate matching attribute</li> <li>——→ CRC size</li> <li>——→ Uplink transport channel type</li> <li>——→ UL Transport channel identity</li> <li>——→ TFS</li> </ul> |           | <p>Reference to TS34.108 clause 6.10 Parameter Set<br/>(This IE is repeated for TFI number.)<br/>Not Present<br/>Reference to TS34.108 clause 6.10 Parameter Set<br/>All</p> <p>Reference to TS34.108 clause 6.10 Parameter Set<br/>Reference to TS34.108 clause 6.10 Parameter Set<br/>Reference to TS34.108 clause 6.10 Parameter Set<br/>Reference to TS34.108 clause 6.10 Parameter Set<br/>Reference to TS34.108 clause 6.10 Parameter Set<br/>DCH<br/>1</p> <p>Dedicated transport channels</p> <p>Reference to TS34.108 clause 6.10 Parameter Set<br/>(This IE is repeated for TFI number.)<br/>Not Present<br/>Reference to TS34.108 clause 6.10 Parameter Set<br/>All</p> <p>Reference to TS34.108 clause 6.10 Parameter Set<br/>Reference to TS34.108 clause 6.10 Parameter Set<br/>Reference to TS34.108 clause 6.10 Parameter Set<br/>Reference to TS34.108 clause 6.10 Parameter Set<br/>Reference to TS34.108 clause 6.10 Parameter Set<br/>DCH<br/>2</p> <p>Dedicated transport channels</p> <p>Reference to TS34.108 clause 6.10 Parameter Set<br/>(This IE is repeated for TFI number.)<br/>Not Present<br/>Reference to TS34.108 clause 6.10 Parameter Set<br/>All</p> <p>Reference to TS34.108 clause 6.10 Parameter Set<br/>Reference to TS34.108 clause 6.10 Parameter Set<br/>Reference to TS34.108 clause 6.10 Parameter Set<br/>Reference to TS34.108 clause 6.10 Parameter Set<br/>Reference to TS34.108 clause 6.10 Parameter Set<br/>DCH<br/>3</p> |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | Condition                        | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <del>CHOICE Transport channel type</del><br><del>Dynamic Transport format information</del><br><del>RLC Size</del><br><br><del>Number of TBs and TTI List</del><br><del>Transmission Time Interval</del><br><del>Number of Transport blocks</del><br><br><del>CHOICE Logical Channel list</del><br><del>Semi-static Transport Format information</del><br><del>Transmission time interval</del><br><br><del>Type of channel coding</del><br><br><del>Coding Rate</del><br><br><del>Rate matching attribute</del><br><br><del>CRC size</del> |                                  | Dedicated transport channels<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br>All<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set |
| CHOICE mode<br><del>CPCCH set ID</del><br><del>Added or Reconfigured TrCH information for DRAC list</del>                                                                                                                                                                                                                                                                                                                                                                                                                                   |                                  | FDD<br>Not Present<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Added or Reconfigured UL TrCH information                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | A5, A6                           | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <del>CHOICE mode</del><br><br><del>CPCCH set ID</del><br><del>Added or Reconfigured TrCH information for DRAC list</del>                                                                                                                                                                                                                                                                                                                                                                                                                    | A1, A4,<br>A5,<br>A6,A7,A8       | FDD<br><br>Not Present<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| DL Transport channel information common for all transport channel<br><del>SCCPCH TFCS</del><br><del>CHOICE mode</del><br><del>CHOICE DL parameters</del>                                                                                                                                                                                                                                                                                                                                                                                    | A1,A7,A8                         | Not Present<br>FDD<br>Same as UL                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| DL Transport channel information common for all transport channel<br><del>SCCPCH TFCS</del><br><del>CHOICE mode</del><br><del>CHOICE DL parameters</del><br><del>DL DCH TFCS</del><br><del>CHOICE TFCI Signalling</del><br><del>TFCI Field 1 Information</del><br><del>CHOICE TFCS representation</del><br><del>TFCS complete reconfigure</del><br><del>CHOICE CTFC Size</del><br><br><del>CTFC information</del><br><br><del>CTFC</del><br><br><del>Power offset information</del>                                                         | A4                               | Not Present<br>FDD<br>Explicit<br><br>Normal<br><br>Complete reconfiguration<br><br>Number of bits used must be enough to cover all combinations of CTFC from clause TS34.108 clause 6.10 Parameter Set.<br>This IE is repeated for TFC numbers and reference to TS34.108 clause 6.10<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Not Present                                                                                                                  |
| DL Transport channel information common for all transport channel<br><del>SCCPCH TFCS</del><br><del>CHOICE mode</del><br><del>CHOICE DL parameters</del>                                                                                                                                                                                                                                                                                                                                                                                    | A5, A6                           | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Deleted DL TrCH information<br><br>Added or Reconfigured DL TrCH information<br><del>Downlink transport channel type</del><br><del>DL Transport channel identity</del><br><del>CHOICE DL parameters</del>                                                                                                                                                                                                                                                                                                                                   | A1, A4,<br>A5,<br>A6,A7,A8<br>A1 | Not Present<br><br>DCH<br>6<br>Same as UL                                                                                                                                                                                                                                                                                                                                                                                                                                |

| <b>Information Element</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | <b>Condition</b> | <b>Value/remark</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>- Uplink transport channel type</li> <li>- UL TrCH identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                  | DCH<br>1<br><br>-6.3<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Added or Reconfigured DL-TrCH information</b> <ul style="list-style-type: none"> <li>- Downlink transport channel type</li> <li>- DL Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- Uplink transport channel type</li> <li>- UL TrCH identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> <li>- Downlink transport channel type</li> <li>- DL Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- CHOICE Transport channel type</li> <li>- Dynamic transport format information</li> <li>- RLC Size</li> <li><br/></li> <li>- Number of TBs and TTI List</li> <li>- Dynamic transport format information</li> <li>- Transmission Time Interval</li> <li>- Number of Transport blocks</li> <li><br/></li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li><br/></li> <li>- Type of channel coding</li> <li><br/></li> <li>- Coding Rate</li> <li><br/></li> <li>- Rate matching attribute</li> <li><br/></li> <li>- CRC size</li> <li><br/></li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul> | A4,A7            | 2-TrCHs(DCH for DCCH and DCH for DTCH)<br>DCH<br>10<br>Same as UL<br>DCH<br>5<br><br><br>Not Present<br>Not Present<br>DCH<br>6<br>Explicit<br><br>Dedicated transport channel<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>(This IE is repeated for TFI number.)<br><br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br><br>-6.3<br>Not Present |
| <b>Added or Reconfigured DL-TrCH information</b> <ul style="list-style-type: none"> <li>- Downlink transport channel type</li> <li>- DL Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- Uplink transport channel type</li> <li>- UL TrCH identity</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> <li>- Downlink transport channel type</li> <li>- DL Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- CHOICE Transport channel type</li> <li>- Dynamic transport format information</li> <li>- RLC Size</li> <li><br/></li> <li>- Number of TBs and TTI List</li> <li>- Dynamic transport format information</li> <li>- Transmission Time Interval</li> <li>- Number of Transport blocks</li> <li><br/></li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> </ul>                                                                                                                                                                                                                                                                                                    | A8               | 4-TrCHs(DCH for DCCH and 3DCHs for DTCH)<br>DCH<br>10<br>Same as UL<br>DCH<br>5<br><br><br>Not Present<br>Not Present<br>DCH<br>6<br>Explicit<br><br>Dedicated transport channel<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>(This IE is repeated for TFI number.)<br><br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br><br>Reference to TS34.108 clause 6.10 Parameter Set                                                                                                                                                                                                                                                                                         |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | Condition | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>——→ Type of channel coding</li> <li>——→ Coding Rate</li> <li>——→ Rate matching attribute</li> <li>——→ CRC size</li> <li>——→ DCH quality target</li> <li>——→ BLER Quality value</li> <li>——→ Transparent mode signalling info</li> <li>——→ Downlink transport channel type</li> <li>——→ DL Transport channel identity</li> <li>——→ CHOICE DL parameters</li> <li>——→ TFS</li> <li>——→ CHOICE Transport channel type</li> <li>——→ Dynamic transport format information</li> <li>——→ RLC Size</li> <li>——→ Number of TBs and TTI List</li> <li>——→ Dynamic transport format information</li> <li>——→ Transmission Time Interval</li> <li>——→ Number of Transport blocks</li> <li>——→ Semi-static Transport Format information</li> <li>——→ Transmission time interval</li> <li>——→ Type of channel coding</li> <li>——→ Coding Rate</li> <li>——→ Rate matching attribute</li> <li>——→ CRC size</li> <li>——→ DCH quality target</li> <li>——→ BLER Quality value</li> <li>——→ Transparent mode signalling info</li> <li>——→ Downlink transport channel type</li> <li>——→ DL Transport channel identity</li> <li>——→ CHOICE DL parameters</li> <li>——→ TFS</li> <li>——→ CHOICE Transport channel type</li> <li>——→ Dynamic transport format information</li> <li>——→ RLC Size</li> <li>——→ Number of TBs and TTI List</li> <li>——→ Dynamic transport format information</li> <li>——→ Transmission Time Interval</li> <li>——→ Number of Transport blocks</li> <li>——→ Semi-static Transport Format information</li> <li>——→ Transmission time interval</li> <li>——→ Type of channel coding</li> <li>——→ Coding Rate</li> <li>——→ Rate matching attribute</li> <li>——→ CRC size</li> <li>——→ DCH quality target</li> <li>——→ BLER Quality value</li> <li>——→ Transparent mode signalling info</li> </ul> |           | <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>-6.3</p> <p>Not Present</p> <p>DCH</p> <p>7</p> <p>Explicit</p> <p>Dedicated transport channel</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>(This IE is repeated for TFI number.)</p> <p>Not Present</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Not Present</p> <p>Not Present</p> <p>DCH</p> <p>8</p> <p>Explicit</p> <p>Dedicated transport channel</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>(This IE is repeated for TFI number.)</p> <p>Not Present</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Reference to TS34.108 clause 6.10 Parameter Set</p> <p>Not Present</p> <p>Not Present</p> |
| Added or Reconfigured DL TrCH information                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | A5, A6    | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Frequency info                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | A1, A4,   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | Condition              | Value/remark                                                                                                                                                                                                                                                                                                                                                                                    |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <del>UARFCN uplink (Nu)</del><br><del>UARFCN downlink (Nd)</del>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | A5, A6                 | Reference to clause 5.1 Test frequencies<br>Reference to clause 5.1 Test frequencies                                                                                                                                                                                                                                                                                                            |
| Maximum allowed UL TX power                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | A1, A4, A5, A6, A7, A8 | 33dBm                                                                                                                                                                                                                                                                                                                                                                                           |
| <del>CHOICE channel requirement</del><br><del>Uplink DPCH power control info</del><br><del>DPCCH power offset</del><br><del>PC Preamble</del><br><del>SRB delay</del><br><del>Power Control Algorithm</del><br><del>TPC step size</del><br><del>Scrambling code type</del><br><del>Scrambling code number</del><br><del>Number of DPDCH</del><br><del>spreading factor</del><br><del>TFCI existence</del><br><del>Number of FBI bit</del><br><del>Puncturing Limit</del>                                                                                                                                                                                                                              | A1, A4, A7, A8         | Uplink DPCH info<br><br>-6dB<br>1 frame<br>7 frames<br>Algorithm1<br>1dB<br>Long<br>0 (0 to 16777215)<br>Not Present(1)<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set          |
| <del>CHOICE channel requirement</del>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | A5, A6                 | Not Present                                                                                                                                                                                                                                                                                                                                                                                     |
| CHOICE Mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | A1, A4, A5, A6, A7, A8 | FDD                                                                                                                                                                                                                                                                                                                                                                                             |
| <del>Downlink PDSCH information</del>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |                        | Not Present                                                                                                                                                                                                                                                                                                                                                                                     |
| Downlink information common for all radio links<br><del>Downlink DPCH info common for all RL</del><br><del>Timing indicator</del><br><del>CFN-targetSFN frame offset</del><br><del>Downlink DPCH power control information</del><br><del>DPC mode</del><br><del>CHOICE mode</del><br><del>Power offset <math>P_{Pilot-DPCH}</math></del><br><del>DL rate matching restriction information</del><br><del>Spreading factor</del><br><del>Fixed or Flexible Position</del><br><del>TFCI existence</del><br><del>CHOICE SF</del><br><del>CHOICE mode</del><br><del>DPCH compressed mode info</del><br><del>TX Diversity mode</del><br><del>SSDT information</del><br><del>Default DPCH Offset Value</del> | A1, A4, A7, A8         | Maintain<br>Not Present<br><br>0 (single)<br>FDD<br>0<br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>FDD<br>Not Present<br>None<br>Not Present<br>Not Present |
| Downlink information common for all radio links                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | A5, A6                 | Not Present                                                                                                                                                                                                                                                                                                                                                                                     |
| Downlink information for each radio link list<br><del>Downlink information for each radio link</del><br><del>Choice mode</del><br><del>Primary CPICH info</del><br><del>Primary scrambling code</del><br><del>PDSCH with SHO-DCH info</del><br><del>PDSCH code mapping</del><br><del>Downlink DPCH info for each RL</del><br><del>Primary CPICH usage for channel estimation</del><br><del>DPCH frame offset</del>                                                                                                                                                                                                                                                                                    | A1, A4, A7, A8         | FDD<br><br>Ref. to the Default setting in TS34.108 clause 6.1 (FDD)<br>Not Present<br>Not Present<br><br>Primary CPICH may be used<br>0 chips                                                                                                                                                                                                                                                   |

| Information Element                                                                                                                                                                                                                                                                                                                                                                      | Condition | Value/remark                                                                                                                                |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|---------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>→ Secondary CPICH info</li> <li>→ DL channelisation code</li> <li>→ Secondary scrambling code</li> <li>→ Spreading factor</li> <li>→ Code number</li> <li>→ Scrambling code change</li> <li>→ TPC combination index</li> <li>→ SSDT Cell Identity</li> <li>→ Closed loop timing adjustment mode</li> <li>→ SCCPCH information for FACH</li> </ul> |           | Not Present<br><br>1<br>Reference to TS34.108 clause 6.10 Parameter Set<br>0<br>No change<br>0<br>Not Present<br>Not Present<br>Not Present |
| Downlink information for each radio link list<br>→ Downlink information for each radio link<br>→ Choice mode<br>→ Primary CPICH info<br>→ Primary scrambling code<br><br>→ PDSCH with SHO-DCH info<br>→ PDSCH code mapping<br>→ Downlink DPCH info for each RL<br>→ SCCPCH information for FACH                                                                                          | A5        | FDD<br><br>Ref. to the Default setting in TS34.108 clause 6.1 (FDD)<br>Not Present<br>Not Present<br>Not present<br>Not Present             |
| Downlink information for each radio link list<br>→ Downlink information for each radio link<br>→ Choice mode<br>→ Primary CPICH info<br>→ Primary scrambling code<br><br>→ PDSCH with SHO-DCH info<br>→ PDSCH code mapping<br>→ Downlink DPCH info for each RL<br>→ SCCPCH information for FACH                                                                                          | A6        | FDD<br><br>Different from the Default setting in TS34.108 clause 6.1 (FDD)<br>Not Present<br>Not Present<br>Not present<br>Not Present      |

| Condition                           | Explanation                                                    |
|-------------------------------------|----------------------------------------------------------------|
| A1                                  | This IE need for "Non-speech from CELL_DCH to CELL_DCH in CS"  |
| A2 is defined in TS34.108 clause 9. | This IE need for "Speech from CELL_DCH to CELL_DCH in CS"      |
| A3 is defined in TS34.108 clause 9. | This IE need for "Packet to CELL_DCH from CELL_DCH in PS"      |
| A4                                  | This IE need for "Packet to CELL_DCH from CELL_FACH in PS"     |
| A5                                  | This IE need for "Packet to CELL_FACH from CELL_DCH in PS"     |
| A6                                  | This IE need for "Packet to CELL_FACH from CELL_FACH in PS"    |
| A7                                  | This IE need for "Non-speech from CELL_FACH to CELL_DCH in CS" |
| A8                                  | This IE need for "Speech from CELL_FACH to CELL_DCH in CS"     |



## Contents of RADIO-BEARER-SETUP-FAILURE message: AM

| Information Element                                          | Value/remark                                                                                                                                                                                                                                       |
|--------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                                 |                                                                                                                                                                                                                                                    |
| RRC transaction identifier                                   | Checked to see if it is set to identical value of the same IE in the downlink RADIO-BEARER-SETUP message.                                                                                                                                          |
| Integrity check info                                         | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| —— Message authentication code                               | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| —— RRC Message sequence number                               | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Failure cause                                                | Checked to see if it meets test requirement                                                                                                                                                                                                        |
| Radio bearers for which reconfiguration would have succeeded | Not checked                                                                                                                                                                                                                                        |

## Contents of RADIO-BEARER-RECONFIGURATION message: AM or UM

| Information Element                 | Condition              | Value/remark                                                                                                                                                                                                                             |
|-------------------------------------|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                        | A1, A2, A3, A4, A5, A6 |                                                                                                                                                                                                                                          |
| RRC transaction identifier          |                        | Arbitrarily selects an integer between 0 and 3                                                                                                                                                                                           |
| Integrity check info                |                        | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| —— message authentication code      |                        | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                 |
| —— RRC message sequence number      |                        | SS provides the value of this IE, from its internal counter.                                                                                                                                                                             |
| Integrity protection mode info      |                        | Not Present                                                                                                                                                                                                                              |
| Ciphering mode info                 |                        | Not Present                                                                                                                                                                                                                              |
| Activation time                     |                        | $(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$                                                                                                                                                                                |
| New U-RNTI                          |                        | Not Present                                                                                                                                                                                                                              |
| New C-RNTI                          |                        | Not Present                                                                                                                                                                                                                              |
| RRC State indicator                 | A1, A2, A3, A4         | CELL_DCH                                                                                                                                                                                                                                 |
| RRC State indicator                 | A5, A6                 | CELL_FACH                                                                                                                                                                                                                                |
| UTRAN-DRX-cycle-length-coefficient  | A1, A2, A3, A4, A5, A6 | Not Present                                                                                                                                                                                                                              |
| CN information info                 |                        | Not Present                                                                                                                                                                                                                              |
| URA identity                        |                        | Not Present                                                                                                                                                                                                                              |
| RAB information to reconfigure list |                        | Not Present                                                                                                                                                                                                                              |
| RB information to reconfigure list  | A1                     | TS25.331 specifies that "Although this IE is not always required, need is MP to align with ASN.1".                                                                                                                                       |
| —— RB information to reconfigure    |                        | (UM-DCCH for RRC)                                                                                                                                                                                                                        |
| —— RB identity                      |                        | 1                                                                                                                                                                                                                                        |
| —— PDCP info                        |                        | Not Present                                                                                                                                                                                                                              |
| —— PDCP-SN info                     |                        | Not Present                                                                                                                                                                                                                              |
| —— RLC info                         |                        | Not Present                                                                                                                                                                                                                              |
| —— RB mapping info                  |                        | Not Present                                                                                                                                                                                                                              |
| —— RB stop/continue                 |                        | Not Present                                                                                                                                                                                                                              |
| —— RB information to reconfigure    |                        | (AM-DCCH for RRC)                                                                                                                                                                                                                        |
| —— RB identity                      |                        | 2                                                                                                                                                                                                                                        |
| —— PDCP info                        |                        | Not Present                                                                                                                                                                                                                              |
| —— PDCP-SN info                     |                        | Not Present                                                                                                                                                                                                                              |
| —— RLC info                         |                        | Not Present                                                                                                                                                                                                                              |
| —— RB mapping info                  |                        | Not Present                                                                                                                                                                                                                              |
| —— RB stop/continue                 |                        | Not Present                                                                                                                                                                                                                              |
| —— RB information to reconfigure    |                        | (AM-DCCH for NAS-DT High priority)                                                                                                                                                                                                       |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | Condition | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <del>RB-identity</del><br><del>PDCP-info</del><br><del>PDCP-SN-info</del><br><del>RLC-info</del><br><del>RB-mapping-info</del><br><del>RB-stop/continue</del><br><del>RB-information-to-reconfigure</del><br><del>RB-identity</del><br><del>PDCP-info</del><br><del>PDCP-SN-info</del><br><del>RLC-info</del><br><del>RB-mapping-info</del><br><del>RB-stop/continue</del><br><del>RB-information-to-reconfigure</del><br><del>RB-identity</del><br><del>PDCP-info</del><br><del>PDCP-SN-info</del><br><del>RLC-info</del><br><del>RB-mapping-info</del><br><del>RB-stop/continue</del>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |           | 3<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>(AM-DCCH for NAS-DT Low-priority)<br>4<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>(TM-DTCH)<br>10<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| RB-information-to-reconfigure-list<br><br><del>RB-information-to-reconfigure</del><br><del>RB-identity</del><br><del>PDCP-info</del><br><del>PDCP-SN-info</del><br><del>RLC-info</del><br><del>RB-mapping-info</del><br><del>RB-stop/continue</del><br><del>RB-information-to-reconfigure</del><br><del>RB-identity</del><br><del>PDCP-info</del><br><del>PDCP-SN-info</del><br><del>RLC-info</del><br><del>RB-mapping-info</del><br><del>RB-stop/continue</del><br><del>RB-information-to-reconfigure</del><br><del>RB-identity</del><br><del>PDCP-info</del><br><del>PDCP-SN-info</del><br><del>RLC-info</del><br><del>RB-mapping-info</del><br><del>RB-stop/continue</del><br><del>RB-information-to-reconfigure</del><br><del>RB-identity</del><br><del>PDCP-info</del><br><del>PDCP-SN-info</del><br><del>RLC-info</del><br><del>RB-mapping-info</del><br><del>RB-stop/continue</del><br><del>RB-information-to-reconfigure</del><br><del>RB-identity</del><br><del>PDCP-info</del><br><del>PDCP-SN-info</del><br><del>RLC-info</del><br><del>RB-mapping-info</del><br><del>RB-stop/continue</del><br><del>RB-information-to-reconfigure</del><br><del>RB-identity</del><br><del>PDCP-info</del><br><del>PDCP-SN-info</del><br><del>RLC-info</del><br><del>RB-mapping-info</del><br><del>RB-stop/continue</del><br><del>RB-information-to-reconfigure</del><br><del>RB-identity</del><br><del>PDCP-info</del><br><del>PDCP-SN-info</del><br><del>RLC-info</del><br><del>RB-mapping-info</del><br><del>RB-stop/continue</del><br><del>RB-information-to-reconfigure</del><br><del>RB-identity</del><br><del>PDCP-info</del><br><del>PDCP-SN-info</del><br><del>RLC-info</del><br><del>RB-mapping-info</del><br><del>RB-stop/continue</del><br><del>RB-information-to-reconfigure</del><br><del>RB-identity</del><br><del>PDCP-info</del><br><del>PDCP-SN-info</del><br><del>RLC-info</del><br><del>RB-mapping-info</del><br><del>RB-stop/continue</del><br><del>RB-information-to-reconfigure</del> | A2        | TS25.331 specifies that "Although this IE is not always required, need is MP to align with ASN.1".<br>(UM-DCCH for RRC)<br>1<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>(AM-DCCH for RRC)<br>2<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>(AM-DCCH for NAS-DT High-priority)<br>3<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>(AM-DCCH for NAS-DT Low-priority)<br>4<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>(TM-DTCH)<br>10<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>(TM-DTCH)<br>11<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>(TM-DTCH)<br>(This IE is needed for 12.2 kbps and 10.2 |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Condition                  | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>——&gt; RB identity</li> <li>——&gt; PDCP info</li> <li>——&gt; PDCP SN info</li> <li>——&gt; RLC info</li> <li>——&gt; RB mapping info</li> <li>——&gt; RB stop/continue</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |                            | kbps)<br>12<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| RB information to reconfigure list<br><br><ul style="list-style-type: none"> <li>——&gt; RB information to reconfigure</li> <li>——&gt; RB identity</li> <li>——&gt; PDCP info</li> <li>——&gt; PDCP SN info</li> <li>——&gt; RLC info</li> <li>——&gt; RB mapping info</li> <li>——&gt; RB stop/continue</li> <li>——&gt; RB information to reconfigure</li> <li>——&gt; RB identity</li> <li>——&gt; PDCP info</li> <li>——&gt; PDCP SN info</li> <li>——&gt; RLC info</li> <li>——&gt; RB mapping info</li> <li>——&gt; RB stop/continue</li> <li>——&gt; RB information to reconfigure</li> <li>——&gt; RB identity</li> <li>——&gt; PDCP info</li> <li>——&gt; PDCP SN info</li> <li>——&gt; RLC info</li> <li>——&gt; RB mapping info</li> <li>——&gt; RB stop/continue</li> <li>——&gt; RB information to reconfigure</li> <li>——&gt; RB identity</li> <li>——&gt; PDCP info</li> <li>——&gt; PDCP SN info</li> <li>——&gt; RLC info</li> <li>——&gt; RB mapping info</li> <li>——&gt; RB stop/continue</li> <li>——&gt; RB information to reconfigure</li> <li>——&gt; RB identity</li> <li>——&gt; PDCP info</li> <li>——&gt; PDCP SN info</li> <li>——&gt; RLC info</li> <li>——&gt; RB mapping info</li> <li>——&gt; RB stop/continue</li> </ul> | A3,A4,A5,<br>A6            | TS25.331 specifies that "Although this IE is not always required, need is MP to align with ASN.1".<br>(UM DCCH for RRC)<br>1<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>(AM DCCH for RRC)<br>2<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>(AM DCCH for NAS_DT High-priority)<br>3<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>(AM DCCH for NAS_DT Low-priority)<br>4<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>(AM DTCH)<br>20<br>Not Present<br>Not Present<br>Not Present<br>Not Present |
| RB information to be affected                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | A1, A2,<br>A3,A4,A5,<br>A6 | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| UL Transport channel information for all transport channels                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | A1, A2,<br>A5,A6           | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| UL Transport channel information for all transport channels<br><ul style="list-style-type: none"> <li>——&gt; PRACH TFCS</li> <li>——&gt; CHOICE mode</li> <li>——&gt; TFC subset</li> <li>——&gt; UL DCH TFCS</li> <li>——&gt; CHOICE TFCI signalling</li> <li>——&gt; TFCI Field 1 information</li> <li>——&gt; CHOICE TFCS representation</li> <li>——&gt; TFCS complete reconfigure information</li> <li>——&gt; CHOICE CTFC Size</li> <li>——&gt; CTFC information</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | A3, A4                     | Not Present<br>FDD<br>Not Present<br><br>Normal<br><br>Complete reconfiguration<br><br>Number of bits used must be enough to cover all combinations of CTFC from TS34.108 clause 6.10 Parameter Set.<br>This IE is repeated for TFC numbers and reference to TS34.108 clause 6.10 Parameter                                                                                                                                                                                                                                                                                                                                            |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | Condition              | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <del>CTFC</del><br><del>Power offset information</del><br><del>CHOICE Gain Factors</del><br><del>Gain factor <math>\beta_c</math></del><br><del>Gain factor <math>\beta_d</math></del><br><del>Reference TFC ID</del><br><del>CHOICE mode</del><br><del>Power offset P<sub>p-m</sub></del>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |                        | Set<br><del>Reference to TS34.108 clause 6.10 Parameter Set</del><br><br>Computed Gain Factors(The last TFC is set to Signalled Gain Factors)<br>11 (below 64 kbps)<br>9 (higher than 64 kbps)<br>(Not Present if the CHOICE Gain Factors is set to Computed Gain Factors)<br>15<br>(Not Present if the CHOICE Gain Factors is set to Computed Gain Factors)<br>0<br>FDD<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Deleted UL TrCH information                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | A1, A2, A3, A4, A5, A6 | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Added or Reconfigured UL TrCH information<br><br>Added or Reconfigured UL TrCH information<br><del>Uplink transport channel type</del><br><del>UL Transport channel identity</del><br><del>TFS</del><br><del>CHOICE Transport channel type</del><br><del>Dynamic Transport format information</del><br><del>RLC Size</del><br><br><del>Number of TBs and TTI List</del><br><del>Transmission Time Interval</del><br><del>Number of Transport blocks</del><br><br><del>CHOICE Logical Channel list</del><br><del>Semi-static Transport Format information</del><br><del>Transmission time interval</del><br><br><del>Type of channel coding</del><br><br><del>Coding Rate</del><br><br><del>Rate matching attribute</del><br><br><del>CRC size</del><br><br><del>Uplink transport channel type</del><br><del>UL Transport channel identity</del><br><del>TFS</del><br><del>CHOICE Transport channel type</del><br><del>Dynamic Transport format information</del><br><del>RLC Size</del><br><br><del>Number of TBs and TTI List</del><br><del>Transmission Time Interval</del><br><del>Number of Transport blocks</del><br><br><del>CHOICE Logical Channel list</del><br><del>Semi-static Transport Format information</del><br><del>Transmission time interval</del><br><br><del>Type of channel coding</del><br><br><del>Coding Rate</del><br><br><del>Rate matching attribute</del><br><br><del>CRC size</del> | A1, A2, A5, A6<br>A4   | Not Present<br><br>2 TrCHs(DCH for DCCH and DCH for DTCH)<br>DCH<br>5<br><br>Dedicated transport channels<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br>All<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>DCH<br>1<br><br>Dedicated transport channels<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br>All<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Condition              | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Added or Reconfigured UL TrCH information<br>— Uplink transport channel type<br>— UL Transport channel identity<br>— TFS<br>— CHOICE Transport channel type<br>— Dynamic Transport format information<br>— RLC Size<br><br>— Number of TBs and TTI List<br>— Transmission Time Interval<br>— Number of Transport blocks<br><br>— CHOICE Logical Channel list<br>— Semi-static Transport Format information<br>— Transmission time interval<br><br>— Type of channel coding<br><br>— Coding Rate<br><br>— Rate matching attribute<br><br>— CRC size | A3                     | (DCH for DTCH)<br>DCH<br>1<br><br>Dedicated transport channels<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br>All<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set |
| CHOICE mode<br><br>— CPCH set ID<br>— Added or Reconfigured TrCH information for DRAC list                                                                                                                                                                                                                                                                                                                                                                                                                                                         | A1,A2,A3,<br>A4,A5,A6  | FDD<br><br>Not Present<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| DL Transport channel information common for all transport channel                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | A1, A2, A5, A6         | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| DL Transport channel information common for all transport channel<br>— SCCPCH TFCS<br>— CHOICE mode<br>— CHOICE DL parameters<br>— DL DCH TFCS<br>— CHOICE TFCI Signalling<br>— TFCI Field 1 Information<br>— CHOICE TFCS representation<br>— TFCS complete reconfigure<br>— CHOICE CTFC Size<br><br>— CTFC information<br><br>— CTFC<br><br>— Power offset information                                                                                                                                                                            | A3,A4                  | Not Present<br>FDD<br>Explicit<br><br>Normal<br><br>Complete reconfiguration<br><br>Number of bits used must be enough to cover all combinations of CTFC from clause TS34.108 clause 6.10 Parameter Set.<br>This IE is repeated for TFC numbers and reference to TS34.108 clause 6.10<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Not Present                                                                                                                                                    |
| Deleted DL TrCH information                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | A1, A2, A3, A4, A5, A6 | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| Added or Reconfigured DL TrCH information                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | A1, A2, A5, A6         | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| Added or Reconfigured DL TrCH information<br>— Downlink transport channel type<br>— DL Transport channel identity<br>— CHOICE DL parameters<br>— Uplink transport channel type<br>— UL TrCH identity<br>— DCH quality target<br>— BLER Quality value<br>— Transparent mode signalling info<br>— Downlink transport channel type<br>— DL Transport channel identity<br>— CHOICE DL parameters<br>— TFS<br>— CHOICE Transport channel type                                                                                                           | A4                     | 2 TrCHs(DCH for DCCH and DCH for DTCH)<br>DCH<br>10<br>Same as UL<br>DCH<br>5<br><br>Not Present<br>Not Present<br>DCH<br>6<br>Explicit<br><br>Dedicated transport channel                                                                                                                                                                                                                                                                                                                                 |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | Condition             | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <del>Dynamic transport format information</del><br><del>RLC Size</del><br><br><del>Number of TBs and TTI List</del><br><del>Dynamic transport format information</del><br><del>Transmission Time Interval</del><br><del>Number of Transport blocks</del><br><br><del>Semi-static Transport Format information</del><br><del>Transmission time interval</del><br><br><del>Type of channel coding</del><br><br><del>Coding Rate</del><br><br><del>Rate matching attribute</del><br><br><del>CRC size</del><br><br><del>DCH quality target</del><br><del>BLER Quality value</del><br><del>Transparent mode signalling info</del>                                                                                                                                                                                                                                         |                       | Reference to TS34.108 clause 6.10 Parameter Set<br>(This IE is repeated for TFI number.)<br><br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br><br>-6.3<br>Not Present                                                                |
| Added or Reconfigured DL TrCH information<br><del>Downlink transport channel type</del><br><del>DL Transport channel identity</del><br><del>CHOICE DL parameters</del><br><del>TFS</del><br><del>CHOICE Transport channel type</del><br><del>Dynamic transport format information</del><br><del>RLC Size</del><br><br><del>Number of TBs and TTI List</del><br><del>Dynamic transport format information</del><br><del>Transmission Time Interval</del><br><del>Number of Transport blocks</del><br><br><del>Semi-static Transport Format information</del><br><del>Transmission time interval</del><br><br><del>Type of channel coding</del><br><br><del>Coding Rate</del><br><br><del>Rate matching attribute</del><br><br><del>CRC size</del><br><br><del>DCH quality target</del><br><del>BLER Quality value</del><br><del>Transparent mode signalling info</del> | A3                    | DCH<br>6<br>Explicit<br><br>Dedicated transport channel<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>(This IE is repeated for TFI number.)<br><br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br><br>-6.3<br>Not Present |
| Frequency info<br><del>UARFCN uplink (Nu)</del><br><del>UARFCN downlink (Nd)</del>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | A1,A2,A3,<br>A4,A5,A6 | Reference to clause 5.1 Test frequencies<br>Reference to clause 5.1 Test frequencies                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Maximum allowed UL TX power                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | A1,A2,A3,<br>A4,A5,A6 | 33dBm                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <del>CHOICE channel requirement</del><br><del>Uplink DPCH power control info</del><br><br><del>DPCCH power offset</del><br><del>PC Preamble</del><br><del>SRB delay</del><br><del>Power Control Algorithm</del><br><del>TPC step size</del><br><del>Scrambling code type</del><br><del>Scrambling code number</del>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | A1, A2, A3,<br>A4     | Uplink DPCH info<br><br><br>-6dB<br>1 frame<br>7 frames<br>Algorithm1<br>1dB<br>Long<br>0 (0 to 16777215)                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | Condition              | Value/remark                                                                                                                                                                                                                                                                                                                                                                           |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>——&gt; Number of DPDCH</li> <li>——&gt; spreading factor</li> <li>——&gt; TFCI existence</li> <li>——&gt; Number of FBI bit</li> <li>——&gt; Puncturing Limit</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |                        | Not Present(1)<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set                                                                                                                                                             |
| CHOICE channel requirement                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | A5, A6                 | Not Present                                                                                                                                                                                                                                                                                                                                                                            |
| CHOICE Mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | A1, A2, A3, A4, A5, A6 | FDD                                                                                                                                                                                                                                                                                                                                                                                    |
| ——> Downlink PDSCH information                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |                        | Not Present                                                                                                                                                                                                                                                                                                                                                                            |
| Downlink information common for all radio links                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | A5, A6                 | Not Present                                                                                                                                                                                                                                                                                                                                                                            |
| Downlink information common for all radio links <ul style="list-style-type: none"> <li>——&gt; Downlink DPCH info common for all RL</li> <li>——&gt; Timing indicator</li> <li>——&gt; CFN-targetSFN frame offset</li> <li>——&gt; Downlink DPCH power control information</li> <li>——&gt; DPC mode</li> <li>——&gt; CHOICE mode</li> <li>——&gt; Power offset <math>P_{\text{Pilot-DPCH}}</math></li> <li>——&gt; DL rate matching restriction information</li> <li>——&gt; Spreading factor</li> <li>——&gt; Fixed or Flexible Position</li> <li>——&gt; TFCI existence</li> <li>——&gt; CHOICE SF</li> <li>——&gt; DPCH compressed mode info</li> <li>——&gt; TX Diversity mode</li> <li>——&gt; SSDT information</li> <li>——&gt; Default DPCH Offset Value</li> </ul> | A1, A2, A3             | Maintain<br>Not Present<br>0 (single)<br>FDD<br>0<br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Not Present<br>None<br>Not Present<br>Not Present                                                      |
| Downlink information common for all radio links <ul style="list-style-type: none"> <li>——&gt; Downlink DPCH info common for all RL</li> <li>——&gt; Timing indicator</li> <li>——&gt; CFN-targetSFN frame offset</li> <li>——&gt; Downlink DPCH power control information</li> <li>——&gt; DPC mode</li> <li>——&gt; CHOICE mode</li> <li>——&gt; Power offset <math>P_{\text{Pilot-DPCH}}</math></li> <li>——&gt; DL rate matching restriction information</li> <li>——&gt; Spreading factor</li> <li>——&gt; Fixed or Flexible Position</li> <li>——&gt; TFCI existence</li> <li>——&gt; CHOICE SF</li> <li>——&gt; DPCH compressed mode info</li> <li>——&gt; TX Diversity mode</li> <li>——&gt; SSDT information</li> <li>——&gt; Default DPCH Offset Value</li> </ul> | A4                     | Initialise<br>Not Present<br>0 (single)<br>FDD<br>0<br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Not Present<br>None<br>Not Present<br>Not Present |
| Downlink information per radio link list <ul style="list-style-type: none"> <li>——&gt; Downlink information for each radio link               <ul style="list-style-type: none"> <li>——&gt; Choice mode</li> <li>——&gt; Primary CPICH info</li> <li>——&gt; Primary scrambling code</li> </ul> </li> <li>——&gt; PDSCH with SHO-DCH info</li> <li>——&gt; PDSCH code mapping</li> <li>——&gt; Downlink DPCH info for each RL</li> <li>——&gt; Primary CPICH usage for channel estimation</li> </ul>                                                                                                                                                                                                                                                              | A1, A2, A3, A4         | FDD<br>Ref. to the Default setting in TS34.108 clause 6.1 (FDD)<br>Not Present<br>Not Present<br>Primary CPICH may be used                                                                                                                                                                                                                                                             |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | Condition | Value/remark                                                                                                                                           |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| <del>DPCH frame offset</del><br><del>Secondary CPICH info</del><br><del>Secondary scrambling code</del><br><del>channelisation code</del><br><del>DL channelisation code</del><br><del>Secondary scrambling code</del><br><del>Spreading factor</del><br><br><del>Code number</del><br><del>Scrambling code change</del><br><del>TPC combination index</del><br><del>SSDT Cell Identity</del><br><del>Closed loop timing adjustment mode</del><br><del>SCCPCH information for FACH</del> |           | 0 chips<br>Not Present<br><br>2<br>Reference to TS34.108 clause 6.10 Parameter Set<br>0<br>No change<br>0<br>Not Present<br>Not Present<br>Not Present |
| <del>Downlink information for each radio link</del><br><del>Choice mode</del><br><del>Primary CPICH info</del><br><del>Primary scrambling code</del><br><br><del>PDSCH with SHO DCH info</del><br><del>PDSCH code mapping</del><br><del>Downlink DPCH info for each RL</del><br><del>SCCPCH Information for FACH</del>                                                                                                                                                                   | A5        | FDD<br><br>Ref. to the Default setting in TS34.108 clause 6.1 (FDD)<br>Not Present<br>Not Present<br>Not present<br>Not Present                        |
| <del>Downlink information for each radio link</del><br><del>Choice mode</del><br><del>Primary CPICH info</del><br><del>Primary scrambling code</del><br><br><del>PDSCH with SHO DCH info</del><br><del>PDSCH code mapping</del><br><del>Downlink DPCH info for each RL</del><br><del>Secondary CCPCH info</del>                                                                                                                                                                          | A6        | FDD<br><br>Different from the Default setting in TS34.108 clause 6.1 (FDD)<br>Not Present<br>Not Present<br>Not Present<br>Not Present                 |

| Condition | Explanation                                                 |
|-----------|-------------------------------------------------------------|
| A1        | This IE need for "Non-speech in CS"                         |
| A2        | This IE need for "Speech in CS"                             |
| A3        | This IE need for "Packet to CELL_DCH from CELL_DCH in PS"   |
| A4        | This IE need for "Packet to CELL_DCH from CELL_FACH in PS"  |
| A5        | This IE need for "Packet to CELL_FACH from CELL_DCH in PS"  |
| A6        | This IE need for "Packet to CELL_FACH from CELL_FACH in PS" |

#### Contents of RADIO BEARER RECONFIGURATION FAILURE message: AM

| Information Element                                                                                                                                                                                                                                      | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier<br><br>Integrity check info<br><br><del>Message authentication code</del><br><del>RRC Message sequence number</del><br><br>Failure cause<br>Radio bearers for which reconfiguration would have succeeded List | Checked to see if it is set to identical value of the same IE in the downlink RADIO BEARER RECONFIGURATION message.<br>The presence if this IE is dependent on IXT statements in TS 34.123-2, if integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent.<br>This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.<br>This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.<br>Checked to see if it meets test requirement<br>Not checked |



## Contents of RADIO-BEARER RECONFIGURATION COMPLETE message: AM

| Information Element                                | Value/remark                                                                                                                                                                                                                                       |
|----------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                       |                                                                                                                                                                                                                                                    |
| RRC transaction identifier                         | Checked to see if the value is identical to the same IE in the downlink RADIO-BEARER RECONFIGURATION COMPLETE message                                                                                                                              |
| Integrity check info                               | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| — Message authentication code                      | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| — RRC Message sequence number                      | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Uplink integrity protection activation info        | Not checked                                                                                                                                                                                                                                        |
| CHOICE mode                                        | FDD                                                                                                                                                                                                                                                |
| COUNT-C activation time                            | The presence of this IE depends on the following 2 factors: (a) There exists RB(s) mapped to RLC-TM and (b) UE is transiting to CELL_DCH state after the reconfiguration procedure. Else, this IE is absent.                                       |
| Radio bearer uplink ciphering activation time info | Not checked                                                                                                                                                                                                                                        |
| Uplink counter synchronisation info                | Not checked                                                                                                                                                                                                                                        |

## Contents of RADIO-BEARER-RELEASE message: AM or UM

| Information Element                                         |                     | Value/remark                                                                                                                                                                                                                                                                                  |
|-------------------------------------------------------------|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                                | A1,A2,A3,A4,A5,A6   | Arbitrarily selects an integer between 0 and 3<br>The presence of this IE is dependent on I-X-I-T statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| RRC transaction identifier                                  |                     | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                                                                      |
| Integrity check info                                        |                     | SS provides the value of this IE, from its internal counter.                                                                                                                                                                                                                                  |
| ——— message authentication code                             |                     | Not Present                                                                                                                                                                                                                                                                                   |
| ——— RRC message sequence number                             |                     | Not Present                                                                                                                                                                                                                                                                                   |
| Integrity protection mode info                              |                     | (256+CFN-(CFN MOD 8 + 8))MOD 256                                                                                                                                                                                                                                                              |
| Ciphering mode info                                         |                     | Not Present                                                                                                                                                                                                                                                                                   |
| Activation time                                             |                     | Not Present                                                                                                                                                                                                                                                                                   |
| New U-RNTI                                                  |                     | Not Present                                                                                                                                                                                                                                                                                   |
| New C-RNTI                                                  |                     | Not Present                                                                                                                                                                                                                                                                                   |
| RRC State indicator                                         | A1,A2, A3, A4       | CELL_DCH                                                                                                                                                                                                                                                                                      |
| RRC State indicator                                         | A5, A6              | CELL_FACH                                                                                                                                                                                                                                                                                     |
| UTRAN DRX cycle length coefficient                          | A1,A2,A3,A4,A5,A6   | Not Present                                                                                                                                                                                                                                                                                   |
| CN information info                                         |                     | Not Present                                                                                                                                                                                                                                                                                   |
| Signalling Connection release indication                    |                     | Not Present                                                                                                                                                                                                                                                                                   |
| URA identity                                                |                     | Not Present                                                                                                                                                                                                                                                                                   |
| RAB information to reconfigure list                         |                     | Not Present                                                                                                                                                                                                                                                                                   |
| RB information to release                                   | A1,A2               | 10                                                                                                                                                                                                                                                                                            |
| ——— RB identity                                             |                     | 11                                                                                                                                                                                                                                                                                            |
| RB information to release                                   | A2                  | 12                                                                                                                                                                                                                                                                                            |
| ——— RB identity                                             |                     | 20                                                                                                                                                                                                                                                                                            |
| RB information to release                                   | A3, A4, A5, A6      | 20                                                                                                                                                                                                                                                                                            |
| ——— RB identity                                             |                     | Not Present                                                                                                                                                                                                                                                                                   |
| RB information to be affected                               | A1,A2, A3,A4,A5, A6 | Not Present                                                                                                                                                                                                                                                                                   |
| Downlink counter synchronisation info                       | A1,A2,A3,A4,A5,A6   | Not Present                                                                                                                                                                                                                                                                                   |
| UL Transport channel information for all transport channels | A1, A2, A3, A4      | TFCS reconfigured to fit the new transport channel configuration.                                                                                                                                                                                                                             |
| UL Transport channel information for all transport channels | A5, A6              | Not Present                                                                                                                                                                                                                                                                                   |
| Deleted UL TrCH Information                                 | A1,A2, A3, A4       | DCH 1                                                                                                                                                                                                                                                                                         |
| ——— Uplink transport channel type                           |                     | DCH 2                                                                                                                                                                                                                                                                                         |
| ——— Transport channel identity                              |                     | DCH 3                                                                                                                                                                                                                                                                                         |
| Deleted UL TrCH Information                                 | A2                  | DCH 2                                                                                                                                                                                                                                                                                         |
| ——— Uplink transport channel type                           |                     | DCH 3                                                                                                                                                                                                                                                                                         |
| ——— Transport channel identity                              |                     | Not Present                                                                                                                                                                                                                                                                                   |
| Deleted UL TrCH Information                                 | A5,A6               | Not Present                                                                                                                                                                                                                                                                                   |
| Added or Reconfigured UL TrCH information                   | A1,A2, A3,A4 A5, A6 | Not Present                                                                                                                                                                                                                                                                                   |
| DL Transport channel information for all transport channels | A1, A2, A3, A4,     | TFCS reconfigured to fit the new transport channel configuration.                                                                                                                                                                                                                             |
| DL Transport channel information for all transport channels | A5, A6              | Not Present                                                                                                                                                                                                                                                                                   |
| Deleted DL TrCH Information                                 | A1,A2, A3,A4        | DCH 6                                                                                                                                                                                                                                                                                         |
| ——— Downlink transport channel type                         |                     | DCH 7                                                                                                                                                                                                                                                                                         |
| ——— Transport channel identity                              |                     |                                                                                                                                                                                                                                                                                               |
| Deleted DL TrCH Information                                 | A2                  | DCH 7                                                                                                                                                                                                                                                                                         |
| ——— Downlink transport channel type                         |                     |                                                                                                                                                                                                                                                                                               |
| ——— Transport channel identity                              |                     |                                                                                                                                                                                                                                                                                               |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |                         | Value/remark                                                                                                                                                                                                                                                                                                                                      |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Deleted DL TrCH Information<br>——> Downlink transport channel type<br>——> Transport channel identity                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | A2                      | DCH<br>8                                                                                                                                                                                                                                                                                                                                          |
| Deleted DL TrCH Information                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | A5,A6                   | Not Present                                                                                                                                                                                                                                                                                                                                       |
| Added or Reconfigured DL TrCH information                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | A1,A2, A3,<br>A4,A5, A6 | Not Present                                                                                                                                                                                                                                                                                                                                       |
| Frequency info<br>——> UARFCN uplink (Nu)<br>——> UARFCN downlink (Nd)<br>Maximum allowed UL-TX power                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | A1,A2,A3,A4,A5<br>,A6   | Reference to clause 5.1 Test frequencies<br>Reference to clause 5.1 Test frequencies<br>33dBm                                                                                                                                                                                                                                                     |
| CHOICE channel requirement                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | A5, A6                  | Not Present                                                                                                                                                                                                                                                                                                                                       |
| -CHOICE channel requirement<br>——> Uplink DPCH power control info<br>——> DPCCCH power offset<br>——> PC Preamble<br>——> SRB delay<br>——> Power Control Algorithm<br>——> TPC step size<br>——> Scrambling code type<br>——> Scrambling code number<br>——> Number of DPDCH<br>——> spreading factor<br><br>——> TFCI existence<br><br>——> Number of FBI bit<br><br>——> Puncturing Limit                                                                                                                                                                                        | A1,A2,A3,A4             | Uplink DPCH info<br><br>-6dB<br>1 frame<br>7 frames<br>Algorithm1<br>1dB<br>Long<br>0 (0 to 16777215)<br>Not Present(1)<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Reference to TS34.108 clause 6.10<br>Parameter Set   |
| CHOICE Mode<br><br>——> Downlink PDSCH information                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | A1,A2,A3,A4,A5<br>,A6   | FDD<br><br>Not Present                                                                                                                                                                                                                                                                                                                            |
| Downlink information common for all radio links                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | A5, A6                  | Not Present                                                                                                                                                                                                                                                                                                                                       |
| Downlink information common for all radio links<br>——> Downlink DPCH info common for all RL<br>——> Timing indicator<br>——> CFN-targetSFN frame offset<br>——> Downlink DPCH power control information<br>——> DPC mode<br>——> CHOICE mode<br>——> Power offset $P_{\text{Pilot-DPCH}}$<br>——> DL rate matching restriction information<br>——> Spreading factor<br><br>——> Fixed or Flexible Position<br><br>——> TFCI existence<br><br>——> CHOICE SF<br><br>——> DPCH compressed mode info<br>——> TX Diversity mode<br>——> SSDT information<br>——> Default DPCH Offset Value | A1,A2, A3, A4           | Maintain<br>Not Present<br><br>0 (single)<br>FDD<br>0<br>Not Present<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>Not Present<br>None<br>Not Present<br>Not Present |
| Downlink information for each radio link list<br>——> Downlink information for each radio link<br>——> Choice mode<br>——> Primary CPICH info<br>——> Primary scrambling code<br><br>——> PDSCH with SHO-DCH info<br>——> PDSCH code mapping<br>——> Downlink DPCH info for each RL<br>——> Primary CPICH usage for channel estimation<br>——> DPCH frame offset<br>——> Secondary CPICH info                                                                                                                                                                                     | A1,A2,A3,A4             | FDD<br><br>Ref. to the Default setting in TS34.108<br>clause 6.1 (FDD)<br>Not Present<br>Not Present<br><br>Primary CPICH may be used<br>0 chips<br>Not Present                                                                                                                                                                                   |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                   |    | Value/remark                                                                                                                    |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----|---------------------------------------------------------------------------------------------------------------------------------|
| <del>Secondary scrambling code</del><br><del>channelisation code</del><br><del>DL channelisation code</del><br><del>Secondary scrambling code</del><br><del>Spreading factor</del><br><br><del>Code number</del><br><del>Scrambling code change</del><br><del>TPC combination index</del><br><del>SSDT Cell Identity</del><br><del>Closed-loop timing adjustment mode</del><br><del>SCCPCH information for FACH</del> |    | 3<br>Reference to TS34.108 clause 6.10<br>Parameter Set<br>0<br>No change<br>0<br>Not Present<br>Not Present<br>Not Present     |
| <del>Downlink information for each radio link</del><br><del>Choice mode</del><br><del>Primary CPICH info</del><br><del>Primary scrambling code</del><br><br><del>PDSCH with SHO-DCH info</del><br><del>PDSCH code mapping</del><br><del>Downlink DPCH info for each RL</del><br><del>SCCPCH information for FACH</del>                                                                                                | A5 | FDD<br><br>Ref. to the Default setting in TS34.108 clause 6.1 (FDD)<br>Not Present<br>Not Present<br>Not present<br>Not Present |
| <del>Downlink information for each radio link</del>                                                                                                                                                                                                                                                                                                                                                                   | A6 | Not Present                                                                                                                     |

| Condition | Explanation                                                 |
|-----------|-------------------------------------------------------------|
| A1        | This IE need for "Non speech in CS"                         |
| A2        | This IE need for "Speech in CS"                             |
| A3        | This IE need for "Packet to CELL_DCH from CELL_DCH in PS"   |
| A4        | This IE need for "Packet to CELL_DCH from CELL_FACH in PS"  |
| A5        | This IE need for "Packet to CELL_FACH from CELL_DCH in PS"  |
| A6        | This IE need for "Packet to CELL_FACH from CELL_FACH in PS" |

#### Contents of RADIO BEARER RELEASE FAILURE message: AM

| Information Element                                                                                                                                                                                                                                 | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier<br><br>Integrity check info<br><br><del>Message authentication code</del><br><del>RRC Message sequence number</del><br><br>Failure cause<br>Radio bearers for which reconfiguration would have succeeded | <br>Checked to see if it is set to identical value of the same IE in the downlink RADIO BEARER RELEASE message.<br>The presence if this IE is dependent on IXT statements in TS 34.123-2, if integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent.<br>This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.<br>This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.<br>Checked to see if it meets test requirement<br>Not checked |

## Contents of UTRAN MOBILITY INFORMATION message: AM or UM

| Information Element                       | Value/remark                                                                                                                                                                                                                             |
|-------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                              |                                                                                                                                                                                                                                          |
| Integrity check info                      | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub IEs as stated below. Else, this IE and the sub IEs are omitted. |
| —— message authentication code            | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                 |
| —— RRC message sequence number            | SS provides the value of this IE, from its internal counter.                                                                                                                                                                             |
| RRC transaction identifier                | Arbitrarily selects an integer between 0 and 3                                                                                                                                                                                           |
| Integrity protection mode info            | Not Present                                                                                                                                                                                                                              |
| Ciphering mode info                       | Not Present                                                                                                                                                                                                                              |
| New U-RNTI                                | See the test content                                                                                                                                                                                                                     |
| New C-RNTI                                | See the test content                                                                                                                                                                                                                     |
| UE Timers and constants in connected mode |                                                                                                                                                                                                                                          |
| —— T301                                   | 2000 milliseconds                                                                                                                                                                                                                        |
| —— N301                                   | 2                                                                                                                                                                                                                                        |
| —— T302                                   | 4000 milliseconds                                                                                                                                                                                                                        |
| —— N302                                   | 3                                                                                                                                                                                                                                        |
| —— T304                                   | 1000 milliseconds                                                                                                                                                                                                                        |
| —— N304                                   | 3                                                                                                                                                                                                                                        |
| —— T305                                   | 60 minutes                                                                                                                                                                                                                               |
| —— T307                                   | 50 seconds                                                                                                                                                                                                                               |
| —— T308                                   | 320 milliseconds                                                                                                                                                                                                                         |
| —— T309                                   | 8 seconds                                                                                                                                                                                                                                |
| —— T310                                   | 320 milliseconds                                                                                                                                                                                                                         |
| —— N310                                   | 5                                                                                                                                                                                                                                        |
| —— T311                                   | 500 milliseconds                                                                                                                                                                                                                         |
| —— T312                                   | 5 seconds                                                                                                                                                                                                                                |
| —— N312                                   | 200                                                                                                                                                                                                                                      |
| —— T313                                   | 10 seconds                                                                                                                                                                                                                               |
| —— N313                                   | 200                                                                                                                                                                                                                                      |
| —— T314                                   | 20 seconds                                                                                                                                                                                                                               |
| —— T315                                   | 30 seconds                                                                                                                                                                                                                               |
| —— N315                                   | 200                                                                                                                                                                                                                                      |
| —— T316                                   | 50 seconds                                                                                                                                                                                                                               |
| —— T317                                   | 1800 seconds                                                                                                                                                                                                                             |
| CN information info                       | Not Present                                                                                                                                                                                                                              |
| URA identity                              | Not present                                                                                                                                                                                                                              |
| Downlink counter synchronisation info     | Not Present                                                                                                                                                                                                                              |

## Contents of UTRAN MOBILITY INFORMATION CONFIRM message: AM

| Information Element                                | Value/remark                                                                                                                                                                                                                                       |
|----------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                       |                                                                                                                                                                                                                                                    |
| RRC transaction identifier                         | Checked to see if it matches the value of the same IE in downlink UTRAN MOBILITY INFORMATION message                                                                                                                                               |
| Integrity check info                               | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub IEs shall be absent. |
| —— Message authentication code                     | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| —— RRC Message sequence number                     | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Uplink integrity protection activation info        | Not checked                                                                                                                                                                                                                                        |
| COUNT-C activation time                            | The presence of this IE depends on the following 2 factors: (a) There exists RB(s) mapped to RLC-TM, (b) UE is transiting to CELL_DCH state after the reconfiguration procedure. Else, this IE is absent.                                          |
| Radio bearer uplink ciphering activation time info | Not checked                                                                                                                                                                                                                                        |
| Uplink counter synchronisation info                | Not checked                                                                                                                                                                                                                                        |

## Contents of RRC CONNECTION REJECT message: UM

| Information Element        | Value/remark                                                                               |
|----------------------------|--------------------------------------------------------------------------------------------|
| Message Type               |                                                                                            |
| RRC transaction identifier | Arbitrarily selects an integer between 0 and 3                                             |
| Initial UE identity        | Select the same type as in the IE "Initial UE Identity" in RRC CONNECTION REQUEST message. |
| Rejection cause            | Unspecified                                                                                |
| Wait Time                  | 0                                                                                          |
| Redirection info           | Not Present                                                                                |

## Contents of RRC CONNECTION SETUP message: UM (Transition to CELL\_FACH)

| Information Element                        | Value/remark                                                                                           |
|--------------------------------------------|--------------------------------------------------------------------------------------------------------|
| Message Type                               |                                                                                                        |
| Initial UE identity                        | Select the same identity as in the IE "Initial UE Identity" in received RRC CONNECTION REQUEST message |
| RRC transaction identifier                 | 0                                                                                                      |
| Activation time                            | Not Present (Now)                                                                                      |
| New U-RNTI                                 |                                                                                                        |
| — SRNC identity                            | 0000-0000-0001B                                                                                        |
| — S-RNTI                                   | 0000-0000-0000-0000-0001B                                                                              |
| New C-RNTI                                 | 0000-0000-0000-0001B                                                                                   |
| RRC state indicator                        | CELL_FACH                                                                                              |
| UTRAN DRX cycle length coefficient         | 9                                                                                                      |
| Capability update requirement              | Not Present                                                                                            |
| Signalling RB information to setup         | (UM-DCCH for RRC)                                                                                      |
| — RB identity                              | 1                                                                                                      |
| — CHOICE RLC info type                     | RLC info                                                                                               |
| — CHOICE Uplink RLC mode                   | UM RLC                                                                                                 |
| — Transmission RLC discard                 |                                                                                                        |
| — SDU discard mode                         | Timer-based no-explicit                                                                                |
| — Timer discard                            | 50                                                                                                     |
| — CHOICE Downlink RLC mode                 | UM RLC                                                                                                 |
| — RB mapping info                          |                                                                                                        |
| — Information for each multiplexing option | 2-RBMuxOptions                                                                                         |
| — RLC logical channel mapping indicator    | Not Present                                                                                            |
| — Number of uplink RLC logical channels    | 1                                                                                                      |
| — Uplink transport channel type            | DCH                                                                                                    |
| — UL Transport channel identity            | 5                                                                                                      |
| — Logical channel identity                 | 1                                                                                                      |
| — CHOICE RLC size list                     | Configured                                                                                             |
| — MAC logical channel priority             | 1                                                                                                      |
| — Downlink RLC logical channel info        |                                                                                                        |
| — Number of downlink RLC logical channels  | 1                                                                                                      |
| — Downlink transport channel type          | DCH                                                                                                    |
| — DL DCH Transport channel identity        | 10                                                                                                     |
| — DL DSCH Transport channel identity       | Not Present                                                                                            |
| — Logical channel identity                 | 1                                                                                                      |
| — RLC logical channel mapping indicator    | Not Present                                                                                            |
| — Number of uplink RLC logical channels    | 1                                                                                                      |
| — Uplink transport channel type            | RACH                                                                                                   |
| — UL Transport channel identity            | Not Present                                                                                            |
| — Logical channel identity                 | 1                                                                                                      |
| — CHOICE RLC size list                     | Explicit list                                                                                          |
| — RLC size index                           | Reference to TS34.108 clause 6 Parameter Set                                                           |
| — MAC logical channel priority             | 2                                                                                                      |
| — Downlink RLC logical channel info        |                                                                                                        |
| — Number of downlink RLC logical channels  | 1                                                                                                      |
| — Downlink transport channel type          | FACH                                                                                                   |
| — DL DCH Transport channel identity        | Not Present                                                                                            |
| — DL DSCH Transport channel identity       | Not Present                                                                                            |
| — Logical channel identity                 | 1                                                                                                      |
| Signalling RB information to setup         | (AM-DCCH for RRC)                                                                                      |
| — RB identity                              | 2                                                                                                      |
| — CHOICE RLC info type                     | RLC info                                                                                               |
| — CHOICE Uplink RLC mode                   | AM RLC                                                                                                 |

| Information Element                      | Value/remark                                 |
|------------------------------------------|----------------------------------------------|
| Transmission RLC discard                 |                                              |
| SDU discard mode                         | Max-DAT retransmissions                      |
| MAX_DAT                                  | 4                                            |
| Timer_MRW                                | 100                                          |
| MaxMRW                                   | 4                                            |
| Transmission window size                 | 8                                            |
| Timer_RST                                | 500                                          |
| Max_RST                                  | 4                                            |
| Polling info                             |                                              |
| Timer_poll_prohibit                      | 200                                          |
| Timer_poll                               | 200                                          |
| Poll_SDU                                 | 1                                            |
| Last transmission PDU poll               | TRUE                                         |
| Last retransmission PDU poll             | TRUE                                         |
| Poll_Windows                             | 99                                           |
| CHOICE Downlink RLC mode                 | AM RLC                                       |
| In-sequence delivery                     | TRUE                                         |
| Receiving window size                    | 8                                            |
| Downlink RLC status info                 |                                              |
| Timer_status_prohibit                    | 200                                          |
| Timer_EPC                                | 200                                          |
| Missing PDU indicator                    | TRUE                                         |
| RB mapping info                          |                                              |
| Information for each multiplexing option | 2-RBMuxOptions                               |
| RLC logical channel mapping indicator    | Not Present                                  |
| Number of uplink RLC logical channels    | 1                                            |
| Uplink transport channel type            | DCH                                          |
| UL Transport channel identity            | 5                                            |
| Logical channel identity                 | 2                                            |
| CHOICE RLC size list                     | Configured                                   |
| MAC logical channel priority             | 2                                            |
| Downlink RLC logical channel info        |                                              |
| Number of downlink RLC logical channels  | 1                                            |
| Downlink transport channel type          | DCH                                          |
| DL DCH Transport channel identity        | 10                                           |
| DL DSCH Transport channel identity       | Not Present                                  |
| Logical channel identity                 | 2                                            |
| RLC logical channel mapping indicator    | Not Present                                  |
| Number of uplink RLC logical channels    | 1                                            |
| Uplink transport channel type            | RACH                                         |
| UL Transport channel identity            | Not Present                                  |
| Logical channel identity                 | 2                                            |
| CHOICE RLC size list                     | Explicit list                                |
| RLC size index                           | Reference to TS34.108 clause 6 Parameter Set |
| MAC logical channel priority             | 3                                            |
| Downlink RLC logical channel info        |                                              |
| Number of downlink RLC logical channels  | 1                                            |
| Downlink transport channel type          | FACH                                         |
| DL DCH Transport channel identity        | Not Present                                  |
| DL DSCH Transport channel identity       | Not Present                                  |
| Logical channel identity                 | 2                                            |
| Signalling RB information to setup       | (AM-DCCH for NAS_DT High priority)           |
| RB identity                              | 3                                            |
| CHOICE RLC info type                     | RLC info                                     |
| CHOICE Uplink RLC mode                   | AM RLC                                       |
| Transmission RLC discard                 |                                              |
| SDU discard mode                         | Max-DAT retransmissions                      |
| MAX_DAT                                  | 4                                            |
| Timer_MRW                                | 100                                          |
| MaxMRW                                   | 4                                            |
| Transmission window size                 | 8                                            |
| Timer_RST                                | 500                                          |
| Max_RST                                  | 4                                            |
| Polling info                             |                                              |
| Timer_poll_prohibit                      | 200                                          |
| Timer_poll                               | 200                                          |
| Poll_SDU                                 | 1                                            |

| Information Element                        | Value/remark                                 |
|--------------------------------------------|----------------------------------------------|
| → Last transmission PDU poll               | TRUE                                         |
| → Last retransmission PDU poll             | TRUE                                         |
| → Poll_Windows                             | 99                                           |
| → CHOICE Downlink RLC mode                 | AM-RLC                                       |
| → In-sequence delivery                     | TRUE                                         |
| → Receiving window size                    | 8                                            |
| → Downlink RLC status info                 |                                              |
| → Timer_status_prohibit                    | 200                                          |
| → Timer_EPC                                | 200                                          |
| → Missing PDU indicator                    | TRUE                                         |
| → RB mapping info                          |                                              |
| → Information for each multiplexing option | 2-RBMuxOptions                               |
| → RLC logical channel mapping indicator    | Not Present                                  |
| → Number of uplink RLC logical channels    | 1                                            |
| → Uplink transport channel type            | DCH                                          |
| → UL Transport channel identity            | 5                                            |
| → Logical channel identity                 | 3                                            |
| → CHOICE RLC size list                     | Configured                                   |
| → MAC logical channel priority             | 3                                            |
| → Downlink RLC logical channel info        |                                              |
| → Number of downlink RLC logical channels  | 1                                            |
| → Downlink transport channel type          | DCH                                          |
| → DL DCH Transport channel identity        | 10                                           |
| → DL DSCH Transport channel identity       | Not Present                                  |
| → Logical channel identity                 | 3                                            |
| → RLC logical channel mapping indicator    | Not Present                                  |
| → Number of uplink RLC logical channels    | 1                                            |
| → Uplink transport channel type            | RACH                                         |
| → UL DCH Transport channel identity        | Not Present                                  |
| → Logical channel identity                 | 3                                            |
| → CHOICE RLC size list                     | Explicit list                                |
| → RLC size index                           | Reference to TS34.108 clause 6 Parameter Set |
| → MAC logical channel priority             | 4                                            |
| → Downlink RLC logical channel info        |                                              |
| → Number of downlink RLC logical channels  | 1                                            |
| → Downlink transport channel type          | FACH                                         |
| → DL DCH Transport channel identity        | Not Present                                  |
| → DL DSCH Transport channel identity       | Not Present                                  |
| → Logical channel identity                 | 3                                            |
| → Signalling RB information to setup       | (AM-DCCH for NAS_DT Low priority)            |
| → RB identity                              | 4                                            |
| → CHOICE RLC info type                     | RLC info                                     |
| → CHOICE Uplink RLC mode                   | AM-RLC                                       |
| → Transmission RLC discard                 |                                              |
| → SDU discard mode                         | Max-DAT retransmissions                      |
| → MAX_DAT                                  | 4                                            |
| → Timer_MRW                                | 100                                          |
| → MaxMRW                                   | 4                                            |
| → Transmission window size                 | 8                                            |
| → Timer_RST                                | 500                                          |
| → Max_RST                                  | 4                                            |
| → Polling info                             |                                              |
| → Timer_poll_prohibit                      | 200                                          |
| → Timer_poll                               | 200                                          |
| → Poll_SDU                                 | 1                                            |
| → Last transmission PDU poll               | TRUE                                         |
| → Last retransmission PDU poll             | TRUE                                         |
| → Poll_Windows                             | 99                                           |
| → CHOICE Downlink RLC mode                 | AM-RLC                                       |
| → In-sequence delivery                     | TRUE                                         |
| → Receiving window size                    | 8                                            |
| → Downlink RLC status info                 |                                              |
| → Timer_status_prohibit                    | 200                                          |
| → Timer_EPC                                | 200                                          |
| → Missing PDU indicator                    | TRUE                                         |
| → RB mapping info                          |                                              |
| → Information for each multiplexing option | 2-RBMuxOptions                               |



| Information Element                                               | Value/remark                                                                                                                                        |
|-------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
| RLC logical channel mapping indicator                             | Not Present                                                                                                                                         |
| Number of uplink RLC logical channels                             | 1                                                                                                                                                   |
| Uplink transport channel type                                     | DCH                                                                                                                                                 |
| UL Transport channel identity                                     | 5                                                                                                                                                   |
| Logical channel identity                                          | 4                                                                                                                                                   |
| CHOICE RLC size list                                              | Configured                                                                                                                                          |
| MAC logical channel priority                                      | 4                                                                                                                                                   |
| Downlink RLC logical channel info                                 |                                                                                                                                                     |
| Number of downlink RLC logical channels                           | 1                                                                                                                                                   |
| Downlink transport channel type                                   | DCH                                                                                                                                                 |
| DL DCH Transport channel identity                                 | 10                                                                                                                                                  |
| DL DSCH Transport channel identity                                | Not Present                                                                                                                                         |
| Logical channel identity                                          | 4                                                                                                                                                   |
| RLC logical channel mapping indicator                             | Not Present                                                                                                                                         |
| Number of uplink RLC logical channels                             | 1                                                                                                                                                   |
| Uplink transport channel type                                     | RACH                                                                                                                                                |
| UL Transport channel identity                                     | Not Present                                                                                                                                         |
| Logical channel identity                                          | 4                                                                                                                                                   |
| CHOICE RLC size list                                              | Explicit list                                                                                                                                       |
| RLC size index                                                    | Reference to TS34.108 clause 6 Parameter Set                                                                                                        |
| MAC logical channel priority                                      | 5                                                                                                                                                   |
| Downlink RLC logical channel info                                 |                                                                                                                                                     |
| Number of downlink RLC logical channels                           | 1                                                                                                                                                   |
| Downlink transport channel type                                   | FACH                                                                                                                                                |
| DL DCH Transport channel identity                                 | Not Present                                                                                                                                         |
| DL DSCH Transport channel identity                                | Not Present                                                                                                                                         |
| Logical channel identity                                          | 4                                                                                                                                                   |
| UL Transport channel information for all transport channels       | Not Present                                                                                                                                         |
| Added or Reconfigured TrCH information list                       | TS 25.331 specifies that "Although this IE is not required when the IE "RRC state indicator" is set to "CELL_FACH", need is MP to align with ASN.1" |
| Added or Reconfigured UL TrCH information                         |                                                                                                                                                     |
| Uplink transport channel type                                     | DCH                                                                                                                                                 |
| UL Transport channel identity                                     | 5                                                                                                                                                   |
| TFS                                                               |                                                                                                                                                     |
| CHOICE Transport channel type                                     | Delicated transport channels                                                                                                                        |
| Dynamic Transport format information                              |                                                                                                                                                     |
| RLC Size                                                          | Reference to TS34.108 clause 6.10 Parameter Set (This IE is repeated for TFI number.)                                                               |
| Number of TBs and TTI List                                        | Not Present                                                                                                                                         |
| Transmission Time Interval                                        | Reference to TS34.108 clause 6.10 Parameter Set                                                                                                     |
| Number of Transport blocks                                        | ALL                                                                                                                                                 |
| CHOICE Logical Channel List                                       |                                                                                                                                                     |
| Semi-static Transport Format information                          | Reference to TS34.108 clause 6.10 Parameter Set                                                                                                     |
| Transmission time interval                                        | Reference to TS34.108 clause 6.10 Parameter Set                                                                                                     |
| Type of channel coding                                            | Reference to TS34.108 clause 6.10 Parameter Set                                                                                                     |
| Coding Rate                                                       | Reference to TS34.108 clause 6.10 Parameter Set                                                                                                     |
| Rate matching attribute                                           | Reference to TS34.108 clause 6.10 Parameter Set                                                                                                     |
| CRC size                                                          | Reference to TS34.108 clause 6.10 Parameter Set                                                                                                     |
| DL Transport channel information common for all transport channel | Not Present(Refer to SIB type 5)                                                                                                                    |
| Added or Reconfigured TrCH information list                       | TS 25.331 specifies that "Although this IE is not required when the IE "RRC state indicator" is set to "CELL_FACH", need is MP to align with ASN.1" |
| Added or Reconfigured DL TrCH information                         |                                                                                                                                                     |
| Downlink transport channel type                                   | DCH                                                                                                                                                 |
| DL Transport channel identity                                     | 10                                                                                                                                                  |
| CHOICE DL parameters                                              | Same as UL                                                                                                                                          |
| Uplink Transport channel type                                     | DCH                                                                                                                                                 |
| UL TrCH identity                                                  | 5                                                                                                                                                   |
| DCH quality target                                                | Not Present                                                                                                                                         |
| Transparent mode signalling info                                  | Not Present                                                                                                                                         |
| Frequency info                                                    |                                                                                                                                                     |
| UARFCN uplink (Nu)                                                | Reference to clause 5.1 Test frequencies                                                                                                            |
| UARFCN downlink (Nd)                                              | Reference to clause 5.1 Test frequencies                                                                                                            |
| Maximum allowed UL TX power                                       | 33dBm                                                                                                                                               |
| CHOICE channel requirement                                        | Not Present                                                                                                                                         |

| Information Element                             | Value/remark                                             |
|-------------------------------------------------|----------------------------------------------------------|
| Downlink information common for all radio links | Not Present                                              |
| Downlink information for each radio link list   |                                                          |
| — Downlink information for each radio link      |                                                          |
| — Choice mode                                   | FDD                                                      |
| — Primary CPICH info                            |                                                          |
| — Primary scrambling code                       | Ref. to the Default setting in TS34.108 clause 6.1 (FDD) |
| — PDSCH with SHO-DCH info                       | Not Present                                              |
| — PDSCH code mapping                            | Not Present                                              |
| — Downlink DPCH info for each RL                | Not present                                              |
| — SCCPCH information for FACH                   | Not Present                                              |

## Contents of RRC STATUS message: AM

| Information Element                | Value/remark                                                                                                                                                                                                                                       |
|------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                       |                                                                                                                                                                                                                                                    |
| Integrity check info               | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| — Message authentication code      | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| — RRC Message sequence number      | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Identification of received message | Not Checked                                                                                                                                                                                                                                        |
| Protocol error information         |                                                                                                                                                                                                                                                    |
| — Protocol error cause             | Refer to test requirement.                                                                                                                                                                                                                         |

## Contents of SECURITY MODE FAILURE message: AM

| Information Element           | Value/remark                                                                                                                                                                                                                                       |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                  |                                                                                                                                                                                                                                                    |
| RRC transaction identifier    | Checked to see if the value is the identical to the same IE in the downlink SECURITY MODE COMMAND message.                                                                                                                                         |
| Integrity check info          | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| — Message authentication code | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| — RRC Message sequence number | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Failure cause                 | Refer to test requirement.                                                                                                                                                                                                                         |

## Contents of TRANSPORT CHANNEL RECONFIGURATION message: AM or UM

| Information Element           | Condition              | Value/remark                                                                                                                                                                                                                             |
|-------------------------------|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                  | A1, A2, A3, A4, A5, A6 |                                                                                                                                                                                                                                          |
| RRC transaction identifier    |                        | Arbitrarily selects an integer between 0 and 3                                                                                                                                                                                           |
| Integrity check info          |                        | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| — message authentication code |                        | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                 |
| — RRC message sequence number |                        | SS provides the value of this IE, from its                                                                                                                                                                                               |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Condition              | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Integrity protection mode info<br>Ciphering mode info<br>Activation time<br>New U-RNTI<br>New C-RNTI                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                        | internal counter.<br>Not Present<br>Not Present<br>(256+CFN-(CFN MOD 8 + 8))MOD 256<br>Not Present<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| RRC State indicator                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | A1, A2, A3, A4         | CELL_DCH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| RRC State indicator                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | A5, A6                 | CELL_FACH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| UTRAN DRX cycle length coefficient                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | A1, A2, A3, A4, A5, A6 | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| CN information info<br>URA identity<br>Downlink counter synchronisation info                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                        | Not Present<br>Not Present<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| UL Transport channel information for all transport channels                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | A1, A2, A5, A6         | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| UL Transport channel information for all transport channels<br><del>PRACH TFCS</del><br><del>CHOICE mode</del><br><del>TFC subset</del><br><del>UL DCH TFCS</del><br><del>CHOICE TFCI signalling</del><br><del>TFCI Field 1 information</del><br><del>CHOICE TFCS representation</del><br><del>TFCS complete reconfigure information</del><br><del>CHOICE CTFC Size</del><br><br><del>CTFC information</del><br><br><del>CTFC</del><br><br><del>Power offset information</del><br><del>CHOICE Gain Factors</del><br><br><del>Gain factor <math>\beta_c</math></del><br><br><del>Gain factor <math>\beta_d</math></del><br><br><del>Reference TFC ID</del><br><del>CHOICE mode</del><br><del>Power offset P<sub>p-m</sub></del> | A3, A4                 | Not Present<br>FDD<br>Not Present<br><br>Normal<br><br>Complete reconfiguration<br><br>Number of bits used must be enough to cover all combinations of CTFC from TS34.108 clause 6.10 Parameter Set.<br>This IE is repeated for TFC numbers and reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br><br>Computed Gain Factors (The last TFC is set to Signalled Gain Factors)<br>11 (below 64 kbps)<br>9 (higher than 64 kbps)<br>(Not Present if the CHOICE Gain Factors is set to Computed Gain Factors)<br>15<br>(Not Present if the CHOICE Gain Factors is set to Computed Gain Factors)<br>0<br>FDD<br>Not Present |
| Added or Reconfigured UL TrCH information                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | A1, A2, A5, A6         | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Condition | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Added or Reconfigured UL TrCH information<br>— Uplink transport channel type<br>— UL Transport channel identity<br>— TFS<br>— CHOICE Transport channel type<br>— Dynamic Transport format information<br>— RLC Size<br><br>— Number of TBs and TTI List<br>— Transmission Time Interval<br>— Number of Transport blocks<br><br>— CHOICE Logical Channel list<br>— Semi-static Transport Format information<br>— Transmission time interval<br><br>— Type of channel coding<br><br>— Coding Rate<br><br>— Rate matching attribute<br><br>— CRC size<br><br>— Uplink transport channel type<br>— UL Transport channel identity<br>— TFS<br>— CHOICE Transport channel type<br>— Dynamic Transport format information<br>— RLC Size<br><br>— Number of TBs and TTI List<br>— Transmission Time Interval<br>— Number of Transport blocks<br><br>— CHOICE Logical Channel list<br>— Semi-static Transport Format information<br>— Transmission time interval<br><br>— Type of channel coding<br><br>— Coding Rate<br><br>— Rate matching attribute<br><br>— CRC size | A4        | 2 TrCHs(DCH for DCCH and DCH for DTCH)<br>DCH<br>5<br><br>Dedicated transport channels<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br>All<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>DCH<br>1<br><br>Dedicated transport channels<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br>All<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set |
| Added or Reconfigured UL TrCH information<br>— Uplink transport channel type<br>— UL Transport channel identity<br>— TFS<br>— CHOICE Transport channel type<br>— Dynamic Transport format information<br>— RLC Size<br><br>— Number of TBs and TTI List<br>— Transmission Time Interval<br>— Number of Transport blocks<br><br>— CHOICE Logical Channel list<br>— Semi-static Transport Format information<br>— Transmission time interval<br><br>— Type of channel coding<br><br>— Coding Rate                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | A3        | (DCH for DTCH)<br>DCH<br>1<br><br>Dedicated transport channels<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br>All<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | Condition         | Value/remark                                                                                                                                                                                                                                                                                                                                                        |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>→ Rate matching attribute</li> <li>→ CRC size</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                        |                   | Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set                                                                                                                                                                                                                                                                  |
| CHOICE mode <ul style="list-style-type: none"> <li>→ CPCH set ID</li> <li>→ Added or Reconfigured TrCH information for DRAC list</li> </ul>                                                                                                                                                                                                                                                                                                                                                                            | A1,A2,A3,A4,A5,A6 | FDD<br><br>Not Present<br>Not Present                                                                                                                                                                                                                                                                                                                               |
| DL Transport channel information common for all transport channel                                                                                                                                                                                                                                                                                                                                                                                                                                                      | A1, A2, A5,A6     | Not Present                                                                                                                                                                                                                                                                                                                                                         |
| DL Transport channel information common for all transport channel <ul style="list-style-type: none"> <li>→ SCCPCH TFCS</li> <li>→ CHOICE mode</li> <li>→ CHOICE DL parameters</li> <li>→ DL DCH TFCS</li> <li>→ CHOICE TFCI Signalling</li> <li>→ TFCI Field 1 Information</li> <li>→ CHOICE TFCS representation</li> <li>→ TFCS complete reconfigure</li> <li>→ CHOICE CTFC Size</li> <li>→ CTFC information</li> <li>→ CTFC</li> <li>→ Power offset information</li> </ul> Added or Reconfigured DL TrCH information | A3,A4             | Not Present<br>FDD<br>Explicit<br><br>Normal<br><br>Complete reconfiguration<br><br>Number of bits used must be enough to cover all combinations of CTFC from clause TS34.108 clause 6.10 Parameter Set. This IE is repeated for TFC numbers and reference to TS34.108 clause 6.10<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Not Present<br>Not Present |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Condition             | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Added or Reconfigured DL TrCH information<br>— Downlink transport channel type<br>— DL Transport channel identity<br>— CHOICE DL parameters<br>— Uplink transport channel type<br>— UL TrCH identity<br>— DCH quality target<br>— BLER Quality value<br>— Transparent mode signalling info<br>— Downlink transport channel type<br>— DL Transport channel identity<br>— CHOICE DL parameters<br>— TFS<br>— CHOICE Transport channel type<br>— Dynamic transport format information<br>— RLC Size<br><br>— Number of TBs and TTI List<br>— Dynamic transport format information<br>— Transmission Time Interval<br>— Number of Transport blocks<br><br>— Semi-static Transport Format information<br>— Transmission time interval<br><br>— Type of channel coding<br><br>— Coding Rate<br><br>— Rate matching attribute<br><br>— CRC size<br><br>— DCH quality target<br>— BLER Quality value<br>— Transparent mode signalling info | A4                    | 2 TrCHs(DCH for DCCH and DCH for DTCH)<br>DCH<br>10<br>Same as UL<br>DCH<br>5<br><br>Not Present<br>Not Present<br>DCH<br>6<br>Explicit<br><br>Dedicated transport channel<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>(This IE is repeated for TFI number.)<br><br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br><br>-6.3<br>Not Present |
| Added or Reconfigured DL TrCH information<br>— Downlink transport channel type<br>— DL Transport channel identity<br>— CHOICE DL parameters<br>— TFS<br>— CHOICE Transport channel type<br>— Dynamic transport format information<br>— RLC Size<br><br>— Number of TBs and TTI List<br>— Dynamic transport format information<br>— Transmission Time Interval<br>— Number of Transport blocks<br><br>— Semi-static Transport Format information<br>— Transmission time interval<br><br>— Type of channel coding<br><br>— Coding Rate<br><br>— Rate matching attribute<br><br>— CRC size<br><br>— DCH quality target<br>— BLER Quality value<br>— Transparent mode signalling info                                                                                                                                                                                                                                                  | A3                    | DCH<br>6<br>Explicit<br><br>Dedicated transport channel<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>(This IE is repeated for TFI number.)<br><br>Not Present<br>Reference to TS34.108 clause 6.10 Parameter Set<br><br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br>Reference to TS34.108 clause 6.10 Parameter Set<br><br>-6.3<br>Not Present                                                                                                                    |
| Frequency info<br><br>— UARFCN uplink (Nu)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | A1,A2,A3,<br>A4,A5,A6 | Reference to clause 5.1 Test frequencies                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

| Information Element                                         | Condition                     | Value/remark                                               |
|-------------------------------------------------------------|-------------------------------|------------------------------------------------------------|
| <del>UARFCN downlink (Nd)</del>                             |                               | Reference to clause 5.1 Test frequencies                   |
| Maximum allowed UL TX power                                 | A1,A2,A3,<br>A4,A5,A6         | 33dBm                                                      |
| <del>CHOICE channel requirement</del>                       | <del>A5, A6</del>             | <del>Not Present</del>                                     |
| <del>CHOICE channel requirement</del>                       | <del>A1, A2, A3,<br/>A4</del> | <del>Uplink DPCH info</del>                                |
| <del>Uplink DPCH power control info</del>                   |                               | <del>-6dB</del>                                            |
| <del>DPCCH power offset</del>                               |                               | <del>1 frame</del>                                         |
| <del>PC Preamble</del>                                      |                               | <del>7 frames</del>                                        |
| <del>SRB delay</del>                                        |                               | <del>Algorithm1</del>                                      |
| <del>Power Control Algorithm</del>                          |                               | <del>1dB</del>                                             |
| <del>TPC step size</del>                                    |                               | <del>Long</del>                                            |
| <del>Scrambling code type</del>                             |                               | <del>0 (0 to 16777215)</del>                               |
| <del>Scrambling code number</del>                           |                               | <del>Not Present(1)</del>                                  |
| <del>Number of DPDCH</del>                                  |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| <del>spreading factor</del>                                 |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| <del>TFCI existence</del>                                   |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| <del>Number of FBI bit</del>                                |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| <del>Puncturing Limit</del>                                 |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| CHOICE Mode                                                 | A1,A2,A3,<br>A4,A5,A6         | FDD                                                        |
| <del>Downlink PDSCH information</del>                       |                               | <del>Not Present</del>                                     |
| Downlink information common for all radio links             | A5, A6                        | Not Present                                                |
| Downlink information common for all radio links             | A1, A2, A3                    |                                                            |
| <del>Downlink DPCH info common for all RL</del>             |                               | <del>Maintain</del>                                        |
| <del>Timing indicator</del>                                 |                               | <del>Not Present</del>                                     |
| <del>CFN-targetSFN frame offset</del>                       |                               | <del>0 (single)</del>                                      |
| <del>Downlink DPCH power control information</del>          |                               | <del>FDD</del>                                             |
| <del>DPC mode</del>                                         |                               | <del>0</del>                                               |
| <del>CHOICE mode</del>                                      |                               | <del>Not Present</del>                                     |
| <del>Power offset <math>P_{\text{Pilot-DPDCH}}</math></del> |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| <del>DL rate matching restriction information</del>         |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| <del>Spreading factor</del>                                 |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| <del>Fixed or Flexible Position</del>                       |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| <del>TFCI existence</del>                                   |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| <del>CHOICE SF</del>                                        |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| <del>DPCH compressed mode info</del>                        |                               | <del>Not Present</del>                                     |
| <del>TX Diversity mode</del>                                |                               | <del>None</del>                                            |
| <del>SSDT information</del>                                 |                               | <del>Not Present</del>                                     |
| <del>Default DPCH Offset Value</del>                        |                               | <del>Not Present</del>                                     |
| Downlink information common for all radio links             | A4                            |                                                            |
| <del>Downlink DPCH info common for all RL</del>             |                               | <del>Initialise</del>                                      |
| <del>Timing indicator</del>                                 |                               | <del>Not Present</del>                                     |
| <del>CFN-targetSFN frame offset</del>                       |                               | <del>0 (single)</del>                                      |
| <del>Downlink DPCH power control information</del>          |                               | <del>FDD</del>                                             |
| <del>DPC mode</del>                                         |                               | <del>0</del>                                               |
| <del>CHOICE mode</del>                                      |                               | <del>Not Present</del>                                     |
| <del>Power offset <math>P_{\text{Pilot-DPDCH}}</math></del> |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| <del>DL rate matching restriction information</del>         |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| <del>Spreading factor</del>                                 |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| <del>Fixed or Flexible Position</del>                       |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| <del>TFCI existence</del>                                   |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| <del>CHOICE SF</del>                                        |                               | <del>Reference to TS34.108 clause 6.10 Parameter Set</del> |
| <del>DPCH compressed mode info</del>                        |                               | <del>Not Present</del>                                     |
| <del>TX Diversity mode</del>                                |                               | <del>None</del>                                            |

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Condition                 | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <del>SSDT information</del><br><del>Default DPCH Offset Value</del>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                           | <del>Not Present</del><br><del>Not Present</del>                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <del>Downlink information for each radio link list</del><br><del>Downlink information for each radio links</del><br><del>CHOICE mode</del><br><del>Primary CPICH info</del><br><del>Primary scrambling code</del><br><del>PDSCH with SHO-DCH info</del><br><del>PDSCH code mapping</del><br><del>Downlink DPCH info for each RL</del><br><del>Primary CPICH usage for channel estimation</del><br><del>DPCH frame offset</del><br><del>Power offset <math>P_{\text{Pilot-DPCH}}</math></del><br><del>Secondary CPICH info</del><br><del>DL channelisation code</del><br><del>Secondary scrambling code</del><br><del>Spreading factor</del><br><del>Code number</del><br><del>Scrambling code change</del><br><del>TPC combination index</del><br><del>SSDT Cell Identity</del><br><del>Closed loop timing adjustment mode</del><br><del>SCCPCH information for FACH</del> | <del>A1, A2, A3, A4</del> | <del>FDD</del><br><del>Ref. to the Default setting in TS34.108 clause 6.1 (FDD)</del><br><del>Not Present</del><br><del>Not Present</del><br><del>Primary CPICH may be used</del><br><del>0 chips</del><br><del>0</del><br><del>Not Present</del><br><del>4</del><br><del>Reference to TS34.108 clause 6.10 Parameter Set</del><br><del>0</del><br><del>No change</del><br><del>0</del><br><del>Not Present</del><br><del>Not Present</del><br><del>Not Present</del> |
| <del>Downlink information for each radio link</del><br><del>Choice mode</del><br><del>Primary CPICH info</del><br><del>Primary scrambling code</del><br><del>PDSCH with SHO-DCH info</del><br><del>PDSCH code mapping</del><br><del>Downlink DPCH info for each RL</del><br><del>SCCPCH information for FACH</del>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | <del>A5</del>             | <del>FDD</del><br><del>Ref. to the Default setting in TS34.108 clause 6.1 (FDD)</del><br><del>Not Present</del><br><del>Not Present</del><br><del>Not present</del><br><del>Not Present</del>                                                                                                                                                                                                                                                                         |
| <del>Downlink information for each radio link</del><br><del>Choice mode</del><br><del>Primary CPICH info</del><br><del>Primary scrambling code</del><br><del>PDSCH with SHO-DCH info</del><br><del>PDSCH code mapping</del><br><del>Downlink DPCH info for each RL</del><br><del>SCCPCH information for FACH</del>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | <del>A6</del>             | <del>FDD</del><br><del>Different from the Default setting in TS34.108 clause 6.1 (FDD)</del><br><del>Not Present</del><br><del>Not Present</del><br><del>Not present</del><br><del>Not Present</del>                                                                                                                                                                                                                                                                  |

| Condition | Explanation                                                 |
|-----------|-------------------------------------------------------------|
| A1        | This IE need for "Non speech in CS"                         |
| A2        | This IE need for "Speech in CS"                             |
| A3        | This IE need for "Packet to CELL_DCH from CELL_DCH in PS"   |
| A4        | This IE need for "Packet to CELL_DCH from CELL_FACH in PS"  |
| A5        | This IE need for "Packet to CELL_FACH from CELL_DCH in PS"  |
| A6        | This IE need for "Packet to CELL_FACH from CELL_FACH in PS" |



## Contents of TRANSPORT CHANNEL RECONFIGURATION COMPLETE message: AM

| Information Element                                | Value/remark                                                                                                                                                                                                                                       |
|----------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                       |                                                                                                                                                                                                                                                    |
| RRC transaction identifier                         | Checked to see if the value is identical to the same IE in the downlink TRANSPORT CHANNEL RECONFIGURATION message                                                                                                                                  |
| Integrity check info                               | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| —— Message authentication code                     | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| —— RRC Message sequence number                     | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Uplink integrity protection activation info        | Not checked                                                                                                                                                                                                                                        |
| CHOICE mode                                        | FDD                                                                                                                                                                                                                                                |
| COUNT-C activation time                            | The presence of this IE depends on the following 2 factors: (a) There exists RB(s) mapped to RLC-TM and (b) UE is transiting to CELL_DCH state after the reconfiguration procedure. Else, this IE is absent.                                       |
| Radio bearer uplink ciphering activation time info | Not checked                                                                                                                                                                                                                                        |
| Uplink counter synchronisation info                | Not checked                                                                                                                                                                                                                                        |

## Contents of TRANSPORT CHANNEL RECONFIGURATION FAILURE message: AM

| Information Element            | Value/remark                                                                                                                                                                                                                                       |
|--------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                   |                                                                                                                                                                                                                                                    |
| RRC transaction identifier     | Checked to see if it is set to identical value of the same IE in the downlink TRANSPORT CHANNEL RECONFIGURATION message.                                                                                                                           |
| Integrity check info           | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| —— Message authentication code | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| —— RRC Message sequence number | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Failure cause                  | Checked to see if it meets test requirement                                                                                                                                                                                                        |

## Contents of TRANSPORT FORMAT COMBINATION CONTROL message: AM or UM (in CELL\_DCH)

| Information Element                     | Value/remark                                                                                                                                                                                                                             |
|-----------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                            |                                                                                                                                                                                                                                          |
| RRC transaction identifier              | Arbitrarily selects an integer between 0 and 3                                                                                                                                                                                           |
| Integrity check info                    | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| —— Message authentication code          | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                 |
| —— RRC Message sequence number          | SS provides the value of this IE, from its internal counter.                                                                                                                                                                             |
| CHOICE mode                             | FDD                                                                                                                                                                                                                                      |
| DPCH/PUSCH TFCS in Uplink               |                                                                                                                                                                                                                                          |
| —CHOICE Subset representation           | Allowed transport format combination list                                                                                                                                                                                                |
| —— Allowed Transport format combination | 0 (The TFC is constructed from ALL TF0)                                                                                                                                                                                                  |
| Activation time for TFC subset          | Not Present                                                                                                                                                                                                                              |
| TFC Control duration                    | Not Present                                                                                                                                                                                                                              |

## Contents of UE CAPABILITY ENQUIRY message: AM or UM

| Information Element                                   | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                          | Arbitrarily selects an integer between 0 and 3<br>The presence of this IE is dependent on IXT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted.<br>SS calculates the value of MAC-I for this message and writes to this IE.<br>SS provides the value of this IE, from its internal counter. |
| RRC transaction identifier                            |                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Integrity check info                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| —— Message authentication code                        |                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| —— RRC Message sequence number                        | TRUE                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Capability update requirement                         |                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| —— UE radio access FDD capability update requirement  |                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| —— UE radio access TDD capability update requirement  |                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| —— System specific capability update requirement list | FALSE                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|                                                       | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                           |

## Contents of UE CAPABILITY INFORMATION message: AM

| Information Element                   | Value/remark                                                                                                                                                                                                                                                                                                                                                |
|---------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                          | Checked to see if the value is identical to the same IE in the downlink UE CAPABILITY ENQUIRY message.<br>The presence of this IE is dependent on IXT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| RRC transaction identifier            |                                                                                                                                                                                                                                                                                                                                                             |
| Integrity check info                  |                                                                                                                                                                                                                                                                                                                                                             |
| —— Message authentication code        |                                                                                                                                                                                                                                                                                                                                                             |
| —— RRC Message sequence number        | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.<br>This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                              |
| UE radio access capability            |                                                                                                                                                                                                                                                                                                                                                             |
| —— ICS Version                        |                                                                                                                                                                                                                                                                                                                                                             |
| —— PDCP Capability                    |                                                                                                                                                                                                                                                                                                                                                             |
| —— RLC Capability                     | Value will be checked. Stated capability must be compatible with 34.123-2 (ICS statements) and the user settings                                                                                                                                                                                                                                            |
| —— Transport channel capability       |                                                                                                                                                                                                                                                                                                                                                             |
| —— RF Capability FDD                  |                                                                                                                                                                                                                                                                                                                                                             |
| —— RF Capability TDD                  |                                                                                                                                                                                                                                                                                                                                                             |
| —— Physical channel capability        |                                                                                                                                                                                                                                                                                                                                                             |
| —— UE multi-mode/multi-RAT capability |                                                                                                                                                                                                                                                                                                                                                             |
| —— Security Capability                |                                                                                                                                                                                                                                                                                                                                                             |
| —— LCS Capability                     |                                                                                                                                                                                                                                                                                                                                                             |
| —— Measurement capability             |                                                                                                                                                                                                                                                                                                                                                             |
| UE radio access capability extension  |                                                                                                                                                                                                                                                                                                                                                             |
| UE system specific capability         | Value will be checked. Stated capability must be compatible with 34.123-2 (ICS statements) and the user settings<br>Not Checked                                                                                                                                                                                                                             |

## Contents of UE CAPABILITY INFORMATION CONFIRM message: UM

| Information Element             | Value/remark                                                                                                                                                                                                                                                                                                                                                                    |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                    | The presence of this IE is dependent on I-XIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub IEs as stated below. Else, this IE and the sub IEs are omitted. SS calculates the value of MAC-I for this message and writes to this IE. SS provides the value of this IE, from its internal counter. |
| Integrity check info            |                                                                                                                                                                                                                                                                                                                                                                                 |
| ——— Message authentication code |                                                                                                                                                                                                                                                                                                                                                                                 |
| ——— RRC Message sequence number |                                                                                                                                                                                                                                                                                                                                                                                 |

## Contents of URA UPDATE message: TM

| Information Element             | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                    | 0000-0000-0001B<br>0000-0000-0000-0000-0001B<br>Checked to see if it is absent<br>The presence of this IE is dependent on I-XIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub IEs shall be absent.<br>This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS. This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.<br>See the test content<br>Checked to see if it is absent or set to 'FALSE'<br>Checked to see if it is absent |
| U-RNTI                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| ——— SRNC identity               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| ——— S-RNTI                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| RRC transaction identifier      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Integrity check info            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| ——— Message authentication code |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| ——— RRC Message sequence number |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| URA update cause                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Protocol error indicator        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Protocol error information      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

## Contents of URA UPDATE CONFIRM message: UM

| Information Element                   | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|---------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                          | If this message is sent on CCCH, use the following values. Else, this IE is absent.<br>0000-0000-0001B<br>0000-0000-0000-0000-0001B<br>Arbitrarily selects and integer between 0 and 3<br>The presence of this IE is dependent on I-XIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub IEs as stated below. Else, this IE and the sub IEs are omitted. SS calculates the value of MAC-I for this message and writes to this IE. SS provides the value of this IE, from its internal counter.<br>Not Present<br>Not Present<br>Not Present<br>Not Present<br>URA_PCH<br>Not Present<br>Not Present<br>See the test content<br>Not Present |
| U-RNTI                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| ——— SRNC identity                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| ——— S-RNTI                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| RRC transaction identifier            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Integrity check info                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| ——— message authentication code       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| ——— RRC message sequence number       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Integrity protection mode info        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Ciphering mode info                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| New U-RNTI                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| New C-RNTI                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| RRC state indicator                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| UTRAN-DRX cycle length coefficient    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| CN information info                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| URA identity                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Downlink counter synchronisation info |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

## A.2 Default RRC Message Contents (3.84 Mcps TDD)

[FFS]

## ~~A.3 Default RRC Message Contents (1.28 Mcps TDD)~~

~~This clause contains the default values of RRC messages, other than those specified in TS 34.108 clauses 6 and 9. Unless indicated otherwise in specific test cases, they shall be transmitted by the system simulator in RRC messages, and which are required to be received from the UE under test.~~

~~The necessary L3 messages are listed in alphabetic order, with the exception of the SYSTEM INFORMATION messages, where it is the information elements which are listed in alphabetic order (this is because some information elements occur in several SYSTEM INFORMATION types).~~

~~In this clause, decimal values are normally used. However, sometimes a hexadecimal value, indicated by an "H", or a binary value, indicated by a "B" is used.~~

~~Default SYSTEM INFORMATION:~~

~~NOTE 1: SYSTEM INFORMATION BLOCK TYPE 1 (except for PLMN type "GSM-MAP"), SYSTEM INFORMATION BLOCK TYPE 8, SYSTEM INFORMATION BLOCK TYPE 9, SYSTEM INFORMATION BLOCK TYPE 10, SYSTEM INFORMATION BLOCK TYPE 14, SYSTEM INFORMATION BLOCK TYPE 15 and SYSTEM INFORMATION BLOCK TYPE 16 messages are not used.~~

## Contents of CELL UPDATE message: TM

| Information Element                  | Value/remark                                                                                                                                                                                                                                       |
|--------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                         |                                                                                                                                                                                                                                                    |
| U-RNTI                               | Checked to see if it is set to the following values<br>0000 0000 0001B                                                                                                                                                                             |
| —— SRNC identity                     | 0000 0000 0000 0000 0001B                                                                                                                                                                                                                          |
| —— S-RNTI                            |                                                                                                                                                                                                                                                    |
| RRC transaction identifier           | Checked to see if it is absent                                                                                                                                                                                                                     |
| Integrity check info                 | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub IEs shall be absent. |
| —— Message authentication code       | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| —— RRC Message sequence number       | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| START List                           | Checked to see if the 'CN domain identity' and 'START' IEs are present for all CN domains supported by the UE                                                                                                                                      |
| —— CN domain identity                | Checked to see if it is one of the supported CN domains                                                                                                                                                                                            |
| —— START                             | Checked to see if it is present                                                                                                                                                                                                                    |
| AM_RLC error indication (RB2 or RB3) | Checked to see if it is set to 'FALSE'                                                                                                                                                                                                             |
| AM_RLC error indication (RB>3)       | Checked to see if it is set to 'FALSE'                                                                                                                                                                                                             |
| Cell update cause                    | See the test content                                                                                                                                                                                                                               |
| Failure cause                        | Checked to see if it is absent                                                                                                                                                                                                                     |
| RB timer indicator                   |                                                                                                                                                                                                                                                    |
| —— T314 expired                      | Checked to see if it is set to 'FALSE'                                                                                                                                                                                                             |
| —— T315 expired                      | Checked to see if it is set to 'FALSE'                                                                                                                                                                                                             |
| Measured results on RACH             | Not checked                                                                                                                                                                                                                                        |

## Contents of CELL UPDATE CONFIRM message: UM

| Information Element                                                | Value/remark                                                                                                                                                                                                                                                                                                     |
|--------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                                       |                                                                                                                                                                                                                                                                                                                  |
| U-RNTI                                                             | If this message is sent on CCCH, use the following values. Else, this IE is absent.                                                                                                                                                                                                                              |
| ——— SRNC identity                                                  | 0000-0000-0001B                                                                                                                                                                                                                                                                                                  |
| ——— S-RNTI                                                         | 0000-0000-0000-0000-0001B                                                                                                                                                                                                                                                                                        |
| RRC transaction identifier                                         | Selects an arbitrary integer between 0 to 3                                                                                                                                                                                                                                                                      |
| Integrity check info                                               | The presence of this IE is dependent on IXT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. SS calculates the value of MAC-I for this message and writes to this IE. |
| ——— message authentication code                                    |                                                                                                                                                                                                                                                                                                                  |
| ——— RRC message sequence number                                    | SS provides the value of this IE, from its internal counter.                                                                                                                                                                                                                                                     |
| Integrity protection mode info                                     | Not Present                                                                                                                                                                                                                                                                                                      |
| Ciphering mode info                                                | Not Present                                                                                                                                                                                                                                                                                                      |
| Activation time                                                    | Not Present — use default value                                                                                                                                                                                                                                                                                  |
| New U-RNTI                                                         | Not Present                                                                                                                                                                                                                                                                                                      |
| New C-RNTI                                                         | Not Present                                                                                                                                                                                                                                                                                                      |
| RRC State indicator                                                | CELL_FACH                                                                                                                                                                                                                                                                                                        |
| UTRAN-DRX cycle length coefficient                                 | Not Present                                                                                                                                                                                                                                                                                                      |
| RLC re-establish indicator (RB2 or RB3)                            | FALSE                                                                                                                                                                                                                                                                                                            |
| RLC re-establish indicator (RB>3)                                  | FALSE                                                                                                                                                                                                                                                                                                            |
| CN information info                                                | Not Present                                                                                                                                                                                                                                                                                                      |
| URA identity                                                       | 0000-0000-0001B                                                                                                                                                                                                                                                                                                  |
| RB information to release list                                     | Not Present                                                                                                                                                                                                                                                                                                      |
| RB information to reconfigure list                                 | Not Present                                                                                                                                                                                                                                                                                                      |
| RB information to be affected list                                 | Not Present                                                                                                                                                                                                                                                                                                      |
| Downlink counter synchronisation info                              | Not Present                                                                                                                                                                                                                                                                                                      |
| UL Transport channel information common for all transport channels | Not Present                                                                                                                                                                                                                                                                                                      |
| Deleted TrCH information list                                      | Not Present                                                                                                                                                                                                                                                                                                      |
| Added or Reconfigured TrCH information list                        | Not Present                                                                                                                                                                                                                                                                                                      |
| CHOICE mode                                                        | TDD                                                                                                                                                                                                                                                                                                              |
| DL Transport channel information common for all transport channels | Not Present                                                                                                                                                                                                                                                                                                      |
| Deleted TrCH information list                                      | Not Present                                                                                                                                                                                                                                                                                                      |
| Added or Reconfigured TrCH information list                        | Not Present                                                                                                                                                                                                                                                                                                      |
| Frequency info                                                     | Not Present                                                                                                                                                                                                                                                                                                      |
| Maximum allowed UL TX power                                        | Not Present                                                                                                                                                                                                                                                                                                      |
| CHOICE channel requirement                                         | Not Present                                                                                                                                                                                                                                                                                                      |
| CHOICE mode                                                        | TDD                                                                                                                                                                                                                                                                                                              |
| Downlink information common for all radio links                    | Not Present                                                                                                                                                                                                                                                                                                      |
| Downlink information per radio link list                           | Not Present                                                                                                                                                                                                                                                                                                      |

## Contents of MEASUREMENT CONTROL message: AM

| Information Element                                    | Value/remark                                                                                                                                                                                                                              |
|--------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                           | Arbitrarily selects an unused integer between 0 to 3                                                                                                                                                                                      |
| RRC transaction identifier                             | The presence of this IE is dependent on I-XIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| Integrity check info                                   | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                  |
| — Message authentication code                          | SS provides the value of this IE, from its internal counter.                                                                                                                                                                              |
| — RRC message sequence number                          | 1                                                                                                                                                                                                                                         |
| Measurement Identity                                   | Setup                                                                                                                                                                                                                                     |
| Measurement Command                                    |                                                                                                                                                                                                                                           |
| Measurement Reporting Mode                             |                                                                                                                                                                                                                                           |
| — Measurement Report Transfer Mode                     | Acknowledged mode RLC                                                                                                                                                                                                                     |
| — Measurement Reporting/Event Trigger Reporting Mode   | Periodical reporting                                                                                                                                                                                                                      |
| Additional measurement list                            | Not Present                                                                                                                                                                                                                               |
| CHOICE Measurement type                                | Intra-frequency measurement                                                                                                                                                                                                               |
| — Intra-frequency measurement                          |                                                                                                                                                                                                                                           |
| — Intra-frequency cell info                            |                                                                                                                                                                                                                                           |
| — New intra-frequency cell                             |                                                                                                                                                                                                                                           |
| — Intra-frequency cell-id                              | 0                                                                                                                                                                                                                                         |
| — Cell info                                            |                                                                                                                                                                                                                                           |
| — Cell individual offset                               | 0dB                                                                                                                                                                                                                                       |
| — Reference time difference to cell                    | Not Present                                                                                                                                                                                                                               |
| — Read SFN number                                      | FALSE                                                                                                                                                                                                                                     |
| — CHOICE mode                                          | TDD                                                                                                                                                                                                                                       |
| — Primary CCPCH info                                   |                                                                                                                                                                                                                                           |
| — CHOICE mode                                          | TDD                                                                                                                                                                                                                                       |
| — CHOICE TDD option                                    | 1.28 Mcps TDD                                                                                                                                                                                                                             |
| — TSTD indicator                                       | TRUE                                                                                                                                                                                                                                      |
| — Cell parameters ID                                   | 4                                                                                                                                                                                                                                         |
| — Block STTD indicator                                 | TRUE                                                                                                                                                                                                                                      |
| — Primary CCPCH TX power                               | Not Present                                                                                                                                                                                                                               |
| — Timeslot List                                        | Not Present                                                                                                                                                                                                                               |
| — Intra-frequency measurement quantity                 |                                                                                                                                                                                                                                           |
| — Filter coefficient                                   | 0                                                                                                                                                                                                                                         |
| — CHOICE mode                                          | TDD                                                                                                                                                                                                                                       |
| — Measurement quantity list                            |                                                                                                                                                                                                                                           |
| — Measurement quantity                                 | Primary CCPCH RSCP                                                                                                                                                                                                                        |
| — Intra-frequency reporting quantity                   |                                                                                                                                                                                                                                           |
| — Reporting quantities for active set cells            |                                                                                                                                                                                                                                           |
| — SFN-SFN observed time difference reporting indicator | No report                                                                                                                                                                                                                                 |
| — Cell synchronisation information reporting indicator | FALSE                                                                                                                                                                                                                                     |
| — Cell Identity reporting indicator                    | TRUE                                                                                                                                                                                                                                      |
| — CHOICE mode                                          | TDD                                                                                                                                                                                                                                       |
| — Timeslot ISCP reporting indicator                    | FALSE                                                                                                                                                                                                                                     |
| — Proposed TGSN Reporting required                     | FALSE                                                                                                                                                                                                                                     |
| — Primary CCPCH RSCP reporting indicator               | TRUE                                                                                                                                                                                                                                      |
| — Pathloss reporting indicator                         | FALSE                                                                                                                                                                                                                                     |
| — Reporting quantities for monitored cells             |                                                                                                                                                                                                                                           |
| — SFN-SFN observed time difference reporting indicator | No report                                                                                                                                                                                                                                 |
| — Cell synchronisation information reporting indicator | FALSE                                                                                                                                                                                                                                     |
| — Cell Identity reporting indicator                    | TRUE                                                                                                                                                                                                                                      |
| — CHOICE mode                                          | TDD                                                                                                                                                                                                                                       |
| — Timeslot ISCP reporting indicator                    | FALSE                                                                                                                                                                                                                                     |
| — Proposed TGSN Reporting required                     | FALSE                                                                                                                                                                                                                                     |
| — Primary CCPCH RSCP reporting indicator               | TRUE                                                                                                                                                                                                                                      |
| — Pathloss reporting indicator                         | FALSE                                                                                                                                                                                                                                     |
| — Reporting quantities for detected set cells          | Not Present                                                                                                                                                                                                                               |
| — Reporting cell status                                |                                                                                                                                                                                                                                           |
| — CHOICE reported cell                                 | Report cell within active set and/or monitored cells on                                                                                                                                                                                   |

|                                                                                                                                                                                                                               |                                                                                                                                                                                               |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>——→ Maximum number of reported cells</li> <li>——→ Measurement validity</li> <li>——→ CHOICE report criteria</li> <li>——→ Amount of reporting</li> <li>——→ Reporting interval</li> </ul> | <ul style="list-style-type: none"> <li>used frequency,</li> <li>2</li> <li>Not Present</li> <li>Periodic reporting criteria</li> <li>Infinity</li> <li>64 sec</li> <li>Not Present</li> </ul> |
| DPCCH Compressed mode status info                                                                                                                                                                                             | Not Present                                                                                                                                                                                   |

#### Contents of MEASUREMENT CONTROL FAILURE message: AM

| Information Element             | Value/remark                                                                                                                                                                                                                                       |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                    |                                                                                                                                                                                                                                                    |
| RRC transaction identifier      | Checked to see if it's set to the identical value for the same IE in the downlink MEASUREMENT CONTROL message                                                                                                                                      |
| Integrity check info            | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| ——→ Message authentication code | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| ——→ RRC Message sequence number | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Failure cause                   | See the test content                                                                                                                                                                                                                               |

#### Contents of MEASUREMENT REPORT message: AM

| Information Element                  | Value/remark                                                                                                                                                                                                                                       |
|--------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                         |                                                                                                                                                                                                                                                    |
| Integrity check info                 | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| ——→ Message authentication code      | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| ——→ RRC Message sequence number      | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Measurement identity                 | 1                                                                                                                                                                                                                                                  |
| Measured Results                     |                                                                                                                                                                                                                                                    |
| ——→ Intra-frequency measured results |                                                                                                                                                                                                                                                    |
| ——→ Cell measured results            |                                                                                                                                                                                                                                                    |
| ——→ Cell Identity                    | Not present                                                                                                                                                                                                                                        |
| ——→ SFN-SFN observed time difference | Checked that this IE is absent                                                                                                                                                                                                                     |
| ——→ Cell synchronisation information | Checked that this IE is absent                                                                                                                                                                                                                     |
| ——→ CHOICE mode                      | Checked that this is TDD                                                                                                                                                                                                                           |
| ——→ Cell parameters Id               | 4                                                                                                                                                                                                                                                  |
| ——→ Proposed TGSN                    | Checked that this IE is absent                                                                                                                                                                                                                     |
| ——→ Primary CCPCH RSCP               | Checked that this IE is present.                                                                                                                                                                                                                   |
| ——→ Pathloss                         | Checked that this IE is absent                                                                                                                                                                                                                     |
| ——→ Timeslot list                    | Checked that this IE is absent                                                                                                                                                                                                                     |
| Measured results on RACH             | Checked that this IE is absent                                                                                                                                                                                                                     |
| Additional measured results          | Checked that this IE is absent                                                                                                                                                                                                                     |
| Event results                        | Checked that this IE is absent                                                                                                                                                                                                                     |



## Contents of PAGING TYPE 1 message: TM (SMS in CS)

| Information Element            | Value/remark                                                        |
|--------------------------------|---------------------------------------------------------------------|
| Message Type                   |                                                                     |
| Paging record                  |                                                                     |
| —— CHOICE Used paging identity | CN identity                                                         |
| —— Paging cause                | Terminating Low Priority Signalling                                 |
| —— CN domain identity          | CS domain                                                           |
| —— CHOICE UE identity          |                                                                     |
| —— IMSI (GSM-MAP)              | Set to the same octet string as in the IMSI stored in the USIM card |
| BCCH modification info         | Not Present                                                         |

## Contents of PAGING TYPE 1 message: TM (SMS in PS)

| Information Element            | Value/remark                                                        |
|--------------------------------|---------------------------------------------------------------------|
| Message Type                   |                                                                     |
| Paging record                  |                                                                     |
| —— CHOICE Used paging identity | CN identity                                                         |
| —— Paging cause                | Terminating Low Priority Signalling                                 |
| —— CN domain identity          | PS domain                                                           |
| —— CHOICE UE identity          |                                                                     |
| —— IMSI (GSM-MAP)              | Set to the same octet string as in the IMSI stored in the USIM card |
| BCCH modification info         | Not Present                                                         |

## Contents of PAGING TYPE 2 message: AM (Speech in CS)

| Information Element            | Value/remark                                                                                                                                                                                                                             |
|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                   |                                                                                                                                                                                                                                          |
| RRC transaction identifier     | Arbitrarily selects an integer between 0 and 3                                                                                                                                                                                           |
| Integrity check info           | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| —— message authentication code | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                 |
| —— RRC message sequence number | SS provides the value of this IE, from its internal counter.                                                                                                                                                                             |
| Paging cause                   | Terminating Conversational Call                                                                                                                                                                                                          |
| CN domain identity             | CS domain                                                                                                                                                                                                                                |
| Paging record type identifier  | Select the same type as in the IE "Initial UE Identity" in RRC CONNECTION REQUEST message.                                                                                                                                               |

## Contents of PHYSICAL CHANNEL RECONFIGURATION message: AM or UM

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | Condition      | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier<br>Integrity check info<br><br>——— message authentication code<br><br>——— RRC message sequence number<br><br>Integrity protection mode info<br>Ciphering mode info<br>Activation time<br>New U-RNTI<br>New C-RNTI                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                | Arbitrarily selects an integer between 0 and 3<br>The presence of this IE is dependent on IXT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted.<br>SS calculates the value of MAC-I for this message and writes to this IE.<br>SS provides the value of this IE, from its internal counter.<br>Not Present<br>Not Present<br>$(256 + CFN - (CFN \bmod 8 + 8)) \bmod 256$<br>Not Present<br>Not Present                                                                                      |
| RRC State indicator                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | A1, A2, A3, A4 | CELL_DCH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| RRC State indicator                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | A5, A6         | CELL_FACH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| UTRAN-DRX cycle length coefficient<br>CN information info<br>URA identity<br>Downlink counter synchronisation info<br>Frequency info<br>——— CHOICE mode<br>——— UARFCN(Nt)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |                | Not Present<br>Not Present<br>Not Present<br>Not Present<br><br>TDD<br>Reference to TS34.108 clause 5.1 Parameter set.<br>30dBm                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Maximum allowed UL TX power                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| CHOICE channel requirement                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                | Uplink DPCH info                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Uplink DPCH info<br><br>——— CHOICE mode<br>——— Uplink DPCH power control info<br>——— UL Target SIR<br>——— CHOICE UL-OL-PC info<br>——— CHOICE TDD option<br>——— TPC step size<br>——— Primary CCPCH Tx Power<br>——— CHOICE mode<br>——— Uplink Timing Advance Control<br>——— UL CCTrCH List<br>——— TFCS ID<br>——— Time info<br>——— Activation time<br>——— Duration<br>——— Common timeslot info<br>——— 2 <sup>nd</sup> interleaving mode<br><br>——— TFCI coding<br><br>——— Puncturing Limit<br><br>——— Repetition Period<br><br>——— Repetition Length<br><br>——— Uplink DPCH timeslots and codes<br>——— First timeslot information<br>——— CHOICE TDD option<br>——— Timeslot number<br><br>——— TFCI existence<br>——— Midamble shift and burst type<br>——— CHOICE TDD option | A1, A2, A3, A4 | TDD<br><br>Reference to TS34.108<br>Individually signalled<br>1.28 Mcps-TDD<br>1 dB<br>Reference to TS34.108<br>TDD<br>Not Present<br><br>1<br><br>$(256 + CFN - (CFN \bmod 8 + 8)) \bmod 256$<br>infinite<br><br>Reference to TS34.108 clause 6 Parameter Set.<br>Reference to TS34.108 clause 6 Parameter Set.<br>Reference to TS34.108 clause 6 Parameter Set.<br>Reference to TS34.108 clause 6 Parameter Set.<br>Reference to TS34.108 clause 6 Parameter Set.<br>Reference to TS34.108 clause 6 Parameter Set.<br><br>1.28 Mcps<br>The number of an uplink timeslot that has unassigned codes.<br>TRUE<br><br>1.28 Mcps |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>----- Midamble Allocation Mode</li> <li>----- Midamble configuration</li> <li>----- CHOICE TDD option</li> <li>----- Modulation</li> <li>----- SS-TPC Symbols</li> <li>----- First timeslot code list</li> <li>----- Channelisation Code</li> <li>----- CHOICE more timeslots</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                | <p>Default<br/>16<br/>1.28 Mcps<br/>QPSK<br/>1<br/>Repeated (1,2) for each channelisation code assigned in the slot to meet the needs of TS34.108 clause 6 Parameter Set. (i/SF) where i denotes an unassigned code matching the SF specified in TS34.108 clause 6 Parameter Set.<br/>The presence of this IE depends on the number of resources specified in TS34.108 section 6 and the number of slots in which they are assigned.</p>                                                                                                                                                                    |
| CHOICE Mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |                | TDD                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <p>Downlink information common for all radio links</p> <ul style="list-style-type: none"> <li>----- Downlink DPCH info common for all RL</li> <li>----- Timing indicator</li> <li>----- CFN target SFN frame offset</li> <li>----- Downlink DPCH power control information</li> <li>----- CHOICE mode</li> <li>----- TPC Step Size</li> <li>----- CHOICE mode</li> <li>----- CHOICE TDD option</li> <li>----- TSTD indicator</li> <li>----- Default DPCH Offset Value</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | A1, A2, A3, A4 | <p>Maintain<br/>Not Present</p> <p>TDD<br/>1<br/>TDD<br/>1.28 Mcps<br/>TRUE<br/>Not Present</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <p>Downlink information for each radio links</p> <ul style="list-style-type: none"> <li>----- CHOICE mode</li> <li>----- Primary CCPCH info</li> <li>----- CHOICE mode</li> <li>----- CHOICE TDD option</li> <li>----- TSTD indicator</li> <li>----- Cell parameters ID</li> <li>----- Block STTD indicator</li> <li>----- Downlink DPCH info for each RL</li> <li>----- CHOICE mode</li> <li>----- DL CCTrCH List</li> <li>----- TFCS ID</li> <li>----- Activation time</li> <li>----- Duration</li> <li>----- Common timeslot info</li> <li>----- 2<sup>nd</sup> interleaving mode</li> <li>----- TFCI coding</li> <li>----- Puncturing limit</li> <li>----- Repetition period</li> <li>----- Repetition length</li> <li>----- Downlink DPCH timeslots and codes</li> <li>----- First Individual timeslot info</li> <li>----- Individual timeslot info</li> <li>----- Timeslot number</li> <li>----- TFCI existence</li> <li>----- Midamble shift and burst type</li> <li>----- CHOICE TDD option</li> <li>----- Midamble allocation mode</li> <li>----- Midamble configuration</li> <li>----- CHOICE TDD option</li> <li>----- Modulation</li> <li>----- SS-TPC Symbols</li> <li>----- First timeslot channelisation codes</li> <li>----- First channelisation code</li> <li>----- Last channelisation code</li> </ul> |                | <p>TDD<br/>TDD<br/>1.28 Mcps<br/>TRUE<br/>0<br/>FALSE</p> <p>TDD<br/>1<br/>(256+CFN-(CFN MOD 8 + 8))MOD 256<br/>Infinite</p> <p>Reference to TS34.108<br/>TRUE<br/>Reference to TS34.108 clause 6 Parameter Set<br/>1<br/>Empty</p> <p>The number of an downlink timeslot that has unassigned codes:<br/>TRUE</p> <p>1.28 Mcps<br/>Default<br/>16<br/>1.28 Mcps-TDD<br/>QPSK<br/>1</p> <p>(i/SF) where i is the lowest numbered code that is being assigned and SF is specified in TS34.108 clause 6 Parameter Set.<br/>(j/SF) where j is the highest numbered code that is being assigned in the slot.</p> |

|                                                                                                                                       |  |                                                                                                                                                                                                                                                            |
|---------------------------------------------------------------------------------------------------------------------------------------|--|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>——→ Bitmap</p> <p>——→ CHOICE more timeslots</p> <p>——→ Secondary CCPCH info</p> <p>——→ References to system information blocks</p> |  | <p>Bitmap of codes that are assigned in the slot. The presence of this IE depends upon whether the requirements of TS34.108 Parameter Set can be met by the codes that have been assigned in the first timeslot.</p> <p>Not Present</p> <p>Not Present</p> |
|---------------------------------------------------------------------------------------------------------------------------------------|--|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

| Condition | Explanation                                                 |
|-----------|-------------------------------------------------------------|
| A1        | This IE need for "Non-speech in CS"                         |
| A2        | This IE need for "Speech in CS"                             |
| A3        | This IE need for "Packet to CELL_DCH from CELL_DCH in PS"   |
| A4        | This IE need for "Packet to CELL_DCH from CELL_FACH in PS"  |
| A5        | This IE need for "Packet to CELL_FACH from CELL_DCH in PS"  |
| A6        | This IE need for "Packet to CELL_FACH from CELL_FACH in PS" |

#### Contents of PHYSICAL CHANNEL RECONFIGURATION COMPLETE message: AM

| Information Element                                | Value/remark                                                                                                                                                                                                                                       |
|----------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                       |                                                                                                                                                                                                                                                    |
| RRC-transaction-identifier                         | Checked to see if it's set to identical value of the same IE in the downlink PHYSICAL CHANNEL RECONFIGURATION message                                                                                                                              |
| Integrity-check-info                               | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub IEs shall be absent. |
| ——→ Message authentication code                    | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| ——→ RRC Message sequence number                    | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Uplink integrity protection activation info        | Not checked                                                                                                                                                                                                                                        |
| CHOICE mode                                        | TDD                                                                                                                                                                                                                                                |
| ——→ CHOICE TDD option                              | 1,28 Mcps                                                                                                                                                                                                                                          |
| COUNT-C activation time                            | The presence of this IE depends on the following 2 factors: (a) There exists RB(s) mapped to RLC-TM, (b) UE is transiting to CELL_DCH state after the reconfiguration procedure. Else, this IE is absent.                                          |
| Radio bearer uplink ciphering activation time info | Not checked                                                                                                                                                                                                                                        |
| Uplink counter synchronisation info                | Not checked                                                                                                                                                                                                                                        |

## Contents of RADIO BEARER SETUP message: AM or UM

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Condition      | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier<br>Integrity check info<br><br>——— message authentication code<br><br>——— RRC message sequence number<br><br>Integrity protection mode info<br>Ciphering mode info<br><br>——— Ciphering mode command<br>——— Ciphering algorithm<br>——— Ciphering activation time for DPCH<br>——— Radio bearer downlink ciphering activation time info<br>Activation time<br>New U-RNTI<br>New C-RNTI                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                | Arbitrarily selects an integer between 0 and 3<br>The presence of this IE is dependent on IXT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted.<br>SS calculates the value of MAC-I for this message and writes to this IE.<br>SS provides the value of this IE, from its internal counter.<br>Not Present<br>The presence of this IE is dependent on IXT statements in TS 34.123-2. If ciphering is indicated to be active, this IE present with the values of the sub-IEs as stated below. Else, this IE is omitted.<br>Start<br>Use one of the supported ciphering algorithms $(256 + CFN - (CFN \bmod 8 + 8)) \bmod 256$<br>Not Present<br><br>$(256 + CFN - (CFN \bmod 8 + 8)) \bmod 256$<br>Not Present<br>Not Present |
| RRC State indicator                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | A1, A2, A3, A4 | CELL_DCH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| RRC State indicator                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | A5, A6         | CELL_FACH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| UTRAN DRX cycle length coefficient                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| CN information info                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |                | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| URA identity                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Signalling RB information to setup                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| RAB information for setup<br>——— RAB info<br>——— RAB identity<br>——— CN domain identity<br>——— NAS Synchronization Indicator<br>——— Re-establishment timer<br>——— T314<br>——— RB information to setup<br>——— RB identity<br>——— PDCP info<br>——— CHOICE RLC info type<br>——— CHOICE Uplink RLC mode<br>——— Transmission RLC discard<br>——— Segmentation indication<br>——— CHOICE Downlink RLC mode<br>——— Segmentation indication<br>——— RB mapping info<br>——— Information for each multiplexing option<br>——— RLC logical channel mapping indicator<br>——— Number of uplink RLC logical channels<br>——— Uplink transport channel type<br>——— UL Transport channel identity<br>——— Logical channel identity<br>——— CHOICE RLC size list<br>——— MAC logical channel priority<br>——— Downlink RLC logical channel info<br>——— Number of downlink RLC logical channels<br>——— Downlink transport channel type<br>——— DL DCH Transport channel identity<br>——— Logical channel identity | A1             | 0000-0001B<br>CS domain<br>Not Present<br><br>20 seconds<br><br>10<br>Not Present<br>RLC info<br>TM RLC<br>Not Present<br>TRUE<br>TM RLC<br>TRUE<br><br>Not Present<br>1<br>DCH<br>1<br>7<br>All<br>1<br><br>1<br>DCH<br>6<br>7                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| RAB information for setup<br>——— RAB info                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | A2             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>——&gt; RAB identity</li> <li>——&gt; CN domain identity</li> <li>——&gt; NAS Synchronisation Indicator</li> <li>——&gt; Re-establishment timer</li> <li>——&gt; T314</li> <li>——&gt; RB information to setup</li> <li>——&gt; RB identity</li> <li>——&gt; PDCP info</li> <li>——&gt; CHOICE RLC info type</li> <li>——&gt; CHOICE Uplink RLC mode</li> <li>——&gt; Transmission RLC discard</li> <li>——&gt; Segmentation indication</li> <li>——&gt; CHOICE Downlink RLC mode</li> <li>——&gt; Segmentation indication</li> <li>——&gt; RB mapping info</li> <li>——&gt; Information for each multiplexing option</li> <li>——&gt; Number of RLC logical channels</li> <li>——&gt; Uplink transport channel type</li> <li>——&gt; UL Transport channel identity</li> <li>——&gt; Logical channel identity</li> <li>——&gt; CHOICE RLC size list</li> <li>——&gt; MAC logical channel priority</li> <li>——&gt; Downlink RLC logical channel info</li> <li>——&gt; Number of RLC logical channels</li> <li>——&gt; Downlink transport channel type</li> <li>——&gt; DL DCH Transport channel identity</li> <li>——&gt; Logical channel identity</li> <li>——&gt; RB information to setup</li> <li>——&gt; RB identity</li> <li>——&gt; PDCP info</li> <li>——&gt; CHOICE RLC info type</li> <li>——&gt; CHOICE Uplink RLC mode</li> <li>——&gt; Transmission RLC discard</li> <li>——&gt; Segmentation indication</li> <li>——&gt; CHOICE Downlink RLC mode</li> <li>——&gt; Segmentation indication</li> <li>——&gt; RB mapping info</li> <li>——&gt; Information for each multiplexing option</li> <li>——&gt; Number of RLC logical channels</li> <li>——&gt; Uplink transport channel type</li> <li>——&gt; UL Transport channel identity</li> <li>——&gt; Logical channel identity</li> <li>——&gt; CHOICE RLC size list</li> <li>——&gt; MAC logical channel priority</li> <li>——&gt; Downlink RLC logical channel info</li> <li>——&gt; Number of RLC logical channels</li> <li>——&gt; Downlink transport channel type</li> <li>——&gt; DL DCH Transport channel identity</li> <li>——&gt; Logical channel identity</li> <li>——&gt; RB information to setup</li> <li>——&gt; RB identity</li> <li>——&gt; PDCP info</li> <li>——&gt; CHOICE RLC info type</li> <li>——&gt; CHOICE Uplink RLC mode</li> <li>——&gt; Transmission RLC discard</li> <li>——&gt; Segmentation indication</li> <li>——&gt; CHOICE Downlink RLC mode</li> <li>——&gt; Segmentation indication</li> <li>——&gt; RB mapping info</li> <li>——&gt; Information for each multiplexing option</li> <li>——&gt; Number of RLC logical channels</li> <li>——&gt; Uplink transport channel type</li> <li>——&gt; UL Transport channel identity</li> <li>——&gt; Logical channel identity</li> <li>——&gt; CHOICE RLC size list</li> <li>——&gt; MAC logical channel priority</li> <li>——&gt; Downlink RLC logical channel info</li> </ul> | <ul style="list-style-type: none"> <li>0000 0001B</li> <li>CS domain</li> <li>Not Present</li> <li>20 seconds</li> <li>10</li> <li>Not Present</li> <li>RLC info</li> <li>TM RLC</li> <li>Not Present</li> <li>TRUE</li> <li>TM RLC</li> <li>TRUE</li> <li></li> <li>1</li> <li>DCH</li> <li>1</li> <li>7</li> <li>All</li> <li>1</li> <li></li> <li>1</li> <li>DCH</li> <li>6</li> <li>7</li> <li></li> <li>11</li> <li>Not Present</li> <li>RLC info</li> <li>TM RLC</li> <li>Not Present</li> <li>TRUE</li> <li>TM RLC</li> <li>TRUE</li> <li></li> <li>1</li> <li>DCH</li> <li>2</li> <li>8</li> <li>All</li> <li>1</li> <li></li> <li>1</li> <li>DCH</li> <li>7</li> <li>8</li> <li>(This IE is needed for 12.2 kbps and 10.2 kbps)</li> <li>12</li> <li>Not Present</li> <li>RLC info</li> <li>TM RLC</li> <li>Not Present</li> <li>TRUE</li> <li>TM RLC</li> <li>TRUE</li> <li></li> <li>1</li> <li>DCH</li> <li>3</li> <li>9</li> <li>All</li> <li>1</li> </ul> |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>——&gt; Number of RLC logical channels</li> <li>——&gt; Downlink transport channel type</li> <li>——&gt; DL DCH Transport channel identity</li> <li>——&gt; Logical channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |        | <ul style="list-style-type: none"> <li>1</li> <li>DCH</li> <li>8</li> <li>9</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| RAB information for setup <ul style="list-style-type: none"> <li>——&gt; RAB info</li> <li>——&gt; RAB identity</li> <li>——&gt; CN domain identity</li> <li>——&gt; NAS Synchronization Indicator</li> <li>——&gt; Re-establishment timer</li> <li>——&gt; T314</li> <li>——&gt; RB information to setup</li> <li>——&gt; RB identity</li> <li>——&gt; PDCP info</li> <li>——&gt; CHOICE RLC info type</li> <li>——&gt; CHOICE Uplink RLC mode</li> <li>——&gt; Transmission RLC discard</li> <li>——&gt; SDU discard mode</li> <li>——&gt; MAX_DAT</li> <li>——&gt; Timer_MRW</li> <li>——&gt; MaxMRW</li> <li>——&gt; Transmission window size</li> <li>——&gt; Timer_RST</li> <li>——&gt; Max_RST</li> <li>——&gt; Polling info</li> <li>——&gt; Timer_poll_prohibit</li> <li>——&gt; Timer_poll</li> <li>——&gt; Poll_SDU</li> <li>——&gt; Last transmission PDU poll</li> <li>——&gt; Last retransmission PDU poll</li> <li>——&gt; Poll_Windows</li> <li>——&gt; CHOICE Downlink RLC mode</li> <li>——&gt; In-sequence delivery</li> <li>——&gt; Receiving window size</li> <li>——&gt; Downlink RLC status info</li> <li>——&gt; Timer_status_prohibit</li> <li>——&gt; Timer_EPC</li> <li>——&gt; Missing PDU indicator</li> <li>——&gt; RB mapping info</li> <li>——&gt; Information for each multiplexing option</li> <li>——&gt; RLC logical channel mapping indicator</li> <li>——&gt; Number of uplink RLC logical channels</li> <li>——&gt; Uplink transport channel type</li> <li>——&gt; UL Transport channel identity</li> <li>——&gt; Logical channel identity</li> <li>——&gt; CHOICE RLC size list</li> <li>——&gt; MAC logical channel priority</li> <li>——&gt; Downlink RLC logical channel info</li> <li>——&gt; Number of downlink RLC logical channels</li> <li>——&gt; Downlink transport channel type</li> <li>——&gt; DL DCH Transport channel identity</li> <li>——&gt; Logical channel identity</li> </ul> | A3, A4 | <ul style="list-style-type: none"> <li>0000-0001B</li> <li>PS domain</li> <li>Not Present</li> <li>20 seconds</li> <li>20</li> <li>Not Present</li> <li>RLC info</li> <li>AM RLC</li> <li>Max-DAT retransmissions</li> <li>4</li> <li>100</li> <li>4</li> <li>8</li> <li>500</li> <li>4</li> <li>200</li> <li>200</li> <li>1</li> <li>TRUE</li> <li>TRUE</li> <li>99</li> <li>AM RLC</li> <li>TRUE</li> <li>8</li> <li>200</li> <li>200</li> <li>TRUE</li> <li>Not Present</li> <li>1</li> <li>DCH</li> <li>1</li> <li>7</li> <li>All</li> <li>1</li> <li>1</li> <li>DCH</li> <li>6</li> <li>7</li> </ul> |
| RAB information for setup <ul style="list-style-type: none"> <li>——&gt; RAB info</li> <li>——&gt; RAB identity</li> <li>——&gt; CN domain identity</li> <li>——&gt; NAS Synchronization Indicator</li> <li>——&gt; Re-establishment timer</li> <li>——&gt; T314</li> <li>——&gt; RB information to setup</li> <li>——&gt; RB identity</li> <li>——&gt; PDCP info</li> <li>——&gt; CHOICE RLC info type</li> <li>——&gt; CHOICE Uplink RLC mode</li> <li>——&gt; Transmission RLC discard</li> <li>——&gt; CHOICE SDU discard mode</li> <li>——&gt; MAX_DAT</li> <li>——&gt; Timer_MRW</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | A5, A6 | <ul style="list-style-type: none"> <li>(AM-DTCH for PS domain)</li> <li>0000-0001B</li> <li>PS domain</li> <li>Not Present</li> <li>20 seconds</li> <li>20</li> <li>Not Present</li> <li>RLC info</li> <li>AM RLC</li> <li>Max-DAT retransmissions</li> <li>4</li> <li>100</li> </ul>                                                                                                                                                                                                                                                                                                                     |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                   |                                                                                                                                                                                                                                                      |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>——&gt; MaxMRW</li> <li>——&gt; Transmission window size</li> <li>——&gt; Timer_RST</li> <li>——&gt; Max_RST</li> <li>——&gt; Polling info</li> <li>——&gt; Timer_poll_prohibit</li> <li>——&gt; Timer_poll</li> <li>——&gt; Poll_SDU</li> <li>——&gt; Last transmission PDU poll</li> <li>——&gt; Last retransmission PDU poll</li> <li>——&gt; Poll_Windows</li> <li>——&gt; CHOICE Downlink RLC mode</li> <li>——&gt; In-sequence delivery</li> <li>——&gt; Receiving window size</li> <li>——&gt; Downlink RLC status info</li> <li>——&gt; Timer_status_prohibit</li> <li>——&gt; Timer_EPC</li> <li>——&gt; Missing PDU indicator</li> <li>——&gt; RB mapping info</li> <li>——&gt; Information for each multiplexing option</li> <li>——&gt; RLC logical channel mapping indicator</li> <li>——&gt; Number of uplink RLC logical channels</li> <li>——&gt; Uplink transport channel type</li> <li>——&gt; Logical channel identity</li> <li>——&gt; CHOICE RLC size list</li> <li>——&gt; RLC size index</li> <li>——&gt; MAC logical channel priority</li> <li>——&gt; Downlink RLC logical channel info</li> <li>——&gt; Number of downlink RLC logical channels</li> <li>——&gt; Downlink transport channel type</li> <li>——&gt; Logical channel identity</li> </ul> |                   | 4<br>8<br>500<br>4<br><br>200<br>200<br>1<br>TRUE<br>TRUE<br>99<br>AM RLC<br>TRUE<br>8<br><br>200<br>200<br>TRUE<br><br><br>Not Present<br>1<br>RACH<br>7<br>Explicit<br>Reference to TS34.108 clause 6 Parameter Set<br>6<br><br>1<br>FACH/PCH<br>6 |
| RB information to be affected <ul style="list-style-type: none"> <li>——&gt; RB identity</li> <li>——&gt; RB mapping info</li> <li>——&gt; Information for each multiplexing option</li> <li>——&gt; RLC logical channel mapping indicator</li> <li>——&gt; Number of uplink RLC logical channels</li> <li>——&gt; Uplink transport channel type</li> <li>——&gt; UL Transport channel identity</li> <li>——&gt; Logical channel identity</li> <li>——&gt; CHOICE RLC size list</li> <li>——&gt; MAC logical channel priority</li> <li>——&gt; Downlink RLC logical channel info</li> <li>——&gt; Number of downlink RLC logical channels</li> <li>——&gt; Downlink transport channel type</li> <li>——&gt; DL DCH Transport channel identity</li> <li>——&gt; Logical channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | A1, A2,<br>A3, A4 | (UM-DCCH for RRC)<br><br>1<br><br>Not Present<br>1<br>DCH<br>5<br>1<br>All<br>1<br><br>1<br>DCH<br>10<br>1                                                                                                                                           |
| RB information to be affected <ul style="list-style-type: none"> <li>——&gt; RB identity</li> <li>——&gt; RB mapping info</li> <li>——&gt; Information for each multiplexing option</li> <li>——&gt; RLC logical channel mapping indicator</li> <li>——&gt; Number of uplink RLC logical channels</li> <li>——&gt; Uplink transport channel type</li> <li>——&gt; UL Transport channel identity</li> <li>——&gt; Logical channel identity</li> <li>——&gt; CHOICE RLC size list</li> <li>——&gt; MAC logical channel priority</li> <li>——&gt; Downlink RLC logical channel info</li> <li>——&gt; Number of downlink RLC logical channels</li> <li>——&gt; Downlink transport channel type</li> <li>——&gt; DL DCH Transport channel identity</li> <li>——&gt; Logical channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | A1, A2,<br>A3, A4 | (AM-DCCH for RRC)<br><br>2<br><br>Not Present<br>1<br>DCH<br>5<br>2<br>All<br>2<br><br>1<br>DCH<br>10<br>2                                                                                                                                           |
| RB information to be affected                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | A1, A2,<br>A3, A4 | (AM-DCCH for NAS_DT High-priority)                                                                                                                                                                                                                   |



|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |                   |                                                                                                                                                        |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>— RB identity</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— Logical channel identity</li> </ul>                               |                   | 3<br><br>Not Present<br>1<br>DCH<br>5<br>3<br>All<br>3<br><br>1<br>DCH<br>10<br>3                                                                      |
| RB information to be affected <ul style="list-style-type: none"> <li>— RB identity</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— Logical channel identity</li> </ul> | A1, A2,<br>A3, A4 | (AM-DCCH for NAS_DT Low priority)<br><br>4<br><br>Not Present<br>1<br>DCH<br>5<br>4<br>All<br>4<br><br>1<br>DCH<br>10<br>4                             |
| RB information to be affected <ul style="list-style-type: none"> <li>— RB identity</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— RLC size index</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— Logical channel identity</li> </ul>                                                             | A5, A6            | (UM-DCCH for RRC)<br>1<br><br>Not Present<br>1<br>RACH<br>1<br>Explicit<br>Reference to TS34.108 clause 6 Parameter Set<br>2<br><br>1<br>FACH/PCH<br>1 |
| RB information to be affected <ul style="list-style-type: none"> <li>— RB identity</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— RLC size index</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— Logical channel identity</li> </ul>                                                             | A5, A6            | (AM-DCCH for RRC)<br>2<br><br>Not Present<br>1<br>RACH<br>2<br>Explicit<br>Reference to TS34.108 clause 6 Parameter Set<br>3<br><br>1<br>FACH/PCH<br>2 |
| RB information to be affected <ul style="list-style-type: none"> <li>— RB identity</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | A5, A6            | (AM-DCCH for NAS_DT High priority)<br>3                                                                                                                |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                |                                                                                                                                                                                                                                                                       |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>——&gt; RLC logical channel mapping indicator</li> <li>——&gt; Number of uplink RLC logical channels</li> <li>——&gt; Uplink transport channel type</li> <li>——&gt; Logical channel identity</li> <li>——&gt; CHOICE RLC size list</li> <li>——&gt; RLC size index</li> <li>——&gt; MAC logical channel priority</li> <li>——&gt; Downlink RLC logical channel info</li> <li>——&gt; Number of downlink RLC logical channels</li> <li>——&gt; Downlink transport channel type</li> <li>——&gt; Logical channel identity</li> </ul>                                                                                                                                                           |                | <p>Not Present</p> <p>1</p> <p>RACH</p> <p>3</p> <p>Explicit</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>4</p> <p>1</p> <p>FACH/PCH</p> <p>3</p>                                                                                                       |
| <p>RB information to be affected</p> <ul style="list-style-type: none"> <li>——&gt; RB identity</li> <li>——&gt; RB mapping info</li> <li>——&gt; Information for each multiplexing option</li> <li>——&gt; RLC logical channel mapping indicator</li> <li>——&gt; Number of uplink RLC logical channels</li> <li>——&gt; Uplink transport channel type</li> <li>——&gt; Logical channel identity</li> <li>——&gt; CHOICE RLC size list</li> <li>——&gt; RLC size index</li> <li>——&gt; MAC logical channel priority</li> <li>——&gt; Downlink RLC logical channel info</li> <li>——&gt; Number of downlink RLC logical channels</li> <li>——&gt; Downlink transport channel type</li> <li>——&gt; Logical channel identity</li> </ul> | A5, A6         | <p>(AM-DCCH for NAS_DT Low priority)</p> <p>4</p> <p>Not Present</p> <p>1</p> <p>RACH</p> <p>4</p> <p>Explicit</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>5</p> <p>1</p> <p>FACH/PCH</p> <p>4</p>                                                     |
| <p>RB information to be affected</p> <ul style="list-style-type: none"> <li>——&gt; RB identity</li> <li>——&gt; RB mapping info</li> <li>——&gt; Information for each multiplexing option</li> <li>——&gt; Number of downlink RLC logical channels</li> <li>——&gt; Downlink transport channel type</li> <li>——&gt; Logical channel identity</li> <li>——&gt; Downlink RLC logical channel info</li> </ul>                                                                                                                                                                                                                                                                                                                     | A5, A6         | <p>(TM-BGCH for RRC)</p> <p>6</p> <p>1</p> <p>FACH/PCH</p> <p>5</p> <p>Not Present</p>                                                                                                                                                                                |
| <p>RB information to be affected</p> <ul style="list-style-type: none"> <li>——&gt; RB identity</li> <li>——&gt; RB mapping info</li> <li>——&gt; Information for each multiplexing option</li> <li>——&gt; Number of downlink RLC logical channels</li> <li>——&gt; Downlink transport channel type</li> <li>——&gt; Logical channel identity</li> <li>——&gt; Downlink RLC logical channel info</li> </ul>                                                                                                                                                                                                                                                                                                                     | A5 or A6       | <p>(TM-PCCH for RRC)</p> <p>7</p> <p>1</p> <p>FACH/PCH</p> <p>1</p> <p>Not Present</p>                                                                                                                                                                                |
| <p>Downlink counter synchronisation info</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |                | Not Present                                                                                                                                                                                                                                                           |
| <p>UL Transport channel information for all transport channels</p> <ul style="list-style-type: none"> <li>——&gt; PRACH TFCS</li> <li>——&gt; CHOICE mode</li> <li>——&gt; Individual UL CCTrCH information</li> <li>——&gt; TFCS-ID</li> <li>——&gt; Shared Channel Indicator</li> <li>——&gt; UL TFCS</li> <li>——&gt; CHOICE TFCI signalling</li> <li>——&gt; TFCI Field 1 information</li> <li>——&gt; CHOICE TFCS representation</li> <li>——&gt; TFCS complete reconfigure information</li> <li>——&gt; CHOICE CTFC Size</li> <li>——&gt; CTFC information</li> <li>——&gt; TFC subset</li> <li>——&gt; CHOICE Subset representation</li> <li>——&gt; Allowed Transport Format combination list</li> </ul>                         | A1, A2, A3, A4 | <p>Not Present</p> <p>TDD</p> <p>1</p> <p>FALSE</p> <p>Normal</p> <p>Complete</p> <p>Refer to TS34.108 clause 6.</p> <p>Refer to TS34.108 clause 6 Parameter Set</p> <p>Allowed transport format combination list</p> <p>Refer to TS34.108 clause 6 Parameter Set</p> |
| <p>UL Transport channel information for all transport channels</p> <ul style="list-style-type: none"> <li>——&gt; TFC subset</li> <li>——&gt; Allowed Transport Format combination</li> <li>——&gt; PRACH TFCS</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | A5, A6         | <p>(This IE is repeated for TFC number.)</p> <p>0 to MaxTFCvalue-1 (MaxTFCvalue is refer to TS34.108 clause 6 Parameter Set.)</p> <p>(This IE is repeated for TFC number.)</p>                                                                                        |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>———— CHOICE TFCI signalling</li> <li>———— TFCI Field 1 information</li> <li>———— CHOICE TFCS representation</li> <li>———— TFCS complete reconfigure information</li> <li>———— CHOICE TFCS Size</li> <li>———— CTFC information</li> <li>———— CHOICE mode</li> <li>———— Individual UL CCTrCH information</li> </ul>                                                                                                                                                                                                                                                                                                                                                                   |                | <p>Normal</p> <p>Number of used bits must be enough to cover all combinations of CTFC from clauses 6. Refer to TS34.108 clause 6 Parameter Set</p> <p>Not Present</p> <p>TDD</p> <p>Not Present</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <p>Deleted UL TrCH information</p> <ul style="list-style-type: none"> <li>———— Uplink transport channel type</li> <li>———— Transport channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | A4             | <p>DCH</p> <p>15</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <p>Deleted UL TrCH information</p> <ul style="list-style-type: none"> <li>———— Uplink transport channel type</li> <li>———— UL Transport channel identity</li> <li>———— Uplink transport channel type</li> <li>———— UL Transport channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                | A5             | <p>DCH</p> <p>1</p> <p>DCH</p> <p>5</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <p>Added or Reconfigured UL TrCH information</p> <ul style="list-style-type: none"> <li>———— Uplink transport channel type</li> <li>———— UL Transport channel identity</li> <li>———— TFS</li> <li>———— CHOICE Transport channel type</li> <li>———— Dynamic Transport format information</li> <li>———— RLC Size</li> <li>———— Number of TBs and TTI List</li> <li>———— Transmission Time Interval</li> <li>———— Number of Transport blocks</li> <li>———— CHOICE Logical Channel list</li> <li>———— Semi-static Transport Format information</li> <li>———— Transmission time interval</li> <li>———— Type of channel coding</li> <li>———— Coding Rate</li> <li>———— Rate matching attribute</li> <li>———— CRC size</li> </ul> | A1, A2, A3, A4 | <p>DCH</p> <p>1</p> <p>Dedicated transport channels (This IE is repeated for TFI number) Reference to TS34.108 clause 6 Parameter Set</p> <p>(This IE is repeated for TFI number.) Not Present Reference to TS34.108 clause 6 Parameter Set</p> <p>ALL</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p>                                                                                                             |
| <p>Added or Reconfigured UL TrCH information</p> <ul style="list-style-type: none"> <li>———— Uplink transport channel type</li> <li>———— UL Transport channel identity</li> <li>———— TFS</li> <li>———— CHOICE Transport channel type</li> <li>———— Dynamic Transport format information</li> <li>———— RLC Size</li> <li>———— Number of TBs and TTI List</li> <li>———— Transmission Time Interval</li> <li>———— Number of Transport blocks</li> <li>———— CHOICE Logical Channel list</li> <li>———— Semi-static Transport Format information</li> <li>———— Transmission time interval</li> <li>———— Type of channel coding</li> <li>———— Coding Rate</li> <li>———— Rate matching attribute</li> <li>———— CRC size</li> </ul> | A1, A2, A3, A4 | <p>If TrCH reconfiguration is executed then this is needed (e.g. The rate of SRB for DCCH is changed.):</p> <p>DCH</p> <p>5</p> <p>Dedicated transport channels (This IE is repeated for TFI number) Reference to TS34.108 clause 6 Parameter Set</p> <p>(This IE is repeated for TFI number.) Not Present Reference to TS34.108 clause 6 Parameter Set</p> <p>ALL</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |             | Set                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Added or Reconfigured UL TrCH information<br>— Uplink transport channel type<br>— UL Transport channel identity<br>— TFS<br>— CHOICE Transport channel type<br>— Dynamic Transport format information<br>— RLC size<br>— Number of TBs and TTI List<br>— Transmission Time Interval<br>— Number of transport blocks<br>— CHOICE Logical Channel List<br>— Semi-static Transport Format information<br>— Transmission time interval<br>— Type of channel coding<br>— Coding Rate<br>— Rate matching attribute<br>— CRC size | A2          | DCH<br>2<br><br>Dedicated transport channels<br>(This IE is repeated for TFI number)<br>Reference to clause 6 Parameter Set<br>Reference to clause 6 Parameter Set<br>Not Present<br>Reference to clause 6 Parameter Set<br>All<br><br>Reference to clause 6 Parameter Set<br>Reference to clause 6 Parameter Set<br>Reference to clause 6 Parameter Set<br>Reference to clause 6 Parameter Set<br>Reference to clause 6 Parameter Set                                                    |
| Added or Reconfigured UL TrCH information<br>— Uplink transport channel type<br>— UL Transport channel identity<br>— TFS<br>— CHOICE Transport channel type<br>— Dynamic Transport format information<br>— RLC size<br>— Number of TBs and TTI List<br>— Transmission Time Interval<br>— Number of transport blocks<br>— CHOICE Logical Channel List<br>— Semi-static Transport Format information<br>— Transmission time interval<br>— Type of channel coding<br>— Coding Rate<br>— Rate matching attribute<br>— CRC size | A2          | (This IE is needed for 12.2 kbps and 10.2 kbps)<br>DCH<br>3<br>(This IE is repeated for TFI number)<br>Dedicated transport channels<br><br>Reference to clause 6 Parameter Set<br>Reference to clause 6 Parameter Set<br>Not Present<br>Reference to clause 6 Parameter Set<br>All<br><br>Reference to clause 6 Parameter Set<br>Reference to clause 6 Parameter Set<br>Reference to clause 6 Parameter Set<br>Reference to clause 6 Parameter Set<br>Reference to clause 6 Parameter Set |
| DL Transport channel information common for all transport channel<br>— SCCPCH TFCS<br>— CHOICE mode<br>— Individual DL CCTrCH information<br>— DL TFCS Identity<br>— TFCS Id<br>— Shared Channel Indicator<br>— CHOICE DL parameters<br>— DL DCH TFCS<br>— CHOICE TFCI signalling<br>— TFCI Field 1 information<br>— CHOICE TFCS representation<br>— TFCS complete reconfigure information<br>— CHOICE CTFC Size<br>— CTFC information                                                                                     | A1,A2,A3,A4 | Not Present<br>TDD<br><br>1<br>FALSE<br>Independent<br>(This IE is repeated for TFC number.)<br>Normal<br><br>Complete<br><br>Refer to TS34.108 clause 6.<br>Refer to TS34.108 clause 6.                                                                                                                                                                                                                                                                                                  |
| DL Transport channel information common for all transport channel<br>— SCCPCH TFCS<br>— CHOICE TFCI signalling<br>— TFCI Field 1 information<br>— CHOICE TFCS representation<br>— TFCS addition information<br>— CHOICE CTFC Size<br><br>— CTFC information<br>— Power offset information<br>— CHOICE mode<br>— Individual DL CCTrCH information                                                                                                                                                                           | A5, A6      | (This IE is repeated for TFC number.)<br>Normal<br><br>Addition<br><br>Number of bits used must be enough to cover all combinations of CTFC from clause 6.<br>Refer to TS34.108 clause 6 Parameter Set<br>Not Present<br>TDD<br>Not Present                                                                                                                                                                                                                                               |
| Deleted DL TrCH information<br>— Downlink transport channel type<br>— Transport channel identity                                                                                                                                                                                                                                                                                                                                                                                                                           | A4          | DCH<br>12                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>——&gt; Downlink transport channel type</li> <li>——&gt; Transport channel identity</li> <li>——&gt; Downlink transport channel type</li> <li>——&gt; Transport channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                | DCH<br>13<br>DCH<br>14                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Deleted DL TrCH information <ul style="list-style-type: none"> <li>——&gt; Downlink transport channel type</li> <li>——&gt; DL Transport channel identity</li> <li>——&gt; Downlink transport channel type</li> <li>——&gt; Transport channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | A5             | DCH<br>6<br>DCH<br>10                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Added or Reconfigured DL TrCH information <ul style="list-style-type: none"> <li>——&gt; Downlink transport channel type</li> <li>——&gt; DL Transport channel identity</li> <li>——&gt; CHOICE DL parameters</li> <li>——&gt; Uplink transport channel type</li> <li>——&gt; UL TrCH identity</li> <li>——&gt; DCH quality target</li> <li>——&gt; BLER Quality value</li> <li>——&gt; Transparent mode signalling info</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | A1,A2          | DCH<br>6<br>Same as UL<br>DCH<br>1<br><br>-6.3<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Added or Reconfigured DL TrCH information <ul style="list-style-type: none"> <li>——&gt; Downlink transport channel type</li> <li>——&gt; DL Transport channel identity</li> <li>——&gt; CHOICE DL parameters</li> <li>——&gt; TFS</li> <li>——&gt; CHOICE Transport channel type</li> <li>——&gt; Dynamic Transport format information</li> <li>——&gt; RLC Size</li> <li>——&gt; Number of TBs and TTI List</li> <li>——&gt; Transmission Time Interval</li> <li>——&gt; Number of Transport blocks</li> <li>——&gt; CHOICE Logical Channel list</li> <li>——&gt; Semi-static Transport Format information</li> <li>——&gt; Transmission time interval</li> <li>——&gt; Type of channel coding</li> <li>——&gt; Coding Rate</li> <li>——&gt; Rate matching attribute</li> <li>——&gt; CRC size</li> <li>——&gt; DCH quality target</li> <li>——&gt; BLER Quality value</li> <li>——&gt; Transparent mode signalling info</li> </ul> | A1, A2, A3, A4 | If TrCH reconfiguration is executed then this is needed(e.g. The rate of SRB for DCCH is changed.):<br>DCH<br>10<br>Explicit<br><br>Dedicated transport channels<br>(This IE is repeated for TFI number)<br>Reference to TS34.108 clause 6 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6 Parameter Set<br>ALL<br><br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br><br>-6.3<br>Not Present |
| Added or Reconfigured DL TrCH information <ul style="list-style-type: none"> <li>——&gt; Downlink transport channel type</li> <li>——&gt; Transport channel identity</li> <li>——&gt; CHOICE DL parameters</li> <li>——&gt; Uplink transport channel type</li> <li>——&gt; UL TrCH identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | A2             | DCH<br>7<br>SameAsUL<br>DCH<br>2                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Added or Reconfigured DL TrCH information <ul style="list-style-type: none"> <li>——&gt; Downlink transport channel type</li> <li>——&gt; Transport channel identity</li> <li>——&gt; CHOICE DL parameters</li> <li>——&gt; Uplink transport channel type</li> <li>——&gt; UL TrCH identity</li> <li>——&gt; DCH quality target</li> <li>——&gt; BLER Quality value</li> <li>——&gt; Transparent mode signalling info</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | A2             | (This IE is needed for 12.2 kbps and 10.2 kbps)<br>DCH<br>8<br>SameAsUL<br>DCH<br>3<br><br>-6.3<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Added or Reconfigured DL TrCH information <ul style="list-style-type: none"> <li>——&gt; Downlink transport channel type</li> <li>——&gt; DL Transport channel identity</li> <li>——&gt; CHOICE DL parameters</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | A3, A4         | DCH<br>6<br>Explicit                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>——&gt; TFS</li> <li>——&gt; CHOICE Transport channel type</li> <li>——&gt; Dynamic Transport format information</li> <li>——&gt; RLC Size</li> <li>——&gt; Number of TBs and TTI List</li> <li>——&gt; Transmission Time Interval</li> <li>——&gt; Number of Transport blocks</li> <li>——&gt; CHOICE Logical Channel list</li> <li>——&gt; Semi-static Transport Format information</li> <li>——&gt; Transmission time interval</li> <li>——&gt; Type of channel coding</li> <li>——&gt; Coding Rate</li> <li>——&gt; Rate matching attribute</li> <li>——&gt; CRC size</li> <li>——&gt; DCH quality target</li> <li>——&gt; BLER Quality value</li> <li>——&gt; Transparent mode signalling info</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |            | <p>Dedicated transport channels<br/>(This IE is repeated for TFI number)<br/>Reference to TS34.108 clause 6 Parameter Set</p> <p>(This IE is repeated for TFI number.)<br/>Not Present<br/>Reference to TS34.108 clause 6 Parameter Set</p> <p>ALL</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>-6.3<br/>Not Present</p>                                                                                              |
| <p>Frequency info</p> <ul style="list-style-type: none"> <li>——&gt; CHOICE mode</li> <li>——&gt; UARFCN (Nt)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |            | <p>TDD<br/>Reference to TS34.108 clause 6 Parameter Set</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <p>Maximum allowed UL TX power</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |            | 30dBm                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <ul style="list-style-type: none"> <li>——&gt; CHOICE channel requirement</li> <li>——&gt; Uplink DPCH power control info</li> <li>——&gt; CHOICE mode</li> <li>——&gt; UL Target SIR</li> <li>——&gt; CHOICE UL OL PC info</li> <li>——&gt; CHOICE TDD option</li> <li>——&gt; TPC step size</li> <li>——&gt; Primary CCPCH Tx Power</li> <li>——&gt; CHOICE mode</li> <li>——&gt; Uplink Timing Advance Control</li> <li>——&gt; UL CCTrCH List</li> <li>——&gt; TFCS Id</li> <li>——&gt; Time info</li> <li>——&gt; Activation time</li> <li>——&gt; Duration</li> <li>——&gt; Common timeslot info</li> <li>——&gt; 2<sup>nd</sup> interleaving mode</li> <li>——&gt; TFCI coding</li> <li>——&gt; Puncturing Limit</li> <li>——&gt; Repetition Period</li> <li>——&gt; Repetition Length</li> <li>——&gt; Uplink DPCH timeslots and code</li> <li>——&gt; First individual timeslot info</li> <li>——&gt; Timeslot number</li> <li>——&gt; TFCI existence</li> <li>——&gt; Midamble shift and burst type</li> <li>——&gt; CHOICE TDD option</li> <li>——&gt; Midamble allocation mode</li> <li>——&gt; Midamble configuration</li> <li>——&gt; CHOICE TDD option</li> <li>——&gt; Modulation</li> <li>——&gt; SS-TPC Symbols</li> <li>——&gt; First timeslot channelisation codes</li> </ul> | A1, A3, A4 | <p>Uplink DPCH info</p> <p>TDD<br/>Reference to TS34.108 Parameter set.<br/>Individually signalled</p> <p>1.28 Mcps<br/>1 dB<br/>Not Present</p> <p>TDD<br/>Not Present</p> <p>1</p> <p>(256+CFN-(CFN MOD 8 + 8))MOD 256<br/>infinite</p> <p>Reference to TS34.108 clause 6 Parameter Set.<br/>Reference to TS34.108 clause 6 Parameter set.<br/>Reference to TS34.108 clause 6 Parameter set.<br/>Reference to TS34.108 clause 6 Parameter set.<br/>Reference to TS34.108 clause 6 Parameter set.</p> <p>The number of an uplink timeslot that has unassigned codes.<br/>TRUE</p> <p>1.28 Mcps<br/>Default<br/>16<br/>1.28 Mcps-TDD<br/>QPSK<br/>1<br/>Repeated (1,2) for each channelisation code</p> |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>————— - Channelisation code</p> <p>————— - CHOICE more timeslots</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |                | <p>assigned in the slot to meet the needs of TS34.108 clause 6 Parameter Set- (<math>i/SF</math>) where <math>i</math> denotes an unassigned code matching the SF specified in TS34.108 clause 6 Parameter Set.</p> <p>The presence of this IE depends upon the number of resources specified in TS34.108 section 6 and the number of slots in which they are being assigned.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <p>-CHOICE channel requirement</p> <p>————— - Uplink DPCH power control info</p> <p>————— - CHOICE mode</p> <p>————— - UL Target SIR</p> <p>————— - CHOICE UL OL PC info</p> <p>————— - CHOICE TDD option</p> <p>————— - TPC step size</p> <p>————— - Primary CCPCH Tx Power</p> <p>————— - CHOICE mode</p> <p>————— - Uplink Timing Advance Control</p> <p>————— - UL CCTrCH List</p> <p>————— - TFCS Id</p> <p>————— - Time info</p> <p>————— - Activation time</p> <p>————— - Duration</p> <p>————— - Common timeslot info</p> <p>————— - 2<sup>nd</sup> interleaving mode</p> <p>————— - TFCI coding</p> <p>————— - Puncturing Limit</p> <p>————— - Repetition Period</p> <p>————— - Repetition Length</p> <p>————— - Uplink DPCH timeslots and code</p> <p>————— - First individual timeslot info</p> <p>————— - Timeslot number</p> <p>————— - TFCI existence</p> <p>————— - Midamble shift and burst type</p> <p>————— - CHOICE TDD option</p> <p>————— - Midamble allocation mode</p> <p>————— - Midamble configuration</p> <p>————— - CHOICE TDD option</p> <p>————— - Modulation</p> <p>————— - SS-TPC Symbols</p> <p>————— - First timeslot channelisation codes</p> <p>————— - Channelisation code</p> <p>————— - CHOICE more timeslots</p> | A2             | <p>Uplink DPCH info</p> <p>TDD</p> <p>Reference to TS34.108 Parameter set: Individually signalled</p> <p>1.28 Mcps</p> <p>1 dB</p> <p>Not Present</p> <p>TDD</p> <p>Not Present</p> <p>1</p> <p><math>(256 + CFN - (CFN \text{ MOD } 8 + 8)) \text{ MOD } 256</math></p> <p>infinite</p> <p>Reference to TS34.108 section 6 Parameter set.</p> <p>Reference to TS34.108 section 6 Parameter set.</p> <p>Reference to TS34.108 section 6 Parameter set.</p> <p>Reference to TS34.108 clause 6 Parameter set.</p> <p>Reference to TS34.108 clause 6 Parameter set.</p> <p>The number of an uplink timeslot that has unassigned codes.</p> <p>TRUE</p> <p>1.28 Mcps</p> <p>Default</p> <p>16</p> <p>1.28 Mcps TDD</p> <p>QPSK</p> <p>1</p> <p>Repeated (1,2) for each channelisation code assigned in the slot to meet the needs of TS34.108 clause 6 Parameter Set- (<math>i/SF</math>) where <math>i</math> denotes an unassigned code matching the SF specified in TS34.108 clause 6 Parameter Set.</p> <p>The presence of this IE depends upon the number of resources specified in TS34.108 section 6 and the number of slots in which they are being assigned.</p> |
| CHOICE Mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                | TDD                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <p>Downlink information common for all radio links</p> <p>————— - Downlink DPCH info common for all RL</p> <p>————— - Timing indicator</p> <p>————— - CFN-targetSFN frame offset</p> <p>————— - Downlink DPCH power control information</p> <p>————— - CHOICE mode</p> <p>————— - TPC step size</p> <p>————— - CHOICE mode</p> <p>————— - CHOICE TDD option</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | A1, A2, A3, A4 | <p>Maintain</p> <p>Not Present</p> <p>TDD</p> <p>1 dB</p> <p>TDD</p> <p>1.28 Mcps</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>——— TSTD indicator</li> <li>——— Default DPCH offset value</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |                       | <p>TRUE</p> <p>0</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <p>Downlink information for each radio link list</p> <ul style="list-style-type: none"> <li>——— Downlink information for each radio link</li> <li>——— CHOICE mode</li> <li>——— Primary CCPCH info</li> <li>——— CHOICE mode</li> <li>——— CHOICE TDD option</li> <li>——— TSTD indicator</li> <li>——— Cell parameters ID</li> <li>——— Block STTD indicator</li> <li>——— Downlink DPCH info for each RL</li> <li>——— CHOICE mode</li> <li>——— DL CCTrCH List</li> <li>——— TFCs ID</li> <li>——— Time info</li> <li>——— Activation time</li> <li>——— Duration</li> <li>——— Common timeslot info</li> <li>——— 2<sup>nd</sup> interleaving mode</li> <li>——— TFCI coding</li> <li>——— Puncturing limit</li> <li>——— Repetition period</li> <li>——— Repetition length</li> <li>——— Downlink DPCH timeslots and codes</li> <li>——— Individual timeslot info</li> <li>——— Timeslot number</li> <li>——— TFCI existence</li> <li>——— Midamble shift and burst type</li> <li>——— CHOICE TDD option</li> <li>——— Midamble allocation mode</li> <li>——— Midamble configuration</li> <li>——— CHOICE TDD option</li> <li>——— Modulation</li> <li>——— SS-TPC Symbols</li> <li>——— First timeslot channelisation codes</li> <li>——— First channelisation code</li> <li>——— Last channelisation code</li> <li>——— Bitmap</li> <li>——— CHOICE more timeslots</li> <li>——— UL CCTrCH TPC List</li> <li>——— SCCPCH information for FACH</li> </ul> | <p>A1, A2, A3, A4</p> | <p>TDD</p> <p>TDD</p> <p>1.28 Mcps</p> <p>TRUE</p> <p>0</p> <p>FALSE</p> <p>TDD</p> <p>1</p> <p><math>(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256</math></p> <p>infinite</p> <p>Reference to TS34.108</p> <p>TRUE</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>1</p> <p>Empty</p> <p>The number of a downlink timeslot that has unassigned codes.</p> <p>TRUE</p> <p>1.28 Mcps</p> <p>Default</p> <p>16</p> <p>1.28 Mcps-TDD</p> <p>QPSK</p> <p>1</p> <p><math>(i/\text{SF})</math> where i is the lowest numbered code that is being assigned and SF is specified in TS34.108 clause 6 Parameter Set..</p> <p><math>(j/\text{SF})</math> where j is the highest numbered code that is being assigned in the slot.</p> <p>Bitmap of the codes that are being assigned in the slot.</p> <p>The presence of this IE depends upon whether the requirements of TS34.108 clause 6 Parameter Set could be met by the codes that have been assigned in the first timeslot..</p> <p>Not Present</p> <p>Not Present</p> |
| <p>Downlink information for each radio link list</p> <ul style="list-style-type: none"> <li>——— Downlink information for each radio link</li> <li>——— Choice mode</li> <li>——— Primary CCPCH info</li> <li>——— CHOICE mode</li> <li>——— CHOICE TDD option</li> <li>——— TSTD indicator</li> <li>——— Cell parameters ID</li> <li>——— Block STTD indicator</li> <li>——— Downlink DPCH info for each RL</li> <li>——— SCCPCH information for FACH</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | <p>A5, A6</p>         | <p>TDD</p> <p>TDD</p> <p>1.28 Mcps</p> <p>TRUE</p> <p>0</p> <p>TRUE</p> <p>Not Present</p> <p>Not Present</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |



| Condition | Explanation                                                 |
|-----------|-------------------------------------------------------------|
| A1        | This IE need for "Non-speech in CS"                         |
| A2        | This IE need for "Speech in CS"                             |
| A3        | This IE need for "Packet to CELL_DCH from CELL_DCH in PS"   |
| A4        | This IE need for "Packet to CELL_DCH from CELL_FACH in PS"  |
| A5        | This IE need for "Packet to CELL_FACH from CELL_DCH in PS"  |
| A6        | This IE need for "Packet to CELL_FACH from CELL_FACH in PS" |

## Contents of RADIO BEARER RECONFIGURATION message: AM or UM

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | Condition      | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier<br>Integrity check info<br><br>——— message authentication code<br><br>——— RRC message sequence number<br><br>Integrity protection mode info<br>Ciphering mode info<br>Activation time<br>New U-RNTI<br>New C-RNTI                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                | Arbitrarily selects an integer between 0 and 3<br>The presence of this IE is dependent on IXT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted.<br>SS calculates the value of MAC-I for this message and writes to this IE.<br>SS provides the value of this IE, from its internal counter.<br>Not Present<br>Not Present<br>$(256 + CFN - (CFN \bmod 8 + 8)) \bmod 256$<br>Not Present<br>Not Present |
| RRC State indicator                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | A1, A2, A3, A4 | CELL_DCH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| RRC State indicator                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | A5, A6         | CELL_FACH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| UTRAN DRX cycle length coefficient<br>CN information info<br>URA identity<br>RAB information to reconfigure list                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                | Not Present<br>Not Present<br>Not Present<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| RB information to reconfigure list                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | A1, A2, A3     | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| RB information to reconfigure list<br>——— RB information to reconfigure<br>——— RB identity<br>——— PDCP info<br>——— CHOICE RLC info type<br>——— RB mapping info<br>——— Information for each multiplexing option<br>——— RLC logical channel mapping indicator<br>——— Number of uplink RLC logical channels<br>——— Uplink transport channel type<br>——— UL Transport channel identity<br>——— Logical channel identity<br>——— CHOICE RLC size list<br>——— MAC logical channel priority<br>——— Downlink RLC logical channel info<br>——— Number of downlink RLC logical channels<br>——— Downlink transport channel type<br>——— DL DCH Transport channel identity<br>——— Logical channel identity<br>——— RB stop/continue<br>——— RB information to reconfigure<br>——— RB identity<br>——— PDCP info<br>——— CHOICE RLC info type<br>——— RB mapping info<br>——— Information for each multiplexing option<br>——— RLC logical channel mapping indicator<br>——— Number of uplink RLC logical channels<br>——— Uplink transport channel type<br>——— UL Transport channel identity<br>——— Logical channel identity<br>——— CHOICE RLC size list<br>——— MAC logical channel priority<br>——— Downlink RLC logical channel info<br>——— Number of downlink RLC logical channels<br>——— Downlink transport channel type<br>——— DL DCH Transport channel identity<br>——— Logical channel identity<br>——— RB stop/continue<br>——— RB information to reconfigure | A4             | (UM-DCCH for RRC)<br>1<br>Not Present<br>Not Present<br><br>Not Present<br><br>1<br>DCH<br>5<br>1<br>All<br>1<br><br>1<br>DCH<br>10<br>1<br>Not Present<br>(AM-DCCH for RRC)<br>2<br>Not Present<br>Not Present<br><br>Not Present<br>5<br>DCH<br>1<br>2<br>All<br>2<br><br>1<br>DCH<br>10<br>2<br>Not Present<br>(AM-DCCH for NAS_DT High-priority)                                                                                                                                                                                             |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>— RB identity</li> <li>— PDCP info</li> <li>— CHOICE RLC info type</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— MAC logical channel priority</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— Logical channel identity</li> <li>— RB stop/continue</li> <li>— RB information to reconfigure</li> <li>— RB identity</li> <li>— PDCP info</li> <li>— RLC info</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— Logical channel identity</li> <li>— RB information to reconfigure</li> <li>— RB identity</li> <li>— PDCP info</li> <li>— CHOICE RLC info type</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— Logical channel identity</li> <li>— RB stop/continue</li> </ul> |       | <ul style="list-style-type: none"> <li>3</li> <li>Not Present</li> <li>Not Present</li> <li></li> <li>Not Present</li> <li>1</li> <li>DCH</li> <li>5</li> <li>3</li> <li>All</li> <li>3</li> <li>1</li> <li>DCH</li> <li>10</li> <li>3</li> <li>Not Present</li> <li>(AM-DCCH for NAS-DT Low priority)</li> <li>4</li> <li>Not Present</li> <li>Not Present</li> <li></li> <li>Not Present</li> <li>1</li> <li>DCH</li> <li>5</li> <li>4</li> <li>All</li> <li>4</li> <li></li> <li>1</li> <li>DCH</li> <li>10</li> <li>4</li> <li>(AM-DTCH)</li> <li>20</li> <li>Not Present</li> <li>Not Present</li> <li></li> <li>Not Present</li> <li>1</li> <li>DCH</li> <li>1</li> <li>7</li> <li>All</li> <li>1</li> <li></li> <li>1</li> <li>DCH</li> <li>6</li> <li>7</li> <li>Not Present</li> </ul> |
| <ul style="list-style-type: none"> <li>RB information to reconfigure list</li> <li>— RB information to reconfigure</li> <li>— RB identity</li> <li>— PDCP info</li> <li>— CHOICE RLC info type</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— RLC size index</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | A5,A6 | <ul style="list-style-type: none"> <li>(UM-DCCH for RRC)</li> <li>1</li> <li>Not Present</li> <li>Not Present</li> <li></li> <li>Not Present</li> <li>1</li> <li>RACH</li> <li>1</li> <li>Explicit list</li> <li>Reference to TS34.108 clause 6 Parameter Set</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |



|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— RLC size index</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— Logical channel identity</li> <li>— RB stop/continue</li> <li>— RB information to reconfigure</li> <li>— RB identity</li> <li>— PDCP info</li> <li>— CHOICE RLC info type</li> <li>— CHOICE Uplink RLC mode</li> <li>— CHOICE Downlink RLC mode</li> <li>— Segmentation Indication</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— Logical channel identity</li> <li>— RB stop/continue</li> <li>— RB information to reconfigure</li> <li>— RB identity</li> <li>— PDCP info</li> <li>— CHOICE RLC info type</li> <li>— CHOICE Uplink RLC mode</li> <li>— CHOICE Downlink RLC mode</li> <li>— Segmentation Indication</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— Logical channel identity</li> <li>— RB stop/continue</li> </ul> |            | <p>Not Present</p> <p>1</p> <p>RACH</p> <p>7</p> <p>Explicit list</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>6</p> <p>1</p> <p>FACH</p> <p>6</p> <p>Not Present<br/>(TM-BCCH for RRC)</p> <p>5</p> <p>Not Present</p> <p>RLC info</p> <p>Not Present</p> <p>TM RLC</p> <p>TRUE</p> <p>1</p> <p>FACH</p> <p>5</p> <p>Not Present<br/>(TM-PCCH for RRC)</p> <p>7</p> <p>Not Present</p> <p>RLC info</p> <p>Not Present</p> <p>TM RLC</p> <p>TRUE</p> <p>1</p> <p>PCH</p> <p>1</p> <p>Not Present</p> |
| <p>RB information to be affected</p> <ul style="list-style-type: none"> <li>— RB identity</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— MAC logical channel priority</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— Logical channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | A1, A2, A3 | <p>(UM-DCCH for RRC)</p> <p>1</p> <p>Not Present</p> <p>1</p> <p>DCH</p> <p>5</p> <p>1</p> <p>All</p> <p>1</p> <p>1</p> <p>DCH</p> <p>10</p> <p>1</p>                                                                                                                                                                                                                                                                                                                                                              |
| <p>RB information to be affected</p> <ul style="list-style-type: none"> <li>— RB identity</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— MAC logical channel priority</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | A1, A2, A3 | <p>(AM-DCCH for RRC)</p> <p>2</p> <p>Not Present</p> <p>1</p> <p>DCH</p> <p>5</p> <p>2</p> <p>All</p> <p>2</p>                                                                                                                                                                                                                                                                                                                                                                                                     |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |            |                                                                                                                         |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|-------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— Logical channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                     |            | 10<br>DCH<br>1<br>2                                                                                                     |
| RB information to be affected <ul style="list-style-type: none"> <li>— RB identity</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— Logical channel identity</li> </ul> | A1, A2, A3 | (AM-DCCH for NAS_DT High priority)<br>3<br><br>Not Present<br>1<br>DCH<br>5<br>3<br>All<br>3<br><br>1<br>DCH<br>10<br>3 |
| RB information to be affected <ul style="list-style-type: none"> <li>— RB identity</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— Logical channel identity</li> </ul> | A1, A2, A3 | (AM-DCCH for NAS_DT Low priority)<br>4<br><br>Not Present<br>1<br>DCH<br>5<br>4<br>All<br>4<br><br>1<br>DCH<br>10<br>4  |
| RB information to be affected <ul style="list-style-type: none"> <li>— RB identity</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— Logical channel identity</li> </ul> | A1, A2, A3 | (TM-DTCH)<br>10<br><br>Not Present<br>1<br>DCH<br>1<br>7<br>All<br>1<br><br>1<br>DCH<br>6<br>7                          |
| RB information to be affected <ul style="list-style-type: none"> <li>— RB identity</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— Logical channel identity</li> </ul> | A2         | (DTCH-TM)<br>11<br><br>Not Present<br>1<br>DCH<br>2<br>8<br>All<br>1<br><br>1<br>DCH<br>7                               |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                |                                                                                                                                                                                                                                               |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>Logical channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                | 8                                                                                                                                                                                                                                             |
| <b>RB information to be affected</b> <ul style="list-style-type: none"> <li>RB identity</li> <li>RB mapping info</li> <li>Information for each multiplexing option</li> <li>RLC logical channel mapping indicator</li> <li>Number of uplink RLC logical channels</li> <li>Uplink transport channel type</li> <li>UL Transport channel identity</li> <li>Logical channel identity</li> <li>CHOICE RLC size list</li> <li>MAC logical channel priority</li> <li>Downlink RLC logical channel info</li> <li>Number of downlink RLC logical channels</li> <li>Downlink transport channel type</li> <li>DL DCH Transport channel identity</li> <li>Logical channel identity</li> </ul> | A2             | (This IE is needed for 12.2 kbps and 10.2 kbps)<br>12<br><br>Not Present<br>1<br>DCH<br>3<br>9<br>All<br>1<br><br>1<br>DCH<br>8<br>9                                                                                                          |
| <b>UL Transport channel information for all transport channels</b> <ul style="list-style-type: none"> <li>PRACH TFCS</li> <li>CHOICE mode</li> <li>Individual UL CCTrCH information</li> <li>TFCS ID</li> <li>Shared channel indicator</li> <li>UL TFCS</li> <li>CHOICE TFCI signalling</li> <li>TFCI Field 1 information</li> <li>CHOICE TFCS representation</li> <li>TFCS addition information</li> <li>CHOICE CTFC Size</li> <li>CTFC information</li> <li>TFC subset</li> <li>CHOICE Subset representation</li> <li>Allowed Transport Format combination list</li> </ul>                                                                                                      | A1, A2, A3, A4 | Not Present<br>TDD<br><br>1<br>FALSE<br><br>Normal<br><br>Addition<br><br>Refer to TS34.108 clause 6<br>Refer to TS34.108 clause 6 Parameter Set<br><br>Allowed transport format combination list<br>Refer to TS34.108 clause 6 Parameter Set |
| <b>UL Transport channel information for all transport channels</b> <ul style="list-style-type: none"> <li>PRACH TFCS</li> <li>CHOICE TFCI signalling</li> <li>TFCI Field 1 information</li> <li>CHOICE TFCS representation</li> <li>TFCS addition information</li> <li>CHOICE CTFC Size</li> <li>CTFC information</li> <li>CHOICE mode</li> <li>Individual UL CCTrCH information</li> </ul>                                                                                                                                                                                                                                                                                       | A5, A6         | Normal<br><br>Addition<br><br>Refer to TS34.108 clause 6<br>Refer to TS34.108 clause 6 Parameter Set<br>TDD<br>Not Present                                                                                                                    |
| <b>Deleted UL TrCH information</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | A1, A2, A3     | Not Present                                                                                                                                                                                                                                   |
| <b>Deleted UL TrCH information</b> <ul style="list-style-type: none"> <li>Uplink transport channel type</li> <li>Transport channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | A4             | DCH<br>15                                                                                                                                                                                                                                     |
| <b>Deleted UL TrCH information</b> <ul style="list-style-type: none"> <li>Uplink transport channel type</li> <li>Transport channel identity</li> <li>Uplink transport channel type</li> <li>Transport channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                 | A5             | DCH<br>1<br>DCH<br>5                                                                                                                                                                                                                          |
| <b>Added or Reconfigured UL TrCH information</b> <ul style="list-style-type: none"> <li>Uplink transport channel type</li> <li>UL Transport channel identity</li> <li>TFS</li> <li>CHOICE Transport channel type</li> <li>Dynamic Transport format information</li> <li>RLC Size</li> <li>Number of TBs and TTI List</li> <li>Transmission Time Interval</li> <li>Number of Transport blocks</li> </ul>                                                                                                                                                                                                                                                                           | A1, A2, A3, A4 | DCH<br>5<br><br>Dedicated transport channels<br>(This IE is repeated for TFI number)<br>Reference to TS34.108 clause 6 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6 Parameter      |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>——&gt; CHOICE Logical Channel list</li> <li>——&gt; Semi-static Transport Format information</li> <li>——&gt; Transmission time interval</li> <li>——&gt; Type of channel coding</li> <li>——&gt; Coding Rate</li> <li>——&gt; Rate matching attribute</li> <li>——&gt; CRC size</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                        |        | Set<br>ALL<br><br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set                                                                                                                                                                                                                                          |
| Added or Reconfigured UL TrCH information <ul style="list-style-type: none"> <li>——&gt; Uplink transport channel type</li> <li>——&gt; UL Transport channel identity</li> <li>——&gt; TFS</li> <li>——&gt; CHOICE Transport channel type</li> <li>——&gt; Dynamic Transport format information</li> <li>——&gt; RLC Size</li> <li>——&gt; Number of TBs and TTI List</li> <li>——&gt; Transmission Time Interval</li> <li>——&gt; Number of Transport blocks</li> <li>——&gt; CHOICE Logical Channel list</li> <li>——&gt; Semi-static Transport Format information</li> <li>——&gt; Transmission time interval</li> <li>——&gt; Type of channel coding</li> <li>——&gt; Coding Rate</li> <li>——&gt; Rate matching attribute</li> <li>——&gt; CRC size</li> </ul> | A4     | DCH<br>1<br><br>Dedicated transport channels<br>(This IE is repeated for TFI number)<br>Reference to TS34.108 clause 6 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6 Parameter Set<br>ALL<br><br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set |
| DL Transport channel information common for all transport channel <ul style="list-style-type: none"> <li>——&gt; SCCPCH TFCS</li> <li>——&gt; CHOICE mode</li> <li>——&gt; Individual DL CCTrCH information</li> <li>——&gt; DL TFCS Identity</li> <li>——&gt; TFCS ID</li> <li>——&gt; Shared Channel Indicator</li> <li>——&gt; CHOICE DL parameters</li> <li>——&gt; DL TFCS</li> <li>——&gt; CHOICE TFCI signalling</li> <li>——&gt; TFCI Field 1 Information</li> <li>——&gt; CHOICE TFCI representation</li> <li>——&gt; TFCS addition information</li> <li>——&gt; CHOICE CTFC size</li> <li>——&gt; CTFC information</li> </ul>                                                                                                                           | A1, A3 | Not Present<br>TDD<br><br>1<br>FALSE<br>Independent<br><br>Normal<br><br>Addition<br><br>Refer to TS34.108 clause 6<br>Refer to TS34.108 clause 6 Parameter Set                                                                                                                                                                                                                                                                                                                                                                                         |
| DL Transport channel information common for all transport channel <ul style="list-style-type: none"> <li>——&gt; SCCPCH TFCS</li> <li>——&gt; CHOICE mode</li> <li>——&gt; Individual DL CCTrCH information</li> <li>——&gt; DL TFCS Identity</li> <li>——&gt; TFCS ID</li> <li>——&gt; Shared Channel Indicator</li> <li>——&gt; CHOICE DL parameters</li> <li>——&gt; DL TFCS</li> <li>——&gt; CHOICE TFCI signalling</li> <li>——&gt; TFCI Field 1 Information</li> <li>——&gt; CHOICE TFCI representation</li> <li>——&gt; TFCS addition information</li> <li>——&gt; CHOICE CTFC size</li> </ul>                                                                                                                                                            | A2, A4 | Not Present<br>TDD<br><br>1<br>FALSE<br>Independent<br><br>Normal<br><br>Addition<br><br>Refer to TS34.108 clause 6                                                                                                                                                                                                                                                                                                                                                                                                                                     |



|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>CTFC information</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                | Refer to TS34.108 clause 6 Parameter Set                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| DL Transport channel information common for all transport channel <ul style="list-style-type: none"> <li>SCCPCH TFCS</li> <li>CHOICE TFCl signalling</li> <li>TFCl Field 1 information</li> <li>CHOICE TFCS representation</li> <li>TFCS addition information</li> <li>CHOICE CTFC Size</li> <li>CTFC information</li> <li>Power offset information</li> <li>CHOICE mode</li> <li>Individual DL CCTrCH information</li> </ul>                                                                                                                                                                                                                                                                                                                                         | A5, A6         | (This IE is repeated for TFC number.)<br>Normal<br><br>Addition<br><br>Number of bits used must be enough to cover all combinations of CTFC from clause 6.<br>Refer to TS34.108 clause 6 Parameter Set<br>Not Present<br>TDD<br>Not Present                                                                                                                                                                                                                                                                                                    |
| jDeleted DL TrCH information                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | A1, A2, A3, A6 | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Deleted DL TrCH information <ul style="list-style-type: none"> <li>Downlink transport channel type</li> <li>Transport channel identity</li> <li>Downlink transport channel type</li> <li>Transport channel identity</li> <li>Downlink transport channel type</li> <li>Transport channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                           | A4             | DCH<br>12<br>DCH<br>13<br>DCH<br>14                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Deleted DL TrCH information <ul style="list-style-type: none"> <li>Downlink transport channel type</li> <li>Transport channel identity</li> <li>Downlink transport channel type</li> <li>Transport channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | A5             | DCH<br>6<br>DCH<br>10                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Added or Reconfigured DL TrCH information <ul style="list-style-type: none"> <li>Downlink transport channel type</li> <li>Transport channel identity</li> <li>CHOICE DL parameters</li> <li>Uplink transport channel type</li> <li>UL TrCH Identity</li> <li>DCH quality target</li> <li>BLER Quality value</li> <li>Transparent mode signalling info</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                      | A1             | DCH<br>10<br>Same as UL<br>DCH<br>5<br><br>-6.3<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Added or Reconfigured DL TrCH information <ul style="list-style-type: none"> <li>Downlink transport channel type</li> <li>DL Transport channel identity</li> <li>CHOICE DL parameters</li> <li>TFS</li> <li>CHOICE Transport channel type</li> <li>Dynamic Transport format information</li> <li>RLC Size</li> <li>Number of TBs and TTI List</li> <li>Transmission Time Interval</li> <li>Number of Transport blocks</li> <li>CHOICE Logical Channel list</li> <li>Semi-static Transport Format information</li> <li>Transmission time interval</li> <li>Type of channel coding</li> <li>Coding Rate</li> <li>Rate matching attribute</li> <li>CRC size</li> <li>DCH quality target</li> <li>BLER Quality value</li> <li>Transparent mode signalling info</li> </ul> | A2, A3, A4     | DCH<br>10<br>Independent<br><br>Dedicated transport channels<br>(This IE is repeated for TFI number)<br>Reference to TS34.108 clause 6 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6 Parameter Set<br>ALL<br><br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>-6.3<br>Not Present |
| Frequency info <ul style="list-style-type: none"> <li>CHOICE mode</li> <li>UARFCN (Nt)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |                | TDD<br>Reference to TS34.108 clause 6                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

|                                                      |                |                                                                                                                                                       |
|------------------------------------------------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| Maximum allowed UL TX power                          |                | 30dBm                                                                                                                                                 |
| -CHOICE channel requirement                          | A1, A2, A3, A4 | Uplink-DPCH info                                                                                                                                      |
| <del>Uplink-DPCH power control info</del>            |                |                                                                                                                                                       |
| <del>CHOICE mode</del>                               |                | TDD                                                                                                                                                   |
| <del>UL Target SIR</del>                             |                | Reference to TS34.108                                                                                                                                 |
| <del>CHOICE UL OL PC info</del>                      |                | Individually signalled                                                                                                                                |
| <del>CHOICE TDD option</del>                         |                | 1.28 Mcps TDD                                                                                                                                         |
| <del>TPC step size</del>                             |                | 1 dB                                                                                                                                                  |
| <del>Primary CCPCH Tx Power</del>                    |                | Reference to TS34.108                                                                                                                                 |
| <del>CHOICE mode</del>                               |                | TDD                                                                                                                                                   |
| <del>Uplink Timing Advance Control</del>             |                | Not Present                                                                                                                                           |
| <del>UL CCTrCH List</del>                            |                |                                                                                                                                                       |
| <del>TFCS ID</del>                                   |                | 1                                                                                                                                                     |
| <del>Time info</del>                                 |                |                                                                                                                                                       |
| <del>Activation time</del>                           |                | (256+CFN-(CFNmod 8 + 8))MOD256                                                                                                                        |
| <del>Duration</del>                                  |                | infinite                                                                                                                                              |
| <del>Common timeslot info</del>                      |                |                                                                                                                                                       |
| <del>2<sup>nd</sup> interleaving mode</del>          |                | Reference to TS34.108 clause 6 Parameter Set.                                                                                                         |
| <del>TFCI coding</del>                               |                | Reference to TS34.108 clause 6 Parameter Set                                                                                                          |
| <del>Puncturing Limit</del>                          |                | Reference to TS34.108 clause 6 Parameter Set                                                                                                          |
| <del>Repetition Period</del>                         |                | 1                                                                                                                                                     |
| <del>Repetition Length</del>                         |                | Empty                                                                                                                                                 |
| <del>Uplink DPCH timeslots and codes</del>           |                |                                                                                                                                                       |
| <del>First timeslot information</del>                |                |                                                                                                                                                       |
| <del>CHOICE TDD option</del>                         |                | 1.28 Mcps                                                                                                                                             |
| <del>Timeslot number</del>                           |                | The number of an uplink timeslot that has unassigned codes.                                                                                           |
| <del>TFCI existence</del>                            |                | TRUE                                                                                                                                                  |
| <del>Midamble shift and burst type</del>             |                |                                                                                                                                                       |
| <del>CHOICE TDD option</del>                         |                | 1.28 Mcps                                                                                                                                             |
| <del>Midamble Allocation Mode</del>                  |                | Default                                                                                                                                               |
| <del>Midamble configuration</del>                    |                | 16                                                                                                                                                    |
| <del>CHOICE TDD option</del>                         |                | 1.28 Mcps                                                                                                                                             |
| <del>Modulation</del>                                |                | QPSK                                                                                                                                                  |
| <del>SS-TPC Symbols</del>                            |                | 1                                                                                                                                                     |
| <del>First timeslot code list</del>                  |                | Repeated (1,2) for each channelisation code that is assigned in the slot.                                                                             |
| <del>Channelisation Code</del>                       |                | (i/SF) where i denotes the code that is being assigned and SF is specified in TS34.108 clause 6 Parameter Set.                                        |
| <del>CHOICE more timeslots</del>                     |                | The presence of this IE depends on number of resources specified in TS34.108 section 6 and whether they are being assigned in more than one timeslot. |
| CHOICE channel requirement                           | A5, A6         | Not Present                                                                                                                                           |
| CHOICE Mode                                          |                | TDD                                                                                                                                                   |
| Downlink information common for all radio links      | A1, A2, A4     |                                                                                                                                                       |
| <del>Downlink DPCH info common for all RL</del>      |                | Maintain                                                                                                                                              |
| <del>Timing indicator</del>                          |                | Not Present                                                                                                                                           |
| <del>CFN-targetSFN frame offset</del>                |                |                                                                                                                                                       |
| <del>Downlink DPCH power control information</del>   |                |                                                                                                                                                       |
| <del>CHOICE mode</del>                               |                | TDD                                                                                                                                                   |
| <del>TPC Step Size</del>                             |                | 1                                                                                                                                                     |
| <del>CHOICE mode</del>                               |                | TDD                                                                                                                                                   |
| <del>CHOICE TDD option</del>                         |                | 1.28 Mcps                                                                                                                                             |
| <del>TSTD indicator</del>                            |                | TRUE                                                                                                                                                  |
| <del>Default DPCH Offset Value</del>                 |                | Not Present                                                                                                                                           |
| <del>Downlink information for each radio link</del>  | A1, A2, A3, A4 |                                                                                                                                                       |
| <del>Downlink information for each radio links</del> |                |                                                                                                                                                       |
| <del>CHOICE mode</del>                               |                | TDD                                                                                                                                                   |
| <del>Primary CCPCH info</del>                        |                |                                                                                                                                                       |
| <del>CHOICE mode</del>                               |                | TDD                                                                                                                                                   |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>----- CHOICE TDD-option</li> <li>----- TSTD-indicator</li> <li>----- Cell parameters ID</li> <li>----- Block STTD-indicator</li> <li>----- Downlink DPCH info for each RL</li> <li>----- CHOICE mode</li> <li>----- DL CCTrCH List</li> <li>----- TFCS ID</li> <li>----- Activation time</li> <li>----- Duration</li> <li>----- Common timeslot info</li> <li>----- 2<sup>nd</sup> interleaving mode</li> <li>----- TFCI coding</li> <li>----- Puncturing limit</li> <li>----- Repetition period</li> <li>----- Repetition length</li> <li>----- Downlink DPCH timeslots and codes</li> <li>----- Individual timeslot info</li> <li>----- Timeslot number</li> <li>----- TFCI existence</li> <li>----- Midamble shift and burst type</li> <li>----- CHOICE TDD-option</li> <li>----- Midamble allocation mode</li> <li>----- Midamble configuration</li> <li>----- CHOICE TDD-option</li> <li>----- Modulation</li> <li>----- SS-TPC Symbols</li> <li>----- First timeslot channelisation codes</li> <li>----- First channelisation code</li> <li>----- Last channelisation code</li> <li>----- Bitmap</li> <li>----- CHOICE more timeslots</li> <li>----- Secondary CCPCH info</li> </ul> |        | 1.28 Mcps<br>TRUE<br>0<br>FALSE<br><br>TDD<br><br>1<br>$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$<br>Infinite<br><br>Reference to TS34.108<br>TRUE<br>Reference to TS34.108 clause 6 Parameter Set<br>1<br>Empty<br><br>The number of a downlink timeslot that has unassigned codes<br>TRUE<br><br>1.28 Mcps<br>Default<br>16<br>1.28 Mcps-TDD<br>QPSK<br>1<br><br>$(i/\text{SF})$ where i is the lowest numbered code assigned within the timeslot and SF is specified in TS34.108 clause 6 Parameter Set.<br>$(j/\text{SF})$ where j is the highest numbered code assigned in the timeslot.<br>Bitmap of the codes assigned in this timeslot.<br>The presence of this IE depends upon slot allocations used in the test.<br>Not Present |
| <ul style="list-style-type: none"> <li>----- Downlink information for each radio link</li> <li>----- Choice mode</li> <li>----- Primary CCPCH info</li> <li>----- CHOICE mode</li> <li>----- CHOICE TDD-option</li> <li>----- TSTD-indicator</li> <li>----- Cell parameters ID</li> <li>----- Block STTD-indicator</li> <li>----- Downlink DPCH info for each RL</li> <li>----- SCCPCH information for FACH</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | A5, A6 | TDD<br><br>TDD<br>1.28 Mcps-TDD<br>TRUE<br>0<br>TRUE<br>Not present<br>Not present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

| Condition | Explanation                                                 |
|-----------|-------------------------------------------------------------|
| A1        | This IE need for "Non speech in CS"                         |
| A2        | This IE need for "Speech in CS"                             |
| A3        | This IE need for "Packet to CELL_DCH from CELL_DCH in PS"   |
| A4        | This IE need for "Packet to CELL_DCH from CELL_FACH in PS"  |
| A5        | This IE need for "Packet to CELL_FACH from CELL_DCH in PS"  |
| A6        | This IE need for "Packet to CELL_FACH from CELL_FACH in PS" |

## Contents of RADIO-BEARER-RECONFIGURATION-COMPLETE message: AM

| Information Element                                | Value/remark                                                                                                                                                                                                                                       |
|----------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message-Type                                       |                                                                                                                                                                                                                                                    |
| RRC-transaction-identifier                         | Checked to see if the value is identical to the same IE in the downlink RADIO-BEARER-RECONFIGURATION-COMPLETE message                                                                                                                              |
| Integrity-check-info                               | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| <del>Message authentication code</del>             | <del>This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.</del>                                                                                                                              |
| <del>RRC-Message-sequence-number</del>             | <del>This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.</del>                                                                                                                                        |
| Uplink integrity protection activation info        | Not checked                                                                                                                                                                                                                                        |
| CHOICE mode                                        | TDD                                                                                                                                                                                                                                                |
| <del>CHOICE-TDD-option</del>                       | <del>1.28-Mcps</del>                                                                                                                                                                                                                               |
| COUNT-C activation time                            | The presence of this IE depends on the following 2 factors: (a) There exists RB(s) mapped to RLC-TM and (b) UE is transiting to CELL_DCH state after the reconfiguration procedure. Else, this IE is absent.                                       |
| Radio-bearer-uplink-ciphering-activation-time-info | Not checked                                                                                                                                                                                                                                        |
| Uplink-counter-synchronisation-info                | Not checked                                                                                                                                                                                                                                        |

## Contents of RADIO BEARER RELEASE message: AM or UM (The others of speech in CS)

| Information Element                           | Value/remark                                                                                                                                                                                                                              |
|-----------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                  | Arbitrarily selects an integer between 0 and 3.                                                                                                                                                                                           |
| RRC transaction identifier                    | The presence of this IE is dependent on I-XIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| Integrity check info                          | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                  |
| ———→ message authentication code              | SS provides the value of this IE, from its internal counter.                                                                                                                                                                              |
| ———→ RRC message sequence number              | Not Present                                                                                                                                                                                                                               |
| Integrity protection mode info                | Not Present                                                                                                                                                                                                                               |
| Ciphering mode info                           | Not Present                                                                                                                                                                                                                               |
| Activation time                               | $(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$                                                                                                                                                                                 |
| New U-RNTI                                    | Not Present                                                                                                                                                                                                                               |
| New C-RNTI                                    | Not Present                                                                                                                                                                                                                               |
| RRC State indicator                           | CELL_DCH                                                                                                                                                                                                                                  |
| UTRAN DRX cycle length coefficient            | Not Present                                                                                                                                                                                                                               |
| CN information info                           | Not Present                                                                                                                                                                                                                               |
| URA identity                                  | Not Present                                                                                                                                                                                                                               |
| RAB information to reconfigure list           | Not Present                                                                                                                                                                                                                               |
| RB information to release                     |                                                                                                                                                                                                                                           |
| ———→ RB identity                              | 10                                                                                                                                                                                                                                        |
| RB information to be affected                 | (UM DCH for RRC)                                                                                                                                                                                                                          |
| ———→ RB identity                              | 1                                                                                                                                                                                                                                         |
| ———→ RB mapping info                          |                                                                                                                                                                                                                                           |
| ———→ Information for each multiplexing option |                                                                                                                                                                                                                                           |
| ———→ RLC logical channel mapping indicator    | Not Present                                                                                                                                                                                                                               |
| ———→ Number of uplink RLC logical channels    | 1                                                                                                                                                                                                                                         |
| ———→ Uplink transport channel type            | DCH                                                                                                                                                                                                                                       |
| ———→ UL Transport channel identity            | 5                                                                                                                                                                                                                                         |
| ———→ Logical channel identity                 | 1                                                                                                                                                                                                                                         |
| ———→ CHOICE RLC size list                     | All                                                                                                                                                                                                                                       |
| ———→ MAC logical channel priority             | 1                                                                                                                                                                                                                                         |
| ———→ Downlink RLC logical channel info        |                                                                                                                                                                                                                                           |
| ———→ Number of downlink RLC logical channels  | 1                                                                                                                                                                                                                                         |
| ———→ Downlink transport channel type          | DCH                                                                                                                                                                                                                                       |
| ———→ DL DCH Transport channel identity        | 10                                                                                                                                                                                                                                        |
| ———→ Logical channel identity                 | 1                                                                                                                                                                                                                                         |
| RB information to be affected                 | (AM DCH for RRC)                                                                                                                                                                                                                          |
| ———→ RB identity                              | 2                                                                                                                                                                                                                                         |
| ———→ RB mapping info                          |                                                                                                                                                                                                                                           |
| ———→ Information for each multiplexing option |                                                                                                                                                                                                                                           |
| ———→ RLC logical channel mapping indicator    | Not Present                                                                                                                                                                                                                               |
| ———→ Number of uplink RLC logical channels    | 1                                                                                                                                                                                                                                         |
| ———→ Uplink transport channel type            | DCH                                                                                                                                                                                                                                       |
| ———→ UL Transport channel identity            | 5                                                                                                                                                                                                                                         |
| ———→ Logical channel identity                 | 2                                                                                                                                                                                                                                         |
| ———→ CHOICE RLC size list                     | All                                                                                                                                                                                                                                       |
| ———→ MAC logical channel priority             | 2                                                                                                                                                                                                                                         |
| ———→ Downlink RLC logical channel info        |                                                                                                                                                                                                                                           |
| ———→ Number of downlink RLC logical channels  | 1                                                                                                                                                                                                                                         |
| ———→ Downlink transport channel type          | DCH                                                                                                                                                                                                                                       |
| ———→ DL DCH Transport channel identity        | 10                                                                                                                                                                                                                                        |
| ———→ Logical channel identity                 | 2                                                                                                                                                                                                                                         |
| RB information to be affected                 | (AM DCH for NAS_DT High priority)                                                                                                                                                                                                         |
| ———→ RB identity                              | 3                                                                                                                                                                                                                                         |
| ———→ RB mapping info                          |                                                                                                                                                                                                                                           |
| ———→ Information for each multiplexing option |                                                                                                                                                                                                                                           |
| ———→ RLC logical channel mapping indicator    | Not Present                                                                                                                                                                                                                               |
| ———→ Number of uplink RLC logical channels    | 1                                                                                                                                                                                                                                         |
| ———→ Uplink transport channel type            | DCH                                                                                                                                                                                                                                       |
| ———→ UL Transport channel identity            | 5                                                                                                                                                                                                                                         |
| ———→ Logical channel identity                 | 3                                                                                                                                                                                                                                         |
| ———→ CHOICE RLC size list                     | All                                                                                                                                                                                                                                       |
| ———→ MAC logical channel priority             | 3                                                                                                                                                                                                                                         |
| ———→ Downlink RLC logical channel info        |                                                                                                                                                                                                                                           |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— Logical channel identity</li> </ul> RB information to be affected <ul style="list-style-type: none"> <li>— RB identity</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— Logical channel identity</li> </ul> Downlink counter synchronisation info | 1<br>DCH<br>10<br>3<br>(AM DCCH for NAS_DT Low priority)<br>4<br><br>Not Present<br>1<br>DCH<br>5<br>4<br>All<br>4<br><br>1<br>DCH<br>10<br>4<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| UL Transport channel information for all transport channels <ul style="list-style-type: none"> <li>— PRACH TFCS</li> <li>— CHOICE mode</li> <li>— Individual UL CCTrCH information</li> <li>— TFCS ID</li> <li>— Shared channel indicator</li> <li>— UL TFCS</li> <li>— CHOICE TFCI signalling</li> <li>— TFCI Field 1 information</li> <li>— CHOICE TFCI representation</li> <li>— TFCS addition information</li> <li>— CHOICE CTFC Size</li> <li>— CTFC information</li> <li>— TFC subset</li> <li>— CHOICE Subset representation</li> <li>— Allowed Transport Format combination list</li> </ul>                                                                                                                                                                                                                                                                                                                                                                    | Not Present<br>TDD<br><br>1<br>FALSE<br><br>Normal<br><br>Addition<br><br>Refer to TS34.108 clause 6<br>Refer to TS34.108 clause 6 Parameter Set<br><br>Allowed transport format combination list<br>Refer to TS34.108 clause 6 Parameter Set                                                                                                                                                                                                                                                                                                                                                                       |
| Deleted UL TrCH Information <ul style="list-style-type: none"> <li>— Transport channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 1                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Added or Reconfigured UL TrCH information <ul style="list-style-type: none"> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— TFS</li> <li>— CHOICE Transport channel type</li> <li>— Dynamic Transport format information</li> <li>— RLC Size</li> <li>— Number of TBs and TTI List</li> <li>— Transmission Time Interval</li> <li>— Number of Transport blocks</li> <li>— CHOICE Logical Channel list</li> <li>— Semi-static Transport Format information</li> <li>— Transmission time interval</li> <li>— Type of channel coding</li> <li>— Coding Rate</li> <li>— Rate matching attribute</li> <li>— CRC size</li> </ul>                                                                                                                                                                                                                                                                                                    | If TrCH reconfiguration is executed then this is needed (e.g. The rate of SRB for DCCH is changed.).<br>DCH<br>5<br><br>Dedicated transport channels<br>(This IE is repeated for TFI number)<br>Reference to TS34.108 clause 6 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6 Parameter Set<br><br>ALL<br><br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set |
| CHOICE mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | TDD                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| DL Transport channel information common for all transport channel <ul style="list-style-type: none"> <li>— SCCPCH TFCS</li> <li>— CHOICE mode</li> <li>— Individual DL CCTrCH information</li> <li>— DL TFCS Identity</li> <li>— TFCS ID</li> <li>— Shared Channel Indicator</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Not Present<br>TDD<br><br>1<br>FALSE                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>- CHOICE DL parameters</li> <li>- DL TFCS</li> <li>- CHOICE TFCI signalling</li> <li>- TFCI Field 1 Information</li> <li>- CHOICE TFCI representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC size</li> <li>- CTFC information</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | <p>Independent</p> <p>Normal</p> <p>Addition</p> <p>Refer to TS34.108 clause 6</p> <p>Refer to TS34.108 clause 6 Parameter Set</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <p>Deleted DL TrCH Information</p> <ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | 6                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <p>Added or Reconfigured DL TrCH information</p> <ul style="list-style-type: none"> <li>- Downlink transport channel type</li> <li>- DL Transport channel identity</li> <li>- CHOICE DL parameters</li> <li>- TFS</li> <li>- CHOICE Transport channel type</li> <li>- Dynamic Transport format information</li> <li>- RLC Size</li> <li>- Number of TBs and TTI List</li> <li>- Transmission Time Interval</li> <li>- Number of Transport blocks</li> <li>- CHOICE Logical Channel list</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul>                                                                                                                                                                                     | <p>If TrCH reconfiguration is executed then this is needed (e.g. The rate of SRB for DCCH is changed.):</p> <p>DCH</p> <p>10</p> <p>Independent</p> <p>Dedicated transport channels<br/>(This IE is repeated for TFI number)</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>(This IE is repeated for TFI number.)</p> <p>Not Present</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>ALL</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>-6.3</p> <p>Not Present</p> |
| <p>Frequency info</p> <ul style="list-style-type: none"> <li>- CHOICE mode</li> <li>- UARFCN (Nt)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | <p>TDD</p> <p>Reference to TS34.108 clause 6 Parameter Set</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <p>Maximum allowed UL TX power</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | 30dBm                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <p>Uplink DPCH info</p> <ul style="list-style-type: none"> <li>- CHOICE mode</li> <li>- Uplink DPCH power control info</li> <li>- UL Target SIR</li> <li>- CHOICE UL OL PC info</li> <li>- CHOICE TDD option</li> <li>- TPC step size</li> <li>- Primary CCPCH Tx Power</li> <li>- CHOICE mode</li> <li>- Uplink Timing Advance Control</li> <li>- UL CCTrCH List</li> <li>- TFCS ID</li> <li>- Time info</li> <li>- Activation time</li> <li>- Duration</li> <li>- Common timeslot info</li> <li>- 2<sup>nd</sup> interleaving mode</li> <li>- TFCI coding</li> <li>- Puncturing Limit</li> <li>- Repetition Period</li> <li>- Repetition Length</li> <li>- Uplink DPCH timeslots and codes</li> <li>- First timeslot information</li> <li>- CHOICE TDD option</li> <li>- Timeslot number</li> <li>- TFCI existence</li> <li>- Midamble shift and burst type</li> <li>- CHOICE TDD option</li> <li>- Midamble Allocation Mode</li> <li>- Midamble configuration</li> <li>- CHOICE TDD option</li> </ul> | <p>TDD</p> <p>Reference to TS34.108</p> <p>Individually signalled</p> <p>1.28 Mcps TDD</p> <p>1</p> <p>Reference to TS34.108</p> <p>TDD</p> <p>Not Present</p> <p>1</p> <p>(256+CFN-(CFN MOD 8 + 8) MOD 256</p> <p>Infinite</p> <p>Reference to TS34.108 clause 6 Parameter Set.</p> <p>Reference to TS34.108 clause 6 Parameter Set.</p> <p>Reference to TS34.108 clause 6 Parameter Set.</p> <p>Reference to TS34.108 clause 6 Parameter Set.</p> <p>Reference to TS34.108 clause 6 Parameter Set.</p> <p>1.28 Mcps</p> <p>The number of an uplink timeslot that has unassigned codes.</p> <p>TRUE</p> <p>1.28 Mcps</p> <p>Default</p> <p>16</p> <p>1.28 Mcps</p>                                                    |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>-----&gt; Modulation</li> <li>-----&gt; SS-TPC-Symbols</li> <li>-----&gt; First timeslot code list</li> <li>-----&gt; Channelisation-Code</li> <li>-----&gt; CHOICE more timeslots</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | <p>QPSK</p> <p>1</p> <p>Repeated (1,2) for each channelisation-code that is assigned in the timeslot.</p> <p>(i/SF) where i denotes an unassigned-code and SF is specified in TS34.108 clause 6 Parameter Set.</p> <p>The presence of this IE depends on number of resources specified in TS34.108 section 6 and whether they are assigned in more than one timeslot.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| CHOICE Mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | TDD                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <p>Downlink information common for all radio-links</p> <ul style="list-style-type: none"> <li>-----&gt; Downlink-DPCH-info-common-for-all-RL</li> <li>-----&gt; Timing-indicator</li> <li>-----&gt; CFN-targetSFN-frame-offset</li> <li>-----&gt; Downlink-DPCH-power-control-information</li> <li>-----&gt; CHOICE-mode</li> <li>-----&gt; TPC-Step-Size</li> <li>-----&gt; CHOICE-mode</li> <li>-----&gt; CHOICE-TDD-option</li> <li>-----&gt; TSTD-indicator</li> <li>-----&gt; Default-DPCH-Offset-Value</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | <p>Maintain</p> <p>Not Present</p> <p>TDD</p> <p>1</p> <p>TDD</p> <p>1.28-Mcps</p> <p>TRUE</p> <p>0</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <p>Downlink information for each radio-link list</p> <ul style="list-style-type: none"> <li>-----&gt; Downlink information for each radio-links</li> <li>-----&gt; CHOICE-mode</li> <li>-----&gt; Primary-CCPCH-info</li> <li>-----&gt; CHOICE-mode</li> <li>-----&gt; CHOICE-TDD-option</li> <li>-----&gt; TSTD-indicator</li> <li>-----&gt; Cell-parameters-ID</li> <li>-----&gt; Block-STTD-indicator</li> <li>-----&gt; Downlink-DPCH-info-for-each-RL</li> <li>-----&gt; CHOICE-mode</li> <li>-----&gt; DL-CCTrCH-List</li> <li>-----&gt; TFCS-ID</li> <li>-----&gt; Activation-time</li> <li>-----&gt; Duration</li> <li>-----&gt; Common-timeslot-info</li> <li>-----&gt; 2<sup>nd</sup>-Interleaving-mode</li> <li>-----&gt; TFCI-coding</li> <li>-----&gt; Puncturing-limit</li> <li>-----&gt; Repetition-period</li> <li>-----&gt; Repetition-length</li> <li>-----&gt; Downlink-DPCH-timeslots-and-codes</li> <li>-----&gt; Individual-timeslot-info</li> <li>-----&gt; Timeslot-number</li> <li>-----&gt; TFCI-existence</li> <li>-----&gt; Midamble-shift-and-burst-type</li> <li>-----&gt; CHOICE-TDD-option</li> <li>-----&gt; Midamble-allocation-mode</li> <li>-----&gt; Midamble-configuration</li> <li>-----&gt; CHOICE-TDD-option</li> <li>-----&gt; Modulation</li> <li>-----&gt; SS-TPC-Symbols</li> <li>-----&gt; First-timeslot-channelisation-codes</li> <li>-----&gt; First-channelisation-code</li> <li>-----&gt; Last-channelisation-code</li> <li>-----&gt; Bitmap</li> <li>-----&gt; CHOICE-more-timeslots</li> <li>-----&gt; Secondary-CCPCH-info</li> </ul> | <p>TDD</p> <p>TDD</p> <p>1.28-Mcps</p> <p>TRUE</p> <p>0</p> <p>FALSE</p> <p>TDD</p> <p>1</p> <p>(256+CFN-(CFN-MOD-8+8))MOD-256</p> <p>Infinite</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>Reference to TS34.108 clause 6 Parameter Set</p> <p>1</p> <p>Empty</p> <p>The number of a downlink timeslot that has unassigned codes.</p> <p>TRUE</p> <p>1.28-Mcps</p> <p>Default</p> <p>16</p> <p>1.28-Mcps-TDD</p> <p>QPSK</p> <p>1</p> <p>(i/SF) where i is the lowest numbered-unused-code that is assigned in the timeslot and SF is specified in TS34.108 Parameter Set.</p> <p>(j/SF) where j is the highest numbered-code that is assigned in the timeslot.</p> <p>Bitmap-of-codes-assigned-in-the-slot.</p> <p>The presence of this IE depends upon whether the resources specified in the TS34.108 clause 6 Parameter Set require the use of more than one timeslot.</p> <p>Not Present</p> |



## Contents of RADIO-BEARER RELEASE message: AM or UM (Speech in CS)

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |                | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier<br>Integrity check info<br><br>——— message authentication code<br><br>——— RRC message sequence number<br><br>Integrity protection mode info<br>Ciphering mode info<br>Activation time<br>New U-RNTI<br>New C-RNTI                                                                                                                                                                                                                                                                                                                                        |                | Arbitrarily selects an integer between 0 and 3<br>The presence of this IE is dependent on IXT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted.<br>SS calculates the value of MAC-I for this message and writes to this IE.<br>SS provides the value of this IE, from its internal counter.<br>Not Present<br>Not Present<br>$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$<br>Not Present<br>Not Present |
| RRC State indicator                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | A2, A3, A4     | CELL_DCH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| RRC State indicator                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | A5, A6         | CELL_FACH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| UTRAN DRX cycle length coefficient<br>CN information info<br>Signalling Connection release indication<br>URA identity<br>RAB information to reconfigure list                                                                                                                                                                                                                                                                                                                                                                                                                                        |                | Not Present<br>Not Present<br>Not Present<br>Not Present<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| RB information to release<br>——— RB identity                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | A2             | 10                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| RB information to release<br>——— RB identity                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | A2             | 11                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| RB information to release<br>——— RB identity                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | A2             | 12                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| RB information to release<br>——— RB identity                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | A3, A4, A5, A6 | 20                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| RB information to release<br>——— RB identity                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | A4             | 6                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| RB information to release<br>——— RB identity                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | A4             | 7                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| RB information to be affected<br>——— RB identity<br>——— RB mapping info<br>——— Information for each multiplexing option<br>——— RLC logical channel mapping indicator<br>——— Number of uplink RLC logical channels<br>——— Uplink transport channel type<br>——— UL Transport channel identity<br>——— Logical channel identity<br>——— CHOICE RLC size list<br>——— MAC logical channel priority<br>——— Downlink RLC logical channel info<br>——— Number of downlink RLC logical channels<br>——— Downlink transport channel type<br>——— DL DCH Transport channel identity<br>——— Logical channel identity | A2, A3, A4     | (UM-DCCH for RRC)<br>1<br><br>Not Present<br>1<br>DCH<br>5<br>1<br>All<br>1<br><br>1<br>DCH<br>10<br>1                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| RB information to be affected<br>——— RB identity<br>——— RB mapping info<br>——— Information for each multiplexing option<br>——— RLC logical channel mapping indicator<br>——— Number of uplink RLC logical channels<br>——— Uplink transport channel type<br>——— UL Transport channel identity<br>——— Logical channel identity<br>——— CHOICE RLC size list<br>——— MAC logical channel priority<br>——— Downlink RLC logical channel info                                                                                                                                                                | A2, A3, A4     | (AM-DCCH for RRC)<br>2<br><br>Not Present<br>1<br>DCH<br>5<br>2<br>All<br>2                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |            |                                                                                                                                                         |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— Logical channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |            | 1<br>DCH<br>10<br>2                                                                                                                                     |
| RB information to be affected <ul style="list-style-type: none"> <li>— RB identity</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— Logical channel identity</li> </ul> | A2, A3, A4 | (AM-DCCH for NAS_DT High-priority)<br>3<br><br>Not Present<br>1<br>DCH<br>5<br>3<br>All<br>3<br><br>1<br>DCH<br>10<br>3                                 |
| RB information to be affected <ul style="list-style-type: none"> <li>— RB identity</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— UL Transport channel identity</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— DL DCH Transport channel identity</li> <li>— Logical channel identity</li> </ul> | A2, A3, A4 | (AM-DCCH for NAS_DT Low-priority)<br>4<br><br>Not Present<br>1<br>DCH<br>5<br>4<br>All<br>4<br><br>1<br>DCH<br>10<br>4                                  |
| RB information to be affected <ul style="list-style-type: none"> <li>— RB identity</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— RLC size index</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— Logical channel identity</li> </ul>                                                             | A5, A6     | (UM-DCCH for RRC)<br>1<br><br>Not Present<br>1<br>RACH<br>1<br>Explicit list<br>Reference to TS34.108 clause 6 Parameter Set<br>2<br><br>1<br>FACH<br>1 |
| RB information to be affected <ul style="list-style-type: none"> <li>— RB identity</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— RLC size index</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— Logical channel identity</li> </ul>                                                             | A5, A6     | (AM-DCCH for RRC)<br>2<br><br>Not Present<br>1<br>RACH<br>2<br>Explicit list<br>Reference to TS34.108 clause 6 Parameter Set<br>3<br><br>1<br>FACH<br>2 |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |        |                                                                                                                                                                                                                                               |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RB information to be affected<br>——> RB identity<br>——> RB mapping info<br>——> Information for each multiplexing option<br>——> RLC logical channel mapping indicator<br>——> Number of uplink RLC logical channels<br>——> Uplink transport channel type<br>——> Logical channel identity<br>——> CHOICE RLC size list<br>——> RLC size index<br><br>——> MAC logical channel priority<br>——> Downlink RLC logical channel info<br>——> Number of downlink RLC logical channels<br>——> Downlink transport channel type<br>——> Logical channel identity                                      | A5, A6 | (AM-DCCH for NAS_DT High priority)<br>3<br><br>Not Present<br>1<br>RACH<br>3<br>Explicit list<br>Reference to TS34.108 clause 6 Parameter Set<br>4<br><br>1<br>FACH<br>3                                                                      |
| RB information to be affected<br>——> RB identity<br>——> RB mapping info<br>——> Information for each multiplexing option<br>——> RLC logical channel mapping indicator<br>——> Number of uplink RLC logical channels<br>——> Uplink transport channel type<br>——> Logical channel identity<br>——> CHOICE RLC size list<br>——> RLC size index<br><br>——> MAC logical channel priority<br>——> Downlink RLC logical channel info<br>——> Number of downlink RLC logical channels<br>——> Downlink transport channel type<br>——> DL Transport channel identity<br>——> Logical channel identity | A5, A6 | (AM-DCCH for NAS_DT Low priority)<br>4<br><br>Not Present<br>1<br>RACH<br>4<br>Explicit list<br>Reference to TS34.108 clause 6 Parameter Set<br>5<br><br>1<br>FACH<br>1<br>4                                                                  |
| RB information to be affected<br>——> RB identity<br>——> RB mapping info<br>——> Information for each multiplexing option<br>——> Downlink RLC logical channel info<br>——> Number of downlink RLC logical channels<br>——> Downlink transport channel type<br>——> Logical channel identity                                                                                                                                                                                                                                                                                               | A5, A6 | (TM-BCCH for RRC)<br>6<br><br>1<br>FACH<br>5                                                                                                                                                                                                  |
| RB information to be affected<br>——> RB identity<br>——> RB mapping info<br>——> Information for each multiplexing option<br>——> Downlink RLC logical channel info<br>——> Number of downlink RLC logical channels<br>——> Downlink transport channel type<br>——> Logical channel identity                                                                                                                                                                                                                                                                                               | A5, A6 | (TM-PCCH for RRC)<br>7<br><br>1<br>PCH<br>1                                                                                                                                                                                                   |
| Downlink counter synchronisation info                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |        | Not Present                                                                                                                                                                                                                                   |
| UL Transport channel information for all transport channels<br>——> PRACH TFCS<br>——> CHOICE mode<br>——> Individual UL CCTrCH information<br>——> TFCS ID<br>——> Shared channel indicator<br>——> UL TFCS<br>——> CHOICE TFCI signalling<br>——> TFCI Field 1 information<br>——> CHOICE TFCS representation<br>——> TFCS addition information<br>——> CHOICE CTFC Size<br>——> CTFC information<br>——> TFC subset<br>——> CHOICE Subset representation<br>——> Allowed Transport Format combination list                                                                                       | A2, A4 | Not Present<br>TDD<br><br>1<br>FALSE<br><br>Normal<br><br>Addition<br><br>Refer to TS34.108 clause 6<br>Refer to TS34.108 clause 6 Parameter Set<br><br>Allowed transport format combination list<br>Refer to TS34.108 clause 6 Parameter Set |
| UL Transport channel information for all transport                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | A3     |                                                                                                                                                                                                                                               |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| channels<br>— PRACH TFCS<br>— CHOICE mode<br>— Individual UL CCTrCH information<br>— TFCS ID<br>— Shared channel indicator<br>— UL TFCS<br>— CHOICE TFCI signalling<br>— TFCI Field 1 information<br>— CHOICE TFCS representation<br>— TFCS addition information<br>— CHOICE CTFC Size<br>— CTFC information<br>— TFC subset<br>— CHOICE Subset representation<br>— Allowed Transport Format combination list                                                                                                                              |            | Not Present<br>TDD<br><br>1<br>FALSE<br><br>Normal<br><br>Addition<br><br>Refer to TS34.108 clause 6<br>Refer to TS34.108 clause 6 Parameter Set<br><br>Allowed transport format combination list<br>Refer to TS34.108 clause 6 Parameter Set                                                                                                                                                                                                                                                                                                                                                                  |
| UL Transport channel information for all transport channels<br>— PRACH TFCS<br>— CHOICE TFCI signalling<br>— TFCI Field 1 information<br>— CHOICE TFCS representation<br><br>— TFCS addition information<br>— CHOICE CTFC Size<br>— CTFC information<br>— CHOICE mode<br>— Individual UL CCTrCH information                                                                                                                                                                                                                                | A5, A6     | Normal<br><br>Addition<br><br>Refer to TS34.108 clause 6<br>Refer to TS34.108 clause 6 Parameter Set<br>TDD<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Deleted UL TrCH Information<br>— Uplink transport channel type                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | A2, A5     | DCH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| — Transport channel identity                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |            | 1                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Deleted UL TrCH Information<br>— Uplink transport channel type                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | A2         | DCH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| — Transport channel identity                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |            | 2                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Deleted UL TrCH Information<br>— Uplink transport channel type<br>— Transport channel identity                                                                                                                                                                                                                                                                                                                                                                                                                                             | A2         | DCH<br>3                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Deleted UL TrCH Information<br>— Uplink transport channel type<br>— Transport channel identity                                                                                                                                                                                                                                                                                                                                                                                                                                             | A3         | DCH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| — Transport channel identity                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |            | 6                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Added or Reconfigured UL TrCH information<br><br>— Uplink transport channel type<br>— UL Transport channel identity<br>— TFS<br>— CHOICE Transport channel type<br>— Dynamic Transport format information<br>— RLC Size<br><br>— Number of TBs and TTI List<br>— Transmission Time Interval<br>— Number of Transport blocks<br><br>— CHOICE Logical Channel list<br>— Semi-static Transport Format information<br>— Transmission time interval<br><br>— Type of channel coding<br>— Coding Rate<br>— Rate matching attribute<br>— CRC size | A2, A3, A4 | If TrCH reconfiguration is executed then this is needed (e.g. The rate of SRB for DCCH is changed).<br>DCH<br>5<br><br>Dedicated transport channels<br>(This IE is repeated for TFI number)<br>Reference to TS34.108 clause 6 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6 Parameter Set<br>ALL<br><br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set |
| DL Transport channel information common for all transport channel                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | A2, A3, A4 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- CHOICE mode</li> <li>- Individual-DL CCTrCH information</li> <li>- DL TFCS Identity</li> <li>- TFCS ID</li> <li>- Shared Channel Indicator</li> <li>- CHOICE-DL parameters</li> <li>- DL TFCS</li> <li>- CHOICE TFCI signalling</li> <li>- TFCI Field 1 Information</li> <li>- CHOICE TFCI representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC size</li> <li>- CTFC information</li> </ul>                                                                                                                                                                                                                                                                                                                                    |            | <p>Not Present<br/>TDD</p> <p>1<br/>FALSE<br/>Independent</p> <p>Normal</p> <p>Addition</p> <p>Refer to TS34.108 clause 6<br/>Refer to TS34.108 clause 6 Parameter Set</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <p>DL Transport channel information common for all transport channel</p> <ul style="list-style-type: none"> <li>- SCCPCH TFCS</li> <li>- CHOICE TFCI signalling</li> <li>- TFCI Field 1 information</li> <li>- CHOICE TFCS representation</li> <li>- TFCS addition information</li> <li>- CHOICE CTFC Size</li> <li>- CTFC information</li> <li>- Power offset information</li> <li>- CHOICE mode</li> <li>- Individual-DL CCTrCH information</li> </ul>                                                                                                                                                                                                                                                                                                                                                             | A5, A6     | <p>(This IE is repeated for TFC-number.)<br/>Normal</p> <p>Addition</p> <p>Number of bits used must be enough to cover all combinations of CTFC from clauses 6.<br/>Refer to TS34.108 clause 6 Parameter Set</p> <p>Not Present<br/>TDD<br/>Not Present</p>                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <p>Deleted DL TrCH Information</p> <ul style="list-style-type: none"> <li>- Downlink transport channel type</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | A2, A3, A5 | DCH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |            | 6                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <p>Deleted DL TrCH Information</p> <ul style="list-style-type: none"> <li>- Downlink transport channel type</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | A2         | DCH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |            | 7                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <p>Deleted DL TrCH Information</p> <ul style="list-style-type: none"> <li>- Downlink transport channel type</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | A2         | DCH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <ul style="list-style-type: none"> <li>- Transport channel identity</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |            | 8                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <p>Added or Reconfigured DL TrCH information</p> <ul style="list-style-type: none"> <li>- Downlink transport channel type</li> <li>- DL Transport channel identity</li> <li>- CHOICE-DL parameters</li> <li>- TFS</li> <li>- CHOICE Transport channel type</li> <li>- Dynamic Transport format information</li> <li>- RLC Size</li> <li>- Number of TBs and TTI List</li> <li>- Transmission Time Interval</li> <li>- Number of Transport blocks</li> <li>- CHOICE Logical Channel list</li> <li>- Semi-static Transport Format information</li> <li>- Transmission time interval</li> <li>- Type of channel coding</li> <li>- Coding Rate</li> <li>- Rate matching attribute</li> <li>- CRC size</li> <li>- DCH quality target</li> <li>- BLER Quality value</li> <li>- Transparent mode signalling info</li> </ul> | A2, A3, A4 | <p>If TrCH reconfiguration is executed then this is needed(e.g. The rate of SRB for DCCH is changed.):<br/>DCH<br/>10<br/>Independent</p> <p>Dedicated transport channels<br/>(This IE is repeated for TFI number)<br/>Reference to TS34.108 clause 6 Parameter Set<br/>(This IE is repeated for TFI number.)<br/>Not Present<br/>Reference to TS34.108 clause 6 Parameter Set<br/>ALL</p> <p>Reference to TS34.108 clause 6 Parameter Set<br/>Reference to TS34.108 clause 6 Parameter Set<br/>Reference to TS34.108 clause 6 Parameter Set<br/>Reference to TS34.108 clause 6 Parameter Set<br/>Reference to TS34.108 clause 6 Parameter Set</p> <p>-6,3<br/>Not Present</p> |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Frequency info<br><ul style="list-style-type: none"> <li>CHOICE mode</li> <li>UARFCN (Nt)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |            | TDD<br>Reference to TS34.108 clause 6 Parameter Set                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Maximum allowed UL TX power                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |            | 30dBm                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <ul style="list-style-type: none"> <li>CHOICE channel requirement</li> <li>Uplink DPCCH power control info</li> <li>CHOICE mode</li> <li>UL Target SIR</li> <li>CHOICE UL-OL PC info</li> <li>CHOICE TDD option</li> <li>TPC step size</li> <li>Primary CCPCH Tx Power</li> <li>CHOICE mode</li> <li>Uplink Timing Advance Control</li> <li>UL CCTrCH List</li> <li>TFCS ID</li> <li>Time info</li> <li>Activation time</li> <li>Duration</li> <li>Common timeslot info</li> <li>2<sup>nd</sup> interleaving mode</li> <li>TFCI coding</li> <li>Repetition Period</li> <li>Repetition Length</li> <li>Uplink DPCCH timeslots and codes</li> <li>First timeslot information</li> <li>CHOICE TDD option</li> <li>Timeslot number</li> <li>TFCI existence</li> <li>Midamble shift and burst type</li> <li>CHOICE TDD option</li> <li>Midamble Allocation Mode</li> <li>Midamble configuration</li> <li>CHOICE TDD option</li> <li>Modulation</li> <li>SS-TPC Symbols</li> <li>First timeslot code list</li> <li>Channelisation Code</li> <li>CHOICE more timeslots</li> </ul> | A2, A2, A4 | Uplink DPCCH info<br><br>TDD<br>Reference to TS34.108<br>Individually signalled<br>1.28 Mcps-TDD<br>1<br>Reference to TS34.108<br>TDD<br>Not Present<br><br>1<br><br>(256+CFN-(CFNmod 8 + 8))MOD256<br>Infinite<br><br>Reference to TS34.108 clause 6.<br>Reference to TS34.108 clause 6.<br>1<br>Empty<br><br>1.28 Mcps<br>The number of an uplink timeslot that has unassigned codes.<br>TRUE<br><br>1.28 Mcps<br>Default<br>16<br>1.28 Mcps<br>QPSK<br>1<br>Repeated (1,2) for each channelisation code that is assigned in the slot.<br>(i/SF) where i denotes the code that is being assigned and SF is specified in TS34.108 clause 6 Parameter Set.<br>The presence of this IE depends on the number of resources specified in TS34.108 section 6 and whether they are assigned in more than one timeslot. |
| CHOICE Mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |            | TDD                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Downlink information common for all radio links <ul style="list-style-type: none"> <li>Downlink DPCCH info common for all RL</li> <li>Timing indicator</li> <li>CFN-targetSFN frame offset</li> <li>Downlink DPCCH power control information</li> <li>CHOICE mode</li> <li>TPC Step Size</li> <li>CHOICE mode</li> <li>CHOICE TDD option</li> <li>TSTD indicator</li> <li>Default DPCCH Offset Value</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | A2, A3, A4 | Maintain<br>Not Present<br><br>TDD<br>1<br>TDD<br>1.28 Mcps<br>TRUE<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| Downlink information for each radio link list <ul style="list-style-type: none"> <li>Downlink information for each radio links</li> <li>CHOICE mode</li> <li>Primary CCPCH info</li> <li>CHOICE mode</li> <li>CHOICE TDD option</li> <li>TSTD indicator</li> <li>Cell parameters ID</li> <li>Block-STTD indicator</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | A2, A3, A4 | TDD<br><br>TDD<br>1.28 Mcps<br>TRUE<br>0<br>FALSE                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>— Downlink DPCH info for each RL</li> <li>— CHOICE mode</li> <li>— DL CCTrCH List</li> <li>— TFCS ID</li> <li>— Activation time</li> <li>— Duration</li> <li>— Common timeslot info</li> <li>— 2<sup>nd</sup> Interleaving mode</li> <li>— TFCI coding</li> <li>— Puncturing limit</li> <li>— Repetition period</li> <li>— Repetition length</li> <li>— Downlink DPCH timeslots and codes</li> <li>— Individual timeslot info</li> <li>— Timeslot number</li> <li>— TFCI existence</li> <li>— Midamble shift and burst type</li> <li>— CHOICE TDD option</li> <li>— Midamble allocation mode</li> <li>— Midamble configuration</li> <li>— CHOICE TDD option</li> <li>— Modulation</li> <li>— SS-TPC Symbols</li> <li>— First timeslot channelisation codes</li> <li>— First channelisation code</li> <li>— Last channelisation code</li> <li>— Bitmap</li> <li>— CHOICE more timeslots</li> <li>— Secondary CCPCH info</li> </ul> |        | <p>TDD</p> <p>1</p> <p><math>(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256</math></p> <p>Infinite</p> <p>Reference to TS34.108 clause 6</p> <p>Reference to TS34.108 clause 6</p> <p>Reference to TS34.108 clause 6</p> <p>1</p> <p>Empty</p> <p>The number of a downlink timeslot that has unassigned codes.</p> <p>TRUE</p> <p>1.28 Mcps</p> <p>Default</p> <p>16</p> <p>1.28 Mcps-TDD</p> <p>QPSK</p> <p>1</p> <p>(i/SF) where i is the lowest numbered code assigned in the timeslot and SF is specified in TS34.108 clause 6 parameter Set.</p> <p>(j/SF) where j is the highest numbered code assigned in the timeslot.</p> <p>Bitmap of the codes assigned in the timeslot.</p> <p>The presence of this IE depends upon the number of resources required by the TS34.108 clause 6 Parameter Set and whether they are assigned using more than one timeslot.</p> <p>Not Present</p> |
| <p>Downlink information common for all radio links</p> <ul style="list-style-type: none"> <li>— Downlink information for each radio link</li> <li>— Choice mode</li> <li>— Primary CCPCH info</li> <li>— CHOICE mode</li> <li>— CHOICE TDD option</li> <li>— TSTD indicator</li> <li>— Cell parameters ID</li> <li>— Block STTD indicator</li> <li>— Downlink DPCH info for each RL</li> <li>— SCCPCH information for FACH</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | A5, A6 | <p>TDD</p> <p>TDD</p> <p>1.28 Mcps-TDD</p> <p>TRUE</p> <p>0</p> <p>FALSE</p> <p>Not present</p> <p>Not present</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

| Condition | Explanation                                                 |
|-----------|-------------------------------------------------------------|
| A1        | This IE need for "Non speech in CS"                         |
| A2        | This IE need for "Speech in CS"                             |
| A3        | This IE need for "Packet to CELL_DCH from CELL_DCH in PS"   |
| A4        | This IE need for "Packet to CELL_DCH from CELL_FACH in PS"  |
| A5        | This IE need for "Packet to CELL_FACH from CELL_DCH in PS"  |
| A6        | This IE need for "Packet to CELL_FACH from CELL_FACH in PS" |

## Contents of UTRAN MOBILITY INFORMATION message: AM or UM

| Information Element                       | Value/remark                                                                                                                                                                                                                             |
|-------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                              |                                                                                                                                                                                                                                          |
| Integrity check info                      | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub IEs as stated below. Else, this IE and the sub IEs are omitted. |
| —— message authentication code            | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                 |
| —— RRC message sequence number            | SS provides the value of this IE, from its internal counter.                                                                                                                                                                             |
| RRC transaction identifier                | Arbitrarily selects an integer between 0 and 3                                                                                                                                                                                           |
| Integrity protection mode info            | Not Present                                                                                                                                                                                                                              |
| Ciphering mode info                       | Not Present                                                                                                                                                                                                                              |
| New U-RNTI                                | See the test content                                                                                                                                                                                                                     |
| New C-RNTI                                | See the test content                                                                                                                                                                                                                     |
| UE Timers and constants in connected mode |                                                                                                                                                                                                                                          |
| —— T301                                   | 2000 milliseconds                                                                                                                                                                                                                        |
| —— N301                                   | 2                                                                                                                                                                                                                                        |
| —— T302                                   | 4000 milliseconds                                                                                                                                                                                                                        |
| —— N302                                   | 3                                                                                                                                                                                                                                        |
| —— T304                                   | 1000 milliseconds                                                                                                                                                                                                                        |
| —— N304                                   | 3                                                                                                                                                                                                                                        |
| —— T305                                   | 60 minutes                                                                                                                                                                                                                               |
| —— T307                                   | 50 seconds                                                                                                                                                                                                                               |
| —— T308                                   | 320 milliseconds                                                                                                                                                                                                                         |
| —— T309                                   | 8 seconds                                                                                                                                                                                                                                |
| —— T310                                   | 320 milliseconds                                                                                                                                                                                                                         |
| —— N310                                   | 5                                                                                                                                                                                                                                        |
| —— T311                                   | 500 milliseconds                                                                                                                                                                                                                         |
| —— T312                                   | 5 seconds                                                                                                                                                                                                                                |
| —— N312                                   | 200                                                                                                                                                                                                                                      |
| —— T313                                   | 10 seconds                                                                                                                                                                                                                               |
| —— N313                                   | 200                                                                                                                                                                                                                                      |
| —— T314                                   | 20 seconds                                                                                                                                                                                                                               |
| —— T315                                   | 30 seconds                                                                                                                                                                                                                               |
| —— N315                                   | 200                                                                                                                                                                                                                                      |
| —— T316                                   | 50 seconds                                                                                                                                                                                                                               |
| —— T317                                   | 1800 seconds                                                                                                                                                                                                                             |
| CN information info                       | Not Present                                                                                                                                                                                                                              |
| URA identity                              | Not present                                                                                                                                                                                                                              |
| Downlink counter synchronisation info     | Not Present                                                                                                                                                                                                                              |

## Contents of UTRAN MOBILITY INFORMATION CONFIRM message: AM

| Information Element                                | Value/remark                                                                                                                                                                                                                                       |
|----------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                       |                                                                                                                                                                                                                                                    |
| RRC transaction identifier                         | Checked to see if it matches the value of the same IE in downlink UTRAN MOBILITY INFORMATION message                                                                                                                                               |
| Integrity check info                               | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub IEs shall be absent. |
| —— Message authentication code                     | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| —— RRC Message sequence number                     | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Uplink integrity protection activation info        | Not checked                                                                                                                                                                                                                                        |
| COUNT-C activation time                            | The presence of this IE depends on the following 2 factors: (a) There exists RB(s) mapped to RLC-TM, (b) UE is transiting to CELL_DCH state after the reconfiguration procedure. Else, this IE is absent.                                          |
| Radio bearer uplink ciphering activation time info | Not checked                                                                                                                                                                                                                                        |
| Uplink counter synchronisation info                | Not checked                                                                                                                                                                                                                                        |



## Contents of RRC CONNECTION REJECT message: UM

| Information Element        | Value/remark                                   |
|----------------------------|------------------------------------------------|
| Message Type               |                                                |
| Initial UE identity        | Set to the UE's IMSI (GSM-MAP) or TMSI.        |
| RRC transaction identifier | Arbitrarily selects an integer between 0 and 3 |
| Rejection cause            | Unspecified                                    |
| Wait Time                  | 0                                              |
| Redirection info           | Not Present                                    |

## Contents of RRC CONNECTION SETUP message: UM (Transition to CELL\_FACH)

| Information Element                                          | Value/remark                                 |
|--------------------------------------------------------------|----------------------------------------------|
| Message Type                                                 |                                              |
| Initial UE identity                                          | Reference to TS34.108 clause 6 Parameter Set |
| RRC transaction identifier                                   | Arbitrarily select a integer between 0 and 3 |
| Activation time                                              | $(256 + CFN - (CFN \bmod 8 + 8)) \bmod 256$  |
| New U-RNTI                                                   |                                              |
| — SRNC identity                                              | 0000-0000-0001B                              |
| — S-RNTI                                                     | 0000-0000-0000-0000-0001B                    |
| New C-RNTI                                                   | 0000-0000-0000-0001B                         |
| RRC state indicator                                          | CELL_FACH                                    |
| UTRAN-DRX cycle length coefficient                           | 5 (2 to 12)                                  |
| Capability update requirement                                |                                              |
| — UE radio access FDD capability update requirement          | FALSE                                        |
| — UE radio access 3.84Mcps TDD capability update requirement | FALSE                                        |
| — UE radio access 1.28Mcps TDD capability update requirement | FALSE                                        |
| — System specific capability update requirement              | Not Present                                  |
| Signalling RB information to setup                           | (UM-DCCH for RRC)                            |
| — RB identity                                                | 1                                            |
| — CHOICE RLC info type                                       | RLC info                                     |
| — CHOICE Uplink RLC mode                                     | UM-RLC                                       |
| — Transmission RLC discard                                   |                                              |
| — SDU discard mode                                           | Max-DAT retransmissions                      |
| — MAX_DAT                                                    | 4                                            |
| — Timer_MRW                                                  | 100                                          |
| — MaxMRW                                                     | 4                                            |
| — CHOICE Downlink RLC mode                                   | UM-RLC                                       |
| — RB mapping info                                            |                                              |
| — Information for each multiplexing option                   |                                              |
| — RLC logical channel mapping indicator                      | Not Present                                  |
| — Number of uplink RLC logical channels                      | 1                                            |
| — Uplink transport channel type                              | RACH                                         |
| — Logical channel identity                                   | 1                                            |
| — CHOICE RLC size list                                       | Explicit list                                |
| — RLC size index                                             | Reference to TS34.108 clause 6 Parameter Set |
| — MAC logical channel priority                               | 2                                            |
| — Downlink RLC logical channel info                          |                                              |
| — Number of downlink RLC logical channels                    | 1                                            |
| — Downlink transport channel type                            | FACH                                         |
| — Logical channel identity                                   | 1                                            |
| Signalling RB information to setup                           | (AM-DCCH for RRC)                            |
| — RB identity                                                | 2                                            |
| — CHOICE RLC info type                                       | RLC info                                     |
| — CHOICE Uplink RLC mode                                     | AM-RLC                                       |
| — Transmission RLC discard                                   |                                              |
| — SDU discard mode                                           | Max-DAT retransmissions                      |
| — MAX_DAT                                                    | 4                                            |
| — Timer_MRW                                                  | 100                                          |
| — MaxMRW                                                     | 4                                            |
| — Transmission window size                                   | 8                                            |
| — Timer_RST                                                  | 500                                          |
| — Max_RST                                                    | 4                                            |
| — Polling info                                               |                                              |
| — Timer_poll_prohibit                                        | 200                                          |
| — Timer_poll                                                 | 200                                          |
| — Poll_SDU                                                   | 1                                            |
| — Last transmission PDU poll                                 | TRUE                                         |
| — Last retransmission PDU poll                               | TRUE                                         |
| — Poll_Windows                                               | 99                                           |
| — CHOICE Downlink RLC mode                                   | AM-RLC                                       |
| — In-sequence delivery                                       | TRUE                                         |
| — Receiving window size                                      | 8                                            |
| — Downlink RLC status info                                   |                                              |
| — Timer_status_prohibit                                      | 200                                          |

|                                            |                                              |
|--------------------------------------------|----------------------------------------------|
| — Timer_EPC                                | 200                                          |
| — Missing PDU indicator                    | TRUE                                         |
| — RB mapping info                          |                                              |
| — Information for each multiplexing option | Not Present                                  |
| — RLC logical channel mapping indicator    | 1                                            |
| — Number of uplink RLC logical channels    | RACH                                         |
| — Uplink transport channel type            | 2                                            |
| — Logical channel identity                 | Explicit list                                |
| — CHOICE RLC size list                     | Reference to TS34.108 clause 6 Parameter Set |
| — RLC size index                           | 3                                            |
| — MAC logical channel priority             |                                              |
| — Downlink RLC logical channel info        | 1                                            |
| — Number of downlink RLC logical channels  | FACH                                         |
| — Downlink transport channel type          | 2                                            |
| — Logical channel identity                 | (AM-DCCH for NAS_DT High priority)           |
| Signalling RB information to setup         | 3                                            |
| — RB identity                              | RLC info                                     |
| — CHOICE RLC info type                     | AM-RLC                                       |
| — CHOICE Uplink RLC mode                   |                                              |
| — Transmission RLC discard                 |                                              |
| — SDU discard mode                         | Max-DAT retransmissions                      |
| — MAX_DAT                                  | 4                                            |
| — Timer_MRW                                | 100                                          |
| — MaxMRW                                   | 4                                            |
| — Transmission window size                 | 8                                            |
| — Timer_RST                                | 500                                          |
| — Max_RST                                  | 4                                            |
| — Polling info                             |                                              |
| — Timer_poll_prohibit                      | 200                                          |
| — Timer_poll                               | 200                                          |
| — Poll_SDU                                 | 1                                            |
| — Last transmission PDU poll               | TRUE                                         |
| — Last retransmission PDU poll             | TRUE                                         |
| — Poll_Windows                             | 99                                           |
| — CHOICE Downlink RLC mode                 | AM-RLC                                       |
| — In-sequence delivery                     | TRUE                                         |
| — Receiving window size                    | 8                                            |
| — Downlink RLC status info                 |                                              |
| — Timer_status_prohibit                    | 200                                          |
| — Timer_EPC                                | 200                                          |
| — Missing PDU indicator                    | TRUE                                         |
| — RB mapping info                          |                                              |
| — Information for each multiplexing option | Not Present                                  |
| — RLC logical channel mapping indicator    | 1                                            |
| — Number of uplink RLC logical channels    | RACH                                         |
| — Uplink transport channel type            | 3                                            |
| — Logical channel identity                 | Explicit list                                |
| — CHOICE RLC size list                     | Reference to TS34.108 clause 6 Parameter Set |
| — RLC size index                           | 4                                            |
| — MAC logical channel priority             |                                              |
| — Downlink RLC logical channel info        | 1                                            |
| — Number of downlink RLC logical channels  | FACH                                         |
| — Downlink transport channel type          | 3                                            |
| — Logical channel identity                 | (AM-DCCH for NAS_DT Low priority)            |
| Signalling RB information to setup         | 4                                            |
| — RB identity                              | RLC info                                     |
| — CHOICE RLC info type                     | AM-RLC                                       |
| — CHOICE Uplink RLC mode                   |                                              |
| — Transmission RLC discard                 |                                              |
| — SDU discard mode                         | Max-DAT retransmissions                      |
| — MAX_DAT                                  | 4                                            |
| — Timer_MRW                                | 100                                          |
| — MaxMRW                                   | 4                                            |
| — Transmission window size                 | 8                                            |
| — Timer_RST                                | 500                                          |
| — Max_RST                                  | 4                                            |
| — Polling info                             |                                              |
| — Timer_poll_prohibit                      | 200                                          |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>— Timer_poll</li> <li>— Poll_SDU</li> <li>— Last transmission PDU poll</li> <li>— Last retransmission PDU poll</li> <li>— Poll_Windows</li> <li>— CHOICE Downlink RLC mode</li> <li>— In-sequence delivery</li> <li>— Receiving window size</li> <li>— Downlink RLC status info</li> <li>— Timer_status_prohibit</li> <li>— Timer_EPC</li> <li>— Missing PDU indicator</li> <li>— RB mapping info</li> <li>— Information for each multiplexing option</li> <li>— RLC logical channel mapping indicator</li> <li>— Number of uplink RLC logical channels</li> <li>— Uplink transport channel type</li> <li>— Logical channel identity</li> <li>— CHOICE RLC size list</li> <li>— RLC size index</li> <li>— MAC logical channel priority</li> <li>— Downlink RLC logical channel info</li> <li>— Number of downlink RLC logical channels</li> <li>— Downlink transport channel type</li> <li>— Logical channel identity</li> </ul> | 200<br>1<br>TRUE<br>TRUE<br>99<br>AM RLC<br>TRUE<br>8<br><br>200<br>200<br>TRUE<br><br>Not Present<br>1<br>RACH<br>4<br>Explicit list<br>Reference to TS34.108 clause 6 Parameter Set<br>5<br><br>1<br>FACH<br>4                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| UL Transport channel information for all transport channels <ul style="list-style-type: none"> <li>— TFC subset</li> <li>— Allowed Transport Format combination</li> <li>— PRACH TFCS</li> <li>— CHOICE mode</li> <li>— UL DCH TFCS</li> </ul> Added or Reconfigured UL TrCH information <ul style="list-style-type: none"> <li>— Transport channel identity</li> <li>— TFS</li> <li>— CHOICE Transport channel type</li> <li>— Dynamic Transport format information</li> <li>— RLC Size</li> <li>— Number of TBs and TTI List</li> <li>— Number of Transport blocks</li> <li>— CHOICE mode</li> <li>— CHOICE Logical Channel List</li> <li>— Semi-static Transport Format information</li> <li>— Transmission time interval</li> <li>— Type of channel coding</li> <li>— Coding Rate</li> <li>— Rate matching attribute</li> <li>— CRC size</li> </ul>                                                                                                                 | (This IE is repeated for TFC number.)<br>0 to MaxTFCValue-1 (MaxTFCValue is refer to TS34.108 clause 6 Parameter Set.)<br>Not Present<br>FDD<br>Not Present<br><br>15<br><br>Common transport channels<br>(This IE is repeated for TFI number)<br>Reference to TS34.108 clause 6 Parameter Set<br>(This IE is repeated for TFI number.)<br>Reference to TS34.108 clause 6 Parameter Set<br>TDD<br>ALL<br><br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set |
| DL Transport channel information common for all transport channel <ul style="list-style-type: none"> <li>— SCCPCH TFCS</li> <li>— CHOICE TFCI signalling</li> <li>— TFCI Field 1 information</li> <li>— CHOICE CTFC representation</li> <li>— TFCS complete reconfigure information</li> <li>— CHOICE CTFC Size</li> <li>— CTFC information</li> <li>— Power offset information</li> <li>— CHOICE DL parameters</li> <li>— DL DCH TFCS</li> </ul> Frequency info <ul style="list-style-type: none"> <li>— UARFCN uplink(Nu)</li> <li>— UARFCN downlink(Nd)</li> </ul> Maximum allowed UL TX power<br>CHOICE channel requirement                                                                                                                                                                                                                                                                                                                                         | (This IE is repeated for TFC number.)<br>Normal<br><br>Complete<br><br>Number of bits used must be enough to cover all combinations of CTFC from clause 6.<br>Refer to TS34.108 clause 6 Parameter Set<br>Not Present<br>Independent<br>Not Present<br><br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>30dBm<br>Not Present                                                                                                                                                                                                                                                                           |

|                                                 |                                                 |
|-------------------------------------------------|-------------------------------------------------|
| Downlink information common for all radio links | Not Present                                     |
| Downlink information for each radio link list   |                                                 |
| → Downlink information for each radio link      |                                                 |
| → Choice mode                                   | TDD                                             |
| → Primary CPICH info                            | Set to the default value of cell 1.             |
| → PDSCH with SHO-DCH info                       | Not Present                                     |
| → PDSCH code mapping                            | Not Present                                     |
| → Downlink DPCH info for each RL                | Not present                                     |
| → Secondary CCPCH info                          |                                                 |
| → Primary CPICH usage for channel estimation    | Primary CPICH may be used                       |
| → Secondary CPICH info                          | Not Present                                     |
| → Secondary scrambling code                     | Not Present                                     |
| → STTD indicator                                | FALSE                                           |
| → Spreading factor                              | Reference to clause 6 Parameter Set             |
| → Code number                                   | SF-1(SF is reference to clause 6 Parameter Set) |
| → Pilot symbol existence                        | FALSE                                           |
| → TFCI existence                                | TRUE                                            |
| → Fixed or Flexible position                    | Flexible                                        |
| → Timing offset                                 | 0                                               |
| → References to system information blocks       | Not present                                     |

#### Contents of RRC STATUS message: AM

| Information Element                | Value/remark                                                                                                                                                                                                                                       |
|------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                       |                                                                                                                                                                                                                                                    |
| Integrity check info               | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| → Message authentication code      | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| → RRC Message sequence number      | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Identification of received message | Not Present                                                                                                                                                                                                                                        |
| → Received message type            |                                                                                                                                                                                                                                                    |
| → RRC transaction identifier       |                                                                                                                                                                                                                                                    |
| Protocol error information         |                                                                                                                                                                                                                                                    |
| → Protocol error cause             | Value will be checked.                                                                                                                                                                                                                             |

#### Contents of SECURITY MODE FAILURE message: AM

| Information Element           | Value/remark                                                                                                                                                                                                                                       |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                  |                                                                                                                                                                                                                                                    |
| RRC transaction identifier    | Checked to see if the value is the identical to the same IE in the downlink SECURITY MODE COMMAND message.                                                                                                                                         |
| Integrity check info          | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| → Message authentication code | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| → RRC Message sequence number | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Failure cause                 | Value will be checked                                                                                                                                                                                                                              |

## Contents of TRANSPORT CHANNEL RECONFIGURATION message: AM or UM

| Information Element                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Condition      | Value/remark                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type<br>RRC transaction identifier<br>Integrity check info<br><br>——— message authentication code<br>——— RRC message sequence number<br><br>Integrity protection mode info<br>Ciphering mode info<br>Activation time<br>New U-RNTI<br>New C-RNTI                                                                                                                                                                                                                                       |                | Arbitrarily selects an integer between 0 and 3<br>The presence of this IE is dependent on IXT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted.<br>SS calculates the value of MAC-I for this message and writes to this IE.<br>SS provides the value of this IE, from its internal counter.<br>Not Present<br>Not Present<br>$(256 + CFN - (CFN \bmod 8 + 8)) \bmod 256$<br>Not Present<br>Not Present |
| RRC State indicator                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | A1, A2, A3, A4 | CELL_DCH                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| RRC State indicator                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | A5, A6         | CELL_DCH should this be CELL_FACH ??? because it indicates the state that is to be entered.                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| UTRAN DRX cycle length coefficient<br>CN information info<br>URA identity<br>Downlink counter synchronisation info                                                                                                                                                                                                                                                                                                                                                                             |                | Not Present<br>Not Present<br>Not Present<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| UL Transport channel information for all transport channels<br>——— PRACH TFCS<br>——— CHOICE mode<br>——— Individual UL CCTrCH information<br>——— TFCS ID<br>——— Shared channel indicator<br>——— UL TFCS<br>——— CHOICE TFCI signalling<br>——— TFCI Field 1 information<br>——— CHOICE TFCS representation<br>——— TFCS addition information<br>——— CHOICE CTFC Size<br>——— CTFC information<br>——— TFC subset<br>——— CHOICE Subset representation<br>——— Allowed Transport Format combination list | A1, A2, A3, A4 | Not Present<br>TDD<br><br>1<br>FALSE<br><br>Normal<br><br>Addition<br><br>Refer to TS34.108 clause 6<br>Refer to TS34.108 clause 6 Parameter Set<br><br>Allowed transport format combination list<br>Refer to TS34.108 clause 6 Parameter Set                                                                                                                                                                                                                                                                                                    |
| UL Transport channel information for all transport channels<br>——— PRACH TFCS<br>——— CHOICE TFCI signalling<br>——— TFCI Field 1 information<br>——— CHOICE TFCS representation<br>——— TFCS addition information<br>——— CHOICE CTFC Size<br>——— CTFC information<br>——— CHOICE mode<br>——— Individual UL CCTrCH information                                                                                                                                                                      | A5, A6         | Normal<br><br>Addition<br><br>Refer to TS34.108 clause 6<br>Refer to TS34.108 clause 6 Parameter Set<br>TDD<br>Not Present                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Added or Reconfigured UL TrCH information<br>——— Uplink transport channel type<br>——— UL Transport channel identity<br>——— TFS<br>——— CHOICE Transport channel type<br>——— Dynamic Transport format information<br>——— RLC Size<br><br>——— Number of TBs and TTI List<br>——— Transmission Time Interval                                                                                                                                                                                        | A1, A2, A3, A4 | DCH<br>5<br><br>Dedicated transport channels<br>(This IE is repeated for TFI number)<br>Reference to TS34.108 clause 6 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present                                                                                                                                                                                                                                                                                                                                                     |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>——&gt; Number of Transport blocks</li> <li>——&gt; CHOICE Logical Channel List</li> <li>——&gt; Semi-static Transport Format information</li> <li>——&gt; Transmission time interval</li> <li>——&gt; Type of channel coding</li> <li>——&gt; Coding Rate</li> <li>——&gt; Rate matching attribute</li> <li>——&gt; CRC size</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                    |                | <p>Reference to TS34.108 clause 6 Parameter Set<br/>ALL</p> <p>Reference to TS34.108 clause 6 Parameter Set<br/>Reference to TS34.108 clause 6 Parameter Set<br/>Reference to TS34.108 clause 6 Parameter Set<br/>Reference to TS34.108 clause 6 Parameter Set<br/>Reference to TS34.108 clause 6 Parameter Set<br/>Reference to TS34.108 clause 6 Parameter Set</p>                                                                                                                                                                                                       |
| <p>Added or Reconfigured UL TrCH information</p> <ul style="list-style-type: none"> <li>——&gt; Uplink transport channel type</li> <li>——&gt; UL Transport channel identity</li> <li>——&gt; TFS</li> <li>——&gt; CHOICE Transport channel type</li> <li>——&gt; Dynamic Transport format information</li> <li>——&gt; RLC Size</li> <li>——&gt; Number of TBs and TTI List</li> <li>——&gt; Transmission Time Interval</li> <li>——&gt; Number of Transport blocks</li> <li>——&gt; CHOICE Logical Channel list</li> <li>——&gt; Semi-static Transport Format information</li> <li>——&gt; Transmission time interval</li> <li>——&gt; Type of channel coding</li> <li>——&gt; Coding Rate</li> <li>——&gt; Rate matching attribute</li> <li>——&gt; CRC size</li> </ul> | A4             | <p>DCH<br/>1</p> <p>Dedicated transport channels<br/>(This IE is repeated for TFI number)<br/>Reference to TS34.108 clause 6 Parameter Set<br/>(This IE is repeated for TFI number.)<br/>Not Present<br/>Reference to TS34.108 clause 6 Parameter Set<br/>ALL</p> <p>Reference to TS34.108 clause 6 Parameter Set<br/>Reference to TS34.108 clause 6 Parameter Set<br/>Reference to TS34.108 clause 6 Parameter Set<br/>Reference to TS34.108 clause 6 Parameter Set<br/>Reference to TS34.108 clause 6 Parameter Set<br/>Reference to TS34.108 clause 6 Parameter Set</p> |
| <p>DL Transport channel information common for all transport channel</p> <ul style="list-style-type: none"> <li>——&gt; SCCPCH TFCS</li> <li>——&gt; CHOICE mode</li> <li>——&gt; Individual DL CCTrCH information</li> <li>——&gt; DL TFCS Identity</li> <li>——&gt; TFCS ID</li> <li>——&gt; Shared Channel Indicator</li> <li>——&gt; CHOICE DL parameters</li> <li>——&gt; DL TFCS</li> <li>——&gt; CHOICE TFCI signalling</li> <li>——&gt; TFCI Field 1 Information</li> <li>——&gt; CHOICE TFCI representation</li> <li>——&gt; TFCS addition information</li> <li>——&gt; CHOICE CTFC size</li> <li>——&gt; CTFC information</li> </ul>                                                                                                                           | A1, A2, A3, A4 | <p>Not Present<br/>TDD</p> <p>1<br/>FALSE</p> <p>Independent</p> <p>Normal</p> <p>Addition</p> <p>Refer to TS34.108 clause 6<br/>Refer to TS34.108 clause 6 Parameter Set</p>                                                                                                                                                                                                                                                                                                                                                                                              |
| <p>DL Transport channel information common for all transport channel</p> <ul style="list-style-type: none"> <li>——&gt; SCCPCH TFCS</li> <li>——&gt; CHOICE mode</li> <li>——&gt; Individual DL CCTrCH information</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | A5, A6         | <p>Not Present<br/>TDD<br/>Not Present</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <p>Added or Reconfigured DL TrCH information</p> <ul style="list-style-type: none"> <li>——&gt; Downlink transport channel type</li> <li>——&gt; DL Transport channel identity</li> <li>——&gt; CHOICE DL parameters</li> <li>——&gt; Uplink transport channel type</li> <li>——&gt; UL TrCH Identity</li> <li>——&gt; DCH quality target</li> <li>——&gt; BLER Quality value</li> </ul>                                                                                                                                                                                                                                                                                                                                                                          | A1, A2         | <p>DCH<br/>10<br/>Same as UL<br/>DCH<br/>5<br/>-6.3</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>Transparent mode signalling info</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |                | Not Present                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <ul style="list-style-type: none"> <li>Added or Reconfigured DL TrCH information <ul style="list-style-type: none"> <li>Downlink transport channel type</li> <li>DL Transport channel identity</li> <li>CHOICE DL parameters</li> </ul> </li> <li>TFS</li> <li>CHOICE Transport channel type</li> <li>Dynamic Transport format information</li> <li>RLC Size</li> <li>Number of TBs and TTI List</li> <li>Transmission Time Interval</li> <li>Number of Transport blocks</li> <li>CHOICE Logical Channel list</li> <li>Semi-static Transport Format information</li> <li>Transmission time interval</li> <li>Type of channel coding</li> <li>Coding Rate</li> <li>Rate matching attribute</li> <li>CRC size</li> <li>DCH quality target</li> <li>BLER Quality value</li> <li>Transparent mode signalling info</li> </ul> | A3, A4         | DCH<br>10<br>Independent<br><br>Dedicated transport channels<br>(This IE is repeated for TFI number)<br>Reference to TS34.108 clause 6 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6 Parameter Set<br>ALL<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>-6.3<br>Not Present                                                |
| <ul style="list-style-type: none"> <li>Added or Reconfigured DL TrCH information <ul style="list-style-type: none"> <li>Downlink transport channel type</li> <li>DL Transport channel identity</li> <li>CHOICE DL parameters</li> </ul> </li> <li>TFS</li> <li>CHOICE Transport channel type</li> <li>Dynamic Transport format information</li> <li>RLC Size</li> <li>Number of TBs and TTI List</li> <li>Transmission Time Interval</li> <li>Number of Transport blocks</li> <li>CHOICE Logical Channel list</li> <li>Semi-static Transport Format information</li> <li>Transmission time interval</li> <li>Type of channel coding</li> <li>Coding Rate</li> <li>Rate matching attribute</li> <li>CRC size</li> <li>DCH quality target</li> <li>BLER Quality value</li> <li>Transparent mode signalling info</li> </ul> | A4             | DCH<br>6<br>Independent<br><br>Dedicated transport channels<br>(This IE is repeated for TFI number)<br>Reference to TS34.108 clause 6 Parameter Set<br>(This IE is repeated for TFI number.)<br>Not Present<br>Reference to TS34.108 clause 6 Parameter Set<br>ALL<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>-6.3<br>Not Present |
| <ul style="list-style-type: none"> <li>Frequency info <ul style="list-style-type: none"> <li>CHOICE mode</li> <li>UARFCN (Nt)</li> </ul> </li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |                | TDD<br>Reference to TS34.108 clause 6                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <ul style="list-style-type: none"> <li>Maximum allowed UL TX power</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                | 30dBm                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <ul style="list-style-type: none"> <li>CHOICE channel requirement <ul style="list-style-type: none"> <li>Uplink DPCH power control info</li> <li>CHOICE mode</li> <li>UL Target SIR</li> <li>CHOICE UL OL PC info</li> </ul> </li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | A1, A2, A3, A4 | Uplink DPCH info<br><br>TDD<br>Reference to TS34.108<br>Individually signalled                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |



|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>----- CHOICE TDD-option</li> <li>----- TPC-step size</li> <li>----- Primary CCPCH Tx Power</li> <li>----- CHOICE mode</li> <li>----- Uplink Timing Advance Control</li> <li>----- UL CCTrCH List</li> <li>----- TFCS ID</li> <li>----- Time info</li> <li>----- Activation time</li> <li>----- Duration</li> <li>----- Common timeslot info</li> <li>----- 2<sup>nd</sup>-interleaving mode</li> <li>----- TFCI coding</li> <li>----- Repetition Period</li> <li>----- Repetition Length</li> <li>----- Uplink DPCH timeslots and codes</li> <li>----- First timeslot information</li> <li>----- CHOICE TDD-option</li> <li>----- Timeslot number</li> <li>----- TFCI-existence</li> <li>----- Midamble shift and burst type</li> <li>----- CHOICE TDD-option</li> <li>----- Midamble Allocation Mode</li> <li>----- Midamble configuration</li> <li>----- CHOICE TDD-option</li> <li>----- Modulation</li> <li>----- SS-TPC Symbols</li> <li>----- First timeslot code list</li> <li>----- Channelisation Code</li> <li>----- CHOICE more timeslots</li> </ul> |                | 1.28 Mcps-TDD<br>1<br>Reference to TS34.108<br>TDD<br>Not Present<br><br>1<br><br>$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$<br>Infinite<br><br>Reference to TS34.108 clause 6 Parameter Set<br>Reference to TS34.108 clause 6 Parameter Set<br>1<br>Empty<br><br>1.28 Mcps<br>The number of an uplink timeslot that has unassigned codes.<br>TRUE<br><br>1.28 Mcps<br>Default<br>16<br>1.28 Mcps<br>QPSK<br>1<br>Repeated (1,2) for each code that is assigned within the timeslot.<br>(i/SF) where i denotes the number of the assigned code and SF is specified in TS34.108 clause 6 Parameter Set.<br>The presence of this IE depends on number of resources specified in TS34.108 section 6 and whether they are assigned in more than one slot. |
| CHOICE Mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                | TDD                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Downlink information common for all radio links <ul style="list-style-type: none"> <li>----- Downlink DPCH info common for all RL</li> <li>----- Timing indicator</li> <li>----- CFN-targetSFN frame offset</li> <li>----- Downlink DPCH power control information</li> <li>----- CHOICE mode</li> <li>----- TPC Step Size</li> <li>----- CHOICE mode</li> <li>----- CHOICE mode</li> <li>----- CHOICE TDD option</li> <li>----- TSTD indicator</li> <li>----- Default DPCH Offset Value</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | A1, A2, A3, A4 | Maintain<br>Not Present<br><br>TDD<br>1<br>TDD<br>TDD<br>1.28 Mcps<br>TRUE<br>0                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Downlink information for each radio link list <ul style="list-style-type: none"> <li>----- Downlink information for each radio links</li> <li>----- CHOICE mode</li> <li>----- Primary CCPCH info</li> <li>----- CHOICE mode</li> <li>----- CHOICE TDD option</li> <li>----- TSTD indicator</li> <li>----- Cell parameters ID</li> <li>----- Block STTD indicator</li> <li>----- Downlink DPCH info for each RL</li> <li>----- CHOICE mode</li> <li>----- DL CCTrCH List</li> <li>----- TFCS ID</li> <li>----- Activation time</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | A1, A2, A3, A4 | TDD<br><br>TDD<br>1.28 Mcps<br>FALSE<br>0<br>FALSE<br><br>TDD<br><br>1<br>$(256 + \text{CFN} - (\text{CFN} \bmod 8 + 8)) \bmod 256$                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

|                                                                                                                                                                                                                                                                                                                                                                                                                                         |        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>→ Duration</li> <li>→ Common timeslot info</li> <li>→ 2<sup>nd</sup> Interleaving mode</li> <li>→ TFCI coding</li> <li>→ Puncturing limit</li> <li>→ Repetition period</li> <li>→ Repetition length</li> <li>→ Downlink DPCH timeslots and codes</li> <li>→ Individual timeslot info</li> <li>→ Timeslot number</li> </ul>                                                                       |        | <p>Infinite</p> <p>Reference to TS34.108 clause 6</p> <p>Reference to TS34.108 clause 6</p> <p>Reference to TS34.108 clause 6</p> <p>1</p> <p>Empty</p> <p>The number of a downlink timeslot that has unassigned codes.</p> <p>TRUE</p>                                                                                                                                                                                                                           |
| <ul style="list-style-type: none"> <li>→ TFCI existence</li> <li>→ Midamble shift and burst type</li> <li>→ CHOICE TDD option</li> <li>→ Midamble allocation mode</li> <li>→ Midamble configuration</li> <li>→ CHOICE TDD option</li> <li>→ Modulation</li> <li>→ SS-TPC Symbols</li> <li>→ First timeslot channelisation codes</li> <li>→ First channelisation code</li> </ul>                                                         |        | <p>1.28 Mcps</p> <p>Default</p> <p>16</p> <p>1.28 Mcps TDD</p> <p>QPSK</p> <p>1</p>                                                                                                                                                                                                                                                                                                                                                                               |
| <ul style="list-style-type: none"> <li>→ Last channelisation code</li> <li>→ Bitmap</li> <li>→ CHOICE more timeslots</li> </ul>                                                                                                                                                                                                                                                                                                         |        | <p>(i/SF) where i is the lowest numbered code assigned within the slot and SF is specified in the TS34.108 clause 6 Parameter Set.</p> <p>(j/SF) where j is the highest numbered code assigned in the timeslot.</p> <p>Bitmap of codes assigned in the timeslot.</p> <p>The presence of this IE depends upon the number of resources required by the TS34.108 clause 6 Parameter Set and whether they are allocated in more than one slot.</p> <p>Not Present</p> |
| <ul style="list-style-type: none"> <li>→ Secondary CCPCH info</li> </ul>                                                                                                                                                                                                                                                                                                                                                                |        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <ul style="list-style-type: none"> <li>→ Downlink information for each radio link list</li> <li>→ Downlink information for each radio link</li> <li>→ Choice mode</li> <li>→ Primary CCPCH info</li> <li>→ CHOICE mode</li> <li>→ CHOICE TDD option</li> <li>→ TSTD indicator</li> <li>→ Cell parameters ID</li> <li>→ Block STTD indicator</li> <li>→ Downlink DPCH info for each RL</li> <li>→ SCCPCH information for FACH</li> </ul> | A5, A6 | <p>TDD</p> <p>Set to the default value of cell 1.</p> <p>TDD</p> <p>1.28 Mcps TDD</p> <p>TRUE</p> <p>0</p> <p>TRUE</p> <p>Not present</p> <p>Not present</p>                                                                                                                                                                                                                                                                                                      |

| Condition | Explanation                                                 |
|-----------|-------------------------------------------------------------|
| A1        | This IE need for "Non-speech in CS"                         |
| A2        | This IE need for "Speech in CS"                             |
| A3        | This IE need for "Packet to CELL_DCH from CELL_DCH in PS"   |
| A4        | This IE need for "Packet to CELL_DCH from CELL_FACH in PS"  |
| A5        | This IE need for "Packet to CELL_FACH from CELL_DCH in PS"  |
| A6        | This IE need for "Packet to CELL_FACH from CELL_FACH in PS" |

## Contents of TRANSPORT CHANNEL RECONFIGURATION COMPLETE message: AM

| Information Element                                | Value/remark                                                                                                                                                                                                                                       |
|----------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                       |                                                                                                                                                                                                                                                    |
| RRC transaction identifier                         | Checked to see if the value is identical to the same IE in the downlink TRANSPORT CHANNEL RECONFIGURATION message                                                                                                                                  |
| Integrity check info                               | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| — Message authentication code                      | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| — RRC Message sequence number                      | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| Uplink integrity protection activation info        | Not checked                                                                                                                                                                                                                                        |
| CHOICE mode                                        | TDD                                                                                                                                                                                                                                                |
| — CHOICE TDD option                                | 1.28 Mcps                                                                                                                                                                                                                                          |
| COUNT-C activation time                            | The presence of this IE depends on the following 2 factors: (a) There exists RB(s) mapped to RLC-TM and (b) UE is transiting to CELL_DCH state after the reconfiguration procedure. Else, this IE is absent.                                       |
| Radio bearer uplink ciphering activation time info | Not checked                                                                                                                                                                                                                                        |
| Uplink counter synchronisation info                | Not checked                                                                                                                                                                                                                                        |

## Contents of TRANSPORT FORMAT COMBINATION CONTROL message: AM or UM (in CELL\_DCH)

| Information Element                                  | Value/remark                                                                                                                                                                                                                             |
|------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                         |                                                                                                                                                                                                                                          |
| RRC transaction identifier                           | Arbitrarily selects an integer between 0 and 3                                                                                                                                                                                           |
| Integrity check info                                 | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| — Message authentication code                        | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                 |
| — RRC Message sequence number                        | SS provides the value of this IE, from its internal counter.                                                                                                                                                                             |
| CHOICE mode                                          | TDD                                                                                                                                                                                                                                      |
| — TFCS Id                                            | 1                                                                                                                                                                                                                                        |
| — Shared Channel Indicator                           | FALSE                                                                                                                                                                                                                                    |
| DPCH TFCS in Uplink                                  |                                                                                                                                                                                                                                          |
| — Minimum allowed Transport format combination index | 0 (The TFC is constructed from ALL TF0)                                                                                                                                                                                                  |

## Contents of UE CAPABILITY ENQUIRY message: AM or UM

| Information Element                                            | Value/remark                                                                                                                                                                                                                                                                                                       |
|----------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                                                   | Arbitrarily selects an integer between 0 and 3                                                                                                                                                                                                                                                                     |
| RRC transaction identifier                                     |                                                                                                                                                                                                                                                                                                                    |
| Integrity check info                                           | The presence of this IE is dependent on I-XIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. SS calculates the value of MAC-I for this message and writes to this IE. |
| —→ Message authentication code                                 |                                                                                                                                                                                                                                                                                                                    |
| —→ RRC Message sequence number                                 | SS provides the value of this IE, from its internal counter.                                                                                                                                                                                                                                                       |
| Capability update requirement                                  |                                                                                                                                                                                                                                                                                                                    |
| —→ UE radio access FDD capability update requirement           | FALSE                                                                                                                                                                                                                                                                                                              |
| —→ UE radio access 3.84 Mcps TDD capability update requirement | FALSE                                                                                                                                                                                                                                                                                                              |
| —→ UE radio access 1.28 Mcps TDD capability update requirement | TRUE                                                                                                                                                                                                                                                                                                               |
| —→ System specific capability update requirement list          | UE only supports 1 system                                                                                                                                                                                                                                                                                          |
| —→ System specific capability update requirement               | GSM                                                                                                                                                                                                                                                                                                                |

## Contents of UE CAPABILITY INFORMATION message: AM

| Information Element                     | Value/remark                                                                                                                                                                                                                                        |
|-----------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                            | Checked to see if the value is identical to the same IE in the downlink UE CAPABILITY ENQUIRY message.                                                                                                                                              |
| RRC transaction identifier              |                                                                                                                                                                                                                                                     |
| Integrity check info                    | The presence of this IE is dependent on I-XIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| —→ Message authentication code          |                                                                                                                                                                                                                                                     |
| —→ RRC Message sequence number          | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS. This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                         |
| UE radio access capability              |                                                                                                                                                                                                                                                     |
| —→ ICS Version                          | Value will be checked. Stated capability must be compatible with 34.123-2 (ICS statements) and the user settings                                                                                                                                    |
| —→ PDCP Capability                      |                                                                                                                                                                                                                                                     |
| —→ RLC Capability                       |                                                                                                                                                                                                                                                     |
| —→ Transport channel capability         |                                                                                                                                                                                                                                                     |
| —→ RF Capability                        |                                                                                                                                                                                                                                                     |
| —→ Physical channel capability          |                                                                                                                                                                                                                                                     |
| —→ UE multi-mode/multi-RAT capability   |                                                                                                                                                                                                                                                     |
| —→ Security capability                  |                                                                                                                                                                                                                                                     |
| —→ UE positioning capability            |                                                                                                                                                                                                                                                     |
| —→ Measurement capability               |                                                                                                                                                                                                                                                     |
| UE system specific capability           | Choice and value will be checked. UE must include the classmark information for the supported RAT                                                                                                                                                   |
| —→ Inter-RAT UE radio access capability |                                                                                                                                                                                                                                                     |

## Contents of UE CAPABILITY INFORMATION CONFIRM message: UM

| Information Element            | Value/remark                                                                                                                                                                                                                                                                                                       |
|--------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                   | The presence of this IE is dependent on I-XIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub-IEs as stated below. Else, this IE and the sub-IEs are omitted. SS calculates the value of MAC-I for this message and writes to this IE. |
| Integrity check info           |                                                                                                                                                                                                                                                                                                                    |
| —→ Message authentication code | SS provides the value of this IE, from its internal counter.                                                                                                                                                                                                                                                       |
| —→ RRC Message sequence number |                                                                                                                                                                                                                                                                                                                    |

## Contents of URA UPDATE message: TM

| Information Element            | Value/remark                                                                                                                                                                                                                                       |
|--------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                   |                                                                                                                                                                                                                                                    |
| U-RNTI                         |                                                                                                                                                                                                                                                    |
| —— SRNC identity               | 0000-0000-0001B                                                                                                                                                                                                                                    |
| —— S-RNTI                      | 0000-0000-0000-0000-0001B                                                                                                                                                                                                                          |
| RRC transaction identifier     | Checked to see if it is absent                                                                                                                                                                                                                     |
| Integrity check info           | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE shall be present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs shall be absent. |
| —— Message authentication code | This IE is checked to see if it is present. The value is compared against the XMAC-I value computed by SS.                                                                                                                                         |
| —— RRC Message sequence number | This IE is checked to see if it is present. The value is used by SS to compute the XMAC-I value.                                                                                                                                                   |
| URA update cause               | See the test content                                                                                                                                                                                                                               |
| Protocol error indicator       | Checked to see if it is absent or set to 'FALSE'                                                                                                                                                                                                   |
| Protocol error information     | Checked to see if it is absent                                                                                                                                                                                                                     |

## Contents of URA UPDATE CONFIRM message: UM

| Information Element                   | Value/remark                                                                                                                                                                                                                             |
|---------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message Type                          |                                                                                                                                                                                                                                          |
| U-RNTI                                | If this message is sent on CCCH, use the following values. Else, this IE is absent.                                                                                                                                                      |
| —— SRNC identity                      | 0000-0000-0001B                                                                                                                                                                                                                          |
| —— S-RNTI                             | 0000-0000-0000-0000-0001B                                                                                                                                                                                                                |
| RRC transaction identifier            | Arbitrarily selects and integer between 0 and 3                                                                                                                                                                                          |
| Integrity check info                  | The presence of this IE is dependent on IXIT statements in TS 34.123-2. If integrity protection is indicated to be active, this IE is present with the values of the sub IEs as stated below. Else, this IE and the sub-IEs are omitted. |
| —— message authentication code        | SS calculates the value of MAC-I for this message and writes to this IE.                                                                                                                                                                 |
| —— RRC message sequence number        | SS provides the value of this IE, from its internal counter.                                                                                                                                                                             |
| Integrity protection mode info        | Not Present                                                                                                                                                                                                                              |
| Ciphering mode info                   | Not Present                                                                                                                                                                                                                              |
| New U-RNTI                            | Not Present                                                                                                                                                                                                                              |
| New C-RNTI                            | Not Present                                                                                                                                                                                                                              |
| RRC state indicator                   | URA_PCH                                                                                                                                                                                                                                  |
| UTRAN DRX cycle length coefficient    | Not Present                                                                                                                                                                                                                              |
| CN information info                   | Not Present                                                                                                                                                                                                                              |
| URA identity                          | See the test content                                                                                                                                                                                                                     |
| Downlink counter synchronisation info | Not Present                                                                                                                                                                                                                              |

## Annex B (informative): (void)Core specification versions to which test cases relate

The table B.1 lists for each clause of the present document the related core specification version on which the test cases were based. Where the test cases have been partially updated towards the next released version, but this work has not completed yet, each change request considered is listed in the final column.

**Table B.1**

| Clause number | Clause heading                                               | Related core specifications | Current R99 version supported | Current Rel-4 version supported | Current change requests taken into account |
|---------------|--------------------------------------------------------------|-----------------------------|-------------------------------|---------------------------------|--------------------------------------------|
| 6             | Idle mode operations                                         | 25.304                      | 3.7.0                         |                                 |                                            |
|               |                                                              | 23.122                      | 3.7.0                         |                                 |                                            |
|               |                                                              | 31.102                      | 3.6.0                         |                                 |                                            |
|               |                                                              | 25.133                      | 3.6.0                         |                                 |                                            |
|               |                                                              | 25.123                      | 3.6.0                         |                                 |                                            |
|               |                                                              | TS 03.22                    | 8.5.0                         |                                 |                                            |
|               |                                                              | TS 05.08                    | 8.10.0                        |                                 |                                            |
| 7.1           | MAG                                                          | 25.321                      | 3.8.0                         |                                 |                                            |
| 7.2           | RLC                                                          | 25.322                      | 3.7.0                         |                                 |                                            |
| 7.3           | PDCP                                                         | 25.323                      | 3.5.0                         |                                 |                                            |
| 7.4           | BMC                                                          | 25.324                      | 3.4.0                         |                                 |                                            |
| 8             | Radio Resource Control (RRC)                                 | 25.331                      | 3.7.0                         |                                 |                                            |
|               |                                                              | 04.18                       | 9.0.0                         |                                 |                                            |
| 9             | Elementary procedures of mobility management                 | 24.008                      | 3.8.0                         |                                 |                                            |
| 10            | Circuit Switched Call Control (CC)                           | 24.008                      | 3.7.0                         |                                 |                                            |
| 11            | Session Management Procedures                                | 24.008                      | 3.8.0                         |                                 |                                            |
| 12            | Elementary procedure for Packet Switched Mobility Management | 24.008                      | 3.8.0                         |                                 |                                            |
| 13            | General Tests                                                | 24.008                      | 3.8.0                         |                                 |                                            |
| 14            | Radio Bearer Services                                        | 34.108                      | 3.5.0                         |                                 |                                            |
| 15            | Supplementary Services                                       | N/A                         |                               |                                 |                                            |
| 16            | Short message service (SMS)                                  | 23.040                      | 3.5.0                         |                                 |                                            |
|               |                                                              | 23.041                      | 3.4.0                         |                                 |                                            |
|               |                                                              | 24.011                      | 3.6.0                         |                                 |                                            |
| 17            | User Equipment features (MMI, VHE, MexE, SAT)                |                             |                               |                                 |                                            |

## Annex C (informative): Change history

| Meeting<br>-1st-<br>Level | Doc-1st-Level | CR  | Rev | Subject                                                                                                        | Cat | Version<br>-<br>Current | Version<br>-New | Doc-2nd-<br>Level |
|---------------------------|---------------|-----|-----|----------------------------------------------------------------------------------------------------------------|-----|-------------------------|-----------------|-------------------|
| TP-08                     |               |     |     | Approval of the specification                                                                                  |     | 2.0.0                   | 3.0.0           |                   |
| TP-09                     | TP-000135     | 001 |     | Idle mode test cases                                                                                           | F   | 3.0.0                   | 3.1.0           | T1-000165         |
| TP-09                     | TP-000135     | 002 |     | Section 8, RRC Tests: RLCSize                                                                                  | C   | 3.0.0                   | 3.1.0           | T1-000169         |
| TP-09                     | TP-000135     | 003 |     | Section 8, RRC Tests: HFN                                                                                      | C   | 3.0.0                   | 3.1.0           | T1-000170         |
| TP-09                     | TP-000135     | 004 |     | Section 8, RRC Tests: RLCParam                                                                                 | C   | 3.0.0                   | 3.1.0           | T1-000171         |
| TP-09                     | TP-000135     | 005 |     | Section 8, RRC Tests: RBIdentity                                                                               | C   | 3.0.0                   | 3.1.0           | T1-000172         |
| TP-09                     | TP-000135     | 006 |     | Section 8, RRC Tests: TrCHParam                                                                                | C   | 3.0.0                   | 3.1.0           | T1-000173         |
| TP-09                     | TP-000135     | 007 |     | Section 8, RRC Tests: UECapability                                                                             | C   | 3.0.0                   | 3.1.0           | T1-000174         |
| TP-09                     | TP-000135     | 008 |     | Section 8, RRC Tests: RBMapping                                                                                | C   | 3.0.0                   | 3.1.0           | T1-000175         |
| TP-09                     | TP-000135     | 009 |     | Section 8, RRC Tests: PagingCause                                                                              | C   | 3.0.0                   | 3.1.0           | T1-000176         |
| TP-09                     | TP-000135     | 010 |     | Section 8, RRC Tests: RRCConnRelease-TM                                                                        | B   | 3.0.0                   | 3.1.0           | T1-000177         |
| TP-09                     | TP-000135     | 011 |     | Section 8, RRC Tests: SignallingRelease                                                                        | B   | 3.0.0                   | 3.1.0           | T1-000178         |
| TP-09                     | TP-000135     | 012 |     | Section 8, RRC Tests: CipheringAndIntegrity                                                                    | C   | 3.0.0                   | 3.1.0           | T1-000179         |
| TP-09                     | TP-000135     | 013 |     | Section 8, RRC Tests: Countercheck_rev                                                                         | B   | 3.0.0                   | 3.1.0           | T1-000180         |
| TP-09                     | TP-000135     | 014 |     | Section 8, RRC Tests: RLCInfo                                                                                  | C   | 3.0.0                   | 3.1.0           | T1-000181         |
| TP-09                     | TP-000135     | 015 |     | Section 8, RRC Tests: CompressedMode                                                                           | C   | 3.0.0                   | 3.1.0           | T1-000182         |
| TP-09                     | TP-000135     | 016 |     | Section 8, RRC Tests: SIB                                                                                      | F   | 3.0.0                   | 3.1.0           | T1-000183         |
| TP-09                     | TP-000135     | 017 |     | Section 8, RRC Tests: PhyCH                                                                                    | D   | 3.0.0                   | 3.1.0           | T1-000184         |
| TP-09                     | TP-000135     | 018 |     | Section 8, RRC Tests: Measurement                                                                              | C   | 3.0.0                   | 3.1.0           | T1-000185         |
| TP-09                     | TP-000135     | 019 |     | Section 8, RRC Tests: FailureCases                                                                             | C   | 3.0.0                   | 3.1.0           | T1-000186         |
| TP-09                     | TP-000135     | 020 |     | Section 8, RRC Tests: TFCS                                                                                     | C   | 3.0.0                   | 3.1.0           | T1-000187         |
| TP-09                     | TP-000135     | 021 |     | Section 8, RRC Tests: DPCHFrameOffset                                                                          | C   | 3.0.0                   | 3.1.0           | T1-000188         |
| TP-09                     | TP-000135     | 022 |     | Section 8, RRC Tests: ReEstablishmentTimer                                                                     | C   | 3.0.0                   | 3.1.0           | T1-000189         |
| TP-09                     | TP-000135     | 023 |     | Section 8, RRC Tests: InterFrequencyHardHandOver                                                               | F   | 3.0.0                   | 3.1.0           | T1-000206         |
| TP-09                     | TP-000135     | 024 |     | clause 12.4.1.5 "Routing area updating / abnormal cases / attempt counter check / miscellaneous reject causes" | C   | 3.0.0                   | 3.1.0           | T1-000211         |
| TP-09                     | TP-000135     | 025 |     | SM test cases                                                                                                  | C   | 3.0.0                   | 3.1.0           | T1-000208         |
| TP-09                     | TP-000135     | 026 |     | MM: Authentication                                                                                             | F   | 3.0.0                   | 3.1.0           | T1-000207         |
| TP-09                     | TP-000135     | 027 |     | Update of radio bearer test cases (aligned to GSMA ISG version 1.3)                                            | F   | 3.0.0                   | 3.1.0           | T1-000213         |
| TP-09                     | TP-000135     | 028 |     | MAC tests                                                                                                      | B   | 3.0.0                   | 3.1.0           | T1-000218         |
| TP-09                     | TP-000135     | 029 |     | PDPC tests                                                                                                     | B   | 3.0.0                   | 3.1.0           | T1-000166         |
| TP-09                     | TP-000135     | 030 |     | BMC tests                                                                                                      | B   | 3.0.0                   | 3.1.0           | T1-000167         |
| TP-09                     | TP-000135     | 031 |     | RRC updates                                                                                                    | F   | 3.0.0                   | 3.1.0           | T1-000168         |
| TP-09                     | TP-000135     | 032 |     | clause 12.6.1.2 "Authentication rejected"                                                                      | F   | 3.0.0                   | 3.1.0           | T1-000210         |
| TP-09                     | TP-000135     | 033 |     | clause 12.6 "PS authentication and ciphering"                                                                  | C   | 3.0.0                   | 3.1.0           | T1-000209         |
| TP-10                     | TP-000218     | 034 |     | Application of integrity mode protection to signalling message by default                                      | F   | 3.1.0                   | 3.2.0           | T1-000297         |
| TP-10                     | TP-000218     | 035 |     | New test cases for CS intersystem handover                                                                     | B   | 3.1.0                   | 3.2.0           | T1-000300         |
| TP-10                     | TP-000218     | 036 |     | CR to 34.123-1, Annex B, Mapping of test cases to core specification versions                                  | D   | 3.1.0                   | 3.2.0           | T1-000319         |
| TP-10                     | TP-000218     | 037 |     | Application of ciphering during conformance testing and changes to integrity mode protection related messages  | C   | 3.1.0                   | 3.2.0           | T1-000286         |
| TP-10                     | TP-000218     | 038 |     | Idle Mode test cases in chapter 6                                                                              | F   | 3.1.0                   | 3.2.0           | T1-000288         |
| TP-10                     | TP-000218     | 039 |     | Update to RLC test cases                                                                                       | F   | 3.1.0                   | 3.2.0           | T1-000301         |
| TP-10                     | TP-000218     | 040 |     | Technical Corrections to RRC test cases in clause 8                                                            | F   | 3.1.0                   | 3.2.0           | T1-000292         |
| TP-10                     | TP-000218     | 041 |     | Updates to clause 8 and Annex A due to RAN2 core specifications modifications                                  | C   | 3.1.0                   | 3.2.0           | T1-000293         |
| TP-10                     | TP-000218     | 042 |     | Editorial modification for CC test cases (Clause 10)                                                           | D   | 3.1.0                   | 3.2.0           | T1-000289         |
| TP-10                     | TP-000218     | 043 |     | Update of radio bearer test cases                                                                              | F   | 3.1.0                   | 3.2.0           | T1-000290         |
| TP-10                     | TP-000218     | 044 |     | Update of Session Management test cases                                                                        | B   | 3.1.0                   | 3.2.0           | T1-000298         |
| TP-10                     | TP-000218     | 045 |     | Modification to the "Authentication rejected by the UE" test case                                              | F   | 3.1.0                   | 3.2.0           | T1-000308         |
| TP-10                     | TP-000218     | 046 |     | Update to 16. SMS test specification                                                                           | F   | 3.1.0                   | 3.2.0           | T1-000309         |
| TP-10                     | TP-000218     | 047 |     | Correction to MM tests                                                                                         | D   | 3.1.0                   | 3.2.0           | T1-000310         |
| TP-11                     | TP-010021     | 048 |     | Idle mode test cases                                                                                           | F   | 3.2.0                   | 3.3.0           | T1-010076         |
| TP-11                     | TP-010021     | 049 |     | Updates to clause 8 of TS 34.123-1 version 3.2.0                                                               | F   | 3.2.0                   | 3.3.0           | T1-010106         |
| TP-11                     | TP-010021     | 050 |     | Update to GMM test case.                                                                                       | F   | 3.2.0                   | 3.3.0           | T1-010086         |
| TP-11                     | TP-010021     | 051 |     | Update to 16. SMS test specification                                                                           | D   | 3.2.0                   | 3.3.0           | T1-010090         |
| TP-11                     | TP-010021     | 052 |     | Annex B: Update of versions of core specifications                                                             | F   | 3.2.0                   | 3.3.0           | T1-010091         |
| TP-12                     | TP-010121     | 053 |     | Idle mode tests                                                                                                | F   | 3.3.0                   | 3.4.0           | T1-010167         |
| TP-12                     | TP-010121     | 054 |     | Clause 7.2: Update of RLC tests to 25.322 v3.5.0                                                               | F   | 3.3.0                   | 3.4.0           | T1-010170         |
| TP-12                     | TP-010121     | 055 |     | Corrections to Clause 7.2: RLC test case updates                                                               | F   | 3.3.0                   | 3.4.0           | T1-010171         |
| TP-12                     | TP-010121     | 056 |     | Corrections to clause 7.3 PDPC                                                                                 | F   | 3.3.0                   | 3.4.0           | T1-010173         |

| Meeting<br>-1st-<br>Level | Doc-1st-Level | CR  | Rev | Subject                                                                                         | Cat | Version<br>-<br>Current | Version<br>-New | Doc-2nd-<br>Level |
|---------------------------|---------------|-----|-----|-------------------------------------------------------------------------------------------------|-----|-------------------------|-----------------|-------------------|
| TP-12                     | TP-010121     | 057 |     | Corrections to clause 7.4 BMC                                                                   | F   | 3.3.0                   | 3.4.0           | T1-010174         |
| TP-12                     | TP-010121     | 058 |     | 7.1 Update to MAC test cases                                                                    | F   | 3.3.0                   | 3.4.0           | T1-010175         |
| TP-12                     | TP-010121     | 059 |     | Modifications to the functional testing of CPCH related UE test cases                           | C   | 3.3.0                   | 3.4.0           | T1-010176         |
| TP-12                     | TP-010121     | 060 |     | Transmission RLC discard                                                                        | F   | 3.3.0                   | 3.4.0           | T1-010178         |
| TP-12                     | TP-010121     | 061 |     | Updates to RRC test case                                                                        | F   | 3.3.0                   | 3.4.0           | T1-010179         |
| TP-12                     | TP-010121     | 062 |     | Deletion of intersystem handover tests GERAN to UTRAN                                           | F   | 3.3.0                   | 3.4.0           | T1-010181         |
| TP-12                     | TP-010121     | 063 |     | Corrections to CC test cases                                                                    | F   | 3.3.0                   | 3.4.0           | T1-010183         |
| TP-12                     | TP-010121     | 064 |     | Corrections to Emergency call test cases                                                        | F   | 3.3.0                   | 3.4.0           | T1-010184         |
| TP-12                     | TP-010121     | 065 |     | Corrections to test of autocalling restrictions                                                 | F   | 3.3.0                   | 3.4.0           | T1-010185         |
| TP-12                     | TP-010121     | 066 |     | Corrections to call re-establishment tests in CC                                                | F   | 3.3.0                   | 3.4.0           | T1-010187         |
| TP-12                     | TP-010121     | 067 |     | MM test case update                                                                             | F   | 3.3.0                   | 3.4.0           | T1-010189         |
| TP-12                     | TP-010121     | 068 |     | CR to 34.123-1                                                                                  | F   | 3.3.0                   | 3.4.0           | T1-010193         |
| TP-12                     | TP-010121     | 069 |     | SMS Update                                                                                      | F   | 3.3.0                   | 3.4.0           | T1-010194         |
| TP-12                     | TP-010121     | 070 |     | SMS test specification                                                                          | F   | 3.3.0                   | 3.4.0           | T1-010196         |
| TP-12                     | TP-010121     | 071 |     | Update to GMM test cases                                                                        | F   | 3.3.0                   | 3.4.0           | T1-010235         |
| TP-12                     | TP-010121     | 072 |     | GMM service request test cases                                                                  | F   | 3.3.0                   | 3.4.0           | T1-010236         |
| TP-12                     | TP-010121     | 073 |     | GMM authentication reject test cases                                                            | F   | 3.3.0                   | 3.4.0           | T1-010237         |
| TP-12                     | TP-010121     | 074 |     | Modifications to Clause 12 (GMM)                                                                | F   | 3.3.0                   | 3.4.0           | T1-010202         |
| TP-12                     | TP-010121     | 075 |     | Correction in test case 11.1, because of problems in core-specs                                 | F   | 3.3.0                   | 3.4.0           | T1-010203         |
| TP-12                     | TP-010121     | 076 |     | Procedure and Expected Sequence Corrections to 11.1.2.                                          | F   | 3.3.0                   | 3.4.0           | T1-010204         |
| TP-12                     | TP-010121     | 077 |     | Adding section for multi-layer functional testing                                               | D   | 3.3.0                   | 3.4.0           | T1-010207         |
| TP-12                     | TP-010121     | 078 |     | Update of interoperability radio bearer test cases                                              | F   | 3.3.0                   | 3.4.0           | T1-010208         |
| TP-12                     | TP-010121     | 079 |     | CR to TS 34.123-1 Update of Table B/1                                                           | D   | 3.3.0                   | 3.4.0           | T1-010217         |
| TP-13                     | TP-010186     | 080 |     | Parameters update and Editorial corrections in clauses 7.2.3.1, 7.2.3.2.1, 7.2.3.2.3, 7.2.3.2.4 | F   | 3.4.0                   | 3.5.0           | T1-010292         |
| TP-13                     | TP-010186     | 081 |     | Corrections to Clause 13 General Tests                                                          | F   | 3.4.0                   | 3.5.0           | T1-010293         |
| TP-13                     | TP-010186     | 082 |     | Modification in "Method of Test" for RBS test cases in Clause 14                                | F   | 3.4.0                   | 3.5.0           | T1-010294         |
| TP-13                     | TP-010186     | 083 |     | Editorial modification for References                                                           | F   | 3.4.0                   | 3.5.0           | T1-010295         |
| TP-13                     | TP-010186     | 084 |     | Clause 7.3, PDCP tests                                                                          | F   | 3.4.0                   | 3.5.0           | T1-010378         |
| TP-13                     | TP-010186     | 085 |     | Idle mode: Merge of T1S-010180 and 188                                                          | F   | 3.4.0                   | 3.5.0           | T1-010297         |
| TP-13                     | TP-010186     | 086 |     | clause 7.4 BMC: editorial correction                                                            | F   | 3.4.0                   | 3.5.0           | T1-010379         |
| TP-13                     | TP-010186     | 087 |     | Clause 7.1, MAC test cases                                                                      | F   | 3.4.0                   | 3.5.0           | T1-010299         |
| TP-13                     | TP-010186     | 088 |     | Corrections to RLC test case 7.2.2.2                                                            | F   | 3.4.0                   | 3.5.0           | T1-010300         |
| TP-13                     | TP-010186     | 089 |     | Corrections to RLC test case 7.2.2.3                                                            | F   | 3.4.0                   | 3.5.0           | T1-010301         |
| TP-13                     | TP-010186     | 090 |     | Corrections to RLC test case 7.2.2.8                                                            | F   | 3.4.0                   | 3.5.0           | T1-010302         |
| TP-13                     | TP-010186     | 091 |     | Corrections to RLC test case 7.2.2.10                                                           | F   | 3.4.0                   | 3.5.0           | T1-010303         |
| TP-13                     | TP-010186     | 092 |     | Corrections to RLC test case 7.2.2.9                                                            | F   | 3.4.0                   | 3.5.0           | T1-010304         |
| TP-13                     | TP-010186     | 093 |     | Corrections to RLC test case 7.2.2.12                                                           | F   | 3.4.0                   | 3.5.0           | T1-010305         |
| TP-13                     | TP-010186     | 094 |     | Corrections to RLC test case 7.2.2.29                                                           | F   | 3.4.0                   | 3.5.0           | T1-010306         |
| TP-13                     | TP-010186     | 095 |     | Corrections to RLC test case 7.2.2.30                                                           | F   | 3.4.0                   | 3.5.0           | T1-010307         |
| TP-13                     | TP-010186     | 096 |     | Corrections to RLC test case 7.2.2.33                                                           | F   | 3.4.0                   | 3.5.0           | T1-010308         |
| TP-13                     | TP-010186     | 097 |     | Corrections to RLC test case 7.2.2.34                                                           | F   | 3.4.0                   | 3.5.0           | T1-010309         |
| TP-13                     | TP-010186     | 098 |     | Updates to clause 8 and Annex A                                                                 | F   | 3.4.0                   | 3.5.0           | T1-010310         |
| TP-13                     | TP-010186     | 099 |     | RRC tests (section 8)                                                                           | F   | 3.4.0                   | 3.5.0           | T1-010311         |
| TP-13                     | TP-010186     | 100 |     | InterSystemHandover tests (section 8.3.7)                                                       | F   | 3.4.0                   | 3.5.0           | T1-010312         |
| TP-13                     | TP-010186     | 101 |     | Update on Mobility Management                                                                   | F   | 3.4.0                   | 3.5.0           | T1-010313         |
| TP-13                     | TP-010186     | 102 |     | Addition of a SM test case for UE in GSM                                                        | F   | 3.4.0                   | 3.5.0           | T1-010314         |
| TP-13                     | TP-010186     | 103 |     | Clause 12 "Elementary procedure for Packet Switched Mobility Management"(GMM)                   | F   | 3.4.0                   | 3.5.0           | T1-010315         |
| TP-13                     | TP-010186     | 104 |     | Update of radio bearer test cases                                                               | F   | 3.4.0                   | 3.5.0           | T1-010316         |
| TP-13                     | TP-010186     | 105 |     | SMS test specification                                                                          | F   | 3.4.0                   | 3.5.0           | T1-010317         |
| TP-13                     | TP-010186     | 106 |     | RACH Test Procedures for 1.28 Mcps TDD (Rel-4)                                                  | F   | 3.4.0                   | 4.0.0           | T1-010318         |
| TP-13                     | TP-010186     | 107 |     | Corrections to RLC test case 7.2.2.14                                                           | F   | 3.4.0                   | 3.5.0           | T1-010319         |
| TP-13                     | TP-010186     | 108 |     | Corrections to RLC test case 7.2.2.7 and 7.2.2.13                                               | F   | 3.4.0                   | 3.5.0           | T1-010320         |
| TP-13                     | TP-010186     | 109 |     | RLC acknowledge mode test cases 7.2.3.14 and 7.2.3.34                                           | F   | 3.4.0                   | 3.5.0           | T1-010321         |
| TP-13                     | TP-010186     | 110 |     | Merging of Rel4 and R99 protocol test specifications                                            | F   | 3.4.0                   | 4.0.0           | T1-010272         |
| TP-13                     | TP-010189     | 112 |     | Update of Annex B                                                                               | F   | 3.4.0                   | 3.5.0           | ----              |
| TP-14                     | TP-010261     | 113 |     | Clause 7.3: PDCP testing: additional configuration information                                  | F   | 4.0.0                   | 4.1.0           | T1-010406         |
| TP-14                     | TP-010261     | 114 |     | Clause 7.4: BMC testing: update for BMC testing                                                 | F   | 4.0.0                   | 4.1.0           | T1-010407         |
| TP-14                     | TP-010261     | 115 |     | Clause 7.2: Update of UM and AM RLC test cases                                                  | F   | 4.0.0                   | 4.1.0           | T1-010408         |
| TP-14                     | TP-010261     | 116 |     | Idle mode tests (34.123-1)                                                                      | F   | 4.0.0                   | 4.1.0           | T1-010409         |
| TP-14                     | TP-010261     | 117 |     | Removal of TBD Power Levels in section 6                                                        | F   | 4.0.0                   | 4.1.0           | T1-010410         |
| TP-14                     | TP-010261     | 118 |     | Idle Mode Test Parameters for Multi-mode environment (2G/3G) TDD                                | F   | 4.0.0                   | 4.1.0           | T1-010411         |
| TP-14                     | TP-010261     | 119 |     | Traffic Volume Measurement test cases (34.123-1 section 8.4)                                    | F   | 4.0.0                   | 4.1.0           | T1-010412         |
| TP-14                     | TP-010261     | 120 |     | New interRAT test cases                                                                         | F   | 4.0.0                   | 4.1.0           | T1-010413         |



| Meeting<br>-1st-<br>Level | Doc-1st-Level | CR  | Rev | Subject                                                                                                           | Cat | Version<br>-<br>Current | Version<br>-New | Doc-2nd-<br>Level |
|---------------------------|---------------|-----|-----|-------------------------------------------------------------------------------------------------------------------|-----|-------------------------|-----------------|-------------------|
| TP-14                     | TP-010261     | 121 |     | Corrections to Annex A                                                                                            | F   | 4.0.0                   | 4.1.0           | T1-010414         |
| TP-14                     | TP-010261     | 122 |     | Clause 12 Packet Switched Mobility Management                                                                     | F   | 4.0.0                   | 4.1.0           | T1-010415         |
| TP-14                     | TP-010261     | 123 |     | Update to GMM test cases                                                                                          | F   | 4.0.0                   | 4.1.0           | T1-010416         |
| TP-14                     | TP-010261     | 124 |     | Update of interoperability radio bearer test cases for FDD.                                                       | F   | 4.0.0                   | 4.1.0           | T1-010417         |
| TP-14                     | TP-010261     | 125 |     | Update to SMS test specification                                                                                  | F   | 4.0.0                   | 4.1.0           | T1-010418         |
| TP-14                     | TP-010261     | 126 |     | Corrections to RRC test cases                                                                                     | F   | 4.0.0                   | 4.1.0           | T1-010419         |
| TP-14                     | TP-010261     | 127 |     | RRC Connection Management Procedure Tests for the TDD options                                                     | F   | 4.0.0                   | 4.1.0           | T1-010420         |
| TP-14                     | TP-010261     | 128 |     | Annex A Default RRC Message Contents for 1.28Mcps TDD Mode                                                        | F   | 4.0.0                   | 4.1.0           | T1-010421         |
| TP-14                     | TP-010261     | 129 |     | Radio Bearer Tests for 1.28 Mcps TDD Mode                                                                         | F   | 4.0.0                   | 4.1.0           | T1-010422         |
| TP-15                     | TP-020041     | 130 |     | Correction to Annex A                                                                                             | F   | 4.1.0                   | 4.2.0           | T1-020037         |
| TP-15                     | TP-020041     | 131 |     | Update of Idle mode tests                                                                                         | F   | 4.1.0                   | 4.2.0           | T1-020038         |
| TP-15                     | TP-020041     | 132 |     | Update to GMM test cases                                                                                          | F   | 4.1.0                   | 4.2.0           | T1-020039         |
| TP-15                     | TP-020041     | 133 |     | Corrections to RRC test cases, 8.2.2 onwards                                                                      | F   | 4.1.0                   | 4.2.0           | T1-020040         |
| TP-15                     | TP-020041     | 134 |     | Corrections to Annex A                                                                                            | F   | 4.1.0                   | 4.2.0           | T1-020041         |
| TP-15                     | TP-020041     | 135 |     | Clause 7.3, PDCP testing: Update                                                                                  | F   | 4.1.0                   | 4.2.0           | T1-020042         |
| TP-15                     | TP-020041     | 136 |     | Corrections to clause 8.1                                                                                         | F   | 4.1.0                   | 4.2.0           | T1-020043         |
| TP-15                     | TP-020041     | 137 |     | Correction to RRC test cases                                                                                      | F   | 4.1.0                   | 4.2.0           | T1-020044         |
| TP-15                     | TP-020041     | 138 |     | Corrections to Measurement test cases                                                                             | F   | 4.1.0                   | 4.2.0           | T1-020045         |
| TP-15                     | TP-020042     | 139 |     | Additional test case for packet                                                                                   | F   | 4.1.0                   | 4.2.0           | T1-020046         |
| TP-15                     | TP-020041     | 140 |     | Changes to MAC conformance test 7.1.1.1                                                                           | F   | 4.1.0                   | 4.2.0           | T1-020047         |
| TP-15                     | TP-020041     | 141 |     | Changes to MAC conformance test 7.1.1.2                                                                           | F   | 4.1.0                   | 4.2.0           | T1-020048         |
| TP-15                     | TP-020041     | 142 |     | Changes to MAC conformance test 7.1.1.3                                                                           | F   | 4.1.0                   | 4.2.0           | T1-020049         |
| TP-15                     | TP-020041     | 143 |     | Changes to MAC conformance test 7.1.1.4                                                                           | F   | 4.1.0                   | 4.2.0           | T1-020050         |
| TP-15                     | TP-020041     | 144 |     | Changes to MAC conformance test 7.1.1.5                                                                           | F   | 4.1.0                   | 4.2.0           | T1-020051         |
| TP-15                     | TP-020041     | 145 |     | Changes to MAC conformance test 7.1.1.8                                                                           | F   | 4.1.0                   | 4.2.0           | T1-020052         |
| TP-15                     | TP-020041     | 146 |     | Changes to MAC conformance test 7.1.2.2.1                                                                         | F   | 4.1.0                   | 4.2.0           | T1-020053         |
| TP-15                     | TP-020041     | 147 |     | Changes to MAC conformance test 7.1.2.4                                                                           | F   | 4.1.0                   | 4.2.0           | T1-020054         |
| TP-15                     | TP-020041     | 148 |     | Changes to MAC conformance test 7.1.2.5                                                                           | F   | 4.1.0                   | 4.2.0           | T1-020055         |
| TP-15                     | TP-020041     | 149 |     | Changes to MAC conformance test 7.1.3.1                                                                           | F   | 4.1.0                   | 4.2.0           | T1-020056         |
| TP-15                     | TP-020041     | 150 |     | Changes to RLC conformance test 7.2.3.20                                                                          | F   | 4.1.0                   | 4.2.0           | T1-020057         |
| TP-15                     | TP-020041     | 151 |     | Changes to RLC conformance test 7.2.3.25                                                                          | F   | 4.1.0                   | 4.2.0           | T1-020058         |
| TP-15                     | TP-020041     | 152 |     | Modifications on Session Management test case 11.1.1.1                                                            | F   | 4.1.0                   | 4.2.0           | T1-020059         |
| TP-15                     | TP-020041     | 153 |     | Modifications on Session Management test case 11.1.2                                                              | F   | 4.1.0                   | 4.2.0           | T1-020060         |
| TP-15                     | TP-020041     | 154 |     | Section 8.1 Connection Management Procedure (TDD both modes)                                                      | F   | 4.1.0                   | 4.2.0           | T1-020061         |
| TP-15                     | TP-020041     | 155 |     | Modification on Session Management test case 11.1.3.2                                                             | F   | 4.1.0                   | 4.2.0           | T1-020062         |
| TP-15                     | TP-020041     | 156 |     | Modifications of MM test cases                                                                                    | F   | 4.1.0                   | 4.2.0           | T1-020063         |
| TP-15                     | TP-020042     | 157 |     | Update of RB test cases                                                                                           | F   | 4.1.0                   | 4.2.0           | T1-020064         |
| TP-15                     | TP-020041     | 158 |     | Section 8.2 Radio Bearer Control Procedure (TDD both modes)                                                       | F   | 4.1.0                   | 4.2.0           | T1-020065         |
| TP-15                     | TP-020041     | 159 |     | Correction of MAC conformance test 7.1.2.1.1                                                                      | F   | 4.1.0                   | 4.2.0           | T1-020089         |
| TP-15                     | TP-020041     | 160 |     | Correction of MAC conformance test 7.1.2.3.1                                                                      | F   | 4.1.0                   | 4.2.0           | T1-020090         |
| TP-15                     | TP-020042     | 161 |     | Additional Measurement Control and Report test cases                                                              | F   | 4.1.0                   | 4.2.0           | T1-020111         |
| TP-15                     | TP-020042     | 162 |     | Clause 8.4.1 Measurement Control and Report                                                                       | F   | 4.1.0                   | 4.2.0           | T1-020112         |
| TP-15                     | TP-020042     | 163 |     | Additional test cases for inter-RAT measurements and UE internal measurements                                     | F   | 4.1.0                   | 4.2.0           | T1-020113         |
| TP-15                     | TP-020042     | 164 |     | Addition of test case for Inter-RAT measurement, event 3C, in CELL_DCH state using sparse compressed mode pattern | F   | 4.1.0                   | 4.2.0           | T1-020114         |
| TP-15                     | TP-020042     | 165 |     | Clause 6.1.2.8 Cell reselection : Equivalent PLMN                                                                 | F   | 4.1.0                   | 4.2.0           | T1-020115         |
| TP-15                     | TP-020042     | 166 |     | Additional test cases for shared networks                                                                         | F   | 4.1.0                   | 4.2.0           | T1-020116         |
| TP-15                     | TP-020042     | 167 |     | Deletion of Equivalent PLMN list in UE                                                                            | F   | 4.1.0                   | 4.2.0           | T1-020117         |
| TP-15                     | TP-020042     | 168 |     | ePLMN list storage at power off                                                                                   | F   | 4.1.0                   | 4.2.0           | T1-020118         |
| TP-15                     | TP-020042     | 169 |     | Interaction of ePLMNs and forbidden PLMNs                                                                         | F   | 4.1.0                   | 4.2.0           | T1-020119         |
| TP-15                     | TP-020042     | 170 |     | PLMN interaction with Manual Mode                                                                                 | F   | 4.1.0                   | 4.2.0           | T1-020120         |
| TP-15                     | TP-020042     | 171 |     | Clause 8.3 HCS cell reselection                                                                                   | F   | 4.1.0                   | 4.2.0           | T1-020121         |
| TP-15                     | TP-020042     | 172 |     | Clause 8.3.7.13 Inter system handover from UTRAN/To GSM/ success / call under establishment                       | F   | 4.1.0                   | 4.2.0           | T1-020122         |
| TP-15                     | TP-020042     | 173 |     | Additional test cases for Physical Channel Reconfiguration from CELL_FACH to CELL_PCH or URA_PCH                  | F   | 4.1.0                   | 4.2.0           | T1-020123         |
| TP-15                     | TP-020042     | 174 |     | Additional test cases for Transport channel Reconfiguration from CELL_FACH to CELL_PCH or URA_PCH                 | F   | 4.1.0                   | 4.2.0           | T1-020124         |
| TP-15                     | TP-020042     | 175 |     | Additional test case for RRC connection establishment on another frequency                                        | F   | 4.1.0                   | 4.2.0           | T1-020125         |
| TP-15                     | TP-020042     | 176 |     | Additional test case for UE response to changes of System Information data and structure                          | F   | 4.1.0                   | 4.2.0           | T1-020126         |

**3rd Generation Partnership Project;  
Technical Specification Group Terminals;  
User Equipment (UE) conformance specification;  
Part 1: Protocol conformance specification  
(Release 4)**



The present document has been developed within the 3<sup>rd</sup> Generation Partnership Project (3GPP™) and may be further elaborated for the purposes of 3GPP.

The present document has not been subject to any approval process by the 3GPP Organisational Partners and shall not be implemented. This Specification is provided for future development work within 3GPP only. The Organisational Partners accept no liability for any use of this Specification. Specifications and reports for implementation of the 3GPP™ system should be obtained via the 3GPP Organisational Partners' Publications Offices.

---

---

**Keywords**

mobile, MS, terminal, testing, UMTS

---

**3GPP**

---

**Postal address**

---

**3GPP support office address**

650 Route des Lucioles - Sophia Antipolis  
Valbonne - FRANCE  
Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

---

**Internet**

<http://www.3gpp.org>

---

**Copyright Notification**

No part may be reproduced except as authorized by written permission.  
The copyright and the foregoing restriction extend to reproduction in all media.

© 2002, 3GPP Organizational Partners (ARIB, CWTS, ETSI, T1, TTA, TTC).  
All rights reserved.

# Contents

|                                                                                               |    |
|-----------------------------------------------------------------------------------------------|----|
| Foreword.....                                                                                 | 22 |
| Introduction .....                                                                            | 22 |
| 1 Scope .....                                                                                 | 23 |
| 2 References .....                                                                            | 23 |
| 3 Definitions and abbreviations.....                                                          | 25 |
| 3.1 Definitions .....                                                                         | 25 |
| 3.2 Abbreviations .....                                                                       | 25 |
| 4 Overview .....                                                                              | 25 |
| 4.1 Test Methodology.....                                                                     | 25 |
| 4.1.1 Testing of optional functions and procedures .....                                      | 25 |
| 4.1.2 Test interfaces and facilities.....                                                     | 25 |
| 4.2 Implicit Testing .....                                                                    | 25 |
| 5 Reference Conditions .....                                                                  | 25 |
| 5.1 Generic setup procedures .....                                                            | 26 |
| 6 Idle mode operations .....                                                                  | 26 |
| 6.1 In a pure 3GPP environment .....                                                          | 29 |
| 6.1.1 PLMN selection and reselection .....                                                    | 29 |
| 6.1.1.1 PLMN selection of RPLMN, HPLMN, UPLMN and OPLMN; Manual mode .....                    | 29 |
| 6.1.1.2 PLMN selection of "Other PLMN / access technology combinations"; Manual mode.....     | 32 |
| 6.1.1.3 PLMN selection; independence of RF level and preferred PLMN; Manual mode .....        | 35 |
| 6.1.1.4 PLMN selection of RPLMN, HPLMN, UPLMN and OPLMN; Automatic mode .....                 | 38 |
| 6.1.1.5 PLMN selection of "Other PLMN / access technology combinations"; Automatic mode ..... | 40 |
| 6.1.1.6 UE will transmit only if PLMN available .....                                         | 43 |
| 6.1.1.7 Cell reselection of ePLMN in manual mode .....                                        | 44 |
| 6.1.2 Cell selection and reselection.....                                                     | 45 |
| 6.1.2.1 Cell reselection.....                                                                 | 45 |
| 6.1.2.2 Cell reselection using Qhyst, Qoffset and Treselection .....                          | 47 |
| 6.1.2.3 HCS Cell reselection .....                                                            | 50 |
| 6.1.2.4 HCS Cell reselection using reselection timing parameters for the H criterion.....     | 52 |
| 6.1.2.5 HCS Cell reselection using reselection timing parameters for the R criterion .....    | 55 |
| 6.1.2.6 Emergency calls .....                                                                 | 57 |
| 6.1.2.7 Emergency calls; Intra-frequency cell "Not allowed" .....                             | 59 |
| 6.1.2.8 Cell reselection: Equivalent PLMN .....                                               | 61 |
| 6.2 Multi-mode environment (2G/3G case).....                                                  | 63 |
| 6.2.1 PLMN and RAT selection and reselection.....                                             | 63 |
| 6.2.1.1 Selection of the correct PLMN and associated RAT.....                                 | 63 |
| 6.2.1.2 Selection of RAT for HPLMN; Manual mode .....                                         | 65 |
| 6.2.1.3 Selection of RAT for UPLMN; Manual mode .....                                         | 67 |
| 6.2.1.4 Selection of RAT for OPLMN; Manual mode .....                                         | 69 |
| 6.2.1.5 Selection of "Other PLMN / access technology combinations"; Manual mode .....         | 71 |
| 6.2.1.6 Selection of RAT for HPLMN; Automatic mode .....                                      | 74 |
| 6.2.1.7 Selection of RAT for UPLMN; Automatic mode .....                                      | 77 |
| 6.2.1.8 Selection of RAT for OPLMN; Automatic mode .....                                      | 78 |
| 6.2.1.9 Selection of "Other PLMN / access technology combinations"; Automatic mode .....      | 80 |
| 6.2.2 Cell selection and reselection.....                                                     | 82 |
| 6.2.2.1 Cell reselection if cell becomes barred or $S < 0$ ; UTRAN to GSM .....               | 82 |
| 6.2.2.2 Cell reselection if cell becomes barred or $C1 < 0$ ; GSM to UTRAN .....              | 85 |
| 6.2.2.3 Cell reselection timings; GSM to UTRAN .....                                          | 87 |
| 7 Layer 2.....                                                                                | 90 |
| 7.1 MAC.....                                                                                  | 90 |
| 7.1.1 Mapping between logical channels and transport channels .....                           | 90 |

|           |                                                                                               |     |
|-----------|-----------------------------------------------------------------------------------------------|-----|
| 7.1.1.1   | CCCH mapped to RACH/FACH / Invalid TCTF .....                                                 | 90  |
| 7.1.1.2   | DTCH or DCCH mapped to RACH/FACH / Invalid TCTF .....                                         | 94  |
| 7.1.1.3   | DTCH or DCCH mapped to RACH/FACH / Invalid C/T Field .....                                    | 97  |
| 7.1.1.4   | DTCH or DCCH mapped to RACH/FACH / Invalid UE ID Type Field .....                             | 99  |
| 7.1.1.5   | DTCH or DCCH mapped to RACH/FACH / Incorrect UE ID .....                                      | 102 |
| 7.1.1.6   | DTCH or DCCH mapped to DSCH or USCH .....                                                     | 104 |
| 7.1.1.7   | DTCH or DCCH mapped to CPCH .....                                                             | 106 |
| 7.1.1.8   | DTCH or DCCH mapped to DCH / Invalid C/T Field.....                                           | 109 |
| 7.1.2     | RACH/FACH procedures .....                                                                    | 113 |
| 7.1.2.1   | Selection and control of Power Level .....                                                    | 113 |
| 7.1.2.1.1 | Selection and control of Power Level (FDD) .....                                              | 113 |
| 7.1.2.1.2 | Selection and control of Power Level (3,84 Mcps TDD option) .....                             | 116 |
| 7.1.2.1.3 | Selection and control of Power Level (1,28 Mcps TDD option) .....                             | 116 |
| 7.1.2.2   | Correct application of Dynamic Persistence .....                                              | 117 |
| 7.1.2.2.1 | Correct application of Dynamic Persistence (FDD) .....                                        | 117 |
| 7.1.2.2.2 | Correct application of Dynamic Persistence (3.84 Mcps TDD option).....                        | 119 |
| 7.1.2.2.3 | Correct application of Dynamic Persistence (1.28 Mcps TDD option).....                        | 119 |
| 7.1.2.3   | Correct Selection of RACH parameters .....                                                    | 120 |
| 7.1.2.3.1 | Correct Selection of RACH parameters (FDD) .....                                              | 120 |
| 7.1.2.3.2 | Correct Selection of RACH parameters (3.84 Mcps TDD option).....                              | 124 |
| 7.1.2.3.3 | Correct Selection of RACH parameters (1.28 Mcps TDD option).....                              | 124 |
| 7.1.2.4   | Correct Detection and Response to FPACH (1.28 Mcps TDD option).....                           | 125 |
| 7.1.2.4a  | Access Service class selection for RACH transmission.....                                     | 128 |
| 7.1.2.5   | Control of RACH transmissions for FDD mode .....                                              | 131 |
| 7.1.3     | Priority handling between data flows of one UE .....                                          | 132 |
| 7.1.3.1   | Priority handling between data flows of one UE.....                                           | 132 |
| 7.1.4     | Control of CPCH transmissions.....                                                            | 134 |
| 7.1.4.1   | Control of CPCH transmissions for FDD.....                                                    | 134 |
| 7.2       | RLC testing.....                                                                              | 141 |
| 7.2.1     | Transparent mode .....                                                                        | 141 |
| 7.2.1.1   | Segmentation and reassembly .....                                                             | 141 |
| 7.2.2     | Unacknowledged mode.....                                                                      | 141 |
| 7.2.2.1   | General information for UM tests .....                                                        | 141 |
| 7.2.2.2   | Segmentation and reassembly / Selection of 7 or 15 bit Length Indicators.....                 | 142 |
| 7.2.2.3   | Segmentation and reassembly / 7-bit Length Indicators / Padding .....                         | 143 |
| 7.2.2.4   | Segmentation and Reassembly / 7-bit Length Indicators / LI = 0 .....                          | 144 |
| 7.2.2.5   | Reassembly / 7-bit Length Indicators / Invalid LI value .....                                 | 145 |
| 7.2.2.6   | Reassembly / 7-bit Length Indicators / LI value > PDU size.....                               | 146 |
| 7.2.2.7   | Reassembly / 7-bit Length Indicators / First data octet LI .....                              | 147 |
| 7.2.2.8   | Segmentation and reassembly / 15-bit Length Indicators / Padding .....                        | 149 |
| 7.2.2.9   | Segmentation and Reassembly / 15-bit Length Indicators / LI = 0 .....                         | 150 |
| 7.2.2.10  | Segmentation and reassembly / 15-bit Length Indicators / One octet short LI .....             | 151 |
| 7.2.2.11  | Reassembly / 15-bit Length Indicators / Invalid LI value .....                                | 152 |
| 7.2.2.12  | Reassembly / 15-bit Length Indicators / LI value > PDU size.....                              | 153 |
| 7.2.2.13  | Reassembly / 15-bit Length Indicators / First data octet LI .....                             | 154 |
| 7.2.3     | Acknowledged mode .....                                                                       | 155 |
| 7.2.3.1   | General information for AM tests .....                                                        | 155 |
| 7.2.3.2   | Segmentation and reassembly / Selection of 7 or 15 bit Length Indicators.....                 | 156 |
| 7.2.3.3   | Segmentation and Reassembly / 7-bit Length Indicators / Padding or Piggy-backed Status .....  | 157 |
| 7.2.3.4   | Segmentation and Reassembly / 7-bit Length Indicators / LI = 0 .....                          | 159 |
| 7.2.3.5   | Reassembly / 7-bit Length Indicators / Reserved LI value.....                                 | 160 |
| 7.2.3.6   | Reassembly / 7-bit Length Indicators / LI value > PDU size .....                              | 161 |
| 7.2.3.7   | Segmentation and Reassembly / 15-bit Length Indicators / Padding or Piggy-backed Status ..... | 163 |
| 7.2.3.8   | Segmentation and Reassembly / 15-bit Length Indicators / LI = 0 .....                         | 164 |
| 7.2.3.9   | Segmentation and reassembly / 15-bit Length Indicators / One octet short LI .....             | 165 |
| 7.2.3.10  | Reassembly / 15-bit Length Indicators / Reserved LI value.....                                | 167 |
| 7.2.3.11  | Reassembly / 15-bit Length Indicators / LI value > PDU size .....                             | 168 |
| 7.2.3.12  | Correct use of Sequence Numbering.....                                                        | 169 |
| 7.2.3.13  | Control of Transmit Window .....                                                              | 170 |
| 7.2.3.14  | Control of Receive Window.....                                                                | 173 |

|           |                                                                                                                       |     |
|-----------|-----------------------------------------------------------------------------------------------------------------------|-----|
| 7.2.3.15  | Polling for status / Last PDU in transmission queue .....                                                             | 174 |
| 7.2.3.16  | Polling for status / Last PDU in retransmission queue .....                                                           | 175 |
| 7.2.3.17  | Polling for status / Poll every Poll_PDU PDUs .....                                                                   | 177 |
| 7.2.3.18  | Polling for status / Poll every Poll_SDU SDUs .....                                                                   | 179 |
| 7.2.3.19  | Polling for status / Timer triggered polling (Timer_Poll_Periodic) .....                                              | 181 |
| 7.2.3.20  | Polling for status / Polling on Poll_Window% of transmission window .....                                             | 182 |
| 7.2.3.21  | Polling for status / Operation of Timer_Poll timer / Timer expiry .....                                               | 184 |
| 7.2.3.22  | Polling for status / Operation of Timer_Poll timer / Stopping Timer_Poll timer .....                                  | 186 |
| 7.2.3.23  | Polling for status / Operation of Timer_Poll timer / Restart of the Timer_Poll timer .....                            | 187 |
| 7.2.3.24  | Polling for status / Operation of timer Timer_Poll_Prohibit .....                                                     | 189 |
| 7.2.3.25  | Receiver Status Triggers / Detection of missing PDUs .....                                                            | 190 |
| 7.2.3.26  | Receiver Status Triggers / Operation of timer Timer_Status_Periodic .....                                             | 192 |
| 7.2.3.27  | Receiver Status Triggers / Operation of timer Timer_Status_Prohibit .....                                             | 193 |
| 7.2.3.28  | Status reporting / Abnormal conditions / Reception of LIST SUFI with Length set to zero .....                         | 194 |
| 7.2.3.29  | Timer based discard, with explicit signalling / Expiry of Timer_Discard .....                                         | 196 |
| 7.2.3.29a | Timer based discard, with explicit signalling / Expiry of Timer_Discard when<br>Timer_STATUS_prohibit is active ..... | 198 |
| 7.2.3.30  | Timer based discard, with explicit signalling / Obsolete MRW_ACK .....                                                | 198 |
| 7.2.3.31  | Timer based discard, with explicit signalling / Failure of MRW procedure .....                                        | 200 |
| 7.2.3.32  | SDU discard after MaxDAT number of retransmissions .....                                                              | 202 |
| 7.2.3.33  | Operation of the RLC Reset procedure / UE Originated .....                                                            | 204 |
| 7.2.3.34  | Operation of the RLC Reset procedure / UE Terminated .....                                                            | 206 |
| 7.3       | PDCP .....                                                                                                            | 208 |
| 7.3.1     | General .....                                                                                                         | 208 |
| 7.3.1.1   | General assumptions .....                                                                                             | 208 |
| 7.3.1.2   | Common Test sequences and Default message contents for PDCP .....                                                     | 208 |
| 7.3.1.2.1 | Common Test sequences for PDCP .....                                                                                  | 208 |
| 7.3.1.2.2 | Default PDCP Message Contents .....                                                                                   | 211 |
| 7.3.2     | IP Header Compression and PID assignment .....                                                                        | 213 |
| 7.3.2.1   | UE in RLC AM .....                                                                                                    | 213 |
| 7.3.2.1.1 | Transmission of uncompressed Header .....                                                                             | 213 |
| 7.3.2.1.2 | Transmission of compressed Header .....                                                                               | 220 |
| 7.3.2.2   | UE in RLC UM .....                                                                                                    | 228 |
| 7.3.2.2.1 | Transmission of uncompressed Header .....                                                                             | 228 |
| 7.3.2.2.2 | Transmission of compressed Header .....                                                                               | 236 |
| 7.3.2.2.3 | Extension of used compression methods .....                                                                           | 243 |
| 7.3.2.2.4 | Compression type used for different entities .....                                                                    | 249 |
| 7.3.2.2.5 | Reception of not defined PID values .....                                                                             | 255 |
| 7.3.3     | PDCP sequence numbering when lossless SRNS Relocation .....                                                           | 258 |
| 7.3.3.1   | Data transmission if lossless SRNS Relocation is supported .....                                                      | 258 |
| 7.3.3.2   | Synchronisation of PDCP sequence numbers .....                                                                        | 264 |
| 7.4       | BMC .....                                                                                                             | 268 |
| 7.4.1     | BMC RAB + SRBs for CCCH + SRB for DCCH + SRB for BCCH .....                                                           | 268 |
| 7.4.1.1   | Transport channel parameters of BMC RAB and SRBs for CCCH, SRB for DCCH, and SRB for<br>BCCH .....                    | 268 |
| 7.4.1.2   | TFCS .....                                                                                                            | 268 |
| 7.4.1.3   | Physical channel parameters .....                                                                                     | 269 |
| 7.4.2     | General BMC message reception .....                                                                                   | 269 |
| 7.4.2.1   | UE in RRC Idle mode .....                                                                                             | 269 |
| 7.4.2.2   | UE in RRC Connected mode, state CELL_PCH .....                                                                        | 271 |
| 7.4.2.3   | UE in RRC Connected mode, state URA_PCH .....                                                                         | 273 |
| 7.4.2.4   | UE in RRC Idle mode (ANSI-41 CB data) .....                                                                           | 276 |
| 7.4.2.5   | UE in RRC Connected mode, state CELL_PCH (ANSI-41 CB data) .....                                                      | 278 |
| 7.4.2.6   | UE in RRC Connected mode, state URA_PCH (ANSI-41 CB data) .....                                                       | 281 |
| 7.4.3     | BMC message reception procedure .....                                                                                 | 283 |
| 7.4.3.1   | Reception of certain CBS message types .....                                                                          | 283 |
| 8         | Radio Resource Control RRC .....                                                                                      | 289 |
| 8.1       | RRC Connection Management Procedure .....                                                                             | 289 |
| 8.1.1     | Paging .....                                                                                                          | 289 |
| 8.1.1.1   | Paging for Connection in idle mode .....                                                                              | 289 |

|          |                                                                                                                                                             |     |
|----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|
| 8.1.1.2  | Paging for Connection in connected mode (CELL_PCH) .....                                                                                                    | 291 |
| 8.1.1.3  | Paging for Connection in connected mode (URA_PCH) .....                                                                                                     | 293 |
| 8.1.1.4  | Paging for Notification in idle mode .....                                                                                                                  | 295 |
| 8.1.1.5  | Paging for Notification in connected mode (CELL_PCH).....                                                                                                   | 297 |
| 8.1.1.6  | Paging for Notification in connected mode (URA_PCH).....                                                                                                    | 300 |
| 8.1.1.7  | Paging for Connection in connected mode (CELL_DCH).....                                                                                                     | 302 |
| 8.1.1.8  | Paging for Connection in connected mode (CELL_FACH).....                                                                                                    | 304 |
| 8.1.2    | RRC Connection Establishment.....                                                                                                                           | 305 |
| 8.1.2.1  | RRC Connection Establishment in CELL_DCH state: Success.....                                                                                                | 305 |
| 8.1.2.2  | RRC Connection Establishment: Success after T300 timeout .....                                                                                              | 306 |
| 8.1.2.3  | RRC Connection Establishment: Failure (V300 is greater than N300).....                                                                                      | 319 |
| 8.1.2.4  | RRC Connection Establishment: Reject ("wait time" is not equal to 0).....                                                                                   | 320 |
| 8.1.2.5  | RRC Connection Establishment: Reject ("wait time" is not equal to 0 and V300 is greater than N300) .....                                                    | 323 |
| 8.1.2.6  | RRC Connection Establishment: Reject ("wait time" is set to 0).....                                                                                         | 325 |
| 8.1.2.7  | RRC Connection Establishment in CELL_FACH state: Success .....                                                                                              | 327 |
| 8.1.2.8  | Void.....                                                                                                                                                   | 328 |
| 8.1.2.9  | RRC Connection Establishment: Success after Physical channel failure and Invalid configuration ..                                                           | 328 |
| 8.1.3    | RRC Connection Release.....                                                                                                                                 | 331 |
| 8.1.3.1  | RRC Connection Release in CELL_DCH state: Success.....                                                                                                      | 331 |
| 8.1.3.2  | RRC Connection Release using on DCCH in CELL_FACH state: Success .....                                                                                      | 333 |
| 8.1.3.3  | RRC Connection Release using on CCCH in CELL_FACH state: Success .....                                                                                      | 334 |
| 8.1.3.4  | RRC Connection Release in CELL_FACH state: Failure.....                                                                                                     | 335 |
| 8.1.3.5  | RRC Connection Release in CELL_FACH state: Invalid message .....                                                                                            | 336 |
| 8.1.4    | Void .....                                                                                                                                                  | 341 |
| 8.1.5    | UE capability .....                                                                                                                                         | 341 |
| 8.1.5.1  | UE Capability in CELL_DCH state: Success .....                                                                                                              | 341 |
| 8.1.5.2  | UE Capability in CELL_DCH state: Success after T304 timeout.....                                                                                            | 343 |
| 8.1.5.3  | UE Capability in CELL_DCH state: Failure (After N304 re-transmissions).....                                                                                 | 344 |
| 8.1.5.4  | UE Capability in CELL_FACH state: Success .....                                                                                                             | 347 |
| 8.1.5.5  | UE Capability in CELL_FACH state: Success after T304 timeout.....                                                                                           | 350 |
| 8.1.6    | Direct Transfer.....                                                                                                                                        | 351 |
| 8.1.6.1  | Direct Transfer in CELL DCH state (invalid message reception and no signalling connection exists) .....                                                     | 351 |
| 8.1.6.2  | Direct Transfer in CELL FACH state (invalid message reception and no signalling connection exists) .....                                                    | 353 |
| 8.1.7    | Security mode command.....                                                                                                                                  | 355 |
| 8.1.7.1  | Security mode command in CELL_DCH state .....                                                                                                               | 355 |
| 8.1.7.2  | Security mode command in CELL_FACH state .....                                                                                                              | 359 |
| 8.1.8    | Counter check .....                                                                                                                                         | 362 |
| 8.1.8.1  | Counter check in CELL_DCH state .....                                                                                                                       | 362 |
| 8.1.8.2  | Counter check in CELL_FACH state.....                                                                                                                       | 365 |
| 8.1.9    | Signalling Connection Release Request.....                                                                                                                  | 369 |
| 8.1.10   | Broadcast of system information .....                                                                                                                       | 370 |
| 8.1.10.1 | Dynamic change of segmentation, concatenation & scheduling and handling of unsupported information blocks .....                                             | 370 |
| 8.2      | Radio Bearer control procedure.....                                                                                                                         | 401 |
| 8.2.1    | Radio Bearer Establishment.....                                                                                                                             | 401 |
| 8.2.1.1  | Radio Bearer Establishment for transition from CELL_DCH to CELL_DCH: Success .....                                                                          | 401 |
| 8.2.1.3  | Radio Bearer Establishment for transition from CELL_DCH to CELL_DCH: Failure (Unsupported configuration) .....                                              | 402 |
| 8.2.1.4  | Radio Bearer Establishment for transition from CELL_DCH to CELL_DCH: Failure (Physical channel Failure and successful reversion to old configuration) ..... | 403 |
| 8.2.1.5  | Radio Bearer Establishment for transition from CELL_DCH to CELL_DCH: Failure (Physical channel Failure and reversion failure).....                          | 404 |
| 8.2.1.6  | Radio Bearer Establishment for transition from CELL_DCH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration).....                               | 406 |
| 8.2.1.7  | Radio Bearer Establishment for transition from CELL_DCH to CELL_DCH: Failure (Invalid message reception and Invalid configuration).....                     | 408 |
| 8.2.1.8  | Radio Bearer Establishment for transition from CELL_DCH to CELL_FACH: Success .....                                                                         | 410 |

|          |                                                                                                                                                              |     |
|----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|
| 8.2.1.9  | Radio Bearer Establishment for transition from CELL_DCH to CELL_FACH: Success (Cell re-selection) .....                                                      | 411 |
| 8.2.1.10 | Radio Bearer Establishment for transition from CELL_FACH to CELL_DCH: Success .....                                                                          | 414 |
| 8.2.1.11 | Radio Bearer Establishment for transition from CELL_FACH to CELL_DCH: Failure (Unsupported configuration) .....                                              | 415 |
| 8.2.1.12 | Radio Bearer Establishment for transition from CELL_FACH to CELL_DCH: Failure (Physical channel Failure and successful reversion to old configuration) ..... | 416 |
| 8.2.1.13 | Radio Bearer Establishment for transition from CELL_FACH to CELL_DCH: Failure (Physical channel Failure and reversion failure) .....                         | 417 |
| 8.2.1.14 | Radio Bearer Establishment for transition from CELL_FACH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration) .....                              | 419 |
| 8.2.1.15 | Radio Bearer Establishment for transition from CELL_FACH to CELL_DCH: Failure (Invalid message reception and Invalid configuration) .....                    | 421 |
| 8.2.1.16 | Radio Bearer Establishment for transition from CELL_FACH to CELL_FACH: Success .....                                                                         | 423 |
| 8.2.1.17 | Radio Bearer Establishment for transition from CELL_DCH to CELL_DCH: success (Subsequently received) .....                                                   | 424 |
| 8.2.1.18 | Radio Bearer Establishment for transition from CELL_FACH to CELL_DCH: Success (Subsequently received) .....                                                  | 426 |
| 8.2.1.19 | Radio Bearer Establishment from CELL_DCH to CELL_PCH: Success .....                                                                                          | 428 |
| 8.2.1.20 | Radio Bearer Establishment from CELL_DCH to URA_PCH: Success .....                                                                                           | 429 |
| 8.2.1.21 | RRC connection establishment in CELL_DCH on another frequency .....                                                                                          | 431 |
| 8.2.2    | Radio Bearer Reconfiguration .....                                                                                                                           | 433 |
| 8.2.2.1  | Radio Bearer Reconfiguration from CELL_DCH to CELL_DCH: Success .....                                                                                        | 433 |
| 8.2.2.2  | Radio Bearer Reconfiguration from CELL_DCH to CELL_DCH: Failure (Unsupported configuration) .....                                                            | 434 |
| 8.2.2.3  | Radio Bearer Reconfiguration from CELL_DCH to CELL_DCH: Failure (Physical channel failure and reversion to old configuration) .....                          | 436 |
| 8.2.2.4  | Radio Bearer Reconfiguration from CELL_DCH to CELL_DCH: Failure (Physical channel failure and reversion failure) .....                                       | 437 |
| 8.2.2.5  | Radio Bearer Reconfiguration from CELL_DCH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration) .....                                            | 439 |
| 8.2.2.6  | Radio Bearer Reconfiguration from CELL_DCH to CELL_DCH: Failure (Invalid message reception and Invalid configuration) .....                                  | 441 |
| 8.2.2.7  | Radio Bearer Reconfiguration from CELL_DCH to CELL_DCH: Success (Continue and stop) .....                                                                    | 443 |
| 8.2.2.8  | Radio Bearer Reconfiguration from CELL_DCH to CELL_FACH: Success .....                                                                                       | 445 |
| 8.2.2.9  | Radio Bearer Reconfiguration from CELL_DCH to CELL_FACH: Success (Cell re-selection) .....                                                                   | 446 |
| 8.2.2.10 | Radio Bearer Reconfiguration: from CELL_FACH to CELL_DCH: Success .....                                                                                      | 448 |
| 8.2.2.11 | Radio Bearer Reconfiguration from CELL_FACH to CELL_DCH: Failure (Unsupported configuration) .....                                                           | 449 |
| 8.2.2.12 | Radio Bearer Reconfiguration from CELL_FACH to CELL_DCH: Failure (Physical channel failure and successful reversion to old configuration) .....              | 450 |
| 8.2.2.13 | Radio Bearer Reconfiguration from CELL_FACH to CELL_DCH: Failure (Physical channel failure and reversion failure) .....                                      | 451 |
| 8.2.2.14 | Radio Bearer Reconfigure from CELL_FACH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration) .....                                               | 453 |
| 8.2.2.15 | Radio Bearer Reconfiguration from CELL_FACH to CELL_DCH: Failure (Invalid message reception and Invalid configuration) .....                                 | 455 |
| 8.2.2.16 | Void .....                                                                                                                                                   | 457 |
| 8.2.2.17 | Radio Bearer Reconfiguration from CELL_FACH to CELL_FACH: Success .....                                                                                      | 457 |
| 8.2.2.18 | Radio Bearer Reconfiguration from CELL_FACH to CELL_FACH: Success (Cell re-selection) .....                                                                  | 459 |
| 8.2.2.19 | Radio Bearer Reconfiguration from CELL_DCH to CELL_DCH: Success (Subsequently received) .....                                                                | 461 |
| 8.2.2.20 | Radio Bearer Reconfigure from CELL_FACH to CELL_DCH: Success (Subsequently received) .....                                                                   | 463 |
| 8.2.2.21 | Radio Bearer Reconfiguration from CELL_DCH to CELL_PCH: Success .....                                                                                        | 465 |
| 8.2.2.22 | Radio Bearer Reconfiguration from CELL_DCH to URA_PCH: Success .....                                                                                         | 467 |
| 8.2.2.23 | Radio Bearer Reconfiguration from CELL_FACH to CELL_PCH: Success .....                                                                                       | 469 |
| 8.2.2.24 | Radio Bearer Reconfiguration from CELL_FACH to URA_PCH: Success .....                                                                                        | 470 |
| 8.2.2.25 | Radio Bearer Reconfiguration for transition from CELL_FACH to CELL_DCH including modification of previously signalled CELL_DCH configuration .....           | 472 |
| 8.2.3    | Radio Bearer Release .....                                                                                                                                   | 475 |



|          |                                                                                                                                                       |     |
|----------|-------------------------------------------------------------------------------------------------------------------------------------------------------|-----|
| 8.2.3.1  | Radio Bearer Release for transition from CELL_DCH to CELL_DCH: Success.....                                                                           | 475 |
| 8.2.3.2  | Radio Bearer Release for transition from CELL_DCH to CELL_DCH: Failure (Unsupported configuration).....                                               | 476 |
| 8.2.3.3  | Radio Bearer Release for transition from CELL_DCH to CELL_DCH: Failure (Physical channel failure and reversion to old configuration).....             | 477 |
| 8.2.3.4  | Radio Bearer Release for transition from CELL_DCH to CELL_DCH: Failure (Physical channel failure and reversion failure).....                          | 478 |
| 8.2.3.5  | Radio Bearer Release for transition from CELL_DCH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration).....                               | 481 |
| 8.2.3.6  | Radio Bearer Release for transition from CELL_DCH to CELL_DCH: Failure (Invalid message reception and Invalid configuration).....                     | 483 |
| 8.2.3.7  | Radio Bearer Release for transition from CELL_DCH to CELL_FACH: Success .....                                                                         | 485 |
| 8.2.3.8  | Radio Bearer Release for transition from CELL_DCH to CELL_FACH: Success (Cell re-selection).....                                                      | 486 |
| 8.2.3.9  | Radio Bearer Release for transition from CELL_FACH to CELL_DCH: Success .....                                                                         | 488 |
| 8.2.3.10 | Radio Bearer Release for transition from CELL_FACH to CELL_DCH: Failure (Unsupported configuration).....                                              | 489 |
| 8.2.3.11 | Radio Bearer Release for transition from CELL_FACH to CELL_DCH: Failure (Physical channel failure and successful reversion to old configuration)..... | 490 |
| 8.2.3.12 | Radio Bearer Release for transition from CELL_FACH to CELL_DCH: Failure (Physical channel failure and reversion failure).....                         | 491 |
| 8.2.3.13 | Radio Bearer Release for transition from CELL_FACH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration).....                              | 493 |
| 8.2.3.14 | Radio Bearer Release for transition from CELL_FACH to CELL_DCH: Failure (Invalid message reception and Invalid configuration).....                    | 495 |
| 8.2.3.15 | Radio Bearer Release for transition from CELL_FACH to CELL_FACH: Success .....                                                                        | 497 |
| 8.2.3.16 | Radio Bearer Release for transition from CELL_DCH to CELL_DCH: Success (Subsequently received).....                                                   | 498 |
| 8.2.3.17 | Radio Bearer Release for transition from CELL_FACH to CELL_DCH: Success (Subsequently received).....                                                  | 500 |
| 8.2.3.18 | Radio Bearer Release from CELL_DCH to CELL_PCH: Success.....                                                                                          | 502 |
| 8.2.3.19 | Radio Bearer Release from CELL_DCH to URA_PCH: Success .....                                                                                          | 504 |
| 8.2.4    | Transport channel reconfiguration .....                                                                                                               | 506 |
| 8.2.4.1  | Transport channel reconfiguration from CELL_DCH to CELL_DCH: Success with no transport channel type switching.....                                    | 506 |
| 8.2.4.1a | Transport channel reconfiguration (Transmission Rate Modification with Timing Maintained) from CELL_DCH to CELL_DCH of the same cell: Success.....    | 507 |
| 8.2.4.2  | Transport channel reconfiguration from CELL_DCH to CELL_DCH: Failure (Unsupported configuration).....                                                 | 509 |
| 8.2.4.3  | Transport channel reconfiguration from CELL_DCH to CELL_DCH: Failure (Physical channel failure and reversion to old configuration).....               | 510 |
| 8.2.4.4  | Transport channel reconfiguration from CELL_DCH to CELL_DCH: Failure (Physical channel failure and reversion failure).....                            | 512 |
| 8.2.4.5  | Transport Channel Reconfiguration from CELL_DCH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration).....                                 | 514 |
| 8.2.4.6  | Transport channel reconfiguration from CELL_DCH to CELL_DCH: Failure (Invalid message reception and Invalid configuration).....                       | 516 |
| 8.2.4.7  | Transport channel reconfiguration from CELL_DCH to CELL_FACH: Success .....                                                                           | 518 |
| 8.2.4.8  | Void.....                                                                                                                                             | 520 |
| 8.2.4.9  | Transport channel reconfiguration from CELL_DCH to CELL_FACH: Success (Cell re-selection).....                                                        | 520 |
| 8.2.4.10 | Transport channel reconfiguration from CELL_FACH to CELL_DCH: Success .....                                                                           | 521 |
| 8.2.4.11 | Transport channel reconfiguration from CELL_FACH to CELL_DCH: Failure (Unsupported configuration).....                                                | 522 |
| 8.2.4.12 | Transport channel reconfiguration from CELL_FACH to CELL_DCH: Failure (Physical channel failure and successful reversion to old channel).....         | 524 |
| 8.2.4.13 | Transport channel reconfiguration from CELL_FACH to CELL_DCH: Failure (Physical channel failure and reversion failure).....                           | 525 |
| 8.2.4.14 | Transport Channel Reconfiguration from CELL_FACH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration).....                                | 527 |

|          |                                                                                                                                                                     |     |
|----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|
| 8.2.4.15 | Transport channel reconfiguration from CELL_FACH to CELL_DCH: Failure (Invalid message reception and Invalid configuration) .....                                   | 529 |
| 8.2.4.16 | Transport channel reconfiguration from CELL_FACH to CELL_FACH: Success with no transport channel type switching.....                                                | 531 |
| 8.2.4.17 | Transport channel reconfiguration from CELL_FACH to CELL_FACH: Success (Cell re-selection) .....                                                                    | 533 |
| 8.2.4.18 | Transport Channel Reconfiguration from CELL_DCH to CELL_DCH: Success (Subsequently received).....                                                                   | 535 |
| 8.2.4.19 | Transport Channel Reconfiguration from CELL_FACH to CELL_DCH: Success (Subsequently received).....                                                                  | 537 |
| 8.2.4.20 | Transport Channel Reconfiguration from CELL_DCH to CELL_PCH: Success .....                                                                                          | 539 |
| 8.2.4.21 | Transport Channel Reconfiguration from CELL_DCH to URA_PCH: Success .....                                                                                           | 541 |
| 8.2.4.22 | Transport Channel Reconfiguration from CELL_FACH to CELL_PCH: Success.....                                                                                          | 542 |
| 8.2.4.23 | Transport Channel Reconfiguration from CELL_FACH to URA_PCH: Success .....                                                                                          | 544 |
| 8.2.5    | Transport format combination control .....                                                                                                                          | 546 |
| 8.2.5.1  | Transport format combination control in CELL_DCH: restriction .....                                                                                                 | 546 |
| 8.2.5.2  | Transport format combination control in CELL_DCH: release a restriction .....                                                                                       | 547 |
| 8.2.5.3  | Void.....                                                                                                                                                           | 548 |
| 8.2.5.4  | Transport format combination control in CELL_DCH: Failure (Invalid message reception and Invalid configuration).....                                                | 549 |
| 8.2.6    | Physical channel reconfiguration .....                                                                                                                              | 551 |
| 8.2.6.1  | Physical channel reconfiguration for transition from CELL_DCH to CELL_DCH (code modification): Success .....                                                        | 551 |
| 8.2.6.2  | Physical channel reconfiguration for transition from CELL_DCH to CELL_DCH (code modification): Failure (Unsupported configuration) .....                            | 553 |
| 8.2.6.3  | Physical channel reconfiguration for transition from CELL_DCH to CELL_DCH (code modification): Failure (Physical channel failure and reversion to old channel)..... | 554 |
| 8.2.6.4  | Physical channel reconfiguration for transition from CELL_DCH to CELL_DCH (code modification): Failure (Physical channel failure and reversion failure).....        | 556 |
| 8.2.6.5  | Physical channel reconfiguration for transition from CELL_DCH to CELL_DCH (code modification): Failure (Incompatible simultaneous reconfiguration).....             | 559 |
| 8.2.6.6  | Physical channel reconfiguration for transition from CELL_DCH to CELL_DCH (code modification): Failure (Invalid message reception and Invalid configuration) .....  | 561 |
| 8.2.6.7  | Physical channel reconfiguration for transition from CELL_DCH to CELL_FACH: Success .....                                                                           | 563 |
| 8.2.6.8  | Physical channel reconfiguration for transition from CELL_DCH to CELL_FACH: Success (Cell re-selection).....                                                        | 564 |
| 8.2.6.9  | Physical channel reconfiguration for transition from CELL_FACH to CELL_DCH: Success .....                                                                           | 566 |
| 8.2.6.10 | Physical channel reconfiguration for transition from CELL_FACH to CELL_DCH: Failure (Unsupported configuration) .....                                               | 567 |
| 8.2.6.11 | Physical channel reconfiguration for transition from CELL_FACH to CELL_DCH: Failure (Physical channel failure and successful reversion to old configuration) .....  | 569 |
| 8.2.6.12 | Physical channel reconfiguration for transition from CELL_FACH to CELL_DCH: Failure (Physical channel failure and reversion failure) .....                          | 571 |
| 8.2.6.13 | Physical channel reconfiguration for transition from CELL_FACH to CELL_DCH: Failure (Incompatible simultaneous reconfiguration).....                                | 573 |
| 8.2.6.14 | Physical channel reconfiguration for transition from CELL_FACH to CELL_DCH: Failure (Invalid message reception and Invalid configuration) .....                     | 575 |
| 8.2.6.15 | Physical channel reconfiguration for transition from CELL_FACH to CELL_FACH: Success .....                                                                          | 578 |
| 8.2.6.16 | Physical channel reconfiguration for transition from CELL_FACH to CELL_FACH: (Cell re-selection) .....                                                              | 579 |
| 8.2.6.17 | Physical channel reconfiguration for transition from CELL_DCH to CELL_DCH (code modification): Success (Subsequently received).....                                 | 582 |
| 8.2.6.18 | Physical channel reconfiguration for transition from CELL_FACH to CELL_DCH: Success (Subsequently received) .....                                                   | 584 |
| 8.2.6.19 | Physical Channel Reconfiguration from CELL_DCH to CELL_PCH: Success.....                                                                                            | 586 |
| 8.2.6.20 | Physical Channel Reconfiguration from CELL_DCH to URA_PCH: Success .....                                                                                            | 588 |
| 8.2.6.21 | Physical Channel Reconfiguration from CELL_FACH to URA_PCH: Success .....                                                                                           | 589 |
| 8.2.6.22 | Physical Channel Reconfiguration from CELL_FACH to CELL_PCH: Success.....                                                                                           | 591 |
| 8.2.7    | Physical Shared Channel Allocation [TDD only] .....                                                                                                                 | 593 |
| 8.2.8    | PUSCH capacity request [TDD only] .....                                                                                                                             | 593 |

|          |                                                                                                     |     |
|----------|-----------------------------------------------------------------------------------------------------|-----|
| 8.2.9    | Void .....                                                                                          | 593 |
| 8.3      | RRC connection mobility procedure .....                                                             | 593 |
| 8.3.1    | Cell Update .....                                                                                   | 593 |
| 8.3.1.1  | Cell Update: cell reselection in CELL_FACH .....                                                    | 593 |
| 8.3.1.2  | Cell Update: cell reselection in CELL_PCH .....                                                     | 598 |
| 8.3.1.3  | Cell Update: periodical cell update in CELL_FACH .....                                              | 600 |
| 8.3.1.4  | Cell Update: periodical cell update in CELL_PCH .....                                               | 604 |
| 8.3.1.5  | Cell Update: UL data transmission in URA_PCH .....                                                  | 607 |
| 8.3.1.6  | Cell Update: UL data transmission in CELL_PCH .....                                                 | 610 |
| 8.3.1.7  | Void .....                                                                                          | 612 |
| 8.3.1.8  | Void .....                                                                                          | 612 |
| 8.3.1.9  | Cell Update: re-entering of service area after T305 expiry and being out of service area .....      | 612 |
| 8.3.1.10 | Cell Update: expiry of T307 after T305 expiry and being out of service area .....                   | 615 |
| 8.3.1.11 | Cell Update: Success after T302 time-out .....                                                      | 618 |
| 8.3.1.12 | Cell Update: Failure (After Maximum Re-transmissions) .....                                         | 620 |
| 8.3.1.13 | Cell Update: Reception of Invalid CELL UPDATE CONFIRM Message .....                                 | 621 |
| 8.3.1.14 | Cell Update: Incompatible simultaneous reconfiguration .....                                        | 623 |
| 8.3.1.15 | Cell Update: Unrecoverable error in Acknowledged Mode RLC .....                                     | 625 |
| 8.3.1.16 | Void .....                                                                                          | 627 |
| 8.3.1.17 | Cell Update: Failure (UTRAN initiate an RRC connection release procedure on CCCH) .....             | 627 |
| 8.3.1.18 | Cell Update: Radio Link Failure (T314>0, T315=0) .....                                              | 629 |
| 8.3.1.19 | Void .....                                                                                          | 632 |
| 8.3.1.20 | Cell Update: Reception of CELL UPDATE CONFIRM Message that causes invalid configuration .....       | 632 |
| 8.3.1.21 | Cell Update: Cell reselection to cell of another PLMN belonging to the equivalent PLMN list .....   | 633 |
| 8.3.1.22 | Cell update: Restricted cell reselection to a cell belonging to forbidden LA list (Cell_FACH) ..... | 636 |
| 8.3.1.23 | Cell Update: HCS cell reselection in CELL_FACH .....                                                | 638 |
| 8.3.1.24 | Cell Update: HCS cell reselection in CELL_PCH .....                                                 | 650 |
| 8.3.2    | URA Update .....                                                                                    | 661 |
| 8.3.2.1  | URA Update: Change of URA .....                                                                     | 661 |
| 8.3.2.2  | URA Update: Periodical URA update and Reception of Invalid message .....                            | 664 |
| 8.3.2.3  | URA Update: re-entering of service area after T305 expiry .....                                     | 666 |
| 8.3.2.4  | URA Update: loss of service after expiry of timers T307 and T305 .....                              | 669 |
| 8.3.2.5  | URA Update: Success after Confirmation error of URA-ID list .....                                   | 671 |
| 8.3.2.6  | URA Update: Failure (V302 is greater than N302: Confirmation error of URA-ID list) .....            | 673 |
| 8.3.2.7  | URA Update: Success after T302 timeout .....                                                        | 674 |
| 8.3.2.8  | Void .....                                                                                          | 675 |
| 8.3.2.9  | URA Update: Failure (UTRAN initiate an RRC connection release procedure on CCCH) .....              | 675 |
| 8.3.2.10 | URA Update: Reception of URA UPDATE CONFIRM message that causes invalid configuration .....         | 677 |
| 8.3.2.11 | URA Update: Cell reselection to cell of another PLMN belonging to the equivalent PLMN list .....    | 679 |
| 8.3.2.12 | Restricted cell reselection to a cell belonging to forbidden LA list (URA_PCH) .....                | 681 |
| 8.3.2.13 | URA Update: Change of URA due to HCS Cell Reselection .....                                         | 682 |
| 8.3.3    | UTRAN Mobility Information .....                                                                    | 694 |
| 8.3.3.1  | UTRAN Mobility Information: Success .....                                                           | 694 |
| 8.3.3.2  | UTRAN Mobility Information: Failure (Invalid message reception) .....                               | 696 |
| 8.3.4    | Active set update in soft handover .....                                                            | 698 |
| 8.3.4.1  | Active set update in soft handover: Radio Link addition .....                                       | 698 |
| 8.3.4.2  | Active set update in soft handover: Radio Link removal .....                                        | 702 |
| 8.3.4.3  | Active set update in soft handover: Combined radio link addition and removal .....                  | 706 |
| 8.3.4.4  | Active set update in soft handover: Invalid Configuration .....                                     | 709 |
| 8.3.4.5  | Active set update in soft handover: Reception of an ACTIVE SET UPDATE message in wrong state .....  | 710 |
| 8.3.4.6  | Void .....                                                                                          | 712 |
| 8.3.4.7  | Active set update in soft handover: Invalid Message Reception .....                                 | 712 |
| 8.3.5    | Hard Handover .....                                                                                 | 714 |
| 8.3.6    | Inter-system hard handover from GSM to UTRAN .....                                                  | 714 |
| 8.3.7    | Inter-system hard handover from UTRAN to GSM .....                                                  | 714 |
| 8.3.7.1  | Inter system handover from UTRAN/To GSM/Speech/Success .....                                        | 716 |
| 8.3.7.2  | Inter system handover from UTRAN/To GSM/Data/Same data rate/Success .....                           | 720 |

|          |                                                                                                                                   |     |
|----------|-----------------------------------------------------------------------------------------------------------------------------------|-----|
| 8.3.7.3  | Inter system handover from UTRAN/To GSM/Data/Data rate down grading/Success .....                                                 | 724 |
| 8.3.7.4  | Inter system handover from UTRAN/To GSM/Speech/Establishment/Success .....                                                        | 726 |
| 8.3.7.5  | Inter system handover from UTRAN/To GSM/Speech/Failure .....                                                                      | 729 |
| 8.3.7.6  | Inter system handover from UTRAN/To GSM/Speech/Failure (L2 Establishment) .....                                                   | 730 |
| 8.3.7.7  | Inter system handover from UTRAN/To GSM/Speech/Failure (L1 Synchronization) .....                                                 | 733 |
| 8.3.7.8  | Inter system handover from UTRAN/To GSM/Speech/Failure (Invalid Inter-RAT message) .....                                          | 735 |
| 8.3.7.9  | Inter system handover from UTRAN/To GSM/Speech/Failure (Unsupported configuration) .....                                          | 737 |
| 8.3.7.10 | Inter system handover from UTRAN/To GSM/Speech/Failure (Reception by UE in<br>CELL_FACH) .....                                    | 739 |
| 8.3.7.11 | Inter system handover from UTRAN/To GSM/Speech/Failure (Invalid message reception) .....                                          | 740 |
| 8.3.7.12 | Inter system handover from UTRAN/To GSM/Speech/Failure (Physical channel Failure and<br>Reversion Failure) .....                  | 742 |
| 8.3.7.13 | Inter system handover from UTRAN/To GSM/ success / call under establishment .....                                                 | 745 |
| 8.3.8    | Inter system cell reselection to UTRAN .....                                                                                      | 747 |
| 8.3.9    | Inter system cell reselection from UTRAN .....                                                                                    | 747 |
| 8.4      | Measurement procedure .....                                                                                                       | 747 |
| 8.4.1    | Measurement Control and Report .....                                                                                              | 747 |
| 8.4.1.1  | Measurement Control and Report: Intra-frequency measurement for transition from idle mode to<br>CELL_DCH state .....              | 747 |
| 8.4.1.2  | Measurement Control and Report: Inter-frequency measurement for transition from idle mode to<br>CELL_DCH state .....              | 756 |
| 8.4.1.3  | Measurement Control and Report: Intra-frequency measurement for transition from idle mode to<br>CELL_FACH state .....             | 765 |
| 8.4.1.4  | Measurement Control and Report: Inter-frequency measurement for transition from idle mode to<br>CELL_FACH state .....             | 770 |
| 8.4.1.5  | Measurement Control and Report: Intra-frequency measurement for transition from CELL_DCH<br>to CELL_FACH state .....              | 773 |
| 8.4.1.6  | Measurement Control and Report: Inter-frequency measurement for transition from CELL_DCH<br>to CELL_FACH state .....              | 782 |
| 8.4.1.7  | Measurement Control and Report: Intra-frequency measurement for transition from<br>CELL_FACH to CELL_DCH state .....              | 790 |
| 8.4.1.8  | Measurement Control and Report: Inter-frequency measurement for transition from<br>CELL_FACH to CELL_DCH state .....              | 801 |
| 8.4.1.9  | Measurement Control and Report: Unsupported measurement in the UE .....                                                           | 812 |
| 8.4.1.10 | Measurement Control and Report: Failure (Invalid Message Reception) .....                                                         | 815 |
| 8.4.1.11 | Measurement Control and Report: Compressed Mode Configuration Failure during radio bearer<br>reconfiguration procedure .....      | 817 |
| 8.4.1.12 | Measurement Control and Report: Compressed Mode Configuration Failure during transport<br>channel reconfiguration procedure ..... | 823 |
| 8.4.1.13 | Measurement Control and Report: Compressed Mode Configuration Failure during physical<br>channel reconfiguration procedure .....  | 829 |
| 8.4.1.14 | Measurement Control and Report: Cell forbidden to affect reporting range .....                                                    | 835 |
| 8.4.1.15 | Measurement Control and Report: Configuration Incomplete .....                                                                    | 844 |
| 8.4.1.16 | Measurement Control and Report: Traffic volume measurement for transition from idle mode to<br>CELL_FACH state .....              | 852 |
| 8.4.1.17 | Measurement Control and Report: Traffic volume measurement for transition from idle mode to<br>CELL_DCH state .....               | 856 |
| 8.4.1.18 | Measurement Control and Report: Traffic volume measurement for transition from<br>CELL_FACH state to CELL_DCH state .....         | 861 |
| 8.4.1.19 | Measurement Control and Report: Traffic volume measurement for transition from CELL_DCH<br>to CELL_FACH state .....               | 869 |
| 8.4.1.20 | Measurement Control and Report: Traffic volume measurement in CELL_PCH state .....                                                | 877 |
| 8.4.1.21 | Measurement Control and Report: Traffic volume measurement in URA_PCH state .....                                                 | 880 |
| 8.4.1.22 | Measurement Control and Report: Quality measurements .....                                                                        | 882 |
| 8.4.1.23 | Measurement Control and Report: Intra-frequency measurement for events 1C and 1D .....                                            | 884 |
| 8.4.1.24 | Measurement Control and Report: Inter-frequency measurement for event 2A .....                                                    | 891 |
| 8.4.1.25 | Measurement Control and Report: Inter-frequency measurement for events 2B and 2E .....                                            | 897 |
| 8.4.1.26 | Measurement Control and Report: Inter-frequency measurement for events 2D and 2F .....                                            | 901 |
| 8.4.1.27 | Measurement Control and Report: UE internal measurement for events 6A and 6B .....                                                | 905 |
| 8.4.1.28 | Measurement Control and Report: UE internal measurement for events 6F and 6G .....                                                | 908 |

|           |                                                                                                                               |      |
|-----------|-------------------------------------------------------------------------------------------------------------------------------|------|
| 8.4.1.29  | Measurement Control and Report: Event based Traffic Volume measurement in CELL_FACH state. ....                               | 912  |
| 8.4.1.30  | Measurement Control and Report: Event based Traffic Volume measurement in CELL_DCH state. ....                                | 914  |
| 8.4.1.31  | Measurement Control and Report: Inter-RAT measurement in CELL_DCH state. ....                                                 | 917  |
| 8.4.1.32  | Void. ....                                                                                                                    | 924  |
| 8.4.1.33  | Measurement Control and Report: Inter-RAT measurement, event 3a. ....                                                         | 924  |
| 8.4.1.34  | Measurement Control and Report: Inter-RAT measurement, event 3b. ....                                                         | 931  |
| 8.4.1.35  | Measurement Control and Report: Inter-RAT measurement, event 3c. ....                                                         | 940  |
| 8.4.1.36  | Measurement Control and Report: Inter-RAT measurement, event 3d. ....                                                         | 946  |
| 8.4.1.37  | Measurement Control and Report: UE internal measurement, event 6c. ....                                                       | 953  |
| 8.4.1.38  | Measurement Control and Report: UE internal measurement, event 6d. ....                                                       | 955  |
| 8.4.1.39  | Measurement Control and Report: UE internal measurement, event 6e. ....                                                       | 957  |
| 8.4.1.40  | Measurement Control and Report: Inter-RAT measurement, event 3C, in CELL_DCH state using sparse compressed mode pattern. .... | 958  |
| 9         | Elementary procedures of mobility management. ....                                                                            | 965  |
| 9.1       | TMSI reallocation. ....                                                                                                       | 965  |
| 9.2       | Authentication. ....                                                                                                          | 968  |
| 9.2.1     | Authentication accepted. ....                                                                                                 | 968  |
| 9.2.2     | Authentication rejected by the network. ....                                                                                  | 970  |
| 9.2.3     | Authentication rejected by the UE (MAC code failure). ....                                                                    | 973  |
| 9.2.4     | Authentication rejected by the UE (SQN failure). ....                                                                         | 975  |
| 9.3       | Identification. ....                                                                                                          | 977  |
| 9.3.1     | General Identification. ....                                                                                                  | 977  |
| 9.3.2     | Handling of IMSI shorter than the maximum length. ....                                                                        | 979  |
| 9.4       | Location updating. ....                                                                                                       | 982  |
| 9.4.1     | Location updating / accepted. ....                                                                                            | 983  |
| 9.4.2     | Location updating / rejected. ....                                                                                            | 986  |
| 9.4.2.1   | Location updating / rejected / IMSI invalid. ....                                                                             | 986  |
| 9.4.2.2   | Location updating / rejected / PLMN not allowed. ....                                                                         | 989  |
| 9.4.2.3   | Location updating / rejected / location area not allowed. ....                                                                | 995  |
| 9.4.2.4   | Location updating / rejected / roaming not allowed in this location area. ....                                                | 998  |
| 9.4.2.5   | Location updating / rejected / No Suitable Cells In Location Area. ....                                                       | 1007 |
| 9.4.3     | Location updating / abnormal cases. ....                                                                                      | 1009 |
| 9.4.3.1   | Void. ....                                                                                                                    | 1009 |
| 9.4.3.2   | Location updating / abnormal cases / attempt counter less or equal to 4, LAI different. ....                                  | 1009 |
| 9.4.3.3   | Location updating / abnormal cases / attempt counter equal to 4. ....                                                         | 1015 |
| 9.4.3.4   | Location updating / abnormal cases / attempt counter less or equal to 4, stored LAI equal to broadcast LAI. ....              | 1025 |
| 9.4.4     | Location updating / release / expiry of T3240. ....                                                                           | 1034 |
| 9.4.5     | Location updating / periodic. ....                                                                                            | 1036 |
| 9.4.5.1   | Location updating / periodic spread. ....                                                                                     | 1036 |
| 9.4.5.2   | Location updating / periodic normal / test 1. ....                                                                            | 1038 |
| 9.4.5.3   | Location updating / periodic normal / test 2. ....                                                                            | 1040 |
| 9.4.5.4   | Location updating / periodic search for higher priority PLMN when in VPLMN. ....                                              | 1042 |
| 9.4.5.4.1 | Location updating / periodic search for higher priority PLMN / UE waits time T. ....                                          | 1042 |
| 9.4.5.4.2 | Location updating / search for higher priority PLMN / UE in manual mode. ....                                                 | 1044 |
| 9.4.5.4.3 | Location updating / search for higher priority PLMN / UE waits at least two minutes and at most T minutes. ....               | 1046 |
| 9.4.6     | Location updating / interworking of attach and periodic. ....                                                                 | 1047 |
| 9.4.7     | Location Updating / accept with deletion of Equivalent PLMN list. ....                                                        | 1050 |
| 9.4.8     | Location Updating after UE power off. ....                                                                                    | 1051 |
| 9.4.9     | Location Updating/ Accept Storage of Equivalent PLMN list. ....                                                               | 1052 |
| 9.5       | MM connection. ....                                                                                                           | 1054 |
| 9.5.1     | Introduction. ....                                                                                                            | 1054 |
| 9.5.2     | MM connection / establishment in security mode. ....                                                                          | 1054 |
| 9.5.3     | MM connection / establishment in non-security mode. ....                                                                      | 1056 |
| 9.5.4     | MM connection / establishment rejected. ....                                                                                  | 1057 |
| 9.5.5     | MM connection / establishment rejected cause 4. ....                                                                          | 1058 |
| 9.5.6     | MM connection / expiry T3230. ....                                                                                            | 1060 |

|             |                                                                                                         |      |
|-------------|---------------------------------------------------------------------------------------------------------|------|
| 9.5.7       | MM connection / abortion by the network.....                                                            | 1061 |
| 9.5.7.1     | MM connection / abortion by the network / cause #6 .....                                                | 1061 |
| 9.5.7.2     | MM connection / abortion by the network / cause not equal to #6 .....                                   | 1064 |
| 9.5.8       | MM connection / follow-on request pending .....                                                         | 1065 |
| 9.5.8.1     | MM connection / follow-on request pending / test 1.....                                                 | 1065 |
| 9.5.8.2     | MM connection / follow-on request pending / test 2.....                                                 | 1066 |
| 9.5.8.3     | MM connection / follow-on request pending / test 3.....                                                 | 1068 |
| 10          | Circuit Switched Call Control (CC) .....                                                                | 1071 |
| 10.1        | Circuit switched Call Control (CC) state machine verification .....                                     | 1071 |
| 10.1.1      | General on CC state machine verification .....                                                          | 1071 |
| 10.1.2      | Establishment of an outgoing call .....                                                                 | 1072 |
| 10.1.2.1    | Outgoing call / U0 null state .....                                                                     | 1074 |
| 10.1.2.1.1  | Outgoing call / U0 null state / MM connection requested .....                                           | 1074 |
| 10.1.2.2    | Outgoing call / U0.1 MM connection pending.....                                                         | 1075 |
| 10.1.2.2.1  | Outgoing call / U0.1 MM connection pending / CM service rejected .....                                  | 1075 |
| 10.1.2.2.2  | Outgoing call / U0.1 MM connection pending / CM service accepted.....                                   | 1076 |
| 10.1.2.2.3  | Outgoing call / U0.1 MM connection pending / lower layer failure.....                                   | 1077 |
| 10.1.2.3    | Outgoing call / U1 call initiated .....                                                                 | 1078 |
| 10.1.2.3.1  | Outgoing call / U1 call initiated / receiving CALL PROCEEDING .....                                     | 1078 |
| 10.1.2.3.2  | Outgoing call / U1 call initiated / rejecting with RELEASE COMPLETE .....                               | 1079 |
| 10.1.2.3.3  | Outgoing call / U1 call initiated / T303 expiry .....                                                   | 1081 |
| 10.1.2.3.4  | Outgoing call / U1 call initiated / lower layer failure .....                                           | 1082 |
| 10.1.2.3.5  | Outgoing call / U1 call initiated / receiving ALERTING .....                                            | 1083 |
| 10.1.2.3.6  | Outgoing call / U1 call initiated / entering state U10 .....                                            | 1084 |
| 10.1.2.3.7  | Outgoing call / U1 call initiated / unknown message received .....                                      | 1085 |
| 10.1.2.4    | Outgoing call / U3 UE originating call proceeding.....                                                  | 1087 |
| 10.1.2.4.1  | Outgoing call / U3 UE originating call proceeding / ALERTING received.....                              | 1087 |
| 10.1.2.4.2  | Outgoing call / U3 UE originating call proceeding / CONNECT received .....                              | 1088 |
| 10.1.2.4.3  | Outgoing call / U3 UE originating call proceeding / PROGRESS received without in band information ..... | 1089 |
| 10.1.2.4.4  | Outgoing call / U3 UE originating call proceeding / PROGRESS with in band information.....              | 1090 |
| 10.1.2.4.5  | Outgoing call / U3 UE originating call proceeding / DISCONNECT with in band tones .....                 | 1092 |
| 10.1.2.4.6  | Outgoing call / U3 UE originating call proceeding / DISCONNECT without in band tones .....              | 1093 |
| 10.1.2.4.7  | Outgoing call / U3 UE originating call proceeding / RELEASE received .....                              | 1094 |
| 10.1.2.4.8  | Outgoing call / U3 UE originating call proceeding / termination requested by the user .....             | 1096 |
| 10.1.2.4.9  | Outgoing call / U3 UE originating call proceeding / traffic channel allocation.....                     | 1097 |
| 10.1.2.4.10 | Outgoing call / U3 UE originating call proceeding / timer T310 time-out .....                           | 1098 |
| 10.1.2.4.11 | Outgoing call / U3 UE originating call proceeding / lower layer failure .....                           | 1099 |
| 10.1.2.4.12 | Outgoing call / U3 UE originating call proceeding / unknown message received.....                       | 1100 |
| 10.1.2.4.13 | Outgoing call / U3 UE originating call proceeding / Internal alerting indication.....                   | 1101 |
| 10.1.2.5    | Outgoing call / U4 call delivered .....                                                                 | 1103 |
| 10.1.2.5.1  | Outgoing call / U4 call delivered / CONNECT received.....                                               | 1103 |
| 10.1.2.5.2  | Outgoing call / U4 call delivered / termination requested by the user .....                             | 1104 |
| 10.1.2.5.3  | Outgoing call / U4 call delivered / DISCONNECT with in band tones .....                                 | 1105 |
| 10.1.2.5.4  | Outgoing call / U4 call delivered / DISCONNECT without in band tones .....                              | 1106 |
| 10.1.2.5.5  | Outgoing call / U4 call delivered / RELEASE received .....                                              | 1107 |
| 10.1.2.5.6  | Outgoing call / U4 call delivered / lower layer failure .....                                           | 1108 |
| 10.1.2.5.7  | Outgoing call / U4 call delivered / traffic channel allocation .....                                    | 1110 |
| 10.1.2.5.8  | Outgoing call / U4 call delivered / unknown message received .....                                      | 1111 |
| 10.1.2.6    | U10 call active.....                                                                                    | 1112 |
| 10.1.2.6.1  | U10 call active / termination requested by the user .....                                               | 1112 |
| 10.1.2.6.2  | U10 call active / RELEASE received .....                                                                | 1113 |
| 10.1.2.6.3  | U10 call active / DISCONNECT with in band tones .....                                                   | 1114 |
| 10.1.2.6.4  | U10 call active / DISCONNECT without in band tones .....                                                | 1116 |
| 10.1.2.6.5  | U10 call active / RELEASE COMPLETE received .....                                                       | 1117 |
| 10.1.2.6.6  | U10 call active / SETUP received .....                                                                  | 1118 |
| 10.1.2.7    | U11 disconnect request .....                                                                            | 1120 |
| 10.1.2.7.1  | U11 disconnect request / clear collision .....                                                          | 1120 |
| 10.1.2.7.2  | U11 disconnect request / RELEASE received.....                                                          | 1121 |
| 10.1.2.7.3  | U11 disconnect request / timer T305 time-out .....                                                      | 1122 |

|            |                                                                                                            |      |
|------------|------------------------------------------------------------------------------------------------------------|------|
| 10.1.2.7.4 | U11 disconnect request / lower layer failure .....                                                         | 1123 |
| 10.1.2.7.5 | U11 disconnect request / unknown message received .....                                                    | 1125 |
| 10.1.2.8   | U12 disconnect indication .....                                                                            | 1126 |
| 10.1.2.8.1 | U12 disconnect indication / call releasing requested by the user .....                                     | 1126 |
| 10.1.2.8.2 | U12 disconnect indication / RELEASE received .....                                                         | 1127 |
| 10.1.2.8.3 | U12 disconnect indication / lower layer failure .....                                                      | 1128 |
| 10.1.2.8.4 | U12 disconnect indication / unknown message received .....                                                 | 1129 |
| 10.1.2.9   | Outgoing call / U19 release request .....                                                                  | 1130 |
| 10.1.2.9.1 | Outgoing call / U19 release request / timer T308 time-out .....                                            | 1130 |
| 10.1.2.9.2 | Outgoing call / U19 release request / 2nd timer T308 time-out .....                                        | 1132 |
| 10.1.2.9.3 | Outgoing call / U19 release request / RELEASE received .....                                               | 1133 |
| 10.1.2.9.4 | Outgoing call / U19 release request / RELEASE COMPLETE received .....                                      | 1134 |
| 10.1.2.9.5 | Outgoing call / U19 release request / lower layer failure .....                                            | 1136 |
| 10.1.3     | Establishment of an incoming call / Initial conditions .....                                               | 1137 |
| 10.1.3.1   | Incoming call / U0 null state .....                                                                        | 1138 |
| 10.1.3.1.1 | Incoming call / U0 null state / SETUP received with a non supported bearer capability .....                | 1138 |
| 10.1.3.2   | Incoming call / U6 call present .....                                                                      | 1140 |
| 10.1.3.2.1 | Incoming call / U6 call present / automatic call rejection .....                                           | 1140 |
| 10.1.3.3   | Incoming call / U9 mobile terminating call confirmed .....                                                 | 1141 |
| 10.1.3.3.1 | Incoming call / U9 mobile terminating call confirmed / alerting or immediate connecting .....              | 1141 |
| 10.1.3.3.2 | Incoming call / U9 mobile terminating call confirmed / DTCH assignment .....                               | 1142 |
| 10.1.3.3.3 | Incoming call / U9 mobile terminating call confirmed / termination requested by the user .....             | 1144 |
| 10.1.3.3.4 | Incoming call / U9 mobile terminating call confirmed / DISCONNECT received .....                           | 1145 |
| 10.1.3.3.5 | Incoming call / U9 mobile terminating call confirmed / RELEASE received .....                              | 1146 |
| 10.1.3.3.6 | Incoming call / U9 mobile terminating call confirmed / lower layer failure .....                           | 1147 |
| 10.1.3.3.7 | Incoming call / U9 mobile terminating call confirmed / unknown message received .....                      | 1149 |
| 10.1.3.4   | Incoming call / U7 call received .....                                                                     | 1150 |
| 10.1.3.4.1 | Incoming call / U7 call received / call accepted .....                                                     | 1150 |
| 10.1.3.4.2 | Incoming call / U7 call received / termination requested by the user .....                                 | 1151 |
| 10.1.3.4.3 | Incoming call / U7 call received / DISCONNECT received .....                                               | 1152 |
| 10.1.3.4.4 | Incoming call / U7 call received / RELEASE received .....                                                  | 1153 |
| 10.1.3.4.5 | Incoming call / U7 call received / lower layer failure .....                                               | 1155 |
| 10.1.3.4.6 | Incoming call / U7 call received / unknown message received .....                                          | 1156 |
| 10.1.3.4.7 | Incoming call / U7 call received / DTCH assignment .....                                                   | 1157 |
| 10.1.3.4.8 | Incoming call / U7 call received / RELEASE COMPLETE received .....                                         | 1158 |
| 10.1.3.5   | Incoming call / U8 connect request .....                                                                   | 1160 |
| 10.1.3.5.1 | Incoming call / U8 connect request / CONNECT acknowledged .....                                            | 1160 |
| 10.1.3.5.2 | Incoming call / U8 connect request / timer T313 time-out .....                                             | 1161 |
| 10.1.3.5.3 | Incoming call / U8 connect request / termination requested by the user .....                               | 1162 |
| 10.1.3.5.4 | Incoming call / U8 connect request / DISCONNECT received with in-band information .....                    | 1163 |
| 10.1.3.5.5 | Incoming call / U8 connect request / DISCONNECT received without in-band information .....                 | 1164 |
| 10.1.3.5.6 | Incoming call / U8 connect request / RELEASE received .....                                                | 1165 |
| 10.1.3.5.7 | Incoming call / U8 connect request / lower layer failure .....                                             | 1167 |
| 10.1.3.5.8 | Incoming call / U8 connect request / DTCH assignment .....                                                 | 1168 |
| 10.1.3.5.9 | Incoming call / U8 connect request / unknown message received .....                                        | 1169 |
| 10.1.4     | In call functions .....                                                                                    | 1170 |
| 10.1.4.1   | In-call functions / DTMF information transfer .....                                                        | 1170 |
| 10.1.4.1.1 | In-call functions / DTMF information transfer / basic procedures .....                                     | 1170 |
| 10.1.4.2   | In-call functions / user notification .....                                                                | 1172 |
| 10.1.4.2.1 | In-call functions / User notification / UE terminated .....                                                | 1172 |
| 10.1.4.3   | In-call functions / channel changes .....                                                                  | 1173 |
| 10.1.4.3.1 | In-call functions / channel changes / a successful channel change in active state/ Hard<br>handover .....  | 1173 |
| 10.1.4.3.2 | In-call functions / channel changes / an unsuccessful channel change in active mode/Hard<br>handover ..... | 1175 |
| 10.1.4.4   | In-call functions / UE terminated in-call modification .....                                               | 1176 |
| 10.1.4.4.1 | In-call functions / UE terminated in-call modification / modify when new mode is not<br>supported .....    | 1176 |
| 10.1.4.5   | In-call functions / UE originated in-call modification .....                                               | 1176 |
| 10.1.4.5.1 | In-call functions / UE originated in-call modification / a successful case of modifying .....              | 1176 |

|            |                                                                                                                                     |      |
|------------|-------------------------------------------------------------------------------------------------------------------------------------|------|
| 10.1.4.5.2 | In-call functions / UE originated in-call modification / modify rejected .....                                                      | 1176 |
| 10.1.4.5.3 | In-call functions / UE originated in-call modification / an abnormal case of acceptance .....                                       | 1176 |
| 10.1.4.5.4 | In-call functions / UE originated in-call modification / an abnormal case of rejection .....                                        | 1176 |
| 10.1.4.5.5 | In-call functions / UE originated in-call modification / time-out of timer T323 .....                                               | 1176 |
| 10.1.4.5.6 | In-call functions / UE originated in-call modification / a successful channel change in state<br>mobile originating modify .....    | 1176 |
| 10.1.4.5.7 | In-call functions / UE originated in-call modification / an unsuccessful channel change in<br>state mobile originating modify ..... | 1176 |
| 10.1.4.5.8 | In-call functions / UE originated in-call modification / unknown message received .....                                             | 1176 |
| 10.1.4.5.9 | In-call functions / UE originated in-call modification / a release complete received .....                                          | 1176 |
| 10.2       | Call Re-establishment .....                                                                                                         | 1177 |
| 10.2.1     | Call Re-establishment/call present, re-establishment allowed .....                                                                  | 1177 |
| 10.3       | User to user signalling .....                                                                                                       | 1178 |
| 11         | Session Management Procedures .....                                                                                                 | 1181 |
| 11.1       | PDP context activation .....                                                                                                        | 1181 |
| 11.1.1     | Initiated by the UE .....                                                                                                           | 1181 |
| 11.1.1.1   | Attach initiated by context activation/QoS Offered by Network is the QoS Requested .....                                            | 1181 |
| 11.1.1.2   | QoS offered by the network is a lower QoS .....                                                                                     | 1183 |
| 11.1.1.2.1 | QoS accepted by UE .....                                                                                                            | 1183 |
| 11.1.1.2.2 | QoS rejected by UE .....                                                                                                            | 1184 |
| 11.1.2     | PDP context activation requested by the network, successful and unsuccessful .....                                                  | 1185 |
| 11.1.3     | Abnormal Cases .....                                                                                                                | 1188 |
| 11.1.3.1   | T3380 Expiry .....                                                                                                                  | 1188 |
| 11.1.3.2   | Collision of UE initiated and network requested PDP context activation .....                                                        | 1190 |
| 11.1.3.3   | Network initiated PDP context activation request for an already activated PDP context (on the<br>UE side) .....                     | 1192 |
| 11.1.4     | Secondary PDP context activation procedures .....                                                                                   | 1193 |
| 11.1.4.1   | Successful Secondary PDP Context Activation Procedure Initiated by the UE .....                                                     | 1193 |
| 11.1.4.1.1 | QoS Offered by Network is the QoS Requested .....                                                                                   | 1193 |
| 11.1.4.1.2 | QoS Offered by Network is a lower QoS .....                                                                                         | 1195 |
| 11.1.4.2   | Unsuccessful Secondary PDP Context Activation Procedure Initiated by the UE .....                                                   | 1199 |
| 11.1.4.3   | Abnormal cases .....                                                                                                                | 1201 |
| 11.1.4.3.1 | T3380 Expiry .....                                                                                                                  | 1201 |
| 11.2       | PDP context modification procedure .....                                                                                            | 1202 |
| 11.2.1     | Network initiated PDP context modification .....                                                                                    | 1202 |
| 11.2.2     | UE initiated PDP context modification .....                                                                                         | 1204 |
| 11.2.2.1   | UE initiated PDP Context Modification accepted by network .....                                                                     | 1204 |
| 11.2.2.2   | UE initiated PDP Context Modification not accepted by the network .....                                                             | 1206 |
| 11.2.3     | Abnormal cases .....                                                                                                                | 1207 |
| 11.2.3.1   | T3381 Expiry .....                                                                                                                  | 1207 |
| 11.2.3.2   | Collision of UE and network initiated PDP context modification procedures .....                                                     | 1209 |
| 11.3       | PDP context deactivation procedures .....                                                                                           | 1210 |
| 11.3.1     | PDP context deactivation initiated by the UE .....                                                                                  | 1210 |
| 11.3.2     | PDP context deactivation initiated by the network .....                                                                             | 1212 |
| 11.3.2.5   | Test requirements .....                                                                                                             | 1213 |
| 11.3.3     | Abnormal cases .....                                                                                                                | 1214 |
| 11.3.3.1   | T3390 Expiry .....                                                                                                                  | 1214 |
| 11.3.3.2   | Collision of UE and network initiated PDP context deactivation requests .....                                                       | 1215 |
| 11.4       | Unknown or Unforeseen Transaction Identifier/Non-semantical Mandatory Information Element Errors ..                                 | 1217 |
| 11.4.1     | Error cases .....                                                                                                                   | 1217 |
| 12         | Elementary procedure for Packet Switched Mobility Management .....                                                                  | 1219 |
| 12.1       | Applicability, default conditions and default messages .....                                                                        | 1219 |
| 12.2       | PS attach procedure .....                                                                                                           | 1220 |
| 12.2.1     | Normal PS attach .....                                                                                                              | 1220 |
| 12.2.1.1   | PS attach / accepted .....                                                                                                          | 1220 |
| 12.2.1.2   | PS attach / rejected / IMSI invalid / illegal UE .....                                                                              | 1223 |
| 12.2.1.3   | PS attach / rejected / IMSI invalid / PS services not allowed .....                                                                 | 1226 |
| 12.2.1.4   | PS attach / rejected / PLMN not allowed .....                                                                                       | 1228 |
| 12.2.1.5a  | PS attach / rejected / roaming not allowed in this location area .....                                                              | 1232 |



|           |                                                                                                               |      |
|-----------|---------------------------------------------------------------------------------------------------------------|------|
| 12.2.1.5b | PS attach / rejected / No Suitable Cells In Location Area .....                                               | 1244 |
| 12.2.1.6  | PS attach / abnormal cases / access barred due to access class control .....                                  | 1246 |
| 12.2.1.7  | PS attach / abnormal cases / change of cell into new routing area .....                                       | 1249 |
| 12.2.1.8  | PS attach / abnormal cases / power off .....                                                                  | 1251 |
| 12.2.1.9  | PS attach / abnormal cases / PS detach procedure collision .....                                              | 1252 |
| 12.2.2    | Combined PS attach .....                                                                                      | 1254 |
| 12.2.2.1  | Combined PS attach / PS and non-PS attach accepted .....                                                      | 1254 |
| 12.2.2.2  | Combined PS attach / PS only attach accepted .....                                                            | 1258 |
| 12.2.2.3  | Combined PS attach / PS attach while IMSI attach .....                                                        | 1264 |
| 12.2.2.4  | Combined PS attach / rejected / IMSI invalid / illegal ME .....                                               | 1266 |
| 12.2.2.5  | Combined PS attach / rejected / PS services and non-PS services not allowed .....                             | 1269 |
| 12.2.2.6  | Combined PS attach / rejected / PS services not allowed .....                                                 | 1272 |
| 12.2.2.7a | Combined PS attach / rejected / location area not allowed .....                                               | 1275 |
| 12.2.2.7b | Combined PS attach / rejected / No Suitable Cells In Location Area .....                                      | 1279 |
| 12.2.2.8  | Combined PS attach / abnormal cases / attempt counter check / miscellaneous reject causes .....               | 1281 |
| 12.2.2.9  | Combined PS attach / abnormal cases / PS detach procedure collision .....                                     | 1285 |
| 12.3      | PS detach procedure .....                                                                                     | 1287 |
| 12.3.1    | UE initiated PS detach procedure .....                                                                        | 1287 |
| 12.3.1.1  | PS detach / power off / accepted .....                                                                        | 1287 |
| 12.3.1.2  | PS detach / accepted .....                                                                                    | 1289 |
| 12.3.1.3  | PS detach / abnormal cases / attempt counter check / procedure timeout .....                                  | 1290 |
| 12.3.1.4  | PS detach / abnormal cases / GMM common procedure collision .....                                             | 1293 |
| 12.3.1.5  | PS detach / power off / accepted .....                                                                        | 1295 |
| 12.3.1.6  | PS detach / accepted / PS/IMSI detach .....                                                                   | 1296 |
| 12.3.1.7  | PS detach / accepted / IMSI detach .....                                                                      | 1297 |
| 12.3.1.8  | PS detach / abnormal cases / change of cell into new routing area .....                                       | 1300 |
| 12.3.1.9  | PS detach / abnormal cases / PS detach procedure collision .....                                              | 1302 |
| 12.3.2    | Network initiated PS detach procedure .....                                                                   | 1304 |
| 12.3.2.1  | PS detach / re-attach not required / accepted .....                                                           | 1304 |
| 12.3.2.2  | PS detach / rejected / IMSI invalid / PS services not allowed .....                                           | 1305 |
| 12.3.2.3  | PS detach / IMSI detach / accepted .....                                                                      | 1308 |
| 12.3.2.4  | PS detach / re-attach requested / accepted .....                                                              | 1310 |
| 12.3.2.5  | PS detach / rejected / location area not allowed .....                                                        | 1312 |
| 12.3.2.6  | PS detach / rejected / No Suitable Cells In Location Area .....                                               | 1317 |
| 12.4      | Routing area updating procedure .....                                                                         | 1319 |
| 12.4.1    | Normal routing area updating .....                                                                            | 1319 |
| 12.4.1.1  | Routing area updating / accepted .....                                                                        | 1319 |
| 12.4.1.2  | Routing area updating / rejected / IMSI invalid / illegal ME .....                                            | 1322 |
| 12.4.1.3  | Routing area updating / rejected / UE identity cannot be derived by the network .....                         | 1324 |
| 12.4.1.4a | Routing area updating / rejected / location area not allowed .....                                            | 1327 |
| 12.4.1.4b | Routing area updating / rejected / No Suitable Cells In Location Area .....                                   | 1331 |
| 12.4.1.5  | Routing area updating / abnormal cases / attempt counter check / miscellaneous reject causes .....            | 1333 |
| 12.4.1.6  | Routing area updating / abnormal cases / change of cell into new routing area .....                           | 1337 |
| 12.4.1.7  | Routing area updating / abnormal cases / change of cell during routing area updating procedure .....          | 1339 |
| 12.4.1.8  | Routing area updating / abnormal cases / P-TMSI reallocation procedure collision .....                        | 1341 |
| 12.4.2    | Combined routing area updating .....                                                                          | 1343 |
| 12.4.2.1  | Combined routing area updating / combined RA/LA accepted .....                                                | 1343 |
| 12.4.2.2  | Combined routing area updating / UE in CS operation at change of RA .....                                     | 1346 |
| 12.4.2.3  | Combined routing area updating / RA only accepted .....                                                       | 1349 |
| 12.4.2.4  | Combined routing area updating / rejected / PLMN not allowed .....                                            | 1356 |
| 12.4.2.5a | Combined routing area updating / rejected / roaming not allowed in this location area .....                   | 1360 |
| 12.4.2.5b | Combined routing area updating / rejected / No Suitable Cells In Location Area .....                          | 1367 |
| 12.4.2.6  | Combined routing area updating / abnormal cases / access barred due to access class control .....             | 1370 |
| 12.4.2.7  | Combined routing area updating / abnormal cases / attempt counter check / procedure timeout .....             | 1375 |
| 12.4.2.8  | Combined routing area updating / abnormal cases / change of cell into new routing area .....                  | 1379 |
| 12.4.2.9  | Combined routing area updating / abnormal cases / change of cell during routing area updating procedure ..... | 1382 |
| 12.4.2.10 | Combined routing area updating / abnormal cases / PS detach procedure collision .....                         | 1384 |
| 12.4.3    | Periodic routing area updating .....                                                                          | 1388 |
| 12.4.3.1  | Periodic routing area updating / accepted .....                                                               | 1388 |

|            |                                                                                                                                         |      |
|------------|-----------------------------------------------------------------------------------------------------------------------------------------|------|
| 12.4.3.2   | Periodic routing area updating / accepted / T3312 default value .....                                                                   | 1390 |
| 12.4.3.3   | Periodic routing area updating / no cell available / network mode I .....                                                               | 1391 |
| 12.4.3.4   | Periodic routing area updating / no cell available .....                                                                                | 1394 |
| 12.5       | P-TMSI reallocation .....                                                                                                               | 1396 |
| 12.6       | PS authentication and ciphering .....                                                                                                   | 1398 |
| 12.6.1     | Test of authentication .....                                                                                                            | 1398 |
| 12.6.1.1   | Authentication accepted .....                                                                                                           | 1398 |
| 12.6.1.2   | Authentication rejected by the network .....                                                                                            | 1400 |
| 12.6.1.3   | Authentication rejected by the UE .....                                                                                                 | 1403 |
| 12.6.1.3.1 | GMM cause 'MAC failure' .....                                                                                                           | 1403 |
| 12.6.1.3.2 | GMM cause 'Synch failure' .....                                                                                                         | 1406 |
| 12.6.1.3.3 | Authentication rejected by the UE / fraudulent network .....                                                                            | 1408 |
| 12.6.2     | Void .....                                                                                                                              | 1411 |
| 12.7       | Identification procedure .....                                                                                                          | 1411 |
| 12.7.1     | General Identification .....                                                                                                            | 1411 |
| 12.8       | GMM READY timer handling .....                                                                                                          | 1413 |
| 12.9       | Service Request procedure (UMTS Only) .....                                                                                             | 1414 |
| 12.9.1     | Service Request Initiated by UE Procedure .....                                                                                         | 1414 |
| 12.9.2     | Service Request Initiated by Network Procedure .....                                                                                    | 1416 |
| 12.9.3     | Service Request / rejected / Illegal MS .....                                                                                           | 1417 |
| 12.9.4     | Service Request / rejected / PS services not allowed .....                                                                              | 1420 |
| 12.9.5     | Service Request / rejected / MS identity cannot be derived by the network .....                                                         | 1423 |
| 12.9.6     | Service Request / rejected / PLMN not allowed .....                                                                                     | 1426 |
| 12.9.7a    | Service Request / rejected / No PDP context activated .....                                                                             | 1428 |
| 12.9.7b    | Service Request / rejected / No Suitable Cells In Location Area .....                                                                   | 1430 |
| 12.9.8     | Service Request / Abnormal cases / Access barred due to access class control .....                                                      | 1432 |
| 12.9.9     | Service Request / Abnormal cases / Routing area update procedure is triggered .....                                                     | 1434 |
| 12.9.10    | Service Request / Abnormal cases / Power off .....                                                                                      | 1436 |
| 12.9.11    | Service Request / Abnormal cases / Service request procedure collision .....                                                            | 1438 |
| 13         | General Tests .....                                                                                                                     | 1440 |
| 13.1       | Emergency call / general .....                                                                                                          | 1440 |
| 13.2       | Emergency call .....                                                                                                                    | 1440 |
| 13.2.1     | Emergency call / with USIM .....                                                                                                        | 1440 |
| 13.2.1.1   | Emergency call / with USIM / accept case .....                                                                                          | 1440 |
| 13.2.2     | Emergency call / without USIM .....                                                                                                     | 1442 |
| 13.2.2.1   | Emergency call / without USIM / accept case .....                                                                                       | 1442 |
| 13.2.2.2   | Emergency call / without USIM / reject case .....                                                                                       | 1444 |
| 14         | Interoperability Radio Bearer Tests .....                                                                                               | 1446 |
| 14.1       | General information for interoperability radio bearer tests .....                                                                       | 1446 |
| 14.1.1     | Generic radio bearer test procedure .....                                                                                               | 1446 |
| 14.2       | Combinations on DPCCH .....                                                                                                             | 1448 |
| 14.2.1     | Stand-alone UL:1.7 DL:1.7 kbps SRBs for DCCH .....                                                                                      | 1448 |
| 14.2.2     | Stand-alone UL:3.4 DL:3.4 kbps SRBs for DCCH .....                                                                                      | 1448 |
| 14.2.3     | Stand-alone UL:13.6 DL:13.6 kbps SRBs for DCCH .....                                                                                    | 1448 |
| 14.2.4     | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH ..                                           | 1449 |
| 14.2.4a    | Conversational / speech / UL:(12.2 7.95 5.9 4.75) DL:(12.2 7.95 5.9 4.75) kbps / CS RAB + UL:3.4<br>DL:3.4 kbps SRBs for DCCH .....     | 1450 |
| 14.2.5     | Conversational / speech / UL:10.2 DL:10.2 kbps / CS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH ..                                          | 1450 |
| 14.2.5a    | Conversational / speech / UL:(10.2, 6.7, 5.9, 4.75) DL:(10.2, 6.7, 5.9, 4.75) kbps / CS RAB +<br>UL:3.4 DL:3.4 kbps SRBs for DCCH. .... | 1452 |
| 14.2.6     | Conversational / speech / UL:7.95 DL:7.95 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH ..                                           | 1452 |
| 14.2.7     | Conversational / speech / UL:7.4 DL:7.4 kbps / CS RAB+ UL:3.4 DL:3.4 kbps SRBs for DCCH .....                                           | 1453 |
| 14.2.7a    | Conversational / speech / UL:(7.4, 6.7, 5.9, 4.75) DL:(7.4, 6.7, 5.9, 4.75) kbps / CS RAB + UL:3.4<br>DL:3.4 kbps SRBs for DCCH .....   | 1455 |
| 14.2.8     | Conversational / speech / UL:6.7 DL:6.7 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....                                          | 1455 |
| 14.2.9     | Conversational / speech / UL:5.9 DL:5.9 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....                                          | 1456 |
| 14.2.10    | Conversational / speech / UL:5.15 DL:5.15 kbps / CS RAB + UL:1.7 DL:1.7 kbps SRBs for DCCH ..                                           | 1458 |
| 14.2.11    | Conversational / speech / UL:4.75 DL:4.75 kbps / CS RAB + UL:1.7 DL:1.7 kbps SRBs for DCCH ..                                           | 1459 |

|           |                                                                                                             |      |
|-----------|-------------------------------------------------------------------------------------------------------------|------|
| 14.2.12   | Conversational / unknown / UL:28.8 DL:28.8 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....           | 1461 |
| 14.2.13   | Conversational / unknown / UL:64 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....               | 1462 |
| 14.2.13.1 | Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 20 ms TTI .....                                      | 1462 |
| 14.2.13.2 | Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 40 ms TTI .....                                      | 1464 |
| 14.2.14   | Conversational / unknown / UL:32 DL:32 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....               | 1465 |
| 14.2.14.1 | Conversational / unknown / UL:32 DL:32 kbps / CS RAB / 20 ms TTI .....                                      | 1465 |
| 14.2.14.2 | Conversational / unknown / UL:32 DL:32 kbps / CS RAB / 40 ms TTI .....                                      | 1466 |
| 14.2.15   | Streaming / unknown / UL:14.4/DL:14.4 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....                | 1468 |
| 14.2.16   | Streaming / unknown / UL:28.8/DL:28.8 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....                | 1469 |
| 14.2.17   | Streaming / unknown / UL:57.6/DL:57.6 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....                | 1470 |
| 14.2.18   | Streaming / unknown / UL:0 DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....                     | 1472 |
| 14.2.19   | Streaming / unknown / UL:64 DL:0 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....                     | 1474 |
| 14.2.20   | Streaming / unknown / UL:0 DL:128 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....                    | 1477 |
| 14.2.21   | Streaming / unknown / UL:128 DL:0 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....                    | 1478 |
| 14.2.22   | Streaming / unknown / UL:0 DL:384 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....                    | 1481 |
| 14.2.23   | Interactive or background / UL:32 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....               | 1483 |
| 14.2.23.1 | Interactive or background / UL:32 DL:8 kbps / PS RAB / (TC, 10 ms TTI) .....                                | 1483 |
| 14.2.23.2 | Interactive or background / UL:32 DL:8 kbps / PS RAB / (TC, 20 ms TTI) .....                                | 1485 |
| 14.2.23.3 | Interactive or background / UL:32 DL:8 kbps / PS RAB / (CC, 10 ms TTI) .....                                | 1486 |
| 14.2.23.4 | Interactive or background / UL:32 DL:8 kbps / PS RAB / (CC, 20 ms TTI) .....                                | 1486 |
| 14.2.23a  | Interactive or background / UL:8 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....                | 1486 |
| 14.2.23b  | Interactive or background / UL:16 DL:16 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....              | 1486 |
| 14.2.23c  | Interactive or background / UL:32 DL:32 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....              | 1487 |
| 14.2.23d  | Interactive or background / UL:32 DL:32 kbps / PS RAB (20 ms TTI) + UL:3.4 DL:3.4 kbps SRBs for DCCH .....  | 1487 |
| 14.2.24   | Interactive or background / UL:64 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....               | 1487 |
| 14.2.24.1 | Interactive or background / UL:64 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / TC .....          | 1487 |
| 14.2.24.2 | Interactive or background / UL:64 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / CC .....          | 1489 |
| 14.2.25   | Interactive or background / UL:32 DL: 64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....             | 1489 |
| 14.2.25.1 | Interactive or background / UL:32 DL: 64 kbps / PS RAB / (TC, 10 ms TTI) .....                              | 1489 |
| 14.2.25.2 | Interactive or background / UL:32 DL: 64 kbps / PS RAB / (TC, 20 ms TTI) .....                              | 1490 |
| 14.2.25.3 | Interactive or background / UL:32 DL:64 kbps / PS RAB / (CC, 10 ms TTI) .....                               | 1492 |
| 14.2.25.4 | Interactive or background / UL:32 DL:64 kbps / PS RAB / (CC, 20 ms TTI) .....                               | 1492 |
| 14.2.26   | Interactive or background / UL:64 DL: 64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....             | 1493 |
| 14.2.27   | Interactive or background / UL:64 DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....             | 1495 |
| 14.2.28   | Interactive or background / UL:128 DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....            | 1497 |
| 14.2.29   | Interactive or background / UL:64 DL:144 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH .....            | 1499 |
| 14.2.30   | Interactive or background / UL:144 DL:144 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH .....           | 1501 |
| 14.2.31   | Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH .....            | 1503 |
| 14.2.31.1 | Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH/ 10 ms TTI ..... | 1503 |
| 14.2.31.2 | Interactive or background / UL:64 DL:256 kbps / PS RAB / 20 ms TTI .....                                    | 1505 |
| 14.2.32   | Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH .....            | 1507 |
| 14.2.32.1 | Interactive or background / UL:64 DL:384 kbps / PS RAB / 10 ms TTI .....                                    | 1507 |
| 14.2.32.2 | Interactive or background / UL:64 DL:384 kbps / PS RAB / 20 ms TTI .....                                    | 1509 |
| 14.2.33   | Interactive or background / UL:128 DL:384 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH .....           | 1511 |
| 14.2.33.1 | Interactive or background / UL:128 DL:384 kbps / PS RAB / 10 ms TTI .....                                   | 1511 |
| 14.2.33.2 | Interactive or background / UL:128 DL:384 kbps / PS RAB / 20 ms TTI .....                                   | 1513 |
| 14.2.34   | Interactive or background / UL:384 DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....            | 1516 |
| 14.2.34.1 | Interactive or background / UL:384 DL:384 kbps / PS RAB / 10 ms TTI .....                                   | 1516 |
| 14.2.34.2 | Interactive or background / UL:384 DL:384 kbps / PS RAB / 20 ms TTI .....                                   | 1518 |
| 14.2.35   | Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....            | 1521 |
| 14.2.35.1 | Interactive or background / UL:64 DL:2048 kbps / PS RAB / 10 ms TTI .....                                   | 1521 |
| 14.2.35.2 | Interactive or background / UL:64 DL:2048 kbps / PS RAB / 20 ms TTI .....                                   | 1524 |
| 14.2.36   | Interactive or background / UL:128 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....           | 1527 |
| 14.2.36.1 | Interactive or background / UL:128 DL:2048 kbps / PS RAB / 10 ms TTI .....                                  | 1527 |

|           |                                                                                                                                                                                                                        |      |
|-----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| 14.2.36.2 | Interactive or background / UL:128 DL:2048 kbps / PS RAB / 20 ms TTI.....                                                                                                                                              | 1530 |
| 14.2.37   | Interactive or background / UL:384 DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for<br>DCCH .....                                                                                                                   | 1533 |
| 14.2.37.1 | Interactive or background / UL:384 DL:2048 kbps / PS RAB / 10 ms TTI.....                                                                                                                                              | 1533 |
| 14.2.37.2 | Interactive or background / UL:384 DL:2048 kbps / PS RAB / 20 ms TTI.....                                                                                                                                              | 1536 |
| 14.2.38   | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32<br>DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....                                                              | 1540 |
| 14.2.38.1 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32<br>DL:8 kbps / PS RAB / (TC, 20 ms TTI).....                                                                               | 1540 |
| 14.2.38.2 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32<br>DL:8 kbps / PS RAB / (TC, 10 ms TTI).....                                                                               | 1542 |
| 14.2.38.3 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32<br>DL:8 kbps / PS RAB / (CC, 20 ms TTI) .....                                                                              | 1542 |
| 14.2.38.4 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32<br>DL:8 kbps / PS RAB / (CC, 10 ms TTI) .....                                                                              | 1542 |
| 14.2.38a  | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:0 DL:0<br>kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH. ....                                                              | 1543 |
| 14.2.38b  | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:8 DL:8<br>kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH. ....                                                              | 1543 |
| 14.2.38c  | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32<br>DL:32 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....                                                             | 1543 |
| 14.2.38d  | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:64 kbps / PS RAB + Interactive or background / UL:64 DL:64 kbps / PS RAB + UL:3.4 DL:3.4<br>kbps SRBs for DCCH. .... | 1543 |
| 14.2.38e  | Conversational / speech / UL:(12.2 7.95 5.9 4.75) DL:(12.2 7.95 5.9 4.75) kbps / CS RAB +<br>Interactive or background / UL:0 DL:0 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH. ....                              | 1543 |
| 14.2.38f  | Conversational / speech / UL:(12.2 7.95 5.9 4.75) DL:(12.2 7.95 5.9 4.75) kbps / CS RAB +<br>Interactive or background / UL:8 DL:8 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH. ....                              | 1543 |
| 14.2.38g  | Conversational / speech / UL:(12.2 7.95 5.9 4.75) DL:(12.2 7.95 5.9 4.75) kbps / CS RAB +<br>Interactive or background / UL:16 DL:16 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH. ....                            | 1543 |
| 14.2.38h  | Conversational / speech / UL:(12.2 7.95 5.9 4.75) DL:(12.2 7.95 5.9 4.75) kbps / CS RAB +<br>Interactive or background / UL:32 DL:32 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH. ....                            | 1544 |
| 14.2.38i  | Conversational / speech / UL:(12.2 7.95 5.9 4.75) DL:(12.2 7.95 5.9 4.75) kbps / CS RAB +<br>Interactive or background / UL:64 DL:64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH. ....                            | 1544 |
| 14.2.38j  | Conversational / speech / UL:(12.2 7.95 5.9 4.75) DL:(12.2 7.95 5.9 4.75) kbps / CS RAB +<br>Interactive or background / UL:64 DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH. ..                             | 1544 |
| 14.2.39   | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32<br>DL:64 kbps / PS RAB+ UL:3.4 DL: 3.4 kbps SRBs for DCCH.....                                                             | 1544 |
| 14.2.39.1 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32<br>DL:64 kbps / PS RAB / (TC, 10 ms TTI).....                                                                              | 1544 |
| 14.2.39.2 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32<br>DL:64 kbps / PS RAB / (TC, 20 ms TTI).....                                                                              | 1547 |
| 14.2.39.3 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32<br>DL:64 kbps / PS RAB / (CC, 10 ms TTI) .....                                                                             | 1551 |
| 14.2.39.4 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:32<br>DL:64 kbps / PS RAB / (CC, 20 ms TTI) .....                                                                             | 1551 |
| 14.2.40   | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:64 kbps / PS RAB+ UL:3.4 DL: 3.4 kbps SRBs for DCCH.....                                                             | 1552 |
| 14.2.41   | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....                                                            | 1555 |
| 14.2.42   | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:256 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....                                                            | 1559 |
| 14.2.42.1 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:256 kbps / PS RAB / 10 ms TTI .....                                                                                  | 1559 |
| 14.2.42.2 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:256 kbps / PS RAB / 20 ms TTI .....                                                                                  | 1563 |
| 14.2.43   | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....                                                            | 1568 |
| 14.2.43.1 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:384 kbps / PS RAB / 10 ms TTI .....                                                                                  | 1568 |

|           |                                                                                                                                                                    |      |
|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| 14.2.43.2 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:384 kbps / PS RAB / 20 ms TTI .....                              | 1573 |
| 14.2.44   | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:128<br>DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....      | 1577 |
| 14.2.44.1 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background /<br>UL:128 DL:2048 kbps / PS RAB / 10 ms TTI .....                            | 1577 |
| 14.2.44.2 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background /<br>UL:128 DL:2048 kbps / PS RAB / 20 ms TTI .....                            | 1583 |
| 14.2.45   | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Streaming / unknown / UL:57.6<br>DL:57.6 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....          | 1591 |
| 14.2.46   | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Streaming / unknown / UL:0 DL:64<br>kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....                | 1595 |
| 14.2.47   | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Streaming / unknown / UL:0 DL:128<br>kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....               | 1599 |
| 14.2.48   | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Streaming / unknown / UL:0 DL:384<br>kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....               | 1604 |
| 14.2.49   | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Conversational / unknown / UL:64<br>DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....         | 1609 |
| 14.2.49.1 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Conversational / unknown / UL:64<br>DL:64 kbps / CS RAB / 20 ms TTI.....                                 | 1609 |
| 14.2.49.2 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Conversational / unknown /<br>UL:64 DL:64 kbps / CS RAB / 40 ms TTI .....                                | 1611 |
| 14.2.50   | Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Conversational / unknown / UL:64<br>DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....            | 1614 |
| 14.2.50.1 | Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Conversational / unknown / UL:64<br>DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI..... | 1614 |
| 14.2.50.2 | Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Conversational / unknown / UL:64<br>DL:64 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 40 ms TTI..... | 1616 |
| 14.2.51   | Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Interactive or background / UL:64<br>DL:64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....            | 1618 |
| 14.2.51.1 | Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 20 ms TTI + Interactive or<br>background / UL:64 DL:64 kbps / PS RAB.....                                   | 1618 |
| 14.2.51.2 | Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 40 ms TTI + Interactive or<br>background / UL:64 DL:64 kbps / PS RAB.....                                   | 1621 |
| 14.2.51a  | Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Interactive or Background / UL:8 DL:8<br>kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH. ....             | 1624 |
| 14.2.51b  | Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Interactive or Background / UL:16<br>DL:64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....            | 1624 |
| 14.2.52   | Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Interactive or background / UL:64<br>DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....           | 1624 |
| 14.2.52.1 | Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 20 ms TTI + Interactive or<br>background / UL:64 DL:128 kbps / PS RAB .....                                 | 1624 |
| 14.2.52.2 | Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 40 ms TTI + Interactive or<br>background / UL:64 DL:128 kbps / PS RAB .....                                 | 1628 |
| 14.2.53   | Conversational / unknown / UL:64 DL:64 kbps / CS RAB + Interactive or background / UL:128<br>DL:128 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....          | 1631 |
| 14.2.53.1 | Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 20 ms TTI + Interactive or<br>background / UL:128 DL:128 kbps / PS RAB .....                                | 1631 |
| 14.2.53.2 | Conversational / unknown / UL:64 DL:64 kbps / CS RAB / 40 ms TTI + Interactive or<br>background / UL:128 DL:128 kbps / PS RAB .....                                | 1634 |
| 14.2.54   | Interactive or background / UL:64 DL:128 kbps / PS RAB + Streaming / unknown / UL:0 DL:64<br>kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....                 | 1637 |
| 14.2.55   | Interactive or background / UL:64 DL:128 kbps / PS RAB + Streaming / unknown / UL:0 DL:128<br>kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....                | 1642 |
| 14.2.56   | Interactive or background / UL:8 DL:8 kbps / PS RAB + Interactive or background / UL:8 DL:8<br>kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH. ....              | 1647 |
| 14.2.57   | Interactive or background / UL:64 DL:64 kbps / PS RAB + Interactive or background / UL:64<br>DL:64 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....           | 1648 |
| 14.2.58   | Streaming / unknown / UL:16 DL:64 kbps / PS RAB + Interactive or background / UL:8 DL:8 kbps<br>/ PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....                   | 1648 |

|          |                                                                                                                                                                           |      |
|----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| 14.3     | Combinations on PDSCH and DPCH.....                                                                                                                                       | 1648 |
| 14.3.1   | Interactive or background / UL:64 DL:256 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH ..                                                                             | 1648 |
| 14.3.1.1 | Interactive or background / UL:64 DL:256 kbps / PS RAB / 10 ms TTI.....                                                                                                   | 1648 |
| 14.3.1.2 | Interactive or background / UL:64 DL:256 kbps / PS RAB / 20 ms TTI.....                                                                                                   | 1650 |
| 14.3.2   | Interactive or background / UL:64 DL:384 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH ..                                                                             | 1653 |
| 14.3.2.1 | Interactive or background / UL:64 DL:384 kbps / PS RAB / 10 ms TTI.....                                                                                                   | 1653 |
| 14.3.2.2 | Interactive or background / UL:64 DL:384 kbps / PS RAB / 20 ms TTI.....                                                                                                   | 1655 |
| 14.3.3   | Interactive or background / UL:64 DL:2048 kbps / PS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH                                                                               | 1658 |
| 14.3.3.1 | Interactive or background / UL:64 DL:2048 kbps / PS RAB / 10 ms TTI.....                                                                                                  | 1658 |
| 14.3.3.2 | Interactive or background / UL:64 DL:2048 kbps / PS RAB / 20 ms TTI.....                                                                                                  | 1662 |
| 14.3.4   | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:256 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....               | 1667 |
| 14.3.4.1 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:256 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI .....  | 1667 |
| 14.3.4.2 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:256 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI .....  | 1667 |
| 14.3.5   | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....               | 1667 |
| 14.3.5.1 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI .....  | 1667 |
| 14.3.5.2 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:384 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 20 ms TTI .....  | 1667 |
| 14.3.6   | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....              | 1668 |
| 14.3.6.1 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI ..... | 1668 |
| 14.3.6.2 | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + Interactive or background / UL:64<br>DL:2048 kbps / PS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH / 10 ms TTI ..... | 1668 |
| 14.4     | Combinations on SCCPCH .....                                                                                                                                              | 1668 |
| 14.4.1   | Stand-alone signalling RB for PCCH .....                                                                                                                                  | 1668 |
| 14.4.2   | Interactive/Background 32 kbps PS RAB + SRBs for CCCH + SRB for DCCH + SRB for BCCH.....                                                                                  | 1668 |
| 14.4.3   | Interactive/Background 32 kbps RAB + SRBs for PCCH + SRB for CCCH + SRB for DCCH +<br>SRB for BCCH .....                                                                  | 1668 |
| 14.4.4   | RB for CTCH + SRB for CCCH +SRB for BCCH. ....                                                                                                                            | 1668 |
| 14.5     | Combinations on PRACH .....                                                                                                                                               | 1668 |
| 14.5.1   | Interactive/Background 32 kbps PS RAB + SRB for CCCH + SRB for DCCH .....                                                                                                 | 1668 |
| 15       | Supplementary Services .....                                                                                                                                              | 1669 |
| 16       | Short message service (SMS).....                                                                                                                                          | 1670 |
| 16.1     | Short message service point to point on CS mode.....                                                                                                                      | 1670 |
| 16.1.1   | SMS mobile terminated .....                                                                                                                                               | 1670 |
| 16.1.2   | SMS mobile originated .....                                                                                                                                               | 1675 |
| 16.1.3   | Test of memory full condition and memory available notification:.....                                                                                                     | 1679 |
| 16.1.4   | Test of the status report capabilities and of SMS-COMMAND: .....                                                                                                          | 1682 |
| 16.1.5   | Test of message class 0 to 3.....                                                                                                                                         | 1686 |
| 16.1.5.1 | Short message class 0.....                                                                                                                                                | 1686 |
| 16.1.5.2 | Test of class 1 short messages.....                                                                                                                                       | 1688 |
| 16.1.5.3 | Test of class 2 short messages.....                                                                                                                                       | 1689 |
| 16.1.5.4 | Test of class 3 short messages.....                                                                                                                                       | 1692 |
| 16.1.6   | Test of short message type 0 .....                                                                                                                                        | 1692 |
| 16.1.7   | Test of the replace mechanism for SM type 1-7 .....                                                                                                                       | 1692 |
| 16.1.8   | Test of the reply path scheme .....                                                                                                                                       | 1694 |
| 16.1.9   | Multiple SMS mobile originated.....                                                                                                                                       | 1697 |
| 16.1.9.1 | UE in idle mode .....                                                                                                                                                     | 1697 |
| 16.1.9.2 | UE in active mode.....                                                                                                                                                    | 1700 |
| 16.1.10  | Test of capabilities of simultaneously receiving a short message whilst sending a mobile originated<br>short message.....                                                 | 1702 |
| 16.2     | Short message service point to point on PS mode.....                                                                                                                      | 1703 |
| 16.2.1   | SMS mobile terminated .....                                                                                                                                               | 1703 |
| 16.2.2   | SMS mobile originated .....                                                                                                                                               | 1709 |

|                                                                                            |                                                                                                                        |             |
|--------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|-------------|
| 16.2.3                                                                                     | Test of memory full condition and memory available notification:.....                                                  | 1712        |
| 16.2.4                                                                                     | Test of the status report capabilities and of SMS-COMMAND: .....                                                       | 1716        |
| 16.2.5                                                                                     | Test of message class 0 to 3 .....                                                                                     | 1719        |
| 16.2.5.1                                                                                   | Short message class 0 .....                                                                                            | 1719        |
| 16.2.5.2                                                                                   | Test of class 1 short messages.....                                                                                    | 1721        |
| 16.2.5.3                                                                                   | Test of class 2 short messages.....                                                                                    | 1723        |
| 16.2.5.4                                                                                   | Test of class 3 short messages.....                                                                                    | 1725        |
| 16.2.6                                                                                     | Test of short message type 0 .....                                                                                     | 1725        |
| 16.2.7                                                                                     | Test of the replace mechanism for SM type 1-7 .....                                                                    | 1725        |
| 16.2.8                                                                                     | Test of the reply path scheme .....                                                                                    | 1728        |
| 16.2.9                                                                                     | Multiple SMS mobile originated.....                                                                                    | 1731        |
| 16.2.9.1                                                                                   | UE in idle mode .....                                                                                                  | 1731        |
| 16.2.9.2                                                                                   | UE in active mode .....                                                                                                | 1731        |
| 16.2.10                                                                                    | Test of capabilities of simultaneously receiving a short message whilst sending a mobile originated short message..... | 1731        |
| 16.3                                                                                       | Short message service cell broadcast.....                                                                              | 1732        |
| 16.4                                                                                       | Default message contents: .....                                                                                        | 1734        |
| 16.4.1                                                                                     | Default message contents for SM-CP protocol.....                                                                       | 1734        |
| 16.4.2                                                                                     | Default message contents for SM-RP protocol.....                                                                       | 1734        |
| 16.4.3                                                                                     | Default message contents for SM-TP protocol .....                                                                      | 1735        |
| 17                                                                                         | User Equipment features (MMI, VHE, MexE, SAT).....                                                                     | 1736        |
| 17.1                                                                                       | Test of autocalling restrictions .....                                                                                 | 1736        |
| 17.1.1                                                                                     | General.....                                                                                                           | 1736        |
| 17.1.2                                                                                     | Constraining the access to a single number (TS 22.001 category 3).....                                                 | 1737        |
| 17.1.3                                                                                     | Constraining the access to a single number (TS 22.001 categories 1 and 2) .....                                        | 1738        |
| 17.1.4                                                                                     | Behaviour of the UE when its list of blacklisted numbers is full.....                                                  | 1740        |
| 18                                                                                         | Multi-Layer Functional Tests .....                                                                                     | 1741        |
| 18.1                                                                                       | Radio Bearer Tests for 1.28 Mcps TDD option.....                                                                       | 1741        |
| 18.1.1                                                                                     | General information for radio bearer tests (1.28 Mcps TDD).....                                                        | 1741        |
| 18.1.1.1                                                                                   | Generic radio bearer test procedure.....                                                                               | 1741        |
| 18.1.2                                                                                     | Combinations on DPCH .....                                                                                             | 1743        |
| 18.1.2.1                                                                                   | Stand-alone UL:1.7 DL:1.7 kbps SRBs for DCCH .....                                                                     | 1743        |
| 18.1.2.2                                                                                   | Stand-alone UL:3.4 DL:3.4 kbps SRBs for DCCH .....                                                                     | 1743        |
| 18.1.2.3                                                                                   | Stand-alone UL:13.6 DL:13.6 kbps SRBs for DCCH.....                                                                    | 1743        |
| 18.1.2.4                                                                                   | Conversational / speech / UL:12.2 DL:12.2 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....                        | 1743        |
| 18.1.2.5                                                                                   | Conversational / speech / UL:10.2 DL:10.2 kbps / CS RAB + UL:3.4 DL: 3.4 kbps SRBs for DCCH.....                       | 1745        |
| 18.1.2.6                                                                                   | Conversational / speech / UL:7.95 DL:7.95 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH.....                        | 1747        |
| 18.1.2.7                                                                                   | Conversational / speech / UL:7.4 DL:7.4 kbps / CS RAB+ UL:3.4 DL:3.4 kbps SRBs for DCCH .....                          | 1748        |
| 18.1.2.8                                                                                   | Conversational / speech / UL:6.7 DL:6.7 kbps / CS RAB + UL:3.4 DL:3.4 kbps SRBs for DCCH .....                         | 1750        |
| <b>Annex A (normative): Default RRC Message Contents.....</b>                              |                                                                                                                        | <b>1752</b> |
| A.1                                                                                        | Default RRC Message Contents (FDD) .....                                                                               | 1752        |
| A.2                                                                                        | Default RRC Message Contents (3.84 Mcps TDD) .....                                                                     | 1799        |
| A.3                                                                                        | Default RRC Message Contents (1.28 Mcps TDD) .....                                                                     | 1800        |
| <b>Annex B (informative): Core specification versions to which test cases relate .....</b> |                                                                                                                        | <b>1858</b> |
| <b>Annex C (informative): Change history .....</b>                                         |                                                                                                                        | <b>1859</b> |

## CHANGE REQUEST

⌘ **TS 34.123-1 CR 256** ⌘ rev **-** ⌘ Current version: **4.2.0** ⌘

For **HELP** on using this form, see bottom of this page or look at the pop-up text over the ⌘ symbols.

**Proposed change affects:** ⌘ (U)SIM ☐ ME/UE ☒ Radio Access Network ☐ Core Network ☐

**Title:** ⌘ Creation of 34.123-1 REL-5: Merging of REL-5, REL-4 and R99 protocol test specifications

**Source:** ⌘ Vodafone D2 GmbH

**Work item code:** ⌘ TEI

**Date:** ⌘ 23.05.2002

**Category:** ⌘ **F**

Use one of the following categories:

**F** (correction)

**A** (corresponds to a correction in an earlier release)

**B** (addition of feature),

**C** (functional modification of feature)

**D** (editorial modification)

Detailed explanations of the above categories can be found in 3GPP [TR 21.900](#).

**Release:** ⌘ Rel-5

Use one of the following releases:

**2** (GSM Phase 2)

**R96** (Release 1996)

**R97** (Release 1997)

**R98** (Release 1998)

**R99** (Release 1999)

**REL-4** (Release 4)

**REL-5** (Release 5)

**Reason for change:** ⌘ New Test Cases applicable for REL-5 added. Therefore a REL-5 Test Specification is required. Since the Protocol Test Specifications of 3GPP TSG-T WG1 are merged, only the latest version of the Protocol Test Specification will be maintained.

Annex B is deleted since it is not necessary to maintain this.

**Summary of change:** ⌘ Addition of references to Release 5, Deletion of Annex B

**Consequences if not approved:** ⌘ High effort for the maintenance of the specification, what will slow down the progress of the group.

**Clauses affected:** ⌘ Front Page, Introduction, s1, s2, Annex B

**Other specs affected:** ⌘ ☐ Other core specifications  
⌘ ☒ Test specifications  
⌘ ☐ O&M Specifications

3GPP TS 34.123-2

**Other comments:** ⌘



# 3GPP TS 34.123-1 ~~V4~~V5.~~20~~.0 (2002-~~03~~06)

---

*Technical Specification*

## **3rd Generation Partnership Project; Technical Specification Group Terminals; User Equipment (UE) conformance specification; Part 1: Protocol conformance specification (Release ~~4~~5)**

---



The present document has been developed within the 3<sup>rd</sup> Generation Partnership Project (3GPP<sup>TM</sup>) and may be further elaborated for the purposes of 3GPP.

The present document has not been subject to any approval process by the 3GPP Organisational Partners and shall not be implemented.  
This Specification is provided for future development work within 3GPP only. The Organisational Partners accept no liability for any use of this Specification.  
Specifications and reports for implementation of the 3GPP<sup>TM</sup> system should be obtained via the 3GPP Organisational Partners' Publications Offices.

---

---

**Keywords**

mobile, MS, terminal, testing, UMTS

---

**3GPP**

---

**Postal address**

---

**3GPP support office address**

650 Route des Lucioles - Sophia Antipolis  
Valbonne - FRANCE  
Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

---

**Internet**

<http://www.3gpp.org>

---

**Copyright Notification**

---

No part may be reproduced except as authorized by written permission.  
The copyright and the foregoing restriction extend to reproduction in all media.

© 2002, 3GPP Organizational Partners (ARIB, CWTS, ETSI, T1, TTA, TTC).  
All rights reserved.



---

## Foreword

This Technical Specification (TS) has been produced by the 3<sup>rd</sup> Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
  - 1 presented to TSG for information;
  - 2 presented to TSG for approval;
  - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

---

## Introduction

The present document is the first part of a multi-part conformance specification valid for 3GPP Release 1999, and 3GPP Release 4 and 3GPP Release 5. 3GPP TS 34.123-2 [11] contains a pro-forma for the Implementation Conformance Statement (ICS) and an applicability table, indicating the release from which each test case is applicable. 3GPP TS 34.123-3 [12] contains a detailed and executable description of the test cases written in a standard testing language, TTCN, as defined in ISO/IEC 9646.

For at least a minimum set of services, the prose descriptions of test cases will have a matching detailed test case implemented in TTCN [12].

For Release 1999, the minimum set of services are defined as:

- voice calls;
- emergency calls;
- SMS (both Point-to-point and Cell broadcast);
- Circuit Switched data at up to 64 k bits/second;
- fax;

including the underlying layers to support these services.

Release 1999 will also include the areas:

- auto-calling restrictions.

The present document may contain descriptions of tests for additional services, but these tests may not have matching TTCN test cases.

The present document will not contain any tests on the USIM, or the interface between the UE and the USIM. These tests are documented elsewhere.

---

# 1 Scope

The present document specifies the protocol conformance testing for the 3<sup>rd</sup> Generation User Equipment (UE).

This is the first part of a multi-part test specification. The following information can be found in this part:

- the overall test structure;
- the test configurations;
- the conformance requirement and reference to the core specifications;
- the test purposes; and
- a brief description of the test procedure, the specific test requirements and short message exchange table.

The following information relevant to testing can be found in accompanying specifications:

- the default setting of the test parameters [9];
- the applicability of each test case [11].

A detailed description of the expected sequence of messages can be found in the 3<sup>rd</sup> part of this test specification.

The Implementation Conformance Statement (ICS) pro-forma can be found in the 2<sup>nd</sup> part of the present document.

The present document is valid for UE implemented according to 3GPP Release 1999, ~~or~~ 3GPP Release 4 or 3GPP Release 5.

---

# 2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document in the same Release as the present document.
  - For a Release 1999 UE, references to 3GPP documents are to version 3.x.y, when available.
  - For a Release 4 UE, references to 3GPP documents are to version 4.x.y, when available.
  - For a Release 5 UE, references to 3GPP documents are to version 5.x.y, when available.

- [1] 3GPP TR 21.905: "Vocabulary for 3GPP Specifications".
- [2] 3GPP TS 23.003: "Numbering, Addressing and Identification".
- [3] 3GPP TS 23.122: "Non-Access-Stratum functions related to Mobile Station (MS) in idle mode".
- [4] 3GPP TS 24.008: "Mobile Radio Interface Layer 3 specification; Core Network Protocols; Stage 3".
- [5] 3GPP TS 25.214: "Physical layer procedures (FDD)".
- [6] 3GPP TS 25.321: "MAC protocol specification".

- [7] 3GPP TS 25.322: "RLC protocol specification".
- [8] 3GPP TS 25.331: "RRC Protocol Specification".
- [9] 3GPP TS 34.108: "Common Test Environments for User Equipment (UE) Conformance Testing".
- [10] 3GPP TS 34.109: "Terminal logical test interface; Special conformance testing functions".
- [11] 3GPP TS 34.123-2: "User Equipment (UE) conformance specification; Part 2: Implementation Conformance Statement (ICS) proforma specification".
- [12] 3GPP TS 34.123-3: "User Equipment (UE) conformance specification; Part 3: Abstract Test Suites (ATS)".
- [13] 3GPP TS 51.010-1: "Mobile Station (MS) conformance specification; Part 1: Conformance specification".
- [14] ISO/IEC 9646 (all parts): "Information technology - Open Systems Interconnection - Conformance testing methodology and framework".
- [15] 3GPP TS 25.304: "UE Procedures in Idle Mode and Procedures for Cell Reselection in Connected Mode".
- [16] 3GPP TS 34.121: "Terminal Conformance Specification; Radio Transmission and Reception (FDD)".
- [17] 3GPP TS 34.122: "Terminal Conformance Specification; Radio Transmission and Reception (TDD)".
- [18] 3GPP TS 31.102: "Characteristics of the USIM Application".
- [19] 3GPP TS 25.224: "Physical Layer Procedures (TDD)".
- [20] 3GPP TS 25.215: "Physical layer - Measurements (FDD)".
- [21] 3GPP TS 25.101: "UE Radio Transmission and Reception (FDD)".
- [22] 3GPP TS 25.123: "Requirements for support of radio resource management (TDD)".
- [23] 3GPP TS 25.133: "Requirements for Support of Radio Resource Management (FDD)".
- [24] 3GPP TS 03.22: "Functions related to Mobile Station (MS) in idle mode and group receive mode".
- [25] 3GPP TS 04.18: "Mobile radio interface layer 3 specification; Radio Resource Control Protocol".
- [26] 3GPP TS 05.08: "Radio Subsystem Link Control".
- [27] 3GPP TS 22.001: "Principles of circuit telecommunication services supported by a Public Land Mobile Network (PLMN)".
- [28] 3GPP TS 24.007: "Mobile radio interface signalling layer 3; General aspects".
- [29] 3GPP TS 25.211: "Physical channels and mapping of transport channels onto physical channels (FDD)".
- [30] 3GPP TS 25.323: "Packet Data Convergence Protocol (PDCP) Specification".
- [31] 3GPP TS 33.102: "3G Security; Security Architecture".
- [32] 3GPP TS 23.060: "General Packet Radio Service (GPRS) Service description; Stage 2".
- [33] Void.
- [34] 3GPP TS 23.040: "Technical realization of the Short Message Service (SMS)".
- [35] 3GPP TS 23.038: "Alphabets and language-specific information".

- [36] 3GPP TS 24.011: "Point-to-Point (PP) Short Message Service (SMS) support on mobile radio interface".
- [37] 3GPP TS 25.324: "Broadcast/Multicast Control BMC".
- [38] 3GPP TS 23.041: "Technical realization of Cell Broadcast Service (CBS)".
- [39] RFC 2507: "IP Header Compression".

...

## Annex B (informative): Core specification versions to which test cases relate

The table B.1 lists for each clause of the present document the related core specification version on which the test cases were based. Where the test cases have been partially updated towards the next released version, but this work has not completed yet, each change request considered is listed in the final column.

Table B.1

| Clause number | Clause heading                                               | Related core specifications | Current R99 version supported | Current Rel-4 version supported | Current change requests taken into account |
|---------------|--------------------------------------------------------------|-----------------------------|-------------------------------|---------------------------------|--------------------------------------------|
| 6             | Idle mode operations                                         | 25.304                      | 3.7.0                         |                                 |                                            |
|               |                                                              | 23.122                      | 3.7.0                         |                                 |                                            |
|               |                                                              | 31.102                      | 3.6.0                         |                                 |                                            |
|               |                                                              | 25.133                      | 3.6.0                         |                                 |                                            |
|               |                                                              | 25.123                      | 3.6.0                         |                                 |                                            |
|               |                                                              | TS 03.22                    | 8.5.0                         |                                 |                                            |
|               |                                                              | TS 05.08                    | 8.10.0                        |                                 |                                            |
| 7.1           | MAC                                                          | 25.321                      | 3.8.0                         |                                 |                                            |
| 7.2           | RLC                                                          | 25.322                      | 3.7.0                         |                                 |                                            |
| 7.3           | PDCCP                                                        | 25.323                      | 3.5.0                         |                                 |                                            |
| 7.4           | BMC                                                          | 25.324                      | 3.4.0                         |                                 |                                            |
| 8             | Radio Resource Control (RRC)                                 | 25.331                      | 3.7.0                         |                                 |                                            |
|               |                                                              | 04.18                       | 9.0.0                         |                                 |                                            |
| 9             | Elementary procedures of mobility management                 | 24.008                      | 3.8.0                         |                                 |                                            |
| 10            | Circuit Switched Call Control (CC)                           | 24.008                      | 3.7.0                         |                                 |                                            |
| 11            | Session Management Procedures                                | 24.008                      | 3.8.0                         |                                 |                                            |
| 12            | Elementary procedure for Packet Switched Mobility Management | 24.008                      | 3.8.0                         |                                 |                                            |
| 13            | General Tests                                                | 24.008                      | 3.8.0                         |                                 |                                            |
| 14            | Radio Bearer Services                                        | 34.108                      | 3.5.0                         |                                 |                                            |
| 15            | Supplementary Services                                       | N/A                         |                               |                                 |                                            |
| 16            | Short message service (SMS)                                  | 23.040                      | 3.5.0                         |                                 |                                            |
|               |                                                              | 23.041                      | 3.4.0                         |                                 |                                            |
|               |                                                              | 24.011                      | 3.6.0                         |                                 |                                            |
| 17            | User Equipment features (MMI, VHE, MexE, SAT)                |                             |                               |                                 |                                            |

## CHANGE REQUEST

⌘ **TS 34.123-1 CR 257** ⌘ rev **-** ⌘ Current version: **4.2.0** ⌘

For **HELP** on using this form, see bottom of this page or look at the pop-up text over the ⌘ symbols.

**Proposed change affects:** ⌘ (U)SIM ☐ ME/UE ☒ Radio Access Network ☐ Core Network ☐

|                        |                                                                                                                                                                                                                                                                                                                                                                               |              |                                                                                                                                                                                                                                 |
|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Title:</b>          | ⌘ CR to 34.123-1 REL-4: Inclusion of pointer to maintained specification                                                                                                                                                                                                                                                                                                      |              |                                                                                                                                                                                                                                 |
| <b>Source:</b>         | ⌘ Vodafone D2 GmbH                                                                                                                                                                                                                                                                                                                                                            |              |                                                                                                                                                                                                                                 |
| <b>Work item code:</b> | ⌘ TEI                                                                                                                                                                                                                                                                                                                                                                         | <b>Date:</b> | ⌘ 23.05.2002                                                                                                                                                                                                                    |
| <b>Category:</b>       | ⌘ <b>F</b><br>Use <u>one</u> of the following categories:<br><b>F</b> (correction)<br><b>A</b> (corresponds to a correction in an earlier release)<br><b>B</b> (addition of feature),<br><b>C</b> (functional modification of feature)<br><b>D</b> (editorial modification)<br>Detailed explanations of the above categories can be found in 3GPP <a href="#">TR 21.900</a> . |              | <b>Release:</b> ⌘ <b>R99+</b><br>Use <u>one</u> of the following releases:<br>2 (GSM Phase 2)<br>R96 (Release 1996)<br>R97 (Release 1997)<br>R98 (Release 1998)<br>R99 (Release 1999)<br>REL-4 (Release 4)<br>REL-5 (Release 5) |

|                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|--------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Reason for change:</b>            | ⌘ It is proposed to create the new REL-5 of 34.123-1 as a merged document with the R99 and REL-4 specification. As consequence, the R99 and REL-4 specification will be no longer maintained.<br>In order to avoid confusion, a pointer to the maintained version of the specification is included in 34.123-1 R99 and REL-4 and the specification can be closed after the implementation of this CR.<br>Note: All the testcases related to R99 and REL-4 can be found in TS 34.123-1 REL-5. |
| <b>Summary of change:</b>            | ⌘ Deletion of text and inclusion of pointer to the updated version of the specification                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Consequences if not approved:</b> | ⌘ It will not be clear that this release of the specification is not longer maintained.                                                                                                                                                                                                                                                                                                                                                                                                      |

|                              |                                                                                                                                                                    |                    |  |
|------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|--|
| <b>Clauses affected:</b>     | ⌘ All                                                                                                                                                              |                    |  |
| <b>Other specs affected:</b> | ⌘ <input type="checkbox"/> Other core specifications<br>⌘ <input checked="" type="checkbox"/> Test specifications<br>⌘ <input type="checkbox"/> O&M Specifications | ⌘ 3GPP TS 34.123-2 |  |
| <b>Other comments:</b>       | ⌘                                                                                                                                                                  |                    |  |

## CHANGE REQUEST

⌘ **TS 34.123-1 CR 255** ⌘ rev **-** ⌘ Current version: **4.2.0** ⌘

For **HELP** on using this form, see bottom of this page or look at the pop-up text over the ⌘ symbols.

**Proposed change affects:** ⌘ (U)SIM ☐ ME/UE ☒ Radio Access Network ☐ Core Network ☐

|                                                                                                |                                                                                   |              |                         |
|------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|--------------|-------------------------|
| <b>Title:</b>                                                                                  | ⌘ CR to section 16.1.6 & 16.2.6: Addition of test of short message type 0 (CS/PS) |              |                         |
| <b>Source:</b>                                                                                 | ⌘ Vodafone D2 GmbH                                                                |              |                         |
| <b>Work item code:</b>                                                                         | ⌘ TEI                                                                             | <b>Date:</b> | ⌘ 22.05.2002            |
| <b>Category:</b>                                                                               | ⌘ <b>F</b>                                                                        |              | <b>Release:</b> ⌘ REL-5 |
| Use <u>one</u> of the following categories:                                                    |                                                                                   |              |                         |
| <b>F</b> (correction)                                                                          |                                                                                   |              |                         |
| <b>A</b> (corresponds to a correction in an earlier release)                                   |                                                                                   |              |                         |
| <b>B</b> (addition of feature),                                                                |                                                                                   |              |                         |
| <b>C</b> (functional modification of feature)                                                  |                                                                                   |              |                         |
| <b>D</b> (editorial modification)                                                              |                                                                                   |              |                         |
| Detailed explanations of the above categories can be found in 3GPP <a href="#">TR 21.900</a> . |                                                                                   |              |                         |
| Use <u>one</u> of the following releases:                                                      |                                                                                   |              |                         |
| 2 (GSM Phase 2)                                                                                |                                                                                   |              |                         |
| R96 (Release 1996)                                                                             |                                                                                   |              |                         |
| R97 (Release 1997)                                                                             |                                                                                   |              |                         |
| R98 (Release 1998)                                                                             |                                                                                   |              |                         |
| R99 (Release 1999)                                                                             |                                                                                   |              |                         |
| REL-4 (Release 4)                                                                              |                                                                                   |              |                         |
| REL-5 (Release 5)                                                                              |                                                                                   |              |                         |

|                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|--------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Reason for change:</b>            | ⌘ For SMS Type 0 there is currently no test existing. However, this feature is used by many network operators in order to get UE positioning data or to check whether an UE is 'on air' in the network. An UE receiving such a message shall behave according to the core specifications. Since the conformance requirement has been made harder from REL-4 to REL-5, the REL-5 relevant Test Cases have been created as sections 16.1.6a and 16.2.6a respectively. |
| <b>Summary of change:</b>            | ⌘ Addition of a new test in section 16.1.6 & 16.1.6a (CS) and 16.2.6 & 16.2.6a (PS)                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Consequences if not approved:</b> | ⌘ The UE is not tested according to this requirement and may show service affecting behaviour when receiving a Type 0 Short Message                                                                                                                                                                                                                                                                                                                                 |

|                              |                                                             |   |                  |
|------------------------------|-------------------------------------------------------------|---|------------------|
| <b>Clauses affected:</b>     | ⌘ Section 16.1.6/6a & 16.2.6/6a, new test                   |   |                  |
| <b>Other specs affected:</b> | ⌘ <input type="checkbox"/> Other core specifications        | ⌘ | 3GPP TS 34.123-2 |
|                              | <input checked="" type="checkbox"/> Test specifications     |   |                  |
|                              | <input type="checkbox"/> O&M Specifications                 |   |                  |
| <b>Other comments:</b>       | ⌘ The corresponding test case of 3GPP TS 51.010-1 is 34.2.6 |   |                  |



## 16.1.6 Test of short message type 0 (R99 and REL-4 UE)

For further study:

### 16.1.6.1 Definition and applicability

This tests that the UE correctly acknowledges the receipt of the short message type 0 to the SC in Circuit Switched mode. It is highly recommended that the UE discards the contents of the short message type 0.

This test shall apply to all R99 and REL-4 UEs supporting receipt of short messages in CS mode.

### 16.1.6.2 Conformance requirement

When a mobile terminated message is type 0, the UE shall acknowledge receipt of the short message to the SC but may discard its contents.

Note: It is highly recommended that the UE discards the type 0 short message. This means that the UE is able to receive the type 0 short message irrespective of whether there is memory available in the (U)SIM or ME or not, the UE does not indicate the receipt of the type 0 short message to the user, and the message is not stored in the (U)SIM or ME.

### Reference(s)

3GPP TS 23.040, 9.2.3.9.

### 16.1.6.3 Test purpose

To verify that the UE will acknowledge receipt of the short message to the SC. The UE should discard its contents.

NOTE: failure of this test in a UE could cause it to reject a type 0 message when the network is trying to reach the UE. This could lead to unwanted repetitions between the US and the service centre.

### 16.1.6.4 Method of test

#### Initial conditions

#### System Simulator:

1 cell, default parameters.

#### User Equipment:

the UE shall be in MM-state "Idle, updated".

#### Related ICS/IXIT Statements

Support for Short Message MT/PP.

The value of timer TC1M.

#### Foreseen Final State of UE

Idle, updated.

#### Test Procedure

The SS sends a type 0 message by using the method described in step a) of section 16.1.1 but with the TPDU described in this section.

Maximum Duration of Test1 minuteExpected Sequence

| <u>Step</u> | <u>Direction</u> |           | <u>Message</u>                                                      | <u>Comments</u>                                                                                                                                                                                                                                                                                                                                                  |
|-------------|------------------|-----------|---------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|             | <u>UE</u>        | <u>SS</u> |                                                                     |                                                                                                                                                                                                                                                                                                                                                                  |
| <u>1</u>    |                  |           | <u>Mobile terminated establishment of Radio Resource Connection</u> | <u>See 3GPP TS34.108</u>                                                                                                                                                                                                                                                                                                                                         |
| <u>2</u>    |                  | -->       | <u>PAGING RESPONSE</u>                                              |                                                                                                                                                                                                                                                                                                                                                                  |
| <u>3</u>    |                  | <--       | <u>AUTHENTICATION REQUEST</u>                                       |                                                                                                                                                                                                                                                                                                                                                                  |
| <u>4</u>    |                  | -->       | <u>AUTHENTICATION RESPONSE</u>                                      |                                                                                                                                                                                                                                                                                                                                                                  |
| <u>5</u>    |                  | <--       | <u>SECURITY MODE COMMAND</u>                                        |                                                                                                                                                                                                                                                                                                                                                                  |
| <u>6</u>    |                  | -->       | <u>SECURITY MODE COMPLETE</u>                                       |                                                                                                                                                                                                                                                                                                                                                                  |
| <u>7</u>    |                  | <--       | <u>CP-DATA</u>                                                      | <u>Contains RP-DATA RPDU (SMS DELIVER TPDU), type 0 Short Message</u>                                                                                                                                                                                                                                                                                            |
| <u>8</u>    |                  | -->       | <u>CP-ACK</u>                                                       |                                                                                                                                                                                                                                                                                                                                                                  |
| <u>9</u>    |                  | -->       | <u>CP-DATA</u>                                                      | <u>Contains RP-ACK TP-Protocol-Identifier (TP-PID).</u>                                                                                                                                                                                                                                                                                                          |
| <u>10</u>   |                  | <--       | <u>CP-ACK</u>                                                       |                                                                                                                                                                                                                                                                                                                                                                  |
| <u>11</u>   |                  | <--       | <u>RRC CONNECTION RELEASE</u>                                       |                                                                                                                                                                                                                                                                                                                                                                  |
| <u>12</u>   |                  | -->       | <u>RRC CONNECTION RELEASE COMPLETE</u>                              |                                                                                                                                                                                                                                                                                                                                                                  |
| <u>13</u>   | <u>UE</u>        |           |                                                                     | <u>It is highly recommended that the UE discards the type 0 short message. This means that the UE is able to receive the type 0 short message irrespective of whether there is memory available in the (U)SIM or ME or not, the UE does not indicate the receipt of the type 0 short message to the user, and the message is not stored in the (U)SIM or ME.</u> |

Specific Message Contents:SMS-DELIVER TPDU (containing a type 0 message) (SS to UE):

| <u>Information element</u> | <u>Comment/Value</u>                        |
|----------------------------|---------------------------------------------|
| <u>TP-MIT</u>              | <u>SMS-DELIVER "00"B</u>                    |
| <u>TP-MMS</u>              | <u>more messages are waiting in SC "0"B</u> |
| <u>TP-RP</u>               | <u>no reply path "0"B</u>                   |
| <u>TP-UDHI</u>             | <u>TP-UD contains only the SM"0"B</u>       |
| <u>TP-SRI</u>              | <u>no status report returned0</u>           |
| <u>TP-OA</u>               | <u>an international number coded E.164</u>  |
| <u>TP-PID</u>              | <u>Type 0: "01000000"B</u>                  |
| <u>TP-DCS</u>              | <u>default alphabet "0000 0000"B</u>        |
| <u>TP-SCTS</u>             | <u>any legal value (cf. 3GPP TS 23.040)</u> |
| <u>TP-UDL</u>              | <u>160</u>                                  |
| <u>TP-UD (140 octets)</u>  | <u>text of message (160 characters)</u>     |

16.1.6a Test of short message type 0 (≥ REL-5 UE)16.1.6a.1 Definition and applicability

This tests that the UE correctly acknowledges the receipt of the short message type 0 to the SC in Circuit Switched mode. The UE shall discard the contents of the short message type 0.

This test shall apply to all ≥ REL-5 UEs supporting receipt of short messages in CS mode.

16.1.6a.2 Conformance requirement

When a mobile terminated message is type 0, the UE shall acknowledge receipt of the short message to the SC but shall discard its contents. This means that

- the UE shall be able to receive the type 0 short message irrespective of whether there is memory available in the (U)SIM or ME or not,
- the UE shall not indicate the receipt of the type 0 short message to the user,
- the short message shall neither be stored in the (U)SIM nor ME.

#### Reference(s)

3GPP TS 23.040, 9.2.3.9.

#### 16.1.6a.3 Test purpose

To verify that the UE will acknowledge receipt of the short message to the SC. The UE shall discard its contents. This means that

- the UE shall be able to receive the type 0 short message irrespective of whether there is memory available in the (U)SIM or ME or not,
- the UE shall not indicate the receipt of the type 0 short message to the user,
- the short message shall neither be stored in the (U)SIM nor ME.

NOTE: failure of this test in a UE could cause it to reject a type 0 message when the network is trying to reach the UE. This could lead to unwanted repetitions between the US and the service centre. In addition service affecting restrictions could happen to the customer.

#### 16.1.6a.4 Method of test

##### Initial conditions

##### System Simulator:

1 cell, default parameters.

##### User Equipment:

the UE shall be in MM-state "Idle, updated".

the ME- and (U)SIM message store shall be empty.

##### Related ICS/IXIT Statements

Support for Short Message MT/PP.

Whether SMS messages are stored in the USIM and/or the ME.

UE capable of displaying short messages

The value of timer TC1M.

##### Foreseen Final State of UE

Idle, updated.

##### Test Procedure

- a) The SS sends a type 0 short message by using the method described in step a) of clause 16.1.1 but with the TPDU described in this section.
- b) The ME- and (U)SIM short message store shall be filled (for example by using the method of clause 16.1.3 test of the memory available notification).
- c) The SS sends a type 0 short message as in step a).

Maximum Duration of Test5 minutesExpected sequence

| <u>Step</u> | <u>Direction</u> |               | <u>Message</u>                                                      | <u>Comments</u>                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-------------|------------------|---------------|---------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|             | <u>UE</u>        | <u>SS</u>     |                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>1</u>    |                  |               | <u>Mobile terminated establishment of Radio Resource Connection</u> | <u>See 3GPP TS34.108</u>                                                                                                                                                                                                                                                                                                                                                                                                               |
| <u>2</u>    |                  | <u>--&gt;</u> | <u>PAGING RESPONSE</u>                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>3</u>    |                  | <u>&lt;--</u> | <u>AUTHENTICATION REQUEST</u>                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>4</u>    |                  | <u>--&gt;</u> | <u>AUTHENTICATION RESPONSE</u>                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>5</u>    |                  | <u>&lt;--</u> | <u>SECURITY MODE COMMAND</u>                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>6</u>    |                  | <u>--&gt;</u> | <u>SECURITY MODE COMPLETE</u>                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>7</u>    |                  | <u>&lt;--</u> | <u>CP-DATA</u>                                                      | <u>Contains RP-DATA RPDU (SMS DELIVER TPDU), type 0 Short Message</u>                                                                                                                                                                                                                                                                                                                                                                  |
| <u>8</u>    |                  | <u>--&gt;</u> | <u>CP-ACK</u>                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>9</u>    |                  | <u>--&gt;</u> | <u>CP-DATA</u>                                                      | <u>Contains RP-ACK TP-Protocol-Identifier (TP-PID).</u>                                                                                                                                                                                                                                                                                                                                                                                |
| <u>10</u>   |                  | <u>&lt;--</u> | <u>CP-ACK</u>                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>11</u>   |                  | <u>&lt;--</u> | <u>RRC CONNECTION RELEASE</u>                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>12</u>   |                  | <u>--&gt;</u> | <u>RRC CONNECTION RELEASE COMPLETE</u>                              |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>13</u>   | <u>UE</u>        |               |                                                                     | <u>The UE shall discard the type 0 short message. This means that the UE does not indicate the receipt of the type 0 short message to the user. The UE shall not store the message in the (U)SIM or ME. This can be checked by verifying that it is impossible to retrieve any short messages from the ME- and (U)SIM message store. The ME- and (U)SIM message store shall be filled (for example by using the method of 16.1.3).</u> |
| <u>14</u>   |                  | <u>SS</u>     |                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>15</u>   |                  |               | <u>Mobile terminated establishment of Radio Resource Connection</u> | <u>See 3GPP TS34.108</u>                                                                                                                                                                                                                                                                                                                                                                                                               |
| <u>16</u>   |                  | <u>--&gt;</u> | <u>PAGING RESPONSE</u>                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>17</u>   |                  | <u>&lt;--</u> | <u>AUTHENTICATION REQUEST</u>                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>18</u>   |                  | <u>--&gt;</u> | <u>AUTHENTICATION RESPONSE</u>                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>19</u>   |                  | <u>&lt;--</u> | <u>SECURITY MODE COMMAND</u>                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>20</u>   |                  | <u>--&gt;</u> | <u>SECURITY MODE COMPLETE</u>                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>21</u>   |                  | <u>&lt;--</u> | <u>CP-DATA</u>                                                      | <u>Contains RP-DATA RPDU (SMS DELIVER TPDU), type 0 Short Message</u>                                                                                                                                                                                                                                                                                                                                                                  |
| <u>22</u>   |                  | <u>--&gt;</u> | <u>CP-ACK</u>                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>23</u>   |                  | <u>--&gt;</u> | <u>CP-DATA</u>                                                      | <u>Contains RP-ACK TP-Protocol-Identifier (TP-PID).</u>                                                                                                                                                                                                                                                                                                                                                                                |
| <u>24</u>   |                  | <u>&lt;--</u> | <u>CP-ACK</u>                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>25</u>   |                  | <u>&lt;--</u> | <u>RRC CONNECTION RELEASE</u>                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>26</u>   |                  | <u>--&gt;</u> | <u>RRC CONNECTION RELEASE COMPLETE</u>                              |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>27</u>   | <u>UE</u>        |               |                                                                     | <u>The UE shall discard the type 0 short message. This means that the UE does not indicate the receipt of the type 0 short message to the user. The UE shall not store the message in the (U)SIM or ME. This can be checked by verifying that it is impossible to retrieve any short messages from the ME- and (U)SIM message store.</u>                                                                                               |

Specific Message Contents:SMS-DELIVER TPDU (containing a type 0 message) (SS to UE):

| <u>Information element</u> | <u>CommentValue</u>                         |
|----------------------------|---------------------------------------------|
| <u>TP-MIT</u>              | <u>SMS-DELIVER "00"B</u>                    |
| <u>TP-MMS</u>              | <u>more messages are waiting in SC "0"B</u> |
| <u>TP-RP</u>               | <u>no reply path "0"B</u>                   |
| <u>TP-UDHI</u>             | <u>TP-UD contains only the SM"0"B</u>       |
| <u>TP-SRI</u>              | <u>no status report returned0</u>           |
| <u>TP-OA</u>               | <u>an international number coded E.164</u>  |
| <u>TP-PID</u>              | <u>Type 0: "01000000"B</u>                  |
| <u>TP-DCS</u>              | <u>default alphabet "0000 0000"B</u>        |
| <u>TP-SCTS</u>             | <u>any legal value (cf. 3GPP TS 23.040)</u> |
| <u>TP-UDL</u>              | <u>160</u>                                  |
| <u>TP-UD (140 octets)</u>  | <u>text of message (160 characters)</u>     |

[...]

## 16.2 Short message service point to point on PS mode

All of test cases in this clause are applied to the UE supported PS mode.

[...]

### 16.2.6 Test of short message type 0 (R99 and REL-4 UE)

For further study:

#### 16.2.6.1 Definition and applicability

This tests that the UE correctly acknowledges the receipt of the short message type 0 to the SC in Packet Switched mode. It is highly recommended that the UE discards the contents of the short message type 0.

This test shall apply to all R99 and REL-4 UEs supporting receipt of short messages in PS mode.

#### 16.2.6.2 Conformance requirement

When a mobile terminated message is type 0, the UE shall acknowledge receipt of the short message to the SC but may discard its contents.

Note: It is highly recommended that the UE discards the type 0 short message. This means that the UE is able to receive the type 0 short message irrespective of whether there is memory available in the (U)SIM or ME or not, the UE does not indicate the receipt of the type 0 short message to the user, and the message is not stored in the (U)SIM or ME.

#### Reference(s)

3GPP TS 23.040, 9.2.3.9.

#### 16.2.6.3 Test purpose

To verify that the UE will acknowledge receipt of the short message to the SC. The UE should discard its contents.

NOTE: failure of this test in a UE could cause it to reject a type 0 message when the network is trying to reach the UE. This could lead to unwanted repetitions between the US and the service centre.



Specific Message Contents:SMS-DELIVER TPDU (containing a type 0 message) (SS to UE):

| <u>Information element</u> | <u>CommentValue</u>                  |
|----------------------------|--------------------------------------|
| TP-MIT                     | SMS-DELIVER "00"B                    |
| TP-MMS                     | more messages are waiting in SC "0"B |
| TP-RP                      | no reply path "0"B                   |
| TP-UDHI                    | TP-UD contains only the SM"0"B       |
| TP-SRI                     | no status report returned0           |
| TP-OA                      | an international number coded E.164  |
| TP-PID                     | Type 0: "01000000"B                  |
| TP-DCS                     | default alphabet "0000 0000"B        |
| TP-SCTS                    | any legal value (cf. 3GPP TS 23.040) |
| TP-UDL                     | 160                                  |
| TP-UD (140 octets)         | text of message (160 characters)     |

16.2.6a Test of short message type 0 ( $\geq$  REL-5 UE)16.2.6a.1 Definition and applicability

This tests that the UE correctly acknowledges the receipt of the short message type 0 to the SC in Packet Switched mode. The UE discards the contents of the short message type 0.

This test shall apply to all  $\geq$  REL-5 UEs supporting receipt of short messages in PS mode.

16.2.6a.2 Conformance requirement

When a mobile terminated message is type 0, the UE shall acknowledge receipt of the short message to the SC but shall discard its contents. This means that

- the UE shall be able to receive the type 0 short message irrespective of whether there is memory available in the (U)SIM or ME or not,
- the UE shall not indicate the receipt of the type 0 short message to the user,
- the short message shall neither be stored in the (U)SIM nor ME.

Reference(s)

3GPP TS 23.040, 9.2.3.9.

16.2.6a.3 Test purpose

To verify that the UE will acknowledge receipt of the short message to the SC. The UE shall discard its contents. This means that

- the UE shall be able to receive the type 0 short message irrespective of whether there is memory available in the (U)SIM or ME or not,
- the UE shall not indicate the receipt of the type 0 short message to the user,
- the short message shall neither be stored in the (U)SIM nor ME.

NOTE: failure of this test in a UE could cause it to reject a type 0 message when the network is trying to reach the UE. This could lead to unwanted repetitions between the US and the service centre. In addition service affecting restrictions could happen to the customer.

16.2.6a.4 Method of testInitial conditionsSystem Simulator:

1 cell, default parameters.

User Equipment:

the UE shall be in GMM-state "GMM-REGISTERED";

the ME- and (U)SIM message store shall be empty.

Related ICS/IXIT Statements

Support for Short Message MT/PP.

Whether SMS messages are stored in the USIM and/or the ME.

UE capable of displaying short messages

The value of timer TC1M.

Foreseen Final State of UE

Idle, updated.

Test Procedure

- a) The SS sends a type 0 short message by using the method described in step a) of clause 16.2.1 but with the TPDU described in this section.
- b) The ME- and (U)SIM short message store shall be filled (for example by using the method of clause 16.2.3 test of the memory available notification).
- c) The SS sends a type 0 short message as in step a).

Maximum Duration of Test

5 minutes



Expected sequence

| <u>Step</u> | <u>Direction</u> |               | <u>Message</u>                                                      | <u>Comments</u>                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-------------|------------------|---------------|---------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|             | <u>UE</u>        | <u>SS</u>     |                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>1</u>    |                  |               | <u>Mobile terminated establishment of Radio Resource Connection</u> | <u>See 3GPP TS34.108</u>                                                                                                                                                                                                                                                                                                                                                                                                               |
| <u>2</u>    |                  | <u>:-&gt;</u> | <u>SERVICE REQUEST</u>                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>3</u>    |                  | <u>&lt;:-</u> | <u>AUTHENTICATION AND CIPHERING REQUEST</u>                         |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>4</u>    |                  | <u>:-&gt;</u> | <u>AUTHENTICATION AND CIPHERING RESPONSE</u>                        |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>5</u>    |                  | <u>&lt;:-</u> | <u>SECURITY MODE COMMAND</u>                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>6</u>    |                  | <u>:-&gt;</u> | <u>SECURITY MODE COMPLETE</u>                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>7</u>    |                  | <u>&lt;:-</u> | <u>CP-DATA</u>                                                      | <u>Contains RP-DATA RPDU (SMS DELIVER TPDU), type 0 Short Message</u>                                                                                                                                                                                                                                                                                                                                                                  |
| <u>8</u>    |                  | <u>:-&gt;</u> | <u>CP-ACK</u>                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>9</u>    |                  | <u>:-&gt;</u> | <u>CP-DATA</u>                                                      | <u>Contains RP-ACK TP-Protocol-Identifier (TP-PID).</u>                                                                                                                                                                                                                                                                                                                                                                                |
| <u>10</u>   |                  | <u>&lt;:-</u> | <u>CP-ACK</u>                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>11</u>   |                  | <u>&lt;:-</u> | <u>RRC CONNECTION RELEASE</u>                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>12</u>   |                  | <u>:-&gt;</u> | <u>RRC CONNECTION RELEASE COMPLETE</u>                              |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>13</u>   | <u>UE</u>        |               |                                                                     | <u>The UE shall discard the type 0 short message. This means that the UE does not indicate the receipt of the type 0 short message to the user. The UE shall not store the message in the (U)SIM or ME. This can be checked by verifying that it is impossible to retrieve any short messages from the ME- and (U)SIM message store. The ME- and (U)SIM message store shall be filled (for example by using the method of 16.1.3).</u> |
| <u>14</u>   |                  | <u>SS</u>     |                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>15</u>   |                  |               | <u>Mobile terminated establishment of Radio Resource Connection</u> | <u>See 3GPP TS34.108</u>                                                                                                                                                                                                                                                                                                                                                                                                               |
| <u>2</u>    |                  | <u>:-&gt;</u> | <u>SERVICE REQUEST</u>                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>3</u>    |                  | <u>&lt;:-</u> | <u>AUTHENTICATION AND CIPHERING REQUEST</u>                         |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>4</u>    |                  | <u>:-&gt;</u> | <u>AUTHENTICATION AND CIPHERING RESPONSE</u>                        |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>16</u>   |                  | <u>:-&gt;</u> | <u>PAGING RESPONSE</u>                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>17</u>   |                  | <u>&lt;:-</u> | <u>AUTHENTICATION REQUEST</u>                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>18</u>   |                  | <u>:-&gt;</u> | <u>AUTHENTICATION RESPONSE</u>                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>19</u>   |                  | <u>&lt;:-</u> | <u>SECURITY MODE COMMAND</u>                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>20</u>   |                  | <u>:-&gt;</u> | <u>SECURITY MODE COMPLETE</u>                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>21</u>   |                  | <u>&lt;:-</u> | <u>CP-DATA</u>                                                      | <u>Contains RP-DATA RPDU (SMS DELIVER TPDU), type 0 Short Message</u>                                                                                                                                                                                                                                                                                                                                                                  |
| <u>22</u>   |                  | <u>:-&gt;</u> | <u>CP-ACK</u>                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>23</u>   |                  | <u>:-&gt;</u> | <u>CP-DATA</u>                                                      | <u>Contains RP-ACK TP-Protocol-Identifier (TP-PID).</u>                                                                                                                                                                                                                                                                                                                                                                                |
| <u>24</u>   |                  | <u>&lt;:-</u> | <u>CP-ACK</u>                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>25</u>   |                  | <u>&lt;:-</u> | <u>RRC CONNECTION RELEASE</u>                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>26</u>   |                  | <u>:-&gt;</u> | <u>RRC CONNECTION RELEASE COMPLETE</u>                              |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <u>27</u>   | <u>UE</u>        |               |                                                                     | <u>The UE shall discard the type 0 short message. This means that the UE does not indicate the receipt of the type 0 short message to the user. The UE shall not store the message in the (U)SIM or ME. This can be checked by verifying that it is impossible to retrieve any short messages from the ME- and (U)SIM message store.</u>                                                                                               |

Specific Message Contents:SMS-DELIVER TPDU (containing a type 0 message) (SS to UE):

| <u>Information element</u> | <u>Comment Value</u>                        |
|----------------------------|---------------------------------------------|
| <u>TP-MIT</u>              | <u>SMS-DELIVER "00"B</u>                    |
| <u>TP-MMS</u>              | <u>more messages are waiting in SC "0"B</u> |
| <u>TP-RP</u>               | <u>no reply path "0"B</u>                   |
| <u>TP-UDHI</u>             | <u>TP-UD contains only the SM"0"B</u>       |
| <u>TP-SRI</u>              | <u>no status report returned0</u>           |
| <u>TP-OA</u>               | <u>an international number coded E.164</u>  |
| <u>TP-PID</u>              | <u>Type 0: "01000000"B</u>                  |
| <u>TP-DCS</u>              | <u>default alphabet "0000 0000"B</u>        |
| <u>TP-SCTS</u>             | <u>any legal value (cf. 3GPP TS 23.040)</u> |
| <u>TP-UDL</u>              | <u>160</u>                                  |
| <u>TP-UD (140 octets)</u>  | <u>text of message (160 characters)</u>     |

...