Remote UE
Relay UE
gNB
0. UL/DL data
1. Measurement configuration and reporting
2. Decision of switching to a target relay UE
2. RRC Reconfiguration for remote UE
3. RRC Reconfiguration message
4. PC5 connection establishment, if not exist
5. RRC Reconfiguration Complete message
6. UL/DL data