releasePreferenceConfig
UEAssistanceInfo#1
UEAssistanceInfo#3
Time
Serving cell
UE
T346f
T1
releasePreference
= outofConnected
T2
Reverts preference
T4
releasePreference
= Connected
musim-LeaveAssistanceConfig
UEAssistanceInfo#2
Time
Serving cell
UE
T346g
T3
musim-PreferredRRC-State
=outofConnected
T5
Moves to
RRC Idle state