UE
AMF/SEAF
AUSF
UDM
PS
DCS
1. Registration Request(UE Universal ID)
2.Nausf_UEAuthentication_Authenticate Request (UE Universal ID, SN-name)
3. Nudm_UEAuthentication_Get Request (UE Universal ID, SN-name)
4. UDM identifies PS address according to UE Universal ID
5.Nudm_UEAuthentication_Get Response (PS address)
6. Authentication Request (UE Universal ID)
7. PS identifies the DCS address via UE Universal ID
8. Authentication Request (UE Universal ID)
9. EAP Authentication
10. Access accept (EAP Success)
11. Authentication Response/Access accept (EAP Success)
12. Authentication Response/Access accept (EAP Success)
13. Registration accept (EAP Success)
14. Provisioning of SNPN credential
15. Provisioning of SNPN credential