S3000601 Document (rev574)

## 3GPP TSG SA 3 Meeting #15 Washington, USA, 12-14 September 2000

e.g. for 3GPP use the format TP-99xxx or for SMG, use the format P-99-xxx

		CHANGE I	REQU	IEST		,	file at the bottom of a to fill in this form co	
		33.102	CR		Cu	ırrent Versi	on: 3.5.0	
GSM (AA.BB) or 3	G (AA.BBB) specific	cation number <sup>↑</sup>		↑ CF	R number as allo	ocated by MCC	support team	
For submission list expected approve	al meeting # here ↑	for infor		X		strate non-strate	gic use o	nly)
Form: CR cover sheet, version 2 for 3GPP and SMG  The latest version of this form is available from: ftp://ftp.3gpp.org/Information/CR-Form-v2.doc  Proposed change affects: (at least one should be marked with an X)  The latest version of this form is available from: ftp://ftp.3gpp.org/Information/CR-Form-v2.doc  WE UTRAN / Radio Core Network X								
Source:	Siemens					Date:	13 Sept. 200	00
Subject:	Change of	computation of the	e anonym	ity key ir	n the re-syr	nchronisatic	n procedure	
Work item:	Security							
(only one category	B Addition of C Functional	ds to a correction		ier relea	se X	Release:	Phase 2 Release 96 Release 97 Release 98 Release 99 Release 00	X
Reason for change:	cryptograp	sed new version is hic functions for au atisfying the secur	uthenticat	ion curre				
Clauses affecte	on 3.2, 6.3.3, 6.3.5							
Other specs Affected:	Other 3G co Other GSM specifica MS test specifica BSS test specification	itions cifications ecifications		List of List of List of List of List of List of	CRs: CRs: CRs:			
Other comments:								
help.doc								

<----- double-click here for help and instructions on how to create a CR.

## 3.2 Symbols

For the purposes of the present document, the following symbols apply:

	Concatenation				
$\oplus$	Exclusive or				
f1	Message authentication function used to compute MAC				
<u>f1*</u>	Message authentication function used to compute MAC-S				
f2	Message authentication function used to compute RES and XRES				
f3	Key generating function used to compute CK				
f4	Key generating function used to compute IK				
f5	Key generating function used to compute AK <u>in normal procedures</u>				
<u>f5*</u>	Key generating function used to compute AK in re-synchronisation procedures				
K	Long-term secret key shared between the USIM and the AuC				

## 6.3.3 Authentication and key agreement

The purpose of this procedure is to authenticate the user and establish a new pair of cipher and integrity keys between the VLR/SGSN and the USIM. During the authentication, the USIM verifies the freshness of the authentication vector that is used.




Figure 8: Authentication and key establishment

The VLR/SGSN invokes the procedure by selecting the next unused authentication vector from the ordered array of authentication vectors in the VLR/SGSN database. The VLR/SGSN sends to the USIM the random challenge RAND and an authentication token for network authentication AUTN from the selected authentication vector.

Upon receipt the user proceeds as shown in Figure 9.




Figure 9: User authentication function in the USIM

Upon receipt of RAND and AUTN the USIM first computes the anonymity key  $AK = f5_K$  (RAND) and retrieves the sequence number  $SQN = (SQN \oplus AK) \oplus AK$ .

Next the USIM computes XMAC =  $f1_K$  (SQN  $\parallel$  RAND  $\parallel$  AMF) and compares this with MAC which is included in AUTN. If they are different, the user sends *user authentication reject* back to the VLR/SGSN with an indication of the cause and the user abandons the procedure. In this case, VLR/SGSN shall initiate an Authentication Failure Report procedure towards the HLR as specified in section 6.3.6. VLR/SGSN may also decide to initiate a new identification and authentication procedure towards the user.

Next the USIM verifies that the received sequence number SQN is in the correct range.

If the USIM considers the sequence number to be not in the correct range, it sends *synchronisation failure* back to the VLR/SGSN including an appropriate parameter, and abandons the procedure.

The synchronisation failure message contains the parameter AUTS. It is AUTS =  $Conc(SQN_{MS}) \parallel MAC-S$ .  $Conc(SQN_{MS}) = SQN_{MS} \oplus f5_{K}^*(RANDMAC-S \parallel 0...0)$  is the concealed value of the counter  $SEQSQN_{MS}$  in the MS, and MAC-S =  $f1_{K}^*(SEQSQN_{MS}) \parallel RAND \parallel AMF)$  where RAND is the random value received in the current user authentication request.  $f1_{S}^*$  is a message authentication code (MAC) function with the property that no valuable information can be inferred from the function values of  $f1_{S}^*$  about those of  $f1_{S}^*$ , ...,  $f5_{S}^*$  and vice versa.  $f5_{S}^*$  is key generating function used to compute AK in re-synchronisation procedures with the property that no valuable information can be inferred from the function values of  $f5_{S}^*$  about those of  $f1_{S}^*$ ,  $f1_{S}^*$ , ...,  $f5_{S}^*$  and vice versa.

The AMF used to calculate MAC-S assumes a dummy value of all zeros so that it does not need to be transmitted in the clear in the re-synch message.

The construction of the parameter AUTS in shown in the following Figure 10:




Figure 10: Construction of the parameter




Figure 10: Construction of the parameter AUTS

If the sequence number is considered to be in the correct range however, the USIM computes RES =  $f2_K$  (RAND) and includes this parameter in a *user authentication response* back to the VLR/SGSN. Finally the USIM computes the cipher key CK =  $f3_K$  (RAND) and the integrity key IK =  $f4_K$  (RAND). Note that if this is more efficient, RES, CK and IK could also be computed earlier at any time after receiving RAND. If the USIM also supports conversion function c3, it shall derive the GSM cipher key Kc from the UMTS cipher/integrity keys CK and IK. UMTS keys are sent to the MS along with the derived GSM key for UMTS-GSM interoperability purposes. USIM shall store original CK, IK until the next successful execution of AKA.

Upon receipt of *user authentication response* the VLR/SGSN compares RES with the expected response XRES from the selected authentication vector. If XRES equals RES then the authentication of the user has passed. The VLR/SGSN also selects the appropriate cipher key CK and integrity key IK from the selected authentication vector. If XRES and RES are different, VLR/SGSN shall initiate an Authentication Failure Report procedure towards the HLR as specified in section 6.3.6. VLR/SGSN may also decide to initiate a new identification and authentication procedure towards the user.

Conditions on the use of authentication information by the VLR/SGSN: The VLR/SGSN shall use a UMTS authentication vector (i.e. a quintuplet) only once and, hence, shall send out each user authentication request *RAND* // *AUTN* only once no matter whether the authentication attempt was successful or not. A consequence is that UMTS authentication vectors (quintuplets) cannot be reused.

## 6.3.5 Re-synchronisation procedure

A VLR/SGSN may send two types of *authentication data requests* to the HE/AuC, the (regular) one described in subsection 6.3.2 and one used in case of synchronisation failures, described in this subsection.

Upon receiving a synchronisation failure message from the user, the VLR/SGSN sends an authentication data request

with a "synchronisation failure indication" to the HE/AuC, together with the parameters

- RAND sent to the MS in the preceding user authentication request and
- AUTS received by the VLR/SGSN in the response to that request, as described in subsection 6.3.3.

An VLR/SGSN will not react to unsolicited "synchronisation failure indication" messages from the MS.

The VLR/SGSN does not send new user authentication requests to the user before having received the response to its authentication data request from the HE/AuC (or before it is timed out).

When the HE/AuC receives an *authentication data request* with a "synchronisation failure indication" it acts as follows:

- 1. The HE/AuC retrieves  $\underline{SQNSEQ}_{MS}$  from  $Conc(\underline{SQNSEQ}_{MS})$  by computing  $f5 *_{K}(\underline{RANDMAC-S \parallel 0...0})$ ,.
- 2. The HE/AuC checks if <u>SQNSEQ</u><sub>HE</sub> is in the correct range, i.e. if the next sequence number generated <u>SQNSEQ</u><sub>HE</sub> using would be accepted by the USIM.
- 3. If <u>SQN</u>SEQ<sub>HE</sub> is in the correct range then the HE/AuC continues with step (6), otherwise it continues with step (4).
- 4. The HE/AuC verifies AUTS (cf. subsection 6.3.3.).
- 5. If the verification is successful the HE/AuC resets the value of the counter <u>SONSEQ</u><sub>HE</sub> to <u>SONSEQ</u><sub>MS</sub>.
- 6. The HE/AuC sends an *authentication data response* with a new batch of authentication vectors to the VLR/SGSN. If the counter <u>SQN-SEQHE</u> was not reset then these authentication vectors can be taken from storage, otherwise they are newly generated after resetting <u>SQNSEQHE</u>. In order to reduce the real-time computation burden on the HE/AuC, the HE/AuC may also send only a single authentication vector in the latter case.

Whenever the VLR/SGSN receives a new batch of authentication vectors from the HE/AuC in an authentication data response to an authentication data request with synchronisation failure indication it deletes the old ones for that user in the VLR/SGSN.

The user may now be authenticated based on a new authentication vector from the HE/AuC. Figure 12 shows how resynchronisation is achieved by combining a *user authentication request* answered by a *synchronisation failure* message (as described in subclause 6.3.3) with an *authentication data request* with *synchronisation failure* indication answered by an *authentication data response* (as described in this subclause).




Figure 12: Resynchronisation mechanism