## TSGR1#3(99)182

### TSG-RAN Working Group1 meeting #3 Stockholm 22<sup>nd</sup> –26<sup>th</sup> , March 1999

Agenda Item	:	7.11
Source	:	Editor
Title	:	S1.31 version 0.0.1
Document for	:	Discussion and Approval

The last 3GPP RAN WG1 decided that the specifications S1.15 (Measurement, FDD) and S1.15 (Measurements, TDD) should be merged into a new specification S1.31 (Measurements). The first draft of S1.31 was hence produced starting from S1.15 and relevant text from S1.25 was incorporated into S1.31. Changed bars represent the modification from S1.15.

The following modification were done :

- 1) Questions regarding the scope were removed since problems arising when drafting S1.15 and S1.25 due to the split between FDD and TDD were not relevant any more .
- 2) Recommendations from the ad-hoc 8 which were agreed at the 3GPP RAN WG1 #2, were taken into account whenever they affect the measurement issues
  - a) Cell sets : cell sets were copied from ETSI
  - b) *Link(s) supporting the slotted mode for HO from FDD* : downlink will be using slotted mode when the UE does not support a dual receiver. Uplink will be using slotted mode for TDD cells and GSM 1800 cells monitoring, independently from the support of dual receiver.
  - c) Slotted frame structure for slotted mode in FDD, in terms of compressed mode, number of idle slots, position of the idle period in the frame : decision from ad-hoc 8 had to be reflected in S1.31 as far as the parametrisation of the downlink slotted mode is concerned, knowing that other parameters need to be taken into account to fully set the slotted mode such as the periodicity of occurrence of the slotted frame, length of the slotted mode/ number of slotted frames ina given period of time.
  - d) Setting of the idle time periods for handover preparation from FDD mode should be aligned to the ARIB proposal.
  - e) Limitation of the idle period to 8 slots per frame in the GSM section ?
  - f) Handover scenarios text from XX.15 from ETSI was copied in an annex
- 3) Slotted mode parametrisation for the handover preparation from FDD to FDD, TDD and GSM were gathered into a single section since there is a lot of commonality between those, but individual section were left for each case in order to allow some descriptive text to be put in as well as more detailed guidance.
- Requirements for the handover preparation for FDD cells, TDD cells and GSM cells were gathered in the same section. Indeed he structure of the handover monitoring set/candidate set/ might have an impact on the requirements
   Point 5 equally applied to the measurements in idle mode.

Most of the editor's note remain. Indeed there are large dependencies for our work to the work in WG2. While waiting for consolidation of some concepts in WG2, it is worth providing information that will be removed as progress is done in WG2 and reflected in this specification.

There are a few points that need clarification from Ad-hoc 8 and ad-hoc 1:

- 1) Some vocabulary should be agreed in order to distinguish between idle period, idle slot period, idle time period...
- 2) Ad-hoc 8 agreed that the setting of the idle time periods from FDD mode should be aligned to the ARIB proposal.
  - a) However the idle time periods are defined in ARIB only in terms of duration, with different durations for each type of cell to monitor (FDD, TDD and GSM). This definition is not consistent to the description of the silence duration and silence pattern that had been adopted for the monitoring of GSM cells. Idle time periods whether these are used for FDD, TDD and GSM cells should be defined in the same way (type of slotted frame (position of the idle slot period, length of the idle slot period), periodicity of the slotted frames, total number of slotted frame in x mx).
  - b) Also it is not clear whether there is mutual exclusion between the different idle periods for GSM/FDD and TDD cells. For example should some idle period for FDD be scheduled and then TDD and then GSM ?
- 3) The level of co-ordination between the uplink and downlink slotted modes is not quite clear. The ad-hoc 8 report from WG1#2 only indicates that smaller idle periods might be used for the uplink vs. downlink. It is not clear whether this means that the uplink slotted frame would be a sub set of the downlink slotted frames or anything else. As progress is done on this particular topic, the need to have separate sections for the uplink slotted mode configuration with possibly specific parameter may arise. So far, only the downlink slotted mode parametrisation is discussed.

- 4) Ad-hoc 8 concluded that the HO for packet mode (section 3.2.6.10.2 from ARIB) should be copied. However the text discusses the handover procedure rather than preparation. So no text was copied. It should be clarified what is the way forward.
- 6) Decision on handover preparation from TDD to GSM was left to be decided to ad-hoc 1 by ad-hoc 8. However no mention of this could be found in the ad-hoc 1 report. So the text is presently left as corresponding to the ETSI description. Decision will be needed from WG1.
- 7) Handover types were agreed to be copied from XX.15 by ad-oc 8 and confirmed by 3GPP RAN WG1. However the way the handover is performed is not systematically linked to the monitoring. So the editor is asking here to reconsider this knowing that the handover types should be described in some other specification

# TS S1.31 V0.0.1 (1999-03)

Technical Specification

# 3<sup>rd</sup> Generation Partnership Project (3GPP); Technical Specification Group (TSG) Radio Access Network (RAN); Working Group 1 (WG1); Physical layer - Measurements

symbol 60 \f "Wingdings" \s 16  $\square$  <

Reference

<Workitem> (<Shortfilename>.PDF)

Keywords <keyword[, keyword]>

3GPP

Postal address

Office address

Internet

secretariat@3gpp.org Individual copies of this deliverable can be downloaded from http://www.3gpp.org

**Copyright Notification** 

No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

> © All rights reserved.

# Contents

Error! Bookmark not defined.1
2 Foreword
3 Scope
4 References
5 Measurements in idle mode
5.1 Measurements for cell selection.
5.1.1 Cell selection monitoring frequency or cell set
5.1.2 Measurement from the cell selection monitoring set and reporting to higher layers
5.2 Measurements for cell reselection
5.2.1 Cell reselection monitoring frequency or cell set
5.2.1.1 Content of the cell reselection monitoring set for FDD cells
5.2.1.2 Content of the cell reselection monitoring set for TDD cells
5.2.1.5 Content of the cell reselection monitoring set for Osivi cells
3.2.2 Wedsurements for centreselection and reporting to higher layers
6 Measurements in connected mode
6.1 Measurements for the handover preparation
6.1.1 Cell sets for the handover preparation
6.1.1.1 Overview of the different sets
6.1.1.2 Content of the sets
6.1.1.2.1 handover monitoring set
6.1.1.2.1.1 FDD cells on the same frequency.
6.1.1.2.1.2 FDD cells on different frequencies
6.1.1.2.1.3 IDD cells
6.1.1.2.1.4 USWI COIDS
6.1.1.2.2 delive set
61.2 Measurement triggering criteria
6.1.3 Measurements for the handover preparation from UTRA FDD at the UE
6.1.3.1 In general
6.1.3.2 Monitoring of FDD cells on the same frequency.
6.1.3.3 Monitoring of cells on different frequencies (FDD, TDD and GSM)
6.1.3.3.1 Use of slotted mode/dual receiver for monitoring
6.1.3.3.2 Parametrisation of the downlink slotted mode (set of idle time periods)
6.1.3.3.3 Measurement requirements
6.1.3.3.4 Monitoring of FDD cells on other frequencies at the UE for the handover
preparation from UTRA FDD to UTRA FDD.
6.1.3.3.5 Monitoring of TDD cell at the UE for the handover preparation from UTRA
FDD to UTRA TDD
0.1.3.3.0 Measurements for the handover preparation from UTKA FDD to GSM at the
613361 Introduction
613367 Definition and setting of silence duration parameters
613363 Definition and setting of shence durations for handover preparation to GSM
6.1.3.4 Overall handover preparation
6.1.4 Mesurements for the Handover preparation in FDD at the UTRAN side
6.1.5 Measurements for the handover preparation from UTRA TDD at the UE
6.1.5.1 In general
6.1.5.2 Measurements for the handover preparation from UTRA TDD to UTRA TDD at
the UE
6.1.5.2.1 monitoring of TDD cells on the same frequency
6.1.5.2.2 Monitoring of TDD cells on different frequencies
6.1.5.2.2.1 Parametrisation/introduction of idle periods

### Physical layer - Measurements

6.1.5.2.2.2 Measurement requirements
6.1.5.3 Measurements for the handover preparation from UTRA TDD to UTRA FDD at
the UE
6.1.5.4 Measurements for the handover preparation from UTRA TDD to GSM at the
UE
6.1.5.4.1 Introduction
6.1.5.4.2 Low data rate traffic : use of TDD idle slots to monitor GSM
6.1.5.4.3 High data rate traffic.
6.1.5.4.3.1 High end dual synthesisers terminals
6.1.5.4.3.2 Use of TDD TSs release to accommodate monitoring windows
6.1.5.5 Mesurements for the Handover preparation in TDD at the UTRAN side
6.1.5.6 Overall handover preparation
6.1.5.7 Measurement reporting to the higher layers
6.1.5.7.1 Reporting scheme
6.1.5.7.2 Measurement report content for cells on the same frequency
6.1.5.7.3 Measurement report content for TDD cells
6.1.5.7.4 Measurement report content for GSM cells
6.2 Measurements for the cell reselection in active mode
6.3 measurements for power control ?
6.4 Measurements for adjacent protection rule
6.4.1.1 Frequencies to measure
6.4.1.2 Measurement to perform
6.4.1.3 Frequency allocation rule
6.5 Measurements for radio link time out (or sync loss) ?
7 Radio link measurements
8 Annex 1 : Handover scenarios (Informative)
8.1 Introduction
8.2 UTRA UTRA handover scenarios
8.3 UTRA GSWI handover scenarios
8.3 UTRA GSM handover scenarios
<ul> <li><u>9</u> Annex 2 : Handover execution (Should be moved to S2.04 at some stage)</li> </ul>
8.3       01RA GSM handover scenarios         9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)         9.1       Soft handover
<ul> <li>9 Annex 2 : Handover execution (Should be moved to S2.04 at some stage)</li> <li>9.1 Soft handover</li></ul>
8.3       0 TRA GSM handover scenarios         9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)         9.1       Soft handover         10       History
8.3       01RA GSM nandover scenarios         9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)         9.1       Soft handover         10       History         1       Intellectual Property Rights
8.3       01RA GSM handover scenarios         9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)         9.1       Soft handover         9.1       Soft handover         10       History         1       Intellectual Property Rights         6       2         2       Foreword
8.3       01RA GSM handover scenarios         9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)         9.1       Soft handover         9.1       Soft handover         10       History         1       Intellectual Property Rights         2       Foreword
8.3       01RA GSM handover scenarios         9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)         9.1       Soft handover         9.1       Soft handover         10       History         1       Intellectual Property Rights         2       Foreword         3       Scope
8.3       01RA GSM handover scenarios         9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)
8.3       01RA GSM handover scenarios         9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)
8.3       01RA GSM handover scenarios         9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)         9.1       Soft handover
8.3       01RA GSM handover scenarios         9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)
8.3       UTRA GSM handover scenarios.         9       Annex 2 : Handover execution (Should be moved to \$2.04 at some stage)         9.1       Soft handover
8.3       UTRA GSM nandover scenarios         9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)
8.3       01RA GSM handover scenarios         9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)
8.3       UTRA GSM handover scenarios         9       Annex 2 : Handover execution (Should be moved to \$2.04 at some stage)         9.1       Soft handover         10       History         11       Intellectual Property Rights         6       6         2       Foreword         6       6         3       Scope         6       6         4       References         7       5         5       Measurements in idle mode         8       5.1         5       Measurements for cell selection         8       5.1.2         4       Measurement from the cell selection monitoring set and reporting to higher layers         8       5.2         5       Measurements for cell reselection
8.3       UTRA GSM nandover scenarios         9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)
8.3       01RA GSM handover scenarios         9       Annex 2 : Handover execution (Should be moved to \$2.04 at some stage)         9.1       Soft handover         10       History         11       Intellectual Property Rights         6       6         2       Foreword         6       6         3       Scope         6       6         4       References         7       7         5       Measurements in idle mode         8       5.1         5       Measurements for cell selection         8       5.1.1         Cell selection monitoring frequency or cell set         8       5.1.2         Measurement from the cell selection monitoring set and reporting to higher layers         8       5.2.1         Cell reselection monitoring frequency or cell set         8       5.2.1         Centent of the cell reselection monitoring set for FDD cells         5.2.1.1       Content of the cell reselection monitoring set for FDD cells
9       Annex 2 : Handover execution (Should be moved to \$2.04 at some stage)
9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)
S.3       CTRA GSM handover scenarios         9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)         9.1       Soft handover         10       History         11       Intellectual Property Rights         12       Foreword         13       Scope         14       References         15       Measurements in idle mode         16       St.1         17       Measurements for cell selection         18       St.1         19       Secope         10       History         11       Cell selection monitoring frequency or cell set         12       Measurements for cell selection monitoring set and reporting to higher layers         12       Measurement for the cell selection monitoring set for FDD cells         12.1       Content of the cell reselection monitoring set for GSM cells         13.2       Content of the cell reselection monitoring set for GSM cells         14.3       Content of the cell reselection monitoring set for GSM cells
9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)
9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)
9       Annex 2 : Handover execution (Should be moved to \$2.04 at some stage)
9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)
9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)
9       Annex 2 : Handover execution (Should be moved to S2.04 at some stage)

6.1.1.2.3	candidate set	
6.1.2	Measurement triggering criteria	
6.1.3	Measurements for the handover preparation from UTRA FDD to UTRA FDD at the	
	UE	
6.1.3.1	In general	
6.1.3.2	monitoring of FDD cells on the same frequency	
6.1.3.3	monitoring of FDD cells on different frequencies	<del>11</del>
6.1.3.3.1	Parametrisation of the slotted mode (set of idle time periods)	<del></del>
6.1.3.3.2	Measurement requirements	
6.1.4	Measurements for the handover preparation from UTRA FDD to UTRA TDD at the	
		12
6.1.4.1.1	Parametrisation of the slotted mode (set of idle time periods).	
6.1.4.1.2	Measurement requirements	12
615	Measurements for the handover preparation from UTRA FDD to GSM at the UE	12
6151	Introduction	12
<u>6152</u>	Definition and setting of silence duration parameters	13
61521	Definition of silence duration parameters	13
61522	Setting of SD parameters for first SCH decoding without any timing	
0.1.3.2.2	knowledge	14
61523	Setting of SD parameters for first SCH decoding with timing knowledge and	
0.1.3.2.5	procedure at the LIF	15
61524	Setting of SD parameters for SCH decoding for BSIC reconfirmation and	
0.1.3.2.4	procedure at the LIE	16
61525	Solution of SD parameters for Power measurements	
6152	Deremetrisation of the silonge durations for handover properties to CSM	
616	Measurements for the Hendover propertion in EDD at the LITP AN side	
<del>0.1.0</del>	Overall handever preparation	
<del>0.1./</del>	Overall nundover preparation	
0.1.8	Measurement reporting to the higher layers	
0.1.8.1	Keporting scheme	
<del>6.1.8.2</del>	Measurement report content for cents on the same frequency	<del>1/</del>
6.1.8.3	Measurement report content for TDD cells	<del>1/</del>
6.1.8.4	Measurement report content for GSM cells	
6.2 N	leasurements for the cell reselection in active mode	
6.3 m	easurements for power control '?	······································
6.4 N	leasurements for adjacent protection rule	
6.4.1.1	Frequencies to measure	
6.4.1.2	Measurement to perform	
6.4.1.3	Frequency allocation rule	
<del>6.5 N</del>	leasurements for radio link time out (or sync loss) ?	<del></del>
7 Radi	o link measurements	18
/ Rau		
8 Ann	ex 1 : Handover scenarios (Informative)	<del>18</del>
8.1 II	ntroduction	
8.2 U	TRA UTRA handover scenarios	
<del>8.3 U</del>	TRA GSM handover scenarios	
0		10
<del>9 Ann</del>	ex 2 : Handover execution (Should be moved to S2.04 at some stage)	
<del>9.1 S</del>	ott handover	<del>19</del>
10 Hist		22
10 1100		

# 1 Intellectual Property Rights

<editor's note : this section will be completed when an official format for the document is agreed>

# 2 Foreword

This Technical Specification (TS) has been produced by the 3G Partnership Project (3GPP) of the European Telecommunications Standards Institute (ETSI).

The contents of this TS are subject to change as the work continues

<Editor's note : this version is the very first version produced in the merging phase between the ETSI and ARIB reference documents. The document-does not-incorporates decisions from the ad-hoc 8 (handover) that had been approved by the plenary of RAN WG1 #2.e yet any of the preferred choices from the ad hocs, in particular ad hoc on Handover. The document will be updated as decision is made by WG1 as a whole.

The text was edited with the following rules :

- the text <u>is</u> restricted to layer 1 issues. However in order not to loose material regarding other layers that was present in the XX.xy documents or ARIB vol 3 and not yet incorporated in the documentation of WG2 and WG3, annexes were created to cover Handover execution aspects.
- When for a particular subjects, both when ETSI and ARIB had different solutions documented and if the work of ad-hocs in particular ad-hoc 8 had not allowed to find a merged solution, then both ETSI and ARIB schemes were documented when differencet identified with explicit note.
- When only one proposal from either ETSI or ARI<u>B</u> was <u>available</u> available <u>x</u> for a particular subject <u>and ad-hoc 8 had not agreed to the proposal and then it was documented again with explicit indication, in an editor's note.</u>
- Text from ETSI and ARIB sometimes required some change either due to terminology or to consistency with other documents from WG1 or WG2. Modifications appear in the form of change bars.
- Editor's notes were incorporated in order to seek progress on some particular areas and to provide a description of the scope of each section of the document
- >

# 3 Scope

This 3GPP Telecommunication Specification TS and the TS S1.25 contains the description of the measurements done at the UE and network in order to support operation in idle mode and connected mode.

As far as the measurements in idle mode are concerned, this TS described the following :

- measurements for the cell selection for a UE supporting FDD and/or TDD
- measurements for cell reselection for a UE camping on an FDD or TDD cell

As far as the measurements in connected mode are concerned, this TS describes measurements when the UE is connected to an FDD cell or cells (in Soft handover) <u>or a TDD cell</u> for the cell connected state (see reference [8]), or camping on an FDD cell for the URA connected state. <del>S1.25 provide an equivalent description for the TDD cells.</del>

This TS provides the minimum requirements for the UE and networks. Some explanatory text is also contained in the TS but it is more of a descriptive nature than normative.

As far as the measurements for the handover preparation, this specification defines the requirements to the UE and network, as well as parametrisation rules for the slotted mode (or compressed mode) in order to accommodate idle periods. This latter aspects may need to be moved to some other specifications. The description of the slotted mode (different type of slotted frames define by the compressed mode A/B, the number if idle slots and the position of such idle slots) is outside the scope of this specification and is expected to be covered in S1.11 and S1.12.

< Editor's note : Two specifications S1.15 and S1.25 are indicated in the WG1 documentation structure as FDD and TDD measurements respectively. Interpretation of title could lead potentially to three different interpretations

 the separation between S1.15 and S1.25 applies to the FDD mobile and the TDD mobiles respectively

- 2) the separation between S1.15 and S1.25 applies to the mode of the cell that the UE is connected to or camped on,
- 3) the separation between S1.15 and S1.25 applies to the cell that is to be monitored independently of the mode the UE is operated in.
- The choice made here correspond to the second listed alternative. Indeed we have to consider multi-mode UE that would need to monitor different type of cells in the same time, so case 1 is irrelevant, as well as case 3) is not appropriate since a multi-modeUE whatever mode it is operating in would need to monitor different type of cells.
- At some point \$1.15 and \$1.25 may need to be merged. Indeed separating leads to duplication of some text >

## 4 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, subsequent revisions do apply.
- A non-specific reference to an ETS shall also be taken to refer to later versions published as an EN with the same number.

[1]	3GPP RAN S1.11	Transport channels and physical channels (FDD)
[2]	3GPP RAN S1.12	Multiplexing and channel coding (FDD)
[3]	3GPP RAN S1.13	Spreading and modulation (FDD)
[4]	3GPP RAN S1.14	Physical layer procedures (FDD)
[5]	3GPP RAN S1.21	Transport channels and physical channels (TDD)
[6]	3GPP RAN S1.22	Multiplexing and channel coding (TDD)
[7]	3GPP RAN S1.23	Spreading and modulation (TDD)
[8]	3GPP RAN S1.24	Physical layer procedures (TDD)
[9]	3GPP RAN S2.02	Services provided by the Physical layer
[10]	3GPP RAN S2.03	UE functions and interlayer procedures in connected mode
[11]	3GPP RAN S2.04	UE procedures in idle mode
[12]	XX.15, version 1.0.0	) UTRA Handover
[13]	XX.07, version 1.0.0	) UTRA FDD, Physical layer procedures
[14]	XX.13, version 1.0.0	) UTRA TDD, Physical layer procedures
[15]	ARIB, Vol 3	

## 5 Measurements in idle mode

### 5.1 Measurements for cell selection

<Editor's note : In both ETSI and ARIB measurements for cell selection are not described apart from the initial cell search. Measurement to support Cell selection and cell reselection rely on synchronisation acquisition procedures currently described in section related to the Initial cell search procedures in [4] and Physical layer procedures (FDD) and Physical layer procedures (TDD) [8] for FDD cells and TDD cells respectively.

This section, measurements for cell selection, of this specification could contained the following subsections with scopes as provided in each section. This is not to be found in any of the reference documents and is only a suggestion for progress by the editor>

### 5.1.1 Cell selection monitoring frequency or cell set

<Editor's note : this section should define how the frequencies or cells to measure for the cell selection process are determined. This set should be provided by higher layers in the primitive that triggers the measurement process. Two following two cases might be considered and would lead to two different cell selection monitoring, defined in section 6.1.1, as in GSM. This is to be discussed with WG2.

#### **Physical layer - Measurements**

- Normal cell selection : the UE has no information at switch on. It would perform measurements on frequencies/cell that correspond to the mode it support and that was manually selected if applicable.
- Cell selection from stored list. The UE stored some information at switch off. At switch on cell selection is performed based on this stored information.
- >

# 5.1.2 Measurement from the cell selection monitoring set and reporting to higher layers

< Editor's note : requirements need to be defined based on collaborative work with other WGs>

### 5.2 Measurements for cell reselection

### 5.2.1 Cell reselection monitoring frequency or cell set

<Editor's note : this section should define how the frequencies or cells to measure for the cell reselection process are passed to the physical layer of the UE by higher layers and what information is passed in terms of cell mode, frequency, synchronisation information, in form of scrambling codes.... This set should be provided by the MAC layer in the primitive that triggers the measurement process. This is referred to as the priority list in ETSI as far as the FDD and TDD cell/frequencies are concerned>.

<Editor's note : the content of this section was extracted from reference [13] XX.07, UTRA FDD Physical layer procedures and modified so that is applies to both FDD and TDD when there is no principle difference. There is not equivalent section in reference [15], ARIB volume 3>

From a very general descriptive point of view, when in idle mode, the UE continuously searches for new cells on the current and other carrier frequencies. The measurement for the cell reselection are performed in basically the same way as the cell selection. The main difference compared to the cell selection is that a UE has received a priority list from the network, called the cell reselection monitoring set, which provides information relative to the cells to monitor.

As far as FDD cells are concerned, provision of the list significantly reduce the time and effort needed for the scrambling-code search (step 3) (see [4]). Also the complexity in the second step may be reduced if the priority list only includes scrambling codes belonging to a subset of the total set of code groups. The priority list is continuously updated to reflect the changing neighbourhood of the moving UE. (ETSI).

Content of the cell reselection monitoring set is further discussed in the following sections for FDD, TDD and GSM cells respectively.

### 5.2.1.1 Content of the cell reselection monitoring set for FDD cells

<Editor's note : the text contained here comes from section 5.2 in [13] (UTRA FDD, Physical layer procedures>)

The content of the cell reselection monitoring set as far as FDD cells are concerned provides the list of FDD cells/frequencies including the downlink scrambling codes and the order in which they should be searched for.

### 5.2.1.2 Content of the cell reselection monitoring set for TDD cells

 $<\!\!Editor's$  note : the text contained here comes from section 6.6.2 in [14] (UTRA TDD , Physical layer procedures>)

The cell reselection monitoring set priority list describes in which order to search for TDD cells.

5.2.1.3 Content of the cell reselection monitoring set for GSM cells  $_{\rm To\ be\ added}$ 

# 5.2.2 Measurements for cell reselection and reporting to higher layers

< Editor's note : requirements need to be defined based on collaborative work with other WGs>

# 6 Measurements in connected mode

### 6.1 Measurements for the handover preparation

### 6.1.1 Cell sets for the handover preparation

<editor's note : A cell set corresponds a list of cells that the UE needs to monitors for a given period of time, with associated requirements, as seen from the physical layer. Several sets are defined since different requirements might be defined, e.g. some cells might need to be monitored more often than others...It is not clear at this stage how such sets will be provided by the MAC layer. The primitives that allow the MAC layer to control the measurement process in the layer 1 are under definition by the RAN WG2. Several cases might be considered :

- the MAC has a very fine control of the measurement, upto the frame level, decides on the measurement of particular cells at particular instant and the physical layer report measurement back to the MAC layer e.g. after a slotted frame, some processing being possibly needed by the MAC
- The MAC provides sets of cells to monitor and monitoring periods in the form of e.g. slotted frame or DTX period and it is up to the physical layer to organise the monitoring
- In the following we consider the second case, because it is more in line with the available documentation from . It the first case of some intermediate case was to be considered in the future then some material of the section would need to be move to the relevant RAN WG2 documentation.
- The text provided here is extracted from reference [12], XX15, UTRA Handover. There is no equivalent section in reference [13].>

### 6.1.1.1 Overview of the different sets

The physical layer of the UE should be provided by higher layers the following lists of cells :

- *Handover Monitoring set* : All cells (UTRA or from other systems like GSM) that the UE has been tasked by the UTRAN to monitor when in active mode.
- *Active Set*: The UTRA cells currently assigning a downlink DPCH to the mobile station, which corresponds to the cell between which the UE in a soft handover\_with. The active set may only correspond to UTRA cells.
- *Handover candidate Set*: The cells that are not currently in the Active Set but have been received by the UE with sufficient strength to indicate that the associated DPCHs could be successfully demodulated. These correspond to the cells that are effectively reported by the UE to the UTRAN. These cells may be on the same or different frequencies from the current frequency assignment. Cells in the handover candidate set may be UTRA or GSM cells.

<Editor's note : these different sets were defined in XX.15 for the definition of requirements for the measurements for handover preparation as well as for the reporting or handover triggering. The cell sets were agreed at the 3GPP RAN WG1 #2. Since the approach now is to reduced the scope of this specification to the measurement only, there might not be a need to make define the same sets. Only set that would lead to different requirements or process for the measurement need to be defined. Here it is anticipated that cells in the active set, which are the serving cell are measure for each frame, whereas cell which are not part of the active set are not measured as often as every frame. Cells which have been identified by the MAC as candidate cell may need to be measured more often than other cell, since they are mamong the x strongest. >

### 6.1.1.2 Content of the sets

### 6.1.1.2.1 handover monitoring set

The handover monitoring set contains the cells to be monitored by the UE in active mode. It is provided to the physical layer by higher layers, as part of the primitives (see [8]). The handover monitoring set may contain cells on the same frequency and/or cells on different frequencies. The following sections indicate which information are included in the handover monitoring set for cell on the same frequency and cells on different frequencies.

### 6.1.1.2.1.1 FDD cells on the same frequency

For each cell to monitor at the same frequency, the handover monitoring list contains at least the following information:

• The cell scrambling code used for downlink scrambling.

#### • The cell ID number

It is assumed that the mapping of the cell scrambling codes in relation to the synchronisation channel codes (groups indicated by the secondary synchronisation channel) is known beforehand with the code grouping being determined beforehand.

<editor's note : this may be better described in the WG2 documentation. Some text may be however useful here for explanatory purposes>

6.1.1.2.1.2 FDD cells on different frequencies <*editor's note : no text in XX.15>* 

### 6.1.1.2.1.3 TDD cells

<editor's note : no text in XX.15>

6.1.1.2.1.4 GSM cells <editor's note : no text in XX.15>

6.1.1.2.2 active set 6.1.1.2.2 active set<pr

6.1.1.2.3 candidate set <e ditor's note : no text in XX.15>

### 6.1.2 Measurement triggering criteria

<Editor's note : >

### 6.1.3 <u>Measurements for the handover preparation from UTRA</u> <u>FDD at the UE</u>

6.1.3.1 In general

To be added

# 6.1.3.2 Measurements for the handover preparation from UTRA FDD to UTRA FDD at the UE

### 6.1.3.3 In general

### 6.1.3.4 Mmonitoring of FDD cells on the same frequency

< Editor's note : no requirement has been defined yet, in terms e.g. of number of cells to be able to monitor in a given time, precision of individual measurements... Text included in this section is more of a descriptive nature and provide the list of measurements to be reported by the physical layer to higher layer. Details on the measurements should be available in section 6.1.1.3.37>

During the measurement process of cells on the same frequencies, the UE shall find the necessary synchronisation to the cells to measure using the primary and secondary synchronisation channels and also the knowledge of the possible scrambling codes in use by the neighbouring cells. As the UE does measurement, at least the following information is obtained:

- Relative signal strength of the measured cell
- Relative timing between the cells, measured for example from the phase difference between the scrambling code, depending on the timing difference between the cells.

# 6.1.3.5 <u>Monitoring of cells on different frequencies (FDD, TDD and GSM)</u> <<u>*Editor's note: no text is currently available>*</u>

### 6.1.3.5.1 Use of slotted mode/dual receiver for monitoring

To support monitoring of cells on other frequencies (FDD, TDD or GSM), the downlink transmission may, on UTRAN command, enter in slotted mode, where the different set of slotted frames is described in reference [2], S1.12.Which frames to be compressed, the frame structure (mode A, B and C) as well

as the position of the idle slot period in the frame are decided by the UTRAN. The UTRAN shall communicate to the UE the slotted mode parameters . The downlink slotted mode shall be applied by the network for UEs not having a dual mode receiver in order to allow them to monitor cells on different frequencies (FDD, TDD, GSM). Alternatively independent measurements not relying on the downlink slotted mode, but using a dual receiver approach can be performed, where the "monitoring" receiver branch can operate independently of the UTRA FDD receiver branch.

<editor's note : it is not clear yet whether there is some value in using the downlink slotted mode for the UE with a dual receiver>

To support monitoring of TDD cells and GSM 1800, the uplink transmission shall, on UTRAN command, enter in slotted mode, The use of the uplink slotted mode is needed for UEs containing a dual receiver as well as UE not containing a dual receiver. The level of co-ordination of the uplink slotted mode and downlink slotted mode, when applied is for further study.

The following section provides rules to parametrise the downlink slotted mode. The downlink slotted mode is not required when a dual receiver is available.

### 6.1.3.5.2 Parametrisation of the downlink slotted mode (set of idle time periods)

<editor's note : separating the parametrisation of the slotted mode for each case (FDD cell, TDD cell, GSM cells) assumes that an idle period is used only for one type of cell. This section could provide some first indication on how to parametrise the slotted mode for each type of cell. There should however be some co-ordination between the parametrisation of the slotted mode, in order for example to make sure that a given frame is not targeted to measure GSM and TDD cells. This could be addressed in this section or in section 61.3.8 dealing with the overall handover preparation. >

Content of the text :

- The text included here corresponds to the text contained in section 3.2.6.6.3.5 of reference [15], <u>ARIB volume 3 and that was agreed for inclusion at the 3GPP RAN WG1#2 meeting, as a result</u> from ad-hoc 8.The text in square brackets was agreed to be removed A set of parameters for the monitoring of TDD cells was though added since it is anticipated that the setting may be different between FDD and TDD cell due to a different organisation of common channel.
- Consistency of the approach with handover preparation from FDD to GSM should be further investigated. The text as it is may be understood as the fact that for e.g. T<sub>A1</sub> msec all frames are slotted; which is different from section xxx, that would correspond to a Periodic pattern. A clear definition of idle time period is needed. Additional parameters defining the idle period not only in terms of ms but also idle slot periods and periodicity of the slotted frames will be needed to ensure consistency. >

To support monitoring of FDD cell on other frequencies, the following set of idle time periods shall be used:

- T<sub>A1</sub> msec for power measurement
- $\blacksquare \frac{T_{A2}}{T_{A2}} \frac{1}{msec for slot/symbol synchronisation}$
- **T** $_{A3}$  msec for frame synchronisation and code-group identification
- $\blacksquare \quad \overline{T_{A4}} \text{ msec for scrambling-code identification}$
- $\blacksquare \quad \underline{T_{A5} \text{ msec for the reception of control information}}$

To support of monitoring of TDD cell on other frequencies, the following set of idle time periods shall be used:

- $\blacksquare \quad \underline{T}_{B1} \text{ msec for power measurement}$
- $\blacksquare \frac{\overline{T_{B2}} \text{ msec for slot/symbol synchronisation}}{T_{B2} \text{ msec for slot/symbol synchronisation}}$
- **T** $_{B3}$  msec for frame synchronisation and code-group identification
- $T_{B4}$  msec for scrambling-code identification
- $T_{B5}$  msec for the reception of control information

To support monitoring of GSM cells, the following set of idle time periods shall be used:

- $\blacksquare \quad \underline{T_{C1a} \text{ msec and } T_{C1b} \text{ msec for power measurement}}$
- **T** $_{\overline{C2}}$  msec for FCCH (Frequency Correction CHannel) detection
- **T** $_{\overline{C3}}$  msec for SCH (Synchronisation CHannel) decoding
- <u>T<sub>C4</sub> msec for SCH decoding (Option)</u>

The parameters T might be adjusted depending on the UE capabilities.

When adjustable idle position is supported, BTS shall broadcast information about the support of

adjustable idle position in BCH, and MS may request adjustable idle position using layer 3 messages.]

### 6.1.3.5.3 Measurement requirements

<Editor's note : there is no requirement specified in either of the reference documents (XX.15 or Vol 3 of ARIB). The reported value itself is not specified but is expected to correspond to a useful received power level, and potentially some relative timing information. The requirements could also be expressed minimum of samples for the monitoring time assigned by higher layers, precision of the relative received power, taking into account to structure of the monitoring set....The requirement should be specified in the WG4 documentation. There ca, be left here in an interim basis and copied here for reference >

#### 6.1.3.5.4 monitoring of FDD cells on different frequencies

To support monitoring of cells on other frequencies, the downlink transmission may, on network command, enter in slotted mode, where the different set of slotted frames is described in reference [2], S1.12. What frames to be compressed are decided by the network.

6.1.3.5.4.1 Parametrisation of the slotted mode (set of idle time periods)

<editor's note : separating the parametrisation of the slotted mode for each case (FDD cell, TDD cell, GSM cells) assumes that an idle period is used only for one type of cell. Though the slotted mode has to be co-ordinated. This section could provide some first indication on how to parametrise the slotted mode knowing that section 7.1.6 must provide a global view, both in terms of slotted mode parametrisation but also requirements>

<Editor's note : there is no text in the equivalent section of reference [12]XX.15, UTRA Handover The text included here corresponds to the text contained in section 3.2.6.6.3.5 of reference [15], ARIB volume 3. Consistency of the approach with handover preparation from FDD to GSM should be further investigated. The text as it is may be understood as the fact that for e.g. TAI msec all frames are slotted; which is different from section 6.5.1.2, that would correspond to a Periodic pattern >

To support allow monitoring of FDD cell on other frequencies, the following set of idle time periods shall be used:

- T<sub>A1</sub> msec [in fixed idle position] [with double frame method] for power measurement
- T<sub>A2</sub> msec [in fixed idle position] [with double frame method] for slot/symbol synchronization
   T<sub>A3</sub> msec [in fixed idle position] [with double frame method] for frame synchronization and
- code group identification ■ T<sub>A4</sub> msec [in fixed idle position] [with double frame method] for scrambling code identification
- T<sub>A5</sub>-msec [in fixed idle position] [with double frame method] for the reception of control information

#### 6.1.3.5.4.2 Measurement requirements

<Editor's note : there is no requirement specified in either of the reference documents (XX.15 or Vol 3 of ARIB). The reported value itself is not specified but is expected to correspond to a useful received power level, and potentially some relative timing information. The requirements could also be expressed minimum of samples for the monitoring time assigned by higher layers, precision of the relative received power, taking into account to structure of the monitoring set....>

# 6.1.3.5.5 Monitoring of FDD cells on other frequencies at the UE for the handover preparation from UTRA FDD to UTRA FDD

This section should described particular rules to set the slotted mode parameters depending on the handover monitoring set, as well as provide some descriptive text on the monitoring process itself.

# 6.1.3.5.6 <u>Monitoring of TDD cell at the UE</u> <u>Measurements</u> for the handover preparation from UTRA FDD to UTRA TDD at the UE

<Editor's note : there is no text in the equivalent section of reference [12]XX.15, UTRA Handover, neither in reference [15], ARIB volume 3>

This section should described particular rules to set the slotted mode parameters when monitoring TDD cell, both for the downlink and uplink slotted mode depending on the handover monitoring set, as well as provide some descriptive text on the monitoring process itself.

6.1.3.5.6.1 Parametrisation of the slotted mode (set of idle time periods)

<Editor's note : it is not clear whether the corresponding section for the FDD cells should be copied here >

Use of the uplink slotted mode together with the downlink slotted mode is needed for the monitoring of TDD cells (ETSI).

#### 6.1.3.5.6.2 Measurement requirements

<editor's note : Same editor's note as for section 6.1.3>

# 6.1.3.5.7 Measurements for the handover preparation from UTRA FDD to GSM at the UE

<editor's note : The content of this section has been extracted from reference [12], XX.15, UTRA Handover and was agreed by 3GPP RAN WG1#2>

#### 6.1.3.5.7.1 Introduction

The handover between UTRA and GSM system offering world-wide coverage already today has been one of the main design criteria taken into account in the UTRA frame timing definition. The GSM compatible multi-frame structure, with the super-frame being multiple of 120 ms, allows similar timing for inter-system measurements as in the GSM system itself. The compatibility in timing is important, that when operating in UTRA mode, a multi-mode UE is able to catch the desired information from the synchronisation bursts in the synchronisation frame on a GSM carrier with the aid of the frequency correction burst. This way the relative timing between a GSM and UTRA carriers is maintained similar to the timing between two asynchronous GSM carriers.

UTRA/FDD-GSM dual mode UEs can be implemented without simultaneous use of two receiver chains. Although the frame length is different from GSM frame length, the GSM traffic channel and UTRA FDD channels use similar 120 ms multi-frame structure. Similar timing can be naturally done with UTRA TDD mode as well.

A UE can do the measurements by using idle periods in the downlink transmission, where such idle <u>slot</u> periods are created by using the downlink slotted mode <u>as defined in reference [2]. (see section In</u> addition to downlink slotted frames for measurements, the UTRAN will provide uplink slotted frames to allow the UE to GSM cells on frequencies closed to the FDD uplink band. The slotted mode is under the control of the UTRAN, and the UTRAN should communicate to the UE which frame is slotted.

Alternatively independent measurements not relying on the slotted mode, but using a dual receiver approach can be performed, where the GSM receiver branch can operate independently of the UTRA FDD receiver branch.

For smooth inter operation between the systems, information needs to be exchanged between the systems, in order to allow the UTRAN to notify the UE of the existing GSM frequencies in the area ( see section 6.1.1.2.1.4). Further more integrated operation is needed for the actual handover where the current service is maintained, taking naturally into account the lower data rate capabilities in GSM when compared to UTRA maximum data rates reaching all the way to 2 Mbits/s.

The current section addresses in a first part the parametrisation of the slotted mode and in second stage the monitoring process in a more global way and encompasses the setting of monitoring set and reporting. The section is organised as follows :

In section 6.5.1.2 silence durations definition and parametrisation for SCH or FCCH tracking for one GSM either at initial search or for reconfirmation are defined. Such silence durations SDc correspond to the time required for a UE to listen to c consecutive GSM time-slots and are therefore contained in the idle period generated by the use of slotted frames. There is hence a correspondence between allocation by the UTRAN of slotted frames and silence durations. The subsequent sections <u>6.1.3.3.6.2.26.5.1.2.1.2</u>, <u>6.1.3.3.6.2.3</u> <u>6.5.1.2.2.3</u> and <u>6.1.3.3.6.2.46.5.1.2.4</u> then discuss the appropriate Silence duration pattern depending on the availability of timing information between UTRA serving cells and the GSM cell and whether the silence duration is used to initial tracking of a new GSM cell or reconfirmation. Addition silence duration will be required for power measurement of one or multiple GSM cells.

- Section <u>9.2.1.2-6.1.3.3.6.3</u> addresses the parametrisation of the silence durations or equivalently the slotted mode when considering the monitoring of all <u>GSM</u> cells, which requires a combination of power measurements and synchronisation tracking of one cell as a minimum. <del>Different handover scenarios in terms of inter operability as defined in XX.16 are addressed.</del>
- Finally section 9.2.1.3 addresses the monitoring in a more general view.

#### 6.1.3.5.7.2 Definition and setting of silence duration parameters

#### 6.1.3.5.7.2.1 Definition of silence duration parameters

This section provides a set of definitions for the parametrisation of the slotted mode, together with minimum requirement in terms of measurement by a UE

 $\boldsymbol{SD}_{\boldsymbol{c}}$  is defined as the following :

$$SD_c = 2 * t_{synth.} + (c+1) *$$

where,

 $t_{synth.}$ :  $t_{synth.}$  is the maximum allowed delay for a UE's synthetizer to switch from one FDD to one GSM frequency. Typically this value could be derived, from the larger frequency difference switch (= 1245 MHz) which is the one from upper FDD downlink frequency (2170 MHz) to lower GSM downlink frequency (925 MHz). The value of  $t_{synth.}$  is set to [500 µs].

c : integer value {0,1,2,3,4,5,6,7,8}

 $TS_{GSM}$ : GSM timeslot duration. 577  $\mu$ s

 $SD_c$ : silence duration number c.  $SD_c$  is the necessary time for a dual mode UE to switch to one GSM frequency, *decode* c consecutive GSM slots and switch back to the current FDD carrier. In the particular case where the scheduling of silence duration  $SD_c$  is synchronised with the scheduling of GSM timeslots, the UE can decode (c+1) consecutive GSM time slots.

<editor's note : SDc with this definition and the 500 us switching time corresponds to a different idle times when looking at the definition of the slotted mode provided in [2][15], ARIB vol 3 table 3.2.6 1 and to be described in [2], S1.12. Each SDc leads to a number of idle slots in a frame. The correspondence between the two is still missing. The requirement for the UE should be that within SDc second the UE decodes a minimum of C GSM time-slot. The 500 us is not a requirement in itself>

**SD pattern** : a set of consecutive silence durations enabling the capture of at least one timeslot 0 of one GSM BCCH carrier.

<Editor's note : this SD pattern is the equivalent of idle time periods in section 6.1.3.3.24>

 $T_{SDc}$ : delay between two consecutive silence durations within a SD pattern when GSM timeslot number i mod(8) is the first timeslot to be captured by the first silence duration and GSM timeslot number (i+c) mod(8) is the first timeslot to be captured by the second silence duration.

 $T_{pattern}$ : delay between two consecutive patterns, optionally generalised to  $T_{pattern1}$  and  $T_{pattern2}$  to be used alternating between consecutive patterns.

 $N_{\text{pattern}}$ : number of consecutive patterns to be used for scanning a particular GSM frequency before this search attempt is assumed to be unsuccessful.

< Editor's note : constraints on Tpattern values taking into account the parameters of the slotted mode (number of idle slots, type of slotted frame....,) should be added, unless the SDc and  $SD_{pattern}$  are turned into exact slotted mode description >

T<sub>pattern1</sub>  $\Gamma_{pattern2}$ 

Figure 1 : illustrations of SD patterns, silence duration SD<sub>c</sub>, T<sub>pattern1</sub>, T<sub>pattern2</sub>, T<sub>SDc</sub> and N<sub>pattern</sub>.

6.1.3.5.7.2.2 Setting of SD parameters for first SCH decoding without any timing knowledge The setting of the SD patterns is described in this section when used for first SCH decoding of one cell when there is no knowledge about the relative timing between the current FDD cells and the neighbouring GSM cell. The UE needs to perform a new SCH search procedure whenever a new neighbour cell is received with a sufficiently high power level (see 9.2.1.1.4).

Silence durations for FDD mode can be used in the downlink in order to enable a one receiver dual mode UE to acquire synchronisation from neighbouring GSM cells. Depending on the UE's capabilities, the search procedure may be sequential (tracking of FCCH burst before decoding of the first SCH) or parallel (parallel tracking of FCCH and SCH bursts). The latter solution achieves SCH decoding faster than the first one thus decreasing the needed number of SD patterns. For example a parallel search with 2 SD patterns every 480 ms using alternatively  $T_{pattern1} = 216,92 \text{ ms} (= 47*4,615 \text{ ms})$  and  $T_{pattern2} = 263,08 \text{ ms} (= 57*4,615 \text{ ms})$  will be as efficient as a sequential search with 4 SD patterns per 480 ms with  $T_{pattern} = 120 \text{ ms}$ . This has been verified by checking which GSM frame numbers will be observed during 6 successive silence durations for each of the 51 possible frame numbers where the search can happen to be started (note that the GSM FCCH/SCCH schedule has a periodicity of 51 frames).

The parameter  $N_{pattern}$  allows to trade in the detection probability on a particular GSM cell against the number of slotted frames i.e. against the impact on the running UTRA connection. By default  $N_{pattern}$  should be set to 11 for the serial and 6 for the parallel search procedure. This makes sure a detection is possible even for the worst case relative timing of the GSM cell.

If silence durations are allocated by the UTRAN on a periodic basis in the downlink, then it is up to the UE to trigger the search procedure with the available silence durations. In this case, no specific signalling is needed between the UE and the UTRAN.

If silence durations are not allocated on a periodic basis, the UE then initiates the search procedure by sending a "request new cell search" message to the UTRAN also signalling its capabilities for serial or parallel search as described above. The UTRAN then determines a suitable silence period pattern and signals this to the UE using the normal silence duration indicators. The UTRAN can delay the onset of this pattern depending on the timing priority the Network Operator has set for new BSIC identification. Once the UE has completed the search it signals the UTRAN with the timing of the associated SCH

burst or with SCH-not-found (see <u>9.2.1.1.3</u>) and the UTRAN ceases the silence duration pattern. Here are some examples of silence durations and associated SD patterns (at least one GSM timeslot 0 is capture within each SD pattern) :

#### **Physical layer - Measurements**

Silence Duration	Number of Silence Durations per SD	T <sub>SDc</sub> between $1^{st}$ and $2^{nd}$ SD (in	T <sub>SDc</sub> between $2^{nd}$ and $3^{rd}$ SD (in	T <sub>SDc</sub> between $3^{rd}$ and $4^{th}$ SD (in
	pattern	TS <sub>FDD</sub> )	TS <sub>FDD</sub> )	TS <sub>FDD</sub> )
$SD_2 (= 5 * TS_{FDD})$	4	24	24	24
$SD_3 (= 6 * TS_{FDD})$	3	84	84	N.A.
$SD_4 (= 7 * TS_{FDD})$	2	48	N.A.	N.A.
$SD_3$ and $SD_5$	2	84	N.A.	N.A.
SD <sub>5</sub> and SD <sub>5</sub>	2	108	N.A.	N.A.
$SD_6$ (=9 * $TS_{FDD}$ ) and	2	72	N.A.	N.A.
$SD_2$				
$SD_8 (=10 * TS_{FDD})$	1	N.A.	N.A.	N.A.

Table 1 . some possible SD<sub>c</sub> combinations for SD pattern.

# 6.1.3.5.7.2.3 Setting of SD parameters for first SCH decoding with timing knowledge and procedure at the UE

The setting of the SD pattern is described in this section for the case where some knowledge on the relative timing between the UTRA FDD cells in the active set and the neighbouring GSM cells is available at the UE, either because delivered by the UTRAN or due to prior knowledge consecutive to previous FCCH detection by the UE

For GSM cells when the timing is known, the slotted frames (silence durations) can be allocated for a specific frame intended to capture a specific SCH (or FCCH if needed) from the GSM cell with known frame timing with relative to UTRA FDD cells in the active set.

The control is implemented over 306 frames, equal to 13 GSM « 51 multi-frame » duration. As the UTRA 720 ms superframe shifts ¼ of superframe during the period, the 4 times 306 period can be used to fully align the timings of a UTRA FDD and a GSM cells.

The UE needs to perform a new SCH search procedure whenever a new neighbour cell is received with a sufficiently high power level . The UE then initiates the search procedure by sending a "request new cell search" message to the UTRAN.

### Signalling from the UTRAN to the UE for the use of one slotted frame for SCH decoding

<Editor's note : the text in this section is written as the peer to peer communication but it should be rewritten from the Layer 1 point of view as the content of the primitive between the physical layuer and higher layers. It should be moved to S2.02 at some point.>

The UTRAN sends to the UE specific signalling with the following information :

- The frame number where slotted mode occurs (frame number x+n times 306, where n=0,1,2,3)
- The GSM carrier for which the particular slotted frame is intended (BS ID, carrier no, etc.)
- The type of slotted mode that will occur (end, middle frame, etc.)

The signalling has to be UE specific as :

• All UEs should not make measurements at the time instant

• All UEs may not be dual mode

### Reporting to higher layers (or to the UTRAN)

Once the UE has completed the search it signals the UTRAN with the timing of the associated SCH burst or with SCH-not-found and the UTRAN ceases the silence duration pattern.

# 6.1.3.5.7.2.4 Setting of SD parameters for SCH decoding for BSIC reconfirmation and procedure at the UE

In this paragraph it is assumed that the UE has successfully decoded one SCH burst of a given neighbouring GSM cell during the call.

If silence durations i.e. slotted frames are allocated on a periodic basis in the downlink, then it is up to the UE to trigger and perform the BSIC reconfirmation procedure with the available silence durations. In this case, no specific signalling is needed between the UE and the UTRAN for BSIC reconfirmation procedure.

If silence durations are not allocated on a periodic basis in the downlink, the UE indicates to the UTRAN the schedule of the received neighbour cell SCH bursts and the size of the necessary silence duration in order to capture one SCH burst. The Network Operator decides the target time for BSIC

#### **Physical layer - Measurements**

reconfirmation and the UTRAN uses this and the schedule indicated by the UE to determine an appropriate silence duration pattern. This is signalled to the UE using the normal silence duration indicators. Also if the FDD network as a priori timing knowledge of neighbouring GSM cells as in 6.1.5.2.3. 6.1.3.3.6.2.3 then it can schedule silence durations for BSIC reconfirmation. In that case the signalling is similar to the one in paragraph 6.1.3.3.6.2.3 - 6.1.5.2.3.

### 6.1.3.5.7.2.5 Setting of SD parameters for Power measurements

For power measurements of GSM carriers, additional silence durations will be used for single receiver FDD/GSM UE. Requirements concerning the number of power measurements per slotted frames are for further study.

6.1.3.5.7.3 Parametrisation of the silence durations for handover preparation to GSM Whereas section 6.1.3.3.6.25.2.2 described the silence duration parametrisation for the initial synchronisation tracking or reconfirmation for one cell and the silence duration parameter for power measurement for one of multiple cells, there is a need to define the global silence duration parameters when considering the monitoring of all GSM cells.

<Editor's note : the overall description for the handover to GSM preparation is still missing. Some text was available in XX.15 but was either outside the scope of this document or inconsistent with previous sectiossn. Moreover it diod not address the point for the global measurement process and associated minimum requirement. Some work is therefore needed on this. >

# 6.1.3.6 Mesurements for the Handover preparation in FDD at the UTRAN side

-<editor's note : this is not described in either of the documents. However the handover triggering might not be due only to conditions on the downlink. Measurements performed by the cells in the active set might be needed as in GSM. This section has been created for that purpose >

### 6.1.3.7 Overall handover preparation

This section should explain how the inter-frequency handover preparation from UTRA FDD to UTRA (either FDD or TDD) and from UTRA to GSM are co-ordinated in terms of measurement and reporting at the UE. Whereas Section 6.1.3.3.4, 6.1.3.3.5.4 and 6.1.3.3.65 give some principle for the monitoring of a given cell type and requirement in e.g. the dimensioning of the slotted mode, this section provides the overall requirement and measurement procedure.

<Editor's note : no text is available is either of the reference documents, XX.15 or ARIB volume 3>

### <u>6.1.4 Mesurements for the Handover preparation in FDD at the</u> <u>UTRAN side</u>

 $\underline{\langle editor's note : this is not described in either of the documents. However the handover triggering might not be due only to conditions on the downlink. Measurements performed by the cells in the active set might be needed as in GSM. This section has been created for that purpose >$ 

### 6.1.5 Measurements for the handover preparation from UTRA TDD at the UE

6.1.5.1 In general

### 6.1.5.2 Measurements for the handover preparation from UTRA TDD to UTRA TDD at the UE

### 6.1.5.2.1 monitoring of TDD cells on the same frequency

< Editor's note : no requirement has been defined yet, in terms e.g. of number of cells to be able to monitor in a given time, precision of individual measurements >

### 6.1.5.2.2 Monitoring of TDD cells on different frequencies

### 6.1.5.2.2.1 Parametrisation/introduction of idle periods

<<u>Editor's note : there is no text in the equivalent section of reference [12]XX.15, UTRA Handover.</u> This section will be needed if there is a need to introduce additional idle periods in either up or dl if idle periods between Tx and Rx are not sufficient>

#### 6.1.5.2.2.2 Measurement requirements

<Editor's note : there is no requirement specified in either of the reference documents (XX.15 or Vol 3 of ARIB). The reported value itself is not specified but is expected to correspond to a useful received power level, and potentially some relative timing information. The requirements could also be expressed minimum of samples for the monitoring time assigned by higher layers, precision of the relative received power, taking into account to structure of the monitoring set....>

### 6.1.5.3 Measurements for the handover preparation from UTRA TDD to UTRA FDD at the UE

<<u>Editor's note : there is no text in the equivalent section of reference [12]XX.15, UTRA Handover,</u> <u>neither in reference [15], ARIB volume 3></u>

# 6.1.5.4 Measurements for the handover preparation from UTRA TDD to GSM at the UE

<editor's note : The content of this section has been extracted from reference [12], XX.15, UTRA Handover; Tehr ehas been no decision yet as far as the approval of that text in the merging process>

### 6.1.5.4.1 Introduction

The handover between UTRA and GSM system offering world-wide coverage already today has been one of the main design criteria taken into account in the UTRA frame timing definition. The GSM compatible multi-frame structure, with the super-frame being multiple of 120 ms, allows similar timing for inter-system measurements as in the GSM system itself. The compatibility in timing is important, that when operating in UTRA mode, a multi-mode UE is able to catch the desired information from the synchronisation bursts in the synchronisation frame on a GSM carrier with the aid of the frequency correction burst. This way the relative timing between a GSM and UTRA carriers is maintained similar to the timing between two asynchronous GSM carriers.

<u>UTRA/TDD-GSM dual mode terminals can be implemented without simultaneous use of two receiver</u> <u>chains</u>. Although the frame length is different from GSM frame length, the GSM traffic channel and UTRA TDD channels rely on similar 120 ms multi-frame structure.

A UE can do the measurements either by efficiently using idle slots or by requesting free continuous periods in the downlink part obtained by reducing the spreading factor and compressing in time TS occupation in a form similar to the FDD slotted mode. The low-cost constraint excludes the dual receiver approach.

For smooth inter-operation, inter-system information exchanges are needed in order to allow The UTRAN to notify the UE of the existing GSM frequencies in the area and vice versa. Further more integrated operation is needed for the actual handover where the current service is maintained, taking naturally into account the lower data rate capabilities in GSM when compared to UMTS maximum data rates reaching all the way to 2 Mbits/s.

Basic requirements to correctly perform a handover in GSM are described in GSM 05.08 "Radio subsystem link control".

### 6.1.5.4.2 Low data rate traffic : use of TDD idle slots to monitor GSM

<Editor's note from XX.15 but still valid: the section evaluates the time to acquire the FCCH is all idle slots are devoted to the tracking of a FCCH burst, meaning that no power measurements is done concurrently. The derived figures are better than those for GSM. The section does not derive though any conclusion. A conclusion may be that the use of the idle slots is a valid option. An alternative conclusion may be that this is the only mode to be used, removing hence the use of the slotted frames for low data traffic or the need for a dual receiver, if we were to considering the monitoring of GSM cells only, rather than GSM, TDD and FDD. A more explicit conclusion could be agreed by the SMG2 UMTS-L1 before releasing this document >

In low data rate traffic case, only a few time slots are busy and idle slots may be used for monitoring purpose.

As an example, a simple speech communication is considered. Only two time slots by frame are used, one for uplink and one for downlink. The mobile station is not in transmit or receive state during 8,75 ms in each frame. According to the TS numbers allocated to the traffic, this period can be split into two continuous intervals A and B as shown in figure 3.

### Error! Bookmark not defined.

#### Figure 2: possible idle periods in a 16 TS frame with two busy TS.

A is defined as the number of idle slots between the Tx and Rx slots and B the number of idle slots between the Rx and Tx slots. It is clear that A+B=14 time slots.

In the scope of low cost terminals, a [0.8] ms period is supposed to be required to perform a frequency jump from UMTS to GSM. As detailed in table 1, this will let free periods of A\*0,625-1.6 ms and B\*0,625-1.6 ms during which the mobile station can monitor GSM. In this table, the UL traffic is assumed to occupy TS0, and the duration of monitoring periods are indicated for each possible location of the DL TS.

<u>Table 1 evaluates the average synchronisation time and maximum synchronisation time, where the</u> <u>announced synchronisation time corresponds to the time needed to find the FCCH. The FCCH is</u> <u>supposed to be perfectly detected meaning that the FCCH is found if it is entirely present in the</u> <u>monitoring window. The FCCH being found the SCH location is unambiguously known from that point.</u>

DL TS	Number	Number	Monitoring	Monitoring	Synchronisati	Maximum
n°	of free	of free	period within	period within	on average	synchronisatio
	TS in A	TS in B	A (ms)	<u>B (ms)</u>	time (ms)	n time (ms)
<u>1</u>	<u>0</u>	<u>14</u>	Not Used	7,15	<u>43</u>	<u>140</u>
2	<u>1</u>	<u>13</u>	NU	<u>6,525</u>	<u>48</u>	<u>187</u>
<u>3</u>	2	<u>12</u>	NU	<u>5,900</u>	<u>56</u>	<u>188</u>
4	<u>3</u>	<u>11</u>	NU	<u>5,275</u>	<u>63</u>	<u>188</u>
<u>5</u>	<u>4</u>	<u>10</u>	<u>0.9</u>	4,65	<u>68</u>	<u>189</u>
<u>6</u>	<u>5</u>	<u>9</u>	1,525	4,025	<u>75</u>	233
<u>7</u>	<u>6</u>	<u>8</u>	2,15	<u>3,4</u>	<u>74</u>	<u>189</u>
<u>8</u>	<u>7</u>	<u>7</u>	<u>2,775</u>	<u>2,775</u>	<u>48</u>	<u>189</u>
<u>9</u>	<u>8</u>	<u>6</u>	<u>3,4</u>	2,15	<u>73</u>	<u>189</u>
<u>10</u>	<u>9</u>	<u>5</u>	4,025	<u>1,525</u>	<u>73</u>	235
<u>11</u>	<u>10</u>	<u>4</u>	4,65	<u>0.9</u>	<u>66</u>	<u>186</u>
<u>12</u>	<u>11</u>	<u>3</u>	<u>5,275</u>	NU	<u>61</u>	<u>186</u>
<u>13</u>	<u>12</u>	<u>2</u>	<u>5,900</u>	NU	<u>54</u>	<u>186</u>
<u>14</u>	13	<u>1</u>	6,525	NU	47	186
<u>15</u>	<u>14</u>	<u>0</u>	7,15	NU	<u>43</u>	<u>139</u>

### <u>Table1: example-monitoring periods and associated synchronisation time in a 16 TS frame with</u> <u>two busy TS and with 0.8 ms switching time (\*).</u>

(\*) All simulations have been performed with a random initial delay between GSM frames and UMTS frames

Each configuration of TS allocation described above allows a monitoring period sufficient to acquire synchronisation.

6.1.5.4.3 High data rate traffic.

6.1.5.4.3.1 High-end dual synthesisers terminals

In case of high data traffic, a monitoring period of at least two slots is desirable as shown by the simulation results appearing on the table 2 below.

Number of consecutive TS per frame available for monitoring	Average synchronisation time (s)	<u>Maximum</u> synchronisation time (s)
3	0,23	0,65
2	<u>0,4</u>	<u>1,9</u>
<u>1</u>	<u>7,2</u>	23,2

# Table 2: synchronisation time for a monitoring period of one,two or three consecutive time slot per frame.

The number of consecutive Time Slots needed to obtain an effective monitoring period of two Time Slots depends on the synthesiser characteristics that can be better for the high-end high-date rate capable terminal than for the low cost terminal considered in section. The switching time could for instance be considered as being one or one half of a TS for one-way, resulting in the effective monitoring period indicated in the table 3 below.

For even better performance, a dual synthesiser terminal could be considered: this would allow a negligible switching time between UMTS and GSM frequencies. When the first synthesiser is used, the frequency jump for monitoring is performed by the second synthesiser.

One-way switching time	Number of free consecutive TSs
for the synthesiser	needed in the frame for an effective
	monitoring period of 2 TSs
<u>1 TS (= 625<math>\mu</math>s)</u>	<u>4</u>
<u>0.5 TS (=312µs)</u>	<u>3</u>
0 (dual synthesiser)	2

# Table3: link between the synthesiser performance and the number of free consecutive TSs for a monitoring period of two TSs, needed for GSM monitoring.

6.1.5.4.3.2 Use of TDD TSs release to accommodate monitoring windows

In high data-rate, when it is not possible to free the number of TS needed for an effective monitoring to prepare a handover from UMTS to GSM, the data rate can be slightly reduced for the duration of the monitoring. This should be acceptable as in any case, the data rate needs to be adapted to the available resource in GSM before the handover can be performed.

# 6.1.5.5 Mesurements for the Handover preparation in TDD at the UTRAN side

<editor's note : this is not described in either of the documents. However the handover triggering might not be due only to conditions on the downlink. Measurements performed by the cells in the active set might be needed as in GSM. This section has been created for that purpose >

### 6.1.5.6 Overall handover preparation

<u>This section should explain how the inter-frequency handover preparation from UTRA TDD to UTRA</u> (either FDD or TDD) and from UTRA to GSM are co-ordinated in terms of measurement and reporting. This section provides the overall requirement and measurement procedure. <Editor's note : no text is available is either of the reference documents, XX.15 or ARIB volume 3>

### 6.1.5.7 Measurement reporting to the higher layers

### 6.1.5.7.1 Reporting scheme

The UE sends regular (or event driven) measurement reports to the UTRAN. The level of filtering done by the physical layer vs. the filtering done by higher layers needs to be further discussed.

### 6.1.5.7.2 Measurement report content for cells on the same frequency

These measurements include (for cells on the same frequency)

- The Cell ID
- The relative signal strength
- The relative timing information, accuracy TBD.

Measurement report content for FDD cells on different frequencies

### 6.1.5.7.3 Measurement report content for TDD cells

6.1.5.7.4 Measurement report content for GSM cells

### 6.2 Measurements for the cell reselection in active mode

<Editor's note : Depending on state the UE is in while in connected mode, the cell change operation can be performed using various procedures, such handover or cell reselection. Cell reselection might be appropriate for packet transmission. As an example this is what is done in GSM GPRS. The text included in this section is copied from reference [13], but is of a descriptive nature. Requirements will need to be defined as soon as the procedure is clarified by WG2>

When in active mode, the UE continuously searches for new base stations on the current carrier frequency. This cell search is carried out in basically the same way as the idle mode cell search.

### 6.3 measurements for power control ?

<Editor's note : there is presently no measurement defined for the support of power control that is reported over the radio. There might be however layer some measurements exchanged between the different UTRAN entities and that will need to be standardised in relation with power control. This is to be clarified with WG2 and WG3>

### 6.4 Measurements for adjacent protection rule

< Editor's note : some additional measurement might be needed in order to provide the network with information on adjacent channel interference. The text in this section is copied from reference [15], section 3.2.6.11.5). There is no equivalent text in ETSI documents>

### 6.4.1.1 Frequencies to measure

On the BCCH, UTRAN transmits frequency information of candidate frequencies and neighbouring frequencies. A candidate frequency is defined as a frequency that can be used by the own network, and a neighbouring frequency is defined as a frequency that is adjacent to a candidate frequency and cannot be used by the own network. Candidate frequencies are classified into adjacent frequencies and non-adjacent frequencies. An adjacent frequency is defined as a candidate frequency that is adjacent to a neighbouring frequency, and a non-adjacent frequency is defined as a candidate frequency that is not adjacent to a neighbouring frequency. A pair of dl-link and up-link non-adjacent frequencies may be allocated to all UE.

### 6.4.1.2 Measurement to perform

To support adjacent channel protection rule, an MS measures  $Q_1$  and  $Q_2$ , where  $Q_1$  is the received power in dBm of the downlink adjacent frequency, and  $Q_2$  is the received power in dBm of the downlink neighbouring frequency that is adjacent to the downlink adjacent frequency.

### 6.4.1.3 Frequency allocation rule

A pair of forward-link and reverse-link adjacent frequencies may be allocated to the MS if  $Q_2 - Q_1$  is less than  $R_{ACP}$  dB. During communication using a pair of downlink and up-link adjacent frequencies, the MS measures  $Q_1$  and  $Q_2$  by the same means with the power measurement for inter-frequency handover described in 3.2.6.6.3. This measurement is conducted at least once in  $T_{INT}$  second, and the

*MS* starts inter-frequency handover to a pair of down-link and up-link non-adjacent frequencies if  $Q_2$  -  $Q_1$  is larger than  $R_{ACP}$  dB.

*<Editor's note : the rule in itself is outside the scope of this document. Only the measurement aspects should remain>* 

(Note: If the separation of some pairs of a forward-link frequency and a reverse-link frequency is not a pre-determined constant in some networks, the following adjacent channel protection rule shall be applied. The italic part may be moved to a higher layer.)

### 6.5 Measurements for radio-link time-out (or sync loss) ?

### 7 Radio link measurements

<editor's note : this section should described the measurements that are performed either at the UE or UTRAN side and that are

• either reported and can be checked on the interfaces

• or lead to some procedures in the mobile, leading to an expected behaviour of the said UE. This section can provide some requirements on the measurement in terms of precision for various conditions, although some of this might be more applicable to the WG4 documentation. The mapping of the raw values onto reported values with a limited range, where such reported values transit between layers or across the interface should be also given. Only the acronyms are provide here>

**RSSI** : Received signal strength for useful part

 $\label{eq:ISSI} \textbf{ISSI}: Interference \ signal \ strength$ 

**SIR** : Signal to interference ratio

Relative signal strength (for Handover)

**Relative timing difference between cells** = for FDD this corresponds to the phase difference between the scrambling codes

# 8 Annex 1 : Handover scenarios (Informative)

<Editor's note : This whole section is based on section 7 in XX15 version 1.0.0 from ETSI>

### 8.1 Introduction

This section studies the handover scenarios from the deployment point of view. It should in particular provide the rules for setting the handover monitoring set (see section ), in particular the number of GSM, FDD and TDD cells to monitor. Based on deployment scenarios and UE's speed, it should also set the requirement in terms of detection time and reporting time of a strong cell.

As far as the handover between UTRA and GSM, the handover scenario will be based on interoperability aspects described in XX.16, which among other things will indicate when a handover is needed between UTRA and GSM from the service availability point of view.

8.2 UTRA-UTRA handover scenarios

### 8.3 UTRA-GSM handover scenarios

# 9 Annex 2 : Handover execution (Should be moved to S2.04 at some stage)

### 9.1 Soft handover

< Editor's note : the handver complete procedure is outrside the scope of this specification. However it order not to loose information and before the documentation of WG2 covers this, the content of the reference document is put here. Detailed study of the differences is still to be made>

<Editor's note : text from XX.15>

The serving cell (s) (the cells in the active set) are expected to have knowledge of the service used by the UE. The new cell decided to be added to the active set shall be informed that a new connection is desired, and it needs to have the following minimum information forwarded to it via UTRAN.

- Maximum data rate of the connection and other service parameters, such as coding schemes, number of parallel code channels etc. parameters which form the set of parameters describing the different transport channel configurations in use both uplink and downlink.
- The UE ID and uplink scrambling code
- The relative timing information of the new cell, in respect to the timing UE is experiencing from the existing connections (as measured by the UE at its location). Based on this the new cellcan determine what should be the timing of the transmission initiated in respect to the timing of the common channels (BCCH) of the new cell.

As a response the UE needs to know via the existing connections:

- From which frame (assuming active set update accepted) does the new cell initiate the transmission to the UE
- What channelisation code(s) are used for that transmission. The channelisation codes from different cells are not required to be the same as they are under different scrambling code anyway.
- The relative timing information, which needs to be made available at the new cell is indicated in Figure 1 (shows the case where the two involved cells are managed by different Node Bs).

### Error! Bookmark not defined.

Figure <u>32</u>. Making transmissions capable to be combined in the Rake receiver from timing point of view.

At the start of diversity handover, the reverse link dedicated physical channel transmitted by the MS, and the forward link dedicated physical channel transmitted by the diversity handover source BTS will have their radio frame number and scrambling code phase counted up continuously as usual, and they will not change at all. Naturally, the continuity of the user information mounted on them will also be guaranteed, and will not cause any interruption.

### <Editor's note : text from ARIB, volume 3, agreed for inclusion by 3GPP RAN WG1#2>

The synchronization timing upon starting diversity handover are presented in Fig. 3.2.5-4. The synchronisation establishment flow upon intra/inter-cell diversity handover is described in Fig. 3.2.6-4.

(a) The MS measures the frame time difference of the radio frame at the same frame number between the reverse link dedicated physical channel and the perch channel transmitted at the handover destination BTS. These measurements shall be notified to the network. The measured value is the time difference of the frame timing of the reverse link dedicated physical channel against the frame timing of the perch channel. The values shall always be positive values in chip units, and the range shall be 0 ~ "reverse link scrambling code cycle-1" chip.

- (b) The MS notifies the frame time difference measurement values as layer 3 signals to the BSC via the diversity handover source BTS with the DCH of the reverse link dedicated physical channel.
- (c) The BSC notifies the frame time difference measurement result, together with the frame offset and slot offset set up upon originating/ terminating call connection, to the diversity handover destination BTS with layer 3 signals. Furthermore, the BSC notifies radio parameters such as the spreading codes used at the handover destination BTS etc., to the MS via the handover source BTS.
- (d) The MS starts the chip synchronisation establishment process of forward link channel from the handover destination BTS with the notified radio parameters. The reverse link channels being transmitted shall continue transmission without any operations performed.
- (e) The handover destination BTS receives the notification of the above frame time difference frame offset, and slot offset. Utilising these informations, the BTS starts the transmission of forward link dedicated physical channels and starts the synchronization establishment process of reverse link dedicated physical channel transmitted by the MS. See chapter 3.2.5.1 for the specific transmission timing of forward link dedicated physical channels, and the reception timing of reverse link dedicated physical channel. As soon as chip synchronisation and frame synchronisation using Frame Synchronization Word are established, hard wired transmission shall be started.
- (f) Based on the handover destination perch channel reception timing, the MS establishes chip synchronisation of forward link channel from handover destination BTS. As soon as chip synchronisation is established, maximal ratio combining with the forward link channel from handover source BTS shall be started.

(See also Appendix D)

Fig. 3.2.6-4 Synchronisation Establishment Flow Upon Intra/Inter-cell Diversity Handover

### 10 History V.0.0.1 19.03.1999<del>10-12</del> First version created by the editor by merging S1.15 version 0.0.1 and S1.25 <del>1998</del> version 0.0.1 on the basis of XX.15 and the Volume 3 of the ARIB specification. V.0.0.2 V.0.0.3 Temporary Editors for 3GPP RAN S1.15 (FDD measurements) are **Evelyne Le Strat** Nortel Networks Tel: +33 1 39 44 53 39, Fax: +33 1 39 44 50 12, e-mail: elestrat@nortelnetworks.com Jin-Sung Choi LGIC Tel (\$2 343) 450 20 82, Fax : (82 343) 450 2000, e mail : jschoi@lginfocomm.com This document is written in Microsoft Word 97.