CD Earmy2

r.

CHANGE REQUEST							
£	25.214 CR 145 <i>K</i> rev - <i>K</i> Current version: 3.5.0 <i>K</i>						
For <u>HELP</u> on t	For HELP on using this form, see bottom of this page or look at the pop-up text over the \varkappa symbols.						
Proposed change affects: (U)SIM ME/UE Radio Access Network X Core Network							
Title: 🖉	Clarification of Nid parameter – when SSDT and uplink compressed mode are in operation						
Source: 🧷	NEC, Telecom Modus						
Work item code: 🗷	Date: ∞ 2001-01-12						
Category: 🧷	F Release: ∞ R99						
	Use one of the following categories:Use one of the following releasesF (essential correction)2(GSM Phase 2)A (corresponds to a correction in an earlier release)R96(Release 1996)B (Addition of feature),R97(Release 1997)C (Functional modification of feature)R98(Release 1998)D (Editorial modification)R99(Release 1999)Detailed explanations of the above categories canREL-4(Release 4)be found in 3GPP TR 21.900.REL-5(Release 5)	5:					
 Reason for change: The definition of N_{id} is unclear, in particular the phase 'length of coded ID'can easily be miss interpreted, in the following cases: - 1) At the end of radio frames, when the ID code is punctured due to the lack of FBI space. 2) When the ID code is transmitted in pairs (as shown in table 4) 							
Summary of chan	ge: Z The third condition in 5.2.1.4.4 is revised for clarification.						
Consequences if not approved:	The specification is otherwise ambiguous.						
Clauses affected:	z 5.2.1.4.4						
Other specs affected:	Image: Second system Image: Second system Image: Second						
Other comments:	×						

How to create CRs using this form: Comprehensive information and tips about how to create CRs can be found at: <u>http://www.3gpp.org/3G_Specs/CRs.htm</u>. Below is a brief summary:

1) Fill out the above form. The symbols above marked & contain pop-up help information about the field that they are closest to.

5.2.1.4 Site selection diversity transmit power control

5.2.1.4.1 General

Site selection diversity transmit power control (SSDT) is another macro diversity method in soft handover mode. This method is optional in UTRAN.

Operation is summarised as follows. The UE selects one of the cells from its active set to be 'primary', all other cells are classed as 'non primary'. The main objective is to transmit on the downlink from the primary cell, thus reducing the interference caused by multiple transmissions in a soft handover mode. A second objective is to achieve fast site selection without network intervention, thus maintaining the advantage of the soft handover. In order to select a primary cell, each cell is assigned a temporary identification (ID) and UE periodically informs a primary cell ID to the connecting cells. The non-primary cells selected by UE switch off the transmission power. The primary cell ID is delivered by UE to the active cells via uplink FBI field. SSDT activation, SSDT termination and ID assignment are all carried out by higher layer signalling.

5.2.1.4.1.1 Definition of temporary cell identification

Each cell is given a temporary ID during SSDT and the ID is utilised as site selection signal. The ID is given a binary bit sequence. There are three different lengths of coded ID available denoted as "long", "medium" and "short". The network decides which length of coded ID is used. Settings of ID codes for 1-bit and 2-bit FBI are exhibited in table 3 and table 4, respectively.

	ID code		
ID label	"long"	"medium"	"short"
а	00000000000000	(0)0000000	00000
b	101010101010101	(0)1010101	01001
С	011001100110011	(0)0110011	11011
d	110011001100110	(0)1100110	10010
е	000111100001111	(0)0001111	00111
f	101101001011010	(0)1011010	01110
g	011110000111100	(0)0111100	11100
h	110100101101001	(0)1101001	10101

Table 3: Settings of ID codes for 1 bit FBI

Table 4: Settings of ID codes for 2 bit FBI

	ID code (Column and Row denote slot position and FBI-bit position.)		
ID label	"long"	"medium"	"short"
а	(0)0000000	(0)000	000
	(0)0000000	(0)000	000
b	(0)0000000	(0)000	000
	(1)111111	(1)111	111
С	(0)1010101	(0)101	101
	(0)1010101	(0)101	101
d	(0)1010101	(0)101	101
	(1)0101010	(1)010	010
е	(0)0110011	(0)011	011
	(0)0110011	(0)011	011
f	(0)0110011	(0)011	011
	(1)1001100	(1)100	100
g	(0)1100110	(0)110	110
	(0)1100110	(0)110	110
h	(0)1100110	(0)110	110
	(1)0011001	(1)001	001

The ID code bits shown in table 3 and table 4 are transmitted from left to right. The ID code(s) are transmitted aligned to the radio frame structure (i.e. ID codes shall be terminated within a frame). If FBI space for sending the last ID code

within a frame cannot be obtained, the first bit(s) from that ID code are punctured. The bit(s) to be punctured are shown in brackets in table 3 and table 4.

The alignment of the ID codes to the radio frame structure is not affected by transmission gaps resulting from uplink compressed mode.

5.2.1.4.2 TPC procedure in UE

The UE shall generate TPC commands to control the network transmit power and send them in the TPC field of the uplink DPCCH. An example on how to derive the TPC commands is given in Annex B.2.

5.2.1.4.3 Selection of primary cell

The UE selects a primary cell periodically by measuring the RSCP of CPICHs transmitted by the active cells. The cell with the highest CPICH RSCP is detected as a primary cell.

5.2.1.4.4 Delivery of primary cell ID

The UE periodically sends the ID code of the primary cell via portion of the uplink FBI field assigned for SSDT use (FBI S field). A cell recognises its state as non-primary if the following <u>three</u> conditions are fulfilled simultaneously:

- <u>T</u>the received primary-ID code does not match with the own ID code.
- <u>T</u>the received uplink signal quality satisfies a quality threshold, Qth, a parameter defined by the network.
- and when If uplink compressed mode is used, the use of uplink compressed mode does not degrade the ID decoding performance excessively result in excessive levels of puncturing on the coded ID. The acceptable level of puncturing on the coded ID is less than This occurs when ?N_{ID}/3? or more bit symbols are lost from the coded ID code (as a result of uplink compressed mode), where N_{ID} is the number length of bits in the coded ID code (after puncturing according to clause 5.2.1.4.1.1, if puncturing has been done).

Otherwise the cell recognises its state as primary.

The state of the cells (primary or non-primary) in the active set is updated synchronously. If a cell receives the last portion of the coded ID in uplink slot j, the state of cell is updated in downlink slot $(j+1+T_{os}) \mod 15$, where T_{os} is defined as a constant of 2 time slots. The updating of the cell state is not influenced by the operation of downlink compressed mode.

At the UE, the primary ID code to be sent to the cells is segmented into a number of portions. These portions are distributed in the uplink FBI S-field. The cell in SSDT collects the distributed portions of the primary ID code and then detects the transmitted ID. The period of the primary cell update depends on the settings of the code length and the number of FBI bits assigned for SSDT use as shown in table 5.

	The number of FBI bits per slot assigned for SSDT		
code length	1	2	
"long"	1 update per frame	2 updates per frame	
"medium "	2 updates per frame	4 updates per frame	
"short"	3 updates per frame	5 updates per frame	

Table 5: Period of primary cell update