

**TSG-RAN WG3 meeting #7**  
**Sophia Antipolis, France, 20-23 September 1999**

***TSGR3#7(99)a78***

**Agenda Item:**

**Source:** Editor (BT)  
**Title:** 25.410 v1.0.0  
**Document for:** Approval

---

**Changes shown with revision marks are based on the decisions of the last RAN3 meeting. These changes have yet to be formally approved by the WG.**

**The editor will also submit an editorial proposal to RAN3#7, including larger editorial corrections/changes. There are some minor editorial changes included in this version.**



**3<sup>rd</sup> Generation Partnership Project (3GPP);  
Technical Specification Group (TSG) RAN;**

**UTRAN I<sub>u</sub> Interface: General Aspects and Principles**

**UMTS 25.410**

---

**3GPP**

---

Reference

<Workitem> (<Shortfilename>.PDF)

---

Keywords

<keyword[, keyword]>

**3GPP**

---

Postal address

---

Office address

---

Internet

secretariat@3gpp.org  
Individual copies of this deliverable  
can be downloaded from  
<http://www.3gpp.org>

---

**Copyright Notification**

No part may be reproduced except as authorized by written permission.  
The copyright and the foregoing restriction extend to reproduction in all media.

©  
All rights reserved.

---

# Contents

<b>1</b>	<b>SCOPE.....</b>	<b>7</b>
<b>2</b>	<b>REFERENCES.....</b>	<b>7</b>
<b>3</b>	<b>DEFINITIONS, SYMBOLS AND ABBREVIATIONS.....</b>	<b>7</b>
3.1	DEFINITIONS .....	7
3.2	SYMBOLS .....	<del>88</del> 7
3.3	ABBREVIATIONS .....	<del>88</del> 7
<b>4</b>	<b>GENERAL ASPECTS .....</b>	<b><del>88</del>7</b>
4.1	UTRAN ARCHITECTURE .....	<del>88</del> 7
4.2	I <sub>U</sub> INTERFACE GENERAL PRINCIPLES .....	<del>99</del> 8
4.3	I <sub>U</sub> INTERFACE SPECIFICATION OBJECTIVES .....	<del>99</del> 8
4.4	I <sub>U</sub> INTERFACE CAPABILITIES .....	<del>104</del> 08
4.5	I <sub>U</sub> INTERFACE CHARACTERISTICS .....	<del>104</del> 08
<b>5</b>	<b>FUNCTIONS OF THE I<sub>U</sub> INTERFACE PROTOCOLS.....</b>	<b><del>131</del>38</b>
<b>6</b>	<b>I<sub>U</sub> INTERFACE PROTOCOL STRUCTURE.....</b>	<b><del>131</del>38</b>
<b>7</b>	<b>OTHER I<sub>U</sub> INTERFACE SPECIFICATIONS.....</b>	<b><del>151</del>510</b>
<b>8</b>	<b>BIBLIOGRAPHY .....</b>	<b><del>161</del>611</b>
<b>9</b>	<b>HISTORY .....</b>	<b><del>181</del>813</b>

---

# Intellectual Property Rights

---

---

## Foreword

This Technical Specification (TS) has been produced by the 3<sup>rd</sup> Generation Partnership Project (3GPP).

The contents of this TS are subject to continuing work within 3GPP and may change following formal TSG approval. Should the TSG modify the contents of this TS, it will be re-released with an identifying change of release date and an increase in version number as follows:

Version m.t.e

where:

m indicates [major version number]

x the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.

y the third digit is incremented when editorial only changes have been incorporated into the specification.

---

## Introduction

~~This clause is optional. If it exists, it is always the third unnumbered clause.~~

~~No text block identified.~~

---

# 1 Scope

The present document is an introduction to the UMTS 25.41x series of Technical Specifications that define the Iu interface for the interconnection of Radio Network Controller (RNC) component of the UMTS Terrestrial Radio Access Network (UTRAN) to the Core Network of the UMTS system.

---

# 2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies.
- A non-specific reference to an ETS shall also be taken to refer to later versions published as an EN with the same number.

[1] UMTS 25.401, UTRAN Overall Description

[2] UMTS 23.930, Iu Principles

[3] UMTS 23.110, [UMTS Access Stratum: Services and Functions](#)

[4] UMTS 25.411, UTRAN Iu Interface: Layer 1

[5] UMTS 25.412, UTRAN Iu Interface: Signalling Transport

[6] UMTS 25.413, UTRAN Iu Interface: RANAP Signalling

[7] UMTS 25.414, UTRAN Iu Interface: Data Transport & Transport Signalling

[8] UMTS 25.415, UTRAN Iu Interface: CN-RAN User Plane Protocols

[9] Q.711 (7/96), Functional description of the signalling connection control part

[10] Q.712 (7/96), Definition and function of signalling connection control part messages

[11] Q.713 (7/96), Signalling connection control part formats and codes

[12] Q.714 (7/96), Signalling connection control part procedures

---

# 3 Definitions, symbols and abbreviations

## 3.1 Definitions

For the purposes of the present document, the [following] terms and definitions [given in ... and the following] apply.

~~Editor's Note—Definitions of Source RNS(C) and Target RNC(C) are required.~~

## 3.2 Symbols

~~For the purposes of the present document, the following symbols apply:~~

## 3.32 Abbreviations

~~For the purposes of the present document, the following abbreviations apply:~~

# 4 General Aspects

~~Editor's Note—Discussion is required about what information should be transferred from the UTRAN Architecture description to this document. Also, from other relevant documents (e.g. UMTS 23.30 Iu Principles).~~

## 4.1 UTRAN Architecture

~~Editor's Note—this chapter should describe enough of the system architecture for the role of the interface to be understood.~~


~~See [1], chapter 8.1.~~

~~Editor's Note—Any explanation of source and target RNC/S that is needed, over and above the definitions above, should be added here.~~

### 4.1.1 Iu Interface Architecture

The overall UMTS architecture and UTRAN architectures are described in [1]. This section specifies only the architecture of the Iu interface, and shall not constrain the network architecture of either Core or Radio Access Networks.

The I<sub>u</sub> interface is specified at the boundary between the Core Network and UTRAN. Figure XX depicts the logical division of the I<sub>u</sub> interface. From the Iu perspective, the Core Network access point is either an MSC or an SGSN and the UTRAN access point is an RNC.



**Figure 1 – Iu Interface Architecture**

The Iu interface towards the PS-domain of the core network is called Iu-PS, and the Iu interface towards the CS-domain is called Iu-CS. The differences between Iu-CS and Iu-PS are treated elsewhere in this specification.

There may be at most two distinct Iu interface for any RNC - one (Iu-CS) towards the CS domain and one (Iu-PS) towards the PS-domain.

In the separated core network architecture, this means that there are separate signalling and user data connections towards the two domains – this applies in both transport and radio network layers.

In the combined architecture, there are separate connections in the user plane (in both transport and radio network layers). In the control plane, there are separate SCCP connections to the two logical domains.

In either architecture, there can be several RNCs within UTRAN and so UTRAN may have several I<sub>u</sub> access points towards the Core Network. As a minimum, each Iu access point (in UTRAN or CN) shall independently fulfil the requirements of the Iu specifications (25.41x series – see section 7).

### 4.1.2 Iu connection principles

The Iu interface has a hierarchical architecture where one higher layer entity controls several lower layer entities. The hierarchy for the CN - UTRAN signalling connection end points is described below.

- Each CN Access Point may be connected to one or more UTRAN Access Points
- Each UTRAN Access Point may be connected to no more than one CN Access Point per CN domain

## 4.2 I<sub>u</sub> Interface General Principles

From a UTRAN perspective, maximising the commonality of the various protocols that flow on the Iu interface is desirable. This means at the minimum that :

- A common set of radio access bearer services will be offered by UTRAN to the Core Network nodes, regardless of their type (e.g. 3G-MSC or 3G-SGSN).

There will be a common functional split between UTRAN and the Core Network nodes, regardless of their type (e.g. 3G-MSC or 3G-SGSN).

Signalling in the radio network control plane shall not depend on the specific choice of transport layers.

## 4.3 I<sub>u</sub> Interface Specification Objectives

See [2], chapter 4.1.

The Iu interface shall be specified such that it can support:

- the interconnection of RNCs with Core Network Access Points within a single PLMN
- the interconnection of RNCs with Core Network Access Points irrespective of the manufacturer of any of the elements.
- all UMTS services

The Iu interface shall facilitate the use of the same RNC, MSC or SGSN in all PLMNs.

Independence between the protocol layers and between control and user planes shall be maintained on the Iu interface.

The Iu interface shall allow independent evolution of technologies within the Core, Radio Access and Transport Networks.

The Iu interface shall be standardised as an open and multi-vendor interface.

The Iu interface specifications shall facilitate the migration of some services from the CS-domain to the PS-domain. In particular, the RANAP protocol shall be common to both domains, and the Iu user plane protocol(s) shall be independent of the core network domain, except where a specific feature is only required for one domain.

*Editor's Note — the two figures should be aligned with this assumption — probably by showing a single Iu-UP protocol (rather than PS and CS specific). A separate contribution will be provided, to maintain alignment with 25.415.*

## 4.4 I<sub>u</sub> Interface Capabilities

*[Editor's note: This chapter should shortly describe the I<sub>u</sub> –Interface Capabilities. In order to avoid inconsistency between documents, reference to [2], chapters 4 and 5, has been made]*

See [2], chapter 4.2.

## 4.5 I<sub>u</sub> Interface Characteristics

### 4.5.1 Use of SCCP

#### 4.5.1.1 General

The SCCP is used to support signalling messages between the CNs and the RNSC. One user function of the SCCP, called Radio Access Network Application Part (RANAP), is defined. The RANAP uses one signalling connection per active UE and CN for the transfer of layer 3 messages.

Both connectionless and connection-oriented procedures are used to support the RANAP. TS 25.413 explains whether connection oriented or connectionless services should be used for each layer 3 procedure.

RANAP may use SSN, SPC and/or GT and any combination of them as addressing schemes for the SCCP. Which of the available addressing scheme to use for the SCCP is an operator matter.

Which of the possible GT formats to be used is FFS. One option is to use the same format as for the MAP specification, i.e. GT format 4.

The following sections describe the use of SCCP connections for RANAP transactions. Section 4.5.1.2 describes the connection establishment procedures. Section 4.5.1.3 describes the connection release procedures. Section 4.5.1.4 describes abnormal conditions.

#### 4.5.1.2 SCCP connection establishment

A new SCCP connection is established when information related to the communication between a UE and the network has to be exchanged between RNS-RNC and CN, and no SCCP connection exists between the CN and the RNSC involved, for the concerned UE.

Various SCCP connection establishment cases have to be distinguished:

- i) RNSC Initiated SCCP Signalling Connection
- ii) CN Initiated SCCP Signalling Connection

The above cases are the only cases currently identified for SCCP connection establishment. Others may emerge in the future.

##### 4.5.1.2.1 Establishment procedure in case i

The SCCP signalling connection establishment is initiated, by the RNSRNC, at the reception of the first layer 3 non access stratum message from the UE.

##### Initiation

The ~~RNS-RNC~~ sends ~~INITIAL\_UE-SCCP connection request~~ message to the Core Network. ~~The INITIAL\_UE-A RANAP~~ message is included in the user data field of ~~an-the~~ SCCP connection request message.

### Termination


#### *- successful outcome*

- The SCCP connection confirm message, which may optionally contain a connection oriented RANAP message in the user data field, is returned to the ~~RNSRNC~~.

#### *- unsuccessful outcome*

- If the SCCP signalling connection establishment fails, an SCCP connection refusal message will be sent back to the ~~RNSRNC~~. This message may contain a transparent message to be sent to the UE.

For more information on how the RANAP procedure Initial UE message is handled, please see the elementary procedure Initial UE message in TS 25.413.



**Figure 1: Setting-up of ~~RNS-RNC~~ Initiated SCCP Signalling Connection**

~~Note: Which addressing scheme for SCCP to be used over lu is TBD.~~

#### 4.5.1.2.2 Establishment procedure in case ii

The SCCP signalling connection establishment is initiated, by the Core Network, in connection with performing a Relocation.

##### Initiation

The Core Network initiates the connection establishment by sending an ~~RELOCATION REQUEST-SCCP connection request~~ message to the RNC. ~~Optionally, a RANAP message may be included in the user data field of the RELOCATION REQUEST message.~~

##### Termination

###### - successful outcome


- The SCCP connection confirm message, which may optionally contain a connection oriented RANAP message in the user data field, is returned to the Core Network.

###### - unsuccessful outcome

- If the SCCP signalling connection establishment fails, an SCCP connection refusal message will be sent back to the Core Network. This message may contain a RANAP message in the user data field.

~~Note: In case of an unsuccessful termination of the UE signalling connection establishment (i.e. when RELOCATION FAILURE is sent to the CN), no radio resources are assigned for the UE in the RNS. If the SCCP signalling connection has been established, the CN is expected to initiate the SCCP connection release.~~

~~For more information on how the RANAP procedure for Relocation is handled, please see the elementary procedure Relocation Resource Allocation in TS 25.413.~~



**Figure 2: Setting-up of CN Initiated SCCP Signalling Connection**

~~Note: Which addressing scheme for SCCP to be used over lu is TBD.~~

#### 4.5.1.3 SCCP connection release

This procedure is always initiated at the Core Network side.

An SCCP connection is released when the CN realises that a given signalling connection is no longer required.

The CN sends a SCCP Released message.

#### 4.5.1.4 General SCCP Abnormal Conditions

If a user-out-of-service information or signalling-point-inaccessible information is received by the RANAP, no new attempt to establish SCCP connections towards the affected point code will be started until the corresponding user-in-service information or signalling-point-accessible information is received.

When a user-out-of-service information or signalling-point-inaccessible is received by the ~~RNSRNC~~, an optional timer may be started. When the timer expires, all the SCCP connections towards the affected point code will be released. When the user-in-service or signalling-point-accessible is received, the timer is stopped.

If for any reason an SCCP connection is released, the optional timer expires or a connection refusal is received while any of the RANAP procedures are being performed or while a dedicated resource is still allocated, the following actions are taken:

**At ~~RNSRNC~~:**

- Any ~~RNS-RNC~~ procedure relating to that connection is abandoned.
- The UTRAN resources allocated to the connection are released.

**At Core Network:**

- The resources associated with the SCCP connection are cleared as soon as possible.

---

## 5 Functions of the I<sub>u</sub> Interface Protocols

*Editor's Note – this section will either contain a functional division across the interface, and/or a reference to the appropriate bit of the UTRAN Architecture Specification*

Congestion control shall be performed over the Iu user plane toward the IP domain using buffer management and no flow control.

---

## 6 I<sub>u</sub> Interface Protocol Structure

### 6.1 General

The Radio Network signalling over Iu consists of the Radio Access Network Application Part (RANAP). The RANAP consists of mechanisms to handle all procedures between the CN and UTRAN. It is also capable of conveying messages transparently between the CN and the UE without interpretation or processing by the UTRAN.

Over the Iu interface the RANAP protocol is, e.g. used for:

- Facilitate a set of general UTRAN procedures from the Core Network such as paging -notification as defined by the notification SAP in [3].
- Separate each User Equipment (UE) on the protocol level for mobile specific signalling management as defined by the dedicated SAP in [3].
- Transfer of transparent non-access signalling as defined in the dedicated SAP in [3].
- Request of various types of UTRAN Radio Access Bearers through the dedicated SAP in [3].
- Perform the streamlining function.

The Radio Access Bearers are provided by the Access Stratum

## 6.2 Iu-CS




Figure 3: I<sub>u</sub> -Interface Protocol Structure towards CS Domain

*Editor's note: Should the next sentence be in here or in 25.414?*

Q.2630.1 is used as the ALCAP protocol for dynamically setup AAL-2 connections over Iu towards the PSTN Domain.

## 6.3 Iu-PS




Figure 4: Iu Interface Protocol Structure towards PS Domain

RANAP Signalling is used to establish, modify and release the GTP-U tunnels.

## 7 Other Iu Interface Specifications

### 7.1 UTRAN Iu Interface: Layer 1 (UMTS 25.411)

UMTS 25.411 specifies the range of physical layer technologies that may be used to support the Iu interface.

### 7.2 UTRAN Iu Interface: Signalling Transport (UMTS 25.412)

UMTS 25.412 specifies the signalling bearers for the RANAP and ALCAP protocols for both Iu-PS and Iu-CS.

### 7.3 RANAP Specification (UMTS 25.413)

UMTS 25.413 specifies the RANAP protocol for radio network control plane signalling over the Iu interface.

## 7.4 UTRAN Iu Interface: Data Transport and Transport Signalling (UMTS 25.414)

UMTS 25.414 specifies the transport bearers for the user plane of the Iu interface. It also specifies the ALCAP protocol used to control these transport bearers.

## 7.5 UTRAN Iu Interface: CN-UTRAN User Plane Protocols (UMTS 25.415)

UMTS 25.415 specifies the user plane frame handling protocol for the Iu interface.

---

# 9 Bibliography

The following material, though not specifically referenced in the body of the present document (or not publicly available), gives supporting information.

## Annex A (Informative) – Stability Information

This annex details the stability of each section of the document, and notes areas where further text is required.

Section	Content missing	Incomplete	Restructuring needed	Checking needed	Editorial work required	Finalisation needed	Almost stable	Stable
1,2						✓		
3	✓							
4.1		✗					✗	
4.2							✓	
4.3		✗					✗	
4.4		✗					✗	
4.5	✗							✗
5		✓						
6								✓
7							✓	

In general, a thorough editorial review will be required to ensure internal consistency.

# 10History

Document history		
v 0.0.1	1999-02	Initial Specification Structure
V0.0.2	1999-02	Text from merged document included.
V0.0.3	1999-03	Updated with decision from WG3 #2 (inclusion of IP domain congestion control)
V0.1.0	1999-04	Approved by WG3
v.0.1.1	1999-05	Updated with decisions from WG3 #3 – mostly from Tdoc 344. References and Ch7 updated according to document renumbering.
v.0.1.2	1999-06	Further changes after SWG review, and text from Iu SWG @ WG3#4 added. – This version was never treated in a WG3 meeting.
v.0.2.1	1999-06	Approved at WG3#4, and showing changes agreed at that meeting – sentence on establishment of GTP-U tunnels, and commonality of U-plane protocols.
v.0.3.1	1999-08	Approved at WG3#5, and showing changes agreed at that meeting – figures updated to show single UP protocol, and with SCCP usage text (modified from tdoc 725)
v.1.0.0	1999-08	Approved at WG3#6, and showing changes agreed at that meeting. Including corrections/clarifications to SCCP section, new text for architecture, objectives and characteristics sections.
Editor for 3GPP RAN 25.410 is:		
Richard Townend BT Tel.: +44 1473 605 429 Fax : +44 1473 623 683 Email : <a href="mailto:richard.townend@bt.com">richard.townend@bt.com</a>		
This document is written in Microsoft Word version 7/97.		